

MS11

DIAGNOSTIC
MD-11-DCMSB-B

EP-DCMSB-B-DL-A

NOV 1976

COPYRIGHT © 1976

digital

FICHE 1 OF 1

MADE IN USA

This microfiche card contains a grid of frames on the left side, with the rest of the card being a dark, mostly blank area. The frames contain various data, including:

- Tables with multiple columns and rows of text.
- Diagrams or flowcharts with boxes and connecting lines.
- Text blocks, possibly instructions or descriptions.
- Small charts or graphs.

The data is too small to read clearly, but it appears to be organized into several distinct sections or pages within the microfiche format.

29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84

1.0 ABSTRACT

THIS PROGRAM IS TO BE USED TO TEST MOS SEMICONDUCTOR MEMORY ONLY AFTER ALL OTHER MEMORY DIAGNOSTICS HAVE BEEN RUN. THIS PROGRAM ONLY CHECKS REFRESH CYCLE PROBLEMS OF MOS MEMORY ON PDP-11/45.

2.0 REQUIREMENTS

2.1 EQUIPMENT

PDP-11/45 STANDARD COMPUTER WITH MOS SEMICONDUCTOR MEMORY.

2.2 STORAGE

THE ROUTINE USES MEMORY 0 TO 11510

3.0 LOADING PROCEDURE

PROCEDURE FOR NORMAL ABSOLUTE TAPES SHOULD BE FOLLOWED.

3.0.1 RELOCATION PROCEDURE

THIS PROGRAM IS RELOCATABLE. FOLLOW NORMAL RELOCATION PROCEDURE. THAT IS SET SWITCH "0". TO INDICATE THAT RELOCATION IS REQUIRED. THEN SET THE SWITCHES WHERE THE PROGRAM IS TO START LOADING. THEN HIT "START" TO LOAD TAPE. ALL PROGRAM ADDRESSES BECOME INCREASED BY THIS RELOCATION FACTOR FOR EXAMPLE IF SWITCH 12 AND 0 WAS SET BEFORE LOADING THEN 40000 IS THE RELOCATION FACTOR AND HENCE 40204 IS THE STARTING ADDRESS

4.0 STARTING PROCEDURE

4.1 CONTROL SWITCH SETTINGS

BASIC SWITCH REGISTER SETTINGS ARE:

SWITCH	USE
15	HALT ON ERROR
14	0 - DISABLE PARITY CHECKING 1 - ENABLE PARITY CHECKING
13	INHIBIT ERROR TYPEOUTS

05
06
07
08
09
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40

- 12 0 - SET PROGRAM TO CATCH BOTH BIT DROPS AND PICKUPS
- 11 1 - SET PROGRAM AS INDICATED BY SWITCH 11
- 10 0 - SET PROGRAM TO CATCH BIT DROPS
- 9 1 - SET PROGRAM TO CATCH BIT PICKUPS
- 8 0 - PRINT END PASS
- 7 1 - BELL ON ERROR
- 6 0 - PRINT FIRST ERROR PER PRECHARGE
- 5 1 - PRINT ALL ERRORS PER PRECHARGE
- 4 INHIBIT PRINTING DATA HEADER
- 3 0=TEST READ AND WRITE FROM OUTSIDE OF THE CHIP
- 2 1=TEST INSTRUCTIONS IN THE CHIP
- 1 LOCK ON PRESENT MOD
- 0 LOCK ON PRESENT PRECHARGE

4.2 STARTING ADDRESSES

- 200 = STARTING ADDRESS IF ALL OF MEMORY IS TO BE TESTED AND NO LIMITS CHOSEN
- 204 = STARTING ADDRESS IF LIMITS ARE TO BE CHOSEN
- 210 = RESTART ADDRESS WITH LAST SPECIFIED LIMITS

4.3 PROGRAM AND/OR OPERATOR ACTION

4.3.1 OPERATOR ACTION

THERE ARE TWO MODES OF OPERATION FOR THIS PROGRAM
 A) NO LIMITS CHOSEN
 B) LIMITS CHOSEN

A) NO LIMITS CHOSEN

FOR THIS MODE OF OPERATION RELOCATION CANNOT BE USED THAT IS BEFORE LOADING TAPE, SWITCH 0 MUST BE 0.
 STARTING ADDRESS IS 200.
 THE MEMORY SIZE IS PRINTED IN OCTAL
 THE PROGRAM TYPES OUT "SET SWITCHES FOR OPERATING MODE. REFER SECTION 4.1
 IE. PICKUPS OR DROPS OR BOTH THEN HIT CONTINUE "
 ON SUBSEQUENT STARTS THE TYPEOUT IS SHORTER.
 NOW CHOOSE ALL SWITCH SETTINGS. SWITCH 11 AND 12 MUST BE LEFT ON AS DESIRED AND IF CHANGED DURING OPERATION NO CHANGE WILL TAKE PLACE TILL THE "END PASS" PRINT OUT. THEN ALL OF MEMORY IS CHECKED STARTING FROM THE SECOND 4K TILL THE LAST ADDRESS IS REACHED. THEN THE PROGRAM IS MOVED INTO THE SECOND 4K AND THE FIRST 4K IS CHECKED.
 THIS MODE OF OPERATION DESTROYES THE LOADER AND IF THE PROGRAM HAS MOVED INTO THE SECOND 4K AND AN OPERATOR HALT IS PERFORMED THEN RESTART ADDRESS IS NOT 200 BUT

141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167
168
169
170
171
172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196

40200.

B) LIMITS CHOSEN

IN THIS MODE OF OPERATION RELOCATION CAN BE USED. TO RELOCATE PROGRAM REFER TO SECTION 3.0.1. STARTING ADDRESS IS 204 OR RELOCATION FACTOR PLUS 204. THE MEMORY SIZE IS PRINTED IN OCTAL THEN THE PROGRAM TYPES "TYPE "STARTING BANK" NUMBER AND CARRIAGE RETURN. REFER TO SECTION 4.3.1 BEFORE CHOOSING" OR SHORTER TYPE OUTS ON SUBSEQUENT STARTS THIS IS THE SECTION REFERED TO

TYPE THE 4K BANK WHERE YOU WISH TO BEGIN TESTING

TYPE	TO START AT		TYPE	TO START AT
0	000000 (0K)		20	400000 (64K)
1	020000 (4K)		21	420000 (68K)
2	040000 (8K)		22	440000 (72K)
3	060000 (12K)		23	460000 (76K)
4	100000 (16K)		24	500000 (80K)
5	120000 (20K)		25	520000 (84K)
6	140000 (24K)		26	540000 (88K)
7	160000 (28K)		27	560000 (92K)
10	200000 (32K)		30	600000 (96K)
11	220000 (36K)		31	620000 (100K)
12	240000 (40K)		32	640000 (104K)
13	260000 (44K)		33	660000 (108K)
14	300000 (48K)		34	700000 (112K)
15	320000 (52K)		35	720000 (116K)
16	340000 (56K)		36	740000 (120K)
17	360000 (60K)			

TYPE ONLY NUMBERS SHOWN !!!

MEMORY CAN ONLY BE TESTED IN 4K GROUPS STARTING AND FINISHING AT 4K BOUNDARY FOR EXAMPLE IF YOU WISH TO TEST THE THIRD 4K BANK (STARTING ADDRESS 40000) TYPE "2".

THEN THE PROGRAM TYPES "TYPE NUMBER OF 4K BANKS TO BE TESTED AND CARRIAGE RETURN". ON SUBSEQUENT STARTS TYPEOUT IS SHORTER. AFTER TYPING THE APPROPRIATE NUMBER AND CARRIAGE RETURN

THE PROGRAM TYPES " SET SWITCHES FOR OPERATING MODE. REFER SECTION 4.1 I.E. PICKUPS OR DROPS OR BOTH THEN HIT CONTINUE" ON SUBSEQUENT STARTS TYPEOUTS ARE SHORTER. THIS MEANS NOW IS THE TIME TO CHOOSE ALL SWITCH SETTINGS. SWITCH 11 AND 12 MUST BE LEFT ON AS DESIRED AND IF CHANGED DURING OPERATION NO CHANGE WILL TAKE PLACE TILL THE "END PASS" PRINT OUT. CHECKING IS NOW STARTED

IF STARTING BANK AND NUMBER OF BANKS ARE INCORRECTLY CHOSEN THEN RUBOUT MAY BE HIT TO DELETE THE LAST CHARACTER IF CARRIAGE RETURN HAS NOT ALREADY BEEN HIT. IF CARRIAGE RETURN

197
198
199
200
201
202
203
204
205
206
207
208
209
210
211
212
213
214
215
216
217
218
219
220
221
222
223
224
225
226
227
228
229
230
231
232
233
234
235
236
237
238
239
240
241
242
243
244
245
246
247
248
249
250
251
252

HAS BEEN HIT THEN RESTARTING IS NECESSARY. IF NO CORRECTION IS MADE THEN THE PROGRAM MAY DESTROY ITSELF OR IT MAY TIME OUT ON A NON EXISTANT MEMORY.

IN ORDER TO TEST THE FIRST 4K OF MEMORY WITH 204 STARTING THAT IS BY CHOOSING LIMITS RELOCATE THE PROGRAM BY LOADING IT INTO A HIGHER AREA OF MEMORY SAY AT 40000 AND TEST THE FIRST FOUR K BY MAKING THE STARTING BANK "0" AND NUMBER OF BANKS "1"

4.3.2 PROGRAM ACTION

THE PROGRAM WILL FIRST FILL A 4K BLOCK WITH WHAT EVER IS IN "BCKGRD" .THEN THE PROGRAM WILL WRITE "TSTPAT" INTO ONE LOCATION CALLED TSTPAT . IN ANOTHER LOCATION CALLED TEST-LOCATION IT WILL WRITE A CLR RD (OR ALL "0" OR ALL "1" DEPENDING ON SWITCHES 7 AND 12. LOC TSTPAT AND TEST-LOCATION WILL HAVE BIT 8 OF OPPOSITE VALUE. THE TEST-LOCATION WILL BE OPERATED ON 1000 TIMES THEN THE 4K WILL BE CHECKED. THEN ONE WILL BE ADDED TO LOCATION TSTPAT AND THE PROCESS REPEATED TILL ONE 4K IS DONE THEN THE NEXT 4K WILL BE STARTED.

5.0 OPERATING PROCEDURE

5.1 OPERATIONAL SWITCH SETTINGS

SEE 4.1

6.0 ERRORS

6.1 ERROR PRINTOUT

THERE ARE THREE TYPES OF ERROR PRINTOUTS

- A) BACK GROUND CHANGED
- B) INSTRUCTION CHANGED
- C) TEST PATTERN

EXAMPLE

ERROR	BCKGRD	EXPECT	RCV'D	COL	ROW	PRECHARGE
PC	ADDRESS	DATA	DATA			
103166	006500	177777	177577	6	23	0

253
254
255
256
257
258
259
260
261
262
263
264
265
266
267
268
269
270
271
272
273
274
275
276
277
278
279
280
281
282
283
284
285
286
287
288
289
290
291
292
293
294
295
296
297
298
299
300
301
302
303
304
305
306
307
308

THE COL=COLIMN AND ROW PRINTOUTS ARE FOR ENGINEERING
USE WHICH TELLS WHAT BIT WITHIN A CHIP IS FAULTY.
IF INFORMATION WITHIN A CHIP IS NOT NECESSARY DISREGARD
THESE TWO (COL, ROW)

6.2 ERROR RECOVERY

IN GENERAL, TEST FAILURES WILL PRINTOUT AN ERROR MESSAGE
AND CONTINUE. IF THE "HALT ON ERROR" SWITCH IS SET,
HITTING CONTINUE WILL RECOVER. IF THE PROGRAM HANGS
UP IN A LOOP, THE ERROR IS LIKELY TO BE A SIGNAL WHICH
WAS NEVER RECEIVED. IF A HALT OCCURS IN THE TRAP AND
VECTER AREA THE PROGRAM MUST BE RESTARTED. IF THE
PROGRAM HALTS IN THE MAIN FLOW, CONSULT THE LISTING
IF NO MESSAGE IS TYPED OUT.

7.0 RESTRICTIONS

RELOCATION CANNOT BE DONE INTO 160000
IF PARITY CHECKING IS ENABLED THEN ON AN ERROR IT
IS NOT GUARANTEED WHICH WILL SHOW UP: THE PARITY ERROR
OR THE BIT ERROR.
IT IS RECOMMENDED THAT PARITY IS ENABLED ONLY WHEN
LOOKING FOR PARITY ERRORS.

8.0 MSCCELLANEOUS

8.1 EXECUTION TIME

APPOXIMATELY 10 MIN PER 4K TESTED. (BOTH PICKUPS & DROPS.)

%
.ENABL ABS
.TITLE TEST MOS MEMORY
;COPYRIGHT 1973 DIGITAL EQUIPMENT CORP., MAYNARD, MASS. 01754
;PROGRAM BY JIM LACEY, SUB MALLICK
;*****

; OPERATIONAL SWITCH SETTINGS

SWITCH	USE
15	HALT ON ERROR
14	0 - DISABLE PARITY CHECKING 1 - ENABLE PARITY CHECKING
13	INHIBIT ERROR TYPEOUTS
12	0 - SET PROGRAM TO CATCH BOTH BIT DROPS AND PICKUPS 1 - SET PROGRAM AS INDICATED BY SWITCH 11
11	0 - SET PROGRAM TO CATCH BIT DROPS 1 - SET PROGRAM TO CATCH BIT PICKUPS
10	0 - PRINT END PASS

309
310
311
312
313
314
315
316
317
318
319
320
321
322
323
324
325
326
327
328
329
330
331
332
333
334
335
336
337
338
339
340
341
342
343
344
345
346
347
348
349
350
351
352
353
354
355
356
357
358
359
360
361
362
363
364

```

;
;          9
;
;          8
;          7
;
;          1
;          0
;*****
1 - BELL ON ERROR
0 - PRINT FIRST ERROR PER PRECHARGE
1 - PRINT ALL ERRORS PER PRECHARGE
INHIBIT PRINTING DATA HEADER
0=TEST READ AND WRITE FROM OUTSIDE OF THE CHIP
1=TEST INSTRUCTIONS IN THE CHIP
LOCK ON PRESENT MOD
LOCK ON PRESENT PRECHARGE

```

```

;BASIC DEFINITIONS
.EQUIV EMT,HLT
.EQUIV IOT,SCOPE
PS= 177776
.EQUIV PS,PSW
SWR= 177570
DISPLAY=SWR
;BASIC DEFINITION OF ERROR CALL
;BASIC DEFINITION OF SCOPE CALL
;PROCESSOR STATUS WORD
;SWITCH REGISTER

```

```

;REGISTER DEFINITION
R0= %0
R1= %1
R2= %2
R3= %3
R4= %4
R5= %5
R6= %6
R7= %7
.EQUIV R6,SP
.EQUIV R7,PC
;GENERAL REGISTER
;GENERAL REGISTER
;GENERAL REGISTER
;GENERAL REGISTER
;GENERAL REGISTER
;GENERAL REGISTER
;GENERAL REGISTER
;GENERAL REGISTER
;STACK POINTER
;PROGRAM COUNTER

```

```

;SWITCH DEFINITION
SW15= 100000
SW14= 40000
SW13= 20000
SW12= 10000
SW11= 4000
SW10= 2000
SW09= 1000
SW08= 400
SW07= 200
SW06= 100
SW05= 40
SW04= 20
SW03= 10
SW02= 4
SW01= 2
SW00= 1
.EQUIV SW09,SW9
.EQUIV SW08,SW8
.EQUIV SW07,SW7
.EQUIV SW06,SW6
.EQUIV SW05,SW5
.EQUIV SW04,SW4
.EQUIV SW03,SW3
.EQUIV SW02,SW2

```

365		.EQUIV SW01,SW1
366		.EQUIV SW00,SW0
367		
368		:MISCELLANEOUS BIT ASSIGNMENT
369	100000	BIT15= 100000
370	040000	BIT14= 40000
371	020000	BIT13= 20000
372	010000	BIT12= 10000
373	004000	BIT11= 4000
374	002000	BIT10= 2000
375	001000	BIT09= 1000
376	000400	BIT08= 400
377	000200	BIT07= 200
378	000100	BIT06= 100
379	000040	BIT05= 40
380	000020	BIT04= 20
381	000010	BIT03= 10
382	000004	BIT02= 4
383	000002	BIT01= 2
384	000001	BIT00= 1
385		.EQUIV BIT09,BIT9
386		.EQUIV BIT08,BIT8
387		.EQUIV BIT07,BIT7
388		.EQUIV BIT06,BIT6
389		.EQUIV BIT05,BIT5
390		.EQUIV BIT04,BIT4
391		.EQUIV BIT03,BIT3
392		.EQUIV BIT02,BIT2
393		.EQUIV BIT01,BIT1
394		.EQUIV BIT00,BIT0
395		
396		:VECTOR ADDRESSES
397	000004	ERRVEC= 4
398	000010	RESVEC= 10
399	000014	TBITVEC=14
400	000014	TRTVEC= 14
401	000014	BPTVEC= 14
402	000020	IOTVEC= 20
403	000024	PWRVEC= 24
404	000030	EMTVEC= 30
405	000034	TRAPVEC=34
406	000114	PARVEC=114
407	000250	MMVEC=250

408
409
410 000100 000100 FIRST: .=100
411 000000 .WORD 0

;KT11-D STATUS REGISTER ADDRESSES

412
413
414
415
416 000102 177572 SR0: 177572
417 000104 177574 SR1: 177574
418 000106 177576 SR2: 177576
419 000110 172516 SR3: 172516

;KERNAL PAGE DESCRIPTOR REGISTERS

420
421
422
423
424
425 000112 172300 KIPDR0: 172300
426 000114 172302 KIPDR1: 172302
427 000116 172304 KIPDR2: 172304
428 000120 172306 KIPDR3: 172306
429 000122 172310 KIPDR4: 172310
430 000124 172312 KIPDR5: 172312
431 000126 172314 KIPDR6: 172314
432 000130 172316 KIPDR7: 172316

;KERNAL PAGE ADDRESS REGISTERS

433
434
435
436 000132 172340 KIPAR0: 172340
437 000134 172342 KIPAR1: 172342
438 000136 172344 KIPAR2: 172344
439 000140 172346 KIPAR3: 172346
440 000142 172350 KIPAR4: 172350
441 000144 172352 KIPAR5: 172352
442 000146 172354 KIPAR6: 172354
443 000150 172356 KIPAR7: 172356

;KT11 VECTOR ADDRESS

444
445
446
447 000152 000250 000252 SEGVEC: 250,252

462 000300 . =300

463
464
465 000300 016701 002364
466 000304 016702 005022
467 000310 016703 005014
468 000314 012122
469 000316 077302
470 000320 000137 000204

RESTOR: MOV T01, R1
MOV FROM, R2
MOV LENGTH, R3
1\$: MOV (R1)+, (R2)+
SOB R3, 1\$
JMP @#204

471
472
473
474
475
476
477
478
479 000324 010704
480 000326 062704 011164
481 000332 016702 002334
482 000336 012701 003132
483 000342 012442
484 000344 077102
485 000346 004767 006666
486 000352 011466
487 000354 000000

LOADER: MOV PC, R4
ADD #LAST+2-., R4
MOV LODER, R2
MOV #17774-LAST/2, R1
1\$: MOV (R4)+, -(R2)
SOB R1, 1\$
JSR PC, TYPE
FIN
HALT

488
489
490

```

491          ;*****
492          ;          .=-1100
493          ;*****
494          ;*****
495          ;*****
496          ;*****
497          ;ROUTINE TO TYPE ASCII MESSAGE. MESSAGE MUST TERMINATE WITH A 0 BYTE.
498          ;*****
499          ;*****
500          ;THE ROUTINE WILL INSERT A NUMBER OF NULL CHARACTERS AFTER A LINE FEED.
501          ;NOTE1: $NULL CONTAINS THE CHARACTER TO BE USED AS THE FILLER CHARACTER.
502          ;NOTE2: $FILLS CONTAINS THE NUMBER OF FILLER CHARACTERS REQUIRED.
503          ;*****
504          ;CALL:
505          ;          JSR      PC,$TYPE          ;CALL TYPE ROUTINE
506          ;          MESADDR          ;FIRST ADDRESS OF MESSAGE
507          ;*****
508          001100 177564          $TPS: 177564          ;TTY PRINTER STATUS REG. ADDRESS
509          001102 177566          $TPB: 177566          ;TTY PRINTER BUFFER REG. ADDRESS
510          001104          000          $NULL: .BYTE 0          ;CONTAINS NULL CHARACTER FOR FILLS
511          001105          002          $FILLS: .BYTE 2          ;CONTAINS # OF FILLER CHARACTERS REQUIRED
512          001106          000          $TPFLG: .BYTE 0          ;"TERMINAL AVAILABLE" FLAG (0=YES)
513          001107          000          ;RESERVED
514          ;*****
515          001110 105767 177772          $TYPE: TSTB          $TPFLG
516          001114 001402          BEQ          6$
517          001116 000000          HALT
518          001120 000407          BR          7$
519          001122 010046          6$: MOV          RO,-(SP)          ;SAVE RO
520          001124 017600 000002          MOV          @2(SP),RO          ;GET ADDRESS OF ASCIZ STRING
521          001130 112046          1$: MOV          (RO)+,-(SP)          ;PUSH CHARACTER TO BE TYPED ONTO STACK
522          001132 001005          BNE          2$          ;BR IF IT ISN'T THE TERMINATOR
523          001134 005726          TST          (SP)+          ;IF TERMINATOR POP IT OFF THE STACK
524          001136 012600          MOV          (SP)+,RO          ;RESTORE RO
525          001140 062716 000002          7$: ADD          #2,(SP)          ;ADJUST RETURN PC
526          001144 000207          RTS          PC          ;RETURN
527          001146 004767 000026          2$: JSR          PC,5$          ;GO TYPE THIS CHARACTER
528          001152 122726 000012          3$: CMP          #12,(SP)+          ;CHECK IF THE CHAR. TYPED WAS A LINE FEED
529          001156 001364          BNE          1$          ;GO GET NEXT CHAR. IF NOT LINE FEED
530          001160 016746 177720          MOV          $NULL,-(SP)          ;GET # OF FILLER CHARS. NEEDED
531          ;AND THE NULL CHAR.
532          001164 105366 000001          4$: DECB          1(SP)          ;DOES A NULL NEED TO BE TYPED?
533          001170 002770          BLT          3$          ;BR IF NO--GO POP THE NULL OFF OF STACK
534          001172 004767 000002          JSR          PC,5$          ;GO TYPE A NULL
535          001176 000772          BR          4$          ;LOOP
536          001200 105777 177674          5$: TST          @2$TPS          ;WAIT UNTIL PRINTER IS READY
537          001204 100375          BPL          5$
538          001206 116677 000002 177666          MOV          2(SP),@2$TPB          ;LOAD CHAR TO BE TYPED INTO DATA REG.
539          001214 000207          RTS          PC
540          001216 000062          .BLKB          62          ;RESERVE SOME MORE CORE FOR OVERLAY CAPIBILITIES
541          ;*****
542          ;*****
543          ;*****
544          ;*****
545          ;*****
546          ;ROUTINE TO SIZE MEMORY

```

547					:CALL:		
548						JSR	PC,\$SIZE
549						RETURN	
550						\$LSTAD	WILL CONTAIN THE LAST VIRTUAL ADDRESS OF THE LAST BANK
551						\$LSTBK	WILL CONTAIN THE LAST BANK AS A SAF
552						\$KT11	IS THE MEMORY MANAGEMENT KEY
553						BIT07	= 0 DON'T USE MEMORY MANAGEMENT
554						BIT15	= 0 DON'T HAVE MEMORY MANAGEMENT OPTION
555					\$SIZE:	MOV	R5,-(SP) ;SAVE R5 ON THE STACK
556	001300	010546				MOV	R4,-(SP)
557	001302	010446				MOV	R3,-(SP)
558	001304	010346				MOV	R1,-(SP) ;SAVE R1 ON THE STACK
559	001306	010146				MOV	RO,-(SP) ;SAVE RO ON THE STACK
560	001310	010046				MOV	SP,R5 ;SAVE THE STACK POINTER
561	001312	010605				MOV	#3776,R1
562	001314	012701	003776			TSTB	(PC)+ ;USE MEMORY MANAGEMENT?
563	001320	105727			\$KT11:	0	
564	001322	000000				BPL	\$SCORE ;BR IF NO
565	001324	100152			\$SEG:	MOV	PC,-(SP)
566	001326	010746				ADD	#SCORE--, (SP)
567	001330	062716	000322			MOV	(SP)+, @#ERRVEC ;SET FOR TIMEOUT
568	001334	012637	000004			TST	@SR0 ;KT11 ARE YOU THERE?
569	001340	005777	176536			BIS	#BIT15,\$KT11 ;YES--SET KT11 KEY
570	001344	052767	100000	177750		MOV	#77406,R3
571	001352	012703	077406			MOV	R3,@KIPDR0
572	001356	010377	176530			MOV	R3,@KIPDR1
573	001362	010377	176526			MOV	R3,@KIPDR2
574	001366	010377	176524			MOV	R3,@KIPDR3
575	001372	010377	176522			MOV	R3,@KIPDR4
576	001376	010377	176520			MOV	R3,@KIPDR5
577	001402	010377	176516			MOV	R3,@KIPDR6
578	001406	010377	176514			MOV	PC,@KIPDR7
579	001412	010377	176512				
580							
581							
582	001416	005077	176510			CLR	@KIPAR0
583	001422	012777	000200	176504		MOV	#200,@KIPAR1
584	001430	012777	000400	176500		MOV	#400,@KIPAR2
585	001436	012777	000600	176474		MOV	#600,@KIPAR3
586	001444	012777	001000	176470		MOV	#1000,@KIPAR4
587	001452	012777	001200	176464		MOV	#1200,@KIPAR5
588	001460	012777	001400	176460		MOV	#1400,@KIPAR6
589	001466	012777	007600	176454		MOV	#7600,@KIPAR7
590							
591							
592	001474	010703				MOV	PC,R3
593	001476	000241				CLC	
594	001500	006103				ROL	R3
595	001502	006103				ROL	R3
596	001504	006103				ROL	R3
597	001506	006103				ROL	R3
598	001510	042703	177770			BIC	#177770,R3
599	001514	022703	000006			CMP	#6,R3
600	001520	001403				BEQ	2\$
601							
602							

```

603 001522 016704 176420      MOV      KIPAR6,R4
604 001526 000425      BR       35
605
606
607
608 001530 016704 176410      25:     MOV      KIPAR5,R4
609 001534 012767 123776 000070      MOV      #123776,15+2
610 001542 012703 120000      MOV      #120000,R3
611 001546 010367 003354      MOV      R3,SEGO+2
612 001552 010367 003356      MOV      R3,SEGO+10
613 001556 010367 003376      MOV      R3,SEG10+2
614 001562 010367 003400      MOV      R3,SEG10+10
615 001566 012767 137776 003346      MOV      #137776,SEGO+16
616 001574 012767 137776 003372      MOV      #137776,SEG10+16
617
618
619
620 001602 010467 001060      35:     MOV      R4,PAGE
621 001606 005014      CLR      (R4)
622
623
624
625
626 001610 012777 000001 176264      MOV      #1,JSRO          ;TURN ON MEMORY MANAGEMENT
627 001616 010746      MOV      PC,-(SP)
628 001620 062716 000026      ADD      #SKTOUT-(SP)
629 001624 012637 000004      MOV      (SP)+,2#ERRVEC ;SET FOR TIME OUT
630 001630 005737 143776      15:     TST      2#143776      ;TRAP ON NON-EX-MEM
631 001634 062714 000040      ADD      #40,(R4)      ;MAKE A 1K STEP
632 001640 027714 176304      CMP      2KIPAR7,(R4) ;LAST ONE?
633 001644 003371      BGT      15           ;NO--TRY IT
634 001646 011400      SKTOUT: MOV      (R4),R0      ;GET LAST BANK+1
635 001650 000420      BR
636 001652 010746      SCORE:  MOV      PC,-(SP)
637 001654 062716 000032      ADD      #SCOROUT-(SP)
638 001660 012637 000004      MOV      (SP)+,2#ERRVEC ;SET FOR TIMEOUT
639 001664 005000      CLR      R0          ;SET UP BANK
640 001666 062701 004000      15:     ADD      #4000,R1      ;INCREMENT BY 1K
641 001672 062700 000040      ADD      #40,R0       ;1K STEP
642 001676 005711      TST      (R1)         ;TRAP ON TIME OUT
643 001700 022701 177776      CMP      #177776,R1   ;LAST ONE
644 001704 001370      BNE      15           ;NO--TRY AGAIN
645 001706 162701 004000      SCOROUT: SUB      #4000,R1
646 001712 162700 000040      SSIZEX: SUB      #40,R0      ;DROP BACK
647 001716 012737 000006 000004      MOV      #6,2#ERRVEC  ;SET FOR ERRORS
648 001724 010506      MOV      R5,SP        ;RESTORE THE STACK
649 001726 010167 000032      MOV      R1,SLSTAD
650 001732 010067 000030      MOV      R0,SLSTBK
651 001736 005767 177360      TST      SKT11
652 001742 100002      BPL      15
653 001744 005077 176132      CLR      JSRO
654 001750 012600      15:     MOV      (SP)+,R0
655 001752 012601      MOV      (SP)+,R1
656 001754 012603      MOV      (SP)+,R3
657 001756 012604      MOV      (SP)+,R4
658 001760 012605      MOV      (SP)+,R5      ;RESTORE R5

```

659 001762 000207
660 001764 000000
661 001766 000000

RTS PC
\$LSTAD: .WORD 0
\$LSTBK: .WORD 0

:CONTAINS THE LAST ADDRESS
:CONTAINS THE LAST BANK

```

662 ;ROUTINE TO GET TYPED ASCII DATA AND CONVERT TO OCTAL.
663 ;LEAVES THE OCTAL DATA IN THE ADDRESS FOLLOWING THE CALL.
664 ;CALL: RECD ;(A TRAP TYPE INST.)
665 ;.WORD 0 ;CONTAINS RETURNED DATA
666 ;CONTINUE ;RETURNS HERE
667
668
669 001770 177560 TKS: 177560
670 001772 177562 TKB: 177562
671
672
673 001774 000240 .RECD: NOP
674 001776 005046 CLR -(SP)
675 002000 105777 177764 1$: TSTB @TKS ;WAIT FOR USER RESPONSE
676 002004 100375 BPL 1$
677 002006 117746 177760 MOVB @TKB, -(SP) ;GET ASCII CHARACTER
678 002012 042716 177600 BIC #177600, (SP)
679 002016 122716 000177 CMPB #177, (SP) ;CHECK IF RUBOUT
680 002022 001013 BNE 2$ ;BRANCH IF NOT RUBOUT
681 002024 012767 000134 000142 MOV #' \, 4$
682 002032 004767 005202 JSR PC, TYPE ;ECHO BACK SLASH
683 002036 002174 4$
684 002040 005726 6$: TST (SP)+ ;POP LAST TYPED CHAR OFF THE STACK
685 002042 006016 ROR (SP) ;SHIFT LAST TYPD CHARACTER
686 002044 006216 ASR (SP)
687 002046 006216 ASR (SP)
688 002050 000753 BR 1$ ;AND WAIT FOR NEXT CHAR.
689
690
691 002052 122716 000015 2$: CMPB #15, (SP) ;CHECK IF CARRIAGE RETURN
692 002056 001011 BNE 3$ ;BRANCH IF NOT A CARRIAGE RETURN
693 002060 004767 005154 JSR PC, TYPE
694 002064 002647 $CRLF
695 002066 005726 TST (SP)+ ;POP CARRIAGE RETURN OFF THE STACK
696 002070 012676 000000 MOV (SP)+, @2(SP) ;PUT DATA IN ADDRESS FOLLOWING CALL
697 002074 062716 000002 ADD #2, (SP)
698 002100 000207 RTS PC
699 002102 111667 000066 3$: MOVB (SP), 4$
700
701 002106 004767 005126 JSR PC, TYPE ;GO TO PRINT ROUTINE
702 002112 002174 4$ ;ECHO CHARACTER
703 002114 042767 177707 000052 BIC #177707, 4$
704 002122 022767 000060 000044 CMP #60, 4$
705 002130 001407 BEQ 5$
706 002132 004767 005102 JSR PC, TYPE
707 002136 002647 $CRLF
708 002140 004767 005074 JSR PC, TYPE
709 002144 011217 SORRY
710 002146 000734 BR 6$
711 002150 042716 177770 5$: BIC #177770, (SP) ;SAVE ONLY 3 MSBS
712 002154 006366 000002 ASL 2(SP) ;SHIFT LAST CHARACTER OVER
713 002160 006366 000002 ASL 2(SP) ;THREE PLACES
714 002164 006366 000002 ASL 2(SP)
715 002170 052616 BIS (SP)+, (SP) ;INSET OCTAL CHAR
716 002172 000702 BR 1$ ;GO WAIT FOR NEXT CHAR.
717 002174 000000 4$: .WORD 0 ;CONTAINS CHARACTER TO BE TYPED

```

```

718                                     ;ROUTINE TO SET PARITY ENABLE ON MA/MF PARITY MEMORIES
719                                     PARCSR= 172100 ;ADDRESS OF FIRST POSSIBLE PARITY REG.
720
721
722
723 002176 012737 002254 000114 MAMF: MOV #PARSRV, @#PARVEC ;LOAD VECTOR
724 002204 012737 000340 000116 MOV #340, @#PARVEC+2 ;AND PRIORITY LEVEL
725 002212 012737 000006 000004 MOV #ERRVEC+2, @#ERRVEC ;SET TIME OUT TRAP VECTOR
726 002220 012737 000002 000006 MOV #RTI, @#ERRVEC+2 ;DO RTI ON TIMEOUT TRAP
727 002226 012700 172100 MOV #PARCSR, R0 ;GET FIRST POSSIBLE ADDRESS
728 002232 012702 000001 MOV #1, R2 ;SET REG. COUNTER
729
730 002236 012720 000001 1S: MOV #1, (R0)+ ;SET ACTION ENABLE IF THERE
731 002242 005302 ASL R2 ;CHECK IF 16 REG. HAVE BEEN DONE
732 002244 103374 BCC 1S ;REPEAT IF 16 NOT ENABLED
733 002246 005037 000006 CLR @#ERRVEC+2 ;RESTORE HALT ON TIMEOUT
734 002252 000207 RTS PC ;RETURN
735
736

```

```

737
738 002254 004767 004760      :PARITY ERROR SERVICE ROUTINE
739 002260 011131      PARSRV: JSR PC, TYPE ;TYPE PARITY ERROR SO PARITY
740 002262 010746      MOV PC, -(SP) ;ERROR TEST STARTED
741 002264 062716 000120      ADD #2$, (SP) ;MAKE 2$ POSITION INDEPENDENT
742 002270 012637 000114      MOV (SP)+, @#PARVEC ;SET PARITY ERROR TRAP
743 002274 010746      MOV PC, -(SP) ;MAKE 4$ POSITION INDEPENDENT
744 002276 062716 000216      ADD #4$, (SP)
745 002302 012637 000004      MOV (SP)+, @#ERRVEC
746 002306 010746      MOV PC, -(SP) ;MAKE 5$ POSITION INDEPENDENT
747 002310 062716 000214      ADD #5$, (SP)
748 002314 012637 000250      MOV (SP)+, @#MMVEC ;SET MEMORY MANAGEMENT ABORT TRAP
749 002320 005000      CLR RO
750 002322 005767 176774      TST $KT11 ;IS MEM MANG. THERE?
751 002326 100024      BPL 1$ ;IF NOT BRANCH
752 002330 012702 077406      MOV #77406, R2 ;SET UP MEM MANGT.
753 002334 005077 175572      CLR @KIPAR0
754 002340 010277 175546      MOV R2, @KIPDR0
755 002344 005077 175564      CLR @KIPAR1
756 002350 005077 175542      CLR @KIPDR2
757 002354 010277 175534      MOV R2, @KIPDR1
758 002360 012777 007600 175562      MOV #7600, @KIPAR7
759 002366 010277 175536      MOV R2, @KIPDR7
760 002372 012777 000001 175502      MOV #1, @SR0 ;ENABLE MEM MANGT.
761
762
763
764 002400 005720      1$: TST (RO)+ ;SCAN MEMORY FOR PARITY
765 002402 000776      BR 1$
766
767
768 002404 004767 004630      2$: JSR PC, TYPE ;TYPE LOCATION GIVING PARITY ERROR
769 002410 011021      PAERR
770 002412 017777 175516 175522      MOV @KIPAR1, @KIPAR4
771 002420 014046      MOV -(RO), -(SP)
772 002422 004067 004672      JSR RO, $B20CT
773 002426 006      .BYTE 6
774 002427 003      .BYTE 3
775 002430 005767 176666      6$: TST $KT11
776 002434 100005      BPL 3$
777 002436 005077 175440      CLR @SR0
778 002442 004767 004572      JSR PC, TYPE
779 002446 002647
780 002450 000005      3$: SCRLF
781 002452 010746      RESET
782 002454 062716 177600      MOV PC, -(SP)
783 002460 012637 000114      ADD #PARSRV-, (SP)
784 002464 010746      MOV (SP)+, @#PARVEC
785 002466 062716 175320      MOV PC, -(SP)
786 002472 012637 000004      ADD #ERRVEC+2-, (SP) ;RESET PARITY ERROR TRAP AND ERROR VECTOR
787 002476 012737 000252 000250      MOV (SP)+, @#ERRVEC ;RESET MEM MANGT. ABORT TRAP
788 002504 010746      MOV #MMVEC+2, @#MMVEC
789 002506 062716 001374      MOV PC, -(SP)
790 002512 000136      ADD #BEGIN3-, (SP) ;JUMP RESTART
791
792

```

TEST MOS MEMORY MACY11 27(732) 22-SEP-76 14:48 PAGE 19
DCMSBB.P11

793								
794	002514	004767	004520		4\$:	JSR	PC,	TYPE
795	002520	011061				NOPARE		
796	002522	000742				BR	6\$	
797								
798								
799								
800	002524	062777	000200	175402	5\$:			
801	002532	012700	020000					
802	002536	000002						

.MEMORY MANAGEMENT ABORT ROUTINE
ADD #200,JKIPAR1 ;ADD NEXT 4K TO ADDRESS
MOV #20000,R0 ;RESET VIRTUAL ADDRESS
RTI

```

803
804
805
806
807
808 002540 000000
809 002542 000000
810 002544 000000
811 002546 000000
812 002550 000000
813 002552 000000
814 002554 000
815 002555 000
816 002556 000000 000000
817 002562 000
818 002563 000
819 002564 000000
820 002566 000000
821 002570 000000
822 002572 000000
823 002574 000000
824 002576 000000
825 002600 000000
826 002602 000000
827 002604 000000
828 002606 000000
829 002610 017776
830 002612 000000
831 002614 000000
832 002616 000000
833 002620 000000
834 002622 023420
835 002624 177777
836 002626 177777
837 002630 000000
838 002632 000400
839 002634 000000
840 002636 000000
841 002640 000000
842 002642 000000
843 002644 000207
844 002646 077
845 002647 015
846 002650 000012
847 002652 000000
848 002654 000000
849 002656 177777
850 002660 000000
851 002662 000000
852 002664 000000
853 002666 000000
854 002670 000000
855 002672 000000

```

;COMMON TAGS

```

$PASS: .WORD 0
$TSTNM: .WORD 0
$ICNT: .WORD 0
$LPADR: .WORD 0
$LPERR: .WORD 0
$ERTTL: .WORD 0
$ERFLG: .BYTE 0
SITEMB: .BYTE 0,0
$HLTAD: .WORD 0
$GDADR: .WORD 0
$BDADR: .WORD 0
$GDDAT: .WORD 0
$BDDAT: .WORD 0
$TMPD: .WORD 0
$TMP1: .WORD 0
$TMP2: .WORD 0
TSTADR: .WORD 0
LOLMT: .WORD 0
HILMT: .WORD 17776
MOD: .WORD 0
COL: .WORD 0
ROW: .WORD 0
PCHRG: .WORD 0
CYCNT: .WORD 1000.
TSTPAT: .WORD -1
BCKGRD: .WORD -1
INSTAD: .WORD 0
MSKBIT: .WORD BIT08
SV400: .WORD 0
SVIN1: .WORD 0
SVIN2: .WORD 0
ESCAPE: .WORD 0
$BELL: .ASCIZ <207>
$QUES: .ASCIZ /?/
$CRLF: .ASCIZ <15>
$LF: .ASCIZ <12>
PASFLG: .WORD 0
SELF: .WORD 0
REDONE: .WORD -1
LOBASE: .WORD 0
HIBASE: .WORD 0
LSTBK: .WORD 0
PAGE: .WORD 0
TO1: .WORD 0
LODER: .WORD 0

```

```

;CONTAINS PASS COUNT
;CONTAINS THE TEST NUMBER
;CONTAINS SUBTEST ITERATION COUNT
;CONTAINS SCOPE LOOP ADDRESS
;CONTAINS SCOPE RETURN FOR ERRORS
;CONTAINS TOTAL ERRORS DETECTED
;CONTAINS ERROR FLAG
;RESERVED--NOT TO BE USED
;RESERVED--NOT TO BE USED
;CONTAINS ITEM CONTROL BYTE
;RESERVED--NOT TO BE USED
;CONTAINS PC OF LAST HLT INSTRUCTION
;CONTAINS ADDRESS OF 'GOOD' DATA
;CONTAINS ADDRESS OF 'BAD' DATA
;CONTAINS 'GOOD' DATA
;CONTAINS 'BAD' DATA
;USER DEFINED
;USER DEFINED
;USER DEFINED
;TEST ADDRESS
;LOW LIMIT
;HIGH LIMIT
;MODULE NUMBER
;COLUMN NUMBER
;ROW NUMBER
;PRECHARGE
;CYCLE COUNT
;TEST PATTERN
;BACK GROUND PATTERN
;ADDRESS OF INSTRUCTION UNDER TEST
;MASK BIT

;CODE FOR BELL
;QUESTION MARK
;CARRIAGE RETURN
;LINE FEED

```

```

;RELOCATE TO HERE IF 0 CHOSEN
;LOADER IS HERE

```

856
857
858
859
860
861
862
863
864
865
866
867
868
869
870
871
872
873
874
875
876
877
878
879
880
881
882
883
884
885
886
887
888
889
890

; THE FOLLOWING TABLE CONTAINS THE INFORMATION FOR EACH ERROR THAT CAN OCCUR.
; THIS INFORMATION IS OBTAINED BY USING THE INDEX NUMBER FOUND IN
; LOCATION \$ITEMB. THIS NUMBER INDICATES WHICH ITEM IN THE TABLE IS PERTINENT.
; NOTE1: IF \$ITEMB IS 0 THE ONLY PERTINENT DATA IS (\$HLTAD).
; NOTE2: EACH ITEM IN THE TABLE CONTAINS 4 POINTERS EXPLAINED AS FOLLOWS:

; EM ;POINTS TO THE ERROR MESSAGE
; DH ;POINTS TO THE DATA HEADER
; DT ;POINTS TO THE DATA
; DF ;POINTS TO THE DATA FORMAT

\$ERRTB:
; ITEM 1

EM1 ;TEST PATTERN
DH1 ;ERROR FAILING
;PC ADDRESS EXPECT RCV'D COL ROW PRECHARGE
; \$HLTAD \$BDADR \$GDDAT \$BDDAT \$TMPO \$TMP1 \$TMP2
DF1 ;ALL NUMBERS ARE TYPED IN OCTAL

; ITEM 2

EM2 ;INSTRUCTION CHANGED
DH2 ;ERROR INST EXPECT RCV'D,
;PC ADDRESS DATA DATA COL ROW PRECHARGE
; \$HLTAD \$BDADR \$GDDAT \$BDDAT \$TMPO \$TMP1 \$TMP2
DF1 ;ALL NUMBERS ARE TYPED IN OCTAL

; ITEM 3

EM3 ;BACK GROUND CHANGED
DH3 ;ERROR BCKGRD EXPECT RCV'D
;PC ADDRESS DATA DATA COL ROW PRECHARGE
; \$HLTAD \$BDADR \$GDDAT \$BDDAT \$TMPO \$TMP1 \$TMP2
DF1 ;ALL NUMBERS ARE TYPED IN OCTAL

;*****

002674

002674 007614

002676 007707

002700 010270

002702 010310

002704 007633

002706 010016

002710 010270

002712 010310

002714 007661

002716 010143

002720 010270

002722 010310

DCMSBB.P11

891
892
893 002724 005010
894 002726 077102
895 002730 000207
896
897 002732 005010
898 002734 077102
899 002736 000207
900
901 002740 000000 177777 177777

```

:*****
:THIS IS WHERE THE TEST INSTRUCTIONS ARE STORED
INSTR1: CLR      (R0)
INSTR2: SOB      R1, INSTR1
INSTR3: RTS      PC
:END OF TEST INSTRUCTIONS
INSIDE: CLR      (R0)
        SOB      R1, INSIDE
        RTS      PC
OUTSID: .WORD    0, -1, -1

```

902
903
904
905
906
907
908
909
910
911
912
913
914
915
916
917
918
919
920
921
922
923
924
925
926
927
928
929
930
931
932
933
934
935
936
937
938
939
940
941
942
943
944
945
946
947
948
949
950
951
952
953
954
955
956
957

;THIS IS THE STARTING POINT IF LIMITS ARE TO BE SELECTED
;ALL TYPING SHOULD BE DONE ONLY AFTER SEEING SECTION
;4.3.1 AT THE BEGINNING OF THIS DOCUMENT

```

BEGIN1: MOV      PC,      SP      ;SET STACK POINTER AND
        ADD      #1000, SP      ;MAKE IT POSITION INDEPENDANT
        CLR      PASFLG        ;PASFLG IS COUNTER FOR WHEN
                                ;BOTH PICKS & DROPS
        JSR      PC,      TYPE
        SCRLF
        MOV      #BIT07, SKT11  ;USE MEM MANG. IF THERE
        JSR      PC,      $SIZE  ;SIZE MEM
        JSR      PC,      TYPE  ;TYPE "LAST ADDRESS IN MEMORY"
        MEMEND
        TST      SKT11          ;IS MEMORY MANAGEMENT THERE?
        BPL      2$           ;BRANCH IF NO MEM MANAGEMENT
        MOV      $LSTBK, $PAGE  ;PAGE CONTAINS KIPAR6 OR KIPAR5
        MOV      #1, $SR0      ;TURN ON MEM. MANAGEMENT
2$:     MOV      $LSTADR, -(SP)  ;GET READY TO TYPE ADDRESS IN OCTAL
        JSR      RD, $B20CT
        .BYTE   6
        .BYTE   3              ;PHYSICAL ADDRESS IF MEM MANG. THERE
        TST      SKT11
        BPL      3$
        CLR      $SR0
3$:     JSR      PC,      TYPE
        SCRLF
        JSR      PC,      TYPE  ;GO TO TYPE "TYPE STARTING
                                ;BANK NUMBER AND CR
                                ;REFER TO SECTION 4.3.1 BEFORE CHOOSING"
1$:     STARTB
        MOV      #START2, 1$
        JSR      PC,      .RECD  ;GET STARTING BANK NUMBER
        .WORD   0              ;AND LEAVE IT HERE
STBANK: JSR      PC,      TYPE  ;GO TO TYPE "TYPE NUMBER OF 4K
                                ;BANKS TO BE TESTED AND CR"
1$:     NUMBER
        MOV      #NUMB2, 1$
        JSR      PC,      .RECD  ;GET NUMBER OF BANKS
        .WORD   0              ;AND LEAVE IT HERE
BANKS:  CLR      SELF
        MOV      #BEGIN2+20000, BEG2 ;THESE FOUR LINES
        MOV      #7736, LENGTH    ;TO SET UP FOR
        MOV      #FIRST, FROM     ;NO LIMIT CHOOSING ON RESTART
        MOV      #FIRST+20000, TO

```

;THE FOLLOWING INSTRUCTIONS IN THIS SECTION IS FOR
;RELOCATION IF STARTING BANK CHOSEN IS 0
;IF RELOCATION IS ALREADY DONE BY OPERATOR THEN NO FURTHER
;RELOCATION IS DONE

958	003162	016704	175600		MOV	\$LSTBK, R4	
959	003166	162704	000140		SUB	#140, R4	
960	003172	022704	001400		CMP	#1400, R4	
961	003176	101002			BHI	1\$	
962	003200	012704	001400		MOV	#1400, R4	
963	003204	000241		1\$:	CLC		
964	003206	006104			ROL	R4	
965	003210	006104			ROL	R4	
966	003212	006104			ROL	R4	
967	003214	006104			ROL	R4	
968	003216	006104			ROL	R4	
969	003220	006104			ROL	R4	
970	003222	010402			MOV	R4, R2	
971	003224	005767	177442		TST	LODER	
972	003230	001027			BNE	5\$; BRANCH IF SOMETHING IN LODER ; THAT IS LOADER ALREADY PULLED IN
973							
974	003232	010403			MOV	R4, R3	
975	003234	062703	020000		ADD	#20000, R3	
976	003240	010367	177426		MOV	R3, LODER	
977	003244	010705			MOV	PC, R5 ; TO	
978	003246	062705	006244		ADD	#LAST+2-., R5	
979	003252	012700	003132		MOV	#17774-LAST/2, R0; LENGTH	
980	003256	014325		2\$:	MOV	-(R3), (R5)+	
981	003260	077002			SOB	R0, 2\$	
982	003262	004767	003752		JSR	PC, TYPE	
983	003266	011402			RELOD		
984	003270	012746	000324		MOV	#LOADER, -(SP)	
985	003274	004067	004020		JSR	R0, \$B20CT	
986	003300	006			.BYTE	6	
987	003301	002			.BYTE	2	
988	003302	004767	003732		JSR	PC, TYPE	
989	003306	011434			RELOD2		
990	003310	005767	177566	5\$:	TST	STBANK	
991	003314	001056			BNE	4\$	
992	003316	010746			MOV	PC, -(SP)	
993	003320	042726	017777		BIC	#17777, (SP)+	
994	003324	001052			BNE	4\$	
995	003326	010406			MOV	R4, SP	
996	003330	062706	001100		ADD	#1100, SP	
997	003334	062704	000100		ADD	#FIRST, R4	
998	003340	010467	177324		MOV	R4, T01	
999	003344	016700	001760		MOV	LENGTH, R0	
1000	003350	016701	001756		MOV	FROM, R1	
1001	003354	012124		3\$:	MOV	(R1)+, (R4)+	
1002	003356	077002			SOB	R0, 3\$	
1003	003360	062702	004042		ADD	#BEGIN2, R2	
1004	003364	004767	003650		JSR	PC, TYPE	
1005	003370	011264			PROTO		
1006	003372	016746	177272		MOV	T01, -(SP)	
1007	003376	062716	000104		ADD	#104, (SP)	
1008	003402	004067	003712		JSR	R0, \$B20CT	
1009	003406	006			.BYTE	6	
1010	003407	002			.BYTE	2	
1011	003410	004767	003624		JSR	PC, TYPE	
1012	003414	002647			\$CRLF		
1013	003416	004767	003616		JSR	PC, TYPE	

1014	003422	011332			PROBAK			
1015	003424	016746	177240		MOV	T01, -(SP)		
1016	003430	062716	000200		ADD	#RESTOR-100, (SP)		
1017	003434	004067	003660		JSR	RO, \$B20CT		
1018	003440	006			.BYTE	6		
1019	003441	002			.BYTE	2		
1020	003442	004767	003572		JSR	PC, TYPE		
1021	003446	002647			\$CRLF			
1022	003450	000112			JMP	(R2)		
1023	003452	000573			BR	BEGIN2		
1024								
1025								
1026								
1027								
1028								
1029	003454	010706			BEGN11: MOV	PC, SP		; SETUP STACK POINTER AND
1030	003456	062706	175422		ADD	#1100-., SP		; MAKE IT POSITION INDEPENDANT
1031	003462	005067	177164		CLR	PASFLG		; PASFLG IS COUNTER WHEN BOTH PICKS
1032								; AND DROPS ARE USED
1033	003466	012767	000200	175626	MOV	#BIT07, \$KT11		; BIT 7 SAYS SEGMENTATION IS THERE
1034	003474	004767	175600		JSR	PC, \$SIZE		; SIZE MEMORY
1035	003500	004767	003534		JSR	PC, TYPE		
1036	003504	010771			MEMEND			
1037	003506	005767	175610		TST	\$KT11		
1038	003512	100006			BPL	2\$		
1039	003514	016777	176246	177144	MOV	\$LSTBK, \$PAGE		
1040	003522	012777	000001	174352	MOV	#1, \$SR0		
1041	003530	016746	176230		2\$: MOV	\$LSTADR, -(SP)		
1042	003534	004067	003560		JSR	RO, \$B20CT		
1043	003540	006			.BYTE	6		
1044	003541	003			.BYTE	3		
1045	003542	005767	175554		TST	\$KT11		
1046	003546	100002			BPL	3\$		
1047	003550	005077	174326		CLR	\$SR0		
1048	003554	004767	003460		3\$: JSR	PC, TYPE		
1049	003560	002647			\$CRLF			
1050	003562	012767	000001	177312	MOV	#1, STBANK		; STARTING BANK # = 1 LOC = 20000
1051	003570	016767	176172	177066	MOV	\$LSTBK, LSTBK		; LAST BANK IS STORED IN LSTBK
1052	003576	062767	000040	177060	ADD	#40, LSTBK		
1053	003604	006067	177054		ROR	LSTBK		; DIVIDE LSTBK BY 200
1054	003610	006067	177050		ROR	LSTBK		; TO GIVE NUMBER OF
1055	003614	006067	177044		ROR	LSTBK		; BANKS PRESENT IN
1056	003620	006067	177040		ROR	LSTBK		; EXISTING MEMORY
1057	003624	006067	177034		ROR	LSTBK		
1058	003630	006067	177030		ROR	LSTBK		
1059	003634	006067	177024		ROR	LSTBK		
1060	003640	005367	177020		DEC	LSTBK		; NOW DECREASE ONE FOR BANKS
1061	003644	016767	177014	177252	MOV	LSTBK, BANKS		; TO BE TESTED AND STORE
1062	003652	012767	177777	176774	MOV	#-1, SELF		; 1 = RELOCATION REQUIRED
1063	003660	012767	024042	001440	MOV	#BEGIN2+20000, BEG2		
1064	003666	012767	007736	001434	MOV	#7736, LENGTH		
1065	003674	012767	000100	001430	MOV	#FIRST, FROM		
1066	003702	012767	020100	001424	MOV	#FIRST+20000, TO		
1067	003710	005067	176742		CLR	REDONE		; RELOCATION EXIT COUNTER
1068	003714	005767	176752		TST	LODER		
1069	003720	001050			BNE	BEGIN2		; BRANCH IF SOMETHING IN LODER

; THIS IS THE STARTING POINT IF NO LIMITS ARE TO
; BE SET AND ALL OF EXISTING MEMORY IS TO BE TESTED

; SETUP STACK POINTER AND
; MAKE IT POSITION INDEPENDANT
; PASFLG IS COUNTER WHEN BOTH PICKS
; AND DROPS ARE USED
; BIT 7 SAYS SEGMENTATION IS THERE
; SIZE MEMORY

; STARTING BANK # = 1 LOC = 20000
; LAST BANK IS STORED IN LSTBK
; DIVIDE LSTBK BY 200
; TO GIVE NUMBER OF
; BANKS PRESENT IN
; EXISTING MEMORY

; NOW DECREASE ONE FOR BANKS
; TO BE TESTED AND STORE
; 1 = RELOCATION REQUIRED
; RELOCATION EXIT COUNTER
; BRANCH IF SOMETHING IN LODER

1126	004136	010367	176516		MOV	R3,	LOBASE	:STORE LOW LIMIT PAGE ADDRESS
1127	004142	010267	176440		MOV	R2,	LCLMT	:SET LOW LIMIT
1128	004146	010267	176440		MOV	R2,	MOD	:SET MODULE NUMBER
1129	004152	162703	000200		SUB	#200,	R3	:GETTING READY FOR HIGH LIMIT PAGE
1130	004156	062702	020000		BEGIN4: ADD	#20000,	R2	:GETTING HIGH LIMIT
1131	004162	062703	000200		ADD	#200,	R3	:GETTING HIGH LIMIT PAGE ADDRESS
1132	004166	077105			SOB	R1,	BEGIN4	:REPEAT FOR BANK NUMBER
1133	004170	005302			DEC	R2,		:GETTING HIGH LIMIT WITHIN BANK
1134	004172	010267	176412		MOV	R2,	HILMT	:STORE HIGH LIMIT
1135	004176	010367	176460		MOV	R3,	HIBASE	:STORE HIGH LIMIT PAGE ADDRESS
1136	004202	022767	000006	176672	CMP	#6,	STBANK	:DOES STARTING BANK NEED SEGMENTATION?
1137	004210	103401			BLO	1\$:BRANCH IF YES
1138	004212	000407			BR	2\$		
1139	004214	162767	000200	176436	1\$: SUB	#200,	LOBASE	:SEGMENTATION REQUIREG 50
1140	004222	005167	176424		COM	PASFLG		
1141	004226	000167	000716		JMP	SEGMT1		:SUBTRACT TO ENABLE REPEATED ADDITION
1142	004232	022703	001600		2\$: CMP	#1600,	R3	:IS SEGMENTATION REQUIRED FOR HIGH?
1143	004236	101003			BHI	BEGIN5		:IF NO THEN BRANCH
1144	004240	012767	157776	176342	MOV	#157776,	HILMT	:IF YES HIGH LIMIT = END OF 32K
1145								
1146								:SETUP ALL TAGS TO THEIR APPROPRIATE VALUES
1147								
1148	004246	005067	176342		BEGIN5: CLR	COL		:MAKE COLUMN ZERO
1149	004252	005067	176340		CLR	ROW		:MAKE ROW ZERO
1150	004256	005067	176336		CLR	PCHRG		:MAKE PRECHARGE ZERO
1151	004262	012767	023420	176332	MOV	#10000.,	CYCNT	:SETUP CYCLE COUNT
1152	004270	012767	177777	176326	MOV	#-1,	TSTPAT	:SETUP TEST PATTERN
1153	004276	012767	177777	176322	MOV	#-1,	BCKGRD	:SETUP BACKGROUND
1154	004304	012767	000400	176320	MOV	#BIT08,	MSKBIT	:SETUP MASK
1155								
1156								
1157								
1158								
1159	004312	032737	010000	177570	BEGIN6: BIT	#SW12,2#SWR		:IS SWITCH 12 SET?
1160	004320	001013			BNE	1\$:IF SET BRANCH TO CHECK SW11
1161	004322	005167	176324		COM	PASFLG		:COMPLEMENT PASS FLAG
1162								:IS BOTH PICKUPS AND DROPS DONE
1163	004326	001037			BNE	3\$:IF YES BRANCH
1164	004330	005067	176272		CLR	BCKGRD		:IF NOT SETUP TO
1165	004334	005067	176264		CLR	TSTPAT		:CATCH
1166	004340	012767	177777	176372	MOV	#-1,	OUTSID	:BIT PICKS
1167	004346	000437			BR	4\$		
1168	004350	005067	176276		1\$: CLR	PASFLG		
1169	004354	032737	010000	177570	BIT	#SW12,2#SWR		:TEST SW12
1170	004362	001410			BEG	2\$:IF NOT SET BRANCH TO CATCH DROPS
1171	004364	005067	176236		CLR	BCKGRD		:IF NOT SET TO CATCH PICKUPS
1172	004370	005067	176230		CLR	TSTPAT		
1173	004374	012767	177777	176336	MOV	#-1,OUTSID		
1174	004402	000421			BR	4\$		
1175	004404	012767	177777	176212	2\$: MOV	#-1,	TSTPAT	
1176	004412	012767	177777	176206	MOV	#-1,	BCKGRD	
1177	004420	005067	176314		CLR	OUTSID		
1178	004424	000410			BR	4\$		
1179	004426	012767	177777	176170	3\$: MOV	#-1,	TSTPAT	
1180	004434	012767	177777	176164	MOV	#-1,	BCKGRD	
1181	004442	005067	176272		CLR	OUTSID		

```

1182 004446 005067 176066      4S:  CLR  $PASS      ;CLEAR PASS COUNT
1183
1184
1185
1186
1187      ;MAKE THE TEST ADDRESS AND THE INSTRUCTION ADDRESS
1188
1189
1190
1191
1192 004452 016746 176134      LOOP1:  MOV  MOD, -(SP)      ;PICKUP MODULE NUMBER
1193 004456 042716 017777      BIC  #17777,(SP)      ;STRIP AWAY ANY JUNK
1194 004462 016746 176126      MOV  COL, -(SP)      ;PICKUP COLUMN NUMBER
1195 004466 042716 160777      BIC  #1C17000,(SP)    ;STRIP AWAY JUNK
1196 004472 032767 020000 176114  BIT  #BIT13,COL      ;CHECK C4=1
1197 004500 001402      BEQ  IS              ;BR IF NO
1198 004502 052716 000002      BIS  #BIT01,(SP)      ;PUT C4 AT PROPER PLACE IN BUS ADDRESS
1199 004506 016746 176106      1S:  MOV  PCHRG, -(SP)    ;PICK UP PRECHARGE
1200 004512 042716 177763      BIC  #1C14,(SP)      ;STRIP JUNK
1201 004516 016746 176074      MOV  ROW, -(SP)      ;GET THE ROW NUMBER
1202 004522 042716 177017      BIC  #1C760,(SP)      ;STRIP THE JUNK IF ANY
1203 004526 012600      MOV  (SP)+,RO        ;FORM THE BUS ADDRESS WITH ROW
1204 004530 052600      BIS  (SP)+,RO        ;PRECHARGE
1205 004532 052600      BIS  (SP)+,RO        ;COLUMN
1206 004534 052600      BIS  (SP)+,RO        ;MODULE
1207 004536 010067 176042      MOV  RO, TSTADR      ;SAVE AS THE TEST ADDRESS
1208 004542 010067 176062      MOV  RO, INSTAD      ;AND AS THE INSTRUCTION ADDRESS
1209
1210
1211
1212      ;MOVE EITHER "0,-1,-1" OR THE "CLEAR RO"
1213      ;INTO THE LOCATION INSTR1: THIS WILL FINALLY BE THE TEST INSTRUCTION
1214
1215
1216
1217 004546 010700      LPERR:  MOV  PC, RO      ;THESE TWO INSTRUCTIONS
1218      ADD  #INSTR1--,RO    ;GETS THE LOCATION
1219 004550 062700 176154      ADD  #INSTR1--,RO    ;OF INSTR1 IN TO RO
1220      MOV  #SWR, SWITCH  ;EVEN AFTER RELOCATION
1221 004554 013767 177570 000160  MOV  #SWR, SWITCH  ;GET SWITCH SETTING
1222      BIC  #177577,      ;TO CHECK FOR
1223 004562 042767 177577 000152  SWITCH ;IF SW07=0 DO OUTSIDE
1224
1225      ;IF SW07=1 DO INSIDE
1226
1227 004570 001404      BEQ  IS              ;IF SW07=0 THEN BRANCH
1228
1229 004572 010701      MOV  PC, R1          ;SW7=1 SO SETUP TO
1230      ADD  #INSIDE--,R1  ;MOVE INSIDE INTO INSTR1
1231 004574 062701 176136      ADD  #INSIDE--,R1  ;MAKE INSIDE POSITION
1232      BR  ZS              ;INDEPENDANT
1233 004600 000403
1234
1235 004602 010701      1S:  MOV  PC, R1          ;SW07=0 SO SETUP TO
1236      ADD  #OUTSID--,R1  ;MOVE OUTSIDE INTO INSTR1
1237 004604 062701 176134      ADD  #OUTSID--,R1  ;MAKE OUTSIDE POSITION

```

```

1238                                     ; INDEPENDANT
1239 004610 012120 2S:  MOV  (R1)+, (R0)+ ; THESE THREE INSTRUCTIONS
1240                                     ;
1241 004612 012120      MOV  (R1)+, (R0)+ ; MOVES THE APPROPRIATE
1242                                     ;
1243 004614 012120      MOV  (R1)+, (R0)+ ; GROUP INTO INSTR1
1244                                     ;
1245 004616 105067 175732  CLRB  SERFLG ; CLEAR ERROR FLAG
1246                                     ;
1247                                     ;
1248                                     ;
1249                                     ;
1250                                     ;
1251                                     ;
1252                                     ;
1253                                     ;
1254                                     ;
1255                                     ;
1256                                     ;
1257                                     ;
1258                                     ;
1259                                     ;
1260                                     ;
1261                                     ;
1262                                     ;
1263                                     ;
1264                                     ;
1265                                     ;
1266                                     ;
1267 004642 016700 175736  LDPAT: MOV  TSTADR, R0 ; MOVE TEST ADDRESS
1268 004646 010001      MOV  R0, R1 ; DUPLICATE IT IN R1 TO BE REINSTATED AFTER ADDING COLUMN
1269 004650 042701 017003  BIC  #160774, R1 ; DON'T KEEP THE COL
1270 004654 016702 175734  MOV  COL, R2 ; PICK UP THE COL
1271 004660 012703 020002  MOV  #BIT13:BIT01, R3 ; GET READY TO TRANSFER BIT 13 TO BIT 1
1272 004664 016704 175734  MOV  TSTPAT, R4 ; MOVE TEST PATTERN=-1
1273 004670 062702 001000  1S:  ADD  #1000, R2 ; ADD ONE TO COLUMN
1274 004674 042702 040000  BIC  #BIT14, R2 ; IF IT WAS ALREADY 37 THEN ADDING ONE WILL GIVE BIT 14
1275 004700 010205      MOV  R2, R5 ; FORM AN ADDRESS
1276 004702 032705 020000  BIT  #BIT13, R5 ; POSITION C4 IF NEEDED
1277 004706 001401      BEQ  2S ; IF BIT 13 IS ZERO THEN BRANCH
1278 004710 074305      XOR  R3, R5 ; IF BIT 13=1 THEN TRANSFER TO BIT 1
1279 004712 050105 2S:  BIS  R1, R5 ; REINSTATE OTHER BITS AFTER ADDING TO COLUMN
1280 004714 010415      MOV  R4, (R5) ; STORE THE PATTERN
1281 004716 020005      CMP  R0, R5 ; TSTADR?
1282 004720 001363      BNE  1S ; BR IF NO
1283                                     ;
1284                                     ;
1285                                     ;
1286                                     ;
1287                                     ;
1288                                     ;
1289                                     ;
1290                                     ;
1291 004722 004767 000732  LOOP2: JSR  PC, LDINT
1292                                     ;
1293 004726 000431      BR   NEXT

```

;FILL 4K WITH BACKGROUND PATTERN
FILL4K:MOV BCKGRD, R0 ;GETTING READY TO MOVE
;BACKGROUND INTO 4K
MOV MOD, R1 ;STARTING FROM MODULE
;NUMBER
1S: MOV #10000, R2 ;10000=4K
MOV R0, (R1)+ ;FILL BACKGROUND
SOB R2, 1S ;REPEAT 4K TIMES
;THIS MOVES CONTENTS OF TEST PATTERN (TSTPAT)
;HERE = -1 INTO MOD AND ALL LOCATIONS GOT
;BY INCREASING COLUMN BY ONE TILL ONE 4K
;IS COMPLETE
LDPAT: MOV TSTADR, R0 ;MOVE TEST ADDRESS
MOV R0, R1 ;DUPLICATE IT IN R1 TO BE REINSTATED AFTER ADDING COLUMN
BIC #160774, R1 ;DON'T KEEP THE COL
MOV COL, R2 ;PICK UP THE COL
MOV #BIT13:BIT01, R3 ;GET READY TO TRANSFER BIT 13 TO BIT 1
MOV TSTPAT, R4 ;MOVE TEST PATTERN=-1
1S: ADD #1000, R2 ;ADD ONE TO COLUMN
BIC #BIT14, R2 ;IF IT WAS ALREADY 37 THEN ADDING ONE WILL GIVE BIT 14
MOV R2, R5 ;FORM AN ADDRESS
BIT #BIT13, R5 ;POSITION C4 IF NEEDED
BEQ 2S ;IF BIT 13 IS ZERO THEN BRANCH
XOR R3, R5 ;IF BIT 13=1 THEN TRANSFER TO BIT 1
2S: BIS R1, R5 ;REINSTATE OTHER BITS AFTER ADDING TO COLUMN
MOV R4, (R5) ;STORE THE PATTERN
CMP R0, R5 ;TSTADR?
BNE 1S ;BR IF NO
;THE FOLLOWING JSR LOADS INSRTUCTION (INSTR1) INTO
;PROPER PLACE
LOOP2: JSR PC, LDINT
BR NEXT

```

1294
1295 004730 011067 175700          MOV      (R0),  SV400
1296
1297 004734 016701 175662          MOV      CYCNT,  R1      ;DO TEST SEQ. THIS
1298                                ;MANY TIMES
1299 004740 005727          TST      (PC)+
1300 004742 000000          SWITCH: .WORD  0
1301 004744 001406          BEQ      1$
1302 004746 016746 175656          MOV      INSTAD, -(SP)   ;SETUP THE STARTING ADDRESS
1303 004752 011637 177570          MOV      (SP),  2$DISPLAY ;DISPLAY THE TEST ADDRESS
1304 004756 004736          JSR      PC, 2$(SP)+    ;GO TO THE TEST SEG.
1305 004760 000406          BR       3$
1306 004762 016702 175642          1$:     MOV      INSTAD, R2
1307 004766 010237 177570          MOV      R2, 2$DISPLAY
1308 004772 011210          2$:     MOV      (R2), (R0)
1309 004774 077102          SOB     R1, 2$
1310 004776 016710 175632          3$:     MOV      SV400, (R0)
1311
1312
1313                                ;CHECK THE 1K BLOCK
1314
1315
1316 005002 004767 001074          JSR      PC, CHECK      ;GO CHECK THE 1K BLOCK
1317 005006 000401          BR       NEXT          ;RETURN HERE ON ERROR
1318 005010 000744          BR       LOOP2
1319 005012 032737 000001 177570  NEXT:   BIT      #BIT00, 2$SWR   ;LOCK ON THIS PRECHARGE?
1320 005020 001007          BNE     1$            ;BR IF YES
1321 005022 062767 000004 175570          ADD     #4, PCHRG      ;GO TO NEXT PRECHARGE
1322 005030 042767 177763 175562          BIC     #14, PCHRG     ;GET RID OF TRASH
1323 005036 001205          BNE     LOOP1         ;LOOP IF MORE TO DO
1324 005040 032737 000002 177570  1$:     BIT      #BIT01, 2$SWR ;LOCK ON THIS MODULE?
1325 005046 001133          BNE     SEOP          ;BR IF YES
1326 005050 062767 020000 175534          ADD     #BIT13, MOD    ;INCREMENT THE MOD
1327 005056 103407          BCS     SEGMT         ;IF ADDING BIT13 MAKES 0
1328                                ;THEN BRANCH
1329 005060 026767 175526 175522          CMP     MOD, HILMT    ;DON'T LET IT GET TO BIG
1330 005066 103401          BLO     LOOP12
1331 005070 000402          BR       SEGMT        ;GO TO CHECK IF SEGMENTATION IS REQUIRED
1332 005072 000167 177354          LOOP12: JMP     LOOP1   ;RETURN
1333                                ;IS SEGMENTATION REQUIRED? IF SO TURN ON MEMORY
1334                                ;MANAGEMENT AND SETUP ALL REQUIRED REGISTERS
1335                                ;ONLY KERNEL MODE INSTRUCTION SPACE IS USED
1336
1337 005076 022767 001600 175556  SEGMT:  CMP     #1600,  HIBASE ;SEGMENTATION REQUIRED FOR HIGH LIMIT?
1338 005104 101114          BHI     SEOP          ;IF NO THEN BRANCH
1339 005106 022767 001600 175544          CMP     #1600,  LOBASE ;IF YES THEN TEST IF LOW LIMIT REQ SEGMENTATION?
1340 005114 101415          BLOS   SEGMT1        ;IF LOW LIMIT DOES REQ SEGMENTATION BRANCH
1341 005116 012767 001600 175534          MOV     #1600,  LOBASE ;IF NO MAKE LOW LIMIT END OF 32K
1342 005124 012767 140000 175454  SEGO:  MOV     #140000, LOLMT ;LOLMT LOOKS AT PAGE OR 6
1343 005132 012767 140000 175452          MOV     #140000, MOD  ;SAME WITH MODULE NUMBER
1344 005140 012767 157776 175442          MOV     #157776, HILMT ;HIGH LIMIT LOOKS AT PAGE END OF 4K
1345 005146 000420          BR     SEGMT2        ;BRANCH TO ENABLE SEGMENTATION
1346 005150 062767 000200 175502  SEGMT1: ADD     #200,  LOBASE ;DO NEXT 4K
1347 005156 012767 140000 175422  SEG10: MOV     #140000, LOLMT ;MAKE LOW LIMIT AND MODULE
1348 005164 012767 140000 175420          MOV     #140000, MOD  ;0 ON PAGE "PAGE OR 6"
1349 005172 012767 157776 175410          MOV     #157776, HILMT ;HIGH LIMIT SAME 4K ON PAGE

```

1350	005200	026767	175456	175452		CMP	HIBASE, LOBASE	; IS IT THE END?
1351	005206	103453				BLO	\$EOP	; IF YES BRANCH
1352	005210	016777	175444	175450	SEGMT2:	MOV	LOBASE, @PAGE	; SET LOW LIMIT ON PAGE 4
1353	005216	005077	172666			CLR	@SR3	; USE ONLY I SPACE IN KERNAL
1354	005222	012700	077406			MOV	#77406, RO	; MOVE INTO RO
1355	005226	010077	172660			MOV	RO, @KIPDR0	; SEGMENT DESCRIPTOR
1356	005232	010077	172656			MOV	RO, @KIPDR1	; REGISTER IS SET FOR
1357	005236	010077	172654			MOV	RO, @KIPDR2	; 128 BLOCKS WITH NO
1358	005242	010077	172652			MOV	RO, @KIPDR3	; SYSTEM TRAPS. THESE
1359	005246	010077	172650			MOV	RO, @KIPDR4	; REGISTERS ARE ALSO
1360	005252	010077	172646			MOV	RO, @KIPDR5	; CALLED PAGE
1361	005256	010077	172644			MOV	RO, @KIPDR6	; DESCRIPTOR REGISTERS
1362	005262	010077	172642			MOV	RO, @KIPDR7	; ONLY PAGE 0 AND 4 IS USED
1363	005266	005077	172640			CLR	@KIPDR0	; MAKE PAGE ADDRESS 0=0
1364	005272	012777	000001	172602		MOV	#1, @SR0	; ENABLE SEGMENTATION
1365	005300	032737	010000	177570		BIT	#SW12, @SWR	; TEST SWITCH 12
1366	005306	00'J03				BNE	2\$; BRANCH IF SET
1367	005310	CW5167	175336			COM	PASFLG	; SW12 NOT SET IE. DO BOTH
1368	005314	000402				BR	3\$; SO COMPLEMENT AND RESTART
1369	005316	005067	175330		2\$:	CLR	PASFLG	; SW12 SET IE. DO ONE SO RESTART
1370	005322	000167	176764		3\$:	JMP	BEGIN6	

```

:*****
:END OF PASS ROUTINE
:INCREMENT THE PASS NUMBER
:IF SW10=0 PRINT END PASS ON END OF PROGRAM
:IF THERE IS A MONITOR GO TO IT.
:IF NONE JUMP TO BEGIN3
:IF LIMITS ARE NOT CHOSEN AND ALL OF MEMORY
:IS TO BE TESTED THIS RELOCATES PROGRAM FROM
:FIRST 4K TO SECOND 4K AND SETS UP FOR
:TESTING THE FIRST 4K. THEN RELOCATES
:TO FIRST 4K TO BE ABLE TO START AGAIN.

```

1388	005326	024042			BEG2:	20000+BEGIN2		
1389	005330	007736			LENGTH:	7736		
1390	005332	000100			FROM:	FIRST		
1391	005334	020100			TO:	20000 + FIRST		
1392								
1393								
1394								
1395	005336	005767	175312		\$EOP:	TST	SELF	; WAS SELF STARTING USED
1396	005342	001523				BEQ	\$EOP1	; IF NOT IE. LIMITS WERE CHOSEN THEN BRANCH
1397								; HAS ENTRY INTO THIS SECTION BEEN MADE?
1398								; IF YES IE. THIS IS SECOND TIME THEN BRANCH
1399	005344	005767	173752			TST	\$KT11	
1400	005350	100005				BPL	5\$	
1401	005352	005077	172524			CLR	@SR0	
1402	005356	000240				NOP		
1403	005360	000240				NOP		
1404	005362	000240				NOP		
1405	005364	016700	177740		5\$:	MOV	LENGTH, RO	; IF NOT IE. FIRST TIME OR THIRD TIME

1406	005370	016701	177736			MOV	FROM, R1	:GETTING READY TO RELOCATE
1407	005374	016702	177734			MOV	TO, R2	:GETTING READY TO RELOCATE
1408	005400	012767	000000	175474		MOV	#0, STBANK	:FILL IN TYPED INFORMATION
1409	005406	012767	000001	175510		MOV	#1, BANKS	:ABOUT STARTING ADDRESSES
1410	005414	005067	175166			CLR	LOLMT	:SETUP LIMITS
1411	005420	005067	175166			CLR	MOD	:MODULE
1412	005424	012767	017775	175156		MOV	#17776, HILMT	:AND HIGH
1413	005432	012122			1\$:	MOV	(R1)+, (R2)+	:FROM INTO TO
1414	005434	077002				SOB	RO, 1\$:REPEAT
1415	005436	005167	175214			COM	REDONE	:BEEN THROUGH ONCE?
1416	005442	016705	175210			MOV	REDONE, R5	:
1417	005446	001401				BEQ	2\$:BRANCH IF SECOND TIME THROUGH
1418	005450	000433				BR	3\$:FIRST TIME GO TO 3\$
1419	005452	012737	000001	003102	2\$:	MOV	#1, @#STBANK	
1420	005460	016737	175200	003124		MOV	LSTBK, @#BANKS	
1421	005466	012706	001100			MOV	#1100, SP	
1422	005472	000240				NOP		
1423	005474	010537	002656			MOV	R5, @#REDONE	
1424	005500	012737	000100	005332		MOV	#FIRST, @#FROM	
1425	005506	012737	020100	005334		MOV	#20000+FIRST, @#TO	
1426	005514	000240				NOP		
1427	005516	000240				NOP		
1428	005520	000240				NOP		
1429	005522	000240				NOP		
1430	005524	000240				NOP		
1431	005526	000240				NOP		
1432	005530	000137	005612			JMP	@#SEOP1	
1433	005534	000137	004102		4\$: 3\$:	JMP	@#BEGIN3	
1434	005540							
1435	005540	012706	021100			MOV	#21100, SP	
1436	005544	010537	022656			MOV	R5, @#20000+REDONE	
1437	005550	012701	005332			MOV	#FROM, R1	:
1438	005554	012702	005334			MOV	#TO, R2	:
1439	005560	062701	020000			ADD	#20000, R1	:
1440	005564	062702	020000			ADD	#20000, R2	:
1441	005570	016703	177536			MOV	FROM, R3	:
1442	005574	016711	177534			MOV	TO, (R1)	:
1443	005600	010312				MOV	R3, (R2)	:
1444	005602	005137	022652			COM	@#20000+PASFLG	:
1445	005606	000137	024312			JMP	@#BEGIN6+20000	:
1446								
1447	005612	005767	175034		SEOP1:	TST	PASFLG	:
1448	005616	001011				BNE	SEOP3	:
1449	005620	005267	174714		SEOP2:	INC	\$PASS	: INCREMENT PASS COUNT
1450	005624	032737	002000	177570		BIT	#SW10, @#SWR	: TYPE END PASS?
1451	005632	001003				BNE	SEOP3	:
1452	005634	004767	001400			JSR	PC, TYPE	:
1453	005640	010335				EPASS		:
1454	005642	005767	173454		SEOP3:	TST	SKT11	:
1455	005646	100002				BPL	1\$:
1456	005650	005077	172226			CLR	@SRO	:
1457	005654	000167	176222		1\$:	JMP	BEGIN3	:
1458								
1459								
1460								
1461								

1462	005660					LDINT:	MOV	R2, -(SP)	; PUSH R2 ON STACK
1463	005660	010246					MOV	R3, -(SP)	; PUSH R3 ON STACK
1464	005662	010346					MOV	INSTAD, R0	; GET THE INSTRUCTION ADDRESS
1465	005664	016700	174740			1S:	BIC	#1C760, R0	; KEEP ROW
1466	005670	042700	177017				CMP	R0, ROW	; AT THE TEST ROW?
1467	005674	020067	174716				BEQ	4S	; BR IF YES
1468	005700	001412					MOV	INSTAD, -(SP)	
1469	005702	016746	174722				MOV	BCKGRD, 2(SP)	; RESTORE BACK GROUND
1470	005706	016776	174714	000000			ADD	#2, (SP)	
1471	005714	062716	000002				MOV	SVIN2, 2(SP)+	
1472	005720	016736	174714				BR	5S	
1473	005724	000403					MOV	TSTPAT, 2INSTAD	
1474	005726	016777	174672	174674	4S:		MOV	TSTPAT, 2TSTADR	; STORE THE TEST PATTERN
1475	005734	016777	174664	174642	5S:		MOV	INSTAD, R0	; GET THE INSTRUCTIONS ADDRESS
1476	005742	016700	174662				JSR	PC, FORMAD	; GO FORM NEXT INSTUCTION ADDRESS
1477	005746	004767	000600		2S:		MOV	R0, R3	; CHECK FOR OUT OF RANGE
1478	005757	010003					MOV	TSTADR, R2	; PICKUP THE TSTADR FOR CHECKING
1479	005754	016702	174624				CMP	R3, R2	; IS INSTR. ADDRESS = TEST ADDRESS?
1480	005760	020302					BEQ	3S	; BR IF YES
1481	005762	001443					ADD	#2, R3	; ADDRESS WHERE INSTR2 GOES
1482	005764	062703	000002				CMP	R3, R2	; IS IT THE SAME AS TSTADR
1483	005770	020302					BEQ	3S	; BR IF YES
1484	005772	001437					ADD	#2, R3	; INSTR3'S ADDRESS
1485	005774	062703	000002				CMP	R3, R2	; SAME AS TSTADR?
1486	006000	020302					BEQ	3S	; BR IF YES
1487	006002	001433					CMP	R3, HILMT	; WILL IT GO OFF THE END?
1488	006004	020367	174600				BHI	2S	; BR IF YES
1489	006010	101356					MOV	R0, INSTAD	; SAVE NEW ADDRESS
1490	006012	010067	174612				MOV	(R0), SVIN1	; SAVE WHATS AT THE 1ST TWO
1491	006016	011067	174614				MOV	2(R0), SVIN2	; TEST INSTRUCTIONS ADDRESSES
1492	006022	016067	000002	174610			MOV	INSTR1, (R0)	; LOAD THE INSTRUCTIONS
1493	006030	016710	174670				MOV	INSTR2, 2(R0)	
1494	006034	016760	174666	000002			MOV	INSTR3, 4(R0)	
1495	006042	016760	174662	000004			MOV	MSKBIT, -(SP)	; PICKUP THE MASK BIT
1496	006050	016746	174556				XOR	R0, (SP)	; HALF ADD TO THE ADDRESS
1497	006054	074016					MOV	(SP)+, R0	; GET THE ADDRESS TO BE WRITTEN INTO
1498	006056	012600					CMP	R0, R2	; IS IT THE SAME AS THE TEST ADDRESS?
1499	006060	020002					BEQ	1S	; BR IF YES
1500	006062	001700					ADD	#2, 4(SP)	; ADJUST THE RETURN ADDRESS
1501	006064	062766	000002	000004			MOV	(SP)+, R3	; POP STACK INTO R3
1502	006072				3S:		MOV	(SP)+, R2	; POP STACK INTO R2
1503	006072	012603					RTS	PC	; GO BACK
1504	006074	012602							
1505	006076	000207							
1506									
1507									
1508									
1509	006100	000000				TCOL:	0		
1510									
1511	006102	010246				CHECK:	MOV	R2, -(SP)	; PUSH R2 ON STACK
1512	006104	010346					MOV	R3, -(SP)	; PUSH R3 ON STACK
1513	006106	010446					MOV	R4, -(SP)	; PUSH R4 ON STACK
1514	006110	010546					MOV	R5, -(SP)	; PUSH R5 ON STACK
1515	006112	016701	174466				MOV	TSTADR, R1	
1516	006116	016702	174506				MOV	INSTAD, R2	; ADDRESS OF THE TEST INSTR1
1517	006122	010200					MOV	R2, R0	

1518	006124	010203			MOV	R2,R3		
1519	006126	062703	000002		ADD	#2,R3		;ADDRESS OF THE TEST INSTR2
1520	006132	010004			MOV	RO,R4		;USED TO KEEP TRACK OF THE TEST ROW
1521	006134	042704	177017		BIC	#1C760,R4		
1522	006140	010067	177734		MOV	RO,TCOL		;USED TO KEEP TRACK OF THE TEST COL
1523	006144	042767	160775	177726	BIC	#1C17002,TCOL		
1524	006152	010746			MOV	PC,-(SP)		;SETUP THE ESCAPE ON ERROR ADDRESS
1525	006154	062716	000352		ADD	#CHK1-(SP)		;MAKE IT POSITION INDEPENDANT
1526	006160	012667	174456		MOV	(SP)+,ESCAPE		
1527	006164	000407			BR	1\$		
1528								
1529	006166	042700	017762	8\$:	BIC	#17762,RO		;FORM ADDRESS
1530	006172	050400			BIS	R4,RO		;GET THE ROW
1531	006174	056700	177700		BIS	TCOL,RO		;AND THE COLUMN
1532	006200	020002			CMP	RO,R2		;IS THIS THE INSTRUCTION ADDRESS?
1533	006202	001551			BEQ	CHK1		;BR IF YES
1534								
1535	006204	011005		1\$:	MOV	(RO)R5		;PICK UP THE DATA
1536	006206	020001			CMP	RO,R1		;AT TSTADR?
1537	006210	001016			BNE	2\$;BR IF NO
1538								
1539	006212	020567	174406		CMP	R5,TSTPAT		;DID THE TSTPAT UNDER TEST CHANGE?
1540	006216	001515			BEQ	7\$;BR IF NO
1541	006220	010567	174350		MOV	R5,\$BDDAT		
1542	006224	016767	174374	174340	MOV	TSTPAT,\$GDDAT		
1543	006232	010067	174332		MOV	RO,\$BDADR		
1544	006236	004767	000352		JSR	PC,\$HLT		
1545	006242	000001			1			
1546	006244	000502			BR	7\$		
1547								
1548	006246	020002		2\$:	CMP	RO,R2		;AT INSTAD
1549	006250	001020			BNE	4\$;BR IF NO
1550	006252	020567	174446		CMP	R5,INSTR1		;DID INSTR1 UNDER TEST CHANGE?
1551	006256	001412			BEQ	3\$;BR IF NO
1552	006260	010567	174310		MOV	R5,\$BDDAT		
1553	006264	016767	174434	174300	MOV	INSTR1,\$GDDAT		
1554	006272	010067	174272		MOV	RO,\$BDADR		
1555	006276	004767	000312		JSR	PC,\$HLT		
1556	006302	000002			2			
1557	006304	016710	174326	3\$:	MOV	SVIN1,(RO)		;RESTORE THIS LOCATION
1558	006310	000460			BR	7\$		
1559								
1560	006312	020003		4\$:	CMP	RO,R3		;AT THE 2ND INSTRUCTION
1561	006314	001020			BNE	6\$;BR IF NO
1562	006316	020567	174404		CMP	R5,INSTR2		;DID IT CHANGE?
1563	006322	001412			BEQ	5\$;BR IF NO
1564	006324	010567	174244		MOV	R5,\$BDDAT		
1565	006330	016767	174372	174234	MOV	INSTR2,\$GDDAT		
1566	006336	010067	174226		MOV	RO,\$BDADR		
1567	006342	004767	000246		JSR	PC,\$HLT		
1568	006346	000002			2			
1569	006350	016710	174264	5\$:	MOV	SVIN2,(RO)		;RESTORE THIS INSTRUCTION
1570	006354	000436			BR	7\$		
1571	006356	026704	174234	6\$:	CMP	ROW,R4		;ON THE SAME ROW AS TSTADR?
1572	006362	001016			BNE	10\$		
1573	006364	026705	174234		CMP	TSTPAT,R5		;DID THE PATTERN CHANGE?

```

1574 006370 001430          BEQ      7$
1575 006372 010567 174176    MOV      R5,$BDDAT
1576 006376 016767 174222 174166    MOV      TSTPAT,$GDDAT
1577 006404 010067 174160    MOV      R0,$BDADR
1578 006410 004767 000200    JSR      PC,$HLT
1579 006414 000001          1
1580 006416 000415          BR       7$
1581 006420 020567 174202    10$:    CMP      R5,BCKGRD          ;DID BACK GROUND CHANGE
1582 006424 001412          BEQ      7$          ;BR IF NO
1583 006426 010567 174142    MOV      R5,$BDDAT
1584 006432 016767 174170 174132    MOV      BCKGRD,$GDDAT
1585 006440 010067 174124    MOV      R0,$BDADR
1586 006444 004767 000144    JSR      PC,$HLT
1587 006450 000003          3
1588
1589 006452 062704 000020    7$:     ADD      #20,R4          ;GO TO THE NEXT ROW
1590 006456 042704 177017    BIC      #1C760,R4      ;DON'T LET IT GET TO BIG
1591 006462 001241          BNE      8$          ;GO DO NEXT ROW IF NOT TIME FOR A NEW COL
1592
1593 006464 062767 001000 177406 11$:    ADD      #1000,TCOL      ;GO TO THE NEXT COL
1594 006472 042767 140775 177400    BIC      #1C37002,TCOL  ;DON'T LET IT GET TO BIG
1595 006500 032767 020000 177372    BIT      #BIT13,TCOL
1596 006506 001627          BEQ      8$          ;IF MORE TO DO GO DO IT
1597 006510 010146          MOV      R1,-(SP)
1598 006512 012701 020002    MOV      #BIT13!BIT01,R1
1599 006516 074167 177356    XOR      R1,TCOL
1600 006522 012601          MOV      (SP)+,R1
1601 006524 000620          BR       8$
1602
1603 006526 012605          CHK1:   MOV      (SP)+,R5      ;POP STACK INTO R5
1604 006530 012604          MOV      (SP)+,R4      ;POP STACK INTO R4
1605 006532 012603          MOV      (SP)+,R3      ;POP STACK INTO R3
1606 006534 012602          MOV      (SP)+,R2      ;POP STACK INTO R2
1607 006536 105767 174012    TSTB    $ERFLG         ;WAS THERE ANY ERRORS?
1608 006542 001002          BNE      EXIT         ;IF YES EXIT
1609 006544 062716 000002    EXIT:   ADD      #2,(SP)  ;SET FOR NO ERRORS EXIT
1610 006550 000207          RTS      PC
1611
1612
1613
1614
1615 006552 010046          FORMAD: MOV      R0,-(SP)      ;SAVE R0
1616 006554 042700 160015    BIC      #1C17762,R0    ;STRIP EVERYTHING BUT THE ROW AND COL
1617 006560 062700 000020    ADD      #20,R0        ;ADD A ROW
1618 006564 032700 020000    BIT      #BIT13,R0     ;C4
1619 006570 001405          BEQ      1$          ;BR IF NO
1620 006572 010146          MOV      R1,-(SP)
1621 006574 012701 020002    MOV      #BIT13!BIT01,R1
1622 006600 074100          XOR      R1,R0
1623 006602 012601          MOV      (SP)+,R1
1624 006604 042716 017762    1$:     BIC      #17762,(SP)   ;STRIP THE ROW AND COL
1625 006610 052600          BIS      (SP)+,R0     ;FORM ADDRESS
1626 006612 000207          RTS      PC
1627
1628
1629
;*****

```

```

1630                                     ; THIS ROUTINE IS THE HLT HANDLER
1631                                     ; SW10=1 BELL ON ERROR
1632                                     ; SW13=1 INHIBIT ERROR TYPEOUTS
1633                                     ; SW15=1 HALT ON ERROR
1634                                     ; GO TO TYPERR ON ERROR
1635 006614                                $HLT:
1636 006614 032737 002000 177570          BIT      #SW10, @#SWR          ; BELL ON ERROR?
1637 006622 001403                        BEQ      1$                    ; NO - SKIP
1638 006624 004767 000410                  JSR      PC, TYPE
1639 006630 002644                        $BELL
1640 006632 005267 173714                  1$: INC      $ERTTL          ; COUNT THE NUMBER OF ERRORS
1641 006636 001775                        BEQ      1$                    ; INSURE SERTTL NOT=0
1642 006640 032737 020000 177570          BIT      #SW13, @#SWR          ; SKIP TYPEOUT IF SET
1643 006646 001015                        BNE      2$                    ; SKIP TYPEOUTS
1644 006650 011667 173710                  MOV      (SP), $HLTAD         ; GET ADDRESS OF HLT INSTRUCTION
1645 006654 117767 173704 173700          MOVB     @$HLTAD, $ITEMB      ; SAVE THE ERROR ITEM CODE
1646 006662 162767 000002 173674          SUB      #2, $HLTAD
1647 006670 004767 000046                  JSR      PC, TYPERR          ; GO TO USER ERROR ROUTINE
1648 006674 004767 000340                  JSR      PC, TYPE
1649 006700 002647                        $CRLF
1650 006702 005737 177570                  2$: TST      @#SWR
1651 006706 100001                        BPL      3$
1652 006710 000000                        HALT
1653 006712 112767 177777 173634          3$: MOVB     #-1, $ERFLG
1654 006720 062716 000002                  ADD      #2, (SP)
1655 006724 032737 001000 177570          BIT      #BIT09, @#SWR
1656 006732 001002                        BNE      4$
1657 006734 016716 173702                  MOV      ESCAPE, (SP)
1658 006740 000207                        4$: RTS      PC
1659
1660 006742 010046                        TYPERR: MOV     RO, -(SP)          ; PUSH RO ON STACK
1661 006744 010146                        MOV     R1, -(SP)          ; PUSH R1 ON STACK
1662 006746 116700 173610                  MOVB    $ITEMB, RO         ; PICKUP THE ITEM NUMBER
1663 006752 005300                        DEC     RO                 ; FORM AN INDEX FOR THE TABLE
1664 006754 006300                        ASL    RO
1665 006756 006300                        ASL    RO
1666 006760 006300                        ASL    RO
1667 006762 010746                        MOV     PC, -(SP)
1668 006764 062716 173710                  ADD     #$ERRTB--, (SP)
1669 006770 062600                        ADD     (SP)+, RO
1670 006772 012067 000012                  MOV     (RO)+, 1$
1671 006776 004767 000236                  JSR     PC, TYPE          ; PICKUP THE ERROR MESSAGE
1672 007002 002647                        $CRLF
1673 007004 004767 000230                  JSR     PC, TYPE
1674
1675 007010 000000                        1$: 0
1676 007012 012067 000014                  MOV     (RO)+, 2$
1677 007016 032737 000400 177570          BIT     #BIT08, @#SWR
1678 007024 001003                        BNE     11$
1679 007026 004767 000206                  JSR     PC, TYPE
1680 007032 000000                        2$: 0
1681 007034 012001                        11$: MOV     (RO)+, R1
1682 007036 011000                        MOV     (RO), RO
1683 007040 010746                        MOV     PC, -(SP)
1684 007042 062716 170736                  ADD     #-, (SP)
1685 007046 061600                        ADD     (SP), RO

```

```

1686 007050 062601          ADD      (SP)+, R1
1687 007052 016767 173552 173516  MOV      INSTAD, $TMP0      ;SETUP THE COLUMN FOR TYPING
1688 007060 000367 173512          SWAB     $TMP0
1689 007064 006267 173506          ASR      $TMP0
1690 007070 042767 177740 173500  BIC      #+C37, $TMP0
1691 007076 016767 173526 173474  MOV      INSTAD, $TMP1      ;SET THE RCW FOR TYPING
1692 007104 006267 173470          ASR      $TMP1
1693 007110 006267 173464          ASR      $TMP1
1694 007114 006267 173460          ASR      $TMP1
1695 007120 006267 173454          ASR      $TMP1
1696 007124 042767 177740 173446  BIC      #+C37, $TMP1
1697 007132 016767 173472 173442  MOV      INSTAD, $TMP2      ;SETUP PRECHARGE FOR TYPING
1698 007140 006267 173436          ASR      $TMP2
1699 007144 006267 173432          ASR      $TMP2
1700 007150 042767 177774 173424  BIC      #+C3, $TMP2
1701 007156 000410          BR       5$
1702 007160 005711          10$:    TST      (R1)              ;TERMINATOR?
1703 007162 001003          BNE     3$              ;BR IF NO
1704 007164 012601          MOV      (SP)+, R1        ;POP STACK INTO R1
1705 007166 012600          MOV      (SP)+, R0        ;POP STACK INTO R0
1706 007170 000207          RTS     PC
1707 007172 004067 000074          3$:    JSR      RO, $SPACE      ;GO TYPE SOME SPACES
1708 007176 000000          4$:    .WORD   0              ;HOW MANY GOES HERE
1709 007200 112067 000030          5$:    MOVB    (RO)+, 6$        ;PICKUP NUMBER OF DIGITS TO TYPE
1710 007204 112067 000025          MOVB    (RO)+, 7$        ;PICKUP THE LEADING ZEROS FLAG
1711 007210 112067 177762          MOVB    (RO)+, 4$        ;PICKUP THE NUMBER OF SPACES
1712 007214 012146          MOV      (R1)+, -(SP)    ;PICKUP THE DATA
1713 007216 010746          MOV      PC, -(SP)
1714 007220 062716 170560          ADD     #-, (SP)
1715 007224 062616          ADD     (SP)+, (SP)
1716 007226 013646          MOV     @2(SP)+, -(SP)
1717 007230 004067 000064          JSR     RO, $B20CT      ;GO TYPE AN OCTAL DIGIT
1718 007234          6$:    .BYTE   0              ;HOW MANY DIGITS
1719 007235          7$:    .BYTE   0              ;LEADING ZERO SWITCH
1720 007236 000750          BR      10$            ;LOOP
1721
1722 ;*****
1723 ;THIS IS A SMALL ROUTINE USED TO MAKE THE TYPE POINTERS POSITION INDEPENT
1724
1725 TYPE:  MOV     PC, -(SP)      ;GET THE POINTER
1726 007240 010746          ADD     #-, (SP)        ;GET THE PC
1727 007242 062716 170536          ADD     @2(SP), (SP)    ;STRIP THE RELATIVE ADDRESS
1728 007246 067616 000002          MOV     (SP)+, 1$      ;AND SAVE IT FOR TYPE OUT
1729 007252 012667 000004          JSR     PC, $TYPE      ;GO TYPE TO
1730 007256 004767 171626          1$:    .WORD   0          ;POINTER TO MESSAGE
1731 007262 000000          ADD     #2, (SP)        ;SETUP TO RETURN
1732 007264 062716 000002          RTS     PC              ;GO BACK
1733 007270 000207
1734
1735 ;*****
1736 ;ROUTINE TO TYPE SPACES ON THE TTY
1737 ;CALL:
1738          JSR     RO, $SPACE
1739          NUMBER OF SPACES
1740          RETURN HERE
1741

```

```

1742 007272 012067 000002    $SPACE: MOV    (RO)+,2$    ;GET NUMBER OF SPACES DESIRED
1743                                ;AND SET RETURN ADR.
1744 007276 005327    1$:    DEC    (PC)+    ;FINISHED?
1745 007300 000000    2$:    0
1746 007302 002001    ;BGE    3$    ;BR IF NO
1747 007304 000200    ;RTS    RO    ;GO HOME
1748 007306    3$:
1749 007306 004767 177726    ;JSR    PC,TYPE
1750 007312 007316    ;4$:    .BYTE 4$
1751 007314 000770    ;BR     1$
1752 007316 040 000    4$:    .BYTE 40,0    ;STORAGE FOR ONE SPACE AND TERMINATOR
1753                                ;*****
1754                                ;BINARY TO OCTAL (ASCII) AND TYPE
1755                                ;$B2OCT---ENTER HERE TO SETUP SUPPRESS ZEROS AND NUMBER OF DIGITS TO TYPE
1756                                ;CALL:
1757                                ;MOV    NUM, -(SP)    ;NUMBER TO BE TYPED
1758                                ;JSR    RO, $B2OCT    ;CALL FOR TYPEOUT
1759                                ;.BYTE N    ;N=1 TO 6 FOR NUMBER OF DIGITS TO TYPE
1760                                ;.BYTE M    ;M=0 TO 3
1761                                ;0=SUPPRESS LEADING ZEROS
1762                                ;1=TYPE LEADING ZEROS
1763                                ;2=SUPPRESS LEADING ZEROS
1764                                ;WITH PHYSICAL ADDRESS
1765                                ;3=TYPE LEADING ZEROS
1766                                ;WITH PHYSICAL ADDRESS
1767
1768                                ;$B201----ENTER HERE TO TYPE OUT WITH THE SAME PARAMETERS AS THE LAST $BSOCT OR $B2016
1769                                ;CALL:
1770                                ;MOV    NUM, -(SP)
1771                                ;JSR    RO, $B201
1772
1773                                ;$B2016---ENTER HERE FOR TYPEOUT OF A 16 BIT NUMBER
1774                                ;CALL:
1775                                ;MOV    NUM, -(SP)
1776                                ;JSR    RO, $B2016
1777
1778 007320 112067 000267    $B2OCT: MOVB   (RO)+, $OMODE+1    ;PICKUP THE NUMBER OF DIGITS TO TYPE
1779 007324 112067 000261    ;MOVB   (RO)+, $OFILL    ;GET THE ZERO FILL SWITCH
1780 007330 000406    ;BR     $B201
1781 007332 112767 000001 000251    $B2016: MOVB   #1, $OFILL    ;SET THE ZERO FILL SWITCH
1782 007340 112767 000006 000245    ;MOVB   #6, $OMODE+1    ;SET FOR SIX(6) DIGITS
1783 007346 112767 000005 000234    $B201:  MOVB   #5, $OCNT    ;SET THE ITERATION COUNT
1784 007354 010346    ;MOV    R3, -(SP)    ;SAVE R3
1785 007356 010446    ;MOV    R4, -(SP)    ;SAVE R4
1786 007360 010546    ;MOV    R5, -(SP)    ;SAVE R5
1787 007362 116704 000225    ;MOVB   $OMODE+1, R4    ;GET THE NUMBER OF DIGITS TO TYPE
1788 007366 005404    ;NEG    R4
1789 007370 062704 000006    ;ADD    #6, R4    ;SUBTRACT IT FOR MAX. ALLOWED
1790 007374 110467 000212    ;MOVB   R4, $OMODE    ;SAVE IT FOR USE
1791 007400 116704 000205    ;MOVB   $OFILL, R4    ;GET THE ZERO FILL SWITCH
1792 007404 042704 177776    ;BIC    #177776, R4
1793 007410 016605 000010    ;MOV    10(SP), R5    ;PICKUP THE INPUT NUMBER
1794 007414 005003    ;CLR    R3    ;CLEAR THE OUTPUT WORD
1795 007416 132767 000002 000165    ;BITB   #2, $OFILL
1796 007424 001424    ;BEQ    1$
1797 007426 005767 171670    ;TST    $K111

```

1798	007432	100021		BPL	1\$	
1799	007434	032777	000001 170440	BIT	#1,2SRO	
1800	007442	001415		BEQ	1\$	
1801	007444	017746	173216	MOV	2PAGE, -(SP)	
1802	007450	042705	160000	BIC	#160000, R5	
1803	007454	006316		ASL	(SP)	
1804	007456	006316		ASL	(SP)	
1805	007460	006316		ASL	(SP)	
1806	007462	006316		ASL	(SP)	
1807	007464	006316		ASL	(SP)	
1808	007466	006103		ROL	R3	
1809	007470	006316		ASL	(SP)	
1810	007472	006103		ROL	R3	
1811	007474	062605		ADD	(SP)+, R5	
1812	007476	006105	1\$:	ROL	R5	; ROTATE MSB INTO "C"
1813	007500	000404		BR	3\$; GO DO MSE
1814	007502	006105	2\$:	ROL	R5	; FORM THIS DIGIT
1815	007504	006105		ROL	R5	
1816	007506	006105		ROL	R5	
1817	007510	010503		MOV	R5, R3	
1818	007512	006103	3\$:	ROL	R3	; GET LSB OF THIS DIGIT
1819	007514	105367	000072	DECB	\$OMODE	; TYPE THIS DIGIT?
1820	007520	100017		BPL	7\$; BR IF NO
1821	007522	042703	177770	BIC	#177770, R3	; GET RID OF JUNK
1822	007526	001002		BNE	4\$; TEST FOR 0
1823	007530	005704		TST	R4	; SUPPRESS THIS 0?
1824	007532	001403		BEQ	5\$; BR IF YES
1825	007534	005204	4\$:	INC	R4	; DON'T SUPPRESS ANYMORE 0'S
1826	007536	052703	000060	BIS	#'0, R3	; MAKE THIS DIGIT ASCII
1827	007542	052703	000040	BIS	#', R3	; MAKE ASCII IF NOT ALREADY
1828	007546	110367	000034	MOV	R3, 8\$; SAVE FOR TYPING
1829	007552	004767	177462	JSR	PC, TYPE	
1830	007556	007606		8\$		
1831	007560	105367	000024	7\$:	DECB	\$OCNT
1832	007564	003346		BGT	2\$; COUNT BY 1
1833	007566	002402		BLT	6\$; BR IF MORE TO DO
1834	007570	005204		INC	R4	; BR IF DONE
1835	007572	000743		BR	2\$; INSURE LAST DIGIT ISN'T A BLANK
1836	007574	012605	6\$:	MOV	(SP)+, R5	; GO DO THE LAST DIGIT
1837	007576	012604		MOV	(SP)+, R4	; RESTORE R5
1838	007600	012603		MOV	(SP)+, R3	; RESTORE R4
1839	007602	012616		MOV	(SP)+, (SP)	; RESTORE R3
1840	007604	000200		RTS	RO	; SET THE STACK FOR RETURNING
1841	007606	000	8\$:	.BYTE	0	; RETURN
1842	007607	000		.BYTE	0	; STORAGE FOR ASCII DIGIT
1843	007610	000	\$OCNT:	.BYTE	0	; TERMINATOR FOR TYPE ROUTINE
1844	007611	000	\$OFILL:	.BYTE	0	; OCTAL DIGIT COUNTER
1845	007612	000000	\$OMODE:	0		; ZERO FILL SWITCH
						; NUMBER OF DIGITS TO TYPE

1846
1847
1848
1849
1850
1851 007614 042524 052123 050040
1852 007622 052101 042524 047122
1853 007630 005015 000
1854 007633 111 051516 051124
1855 007640 041525 044524 047117
1856 007646 041440 040510 043516
1857 007654 042105 005015 000
1858 007661 102 041501 020113
1859 007666 051107 052517 042116
1860 007674 041440 040510 043516
1861 007702 042105 005015 000
1862 007707 105 051122 051117
1863 007714 020040 043040 044501
1864 007722 044514 043516 005015
1865 007730 041520 020040 020040
1866 007736 020040 042101 051104
1867 007744 051505 020123 054105
1868 007752 042520 052103 020040
1869 007760 041522 023526 020104
1870 007766 020040 047503 020114
1871 007774 051040 053517 020040
1872 010002 051120 041505 040510
1873 010010 043522 006505 000012
1874 010016 051105 047522 020122
1875 010024 020040 047111 052123
1876 010032 020040 020040 054105
1877 010040 042520 052103 020040
1878 010046 041522 023526 006504
1879 010054 012
1880 010055 120 020103 020040
1881 010062 020040 040440 042104
1882 010070 042522 051523 042040
1883 010076 052101 020101 020040
1884 010104 042040 052101 020101
1885 010112 020040 041440 046117
1886 010120 020040 047522 020127
1887 010126 050040 042522 044103
1888 010134 051101 042507 005015
1889 010142 000
1890 010143 105 051122 051117
1891 010150 020040 041040 045503
1892 010156 051107 020104 042440
1893 010164 050130 041505 020124
1894 010172 051040 053103 042047
1895 010200 005015
1896 010202 041520 020040 020040
1897 010210 020040 042101 051104
1898 010216 051505 020123 040504
1899 010224 040524 020040 020040
1900 010232 040504 040524 020040
1901 010240 020040 047503 020114

```

:*****
:*****
:ASCII MESSAGES
EM1:  .ASCIZ  /TEST PATTERN/<15><12>
EM2:  .ASCIZ  /INSTRUCTION CHANGED/<15><12>
EM3:  .ASCIZ  /BACK GROUND CHANGED/<15><12>
DH1:  .ASCII  /ERROR  FAILING/<15><12>
      .ASCIZ  /PC      ADDRESS EXPECT  RCV'D  COL  ROW  PRECHARGE/<15><12>
DH2:  .ASCII  /ERROR  INST  EXPECT  RCV'D/<15><12>
      .ASCIZ  /PC      ADDRESS DATA  DATA  COL  ROW  PRECHARGE/<15><12>
DH3:  .ASCII  /ERROR  BCKGRD  EXPECT  RCV'D/<15><12>
      .ASCIZ  /PC      ADDRESS DATA  DATA  COL  ROW  PRECHARGE/<15><12>

```

1902	010246	051040	053517	020040
1903	010254	051120	041505	040510
1904	010262	043522	006505	000012
1905				
1906	010270	002564	002570	002572
1907	010276	002574	002576	002600
1908	010304	002602	000000	
1909	010310	006	001	002
1910	010313	006	003	002
1911	010316	006	001	002
1912	010321	006	001	003
1913	010324	002	000	003
1914	010327	002	000	005
1915	010332	002	000	000
1916	010335	105	042116	050040
1917	010342	051501	006523	000012
1918	010350	042523	020124	053523
1919	010356	052111	044103	051505
1920	010364	043040	051117	047440
1921	010372	042520	040522	044524
1922	010400	043516	046440	042117
1923	010406	020105	042522	042506
1924	010414	020122	042523	052103
1925	010422	047511	020116	027064
1926	010430	006461	012	
1927	010433	040	042511	020056
1928	010440	044520	045503	050125
1929	010446	020123	051117	042040
1930	010454	047522	051520	047440
1931	010462	020122	047502	044124
1932	010470	052040	042510	020116
1933	010476	044510	020124	047503
1934	010504	052116	047111	042525
1935	010512	005015	000	
1936	010515	123	052105	051440
1937	010522	044527	041524	042510
1938	010530	006523	000012	
1939	010534	054524	042520	021040
1940	010542	052123	051101	044524
1941	010550	043516	041040	047101
1942	010556	021113	047040	046525
1943	010564	042502	020122	047101
1944	010572	020104	051103	006440
1945	010600	012		
1946	010601	122	043105	051105
1947	010606	052040	020117	042523
1948	010614	052103	047511	020116
1949	010622	027064	027063	020061
1950	010630	042502	047506	042522
1951	010636	041440	047510	051517
1952	010644	047111	020107	005015
1953	010652	000		
1954	010653	123	040524	052122
1955	010660	047111	020107	040502
1956	010666	045516	006477	000012
1957	010674	054524	042520	047040

.EVEN
DT1: .WORD \$HLTAD,\$BDADR,\$GDDAT,\$BDDAT,\$TMPG,\$TMP1,\$TMP2,0

DF1: .BYTE 6,1,2
.BYTE 6,3,2,2
.BYTE 6,1,2,2
.BYTE 6,1,3,3
.BYTE 2,0,3,3
.BYTE 2,0,5,5
.BYTE 2,0,0

EPASS: .ASCIZ /END PASS/<15><12>

OPMODE: .ASCII /SET SWITCHES FOR OPERATING MODE REFER SECTION 4.1/<15><12>

.ASCIZ / IE. PICKUPS OR DROPS OR BOTH THEN HIT CONTINUE/<15><12>

OPMOD2: .ASCIZ /SET SWITCHES/<15><12>

STARTB: .ASCII /TYPE "STARTING BANK" NUMBER AND CR /<15><12>

.ASCIZ /REFER TO SECTION 4.3.1 BEFORE CHOOSING /<15><12>

START2: .ASCIZ /STARTING BANK?/<15><12>

NUMBER: .ASCIZ /TYPE NUMBER OF 4K BANKS TO BE TESTED AND CR /<15><12>

1958	010702	046525	042502	020122	
1959	010710	043117	032040	020113	
1960	010716	040502	045516	020123	
1961	010724	047524	041040	020105	
1962	010732	042524	052123	042105	
1963	010740	040440	042116	041440	
1964	010746	020122	005015	000	
1965	010753	043	047440	020106	NUMB2: .ASCIZ /# OF BANKS?/(15)<(12)>
1966	010760	040502	045516	037523	
1967	010766	005015	000		
1968	010771	114	051501	020124	MEMEND: .ASCIZ /LAST MEMORY ADDRESS IS /
1969	010776	042515	047515	054522	
1970	011004	040440	042104	042522	
1971	011012	051523	044440	020123	
1972	011020	000			
1973	011021	120	051101	052111	PAERR: .ASCIZ /PARITY ERROR DETECTED AT LOC. /
1974	011026	020131	051105	047522	
1975	011034	020122	042504	042524	
1976	011042	052103	042105	040440	
1977	011050	020124	047514	027103	
1978	011056	020040	000		
1979	011061	111	020116	040520	NOPARE: .ASCIZ /IN PARITY TEST NO PARITY ERROR DETECTED/(15)<(12)>
1980	011066	044522	054524	052040	
1981	011074	051505	020124	047516	
1982	011102	050040	051101	052111	
1983	011110	020131	051105	047522	
1984	011116	020122	042504	052103	
1985	011124	042105	005015	000	
1986	011131	120	051101	052111	PARERR: .ASCIZ /PARITY ERROR HAS OCCURED SO PARITY TEST HAS STARTED/(15)<(12)>
1987	011136	020131	051105	047522	
1988	011144	020122	040510	020123	
1989	011152	041517	052503	042522	
1990	011160	020104	047523	050040	
1991	011166	051101	052111	020131	
1992	011174	042524	052123	044040	
1993	011202	051501	051440	040524	
1994	011210	052122	042105	005015	
1995	011216	000			
1996	011217	123	051117	054522	SORRY: .ASCIZ /SORRY LAST INPUT INVALID TRY AGAIN/(15)<(12)>
1997	011224	046040	051501	020124	
1998	011232	047111	052520	020124	
1999	011240	047111	040526	044514	
2000	011246	020104	051124	020131	
2001	011254	043501	044501	006516	
2002	011262	000012			
2003	011264	051120	043517	040522	PROTO: .ASCII /PROGRAM RELOCATED/(15)<(12)>
2004	011272	020115	042522	047514	
2005	011300	040503	042524	006504	
2006	011306	012			
2007	011307	122	051505	040524	.ASCIZ /RESTART ADDRESS /
2008	011314	052122	040440	042104	
2009	011322	042522	051523	020040	
2010	011330	000040			
2011	011332	047524	050040	052125	PROBAK: .ASCIZ /TO PUT PROGRAM BACK TO FIRST 4K START /
2012	011340	050040	047522	051107	
2013	011346	046501	041040	041501	

2014	011354	020113	047524	043040	
2015	011362	051111	052123	032040	
2016	011370	020113	052123	051101	
2017	011376	020124	000040		
2018	011402	047524	051040	051505	RELOD: .ASCIZ /TO RESTORE LOADER START /
2019	011410	047524	042522	046040	
2020	011416	040517	042504	020122	
2021	011424	052123	051101	020124	
2022	011432	000040			
2023	011434	050040	052514	020123	RELOD2: .ASCIZ / PLUS RELOCATION FACTOR/<15><12>
2024	011442	042522	047514	040503	
2025	011450	044524	047117	043040	
2026	011456	041501	047524	006522	
2027	011464	000012			
2028	011466	047514	042101	051105	FIN: .ASCIZ /LOADER RESTORED/<15><12>
2029	011474	051040	051505	047524	
2030	011502	042522	006504	000012	
2031					.EVEN
2032	011510	000000			LAST: .WORD 0
2033		000001			.END

PAGE	002666	620*	853*	923*	1039*	1352*	1801											
PARCSR=	172100	719*	727															
PARERR	011131	739	1986*															
PARSRV	002254	723	738*	782														
PARVEC=	000114	406*	723*	724*	742*	783*												
PASFLG	002652	847*	913*	1031*	1140*	1161*	1168*	1367*	1369*	1444*	1447							
PC	=%000007	338*	479	485*	526*	527*	534*	539*	563	566	592	627	636	659*				
		682*	693*	698*	701*	706*	708*	734*	738*	740	743	746	768*	778*				
		781	784	788	794*	895*	899*	911	915*	918*	919*	932*	934*	938*				
		940*	943*	977	982*	988*	992	1004*	1011*	1013*	1020*	1029	1034*	1035*				
		1048*	1087	1092*	1098*	1104*	1106*	1112*	1217	1229	1235	1291*	1299	1304*				
		1316*	1452*	1477*	1505*	1524	1544*	1555*	1567*	1578*	1586*	1610*	1626*	1638*				
		1647*	1648*	1658*	1667	1671*	1673*	1679*	1683	1706*	1713	1726	1730*	1733*				
		1744*	1749*	1829*														
		833*	1150*	1199	1321*	1322*												
PCHRG	002620	1014	2011*															
PROBAK	011332	1005	2003*															
PROTO	011264	323*	324															
PS	= 177776	324*																
PSM	= 177776	403*																
PWRVEC=	000024	849*	1067*	1415*	1416	1423*	1436*											
REDONE	002656	983	1093	2018*														
RELOD	011402	989	1099	2023*														
RELOD2	011434	465*	1016															
RESTOR	000300	398*																
RESVEC=	000010	832*	1149*	1201	1467	1571												
ROW	002616	329*	519	520*	521	524*	560	634*	639*	641*	646*	650	654*	727*				
RO	=%000000	730*	749*	764	771	772*	801*	893*	897*	926*	979*	981*	985*	999*				
		1002*	1008*	1017*	1042*	1089*	1091*	1095*	1118*	1119*	1125*	1203*	1204*	1205*				
		1206*	1207	1208	1217*	1219*	1239*	1241*	1243*	1255*	1260	1267*	1268	1281				
		1295	1308*	1310*	1354*	1355	1356	1357	1358	1359	1360	1361	1362	1405*				
		1414*	1465*	1466*	1467	1476*	1478	1490	1491	1492	1493*	1494*	1495*	1497				
		1498*	1499	1517*	1520	1522	1529*	1530*	1531*	1532	1535	1536	1543	1548				
		1554	1557*	1560	1566	1569*	1577	1585	1615	1616*	1617*	1618	1622*	1625*				
		1660	1662*	1663*	1664*	1665*	1666*	1669*	1670	1676	1681	1682*	1685*	1705*				
		1707*	1709	1710	1711	1717*	1742	1747*	1778	1779	1840*							
R1	=%000001	330*	465*	468	482*	484*	559	562*	640*	642	643	645*	649	655*				
		894*	898*	1000*	1001	1121*	1132*	1229*	1231*	1235*	1237*	1239	1241	1243				
		1257*	1260*	1268*	1269*	1279	1297*	1309*	1406*	1413	1437*	1439*	1442*	1515*				
		1536	1597	1598*	1599	1600*	1620	1621*	1622	1623*	1661	1681*	1686*	1702				
		1704*	1712															
R2	=%000002	331*	466*	468*	481*	483*	728*	731*	752*	754	757	759	970*	1003*				
		1022	1083*	1122*	1123*	1127	1128	1130*	1133*	1134	1259*	1261*	1270*	1273*				
		1274*	1275	1306*	1307	1308	1407*	1413*	1438*	1440*	1443*	1463	1479*	1480				
		1483	1486	1499	1504*	1511	1516*	1517	1518	1532	1548	1606*						
R3	=%000003	332*	467*	469*	558	571*	572	573	574	575	576	577	578	579				
		592*	594*	595*	596*	597*	598*	599	610*	611	612	613	614	656*				
		974*	975*	976	980	1084*	1085*	1086	1090	1120*	1124*	1126	1129*	1131*				
		1135	1142	1271*	1278	1441*	1443	1464	1478*	1480	1482*	1483	1485*	1486				
		1488	1503*	1512	1518*	1519*	1560	1605*	1784	1794*	1808*	1810*	1817*	1818*				
		1821*	1826*	1827*	1828	1838*												
R4	=%000004	333*	479*	480*	483	557	603*	608*	620	621*	631*	632	634	657*				
		958*	959*	960	962*	964*	965*	966*	967*	968*	969*	970	974	995				
		997*	998	1001*	1071*	1072*	1073	1075*	1077*	1078*	1079*	1080*	1081*	1082*				
		1083	1084	1272*	1280	1513	1520*	1521*	1530	1571	1589*	1590*	1604*	1785				
		1787*	1788*	1789*	1790	1791*	1792*	1823	1825*	1834*	1837*							

L04

TEST MOS MEMORY MACY11 27(732) 22-SEP-76 14:48 PAGE 52
DCMSBB.P11 CROSS REFERENCE TABLE -- MACRO NAMES

HLT 321#
SCOPE 322#

ADD	480	525	567	628	631	637	640	641	697	741	744	747	782	785	789
	800	912	975	978	996	997	1003	1007	1016	1030	1052	1085	1088	1123	1124
	1130	1131	1219	1231	1237	1273	1321	1326	1346	1439	1440	1471	1482	1485	1501
	1519	1525	1589	1593	1609	1617	1654	1668	1669	1684	1685	1686	1714	1715	1727
ASL	1728	1732	1789	1811											
ASR	712	713	714	731	1664	1665	1666	1803	1804	1805	1806	1807	1809		
BCC	686	687	1689	1692	1693	1694	1695	1698	1699						
BCS	732														
BEQ	1327														
	516	600	705	1111	1170	1197	1227	1277	1301	1396	1417	1468	1481	1484	1487
	1500	1533	1540	1551	1563	1574	1582	1596	1619	1637	1641	1796	1800	1824	
BGE	1746														
BGT	633	1832													
BHI	961	1074	1143	1338	1489										
BIC	598	678	703	711	993	1193	1195	1200	1202	1223	1269	1274	1322	1466	1521
	1523	1529	1590	1594	1616	1624	1690	1696	1700	1792	1802	1821			
BIS	570	715	1198	1204	1205	1206	1279	1530	1531	1625	1826	1827			
BIT	1110	1159	1169	1196	1276	1319	1324	1365	1450	1595	1618	1636	1642	1655	1677
	1799														
BITB	1795														
BLO	1137	1330	1351												
BLOS	1340														
BLT	533														
BNE	522	1833													
	1366	529	644	680	692	972	991	994	1069	1160	1163	1282	1320	1323	1325
	537	1448	1451	1537	1549	1561	1572	1591	1608	1643	1656	1678	1703	1822	
BPL	518	565	652	676	751	776	922	930	1038	1046	1400	1455	1651	1798	1820
BR	1293	535	604	635	688	710	716	765	796	1023	1138	1167	1174	1178	1233
	1701	1305	1317	1318	1331	1345	1368	1418	1473	1527	1546	1558	1570	1580	1601
	593	1720	1751	1780	1813	1835									
CLC	582	963	1076												
CLR	945	621	639	653	674	733	749	753	755	756	777	893	897	913	931
	1353	1031	1047	1067	1145	1149	1150	1164	1165	1168	1171	1172	1177	1181	1182
	1245	1363	1369	1401	1410	1411	1456	1794							
CLRB	599	632	643	704	960	1073	1136	1142	1281	1329	1337	1339	1350	1467	1480
CMP	1483	1486	1488	1499	1532	1536	1539	1548	1550	1560	1562	1571	1573	1581	
CMPB	528	679	691												
COM	1140	1161	1367	1415	1444										
DEC	1060	1133	1663	1744											
DECB	532	1819	1831												
EMT	321														
HALT	487	517	1109	1652											
INC	1119	1449	1640	1825	1834										
IOT	322														
JMP	449	451	452	470	790	1022	1141	1332	1370	1432	1433	1445	1457		
JSR	485	527	534	682	693	701	706	708	738	768	772	778	794	915	918
	919	926	932	934	938	940	943	982	985	988	1004	1008	1011	1013	1017
	1020	1034	1035	1042	1048	1092	1095	1098	1104	1106	1112	1291	1304	1316	1452
	1477	1544	1555	1567	1578	1586	1638	1647	1648	1671	1673	1679	1707	1717	1730
	1749	1829													
MOV	465	466	467	468	479	481	482	483	519	520	524	530	556	557	558
	559	560	561	562	566	568	571	572	573	574	575	576	577	578	579
	583	584	585	586	587	588	589	592	603	608	609	610	611	612	613
	614	615	616	620	626	627	629	634	636	638	647	648	649	650	654
	655	656	657	658	681	696	723	724	725	726	727	728	730	740	742
	743	745	746	748	752	754	757	758	759	760	770	771	781	783	784

TEST MOS MEMORY MACY11 27(732) 22-SEP-76 14:48 PAGE 56
DCMSBB.P11 CROSS REFERENCE TABLE -- PERMANENT SYMBOLS

ERRORS DETECTED: 0
DEFAULT GLOBALS GENERATED: 0

* DCMSBB.SEQ/SOL/CRF/PAGNUM/NL:TOC=DCMSBB
RUN-TIME: 5 12 3 SECONDS
RUN-TIME RATIO: 87/20=4.2
CORE USED: BK (15 PAGES)