

TSV05 Tape Transport Subsystem

Installation Manual

TSV05 Tape Transport Subsystem

Installation Manual

Prepared by Computer Special Systems
of
Digital Equipment Corporation

1st Edition, September 1982

Copyright © 1982 by Digital Equipment Corporation

The material in this manual is for informational purposes and is subject to change without notice.

Digital Equipment Corporation assumes no responsibility for any errors which may appear in this manual.

Printed in U.S.A.

The following are trademarks of Digital Equipment Corporation, Maynard, Massachusetts:

digital™
DEC
PDP
DECUS
UNIBUS

DECsystem-10
DECSYSTEM-20
DIBOL
EDUSYSTEM
VAX
VMS

MASSBUS
OMNIBUS
OS/8
RSTS
RSX
IAS

CONTENTS

	Page
CHAPTER 1 INTRODUCTION	
1.1	PURPOSE AND SCOPE.....1-1
1.2	GENERAL DESCRIPTION.....1-1
1.2.1	Features and Capabilities.....1-3
1.2.2	Functional Overview.....1-5
1.2.3	Controls and Indicators.....1-6
1.3	PHYSICAL DESCRIPTION.....1-9
1.3.1	Mechanical Characteristics.....1-9
1.3.2	Electrical Requirements.....1-9
1.3.3	Environmental Considerations.....1-10
1.3.3.1	Operating Conditions.....1-10
1.3.3.2	Nonoperating Conditions.....1-11
1.3.3.3	Emissions.....1-11
1.4	RELATED DOCUMENTS.....1-12
CHAPTER 2 INSTALLATION	
2.1	SITE PREPARATION.....2-1
2.1.1	Accessibility.....2-2
2.1.2	Power Receptacles.....2-2
2.1.3	Cooling.....2-2
2.1.4	Air Purity.....2-4
2.2	UNPACKING AND INSPECTION.....2-4
2.2.1	Tools and Working Space.....2-4
2.2.2	Unpacking the Cabinet.....2-4
2.2.3	Deskidding the Cabinet.....2-6
2.2.4	Unpacking the Smaller Cartons.....2-8
2.3	TAPE TRANSPORT CABINET INSTALLATION.....2-8
2.3.1	Tools Required.....2-10
2.3.2	Moving the Side Panel.....2-10
2.3.3	Connecting the Cabinets.....2-15
2.3.4	Removing Shipping Foam.....2-18
2.3.4.1	Removing the Top Foam Piece.....2-18
2.3.4.2	Removing the Bottom Foam Pieces.....2-18
2.3.5	Connecting Line Power.....2-23
2.4	TAPE TRANSPORT CHECKOUT.....2-24
2.4.1	Power Up Test.....2-24
2.4.2	Tape Loading Test.....2-25
2.4.3	Tape Movement Test.....2-27
2.4.4	Tape Unloading Test.....2-28
2.5	BUS INTERFACE/CONTROLLER MODULE INSTALLATION.....2-28
2.6	CABLE INSTALLATION.....2-29
2.6.1	M7196 Module and Tape Transport Interconnection.....2-29
2.6.2	Power Controller Interconnection.....2-31
2.7	TSV05 SUBSYSTEM CHECKOUT.....2-32
2.7.1	Power Up Checks.....2-32

CONTENTS (CONT)

	Page
2.7.2	System Setup.....2-33
2.7.3	TSV05 Logic Test.....2-33
2.7.4	Advanced Logic Test.....2-35
2.7.5	Tape Transport Test.....2-35
2.7.6	Advanced Tape Transport Test.....2-36
2.7.7	Data Reliability Test.....2-36
2.7.8	Additional Testing.....2-37
APPENDIX A	CONFIGURATION DATA..... A-1
APPENDIX B	MANUAL LOADING..... B-1

FIGURES

Figure No.	Title	Page
1-1	TSV05 Subsystem Components.....	1-2
1-2	Operator Front Panel.....	1-7
2-1	Cabinet Access Requirements.....	2-3
2-2	Cabinet Carton Removal.....	2-5
2-3	Removing Shipping Bolts.....	2-6
2-4	Deskidding the Cabinet.....	2-7
2-5	Tape Transport Cabinet Connection.....	2-9
2-6	Installing Leveling Feet.....	2-11
2-7	Computer Cabinet Ground Connection.....	2-12
2-8	Removing Side Panel.....	2-13
2-9	Mounting the Side Panel.....	2-14
2-10	Cabinet Alignment.....	2-16
2-11	Cabinet Interconnection Hardware.....	2-17
2-12	Cabinet Top Cover.....	2-19
2-13	Tape Transport Top Cover.....	2-20
2-14	Tachometer and Takeup Hub.....	2-21
2-15	Service Access Position.....	2-22
2-16	Front Panel Controls and Indicators.....	2-24
2-17	Inserting Tape.....	2-26
2-18	Cabling the M7196 Module.....	2-30
2-19	Cabling the Tape Transport.....	2-30
2-20	Remote Power Control Connections.....	2-31
A-1	M7196 Switch and Jumper Identification.....	A-1
A-2	M7196 Vector and Address Switches.....	A-2
A-3	Transport Switch and Terminator Identification.....	A-3
B-1	Accessing the Tape Path Area.....	B-2
B-2	Tape Threading Path.....	B-3

TABLES

Table No.	Title	Page
1-1	Controls and Indicators.....	1-7
2-1	Power Line Connections.....	2-2
2-2	TSV05 Subsystem Diagnostics.....	2-32

1.1 PURPOSE AND SCOPE

This manual describes how to unpack, install, and check out the TSV05 Tape Transport Subsystem. It also describes the capabilities and basic functions of the subsystem. An overview of the functional characteristics and the physical specifications appears in Chapter 1, while Chapter 2 is devoted to the installation procedures. Readers interested in only the installation procedures should bypass Chapter 1 and go directly to Chapter 2. For further information, refer to the documents listed in Section 1.4.

1.2 GENERAL DESCRIPTION


The TSV05 Tape Transport Subsystem provides magnetic tape storage capabilities to computer systems using quad-sized LSI-11 bus backplanes. The subsystem reads or writes up to 160,000 bytes per second in ANSI standard format. Data is recorded by phase encoding 1600 bits per inch on nine-track tape. Reading and writing are performed at either 25 or 100 inches per second.* The TSV05 subsystem is hardware compatible with 18- and 22-bit addressing versions of the LSI-11 bus quad backplane. It is software compatible with system and application programs written for the TS11 tape transport subsystem (as long as such programs use the DEC-supplied device handler). Tape formatting, error detection and correction, and self-test diagnostics are included as integral components of the TSV05 subsystem.

The TSV05 hardware consists of four items:

1. TS05 tape transport
2. M7196 LSI-11 bus interface/controller module
3. H9642-series cabinet, including 874 power controller and remote power control cable
4. Pair of 7016855 bus cables for connecting tape transport input and output to the bus interface/controller module.

The bus interface/controller module plugs into the LSI-11 bus (see Figure 1-1). The two cables connect the module with the tape transport.

*100 IPS operating speed requires enabling special features and the appropriate software.



CS-2428

CS-2448

Figure 1-1 TSV05 Subsystem Components

1.2.1 Features and Capabilities

The TSV05 Tape Transport Subsystem offers the following:

- Bidirectional reading capability
- 3.5K bytes of RAM in controller for buffering tape data
- Streaming, or reel-to-reel, technology (meaning that the tape is not required to stop in the interrecord gap)
- Automatic tape loading (threading)
- Microprocessor control in both the controller and the tape transport
- Microcoded diagnostic and maintenance features
- Tape formatting and error detection following ANSI X 3.39-1973 Standard
- Both ANSI and IBM tape mark detection
- Industry standard bus between controller and tape transport
- On-line diagnostics that verify data path integrity during idle periods
- Uses media conforming to ANSI X 3.40-1976 Standard
- Automatic read after write verification
- Small form factor with low power consumptions.

The tape handling characteristics and parameters are as follows:

Tape Characteristics

Type:	Mylar base, iron-oxide coated
Length:	731 m (2400 ft) maximum
Width:	1.3 cm (0.5 in)
Thickness:	1.5 mil (industry compatible)
Reel Diameter:	26.7 cm (10.5 in) 2400 ft 21.6 cm (8.5 in) 1200 ft 17.8 cm (7.0 in) 600 ft
Capacity/Tape Reel:	46 million bytes (10.5 in reel, unformatted)

Tape Motion

Handling: Bidirectional reel-to-reel, with compliance arm

Tape Tension: 212.6 g (7.5 oz) nominal

Read/Write Speed: 64 cm/sec (25 in/sec) (using TS11 software)
64 or 254 cm/sec (25 or 100 in/sec) (program selectable using special software)

Rewind Speed: 330 to 457 cm/sec (130 to 180 in/sec) (nominal), depending on reel size
445 cm/sec (175 in/sec) (average), using 26.7 cm (10.5 in) reel

Rewind Time:

<u>Reel Size, cm (in)</u>	<u>Minutes, maximum</u>
17.8 (7.0)	0.9
21.6 (8.5)	1.6
26.7 (10.5)	2.8

Auto Loading

Reliability: An average of 96% of attempted loads will be successful, with automatic retries, assuming a properly maintained transport and tape library.

Retries: Three automatically provided.

Times: 30 sec typical with no retry
30 sec maximum for each additional retry

Unloading

Time: 15 sec maximum with tape located at BOT

Tape Speed Variation:

Long Term: + 1% of nominal
Instantaneous: + 4% of long term

Data Access Times:

	<u>64 cm/sec (25 in/sec)</u>	<u>254 cm/sec (100 in/sec)</u>
Tape at Rest:	40 ms	260 ms
Worst Case:	140 ms	1040 ms

Data Transfer Rate: 40K bytes/sec at 64 cm/sec (25 in/sec)
 160K bytes/sec at 254 cm/sec (100 in/sec)

Data Organization

Number of Tracks: Nine (eight data; one parity)
 Recording Density: 1600 bits/in (nonselectable)
 Interrecord Gap: 1.3 cm (0.5 in) minimum, 1.65 cm (0.65 in) typical at 64 cm/sec (25 in/sec)
 Recording Method: Phase encoded (PE)
 Error Rates: Recoverable Write: 1 error in 10^8 bits transferred
 Recoverable Read: 1 error in 10^9 bits transferred
 Unrecoverable Read: 1 error in 10^{10} bits transferred

The LSI-11 bus interface characteristics are as follows:

Address Space Required:	772520/772522	1st	unit
	772524/772526	2nd	unit
	772530/772532	3rd	unit
	772534/772536	4th	unit
Vectors Required:	224	1st	unit
	*	2nd	unit
	*	3rd	unit
	*	4th	unit

1.2.2 Functional Overview

Tape loading is automatic. There are no vacuum columns, retaining clips, or multiple tension arms. When the tape transport is powered up, sets of internal diagnostics are run by the microprocessors in the tape transport electronics package and the bus interface/controller module. The subsystem is then ready for loading. Once the tape has been inserted and the door closed, the TS05 tape transport automatically seats and locks the tape reel on the spindle, and threads the tape through the correct path to the takeup reel. The threading operation is accomplished by precisely directed air flows that blow the tape along the path to the takeup reel. When this power up and load sequence is complete, control of the tape transport switches to the controller module.

* Rank of 37 in the floating vector area starting at 300.


The TSV05 subsystem operates under the control of a microprocessor on the M7196 bus interface/controller module. The module is a direct memory access (DMA) device in that it transfers data directly into or out of the LSI-11 memory without requiring the control of the LSI-11 CPU. To perform a data transaction with the TSV05 subsystem, the LSI-11 first builds a "packet" of command words in main memory. Next, it passes the starting address of the command packet to the M7196 module. Using this address, the M7196 module performs a DMA transfer to bring the command packet out to the controller memory. The command packet tells the controller what type of operation is to be performed and where the data is to come from or go to. The module then controls the movement of data from LSI-11 memory to the tape, or from tape to memory. It buffers this data so that DMA transfers can be handled independently of the mechanical movements of the tape. Additionally, it generates interrupts when necessary to provide the LSI-11 with status information.

The TS05 tape transport has an internal formatter that controls tape motion, formatting and writing of data on tape, reading of data from tape, and tape transport status monitoring. Commands from the M7196 module are latched into registers and then processed by a microprocessor in the formatter electronics. The formatter creates the identification (ID) burst, preamble, postamble, and file mark during a write operation, and it interprets these during a read operation. The formatter also oversees the handling of error conditions.

1.2.3 Controls and Indicators

The M7196 bus interface/controller module has jumpers, DIP switchpacks, and LED indicators. The jumpers and switchpacks are preset to the normal configuration and do not need to be changed unless there is an address conflict with an existing device. The LED indicators are provided as maintainability features, and are not exposed to view during normal operation.

The TS05 tape transport has an ON/OFF (1/0) power switch and five tactile switches, each with an LED indicator. (Refer to Figure 1-2.) The functions of these controls and indicators are described in Table 1-1. The TS05 tape transport also has internal switches for selecting tape units and enabling certain features, but these are preset and normally not changed. It also has an LED fault indicator. This LED is not exposed to view during normal operation.



CS-2429

Figure 1-2 Operator Front Panel

Table 1-1 Controls and Indicators

Control/ Indicator	Type	Function
POWER	On/off rocker switch and indicator	Switches line power on and off.
LOAD REWIND	Tactile switch and indicator	<ol style="list-style-type: none"> 1. Blinks when the tape drive is executing a load or re-wind sequence. 2. Lit continuously when the beginning of tape (BOT) marker is sensed. 3. Pressing the switch: <ol style="list-style-type: none"> a. Initiates load sequence and advances tape to load point. b. Rewinds the tape to load point.
UNLOAD	Tactile switch and indicator	<ol style="list-style-type: none"> 1. Pressing the switch causes the tape to be unloaded regardless of tape position. 2. Blinks when the tape drive is executing an unload sequence.

Table 1-1 Controls and Indicators (Cont)

Control/ Indicator	Type	Function
		<ul style="list-style-type: none"> 3. Lit continuously when the tape drive has completed its unload sequence and the front access door is unlocked. At this time, the tape may be removed and another tape inserted into the drive. 4. Lit continuously after a successful power up, indicating a tape may be loaded.
ON-LINE	Tactile switch and Indicator	<ul style="list-style-type: none"> 1. Lit when drive is ready and on-line. 2. Pressing the switch: <ul style="list-style-type: none"> a. Takes the tape drive off-line and extinguishes the indicator. b. Puts the tape drive on-line and lights the indicators.
<p>NOTE</p> <p>Pressing the switch during a load sequence puts the tape drive on-line when the BOT marker is sensed.</p>		
TEST	Tactile switch	Operational only in the test mode. Selects alternative operational mode for other switches.
WRITE	Indicator	<ul style="list-style-type: none"> 1. Lit when the write ring is installed and data may be written on tape. 2. When indicator is off, write ring is not installed and tape is file protected.
ENTER	Tactile switch	This control is used for manual loading, and controlling the test mode.

1.3 PHYSICAL DESCRIPTION

1.3.1 Mechanical Characteristics

Tape Transport Cabinet

Height: 111.13 cm (43.75 in)
Width: 59.69 cm (23.50 in)
Depth: 83.82 cm (33.00 in)
Weight: 121 kg (265 lb)

M7196 Bus Interface/Controller Module

Length: (From contact fingers to handles): 228.6 mm (9.0 in)
Width: 266.7 mm (10.5 in)
Thickness: 12.7 mm (0.5 in)
Weight: 0.51 kg (1.13 lb)

Formatter Bus Cables

Connectors: 50-pin, right-angle, flat cable header connectors at controller end; industry standard formatter connectors at tape transport end.
Length: 2.4 m (8.0 ft)

1.3.2 Electrical Requirements

Tape Transport Cabinet

Power Consumption: 220 W average
270 W maximum

Voltage (+7% or -15%):

	<u>Nominal, Vdc</u>	<u>Low Limit, Vdc</u>	<u>High Limit, Vdc</u>
TSV05-BA	120	102	128
TSV05-BB	240	204	256
TSV05-BD	220	187	235

Frequency: \pm 1 Hz

	<u>Nominal, Hz</u>	<u>Low Limit, Hz</u>	<u>High Limit, Hz</u>
	50 or 60	49	61

Frequency Rate of Change: 1.5 Hz/sec maximum

M7196 Controller

Power Consumption: 5 Vdc \pm 5% at 6.5 A (maximum)

LSI-11 Bus Loading: DC: One load
AC: Three loads (maximum)

1.3.3 Environmental Considerations

1.3.3.1 Operating Conditions -- The TSV05 subsystem is designed to operate under the following conditions:

Temperature

15°C to 32°C

Temperature Shock: 20° C change/hr maximum

Relative Humidity

20% to 80% noncondensing

Altitude

Sea level to 3 km (10,000 ft)

Vibration

Frequency Range: 5 to 500 Hz

Peak Acceleration: 0.25 g, 22 to 500 Hz, 0.01 in DA5-22 Hz

Application: Each of three orthogonal axes

Shock

+10 g peak, Halfsine, 10 ms

Pollutants

Atmospheric Particulates: 60 mg/1000 cu ft air by weight of particle (5 micron diameter)

Electrostatic Discharge

10 kV through 100 ohms from 350 pF

1.3.3.2 Nonoperating Conditions -- The TSV05 subsystem is designed to withstand the following conditions during nonoperating periods (e.g., shipping):

Temperature

-40° C to 66° C

Relative Humidity

95% maximum, noncondensing

Altitude

Sea level to 15 km (49,000 ft)

NOTE

Magtape media typically has more restricting nonoperating environmental considerations.

Vibration (in shipping container)

Frequency Range: 10 to 300 Hz

Peak Acceleration: 1.4 g rms vertical axis

0.68 g rms longitudinal and lateral axis
200 Hz maximum

Shock (in shipping container)

Peak Acceleration: 20 g

Duration: 30 ± 10 ms

Waveshape: 1/2 sine

1.3.3.3 Emissions -- During normal operation, the TSV05 subsystem is designed to emit no more than the following levels:

Heat

1100 Btu/hr maximum

Acoustic Noise

Standby (blower on): 57 dB A scale

Operating Conditions: 60 dB A scale

Electromagnetic Interference (EMI)

Complies with FCC Part 15, Subpart J, Class A.

Designed to comply with VDE 0871 B requirements.

NOTE

The TSV05 subsystem has been designed and tested to meet Digital standards including FCC requirements. The specifications in this chapter are based on this testing. Digital cannot guarantee the TSV05 subsystem will meet these specifications if nontested equipment is installed into the TSV05 cabinet or the TSV05 cabinet is installed in nontested configurations.

1.4 RELATED DOCUMENTS

Title	Order Number
TSV05 Tape Transport Pocket Service Guide	EK-TSV05-PS
Operation and Maintenance Instructions for Model F880 Tape Transport	799816-000*
TSV05 Tape Transport Subsystem Installation Guide	EK-TSV05-IN
XXDP User Guide	AC-90931-MC
DEC/X11 User Document	AC-8240Z-MC
TS05 Tape Transport Operation and Acceptance Preventive Maintenance Remove/Replace	EY-D3142-PS
TSV05 Field Print Set	MP-01157
TSV05 Subsystem Technical Manual	EK-TSV05-TM
Microcomputers and Memories	EB-18451-20
Microcomputer Interfaces Handbook	EB-17723-20

CAUTION

Reference the appropriate TSV05 Manual for installation, operation, and maintenance information.

*Available from Cipher Data Products, 10225 Willow Creek Road, San Diego, California 92131. This document contains detailed drawings of the TS05 formatter and power supply.

This chapter explains the TSV05 Tape Transport Subsystem installation. A section is devoted to each of the following:

1. Site preparation
2. Unpacking and inspection
3. Installing the tape transport cabinet
4. Checking out the tape transport
5. Installing the bus interface/controller module
6. Installing the interconnecting cables
7. Checking out the TSV05 subsystem.

NOTE

BEFORE YOU UNPACK the cartons, inspect for signs of shipping damage. If the shipment has been damaged, call the dealer from whom the equipment was purchased. If the equipment is covered under "Digital Transit Insurance", the Digital representative will estimate the damage and put in a claim. If the equipment is not insured by "Digital Transit Insurance" contact the carrier who handled the equipment and your own insurance company. Digital Field Service is available on a per-call basis to make estimates of damage for any resulting insurance claims.

2.1 SITE PREPARATION

The TSV05 Tape Transport Subsystem mounts to the left side of the existing computer cabinet. It requires a 59.7 centimeter (23.5 inch) wide by 83.8 centimeter (33.0 inch) deep area of floor space that is capable of supporting, as a minimum, 121 kilograms (265 pounds). The cabinet is capable of supporting up to 205 kilograms (450 pounds).

Beyond this mounting space, the TSV05 subsystem also requires room for access to the cabinet, the correct power receptable, and an adequate flow of cooling air.





2.1.1 Accessibility

The cabinet requires sufficient space behind it for opening the rear door. If any expansion is anticipated, room in front of the cabinet will be required to allow future equipment to be pulled out of the cabinet for maintenance. Refer to Figure 2-1 for the required dimensions.

2.1.2 Power Receptacles

Ensure that the correct power receptacle is available (refer to Table 2-1). It should be capable of handling at least the 270 watts required by the tape transport.

Table 2-1 Power Line Connections

MODEL	PLUG	RECEPTACLE	CIRCUIT RATING
TSV05-BA	 <p>SILVER → BRASS → NEMA #L5-30P DEC #12-11193</p>	 <p>L5-30R 12-11194</p>	120 V 24 A
TSV05-BB -BD	 <p>BRASS 2 → BRASS 1 → NEMA #6-15P DEC #90-08853</p>	 <p>6-15R 12-11204</p>	220/240 V 12A

CS-2431


Power Cord Color Code

<u>Color</u>	<u>Function</u>	<u>Pin Connection</u>	
		<u>L5-30P</u>	<u>6-15P</u>
Brown	Hot	Brass	Brass 1
Blue	Neutral	Silver	Brass 2
Green/yellow	Ground	Ground	Ground


2.1.3 Cooling

The TSV05 subsystem requires 1100 Btu per hour of cooling to be provided by the movement of room air through the cabinet.

TOP VIEW



FRONT VIEW



CS-2430

Figure 2-1 Cabinet Access Requirements

2.1.4 Air Purity

The tape transport is equipped with internal filters to prevent dust from accumulating on the tape and tape heads. Nevertheless, it is good practice to avoid placing the cabinet in the path of a dust-laden current of air (such as beside a door).

2.2 UNPACKING AND INSPECTION

The TSV05 is shipped as one skid-mounted carton and one or more smaller cartons. The carton on the skid contains the TS05 tape transport cabinet. The smaller carton(s) contain the M7196 controller, the documentation and accessories, and two individually packaged cables. These smaller items may be shipped in one carton or two, depending on shipping requirements. Check the shipping documents to ensure that the correct model has been shipped. If anything is missing, damaged, or incorrect, contact the dealer from whom the equipment was ordered.

2.2.1 Tools and Working Space

The following tools are required for unpacking the TSV05 subsystem:

1. Scissors
2. 9/16 inch wrench
3. 3/4 inch wrench
4. Hammer
5. 5/32 inch hex key

Also, an area of approximately 3 meters (10 feet) square is required for moving the cabinet off the shipping skid.



2.2.2 Unpacking the Cabinet

1. Cut the nylon straps and remove the cardboard pieces of the cabinet carton as shown in Figure 2-2. Remove the plastic bag.
2. Using a 9/16 inch wrench, remove the four bolts that hold the cabinet to the skid.
3. Slide the wooden blocks out from under the cabinet (see Figure 2-3).

CAUTION


Once the blocks have been removed, the cabinet is free to roll on its casters. The cabinet is top-heavy and must be handled with care.

The blocks may require a few taps with a hammer to move them out from under the cabinet. It may be helpful to tilt the cabinet slightly while removing the blocks.



CS-2432

Figure 2-2 Cabinet Carton Removal



CS-2433

Figure 2-3 Removing Shipping Bolts


2.2.3 Deskidding the Cabinet

WARNING

Two people are required for moving the cabinet off the skid.

The recommended procedure for removing the tape transport cabinet from the skid is as follows:

1. One person stands in front of the cabinet while the other person stands behind it.
2. Grasp the cabinet by right top and by the left center, as shown in Figure 2-4.
3. Roll the cabinet off the side of the skid, taking care to prevent it from toppling over.
4. When the casters on the left side of the cabinet are on the floor, push the skid out from under the right side of the cabinet. Take care to prevent the cabinet from hitting the floor hard or toppling.



CS-2435

Figure 2-4 Deskidding the Cabinet

5. With the cabinet standing on the floor, use a 3/4 inch wrench to remove the red metal shipping brackets from the bottom. After they are loosened, the brackets slide outward.
6. Open the rear door using a 5/32 inch hex key (see Figure 2-6) and verify that the envelope taped to the bottom of the cabinet contains:
 - a. 7008288-8F remote cable
 - b. H9544-HB leveler feet and hardware
 - c. 7422224/7422225 intercabinet hardware

2.2.4 Unpacking the Smaller Cartons


Open the smaller cartons and check that they contain the following:

1. M7196 bus interface/controller module
2. Two interconnection cables (part number 7016855-08)
3. TSV05 Tape Transport Installation Manual (EK-TSV05-IN) (this manual)
4. TSV05 Tape Transport User's Guide (EK-TSV05-UG)
5. TSV05 Pocket Service Guide (EK-TSV05-PS)
6. 26.7 centimeter (10.5 inch) magtape number 30-18709-08
7. Tape cleaning kit part number TUC02
8. MP01157 field print set.

Visually inspect each item. If any item is damaged, missing, or incorrect, contact the dealer from whom the system was purchased.


2.3 TAPE TRANSPORT CABINET INSTALLATION

The TSV05 subsystem is designed to be connected to the left side of an H9642 cabinet that contains a PDP-11/23 computer. Older LSI-11 computer systems that use H9612 cabinetry require alternative installation procedures. These procedures are defined in the MP01157 print set. The tape transport cabinet is shipped with no side panels, but with an expansion ring on the right side of the cabinet. (Refer to Figure 2-5.) The left side panel of the computer cabinet is moved to the left side of the tape transport cabinet. Then the right side of the tape transport cabinet is bolted to the left side of the computer cabinet.



TAPE TRANSPORT
CABINET

EXISTING LSI-11
COMPUTER CABINET



EXPANDED SYSTEM

CS-2436

Figure 2-5 Tape Transport Cabinet Connection

This configuration has been tested for compliance with FCC requirements. Installing the TSV05 subsystem in other configurations may result in higher levels of EMI radiation.

2.3.1 Tools Required

Cabinet installation requires the following tools:

1. 9/16 and 11/16 inch wrench (for leveling feet)
2. 5/32 inch hex key (for door)
3. 7/16 inch wrench (for bolting cabinet together)
4. Screwdriver or nut driver, as applicable, for connecting ground cable.

2.3.2 Moving the Side Panel

Install the TS05 cabinet levelers and move the side panel as follows:

1. Install the four leveling feet on the bottom of the TS05 cabinet (Refer to Figure 2-6.) The leveling feet are screwed into the holes previously used by the red shipping brackets. The cabinet must be tilted to the left to provide clearance for installing the feet on the right side, and tilted to the right while installing the feet on the left side.


CAUTION

Do not tilt cabinet more than necessary. Approximately 5 centimeters (2 inches) of clearance is necessary to insert the leveling feet.

2. Open the rear door of the TS05 cabinet and the CPU cabinet. Typically, this requires inserting the hex key into the latch and turning it 1/4 turn counterclockwise. (See Figure 2-7.)
3. Remove the locking bracket located at the rear bottom, right-hand side of both cabinets. Each bracket is held by two bolts. Loosen but DO NOT remove the bolts.
4. Lift the side panel straight up and remove it from the CPU cabinet left side (see Figure 2-8). Disconnect the side panel ground wire from the cabinet frame.
5. Place the side panel removed in step 4 next to the TS05 cabinet left side. Connect the side panel ground strap to the TS05 cabinet using the hardware supplied on the left rear cabinet rail.




1. REMOVE LEVELING FEET FROM SHIPPING BAG.
2. ENSURE THAT NUT, LOCK WASHER AND FLAT WASHER ARE ON EACH FOOT.
3. TURN NUT DOWN TO BOTTOM.
4. SCREW FOOT INTO THREADED HOLE IN BOTTOM OF CABINET FAR ENOUGH TO PERMIT THE CABINET TO BE ROLLED ON ITS CASTERS.




CS-2443

Figure 2-6 Installing Leveling Feet



CS-2439


Figure 2-7 Computer Cabinet Ground Connection



CS-2441

Figure 2-8 Removing Side Panel

6. Position the side panel against the TS05 cabinet such that the slots align with the pins. (Refer to Figure 2-9.) Hold the side panel a few inches above its mounted position until it is even with the front and rear of the cabinet. Slide the panel straight down such that the four pins engage the four slots.
7. Reinstall and tighten the bracket located on the TS05 cabinet at the rear bottom right side. This was one of the brackets removed in step 3.





CS-2442

Figure 2-9 Mounting the Side Panel

2.3.3 Connecting the Cabinets


The two cabinets must be connected together both mechanically and electrically. The mechanical connection is made as follows:

1. Roll the TS05 cabinet, with side panel attached, next to the CPU cabinet left side. Place the TS05 cabinet 1 inch forward of the CPU cabinet such that the pins in the CPU cabinet align with the cutouts in the trim panel. To obtain this alignment, adjust the TS05 leveling feet until the top of the TS05 cabinet is level with the top of the CPU cabinet.
2. Push the TS05 cabinet sideways so that it is against the computer cabinet. Push the TS05 cabinet backwards until it is even with the CPU cabinet. Check that all the pins are engaged properly into the trim panel. (Refer to Figure 2-10.)
3. Reinstall the second locking bracket that was removed in Section 2.3.2, step 3. Do not tighten it. This bracket is located on the CPU cabinet bottom rear, right-hand side. (Refer to Figure 2-11.)
4. Loosen, but DO NOT REMOVE, the TS05 locking bracket that holds the rear door bottom pivot pin. This is easier if you partially remove the TS05 rear door by pushing down on the top pivot pin and raising the rear door out of the bottom pivot hole.
5. Install the rear intercab bracket as shown in Figure 2-11. Tighten the four screws, ensuring all brackets are fully down. Reinstall the TS05 rear door if it was removed in step 4.
6. Remove the bottom trim panels located on the CPU and TS05 cabinets. Typically, this panel is held in place by two phillips head screws.
7. Remove the four center-most bolts and two center-most trim panel brackets from the cabinetry.
8. Refer to Figure 2-11 and install the front intercab bracket. Reinstall the two trim panel brackets and tighten the four bolts, and then reinstall both bottom trim panels.
9. Recheck the cabinetry leveling. Adjust the leveling feet of both cabinets, if necessary, to ensure that the system is properly leveled and all leveling feet are properly supporting the system.



CS-2437

Figure 2-10 Cabinet Alignment



CS-2440

Figure 2-11 Cabinet Interconnection Hardware

2.3.4 Removing Shipping Foam

The tape transport is shipped with foam cushions protecting the takeup hub and blower motor. These cushions must be removed before the unit is powered up. This requires opening the tape transport to the operator maintenance access position to remove the foam from around the takeup hub, and opening it to the service access position to remove two other pieces of foam.

2.3.4.1 Removing the Top Foam Pieces



1. Raise the top of the cabinet by grasping the handle on the top cover and lifting. When the top cover is raised far enough, the support arm latches to keep the cover up. (Refer to Figure 2-12.)
2. Raise the top cover of the tape transport unit by reaching in through the front door and pushing upward on the front of the top cover. Prop the cover up using the nylon support that hangs from the left side of the cover. (Refer to Figure 2-13.)
3. Refer to Figure 2-14. Gently move the tachometer assembly away from the takeup hub. Remove the foam cushion. Carefully place the tachometer assembly back on the takeup hub.
4. Inspect and ensure that the tape path area is free of any foreign matter. With the cover still in the operator maintenance access position, proceed to Section 2.3.4.2.

2.3.4.2 Removing the Bottom Foam Pieces

1. Loosen the two spring-loaded captive screws, located on each side (as viewed from the top of the TS05 tape transport unit), that secure the TS05 unit to the top rail assembly. (See Figure 2-15.)
2. Lower the top cover of the tape transport unit.
3. With both hands, grasp the lower front of the TS05 unit and lift the entire assembly to its maximum upright position. (This engages the locking mechanism automatically.)

WARNING

Keep hands clear of the corners of the tape unit while lifting. This is important to avoid brushing the mounting rails with your hands while lifting the unit.



CS-2438

Figure 2-12 Cabinet Top Cover





Figure 2-13 Tape Transport Top Cover

CS-2444



CS-2466

Figure 2-14 Tachometer and Takeup Hub




Figure 2-15 Service Access Position

4. Carefully lower the TS05 unit approximately 2.5 centimeters (1.0 inch). (This will activate the locking mechanism automatically.)

WARNING

To eliminate the possibility of the tape unit dropping due to a failure in the locking mechanism, insert the supplied safety pin into the hole provided [2.5 centimeters (1.0 inch)] above the locking mechanism on the top plate supporting slide. Route the safety pin behind the supporting slide and across in front, and install it from left to right.

5. Release the drive/formatter module by pulling down on the two Ny-Lok fasteners that secure it to the bottom of the top plate assembly. When the Ny-Lok fasteners are released, carefully lower the drive/formatter module as far as it will go.
6. Remove the sheet and block of foam from the unit.
7. Place the TS05 unit back to the operating position by reversing steps 1 through 5.
8. Close the top cover of the tape unit and the top cover of the cabinet.

NOTE

To release the cabinet top cover support arm, it is necessary to raise the top cover slightly and move the top of the arm forward.

2.3.5 Connecting Line Power

Before connecting the line power, perform the following checks:

1. Power switch on the front panel of the tape transport is in the 0 (OFF) position.
2. Power controller voltage rating is correct for your system.
3. Power controller circuit breaker switches are in the OFF position.
4. Power controller LOCAL/REMOTE switch is in the LOCAL position.

With the switches in these positions, unwind the power cable and plug it into the receptacle.


2.4 TAPE TRANSPORT CHECKOUT

The tape transport is tested by itself before being cabled to the bus interface/controller module. This standalone testing is performed with the line power controlled locally at the cabinet power controller. After standalone operation has been verified, operation with the computer system is tested. At that point, the tape transport cabinet power is placed under the control of computer cabinet power controller by connecting the remote control cable. For the tests in this section, however, the remote control cable remains unconnected.

2.4.1 Power Up Test

1. Switch the circuit breaker switches on the cabinet power to the ON position. Observe that the power controller pilot lamp lights. Close the cabinet rear door.
2. On the tape transport front panel (Figure 2-16), press the power switch to the 1 (ON) position. Observe that all indicators light for approximately 2 seconds.
3. Observe that after 2 seconds all the indicators extinguish, and then the UNLOAD indicator lights.

If these indications have occurred, the tape transport unit has successfully completed the internal verification checks that it performs automatically at power up. If the indications were different, there is a problem. Refer to the TSV05 Pocket Service Guide or call your local Digital representative.



CS-2429

Figure 2-16 Front Panel Controls and Indicators

2.4.2 Tape Loading Test

This test verifies the ability of the TSV05 subsystem to automatically load a tape. It requires a tape that is blank except for the beginning-of-tape (BOT) and end-of-tape (EOT) markers. Refer to Figure 2-17 and proceed as follows:

1. Ensure that the tape is wound completely onto the reel and that the end has been properly crimped.
2. Open the front panel door by gently pressing down on the top center area of the door.
3. Hold the tape with the file-protect ring side down, and insert it into the transport unit, centering it on the hub.
4. Close the door.

CAUTION

Both the tape transport top cover and the front panel door are locked when a tape is loaded. Any attempt to force open either the cover or the door before the tape is unloaded will result in mechanical damage to the locking mechanism.

5. Press the LOAD switch. This locks the cover and the door and begins the loading sequence.
6. Observe the LOAD indicator. It blinks while the tape is being loaded. After a maximum of 135 seconds, it stops blinking and remains lit. This indicates that the tape loading sequence is complete.

If the LOAD indicator does not stop blinking, or if the other indicators begin to blink, there is a problem. Unload the tape, check for a proper crimp, and retry the test. If the tape does not load, refer to the TSV05 Pocket Service Guide or to the manual loading instructions in Appendix B.




Figure 2-17 Inserting Tape

2.4.3 Tape Movement Test

This test exercises the tape drive in both forward and reverse directions and at both high and low speeds.

NOTE

If you make an error and enter an illegal test sequence, or if you stop during the sequence and permit more than 2 seconds to pass before pressing the next switch in the sequence, the system aborts the test instruction and you must start the sequence from the beginning. An erroneous or aborted test instruction results in an expanding pattern of blinking.

1. Start the test by pressing the front panel control switches in the following sequence:
 - a. TEST
 - b. ENTER
 - c. UNLOAD
 - d. UNLOAD
 - e. ENTER
2. The tape should begin to move after step e.
3. Observe the indicators. If, over a period of 2 minutes, they change their blinking value substantially, there is a problem. If the blinking remains about the same, the test is progressing successfully.
4. After 2 minutes, terminate the test by pressing the TEST key. This causes the tape to rewind (which may take several minutes) and the LOAD indicator to light.

If problems are encountered, refer to the TSV05 Pocket Service Guide.

2.4.4 Tape Unloading Test

This test verifies the ability of the tape unit to unload the tape automatically.

1. Press the UNLOAD switch.
2. Observe the UNLOAD indicator. It blinks to indicate that the tape is being unloaded. When the unloading process is complete, the UNLOAD indicator lights continuously, and the front panel door and top cover are unlocked. This should take a maximum of 15 seconds.
3. Open the front panel door and lift the tape reel out of the tape transport.
4. Close the door.
5. Press the tape transport power switch to the 0 (OFF) position.
6. Switch the circuit breaker switches on the cabinet power controller to the OFF position.

2.5 BUS INTERFACE/CONTROLLER MODULE INSTALLATION

The M7196 bus interface/controller module plugs into a quad slot in the LSI-11 backplane. It connects to the LSI-11 bus on the A and B sets of edge connectors (module fingers). It is shipped with the DIP switches set for an interrupt vector of 224 and for addresses of 772520 and 772522. If your system already uses any of these addresses, the M7196 module must be switched to other addresses. Refer to Appendix A for information on switching the DIP switchpacks on the M7196 module. Refer to the Microcomputers and Memories Handbook or your system configurator for guidance in selecting new addresses.

For guidance in choosing the best backplane slot in which to install the M7196 module, refer to your system documentation or to the Microcomputers and Memories Handbook.

Install the M7196 module as follows:

1. Test the computer system to verify that it is functioning properly.
2. Power down the computer system.
3. Remove the cover to gain access to the backplane. (Which panel must be removed depends on which system you have. Earlier systems accept modules in the front, while in more recent models the modules are inserted in the back. Refer to your system documentation.)
4. Insert the module into the LSI-11 backplane. Do not fully seat the module until the cables have been installed.


2.6 CABLE INSTALLATION

Cable installation involves connecting the M7196 module to the tape transport unit and connecting the tape transport cabinet power controller to the computer cabinet power controller.

2.6.1 M7196 Module and Tape Transport Interconnection

Each of the two flat interconnection cables has a large connector on one end and a small connector on the other end. The large connectors go to the tape transport unit and the small connectors to the M7196 module. Refer to Figure 2-18 and proceed as follows:

1. Take a cable and position it so that pin 1 of the smaller, "low profile" connector lines up with pin 1 of connector J1 on the M7196 module. Pin 1 on the cable connector is indicated by a red stripe on the cable.
2. Gently push the cable connector into the J1 module connector until it is seated.
3. Route the cable to the rear of the cabinet. Cable routing depends on the model and configuration of the computer system, however, try to avoid blocking ventilation or running the cable where it may get caught on other equipment when a chassis is pulled out. Refer to drawing UA-TSV05-B for typical cable routing.
4. Pass the cable through the open side of the computer cabinet and into the tape transport cabinet. Do not route the cables outside the cabinetry.
5. Refer to Figure 2-19. Line up pin 1 of the cable connector with pin 1 of connector P1 on the tape transport unit. There are two sets of connectors on the back of the tape transport unit. The TSV05 subsystem uses the left-hand set of connectors.
6. Gently press the cable connector onto the P1 edge connector in the back of the tape transport cabinet.
7. Repeat this procedure to cable J2 of the M7196 module to P2 of the tape transport unit. Ensure that pin 1 of J2 connects to pin 1 of P2.
8. After both interconnection cables have been installed, fully seat the module.



CS-2447

Figure 2-18 Cabling the M7196 Module




Figure 2-19 Cabling the Tape Transport

2.6.2 Power Controller Interconnection

The power controllers in the two cabinets are to be interconnected by a remote control cable. This enables the computer cabinet power to switch on the tape transport cabinet power automatically whenever the computer is powered up.

The remote control cable, part number 7008288-8F, has a three-pin connector on each end. The cable connectors are the same, and they are keyed to plug in only one way. Refer to Figure 2-20 and install the remote control cable as follows:

1. In the computer cabinet, plug one end of the cable into the power controller connector labeled DEC POWER CONTROL BUS.
2. Route the remote control cable through the open side of the computer cabinet and into the tape transport cabinet. Do not route the cable outside the cabinetry.
3. In the tape transport cabinet, plug the cable into the power controller connector labeled DEC POWER CONTROL BUS.
4. Place the LOCAL/REMOTE switch in the REMOTE position.
5. Switch the circuit breaker switches to the ON position.

The tape transport cabinet power is now fully interconnected with the computer cabinet.




Figure 2-20 Remote Power Control Connections

CS-2434

2.7 TSV05 SUBSYSTEM CHECKOUT

The TSV05 subsystem is tested by checking the M7196 LED indicators and voltage supply, and by running the diagnostic programs listed in Table 2-2. These programs are available on the XXDP+ diagnostic software package that is shipped with the computer system. If your system is an earlier model and has the XXDP package instead of the XXDP+, contact your local Digital representative for ordering information.

2.7.1 Power Up Checks

1. Set the power switch on the tape transport unit to the ON position.
2. Switch on the computer system power and observe that the tape unit powers up with the system.
3. After a few seconds, all the tape unit indicators should be extinguished except for the the UNLOAD indicator.
4. Verify that the +5 V power to the M7196 module is within specification. Typically, the additional load of the M7196 module lowers the power supply voltage slightly. Adjust if necessary.
5. On the M7196 module, verify that the center LED (D2) is blinking. This indicates that the M7196 module self-test diagnostics are running. If other indications occur, there is a problem. Refer to the TSV05 Pocket Service Guide or contact your local Digital representative.
6. Replace the access panel on the computer and close the rear doors of the cabinets.

Table 2-2 TSV05 Subsystem Diagnostics

Program Title	File Name
Logic Test	CVTSAA
Advanced Logic Test	CVTSBA
Transport Test	CVTSCA
Advanced Transport Test	CVTSDA
Data Reliability Test	CVTSEA
DEC-X11	XTSAA0

2.7.2 System Setup

1. To prevent erroneous error indications, ensure the tape transport is clean and the blank tape is of known good quality.
2. Load the blank tape into the tape transport by:
 - a. Opening the front panel access door.
 - b. Inserting the tape reel, with the file-protect ring side down, and centering it on the hub.
 - c. Closing the door.
 - d. Pressing the LOAD switch.
 - e. Waiting for the LOAD indicator to stop blinking and stay on continuously.
 - f. Pressing the ON-LINE switch.
3. Load the computer system diagnostic diskpack or floppy.
4. Before running the tape subsystem diagnostics, run the system exerciser or diagnostics to verify that the computer is operating properly. For instructions on running the computer system tests, refer to the documentation for the system.

NOTE

The logic test and the advanced logic test (CVTSAA and CVTSBA) do not require a tape to be loaded in order to run. The other diagnostics, however, require the tape to be loaded and the tape subsystem to be ON-LINE.

2.7.3 TSV05 Logic Test

This program tests the logic on the M7196 bus interface/controller module. It checks the microprocessor, RAM, and various registers. It verifies that the computer can move data out to the module and receive status in from the module. After you have booted the XXDP+ disk (DL, DX, or DY) and answered the questions about the date, the processor, and the power line frequency, start the logic test as follows (operator responses are underlined):

.R VTSA?? <CR>

The system responds with a display similar to the following:

```
DIAG. RUN-TIME SERVICES
CVTSA-A-0
****TSV05 LOGIC DIAGNOSTIC****
UNIT IS TSV05
DR>
```

At this point, type in the following commands:

```
DR> START/FLAG:PNT:HOE <CR>
```

This instructs the program to start the test, display the test number as each of its 11 tests are executed, and halt it if an error is detected. The computer now asks:

```
CHANGE HW (L) ?
```

Type in a "Y" for yes:

```
CHANGE HW (L)? Y <CR>
```

The computer then asks:

```
# UNITS (D) ?
```

Type in a "1" to indicate that there is one tape unit:

```
# UNITS (D) ? 1 <CR>
```

The computer then displays the device address, the interrupt vector, and the interrupt priority. If you have left the M7196 module in the configuration in which it was shipped, respond to these queries by typing a carriage return:

```
UNIT 0
DEVICE ADDRESS (TSBA/TSDB) (0) 172520? <CR>
INTERRUPT VECTOR (0) 224? <CR>
```

If, on the other hand, you have changed the DIP switchpack settings on the M7196 module, then you must type in the parameters you selected.

The computer then asks if you wish to change the software parameters:

```
CHANGE SW (L) ?
```

For the subsystem checkout, the answer to this question is no:

```
CHANGE SW (L) ? N <CR>
```

After you have responded to these questions, the program starts testing the subsystem. The program runs continuously, repeating itself until it detects an error or until you halt it. If the program halts because of an error, refer to the CVTSAA TSV05 MAGTAPE Diagnostic User's Document for a detailed description of the tests. For assistance, contact your local Digital Field Service office.

After the program has made one pass through all the tests, halt it by pressing CONTROL C. This passes control of the system back to the diagnostic supervisor program. Then type "EXIT" to get back to the system monitor:

```
^C  
DR> EXIT <CR>
```

2.7.4 Advanced Logic Test

This program verifies that the M7196 module can get status and write characteristics from the computer memory, and that it can deposit message packets in the computer memory. It tests error detection circuits and verifies that the computer can initialize and write into the controller RAM memory. It checks the internal timers, buffers, and status and control logic. Also, it verifies that the controller can move signals to and from the cables that connect it to the tape transport unit.

Load this program as follows:

```
.R VTSB?? <CR>
```

After the program title is displayed and the diagnostic supervisor returns the DR prompt, enter the command line:

```
DR> START/FLAG:PNT:HOE:UAM <CR>
```

The program responds by asking the same questions about hardware and software parameters as were asked by the logic test. Type in the same answers. After the last question is answered, the program starts running its tests (this one has 12 tests, with the last 3 not executed). It runs continuously until there is an error or until you halt it. After one pass, halt the program by typing CONTROL C, and type "EXIT" to return to the system monitor:

```
^C  
DR> EXIT <CR>
```

2.7.5 Tape Transport Test

This program verifies correct tape motion command decoding. It checks the basic operation of the rewind positioning command, the write data command, and the read forward and read reverse commands. It verifies that the system can space over records forward and in reverse direction, and that it can reread records. The

ability of the subsystem to respond to error conditions is also tested. The program checks the commands for retrying to write data and tape marks. It also tests the skipping of tape marks in forward and reverse directions.

Load the program as follows:

```
.R VTSC?? <CR>
```

After the system displays the program title, enter the same command line and answers to the parameter questions as for the previous program (described in Section 2.7.4). After one successful pass of the eight tests in this program, halt the program and exit to the system monitor.

2.7.6 Advanced Tape Transport Test

This program verifies the functioning of the No-Op, Initialize, and Erase commands. It checks that errors are indicated when no data is found on the tape and it tests the data parity checking circuitry in both the controller and the tape transport electronics. It checks for the proper handling of the EOT status and tests the record buffering functions. It also checks that records and gaps written on the tape are the correct length.

Load the program as follows:

```
.R VTSD?? <CR>
```

After the title is displayed, enter the commands:

```
DR> START/FLAG:PNT:HOE <CR>
```

The program starts and runs its nine tests. After one successful pass, halt the program and exit to the system monitor.

2.7.7 Data Reliability Test

This program exercises and verifies the correct completion of all tape transport functions. It executes read and write commands a random number of times, with records of random length and data, for the entire tape.

Load the program by typing:

```
.R VTSE?? <CR>
```

and then, after the title is displayed, enter:

```
DR> START/FLAG:PNT:HOE <CR>
```

NOTE

Magtape media typically will have several flaws per reel that will cause this diagnostic to indicate write errors or write retries due to bad tape spots. These types of errors do not indicate a problem with the subsystem.

The program then asks:

```
SELECT DRIVE 0-1 (0)?
```

Answer by typing 0 and a carriage return:


```
. 0<CR>
```

2.7.8 Additional Testing

The tests described in the preceding sections provide a high confidence level that the TSV05 subsystem is functioning correctly. More exhaustive checks are available by allowing the diagnostic programs to run for more than one pass. The second pass of the program is more comprehensive than the first pass. All iterations after the first pass are the same, however, they are substantially longer than the first one. Running tests that cause tape motion for extended periods will require transport cleaning to prevent erroneous error reports. The logic type tape motion tests, when run continuously, can cause high tape wear to occur in the first few feet of tape. In these cases, errors due to faulty or worn tape do not indicate a failure.

Another test that may be run is the DEC/X11 runtime system exerciser. This test exercises the entire system to verify that there are no spurious interactions between various subsystems and components. There is an exerciser program module for each major system component, and these are linked together to create a system exerciser that is tailored to your system. The DEC/X11 module for the TSV05 subsystem is XTSA00. Although this exerciser can be run by itself, its full value is not realized unless it is linked to and run with the system exerciser. For information about building a system exerciser to include the TSV05 subsystem, refer to DEC/X11 User's Manual, AC-8240Z-MC.

APPENDIX A
CONFIGURATION DATA



CS-2449

VECTOR SWITCHPACK

	1	2	3	4	5	6	7	8	9	10	
ON	V8	V7	V6	V5	V4	V3	V2	S1	S0	A12	E58
OFF											

ADDRESS SWITCHPACK

	1	2	3	4	5	6	7	8	9	10	
ON	A11	A10	A9	A8	A7	A6	A5	A4	A3	A2	E57
OFF											

V = VECTOR BIT S1 = BUFFERING
A = ADDRESS BIT S0 = EXTENDED FEATURES

JUMPERS

W1	BIRQ5
W2	BIRQ7
W3	BIRQ6
W4	BUS GRANT CONTINUITY
W5	BUS GRANT CONTINUITY
W6	SCLOCK ENABLE (USED DURING FACTORY REPAIR ONLY)


AS SHIPPED

OUT
OUT
OUT
IN
IN
IN

CS-2450


Figure A-1 M7196 Switch and Jumper Identification

M7196 VECTOR AND ADDRESS SWITCHES



CS-2468

Figure A-2 M7196 Vector and Address Switches



CS-2451

TAPE TRANSPORT UNIT SELECT SWITCH





Figure A-3 Transport Switch and Terminator Identification

APPENDIX B
MANUAL LOADING

If the autoloading routine does not successfully load the tape, the manual loading procedure may be used. Refer to Figure B-1 and proceed as follows:


1. Switch off the tape transport power.
2. Raise the cabinet top cover by grasping the handle on the top cover and lifting. When the top cover is raised far enough, the support arm latches to keep the cover up.
3. Raise the top cover of the tape transport unit by reaching in through the front panel door and pushing upward on the front of the top cover.
4. Ensure that there are no foreign objects in the tape path.
5. Place the reel of tape on the supply hub. Ensure that it is evenly seated on the hub, and then close the front door.
6. Thread the tape along the tape path as shown in Figure B-2. Carefully move the tachometer assembly away from the takeup hub and wrap the tape clockwise around the hub. Wrap the tape just short of one complete turn. Note that the tape should not overwind at this point (i.e., there should be a short section of the takeup hub that has no tape on it yet).
7. Gently move the tachometer assembly back against the hub. (The tape should pass between the tachometer and the takeup hub.)
8. Check that the tape is seated correctly on the guides and threaded properly over the head assembly. Remove any excess slack by gently turning the supply reel counterclockwise.
9. Turn the takeup hub clockwise to wrap two additional turns of tape on the hub. Ensure that the tape does not ride up and extend over the top surface of the hub.
10. Close the top covers of the tape transport and the cabinet.
11. Switch on the tape transport power.
12. Press ENTER, with ENTER depressed, press LOAD. When the LOAD indicator stops blinking, the tape is loaded and ready to be switched on-line.

TAPE TRANSPORT
TOP COVER SUPPORT
CABINET TOP
COVER SUPPORT



CS-2444

Figure B-1 Accessing the Tape Path Area



CS-2467

Figure B-2 Tape Threading Path

·Fold Here·

Do Not Tear — Fold Here and Staple

digital



No Postage
Necessary
if Mailed in the
United States

BUSINESS REPLY MAIL

FIRST CLASS PERMIT NO. 33 MERRIMACK, NH

POSTAGE WILL BE PAID BY ADDRESSEE

**Digital Equipment Corporation
Educational Services/Quality Assurance
12 Crosby Drive, BU/E08
Bedford, MA 01730**



