
# TEK 8540

8- and 16-bit emulators
Flexible host communications
package
Compatible with Tektronix
8560 Multi-user Software
Development Unit
Symbolic references

# INTEGRATION UNIT



The Tektronix 8540 Integration Unit is used with a 8560 Multiuser Software Development Unit or a general host computer, to integrate, test and debug microprocessor based software. The 8540 supports the hardware and software integration phase of a microprocessor/microcomputer based design. The Tektronix 8560 or other host computer supports the software development task.

## **Application**

8540 support is employed when the software has been developed to the object code level and is ready to be tested with the hardware. The object code binary program is downloaded to the 8540 and stored in its resident program memory or, if available, in the prototype's own memory. If the prototype hardware is not available, the software can be executed on the 8540 emulator processor using Mode 0 emulation.

A wide variety of emulators are available for in-circuit testing and debugging. For in-circuit testing, the emulator probe replaces the microprocessor chip in the prototype. In emulation mode 1 or mode 2, the software can interact directly with the prototype hardware.

The designer controls and monitors the testing process via a CRT Terminal like the Tektronix CT8500.






Figure 1. 8540 Block Diagram

#### **Block Diagram**

As shown in figure 1, a block diagram of the 8540, the complete operating system is contained in 100k byte PROM/ROM memory. The operating system is loaded and executed in the 64k-byte system memory. User symbol table information is also stored in system memory.

Part of the 8540 memory system also contains a non-volatile EEPROM buffer to store command strings and firmware update information. Complex and repeated command sequences can be permanently stored and then recalled

by employing one user-definable string name. The EEPROM is also used to store update information for firmware maintenance.

The 8540 also includes 32k bytes of static program memory for use by the emulator processor. The static program memory can be expanded to 128k bytes and with the optional Memory Allocation Controller, segments of this memory can be mapped anywhere in the emulator processor's address range.

#### 8540/8560 System Configuration

Local Interface Configuration. The 8540 Integration Unit connects to the 8560 Multi-user Software Development Unit via a high speed serial interface. Interconnecting cable lengths of up to 2,000 feet can be accomodated without performance degradation. A specialized interface protocol is used between the 8540 and the 8560 to eliminate any errors that might occur in the transmission process.

Remote Interface Configuration. For remote configurations (greater than 2,000 feet), the 8540 can be connected to the 8560 via RS-232 compatible data sets. Typical intermediate range data sets can be used over dedicated lines for distances of approximately 8 kilometers (5 miles) at data rates up to 9600 baud. For longer distances, data sets can also be used in conjunction with dial-up phone lines.

Operating Modes. The Tektronix CT8500 CRT Terminal (or a user supplied RS-232 terminal) is the user's interface with the 8540/8560 system. Command and setup information is entered from the Terminal's keyboard and processed by the the 8560. Appropriate responses are routed to the CT8500 display. Any 8540 commands are first routed to the 8560 and then sent to the 8540. A local mode is also available so the user can communicate directly with the 8540. (The 8540 can be configured to operate through a separate 8560 port with no terminal attached.)

#### 8540 (With Option 1 Comm Interface) Host Computer Configuration

The 8540 Integration Unit is interfaced to a host computer via an RS-232 serial port. Data bytes are ASCII encoded and transmitted asynchronously at speeds up to 9600 baud between the 8540 and the host computer. For local interface configurations (up to 50 feet), the 8540 can be hardwired directly to the host computer using a standard RS-232 cable. For remote




Figure 2. 8540/8560 System configuration.




Figure 3. 8540/General host system configuration.

configurations (more than 50 feet) the 8540 interfaces to the host computer via a data set arrangement. Data sets can connect over moderate distances using dedicated lines or virtually unlimited distances with conventional phone lines.

The 8540 can communicate with a host computer in several modes including:

Local Mode. In this mode the terminal communicates directly with the 8540 operating system to control the emulation and debugging process.

Terminal Transparent Mode. In this mode the terminal communicates with a host computer using standard protocol; keyboard data is transmitted to the host and host data is displayed on the terminal's display screen.

Formatted Upload/Download. In this mode microprocessor object code is transferred between the host computer and the 8540 program (emulation) memory. Binary data is encoded into Extended TEKHEX format and transmitted in message blocks. TEKHEX formatting, used by the 8001, is also supported. Checksum information is included in the message blocks to allow detection of communication errors.

Details of TEKHEX encoding and protocol are included in the 8540 System Users Manual.

#### **Emulation Support**

When a program is ready for testing, the object module is downloaded from the host computer (or 8560) into 8540 emulator memory. When a symbol table is included with the object module, it is also downloaded and stored in a separate portion of system memory. Program symbols can then be used to reference memory locations instead of the absolute addresses.

The object code is now executed by the emulator processor under control of the 8540 debugging system. Trace displays to the screen (or line printer) show all pertinent information including instruction mneumonics, processor status and any program symbols. The user can set breakpoints to stop in critical sections or use the trace display to show selected instructions or address ranges.

There are three progressive emulation modes available in the 8540. In the first (mode 0) the 8540 supplies all memory, clock, and interface signals to the emulator processor. No prototype hardware is required. In the second (mode 1) the clock and interface signals are provided by the

prototype hardware. The emulator processor connects to the prototype microprocessor socket via the prototype control probe. The program under test still resides in the 8540 but as debugging progresses, it can be gradually transferred (mapped) over to the prototype's memory. In the third (mode 2) all of the program is transferred to prototype memory. The 8540 still maintains control of program execution through the debugging system. For more specific emulator support information. refer to the appropriate data sheet for each (supported) emulator.

#### **Diagnostics**

The 8540 has a complex diagnostic subsystem. On each power-up cycle, diagnostic firmware checks all available 8540 memory and verifies that all boards are functional.

# Trigger Trace Analyzer (Optional)

The Trigger Trace Analyzer (TTA), optional equipment for the 8540 is a powerful debugging tool. It monitors program flow in real time and allows sophisticated control and analysis of the emulator processor. The TTA stores program information in a high-speed 255-event buffer. Each event contains 63-bits of information; up to 24-bits of address, 16-bits of data, 8-bits of processor information, and 8-bits of external probe information. TTA information is displayed on the terminal in processor specific mnemonics along with all pertinent register and flag information.

#### **PROM Programmer (Optional)**

The PROM Programmer, optional equipment for the 8540 is a general purpose controller unit with plug-in adapter modules. Each module supports a range or family of programmable devices. Functions include: READ WRITE and COMPARE.

#### CT8500 Terminal (Optional)

The CT8500 Terminal is an optional peripheral that is recommended for use with the 8540 in system applications. It is connected to the 8540 system controller as shown in figure 1 (block diagram). The CT8500 features: a detachable typewriter keyboard with programmable function keys, split screen operation, scrolling and paging, 4k display memory, and a full duplex RS-232C interface.

#### Compatibility

The 8540 Integration Unit is compatible with existing 8001 Microprocessor Lab support software (8540/General host configuration). Additional support software will be required for 16-bit emulators to accomodate downloading of large address object files and symbol table information.

#### 8540 General Specifications

Operating System (Software): DOS/50 derivative (contained in 8k PROM/ROM's) i.e., 96k bytes, command interpreter and kernel 20k bytes diagnostics; 4k bytes patch and command storage (EEPROM)

#### Card Slot Usage

#### Standard Boards:

system controller emulator controller system memory (64k RAM) program memory, (32k RAM) system memory (224k PROM/ROM)

#### **Empty Board Slots:**

system side = I slot program side = 11 slots

#### **Electrical Characteristics**

Nominal Operating Voltage: 115 Vac and 230 Vac at 60 Hz

Power Requirements: 700 W max

Line Voltage Ranges: 90 to 132 Vac and I80 to 250 Vac.

Line Frequency Range: 48 to 66

Ηz

#### I/O Ports

I/O Ports: J100 (8560 Interface) J101 (remote DTE male); J102 (remote DCE female) J103 (Line Printer, Aux); J104 (Terminal)

#### I/O Port Data Rates:

J100(HSI) = 153.6k baud J101, J102, J103, J104 = 110/extCLK, 150, 300, 600, 1200, 2400, 4800. 9600 baud

#### Reliability

MTBF: 6700 hr (calculated) MTTR Board: 0.5 hr. MTTR Component: 1.5 hr.

Standards Compliance: UL1244: CSA Bulletin 556B; IEC 348

#### **Environmental Characteristics**

#### Temperature Range

Operating: 0°C to 50°C (32°F to

Storage: 55°C to 75°C (67°F to

167°F)

#### Altitude Range

Operating: Sea level to 4500 m

(15.000 ft)

Storage: Sea level to 15000 m

(50.000 ft)

Humidity: 0 to 90% noncondensing (0 to 50°C)

#### **Physical Characteristics**

#### Cabinet Dimensions:

Height = 280 mm (11 in)Width = 430 mm (17 in)Depth = 585 mm (23 in)

Cabinet Weight: 26 kg (57.5 lb) Shipping Weight: 35 kg (77.5 lb)\*

Cabinet Color: 3 tone; ivory/gray, smoke tan, earth brown

\*Standard configuration only, no options.

#### Communications Interface (Optional)

Interface signals are routed to and from the 8540 system controller board via rear panel connectors J101 (male) and J102 (female). Table 2 lists the J101/J102 pin numbers and corresponding signal names and descriptions. Baud rate on transmitted data and received data is selectable from 110 to 9600 baud. All signals are RS-232-C compatible.

## Table 2. Interface signals (Option 1, Comm Interface)

Signal Name	Circuit	J101 DTE	J102 DCE	Pin
GND	AA	Protective ground	Protective ground	1
Tx	BA	Out	ln '	2 <sup>a</sup>
Rx	BB	In	Out	3ª
RTS	CA	Out <sup>b</sup>	In <sup>c</sup>	4
CTS	CB	Ind	Out <sup>e</sup>	5
DSR	CC	In <sup>f</sup>	Out	6
GND	AB	Signal ground	Signal ground	7
DCD	CF	In <sup>g</sup>	Out	8
DTR	CD	Out	In <sup>h</sup>	20

<sup>&</sup>lt;sup>a</sup> Selectable, 110-9600 baud

#### Standard Accessories

Power Cord
8540 System Users manual 070-3939-00*
8540 Installation Guide
8540 System Reference Booklet 070-3992-00*
Simplifying Microcomputer Based Product Design
*Orderable after Oct. 15, 1981

# Ordering Information 8540 Integration Unit

Factory Configuration Order as 8540 Option No.

#### System Options

8550F02 8540F01	32k Memory Board Comm Interface	02		
	package	01		
8540F03	TTA and Control Firmware	03		
8550F04	64k Program Memory	04		
8550F05	128k Program	04		
055050001	Memory	05		
8550F3001 8550F31	PROM Controller 2716/32 PROM	30		
	module	31		
8550F32	8748/41A/55 PROM	1 32		
	Rackmount ver-			
N/A	sion*	47		
IN/A	220 V, European plug	A1		
N/A	240 V, UK	A2		
N/A	240 V, Australian			
	plug	А3		
N/A	240 V, N. American			
	plug	A4		
Emulators				
8300E0401	Z80A Emulator			
	and Control	00		
8300E0601	Firmware 8085A Emulator	2C		
030000001	and Control			
		_		

\* for field installed rackmount version, order 040-1020-00

8300E20

8300E28

Firmware

Z8001/2 Emulator

68xx Emulator

2E

2M

2Q

b DTE 1, DTE 2 modes; goes high when data to send DCE mode; must be high before 8540 accepts data DTE 1 mode; must be high before 8540 sends data DCE mode; goes low when 8540 sends data

<sup>&</sup>lt;sup>f</sup> DTE 2 mode; must be high before 8540 sends data

<sup>&</sup>lt;sup>9</sup> DTE 1, DTE 2 mode; must be high before 8540 accepts data

h DCE mode; must be high before 8540 sends data

#### **Probes**

8300P04	Z80A Probe	3D
8300P06	8085A Probe	3F
8300P2001	Z8001 Probe and	
	Control Firmware	3Q
8300P2201	Z8002 Probe and	
	Control Firmware	3S
8300P2801	6809 Probe and	
	Control Firmware	3V

#### Optional Accessories and Interface Cables 8540 to 8560

HSI Cable, 24.35 m
(8 ft) 012-1009-00
HSI Cable, 6.1 m
(20 ft) 012-1008-00
HSI Cable, 15.24 m
(50 ft) 012-1007-00
HSI Cable, 76.2 m
(250 ft) 012-1010-00

#### 8540 To Host/Data Set

RS-232 Interface Cable, 6.1 m (20 ft) . . . . . . . . . 012-0757-00 (for general data set and host connection)

### Peripheral Options

CT8500 CRT Terminal LP8200 Line Printer (220 V at 50 Hz, 4 W) For further information, contact:

U.S.A., Asia, Australia, Central & South America, Japan Tektronix, Inc. P.O. Box 4828 Portland, OR 97208 Phone: 800/547-6711 Oregon only 800/452-6773 Telex: 910-467-8708 Cable: TEKTRONIX

Europe, Africa, Middle East Tektronix International, Inc. European Marketing Centre Postbox 827 1180 AV Amstelveen The Netherlands Telex: 18312

Canada Tektronix Canada Inc. P.O. Box 6500 Barrie, Ontario L4M 4V3 Phone: 705/737-2700

Tektronix sales and service offices around the world: Argentina, Australia, Austria, Belgium, Bolivia, Brazil, Canada, Chile, Colombia, Costa Rica, Denmark, East Africa, Ecuador, Egypt, El Salvador, Federal Republic of Germany, Finland, France, Greece, Hong Kong, Iceland, India, Indonesia, Iraq, Israel, Italy, Ivory Coast, Japan, Jordan, Korea, Kuwait, Lebanon, Malaysia, Mexico, Morocco, The Netherlands, New Zealand, Norway, Pakistan, Panama, Peru, Philippines, Portugal, Republic of South Africa, Saudi Arabia, Singapore, Spain, Sri Lanka, Sudan, Surinam, Sweden, Switzerland, Syria, Taiwan, Thailand, Turkey, Tunisia, United Kingdom, Uruguay, Venezuela, Zambia.

Copyright © 1981, Tektronix, Inc. All rights reserved. Printed in U.S.A. Tektronix products are covered by U.S. and foreign patents, issued and pending. Information in this publication supersedes that in all previously published material. Specification and price change privileges reserved. TEKTRONIX, TEK, SCOPE-MOBILE, and are registered trademarks of Tektronix, Inc. TELEQUIPMENT is a registered trademarks of Tektronix U.K. Limited.

