





```
0001      Subroutine ERFPRC4INI ( Array_addr, Array_size )
0002
0003      C
0004      C Version:      'V04-000'
0005      C
0006      C*****
0007      C*
0008      C* COPYRIGHT (c) 1978, 1980, 1982, 1984 BY
0009      C* DIGITAL EQUIPMENT CORPORATION, MAYNARD, MASSACHUSETTS.
0010      C* ALL RIGHTS RESERVED.
0011      C*
0012      C* THIS SOFTWARE IS FURNISHED UNDER A LICENSE AND MAY BE USED AND COPIED
0013      C* ONLY IN ACCORDANCE WITH THE TERMS OF SUCH LICENSE AND WITH THE
0014      C* INCLUSION OF THE ABOVE COPYRIGHT NOTICE. THIS SOFTWARE OR ANY OTHER
0015      C* COPIES THEREOF MAY NOT BE PROVIDED OR OTHERWISE MADE AVAILABLE TO ANY
0016      C* OTHER PERSON. NO TITLE TO AND OWNERSHIP OF THE SOFTWARE IS HEREBY
0017      C* TRANSFERRED.
0018      C*
0019      C* THE INFORMATION IN THIS SOFTWARE IS SUBJECT TO CHANGE WITHOUT NOTICE
0020      C* AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT
0021      C* CORPORATION.
0022      C*
0023      C* DIGITAL ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS
0024      C* SOFTWARE ON EQUIPMENT WHICH IS NOT SUPPLIED BY DIGITAL.
0025      C*
0026      C*
0027      C*****
0028      C
0029      C
0030      C
0031      C      AUTHOR: Elliott A. Drayton      CREATION DATE: 27-Jan-1983
0032      C
0033      C      Functional description:
0034      C
0035      C      This is the initialization module for the loadable image ERFPROC4.EXE.
0036      C      After ERFPRC4 has been loaded this routine is called to return
0037      C      the information from its tables. These tables specify which error
0038      C      log packets this loadable image will process. The tables consist of:
0039      C
0040      C      ENTRY TYPE, DEVICE CLASS, MODULE VERSION, TRANSFER VECTOR OFFSET
0041      C
0042      C      The ENTRY TYPE value is the packet type identifier for the packets that
0043      C      this loadable image will process.
0044      C
0045      C      The DEVICE CLASS value specifies the class of the packet that will
0046      C      be process by this loadable image.
0047      C
0048      C      The MODULE VERSION is used to determine if the module in this image
0049      C      is the one to use. This is accomplished by the root image comparing
0050      C      this value against the value in the master tables in the root image.
0051      C
0052      C      The TRANSFER VECTOR OFFSET is the index to the transfer vector to
0053      C      be used for a specific device or entry type. For example, the transfer
0054      C      vectors for the disk image are ordered as:
0055      C
0056      C      INITDISK 0      ! a routine similar to this one
0057      C      MASSDISK 1     ! a device specific routine
```

F 13  
16-Sep-1984 00:04:19  
5-Sep-1984 13:58:16

VAX-11 FORTRAN V3.4-56  
DISK\$VMSMASTER:[ERF.SRC]INITPROC4.FOR;1

0058 C  
0059 C  
0060 C  
0061 C  
0062 C  
0063 C  
0064 C  
0065 C  
0066 c  
0067 C\*\*

RKDISK 2  
RLDISK 3  
ECT.

Modified by:

SR0001 Sharon Reynolds 17-Mar-1983  
Change tables to support UBA interrupts and errors,  
MBA interrupts, and undefined interrupts.

0068  
0069  
0070  
0071  
0072  
0073  
0074  
0075  
0076  
0077  
0078  
0079  
0080  
0081  
0082  
0083  
0084  
0085  
0086  
0087  
0088  
0089  
0090  
0091  
0092  
0093  
0094  
0095  
0096  
0097  
0098  
0099  
0100  
0101  
0102  
0103

DEFINE ENTRY TYPES

```
Parameter EMB$K_UBA = 9      : UBAINT module  
                             : 11/780 unibus adapter error  
  
Parameter EMB$K_UE = 11     : UBAERR module  
                             : 11/730 unibus error %XB  
  
Parameter EMB$K_MBA = 12    : MBAINT module  
                             : 11/780 massbus adapter error %XC  
  
Parameter EMB$K_UI = 97     : UNDEFINED module  
                             : Undefined interrupt %X61  
  
Parameter Zero = 0  
Parameter V1 = 1           : Device module version number  
  
Parameter      Maxtypes = 4  
Integer*4      Array_addr, Array_size  
Integer*2      Proc4_codes ( 4 * Maxtypes )  
  
Data           Proc4_codes /  
1 EMB$K_UBA, zero, V1, 1,   : 11/780 unibus adapter error  
2 EMB$K_UE, zero, V1, 2,   : 11/730 unibus error  
3 EMB$K_MBA, zero, V1, 3,  : 11/780 massbus adapter error  
4 EMB$K_UI, zero, V1, 4,   : Undefined interrupt  
  
Array_addr = %LOC (proc4_codes(1))  
Array_size = Maxtypes  
  
Return  
End
```

## PROGRAM SECTIONS

Name	Bytes	Attributes
0 \$CODE	19	PIC CON REL LCL SHR EXE RD NOWRT LONG
2 \$LOCAL	32	PIC CON REL LCL NOSHR NOEXE RD WRT LONG
Total Space Allocated	51	

## ENTRY POINTS

Address	Type	Name
0-00000000		ERFPRC4INI

## VARIABLES

Address	Type	Name	Address	Type	Name
AP-00000004a	1*4	ARRAY_ADDR	AP-00000008a	1*4	ARRAY_SIZE

## ARRAYS

Address	Type	Name	Bytes	Dimensions
2-00000000	1*2	PROC4_CODES	32	(16)

## COMMAND QUALIFIERS

FORTRAN /LIS=LIS\$:INITPROC4/OBJ=OBJ\$:INITPROC4 MSRC\$:INITPROC4

/CHECK=(NOBOUNDS,OVERFLOW,NOUNDERFLOW)

/DEBUG=(NOSYMBOLS,TRACEBACK)

/STANDARD=(NOSYNTAX,NOSOURCE FORM)

/SHOW=(NOPREPROCESSOR,NOINCLUDE,MAP)

/F77 /NOG\_FLOATING /I4 /OPTIMIZE /WARNINGS /NOD\_LINES /NOCROSS\_REFERENCE /NOMACHINE\_CODE /CONTINUATIONS=19

## COMPILATION STATISTICS

Run Time: 0.75 seconds  
 Elapsed Time: 3.58 seconds  
 Page Faults: 95  
 Dynamic Memory: 155 pages

