


```

YY      YY  FFFFFFFF  DDDDDDD  RRRRRRR  I I I I I  VV      VV  EEEEEEEEE  RRRRRRR
YY      YY  FFFFFFFF  DDDDDDD  RRRRRRR  I I I I I  VV      VV  EEEEEEEEE  RRRRRRR
YY      YY  FF        DD          RR        RR        II      II  EE          RR        RR
YY      YY  FF        DD          RR        RR        II      II  EE          RR        RR
  YY    YY  FF        DD          RR        RR        II      II  EE          RR        RR
  YY    YY  FF        DD          RR        RR        II      II  EE          RR        RR
    YY  YY  FFFFFFFF  DD          RRRRRRR  II      II  EEEEEEEEE  RRRRRRR
    YY  YY  FFFFFFFF  DD          RRRRRRR  II      II  EEEEEEEEE  RRRRRRR
    YY  FF        DD          RR        RR        II      II  EE          RR        RR
    YY  FF        DD          RR        RR        II      II  EE          RR        RR
    YY  FF        DD          RR        RR        II      II  EE          RR        RR
    YY  FF        DD          RR        RR        II      II  EE          RR        RR
    YY  FF        DD          RR        RR        II      II  EE          RR        RR
    YY  FF        DDDDDDD  RR        RR        II      II  EEEEEEEEE  RR        RR
    YY  FF        DDDDDDD  RR        RR        I I I I I  VV      VV  EEEEEEEEE  RR        RR

```

```

LL      I I I I I  SSSSSSS
LL      I I I I I  SSSSSSS
LL      II        SS
LL      II        SS
LL      II        SS
LL      II        SS
LL      II        SSSSSS
LL      II        SSSSSS
LL      II        SS
LL      II        SS
LL      II        SS
LL      II        SS
LLLLLLLL  I I I I I  SSSSSSS
LLLLLLLL  I I I I I  SSSSSSS

```

(1)	62	DECLARATIONS
(1)	200	REGISTER DEFINITIONS
(1)	332	SPEED CONVERSION TABLES
(1)	390	CONTROLLER INITIALIZATION
(1)	440	CONTROLLER INITIALIZATION
(1)	516	UNIT INITIALIZATION
(1)	668	MAINTENANCE ROUTINES
(1)	742	OUTPUT MODEM CONTROL
(1)	783	RECEIVER INTERRUPT SERVICE
(1)	900	START I/O ROUTINE
(1)	994	PORT DMA ROUTINES
(1)	1290	PORT ROUTINES STOP, RESUME, XON, XOFF
(1)	1437	OUTPUT INTERRUPT SERVICE
(1)	1653	SET SPEED, PARITY PARAMETERS

```

0000 1      .TITLE YFDRIVER - Port Driver for DHU/DHV
0000 2      .IDENT 'V04-000'
0000 3      :
0000 4      :*****
0000 5      :*
0000 6      :* COPYRIGHT (c) 1978, 1980, 1982, 1984 BY
0000 7      :* DIGITAL EQUIPMENT CORPORATION, MAYNARD, MASSACHUSETTS.
0000 8      :* ALL RIGHTS RESERVED.
0000 9      :*
0000 10     :* THIS SOFTWARE IS FURNISHED UNDER A LICENSE AND MAY BE USED AND COPIED
0000 11     :* ONLY IN ACCORDANCE WITH THE TERMS OF SUCH LICENSE AND WITH THE
0000 12     :* INCLUSION OF THE ABOVE COPYRIGHT NOTICE. THIS SOFTWARE OR ANY OTHER
0000 13     :* COPIES THEREOF MAY NOT BE PROVIDED OR OTHERWISE MADE AVAILABLE TO ANY
0000 14     :* OTHER PERSON. NO TITLE TO AND OWNERSHIP OF THE SOFTWARE IS HEREBY
0000 15     :* TRANSFERRED.
0000 16     :*
0000 17     :* THE INFORMATION IN THIS SOFTWARE IS SUBJECT TO CHANGE WITHOUT NOTICE
0000 18     :* AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT
0000 19     :* CORPORATION.
0000 20     :*
0000 21     :* DIGITAL ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS
0000 22     :* SOFTWARE ON EQUIPMENT WHICH IS NOT SUPPLIED BY DIGITAL.
0000 23     :*
0000 24     :*
0000 25     :*****
0000 26     :
0000 27     :++
0000 28     : FACILITY:
0000 29     :
0000 30     :     VAX/VMS TERMINAL DRIVER
0000 31     :
0000 32     : ABSTRACT:
0000 33     :
0000 34     :     DHU/DHV ASYNC PORT DRIVER
0000 35     :
0000 36     : AUTHOR:
0000 37     :
0000 38     :     RICK SPITZ/ANDREW PALKA
0000 39     :
0000 40     : Revision history:
0000 41     :
0000 42     :     V03-004 LMP0275      L. Mark Pilant,      12-Jul-1984 21:05
0000 43     :     Initialize the ACL info in the ORB to be a null descriptor
0000 44     :     list rather than an empty queue. This avoids the overhead
0000 45     :     of locking and unlocking the ACL mutex, only to find out
0000 46     :     that the ACL was empty.
0000 47     :
0000 48     :     V03-003 EMD0097      Ellen M. Dusseault  30-Apr-1984
0000 49     :     Fix a few bugs - device timeout problem and test the
0000 50     :     abort flag first to see if it is necessary to clear it.
0000 51     :     Also add DEV$M_NNM characteristic to DEVCHAR2 so that
0000 52     :     these devices will have the prefix "node$".
0000 53     :
0000 54     :     V03-002 TMH0002      Tim Halvorsen      14-Apr-1984
0000 55     :     Fix references to UCBS$L_OWNUIC and UCBSW_VPROT to use ORB.
0000 56     :
0000 57     :     V03-001 EMD0070      Ellen M. Dusseault  30-MAR-1984

```

YFDRIIVER
V04-000

- Port Driver for DHU/DHV

M 5

16-SEP-1984 02:26:48 VAX/VMS Macro V04-00
5-SEP-1984 04:17:43 [TTDRVR.SRC]YFDRIIVER.MAR;1

Page 2
(1)

0000 58 :
0000 59 :
0000 60 :--

Modify to make code more efficient.

YFDI
V04-

```

0000 62          .SBTTL  DECLARATIONS
0000 63
0000 64  :
0000 65  : EXTERNAL DEFINITIONS:
0000 66  :
0000 67          $PRDEF
0000 68          $ACBDEF          : DEFINE ACB
0000 69          $CRBDEF          : DEFINE CRB
0000 70          $DCDEF           : DEFINE ADAPTER TYPES
0000 71          $DDBDEF          : DEFINE DDB
0000 72          $DEVDEF          : DEFINE DEVICE TYPES
0000 73          $DYNDDEF         : DEFINE DYNAMIC STRUCTURE TYPES
0000 74          $IDBDEF          : DEFINE IDB OFFSETS
0000 75          $IODEF           : DEFINE I/O FUNCTION CODES
0000 76          $IRPDEF          : DEFINE IRP
0000 77          $ORBDEF          : DEFINE OBJECT RIGHTS BLOCK
0000 78          $SSDEF           : DEFINE SYSTEM STATUS CODES
0000 79          $TTYDEF          : DEFINE TERMINAL DRIVER SYMBOLS
0000 80          $TTDEF           : DEFINE TERMINAL TYPES
0000 81          $TT2DEF          : DEFINE EXTENDED CHARACTERISTICS
0000 82          $TQEDEF          : DEFINE TIMER QUEUE OFFSETS
0000 83          $UCBDEF          : DEFINE UCB
0000 84          $UBADEF          : DEFINE UBA
0000 85          $VECDEF          : DEFINE VECTOR FOR CRB
0000 86          $TTYMACS         : DEFINE TERMINAL DRIVER MACROS
0000 87          $TTYDEFS         : DEFINE TERMINAL DRIVER SYMBOLS
0000 88          $TTYMODEM        : DEFINE MODEM DEFINITIONS
0000 89
0000 90
0000 91
0000 92  :
0000 93  : LOCAL STORAGE
0000 94  :
0000 95          .PSECT $$$105_PROLOGUE
0000 96
0000 97  :
0000 98  : Driver prologue table:
0000 99  :
0000 100
0000 101  :
0000 102  : Note. The DPT says that this driver has a UBA adapter type.
0000 103  : In fact it will work with a Q-bus VAX, either mapped or unmapped
0000 104  :
0000 105  YFSDPT::
0000 106          DPTAB          - : DRIVER START
0000 107          END=YF$END,-    : DRIVER PROLOGUE TABLE
0000 108          UCBSIZE=UCB$C TT LENGTH+4,- : End and offset to INIT's vectors
0000 109          FLAGS=DPT$M_NOUNLOAD,- : NO UNLOAD ALLOWED
0000 110          ADAPTER=UBA,-    : ADAPTER TYPE
0000 111          MAXUNITS=16,-   : Number of units to create
0000 112          DEFUNITS=16,-   : Number of units to create
0000 113          NAME=YFDRIVER,-   : NAME OF DRIVER
0000 114          VECTOR=PORT VECTOR,- : PORT DRIVER VECTOR TABLE
0000 115          DELIVER=YF$DELIVER : Unit delivery routine
0038 116          DPT_STORE INIT
0038 117          DPT_STORE UCB,UCB$B_FIPL,B,8 : FORK IPL
003C 118          DPT_STORE UCB,UCB$S_DEVCHAR,L,<- : CHARACTERISTICS

```

```

003C 119 DEVSM_REC!- ;
003C 120 DEVSM_AVL!- ;
003C 121 DEVSM_IDV!- ;
003C 122 DEVSM_ODV!- ;
003C 123 DEVSM_TRM!- ;
003C 124 DEVSM_CCL> ;
0043 125 DPT_STORE UCB,UCBSL_DEVCHAR2,L,- ; DEVICE CHARACTERISTICS
0043 126 <DEVSM_NNM> ; PREFIX WITH 'NODES'
004A 127 DPT_STORE UCB,UCBSB_DEVCLASS,B,DC$ TERM;
004E 128 DPT_STORE UCB,UCBSB_TT_DETYPE,B,TT$ UNKNOWN ; TYPE
0052 129 DPT_STORE UCB,UCBSW_TT_DESIZE,@W,TTY$GW_DEFBUF ; BUFFER SIZE
0059 130 DPT_STORE UCB,UCBSL_TT_DECHAR,@L,TTY$GL_DEFCHAR ; DEFAULT CHARACTERS
0060 131 DPT_STORE UCB,UCBSL_TT_DECHA1,@L,TTY$GL_DEFCHAR2; DEFAULT CHARACTERS
0067 132 DPT_STORE UCB,UCBSW_TT_DESPEE,@B,TTY$GB_DEFSPEED; DEFAULT SPEED
006E 133 DPT_STORE UCB,UCBSW_TT_DESPEE+1,@B,TTY$GB_RSPEED; DEFAULT RSPEED
0075 134 DPT_STORE UCB,UCBSB_TT_DEPARI,@B,TTY$GB_PARITY ; DEFAULT PARITY
007C 135 DPT_STORE UCB,UCBSB_DEVTYPE,B,TT$ UNKNOWN ; TYPE
0080 136 DPT_STORE UCB,UCBSW_DEVBUFSIZ,@W,TTY$GW_DEFBUF ; BUFFER SIZE
0087 137 DPT_STORE UCB,UCBSL_DEVDEPEND,@L,TTY$GL_DEFCHAR ; DEFAULT CHARACTERS
008E 138 DPT_STORE UCB,UCBSL_DEVDEPN2,@L,TTY$GL_DEFCHAR2; DEFAULT CHARACTERS
0095 139 DPT_STORE UCB,UCBSW_TT_SPEED,@B,TTY$GB_DEFSPEED ; DEFAULT SPEED
009C 140 DPT_STORE UCB,UCBSW_TT_SPEED+1,@B,TTY$GB_RSPEED ; DEFAULT RSPEED
00A3 141 DPT_STORE UCB,UCBSB_DIPL,B,21 ; DEVICE IPL
00A7 142 DPT_STORE UCB,UCBSL_TT_WFLINK,L,0 ; Zero write queue.
00AE 143 DPT_STORE UCB,UCBSL_TT_WBLINK,L,0 ; Zero write queue.
00B5 144 DPT_STORE UCB,UCBSL_TT_RTIMOU,L,0 ; Zero read timed out disp.
00BC 145 DPT_STORE ORB,ORBSB_FLAGS,B,- ; Protection block flags
00BC 146 ; ZORBSM_PROT 16> ; SOGW protection word
00C0 147 DPT_STORE ORB,ORBSW_PROT,@W,TTY$GW_PROT ; Default allocation protect
00C7 148 DPT_STORE ORB,ORBSL_OWNER,@L,TTY$GL_OWNUIC ; Default owner UIC
00CE 149 DPT_STORE DDB,DDBSL_DDT,D,YF$DDT
00D3 150 DPT_STORE REINIT
00D3 151 DPT_STORE CRB,CRBSL_INTD+4,D,YF$INTINP ; RECEIVER INTERRUPT
00D8 152 DPT_STORE CRB,CRBSL_INTD2+4,D,YF$INTOUT ; TRANSMITTER INTERRUPT
00DD 153 DPT_STORE CRB,CRBSL_INTD+VECSL_INITIAL,D,YF$INITIAL ; CONTROLLER INIT
00E2 154 DPT_STORE CRB,CRBSL_INTD+VECSL_UNITINIT,D,YF$INITLINE; UNIT INIT
00E7 155
00E7 156 DPT_STORE END
0000 157
0000 158 DDTAB DEVNAM = YF,- ; DUMMY DHU PORT DRIVER DISPATCH TABLE
0000 159 START = 0,-
0000 160 FUNCTB = C
00000038 161 .PSECT $$$115_DRIVER, LONG
0038 162
0038 163 ;
0038 164 ; THE ASSOCIATED CLASS DRIVER USES THIS TABLE TO COMMAND THE PORT DRIVER.
0038 165 ; THE ADDRESS OF THIS TABLE IS CONTAINED IN THE TERMINAL UCB EXTENSION AREA.
0038 166 ; THE OFFSET DEFINITIONS ARE DEFINED BY TTYDEFS.
0038 167 ;
00000000 0038 168 YFSL_SIL_ERROR::
0038 169 .LONG 0 ; Indicates Silo not empty at interrupt
00000000 003C 170 YFSL_ERROR::
0040 171 .LONG 0 ; Indicates DMA count non zero at
; interrupt
00000000 0040 173 YFSL_DMAXMT_ERROR::
0040 174 .LONG 0 ; Indicates DMA error bit set by DHU
0044 175 YFSL_INACT_ERROR::

```

```
00000000 0044 176 .LONG 0 ; Indicates UCBSM_INT clear at interrupt
          0048 177 PORT_VECTOR:
          0048 178
          0048 179 ;
          0048 180 ; DHU/DHV SPECIFIC DISPATCH TABLE
          0048 181 ;
          0048 182 $VECINI YF,YF$NULL
          0080 183 $VEC STARTIO,YF$STARTIO ; START NEW OUTPUT
          004C 184 $VEC SET_LINE,YF$SET_LINE ; SET NEW SPEED/PARITY
          0054 185 $VEC DS_SET,YF$DS_SET ; SET OUTPUT MODEM SIGNALS
          0058 186 $VEC XON,YF$XON ; SEND XON SEQUENCE
          005C 187 $VEC XOFF,YF$XOFF ; SEND XOFF SEQUENCE
          0060 188 $VEC STOP,YF$STOP ; STOP OUTPUT
          0064 189 $VEC ABORT,YF$ABORT ; ABORT OUTPUT IN PROGRESS
          006C 190 $VEC RESUME,YF$RESUME ; RESUME STOPPED OUTPUT
          0070 191 $VEC MAINT,YF$MAINT ; INVOKE MAINTENANCE FUNCTION
          007C 192 $VEC FORKRET,YF$FORK ; PORT FORK CALLBACK
          0080 193 $VECEND
          0084 194
          0084 195 ;
          05 0084 196 YF$NULL: ; NULL PORT ROUTINE
          0084 197 RSB
          0085 198
```

```

0085 200 .SBTTL REGISTER DEFINITIONS
0085 201
0085 202
00000000 0085 203 DHUCSR = 0 ; Base CSR
00000002 0085 204 DHURBF = 2 ; Received data fifo
00000002 0085 205 DHUTXC = 2 ; DHV single char register
00000002 0085 206 DHUTCR = 2 ; DHU timer control
00000004 0085 207 DHULPR = 4 ; Line parameters
00000006 0085 208 DHUTXF = 6 ; Transmit FIFO
00000006 0085 209 DHUTFS = 6 ; Transmit FIFO size
00000007 0085 210 DHUSTT = 7 ; Modem status
00000008 0085 211 DHULCT = 8 ; Line control
0000000A 0085 212 DHUTBF1 = 10 ; low bits of address
0000000C 0085 213 DHUTBF2 = 12 ; High bits of address
0000000E 0085 214 DHUTCT = 14 ; Byte count
0085 215
0085 216
0085 217 :: CSR BIT DEFINITIONS ( CSR ) ( READ/WRITE )
0085 218 :: (NOTE: THIS REGISTER MUST ONLY BE READ IN RESPONSE TO A TRANSMIT INTERRUPT.
0085 219 :: TO LOAD AN INDIRECT REGISTER, ONLY WRITE OPERATIONS MAY BE USED.
0085 220 :: READ-MODIFY-WRITE OPERATIONS MUST NEVER BE USED)
0085 221
0085 222 $FIELD DHUCSR,0,<-
0085 223 <IADDR,4,M>,- ; INDIRECT REGISTER ADDRESS
0085 224 <1>,- ; DON'T USE THIS BIT
0085 225 <CLEAR,1,M>,- ; MASTER RESET
0085 226 <RCVINT,1,M>,- ; RECEIVER INTERRUPT ENABLE
0085 227 <1>,- ; DON'T USE THIS BIT
0085 228 <LINE,4,M>,- ; LINE NUMBER (0 - 15)
0085 229 <DMAERR,1,M>,- ; DMA error
0085 230 <DIGFAL,1,M>,- ; Diagnostic failed
0085 231 <SNDINT,1,M>,- ; TRANSMIT INTERRUPT ENABLE
0085 232 <SNDRDY,1,M>,- ; TRANSMITTER READY
0085 233 >
0085 234
0085 235 :: RECEIVER BUFFER ( CSR+2 ) ( READ ONLY )
0085 236
0085 237 $FIELD DHURCV,0,<-
0085 238 <BUF,8,M>,- ; RECEIVER DATA
0085 239 <LINE,4,M>,- ; LINE NUMBER (0 - 7)
0085 240 <PARERR,1,M>,- ; PARITY ERROR
0085 241 <FRAMER,1,M>,- ; FRAME ERROR
0085 242 <OVERRUN,1,M>,- ; OVERRUN ERROR
0085 243 <VALID,1,M>,- ; DATA VALID
0085 244 >
0085 245
0085 246 :: LINE PARAMETER REGISTER ( CSR+4 , Indirect register)
0085 247
0085 248
0085 249 $FIELD DHULPR,0,<-
0085 250 <1>,- ; DON'T USE THIS BIT
0085 251 <DIAG1,1,M>,- ; Diagnostics control
0085 252 <DIAG2,1,M>,- ; Diagnostics control
0085 253 <SIZE,2,M>,- ; CHARACTER SIZE
0085 254 <PARITY,1,M>,- ; PARITY ENABLE
0085 255 <ODD,1,M>,- ; ODD PARITY
0085 256 <STOP,1,M>,- ; NUMBER STOP BITS

```

```

0085 257 <RSPEED,4,M>,- ; RECEIVER LINE SPEED
0085 258 <TSPEED,4,M>,- ; TRANSMITTER LINE SPEED (BOTH RVC/TX FOR LINES 2-7)
0085 259 >
0085 260 :
0085 261 : LINE CONTROL INDIRECT REGISTER (CSR + 8, Indirect register)
0085 262 :
0085 263 :
0085 264 $VIELD DHULCT,0,<-
0085 265 <ABORT,1,M>,- ; Output abort
0085 266 <OAUTO,1,M>,- ; AUTO XON/OFF
0085 267 <RCV,1,M>,- ; RECEIVER ENABLE
0085 268 <BREAK,1,M>,- ; SEND BREAK
0085 269 <IAUTO,1,M>,- ; Incoming Auto flow enable
0085 270 <SNDOFF,1,M>,- ; Send XOFF
0085 271 <MAINT,2,M>,- ; Maintenance
0085 272 <MODEM,1,M>,- ; Modem control line
0085 273 <DTR,1,M>,- ; Data terminal ready
0085 274 <2>-
0085 275 <RTS,1,M>,- ; Request to send
0085 276 >
0085 277 :
0085 278 : Status register
0085 279 $VIELD DHUSTT,0,<-
0085 280 <3>-
0085 281 <CTS,1,M>,-
0085 282 <DCD,1,M>,-
0085 283 <RI,1,M>,-
0085 284 <1>-
0085 285 <DSR,1,M>,-
0085 286 >
0085 287 :
0085 288 ; Constant value for Base CSR
0085 289 ; Enables both receive and transmit interrupts
0085 290
0004040 0085 291 DHUCSR$C_BASE = <DHUCSR$M_RCVINT!DHUCSR$M_SNDINT>
0085 292 :
0085 293 : MACRO USED TO ACCESS INDIRECT REGISTERS
0085 294 :
0085 295 :
0085 296 .MACRO SETIND REG
0085 297 .IF B, REG
0085 298 MOVL UCBSL CRB(R5),R0 ; GET CRB ADDRESS
0085 299 MOVL @CRB$C_INTD+VECSL_IDB(R0),R0 ; GET CSR ADDRESS
0085 300 BISW3 #<DHUCSR$C_BASE>,-
0085 301 UCBSW_UNIT(R5),DHUCSR(R0); SELECT INDIRECT FIELD
0085 302 .IFF
0085 303 BISW3 #<DHUCSR$C_BASE>,-
0085 304 UCBSW_UNIT(R5),DHUCSR(REG); SELECT INDIRECT FIELD
0085 305 .ENDC
0085 306 .ENDM SETIND
0085 307 :
0085 308 :
0085 309 : Extra field in UCB
0085 310 : This field could be removed if 2 spare bits can be found in the UCB for
0085 311 : the use of the port driver. (This would save 4 bytes from the declared length
0085 312 : of the UCB)
0085 313

```

```
00000134 0085 314 UCBSB_DHUFLG = UCBSB_TT_LENGTH ; Allocate at end of previous ucb
0085 315
0085 316 $VIELD UCB,0,<-
0085 317 <MAP,1,M>,- ; Map registers available if 1
0085 318 <DHU,1,M>,- ; DHU if 1, DHV if 0
0085 319 <XOFF,1,M>,- ; XOFF if 1, XON if 0
0085 320 >
0085 321
0085 322 :: OUTPUT DELAY MACRO
0085 323 :: TO RELEASE THE UNIBUS
0085 324
0085 325 .MACRO DELAY
0085 326 .REPEAT 3
0085 327 NOP
0085 328 .ENDR
0085 329 .ENDM
0085 330
```

```

0085 332      .sbttl  SPEED CONVERSION TABLES
0085 333
0085 334  ::
0085 335  :: macro to generate table of acceptable speeds for DHU/DHV
0085 336  ::
0085 337      .MACRO  SPDCONV BAUD
0085 338  .=yf$vmc_speeds+tt$c 'baud'
0085 339  .byte dhuspdc 'baud'
0085 340  .=yf$dhu_speeds+dhuspdc 'baud'
0085 341  .byte tt$c 'baud'
0085 342  .ENDM
0085 343
0085 344  ::
0085 345  :: speed values recognized by the DHU/DHV
0085 346  ::
00000000 0085 347 DHUSPD$c_BAUD_50=0
00000001 0085 348 DHUSPD$c_BAUD_75=1
00000002 0085 349 DHUSPD$c_BAUD_110=2
00000003 0085 350 DHUSPD$c_BAUD_134=3
00000004 0085 351 DHUSPD$c_BAUD_150=4
00000005 0085 352 DHUSPD$c_BAUD_300=5
00000006 0085 353 DHUSPD$c_BAUD_600=6
00000007 0085 354 DHUSPD$c_BAUD_1200=7
00000008 0085 355 DHUSPD$c_BAUD_1800=8
00000009 0085 356 DHUSPD$c_BAUD_2000=9
0000000A 0085 357 DHUSPD$c_BAUD_2400=10
0000000B 0085 358 DHUSPD$c_BAUD_4800=11
0000000C 0085 359 DHUSPD$c_BAUD_7200=12
0000000D 0085 360 DHUSPD$c_BAUD_9600=13
0000000E 0085 361 DHUSPD$c_BAUD_19200=14
0000000F 0085 362 DHUSPD$c_BAUD_38400=15
0085 363
0085 364 ; Allocate and initialize table of speed values
0085 365 YF$VMS_SPEEDS:
0085 366     .REPEAT 16
0085 367     .BYTE  -1 ; Initial to illegal value
FF 0085 368     .ENDR
0095 369 YF$DHU_SPEEDS:
0095 370     .REPEAT 16
0095 371     .BYTE  0 ; Initial to zero
00 0095 372     .ENDR
00A5 373
00A5 374 ; Now build up the table of acceptable speed values
00A5 375
00A5 376     SPDCONV BAUD_75
0097 377     SPDCONV BAUD_110
0098 378     SPDCONV BAUD_134
0099 379     SPDCONV BAUD_150
009A 380     SPDCONV BAUD_300
009B 381     SPDCONV BAUD_600
009C 382     SPDCONV BAUD_1200
009D 383     SPDCONV BAUD_1800
009E 384     SPDCONV BAUD_2000
009F 385     SPDCONV BAUD_2400
00A0 386     SPDCONV BAUD_4800
00A1 387     SPDCONV BAUD_9600
00A3 388     SPDCONV BAUD_19200

```

```

00A4 390          .SBTTL CONTROLLER INITIALIZATION
00A4 391
00A4 392
00A4 393
00A4 394 :++
00A4 395 : YF$DELIVER - Unit delivery routine
00A4 396 :
00A4 397 : FUNCTIONAL DESCRIPTION:
00A4 398 :
00A4 399 : THIS ROUTINE IS ENTERED AT SYSTEM STARTUP
00A4 400 :
00A4 401 : It checks the device to see if the specified unit number exists.
00A4 402 : This is necessary as the DHV has 8 lines, while the DHU has 16
00A4 403 :
00A4 404 : INPUTS:
00A4 405 :
00A4 406 :     R4 = ADDRESS OF THE CONTROLLER CSR
00A4 407 :     R5 = Unit number
00A4 408 :
00A4 409 : OUTPUTS:
00A4 410 :
00A4 411 :     R0 = 1 if unit exists
00A4 412 :     = 0 if unit does not exist
00A4 413 :
00A4 414 : IMPLICIT INPUTS:
00A4 415 :
00A4 416 :
00A4 417 :--
00A4 418 YF$DELIVER::
10 55 D1 00A4 419          CMPL      R5,#16
          1C 18 00A7 420          BGEQ      10$          ; exit if unit too large
          50 64 B0 00A9 421          MOVW     (R4),R0          ; Read base CSR
15 50 05 E0 00AC 422          BBS      #DHUCSR$V_CLEAR,R0,10$ ; controller bad
11 50 0D E0 00B0 423          BBS      #DHUCSR$V_DIGFAL,R0,10$ ; controller bad
00B4 424 :
00B4 425 : Note. If controller has not passed self test then we cannot rely on
00B4 426 : the value read from DHUSTT
00B4 427 :
50 07 A4 90 00B4 428          MOVW     DHUSTT(R4),R0          ; get status byte
          05 50 E8 00B8 429          BLBS     R0,5$          ; low bit indicates DHU
          08 55 D1 00BB 430          CMPL     R5,#8          ; DHV has only 8 lines
          05 18 00BE 431          BGEQ     10$
          00C0 432 5$:
          50 01 D0 00C0 433          MOVL     #1,R0          ; unit exists
          02 11 00C3 434          BRB     20$
          00C5 435 10$:
          50 05 D4 00C5 436          CLRL     R0          ; unit does not exist
          00C7 437 20$:
          05 00C7 438          RSB

```

```

00C8 440          .SBTTL CONTROLLER INITIALIZATION
00C8 441
00C8 442
00C8 443
00C8 444 :++
00C8 445 : YF$INITIAL - INITIALIZE INTERFACE
00C8 446 :
00C8 447 : FUNCTIONAL DESCRIPTION:
00C8 448 :
00C8 449 : THIS ROUTINE IS ENTERED AT SYSTEM STARTUP AND POWER RECOVERY.
00C8 450 :
00C8 451 : INPUTS:
00C8 452 :
00C8 453 :         R4 = ADDRESS OF THE UNIT CSR
00C8 454 :         R5 = IDB OF UNIT
00C8 455 :         R8 = ADDRESS OF THE UNIT CRB
00C8 456 :
00C8 457 : OUTPUTS:
00C8 458 :
00C8 459 :         R2 is destroyed.
00C8 460 :
00C8 461 : IMPLICIT INPUTS:
00C8 462 :
00C8 463 :         IPL = IPL$_POWER
00C8 464 :
00C8 465 :--
00C8 466 YF$INITIAL::          ; INITIALIZE DHU UNIT
00C8 467 :
00C8 468 : SET UP CONTROLLER
00C8 469 :
00C8 470 :         CLASS_CTRL_INIT YFSDPT,PORT_VECTOR; RELOCATE THE NECESSARY TABLES
00F5 471 25$:
00F5 472 :
00F5 473 : Note. The DHV takes about 2 seconds to initialise
00F5 474 : and the DHU up to 5
00F5 475 : so we assume that initialization has taken place
00F5 476 : We could start the initialization and then do a 'skip self test'
00F5 477 : operation to bring the self test time down to a few milliseconds,
00F5 478 : however we would not then know if the board was good or not.
00F5 479 :
00F5 480 :
00F5 481          BITW    #DHUCSR$M_CLEAR,(R4)
64 20 B3 00F5 482          BNEQ    26$          ; dont do reset if still there
64 20 B0 00FA 483          MOVW    #DHUCSR$M_CLEAR,(R4)          ; CONTROLLER RESET
00FD 484 26$:
00FD 485 :
00FD 486 : WAIT TILL CONTROLLER INITIALIZATION IS COMPLETE
00FD 487 :
00FD 488 : 5 second wait here !!!
00FD 489 :
00FD 490          TIMEWAIT    #500000,#DHUCSR$M_CLEAR,(R4),W,.FALSE.
0124 491
0124 492
64 2E 50 E9 0124 493          BLBC    R0,YF$CTRL_ERROR
64 2000 8F B3 0127 494          BITW    #DHUCSR$M_DIGFAL,(R4)
50 00 B0 012C 495          BEQL    90$
64 2000 8F B3 012E 496          MOVW    #0,R0          ; failed self test, dont use

```

- Port Driver for DHU/DHV
CONTROLLER INITIALIZATION

```

22 11 0131 497 BRB YF$CTRL_ERROR
0133 498 90$:
64 4040 8F B0 0133 499 MOVW #DHUCSR$C_BASE,(R4) ; set up base csr value
0138 500
0138 501
0138 502 100$:
OB A8 46 8F 90 0138 503 MOVB #DTS_DHV,CRB$B_TT_TYPE(R8) ; CONTROLLER IS DHV
50 07 A4 90 013D 504 MOVB DHUSTT(R4),R0 ; test for DHU or DHV
0D 50 E9 0141 505 BLBC R0,110$ ; DHV does not have silo timeout
02 A4 00000000'GF 90 0144 506 MOVB G^TTYS$B_SILOTIME,DHUTCR(R4) ; INIT INPUT SILO TIMEOUT VALUE
OB A8 47 8F 90 014C 507 MOVB #DTS_DHU,CRB$B_TT_TYPE(R8) ; CONTROLLER IS DHU
50 01 D0 0151 508 110$:
RSB #SS$_NORMAL,R0
05 0154 510
0155 511
05 0155 512 YF$CTRL_ERROR:
0155 513 RSB
0156 514

```

```

0156 516          .SBTTL UNIT INITIALIZATION
0156 517
0156 518 : YF$INITLINE - UNIT INITIALIZATION
0156 519 :
0156 520 : FUNCTIONAL DESCRIPTION:
0156 521 :
0156 522 : THIS ROUTINE PERFORMS A SIMPLE UNIT INITIALIZATION.
0156 523 :
0156 524 : INPUTS:
0156 525 :
0156 526 :     R5 = UCB ADDRESS
0156 527 :
0156 528 : OUTPUTS:
0156 529 :
0156 530 :     R4,R5 ARE PRESERVED.
0156 531 :--
0156 532
0156 533 YF$INITLINE::
50  FEEF CF  DE 0156 534 MOVAL YF$VEC,R0          ; GET THE DISPATCH TABLE ADDRESS
      64 A5  10  A8 015B 535 CLASS_UNIT_INIT
53  01  54 A5  78 01A4 536 BISW #UCB$M_ONLINE,UCB$W_STS(R5); SET ONLINE
      0106 C5 53 01A8 537
OOFB C5 00000000'GF 90 01A8 538 ASHL UCB$W_UNIT(R5),#1,R3 ; BUILD UNIT'S BIT MASK
      0122 C5 80 01AD 539 MOVW R3,UCB$W_TT_UNITBIT(R5) ; SAVE IT
51  0114 C5  D0 01B2 540 MOVB G^TTYSGB_PARITY,UCB$B_TT_PARITY(R5) ; STORE TERMINAL'S PARITY VALUE IN UCB
      08 B1  16 01BB 541 ;
      24  A8 01BB 542 BISW #TTY$M_PC_DMAAVL!TTY$M_PC_XOFAVL,-; SHOW DMA FEATURE AVAILABLE FOR U
      0122 C5 01BD 543 UCB$W_TT_PRTCTL(R5) ; IN PORT LEVEL
      01C0 544
      01C0 545 MOVL UCB$W_TT_CLASS(R5),R1 ; ADDRESS CLASS VECTOR TABLE
      01C5 546 JSB @CLASS_SETUP_UCB(R1) ; INIT UCB FIELDS
      01C8 547
      01C8 548 :
      01C8 549 : Perform check to see if device is good
      01C8 550 :
      30  BB 01C8 551 PUSHR #^M<R4,R5>
54  24 A5  D0 01CA 552 MOVL UCB$W_CRB(R5),R4 ; GET CRB ADDRESS
54  2C B4  D0 01CE 553 MOVL @CRB$C_INTD+VEC$C_IDB(R4),R4 ; GET CSR ADDRESS
55  54 A5  3C 01D2 554 MOVZWL UCB$W_UNIT(R5),R5
      FECA CF  16 01D6 555 JSB YF$DECIVER ; test this device is ok
      04  30  BA 01DA 556 POPR #^M<R4,R5>
      04  50  E8 01DC 557 BLBS R0,11$
      01DF 558 :
      01DF 559 : DHU is in a bad way, set device offline
      01DF 560 :
      64 A5  10  AA 01DF 561 BICW #UCB$M_ONLINE,UCB$W_STS(R5); SET OFFLINE
      01E3 562 11$:
      01E3 563 : Test to see the type of configuration
      01E3 564 :
      0134 C5  94 01E3 565 CLRB UCB$B_DHUFLG(R5)
      01E7 566 SETIND
0134 C5  02  88 01F6 567 BISB #UCB$M_DHU,UCB$B_DHUFLG(R5); Assume DHU
50  07 A0  90 01FB 568 MOVW DHUSTT(R0),R0 ; test if DHU or DHV
      09  50  E8 01FF 569 BLBS R0,12$
      0202 570 :
      0202 571 : Note. The DHV always interrupts at BR4
      0202 572 : This becomes IPL 20 on a VAX

```

```

0202 573 ;
0134 5E A5 14 90 0202 574      MOVB  #20,UCBSB_DIPL(R5)
0134 C5 02 8A 0206 575      BICB  #UCBSM_DHO,UCBSB_DHUFLG(R5); Actually its a DHV
0208 576
0208 577 12$:
0208 578
0208 579 : Find out what kind of machine the device is connected to.
0208 580 : This tells us what kind of mapping registers we have
0208 581 :
0208 582      CPUDISP <-
0208 583      YF_INITMAP,-          : 11/780
0208 584      YF_INITMAP,-          : 11/750
0208 585      YF_INITMAP,-          : 11/730
0208 586      YF_INITMAP,-          : 11/790
0208 587      YF_INITNULL,-        : unknown
0208 588      YF_INITNULL,-        : unknown
0208 589      YF_NOMAP,-         : Seahorse
0208 590      YF_INITMAP-        : Mayflower
0208 591      >
0227 592 : Unknown processor type
0227 593 YF_INITNULL:
0227 594 :
0227 595 : prevent DMA being used, because we do not understand how the adapter
0227 596 : works.
0227 597 :
0122 04 AA 0227 598      BICW  #TTYSM_PC_DMAAVL,-; SHOW DMA FEATURE NOT AVAILABLE FOR USE
0122 C5 07 11 0229 599      UCBSW_TT_PRTCTL(R5) ; IN PORT LEVEL
022C 600
022C 601      BRB  INIT_CONTINUE
022E 602 : These processors have map registers for DMA operation
022E 603 YF_INITMAP:
022E 604
0134 C5 01 88 022E 605      BISB  #UCBSM_MAP,UCBSB_DHUFLG(R5)
0134 C5 00 11 0233 606      BRB  INIT_CONTINUE
0235 607
0235 608 : These processors do not have map registers
0235 609
0235 610 YF_NOMAP:
0235 611 : No bits set
0235 612
0235 613 INIT_CONTINUE:
0235 614 :
0235 615 :SET MODE CODE NEEDS TO TOGGLE THESE BITS
000009EB'EF 16 0235 616
0235 617      JSB  YF$SET_LINE          ; INIT SPEED/PARITY
023B 618
023B 619 :
023B 620 : ENABLE LINE RECEIVER , TRANSMITTER AND MODEM INTERRUPTS
023B 621 :
023B 622
23 64 A5 04 E1 023B 623      BBC  #UCBSV_ONLINE,UCBSW_STS(R5),20$ ; TEST ONLINE
0240 624      SETIND R4
0247 625      CLRB  DHUTBF2+1(R4)          ; assume transmitter should
024A 626          ; be disabled
024A 627      BISW  #DHULCTSM_ABORT,DHULCT(R4) ; assume abort to be set
024E 628
OF 012A C5 07 E0 024E 629      BBS  #UCBSV_TT_DSBL,UCBSB_TT_MAINT(R5),20$ ; Test if disabled

```

```

08 A4 0104 8F A8 0254 630
   08 A4 01 AA 0254 631 BISW #DHULCTSM_RCV!DHULCTSM MODEM,DHULCT(R4) ; enable receiver and modem
OD A4 80 8F 90 025A 632 BICW #DHULCTSM_ABORT,DHULCT(R4) ; clear abort bit
   90 025E 633 MOVB #^X80,DHUTBF2+1(R4) ; enable transmitter
   0263 634 20$:
   0263 635 :
   0263 636 : INIT RECEIVER MODEM STATUS FOR DHU
   0263 637 :
   50 07 A4 90 0263 638
   0263 639 MOVB DHUSTT(R4),R0
   0267 640 :
   0267 641 : Unfortunately the DHU/DHV dont put the modem bits where we want them
   0267 642 : To get the correct bits we have to move RI,DCD,CTS up one place, while not
   0267 643 : changing DSR. spare bits have to be ignored.
   50 50 50 C0 0267 644 ADDL R0,R0 ; (This shifts DSR out of bottom byte)
   50 8F 8F 8A 026A 645 BICB #^C<TTSM_DS_RING!TTSM_DS_CTS!TTSM_DS_CARRIER>,R0
0124 C5 50 90 026E 646 MOVB R0,UCBSB_TT_DS_RCV(R5) ; UPDATE CURRENT INPUT MODEM SIGNALS
   06 50 08 E1 0273 647 BBC #DHUSTT$V_DSR+T,R0,25$
00 0124 C5 07 E2 0277 648 BBSS #TT$V_DS_DSR,UCBSB_TT_DS_RCV(R5),25$
   027D 649 25$:
   50 51 00 9A 027D 650 MOVZBL #MODEM$C_INIT,R1 ; ASSUME INIT MODEM PROTOCOL
   50 0114 C5 D0 0280 651 MOVL UCBSL_TT_CLASS(R5),R0 ; ADDRESS CLASS VECTOR TABLE
   0C B0 16 0285 652 JSB @CLASS_DS_TRAN(R0) ; INVOKE TO INIT MODEM PROTOCOL
   0288 653 30$:
08 64 A5 05 E1 0288 654 BBC #UCBSV_POWER,UCBSW_STS(R5),40$; DID WE DETECT A POWER FAIL
   50 0114 C5 D0 028D 655 MOVL UCBSL_TT_CLASS(R5),R0 ; GET THE CLASS VECTOR TABLE ADDRESS
   20 B0 17 0292 656 JMP @CLASS_POWERFAIL(R0) ; AND GOTO THE POWERFAIL CODE
   0295 657
   05 0295 658 40$: RSB
   0296 659 :
   0296 660 : ERROR DETECTED DURING INITIALIZATION
   0296 661 :
   0296 662
   64 A5 10 AA 0296 663 YF$UNIT_ERROR:
   05 029A 664 BICW #UCBSM_ONLINE,UCBSW_STS(R5) ; UNIT NOT ON LINE
   029B 665 RSB
   029B 666

```

```

029B 668 .SBTTL MAINTENANCE ROUTINES
029B 669 :++
029B 670 : YFSMAINT - MAINTENANCE FUNCTIONS
029B 671 :
029B 672 : FUNCTIONAL DESCRIPTION:
029B 673 : THIS ROUTINE PERFORMS MAINTENANCE FUNCTIONS FOR THE DHU
029B 674 : (LOOPBACK IS ONLY ALLOWED ON LINES 0 AND 1)
029B 675 :
029B 676 : INPUTS:
029B 677 :
029B 678 : R5 = UCB ADDRESS
029B 679 : UCBSB_TT_MAINT = FUNCTION TO BE PERFORMED
029B 680 :
029B 681 : OUTPUTS:
029B 682 : R0-R4 SCRATCH
029B 683 :--
029B 684 :
029B 685 YFSMAINT:
012A 01 93 029B 686 BITB #IOSM_LOOPa-7,- ; LOOPBACK FUNCTION
029D 687 UCBSB_TT_MAINT(R5)
52 05 13 02A0 688 BEQL 5$ ; NO
02A2 689 MOVZWL #^X02,R2 ; SPECIFY LOOPBACK CODE
02A5 690 BRB 10$
02A7 691 5$:
012A 02 93 02A7 692 BITB #IOSM_UNLOOPa-7,- ; RESET LOOPBACK FUNCTION
02A9 693 UCBSB_TT_MAINT(R5)
52 26 13 02AC 694 BEQL 15$ ; NO
02AE 695 MOVZWL #^X00,R2 ; SPECIFY UNLOOP CODE
02B1 696 10$:
51 02 51 08 A0 B0 02C0 698 SETIND
02C4 699 MOVW DHULCT(R0),R1
02C9 700 INSV R2,#DHULCT$V_MAINT,#2,R1 ; SET MAINT FIELD
02CD 701 MOVW R1,DHULCT(R0) ; Update
02D0 702 MOVZBL #1,R0 ; INDICATE SUCCESS
02D1 703 50$:
50 05 D4 02D1 704 CLRL R0
02D3 705 RSB
02D4 706
02D4 707 15$:
40 8F 93 02D4 708 BITB #IOSM_AUTOXOF_ENAa-7,- ; AUTOXON ENABLED
012A C5 02D7 709 UCBSB_TT_MAINT(R5) ; NO THEN MAYBE DISABLE
05 13 02DA 710 BEQL 17$
0122 C5 A8 02DC 711 BISW #TTYSM_PC_XOFAVL,- ; SET THE BIT AVAILABLE
02DE 712 UCBSW_TT_PRTCTL(R5)
80 8F 93 02E1 714 17$: BITB #IOSM_AUTOXOF_DISa-7,- ; AUTOXON disabled
012A C5 02E4 715 UCBSB_TT_MAINT(R5) ; no then don't disable it
05 13 02E7 716 BEQL 19$
0122 C5 AA 02E9 717 BICW #TTYSM_PC_XOFAVL,-
02EB 718 UCBSW_TT_PRTCTL(R5)
02EE 719
02EE 720 19$:
012A 04 93 02EE 721 BITB #IOSM_LINE_OFFa-7,- ; LINE OFF
02F0 722 UCBSB_TT_MAINT(R5)
02F3 723 BEQL 30$ ; NO
02F5 724 SETIND

```

08 A0	0104	8F	AA	0304	725	BICW	#DHULCTSM_RCV!DHULCTSM_MODEM,DHULCT(R0) ; Disable Receive and modem
08 A0	01	01	A8	030A	726	BISW	#DHULCTSM_ABORT,DHULCT(R0) ; Abort any current activity
	OD	A0	94	030E	727	CLRB	DHUTBF2+1(R0) ; Disable Transmit
		25	11	0311	728	BRB	40\$
				0313	729		
		10	93	0313	730	BITB	#IOSM_LINE_ON@-7- ; LINE ON
	012A	C5		0315	731		UCBSB_TT_MAINT(R5)
		B7	13	0318	732	BEQL	50\$; NO
				031A	733	SETIND	
08 A0	0104	8F	A8	0329	734	BISW	#DHULCTSM_RCV!DHULCTSM_MODEM,DHULCT(R0) ; Enable Receive and modem
08 A0	01	01	AA	032F	735	BICW	#DHULCTSM_ABORT,DHULCT(R0)
OD A0	80	8F	90	0333	736	MOVB	#^X80,DHUTBF2+1(R0) ; Enable Transmit
	50	01	9A	0338	737	MOVZBL	#1,R0
			05	033B	738	RSB	
				033C	739		
				033C	740		

```

033C 742      .SBTTL OUTPUT MODEM CONTROL
033C 743      :++
033C 744      : YF$DS_SET - SET OUTPUT MODEM SIGNALS
033C 745      :
033C 746      : FUNCTIONAL DESCRIPTION:
033C 747      :
033C 748      : THIS ROUTINE OUTPUTS THE OUTPUT MODEM SIGNALS FOR THE SPECIFIED UNIT
033C 749      :
033C 750      : INPUTS:
033C 751      :
033C 752      :         R2 = LOW BYTE - SIGNALS TO ACTIVATE
033C 753      :         HIGH BYTE- SIGNALS TO DEACTIVATE
033C 754      :
033C 755      :         R5 = UCB ADDRESS
033C 756      :
033C 757      : OUTPUTS:
033C 758      :
033C 759      :         R0-R3 ARE USED.
033C 760      :--
033C 761      : YF$DS_SET:
033C 762      :
033C 763      : Check that the DHU/DHV modem control signals have the standard values
033C 764      :
033C 765      :     BISB  R2,UCB$B_TT_DS_TX(R5)  ; SET NEW OUTPUT SIGNALS
52  0125 C5  52  88 0341 766      :     ASHL  #-8,R2,R2                ; ACCESS SIGNALS TO RESET
    52  F8  8F  78 0346 767      :     BICB  R2,UCB$B_TT_DS_TX(R5)  ; RESET THEM
    0125 C5  52  8A 034B 768      :     SETIND
7E  0125 C5  ED 8F  8B 035A 769      :     BICB3 #^C<<DHULCT$M_DTR!DHULCT$M_RTS>/256>,UCB$B_TT_DS_TX(R5),-(SP);
0361 770      :
0361 771      : The DHU/DHV is set to report modem change events in the receive fifo
0361 772      : (Unless the line is disabled)
0361 773      :
03  012A C5  07  E0 0361 774      :     BBS  #UCB$V_TT_DSBL,UCB$B_TT_MAINT(R5),10$ ; Test if disabled
    6E  01  88 0367 775      :     BISB #<DHULCT$M_MODEM/256>,(SP)
    09 A0  8E  90 036A 776 10$:   :     MOVB (SP)+,DHULCT+1(R0) ; OUTPUT NEW VALUE
036E 778      :
05  036E 779      :     RSB
036F 780      :
036F 781      :

```

```

036F 783 .SBTTL RECEIVER INTERRUPT SERVICE
036F 784 :++
036F 785 : YF$INTINP - DHU RECEIVER READY INTERRUPTS
036F 786 :
036F 787 : FUNCTIONAL DESCRIPTION:
036F 788 :
036F 789 : THIS ROUTINE IS ENTERED WHEN A CHARACTER IS AVAILABLE IN THE UNIT'S
036F 790 : SILO. THE CHARACTER IS EXTRACTED AND IS PASSED TO THE ASSOCIATED
036F 791 : CLASS DRIVER. IF THE CLASS DRIVER RETURNS CHARACTER(S) THEN NEW
036F 792 : OUTPUT IT INITIATED (NORMALLY ECHO).
036F 793 :
036F 794 : INPUTS:
036F 795 :
036F 796 :         00(SP) = ADDRESS OF IDB
036F 797 :
036F 798 : IMPLICIT INPUTS:
036F 799 :
036F 800 :         R0,R1,R2,R3,R4,R5 ARE SAVED ON STACK.
036F 801 :
036F 802 : OUTPUTS:
036F 803 :
036F 804 :         THE INTERRUPT IS DISMISSED WHEN THE SILO IS EMPTY.
036F 805 :
036F 806 :--
036F 807 YF$INTINP:: ; DHU/DHV INPUT INTERRUPTS
036F 808 :
036F 809 : GET THE CSR ADDRESS
036F 810 :
036F 811 :         MOVL @ (SP)+,R4 ; GET THE IDB ADDRESS
036F 812 :         PUSHL R4 ; SAVE IDB ADDRESS
036F 813 :         MOVL (R4),R0 ; GET THE CSR ADDRESS
0377 814 :
0377 815 : GET THE CHARACTER FROM THE INTERFACE
0377 816 :
0377 817 25$: MOVW DHURBF(R0),R3 ; Get the silo entry
037B 818 : BGEQ 45$ ; Silo empty (== BRW 100$)
52 53 F8 8F 78 037D 819 : ASHL #-8,R3,R2 ; shift the line number
52 FFFFFFF0 8F CA 0382 820 : BICL #^C<15>,R2 ; use mask to obtain line number
55 18 A442 D0 0389 821 : MOVL IDB$L_UCBLST(R4)[R2],R5 ; GET THE UCB FOR THAT LINE
53 7000 8F B3 038E 822 : BEQL 25$ ; IF EQL THEN NOT THERE
0390 823 : BITW #<DHURCVSM_PARERR>!--
0395 824 : <DHURCVSM_OVERRUN>!--
0395 825 : <DHURCVSM_FRAMER>,R3 ; ERRORS OR MODEM TRANSITION ?
0395 826 :
0395 827 : BNEQ 50$ ; YES, PROCESS THEM
0397 828 27$:
53 53 9A 0397 829 : MOVZBL R3,R3 ; CLEAR THE HIGH BYTES OF CHARACTER
0110 D5 16 039A 830 : JSB @UCB$L_TT_PUTNXT(R5) ; BUFFER THE CHARACTER
40 15 039E 831 : BLEQ 40$ ; NONE OR STRING OUTPUT
03A0 832 : TIMSET #1,R1,LOCKOUTPUT ; SET TIMEOUT AND INTERRUPT BIT
03C1 833 : SETIND R0
02 A0 09 0134 C5 01 E0 03C8 834 : BBS #UCB$V DHU,UCB$B DHUFLG(R5),28$
53 8000 8F A9 03CE 835 : BISW3 #^X8000,R3,DHUTXC(R0) ; DHV single char output
04 11 03D5 836 : BRB 30$
03D7 837 28$:
06 A0 53 90 03D7 838 : MOVB R3,DHUTXF(R0) ; DHU fifo output
54 6E D0 03DB 839 30$: MOVL (SP),R4 ; GET IDB ADDRESS

```

```

97 11 03DE 840 BRB 25$ ; CONTINUE
03E0 841 40$:
00000443' F9 13 03E0 842 BEQL 30$ ; NO CHARACTER
EF 16 03E2 843 JSB BURST_OUTPUT ; START BURST
F1 11 03E8 844 BRB 30$
03EA 845
18 11 03EA 846 45$: BRB 100$
03EA 847
03EC 848 :
03EC 849 50$:
03EC 850 :
03EC 851 : PROCESS PARITY, FRAME OVERRUN ERROR OR MODEM TRANSITION
03EC 852 :
03EC 853 :
03EC 854 : The DHU indicates modem transition by setting all the
03EC 855 : error bits
08 53 0C E1 03EC 856 BBC #DHURCV$V_PARERR,R3,60$
04 53 0E E1 03F0 857 BBC #DHURCV$V_OVERRUN,R3,60$
19 53 0D E0 03F4 858 BBS #DHURCV$V_FRAMER,R3,200$; Modem transition if all set
52 0114 C5 D0 03F8 859 60$:
14 B2 16 03FD 860 MOVL UCBSL TT_CLASS(R5),R2 ; GET CLASS DISPATCH
95 12 0400 861 JSB @CLASS_READERROR(R2) ; SIGNAL ERROR
0402 862 BNEQ 27$ ; CHRRACTER TO ECHO
D7 11 0402 863 70$: BRB 30$
0404 864
5E 04 C0 0404 866 100$: ADDL #4,SP ; REMOVE IDB ADDRESS
50 8E 7D 0407 867 MOVQ (SP)+,R0 ; RESTORE REGISTERS
52 8E 7D 040A 868 MOVQ (SP)+,R2 ;
54 8E 7D 040D 869 MOVQ (SP)+,R4 ;
02 0410 870 REI ;
0411 871 :
0411 872 : Modem transition routine
0411 873 :
0411 874 200$:
0411 875 : If lsb set then it is a self test code
0411 876 : We currently ignore self test codes, although these could be used
0411 877 : for error logging purposes
0411 878
C7 53 E8 0411 879 BLBS R3,30$
0414 880 :
0414 881 : Unfortunately the DHU and DHV dont put the modem bits where we want them
0414 882 : To get the correct bits we have to move RI,DCD,CTS up one place, while not
0414 883 : changing DSR. spare bits have to be ignored.
53 53 53 C0 0414 884 ADDL R3,R3 ; (This shifts DSR out of bottom byte)
53 8F 8F 8A 0417 885 BICB #^C<TTSM_DS_RING!TTSM_DS_CTS!TTSM_DS_CARRIER>,R3
04 53 08 E1 041B 886 BBC #DHUSTT$V_DSR+1,R3,210$
00 53 07 E2 041F 887 BBSS #TT$V_DS_DSR,R3,210$
0124 C5 53 90 0423 888 210$:
52 53 90 0428 889 MOVB R3,UCBSB_TT_DS_RCV(R5) ; UPDATE CURRENT INPUT MODEM SIGNALS
51 03 9A 042B 890 MOVB R3,R2 ; PASS CURRENT INPUT MODEM SIGNALS IN R2
50 DD 042E 891 MOVZBL #MODEM$C_DATASET,R1 ; TRANSITION TYPE IS DATASET
54 0114 C5 D0 0430 892 PUSHL R0 ; SAVE CSR ADDRESS
OC B4 16 0435 893 MOVL UCBSL TT_CLASS(R5),R4 ; GET CLASS DISPATCH
50 8ED0 0438 894 JSB @CLASS_DS_TRAN(R4) ; INVOKE TRANSITION ROUTINE
FF9D 31 043B 895 POPL R0 ; RESTORE CSR ADDRESS
BRW 30$

```

YFDRI
V04-000

- Port Driver for DHU/DHV
RECEIVER INTERRUPT SERVICE

F 7

16-SEP-1984 02:26:48
5-SEP-1984 04:17:43

VAX/VMS Macro V04-00
[TTDRVR.SRC]YFDRI
V04-

Page 21
(1)

043E 897
043E 898

```

043E 900      .SBTTL  START I/O ROUTINE
043E 901      :++
043E 902      : YFS$STARTIO - START I/O OPERATION ON DHU
043E 903      :
043E 904      : FUNCTIONAL DESCRIPTION:
043E 905      :
043E 906      : THIS ROUTINE IS ENTERED FROM THE DEVICE INDEPENDENT TERMINAL STARTIO
043E 907      : ROUTINE TO ENABLE OUTPUT INTERRUPTS ON AN IDLE DHU UNIT.
043E 908      :
043E 909      : INPUTS:
043E 910      :
043E 911      :         R3 = CHARACTER AND CC = PLUS
043E 912      :         ADDRESS AND CC = NEGATIVE
043E 913      :
043E 914      :         R5 = UCB ADDRESS
043E 915      :
043E 916      : OUTPUTS:
043E 917      :
043E 918      :         R5 = UCB ADDRESS
043E 919      : --
043E 920      : .ENABLE LSB
043E 921      : YFS$STARTIO:: ; START I/O ON UNIT
043E 922      : BLSS BURST_OUTPUT
043E 923      : BRW 90$
0443 924
0443 925 BURST_OUTPUT:
0443 926      SETIND
0452 927      MOVZWL UCBSW TT_OUTLEN(R5),R2 ; GET LENGTH
0457 928      BBC #TTY$P DMAENA,- ; USE SILO IF DMA NOT ENABLED ON THIS LINE
0459 929      UCBSW TT_PRTCTL(R5),SILO_OUTPUT
045D 930      CMPW R2,G*TTY$GW_DMASIZE ; LARGE ENOUGH FOR DMA
0464 931      BLSS SILO_OUTPUT
0466 932 10$: BRW DMA_START ; YES SO DO DMA
0469 933
0469 934 SILO_OUTPUT:
0469 935      BBC #UCBSV DHU,UCBSB_DHUFLG(R5),200$ ; DHV has single char output
046F 936      MOVZBL DHUTFS(TRO),R1 ; get number of slots
0473 937      CMPW R2,R1 ; BURST LARGER THAN SILO?
0476 938      BLEQU 50$ ; NO
0478 939      MOVZBL R1,R2 ; SLOTS AVAILABLE IS MAXIMUM
047B 940 50$:
047B 941      MOVL UCBSL TT_OUTADR(R5),R3 ; GET ADDRESS
0480 942      ADDL R2,UCBSL TT_OUTADR(R5) ; UPDATE POINTER
0485 943      SUBW R2,UCBSW TT_OUTLEN(R5) ; AND COUNT
048A 944      BEQL 60$ ; ALL DONE, NO NEED FOR BURST
048C 945      BISW #TTY$M TANK BURST,- ; SIGNAL BURST ACTIVE
0490 946      UCBSW TT_HOCD(R5)
0493 947 60$:
0493 948      BLBC R2,70$ ; EVEN TRANSFER
0496 949      MOVB (R3)+,DHUTXF(R0) ; OUTPUT ODD BYTE
049A 950      DECL R2 ; UPDATE COUNT
049C 951      BEQL 80$ ; DONE
049E 952 70$:
049E 953      ASHL #-1,R2,R2 ; CONVERT TO WORD COUNT
04A3 954 75$:
04A3 955      MOVW (R3)+,DHUTXF(R0)
04A7 956      DELAY ; TO RELEASE THE UNIBUS

```

```

F6 52  F5 04AA 957      SOBGR R2,75$      ; LOOP TILL DONE
          04AD 958
          05 04AD 959 80$:  RSB      ; RETURN TO CALLER
          04AE 960
          04AE 961 90$:
          22 13 04AE 962      BEQL    100$      ; SKIP IF NONE
          04B0 963      SETIND
09 0134 C5 01 E0 04BF 964      BBS    #UCBSV_DHU,UCBSB_DHUFLG(R5),95$
          04C5 965      ;
          04C5 966      ; DHV single character output
          04C5 967      ;
02 A0  53  8000 8F A9 04C5 968      BISW3  #^X8000,R3,DHUTXC(R0)
          04 11 04CC 969      BRB    100$
          04CE 970      ;
          04CE 971      ; DHU fifo output
          04CE 972      ;
          06 A0  53  90 04CE 973 95$:
          04D2 974      MOVB   R3,DHUTXF(R0)
          05 04D2 975 100$:
          04D3 976      RSB
          04D3 977      ;
          04D3 978      ; DHV 'silo' output, uses single character mode
          04D3 979      ;
          53  011C D5 9A 04D3 980 200$:
          011C C5 D6 04D8 981      MOVZBL @UCBSL_TT_OUTADR(R5),R3 ; GET character
          0120 C5 B7 04DC 982      INCL  UCBSL_TT_OUTADR(R5) ; UPDATE POINTER
          07 13 04E0 983      DECW  UCBSW_TT_OUTLEN(R5) ; AND COUNT
          0800 8F A8 04E2 984      BEQL  260$ ; ALL DONE, NO NEED FOR BURST
          0108 C5 04E6 985      BISW  #TTY$M_TANK_BURST,- ; SIGNAL BURST ACTIVE
          04E9 986      UCBSW_TT_HOLD(R5)
          02 A0  53  8000 8F A9 04E9 987 260$:
          05 04E9 988      BISW3  #^X8000,R3,DHUTXC(R0) ; output the character
          04F0 989      RSB
          04F1 990
          04F1 991      .DISABLE      LSB
          04F1 992

```

```

04F1 994 .SBTTL PORT DMA ROUTINES
04F1 995 :++
04F1 996 : DMA_START - INITIATE DMA OUTPUT
04F1 997 :
04F1 998 : FUNCTIONAL DESCRIPTION:
04F1 999 :
04F1 1000 : THESE ROUTINES ARE CALLED BY THE PORT INPUT INTERRUPT, OUTPUT
04F1 1001 : INTERRUPT, AND STARTIO TO INITIATE NEW DMA OUTPUT.
04F1 1002 : THEY HANDLE ALLOCATION AND LOADING OF MAP REGISTERS
04F1 1003 : TO HANDLE DMA OUTPUT. MAP REGISTERS ARE ALLOCATED IN PAIRS
04F1 1004 : TO ALLOW OUTPUT BURSTS UP TO 512 BYTES. TRANSFERS LARGER THAN
04F1 1005 : THAT ARE DONE IN SEGMENTS. IF INSUFFICIENT MAPS ARE AVAILABLE,
04F1 1006 : THE TRANSFER IS DONE SILO MODE.
04F1 1007 :
04F1 1008 :
04F1 1009 : INPUTS:
04F1 1010 :
04F1 1011 : R5 = UCB ADDRESS
04F1 1012 :
04F1 1013 : OUTPUTS:
04F1 1014 :
04F1 1015 : R5 = UCB ADDRESS
04F1 1016 :
04F1 1017 : R0 PRESERVED
04F1 1018 : R1,R2,R3,R4 DESTROYED
04F1 1019 :--
04F1 1020 DMA_START:
04F1 1021 BISW #TTY$M_TANK_DMA,- ; SHOW DMA MODE ACTIVE
04F5 1022 UCBSW TT_HOLD(R5)
04F8 1023 BBCC #TTY$V_TP_ABORT,- ; RESET ANY OLD ABORT REQUESTS
04FA 1024 UCBSB TP_STAT(R5),3$
04FE 1025 BICW #DHULCT$M_ABORT, DHULCT(R0)
0502 1026 :
0502 1027 : If there are no mapping registers for the device then don't allocate them
0502 1028 :
55 0134 C5 00 E1 0502 1029 3$: BBC #UCBSV_MAP, UCBSB_DHUFLG(R5),DMA_CONTINUE
0508 1030 : CHECK IF UNIT HAS PERMANENT MAP REGISTERS
0508 1031 :
06 0122 03 E1 0508 1032 BBC #TTY$V_PC_PRRMAP,- ; SKIP IF NOT AUTHORIZED FOR PERM MAPS
050A 1033 UCBSW TT_PRTCTL(R5),5$
49 0122 04 E0 050E 1034 BBS #TTY$V_PC_MAPAVL,- ; SKIP FORK IF MAPS ALLOCATED ALREADY
0510 1035 UCBSW_TT_PRTCTL(R5),DMA_CONTINUE
0514 1036 5$:
0514 1037 BISB #TTY$M_TP_ALLOC,- ; SHOW ALLOC FORK ACTIVE
0516 1038 UCBSB_TP_STAT(R5)
51 0130 02 88 0514 1037
51 0114 C5 D0 0519 1039 MOVL UCBSL_TT_CLASS(R5),R1 ; GET CLASS VECTOR ADDRESS
1C B1 16 051E 1040 JSB @CLASS_FORK(R1) ; FORK TO FIPL FOR MAP
0521 1041 ; REGISTER ALLOCATION
05 0521 1042 RSB ; RETURN TO CALLER WITH
0522 1043 ; "INT" LEFT ON TO INTERLOCK
0522 1044 ; OUTPUT. FORK ROUTINE WILL
0522 1045 ; RESUME AT DMA_ALLOC.
0522 1046 DMA_ALLOC:
0522 1047
0522 1048
0522 1049 5$:
53 02 9A 0522 1050 MOVZBL #2,R3 ; REQUEST 2 MAP REGISTERS

```

```

00000000'GF 16 0525 1051 JSB G^IOCSALOUBAMAPN ;
                052B 1052
                052B 1053 SETIPL UCBSB DIPL(R5) ; INTERLOCK TO DEVICE IPL
0122 10 AB 052F 1054 BISW #TTY$M_PC_MAPAVL,- ; SHOW MAP ALLOCATED
                C5 0531 1055 UCBSW TT_PRTCTL(R5)
0130 02 8A 0534 1056 BICB #TTY$M_TP_ALLOC,- ; SHOW ALLOC FORK DONE
                C5 0536 1057 UCBSB TP_STAT(R5)
                17 50 E8 0539 1058 BLBS R0,20$ ; SUCCESS
                053C 1059
50 24 A5 DO 053C 1060 MOVL UCBSL_CRB(R5),R0 ; GET CRB OF UNIT
50 2C B0 DO 0540 1061 MOVL @CRB$C_INTD+VEC$SL_IDB(R0),R0 ; GET CSR
                1000 8F AA 0544 1062 BICW #TTY$M_TANK_DMA,- ; RESET DMA MODE
0108 C5 0548 1063 UCBSW TT_HOCD(R5)
52 0120 C5 3C 054B 1064 MOVZWL UCBSW TT_OUTLEN(R5),R2 ; RESTORE OUTPUT LENGTH
                FF16 31 0550 1065 BRW SILO_OUTPUT ; USE SILO FOR OUTPUT
                0553 1066
                0553 1067 20$:
50 24 A5 DO 0553 1068 MOVL UCBSL_CRB(R5),R0 ; GET CRB ADDRESS
                34 A0 DO 0557 1069 MOVL CRB$C_INTD+VEC$M_MAPREG(R0),-
012C C5 055A 1070 UCBSL_TP_MAP(R5) ; SAVE MAP FIELD IN UCB
                055D 1071
                055D 1072
                055D 1073 DMA_CONTINUE:
0C 0130 C5 E0 055D 1074 BBS #TTY$V_TP_ABORT,- ; BRANCH IF DMA TO BE ABORTED
                055F 1075 UCBSB_TP_STAT(R5),2$
                0563 1076
53 011C C5 DO 0563 1077 MOVL UCBSL TT_OUTADR(R5),R3 ; GET ADDRESS OF NEXT STRING
52 0120 C5 3C 0568 1078 MOVZWL UCBSW TT_OUTLEN(R5),R2 ; LENGTH OF OUTPUT
                03 12 056D 1079 BNEQ 4$ ; SKIP IF MORE TO DO
                0162 31 056F 1080 2$: BRW DMA_DONE ; BRANCH IF TRANSFER IS DONE
                50 DD 0572 1081 4$:
                0572 1082 PUSHL R0 ; SAVE INPUT VOLITAL REGISTER "CSR"
                0574 1083
                0574 1084
                0574 1085 ; If there are no mapping registers for the device then
                0574 1086 ; start dma directly
                0574 1087
03 0134 C5 00 E1 0574 1088 BBC #UCBSV MAP, UCBSB_DHUFLG(R5),DMA_NOMAP
                00A0 31 057A 1089 BRW DMA_MAP

```

```

057D 1091 DMA_NOMAP:
057D 1092 :
057D 1093 : Special code to work with an unmapped DHU/DHV
057D 1094 : (I.e. Seahorse configuration)
057D 1095 :
057D 1096 : this code examines the DMA buffer to find the maximum physically
057D 1097 : contiguous area, and starts a DMA on that part.
057D 1098 :
057D 1099 : It assumes that the buffer is in non-paged pool
057D 1100 : (I.e. that it is in system address space and that the PTE
057D 1101 : will always contain the PFN for the page)
057D 1102 :
057D 1103 : Find physical address of first page
057D 1104 :
54 53 53 011C C5 D0 057D 1105      MOVL   UCBSL TT_OUTADR(R5),R3
54 53 80000000 8F CB 0582 1106      BICL3  #^X80000000,R3,R4      : CALC SVAPTE OF BUFFER
54 54 54 F7 8F 78 058A 1107      ASHL   #-9,R4,R4      : ISOLATE PAGE
50 00000000 GF D0 058F 1108      MOVL   G^MMG$GL_SPTBASE,R0  : GETS SVAPTE OF BUFFER
54 54 6044 DE 0596 1109      MOVAL  (R0)[R4],R4      : INTO R4
53 FFFFFFFE00 8F CA 059A 1110      BICL   #^C^X1FF,R3      : COMPUTE BYTE OFFSET IN PAGE
05A1 1111 :
05A1 1112 : calculate length of DMA in this page
51 00000200 8F 53 C3 05A1 1113 :
05A1 1114      SUBL3  R3,#512,R1
05A9 1115 :
05A9 1116 : See if this is longer than buffer
05A9 1117 :
05A9 1118      CMPW   R1,UCBSW_TT_OUTLEN(R5)
05AE 1119      BLEQ  10$
05B0 1120      MOVW  UCBSW_TT_OUTLEN(R5),R1 ; use actual buffer length
05B5 1121 10$:
05B5 1122      SUBW  R1,UCBSW_TT_OUTLEN(R5)
05BA 1123 :
05BA 1124 : Get the PFN for the first page
05BA 1125 :
52 84 D0 05BA 1126      MOVL   (R4)+,R2
05BD 1127 :
05BD 1128 : calculate physical address from PTE
05BD 1129 : (assuming that it fits into a 22-bit address)
05BD 1130 :
52 52 15 00 EF 05BD 1131      EXTZV #0,#21,R2,R2      : get PFN only
53 0D 09 52 FO 05C2 1132      INSV  R2,#9,#13,R3
05C7 1133 :
05C7 1134 : Loop through remaining pages to see if they are contiguous with this one
05C7 1135 :
05C7 1136 20$:
05C7 1137      TSTW  UCBSW_TT_OUTLEN(R5)
05CB 1138      BEQL  50$      : No more DMA
05CD 1139      INCL  R2      : get expected PTE
52 64 15 00 ED 05CF 1140      CMPZV #0,#21,(R4),R2  : test next PTE
05D4 1141      BNEQ  50$      : not contiguous
05D6 1142      TSTL  (R4)+    : step to next PTE
05D8 1143 :
05D8 1144 : concatenate this page to previous DMA
05D8 1145 :
0200 8F 0120 C5 B1 05D8 1146      CMPW  UCBSW_TT_OUTLEN(R5),#512
05DF 1147      BLEQ  40$      : partial page

```

```

51 00000200 8F C0 05E1 1148
0120 C5 0200 8F A2 05E1 1149      ADDL #512,R1      ; whole page gets added
                                SUBW #512,UCBSW_TT_OUTLEN(R5)
                                BRB 20$
                                05F1 1151
                                05F1 1152
                                05F1 1153 ; partial page gets added, to complete the DMA
51 0120 C5 A0 05F1 1154 40$:
0120 C5 B4 05F6 1155      ADDW UCBSW_TT_OUTLEN(R5),R1
                                CLRW UCBSW_TT_OUTLEN(R5)
                                05FA 1156 50$:
                                05FA 1157 : Start up the DMA
                                05FA 1158 :
                                05FA 1159 :
011C C5 51 C0 05FA 1160 :
                                50 8ED0 05FF 1161      ADDL R1,UCBSL_TT_OUTADR(R5) ; step to next DMA address
                                0602 1162      POPL R0 ; RESTORE CSR ADDRESS
                                OE A0 51 B0 0609 1163      SETIND R0
                                OA A0 53 B0 060D 1164      MOVW R1,DHUTCT(R0) ; load the count
53 53 06 10 EF 0611 1165      MOVW R3,DHUTBF1(R0) ; load low address
OC A0 53 80 8F 89 0616 1166      EXTZV #16,#6,R3,R3 ; get high address
                                05 061C 1167      BISB3 #^X80,R3,DHUTBF2(R0) ; load high address and start
                                RSB

```

```

061D 1170 :
061D 1171 : Code to do mapped DMA transfers
061D 1172 :
061D 1173 DMA_MAP:
00000200 8F 52 D1 061D 1174 Cmpl R2,#512 ; NEXT BURST TOO LONG FOR MAPS?
      05 15 0624 1175 BLEQ 5$ ; NO
      52 0200 8F 3C 0626 1176 MOVZWL #512,R2
      062B 1177
      062B 1178
      011C C5 52 C0 062B 1179 5$: ADDL R2,UCB$$_TT_OUTADR(R5) ; UPDATE CHARACTER POINTER FOR NEXT TIME
      0120 C5 52 A2 0630 1180 SUBW R2,UCB$$_TT_OUTLEN(R5) ; UPDATE COUNT FOR NEXT TIME
      0635 1181
      21 0134 C5 02 E0 0635 1182 BBS #U(B$V_XOFF,UCB$$_DHUFLG(R5),6$ ; IF XOFF, DON'T SET TIMER
      063B 1183 TIMSET R2,R1,COCKOUTPUT ; RECOMPUTE TIMEOUT VALUE FOR THIS
      065C 1184 ; PORTION OF THE DMA BURST
      065C 1185
      065C 1186
      065C 1187 : R3 - STRING ADDRESS
      065C 1188 : R2 - LENGTH
      065C 1189 : R5 - UCB
      065C 1190
      50 24 BB 065C 1191 6$: PUSHR #^M<R2,R5>
      50 24 A5 DO 065E 1192 MOVL UCB$$_CRB(R5),R0 ; GET CRB ADDRESS
      51 38 B0 DO 0662 1193 MOVL @CRB$$_INTD+VEC$$_ADP(R0),R1 ; CONFIG REGISTER
      OF 00 EF 0666 1194 EXTZV #VEC$$_MAPREG,#VEC$$_MAPREG,-
      50 012C C5 0669 1195 MOVL UCB$$_TP_MAP(R5),R0 ; GET STARTING MAP REGISTER
      51 0800 C140 DE 066D 1196 MOVAL UBAS$$_MAP(R1)[R0],R1 ; GET 1ST MAP REGISTER ADDRESS
      0673 1197
      54 53 80000000 8F CB 0673 1198 BICL3 #^X80000000,R3,R4 ; CALC SVAPTE OF BUFFER
      54 54 F7 8F 78 067B 1199 ASHL #-9,R4,R4 ; ISOLATE PAGE
      55 00000000 GF DO 0680 1200 MOVL G^MMG$$_SPTBASE,R5 ; GETS SVAPTE OF BUFFER
      54 6544 DE 0687 1201 MOVAL (R5)[R4],R4 ; INTO R4
      53 FFFFFFFE00 8F CA 068B 1202 BICL #^C^X1FF,R3 ; COMPUTE BYTE OFFSET IN PAGE
      0692 1203
      0692 1204 : LOAD MAP REGISTERS
      0692 1205 : R0 - MAP REGISTER NUMBER
      0692 1206 : R1 - ADDRESS OF FIRST MAP REGISTER
      0692 1207 : R2 - BUFFER LENGTH
      0692 1208 : R3 - BYTE OFFSET IN PAGE
      0692 1209 : R4 - SVAPTE OF BUFFER
      0692 1210
      52 02 9A 0692 1211 MOVZBL #2,R2
      55 84 DO 0695 1212 10$: MOVL (R4)+,R5 ; GET CONTENTS OF NEXT PTE
      0698 1213
      0698 1214 : THIS CODE ASSUMES THAT DMA IS FROM NONPAGED POOL
      0698 1215
      55 OB 15 00000400 8F F0 0698 1216 INSV #^X400,#21,#11,R5 ; SET VALID BIT, DATA PATH 0
      81 55 DO 06A1 1217 MOVL R5,(R1)+ ; LOAD INTO MAP REGISTER
      EE 52 F5 06A4 1218 SOBGR R2,10$
      06A7 1219
      24 BA 06A7 1220 POPR #^M<R2,R5> ; RESTORE LENGTH,WRITE BUFFER, UCB
      06A9 1221
      06A9 1222 :
      06A9 1223 : Note that the following code works with 22 bit Qbus addresses
      06A9 1224 : As well as with 18 bit Unibus addresses
      06A9 1225
      53 OD 09 50 F0 06A9 1226 INSV R0,#9,#13,R3 ; COMPUTE UNIBUS ADDRESS

```



```

OF BB 0806 1404 PUSHR #^M<R0,R1,R2,R3>
      0808 1405 SETIND
OD A0 80 8F 90 0817 1406 MOVB #^X80,DHUTBF2+1(R0) ; ENABLE TRANSMIT
  0134 C5 04 8A 081C 1407 BICB #UCBSM_XOFF,UCBSB_DHUFLG(R5) ; clear to indicate xon
  33 64 A5 01 E0 0821 1408 BBS #UCBSV_INT,UCBSW_STS(R5),50$ ; Recalculate timeout
2A 0108 C5 0B E5 0826 1409 BBCC #TTY$V_TANK_BURST,UCBSW_TT_HOLD(R5),40$ ; NO BURST IN PROGRESS
      082C 1410 ; (RESET ANYWAY. WILL BE
      082C 1411 ; SET IF NEEDED BY BURST_OUT
51 0120 C5 3C 082C 1412 MOVZWL UCBSW_TT_OUTLEN(R5),R1 ; GET NUMBER CHARACTERS
      0831 1413 TIMSET R1,R1,LOCKOUTPUT ; COMPUTE TIMEOUT AND
      0852 1414 ; SET INTERRUPT EXPECTED
      FBED CF 16 0852 1415 JSB BURST_OUTPUT ; RESTART OUTPUT
      0856 1416 40$:
      OF BA 0856 1417 POPR #^M<R0,R1,R2,R3>
      05 0858 1418 RSB
      0859 1419
      0859 1420 50$:
      0859 1421 ;
      0859 1422 ; reset timeout for the DHU/DHV
      0859 1423 ;
      0859 1424 ; We use the number of characters that the DHU has got left to send
      0859 1425 ; plus the number in the remaining part of the buffer
      0859 1426 ; Note that the byte count may not be updated by the DHU/DHV
      0859 1427 ; so we will over estimate the timeout value
      0859 1428 ; We have to add 64 because these characters may be in the Transmit fifo
51 0040 8F 3C 0859 1429 MOVZWL #64,R1
  51 0E A0 A0 085E 1430 ADDW DHUTCT(R0),R1
51 0120 C5 A0 0862 1431 ADDW UCBSW_TT_OUTLEN(R5),R1
      0867 1432 TIMSET R1,R1,LOCKOUTPUT ; COMPUTE TIMEOUT AND
      0888 1433 ; SET INTERRUPT EXPECTEDD
      CC 11 0888 1434 BRB 40$
      088A 1435

```

```

088A 1437      .SBTTL OUTPUT INTERRUPT SERVICE
088A 1438      :++
088A 1439      : YF$INTOUT - DHU OUTPUT INTERRUPT SERVICE
088A 1440      :
088A 1441      : FUNCTIONAL DESCRIPTION:
088A 1442      :
088A 1443      : THIS ROUTINE IS ENTERED WHEN THE DHU FINDS A LINE ENABLED
088A 1444      : AND AN EMPTY UART. THE CORRESPONDING UCB IS FOUND AND
088A 1445      : ANY OUTSTANDING PORT OUTPUT IS DONE. WHEN ALL OUTSTANDING PORT
088A 1446      : OUTPUT IS COMPLETED, THE CLASS DRIVER IS CALLED TO RETURN THE NEXT
088A 1447      : CHARACTER OR STRING TO BE OUTPUT. IF NO MORE OUTPUT IS FOUND, THEN
088A 1448      : THE LINE IS DISABLED.
088A 1449      :
088A 1450      : INPUTS:
088A 1451      :
088A 1452      :     SP(00) = ADDRESS OF THE IDB
088A 1453      :
088A 1454      : IMPLICIT INPUTS:
088A 1455      :
088A 1456      :     R0,R1,R2,R3,R4,R5 SAVED ON THE STACK.
088A 1457      :
088A 1458      : OUTPUTS:
088A 1459      :
088A 1460      :     THE INTERRUPT IS DISMISSED.
088A 1461      :
088A 1462      :--
088A 1463      YF_OUT_EXIT:
088A 1464      ADDL    #4,SP          ; EXIT OUTPUT INTERRUPT
088D 1465      MOVQ   (SP)+,R0      ; REMOVE IDB ADDRESS
0890 1466      MOVQ   (SP)+,R2      ; RESTORE REGISTERS
0893 1467      MOVQ   (SP)+,R4
0896 1468      REI
0897 1469
0897 1470      YF$INTOUT::
0897 1471
0897 1472      YF_OUT_LOOP:
0897 1473      MOVL   @ (SP),R4        ; GET THE IDB ADDRESS
089B 1474      MOVL   (R4),R0       ; GET THE CSR ADDRESS
089E 1475
089E 1476      : GET THE LINE INFO FROM THE CSR
089E 1477
089E 1478
089E 1479      MOVW   (R0),R2            ; GET THE CSR VALUE
08A1 1480      BGEQ   YF_OUT_EXIT
08A3 1481      ASHL   #-2,R2,R1    ; Get the line number
08A8 1482      BICL   #^C<15>,R1
08AF 1483      MOVL   IDB$U_CBLST(R4)[R1],R5 ; GET THE UCB ADDRESS
08B4 1484      BEQL   YF_OUT_LOOP   ; IF EQL THEN DISMISS
08B6 1485
08B6 1486      : CHECK FOR BURST OR DMA ACTIVE ON LINE
08B6 1487
08B6 1488
08BD 1489      SETIND R0
08C1 1490      BITW   #DHULCT$M_ABORT, DHULCT(R0) ; CHECK TO SEE IF ABORT IS SET
08C3 1491      BEQL   5$                ; EQUAL, ABORT NOT SET
08C7 1492      BICW   #DHULCT$M_ABORT, DHULCT(R0) ; CLEAR ABORT
08C9 1493      CMPB   #TTY$M_TANK_BURST@-8,- ; ONLY BURST ACTIVE?
08C9 1493      UCB$W_TT_HOCD+1(R5)
51 52 F8 8F 78 08A3 1481
51 FFFFFFF0 8F CA 08A8 1482
55 18 A441 DO 08AF 1483
0109 C5 08B4 1484
08 A0 01 B3 08BD 1489
08 A0 01 AA 08C3 1491
0109 C5 08C7 1492
08C9 1493

```

```

0100 42 13 08CC 1494      BEQL  YF_SILO      ; YES, CONTINUE SILO OUTPUT
0108 8F B3 08CE 1495      BITW  #TTY$M_TANK_PREMPT,- ; Preempt required ?
      C5 12 08D2 1496      UCBSW_TT_HOCD(R5)
      2C      08D5 1497      BNEQ  40$         ; == BRW YF_PREEMPT
1000 8F B3 08D7 1498 9$:  BITW  #TTY$M_TANK_DMA,-   ; DMA ACTIVE?
0108 C5      08DB 1500      UCBSW_TT_HOCD(R5)
      26 12 08DE 1501      BNEQ  45$         ; YES, PROCESS IT. (== BRW YF_DMA_INTERRUPT)
      08E0 1502      : NO PENDING DATA - LOOK FOR NEXT CHARACTER
      08E0 1503      :
      08E0 1504      :
64 A5 03 8A 08E0 1505 10$: BICB  #UCBSM_TIM!UCBSM_INT,UCBSW_STS(R5); CLEAR TIMEOUT AND EXPECTED
      08E4 1506      :
      08E4 1507      : CALL CLASS DRIVER FOR MORE OUTPUT
      08E4 1508      :
010C D5 16 08E4 1509      JSB   @UCBSL_TT_GETNXT(R5) ; GET THE NEXT CHARACTER
      1F 19 08E8 1510      BLSS  YF_START_BURST    ; BURST SPECIFIED
      AB 13 08EA 1511      BEQL  YF_OUT_LOOP      ; NONE
      08EC 1512      :
      08EC 1513      : OUTPUT A CHARACTER TO THE DHU/DHV
      08EC 1514      :
      08EC 1515 20$:      :
0A 0134 C5 01 E0 08EC 1516      BBS   #UCBSV_DHU,UCBSB_DHUFLG(R5),30$
      08F2 1517      :
      08F2 1518      : Single char output to DHV
      08F2 1519      :
02 A0 53 8000 8F A9 08F2 1520      BISW3 #^X8000,R3,DHUTXC(R0)
      FF9B 31 08F9 1521      BRW   YF_OUT_LOOP
      08FC 1522      :
      08FC 1523      : Fifo output to DHU
      08FC 1524      :
      08FC 1525 30$:      :
06 A0 53 90 08FC 1526      MOVB  R3,DHUTXF(R0)
      FF94 31 0900 1527 35$:  BRW   YF_OUT_LOOP
      0089 31 0903 1528 40$:  BRW   YF_OUT_LOOP
      00A8 31 0903 1529 40$:  BRW   YF_OUT_LOOP
      0906 1530 40$:  BRW   YF_PREEMPT
      0906 1531 45$:  BRW   YF_PREEMPT
      0906 1532      BRW   YF_DMA_INTERRUPT
      0909 1533
      0909 1534

```

```

0909 1536
FB36 CF 16 0909 1537 YF_START BURST:
FF87 31 0909 1538 JSB BURST_OUTPUT ; START OUTPUT SILO OR DMA
090D 1539 BRW YF_OUT_LOOP
0910 1540 :
0910 1541 : CONTINUE SILO OUTPUT
0910 1542 :
0910 1543 YF_SILO:
0910 1544 :
0910 1545 : Note. THE DHV does not have SILO output
0910 1546 :
09 0134 C5 01 E1 0910 1547 BBC #UCBSV_DHU,UCBSB_DHUFLG(R5),5$
40 8F 06 A0 91 0916 1548 CMPB DHUTFSTR0),#64 ; ANY SILO OUTPUT IN PROGRESS ?
22 12 091B 1549 BNEQ 15$ ; YES THEN LET IT COMPLETE
26 11 091D 1550 BRB 20$ ; OTHERWISE CONTINUE SILO OUTPUT
091F 1551 :
091F 1552 : DHV single char mode
091F 1553 :
091F 1554 5$:
02 A0 53 011C D5 9A 091F 1555 MOVZBL @UCBSL_TT_OUTADR(R5),R3
53 8000 8F A9 0924 1556 BISW3 #^X8000,R3,DHUTXC(R0)
011C C5 D6 092B 1557 INCL UCBSL_TT_OUTADR(R5)
0120 C5 B7 092F 1558 DECB UCBSW_TT_OUTLEN(R5)
07 12 0933 1559 BNEQ 10$ ; NOT DONE
0800 8F AA 0935 1560 BICW #TTY$M_TANK_BURST,- ; RESET BURST ACTIVE
0108 C5 0939 1561 UCBSW_TT_HOCD(R5)
FF58 31 093C 1562 10$: BRW YF_OUT_LOOP
093F 1564 15$:
093F 1565 INCL YF$L_SIL_ERROR ; INCREMENT ERROR COUNTER
F6F5 CF D6 093F 1566 BRB 10$ ; == BRW YF_OUT_LOOP
F7 11 0943 1567 :
0945 1568 : DHU silo output
0945 1569 :
0945 1570 :
0945 1571 20$:
51 06 A0 9A 0945 1572 MOVZBL DHUTFS(R0),R1 ; number of slots
0949 1573 :
52 0120 C5 3C 0949 1574 MOVZWL UCBSW_TT_OUTLEN(R5),R2 ; GET CURRENT LENGTH
53 011C C5 D0 094E 1575 MOVL UCBSL_TT_OUTADR(R5),R3 ; GET CURRENT ADDRESS
51 52 B1 0953 1576 CMPW R2,R1 ; BURST LARGER THAN SILO?
03 1B 0956 1577 BLEQU 50$ ; NO
52 51 9A 0958 1578 MOVZBL R1,R2 ; MAXIMUM
095B 1579 50$:
011C C5 52 C0 095B 1580 ADDL R2,UCBSL_TT_OUTADR(R5) ; UPDATE POINTER
0120 C5 52 A2 0960 1581 SUBW R2,UCBSW_TT_OUTLEN(R5) ; AND COUNT
07 12 0965 1582 BNEQ 60$ ; NOT DONE
0800 8F AA 0967 1583 BICW #TTY$M_TANK_BURST,- ; RESET BURST ACTIVE
0108 C5 096B 1584 UCBSW_TT_HOCD(R5)
52 D5 096E 1585 60$: TSTL R2 ; ANY ROOM AT ALL
1A 13 0970 1586 BEQL 80$ ; NO THEN EXIT
0972 1587 :
06 A0 08 52 E9 0972 1588 BLBC R2,70$ ; EVEN TRANSFER
83 90 0975 1589 MOVB (R3)+,DHUTXF(R0) ; OUTPUT ODD BYTE
52 D7 0979 1590 DECL R2 ; UPDATE COUNT
OF 13 097B 1591 BEQL 80$ ; DONE
097D 1592 70$:

```

```

52 52 FF 8F 78 097D 1593 ASHL #-1,R2,R2 ; CONVERT TO WORD COUNT
      0982 1594 75$:
06 A0 83 B0 0982 1595 MOVW (R3)+,DHUTXF(R0)
      0986 1596 DELAY ; TO RELEASE THE UNIBUS
      F6 52 F5 0989 1597 SOBGTR R2,75$ ; LOOP TILL DONE
      FF08 31 098C 1598
      098F 1600 80$: BRW YF_OUT_LOOP
      098F 1601 YF_PREEMPT:
0108 C5 0100 8F AA 098F 1602 BICW #TTY$M_TANK_PREMPT,UCB$W_TT_HOLD(R5) ; CLEAR PREEMPT BIT
      53 010A C5 9A 0996 1603 MOVZBL UCB$B_TT_PREMPT(R5),R3 ; -GET CHARACTER
09 0134 C5 01 E0 0998 1604 BBS #UCB$V_DHU,UCB$B_DHUFLG(R5),10$
      09A1 1605 :
      09A1 1606 : DHV single character
02 A0 53 8000 8F A9 09A1 1607 BISW3 #^X8000,R3,DHUTXC(R0)
      04 11 09A8 1608 BRB 20$
      09AA 1609 :
      09AA 1610 : DHU FIFO output
      09AA 1611 :
      09AA 1612 10$:
06 A0 53 90 09AA 1613 MOVB R3,DHUTXF(R0)
      FEE6 31 09AE 1614 20$: BRW YF_OUT_LOOP
      09B1 1616
      09B1 1617 YF_DMA_INTERRUPT:
      09B1 1618 :
      09B1 1619 : CHECK TO MAKE SURE NO DATA IS PENDING BEFORE ASKING FOR MORE
      09B1 1620 :
04 FEE2 CF DF 09B1 1621 PUSHAL YF_OUT_LOOP ; BUILD RETURN ADDRESS ON STACK
      52 0C E1 09B5 1622 BBC #DHUCSR$V_DMAERR,R2,5$ ; CHECK FOR A DMA ERROR
      F683 CF D6 09B9 1623 INCL YF$SIL_DMAERR ; ERROR OCCURED INCREMENT COUNTS
      09BD 1624 5$:
      09BD 1625 BITB #TTY$M_TP_ALLOC!TTY$M_TP_DLLOC,- ;CHECK FOR FORKS ACTIVE
0130 06 93 09BF 1626 UCB$B_TP_STAT(R5) ; AND IGNORE IF SO
      C5 1C 12 09C2 1627 20$
0130 C5 00 E0 09C4 1628 BNEQ
      10 09C9 1629 BBS #TTY$V_TP_ABORT,UCB$B_TP_STAT(R5),-
      0C A0 95 09CA 1630 10$ ;ABORT ACTIVE DMA
      12 19 09CD 1631 TSTB DHUTBF2(R0) ; ANY DMA IN PROGRESS ?
      OE A0 B5 09CF 1632 BLSS 30$ ; YES, then let it complete
      06 13 09D2 1633 TSTW DHUTCT(R0) ; TEST DMA BYTE COUNT
      F664 CF D6 09D4 1634 BEQL 10$ ; DMA BYTE COUNT DONE
      06 11 09D8 1635 INCL YF$SIL_ERROR
      09DA 1636 BRB 20$ ; NO THEN CONTINUE
      OE A0 B4 09DA 1637 10$: CLRW DHUTCT(R0) ; CLEAR DMA BYTE COUNT (ABORT WAS CLEARED)
      FB7D 31 09DD 1638 BRW DMA_CONTINUE ; OTHERWISE, CONTINUE THE DMA
      09E0 1639
      09E0 1640 : IF THIS INTERRUPT WAS THE RESULT
      09E0 1641 : OF AN ABORT, THIS WILL BE HANDLED
      09E0 1642 : BY DMA_CONTINUE
      09E0 1643 20$:
      09E1 1644 RSB
      09E1 1645
      09E1 1646
      09E1 1647 30$:
      F653 CF D6 09E1 1648 INCL YF$SIL_ERROR
      SE 04 C0 09E5 1649 ADDL #4,SP ; Pop off return address

```

YFDRIVER
V04-000

- Port Driver for DHU/DHV
OUTPUT INTERRUPT SERVICE

J 8

16-SEP-1984 02:26:48
5-SEP-1984 04:17:43

VAX/VMS Macro V04-00
[TTDRVR.SRC]YFDRIVER.MAR;1

Page 38
(1)

FEAC	31	09E8	1650	BRW	YF_OUT_LOOP
		09E8	1651		

_S2

Pse

SAD

SDA

SGL

SOW

DIG

REA

SEE

SYS

SYS

SCO

SCO

```

09EB 1653      .SBTTL SET SPEED, PARITY PARAMETERS
09EB 1654
09EB 1655      :++
09EB 1656      : YFSSET_LINE - RESET SPEED, PARITY
09EB 1657      :
09EB 1658      : FUNCTIONAL DESCRIPTION:
09EB 1659      :
09EB 1660      : INPUTS:
09EB 1661      :
09EB 1662      :     R5 - UCB ADDRESS
09EB 1663      :
09EB 1664      : OUTPUTS:
09EB 1665      :
09EB 1666      :     R4 USED
09EB 1667      :--
09EB 1668
09EB 1669      YFSSET_LINE:
54 24 0C BB 09EB 1670      PUSH  #^M<R2,R3>
54 2C B4 DO 09ED 1671      MOVL  UCB$$_CRB(R5),R4 ; ADDRESS CRB
52 08 A0 3C 09F1 1672      MOVL  @CRB$_INTD+VEC$_IDB(R4),R4 ; GET THE CSR ADDRESS VIA CRB
09F5 1673      SETIND
0A04 1674      MOVZWL DHULCT(R0),R2 ; Fetch the line control reg
0A08 1675
0A08 1676      :
0A08 1677      : The DHU/DHV have automatic detection of received XON/XOFF and also
0A08 1678      : automatic generation of XON/XOFF options
0A08 1679      :
14 0122 C5 05 E1 0A08 1680      BBC   #TTY$_PC_XOFAVL,UCB$_TT_PRTCTL(R5),4$; AUTOXON XOFF AVAILABLE ON T
0A0E 1681      : ; YES THEN IS
0A0E 1682      :
0A0E 1683      : Assume that both modes are required
0A0E 1684      :
12 52 AB 0A0E 1685      BISW  #<DHULCT$_OAUTO ! DHULCT$_IAUTO>,-
0A10 1686      : R2; Assume AUTOXOFF
0A11 1687      :
0A11 1688      : Disable detection of received XON/XOFF if not allowed
0A11 1689      :
03 0122 C5 06 E0 0A11 1690      BBS   #TTY$_PC_XOFENA,UCB$_TT_PRTCTL(R5),2$; AUTOXON XOFF ENABLED
52 02 AA 0A17 1691      BICW  #DHULCT$_OAUTO,R2 ; NO THEN CLEAR THE AUTOXOFF ENABLE
0A1A 1692      2$:
0A1A 1693      :
0A1A 1694      : Disable sending of XON/XOFF is hostsync is not set
0A1A 1695      : (The DHU/DHV can send XON/XOFF automatically if the receive fifo fills up)
0A1A 1696      :
03 44 A5 04 E0 0A1A 1697      BBS   #TTY$_HOSTSYNC,UCB$_DEVDEPEND(R5),4$; Host sync specified ?
52 10 AA 0A1F 1698      BICW  #DHULCT$_IAUTO,R2 ; No, then clear enable flag
0A22 1699      :
52 0100 8F AA 0A22 1700      4$: BICW  #DHULCT$_MODEM,R2
05 44 A5 15 E1 0A27 1701      BBC   #TTY$_MODEM,UCB$_DEVDEPEND(R5),6$
52 0100 8F AB 0A2C 1702      BISW  #DHULCT$_MODEM,R2
0A31 1703      :
0A31 1704      :
0A31 1705      : move updated register back into device
0A31 1706      :
08 A0 52 B0 0A31 1707      6$: MOVW  R2,DHULCT(R0)
7E D4 0A35 1708      CLRL  -(SP) ; RESET A TEMPORARY LOCATION
0A37 1709      :

```

```

0A37 1710 : SET UP LINE SPEED AND PARITY
0A37 1711 :
0A37 1712 :
OOF5 C5 95 0A37 1713 TSTB UCBSW_TT_SPEED+1(R5) ; RECEIVE SPEED SPECIFIED?
07 12 0A3B 1714 BNEQ 8$ ; YES
OOF4 C5 90 0A3D 1715 MOVB UCBSW_TT_SPEED(R5) - ; NO, SO USE TRANSMITTER SPEED
OOF5 C5 0A41 1716 UCBSW_TT_SPEED+1(R5)
53 00F4 C5 9A 0A44 1717 8$:
53 F637 CF43 90 0A44 1718 MOVZBL UCBSW TT SPEED(R5),R3 ; Get TRANSMIT SPEED
19 0A49 1719 MOVB YF$VMS_SPEEDS[R3],R3
6E 04 OC 53 FO 0A4F 1720 BLSS 10$ ; Illegal speed
53 00F5 C5 9A 0A51 1721 INSV R3,#DHULPR$V_TSPEED,#4,(SP) ; SET TRANSMIT SPEED
53 F625 CF43 90 0A56 1722 MOVZBL UCBSW TT SPEED+1(R5),R3
07 19 0A61 1723 MOVB YF$VMS_SPEEDS[R3],R3
6E 04 08 53 FO 0A63 1724 BLSS 10$ ; Illegal speed
27 11 0A68 1725 INSV R3,#DHULPR$V_RSPEED,#4,(SP) ; SET RECEIVE SPEED
0A6A 1726 BRB 20$ ; set current speed
0A6A 1727
0A6A 1728 10$:
0A6A 1729 :
0A6A 1730 : This code restores the speed to its previous value
0A6A 1731 : It is entered when an illegal speed combination is detected.
0A6A 1732
53 04 A0 B0 0A6A 1733 MOVW DHULPR(R0),R3 ; get line parameters
6E 53 B0 0A6E 1734 MOVW R3,(SP) ; use previous speed as new
53 53 C4 OC EF 0A71 1735 CLRB (SP)
00F4 C5 F618 CF43 90 0A73 1736 EXTZV #DHULPR$V_TSPEED,#4,R3,R3 ; extract speed
53 53 04 A0 B0 0A78 1737 MOVW YF$DHU_SPEEDS[R3],UCBSW_TT_SPEED(R5); convert to VMS value
53 53 04 08 EF 0A80 1738 MOVW DHULPR(R0),R3 ; get line parameters
00F5 C5 F607 CF43 90 0A84 1740 EXTZV #DHULPR$V_RSPEED,#4,R3,R3 ; extract speed
0A89 1741 MOVW YF$DHU_SPEEDS[R3],UCBSW_TT_SPEED+1(R5); convert to VMS value
0A91 1742
0A91 1743 : insert other parameters in the new LPR value
0A91 1744
0A91 1745 20$:
53 00F8 C5 02 03 EE 0A91 1746 EXTV #UCBSV TT LEN,#2,UCBSB TT_PARITY(R5),R3 ; GET CHAR SIZE
6E 02 03 53 FO 0A98 1747 INSV R3,#DHULPR$V_SIZE,#2,(SP) ; SET IT
53 00F8 C5 02 06 EE 0A9D 1750 EXTV #UCBSV TT PARTY,#2,UCBSB TT_PARITY(R5),R3 ; GET PARITY/ODD
6E 02 05 53 FO 0AA4 1751 INSV R3,#DHULPR$V_PARITY,#2,(SP)
6E 00000040 8F CC 0AA9 1752 XORL #DHULPR$M_ODD,(SP) ; Correct sense
53 00F8 C5 01 05 EE 0AB0 1753 EXTV #UCBSV TT STOP,#1,UCBSB TT_PARITY(R5),R3 ; GET STOP
6E 01 07 53 FO 0AB7 1754 INSV R3,#DHULPR$V_STOP,#1,(SP)
04 A0 6E B1 0ABC 1755 CMPW (SP),DHULPR(R0) ; Any modifications to be made?
04 13 0ACO 1756 BEQL 30$ ; EQL, no then return
04 A0 6E F7 0AC2 1759 CRTLW (SP),DHULPR(R0) ; INSERT AS LINE PARAMETER
SE 04 6E C0 0AC6 1760 ADDL #4, SP ; Restore stack
OC BA 0AC9 1761 POPR #^M<R2,R3> ; Restore registers
05 0ACB 1762 RSB
OACC 1763
OACC 1764
OACC 1765
OACC 1766 YF$END: ; end of driver
    
```

Sym

ACCI
ADD
ADD
ADJ
ASK
ATTI
AUTI
BY
CACI
CLIS
CMDI
COP
CREA
DCL
DEF
DIGI
DIR
DIR
DIS
DIS
ENCI
EXE
EXI
FAO
FAO
FMG
FMT

YFDRIVER
V04-000

- Port Driver for DHU/DHV
SET SPEED, PARITY PARAMETERS

OACC 1767 .END

M 8

16-SEP-1984 02:26:48
5-SEP-1984 04:17:43

VAX/VMS Macro V04-00
[TTDRVR.SRC]YFDRIVER.MAR;1

Page 41
(1)

-\$25

Symb

FOUN

GENE

GETC

GETC

GETF

GETF

GETF

GETS

GETU

GETV

GET

GRP

HELP

HOLD

IDEN

LBR

LETT

LGIS

LIB

YFDRIVER
Symbol table

- Port Driver for DHU/DHV

N 8

16-SEP-1984 02:26:48 VAX/VMS Macro V04-00
5-SEP-1984 04:17:43 [TTDRVR.SRC]YFDRIVER.MAR;1

Page 42
(1)

```

$$$ = 00000020 R 02
$$OP = 00000002
ATS_UBA = 00000001
BIT... = 00000003
BUGS_UNSUPRTCPU *****
BURST_OUTPUT 00000443 R X 03
CLASS_DDT = 00000010
CLASS_DS_TRAN = 0000000C
CLASS_FORK = 0000001C
CLASS_GETNXT = 00000000
CLASS_POWERFAIL = 00000020
CLASS_PUTNXT = 00000004
CLASS_READERROR = 00000014
CLASS_SETUP_UCB = 00000008
CRBSB_TT_TYPE = 0000000B
CRBSL_INTD = 00000024
CRBSL_INTD2 = 00000048
DCS_TERM = 00000042
DDBSL_DDT = 0000000C
DEVSM_AVL = 00040000
DEVSM_CCL = 00000002
DEVSM_IDV = 04000000
DEVSM_NNM = 00000200
DEVSM_ODV = 08000000
DEVSM_REC = 00000001
DEVSM_TRM = 00000004
DHUCSR = 00000000
DHUCSR$C_BASE = 00004040
DHUCSR$M_CLEAR = 00000020
DHUCSR$M_DIGFAL = 00002000
DHUCSR$M_DMAERR = 00001000
DHUCSR$M_IADDR = 0000000F
DHUCSR$M_LINE = 00000F00
DHUCSR$M_RCVINT = 00000040
DHUCSR$M_SNDINT = 00004000
DHUCSR$M_SNDRDY = 00008000
DHUCSR$S_CLEAR = 00000001
DHUCSR$S_DIGFAL = 00000001
DHUCSR$S_DMAERR = 00000001
DHUCSR$S_IADDR = 00000004
DHUCSR$S_LINE = 00000004
DHUCSR$S_RCVINT = 00000001
DHUCSR$S_SNDINT = 00000001
DHUCSR$S_SNDRDY = 00000001
DHUCSR$V_CLEAR = 00000005
DHUCSR$V_DIGFAL = 0000000D
DHUCSR$V_DMAERR = 0000000C
DHUCSR$V_IADDR = 00000000
DHUCSR$V_LINE = 00000008
DHUCSR$V_RCVINT = 00000006
DHUCSR$V_SNDINT = 0000000E
DHUCSR$V_SNDRDY = 0000000F
DHULCT = 00000008
DHULCT$M_ABORT = 00000001
DHULCT$M_BREAK = 00000008
DHULCT$M_DTR = 00000200
DHULCT$M_IAUTO = 00000010

```

```

DHULCT$M_MAINT = 000000C0
DHULCT$M_MODEM = 00000100
DHULCT$M_OAUTO = 00000002
DHULCT$M_RCV = 00000004
DHULCT$M_RTS = 00001000
DHULCT$M_SNDOFF = 00000020
DHULCT$S_ABORT = 00000001
DHULCT$S_BREAK = 00000001
DHULCT$S_DTR = 00000001
DHULCT$S_IAUTO = 00000001
DHULCT$S_MAINT = 00000002
DHULCT$S_MODEM = 00000001
DHULCT$S_OAUTO = 00000001
DHULCT$S_RCV = 00000001
DHULCT$S_RTS = 00000001
DHULCT$S_SNDOFF = 00000001
DHULCT$V_ABORT = 00000000
DHULCT$V_BREAK = 00000003
DHULCT$V_DTR = 00000009
DHULCT$V_IAUTO = 00000004
DHULCT$V_MAINT = 00000006
DHULCT$V_MODEM = 00000008
DHULCT$V_OAUTO = 00000001
DHULCT$V_RCV = 00000002
DHULCT$V_RTS = 0000000C
DHULCT$V_SNDOFF = 00000005
DHULPR = 00000004
DHULPR$M_DIAG1 = 00000002
DHULPR$M_DIAG2 = 00000004
DHULPR$M_ODD = 00000040
DHULPR$M_PARITY = 00000020
DHULPR$M_RSPEED = 00000F00
DHULPR$M_SIZE = 00000018
DHULPR$M_STOP = 00000080
DHULPR$M_TSPEED = 0000F000
DHULPR$S_DIAG1 = 00000001
DHULPR$S_DIAG2 = 00000001
DHULPR$S_ODD = 00000001
DHULPR$S_PARITY = 00000001
DHULPR$S_RSPEED = 00000004
DHULPR$S_SIZE = 00000002
DHULPR$S_STOP = 00000001
DHULPR$S_TSPEED = 00000004
DHULPR$V_DIAG1 = 00000001
DHULPR$V_DIAG2 = 00000002
DHULPR$V_ODD = 00000006
DHULPR$V_PARITY = 00000005
DHULPR$V_RSPEED = 00000008
DHULPR$V_SIZE = 00000003
DHULPR$V_STOP = 00000007
DHULPR$V_TSPEED = 0000000C
DHURBF = 00000002
DHURCV$M_BUF = 000000FF
DHURCV$M_FRAMER = 00002000
DHURCV$M_LINE = 00000F00
DHURCV$M_OVERRUN = 00004000
DHURCV$M_PARRR = 00001000

```

_\$2
Sym

PAR
PAR
PLI
PRO
PRO
PRV
PRV
PRV
PRV
PRV
PUR
PWD
R
RAB
RAN
RAN
RDB
RDB
REC
REC
REC
REM
REM
RES
RES
RIG
RMS
SET
SET
SHO
SHO
SIG
SS\$
SS\$
SS\$
SS\$
STR

YFDRIVER
Symbol table

- Port Driver for DHU/DHV

B 9

16-SEP-1984 02:26:48 VAX/VMS Macro V04-00
5-SEP-1984 04:17:43 [TTDRVR.SRC]YFDRIVER.MAR;1

Page 43
(1)

DHURCVSM_VALID	=	00008000		
DHURCVSS_BUF	=	00000008		
DHURCVSS_FRAMER	=	00000001		
DHURCVSS_LINE	=	00000004		
DHURCVSS_OVERRUN	=	00000001		
DHURCVSS_PARERR	=	00000001		
DHURCVSS_VALID	=	00000001		
DHURCVSV_BUF	=	00000000		
DHURCVSV_FRAMER	=	0000000D		
DHURCVSV_LINE	=	00000008		
DHURCVSV_OVERRUN	=	0000000E		
DHURCVSV_PARERR	=	0000000C		
DHURCVSV_VALID	=	0000000F		
DHUSPDSC_BAUD_110	=	00000002		
DHUSPDSC_BAUD_1200	=	00000007		
DHUSPDSC_BAUD_134	=	00000003		
DHUSPDSC_BAUD_150	=	00000004		
DHUSPDSC_BAUD_1800	=	00000008		
DHUSPDSC_BAUD_19200	=	0000000E		
DHUSPDSC_BAUD_2000	=	00000009		
DHUSPDSC_BAUD_2400	=	0000000A		
DHUSPDSC_BAUD_300	=	00000005		
DHUSPDSC_BAUD_38400	=	0000000F		
DHUSPDSC_BAUD_4800	=	0000000B		
DHUSPDSC_BAUD_50	=	00000000		
DHUSPDSC_BAUD_600	=	00000006		
DHUSPDSC_BAUD_7200	=	0000000C		
DHUSPDSC_BAUD_75	=	0000C001		
DHUSPDSC_BAUD_9600	=	0000000D		
DHUSTT	=	00000007		
DHUSTTSM_CTS	=	00000008		
DHUSTTSM_DCD	=	00000010		
DHUSTTSM_DSR	=	00000080		
DHUSTTSM_RI	=	00000020		
DHUSTTSS_CTS	=	00000001		
DHUSTTSS_DCD	=	00000001		
DHUSTTSS_DSR	=	00000001		
DHUSTTSS_RI	=	00000001		
DHUSTTSV_CTS	=	00000003		
DHUSTTSV_DCD	=	00000004		
DHUSTTSV_DSR	=	00000007		
DHUSTTSV_RI	=	00000005		
DHUTBF1	=	0000000A		
DHUTBF2	=	0000000C		
DHUTCR	=	00000002		
DHUTCT	=	0000000E		
DHUTFS	=	00000006		
DHUTXC	=	00000002		
DHUTXF	=	00000006		
DMA_ALLOC	=	00000522	R	03
DMA_CONTINUE	=	0000055D	R	03
DMA_DEALLOC	=	000006E8	R	03
DMA_DONE	=	000006D4	R	03
DMA_MAP	=	0000061D	R	03
DMA_NOMAP	=	0000057D	R	03
DMA_POST	=	00000708	R	03
DMA_START	=	000004F1	R	03

DPTSC_LENGTH	=	00000038		
DPTSC_VERSION	=	00000004		
DPT\$INITAB	=	00000038	R	02
DPTSM_NOUNLOAD	=	00000004		
DPT\$REINITAB	=	000000D3	R	02
DPT\$TAB	=	00000C00	R	02
DPT\$W_VECTOR	=	0000001E		
DTS_DRU	=	00000047		
DTS_DHV	=	00000046		
DYN\$C_CRB	=	00000005		
DYN\$C_DDB	=	00000006		
DYN\$C_DPT	=	0000001E		
DYN\$C_ORB	=	00000049		
DYN\$C_UCB	=	00000010		
EXE\$GB_CPUTYPE	=	*****	X	03
EXE\$GL_ABSTIM	=	*****	X	03
EXE\$GL_TENUSEC	=	*****	X	03
EXE\$GL_UBDELAY	=	*****	X	03
FUNCTAB_LEN	=	00000000		
IDBSL_UCBLST	=	00000018		
INIT_CONTINUE	=	00000235	R	03
IOSM_AUTXOF_DIS	=	00004000		
IOSM_AUTXOF_ENA	=	00002000		
IOSM_LINE_OFF	=	00000200		
IOSM_LINE_ON	=	00000800		
IOSM_LOOP	=	00000080		
IOSM_UNLOOP	=	00000100		
IOCS\$ALOUBAMAPN	=	*****	X	03
IOCS\$MNTVER	=	*****	X	03
IOCS\$RELMAPREG	=	*****	X	03
IOCS\$RETURN	=	*****	X	03
MMG\$GL_SPTBASE	=	*****	X	03
MODEM\$C_DATASET	=	00000003		
MODEM\$C_INIT	=	00000000		
ORBSB_FLAGS	=	0000000B		
ORBSL_OWNER	=	00000000		
ORBSM_PROT_16	=	00000001		
ORBSW_PROT	=	00000018		
PORT_ABORT	=	00000020		
PORT_DS_SET	=	0000000C		
PORT_FORKRET	=	00000034		
PORT_LENGTH	=	00000038		
PORT_MAINT	=	00000030		
PORT_RESUME	=	00000024		
PORT_SET_LINE	=	00000008		
PORT_STARTIO	=	00000000		
PORT_STOP	=	00000018		
PORT_VECTOR	=	00000048	R	03
PORT_XOFF	=	00000014		
PORT_XON	=	00000010		
PR\$ IPL	=	00000012		
PR\$ SID TYP780	=	00000001		
SILO_OUTPUT	=	00000469	R	03
SIZ...	=	00000001		
SS\$ NORMAL	=	00000001		
TT\$C_BAUD_110	=	00000003		
TT\$C_BAUD_1200	=	00000008		

_\$2

Symb

STR

STR

SYME

SYSS

YFDRIVER
Symbol table

- Port Driver for DHU/DHV

C 9

16-SEP-1984 02:26:48 VAX/VMS Macro V04-00
5-SEP-1984 04:17:43 [TTDRVR.SRC]YFDRIVER.MAR;1

Page 44
(1)

TTSC_BAUD_134	= 00000004			UCBSB_TT_DS_RCV	= 0C000124
TTSC_BAUD_150	= 00000005			UCBSB_TT_DS_TX	= 00000125
TTSC_BAUD_1800	= 00000009			UCBSB_TT_MAINT	= 0000012A
TTSC_BAUD_19200	= 00000010			UCBSB_TT_PARITY	= 000000F8
TTSC_BAUD_2000	= 0000000A			UCBSB_TT_PREMPT	= 0000010A
TTSC_BAUD_2400	= 0000000B			UCBSC_TT_LENGTH	= 00000134
TTSC_BAUD_300	= 00000006			UCBSL_CRB	= 00000024
TTSC_BAUD_4800	= 0000000D			UCBSL_DDB	= 00000028
TTSC_BAUD_600	= 00000007			UCBSL_DDT	= 00000088
TTSC_BAUD_75	= 00000002			UCBSL_DEVCHAR	= 00000038
TTSC_BAUD_9600	= 0000000F			UCBSL_DEVCHAR2	= 0000003C
TTSM_DS_CARRIER	= 00000020			UCBSL_DEVDEPEND	= 00000044
TTSM_DS_CTS	= 00000010			UCBSL_DEVDEPND2	= 00000048
TTSM_DS_RING	= 00000040			UCBSL_DUETIM	= 0000006C
TTSV_DS_DSR	= 00000007			UCBSL_TP_MAP	= 0000012C
TTSV_HOSTSYNC	= 00000004			UCBSL_TT_CLASS	= 00000114
TTSV_MODEM	= 00000015			UCBSL_TT_DECHA1	= 000000C8
TTS_UNKNOWN	= 00000000			UCBSL_TT_DECHAR	= 000000C4
TTY\$GB_DEFSPEED	*****	X	02	UCBSL_TT_GETNXT	= 0000010C
TTY\$GB_PARITY	*****	X	02	UCBSL_TT_OUTADR	= 0000011C
TTY\$GB_RSPEED	*****	X	02	UCBSL_TT_PORT	= 00000118
TTY\$GB_SILOTIME	*****	X	03	UCBSL_TT_PUTNXT	= 00000110
TTY\$GL_DEFCHAR	*****	X	02	UCBSL_TT_RTIMOU	= 000000B4
TTY\$GL_DEFCHAR2	*****	X	02	UCBSL_TT_WBLINK	= 000000D0
TTY\$GL_DPT	*****	X	03	UCBSL_TT_WFLINK	= 000000CC
TTY\$GL_OWNUIC	*****	X	02	UCBSM_DHO	= 00000002
TTY\$GW_DEFBUF	*****	X	02	UCBSM_INT	= 00000002
TTY\$GW_DMASIZE	*****	X	03	UCBSM_MAP	= 00000001
TTY\$GW_PROT	*****	X	02	UCBSM_ONLINE	= 00000010
TTYSM_PC_DMAAVL	= 00000004			UCBSM_TIM	= 00000001
TTYSM_PC_MAPAVL	= 00000010			UCBSM_XOFF	= 00000004
TTYSM_PC_XOFAVL	= 00000020			UCBSS_DHU	= 00000001
TTYSM_TANK_BURST	= 00000800			UCBSS_MAP	= 00000001
TTYSM_TANK_DMA	= 00001000			UCBSS_XOFF	= 00000001
TTYSM_TANK_PREMPT	= 00000100			UCBSV_DHU	= 00000001
TTYSM_TP_ABORT	= 00000001			UCBSV_INT	= 00000001
TTYSM_TP_ALLOC	= 00000002			UCBSV_MAP	= 00000000
TTYSM_TP_DLLOC	= 00000004			UCBSV_ONLINE	= 00000004
TTYSV_PC_DMAENA	= 00000001			UCBSV_POWER	= 00000005
TTYSV_PC_MAPAVL	= 00000004			UCBSV_TT_DSBL	= 00000007
TTYSV_PC_NOTIME	= 00000000			UCBSV_TT_LEN	= 00000003
TTYSV_PC_PRMMAP	= 00000003			UCBSV_TT_PARTY	= 00000006
TTYSV_PC_XOFAVL	= 00000005			UCBSV_TT_STOP	= 00000005
TTYSV_PC_XOFENA	= 00000006			UCBSV_XOFF	= 00000002
TTYSV_TANK_BURST	= 0000000B			UCBSW_DEVBUFSIZ	= 00000042
TTYSV_TP_ABORT	= 00000000			UCBSW_STS	= 00000064
TTYSV_TP_ALLOC	= 00000001			UCBSW_TT_DESIZE	= 000000F1
TTYSV_TP_DLLOC	= 00000002			UCBSW_TT_DESPEE	= 000000E8
UBASL_MAP	= 00000800			UCBSW_TT_HOLD	= 00000108
UCBSB_DEVCLASS	= 00C00040			UCBSW_TT_OUTLEN	= 00000120
UCBSB_DEVTYPE	= 00000041			UCBSW_TT_PRTCTL	= 00000122
UCBSB_DHUFLG	= 00000134			UCBSW_TT_SPEED	= 000000F4
UCBSB_DIPL	= 0000005E			UCBSW_TT_UNITBIT	= 00000106
UCBSB_FIPL	= 0000000B			UCBSW_UNIT	= 00000054
UCBSB_TP_STAT	= 00000130			VEC\$SL_ADP	= 00000014
UCBSB_TT_DEPARI	= 000000EC			VEC\$SL_IDB	= 00000008
UCBSB_TT_DETYPE	= 000000F0			VEC\$SL_INITIAL	= 0000000C

_\$2

Sym

UAF

VECSL_UNITINIT	=	00000018		
VECSS_MAPREG	=	0000000F		
VECSV_MAPREG	=	00000000		
VECSW_MAPREG	=	00000010		
YF\$ABORT		000007E4	R	03
YF\$CTRL_ERROR		00000155	R	03
YF\$DDT		00000000	RG	03
YF\$DELIVER		000000A4	RG	03
YF\$DHU_SPEEDS		00000095	R	03
YF\$DPT		00000000	RG	02
YF\$DS_SET		0000033C	R	03
YF\$END		00000ACC	R	03
YF\$FORK		0000071F	R	03
YF\$INITIAL		000000C8	RG	03
YF\$INITLINE		00000156	RG	03
YF\$INTINP		0000036F	RG	03
YF\$INTOUT		00000897	RG	03
YF\$SL_DMAXMT_ERROR		00000040	RG	03
YF\$SL_ERROR		0000003C	RG	03
YF\$SL_INACT_ERROR		00000044	RG	03
YF\$SL_SIL_ERROR		00000038	RG	03
YF\$MAINT		0000029B	R	03
YF\$NULL		00000084	R	03
YF\$PREEMPT		00000777	R	03
YF\$RESUME		00000806	R	03
YF\$SET_LINE		000009EB	R	03
YF\$STARTIO		0000043E	RG	03
YF\$STOP		000007C4	R	03
YF\$UNIT_ERROR		00000296	R	03
YF\$VEC		00000048	R	03
YF\$VECEND		00000080	R	03
YF\$VMS_SPEEDS		00000085	R	03
YF\$XOFF		0000075E	R	03
YF\$XON		0000073E	R	03
YF_DMA_INTERRUPT		000009B1	R	03
YF_INITMAP		0000022E	R	03
YF_INITNULL		00000227	R	03
YF_NOMAP		00000235	R	03
YF_OUT_EXIT		0000088A	R	03
YF_OUT_LOOP		00000897	R	03
YF_PREEMPT		0000098F	R	03
YF_SILO		00000910	R	03
YF_START_BURST		00000909	R	03

! Psect synopsis !

PSECT name	Allocation	PSECT No.	Attributes
. ABS .	00000000 (0.)	00 (0.)	NOPIC USR CON ABS LCL NOSHR NOEXE NORD NOWRT NOVEC BYTE
\$AB\$\$	00000000 (0.)	01 (1.)	NOPIC USR CON ABS LCL NOSHR EXE RD WRT NOVEC BYTE
\$\$\$105_PROLOGUE	000000E8 (232.)	02 (2.)	NOPIC USR CON REL LCL NOSHR EXE RD WRT NOVEC BYTE
\$\$\$115_DRIVER	00000ACC (2764.)	03 (3.)	NOPIC USR CON REL LCL NOSHR EXE RD WRT NOVEC LONG

! Performance indicators !

Phase	Page faults	CPU Time	Elapsed Time
Initialization	29	00:00:00.04	00:00:00.19
Command processing	123	00:00:00.39	00:00:01.17
Pass 1	754	00:00:23.82	00:00:27.56
Symbol table sort	0	00:00:03.37	00:00:03.47
Pass 2	296	00:00:04.93	00:00:05.45
Symbol table output	44	00:00:00.23	00:00:00.45
Psect synopsis output	2	00:00:00.01	00:00:00.01
Cross-reference output	0	00:00:00.00	00:00:00.00
Assembler run totals	1250	00:00:32.79	00:00:38.30

The working set limit was 2550 pages.
198247 bytes (388 pages) of virtual memory were used to buffer the intermediate code.
There were 170 pages of symbol table space allocated to hold 3101 non-local and 128 local symbols.
1767 source lines were read in Pass 1, producing 24 object records in Pass 2.
80 pages of virtual memory were used to define 74 macros.

! Macro library statistics !

Macro library name	Macros defined
_\$255\$DUA28:[SYS.OBJ]LIB.MLB;1	35
_\$255\$DUA28:[SYSLIB]STARLET.MLB;2	12
TOTALS (all libraries)	47

3572 GETS were required to define 47 macros.

There were no errors, warnings or information messages.

MACRO/LIS=LISS:YFDRIVER/OBJ=OBJ\$:YFDRIVER MSRCS:YFDRIVER/UPDATE=(ENHS:YFDRIVER)+EXECMLS/LIB

