

MAINTAIN III

PWRFL

PAGE 1
thru 16

```

1 * THIS IS A COPYRIGHTED PROGRAM. COPYRIGHT 1970 BY VARIAN DATA MACHINES 04 00001
2 * V.D.M. PART NO. 92L0107-008F 04 00002
3 * 04 00003
4 * 04 00004
5 * 04 00005
6 * 04 00006
7 * 04 00007
8 * 04 00008
9 * 04 00009
10 * 04 00010
11 * 04 00011
12 * 04 00012
13 * 04 00013
14 * 04 00014
15 * 04 00015
16 * 04 00016
17 * 04 00017
18 * 04 00018
19 * 04 00019
20 * 04 00020
21 * 04 00021
22 * 04 00022
23 * 04 00023
24 * 04 00024
25 * 04 00025
26 * 04 00026
27 * 04 00027
28 * 04 00028
29 * 04 00029
30 * 04 00030
31 * 04 00031
32 * 04 00032
33 * 04 00033
34 * 04 00034
35 * 04 00035
36 * 04 00036
37 * THIS TEST PROGRAM IS PART OF THE MAINTAIN D 04 00037
38 * TEST PROGRAM SYSTEM D 04 00038
39 * 04 00039
40 * 04 00040
41 * 04 00041
42 ***** 04 00042
43 * 04 00043
44 * POWER FAIL / RESTART TEST PROGRAM. *04 00044
45 * THE PURPOSE OF THIS TEST IS TO VERIFY THAT THE A, B AND X *04 00045
46 * REGISTER, OVERFLOW BIT, AND CORE MEMORY HAS NOT BEEN MODIFIED *04 00046
47 * UPON COMPLETION OF A POWER FAILURE. *04 00047
48 * 04 00048
49 ***** 04 00049
50 * 04 00050
51 * 04 00051
52 * 04 00052
53 * 04 00053
54 * ****
55 * *
56 * * AREAS RESERVED BY EXECUTIVE * 04 00055
57 * **** 04 00056
58 * ORG 0 04 00058
59 * JMP EXECUTIVE 04 00059
60 * ORG 040 04 00060
61 * JMPM POWER DOWN ROUTINE 04 00061
62 * JMP POWER UP ROUTINE 04 00062
63 * NOTE: THE TEST EXECUTIVE ALSO RESERVES LOCATIONS 0400 TO 0477 04 00063
64 * FOR A POINTER TABLE TO STANDARD ROUTINES, AND AS AN AREA 04 00064
65 * FOR EXECUTIVE DATA. ALL TEST PROGRAMS WORKING WITH THE 04 00065
66 * EXECUTIVE MUST PRESERVE THIS BLOCK. 04 00066
67 * STANDARD ROUTINES WILL BE CALLED INDIRECTLY THRU 04 00067
68 * THIS TABLE 04 00068
69 * 04 00069
70 * 04 00070
71 * 04 00071
72 * 04 00072
000000 A 73 R0 SET 0 F 04 00073
000001 A 74 R1 SET 1 FF 04 00074
000002 A 75 R2 SET 2 FF 04 00075
000003 A 76 R3 SET 3 FF 04 00076
000004 A 77 R4 SET 4 FF 04 00077
000005 A 78 R5 SET 5 FF 04 00078
000006 A 79 R6 SET 6 FF 04 00079
000007 A 80 R7 SET 7 F 04 00080
81 *
82 *
000400 83 ORG 0400 04 00083
000400 84 OUTA BSS 1 OUTPUT ONE CHAR ROUTINE 04 00084
000401 85 OUTB BSS 1 OUTPUT TWO CHAR ROUTINE 04 00085
000402 86 OUTC BSS 1 OUTPUT CR/LF ROUTINE 04 00086
000403 87 OUTD BSS 1 OUTPUT MESSAGE ROUTINE 04 00087
000404 88 OUTE BSS 1 OUTPUT OCTAL WORD ROUTINE 04 00088
000405 89 OUTF BSS 1 OUTPUT OCTAL ADDR ROUTINE 04 00089
000406 90 OUTG BSS 1 OUTPUT ERROR MSG ROUTINE 04 00090
000407 91 OUTH BSS 1 OUTPUT CONTROL CHAR TO TTY ROUTINE 04 00091
000410 92 INPA BSS 1 INPUT ONE CHAR ROUTINE 04 00092
000411 93 INPB BSS 1 INPUT AND PRINT ONE CHAR ROUTINE 04 00093
000412 94 INPC BSS 1 INPUT ONE CHAR EDITED ROUTINE 04 00094
000413 95 INPD BSS 1 INPUT ONE ALPHA CHAR ROUTINE 04 00095

```

PAGE 2

MAINTAIN III

PWRFAL

000414		96	INPE	BSS	1	INPUT TWO ALPHA CHAR ROUTINE	04	00096
000415		97	INPF	BSS	1	INPUT COMMA/PERIOD TERMINATION ROUTINE	04	00097
000416		98	INPG	BSS	1	INPUT OCTAL NUMBER ROUTINE	04	00098
000417		99	TOUT	BSS	1	TIME-OUT ROUTINE	04	00099
000420		100	TDLY	BSS	1	TIME DELAY ROUTINE	04	00100
000421		101	SSWT	BSS	1	STANDARD SENSE SWITCH ROUTINE	04	00101
000422		102	SLWE	BSS	1	LOWEST WORD USED BY EXEC	04	00102
000423		103	ESZC	BSS	1	MEMORY SIZE DETERMINATION ROUTINE	04	00103
000424		104	SMSM	BSS	1	MEMORY SIZE MESSAGE	04	00104
		105	*				04	00105
		106	*				04	00106
000440		107	ORG	0440			04	00107
		108	*				04	00108
		109	*	EXECUTIVE DATA TABLE			04	00109
		110	*				04	00110
000440		111	SFLG	BSS	1	LOOP ON ERROR FLAG, 0=DON'T LOOP 1=LOOP	04	00111
000441		112	SMEM	BSS	1	MEMORY SIZE (HIGHEST AVAIL CORE)	04	00112
000442		113	SCDN	BSS	1	0=CONSOLE MODE 1=TTY MODE	04	00113
000443		114		BSS	22		04	00114
000471		115	SDCT	BSS	1	DIGIT COUNTER FOR INPG	04	00115
		116	*				04	00116
		117	*****	*****	*****	*****	04	00117
		118	*				*04	00118
		119	*****	*****	*****	*****	04	00119
000500	010041 A	120	ORG	0500			04	00120
000500	052650 A	121	FFRS	LDA	041		04	00121
000501	052650 A	122		STA	PFDN	SAVE POWER DOWN ADDRESS	04	00122
000502	010043 A	123		LDA	043		04	00123
000503	052651 A	124		STA	PFUP	SAVE POWER UP ADDRESS	04	00124
000504	010001 A	125		LDA	01		04	00125
000505	052652 A	126		STA	PFEX	TEST EXECUTIVE RESTART LOCATION	04	00126
000506	006010 A	127		LDAI	PFTM	POWER/FAILURE TERMINATION ROUTINE	04	00127
000507	002637 A							
000510	050001 A	128		STA	01		04	00128
000511	06020 A	129	PFRT	LDBI	02	SET ADDRESS PLUS SET BIT 8 IN LOCATIONS	04	00129
000512	000002 A					2 THROUGH 0377.		
000513	005021 A	130	PFR0	TBA			04	00130
000514	006110 A	131		ORAI	0400		04	00131
000515	000400 A							
000516	056000 A	132		STA	0,2		04	00132
000517	005122 A	133		IBR			04	00133
000520	005021 A	134		TBA			04	00134
000521	006140 A	135		SUBI	0400		04	00135
000522	000400 A							
000523	001010 A	136		JAZ	*+4		04	00136
000524	000527 A							
000525	001000 A	137		JMP	PFR0		04	00137
000526	000513 A							
000527	006010 A	138		LDAI	02000	SET UP POWER FAIL/RESTART ADDRESS IN	04	00138
000530	002000 A					INTERRUPT ADDRESSES.		
000531	050040 A	139		STA	040		04	00139
000532	050042 A	140		STA	042		04	00140
000533	006010 A	141		LDAI	PWRD		04	00141
000534	002475 A							
000535	050041 A	142		STA	041		04	00142
000536	006010 A	143		LDAI	PWRU		04	00143
000537	002427 A							
000540	050043 A	144		STA	043		04	00144
000541	010442 A	145	STRT	LDA	SCDN	CHECK IF CONSOLE MODE	04	00145
000542	001010 A	146		JAZ	PFR6		04	00146
000543	001021 A							
000544	006030 A	147		LDXI	MES1	NO - WRITE TEST TITLE	04	00147
000545	001026 A							
000546	002000 A	148		CALL*	OUTD		04	00148
000547	100403 A							
000550	006030 A	149		LDXI	MES6	ASK FOR TIME DELAY CONSTANT	04	00149
000551	001105 A							
000552	002000 A	150		CALL	<OUTD>*		04	00150
000553	100403 A							
000554	002000 A	151		CALL	<INPG>*	INPUT NO.	04	00151
000555	100416 A							
000556	001000 A	152		JMP	STRT	TERM. EXIT	04	00152
000557	000541 A							
000560	001000 A	153		JMP	STRT	ABORT EXIT	04	00153
000561	000541 A							
000562	001000 A	154		JMP	*+2	COMMA EXIT	04	00154
000563	000564 A							
000564	052532 A	155		STA	CNTT	SET CONSTANT	04	00155
000565	002000 A	156		CALL	<OUTC>*	CR/LF	04	00156
000566	100402 A							
000567	010442 A	157	PFR2	LDA	\$CON	CHECK IF CONSOLE MODE	04	00157
000570	001010 A	158		JAZ	PFR3		04	00158
000571	000600 A							
000572	006030 A	159		LDXI	MES2	WRITE HALT TEST TITLE	04	00159
000573	001045 A							
000574	002000 A	160		CALL*	OUTD		04	00160
000575	100403 A							
000576	002000 A	161		CALL	RING		04	00161
000577	002353 A							
000600	006010 A	162	PFR3	LDAI	2	SET UP INITIAL STOP CODE	04	00162
000601	000002 A							
000602	051157 A	163		STA	HLT4+2		04	00163
000603	002000 A	164		CALL	HLTT,0		04	00164
000604	001115 A							
000605	000000 A							

		MAINTAIN III		PWRFL		PAGE	3
000606	002000	A	165	CALL	RING		04 00165
000607	002353	A	166	JSS3	PFRT		04 00166
000610	001400	A	167	CALL	HLTT,0177777		04 00167
000611	000511	A					
000612	002000	A					
000613	001115	A					
000614	172777	A					
000615	002000	A	168	CALL	RING		04 00168
000616	002353	A	169	JSS3	PFRT		04 00169
000617	001400	A					
000620	000511	A					
000621	002000	A	170	CALL	HLTT,0125252		04 00170
000622	001115	A					
000623	125252	A					
000624	002000	A	171	CALL	RING		04 00171
000625	002353	A	172	JSS3	PFRT		04 00172
000626	001400	A					
000627	000511	A					
000630	002000	A	173	CALL	HLTT,0052525		04 00173
000631	001115	A					
000632	052525	A					
000633	001400	A	174	JSS3	PFRT		04 00174
000634	000511	A					
			175	*****	*****		04 00175
			176	*			04 00176
			177	*	HALT TEST COMPLETED		04 00177
			178	*			04 00178
			179	*	START VOLATILE REGISTER TEST		04 00179
			180	*****	*****		04 00180
000635	010442	A	181	LDA	\$CON	CHECK IF CONSOLE MODE.	04 00181
000636	001010	A	182	JAZ	PFR4		04 00182
000637	000650	A					
000640	006030	A	183	LDXI	MES4	NO - WRITE (VOLATILE REGISTER TEST)	04 00183
000641	001054	A					
000642	002000	A	184	CALL*	OUTD		04 00184
000643	100403	A					
000644	002000	A	185	CALL	RING		04 00185
000645	002353	A					
000646	001400	A	186	JSS3	PFRT		04 00186
000647	000511	A					
000650	007400	A	187	PFR4	ROF	SET UP VOLATILE REGISTERS	04 00187
000651	006010	A	188	LDI	6	SET UP ERROR HALT ADDRESS VALUE.	04 00188
000652	000006	A					
000653	051766	A	189	STA	PFV6+2		04 00189
000654	012426	A	190	LDA	V75		F 04 00190
000655	001010	A	191	JAZ	NOV75		F 04 00191
000656	000671	A					
000657	007443	A	192	LDI,R3	025253	DO IT	F 04 00192
000660	025253	A					
000661	007444	A	193	LDI,R4	025254	FOR	F 04 00193
000662	025254	A					
000663	007445	A	194	LDI,R5	025255	R3 THRU R7	F 04 00194
000664	025255	A					
000665	007446	A	195	LDI,R6	025256	IF A	F 04 00195
000666	025256	A					
000667	007447	A	196	LDI,R7	025257	V75 CPU	F 04 00196
000670	025257	A					
000671	006010	A	197	NOV75	LDI	0177777	
000672	172777	A					
000673	006020	A	198	LDI	0111111		04 00198
000674	111111	A					
000675	006030	A	199	LDXI	0155555		04 00199
000676	155555	A					
000677	002000	A	200	CALL	PFVE		04 00200
000700	001570	A					
000701	002000	A	201	CALL	RING		04 00201
000702	002353	A					
000703	001400	A	202	JSS3	PFRT		04 00202
000704	000511	A					
000705	006010	A	203	LDI	7	SET UP ERROR HALT ADDRESS VALUE.	04 00203
000706	000007	A					
000707	051766	A	204	STA	PFV6+2		04 00204
000710	007401	A	205	SDF			04 00205
000711	012426	A	206	LDA	V75		F 04 00206
000712	001010	A	207	JAZ	V75NOT		F 04 00207
000713	000726	A					
000714	007443	A	208	LDI,R3	0125254	V75	F 04 00208
000715	125254	A					
000716	007444	A	209	LDI,R4	0125253	REGISTERS	F 04 00209
000717	125253	A					
000720	007445	A	210	LDI,R5	0125252	T00	F 04 00210
000721	125252	A					
000722	007446	A	211	LDI,R6	0125251		F 04 00211
000723	125251	A					
000724	007447	A	212	LDI,R7	0125250		F 04 00212
000725	125250	A					
000726	006010	A	213	V75NOT	LDI	0100000	F 04 00213
000727	100000	A					
000730	006020	A	214	LDI	0066666		04 00214
000731	066666	A					
000732	006030	A	215	LDXI	0022222		04 00215
000733	022222	A					
000734	002000	A	216	CALL	PFVE		04 00216
000735	001570	A					
000736	001400	A	217	JSS3	PFRT		04 00217

PAGE 4

MAINTAIN III

PWRFAL

000737	000511	A	218	*****	*****	*****	04	00218
			219	*			04	00219
			220	*	VOLATILE REGISTER TEST COMPLETE		04	00220
			221	*****	*****	*****	04	00221
			222	*****	*****	*****	04	00222
			223	*			04	00223
			224	*	START CORE VALIDITY CHECK		04	00224
			225	*			04	00225
			226	*****	*****	*****	04	00226
000740	010442	A	227	LDA	\$CON	CHECK IF CONSOLE MODE	04	00227
000741	001010	A	228	JAZ	PFR5		04	00228
000742	000753	A	229	LDXI	MESS	WRITE - CORE VALIDITY CHECK.	04	00229
000743	006030	A	230	CALL*	OUTD		04	00230
000744	001071	A	231	CALL	RING		04	00231
000745	002000	A	232	JSS3	PFRT		04	00232
000746	100403	A	233	PFR5	LDAI	8	04	00233
000747	002000	A	234	STA	CRE5+2		04	00234
000748	000010	A	235	CALL	CREV,0		04	00235
000749	051254	A	236	CALL	RING		04	00236
000750	002353	A	237	JSS3	PFRT		04	00237
000751	001400	A	238	LDAI	9		04	00238
000752	000511	A	239	STA	CRE5+2		04	00239
000753	006010	A	240	CALL	CREV,0177777		04	00240
000754	000000	A	241	CALL	RING		04	00241
000755	002353	A	242	JSS3	PFRT		04	00242
000756	001400	A	243	LDAI	10		04	00243
000757	000511	A	244	STA	CRE5+2		04	00244
000758	006010	A	245	CALL	CREV,0125252		04	00245
000759	001174	A	246	CALL	RING		04	00246
000760	002353	A	247	JSS3	PFRT		04	00247
000761	001400	A	248	LDAI	11		04	00248
000762	000511	A	249	STA	CRE5+2		04	00249
000763	006010	A	250	CALL	CREV,0052525		04	00250
000764	001174	A	251	JMP	PFR2	RETURN TO BEGINNING OF TEST	04	00251
000765	000567	A	252	PFR6	TZA		04	00252
000766	005001	A	253	HLT	0777	ASK FOR TIME DELAY CONSTANT	04	00253
000767	000777	A	254	STA	CNTT	SET CONSTANT	04	00254
000768	052532	A	255	JMP	PFR3		04	00255
000769	000600	A	256	MES1	DATA	*POWER FAILURE/RESTART TEST*	04	00256
000770	150317	A	257	DATA	0106612	CARRIAGE RETURN/LINE FEED	04	00257
000771	153705	A	258	DATA	0		04	00258
000772	001240	A	259	MES2	DATA	*HALT TEST *	04	00259
000773	143301	A						
000774	144714	A						
000775	152722	A						
000776	142657	A						
000777	151305	A						
000778	151724	A						
000779	140722	A						
000780	152240	A						
000781	152305	A						
000782	151724	A						
000783	106612	A	257	DATA	0106612	CARRIAGE RETURN/LINE FEED	04	00257
000784	000000	A	258	DATA	0		04	00258
000785	144301	A	259	MES2	DATA	*HALT TEST *	04	00259
000786	146324	A						
000787	120324	A						
000788	142723	A						
000789	152240	A						
000790	106612	A	260	DATA	0106612,0		04	00260
000791	000000	A						
000792	153317	A	261	MES4	DATA	*VOLATILE REGISTER TEST*	04	00261
000793	146301	A						
000794	152311	A						
000795	146305	A						
000796	120322	A						
000797	142707	A						
000798	144723	A						
000799	152305	A						
000800	151240	A						

MAINTAIN III

PWRFLAL

PAGE 5

001065	152305	A				
001066	151724	A				
001067	106612	A	262	DATA	0106612,0	
001070	000000	A	263	MESS	DATA	
001071	141717	A	'CORE VALIDITY CHECK ',0106612,0			
001072	151305	A				
001073	120326	A				
001074	140714	A				
001075	144704	A				
001076	144724	A				
001077	154640	A				
001100	141710	A				
001101	142703	A				
001102	145640	A				
001103	106612	A				
001104	000000	A	264	MES6	DATA	
001105	152311	A	'TIME DELAY = ',0			
001106	146705	A				
001107	120304	A				
001110	142714	A				
001111	140731	A				
001112	120275	A				
001113	120240	A				
001114	000000	A				
001115	000000	A	265	*****		
001116	021115	A	266	*	04 00265	
001117	016000	A	267	*	*04 00266	
001120	051453	A	268	*	*04 00267	
001121	002000	A	269	HALT TEST SUBROUTINE	04 00268	
001122	001414	A	270	HLTT ENTR	04 00269	
001123	006010	A	271	LDB HLTT	STORE BACKGROUND VALUE IN BKGR.	
001124	001000	A	272	LDA 0,2	04 00270	
001125	052530	A	273	STA BKGR	04 00271	
001126	006010	A	274	CALL BCKG	04 00272	
001127	001143	A	275	LDAI 01000	BACKGROUND ALL UNUSED CORE.	
001128	052531	A	276	STA PHLT+1	04 00273	
001129	006010	A	277	LDAI HLT3	POWER DN/UP SEQ.	
001130	005000	A	278	STA PHLT+2	04 00274	
001131	052527	A	279	LDAI 05000	STORE NOP IN HALT INST. IN POWER UP SUB.	
001132	006010	A	280	HLT1 LDAI PHLT+1	04 00275	
001133	002530	A	281	TZB	04 00276	
001134	005002	A	282	TZX	04 00277	
001135	005004	A	283	HLT 01	HALT - WAIT FOR POWER DN/UP SEQ.	
001136	001000	A	284	JMP *-1	04 00278	
001141	001140	A	285	*****		
001142	001140	A	286	*	UPON DETECTING A PF/R WHILE IN THE HALT MODE, THE PF/R SAVE	
001143	005001	A	287	*	ROUTINE IS NOT EXECUTED. THE PF/R RESTORE ROUTINE IS	
001144	052530	A	288	*	EXECUTED UPON POWER UP. THIS SUBROUTINE DETECTS THAT THE SAVE	
001145	052527	A	289	*	ROUTINE HAS NOT EXECUTED AND HALTS AT LOCATION PHLT.	
001146	002000	A	290	*	THE OPERATOR PUSHES RUN AND CONTROL RETURNS TO HALT TEST SUB.	
001147	001456	A	291	*	04 00279	
001148	001010	A	292	*	04 00280	
001149	001163	A	293	*	04 00281	
001150	006020	A	294	HLT3 TZA	04 00282	
001151	001163	A	295	STA PHLT+1	ZERO OUT JUMP BACK TO HALT TEST SUB.	
001152	002543	A	296	STA PHLT	04 00283	
001153	032543	A	297	CALL CRCK	RESTORE HALT INST IN POWER UP SUB.	
001154	002000	A	298	JAZ NLTS	CHECK IF ANY BACKGROUND VALUES CHANGED.	
001155	100421	A	299	HLT6 LDBI EBUF	04 00284	
001156	000002	A	300	LDX EBUF	CHECK IF ERROR OCCURED	
001157	101263	A	301	*	04 00285	
001158	000511	A	302	*	A = NO. OF MODIFIED WORDS	
001159	001116	A	303	*	B = LOC OF ERROR TABLE	
001160	010440	A	304	*	X = 1ST LOC. WHERE BACKGROUND WORD	
001161	001010	A	305	HLT4 CALL*	MODIFIED.	
001162	001116	A	306	HLT5 LDA \$FLG	04 00286	
001163	010440	A	307	JAZ *+4	CHECK IF LOOPING	
001164	001010	A	308	JMP HLT6	04 00287	
001165	001170	A	309	INR HLT5	RETURN TO CALLING PROGRAM.	
001166	001000	A	310	INR HLT4+2	04 00309	
001167	001152	A	311	JMP* HLT5	04 00310	
001168	041115	A	312	*****		
001169	041157	A	313	*	CORE VALIDITY TEST	
001170	001000	A	314	*	ALL UNUSED CORE IS BACKGROUNDED TO CALLING PARAMETER.	
001171	001000	A	315	*	CORE IS CHECKED FOR MODIFIED VALUES.	
001172	001115	A	316	*	04 00311	
001173	101115	A	317	CREV ENTR	04 00312	
001174	000000	A	318	LDB CREV	GET PARAMETER (BACK-GROUND VALUE)	
001175	021174	A			04 00313	

PAGE	6	MAINTAIN III		PWRFLA				
001176	016000	A	319	LDA	0,2	04 00319		
001177	051453	A	320	STA	BKGR	04 00320		
001200	006010	A	321	CREL	LDAI	59	04 00321	
001201	000073	A	322	TAB		04 00322		
001202	005012	A	323	ADDI	EBUF	04 00323		
001204	002543	A	324	TAX		04 00324		
001205	005014	A	325	TZA		04 00325		
001206	005001	A	326	CRE1	STA	0,1	04 00326	
001207	055000	A	327	DXR		04 00327		
001210	005344	A	328	DBR		04 00328		
001211	005322	A	329	JBZ	*+4	04 00329		
001213	001216	A	330	JMP	CRE1		04 00330	
001214	001000	A	331	CALL	BCKG	BACKGROUND ALL UNUSED CORE	04 00331	
001216	002000	A	332	COMP	1	STORE NEG. NUMBER IN	04 00332	
001221	052475	A	333	STA	PWRD	INTERRUPT MARK LOCATION.	04 00333	
001222	020441	A	334	CRE3	LDB	\$MEM	04 00334	
001223	016000	A	335	CRE4	LDA	0,2	04 00335	
001224	005322	A	336	DBR			04 00336	
001225	001020	A	337	JBZ	*+4		04 00337	
001226	001231	A	338	JMP	CRE4		04 00338	
001227	001000	A	339	LDA	PWRD		04 00339	
001230	001223	A	340	JAP	*+4		04 00340	
001231	012475	A	341	JMP	CRE3		04 00341	
001235	001222	A	342	*	CALL	CRCK	PF/R INTERRUPT PROCESSED	04 00342
001236	002000	A	343			CHECK CORE VALIDITY	04 00343	
001237	001456	A	344	LDB	\$FLG		04 00344	
001240	020440	A	345	JAZ	*+4	CHECK ERROR FLAG	04 00345	
001241	001010	A	346	JMP	*+4	YES ERROR	04 00346	
001242	001245	A	347	JBZ	CRE6	CHECK IF LOOPING	04 00347	
001243	001000	A	348	LDBI	EBUF		04 00348	
001245	001020	A	349	LDX	EBUF		04 00349	
001252	002000	A	350	CRE5	CALL*	SSWT,7,(MSGE)*,PFRT,CREL	04 00350	
001253	100421	A						
001254	000007	A						
001255	101263	A						
001256	000511	A						
001257	001200	A	351	CRE6	INR	CREV	RETURN TO CALLING PROGRAM.	04 00351
001261	001000	A	352		JMP*	CREV		04 00352
001262	101174	A	353	MSGE	ENTR			
001263	000000	A	354		LDXI	MSG A	CURE MODIFIED WRITE ERROR MESSAGE ROUTINE	04 00353
001264	006030	A	355		CALL*	DUTD		04 00354
001265	001355	A	356	LDA	ERFG			04 00355
001266	002000	A	357	STA	MSG Z			04 00356
001270	012542	A	358	CALL*	DUTE			04 00357
001271	051413	A	359	LDAI	20			04 00358
001272	002000	A	360	LDXI	MSG B			04 00359
001273	100404	A	361	CALL*	DUTD			04 00360
001274	006030	A	362	LDAI	20			04 00361
001275	001371	A	363	SUB	MSG Z			04 00362
001276	002000	A	364	JAP	MSG X			04 00363
001277	100403	A	365	LDAI	20			04 00364
001300	006010	A	366	MSG X	STA	MSG Z		04 00365
001301	000024	A	367		TZA			04 00366
001302	141413	A	368	MSG 3	STA	MSG C		04 00367
001303	001002	A	369		LDA	MSG C		04 00368
001304	001310	A	370	ADDI	EBUG			04 00369
001305	006010	A	371	TAB				04 00370
001306	000024	A	372	LDA	0,2			04 00371
001307	051413	A	373	CALL*	DUTE			04 00372
001310	005001	A	374	INR	MSG C			04 00373
001311	051412	A	375	LDA	MSG C			04 00374
001312	011412	A	376	ADDI	EBUG			04 00375
001313	006120	A	377	TAB	0,2			04 00376
001314	002543	A	378	LDA	DUTE			04 00377
001315	005012	A	379	INR	MSG C			04 00378
001316	016000	A	380	LDA	MSG C			04 00379
001322	011412	A	381	ADDI	EBUG			04 00380
001333	006120	A						04 00381

MAINTAIN III

PHRFAL

PAGE 7

001334	002543	A	382	TAB			04	00382	
001335	005012	A	383	LDA	0,2		04	00383	
001336	016000	A	384	CALL*	OUTE		04	00384	
001337	002000	A	385	CALL*	OUTC	OUTPUT CR/LF	04	00385	
001340	100404	A	386	INR	MSGC		04	00386	
001342	100402	A	387	LDA	MSGZ		04	00387	
001343	041412	A	388	DAR			04	00388	
001344	011413	A	389	STA	MSGZ		04	00389	
001345	005311	A	390	JAZ*	MSGE		04	00390	
001347	001010	A	391	JSS1*	MSGE	IF SS1 SET TERMINATE MESSAGE	04	00391	
001350	101263	A	392	JMP	MSG3		04	00392	
001354	001312	A	393	MGSA	DATA	*ERROR - CORE MODIFIED ',0	04	00393	
001356	151317	A	394	MSGB	DATA	' TIMES',0106612	04	00394	
001357	151240	A	395		DATA	' LOC INITIAL FINAL ',0106612,0	04	00395	
001360	126640	A	396	MSGC	DATA	0	04	00396	
001361	141717	A	397	MSGZ	DATA	0	04	00397	
001362	151305	A	398	*****	*****	*****	04	00398	
001363	120315	A	399	*	THIS SUBROUTINE BACKGROUND ALL UNUSED CORE TO VALUE IN BKGR.		*04	00399	
001364	147704	A	400	*	IF OVER 4 K OF CORE, ALL THE REST IS BACKGROUNDED WITH BKGR		*04	00400	
001365	144706	A	401	*	VALUE.		*04	00401	
001366	144705	A	402	*****	*****	*****	04	00402	
001367	142240	A	403	BCKG	ENTR		04	00403	
001370	000000	A	404	LDA	\$LWE	CALC NO. OF WORDS IN 1'ST 4K TO BE	04	00404	
001371	120324	A	405	SUB	TBLG	BACKGROUNDED.	04	00405	
001372	144715	A	406	STA	NWBG		04	00406	
001373	142723	A	407	TZB			04	00407	
001374	106612	A	408	LDX	TBLG		04	00408	
001375	120314	A	409	BCK1	LDA	BCKG ALL UNUSED CORE IN 1ST. 4K.	04	00409	
001376	147703	A	410	STA	0,1		04	00410	
001377	120240	A	411	IXR			04	00411	
001400	144716	A	412	IBR			04	00412	
001401	144724	A	413	TBA			04	00413	
001402	144701	A	414	SUB	NWBG		04	00414	
001403	146240	A	415	JAN	BCK1		04	00415	
001404	120306	A	416	BCK3	LDA	\$MEM	CHECK IF MORE THAN 4K	04	00416
001405	144716	A	417	LSRA	12		04	00417	
001406	140714	A	418	JAZ*	BCKG		04	00418	
001407	120240	A	419	LDA	\$MEM	BACK-GROUND ALL CORE FROM 4K ON.	04	00419	
001410	106612	A	420	TAX			04	00420	
001411	000000	A	421	SUBI	907777		04	00421	
001431	001422	A	422	TAB			04	00422	
001432	010441	A	423	LDA	BKGR		04	00423	
001433	004354	A	424	BCK4	STA	0,1	04	00424	
001434	001010	A	425	DXR			04	00425	
001435	101414	A	426	DBR			04	00426	
001436	010441	A	427	JBZ*	BCKG		04	00427	
001440	006140	A	428	JMP	BCK4		04	00428	
001441	007777	A	429	BKGR	DATA	0	04	00429	
001453	000000	A	430	NWBG	DATA	0	04	00430	
001455	002653	A	431	TBLG	DATA	LLTP	LAST LOCATION OF TEST PROGRAM	04	00431
001456	000000	A	432	*****	*****	*****	04	00432	
001457	005001	A	433	*	CHECK BACKGROUND VALUES FOR MODIFICATION		*04	00433	
001460	052542	A	434	*****	*****	*****	04	00434	
001461	005002	A	435	CRCK	ENTR	ZERO ERROR FLAG	04	00435	
001462	005021	A	436	TZA			04	00436	
001463	005002	A	437	STA	ERFG		04	00437	
001464	005021	A	438	I2B			04	00438	
001465	005021	A	439	CRC1	TBA	CHECK IF 1ST 4K BACK-GROUND VALUES HAVE	04	00439	

PAGE	8	MAINTAIN III	PWRFL	
001463	121455	A 440	ADD TBLC	04 00440
001464	005014	A 441	TAX	04 00441
001465	015000	A 442	LDA 0,1	04 00442
001466	005014	A 443	TAX	04 00443
001467	141453	A 444	SUB BKGR	04 00444
001470	001010	A 445	JAZ CRC2	04 00445
001471	001475	A		
001472	002000	A 446	CALL CRER,LLTP	SAVE ERROR VALUES 04 00446
001473	001536	A		
001474	002653	A		
001475	005122	A 447	CRC2 IBR	04 00447
001476	005021	A 448	TBA	04 00448
001477	141454	A 449	SUB NWBG	04 00449
001500	001004	A 450	JAN CRC1	04 00450
001501	001462	A		
001502	010441	A 451	LDA \$MEM	CHECK IF MORE THAN 4 K. 04 00451
001503	004354	A 452	LSRA 12	04 00452
001504	001010	A 453	JAZ CRC4	04 00453
001505	001533	A		
001506	010441	A 454	LDA \$MEM	CHECK IF BACKGROUND MODIFIED 04 00454
001507	006140	A 455	SUBI 007777	OVER 4 K. 04 00455
001510	007777	A		
001511	005012	A 456	TAB	04 00456
001512	005021	A 457	CRC3 TBA	04 00457
001513	006120	A 458	ADDI 07777	04 00458
001514	007777	A		
001515	005014	A 459	TAX	04 00459
001516	015000	A 460	LDA 0,1	04 00460
001517	005014	A 461	TAX	04 00461
001520	141453	A 462	SUB BKGR	04 00462
001521	001010	A 463	JAZ *+3	SAVE ERROR VALUE 04 00463
001522	001526	A		
001523	002000	A 464	CALL CRER,07777	04 00464
001524	001536	A		
001525	007777	A		
001526	005322	A 465	DBR	04 00465
001527	001020	A 466	JBZ CRC4	CHECK IF ALL WORDS OVER 4K CHECKED 04 00466
001530	001533	A		
001531	001000	A 467	JMP CRC3	04 00467
001532	001512	A		
001533	012542	A 468	CRC4 LDA ERFG	STORE ERROR CODE IN A 04 00468
001534	001000	A 469	JMP* CRCK	04 00469
001535	101456	A		
001536	000000	A 470	CRER ENTR	04 00470
001537	061567	A 471	STB SVB	04 00471
001540	012542	A 472	LDA ERFG	04 00472
001541	006140	A 473	SUBI 20	CHECK IF OVER 20 ERRORS 04 00473
001542	000024	A		
001543	001002	A 474	JAP CREZ	04 00474
001544	001563	A		
001545	012542	A 475	LDA ERFG	GET TABLE LOC. 04 00475
001546	122542	A 476	ADD ERFG	04 00476
001547	122542	A 477	ADD ERFG	04 00477
001550	006120	A 478	ADDI EBUF	STORE INITIAL BACKGROUND 04 00478
001551	002543	A		
001552	005012	A 479	TAB	VALUE IN 2ND WORD 04 00479
001553	076002	A 480	STX 2,2	04 00480
001554	011453	A 481	LDA BKGR	STORE ACTURAL CORE VALUE IN 3RD. WORD 04 00481
001555	056001	A 482	STA 1,2	04 00482
001556	031536	A 483	LDX CRER	04 00483
001557	015000	A 484	LDA 0,1	04 00484
001560	041536	A 485	INR CRER	TABLE SIZE IS (3,20) 04 00485
001561	121567	A 486	ADD SVB	04 00486
001562	036000	A 487	STA 0,2	04 00487
001563	042542	A 488	CREZ INR ERFG	04 00488
001564	021567	A 489	LDB SVB	RETURN B REGISTER 04 00489
001565	001000	A 490	JMP* CRER	04 00490
001566	101536	A		
001567	000000	A 491	SVB DATA 0	04 00491
		492	*****	04 00492
		493	X	SUBROUTINE TO CHECK VOLATILE REGISTERS UPON PF/R 04 00493
		494	*****	04 00494
001570	000000	A 495	PFVE ENTR	04 00495
001571	052016	A 496	STA PFVS	04 00496
001572	062017	A 497	STB PFVS+1	04 00497
001573	072020	A 498	STX PFVS+2	04 00498
001574	012426	A 499	LDA V75	F 04 00499
001575	001010	A 500	JAZ NOTV75	F 04 00500
001576	001611	A		
001577	007130	A 501	ST,R3 PFVS+5	F 04 00501
001600	002023	A 502	ST,R4 PFVS+6	F 04 00502
001601	007140	A 503	ST,R5 PFVS+7	F 04 00503
001602	002024	A 504	ST,R6 PFVS+8	F 04 00504
001603	007150	A 505	ST,R7 PFVS+9	F 04 00505
001604	002025	A		
001605	007160	A 506	NOTV75 TZ	F 04 00506
001606	002026	A 507	ADFA	04 00507
001607	007170	A 508	STA PFVS+3	04 00508
001610	002027	A 509	LDAI PFV1+2	04 00509
001611	005001	A 510	STA PFVS+4	04 00510

MAINTAIN III				PWRFAL	PAGE 9
001617	006010	A	511 *		
001620	005000	A	512 PFVL LDAI	05000	04 00511 04 00512
001621	051654	A	513 STA	PFV1	04 00513
001622	022017	A	514 LDB	PFVS+1	04 00514
001623	032020	A	515 LDX	PFVS+2	04 00515
001624	012426	A	516 LDA	V75	F 04 00516
001625	001010	A	517 JAZ	PFVL1	F 04 00517
001626	001641	A		AND	
001627	007030	A		R3	
001630	002023	A	518 LD,R3	PFVS+5	F 04 00518
001631	007040	A	519 LD,R4	PFVS+6	F 04 00519
001632	002024	A	520 LD,R5	PFVS+7	F 04 00520
001633	007050	A	521 LD,R6	PFVS+8	F 04 00521
001634	002025	A		A	
001635	007060	A			
001636	002026	A			
001637	007070	A	522 LD,R7	PFVS+9	F 04 00522
001640	002027	A		V75	
001641	007400	A	523 PFVL1 R0F		F 04 00523
001642	012021	A	524 LDA	PFVS+3	04 00524
001643	001010	A	525 JAZ	*+3	04 00525
001644	001646	A			
001645	007401	A	526 SDF		04 00526
001646	012016	A	527 LDA	PFVS	04 00527
001647	001004	A	528 JAN	*+4	04 00528
001650	001653	A			
001651	005211	A	529 CPA		04 00529
001652	052016	A	530 STA	PFVS	04 00530
001653	052475	A	531 STA	PWRD	04 00531
001654	005000	A	532 *		04 00532
001655	012475	A	533 PFV1 NOP		04 00533
001656	002004	A	534 LDA	PWRD	04 00534
001657	001654	A	535 JANM	PFV1	04 00535
001660	052034	A	536 STA	PFVI+4	F 04 00536
001661	012463	A	537 LDA	SAVA	04 00537
001662	052030	A	538 STA	PFVI	04 00538
001663	012464	A	539 LDA	SAVB	04 00539
001664	052031	A	540 STA	PFVI+1	04 00540
001665	012465	A	541 LDA	SAVX	04 00541
001666	052032	A	542 STA	PFVI+2	04 00542
001667	012466	A	543 LDA	SAVO	04 00543
001670	052033	A	544 STA	PFVI+3	04 00544
001671	012426	A	545 LDA	V75	F 04 00545
001672	001010	A	546 JAZ	PFVEII1	F 04 00546
001673	001712	A			
001674	012467	A	547 LDA	SAVR3	F 04 00547
001675	052035	A	548 STA	PFVI+5	F 04 00548
001676	012470	A	549 LDA	SAVR4	F 04 00549
001677	052036	A	550 STA	PFVI+6	F 04 00550
001700	012471	A	551 LDA	SAVR5	F 04 00551
001701	052037	A	552 STA	PFVI+7	F 04 00552
001702	012472	A	553 LDA	SAVR6	F 04 00553
001703	052040	A	554 STA	PFVI+8	F 04 00554
001704	012473	A	555 LDA	SAVR7	F 04 00555
001705	052041	A	556 STA	PFVI+9	F 04 00556
001706	006030	A	557 LDXI	9	F 04 00557
001707	000011	A			
001710	001000	A	558 JMP	PFVEII1+2	F 04 00558
001711	001714	A			
001712	006030	A	559 PFVEII1 LDXI	4	F 04 00559
001713	000004	A			
001714	005002	A	560 T2B		04 00560
001715	062045	A	561 STB	PFVT+3	04 00561
001716	005041	A	562 PFV2 TXA		04 00562
001717	006120	A	563 ADDI	PFVS	04 00563
001720	002016	A			
001721	005012	A	564 TAB		04 00564
001722	016000	A	565 LDA	0+2	04 00565
001723	051733	A	566 STA	PFV7+1	04 00566
001724	005041	A	567 TXA		04 00567
001725	006120	A	568 ADDI	PFVI	04 00568
001726	002030	A			
001727	005012	A	569 TAB		04 00569
001730	016000	A	570 LDA	0+2	04 00570
001731	052044	A	571 STA	PFVT+2	04 00571
001732	006140	A	572 PFV7 SUBI	0	04 00572
001733	000000	A			
001734	001010	A	573 JAZ	PFV3	04 00573
001735	001751	A			
001736	005111	A	574 IAR		
001737	002019	A	575 JAZM	PFV9	MEMORY PROTECT OPTION CAN INT AT 2 LOCATION TEST FOR 2'ND LOCATION 04 00574 04 00575
001740	002001	A			
001741	022045	A	576 LDB	PFVT+3	04 00576
001742	004041	A	577 LRLB	1	04 00577
001743	005122	A	578 IBR		04 00578
001744	062045	A	579 STB	PFVT+3	04 00579
001745	011733	A	580 LDA	PFV7+1	04 00580
001746	052042	A	581 STA	PFVT	04 00581
001747	012044	A	582 LDA	PFVT+2	04 00582
001750	052043	A	583 STA	PFVT+1	04 00583
001751	001040	A	584 PFV3 JXZ	*+5	CHECK IF 5 REGISTERS CHECKED 04 00584
001752	001756	A			
001753	005344	A	585 DXR		04 00585

PAGE	10	MAINTAIN III		PWRFL			
001754	001000	A	586	JMP	PFV2	04 00586	
001755	001716	A	587	LDB	PFVT+3	04 00587	
001756	022045	A	588	JBZ	PFV5	04 00588	
001757	001020	A			CHECK IF ERROR		
001760	001774	A					
001761	005021	A	589	PFV4	TBA	04 00589	
001762	022042	A	590	LDB	PFVT	04 00590	
001763	032043	A	591	LDX	PFVT+1	04 00591	
001764	002000	A	592	CALL*	SSWT,5,(MSGR)*,PFRT,PFVL	04 00592	
001765	100421	A					
001766	000005	A					
001767	102046	A					
001770	000511	A					
001771	001617	A					
001772	001000	A	593	JMP*	PFVE	04 00593	
001773	101570	A					
001774	010440	A	594	PFV5	LDA \$FLG	04 00594	
001775	001010	A	595	JAZ*	PFVE	04 00595	
001776	101570	A					
001777	001000	A	596	JMP	PFV4	04 00596	
002000	001761	A					
002001	000000	A	597	PFV9	ENTR 0	04 00597	
002002	005041	A	598	TXA	IF CHECKING (P), O.K.	04 00598	
002003	006140	A	599	SUBI	ELSE	04 00599	
002004	000004	A					
002005	001004	A	600	JAN	(PFV9)*	04 00600	
002006	102001	A			ERROR RETURN		
002007	001000	A	601	JMP	PFV3	04 00601	
002010	001751	A					
002011	005311	A	602	DAR	WILL BE NEEDED IF MP OPTION USED.	04 00602	
002012	001010	A	603	JAZ	(INTERRUPTS WILL NOT BE DISABLED ON A	04 00603	
002013	001751	A					
002014	001000	A	604	JMP*	PFV9	04 00604	
002015	102001	A			JUMP AND MARK INSTRUCTION. >		
002016			605	PFVS	BSS 10	F 04 00605	
002030			606	PFVI	BSS 10	F 04 00606	
002042			607	PFVT	BSS 4	04 00607	
002046	000000	A	608	MSGR	ENTR	04 00608	
002047	006030	A	609	LDXI	MSG1	04 00609	
002050	002270	A					
002051	002000	A	610	CALL*	OUTD	04 00610	
002052	100403	A					
002053	012016	A	611	LDA	PFVS	04 00611	
002054	002000	A	612	CALL*	OUTE	04 00612	
002055	100404	A					
002056	012030	A	613	LDA	PFVI	04 00613	
002057	002000	A	614	CALL*	OUTE	04 00614	
002060	100404	A					
002061	002000	A	615	CALL*	OUTC	04 00615	
002062	100402	A			OUTPUT CR/LF		
002063	006030	A	616	LDXI	MSG2+8	04 00616	
002064	002314	A					
002065	002000	A	617	CALL*	OUTD	04 00617	
002066	100403	A					
002067	012017	A	618	LDA	PFVS+1	04 00618	
002070	002000	A	619	CALL*	OUTE	04 00619	
002071	100404	A					
002072	012031	A	620	LDA	PFVI+1	04 00620	
002073	002000	A	621	CALL*	OUTE	04 00621	
002074	100404	A					
002075	002000	A	622	CALL*	OUTC	04 00622	
002076	100402	A					
002077	006030	A	623	LDXI	MSG2+4	04 00623	
002100	002318	A			X REGISTER VALUES		
002101	002000	A	624	CALL*	OUTD	04 00624	
002102	100403	A					
002103	012020	A	625	LDA	PFVS+8	04 00625	
002104	002000	A	626	CALL*	OUTE	04 00626	
002105	100404	A					
002106	012032	A	627	LDA	PFVI+8	D 04 00627	
002107	002000	A	628	CALL*	OUTE	04 00628	
002110	100404	A					
002111	002000	A	629	CALL*	OUTC	04 00629	
002112	100402	A					
002113	012426	A	630	LDA	V75	F 04 00630	
002114	001010	A	631	JAZ	PREGMS	F 04 00631	
002115	002212	A					
002116	006030	A	632	LDXI	MSGR3	R3 REGISTER VALUES	F 04 00632
002117	002334	A					
002120	002000	A	633	CALL*	OUTD	F 04 00633	
002121	100403	A					
002122	012023	A	634	LDA	PFVS+5	F 04 00634	
002123	002000	A	635	CALL*	OUTE	F 04 00635	
002124	100404	A					
002125	012035	A	636	LDA	PFVI+5	F 04 00636	
002126	002000	A	637	CALL*	OUTE	F 04 00637	
002127	100404	A					
002130	002000	A	638	CALL*	OUTC	F 04 00638	
002131	100402	A					
002132	006030	A	639	LDXI	MSGR4	R4 REGISTER VALUES	F 04 00639
002133	002337	A					
002134	002000	A	640	CALL*	OUTD	F 04 00640	
002135	100403	A					
002136	012024	A	641	LDA	PFVS+6	F 04 00641	
002137	002000	A	642	CALL*	OUTE	F 04 00642	

MAINTAIN III

PWRFL

PAGE 11

002140	100404	A	643	LDA	PFVI+6		F	04 00643
002141	012036	A	644	CALL*	DUTE		F	04 00644
002142	002000	A	645	CALL*	DUTC	OUTPUT CR/LF	F	04 00645
002143	100404	A	646	LDXI	MSGR5	R5 REGISTER VALUES	F	04 00646
002147	002342	A	647	CALL*	DUTD		F	04 00647
002150	002000	A	648	LDA	PFVS+7		F	04 00648
002152	012025	A	649	CALL*	DUTE		F	04 00649
002154	100404	A	650	LDA	PFVI+7		F	04 00650
002155	012037	A	651	CALL*	DUTE		F	04 00651
002157	100404	A	652	CALL*	DUTC	OUTPUT CRLF	F	04 00652
002161	100402	A	653	LDXI	MSGR6	R6 VALUES	F	04 00653
002163	002345	A	654	CALL*	DUTD		F	04 00654
002165	100403	A	655	LDA	PFVS+8		F	04 00655
002167	002000	A	656	CALL*	DUTE		F	04 00656
002170	100404	A	657	LDA	PFVI+8		F	04 00657
002172	002000	A	658	CALL*	DUTE		F	04 00658
002173	100404	A	659	CALL*	DUTC	CRLF	F	04 00659
002175	100402	A	660	LDXI	MSGR7	R7 VALUES	F	04 00660
002177	002350	A	661	CALL*	DUTD		F	04 00661
002200	002000	A	662	LDA	PFVS+9		F	04 00662
002201	100403	A	663	CALL*	DUTE		F	04 00663
002204	100404	A	664	LDA	PFVI+9		F	04 00664
002205	012041	A	665	CALL*	DUTE		F	04 00665
002207	100404	A	666	CALL*	DUTC	CRLF	F	04 00666
002211	100402	A	667	PREGMS	LDXI	P REGISTER VALUE	F	04 00667
002213	002322	A	668	CALL*	DUTD			04 00668
002214	002000	A	669	LDA	PFVS+4			04 00669
002216	012022	A	670	CALL*	DUTE			04 00670
002220	100404	A	671	LDA	PFVI+4			04 00671
002221	012034	A	672	CALL*	DUTE			04 00672
002223	100404	A	673	CALL*	DUTC	OUTPUT CR/LF		04 00673
002225	100402	A	674	LDXI	MSG2+6	WRITE OVER FLOW MESSAGE		04 00674
002227	002320	A	675	CALL*	DUTD			04 00675
002230	002000	A	676	LDA	PFVS+3			04 00676
002231	100403	A	677	JAZ	*+6			04 00677
002232	012021	A	678	LDXI	MSG2+14			04 00678
002233	001010	A	679	JMP	*+4			04 00679
002234	002241	A	680	LDXI	MSG2+10			04 00680
002236	002330	A	681	CALL*	DUTD			04 00681
002244	100403	A	682	LDAI	*	WRITE 1 BLANK CHAR.		04 00682
002245	006010	A	683	CALL*	DUTA			04 00683
002246	120240	A	684	LDA	PFVI+3			04 00684
002247	002000	A	685	JAZ	*+6			04 00685
002250	100400	A	686	LDXI	MSG2+14			04 00686
002251	012033	A	687	JMP	*+4			04 00687
002252	001010	A	688	LDXI	MSG2+10			04 00688
002253	002260	A	689	CALL*	DUTD			04 00689
002254	006030	A	690	CALL*	DUTC	OUTPUT CR/LF		04 00690
002255	002330	A	691	JMP*	MSGR			04 00691
002257	002262	A	692	MSG1	DATA	' REGISTER ERROR ',0106612		04 00692
002271	142707	A						
002272	144723	A						
002273	152305	A						
002274	151240	A						
002275	142722	A						
002276	151317	A						

PAGE 12

MAINTAIN III

PWRFL

002277	151240	A					
002300	106612	A					
002301	120311	A	693	DATA	' INITIAL . FINAL ',0106612	04 00693	
002302	147311	A					
002303	152311	A					
002304	140714	A					
002305	120240	A					
002306	143311	A					
002307	147301	A					
002310	146240	A					
002311	106612	A					
002312	140640	A	694	MSG2	DATA "A ",0,"B ",0,"X ",0,"OF",0,"P ",0,"DM",0,"OFF",0	04 00694	
002313	000000	A					
002314	141240	A					
002315	000000	A					
002316	154240	A					
002317	000000	A					
002320	147706	A					
002321	000000	A					
002322	150240	A					
002323	000000	A					
002324	120240	A					
002325	120240	A					
002326	147716	A					
002327	000000	A					
002330	120240	A					
002331	120317	A					
002332	143306	A					
002333	000000	A					
002334	151263	A	695	MSGR3	DATA "R3 ",0	F 04 00695	
002335	120240	A					
002336	000000	A					
002337	151264	A	696	MSGR4	DATA "R4 ",0	F 04 00696	
002340	120240	A					
002341	000000	A					
002342	151265	A	697	MSGR5	DATA "R5 ",0	F 04 00697	
002343	120240	A					
002344	000000	A					
002345	151266	A	698	MSGR6	DATA "R6 ",0	F 04 00698	
002346	120240	A					
002347	000000	A					
002350	151267	A	699	MSGR7	DATA "R7 ",0	F 04 00699	
002351	120240	A					
002352	000000	A					
002353	000000	A	700	RING	ENTR	04 00700	
002354	010442	A	701	LDA	\$CON	04 00701	
002355	001010	A	702	JAZ*	RING	04 00702	
002356	102353	A					
002357	006030	A	703	LDXI	MRNG	04 00703	
002360	002365	A					
002361	002000	A	704	CALL*	OUTD	04 00704	
002362	100403	A					
002363	001000	A	705	JMP*	RING	04 00705	
002364	102353	A					
002365	100200	A	706	MRNG	DATA 0100200	04 00706	
002366	100200	A	707		DATA 0100200	04 00707	
002367	100200	A	708		DATA 0100200	04 00708	
002370	100200	A	709		DATA 0100200	04 00709	
002371	100207	A	710		DATA 0100207	04 00710	
002372	000000	A	711		DATA 0	04 00711	
002373	006020	A	712	M23	LDBI 04354	MAINTAIN II	D 04 00712
002374	004354	A	713	LDXI	07777		D 04 00713
002376	007777	A					
002377	010422	A	714	LDA	\$LWE	LOWEST LOCATION USED BY EXEC	D 04 00714
002400	006150	A	715	ANAI	010000		D 04 00715
002401	010000	A					
002402	001010	A	716	JAZ	M23C		E 04 00716
002403	002410	A					
002404	006020	A	717	LDBI	04355	MAINTAIN III	E 04 00717
002405	004353	A					
002406	006030	A	718	LDXI	017777		D 04 00718
002407	017777	A					
002410	061433	A	719	M23C	STB BCK3+1		D 04 00719
002411	061503	A	720		STB CRC2+6		D 04 00720
002412	071441	A	721		STX BCK3+7		D 04 00721
002413	071510	A	722		STX CRC3-2		D 04 00722
002414	071514	A	723		STX CRC3+2		D 04 00723
002415	007400	A	724		ROF		F 04 00724
002416	007411	A	725		DATA 07411		F 04 00725
002417	001001	A	726		JOF PFRS		F 04 00726
002420	000500	A					
002421	006010	A	727	LDAI	-1		F 04 00727
002422	177777	A					
002423	052426	A	728	STA	V75		F 04 00728
002424	001000	A	729	JMP	PFRS		D 04 00729
002425	000500	A					
002426	000000	A	730	V75	DATA 0		F 04 00730
731	*****						04 00731
732	*						04 00732
733	*				TYPICAL POWER UP/DOWN SUBROUTINE		04 00733
734	*				POWER DOWN INTERRUPT ADDRESS 040		04 00734
735	*				POWER UP INTERRUPT ADDRESS 042		04 00735
736	*						04 00736
737	*						04 00737

MAINTAIN III			PWRFL			PAGE 13	
			738 *	POWER UP PROCESSOR		04 00738	
			739 *			04 00739	
			740 *****			04 00740	
002427	000000 A	741 PWRU	ENTR			04 00741	
002430	012474 A	742 LDA	HLTF	CHECK IF POWERING UP FROM RUN CONDITION		04 00742	
002431	001010 A	743 JAZ	PHLT			04 00743	
002432	002527 A						
002433	005001 A	744 TZA		CLEAR POWER FAIL/RESTR RT FLAG		04 00744	
002434	052474 A	745 STA	HLTF			04 00745	
		746 *****				04 00746	
		747 *				04 00747	
		748 *	CODING TO REINSTATE 620/F OPTIONAL HARDWARE AFTER A			04 00748	
		749 *	POWER FAILURE, MUST BE DEFINED HERE. THE TOTAL EXECUTION			04 00749	
		750 *	TIME NOT TO EXCEED A SPECIFIED TIME PERIOD. SEE PPS			04 00750	
		751 *	FOR TIMING CONSTRAINTS.			04 00751	
		752 *****				04 00752	
002435	012466 A	753 LDA	SAVO	SETUP OVERFLOW FLAG		04 00753	
002436	001010 A	754 JAZ	*+3			04 00754	
002437	002441 A						
002440	007401 A	755 SDF				04 00755	
002441	012426 A	756 LDA	V75		F	04 00756	
002442	001010 A	757 JAZ	NAYV75		F	04 00757	
002443	002456 A						
002444	007030 A	758 LD,R3	SAVR3		F	04 00758	
002445	002467 A						
002446	007040 A	759 LD,R4	SAVR4		F	04 00759	
002447	002470 A						
002450	007050 A	760 LD,R5	SAVR5		F	04 00760	
002451	002471 A						
002452	007060 A	761 LD,R6	SAVR6		F	04 00761	
002453	002472 A						
002454	007070 A	762 LD,R7	SAVR7		F	04 00762	
002455	002473 A						
002456	012463 A	763 NAYV75	LDA	SAVA		F	04 00763
002457	022464 A	764 LDB	SAVB			04 00764	
002460	032465 A	765 LDX	SAVX			04 00765	
002461	001000 A	766 JMP*	PWRD	RETURN TO LOCATION INTERRUPTED FROM		04 00766	
002462	102475 A						
		767 *				04 00767	
002463	000000 A	768 SAVA	DATA	0		04 00768	
002464	000000 A	769 SAVB	DATA	0		04 00769	
002465	000000 A	770 SAVX	DATA	0		04 00770	
002466	000000 A	771 SAVO	DATA	0		04 00771	
002467	000000 A	772 SAVR3	DATA	0		F 04 00772	
002470	000000 A	773 SAVR4	DATA	0		F 04 00773	
002471	000000 A	774 SAVR5	DATA	0		F 04 00774	
002472	000000 A	775 SAVR6	DATA	0		F 04 00775	
002473	000000 A	776 SAVR7	DATA	0		F 04 00776	
002474	000000 A	777 HLTF	DATA	0		04 00777	
		778 *****				04 00778	
		779 *				04 00779	
		780 *	POWER DOWN PROCESSOR			04 00780	
		781 *				04 00781	
		782 *****				04 00782	
002475	000000 A	783 PWRD	ENTR			04 00783	
002476	072533 A	784 STX	TSX			04 00784	
002477	032532 A	785 LDY	CNTT			04 00785	
002500	002500 A	786 CALL	TMDL			04 00786	
002501	002504 A						
002502	032533 A	787 LDX	TSX			04 00787	
002503	052463 A	788 STA	SAVA	SAVE A, B AND X REGISTERS		04 00788	
002504	062464 A	789 STB	SAVB			04 00789	
002505	072465 A	790 STX	SAVX			04 00790	
002506	012426 A	791 LDA	V75		F	04 00791	
002507	001010 A	792 JAZ	PWDN1		F	04 00792	
002510	002523 A						
002511	007130 A	793 ST,R3	SAVR3			F 04 00793	
002512	002467 A						
002513	007140 A	794 ST,R4	SAVR4			F 04 00794	
002514	002470 A						
002515	007150 A	795 ST,R5	SAVR5			F 04 00795	
002516	002471 A						
002517	007160 A	796 ST,R6	SAVR6			F 04 00796	
002520	002472 A						
002521	007170 A	797 ST,R7	SAVR7			F 04 00797	
002522	002473 A						
002523	005001 A	798 PWDN1	TZA	CHECK AND SAVE OVER-FLOW CONDITION		F 04 00798	
002524	005511 A	799 ADFA		INCREMENT A IF OVERFLOW SET		04 00799	
002525	052466 A	800 STA	SAVO			04 00800	
002526	042474 A	801 INR	HLTF	SET POWER FAIL/RESTR RT FLAG.		04 00801	
002527	000000 A	802 PHLT	HLT			04 00802	
002530		803 BSS	2			04 00803	
		804 *****				04 00804	
		805 *				04 00805	
		806 *****				04 00806	
002532	000507 A	807 CNTT	DATA	327		04 00807	
002533	000000 A	808 TSX	DATA	0		04 00808	
002534	000000 A	809 TMDL	ENTR			04 00809	
002535	001040 A	810 JXZ*	TMDL			04 00810	
002536	102534 A						
002537	005344 A	811 DXR				04 00811	
002540	001000 A	812 JMP	*-3			04 00812	
002541	002535 A						
002542	000000 A	813 ERFG	DATA	0		04 00813	
002543	000000 A	814 EBUF	BSS	60		04 00814	

96	INPE	*									
97	INPF	*									
98	INPG	151									
826	LLTP	431	446								
712	M23	827									
719	M23C	716									
256	MES1	147									
259	MES2	159									
261	MES4	183									
263	MES5	229									
264	MES6	149									
393	MGSA	354									
706	MRNG	703									
692	MSG1	609									
694	MSG2	616	623	667	674	678	680	686	688		
368	MSG3	392									
394	MSGB	359									
396	MSGC	367	368	373	374	379	380	386			
353	MSGE	305	350	390	391						
608	MSGR	592	691								
695	MSGR3	632									
696	MSGR4	639									
697	MSGR5	646									
698	MSGR6	653									
699	MSGR7	660									
366	MSGX	363									
397	MSGZ	357	362	365	387	389					
763	NAYV75	757									
506	NOTV75	500									
197	NOV75	191									
430	NWBG	406	414	449							
84	OUTA	683									
85	OUTB	*									
86	OUTC	156	385	615	622	629	638	645	652	659	
		666	673	690							
87	OUTD	148	150	160	184	230	355	360	610	617	
		624	633	640	647	654	661	668	675	681	
		689	704								
88	OUTE	358	372	378	384	612	614	619	621	626	
		628	635	637	642	644	649	651	656	658	
		663	665	670	672						
89	OUTF	*									
90	OUTG	*									
91	OUTH	*									
823	PFDM	122	816								
825	PFEX	126	820								
130	PFR0	137									
157	PFR2	251									
162	PFR3	158	255								
187	PFR4	182									
233	PFR5	228									
252	PFR6	146									
121	PFRS	726	729								
129	PFRT	166	169	172	174	186	202	217	232	237	
		242	247	305	350	592					
815	PFTM	127									
824	PFUP	124	818								
533	PFV1	509	513	535							
562	PFV2	586									
584	PFV3	573	601	603							
589	PFV4	596									
594	PFV5	588									
592	PFV6	199	204								
572	PFV7	566	580								
597	PFV9	575	600	604							
495	PFVE	200	216	593	595						
559	PFVEII	546	558								
606	PFVI	536	538	540	542	544	548	550	552	554	
		556	568	613	620	627	636	643	650	657	
		664	671	684							
512	PFVL	592									
523	PFVLI	517									
605	PFVS	496	497	498	506	510	514	515	524	527	
		530	563	611	618	625	634	641	648	655	
		662	669	676							
607	PFVT	561	571	576	579	581	582	583	587	590	
		591									
802	PHLT	275	277	279	280	295	296	743			
667	PREGMS	631									
798	PWDN1	792									
783	PWRD	141	333	339	531	534	766				
741	PWRU	143									
73	R0	*									
74	R1	*									
75	R2	*									
76	R3	192	208	501	518	758	793				
77	R4	193	209	502	519	759	794				
78	R5	194	210	503	520	760	795				
79	R6	195	211	504	521	761	796				
80	R7	196	212	505	522	762	797				
700	RING	161	165	168	171	185	201	231	236	241	
		246	702	705							
768	SAVA	537	763	788							
769	SAVE	539	764	789							
771	SAVO	543	753	800							

PAGE 16

MAINTAIN III

PWRFAL