

MAINTAIN III

MEMPT1

PAGE 1
thru 19

1 * THIS IS A COPYRIGHTED PROGRAM. COPYRIGHT 1971 BY VARIAN DATA MACHINES 04 00001
 2 * 04 00002
 3 * V.D.M. PART NO. 92L0107-020J 04 00003
 4 * 04 00004

RELEASED 6-16-75

620 MEMORY TEST

7 * 04 00005
 8 * 04 00006
 9 * 04 00007
 10 * 04 00008
 11 * 04 00009
 12 * 04 00010
 13 * 04 00011
 14 * 04 00012
 15 * 04 00013
 16 * 04 00014
 17 * 04 00015
 18 * 04 00016
 19 * 04 00017
 20 * 04 00018
 21 * 04 00019
 22 * 04 00020
 23 * 04 00021
 24 * 04 00022
 25 * 04 00023
 26 * 04 00024
 27 * 04 00025
 28 * 04 00026
 29 * 04 00027
 30 * 04 00028
 31 * 04 00029
 32 * 04 00030
 33 * 04 00031
 34 * 04 00032
 35 * 04 00033
 36 * 04 00034
 37 * 04 00035
 38 * 04 00036
 39 * 04 00037
 40 * 04 00038
 41 * 04 00039
 42 * 04 00040
 43 * 04 00041
 44 * 04 00042
 45 * 04 00043
 46 * 04 00044
 47 * 04 00045
 48 * 04 00046
 49 * 04 00047
 50 * 04 00048
 51 * 04 00049
 52 PRTY SET 045 PARITY HARDWARE DEVICE ADDRESS 04 00050
 53 * 04 00051
 54 * 04 00052
 55 **** 04 00053
 56 **** 04 00054
 57 * ESTABLISH HARDWARE CONFIGURATION 04 00055
 58 * * B=TTY DA 04 00056
 59 **** 04 00057
 60 ORG ? 04 00058
 61 * 04 00059
 62 TZA EFLG ZERO TO EFLG J 04 00060
 63 STA EFLG -1 TO EFLG IF EXTENDED ADDRESSING J 04 00061
 64 DAR 0442 SET MODE(TTY OR CONSOLE) WHICH IS 04 00062
 65 STAE EFLG ESTABLISHED BY TEST EXEC AT START-UP. 04 00063
 66 MERGE 003 ZERO A AND B 04 00064
 67 IBR 0442 SET A AND B AS REQUIRED 04 00065
 68 HLT 0777 TTY DA 04 00066
 69 STE 0442 SET MODE(TTY OR CONSOLE) WHICH IS 04 00067
 70 LDA 0442 ESTABLISHED BY TEST EXEC AT START-UP. 04 00068
 71 STA \$CON LOC. 0442 IS TEST EXEC \$CON. 04 00069
 72 * **** 04 00070
 73 * MEMO TOP - COMMON ENTRY POINT 04 00071
 74 * **** 04 00072
 75 * **** 04 00073
 76 MTOP LDA \$CON CONSOLE MODE ? 04 00074
 77 JAZ MTTM YES 04 00075
 78 JMP MTTM 04 00076
 79 **** 04 00077
 80 * INPUT PARAMETERS (TTY MODE) 04 00078
 81 **** 04 00079
 82 ORG 044 04 00080
 83 MTTM EXC 0400+PRTY ENABLE PARITY INTERRUPTS 04 00081
 84 LDXI HDG1 *MEMORY TEST* 04 00082
 85 D2K EQU * 04 00083
 86 CALL OUTD 04 00084
 87 MTT5 LDXI HDG6 CYCLES = 04 00085
 88 CALL OUTD 04 00086
 89 **** 04 00087
 90 **** 04 00088
 91 **** 04 00089

000044 00044 100445 A 83 MTTM EXC 0400+PRTY 04 00089
 000045 006030 A 84 LDXI HDG1 *MEMORY TEST* 04 00081
 000046 001671 A 85 D2K EQU * 04 00082
 000047 00047 A 86 CALL OUTD 04 00083
 000048 002000 A 87 MTT5 LDXI HDG6 CYCLES = 04 00084
 000049 002537 A 88 CALL OUTD 04 00085
 000050 006030 A 89 **** 04 00086
 000051 001701 A 90 **** 04 00087
 000052 002000 A 91 **** 04 00088
 000053 002537 A 92 **** 04 00089

PAGE 2

			MAINTAIN III	MEMPT1				
000055	002000	A	89	CALL	INPG	INPUT CYCLES	04 00089	
000056	002410	A	90	JMP	MTTM	SS3 TERMINATE	04 00090	
000057	001000	A	91	JMP	MTT5	BACKSLASH	04 00091	
000060	000044	A	92	JMP	MTT6	COMMA <PRINT "END MEMO">	04 00092	
000061	001000	A	93	STA	CYCL	SAVE CYCLES	04 00093	
000062	000051	A	94	TZA	EMEM	SET FLAG TO SUPRESS END MEMO	04 00094	
000063	001000	A	95	STA	MINT	BRANCH TO TEST INITIALIZATION	04 00095	
000064	000072	A	96	JMP			04 00096	
000065	051652	A	97	MTT6	STA	SAVE CYCLES	04 00097	
000066	005001	A	98	TZA	CYCL		04 00098	
000067	051653	A	99	CPA	EMEM	SET FLAG TO PRINT END MEMO	04 00099	
000070	001000	A	100	STA	MINT	BRANCH TO TEST INITIALIZATION	04 00100	
000071	000177	A	101	JMP			04 00101	
000072	051652	A	102	ORG	0120		J 04 00102	
000073	005001	A	103	*			04 00103	
000074	005211	A	104	*****	*****	*****	04 00104	
000075	051653	A	105	*	INPUT PARAMETERS (CONSOLE MODE)	*****	*04 00105	
000076	001000	A	106	*****	*****	*****	04 00106	
000077	000177	A	107	MTCM	EXC	0400+PRTY	ENABLE PARITY INTERRUPTS	04 00107
000120	100445	A	108	INC	03	INPUT CYCLES	04 00108	
000121	005103	A	109	LLSR	1		04 00109	
000122	004541	A	110	TBA		A=10---0	04 00110	
000123	005021	A	111	JMP	MTC1+1		04 00111	
000125	000127	A	112	MTC1	TZA		04 00112	
000127	000037	A	113	HLT	037	INPUT PARAMETERS	04 00113	
000130	001004	A	114	JAN	MTC4	INPUT CYCLES? YES, GOTO MTC4	04 00114	
000131	000134	A	115	JMP	MTCM		04 00115	
000132	001000	A	116	MTC4	ANA	B014	STORE CYCLES	E 04 00116
000134	152153	A	117	STA	CYCL		04 00117	
000135	051652	A	118	JMP	MINT		04 00118	
000137	000177	A	119	*			04 00119	
			120	*			04 00120	
			121	*	*****	*****	04 00121	
			122	*	*	*	04 00122	
			123	*	* GET NEXT ITEM FROM TABLE *	*	04 00123	
			124	*	*	*	04 00124	
			125	*	*****	*****	04 00125	
			126	*	CALL UACA,TBLPTR,ENDEXIT	(A)=0(TBL+1+0(TBLPTR))	04 00126	
			127	*			04 00127	
			128	*	TBL=INDEX,TBLSIZE,ITEM1,...,ITEMN		04 00128	
000140	030170	A	129	UACB	LDX	UACA	(B)=TBLPTR	04 00129
000141	025000	A	130	LDB	0,1		04 00130	
000142	046000	A	131	INR	0,2	INCR (>TBLPTR	04 00131	
000143	016001	A	132	LDA	1,2	IF (>TBLPTR .GT. ()(TBLPTR+1),GOTO ENDEXIT	04 00132	
000144	146000	A	133	SUB	0,2		04 00133	
000145	001004	A	134	JAN	UACC		04 00134	
000146	000161	A	135	INCR	021	(A)=0(TBLPTR+1+0(TBLPTR))	04 00135	
000150	126000	A	136	ADD	0,2		04 00136	
000151	005012	A	137	TAS			04 00137	
000152	016000	A	138	LDA	0,2		04 00138	
000153	020173	A	139	LDB	UACD	RESTORE B,X	04 00139	
000154	030176	A	140	LDX	UACD+1		04 00140	
000155	040170	A	141	INR	UACA	EXIT (RETURN+2)	04 00141	
000156	040170	A	142	INR	UACA		04 00142	
000157	001000	A	143	JMP	(UACA)*		04 00143	
000160	10010	A	144	UACC	LDA	1,2	(A)=TBLSIZE	04 00144
000162	035001	A	145	LDX	1,1	SETEXIT	04 00145	
000163	070167	A	146	STX	UACA-1		04 00146	
000164	020175	A	147	LDS	UACD	RESTORE B,X	04 00147	
000165	030176	A	148	LDX	UACD+1		04 00148	
000166	001000	A	149	JMP	0	EXIT (RETURN+1)* =GOTO ENDEXIT	04 00149	
000167	000000	A	150	UACA	ENTR			
000170	000000	A	151	STB	UACD	ENTRY POINT	04 00150	
000171	060175	A	152	STX	UACD+1	SAVE B,X	04 00151	
000172	070176	A	153	JMP	UACB	CONTINUE	04 00152	
000173	001000	A	154	UACD	BSS	2	(B),(X)	04 00153
000175			155	*			04 00154	
			156	*****	*****	*****	04 00155	
			157	*	SUBTEST DRIVER, AND CYCLS COUNTER		*04 00156	
			158	*****	*****	*****	04 00157	
000177	005001	A	159	MINT	TZA		04 00158	
000200	051664	A	160	STA	TERR	INIT ERROR CTR	04 00159	
000201	051665	A	161	STA	SWCH	SET TO PRINT ERROR TABLE HEADING	04 00160	
000202	051651	A	162	STA	TCYC	TOTAL CYCLES EXECUTED = 0	04 00161	
000203	002000	A	163	JMPM	UTAC		04 00162	
000204	000354	A	164	MIN1	RDF	RESET ERROR INDICATOR	F 04 00163	
000205	007400	A	165	CALL	TUAT	UNIQUE ADDRS	04 00164	
000206	002000	A	166	TZA		INIT TBL	04 00165	
000207	000726	A	167	STA	TBL		04 00166	
000210	005001	A					04 00167	
000211	052002	A						

MAINTAIN III						MEMPT1	PAGE 3	
000212	002000	A	168	MIN2	CALL	UACA,TBL,MIN3 GET FRST ADDRS	04 00168	
000213	000170	A						
000214	002002	A						
000215	000236	A						
000216	051657	A	169	STA	FRST		04 00169	
000217	002000	A	170	CALL	UACA,TBL,MIN3 GET LAST ADDRS	04 00170		
000220	000170	A						
000221	002002	A						
000222	000236	A						
000223	051660	A	171	STA	LAST		04 00171	
000224	002000	A	172	CALL	TAZT	ALL ZEROS	04 00172	
000225	001052	A						
000226	002000	A	173	CALL	TAOT	ALL ONES	04 00173	
000227	001075	A						
000230	002000	A	174	CALL	TCBT	CHECKERBOARD	04 00174	
000231	001121	A						
000232	002000	A	175	CALL	TBCT	BIT COMPLIMENT	E 04 00175	
000233	001300	A						
000234	001000	A	176	JMP	MIN2	CONTINUE TO NEXT CASE	04 00176	
000235	000212	A						
000236	002000	A	177	MIN3	CALL	DEM	DISPLAY "END MEMO"	04 00177
000237	000251	A						
000240	011652	A	178	LDA	CYCL	CONTINUES ?	04 00178	
000241	001010	A	179	JAZ	MIN1	YES, GOTO MIN1	04 00179	
000242	000205	A						
000243	005311	A	180	DAR		NO, DONE ?	04 00180	
000244	051652	A	181	STA	CYCL		04 00181	
000245	001010	A	182	JAZ	TERM	YES, GOTO TERM	04 00182	
000246	000271	A						
000247	001000	A	183	JMP	MIN1	NO, CONTINUE TO MIN1	04 00183	
000250	000205	A						
000251	000000	A	184	DEM	ENTR	0	DISPLAY END MEMO	04 00184
000252	041651	A	185	INR	TCYC	TCYC = TCYC+1	04 00185	
000253	002000	A	186	JMPM	OTAC		F 04 00186	
000254	000354	A						
000255	012557	A	187	LDA	SCON	CONSOLE MODE? YES, RETURN	04 00187	
000256	001010	A	188	JAZ	(DEM)*		04 00188	
000257	100251	A						
000260	011653	A	189	LDA	ENEM	SUPPRESS MESSAGE ? YES, RETURN	04 00189	
000261	001010	A	190	JAZ	(DEM)*		04 00190	
000262	100251	A						
000263	006030	A	191	LDXI	HDG8	"END MEMO"	04 00191	
000264	001710	A						
000265	002000	A	192	CALL	OUTD		04 00192	
000266	002537	A						
000267	001000	A	193	JMP	(DEM)*	RETURN	04 00193	
000270	100251	A						
000271	012557	A	194	***** TERMINATE TESTS *****				
000272	001010	A	195	***** TERMINATE TESTS *****				
000273	000320	A	196	***** TERMINATE TESTS *****				
000274	006030	A	197	TERM	LDA	SCON	TERMINATE TEST, REPORT TOTALS	
000275	001710	A	198	JAZ	TEPN		04 00197	
000276	002000	A	199				04 00198	
000277	002537	A	200	LDXI	HDG9	MODE = CONSOLE ? YES, GO TO TERM	04 00199	
000300	011664	A	201	CALL	OUTD			
000301	002000	A	202	LDA	TERR		04 00201	
000302	002513	A		CALL	OUTE		04 00202	
000303	002000	A	203	CALL	OUTD		04 00203	
000304	002537	A		LDXI	HDG9	"ERROR TOTAL =", TERR	04 00204	
000305	006030	A	204	CALL	OUTD			
000306	001755	A		LDXI	HG11	'NO. CYCLES RUN ='	04 00205	
000307	002000	A	205	CALL	OUTD			
000310	002537	A		LDXI	TCYC			
000311	011651	A	206	CALL	OUTE	TOTAL CYCLES EXECUTED	04 00206	
000312	002000	A	207	LDA	TCYC		04 00207	
000313	002513	A		CALL	OUTE			
000314	002000	A	208	CALL	OUTD	CR/LF	04 00208	
000315	002505	A		CALL	OUTD			
000316	001000	A	209	JMP	MTOP	CONTINUE	04 00209	
000317	000022	A						
000320	011664	A	210	TERN	LDA	TERR	A = TOTAL ERRORS	04 00210
000321	021651	A	211	LDB	TCYC	B = NO. CYCLES	04 00211	
000322	031654	A	212	LDX	TEST	X = CURRENT (OR LAST) TEST	04 00212	
000323	000777	A	213	HLT	0777	DISPLAY TOTALS	E 04 00213	
000324	001000	A	214	JMP	MTOP	CONTINUE	04 00214	
000325	000022	A						
000326	000000	A	215	***** ERROR REPORTING ROUTINE *****				
000327	007401	A	216	MERR	ENTR	0	*04 00215	
000329	041664	A	217	SOF			*04 00216	
000330	061666	A	218	INR	TERR	INCR ERR CTR	*04 00217	
000331	071667	A	219	STB	SAVB	SAVE B (@TEST CYCLES)	04 00218	
000332	021667	A	220	STX	SAVX	ERROR ADDRESS	04 00219	
000333	002000	A	221	JMPM	OTAC			
000334	000354	A	222					
000335	011654	A	223	LDA	TEST			
000336	150323	A	224	ANA	0777			
000337	050344	A	225	STA	ERR1+2	SAVE HALT	E 04 00225	
000340	011647	A	226	TEST		GET TEST NO.	04 00226	
000341	021650	A	227	LDA	MTW1	EXPECTED	04 00227	
000342	002000	A	228	LDB	MTW2	ACTUAL	04 00228	
			229	ERR1	CALL	CALL SENSE SWITCH ROUTINE	04 00229	

PAGE	4	MAINTAIN III	MEMPT1	
000343	002200	A 230	DATA 0 (ERPO)*	TEST# ERR PRINTOUT
000344	000000	A 231	DATA TERM	SS3 EXIT
000345	100634	A 232	DATA ELOP	LOOP ON ERROR
000346	000271	A 233	DATA SAVB	RESTORE B
000347	000712	A 234	LDB SAVX	
000350	021666	A 235	LDX MERR	PROCEED WITH TEST
000351	031667	A 236	JMP*	
000353	100326	A 237	BTAC ENTR	OUTPUT ERROR AND CYCLE
000354	000000	A 238	TZB	CLEAR B
000355	005002	A 239	LDA TERR	GET ERROR CNTR
000356	011664	A 240	JAZ *+4	JUMP IF NO ERRORS
000357	001010	A 241	LDBI 3100000	SET SIGN OF B
000360	000363	A 242	LDA TCYC	TOTAL CYCLES
000361	006020	A 243	MERG 031	ERROR & CYCLE TO A
000363	011651	A 244	OAR 077	A TO DISPLAY
000365	103177	A 245	JMP* BTAC	-EXIT-
000367	100354	A 246	ORG 0622	
000622	010422	A 247	M23 LDA 0422	LOWEST LOCATION USED BY EXEC
000623	006150	A 248	ANAI 010000	
000624	010000	A 249	JAZ 7	4K MAINTAINIII
000625	001010	A 250	LDAI 017777	
000626	000007	A 251	STA 01+10	8K MAINTAIN III
000627	006010	A 252	JMP 7	
000633	000007	A 253	* ERROR PRINTOUT SUBROUTINE	
000634	000000	A 254	ERPO ENTR 0	
000635	002000	A 255	CALL DUTC	CR/LF
000636	002505	A 256	LDA SWCH	
000637	011665	A 257	JAZ *+4	
000640	001010	A 258	JMP ERPI	
000641	000644	A 259	INR SNCH	
000642	001000	A 260	LDXI HG10	SET TO BYPASS HEADING
000643	000651	A 261	CALL OUTD	
000644	041665	A 262	ERPI LDA TEST	
000645	006030	A 263	CALL DUTE	TEST NO.
000646	001727	A 264	LDA SAVX	
000647	002000	A 265	CALL DUTE	ADDR
000650	002537	A 266	JMP ERP3	
000651	011654	A 267	ERP3 LDA BB	
000652	002000	A 268	CALL OUTB	
000653	002513	A 269	LDA MTW1	EXP
000654	011667	A 270	ERP2 CALL DUTE	
000655	002000	A 271	LDA BB	
000656	002513	A 272	CALL OUTB	
000657	001000	A 273	CALL DUTA	
000660	000661	A 274	LDA MTW2	ACTUAL
000661	011731	A 275	CALL DUTE	
000662	002000	A 276	LDA BB	
000663	002472	A 277	CALL OUTB	
000664	011647	A 278	LDA MTW1	EXP
000665	002000	A 279	ERP2 CALL DUTE	
000666	002513	A 280	LDA BB	
000667	011731	A 281	CALL DUTA	
000670	002000	A 282	JSS2 ERRI-2	GET TOTAL CYCLES PERFORMED
000671	002440	A 283	IAR MAKE IT THE CURRENT CYCLE	
000672	011651	A 284	CALL DUTE	
000673	005111	A 285	JSS3 TERM	SS3 EXIT
000674	002000	A 286	ELOP JSS3	
000675	002513	A 287	LDA MTW1	
000676	001000	A 288	STA 0,1	
000677	100634	A 289	NOP	
000700	002000	A 290	ERA 0,1	READ ERROR WORD
000701	002440	A 291	JAZ ELOP-2	ERROR AGAIN? NO, TRY AGAIN
000702	011651	A 292	ERA MTW1	RESTORE
000703	005111	A 293	STA MTW2	
000704	002000	A 294	JMP ERRI-2	REPORT
000705	002513	A 295	*****	04 00281
000710	001200	A 296	*****	04 00282
000711	000340	A 297	*****	04 00283
000712	001400	A 298	*****	04 00284
000713	000271	A 299	*****	04 00285
000714	011647	A 300	*****	04 00286
000715	055000	A 301	*****	04 00287
000716	005000	A 302	*****	04 00288
000717	135000	A 303	*****	04 00289
000720	001010	A 304	*****	04 00290
000721	000710	A 305	*****	04 00291
000722	131647	A 306	*****	04 00292
000723	051650	A 307	*****	04 00293
000724	001000	A 308	*****	04 00294
000725	000340	A 309	*****	04 00295

MAINTAIN III

MEMPT1

PAGE 5

		296	*	SUBTEST ROUTINES	*04 00296	
		297	*****	*****	*****04 00297	
		298	*	UNIQUE ADDRS	04 00298	
		299	*		04 00299	
000726	000000	A	300	TUAT ENTR 0	04 00300	
000727	005101	A	301	INCR 1 TEST = 1	E 04 00301	
000730	051654	A	302	STA TEST	04 00302	
000731	005001	A	303	TZA INIT TBL	04 00303	
000732	052002	A	304	STA TBL	04 00304	
000733	002000	A	305	TUAA CALL UAACA,TBL,TUAB GET FRST	04 00305	
000734	000170	A				
000735	002002	A				
000736	000753	A				
000737	051657	A	306	STA FRST	04 00306	
000740	002000	A	307	CALL UAACA,TBL,TUAB GET LAST	04 00307	
000741	000170	A				
000742	002002	A				
000743	000753	A				
000744	051660	A	308	STA LAST	04 00308	
000745	001400	A	309	JSS3 TERM	04 00309	
000746	000271	A				
000747	002000	A	310	CALL IUA INIT MEMORY	04 00310	
000750	000777	A				
000751	001000	A	311	JMP TUAA CONTINUE	04 00311	
000752	000733	A				
000753	005001	A	312	TUAB TZAA INIT TBL	04 00312	
000754	052007	A	313	STA TBL	04 00313	
000755	005101	A	314	INCR 1 REP = 1	E 04 00314	
000756	051656	A	315	STA REP	04 00315	
000757	002000	A	316	TUAC CALL UAACA,TBL,(TUAT)* GET FRST	04 00316	
000760	000170	A				
000761	002002	A				
000762	100726	A				
000763	051657	A	317	STA FRST	04 00317	
000764	002000	A	318	CALL UAACA,TBL,(TUAT)* GET LAST	04 00318	
000765	000170	A				
000766	002002	A				
000767	100726	A				
000770	051660	A	319	STA LAST	04 00319	
000771	001400	A	320	JSS3 TERM	04 00320	
000772	000271	A				
000773	002000	A	321	CALL TUA TEST UNIQUE ADDRS	04 00321	
000774	001011	A				
000775	001000	A	322	JMP TUAC CONTINUE	04 00322	
000776	000757	A				
000777	000000	A	323	*	INIT UNIQUE ADDRS	04 00323
001000	031657	A	324	IUA ENTR 0	04 00324	
001001	005041	A	325	LDX FRST	04 00325	
001002	055000	A	326	IUA1 TXA	04 00326	
001003	005144	A	327	STA 0,1	04 00327	
001004	141660	A	328	IXR	04 00328	
001005	001004	A	329	SUB LAST DONE ?	04 00329	
001006	001001	A	330	JAN IUAI NO,CONTINUE	04 00330	
001007	001000	A	331	JMP (IUAD)* RETURN	04 00331	
001010	100777	A				
001011	000000	A	332	*	TEST UNIQUE ADDRS	04 00332
001012	021656	A	333	TUA ENTR 0	04 00333	
001013	031657	A	334	LDB REP	04 00334	
001014	011670	A	335	LDX FRST	04 00335	
001015	001010	A	336	TUA1 LDA EFLG	J 04 00336	
001016	001023	A	337	JAZ TUAA2	J 04 00337	
001017	005041	A	338	TXP		
001020	071022	A	339	STX *+2	J 04 00338	
001021	006127	A	340	ERAEE 000	J 04 00339	
001022	000000	A			J 04 00340	
001023	001000	A	341	JMP TUAB	J 04 00341	
001024	001027	A				
001025	005041	A	342	TUA2 TXA	J 04 00342	
001026	135000	A	343	ERA 0,1	J 04 00343	
001027	001010	A	344	TUA3 JAZ *+2	J 04 00344	
001030	001036	A				
001031	071647	A	345	STX MTW1 NO,CALL MERR	04 00345	
001032	131647	A	346	ERA MTW1	04 00346	
001033	051650	A	347	STA MTW2	04 00347	
001034	002000	A	348	CALL MERR	04 00348	
001035	000326	A				
001036	005041	A	349	TXA	04 00349	
001037	005144	A	350	IXR	04 00350	
001040	141660	A	351	SUB LAST DONE ?	04 00351	
001041	001004	A	352	JAN IUAI NO,CONTINUE	04 00352	
001042	001014	A				
001043	001020	A	353	JBZ TUA+1 CONTINUES ? YES	04 00353	
001044	001012	A				
001045	005322	A	354	DBR	04 00354	
001046	001020	A	355	JBZ (TUAD)* YES,RETURN	04 00355	
001047	101011	A				
001050	001000	A	356	JMP TUA+1 NO,CONTINUE	04 00356	
001051	001010	A				
001052	000000	A	357	*****	04 00357	
			358	*	04 00358	
			359	*	ALL ZEROS 04 00359	
			360	*	04 00360	
			361	TAZT ENTR 0 ENTRY/EXIT	04 00361	

PAGE 6 MAINTAIN III MEMPT1

```

001053 002000 A 362 CALL IAZ INIT 04 00362
001054 001060 A 363 LDA D3 REP = 3 E 04 00363
001055 011253 A 364 STA REP 04 00364
001056 051636 A 365 CALL TES TEST PATTERN 04 00365
001057 002000 A 366 JMP (TAZT)* RETURN 04 00366
001060 001611 A 367 * INIT ALL ZEROS 04 00367
001062 101052 A 368 IAZ ENTR 0 04 00368
001063 000000 A 369 LDA D2 TEST = 2 E 04 00369
001064 012421 A 370 STA TEST 04 00370
001065 051654 A 371 TZA BITS 04 00371
001066 005001 A 372 STA PAT1 PATTERN1 = 0 04 00372
001067 051661 A 373 STA SET SET PATTERN INTO MEMORY 04 00373
001070 051662 A 374 CALL 04 00374
001071 002000 A 375 JMP (IAZD)* 04 00375
001072 001574 A 376 ***** 04 00376
001073 001000 A 377 * 04 00377
001074 101063 A 378 * ALL ONES 04 00378
001079 * 04 00379
001075 000000 A 380 TAOT ENTR 0 ENTRY/EXIT 04 00380
001076 002000 A 381 CALL IAO INIT 04 00381
001077 001106 A 382 LDA D3 REP = 3 E 04 00382
001100 011253 A 383 STA REP 04 00383
001101 051656 A 384 CALL TES TEST PATTERN 04 00384
001102 002000 A 385 JMP (TAOT)* RETURN 04 00385
001103 001611 A 386 * INIT ALL ONES 04 00386
001104 001000 A 387 IAO ENTR 0 04 00387
001106 000000 A 388 LDA D3 TEST = 3 E 04 00388
001107 011253 A 389 STA TEST 04 00389
001110 051654 A 390 TZA BITS 04 00390
001111 005001 A 391 STA PAT1 PATTERN1 = 1'S 04 00391
001112 051661 A 392 CPA 04 00392
001113 005211 A 393 STA PAT1 PATTERN1 = 1'S 04 00393
001114 051662 A 394 CALL SET SET PATTERN INTO MEMORY 04 00394
001115 002000 A 395 JMP (IAOD)* 04 00395
001116 001574 A 396 ***** 04 00396
001117 001000 A 397 * 04 00397
001118 101106 A 398 * CHECKER BOARD 04 00398
001119 * 04 00399
001121 000000 A 400 TCBT ENTR 0 04 00400
001122 006010 A 401 LDAI S REP = 3 04 00401
001123 000003 A 402 STA REP 04 00402
001124 051656 A 403 CALL ICB INIT CHECKER BOARD 04 00403
001125 002000 A 404 CALL TCB TEST CHECKER BOARD 04 00404
001126 001137 A 405 CALL ICBC INIT CHECKER BOARD COMPLIMENTED 04 00405
001127 002000 A 406 CALL TCB TEST CHECKER BOARD 04 00406
001128 001206 A 407 JMP (TCBT)* 04 00407
001129 002000 A 408 * INIT CHECKER BOARD 04 00408
001130 001136 A 409 ICB ENTR 0 04 00409
001131 002000 A 410 CALL ICB1 B = 0252525 04 00410
001132 001146 A 411 CALL ICB2 WRITE B AND NOT B INTO MEMORY 04 00411
001133 002000 A 412 JMP (ICB)* RETURN 04 00412
001134 001206 A 413 * INTT CHECKER BOARD COMPLIMENTED 04 00413
001135 001000 A 414 ICBC ENTR 0 04 00414
001136 101121 A 415 CALL ICB1 B = 0525252 04 00415
001137 000000 A 416 CPA 04 00416
001138 002000 A 417 CALL ICB2 WRITE B AND NOT B INTO MEMORY 04 00417
001139 001170 A 418 JMP (ICBC)* RETURN 04 00418
001140 001146 A 419 * 04 00419
001141 001137 A 420 ICB1 ENTR 04 00420
001142 002000 A 421 LDA D4 TEST = 4 E 04 00421
001143 001156 A 422 STA TEST 04 00422
001144 002000 A 423 LDA D525 B = 252525 E 04 00423
001145 001156 A 424 LRLA 8 04 00424
001146 006110 A 425 ORAI 0525 04 00425
001147 000525 A 426 0525 EQU *-1 E 04 00426
001148 001164 A 427 TAB 04 00427
001149 004250 A 428 JMP (ICB1)* RETURN 04 00428
001150 006110 A 429 * 04 00429
001151 000525 A 430 ICB2 ENTR 04 00430
001152 002000 A 431 LDX FRST X = FRST 04 00431
001153 001170 A 432 DATA 05221 A = NOT (B) , WRITE PATTERN 04 00432

```

			MAINTAIN III	MEMPT1	PAGE		
001173	065000	A	433	STB	0,1	04 00433	
001174	005144	A	434	IXR		04 00434	
001175	055000	A	435	STA	0,1	04 00435	
001176	005144	A	436	IXR		04 00436	
001177	005041	A	437	TXA		04 00437	
001200	141660	R	438	SUB	LAST	04 00438	
001201	005311	A	439	DAR		04 00439	
001202	001010	A	440	JAZ	(ICB2)*	04 00440	
001203	101170	A			DONE ? YES, RETURN	04 00440	
001204	001000	A	441	JMP	ICB2+2	CONTINUE	04 00441
001205	001172	A	442	*	TEST CHECKER BOARD		04 00442
001206	000000	A	443	TCB	ENTR 0		04 00443
001207	011656	A	444	LDA	REP	REP1 = REP	04 00444
001210	051655	A	445	STA	REP1	READ PATTERN , INIT	04 00445
001211	031657	A	446	LDX	FRST	EXPECTED = PATTERN	04 00446
001212	061647	A	447	TCBB	STB MTW1	TEST FIRST WORD	04 00447
001213	005031	A	448	TBA			04 00448
001214	135000	A	449	ERA	0,1		04 00449
001215	001010	A	450	JAZ	*+6		04 00450
001216	001223	A				BAD, CALL MERR	04 00451
001217	131647	A	451	ERA	MTW1		04 00452
001220	051650	A	452	STA	MTW2		04 00453
001221	002000	A	453	CALL	MERR		
001222	000326	A					
001223	005221	A	454	DATA	05221	OK,	04 00454
001224	005144	A	455	IXR		TEST SECOND WORD	04 00455
001225	051647	A	456	STA	MTW1		04 00456
001226	135000	A	457	ERA	0,1		04 00457
001227	001010	A	458	JAZ	*+6		04 00458
001230	001235	A					
001231	131647	A	459	ERA	MTW1	BAD, CALL MERR	04 00459
001232	051650	A	460	STA	MTW2		04 00460
001233	002000	A	461	CALL	MERR		04 00461
001234	000326	A					
001235	005041	A	462	TXA		DONE?	04 00462
001236	005144	A	463	IXR			04 00463
001237	141660	A	464	SUB	LAST		04 00464
001240	001004	A	465	JAN	TCBB	NO, CONTINUE	04 00465
001241	001212	A					
001242	011655	A	466	LDA	REP1	CONTINUES ?	04 00466
001243	001010	A	467	JAZ	TCBB-1	YES, CONTINUE	04 00467
001244	001211	A					
001245	005311	A	468	DAR			04 00468
001246	001010	A	469	JAZ	(TCB)*	DONE ? YES, RETURN	04 00469
001247	101206	A					
001250	051653	A	470	STA	REP1		04 00470
001251	001000	A	471	JMP	TCBB-1	CONTINUE	04 00471
001252	001211	A					
001253	000003	A	472	03	DATA		F 04 00472
001254	000000	A	473	*	INIT WORST CASE		04 00473
001255	051661	A	474	IWC	ENTR 0		04 00474
001256	005001	A	475	STA	PITS		04 00475
001257	051662	A	476	TZA		PAT1 = 0	04 00476
001260	005211	A	477	STA	PAT1		04 00477
001261	051663	A	478	CRA		PAT2 = 1	04 00478
001262	002000	A	479	STA	PAT2		04 00479
001263	001574	A	480	CALL	SET	SET PATTERN INTO MEMORY	04 00480
001264	041654	A	481	INR	TEST	TEST = TEST + 1	04 00481
001265	001000	A	482	JMP	(IWC)*		04 00482
001266	101254	A					
001267	000000	A	483	*	INIT WORST CASE COMPLIMENT		04 00483
001270	005001	A	484	IWC	ENTR 0	COMPLIMENT PAT1 AND PAT2	04 00484
001271	051663	A	485	TZA			04 00485
001272	005211	A	486	STA	PAT2		04 00486
001273	051662	A	487	CRA			04 00487
001274	002000	A	488	STA	PAT1		04 00488
001275	001574	A	489	CALL	SET	SET PATTERN INTO MEMORY	04 00489
001276	001000	A	490	JMP	(IWC)*		04 00490
001277	101267	A					
001278	000000	A	491	*****			04 00491
001279	000000	A	492	*			E 04 00492
001280	000000	A	493	*	BIT COMPLIMENT		E 04 00493
001281	000000	A	494	*			E 04 00494
001300	000000	A	495	TBCT	ENTR 0	SELECT WORST CASE PATTERN TABLE	E 04 00495
001301	006010	A	496	-	PAI 037	TEST = 037+N	E 04 00496
001302	000000	A					
001303	051654	A	497	STA	TEST		E 04 00497
001304	011253	R	498	LDA	03	REP=3	E 04 00498
001305	051656	A	499	STA	REP		E 04 00499
001306	006020	A	500	LDBI	TBLI	TABLE OF WORSE CASE PATTERNS	E 04 00500
001307	001722	A					
001310	005001	A	501	TECA	TZA	INIT TBL	E 04 00501
001311	056000	A	502	STA	0,2		E 04 00502
001312	061315	A	503	STB	TCB+2		E 04 00503
001313	002000	A	504	TBCB	CALL UACA,0,(TBCT)*	GET WORST CASE PATTERN FROM TABLE	E 04 00504
001314	000170	A					
001315	000000	A					
001316	101300	A					
001317	002000	A	505	CALL	INC	SET WORST CASE PATTERN INTO MEMORY	E 04 00505
001320	001254	A	506	CALL	TBC	TEST BIT COMPLIMENT	E 04 00506
001321	002000	A					
001322	001331	A					

PAGE	S	MAINTAIN III		MEMPT1				
001323	002000	A	507	CALL	IWCC	COMPLIMENT PATTERN	E	04 00507
001324	001267	A	508	CALL	TBC		E	04 00508
001325	002000	A	509	JMP	TBCB		E	04 00509
001326	001331	A	510 *				E	04 00510
001327	001000	A	511 TBC	ENTR	0		E	04 00511
001328	005103	A	512	INCR	03		E	04 00512
001329	004541	A	513	LLSR	1	B = REP BITX = SIGN BIT ON	E	04 00513
001330	061536	A	514	STB	BITX		E	04 00514
001331	021656	A	515	LDB	REP		E	04 00515
001332	031657	A	516	LDX	FRST	X = FRST	E	04 00516
001333	011536	A	517 TBC1	LDA	BITX	INIT BITC	E	04 00517
001334	051535	A	518	STA	BITC		E	04 00518
001335	005041	A	519	TXA		C>X = 1'S	E	04 00519
001336	002000	A	520	CALL	DAP		E	04 00520
001337	001537	A	521	JAN	TBC5	YES, GOTO	E	04 00521
001338	001430	A	522 TBC2	TZA		ZERO EXPECTED	E	04 00522
001339	051647	A	523	STA	MTW1		E	04 00523
001340	015000	A	524	LDA	0,1		E	04 00524
001341	051650	A	525	STA	MTW2	ACTUAL	E	04 00525
001342	001010	A	526	JAZ	*+4		E	04 00526
001343	001356	A	527	JMP	TBCC	-ERROR-	E	04 00527
001344	001000	A	528	LDA	BITC	C>X = C>X XOR BITC	E	04 00528
001345	001523	A	529	ERA	0,1		E	04 00529
001346	135000	A	530	STA	0,1		E	04 00530
001347	055000	A	531	STA	MTW1	SAVE S/B	F	04 00531
001348	051647	A	532	LDA	0,1		F	04 00532
001349	015000	A	533	STA	MTW2	SAVE WAS	F	04 00533
001350	051630	A	534	ERA	MTW1		F	04 00534
001351	131647	A	535	JAZ	*+4	JUMP IF SAME	F	04 00535
001352	001010	A	536	JMP	TBCG		F	04 00536
001353	001371	A	537	LDA	BITC	C>X = C>X XOR BITC	E	04 00537
001354	001000	A	538	ERA	0,1		E	04 00538
001355	001401	A	539	STA	0,1		E	04 00539
001356	011535	A	540	JAZ	TBC3	ERROR ? NO, SKIP REPORT	E	04 00540
001357	001405	A	541	STA	MTW2		E	04 00541
001358	051650	A	542	TZA		YES SET MTW1 = EXP, MTW2 = ACT	E	04 00542
001359	005001	A	543	STA	MTW1		E	04 00543
001360	051647	A	544 TBCG	CALL	TBC8	MODIFY TEST # TO INCLUDE BIT	F	04 00544
001361	002000	A	545	CALL	MERR		E	04 00545
001362	001501	A	546 TBC3	LDA	BITC	BITC = LOGICAL SHIFT RIGHT 1(BITC)	E	04 00546
001363	000326	A	547	LSRA	1		E	04 00547
001364	011535	A	548	STA	BITC	DONE ?	E	04 00548
001365	004341	A	549	JAZ	TBC7	YES	E	04 00549
001366	051535	A	550	JMP	TBC2	NO, CONTINUE WITH SAME WORD	E	04 00550
001367	001346	A	551 TBC7	TXA			E	04 00551
001368	003041	A	552	IKR		A = X	E	04 00552
001369	005144	A	553	SUB	LAST	X = X+1	E	04 00553
001370	141660	A	554	JAN	TBC1	DONE ?	E	04 00554
001371	001004	A	555 TBC4	JBZ	TBC1-1	NO, GET NEXT WORD	E	04 00555
001372	001337	A	556	DBR			E	04 00556
001373	005322	A	557	JBZ	(TBC)*	FINISHED ? NO, CONTINUES	E	04 00557
001374	001020	A	558	JMP	TBC1-1	YES, RETURN	E	04 00558
001375	101331	A	559 TBC5	DEC R	1		E	04 00559
001376	005301	A	560	STA	MTW1	ONES	E	04 00560
001377	051647	A	561	LDA	0,1	EXPECTED	E	04 00561
001378	015000	A	562	STA	MTW2		E	04 00562
001379	051650	A	563	CPA		ACTUAL	E	04 00563
001380	005211	A	564	JAZ	*+4		E	04 00564
001381	001441	A	565	JMP	TBCC	-ERROR-	E	04 00565
001382	001523	A	566	LDA	BITC	C>X = C>X XOR BITC	E	04 00566
001383	011535	A	567	ERA	0,1		E	04 00567
001384	135000	A	568	STA	0,1		E	04 00568
001385	055000	A	569	STA	MTW1	SAVE S/B	F	04 00569
001386	051647	A	570	LDA	0,1		F	04 00570
001387	015000	A	571	STA	MTW2	SAVE WAS	F	04 00571
001388	051650	A	572	ERA	MTW1		F	04 00572
001389	131647	A	573	JAZ	*+4	JUMP IF SAME	F	04 00573
001390	001010	A	574	JMP	TBCF		F	04 00574
001391	001466	A	575	LDA	BITC		E	04 00575
001392	011535	A	576	ERA	0,1		E	04 00576
001393	135000	A	577	STA	0,1		E	04 00577
001394	055000	A	578	CPA		ERROR ?	E	04 00578
001395	005211	A	579	JAZ	TBC6	NO, SKIP REPORT	E	04 00579

MAINTAIN III

MEMPT1

PAGE 3

PAGE 10 MAINTAIN III MEMPT1

```

001604 001010 A 657 JAZ (SET)* YES,RETURN 04 00657
001605 101574 A 658 IXR ADDRS = ADDRS+1 04 00658
001606 005144 A 659 JMP SET1 CONTINUE 04 00659
001610 001576 A 660 * 04 00660
001611 000000 A 661 * TES 04 00661
001612 021656 A 662 * TEST MEMORY PATTERN 04 00662
001613 031657 A 663 * REP,FRST,LAST,BITS,PAT1,PAT2 04 00663
001614 005041 A 664 * 04 00664
001615 002000 A 665 TES ENTR 0 ENTRY/EXIT 04 00665
001616 001537 A 666 LDB REP B = REPETITIONS 04 00666
001617 031647 A 667 LDX FRST X = FIRST ADDR 04 00667
001618 005041 A 668 TES1 TXA DERIVE ADDRS PATTERN 04 00668
001619 002000 A 669 CALL DAF 04 00669
001620 015000 A 670 STA MTW1 GET ACTUAL PATTERN 04 00670
001621 051650 A 671 LDA 0,1 04 00671
001622 131647 A 672 STA MTW2 04 00672
001623 001010 A 673 ERA MTW1 ERROR? 04 00673
001624 001627 A 674 JAZ *+4 04 00674
001625 002000 A 675 CALL MERR YES,CALL MERR 04 00675
001626 000326 A 676 JSS3 TERM SSS TERMINATE TESTS 04 00676
001627 001400 A 677 TXA LAST? 04 00677
001628 005041 A 678 SUB TES2 YES,JMP TES2 04 00678
001629 001010 A 679 JAZ 04 00679
001630 000271 A 680 IXR ADVANCE X TO NEXT WORD 04 00680
001631 005041 A 681 JMP TES1 CONTINUE 04 00681
001632 001614 A 682 TES2 JBZ TES+2 CONTINUES ?,YES 04 00682
001633 001613 A 683 DBR JBZ (TES)* NO,DONE ? 04 00683
001634 001020 A 684 JBZ (TES)* YES,RETURN 04 00684
001635 005144 A 685 JMP TES+2 NO,CONTINUE 04 00685
001636 001613 A 686 **** DATA TABLE **** 04 00686
001637 001613 A 687 * DATA * 04 00687
001638 001613 A 688 **** DATA TABLE **** 04 00688
001639 001613 A 689 * 04 00689
001640 001613 A 690 * DATA TABLE 04 00690
001641 001613 A 691 * 04 00691
001642 005322 A 692 MTW1 BSS 1 SAVE VALID PATTERN 04 00692
001643 005322 A 693 MTW2 BSS 1 SAVE PATTERN READ 04 00693
001644 005322 A 694 TCYC BSS 1 TOTAL CYCLES EXECUTED 04 00694
001645 000000 A 695 CYCL DATA 0 CYCLES 04 00695
001646 000000 A 696 EMEM DATA 0 PRINT END MEMO FLAG 04 00696
001647 000000 A 697 TEST DATA 0 TEST NUMBER 04 00697
001648 000000 A 698 REP1 BSS 1 REP CTR 04 00698
001649 000000 A 699 REP BSS 1 REP CTR 04 00699
001650 000000 A 700 FRST DATA 0 FIRST ADDRESS 04 00700
001651 000000 A 701 LAST DATA 0 LAST ADDRESS 04 00701
001652 000000 A 702 BITS BSS 1 BIT SELECT PATTERN 04 00702
001653 000000 A 703 PAT1 BSS 1 PATTERN 1 04 00703
001654 000000 A 704 PAT2 BSS 1 PATTERN 2 04 00704
001655 000000 A 705 TERR DATA 0 ERROR TOTAL 04 00705
001656 000000 A 706 SWCH DATA 0 PRINT ERROR HDG FLG 04 00706
001657 000000 A 707 SAVB DATA 0 04 00707
001658 000000 A 708 SAVX DATA 0 04 00708
001659 000000 A 709 EFLG DATA 0 EXTENDED ADDRESSING FLAG J 04 00709
001660 000000 A 710 * 04 00710
001661 000000 A 711 * MESSAGE TABLE 04 00711
001662 000000 A 712 * 04 00712
001663 106612 A 713 CRLF SET 0106612 CARRIAGE RETURN / LINE FEED 04 00713
001664 106612 A 714 HDG1 DATA CRLF,"MEMORY TEST",0 04 00714
001665 146705 A 715 HDG6 DATA CRLF,"CYCLES = ",0 04 00715
001666 146717 A 716 HDG8 DATA CRLF,"END MEMO",0 04 00716
001667 151331 A 717 HDG9 DATA CRLF,"ERROR TOTAL = ",0 04 00717
001668 120324 A
001669 142723 A
001670 152240 A
001671 000000 A
001672 106612 A
001673 146717 A
001674 151331 A
001675 120324 A
001676 142723 A
001677 152240 A
001678 000000 A
001679 106612 A
001680 146717 A
001681 151331 A
001682 120324 A
001683 142723 A
001684 152240 A
001685 000000 A
001686 106612 A
001687 146717 A
001688 151331 A
001689 120324 A
001690 142723 A
001691 152240 A
001692 000000 A
001693 106612 A
001694 146717 A
001695 151331 A
001696 120324 A
001697 142723 A
001698 152240 A
001699 000000 A
001700 106612 A
001701 146717 A
001702 151331 A
001703 120324 A
001704 142723 A
001705 152240 A
001706 000000 A
001707 106612 A
001708 146717 A
001709 151331 A
001710 120324 A
001711 142723 A
001712 152240 A
001713 000000 A
001714 106612 A
001715 146717 A
001716 151331 A
001717 120324 A
001718 142723 A
001719 152240 A
001720 000000 A
001721 106612 A
001722 146717 A
001723 151331 A
001724 120324 A
001725 142723 A
001726 152240 A
001727 000000 A
001728 106612 A
001729 146717 A
001730 151331 A
001731 120324 A
001732 142723 A
001733 152240 A
001734 000000 A
001735 106612 A
001736 146717 A
001737 151331 A
001738 120324 A
001739 142723 A
001740 152240 A
001741 000000 A
001742 106612 A
001743 146717 A
001744 151331 A
001745 120324 A
001746 142723 A
001747 152240 A
001748 000000 A
001749 106612 A
001750 146717 A
001751 151331 A
001752 120324 A
001753 142723 A
001754 152240 A
001755 000000 A
001756 106612 A
001757 146717 A
001758 151331 A
001759 120324 A
001760 142723 A
001761 152240 A
001762 000000 A
001763 106612 A
001764 146717 A
001765 151331 A
001766 120324 A
001767 142723 A
001768 152240 A
001769 000000 A
001770 106612 A
001771 146717 A
001772 151331 A
001773 120324 A
001774 142723 A
001775 152240 A
001776 000000 A
001777 106612 A
001778 146717 A
001779 151331 A
001780 120324 A
001781 142723 A
001782 152240 A
001783 000000 A
001784 106612 A
001785 146717 A
001786 151331 A
001787 120324 A
001788 142723 A
001789 152240 A
001790 000000 A
001791 106612 A
001792 146717 A
001793 151331 A
001794 120324 A
001795 142723 A
001796 152240 A
001797 000000 A
001798 106612 A
001799 146717 A
001800 151331 A
001801 120324 A
001802 142723 A
001803 152240 A
001804 000000 A
001805 106612 A
001806 146717 A
001807 151331 A
001808 120324 A
001809 142723 A
001810 152240 A
001811 000000 A
001812 106612 A
001813 146717 A
001814 151331 A
001815 120324 A
001816 142723 A
001817 152240 A
001818 000000 A
001819 106612 A
001820 146717 A
001821 151331 A
001822 120324 A
001823 142723 A
001824 152240 A
001825 000000 A
001826 106612 A
001827 146717 A
001828 151331 A
001829 120324 A
001830 142723 A
001831 152240 A
001832 000000 A
001833 106612 A
001834 146717 A
001835 151331 A
001836 120324 A
001837 142723 A
001838 152240 A
001839 000000 A
001840 106612 A
001841 146717 A
001842 151331 A
001843 120324 A
001844 142723 A
001845 152240 A
001846 000000 A
001847 106612 A
001848 146717 A
001849 151331 A
001850 120324 A
001851 142723 A
001852 152240 A
001853 000000 A
001854 106612 A
001855 146717 A
001856 151331 A
001857 120324 A
001858 142723 A
001859 152240 A
001860 000000 A
001861 106612 A
001862 146717 A
001863 151331 A
001864 120324 A
001865 142723 A
001866 152240 A
001867 000000 A
001868 106612 A
001869 146717 A
001870 151331 A
001871 120324 A
001872 142723 A
001873 152240 A
001874 000000 A
001875 106612 A
001876 146717 A
001877 151331 A
001878 120324 A
001879 142723 A
001880 152240 A
001881 000000 A
001882 106612 A
001883 146717 A
001884 151331 A
001885 120324 A
001886 142723 A
001887 152240 A
001888 000000 A
001889 106612 A
001890 146717 A
001891 151331 A
001892 120324 A
001893 142723 A
001894 152240 A
001895 000000 A
001896 106612 A
001897 146717 A
001898 151331 A
001899 120324 A
001900 142723 A
001901 152240 A
001902 000000 A
001903 106612 A
001904 146717 A
001905 151331 A
001906 120324 A
001907 142723 A
001908 152240 A
001909 000000 A
001910 106612 A
001911 146717 A
001912 151331 A
001913 120324 A
001914 142723 A
001915 152240 A
001916 000000 A
001917 106612 A
001918 146717 A
001919 151331 A
001920 120324 A
001921 142723 A
001922 152240 A
001923 000000 A
001924 106612 A
001925 146717 A
001926 151331 A
001927 120324 A
001928 142723 A
001929 152240 A
001930 000000 A
001931 106612 A
001932 146717 A
001933 151331 A
001934 120324 A
001935 142723 A
001936 152240 A
001937 000000 A
001938 106612 A
001939 146717 A
001940 151331 A
001941 120324 A
001942 142723 A
001943 152240 A
001944 000000 A
001945 106612 A
001946 146717 A
001947 151331 A
001948 120324 A
001949 142723 A
001950 152240 A
001951 000000 A
001952 106612 A
001953 146717 A
001954 151331 A
001955 120324 A
001956 142723 A
001957 152240 A
001958 000000 A
001959 106612 A
001960 146717 A
001961 151331 A
001962 120324 A
001963 142723 A
001964 152240 A
001965 000000 A
001966 106612 A
001967 146717 A
001968 151331 A
001969 120324 A
001970 142723 A
001971 152240 A
001972 000000 A
001973 106612 A
001974 146717 A
001975 151331 A
001976 120324 A
001977 142723 A
001978 152240 A
001979 000000 A
001980 106612 A
001981 146717 A
001982 151331 A
001983 120324 A
001984 142723 A
001985 152240 A
001986 000000 A
001987 106612 A
001988 146717 A
001989 151331 A
001990 120324 A
001991 142723 A
001992 152240 A
001993 000000 A
001994 106612 A
001995 146717 A
001996 151331 A
001997 120324 A
001998 142723 A
001999 152240 A
002000 000000 A
002001 106612 A
002002 146717 A
002003 151331 A
002004 120324 A
002005 142723 A
002006 152240 A
002007 000000 A
002008 106612 A
002009 146717 A
002010 151331 A
002011 120324 A
002012 142723 A
002013 152240 A
002014 000000 A
002015 106612 A
002016 146717 A
002017 151331 A
002018 120324 A
002019 142723 A
002020 152240 A
002021 000000 A
002022 106612 A
002023 146717 A
002024 151331 A
002025 120324 A
002026 142723 A
002027 152240 A
002028 000000 A
002029 106612 A
002030 146717 A
002031 151331 A
002032 120324 A
002033 142723 A
002034 152240 A
002035 000000 A
002036 106612 A
002037 146717 A
002038 151331 A
002039 120324 A

```

001724	146240	A					
001725	136640	A					
001726	000000	A					
001727	152305	A	718 HG10	DATA	*TEST ADDRESS EXPECTED ACTUAL CYCLE*,CRLF,0	J	04 00718
001730	151724	A					
001731	120240	A					
001732	120301	A					
001733	142304	A					
001734	151305	A					
001735	151723	A					
001736	120240	A					
001737	142730	A					
001740	150305	A					
001741	141724	A					
001742	142704	A					
001743	120240	A					
001744	140703	A					
001745	152325	A					
001746	140714	A					
001747	120240	A					
001750	141731	A					
001751	141714	A					
001752	142610	A					
001753	106612	A					
001754	000000	A					
001755	106612	A	719 HG11	DATA	CRLF,'NUMBER OF CYCLES RUN =',0		04 00719
001756	147325	A					
001757	146702	A					
001760	142722	A					
001761	120317	A					
001762	143240	A					
001763	141731	A					
001764	141714	A					
001765	142723	A					
001766	120322	A					
001767	152716	A					
001770	120275	A					
001771	000000	A					
	720	*					
	721	*	TABLES HAVE THE FORM				
	722	*	NAME BSS 1	TABLE NAME, INDEX PTR FOR TABLE			04 00720
	723	*	BSS 1	MAX LENGTH OR CURRENT LENGTH OF TABLE			04 00721
	724	*		(DEPENDING ON ROUTINE ACCESSING TABLE)			04 00722
	725	*	BSS N	BODY OF TABLE, N=OCTAL MAX LENGTH			04 00723
	726	*					04 00724
001772	000000	A	727 TBLI	DATA 0,6	TABLE OF WORSE CASE PATTERNS	F	04 00725
001773	000006	A					04 00726
001774	000203	A	728	DATA 0203	AMPEX		04 00727
001775	004001	A	729	DATA 04001	FABRI-TEK OR LITTON		04 00728
001776	000024	A	730	DATA 024,0144,044		E	04 00729
001777	000144	A					
002000	000044	A					
002001	003000	A	731	DATA 03000		F	04 00730
	732	*					04 00731
	733	*	TBL CONTAINS BEGINNING AND ENDING ADDRS OF MEMORY SEGMENT TO BE TESTED				04 00732
	734	*					04 00733
002002	000000	A	735 TBL	DATA 0	TBL INDEX	J	04 00734
002003	000014	A	736	DATA 12	TBL LENGTH		04 00735
	737	*					04 00736
	738	*	W A R N I N G			E	04 00737
	739	*					04 00738
	740	*	NUMBER PAIRS MUST REFERENCE AN EVEN NUMBER OF WORDS			E	04 00739
	741	*	-----				04 00740
	742	*				E	04 00741
002004	000000	A	743	DATA 0,1		E	04 00742
002005	000001	A	744	DATA 2,5			04 00743
002006	000002	A	745	DATA 040,043		J	04 00744
002007	000005	A	746	DATA 0100,0117			04 00745
002010	000040	A	747	DATA 0400,0621		E	04 00746
002011	000043	A	748	DATA ((EM1/2)*2)+2,07755			04 00747
002012	000100	A	749	01 EQU TBL+3		E	04 00748
002013	000117	A	750	*			04 00749
002014	000400	A	751 MSG3	DATA * INVALID*,0			04 00750
002020	120240	A					04 00751
002021	144716	A					
002022	153301	A					
002023	146311	A					
002024	142240	A					
002025	000000	A					
	752	*					04 00752
	753	*	*****				04 00753
	754	*					04 00754
	755	*	SENSE SWITCH SUBROUTINE				04 00755
	756	*	THIS SUBROUTINE PROVIDES A STANDARD SENSE SWITCH INTERFACE.				04 00756
	757	*	THE CALLING SEQUENCE IS AS FOLLOWS				04 00757
	758	*	THE A, B, AND X REGISTERS CONTAIN ERROR HALT VALUES.				04 00758
	759	*	CALL SSWT				04 00759
	760	*	DATA (U REGISTER VALUE)				04 00760
	761	*	DATA (ERROR MESSAGE ADDRESS) (IF NEG. ERROR SUB.)				04 00761
	762	*	DATA (TERMINATION EXIT)				04 00762

	763 *	DATA	(LOOP ON ERROR EXIT)	*04 00763	
	764 *	*	NORMAL EXIT RETURN	*04 00764	
	765 *			*04 00765	
	766 *		STANDARD SENSE SWITCH SETTINGS	*04 00766	
	767 *	SS1	- (SET) SUPPRESS ERROR PRINTOUT	*04 00767	
	768 *		(RESET) ALLOW ERROR PRINTOUTS	*04 00768	
	769 *	SS2	(SET) HALT ON ERROR	*04 00769	
	770 *		(IF SET AFTER HALT - CONTINUE)	*04 00770	
	771 *		(RESET) DO NOT HALT ON ERROR	*04 00771	
	772 *		(IF HALT ON ERROR SET FIRST THEN RESET ON	*04 00772	
	773 *		HALT CONDITION - LOOP UNTIL SET)	*04 00773	
	774 *	SS3	(SET) TERMINATE TEST - RETURN TO BEGINNING OF TEST	*04 00774	
	775 *		(RESET) CONTINUE TEST	*04 00775	
	776 *		*****	*04 00776	
	777 *			04 00777	
002026	052164 A	778 SSWP	STA SSWS	SAVE VOLATILE REGISTERS	04 00778
002027	062165 A	779 STB	SSWS+1		04 00779
002030	072166 A	780 STX	SSWS+2		04 00780
002031	001400 A	781 JSS3	SSWE	IF SS3 SET RETURN THROUGH TERMINATION EXIT	04 00781
002032	002167 A				
002033	012557 A	782 LDA \$CON		CHECK IF CONSOLE OR TTY MODE	04 00782
002034	001010 A	783 JAZ SSWN			04 00783
002035	002122 A				
002036	001100 A	784 JSS1	SSW1	TELETYPE MODE - CHECK IF TTY SUPPRESSED	04 00784
002037	002061 A	785 LDB SSWT		GET 2ND PARAMETER	04 00785
002040	022200 A	786 IBR			04 00786
002041	005122 A	787 LDA 0,2			04 00787
002042	016000 A	788 JAZ SSW1			04 00788
002043	001010 A				
002044	002061 A	789 TAB		CHECK IF BIT 15 SET	04 00789
002045	005012 A	790 ANAI	0100000		04 00790
002047	1000000 A				
002050	005014 A	791 TAX			04 00791
002051	005021 A	792 TBA			04 00792
002052	001040 A	793 JXZ *+4			04 00793
002053	002056 A				
002054	001003 A	794 JMP SSWR		CALL ERROR SUBROUTINE	04 00794
002055	002152 A				
002056	005014 A	795 TAX		PRINT ERROR MESSAGE	04 00795
002057	002000 A	796 CALL OUTD			04 00796
002060	002537 A				
002061	001400 A	797 SSW1	JSS3	IF SS3 SET - RETURN THROUGH TERMINATION EXIT	04 00797
002062	002167 A				
002063	012560 A	798 LDA \$FLG		CHECK IF LOOPING	04 00798
002064	001010 A	799 JAZ SSW4			04 00799
002065	002116 A				
002066	001200 A	800 SSW2	JSS2	LOOPING - CHECK IF TERMINATE LOOPING.	04 00800
002067	002103 A	801 SSWL	LDB SSWT	RETURN THROUGH LOOP EXIT	04 00801
002070	022200 A	802 IBR			04 00802
002071	005122 A	803 IBR			04 00803
002072	005122 A	804 IBR			04 00804
002073	005122 A	805 LDA 0,2			04 00805
002074	016000 A	806 STA *+5			04 00806
002075	052102 A	807 LDB SSWS		RETURN VOLATILE REGISTERS.	04 00807
002076	012164 A	808 LDB SSWS+1			04 00808
002077	022165 A	809 LDW SSWS+2			04 00809
002100	032166 A	810 JMP *			04 00810
002101	001000 A				
002102	002101 A	811 SSW3	TZA	RETURN TO NORMAL EXIT (CONTINUATION EXIT)	04 00811
002104	052560 A	812 STA \$FLG		CLEAR LOOP FLAG.	04 00812
002105	012200 A	813 LDA SSWT			04 00813
002106	006100 A	814 ADDI 4			04 00814
002107	000004 A				
002107	002107 A	815 04 EQU *-1			E 04 00815
002110	032115 A	816 STA *+5			04 00816
002111	012164 A	817 LDA SSWS		RETURN VOLATILE REGISTERS.	04 00817
002112	022165 A	818 LDB SSWS+1			04 00818
002113	032166 A	819 LDW SSWS+2			04 00819
002114	001000 A	820 JMP *			04 00820
002115	002114 A				
002116	001200 A	821 SSW4	JSS2	CHECK IF HALT ON ERROR	04 00821
002117	002127 A	822 JMP SSW3		RETURN TO NORMAL EXIT LOC.	04 00822
002120	001000 A				
002121	002100 A	823 SSWM	LDA \$FLG	CHECK IF LOOP FLAG ZERO	04 00823
002122	012560 A	824 JAZ SSW4			04 00824
002123	001010 A				
002124	002116 A	825 JSS1	SSW6		04 00825
002125	001100 A				
002126	002136 A	826 SSW5	LDB SSWT	GET FIRST PARAMETER	04 00826
002127	022200 A	827 LDA 0,2			04 00827
002130	016000 A	828 STA *+4			04 00828
002131	052135 A	829 LDA SSWS		RETURNED SAVED PARAMETERS.	04 00829
002132	012164 A	830 LDB SSWS+1			04 00830
002133	022165 A	831 LDW SSWS+2			04 00831
002134	032166 A	832 NOP		1ST PARAMETER STORED HERE AND EXECUTED.	04 00832
002135	005000 A	833 SSW6	JSS3	IF SS3 SET RETURN THROUGH TERMINATION EXIT	04 00833
002136	001400 A				
002137	002167 A	834 LDA \$FLG		CHECK IF LOOPING	04 00834
002140	012560 A	835 JAZ *+4			04 00835
002141	001010 A				
002142	002145 A	836 JMP SSW2			04 00836
002143	001000 A				
002144	002066 A				

MAINTAIN III						MEMPT1	PAGE 13
002145	001200	A	837	JSS2	SSW3	LOOP FLAG ZERO - CHECK IF LOOP REQUEST	04 00837
002146	002103	A	838	INR	\$FLG	INCREMENT LOOP FLAG	04 00838
002147	042560	A	839	JMP	SSWL	JUMP THROUGH LOOP EXIT	04 00839
002150	001000	A					
002151	002070	A					
002152	006150	A	840	SSWR	ANAI	077777	ERROR SUBROUTINE MASK OUT BIT 15 F 04 00840
002153	077777	A	841	B014	EQU	*-1	F 04 00841
002154	052161	A	842	STA	*+5		04 00842
002155	012164	A	843	LDB	SSWS		04 00843
002156	022165	A	844	LDB	SSWS+1		04 00844
002157	032166	A	845	LDB	SSWS+2		04 00845
002160	002000	A	846	JMPM	*	CALL ERROR SUBROUTINE	04 00846
002161	002100	A					
002162	001000	A	847	JMP	SSW1		04 00847
002163	002061	A					
002164			848	SSWS	BSS	3	
002167	005001	A	849	SSWE	TZA		04 00848
002170	052560	A	850	STA	\$FLG	JUMP THROUGH TERMINATION EXIT.	04 00849
002171	022200	A	851	LDB	SSWT	CLEAR LOOP FLAG.	04 00850
002172	005122	A	852	IBR		SET UP TERMINATION EXIT	04 00851
002173	005122	A	853	IBR			04 00852
002174	016000	A	854	LDA	0,2		04 00853
002175	052177	A	855	STA	*+2		04 00854
002176	001000	A	856	JMP	*		04 00855
002177	002176	A					04 00856
002200	000000	A	857	SSWT	ENTR		04 00857
002201	001000	A	858	JMP	SSWP	SENSE SWITCH SUBROUTINE ENTRANCE	04 00858
002202	002026	A					
			859	*			04 00859
			860	*		INPUT ONE CHARACTER FROM TTY TO A REGISTER	04 00860
			861	*			04 00861
002203	012471	A	862	INAI	LDA	STTY	
002204	006110	A	863	DRAI	0101200	ADJUST TTY DA	04 00862
002205	101200	A					04 00863
002206	0522212	A	864	STA	*+4		04 00864
002207	006120	A	865	ADDI	001300		04 00865
002210	001300	A					
002211	0522221	A	866	STA	*+8		04 00866
002212	101000	A	867	SEN	0,*+7	READ REGISTER READY	04 00867
002213	002221	A					
002214	005011	A	868	MERG	011		04 00868
002215	001400	A	869	JSS3*	INPA	TERMINATE EXIT	04 00869
002216	102225	A					
002217	001000	A	870	JMP	*-5		04 00870
002220	002212	A					
002221	102500	A	871	CIA	0	INPUT CHARACTER	04 00871
002222	042225	A	872	INR	INPA		04 00872
002223	042225	A	873	INR	INPA		04 00873
002224	001000	A	874	JMP*	0	EXIT	04 00874
002225	100000	A					
002225			875	INPA	BES	0	04 00875
002226	001000	A	876	JMP	INAI		04 00876
002227	002203	A					
			877	*			04 00877
			878	*		INPUT ONE CHARACTER + PRINT FROM TTY TO A REGISTER	04 00878
			879	*			04 00879
002230	002000	A	880	INB1	CALL	INPA	INPUT ONE CHARACTER 04 00880
002231	002225	A	881	JMP*	INPB	TERMINATE EXIT	
002232	001000	A					04 00881
002233	102241	A	882	CALL	OUTA	OUTPUT ONE CHARACTER	04 00882
002234	002000	A					
002235	002440	A					
002236	042241	A	883	INR	INPB		04 00883
002237	042241	A	884	INR	INPB		04 00884
002240	001000	A	885	JMP*	0	EXIT	04 00885
002241	100000	A					
002241			886	INPB	BES	0	04 00886
002242	001000	A	887	JMP	INB1		04 00887
002243	002230	A					
			888	*			04 00888
			889	*		INPUT ONE CHARACTER (EDITED)	04 00889
			890	*			04 00890
002244	002000	A	891	INC3	CALL	INPB	
002245	002241	A	892	JMP*	INPC	TERMINATE EXIT	04 00892
002246	001000	A					
002247	102272	A					
002250	132234	A	893	ERA	ABS	BACKSLASH	
002251	001010	A	894	JAZ	INC2	ABORT INPUT EXIT	E 04 00893
002252	002267	A					04 00894
002253	006130	A	895	ERAI	'\n'	RESTORE A	04 00895
002254	000334	A					
			896	ABS	EQU	*-1	E 04 00896
002255	006130	A	897	ERAI	0337	BACKARROW	04 00897
002256	000337	A					
002257	001010	A	898	JAZ	INC1	DELETE ONE CHARACTER EXIT	04 00898
002260	002265	A					
002261	006130	A	899	ERAI	0337	RESTORE A	04 00899
002262	000337	A					
002263	042272	A	900	INR	INPC		04 00900
002264	042272	A	901	INR	INPC		04 00901
002265	042272	A	902	INC1	INR	INPC	04 00902
002266	042272	A	903	INR	INPC		04 00903
002267	042272	A	904	INC2	INR	INPC	04 00904
002270	042272	A	905	INR	INPC		04 00905

PAGE 14 MAINTAIN III MEMPT1

002271	001000	A	906	JMP*	0	EXIT	04 00906	
002272	100000	A	907	INPC	BES	0	04 00907	
002273	001000	A	908	JMP	INC3		04 00908	
002274	002244	A	909	*			04 00909	
			910	*	INPUT ONE ALPHA CHARACTER FROM TTY KEYBOARD TO A REG		04 00910	
			911	*			04 00911	
002275	002000	A	912	IND4	CALL	INPC	04 00912	
002276	002272	A	913	JMP*	INPD	INPUT ONE CHAR		
002277	001000	A	914	JMP	IND2	TERMINATE EXIT	04 00913	
002300	102326	A	915	JMP	IND1	ABORT INPUT EXIT	04 00914	
002301	001000	A	916	SUBI	0301	DELETE PREVIOUS CHARACTER EXIT	04 00915	
002302	002323	A	917	EQU	*-1	CHAR A	04 00916	
002303	001000	A	918	JAN	IND3	INVALID INPUT	E 04 00917	
002304	002321	A	919	SUBI	032	CHAR Z	04 00918	
002305	006140	A	920	JAP	IND3	INVALID INPUT	04 00919	
002306	000301	A	921	ADDI	0333	RESTORE A	04 00920	
002310	002331	A	922	INR	INPD	NORMAL EXIT	04 00921	
002311	006140	A	923	INR	INPD	DELETE PREVIOUS CHARACTER EXIT	04 00922	
002312	000032	A	924	IND1	INR		04 00923	
002313	001002	A	925	INR	INPD	ABORT INPUT EXIT	04 00924	
002314	002331	A	926	IND2	INR		04 00925	
002315	006120	A	927	INR	INPD		04 00926	
002316	000333	A	928	JMP*	0	EXIT	04 00927	
002317	042326	A	929	INPD	BES	0	04 00928	
002320	042326	A	930	JMP	IND4		04 00929	
002321	042326	A	931	IND3	CALL	DUTG	INVALID INPUT--PRINT MESSAGE	04 00930
002322	042326	A	932	JMP	IND2	ABORT	04 00931	
002323	042326	A	933	*			04 00932	
			934	*	INPUT OCTAL NUMBER FROM TTY KEYBOARD		04 00933	
			935	*	ASSEMBLE AS 16 BIT NUMBER IN A REG		04 00934	
			936	*	ONLY OCTAL NUMBERS ACCEPTED		04 00935	
			937	*			04 00936	
			938	ING7	TZA		04 00937	
002335	005001	A	939	STA	TS02	TEMP STORAGE FOR OCTAL NUMBER	04 00938	
002336	052562	A	940	STA	TS04	TEMP STORAGE FOR DIGIT COUNTER	04 00939	
002337	052564	A	941	STB	TS07		04 00940	
002340	062567	A	942	TZB			04 00941	
002341	005002	A	943	ING5	CALL	INPC	04 00942	
002342	002000	A	944	JMP*	INPG	INPUT ONE CHARACTER	04 00943	
002343	002272	A	945	JMP	ING2	TERMINATE EXIT	04 00944	
002344	001000	A	946	JMP	ING1	ABORT INPUT EXIT	04 00945	
002345	102410	A	947	STA	TS05	DELETE PREVIOUS CHARACTER EXIT	04 00946	
002346	001000	A	948	SUB	A0	SAVE INPUT	E 04 00947	
002347	002403	A	949	JAN	IMG6	INVALID IF NOT OCTAL NUMBER	04 00948	
002350	001000	A	950	SUB	D10		04 00949	
002351	002430	A	951	JAP	IMG6	INVALID IF NOT OCTAL NUMBER	E 04 00950	
002352	052565	A	952	JMP	IND2		04 00951	
002353	142520	A	953	ING5	CALL	INPC		
002354	001004	A	954	JMP*	INPG	INPUT ONE CHARACTER		
002355	002413	A	955	STA	TS02	TEMP STORAGE FOR OCTAL NUMBER		
002356	142362	A	956	LDA	TS04	TEMP STORAGE FOR DIGIT COUNTER		
002357	001002	A	957	LLRL	3	INSERT CHARACTER		
002358	001020	A	958	ORA	TS03	INTO		
002359	002373	A	959	JBZ	*+4	OCTAL NUMBER		
002360	002413	A	960			TOO MANY BITS ?		
002361	006120	A	961	JMP	IMG8	YES	04 00952	
002362	000010	A	962	EQU	*-1		E 04 00953	
002363	052563	A	963	STA	TS03	SAVE CHARACTER	04 00954	
002364	012562	A	964	LDA	TS02	INSERT CHARACTER	04 00955	
002365	004443	A	965	LLRL	3	INTO	04 00956	
002366	112563	A	966	ORA	TS03	OCTAL NUMBER	04 00957	
002367	001020	A	967	JBZ	*+4	TOO MANY BITS ?	04 00958	
002368	002373	A	968	JMP	IMG8			
002369	001060	A	969	NO			04 00959	
002370	002424	A	970	INR	TS04	INCR # DIGITS	04 00960	
002371	052562	A	971	JMP	IMG5	GET NEXT DIGIT	04 00961	
002372	042564	A	972	JMP	IMG5		04 00962	
002373	001000	A	973	ING3	INR	NORMAL EXIT	04 00963	
002374	042410	A	974	INR	INPG	COMMA EXIT	04 00964	
002375	001000	A	975	ING4	INR		04 00965	
002376	002342	A	976	INR	INPG	ABORT INPUT EXIT	04 00966	
002377	042410	A	977	ING2	INR		04 00967	
002400	042410	A	978	INR	INPG		04 00968	
002401	042410	A	979	INR	INPG		04 00969	
002402	042410	A	980	INR	INPG		04 00970	
002403	042410	A	981	INR	INPG		04 00971	
002404	042410	A	982	INR	INPG		04 00972	
002405	022567	A	983	LDB	TS07		04 00973	
002406	012562	A	984	LDA	TS02	GET ASSEMBLED OCTAL NUMBER		
002407	001000	A	985	JMP	0	EXIT		
002410	000000	A	986	ING7				
002411	001000	A	987	INPG	BES			
002412	002335	A	988	JMP	IMG7			

MAINTAIN III						MEMPT1	PAGE 15	
002413	012565	A	974	ING6	LDA	TS05	GET LAST INPUT IS IT A COMMA	04 00974
002414	006140	A	975	SUBI	0254			04 00975
002415	000254	A	976	JAZ	ING4		YES	04 00976
002416	001010	A	977	SUBI	02		IS IT A PERIOD	04 00977
002417	002401	A						E 04 00978
002420	006140	A	978	02	EQU	*-1		04 00979
002421	000002	A	979	JAZ	ING3		YES	
002422	001010	A	980	ING8	CALL	OUTG	PRINT INVALID MESSAGE	04 00980
002423	002377	A						
002424	002000	A	981	JMP	ING2		ABORT	04 00981
002425	002550	A						
002426	001000	A	982	*				04 00982
002427	002403	A	983	ING1	LDA	TS02	DELETE LAST CHARACTER	04 00983
002430	012562	A	984	LSRA	3			04 00984
002431	004343	A	985	STA	TS02			04 00985
002432	052562	A	986	LIA	TS04			04 00986
002433	012554	A	987	DAR			REDUCE DIGIT COUNT	04 00987
002434	005311	A	988	STA	TS04			04 00988
002435	052564	A	989	JMP	ING5			04 00989
002437	002342	A	990	*				
			991	*	OUTPUT ONE CHARACTER FROM A REG TO TTY			04 00990
			992	*				04 00991
002440	000000	A	993	DUTA	ENTR	0	SAVE X	04 00992
002441	072561	A	994	STX	TS01			04 00993
002442	005014	A	995	TAX				04 00994
002443	012471	A	996	LDA	\$TTY			04 00995
002444	006110	A	997	ORAI	0101100		ADJUST TTY DA	04 00996
002445	101100	A						E 04 00997
002446	052453	A	998	STA	*+5			04 00998
002447	120047	A	999	ADD	02K			E 04 00999
002450	052465	A	1000	STA	OUT1			04 01000
002451	005041	A	1001	TXA				04 01001
002452	005004	A	1002	TZX				E 04 01002
002453	101000	A	1003	SEN	0,DUT1		WRITE REGISTER READY	04 01003
002454	002465	A						
002455	005344	A	1004	BXR				04 01004
002456	001040	A	1005	JXZ	*+4			04 01005
002457	002462	A						
002460	001000	A	1006	JMP	*-5			04 01006
002461	002453	A						
002462	000077	A	1007	D77	HLT	077		E 04 01007
002463	001000	A	1008	JMP	*-10			04 01008
002464	002451	A						
002465	103100	A	1009	DUT1	DAR	0		04 01009
002466	032561	A	1010	LDX	TS01		RESTORE X	04 01010
002467	001000	A	1011	JMP*	DUTA		RETURN	04 01011
002470	102440	A	1012	*				
			1013	*				04 01012
002471	000001	A	1014	STTY	DATA	01		04 01013
			1015	*				04 01014
			1016	*				04 01015
			1017	*				04 01016
			1018	*	OUTPUT TWO CHARACTERS FROM A REG TO TTY (HIGH ORDER FIRST)			04 01017
			1019	*	ENTER WITH CHARACTERS IN A REG			04 01018
			1020	*				04 01019
002472	000000	A	1021	DUTB	ENTR	0		04 01020
002473	062565	A	1022	STB	TS06		SAVE B	04 01021
002474	004550	A	1023	LLSR	8			04 01022
002475	002000	A	1024	CALL	DUTA		OUTPUT FIRST CHAR	04 01023
002476	002443	A						04 01024
002477	004150	A	1025	LLRL	8			04 01025
002500	002000	A	1026	CALL	CUTA		OUTPUT SECOND CHAR	04 01026
002501	002440	A						
002502	022566	A	1027	LDB	TS06		RESTORE B	04 01027
002503	001000	A	1028	JMP*	DUTB		RETURN	04 01028
002504	102472	A	1029	*				
			1030	*	OUTPUT CARRIAGE RETURN AND LINE FEED TO TTY			04 01029
			1031	*				04 01030
002505	000000	A	1032	DUTC	EMTR	0		04 01031
002506	011671	A	1033	LDA	NL		CR AND LF	04 01032
002507	002000	A	1034	CALL	DUTB		OUTPUT 2 CHAR	04 01033
002510	002472	A						E 04 01034
002511	001000	A	1035	JMP*	DUTC		RETURN	04 01035
002512	102505	A	1036	*				
			1037	*	OUTPUT OCTAL WORD AND A SPACE TO TTY			04 01036
			1038	*				04 01037
002513	000000	A	1039	DUTE	ENTR	0		04 01038
002514	005002	A	1040	TZB				04 01039
002515	004557	A	1041	LLSR	15			04 01040
002516	005122	A	1042	IBR				04 01041
002517	006110	A	1043	DUT2	ORAI	*0*	MAKE DIGIT	04 01042
002520	000260	A						04 01043
002520	002520	A	1044	A0	EQU	*-1		E 04 01044
002521	002000	A	1045	CALL	DUTA		OUTPUT ONE DIGIT	04 01045
002522	002440	A						
002523	005001	A	1046	TZA				04 01046
002524	004443	A	1047	LLRL	3			04 01047
002525	001020	A	1048	JBZ	*+4		OCTAL OUTPUT COMPLETE	04 01048

PAGE 16 MAINTAIN III MEMPT1

```

002526 002531 A 1049      JMP    OUT2          04 01049
002527 001000 A 1050      LDAI   0240          ASCII BLANK CODE 04 01050
002530 002517 A 1051      CALL   OUTA          OUTPUT SPACE 04 01051
002533 002000 A 1052      JMP*   OUTE          RETURN 04 01052
002536 102513 A 1053 *    OUTP   *             OUTPUT MESSAGE TO TTY (X REG CONTAINS ADDRESS OF MESSAGE) 04 01053
002537 000000 A 1054 *    OUTD   ENTR  0          04 01054
002540 015000 A 1055 *    OUTD   LDA   0,1          04 01055
002541 001010 A 1056 OUTD  ENTR  0          04 01056
002542 102537 A 1057 LDA   0,1          04 01057
002543 002000 A 1058 JAZ*   OUTD          04 01058
002544 002472 A 1059 CALL   OUTB          04 01059
002545 005144 A 1060 IXR   *             04 01060
002546 001000 A 1061 JMP   OUTD+1        04 01061
002547 002540 A 1062 *    OUTP   *             INVALID INPUT--PRINT MESSAGE 04 01062
002550 000000 A 1063 *    OUTG   ENTR  0          04 01063
002551 006030 A 1064 *    OUTG   LDXI  MSG5        INVALID MESSAGE 04 01064
002552 002020 A 1065 OUTG  ENTR  0          04 01065
002553 002000 A 1066 LDIXI MSG5          INVALID MESSAGE 04 01066
002554 002537 A 1067 CALL   OUTD          OUTPUT MESSAGE 04 01067
002555 001000 A 1068 JMP*   OUTG          04 01068
002556 102550 A 1069 *    OUTP   *             EXECUTIVE DATA TABLE 04 01069
002557 000000 A 1070 *    OUTP   *             04 01070
002560 000000 A 1071 *    OUTP   *             04 01071
002561 000000 A 1072 $CON  BSS   1             MODE FLAG 0 = CONSOLE + 1 = TTY 04 01072
002562 000000 A 1073 $FLG  BSS   1             LOOP FLG USED IN SSWT 04 01073
002563 000000 A 1074 *    OUTP   *             04 01074
002564 000000 A 1075 *    OUTP   *             04 01075
002565 000000 A 1076 *    OUTP   *             DATA TABLE 04 01076
002566 000000 A 1077 *    OUTP   *             04 01077
002567 000000 A 1078 TS01  DATA  0             TEMPORARY STORAGE 04 01078
002568 000000 A 1079 TS02  DATA  0             TEMPORARY STORAGE 04 01079
002569 000000 A 1080 TS03  DATA  0             TEMPORARY STORAGE 04 01080
002570 000000 A 1081 TS04  DATA  0             DIGIT COUNTER FOR INPG 04 01081
002571 000000 A 1082 TS05  DATA  0             TEMPORARY STORAGE 04 01082
002572 000000 A 1083 TS06  DATA  0             TEMPORARY STORAGE 04 01083
002573 000000 A 1084 TS07  DATA  0             TEMPORARY STORAGE 04 01084
001671 A 1085 NL   EQU   HDG1          J 04 01085
001731 A 1086 BB   EQU   HG10+2        J 04 01085
002570 A 1087 EM1  EQU   *             E 04 01087
000622 A 1088 END   M23          H 04 01088

```

ENTRY NAMES
EXTERNAL NAMES
SYMBOLS

002557 A \$CON	002560 A \$FLG	002471 A \$TTY	002520 A AO
002306 A AA	002254 A ABS	002153 A B014	001731 A BB
001535 A BITC	001661 A BITS	001536 A BITX	106612 A CRLF
001652 A CYCL	001537 A DAP	001547 A DAP1	001560 A DAP2
001572 A DAP3	000251 A IEM	001670 A EFLG	000712 A ELOP
002570 A EM1	001653 A EMEM	000651 A ERP1	000665 A ERP2
000661 A ERP3	000634 A ERPO	000342 A ERR1	001657 A FRST
001671 A HDG1	001701 A HDG6	001710 A HDG8	001716 A HDG9
001727 A HG10	001735 A HG11	001106 A IAO	001063 A IAZ
001137 A ICB	001136 A ICB1	001170 A ICB2	001146 A ICBC
002203 A INA1	002230 A INB1	002265 A INC1	002267 A INC2
002244 A INC3	002321 A IND1	002323 A IND2	002331 A IND3
002275 A IND4	002430 A IMG1	002403 A IMG2	002377 A IMG3
002401 A IMG4	002342 A IMG5	002413 A IMG6	002335 A IMG7
002424 A INGS	002225 A INPA	002241 A INPB	002272 A INPC
002326 A INPD	002410 A INPG	000777 A IUA	001001 A IUAI
001254 A IWC	001267 A IWCC	001660 A LAST	000622 A M23
000326 A MERR	000205 A MIN1	000212 A MIN2	000236 A MIN3
000177 A MINT	002220 A MSG5	000126 A MTC1	000124 A MTC4
000120 A MTCM	000022 A MTDP	000051 A MTT5	000072 A MTT6
000044 A MTTM	001647 A MTW1	001650 A MTW2	001671 A NL
002003 A D1	002362 A D10	002421 A D2	000047 A D2K
001253 A D3	002107 A D4	001164 A D525	002462 A D77
000323 A D777	000354 A DTAC	002465 A OUT1	002517 A OUT2
002440 A OUTA	002472 A OUTB	002505 A OUTC	002537 A OUTD
002513 A OUTE	002550 A OUTG	001662 A PAT1	001663 A PAT2
000045 A PRTY	001656 A REP	001655 A REP1	001666 A SAVB
001667 A SAVX	001574 A SET	001576 A SET1	002061 A SSW1
002066 A SSW2	002103 A SSW3	002116 A SSW4	002127 A SSW5
002136 A SSW6	002167 A SSWE	002070 A SSWL	002122 A SSWN
002026 A SSWP	002152 A SSWR	002164 A SSWS	002200 A SSWT
001665 A SWCH	001075 A TAOT	001052 A TA2T	001331 A TBC
001337 A TBC1	001346 A TBC2	001405 A TBC3	001421 A TBC4
001430 A TBC5	001472 A TBC6	001414 A TBC7	001501 A TBC8
001505 A TBC9	001310 A TBCA	001313 A TBCB	001523 A TBCC
001513 A TBCD	001534 A TBCE	001466 A TBCF	001401 A TBCG
001300 A TBCT	002002 A TBL	001772 A TBLI	001206 A TCB
001212 A TCBB	001121 A TCBT	001651 A TCYC	000271 A TERM
000320 A TERN	001664 A TERR	001611 A TES	001614 A TES1
001640 A TES2	001654 A TEST	002561 A TS01	002562 A TS02
002563 A TS03	002564 A TS04	002565 A TS05	002566 A TS06

MAINTAIN III

MEMPT1

PAGE 17

002567 A TS07	001011 A TUA	001014 A TUAI	001025 A TUAS
001027 A TUAS	000733 A TUGA	000753 A TUAB	000757 A TUAC
000726 A TUAT	000170 A UACA	000140 A UACB	000161 A UACC
000175 A UACD			
0 ERRORS ASSEMBLY COMPLETE			
LITERALS			
POINTERS			
1072 \$CON	71	76	187
1073 \$FLG	798	812	823
1014 \$TTY	69	862	996
1044 AA	948		
917 AA	*		
896 ABS	893		
841 B014	116		
1086 BB	267	271	276
614 BITC	518	528	537
	546	548	566
	575	586	588
702 BITS	372	391	475
615 BITX	514	517	
713 CRLF	714	715	716
695 CYCL	93	97	117
623 DAP	520	643	653
630 DAP1	632	635	
636 DAP2	630		
644 DAP3	625	626	641
104 DEM	177	188	190
709 EFLG	63	65	336
286 ELOP	233	291	
1087 EM1	748		
696 EMEM	95	100	189
262 ERP1	258		
270 ERP2	*		
267 ERP3	266		
254 ERP0	231	281	
229 ERR1	226	285	294
700 FRST	169	306	317
	325	335	431
	446	516	628
651 667			
714 HDG1	84	1085	
715 HDG6	87		
716 HDG8	191		
717 HDG9	199		
718 HG10	260	1086	
719 HG11	204		
387 IAO	381	395	
368 IAZ	362	375	
409 ICB	403	412	
420 ICB1	410	415	428
430 ICB2	411	417	440
	441		
414 ICBC	403	418	
862 IMA1	876		
880 INB1	887		
902 INC1	838		
904 INC2	894		
891 INC3	908		
924 IND1	915		
926 IND2	914	932	
931 IND3	918	920	
912 IND4	930		
983 ING1	946		
967 ING2	945	981	
963 ING3	979		
965 ING4	976		
943 ING5	962	989	
974 ING6	949	951	
938 ING7	973		
980 ING8	959		
875 IMPA	869	872	873
086 INPB	881	883	891
907 INPC	892	900	901
929 INPD	913	922	923
972 IMPG	89	944	963
	964	964	965
324 IUA	310	331	
326 IUAI	330		
474 IWC	482	505	
484 IWCC	490	507	
701 LAST	171	308	319
	329	351	438
	464	553	656
679			
247 M23	1086		
218 MERR	236	348	453
164 MIN1	179	183	
168 MIN2	176		
177 MIN3	168	170	
159 MINT	96	101	118
751 MSG5	1066		
112 MTC1	111		
116 MTC4	114		
107 MTCM	77	115	
76 MTOP	209	214	
87 MTT5	91		
97 MTT6	92		
83 MTTM	78	90	
692 MTW1	227	269	287
	459	523	531
	670	673	534
693 MTW2	228	274	293
	347	452	460
	525	533	541

PAGE	18	MAINTAIN III					MEMPT1
1085	ML	562	571	581	672		
749	01	1033	251	637			
953	010		950				
978	02		369				
65	02K		999				
472	03		363	382	388	498	
815	04		421				
426	0525		423				
1007	077		601	608			
213	0777		225				
237	0TAC		163	186	223	245	
1009	0UT1	1000	1003				
1043	0UT2	1049					
993	0UTA		273	277	882	1011	1024
1021	0UTB		268	272	1028	1034	1059
1032	0UTC		208	255	1035		
1056	0UTD		86	88	192	200	203
		1061	1067				
1039	0UTE		202	207	263	265	270
1065	0UTG		931	980	1068		
703	PAT1		373	393	477	488	638
704	PAT2		479	486			
52	PRTY		63	107			
699	REP		315	334	364	393	402
698	REP1		445	466	470		
707	SAVB		221	234			
708	SAVX		222	235	264		
650	SET		374	394	480	489	657
652	SET1		659				
797	SSW1		784	788	847		
800	SSW2		836				
811	SSW3		800	822	837		
821	SSW4		799	824			
826	SSW5		821				
833	SSW6		825				
849	SSWE		781	797	833		
801	SSWL		839				
323	SSWN		783				
778	SSWP		858				
840	SSWR		794				
848	SSWS		778	779	780	807	808
			829	830	831	843	844
857	SSWT		229	785	801	813	826
706	SWCH		161	256	259		851
380	TAOT		173	385			
361	TAZT		172	366			
511	TBC		506	508	557		
517	TBC1		554	555	558		
522	TBC2		550				
546	TBC3		540				
555	TBC4	*					
559	TBC5		521	590			
586	TBC6		579				
551	TBC7		549	589	612		
592	TBC8		544	584	606		
596	TBC9		599				
501	TBCA	*					
504	TBCB		503	509			
607	TBCC		527	563			
600	TBCD		596				
613	TBCE		593	605			
584	TBCF		574				
544	TBCG		536				
495	TBCI		175	504			
735	TBL		167	168	170	304	305
			749				
727	TBLI		500				
443	TCB		404	406	469		
447	TCBB		455	467	471		
400	TCBT		174	407			
694	TCYC		162	185	206	211	242
197	TERM		182	232	286	309	320
210	TERN		198				
705	TERR		160	201	210	220	239
665	TES		365	384	682	684	685
668	TES1		681				
682	TES2		679				
697	TEST		212	224	262	302	370
			600	604	607	610	
1078	TS01		994	1010			
1079	TS02		939	955	960	970	983
1080	TS03		954	957			985
1081	TS04		940	961	986	988	
1082	TS05		947	974			
1083	TS06		1022	1027			
1084	TS07		941	969			
333	TUA		321	353	355	356	
336	TUA1		352				
342	TUA2		337				
344	TUA3		341				
305	TUAA		311				
312	TUAB		305	307			
316	TUAC		322				
300	TUAT		165	316	318		

MAINTAIN III

MEMPT1

PAGE 19

150	UACA	129	141	142	143	146	168	170	305	307
		316	318	504						
129	UACB	153								
144	UACC	134								
154	UACD	129	140	147	148	151	152			

