

PDP11

07124K MEMORY EXERCISER
MD-11-DDQAB-A

EP DDQAB A DL A

OCT 1976

COPYRIGHT © 1976

digital

FICHE 1 OF 1

Made in U.S.A.

The image displays a grid of 100 small tables, arranged in 10 rows and 10 columns. Each table is a data set for a memory exercise. The tables are numbered sequentially from 1 to 100. Each table contains several columns of data, likely representing memory addresses and values. The data is presented in a structured, tabular format, typical of a memory exerciser program output. The tables are arranged in a grid that is 10 rows high and 10 columns wide. Each table has a header with a number and contains several columns of data, likely representing memory addresses and values. The data is presented in a structured, tabular format, typical of a memory exerciser program output.

A small table located in the bottom right corner of the page, containing a few lines of data. It appears to be a summary or a specific data point related to the memory exercises.

TABLE OF CONTENTS

ABSTRACT

CHAPTER 1 REQUIREMENTS

1.1 EQUIPMENT

1.2 STORAGE

1.3 PRELIMINARY PROGRAMS

CHAPTER 2 LOADING AND STARTING PROCEDURE

2.1 ACT11 OPERATION

CHAPTER 3 SWITCH SETTINGS

CHAPTER 4 SUBROUTINE ABSTRACTS

4.1 SCOPE

CHAPTER 5 ERRORS

5.1 PARITY ERROR

CHAPTER 6 RESTRICTIONS

6.1 STARTING RESTRICTION

6.2 OPERATIONAL RESTRICTION

CHAPTER 7 MISCELLANEOUS

7.1 STACK POINTER

7.2 PASS COUNT

7.3 ERROR COUNT

7.4 DISPLAY REGISTER

7.5 PROGRAM RELOCATION

7.6 POWER FAIL

7.7 EXECUTION TIME

TABLE OF CONTENTS (CONT'D)

CHAPTER 8 PROGRAM DESCRIPTION

- 8.1 PROGRAM 2 (USER SELECTIONS
 - 8.1.1 PROGRAM 2 STARTING PROCEDURE
 - 8.1.2 PROGRAM 2 USER PARAMETERS
 - 8.1.3 PROGRAM 2 RESTARTING PROCEDURE
 - 8.1.4 PROGRAM 2 USE

8.2 PROGRAM 3

8.3 PROGRAM 4

8.4 PROGRAM 5

8.5 PROGRAM 6

CHAPTER 9 BRANCH GOBBLE MOS TEST

- 9.1 ABSTRACT
- 9.2 OPERATING PROCEDURE
- 9.3 ERRORS
- 9.4 PROGRAM DESCRIPTION

E01

TEST DDQAB-A 0-124K MEMORY EXERCISER MACY11 27(732) 10-SEP-76 10:35 PAGE 4
DDQABA.P11

PDP-11 0-124K MEMORY EXERCISER
ABSTRACT

PAGE 5

ABSTRACT

PROGRAM DDQAB TESTS CONTIGUOUS MEMORY ADDRESS FROM 000000 TO 757776. IT VERIFIES THAT EACH ADDRESS IS UNIQUE (AN ADDRESS TEST) AND THAT EACH MEMORY LOCATION CAN BE READ/Written RELIABLY (WORST CASE NOISE TESTS). IF MEMORY MANAGEMENT IS AVAILABLE, ALL TESTING IS PERFORMED WITH MEMORY MANAGEMENT ENABLED, (UNLESS DISABLED).

THIS PROGRAM MAY BE USED TO ADJUST/MARGIN MEMORY.

ALSO INCLUDED IS A TOGGLE IN ADDRESS TEST.

ALSO INCLUDED IS THE BRANCH GOBBLE MOS TEST. NOTE THAT ONLY SECTIONS 9.1 THROUGH 9.4 APPLY TO BRANCH GOBBLE.

THE PROGRAM DDQAB HAS BEEN CREATED BY MODIFYING THE

F01

TEST DDQAB-A 0-124K MEMORY EXERCISER MACY11 27(732) 10-SEP-76 10:35 PAGE 5
DDQABA.P11

DZQMB PROGRAM. THE DZQMB PROGRAM IS A 0 - 124K
MEMORY EXERCISER. BUT THE SEDM SYSTEM HAS MUCH LESS
MEMORY AND NO MOS MEMORY AND NO MEMORY MANAGEMENT OPTION.
SO, THERE ARE SOME HARMLESS EXTRA CODES (E.G. BRANCH GOBBLE
MOS MEMORY TEST) IN DDQAB PROGRAM WHICH COULD HAVE BEEN
DELETED TO CREATE AN EXCLUSIVE SEDM MEMORY EXERCISER.
PLEASE IGNORE SUCH EXTRA CODES WHILE RUNNING
A SEDM SYSTEM.

CHAPTER 1
REQUIREMENTS

1.1 EQUIPMENT

THE PDP-11 FAMILY PROCESSOR WITH 8K MEMORY.

OPTIONAL...

KT11-C OR KT11-D MEMORY MANAGEMENT OPTION OR MF11 PARITY OPTION.

1.2 STORAGE

PROGRAM STORAGE - THE PROGRAM USES MEMORY 0-17777.

1.3 PRELIMINARY PROGRAMS

IPDP-11 FAMILY INSTRUCTION EXERCISER (DCQKC OR DZQKC) KT11-C/KT11-D
LOGIC TESTS.

CHAPTER 2

LOADING AND STARTING PROCEDURE

LOAD PROGRAM INTO MEMORY USING ABS LOADER.

LOAD ADDRESS 200
SET SW12 IN DESIRED POSITION (SEE CHAPTER 3).
SET SW15=1 OR UP---IF NO TTY WITH THE SYSTEM
PRESS START.

THERE WILL BE A 5 ON THE DISPLAY LIGHTS FOR A
FEW SECONDS AFTER EACH PASS. THEN PROGRAM WILL HALT
AT LOCATION 252, IF SW6 WAS UP.
IF PROGRAM HALTS AT 252, PRESS CONTINUE.

ASTERISK "*" WILL BE PRINTED AFTER EACH PASS.
"DZQMB DONE!" WILL BE PRINTED AFTER 8 PASSES.

PASS COUNT MAY BE MONITORED IN THE DISPLAY REGISTER (11/45) OR
LOCATION 756.

NOTE

THIS PROGRAM SAVES THE LOADERS BOOT AND
ABS. TO RESTORE THE LOADERS, RESTART AT
162. BEFORE RESTARTING INSURE THAT THE
PROGRAM IS NOT RELOCATED. IF THE
PROGRAM IS RELOCATED, THE PC WILL
INDICATE WHICH BANK CONTAINS THE
PROGRAM. NEXT START THE PROGRAM AT **
12354, WHERE * = BITS 13-15 OF THE PC.
THE PROGRAM WILL RELOCATE BACK TO 0-4K
AND HALT AT 176. PRESS CONTINUE TO
RESUME TESTING.

2.1 ACT11 OPERATION

IF THE PROGRAM IS RUN IN QUICK VERIFY MODE UNDER ACT11 THE PROGRAM IS DONE AFTER THE FIRST PASS. ALSO THE PROGRAM DOES NOT RELOCATE TO TEST THE LOWER 4K OF MEMORY.

CHAPTER 3
SWITCH SETTINGS

SW15=1 OR UP	HALT ON ERROR AT LOC. 1430
SW14=1 OR UP	LOOP SUBTEST
SW13=1 OR UP	INHIBIT ERROR TYPEOUT
SW12=1 OR UP	INHIBIT USE OF MEMORY MANAGEMENT

NOTE

INHIBITING THE USE OF MEMORY MANAGEMENT CAN BE DONE ONLY WHEN THE PROGRAM IS STARTED. IF THE USE OF MEMORY MANAGEMENT IS INHIBITED THE LAST ADDRESS AS TYPED BY THE PROGRAM WILL ONLY REFLECT THE AMOUNT OF MEMORY UP TO 28K (LAST ADDRESS = 160000).

SW11=1 OR UP	INHIBIT SUBTEST ITERATION
SW10=1 OR UP	RING BELL ON ERROR

K01

TEST DDQAB-A 0-124K MEMORY EXERCISER MACY11 27(732) 10-SEP-76 10:35 PAGE 10
DDQABA.P11

PDP-11 0-124K MEMORY EXERCISER
SWITCH SETTINGS

PAGE 9

SW9=1 OR UP	DISPLAY ERROR COUNT IN DISPLAY REGISTER
SW9=0 OR DOWN	DISPLAY PASS COUNT IN DISPLAY REGISTER
SW8=1 OR UP	HALT PROGRAM UNRELOCATED AND RESTORE LOADERS
SW6=1 OR UP	HALT ON END OF PASS
SW5=1 OR UP SW1=1 OR UP	INHIBIT PARITY ERROR DETECTION (INITIAL THERE IS NO TTY WITH THE SYSTEM;SO PATCH TAGS STARTUP ONLY)

NOTE

WITH PARITY ERROR DETECTION ENABLED, A MEMORY FAILURE WILL CAUSE A PARITY ERROR. THE ERROR PRINTOUT ON A PARITY ERROR DOES NOT TYPE THE GOOD DATA. THUS, A BIT DROP OR PICKUP WILL NOT BE TYPED AS SUCH. IT IS BEST TO RUN THE PROGRAM FOR 1 PASS (UNTIL AN * IS TYPED) WITH PARITY DISABLED, THEN RESTART THE PROGRAM WITH PARITY ENABLED.

L01

TEST DDQAB-A 0-124K MEMORY EXERCISER
DDQABA.P11

MACY11 27(732) 10-SEP-76 10:35 PAGE 11

PDP-11 0-124K MEMORY EXERCISER
SUBROUTINE ABSTRACTS

PAGE 10

CHAPTER 4
SUBROUTINE ABSTRACTS

4.1 SCOPE

THE PROGRAM STORES IN R1 THE PC OF THE LAST TEST SUCCESSFULLY EXECUTED
AND MAY BE USED AS AN AID IN DEBUGGING IF THE PROGRAM 'BOMBS' BECAUSE
OF A HARDWARE FAILURE.

CHAPTER 5
ERRORS

THESE TESTS PRINT OUT THE PC WHERE THE ERROR WAS DETECTED, THE FAILING ADDRESS, THE GOOD DATA, AND THE BAD DATA I.E.

PC=XXXXXX ADDRESS AAAAAA GOOD DATA GGGGGG BAD DATA BBBBBB

THE ADDRESS OF THE FAILING LOCATION IS THE TRUE 18 BIT PHYSICAL ADDRESS.

IF SW15 WAS UP, PROGRAM WILL HALT AT LOC. 1430 ON ERROR.

NOTE

WHEN TESTING MEMORY LOCATIONS 0-17776
THE PC TYPED WILL BE A MULTIPLE OF 20000
GREATER THAN REFLECTED IN THE PROGRAM
LISTING.

THE FAILING ADDRESS (PC + 2) IS IN R1

THE ADDRESS OF THE BAD DATA IS IN (R2) -2

THE GOOD DATA IN R0

THE BAD DATA IN R3

THE ADDRESS OF GOOD DATA IS IN R4 (RANDOM DATA TEST ONLY). WHEN AN ERROR IS DETECTED WHEN EXERCISING THE MEMORY USING THE WORST CASE NOISE PATTERNS, THE USER SHOULD RESTART THE PROGRAM SELECTING PROGRAM (SEE CHAPTER 8 FOR DETAILS) SELECTING THE APPROPRIATE PARAMETERS. THE USER CAN USE THE PC AND ADDRESS OF THE FAILURE TO SELECT THE PROPER CORE BANK(S) AFFECTED AND ALSO THE SPECIFIC PATTERN. THIS ALLOWS MAXIMUM SCOPE CAPABILITIES.

NO1

TEST DDQAB-A 0-124K MEMORY EXERCISER
DDQABA.P11

MACY11 27(732) 10-SEP-76 10:35 PAGE 13

6.1 PARITY ERROR

IF THE MEMORY PARITY OPTIONS ARE INSTALLED THE PROGRAM RUNS WITH THE

PDP-11 0-124K MEMORY EXERCISER
ERRORS

PAGE 12

ACTION ENABLE BIT SET (BIT 0). IF A PARITY ERROR IS DETECTED THE PROGRAM WILL TYPE:

PARITY ERROR

AND SCAN MEMORY FOR THE ADDRESS(ES) CAUSING THE PARITY ERROR(S). WHEN THE PARITY ERROR IS DETECTED AN ERROR WILL BE TYPED AS SHOWN BELOW:

PC=XXXXXX ADDRESS AAAAAA BAD DATA BBBBBB

PRESS CONTINUE OR RESTART TO RESUME TESTING. IF A PARITY ERROR IS NOT DETECTED ON SCAN THE PROGRAM WILL TYPE:

PARITY ERROR NOT FOUND ON SCAN

PC=XXXXXX ADDRESS=AAAAAA

WHERE:

AAAAAA=PC AT TIME PARITY ERROR WAS DETECTED.

NOTE

PARITY IS DISABLED WHEN THE PROGRAM IS RELOCATED.

CHAPTER 6
RESTRICTIONS

7.1 STARTING RESTRICTION

WHEN PROGRAM IS RELOCATED, DONOT RESTART AT ADDRESS 200
OR 214.

7.2 OPERATIONAL RESTRICTION

PROGRAM CHECKS CONTIGUOUS MEMORY. IF A PARITY ERROR TRAP OCCURS WHEN
THE PROGRAM IS RELOCATED PROGRAM ACTION IS UNDEFINED. IF PARITY
MEMORY IS AVAILABLE OR SELECTED THE 3 XOR 9 TEST PATTERN IS FOR PARITY
MEMORY ONLY. DO NOT POWER FAIL THE PROGRAM WHEN THE PROGRAM IS
RUNNING IN MOS MEMORY OR RELOCATED.

CHAPTER 7
MISCELLANEOUS

IF THE PROGRAM HALTS IN THE TRAP/INTERRUPT VECTOR AREA (0-1000), EXAMINE REGISTER 6 (THE STACK PTR). R6 CONTAINS THE ADDRESS WHERE THE PC OF THE INSTRUCTION THAT CAUSED THE TRAP ABORT IS STORED. SEE ALSO R1 (R1 SPECIFIES THE LAST TEST COMPLETED).

NOTE

THE PDP11/45 WILL DISPLAY THE TRAP VECTOR ADDRESS+4 IN THE ADDRESS LIGHTS. THUS, A TRAP TO 4 (BUS ERROR) WILL DISPLAY 10 IN THE ADDRESS LIGHTS.

7.1 STACK POINTER

THE STACK POINTER IS INITIALLY SET TO 500. AND IS RESET TO THIS VALUE AT THE START OF EACH SUBTEST.

7.2 PASS COUNT

SEVEN PASSES ARE REQUIRED FOR COMPLETION OF THIS PROGRAM. AT WHICH TIME AN "*" WILL BE PRINTED. THE PASS COUNT MAY BE OBSERVED BY TURNING THE SWITCH TO THE DISPLAY POSITION. (THE PASS COUNT IS ALSO STORED IN LOCATION 1000.) THE PASS COUNT SHOULD BE MONITORED IN THE EVENT THAT THE PROGRAM ENTERS AN UNDEFINED LOOP. NOTE THAT BIT 15 OF THE DISPLAY REGISTER IS NOT PART OF THE PASS COUNT. BIT 15, IF ON, INDICATES THAT THE PROGRAM IS IN ITS RELOCATED CYCLE.

E02

TEST DDQAB-A 0-124K MEMORY EXERCISER
DDQABA.P11

MACY11 27(732) 10-SEP-76 10:35 PAGE 17

7.3 ERROR COUNT

PDP-11 0-124K MEMORY EXERCISER
MISCELLANEOUS

PAGE 15

EACH TIME AN ERROR OCCURS, THE ERROR COUNT IS INCREMENTED. THE ERROR COUNT CAN BE OBSERVED BY TURNING THE SWITCH TO THE DISPLAY POSITION AND SETTING SWITCH 9. (THE ERROR COUNT IS ALSO STORED IN LOCATION 1002.) THE PROGRAM WILL COUNT 17777(OCTAL) ERRORS; THE ERROR COUNT IS NOT INCREMENTED PAST THIS VALUE. NOTE THAT BIT 15, OF THE DISPLAY REGISTER, IS NOT PART OF THE ERROR COUNT. BIT 15, IF ON, INDICATES THAT THE PROGRAM IS IN ITS RELOCATED CYCLE.

7.4 DISPLAY REGISTER

EITHER THE PASS COUNT OR THE ERROR COUNT IS DISPLAYED IN THE DISPLAY REGISTER. THE COUNT TO BE DISPLAYED IS CONTROLLED BY THE SETTING OF SWITCH 9. BIT 15 OF THE DISPLAY REGISTER, HOWEVER, IS USED AS A RELOCATION INDICATOR AND IS NOT PART OF EITHER THE PASS COUNT OR THE ERROR COUNT. WHEN BIT 15 IS ON, THE PROGRAM IS PERFORMING A RELOCATED CYCLE. WHEN THE PROGRAM IS RELOCATED, THE SPECIAL RESTART PROCEDURES OF CHAPTER 2 MUST BE FOLLOWED.

7.5 PROGRAM RELOCATION

WHEN THE PROGRAM IS RELOCATED, VERIFICATION IS MADE THAT THE PROGRAM HAS BEEN RELOCATED CORRECTLY. IF THE PROGRAM CANNOT BE RELOCATED UPWARD, THE RELOCATED TEST PHASE IS BYPASSED. IF AN ERROR OCCURS WHILE RELOCATING THE PROGRAM BACK TO THE LOWER 4K, AN ERROR MESSAGE IS TYPED AND THE PROGRAM HALTS. CONTINUING THE PROGRAM RETRIES THE DOWNWARD RELOCATION. DOWNWARD RELOCATION WILL BE ATTEMPTED UNTIL IT IS SUCCESSFUL OR THE PROGRAM IS RELOADED.

7.6 POWER FAIL

THE PROGRAM MAY BE POWER FAILED WHEN RUNNING. WHEN THE POWER RETURNS THE PROGRAM WILL CONTINUE IN SEQUENCE.

CAUTION

PROGRAM ACTION IS UNDEFINED IF THE PROGRAM IS RELOCATED OR IN MOS MEMORY.

DO NOT TURN POWER OFF/ON UNTIL THE MESSAGE 'POWER FAILED' HAS BEEN TYPED. THIS IS BECAUSE THE STACK MAY OVERFLOW.

7.7 EXECUTION TIME

G02

TEST DDQAB-A 0-124K MEMORY EXERCISER MACY11 27(732) 10-SEP-76 10:35 PAGE 19
DDQABA.P11

EXECUTION TIME IS DEPENDENT ON TYPE OF PROCESSER, TYPE OF MEMORY, AND

H02

TEST DDQAB-A 0-124K MEMORY EXERCISER MACY11 27(732) 10-SEP-76 10:35 PAGE 20
DDQABA.P11

PDP-11 0-124K MEMORY EXERCISER
MISCELLANEOUS

PAGE 16

AMOUNT OF MEMORY. SOME REPRESENTATIVE TIMES (PER PASS) ARE:

11/05 WITH 28K MEMORY - 1 MIN.
11/45 WITH 96K MEMORY - 3 MIN.

CHAPTER 8
PROGRAM DESCRIPTION

THE PROGRAM VERIFIES EACH ADDRESS BY WRITING THE VALUE OF EACH ADDRESS INTO ITSELF STARTING AT LOCATION 20000 AND ENDING AT THE LAST LOCATION IN MEMORY. THE VALUE OF THE LAST LOCATION +2 IS TYPED ON THE TTY. NEXT THE VALUES WRITTEN ARE VERIFIED. TO COMPLETE THE ADDRESS TEST THE COMPLEMENT VALUE OF EACH MEMORY ADDRESS IS WRITTEN STARTING AT THE LAST MEMORY ADDRESS AND ENDING AT ADDRESS 20000. THE WRITTEN COMPLEMENT VALUES ARE THEN VERIFIED. THE NEXT PHASE OF TESTING INCLUDES READING, WRITING AND CHECKING MEMORY USING SEVERAL WORST CASE NOISE TEST PATTERNS (1 XOR 8, 3 XOR 9, AND 8 XOR 13). A SUBTEST IS DEDICATED TO CHECKING EACH PATTERN. THE TEST PROCEEDS BY EXERCISING EACH BANK OF MEMORY USING THE TEST PATTERNS NOTED ABOVE. NOTE THAT WITH THE MEMORY MANAGEMENT OPTION INSTALLED THAT ALL ADDRESSES ARE WRITTEN, READ AND CHECKED WITH THE MEMORY MANAGEMENT ENABLED. AFTER ALL MEMORY FROM 20000 TO THE LAST ADDRESS HAS BEEN TESTED, THE PROGRAM RELOCATES TO THE NEXT 4K MEMORY BANK AND TESTS LOCATIONS 0-17776 USING (1 XOR 8). THE PROGRAM THEN RELOCATES TO 40000 (100000 IF AVAILABLE) AND CHECKS MEMORY USING 3 XOR 9, AND 8 XOR 13 TEST PATTERN. THE PROGRAM THEN CHECKS MEMORY USING RANDOM DATA (RANTST). THIS ROUTINE MOVES THE PROGRAM CODE THROUGHOUT MEMORY STARTING AT LOCATION 20000, AND RELOCATES THE DATA BY A 32(DECIMAL) WORD OFFSET ON EACH SUBSEQUENT RELOCATION. I.E., FIRST RELOCATION IS TO 20000, NEXT IS TO 20100, THEN 20200, ETC. AFTER RELOCATION THE CODE MOVED IS CHECKED AGAINST THE ORIGINAL CODE (0-17776). WHEN THE RANDOM DATA TEST IS COMPLETE THE PROGRAM THEN SUCCESSIVELY ROTATES A '0' BIT (ROT0) AND A '1' BIT (ROT1) THROUGH ALL OF MEMORY. WHEN ALL TESTING IS COMPLETE THE PROGRAM RELOCATES TO ITS ORIGINAL POSITION, INCREMENTS THE PASS COUNT (LOCATION 1000) AND RESTARTS BEGINNING WITH THE WORST CASE NOISE TESTS. AN ASTERISK (*) WILL BE TYPED ON COMPLETION OF EACH PASS, AND WHEN 8 PASSES HAVE BEEN COMPLETED THE PROGRAM WILL TYPE 'DZQMB DONE' AND RESTART THE PROGRAM BEGINNING WITH THE MEMORY ADDRESS TESTS.

J02

8.1 PROGRAM 2 (USER SELECTIONS)

PDP-11 0-124K MEMORY EXERCISER
PROGRAM DESCRIPTION

PAGE 18

THIS PROGRAM IS PROVIDED TO ALLOW THE USER TO SPECIFY CERTAIN TEST PARAMETERS AS SHOWN BELOW:

1. ENABLE/DISABLE PARITY ERROR INTERRUPTS
2. STARTING BANK NUMBER FOR TEST
3. NUMBER OF 4K BANKS TO TEST
4. PATTERN TO BE USED

NOTE

ALL INPUTS ARE IN OCTAL.

8.1.1 STARTING PROCEDURE:

1. LOAD ADDRESS 214
2. SET SWD1=1 (UP)---ONLY IF THERE IS NO TTY

3. PRESS START

IF SWD1 WAS UP I.E., IF THERE IS NO TTY, PROGRAM WILL HALT AT LOC. 5012.
IF SO, PATCH THE FOLLOWING TAGS: (REFER TO 8.1.2)

.PARIT --- WITH 0 (DISABLE PARITY) OR 1 (ENABLE PAR.)
.STBANK --- WITH 0 OR 1 OR 2 ETC (STARTING BANK #)
.BANKS ---- WITH 1 IF THERE IS BK OR LESS OF MEMORY
.PAT --- WITH PATTERN #

4. PRESS CONTINUE (IF PROGRAM HAD HALTED BECAUSE OF SWD1 BEING UP)

8.1.2 PROGRAM 2 USER PARAMETERS

1. ENABLE PARITY? 1/0 = YES/NO. TYPE (OR PATCH .PARIT) 1 TO ENABLE INTERRUPT ON PARITY ERROR. TYPE (OR PATCH) 0 TO DISABLE INTERRUPT.
2. STARTING BANK #(8)? TYPE (OR PATCH .STBANK) THE 4K BANK WHERE YOU WISH TO BEGIN TESTING.

TYPE (OR PATCH)	TO START AT	TYPE	TO START AT
0	000000		
1	020000	20	400000
2	040000	21	420000
3	060000	22	440000
4	100000	23	460000
5	120000	24	500000
6	140000	25	520000

7	160000	26	540000
10	200000	27	560000
11	220000	30	600000
12	240000	31	620000
13	260000	32	640000
14	300000	33	660000
15	320000	34	700000
16	340000	35	720000
17	360000	36	740000

NOTE

TYPE ONLY NUMBERS SHOWN!!!

- 3. INUMBER OF 4K BANKS TO TEST (8)? TYPE (OR PATCH .BANKS) IN OCTAL THE NUMBER OF 4K BANKS TO TEST.
- 4. PATTERN #?
TYPE TO SELECT
(OR PATCH)

PDP-11 0-124K MEMORY EXERCISER
PROGRAM DESCRIPTION

PAGE 19

0	1 XOR 8 TEST PATTERN
1	3 XOR 9 TEST PATTERN
2	8 XOR 13 TEST PATTERN
3	USER CONSTANT
4	ROTATING 0
5	ROTATING 1
6	3 XOR 9 PARITY PATTERN
7	0,1,2,4,5 ABOVE

NOTE

PROGRAM WILL NOT ALLOW AN ODD NUMBER OF 4K BANKS TO BE TESTED IF PATTERN 2 OR 7 IS SELECTED. IF PATTERN #3 IS SELECTED THE PROGRAM WILL REQUEST A CONSTANT. TYPE A 6 DIGIT OCTAL NUMBER, TO ENTER A NEW CONSTANT TYPE AN 'A' AND WAIT FOR THE PROGRAM TO RESPOND. THE STARTING ADDRESS IS 214.

8.1.3 RESTARTING PROCEDURE:
IF YOU HAD SELECTED BANK 0 TO START, RESTART AT 32460 THEN AT 214. OTHERWISE, YOU WILL HAVE TO START BY RELOADING ABS. LOADER + PROGRAM.

8.1.4 PROGRAM 2 USE

PROGRAM 2 CAN BE EFFECTIVELY USED TO MAKE PROPER ADJUSTMENTS TO A SPECIFIC MEMORY BANK AND ALSO TO 'MARGIN' MEMORY. THIS IS SO BECAUSE THE PROGRAM IS NOT RUNNING IN THE MEMORY BANK(S) BEING ADJUSTED/MARGINED. THUS ALL MEMORY FROM 0-124K MAY BE ADJUSTED/MARGINED. PARITY SHOULD BE DESELECTED WHEN MAKING ANY ADJUSTMENTS PARTICULARLY WHEN TESTING THE FIRST 4K BANK(S).

8.2 PROGRAM 3

THIS PROGRAM IS THE SAME AS PROGRAM 2 WITH THE FOLLOWING EXCEPTIONS:

1. INSTEAD OF NUMBER OF 4K BANKS TO TEST, TYPE NUMBER OF 256(DECIMAL), 400(OCTAL) WORD BLOCKS TO TEST.
2. DO NOT SELECT PATTERN 2 OR 7.

THE STARTING ADDRESS IS 220.

8.3 PROGRAM 4

PROGRAM 4 CAN BE USED TO WRITE/READ USER DEFINED DATA INTO ANY SINGLE ADDRESS. THE PROGRAM WRITES THE DATA AND CHECKS IT.

THE PROGRAM WILL REQUEST AN 18 BIT ADDRESS AND IF SWITCH 0 = 0, A 16 BIT CONSTANT (DATA). IF SWITCH 0 = 1 THE PROGRAM WILL TYPE THE

PDP-11 0-124K MEMORY EXERCISER
PROGRAM DESCRIPTION

PAGE 20

CONTENTS OF SEQUENTIAL ADDRESSES UNTIL EITHER SWITCH 0 = 0 OR A NEW ADDRESS IS ENTERED.

TO ENTER A NEW ADDRESS AND CONSTANT TYPE AN 'A' AND WAIT FOR THE PROGRAM TO RESPOND.

THE STARTING ADDRESS IS 224.

8.4 PROGRAM 5

PROGRAM 5 IS A TOGGLE IN MEMORY ADDRESS TEST. THIS TEST IS USEFUL WHEN AN ADDRESS SELECTION FAILURE IS SUSPECTED INVOLVING THE FIRST 4K OF MEMORY. THIS PROGRAM WRITES THE VALUE OF EACH ADDRESS INTO ITSELF STARTING WITH THE LOWER LIMIT AND CONTINUING TO THE UPPER LIMIT. AFTER ALL ADDRESSES HAVE BEEN WRITTEN EACH ADDRESS IS CHECKED FOR THE CORRECT CONTENTS STARTING WITH THE UPPER LIMIT AND CONTINUING TO THE LOWER LIMIT.

LOCATION	CONTENTS	MNEMONIC	COMMENT
10	012700	MOV #50,R0	;GET FIRST ADDRESS
* 12	000050		;TO TEST
14	010001	MOV R0,R1	;SAVE IN R1
16	020037	15: CMP R0,3#SWR	;CHECK UPPER LIMIT
20	177570		; (IN SWITCH REGISTER)
22	001403	BEQ 25	;BRANCH IF AT UPPER LIMIT
24	010010	MOV R0,(R0)	;LOAD VALUE INTO ADDRESS
26	005720	TST (R0)+	;STEP TO NEXT ADDRESS
30	000772	BR 15	;LOOP UNTIL DONE
32	010004	25: MOV R0,R4	;SAVE UPPER LIMIT
34	020001	35: CMP R0,R1	;CHECK IF AT LOWER LIMIT
* 36	001767	BEQ 15	;BRANCH IF DONE
40	024000	CMP -(R0),R0	;CHECK DATA WRITTEN
42	001774	BEQ 35	;BRANCH IF OK
44	000000	HALT	;ERROR
46	000772	BR 35	;LOOP BACK

AFTER TOGGING THE PROGRAM LA=10 **SET UPPER LIMIT**, START.

NOTE

THE UPPER LIMIT ADDRESS OBTAINED FROM THE SWITCH REGISTER MAY BE CHANGED DURING PROGRAM OPERATION. HOWEVER, OCCASIONALLY THE PROGRAM MAY HALT BECAUSE OF 'SWITCH BOUNCE'. (THE BEST PROCEDURE WHEN CHANGING LIMITS IS TO STOP THE PROGRAM MAKE THE CHANGE AND

C03

TEST DDQAB-A 0-124K MEMORY EXERCISER
DDQABA.P11

MACY11 27(732) 10-SEP-76 10:35 PAGE 28

CONTINUE.) THE LOWER LIMIT ADDRESS (12)
MAY BE PATCHED TO ANY DESIRED ADDRESS.

PDP-11 0-124K MEMORY EXERCISER
PROGRAM DESCRIPTION

PAGE 21

8.5 PROGRAM 6

PROGRAM 6 IS ALSO A TOGGLE IN PROGRAM TO BE USED WITH PROGRAM 5 FOR MORE COMPLETE ADDRESS TESTING. THIS PROGRAM WRITES THE COMPLEMENT VALUE OF EACH ADDRESS INTO ITSELF STARTING WITH THE UPPER LIMIT AND CONTINUING TO THE LOWER LIMIT. AFTER ALL ADDRESSES HAVE BEEN WRITTEN EACH ADDRESS IS CHECKED FOR THE CORRECT CONTENTS STARTING WITH THE LOWER LIMIT ADDRESS AND CONTINUING TO THE UPPER LIMIT. TOGGLE IN THE FOLLOWING PATCHES TO PROGRAM 5 ABOVE.

LOCATION	CONTENTS	MNEMONIC	COMMENT
12	100		:CHANGE LOWER LIMIT
36	001404	BEG 4\$:BRANCH TO PROGRAM 6
50	010402	4\$: MOV R4,R2	:GET UPPER LIMIT
52	005142	5\$: COM -(R2)	:COMPLEMENT ADDRESS
54	020201	CMP R2,R1	:CHECK IF AT LOWER LIMIT
56	001375	BNE 5\$:LOOP UNTIL DONE
60	020204	6\$: CMP R2,R4	:CHECK IF AT UPPER LIMIT
62	001755	BEG 1\$:GO TO PROGRAM 5 IF DONE
64	010203	MOV R2,R3	:GET VALUE OF ADDRESS
66	005103	COM R3	:COMPLEMENT VALUE
70	020322	CMP R3,(R2)+	:CHECK ADDRESS
72	001772	BEG 6\$:BRANCH IF OK
74	000000	HALT	:ERROR
76	000770	BR 6\$:GO CHECK NEXT ADDRESS

CHAPTER 9
BRANCH GOBBLE MOS TEST

9.1 ABSTRACT

THE BRANCHGOBBLE PROGRAM IS USED TO TEST MOS MEMORY. CONTIGUOUS LOCATIONS ARE TESTED BETWEEN TWO LIMITS IN A MINIMUM BK, MAXIMUM 124K MEMORY MACHINE. IF PARITY IS AVAILABLE IT IS ENABLED.

9.2 OPERATING PROCEDURE

1. LOADING: LOAD THE DZQMBG PROGRAM INTO MEMORY USING THE ABSOLUTE LOADERS.
2. STARTING: LOAD ADDRESS 270 AND PRESS THE START BUTTON.
3. THE PROGRAM WILL FIRST IDENTIFY ITSELF ON TTY:

BRANCH GOBBLE

4. THEN THE ABSOLUTE LOADER WILL BE SAVED.
5. A CHECK WILL BE MADE FOR PARITY REGISTERS. IF NONE ARE FOUND THE MESSAGE:

NO PARITY

WILL BE TYPED TO THE USER. IF PARITY IS FOUND IT IS TURNED ON, AND THE MESSAGE,

PARITY ENABLED

WILL BE TYPED TO THE USER. THIS WILL BE FOLLOWED BY A LIST OF THE UNIBUS ADDRESSES OF THE PARITY REGISTERS FOUND AND ENABLED.

F03

TEST DDQAB-A 0-124K MEMORY EXERCISER
DDQABA.P11

MACY11 27(732) 10-SEP-76 10:35 PAGE 31

6. THE USER WILL THEN BE ASKED IF HE WANTS THE PENDING TEST TO

POP-11 0-124K MEMORY EXERCISER
BRANCH GOBBLE MOS TEST

PAGE 23

BE RUN USING MEMORY MANAGEMENT.

USE KT11? (Y OR N)

>

IF THE USER TYPES Y THEN MEMORY MANAGEMENT WILL BE USED DURING THE PENDING TEST. IF HE TYPES N, THEN MEMORY MANAGEMENT WILL NOT BE USED. TYPING ANYTHING ELSE OTHER THAN Y OR N WILL CAUSE THE QUESTION TO BE REPEATED.

7. THE USER WILL THEN BE ASKED TO GIVE THE LIMITS OF THE TEST SPAN:

HIGH LIMIT?

>

AND:

LOW LIMIT?

>

RESTRICTIONS ON THE USER'S RESPONSE ARE:

- A. THE NUMBERS MUST BE VALID (18-BIT) 6-DIGIT OCTAL ADDRESSES, REAL NOT VIRTUAL.
- B. THE NUMBERS SHOULD BE MULTIPLES OF 100 (OCTAL).
- C. THE HIGH LIMIT MUST BE GREATER THAN THE LOW LIMIT.
- D. IF MEMORY MANAGEMENT IS NOT USED, HIGH LIMIT MUST BE LESS THAN OR EQUAL TO 160000.
- E. HIGH LIMIT CAN BE 1 + THE HIGHEST REAL CORE ADDRESS. FOR EXAMPLE, IN AN 8K MACHINE, HIGH LIMIT CAN EQUAL 40000.

VIOLATIONS TO THESE RESTRICTIONS WILL BE DEALT WITH IN THIS WAY:

- A. A QUESTION MARK AND THE PROMPT WILL BE ISSUED:

?

>

THE USER IS THEN EXPECTED TO INPUT THAT LIMIT AGAIN; THIS TIME CORRECTLY.

- B. WHAT EVER THE LAST TWO OCTAL DIGITS OF THE NUMBER WHICH THE USER TYPED THEY WILL BE ASSEMBLED AS ZEROES.
- C. THE USER WILL BE ASKED FOR OTHER LIMITS BY REPEATING THIS STEP (7). BEFORE STEP (7) IS REPEATED

H03

TEST DDQAB-A 0-124K MEMORY EXERCISER
DDQABA.P11

MACY11 27(732) 10-SEP-76 10:35 PAGE 33

NOT VALID!

PDP-11 0-124K MEMORY EXERCISER
BRANCH GOBBLE MOS TEST

PAGE 24

WILL BE TYPED.

- D. SAME AS 3.
8. THE TEST STARTS. THE TEST WILL LOOP INDEFINITELY BETWEEN THE TWO LIMITS UNLESS THE USER HALTS THE PROGRAM OR AN ERROR IS ENCOUNTERED. AN ASTERISK IS TYPED AT THE BEGINNING OF EACH PASS MODE.
 9. TO STOP THE TEST RUNNING AND START ANOTHER HIT THE HALT SWITCH AND RETURN STEP 2. ANY TEST BUT THE FIRST WILL NOT INCLUDE STEP 4.
 10. TO STOP THE TEST AND RESTORE THE LOADER, HIT THE HALT SWITCH, LOAD ADDRESS 162 AND START. WHEN THE LOADER IS RESTORED THE PROGRAM WILL HALT AT LOCATION 200.
 11. TO STOP THE TEST AND START THE 0-124K MEMORY TEST HIT THE HALT SWITCH, LOAD ADDRESS 200, AND START.
 12. DATA LIGHTS. THE DATA LIGHTS WILL DISPLAY THE CURRENT LOCATION BEING TESTED DURING A BRANCH GOBBLE TEST. WHEN A MOS MEMORY FAILURE OCCURS THESE LIGHTS WILL CONTAIN VIRTUAL (16-BIT) ADDRESS "NEAR" THE FAILURE.

9.3 ERRORS

1. ERRORS IN OPERATING THE PROGRAM ARE DESCRIBED IN OPERATING PROCEDURE 9.2.
2. IF A PARITY ERROR IS DETECTED THE USER IS TOLD THE PC+2 AT THE TIME OF THE ERROR:

PARITY ERROR
PC=XXXXXX

THEN THE SCAN IS MADE THROUGH ALL OF MEMORY TO TRY TO FORCE THE ERROR TO ARISE AGAIN. IF IT IS NOT FOUND THE MESSAGE

SCAN COMPLETE

IS TYPED AND THE TEST IS RESTARTED.

IF THE ERROR IS DETECTED ON THE SCAN THEN THE USER IS GIVEN THE ADDRESS OF THE LOCATION CAUSING THE PARITY ERROR AND THE CONTENTS OF THAT LOCATION:

XXXXXX HAD BAD DATA XXXXXX

IF MEMORY MANAGEMENT WAS OFF DURING THE SCAN FOR THE ERROR

J03

TEST DDGAB-A 0-124K MEMORY EXERCISER MACY11 27(732) 10-SEP-76 10:35 PAGE 35
DDGABA.P11

THE ADDRESS GIVEN FOR THE ERROR IS REAL AND:

PDP-11 0-124K MEMORY EXERCISER
BRANCH GOBBLE MOS TEST

PAGE 25

KT11 OFF

IS TYPED.

IF MEMORY MANAGEMENT WAS ON DURING THE SCAN:

KT11 ON PAR=XXXXXX

IS TYPED, WHERE THE PAR (PAGE ADDRESS REGISTER) GIVEN IS THAT PAR WHICH SHOULD BE USED IN RELOCATING THE VIRTUAL ADDRESS GIVEN FOR THE ERROR ONTO A REAL CORE ADDRESS. THE METHOD FOR THIS RELOCATION IS GIVEN IN THE NOTE BELOW.

AFTER ANY PARITY IS ENCOUNTERED AND THE USER NOTIFIED, THE TEST WILL BE RESTARTED.

3. WHENEVER THE BRANCH GOBBLE TEST BRINGS OUT AN ERROR IN MOS MEMORY IT MAY SURFACE AS A PARITY AND BE HANDLED AS DESCRIBED ABOVE. OTHERWISE THE ADDRESS (VIRTUAL IF MEMORY MANAGEMENT IS ON) IN THE DATA LIGHTS WILL DESIGNATE THE VICINITY OF THE ERROR. IF MEMORY MANAGEMENT IS ON, RELOCATE THE ADDRESS IN THE DATA LIGHTS IN THE MANNER DESCRIBED IN THE NOTE BELOW.

NOTE

TO COMPUTE THE REAL ADDRESS OF AN ADDRESS RELOCATED BY MEMORY MANAGEMENT, ADD THE LOW ORDER 13-BITS OF THE VIRTUAL ADDRESS TO THE CORRESPONDING PAR SHIFTED, 6 BITS TO THE LEFT:

VIRTUAL ADDRESS = 0 00X XXX XXX XXX XXX

PAR = YYY YYY YYY YYY 000 000

REAL ADDRESS = ZZZ ZZZ ZZZ ZZZ ZZZ ZZZ

TO DETERMINE WHICH PAR TO USE REMEMBER THAT ON KERNEL SPACE IS USED IN ANY TEST HERE. TAKE THE HIGH ORDER 3-BITS OF THE VIRTUAL ADDRESS AND USE THEM TO DESIGNATE THE KIPAR TO USE. FOR INSTANCE, IF THE VIRTUAL ADDRESS IS 031676 USE KIPAR1 BECAUSE THE UPPER 3 BITS OF THE VIRTUAL ADDRESS ARE 001=1.

4. IF AN ERROR CONDITION ARISES, EITHER AS A PARITY ERROR OR ONE NOT APPARENT SUCH AS THE PROGRAM HALTS OR IT IS CLEAR FROM THE ADDRESS AND DISPLAY LIGHTS THAT THE PROGRAM IS NOT RUNNING ITS NORMAL COURSE, THE USER CAN ENTER CONSOLE MODE AND EXAMINE THE CONTENTS OF THE MEMORY LOCATIONS STARTING AT THE

L03

TEST DDQAB-A 0-124K MEMORY EXERCISER MACY11 27(732) 10-SEP-76 10:35 PAGE 37
DDQABA.P11

ADDRESS IN THE DISPLAY REGISTER. THE CONTENTS OF THESE
LOCATIONS SHOULD BE COMPARED TO THE CONTENTS (IN THE

PDP-11 0-124K MEMORY EXERCISER
BRANCH GOBBLE MOS TEST

PAGE 26

LISTINGS) OF LOCATIONS 15226 THROUGH 15304 (WITH THE EXCEPTIONS: 15232 IS UNDETERMINABLE AND 15304 SHOULD CONTAIN EITHER 15370 OR 35370). IN THIS WAY THE USER SHOULD BE ABLE TO DETERMINE WHICH BITS WERE LOST IN WHAT WORDS.

9.4 PROGRAM DESCRIPTION

THIS VERSION OF THE BRANCH GOBBLE TEST IS TAKEN ALMOST DIRECTLY FROM THE DZQKA-A INSTRUCTION EXERCISER WHICH CONTAINED THE ORIGINAL BRANCH GOBBLE. WHAT HAS BEEN DONE HERE IS TO GIVE THAT TEST AN INTERFACE TO THE USER AND MEMORY MANAGEMENT FACILITIES. THESE ADDITIONS HAVE BEEN DONE IN A WAY WHICH ALLOWS THE TEST TO RUN AS IT DID IN ITS ORIGINAL FORM. DATA IS COLLECTED FROM THE USER AND IF MEMORY MANAGEMENT IS NEEDED IT IS SET UP AND THAT TEST IS ALLOWED TO RUN BETWEEN THE DESIGNATED LIMITS.

1197
1198
1199
1200
1201
1202
1203
1204
1205
1206
1207
1208
1209
1210
1211
1212
1213
1214
1215
1216
1217
1218
1219
1220
1221
1222
1223
1224
1225
1226
1227
1228

```
.NLIST MD,MC
.LIST ME
.ABS
.MCALL STYPE
.TITLE TEST DDQAB-A 0-124K MEMORY EXERCISER
.SBTTL STARTING INST & DEFINITIONS
;COPYRIGHT 1973 DIGITAL EQUIPMENT CORP., MAYNARD, MASS.
;THIS TEST CHECKS THAT ALL MEMORY ADDRESSES ARE UNIQUE USING ADDRESS TESTS
;AND CHECKS DATA RELIABILITY OF MEMORY USING WORST CASE NOISE TEST PATTERNS
;A RANDOM # PATTERN (PROGRAM CODE RELOCATED), A ROTATING 0 AND ROTATING
;1 PATTERN.
;ALSO INCLUDED ARE USER TESTS WHICH CAN BE USED TO TEST SPECIFIED SEG-
;MENTS OF MEMORY USING THE PATTERNS MENTIONED ABOVE. ADDITIONALLY A
;28 WORD TOGGLE IN PROGRAM IS DOCUMENTED (SEC 9.5 OF THE DOCUMENT) WHICH
;CAN BE USED IF AN ADDRESSING MALFUNCTION IS SUSPECTED INVOLVING THE FIRST
;4K OF MEMORY.
;A MOS MEMORY TEST HAS BEEN ADDED, THE BRANCH GOBBLE ROUTINE.
;THE PROGRAM MAY BE POWER FAILED WHEN RUNNING. THE PROGRAM WILL PRINT
;A MESSAGE (POWER FAILED) AND CONTINUE IN SEQUENCE WHEN THE POWER COMES
;BACK UP. **CAUTION** DO NOT POWER FAIL THE PROGRAM IF THE PROGRAM IS IN
;MOS MEMORY OR IF THE PROGRAM IS RELOCATED.
;LOADING AND STARING INSTRUCTIONS
;LOAD ADDRESS 200 AND START
;NOTE: PROGRAM WILL RUN WORST CASE TEST PATTERNS IN LOWEST 4K
;THUS THE PROGRAM CANNOT BE RESTARTED AT 200 IF RELOCATED. TO PREVENT
;RELOCATION FROM OCCURING DEPOSIT 200 INTO LOCATION 42 (NOT NECESSARY
;IF LOADED VIA ACT11). THIS ACTION WILL PREVENT RELOCATION AND ALSO
;INHIBIT TESTING MEMORY IN LOWEST 4K.
;THIS PROGRAM ALSO RELOCATES THE ABS AND BOOT LOADERS TO ALLOW TESTING
```

1229
 1230
 1231
 1232
 1233
 1234
 1235
 1236
 1237
 1238
 1239
 1240
 1241
 1242
 1243
 1244
 1245
 1246
 1247
 1248
 1249
 1250
 1251
 1252
 1253
 1254
 1255
 1256
 1257
 1258
 1259
 1260
 1261
 1262
 1263
 1264
 1265
 1266
 1267
 1268
 1269
 1270
 1271
 1272
 1273
 1274
 1275
 1276
 1277
 1278
 1279
 1280
 1281
 1282
 1283
 1284

000000
 000001
 000002
 000003
 000004
 000005
 000006
 000007
 000000
 000001
 000002
 000003
 000004
 000005
 000001
 000002
 000003
 000004
 000005
 000001
 000002
 000004
 000010
 000020
 000340
 000200
 000000
 040000
 140000
 000000
 010000
 030000
 004000
 000004
 000010
 000014
 000014
 000014
 000014
 000020
 000024
 000030
 000034
 000060
 000064
 000240
 000244
 000250
 177776

; OF MEMORY, TO RESTORE THE LOADERS RESTART AT 162.
 ; STACK POINTER IS SET AT 500
 ; AN ASTERISK '*' WILL BE PRINTED ON COMPLETION OF EACH PASS, AND
 ; THE PROGRAM NAME WILL BE PRINTED WHEN TEST IS COMPLETE.

;GENERAL REGISTER ASSIGNMENTS

RO=%0
 R1=%1
 R2=%2
 R3=%3
 R4=%4
 R5=%5
 SP=%6
 PC=%7
 R10=%0
 R11=%1
 R12=%2
 R13=%3
 R14=%4
 R15=%5

;STATUS REGISTER (PSW) BIT ASSIGNMENTS

C=1 ; C BIT
 V=2 ; V BIT
 Z=4 ; Z BIT
 N=10 ; N BIT
 T=20 ; 'T' BIT
 PRTY7=340 ; PRIORITY LEVEL 7
 PRTY4=200 ; PRIORITY LEVEL 4
 KM=000000 ; KERNEL MODE
 SM=040000 ; SUPERVISORY MODE
 UM=140000 ; USER MODE
 PKM=000000 ; PREVIOUS KERNEL MODE
 PSM=010000 ; PREVIOUS SUPERVISORY MODE
 PUM=030000 ; PREVIOUS USER MODE
 REG=004000 ; SELECT R10-R15

;VECTOR ADDRESSES

ERRVEC=4 ; ADDRESS OF ERROR VECTOR
 RESVEC=10 ; ADDRESS OF RESERVED INST. TRAP VECTOR
 TBITVEC=14 ; ADDRESS OF 'T' BIT TRAP VECTOR
 TRTVEC=14 ; ADDRESS OF 'TRACE' TRAP VECTOR
 BPTVEC=14 ; ADDRESS OF 'BREAKPOINT' TRAP VECTOR
 IOTVEC=20 ; ADDRESS OF IOT TRAP VECTOR
 PFVEC=24 ; ADDRESS OF POWER FAIL TRAP VECTOR
 EMTVEC=30 ; ADDRESS OF EMT VECTOR
 TRAPVEC=34 ; ADDRESS OF TRAP VECTOR
 TKVEC=60 ; ADDRESS OF TTY KEYBOARD INTERRUPT VECTOR
 TPVEC=64 ; ADDRESS OF TTY PRINTER INTERRUPT VECTOR
 PIRVEC=240 ; ADDRESS OF PIRQ VECTOR
 FPEVEC=244 ; ADDRESS OF FLOATING POINT INT. VECTOR
 MMVEC=250 ; ADDRESS OF MEM MGMT ERROR TRAP VECTOR

;REGISTER ADDRESSES

PSW=177776 ; ADDRESS OF STATUS REGISTER


```

1295      177774      SLR=177774      ;ADDRESS OF STACK LIMIT REGISTER
1296      177772      PIRQ=177772     ;ADDRESS OF PROGRAM INTERRUPT REQUEST
1297      177770      UBREAK=177770   ;ADDRESS OF MICRO BREAK REGISTER
1298      177560      TKS=177560     ;ADDRESS OF KEYBOARD CSR
1299      177562      TKB=177562     ;ADDRESS OF KEYBOARD BUFFER
1290      177564      TPS=177564     ;ADDRESS OF TELEPRINTER CSR
1291      177566      TPB=177566     ;ADDRESS OF TELEPRINTER BUFFER
1292      177570      SWR=177570     ;ADDRESS OF CONSOL SWITCH REGISTER
1293      177570      DISPLAY=177570  ;ADDRESS OF CONSOL DISPLAY REGISTER
1294
1295      ;INITIAL STACK POINTER SETTING
1296      000500      STKPTR=500
1297
1298      ;MISCELLANEOUS BIT ASSIGNMENTS
1299      000100      BIT15= 100
1300      040000      BIT14= 040000
1301      020000      BIT13= 020000
1302      010000      BIT12= 010000
1303      001000      BIT9= 001000
1304      000400      BIT8= 000400
1305      000100      BIT6= 000100
1306
1307      000001      SW00=000001
1308      000002      SW01=000002
1309      000100      SW06=000100
1310      ;MEMORY MANAGEMENT REGISTER ADDRESS ASSIGNMENTS
1311      177572      SR0=177572     ;ADDRESS OF MEM MGMT REGISTER SR0
1312      177574      SR1=177574     ;" " " " " " SR1
1313      177576      SR2=177576     ;" " " " " " SR2
1314      172516      SR3=172516     ;ADDRESS OF MEM MGMT REGISTER SR3
1315
1316      172300      KIPDR0=172300   ;ADDRESS OF KERNEL 'I' PAGE
1317      172302      KIPDR1=172302   ;DESCRIPTOR REGISTERS
1318      172304      KIPDR2=172304
1319      172306      KIPDR3=172306
1320      172310      KIPDR4=172310
1321      172312      KIPDR5=172312
1322      172314      KIPDR6=172314
1323      172316      KIPDR7=172316
1324
1325      172340      KIPAR0=172340   ;ADDRESSES OD KERNEL 'I' SPACE
1326      172342      KIPAR1=172342   ;PAGE ADRESS REGISTERS
1327      172344      KIPAR2=172344
1328      172346      KIPAR3=172346
1329      172350      KIPAR4=172350
1330      172352      KIPAR5=172352
1331      172354      KIPAR6=172354
1332      172356      KIPAR7=172356
1333
1334
1335      ;INSTRUCTION EQUATES
1336      104400      HLT=TRAP
1337      104000      SCOPE=EMT      ;SCOPE IS AN EMT TRAP
1338
1339      ;MISC. EQUATES
1340      000006      RW=6          ;R/W BIT IN PDR REGISTERS

```

```

1341      000000
1342
1343
1344
1345
1346
1347
1348
1349
1350
1351
1352
1353
1354
1355
1356
1357      000000
1358      000000 000000
1359      000002 000000
1360
1361      000004 001116
1362      000006 000002
1363
1364      000034 001174
1365      000036 000340
1366
1367      000046 004654
1368
1369      000052 040000
1370
1371      000250
1372      000250 000000
1373
1374
1375
1376      000252 000207
1377
1378      000120
1379      000120 000000
1380      000122 000000
1381
1382
1383
1384
1385
1386
1387
1388
1389
1390
1391
1392
1393      000124 005737 000120
1394      000130 100401
1395      000132 000207
1396      000134 011557 017762
  
```

```

UP=0 ;UP BIT IN PDR REGISTERS

.=0
.WORD 0 ;SPECIAL TRAP/INTERRUPT CATCHER IF PRO-
.WORD 0 ;GRAM HALTS AT 0 THEN ADDRESS WAS NOT
;LOADED PROPERLY FROM VECTOR.

.WORD ERRTRP
.WORD RTI
.=TRAPVEC
.WORD ERROR
.WORD PRTY7
.=46
.WORD LOGICAL
.=52
.WORD BIT14

.=250
EOPHLT: HALT ;THIS IS AN END OF PASS HALT;
;NOT AN ERROR HALT. YOU GET HERE ONLY
;IF SW06 IS UP. PRESS CONTINUE TO
;RESUME THE PROGRAM.

RTS PC

.=120
RELFL: .WORD 0
SAVPC2: .WORD 0
;THE SUBROUTINE WHERE IS CALLED BEFORE ANY TEST IS RUN TO SEE
;IF BRANCH GOBBLE RELOCATED THE ENTIRE FIRST FOUR K OF CORE INTO
;THE SECOND FOR K AND DIDN'T RELOCATE EVERYTHING BACK. IF THIS IS
;THE CASE THE WHERE WILL PUT THE PROGRAM BACK INTO THE FIRST FOUR K
;AND RETURN TO THE BEGINNING OF THE TEST THE USER DESIGNATED
;BY LOADING HIS STARTING ADDRESS. NOTE THAT THIS ROUTINE WILL NOT
;RELOCATE THE PROGRAM IF IT HAS BEEN MOVED BY ANY OTHER SUBPROGRAM
;EXCEPT THE BRANCH BOBBLE PROGRAM. THE RELOCATION OF THE PROGRAM
;TO THE FIRST FOUR K IS INACTED BY THE USER IN THE SAME WAY IT WAS
;IN THE DZOMBF AND DZOMBE VERSIONS OF THE 0-124 TEST, IF IT HAS BEEN
;RELOCATED BY THE PART OF THIS TEST WHICH WAS TAKEN FROM DDQAB, THAT
;IS ALL THIS PROGRAM EXCEPT BRANCH GOBBLE.
WHERE: TST 2#120
BMI 1$
RTS PC
1$: MOV (SP),SAVPC2+20000
  
```

```

1397 000140 004567 026204      JSR      R5,RELOC+20000
1398 000144 020000              .WORD   20000
1399 000146 000000              .WORD   0
1400 000150 016716 177746      MOV      SAVPC2,(SP)
1401 000154 005037 000120      CLR      @#120
1402 000160 000207              RTS      PC
1403
1404 ;
1405 000162 012706 000500      PONE:   MOV      .=162
1406 000166 004767 177732              JSR      #500,SP ;STARTING ADDRESS TO RELOCATE LOADERS.
1407 000172 004767 001732              JSR      PC,WHERE
1408 000176 000000              JSR      PC,$RLDR
1409 000200 012706 000500      PTWO:   MOV      HALT
1410 000204 004767 177714              MOV      #500,SP ;STARTING ADDRESS OF 0-124K MEMORY EXERCISER.
1411 000210 000137 002304              JSR      PC,WHERE
1412 000214 012706 000500      PTHREE: JMP      @#START ;GO TO START OF TEST
1413 000220 004767 177700              MOV      #500,SP ;STARTING ADDRESS OF PROGRAM #2.
1414 000224 000137 004670              JSR      PC,WHERE
1415 000230 012706 000500      PFOUR:  JMP      @#PRG2 ;GO START PROGRAM #2
1416 000234 004767 177664              MOV      #500,SP ;STARTING ADRESS OF PROGRAM #3.
1417 000240 000137 006010              JSR      PC,WHERE
1418 000250 000250              JMP      @#PRG3 ;GO START PROGRAM #3
1419 000250 000000              .=250
1420 000252 000000              .WORD   0 ;MEMORY MANAGEMENT TRAP VECTOR.
1421 000254 012706 000500      PFIVE:  .WORD   0
1422 000260 004767 177640              MOV      #500,SP ;START ADDRESS OF PROGRAM #4.
1423 000264 000137 006042              JSR      PC,WHERE
1424 000270 012706 000500      PSIX:   JMP      @#PRG4
1425 000274 004767 177624              MOV      #500,SP ;STARTING ADDRESS OF BRANCH GOBBLE MOS TEST.
1426 000300 000167 012236              JSR      PC,WHERE
1427 ;
1428 ;
1429 ;ROUTINE TO SAVE REGISTERS ON THE STACK
1430 ;CALLED BY SAVE MACRO OR JSR PC,$SAVR
1431 000304 012667 000016      $SAVR: MOV      (SP)+,1$ ;SAVE RETURN PC
1432 000310 010546              MOV      %5,-(SP)
1433 000312 010446              MOV      %4,-(SP)
1434 000314 010346              MOV      %3,-(SP)
1435 000316 010246              MOV      %2,-(SP)
1436 000320 010146              MOV      %1,-(SP)
1437 000322 010046              MOV      %0,-(SP)
1438 000324 012707              MOV      (PC)+,PC ;RETURN
1439 000326 000000      1$:    0 ;CONTAINS RETURN ADDRESS
1440 ;
1441 ;ROUTINE TO RESTORE REGISTERS SAVED ON THE STACK
1442 ;CALLED BY RESTORE MACRO OR JSR PC,$RESTR
1443 000330 012667 000016      $RESTR: MOV      (SP)+,1$ ;SAVE RETURN PC
1444 000334 012600              MOV      (SP)+,%0
1445 000336 012601              MOV      (SP)+,%1
1446 000340 012602              MOV      (SP)+,%2
1447 000342 012603              MOV      (SP)+,%3
1448 000344 012604              MOV      (SP)+,%4
1449 000346 012605              MOV      (SP)+,%5
1450 000350 012707              MOV      (PC)+,PC ;RETURN
1451 000352 000000      1$:    0 ;CONTAINS RETURN ADDRESS
1452

```

```

1453          .SBTTL POWER FAIL ROUTINE
1454          =502
1455          ;POWER FAIL ROUTINE
1456          ;THE POWER DOWN ROUTINE SAVES THE KEYBOARD STATUS,THE GENERAL REGISTERS
1457          ;:(R0-R5) AND MEM MGMT REGISTERS (KIPDR0-KIPDR7,KIPAR0-KIPAR7,SR2,SRO)
1458          ;ON THE STACK AND SAVES THE STACK POINTER IN PFSTK BELOW.
1459 000502 013746 177560 PDWN: MOV    J#TKS,-(SP)    ;SAVE KEYBOARD STATUS
1460 000506 004767 177572 JSR    PC,$SAVR        ;GO SAVE REGISTERS ON THE STACK
1461 000512 005737 000752 TST    J#MMAVA        ;CHECK IF MEM MGMT IS AVAILABLE
1462 000516 001417 BEQ    3$             ;BRANCH IF NOT AVAILABLE
1463 000520 013746 177572 MOV    J#SRO,-(SP)    ;SAVE SRO
1464 000524 013746 177576 MOV    J#SR2,-(SP)    ;SAVE SR2
1465 000530 012700 172300 MOV    #KIPDR0,R0     ;GET ADDRESS OF KIPDR0
1466 000534 012702 000010 MOV    #8,R2
1467 000540 010203 MOV    R2,R3
1468 000542 012046 1$:  MOV    (R0)+,-(SP)    ;SAVE KIPDR0-KIPDR7
1469 000544 077202 SOB    R2,1$
1470 000546 012700 172340 MOV    #KIPAR0,R0     ;GET ADDRESS OF KIPAR0
1471 000552 012046 2$:  MOV    (R0)+,-(SP)    ;SAVE KIPAR0-KIPAR7
1472 000554 077302 SOB    R3,2$
1473 000556 010627 3$:  MOV    SP,(PC)+      ;SAVE STACK PTR IN FOLLOWING LOCATION
1474 000560 000000 PFSTK: .WORD 0        ;CONTAINS STACK PTR AFTER POWER FAIL
1475 000562 012737 000572 000024 MOV    #PUP,J#PFVEC   ;SET POWER FAIL VECTOR TO PUP ROUTINE
1476 000570 000000 HALT
1477
1478          ;POWER UP ROUTINE.
1479 000572 000240 PUP:  NOP
1480 000574 013706 000560 MOV    J#PFSTK,SP     ;SET STACK PTR
1481 000600 005767 000146 TST    MMAVA         ;CHECK IF MEM MGMT IS AVAILABLE
1482 000604 001417 BEQ    4$
1483 000606 012700 172360 MOV    #KIPAR7+2,R0   ;GET ADDRESS OF KIPAR7+2
1484 000612 012702 000010 MOV    #8,R2
1485 000616 010203 MOV    R2,R3
1486 000620 012640 1$:  MOV    (SP)+,-(R0)    ;RESTORE KIPAR7-KIPAR0
1487 000622 077302 SOB    R3,1$
1488 000624 012700 172320 MOV    #KIPDR7+2,R0   ;GET ADDRESS OF KIPDR7+2
1489 000630 012640 2$:  MOV    (SP)+,-(R0)    ;RESTORE KIPDR7-KIPDR0
1490 000632 077202 SOB    R2,2$
1491 000634 012637 177576 MOV    (SP)+,J#SR2    ;RESTORE SR2
1492 000640 012637 177572 MOV    (SP)+,J#SRO    ;RESTORE SRO
1493 000644 005767 006246 4$:  TST    PARAVA        ;CHECK IF PARITY REGISTERS ARE ENABLED
1494 000650 001402 BEQ    5$             ;BRANCH IF NOT
1495 000652 004767 006170 JSR    PC,.$MAMF      ;GO ENABLE PARITY REGISTERS
1496 000656 5$:
1497 000656 004767 177446 JSR    PC,$RESTR      ;RESTORE REGISTERS FROM STACK
1498 000662 012637 177560 MOV    (SP)+,J#TKS
1499 000666 012737 000502 000024 MOV    #PDWN,J#PFVEC ;SET POWER FAIL TRAP TO PDWN ROUTINE
1500 000674 005027 CLR    (PC)+
1501 000676 000000 10$: .WORD 0
1502 000700 005267 177772 11$: INC    10$
1503 000704 100375 BPL    11$
1504 000706 004567 000046 JSR    R5,$PRINT     ;GO TO PRINT ROUTINE
1505 000712 000720 PWRFAIL
1506 000714 000240 6$:  NOP
1507 000716 000002 RTI
1508

```

```

1509 000720 005015 047520 042527 PWRFAIL:.ASCIZ <15><12>'POWER FAILED'<15><12>
1510 000726 020122 040506 046111
1511 000734 042105 005015 000
1512
1513
1514 .SBTTL TAGS & PRINT ROUTINE
1515 000742 000000 ICNT: .EVEN
1516 000744 000000 ICOUNT: .WORD 0 ;CONTAINS PASS COUNT
1517 000746 000000 ERCNT: 0 ;CONTAINS ITERATION PATTERN
1518 000750 000000 LDDISP: 0 ;CONTAINS ERROR COUNT
1519 000752 000000 MMAVA: 0 ;CONTAINS DISPLAY REGISTER IMAGE
1520 ;MEM MGMT AVAILABLE INDICATOR
1521 000754 000000 RELOCF: .WORD 0 ;0=NOT AVAIL,-1=AVAIL
1522 000756 000000 COUNT: .WORD 0 ;CONTAINS RELOCATION FACTOR
1523 ;TEMPORARY WORKING LOCATION
1524 ;ROUTINE TO PASS MESSAGE ADDRESS TO TYPE ROUTINE BELOW
1525 ;CALL: JSR R5,$PRINT
1526 ; MESSAGE ADDRESS
1527 000760 000240 $PRINT: NOP
1528 000762 012567 000016 MOV (R5)+,1$ ;GET MESSAGE ADDRESS
1529 000766 066767 177762 000010 ADD RELOCF,1$ ;ADD RELOCATION FACTOR
1530 000774 013746 177776 MOV #PSW,-(SP) ;PUSH PSW ON THE STACK
1531 001000 004767 000014 JSR PC,.TYPE ;CALL TYPE ROUTINE
1532 001004 000000 1$: .WORD 0 ;CONTAINS MESSAGE ADDRESS
1533 001006 000205 RTS R5 ;RETURN
1534
1535 ;ROUTINE TO TYPE ASCII MESSAGE. MESSAGE MUST TERMINATE WITH A 0 BYTE.
1536 ;THE ROUTINE WILL INSERT A NUMBER OF NULL CHARACTERS AFTER A LINE FEED.
1537 ;CALL: TYPE
1538 ; MESADR ;MESADR IS FIRST ADDRESS OF ASCIZ STRING
1539
1540 ;TAGS USED BY THE TYPE ROUTINE BELOW
1541 001010 000 $NULL: .BYTE 0 ;CONTAINS NULL CHARACTER
1542 001011 002 $FILL: .BYTE 2 ;CONTAINS # OF FILLER CHARACTERS
1543 001012 000 $TPFLG: .BYTE 0 ;CONTAINS TELEPRINTER AVAILABLE FLAG
1544 ;0/377 = AVAIL/NOT AVAIL
1545 001013 000 $TKFLG: .BYTE 0 ;CONTAINS KEYBOARD AVAILABLE FLAG
1546 001014 177564 $TPS: .WORD 177564 ;ADDRESS OF TELEPRINTER STATUS REGISTER
1547 001016 177566 $TPB: .WORD 177566 ;ADDRESS OF TELEPRINTER DATA BUFFER
1548 001020 010046 .TYPE: MOV R0,-(SP) ;SAVE R0
1549 001022 017600 000002 MOV #2(SP),R0 ;GET MESSAGE ADDRESS
1550 001026 062766 000002 000002 ADD #2,2(SP) ;ADJUST RETURN PC
1551
1552 001034 112046 1$: MOV (R0)+,-(SP) ;PUSH CHARACTER TO BE TYPED ONTO STACK
1553 001036 001003 BNE 2$ ;BRANCH IF NOT THE TERMINATOR
1554 001040 005726 TST (SP)+ ;POP TERMINATOR CHAR OFF THE STACK
1555 001042 012600 MOV (SP)+,R0 ;RESTORE R0
1556 001044 000002 RTI ;RETURN TO CALLER
1557
1558 001046 004767 000026 2$: JSR PC,5$ ;TYPE CHARACTER
1559 001052 122726 000012 3$: CMPB #12,(SP)+ ;CHECK IF CHARACTER WAS A LINE FEED
1560 001056 001366 BNE 1$ ;BRANCH IF NOT LINE FEED
1561 001060 016746 177724 MOV $NULL,-(SP) ;GET # OF FILLERS REQUIRED AND FILLER
1562 ;CHARACTER.
1563
1564 001064 105366 000001 4$: DECB 1(SP) ;DECREMENT FILLERS REQ. COUNT

```

```

1565 001070 002770          BLT      3$          ;BRANCH IF NO MORE FILLERS ARE REQUIRED
1566 001072 004767 000002   JSR      PC,5$      ;TYPE FILLER CHARACTER
1567 001076 000772          BR       4$
1568
1569 001100 105777 177710   5$:     TSTB      2$TSPS      ;WAIT FOR OUTPUT DEVICE
1570 001104 100375          BPL      -4
1571 001106 116677 000002 177702   MOVB     2(SP),2$TPB    ;OUTPUT CHARACTER
1572 001114 000207          RTS      PC
1573
1574          ;XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX
1575          ;ERROR TRAP SERVICE ROUTINE
1576 001116 005737 177570   ERRTRP: TST      2$SWR      ;CHECK IF HALT ON ERROR
1577 001122 100001          BPL      +4          ;BRANCH IF NO HALT ON ERROR
1578 001124 000000          HALT
1579 001126 005727          TST      (PC)+        ;CHECK IF PREV TRAP TO 4 REPORTED
1580 001130 000000   1$:     .WORD     0          ;CONTAINS ERROR REPORTED FLAG
1581 001132 001013          BNE      2$          ;BRANCH IF NOT REPORTED
1582 001134 010667 177770   MOV      SP,1$
1583 001140 011602          MOV      (SP),R2      ;GET PC OFF STACK
1584 001142 004767 000352   JSR      PC,$FORMO    ;GO TO FORMAT ROUTINE
1585 001146 004567 177606   JSR      R5,$SPRINT   ;GO TO PRINT ROUTINE
1586 001152 001446          TRAP4
1587 001154 004567 177600   JSR      R5,$SPRINT   ;GO TO PRINT ROUTINE
1588 001160 002271          DIGITS
1589 001162 000000   2$:     HALT          ;ERROR! SECOND TRAP TO 4 OCCURRED
1590          ;BEFORE FIRST WAS PRINTED
1591 001164 005067 177740   CLR      1$
1592 001170 000137 000200   JMP      2$200        ;RESTART AT 200
1593
1594          .SBTTL  ERROR SERVICE ROUTINE
1595          ;ERROR SERVICE CALLED BY JSR PC,ERROR INSTRUCTION
1596          ;OR HLT (A TRAP INST)
1597 001174 000240          ERROR: NOP
1598 001176 022767 017777 177542   CMP      #17777,ERCNT ;CHECK FOR MAX ERROR CNT
1599 001204 001403          BEQ      4$
1600 001206 062767 000001 177532   ADD      #1,ERCNT     ;INCREMENT ERROR COUNT
1601 001214 032737 001000 177570   4$:     BIT      #BIT9,2$SWR ;SWITCH 9 UP?
1602 001222 001411          BEQ      5$
1603 001224 042767 017777 177516   BIC      #17777,LDDISP ;SAVE RELOCATION BITS
1604 001232 056767 177510 177510   BIS      ERCNT,LDDISP ;LOAD ERROR COUNT
1605 001240 016737 177504 177570   MOV      LDDISP,2$DISPLAY ;LOAD DISPLAY REGISTER
1606 001246 004767 177032   5$:     JSR      PC,$SAVR      ;SAVE REGISTERS ON THE STACK
1607 001252 016602 000014          MOV      14(SP),R2    ;GET PC OF ERROR CALL
1608 001256 010201          MOV      R2,R1
1609 001260 162701 000002          SUB      #2,R1
1610 001264 032737 020000 177570   BIT      #20000,2$SWR ;PRINT OUT DESIRED?
1611 001272 001044          BNE      1$          ;BRANCH IF NO PRINTOUT
1612 001274 004767 000220          JSR      PC,$FORMO    ;GO TO FORMAT ROUTINE
1613 001300 004567 177454          JSR      R5,$SPRINT   ;GO TO PRINT ROUTINE
1614 001304 001463          ERRPC
1615 001306 004567 177446          JSR      R5,$SPRINT   ;GO TO PRINT ROUTINE
1616 001312 002271          DIGITS
1617 001314 016602 000004          MOV      4(SP),R2    ;GET FAILING ADDRESS (IN R2)
1618 001320 004767 000174          JSR      PC,$FORMO    ;GO TO FORMAT ROUTINE
1619 001324 004567 177430          JSR      R5,$SPRINT   ;GO TO PRINT ROUTINE
1620 001330 002247          ADRESS

```

1621	001332	105767	005265			TSTB	PENFLG		;BRANCH IF PARITY ERROR DETECTED
1622	001336	001017				BNE	11\$;BUT NOT FOUND
1623	001340	105767	005256			TSTB	PEFLG		;BRANCH IF PARITY ERROR DETECTED
1624	001344	001006				BNE	10\$;BUT FOUND
1625	001346	004567	177406			JSR	R5,\$SPRINT		;GO TO PRINT ROUTINE
1626	001352	001467				XMTDAT			
1627	001354	010046				MOV	RO,-(SP)		;PUSH VALUE TO TYPED ONTO STACK
1628	001356	004767	000360			JSR	PC,02A		;GO PRINT VALUE
1629	001362				10\$:				
1630	001362	004567	177372			JSR	R5,\$SPRINT		;GO TO PRINT ROUTINE
1631	001366	001502				RECDAT			
1632	001370	010346				MOV	R3,-(SP)		;PUSH VALUE TO BE TYPED ONTO STACK
1633	001372	004767	000344			JSR	PC,02A		
1634	001376				11\$:				
1635	001376	004567	177356			JSR	R5,\$SPRINT		;GO TO PRINT ROUTINE
1636	001402	015122				\$CRLF			
1637	001404	032737	002000	177570	1\$:	BIT	#2000,2\$SWR		;RING BELL ON ERROR
1638	001412	001403				BEQ	2\$		
1639	001414	004567	177340			JSR	R5,\$SPRINT		;GO TO PRINT ROUTINE
1640	001420	001515				BELL			
1641	001422	005737	177570		2\$:	TST	2\$SWR		;HALT AFTER PRINT OUT
1642	001426	100001				BPL	+.4		
1643	001430	000000				HALT			
1644	001432	004767	176672			JSR	PC,\$RESTR		;RESTORE REGISTERS FROM STACK
1645	001436	010042			3\$:	MOV	RO,-(R2)		;RESTORE CORRECT DATA TO ADDRESS
1646	001440	062702	000002			ADD	#2,R2		
1647	001444	000002				RTI			
1648									
1649	001446	051124	050101	042520	TRAP4:	.ASCII	'TRAPPED TO 4'		
1650	001454	020104	047524	032040					
1651	001462	040							
1652	001463	120	036503	000	ERRPC:	.ASCIZ	'PC='		
1653	001467	107	047517	020104	XMTDAT:	.ASCIZ	'GOOD DATA='		
1654	001474	040504	040524	000075					
1655	001502	041040	042101	042040	RECDAT:	.ASCIZ	'BAD DATA='		
1656	001510	052101	036501	000					
1657	001515	007	000		BELL:	.ASCIZ	<7>		
1658		001520				.EVEN			
1659									;ROUTINE TO PLACE ASCII VALUE OF AN ADDRESS IN TO ADDRESS MESSAGE
1660	001520	066767	177230	000014	\$FORMO:	ADD	RELOC,11\$+2		
1661	001526	066767	177222	000134		ADD	RELOC,41\$+2		
1662	001534	004767	176544			JSR	PC,\$SAVR		;GO SAVE REGISTERS ON THE STACK
1663	001540	012704	002271		11\$:	MOV	#DIGITS,R4		;ADDRESS WHERE ASCII VALUES ARE STORED
1664	001544	005003				CLR	R3		;WORKING & INDEX REGISTER
1665	001546	162702	000002			SUB	#2,R2		;ADJUST ADDRESS
1666	001552	010205				MOV	R2,R5		;SAVE
1667	001554	010501				MOV	R5,R1		
1668	001556	005767	177170			TST	MMAVA		;CHECK IF MEM MGMT IS AVAILABLE
1669	001562	001426				BEQ	1\$;BRANCH IF NOT AVAILABLE
1670	001564	032737	000001	177572		BIT	#1,2\$SRO		;IS MEM MGMT ENABLED
1671	001572	001422				BEQ	1\$		
1672	001574	042701	017777			BIC	#17777,R1		;SAVE PAR SELECTOR BITS
1673	001600	000301				SWAB	R1		;SWAP BYTES
1674	001602	006001				ROR	R1		
1675	001604	006001				ROR	R1		;FORM INDEX VALUE
1676	001606	006001				ROR	R1		

```

1677 001610 006001          ROR      R1
1678 001612 017102 001722  MOV     @PARTAB(1),R2 ;GET CONTENTS OF PAR
1679 001616 012700 000006  MOV     #6,R0        ;SHIFT COUNT
1680 001622 006302          ASL     R2            ;SHIFT KIPAR1 6 PLACES LEFT
1681 001624 006103          ROL     R3            ;2 MSB'S GO INTO R3
1682 001626 077003          SOB     R0,-4
1683 001630 042705 160000  BIC     #160000,R5    ;CLEAR PAR SELECTOR BITS
1684 001634 060502          ADD     R5,R2        ;FORM 18 BIT ADDRESS
1685 001636 005503          ADC     R3            ;IN R2 & R3
1686 001640 006302 1$:    ASL     R2            ;FIRST DIGIT TO R3
1687 001642 006103          ROL     R3
1688 001644 012700 000006  MOV     #6,R0        ;DIGIT COUNT
1689 001650 000404          BR     3$           ;PRINT FIRST DIGIT
1690 001652 006302 2$:    ASL     R2
1691 001654 006103          ROL     R3
1692 001656 005305          DEC     R5
1693 001660 001374          BNE     2$
1694 001662 012705 000003 3$:    MOV     #3,R5
1695 001666 116324 002232 41$:   MOVVB  DIGTAB(3),(4)+ ;LOAD DIGIT INTO MESSAGE
1696 001672 005003          CLR     R3            ;CLEAR INDEX
1697 001674 005300          DEC     R0            ;DEC DIGIT COUNT
1698 001676 001365          BNE     2$
1699 001700 004767 176424  JSR     PC,$RESTR    ;RESTORE REGISTERS FROM STACK
1700 001704 046767 177044 177630  BIC     RELOCF,11$+2
1701 001712 046767 177036 177750  BIC     RELOCF,41$+2
1702 001720 000207          RTS     PC            ;RETURN
1703
1704 001722 172340          PARTAB: KIPAR0
1705 001724 172342          KIPAR1
1706 001726 172344          KIPAR2
1707 001730 172346          KIPAR3
1708 001732 172350          KIPAR4
1709 001734 172352          KIPAR5
1710 001736 172354          KIPAR6
1711 001740 172356          KIPAR7
1712
1713          ;ROUTINE TO TYPE OCTAL VALUE PUSHED ONTO STACK
1714          ;CALL: MOV     VALUE,-(SP) ;PUSH VALUE ONTO STACK
1715          ;      JSR     PC,02A     ;CALL ROUTINE
1716 001742
1717 001742 004767 176336 02A:   JSR     PC,$SAVR    ;GO SAVE REGISTERS ON THE STACK
1718 001746 016600 000016  MOV     16(SP),R0   ;GET VALUE
1719 001752 012703 000006  MOV     #6,R3        ;COUNTER
1720 001756 005002          CLR     R2            ;WORKING REGISTER
1721 001760 006100          ROL     R0
1722 001762 006102          ROL     R2
1723 001764 062702 000260 1$:    ADD     #260,R2     ;FORM ASCII VALUE
1724 001770 010267 000040  MOV     R2,2$        ;MOVE CHAR TO TYPE LOCATION
1725 001774 004567 176760  JSR     R5,$PRINT   ;GO TO PRINT ROUTINE
1726 002000 002034          2$
1727 002002 005002          CLR     R2
1728 002004 006100          ROL     R0
1729 002006 006102          ROL     R2
1730 002010 006100          ROL     R0
1731 002012 006102          ROL     R2
1732 002014 006100          ROL     R0

```



```

1733 002016 006102          ROL      R2
1734 002020 005303          DEC      R3
1735 002022 001360          BNE     1$
1736 002024 004767 176300  JSR     PC,$RESTR ;RESTORE REGISTERS FROM STACK
1737 002030 012616          MOV     (SP)+,(SP)
1738 002032 000207          RTS     PC
1739 002034 000000 2$:      .WORD 0 ;CONTAINS CHARACTER TO BE TYPED
1740
1741 002036 000000  LODFLO: .WORD 0
1742          :ROUTINE TO SAVE ABS LOADER
1743 002040 005767 177772  $LDR:   TST     LODFLO
1744 002044 001401          BEQ     3$
1745 002046 000207          RTS     PC
1746 002050 012700 017776 3$:      MOV     #17776,R0
1747 002054 012737 002066 000004  MOV     #2$,$ERRVEC ;SET TIME OUT TRAP VECTOR
1748 002062 005720          TST     (R0)+
1749 002064 000776          BR      -2
1750 002066 022626 2$:      CMP     (SP)+,(SP)+
1751 002070 162700 002202          SUB     #2202,R0 ;POINT R0 BACK TO LOADER
1752 002074 010067 000102          MOV     R0,$LDR1 ;SAVE FOR RESTORE ROUTINE
1753 002100 012702 001100          MOV     #1100,R2 ;WORD COUNT
1754 002104 012703 015556          MOV     #LODAR,R3 ;WHERE LOADER IS TO BE STORED
1755 002110 012023 1$:      MOV     (R0)+,(R3)+ ;STORE LOADER
1756 002112 005302          DEC     R2
1757 002114 001375          BNE     1$
1758 002116 014367 000042          MOV     -(R3),LSTLOC ;SAVE LAST WORD OF LOADERS
1759 002122 005367 177710          DEC     LODFLO
1760 002126 000207          RTS     PC ;RETURN
1761
1762          :ROUTINE TO RESTORE LOADER
1763 002130 005767 177702  $RLDR:  TST     LODFLO
1764 002134 001001          BNE     2$
1765 002136 000207          RTS     PC
1766 002140 016705 000036 2$:      MOV     $LDR1,R5 ;GET FIRST ADDRESS OF WHERE LOADER IS
1767          ;TO BE RESTORED
1768 002144 012704 015556          MOV     #LODAR,R4 ;ADDRESS WHERE LOADER IS STORED
1769 002150 012702 001100          MOV     #1100,R2 ;WORD COUNT
1770 002154 012425 1$:      MOV     (R4)+,(R5)+ ;RESTORE
1771 002156 005302          DEC     R2
1772 002160 001375          BNE     1$
1773 002162 012745          MOV     (PC)+,-(R5) ;RESTORE LAST LOCATION (SAVED BY SAVE
1774 002164 000000  LSTLOC: .WORD 0 ;LOADERS ROUTINE ABOVE)
1775 002166 004567 176566          JSR     R5,$PRINT ;GO TO PRINT ROUTINE
1776 002172 002204          $LDRM  CLR     LODFLO
1777 002174 005067 177636          CLR     LODFLO
1778 002200 000207          RTS     PC ;RETURN TO CALLER
1779
1780 002202 000000  $LDR1:  .WORD 0 ;FIRST ADDRESS WHERE LOADERS ARE TO BE
1781          ;RESTORED TO
1782 002204 047514 042101 051105  $LDRM:  .ASCIZ 'LOADER IS RESTORED'<15><12>
1783 002212 044440 020123 042522
1784 002220 052123 051117 042105
1785 002226 005015 000
1786          .EVEN
1787          :DIGIT TABLE
1788 002232 030460  DIGTAB: "01

```

K04

TEST DDQAB-A 0-124K MEMORY EXERCISER
DDQABA.P11 ERROR SERVICE ROUTINE

MACY11 27(732) 10-SEP-76 10:35 PAGE 49

1789	002234	031462				"23
1790	002236	032464				"45
1791	002240	033466				"67
1792						
1793						:MESSAGES
1794	002242	040514	052123	040	LST:	.ASCII 'LAST '
1795	002247	115	046505	051117	ADRESS:	.ASCII 'MEMORY ADDRESS IS '
1796	002254	020131	042101	051104		
1797	002262	051505	020123	051511		
1798	002270	040				
1799	002271	060	030060	030060	DIGITS:	.ASCIZ '000000 '
1800	002276	020060	000			
1801		002302				.EVEN

1802
1803 002302 000000

PLACE: .WORD 0
.SBTTL MEMORY ADDRESS TESTS

1804
1805
1806
1807
1808
1809
1810
1811

: THIS TEST ADDRESS MEMORY UP TO 128K AND PROVES 'UNIQUENESS' OF ALL
: MEMORY ADDRESS IN A 32K SEGMENT. THE TEST WRITES INTO EACH MEMORY
: ADDRESS THE VALUE OF THAT ADDRESS AND THEN CHECKS FOR THE CORRECT
: DATA IN EACH ADDRESS.
: THE TWELVE MOST SIGNIFICANT BITS OF THE LAST AVAILABLE MEMORY ADDRESS
: IS STORED IN R5.

1812
1813
1814
1815
1816
1817

: STARTING INSTRUCTIONS
: LOAD ADDRESS=200
: PRESS START
: STACK POINTER IS AT 500
: *****RESTART AT 162 TO RESTORE LOADER*****
: MEMORY ADDRESS TEST

1818 002304 012737 002346 000212
1819 002312 012706 000500
1820 002316 004767 177516
1821 002322 004567 176432
1822 002326 012054
1823 002330 005037 000746
1824 002334 005037 000750
1825 002340 013737 000750 177570
1826 002346 012706 000500
1827 002352 005037 006622
1828 002356 012727 002346
1829 002362 000000
1830 002364 005037 000742
1831 002370 005037 000754
1832 002374 012737 000502 000024
1833 002402 005037 000026

START: MOV #START1, @#212 ; CHANGE START ADDRESS
MOV #STKPTR, SP ; SET UP STACK PTR
JSR PC, \$LDR ; GO SAVE MONITOR & LOADERS
JSR R5, \$PRINT ; GO TO PRINT ROUTINE
RESLDR
CLR @#ERCNT ; CLEAR ERROR COUNT
CLR @#LDDISP ; CLEAR DISPLAY REGISTER STORAGE LOCN
MOV @#LDDISP, @#DISPLAY ; CLEAR DISPLAY REGISTER
START1: MOV #STKPTR, SP ; SET STACK PTR
CLR @#PEFLG ; CLEAR PARITY ERROR INDICATORS
MOV #START1, (PC)+ ; LOAD PARITY ERROR RESTART ADDRESS
PERSTRT: .WORD 0 ; CONTAINS RESTART ADDRESS AFTER PAR ERR
CLR @#ICNT ; CLEAR PASS COUNT
CLR @#RELOCF ; CLEAR RELOCATION FACTOR
MOV #PDWN, @#PFVEC ; SET POWER FAIL TRAP VECTOR
CLR @#PFVEC+2

1834
1835
1836 002406 005067 176340
1837 002412 032737 010000 177570
1838 002420 001007
1839 002422 012737 002440 000004
1840 002430 005037 177572
1841 002434 005167 176312
1842 002440 004767 004402

; CHECK IF MEMORY MANAGEMENT IS AVAILABLE
CLR MMAVA ; CLEAR MEM MGMT AVAILABLE INDICATOR
BIT #BIT12, @#SWR ; CHECK IF TO RUN WITH MEM MGMT
BNE IS ; DO NOT USE MEM MGMT IF SW12 WAS SET
MOV #IS, @#ERRVEC ; SET TIME OUT TRAP
CLR @#SRO ; REFERENCE MEM MGMT
COM MMAVA ; SET INDICATOR TO -1 IF AVAILABLE
IS: JSR PC, .MAMF ; GO ENABLE PARITY ACTION

1843
1844
1845

: ROUTINE TO WRITE VALUE OF MEMORY ADDRESS INTO MEMORY ADDRESS
: FOR EXAMPLE ROUTINE WRITES 20000 INTO LOCATION 20000

1846
1847 002444 012737 002504 000004
1848 002452 010701
1849 002454 004767 004466
1850 002460 012737 007244 000250
1851 002466 012702 020000
1852 002472 010203
1853 002474 010322
1854 002476 062703 000002
1855 002502 000774

WRTUP: MOV #DONE0, @#ERRVEC ; SET TIME OUT TRAP VECTOR
MOV PC, R1 ; LOAD TRACE REGISTER
JSR PC, LDMMO
MOV #MMABTO, @#MMVEC ; SET MEM MGMT ABORT VECTOR
MOV #20000, R2 ; FIRST ADDRESS
MOV R2, R3 ; LOAD CONSTANT
MOV R3, (R2)+ ; WRITE VALUE OF ADDRESS INTO ADDRESS
ADD #2, R3 ; NEXT VALUE
BR -.6 ; WRITE UNTIL DONE

1856
1857 002504 012706 000500

DONE0: MOV #STKPTR, SP ; SET STACK PTR

```

1858 002510 004767 177004      JSR    PC,$FORMD      ;GO TO FORMAT ROUTINE
1859 002514 004567 176240      JSR    R5,$SPRINT     ;GO TO PRINT ROUTINE
1860 002520 002242                LST
1861 002522 004567 176232      JSR    R5,$SPRINT     ;GO TO PRINT ROUTINE
1862 002526 015122                $CRLF
1863
1864                               ;ROUTINE TO CHECK THAT VALUE OF MEMORY ADDRESS WAS WRITTEN CORRECTLY
1865 002530 010701                MOV    PC,R1          ;LOAD TRACE REGISTER
1866 002532 012702 020000        MOV    #20000,R2      ;SET R2
1867 002536 012737 002574 000004  MOV    #DONE1,@#ERRVEC ;SET TIME OUT TRAP
1868 002544 010200                MOV    R2,R0
1869 002546 162700 000002        SUB    #2,R0          ;SUBTRACT 2
1870 002552 004767 004370        JSR    PC,LDMMO
1871 002556 062700 000002        1$:   ADD    #2,R0
1872 002562 012203                MOV    (R2)+,R3      ;GET WRITTEN VALUE
1873 002564 020003                CMP    R0,R3         ;CHECK
1874 002566 001773                BEQ    1$
1875 002570 104400                HLT
1876                               ;ERROR! TO DETERMINE WHICH ADDRESS WAS
1877                               ;WRITTEN IMPROPERLY EXAMINE R2. NEXT EXAMINE MEM MGMT REGISTER KIPAR1
1878                               ;(IF MEM MGMT IS AVAILABLE). ADD R2 AND KIPAR1 TOGETHER AS SHOWN BELOW
1879
1880                               ;
1881                               ;
1882                               ;
1883                               ;
1884                               ;
1885                               ;
1886                               ;
1887                               ;
1888                               ;
1889                               ;
1890 002602 005767 176144        TST    MMAVA          ;MEMORY MAGNAGEMENT AVAILABLE?
1891 002606 001420                BEQ    3$
1892 002610 013703 172342        MOV    @#KIPAR1,R3   ;FIND LAST ADDRESS IF MEM MANAGE USED
1893 002614 006303                ASL    R3
1894 002616 006303                ASL    R3
1895 002620 006303                ASL    R3
1896 002622 006303                ASL    R3
1897 002624 006303                ASL    R3
1898 002626 006303                ASL    R3
1899 002630 010246                MOV    R2,-(SP)      ;DEVELOP COMPLEMENT OF LAST ADDRESS
1900 002632 042716 020000        BIC    #20000,(SP)   ;SAVE BITS IF MEMORY IS NOT A MULTIPLE OF 4K
1901 002636 062603                ADD    (SP)+,R3
1902 002640 012737 007276 000250  MOV    #MMABT1,@#MMVEC ;SET ABORT VECTOR
1903 002646 000403                BR    2$
1904 002650 162702 000002        3$:   SUB    #2,R2          ;R2=LAST ADDRESS
1905 002654 010203                MOV    R2,R3
1906 002656 005103                2$:   COM    R3          ;COMPLEMENT VALUE IN R3
1907 002660 062703 000002        1$:   ADD    #2,R3
1908 002664 010342                MOV    %3,-(R2)     ;WRITE COMPLIMENT VALUE INTO ADDRESS
1909 002666 102403                BVS    DONE3
1910 002670 020227 017776        CMP    R2,#17776
1911 002674 001371                BNE    1$
1912
1913                               ;SET UP TO CHECK COMPLEMENT DATA WRITTEN DOWN

```

```

1914 002676 000240
1915 002700 010701
1916 002702 005767 176044
1917 002706 001406
1918 002710 012737 000200 172342
1919 002716 012737 007244 000250
1920 002724 012737 002764 000004 1$:
1921 002732 012702 020000
1922 002736 010200
1923 002740 005100
1924 002742 062700 000002
1925 002746 162700 000002 2$:
1926 002752 012203
1927 002754 020003
1928 002756 001773
1929 002760 104400
1930 002762 000771
1931 002764 000240
1932
1933
1934 002766 012737 003034 000004 ;ROUTINE TO WRITE BANK # INTO ALL ADDRESSES IN A 4K BANK
1935 002774 010701
1936 002776 004767 004144
1937 003002 012737 007244 000250
1938 003010 012702 020000
1939 003014 005000
1940 003016 005200 1$:
1941 003020 012704 010000
1942 003024 010022 2$:
1943 003026 005304
1944 003030 001375
1945 003032 000771
1946
1947 003034 022626 DONE4A:
1948
1949 ;CHECK THAT DATA WRITTEN ABOVE CAN BE READ
1950 003036 012737 003104 000004
1951 003044 010701
1952 003046 004767 004074
1953 003052 012702 020000
1954 003056 005000
1955 003060 005200 1$:
1956 003062 012704 010000
1957 003066 012203 2$:
1958 003070 020003
1959 003072 001401
1960 003074 104400
1961 003076 005304
1962 003100 001372
1963 003102 000766
1964 003104 022626 DONE4B:
1965
1966 ;ROUTINE TO WRITE CONSTANT DATA INTO 4K
1967 ;BANK STARTING WITH LAST MEMORY LOCATION
1968 003106 010701
1969 003110 012737 007276 000250

```

```

DONE3: NOP
MOV PC,R1 ;LOAD TRACE REGISTER
TST MMAVA ;CHECK IF MM IS AVAIL
BEQ 1$
MOV #200,2#KIPARI ;INIT KIPARI
MOV #MMABTO,2#MMVEC ;SET ABORT VECTOR
1$: MOV #DONE4,2#ERRVEC
MOV #20000,R2 ;FIRST ADDRESS
MOV R2,R0 ;FIRST DATA (COM OF ADDRESS)
COM R0
ADD #2,R0
2$: SUB #2,R0
MOV (R2)+,R3 ;GET VALUE
CMP R0,R3 ;CHECK
BEQ 2$
HLT
BR 2$
DONE4: NOP
;ROUTINE TO WRITE BANK # INTO ALL ADDRESSES IN A 4K BANK
MOV #DONE4A,2#ERRVEC;SET TIME OUT TRAP VECTOR
MOV PC,R1
JSR PC,LDMMO
MOV #MMABTO,2#MMVEC
MOV #20000,R2
CLR R0
1$: INC R0 ;R0 WILL BE DATA WRITTEN
MOV #4096,R4 ;SET 4K COUNTER
2$: MOV R0,(R2)+ ;WRITE BANK # INTO ALL ADDRESSES
DEC R4
BNE 2$
BR 1$
DONE4A: CMP (SP)+,(SP)+ ;ADJUST STACK PTR
;CHECK THAT DATA WRITTEN ABOVE CAN BE READ
MOV #DONE4B,2#ERRVEC
MOV PC,R1
JSR PC,LDMMO
MOV #20000,R2
CLR R0
1$: INC R0
MOV #4096,R4
2$: MOV (R2)+,R3
CMP R0,R3
BEQ .+4
HLT
DEC R4
BNE 2$
BR 1$
DONE4B: CMP (SP)+,(SP)+
;ROUTINE TO WRITE CONSTANT DATA INTO 4K
;BANK STARTING WITH LAST MEMORY LOCATION
MOV PC,R1
MOV #MMABT1,2#MMVEC

```

1970	003116	162702	000002			SUB	#2,R2	
1971	003122	005000				CLR	RO	
1972	003124	005300			1\$:	DEC	RO	
1973	003126	012704	010000			MOV	#4096.,R4	
1974	003132	010042			2\$:	MOV	RO,-(R2)	
1975	003134	102406				BVS	DONE4C	
1976	003136	020227	017776			CMP	R2,#17776	;CHECK IF DONE
1977	003142	001403				BEQ	DONE4C	
1978	003144	005304				DEC	R4	
1979	003146	001371				BNE	2\$	
1980	003150	000765				BR	1\$	
1981								
1982	003152	012737	003246	000004		DONE4C: MOV	#DNE4D,#ERRVEC	
1983	003160	010701				MOV	PC,R1	
1984	003162	004767	003760			JSR	PC,LDMO	
1985	003166	012737	007244	000250		MOV	#MMABTO,#MMVEC	;SET ABORT VECTOR
1986	003174	012702	020000			MOV	#20000,R2	
1987	003200	022704	010000		1\$:	CMP	#4096.,R4	;CHECK IF WRITE ABOVE STARTED ON ;4K BOUNDARY
1988								
1989	003204	001406				BEQ	2\$	
1990	003206	012203				MOV	(R2)+,R3	
1991	003210	020003				CMP	RO,R3	
1992	003212	001401				BEQ	+.4	
1993	003214	104400				HLT		
1994	003216	005204				INC	R4	
1995	003220	001367				BNE	1\$	
1996	003222	005200			2\$:	INC	RO	
1997	003224	012704	010000			MOV	#4096.,R4	
1998	003230	012203			3\$:	MOV	(R2)+,R3	
1999	003232	020003				CMP	RO,R3	
2000	003234	001401				BEQ	+.4	
2001	003236	104400				HLT		
2002	003240	005304				DEC	R4	
2003	003242	001372				BNE	3\$	
2004	003244	000766				BR	2\$	
2005								
2006	003246	022626				DONE4D: CMP	(SP)+,(SP)+	
2007	003250	005737	000042			TST	#42	;BRANCH IF PROGRAM WAS NOT ;LOADED VIA ACT11 IN QV OR RA MODES
2008	003254	001406				BEQ	BEGIN1	;BRANCH IF NOT IN QV MODE
2009	003256	005767	001374			TST	LOGICAL+2	
2010	003262	100003				BPL	BEGIN1	
2011	003264	012737	000006	000742		MOV	#6,#ICNT	;SET ICNT TO DO 1 PASS ONLY IN QV
2012								

```

2013
2014
2015
2016
2017
2018 003272 012706 000500
2019 003276 004767 003544
2020 003302 004767 006444
2021 003306 012737 003330 000004
2022
2023
2024 003314 010701
2025 003316 012746 000001
2026 003322 005046
2027 003324 004767 004162
2028
2029
2030 003330 012737 001116 000004
2031 003336 012706 000500
2032 003342 010701
2033 003344 012746 000001
2034 003350 005403
2035 003352 010346
2036 003354 004767 004244
2037
2038 003360 005027
2039 003362 000000
2040
2041
2042
2043
2044
2045
2046 003364 012706 000500
2047 003370 010701
2048 003372 012737 003412 000004
2049 003400 012746 000001
2050 003404 005046
2051 003406 004767 004446
2052
2053
2054 003412 012737 001116 000004
2055 003420 016600 000006
2056 003424 005400
2057 003426 010027
2058 003430 000000
2059 003432 012706 000500
2060 003436 010701
2061 003440 012746 000001
2062 003444 010046
2063 003446 004767 004626
2064
2065
2066 003452 005737 007116
2067 003456 001406
2068 003460 005737 003362

```

.SBTTL WORST CASE NOISE TESTS

```

; THIS TEST WRITES MEMORY WORST CASE NOISE TEST PATTERNS THROUGHOUT
; MEMORY AND CHECKS THAT THEY CAN BE WRITTEN AND READ.
; SET UP TRAP VECTORS
BEGIN1: MOV #STKPTR, SP ; SET STACK PTR
        JSR PC, .MAMF ; GO ENABLE PARITY ACTION
        JSR PC, CKSWR ; GO CHECK SWITCHES
        MOV #DONES, @ERRVEC ; SET UP TIME OUT TRAP

; WRITE 1 XOR 8 TEST PATTERN STARTING AT ADDRESS 20000
        MOV PC, R1 ; UPDATE TRACE REGISTER
        MOV #1, -(SP) ; PUSH STARTING BANK # ON THE STACK
        CLR -(SP) ; PUSH # OF 128. WORD BLOCKS TO WRITE
        JSR PC, .1XB ; GO TO ROUTINE TO WRITE 1 XOR 8 PATTERN

; CHECK 1 XOR 8 TEST PATTERN WRITTEN ABOVE
DONES: MOV #ERRTRP, @ERRVEC
15: MOV #STKPTR, SP ; SET STACK PTR
     MOV PC, R1 ; UPDATE TRACE REGISTER
     MOV #1, -(SP) ; PUSH STARTING BANK # ON THE STACK
     NEG R3 ; R3 CONTAINS # OF 128. WORD BLOCKS
     MOV R3, -(SP) ; WRITTEN BY .1XB ROUTINE ABOVE
     JSR PC, .1XB ; GO CHECK 1XB PATTERN

        CLR (PC)+ ; SET INDICATOR TO WRITE NORMAL 3X9 PAT
PARPAT: .WORD 0

; WRITE 3 XOR 9 TEST PATTERN STARTING AT ADDRESS 20000
; NOTE PATTERN IS NORMAL 3 XOR 9 IF NO PARITY MEMORY IS AVAILABLE,
; AND IS A MODIFIED PATTERN IF PARITY MEMORY IS AVAILABLE.
; THE CONTENTS OF PARPAT IF 0/NOT 0 INDICATE IF NORMAL/MODIFIED PATTERN
; IS BEING USED IN TESTS BELOW.
DONE6: MOV #STKPTR, SP ; SET STACK PTR
        MOV PC, R1 ; UPDATE TRACE REGISTER
        MOV #DONES7, @ERRVEC ; SET TIME OUT TRAP VECTOR
        MOV #1, -(SP) ; PUSH STARTING BANK # ON STACK
        CLR -(SP) ; PUSH # OF 256. WORD BLOCKS TO WRITE
        JSR PC, .3X9 ; CALL ROUTINE TO WRITE 3XOR9 PATTERN

; CHECK 3 XOR 9 TEST PATTERN WRITTEN ABOVE
DONE7: MOV #ERRTRP, @ERRVEC
        MOV 6(SP), R0 ; GET # OF 256. WORD BLOCKS WRITTEN
        NEG R0 ; FORM TWO'S COMPLEMENT
        MOV R0, (PC)+ ; SAVE # OF 256 WORD BLOCKS
WDS.256: .WORD 0 ; CONTAINS # OF 256 WORD BLOCKS IN MEM.
        MOV #STKPTR, SP ; SET STACK PTR
        MOV PC, R1 ; SET SCOPE PTR
        MOV #1, -(SP) ; PUSH BANK # ON THE STACK
        MOV R0, -(SP) ; PUSH # OF 256. WORD BLOCKS TO WRITE
        JSR PC, .3X9 ; GO CHECK DATA WRITTEN

; SETUP TO RUN MODIFIED 3 XOR 9 PATTERN IF PARITY MEMORY IS AVAILABLE
        TST @PARAVA ; BRANCH IF PARITY MEMORY IS NOT AVAIL
        BEQ DONE8
        TST @PARPAT ; BRANCH IF PARITY PAT JUST WRITTEN

```

```

2069 003464 001003          BNE     DONE8
2070 003466 010637 003362  MOV     SP,2#PARPAT ;SET INDICATOR TO WRITE 3X9 PAR PAT
2071 003472 000734          BR      DONE8       ;REPEAT TEST USING MODIFIED 3X9 PATTERN
2072
2073          ;WRITE 8 XOR 13 TEST PATTERN STARTING AT ADDRESS 40000
2074 003474 012706 000500 000004  DONE8:  MOV     #STKPTR,SP ;SET STACK PTR
2075 003500 012737 003522          MOV     #DONE9,2#ERRVEC ;SET TIME OUT TRAP VECTOR
2076 003506 010701          MOV     PC,R1         ;UPDATE TRACE REGISTER
2077 003510 012746 000002          MOV     #2,-(SP)     ;PUSH STARTING BANK # ON THE STACK
2078 003514 005046          CLR     -(SP)        ;PUSH # OF BANKS TO WRITE ON THE STACK
2079 003516 004767 005226          JSR     PC,.8X13     ;GO TO ROUTINE TO WRITE DATA
2080
2081          ;CHECK 8 XOR 13 TEST PATTERN WRITTEN ABOVE
2082 003522 012706 000500 000004  DONE9:  MOV     #STKPTR,SP ;SET STACK PTR
2083 003526 010701          MOV     PC,R1         ;UPDATE TRACE REGISTER
2084 003530 012737 001116          MOV     #ERRTRP,2#ERRVEC
2085 003536 012746 000002          MOV     #2,-(SP)
2086 003542 005404          NEG     R4
2087 003544 042704 000001          BIC     #1,R4        ;SET 4K BANK COUNT TO 8K INCREMENT
2088 003550 001403          BEQ     DONE10       ;DO NOT CHECK IF ONLY 12K
2089 003552 010446          MOV     R4,-(SP)
2090 003554 004767 005246          JSR     PC,..8X13   ;GO CHECK 8 XOR 13 PATTERN WRITTEN ABOVE
2091
2092          ;RELOCATE PROGRAM TO CHECK ADDRESSES FROM 000000-017776 USING 1 XOR 8 PATTERN
2093  DONE10:  RESET ;DISABLE MEM MGMT AND PARITY ACTION
2094 003560 000005          TST     2#42        ;CHECK IF PROGRAM LOADED VIA ACT11
2095 003562 005737 000042          BEQ     2$
2096 003566 001402          JMP     2#RANTST    ;DO NOT RELOCATE IF ACT11
2097 003570 000137 004252          MOV     #STKPTR,SP ;SET STACK PTR
2098 003574 012706 000500          JSR     5,RELOC     ;RELOCATE PROGRAM CODE
2099 003600 004567 002544          000000 ;FROM 000000 TO
2100 003604 000000          20000 ;20000
2101 003606 020000          TST     R4         ;WAS RELOCATION SUCCESSFUL?
2102 003610 005704          BEQ     3$        ;BRANCH IF SUCCESSFUL I.E. WAS THERE
2103 003612 001402          JMP     2#RANTST    ;SUFFICIENT MEMORY TO RELOCATE TO.
2104          ;END OF TEST
2105 003614 000137 004252          ADD     #20000,PC  ;RELOCATE PC
2106 003620 062707 020000          ADD     #20000,SP  ;SET NEW STACK PTR
2107 003624 062706 020000          BIS     #100000,LDDISP ;SET RELOCATION INDICATOR
2108 003630 052767 100000 175112  MOV     LDDISP,2#DISPLAY ;LOAD DISPLAY REGISTER
2109 003636 016737 175106 177570
2110
2111          ;*****IMPORTANT NOTE*****
2112          ;PROGRAM IS NOW EXECUTING CODE FROM PC AS SHOWN BELOW +20000.
2113          ;CAUTION: DO NOT ATTEMPT TO RESTART PROGRAM AT 200
2114          ;*****
2115
2116 003644 010701          DONE11: MOV     PC,R1 ;RESTART ADDRESS TO LOOP TEST
2117
2118          ;WRITE 1 XOR 8 TEST PATTERN IN LOCATIONS 000000-017776
2119 003646 005046          CLR     -(SP)      ;PUSH STARTING BANK # ON THE STACK
2120 003650 012746 000040          MOV     #32,-(SP) ;PUSH # OF 128. WORD BLOCKS TO WRITE
2121 003654 004767 003632          JSR     PC,.1X8    ;GO TO ROUTINE TO WRITE 1 XOR 8 DATA
2122
2123 003660 010701          MOV     PC,R1     ;RESTART & LOOP TEST ADDRESS
2124

```



```

2125 ;CHECK 1 XOR 8 TEST PATTERN AS WRITTEN ABOVE
2126 003662 005046 CLR -(SP) ;PUSH STARTING BANK # ON THE STACK
2127 003664 012746 000040 MOV #32,-(SP) ;PUSH # OF 128. WORD BLOCKS TO WRITE
2128 003670 004767 003730 JSR PC,..1X8 ;GO TO ROUTINE TO CHECK DATA
2129
2130 ;RELOCATE PROGRAM TO CHECK ADDRESSES 000000 - 037776 USING
2131 ;3 XOR 9 AND 8 XOR 13 PATTERNS
2132 003674 010701 DONE12: MOV PC,R1 ;UPDATE TRACE REGISTER
2133 003676 004567 002446 JSR R5,RELOC ;MOVE PROGRAM BACK TO LOWEST 4K
2134 003702 020000 20000 ;FROM 20000 TO
2135 003704 000000 000000 ;000000
2136 003706 000137 003712 JMP @#. +4 ;RETURN UNRELOCATED
2137 003712 012767 040000 000106 MOV #40000,25
2138 003720 012767 000040 000150 MOV #32, BLKCNT
2139 003726 042737 100000 000750 BIC #100000,@#LDDISP ;CLEAR RELOCATION INDICATOR
2140 003734 016737 175010 177570 MOV LDDISP,@#DISPLAY ;DISPLAY NOT RELOCATED
2141 003742 012737 004034 000004 MOV #35,@#ERRVEC ;SET TIME OUT TRAP
2142 003750 005737 057776 TST @#057776 ;CHECK IF 12K OF MEMORY IS AVAILABLE
2143 003754 012737 003776 000004 MOV #15,@#ERRVEC
2144 003762 005737 117776 TST @#117776 ;CHECK IF 20K OF MEMORY
2145 003766 006367 000034 ASL 25
2146 003772 006367 000100 ASL BLKCNT
2147 003776 012706 000500 15: MOV #STKPTR,SP ;SET STACK POINTER
2148 004002 010701 MOV PC,R1 ;UPDATE TRACE REGISTER
2149 004004 042737 100000 000750 BIC #100000,@#LDDISP ;CLEAR RELOCATION INDICATOR
2150 004012 013737 000750 177570 MOV @#LDDISP,@#DISPLAY ;LOAD DISPLAY REGISTER
2151 004020 004567 002324 JSR R5,RELOC ;RELOCATE PROGRAM
2152 004024 000000 000000 ;FROM 000000
2153 004026 040000 40000 ;TO 40000
2154 004030 005704 25: TST R4 ;RELOCATION SUCCESSFUL?
2155 004032 001402 BEQ 45 ;YES
2156 004034 000137 004252 35: JMP @#RANTST ;GO TO RANDOM DATA TEST
2157 004040 066707 177762 45: ADD 25,PC ;RELOCATE PC
2158 004044 066706 177756 ADD 25,SP ;SET NEW STACK PTR
2159 004050 052767 100000 174672 BIS #100000,LDDISP ;SET RELOCATION INDICATOR
2160 004056 016737 174666 177570 MOV LDDISP,@#DISPLAY;RELOAD DISPLAY REGISTER
2161
2162 ;*****IMPORTANT NOTE*****
2163 ;PROGRAM IS NOW EXECUTING CODE FROM PC AS SHOWN BELOW +40000 OR +100000
2164 ;CAUTION: DO NOT ATTEMPT TO RESTART PROGRAM AT 200
2165 ;*****
2166
2167 004064 005037 003362 DONE13: CLR @#PARPAT ;SET INDICATOR TO WRITE NORMAL 3X9 PAT
2168 004070 010701 MOV PC,R1 ;UPDATE TRACE REGISTER
2169
2170 ;WRITE 3XOR9 TEST PATTERN IN LOCATIONS 000000-037776 OR 000000-077776
2171 004072 005046 CLR -(SP) ;PUSH BANK # 0 ON THE STACK
2172 004074 012746 MOV (PC)+,-(SP) ;PUSH 256. BLOCK WORD COUNT ON STACK
2173 004076 000000 BLKCNT: .WORD 0 ;CONTAINS 256. BLOCK WORD COUNT LOADED
2174 ;BY ABOVE ROUTINE. 40/100 IF 8/16K
2175 004100 004767 003754 JSR PC,.3X9
2176
2177 ;CHECK PATTERN WRITTEN IN LOCATIONS 000000-037776 OR 000000-077776
2178 004104 010701 MOV PC,R1
2179 004106 005046 CLR -(SP) ;PUSH STARTING BANK # ON THE STACK
2180 004110 016746 177762 MOV BLKCNT,-(SP) ;PUSH 256. WORD BLOCK COUNT ON THE STACK

```

```

2181 004114 004767 004160          JSR    PC,..3X9          ;CHECK
2182
2183          ;ROUTINE TO CHECK IF MODIFIED 3 XOR9 PATTERN SHOULD BE RUN
2184 004120 005737 007116          TST    @#PARAVA          ;BRANCH IF PARITY MEMORY NOT AVAIL
2185 004124 001406                   BEQ    DONE14
2186 004126 005737 003362          TST    @#PARPAT          ;BRANCH IF MODIFIED PATTERN JUST RUN
2187 004132 001003                   BNE    DONE14
2188 004134 010667 177222          MOV    SP,PARPAT          ;SET INDICATOR TO WRITE MODIFIED PAT
2189 004140 000753                   BR     DONE13             ;LOOP TEST USING MODIFIED PATTERN
2190          ;WRITE 8 XOR 13 TEST PATTERN IN LOCATIONS 000000-037777
2191 004142 010701 000000 000000  DONE14: MOV    PC,R1          ;UPDATE RESTART & LOOP ADDRESS
2192 004144 005046                   CLR    -(SP)              ;PUSH STARTING BANK # ON THE STACK
2193 004146 012746 000002          MOV    #2,-(SP)          ;PUSH # OF BANKS TO WRITE ON THE STACK
2194 004152 004767 004572          JSR    PC,..8X13          ;GO TO ROUTINE TO WRITE DATA
2195
2196          ;CHECK 8 XOR 13 PATTERN WRITTEN ABOVE
2197 004156 010701 000000 000000  MOV    PC,R1          ;UPDATE RESTART & LOOP ADDRESS
2198 004160 005046                   CLR    -(SP)              ;PUSH BANK # ON THE STACK
2199 004162 012746 000002          MOV    #2,-(SP)          ;AND # OF BANKS TO CHECK (2)
2200 004166 004767 004634          JSR    PC,..8X13          ;GO TO CHECK ROUTINE
2201
2202          ;RELOCATE PROGRAM BACK TO LOWER MEMORY
2203 004172 012767 040000 000022  DONE15: MOV    #40000,1$
2204 004200 022767 000040 177670  CMP    #40,BLKCNT
2205 004206 001402                   BEQ    .+6
2206 004210 006367 000006          ASL    1$
2207 004214 010701 000000 000000  MOV    PC,R1          ;UPDATE TRACE REGISTER
2208 004216 004567 002126          JSR    RS,RELOC          ;MOVE PROGRAM BACK INTO LOWER
2209 004222 040000 000000 000000  1$: 40000          ;FROM 40000 OR 10000
2210 004224 000000 000000 000000  000000          ;TO 000000
2211 004226 000137 004232 000000  JMP    @#.+4             ;RETURN UNRELOCATED
2212 004232 012706 000500 000000  MOV    #STKPTR,SP        ;RESET STACK POINTER
2213 004236 042737 100000 000750  BIC    #10000,@#LDDISP   ;CLEAR RELOCATION INDICATOR
2214 004244 013737 000750 177570  MOV    @#LDDISP,@#DISPLAY ;LOAD DISPLAY REGISTER
2215
2216          .SBTTL RANDOM DATA ROTATING I/O TESTS
2217          ;RANDOM DATA TEST. THIS TEST MOVES THE PROGRAM CODE THROUGHOUT MEMORY
2218 004252 010701 000000 000004  RANTST: MOV    PC,R1          ;SET TRACE POINTER
2219 004254 012737 004412 000004  MOV    #7$,@#ERRVEC      ;SET TIME OUT TRAP
2220 004262 005767 174464 000000  TST    MMAVA             ;CHECK IF MEM MGMT IS AVAILABLE
2221 004266 001412 000000 000000  BEQ    1$                ;BRANCH IF NOT AVAILABLE
2222 004270 004767 002652 000000  JSR    PC,LDMMO          ;GO SET UP MEM MGMT
2223 004274 105237 172301 000000  INCB   @#KIPDR0+1        ;ALLOW 4K ADDRESSING IN FIRST 4K
2224 004300 012737 077406 172304  MOV    #200*256.-400+UP+RW,@#KIPDR2 ;SET KIPDR2=RW UP 200 BLOCKS
2225 004306 012737 000400 172344  MOV    #400,@#KIPAR2
2226 004314 012702 020000 000000  1$: MOV    #20000,R2       ;SET 'TO' ADDRESS POINTER
2227 004320 005004 000000 000000  CLR    R4                ;SET 'FROM' ADDRESS POINTER
2228 004322 012705 004000 000000  2$: MOV    #2048,R5        ;SET 4K WORD COUNT
2229 004326 012422 000000 000000  3$: MOV    (R4)+,(R2)+     ;MOVE CODE
2230 004330 012422 000000 000000  MOV    (R4)+,(R2)+
2231 004332 005305 000000 000000  DEC    R5                ;DECREMENT 4K WORD COUNTER
2232 004334 001374 000000 000000  BNE    3$
2233
2234 004336 012705 005477 000000  MOV    #4096.-PLACE+1,R5 ;SET 4K WORD COUNTER
2235 004342 014400 000000 000000  4$: MOV    -(R4),R0        ;GET 'GOOD' DATA
2236 004344 014203 000000 000000  MOV    -(R2),R3          ;GET 'BAD' DATA

```

```

2237 004346 020003          CMP      R0,R3          ;COMPARE 'GOOD' & 'BAD' DATA
2238 004350 001403          BEQ      5$
2239 004352 005722          TST      (R2)+          ;STEP ADDRESS FOR ERROR ROUTINE
2240 004354 104400          HLT
2241 004356 005742          TST      -(R2)          ;REPORT ERROR
2242 004360 005305          5$: DEC     R5           ;RESTORE ADDRESS POINTER
2243 004362 001367          BNE      4$           ;DECREMENT 4K WORD COUNTER
2244
2245 004364 005767 174362          TST      MAVA          ;CHECK IF MEM MGMT IS AVAILABLE
2246 004370 001405          BEQ      6$           ;BRANCH IF NOT AVAILABLE
2247 004372 005237 172342          INC     @#KIPAR1
2248 004376 005237 172344          INC     @#KIPAR2
2249 004402 000744          BR      1$
2250 004404 062702 000100          6$: ADD     @64.,R2      ;STEP ADDRESS
2251 004410 000744          BR      2$
2252 004412 012706 000500          7$: MOV     @STKPTR,SP   ;RESET STACK PTR
2253 004416 012737 001116 000004          MOV     @ERRTRP,@#ERRVEC;RESTORE ERROR TRAP VECTOR
2254
2255          ;ROTATING 0 TEST. THIS TEST ROTATES A SINGLE '0' THROUGH MEMORY
2256 004424 012767 177777 001052          ROT0: MOV     @-1,CONST ;SET CONSTANT =177777
2257 004432 012746 000001          MOV     @1, -(SP)      ;SET BANK #1
2258 004436 016746 176766          MOV     WDS.256, -(SP) ;GET # OF 256. WORD BLOCKS IN MEMORY
2259 004442 004767 005004          JSR     PC, USER      ;GO WRITE 1'S THROUGHOUT MEMORY
2260 004446 010701          MOV     PC,R1         ;SET SCOPE PTR
2261 004450 012746 000001          MOV     @1, -(SP)      ;SET STARTING BANK #
2262 004454 016746 176750          MOV     WDS.256, -(SP) ;SET # OF 256. WORD BLOCKS TO CHECK
2263 004460 004767 004536          JSR     PC, .ROT0      ;GO TO ROTATE 0 ROUTINE
2264
2265          ;ROTATING 1 TEST THIS TEST ROTATES A SINGLE '1' BIT THROUGH ALL OF
2266          ;MEMORY
2267 004464 005067 001014          ROT1: CLR     .CONST    ;CLEAR CONSTANT
2268 004470 012746 000001          MOV     @1, -(SP)      ;PUSH STARTING BANK ONTO STACK
2269 004474 016746 176730          MOV     WDS.256, -(SP) ;AND # OF 256. WORD BLOCKS IN MEMORY
2270 004500 004767 004746          JSR     PC, USER      ;GO WRITE 0'S THROUGHOUT MEMORY
2271 004504 010701          MOV     PC,R1         ;SET SCOPE PTR
2272 004506 012746 000001          MOV     @1, -(SP)      ;SET STARTING BANK #
2273 004512 016746 176712          MOV     WDS.256, -(SP) ;SET # OF 256. WORD BLOCKS TO CHECK
2274 004516 004767 004574          JSR     PC, .ROT1      ;GO ROTATE A '1' BIT THROUGHOUT MEMORY
2275
2276          ;END OF CYCLE
2277 004522 012767 000050 000072          END: MOV     #50,TEMPO
2278 004530 000005          1$: RESET
2279 004532 005367 000064          DEC     TEMPO
2280 004536 001374          BNE     1$
2281 004540 032767 000100 173022          BIT     @SW06,SWR
2282 004546 001407          BEQ     2$
2283 004550 005067 173474          CLR     EOPHLT
2284 004554 012767 000207 173470          MOV     @207,252
2285 004562 004767 173462          JSR     PC,EOPHLT
2286 004566 010701          2$: MOV     PC,R1
2287 004570 012706 000500          MOV     @STKPTR,SP    ;UPDATE TRACE REGISTER
2288 004574 005237 000742          INC     @#ICNT        ;SET STACK PTR
2289 004600 022737 000007 000742          CMP     @7,@#ICNT     ;INCREMENT PASS COUNT
2290 004606 001406          BEQ     DONE          ;8 PASSES?
2291 004610 004567 174144          JSR     R5,$PRINT     ;BRANCH IF 8 PASSES COMPLETED
2292 004614 012442          ASTERISK              ;GO TO PRINT ROUTINE

```

2293	004616	000137	003272		JMP	Q#BEGIN1	
2294							
2295	004622	000000			TEMPO:	.WORD	0
2296							
2297	004624				DONE:		
2298	004624	004567	174130		JSR	RS, \$PRINT	;GO TO PRINT ROUTINE
2299	004630	012444			ENDMSG		
2300	004632	105737	177564		TSTB	Q#TPS	;WAIT FOR BELL TO RING
2301	004636	100375			BPL	-4	
2302	004640	013700	000042		MOV	Q#42, RO	;GET DECTAPE MONITOR RETURN ADDRESS
2303	004644	001407			BEQ	FINISH	
2304	004646	004767	175256		JSR	PC, \$RLDR	;RESTORE MONITOR & LOADERS
2305	004652	000005			RESET		
2306	004654	004710			LOGICAL: JSR	PC, (RO)	;GO TO DECTAPE MONITOR
2307	004656	000240			NOP		
2308	004660	000240			NOP		
2309	004662	000240			NOP		
2310	004664	000167	175456		FINISH: JMP	START1	
2311							
2312					.SBTTL	USER TESTS	
2313					.SBTTL	PROGRAM # 2	
2314					;PROGRAM # 2		
2315					;THIS PROGRAM ALLOWS THE USER TO SELECT A STARTING 4K BANK #, # OF 4K		
2316					;BANKS TO TEST, AND A WORST CASE PATTERN TO WRITE AND CHECK.		
2317	004670	005067	001124		PRG2: CLR	PRG3FLG	;CLEAR PROGRAM # 3 FLAG
2318					;NOTE: PROGRAM 3 ENTERS PROGRAM # 2 HERE, WITH PRG3FLG = 1.		
2319	004674	012706	000500		PRG2A: MOV	#STKPTR, SP	;SET STACK PTR
2320	004700	005037	006622		CLR	Q#PEFLG	;CLEAR PARITY ERROR INDICATORS
2321	004704	005027			CLR	(PC)+	;CLEAR RUNNING ALL PATTERNS FLAG
2322	004706	000000			ALLFLG: .WORD	0	;CONTAINS RUNNING ALL PATERNS FLAG
2323							;0/-1 = RUNNING SELECTED/ALL PATTERNS
2324	004710	012737	000502	000024	MOV	#PDWN, Q#PFVEC	;SET POWER FAIL TRAP VECTOR
2325	004716	012737	000006	000004	MOV	#ERRVEC+2, Q#ERRVEC	
2326	004724	005067	174022		CLR	MMAVA	
2327	004730	000412			BR	1\$;TELCO SYSTEM DOES NOT HAVE MEM. MANAGEMENT
2328							;HENCE SW12 IS BEING DISCONNECTED.
2329							;CAN BE RECONNECTED BY DELETING
2330							;THIS BR INSTRUCTION.
2331	004732	032737	010000	177570	BIT	#BIT12, Q#SWR	;CHECK IF TEST IS TO BE RUN
2332	004740	001006			BNE	1\$;WITH MEM MGMT ENABLED
2333	004742	000261			SEC		
2334	004744	005737	177572		TST	Q#SRO	;CHECK IF MEM MGMT IS AVAILABLE
2335	004750	103402			BCS	1\$;BRANCH IF NOT AVAILABLE
2336	004752	005167	173774		COM	MMAVA	
2337	004756	012737	001116	000004	1\$:	MOV	#ERRTRP, Q#ERRVEC
2338	004764	005037	000742		CLR	Q#ICNT	
2339	004770	005037	000750		CLR	Q#LDDISP	
2340	004774	005037	003362		CLR	Q#PARPAT	;SET INDICATOR TO WRITE NORM 3X9 PAT
2341	005000	032767	000002	172562	BIT	#SW01, SWR	;IS THERE A TTY?
2342	005006	001414			BEQ	5\$	
2343	005010	000000			HALT		
2344	005012	005767	000034		TST	.PARIT	
2345	005016	001402			BEQ	3\$	
2346	005020	004767	002022		JSR	PC, MAMF	
2347	005024	005767	000050		3\$:	TST	.STBANK
2348	005030	001002			BNE	4\$	

```

2349 005032 004767 001414          JSR    PC,RELOCP
2350 005036 000442          4$:   BR    PRG2R
2351 005040 004567 173714          5$:   JSR    RS,$SPRINT ;GO TO PRINT ROUTINE
2352 005044 012120          PARITY
2353 005046 004767 004616          JSR    PC,RECD ;GO GET ANSWER TO THE PARITY QUESTION
2354 005052 000000          .PARIT: .WORD 0 ;TYPE 1 IF PARITY DESIRED 0 IF NOT
2355 005054 005767 177772          TST   .PARIT
2356 005060 001402          BEQ   1$ ;BRANCH IF PARITY NOT DESIRED
2357 005062 004767 001760          JSR   PC,.MAMF ;GO ENABLE PARITY ACTION
2358 005066
2359 005066 004567 173666          1$:   JSR    RS,$SPRINT ;GO TO PRINT ROUTINE
2360 005072 012155          STBANK ;ASK USER FOR STARTING BANK
2361 005074 004767 004570          JSR    PC,RECD
2362 005100 000000          .STBANK: .WORD 0 ;CONTAINS STARTING BANK #
2363 005102 005767 177772          TST   .STBANK ;CHECK IF STARTING AT BANK #0
2364 005106 001002          BNE   1$
2365 005110 004767 001336          JSR   PC,RELOCP ;GO RELOCATE THE PROGRAM TO TOP OF MEM
2366 005114
2367 005114 004567 173640          1$:   JSR    RS,$SPRINT ;GO TO PRINT ROUTINE
2368 005120 012204          BANKS ;ASK USER FOR # OF 4K BANKS TO TEST
2369 005122 004767 004542          JSR    PC,RECD
2370 005126 000000          .BANKS: .WORD 0 ;CONTAINS # OF BANKS TO CHECK
2371 005130 004567 173624          JSR    RS,$SPRINT ;GO TO PRINT ROUTINE
2372 005134 012241          PAT   ;ASK USER WHICH PATTERN
2373 005136 004767 004526          JSR    PC,RECD
2374 005142 000000          .PAT:  .WORD 0 ;CONTAINS PATTERN #
2375 005144 012767 005144 175210 PRG2R: MOV   #PRG2R,PERSTR ;SET PAR ERROR RESTART ADDRESS
2376 005152 004767 004574          JSR    PC,CKSWR ;GO CHECK SWITCHES
2377 005156 016700 177760          MOV   .PAT,RO
2378 005162 006300          ASL   RO ;SHIFT PATTERN # TO FORM INDEX
2379 005164 066700 173564          ADD   RELOCF,RO ;ADD RELOCATION FACTOR
2380 005170 016000 005202          MOV   WRTTAB(0),RO ;GET UNRELOCATED PC OF ROUTINE
2381 005174 066700 173554          ADD   RELOCF,RO ;ADD RELOCATION FACTOR
2382 005200 010007          MOV   RO,PC ;GO TO APPROPRIATE ROUTINE
2383
2384 ;TABLE OF ROUTINES TO WRITE SELECTED PATTERNS
2385 005202 005222          WRTTAB: .WORD $1X8 ;1 XOR 8 ROUTINE (0)
2386 005204 005312          .WORD $3X9 ;3 XOR 9 ROUTINE (1)
2387 005206 005400          .WORD $8X13 ;8 XOR 13 ROUTINE (2)
2388 005210 005472          .WORD $USER ;USER ROUTINE (3)
2389 005212 005600          .WORD $ROTO ;ROTATING '0' ROUTINE (4)
2390 005214 005674          .WORD $ROT1 ;ROTATING '1' ROUTINE (5)
2391 005216 005770          .WORD $3X9P ;PARITY 3 XOR 9 PATTERN (6)
2392 005220 006000          .WORD $ALL ;ALL EXCEPT USER (7)
2393
2394 ;ROUTINES
2395 005222 016746 177652          $1X8: MOV   .STBANK,-(SP) ;GET STARTING BANK #
2396 005226 016746 177674          MOV   .BANKS,-(SP) ;GET # OF 4K BANKS
2397 005232 006316          ASL   (SP) ;MULTIPLY BY 32.
2398 005234 005767 000560          TST   PRG3FLG ;IF PROGRAM # 3 STOP WITH 256.
2399 005240 001004          BNE   1$ ;WORD BLOCK COUNT
2400 005242 006316          ASL   (SP) ;TO FORM 128.
2401 005244 006316          ASL   (SP) ;WORD BLOCK
2402 005246 006316          ASL   (SP) ;COUNT
2403 005250 006316          ASL   (SP)
2404 005252 011627          1$:   MOV   (SP),(PC)+ ;SAVE

```

```

2405 005254 000000          2$:   WORD   0           ;CONTAINS 128. WORD BLOCK COUNT
2406 005256 004767 002230   JSR   PC,.1X8        ;GO WRITE 1 XOR 8 TEST PATTERN
2407
2408 005262 016746 177612   MOV   .STBANK,-(SP)   ;GET STARTING BANK #
2409 005266 016746 177762   MOV   2$,-(SP)       ;GET 128. WORD BLOCK COUNT
2410 005272 004767 002326   JSR   PC,.1X8        ;GO CHECK PATTERN
2411 005276 005267 173440   INC   ICNT
2412 005302 005767 177400   TST   ALLFLG         ;CHECK IF RUNNING ALL PATERNS
2413 005306 001001          BNE   $3X9           ;GO START 3X9 PATTERN IF RUNNING ALL
2414 005310 000744          BR    $1X8           ;OTHERWISE LOOP
2415
2416 005312 016746 177562   $3X9: MOV   .STBANK,-(SP) ;GET STARTING BANK #
2417 005316 016746 177604   MOV   .BANKS,-(SP)  ;GET # OF BANKS
2418 005322 005767 000472   TST   PRG3FLG       ;IF PROGRAM # 2 STOP WITH 256.
2419 005326 001004          BNE   1$            ;WORD BLOCK COUNT
2420 005330 006316          ASL   (SP)           ;MULTIPLY BY 16.
2421 005332 006316          ASL   (SP)           ;TO FORM
2422 005334 006316          ASL   (SP)           ;256. WORD
2423 005336 006316          ASL   (SP)           ;BLOCK COUNT
2424 005340 011627          1$:   MOV   (SP),(PC)+ ;SAVE
2425 005342 000000          2$:   WORD   0           ;CONTAINS 256. WORD BLOCK COUNT
2426 005344 004767 002510   JSR   PC,.3X9       ;GO WRITE PATTERN
2427
2428   ;CHECK PATTERN WRITTEN ABOVE
2429 005350 016746 177524   3$:   MOV   .STBANK,-(SP) ;GET STARTING BANK #
2430 005354 016746 177762   MOV   2$,-(SP)       ;GET # OF 256. WORD BLOCKS
2431 005360 004767 002714   JSR   PC,.3X9       ;GO CHECK PATTERN
2432 005364 005267 173352   INC   ICNT
2433 005370 005767 177312   TST   ALLFLG         ;CHECK IF RUNNING ALL PATTERNS
2434 005374 001001          BNE   $8X13         ;GO START 8X13 PATTERN IF RUNNING ALL
2435 005376 000764          BR    3$
2436
2437 005400 005737 006020   $8X13: TST   2$PRG3FLG ;CANNOT DO 8X13 PATTERN USING
2438 005404 001007          BNE   1$            ;PROGRAM # 3
2439 005406 016746 177466   MOV   .STBANK,-(SP) ;GET STARTING BANK #
2440 005412 016746 177510   MOV   .BANKS,-(SP)  ;AND # OF 4K BANKS
2441 005416 032716 000001   BIT   #1,(SP)       ;MUST BE AN EVEN # OF 4K BANKS
2442 005422 001405          BEQ   2$
2443
2444 005424 004567 173330   1$:   JSR   R5,$PRINT   ;GO TO PRINT ROUTINE
2445 005430 012257          QUEST                ;PRINT ?
2446 005432 000167 177232   JMP   PRG2          ;RESTART
2447
2448 005436 004767 003306   2$:   JSR   PC,.8X13   ;GO WRITE PATTERN
2449 005442 016746 177432   MOV   .STBANK,-(SP)
2450 005446 016746 177454   MOV   .BANKS,-(SP)
2451 005452 004767 003350   JSR   PC,.8X13     ;GO CHECK PATTERN
2452 005456 005267 173260   INC   ICNT
2453 005462 005767 177220   TST   ALLFLG       ;CHECK IF RUNNING ALL PATERNS
2454 005466 001044          BNE   $ROTO        ;GO DO ROTO PATTERN IF ALL SELECTED
2455 005470 000743          BR    $8X13
2456
2457
2458   ;ROUTINE TO WRITE & CHECK USER CONSTANT
2459 $USER:
2460 005472 004567 173262   JSR   R5,$PRINT   ;GO TO PRINT ROUTINE

```

```

2461 005476 012263          CONST          ;ASK FOR USER CONSTANT
2462 005500 004767 004164   JSR          PC,RECD
2463 005504 000000          CONST: .WORD 0          ;CONTAINS USER CONSTANT
2464 005506 016746 177366   i$: MOV       .STBANK,-(SP) ;GET STARTING BANK #
2465 005512 016746 177410   MOV       .BANKS,-(SP)    ;GET 4K COUNT
2466 005516 005767 000276   TST      PRG3FLG
2467 005522 001004          BNE        2$
2468 005524 006316          ASL        (SP)          ;MULTIPLY 4K BANK COUNT BY 16.
2469 005526 006316          ASL        (SP)          ;TO FORM 256. WORD BLOCK COUNT
2470 005530 006316          ASL        (SP)
2471 005532 006316          ASL        (SP)
2472 005534 011627          2$: MOV       (SP),(PC)+   ;SAVE
2473 005536 000000          3$: .WORD 0
2474 005540 004767 003706   JSR      PC,.USER        ;GO WRITE USER CONSTANT
2475 005544 016746 177330   MOV      .STBANK,-(SP)   ;GET STARTING BANK #
2476 005550 016746 177762   MOV      3$,-(SP)        ;AND # OF 256. WORD BLOCKS
2477 005554 004767 003744   JSR      PC,.USER        ;GO TO USER CHECK ROUTINE
2478 005560 005267 173156   INC      ICNT
2479 005564 105737 177560   TSTB    @#TKS           ;CHECK IF USER HAS TYPED A CHARACTER
2480 005570 100346          BPL        1$
2481 005572 005737 177562   TST      @#TKB           ;CLEAR FLAG
2482 005576 000735          BR         $USER
2483
2484          ;ROTATING '0' ROUTINE
2485 005600 016746 177274   $ROTO: MOV      .STBANK,-(SP) ;GET STARTING BANK #
2486 005604 016746 177316   MOV      .BANKS,-(SP)    ;GET # OF BANKS
2487 005610 005767 000204   TST      PRG3FLG
2488 005614 001004          BNE        2$
2489 005616 006316          ASL        (SP)          ;MULTIPLY 4K BANK COUNT BY 16.
2490 005620 006316          ASL        (SP)          ;TO FORM 256. WORD BLOCK COUNT
2491 005622 006316          ASL        (SP)
2492 005624 006316          ASL        (SP)
2493 005626 011627          2$: MOV       (SP),(PC)+   ;SAVE
2494 005630 000000          3$: .WORD 0
2495 005632 012767 177777 177644 MOV      #-1,.CONST      ;CONTAINS 256. WORD BLOCK COUNT
2496 005640 004767 003606   JSR      PC,.USER        ;SET CONSTANT
2497 005644 016746 177230   MOV      .STBANK,-(SP)   ;GO WRITE ALL 1'S THROUGH MEMORY
2498 005650 016746 177754   MOV      3$,-(SP)        ;GET STARTING BANK #
2499 005654 004767 003342   JSR      PC,.ROTO        ;GET # OF 256. WORD BLOCKS TO CHECK
2500 005660 005267 173056   INC      ICNT           ;GO CHECK ROTATING 0 PATTERN
2501 005664 005767 177016   TST      ALLFLG         ;INCREMENT DISPLAY COUNT
2502 005670 001001          BNE        $ROTI        ;CHECK IF RUNNING ALL PATERNS
2503 005672 000742          BR         $ROTO        ;GO TO $ROTI IF RUNNING ALL PATTERNS
2504          ;LOOP
2505 005674 016746 177200   $ROTI: MOV      .STBANK,-(SP) ;GET STARTING BANK #
2506 005700 016746 177222   MOV      .BANKS,-(SP)    ;GET # OF 4 K BANKS
2507 005704 005767 000110   TST      PRG3FLG        ;CHECK IF RUNNING PROGRAM 3
2508 005710 001004          BNE        2$           ;BRANCH IF RUNNING PROGRAM 3
2509 005712 006316          ASL        (SP)          ;SHIFT 4K BANK COUNT BY 16.
2510 005714 006316          ASL        (SP)          ;TO FORM 256. WORD BLOCK COUNT
2511 005716 006316          ASL        (SP)
2512 005720 006316          ASL        (SP)
2513 005722 011627          2$: MOV       (SP),(PC)+   ;SAVE
2514 005724 000000          3$: .WORD 0
2515 005726 005067 177552   CLR      .CONST
2516 005732 004767 003514   JSR      PC,.USER        ;GO WRITE 0'S THROUGHOUT

```

```

2517 005736 016746 177136      MOV      .STBANK, -(SP)      ;GET STARTING BANK #
2518 005742 016746 177756      MOV      3$, -(SP)          ;AND 256. WORD BLOCK COUNT
2519 005746 004767 003344      JSR      PC, ROT1           ;GO CHECK ROTATING 1 PATTERN
2520 005752 005267 172764      INC      ICNT               ;INCREMENT PASS COUNT
2521 005756 005767 176724      TST     ALLFLG              ;CHECK IF RUNNING ALL PATTERNS
2522 005762 001744                BEQ      $ROT1              ;LOOP IF NOT RUNNING ALL PATTERNS
2523 005764 000167 177232      JMP      $1X8                ;GO DO $1X8 PATTERN
2524
2525      ;ROUTINE TO CHECK MEMORY USING 3 XOR 9 PARITY PATTERN
2526 005770 010667 175366      $3X9P: MOV      SP, PARPAT   ;SET INDICATOR TO WRITE PARITY PATTERN
2527 005774 000167 177312      JMP      $3X9
2528
2529      ;ALL PATTERNS
2530 006000 010667 176702      $ALL:  MOV      SP, ALLFLG   ;SET INDICATOR
2531 006004 000167 177212      JMP      $1X8                ;BEGIN WITH 1X8 TEST PATTERN
2532      .SBTTL PROGRAM # 3
2533      ;THIS PROGRAM IS THE SAME AS PROGRAM # 2 ABOVE EXCEPT THAT 256. WORD
2534      ;DATA BLOCKS MAY BE WRITTEN
2535 006010 012706 000500      PRG3:  MOV      #STKPTR, SP   ;SET STACK PTR
2536 006014 012727 000001      MOV      #1, (PC)+          ;SET PROGRAM 3 FLAG
2537 006020 000000                PRG3FLG: WORD 0              ;CONTAINS PRG3 INDICATOR
2538 006022 004567 172732      JSR      R5, $SPRINT        ;GO TO PRINT ROUTINE
2539 006026 012303                PRG3M   JSR      R5, $SPRINT        ;GO TO PRINT ROUTINE
2540 006030 004567 172724      JSR      R5, $SPRINT        ;GO TO PRINT ROUTINE
2541 006034 012204                BANKS   JMP      PRG2A                ;GO TO PROGRAM 2
2542 006036 000167 176632      JMP      PRG2A
2543
2544      .SBTTL PROGRAM # 4
2545      ;THIS PROGRAM MAY BE USED TO READ/WRITE A USER CONTANT INTO ANY
2546      ;MEMORY LOCATION
2547 006042 012706 000500      PRG4:  MOV      #STKPTR, SP   ;SET STACK PTR
2548 006046 005037 006622      CLR      @#PEFLG            ;CLEAR PARITY ERROR INDICATORS
2549 006052 012737 001116 000004  MOV      #ERRTRP, @#ERRVEC
2550 006060 000005                RESET
2551 006062 012707 006066      MOV      #.+4, PC           ;RELOCATE BACK TO FIRST 4K
2552 006066 004567 172666      JSR      R5, $SPRINT        ;GO TO PRINT ROUTINE
2553 006072 012364                PRG4M   JSR      PC, RECD
2554 006074 004767 003570      JSR      PC, RECD
2555 006100 000000      $ADRSO: .WORD 0              ;SONTAINS ADDRESS BITS <15-0>
2556 006102 016767 003634 000236  MOV      .1617, .EXTAD      ;GET EXTENDED ADDRESS BITS <17-16>
2557 006110 006037 177570      ROR      @#SWR              ;CHECK SWITCH 0
2558 006114 103406                BCS     PRG4A              ;GO TO PRG4A IF SET
2559 006116 004567 172636      JSR      R5, $SPRINT        ;GO TO PRINT ROUTINE
2560 006122 012263                CONST
2561 006124 004767 003540      JSR      PC, RECD
2562 006130 000000      $CONST: .WORD 0              ;CONTAINS USER CONSTANT
2563 006132 012767 006132 174222  PRG4A: MOV      #PRG4A, PERSTRT ;SET RESTART ADDRESS ON PAR ERROR
2564 006140 016703 177734      MOV      $ADRSO, R3         ;GET ADDRESS BITS <15-0>
2565 006144 016704 000176      MOV      .EXTAD, R4         ;GET ADDRESS BITS <17-16>
2566 006150 001020                BNE     10$                ;BRANCH IF MEM MGMT REQUIRED
2567 006152 022703 020000      CMP      #20000, R3         ;CHECK IF ADDRESS IS LESS THAN 20000
2568 006156 101412                BLOS   1$                  ;BRANCH IF IT IS NOT
2569 006160 006037 177570      ROR      @#SWR              ;CHECK IF READING
2570 006164 103431                BCS     3$                  ;BRANCH IF READING
2571 006166 004767 172112      JSR      PC, $SAVR          ;GO SAVE REGISTERS ON THE STACK
2572 006172 004767 000254      JSR      PC, RELOC          ;GO RELOCATE PROGRAM

```


2573	006176	004767	172126		JSR	PC,\$RESTR	;RESTORE REGISTERS FROM STACK
2574	006202	000422			BR	3\$;GO TO 3\$
2575	006204	022703	160000	1\$:	CMP	#160000,R3	;CHECK IF MEM MGMT WILL BE REQUIRED
2576	006210	101017			BHI	3\$;GO TO 3\$ IF NOT REQUIRED
2577	006212	010302		10\$:	MOV	R3,R2	;GET ADDRESS BITS <15-0>
2578	006214	012700	000006		MOV	#6,R0	;SET SHIFT COUNT
2579	006220	006204		2\$:	ASR	R4	;SHIFT 18 BIT ADDRESS
2580	006222	006003			ROR	R3	;6 PLACES RIGHT
2581	006224	077003			SOB	R0,2\$	
2582	006226	004767	000714		JSR	PC,LDMMO	;GO SETUP MEM MGMT
2583	006232	010337	172342		MOV	R3,@#KIPAR1	;SET KIPAR1
2584	006236	042702	177700		BIC	#177700,R2	;CLEAR ADDRESS BITS <15-6>
2585	006242	052702	020000		BIS	#20000,R2	;SET ADDRESS REGISTER
2586	006246	000401			BR	4\$;GO TO 4\$
2587	006250	010302		3\$:	MOV	R3,R2	;SET ADDRESS REGISTER
2588	006252	016700	177652	4\$:	MOV	\$CONST,R0	;GET USER CONSTANT
2589	006256	012737	006042	000060	MOV	#PRG4,@#TKVEC	;SET KEYBOARD INTERRUPT VECTOR
2590	006264	052737	000100	177560	BIS	#100,@#TKS	;SET IE BIT IN KEYBOARD CSR
2591	006272	006037	177570		ROR	@#SWR	;CHECK SWITCH 0
2592	006276	103014			BCC	5\$;BRANCH IF NOT SET
2593	006300	011246			MOV	(R2),-(SP)	;PUSH DATA TO BE TYPED ONTO STACK
2594	006302	004767	173434		JSR	PC,02A	;GO TYPE DATA
2595	006306	004567	172446		JSR	R5,\$PRINT	;GO TO PRINT ROUTINE
2596	006312	015122			\$CRLF		
2597	006314	062767	000002	177556	ADD	#2,\$ADR50	;STEP ADDRESS
2598	006322	005567	000020		ADC	.EXTAD	
2599	006326	000701			BR	PRG4A	
2600	006330	010012		5\$:	MOV	R0,(R2)	;WRITE USER CONSTANT INTO ADDRESS
2601	006332	012203			MOV	(R2)+,R3	;GET DATA WRITTEN
2602	006334	020003			CMP	R0,R3	;CHECK DATA
2603	006336	001401			BEQ	6\$	
2604	006340	104400			HLT		;REPORT ERROR
2605	006342	005742		6\$:	TST	-(R2)	;RESTORE ADDRESS
2606	006344	000771			BR	5\$;LOOP BACK
2607	006346	000000		.EXTAD:	.WORD	0	;CONTAINS EXTENDED ADDRESS BITS
2608					.SBTTL	PROGRAM SUBROUTINES	
2609					.SBTTL	RELOCATION ROUTINES	
2610					.ROUTINE	TO RELOCATE PROGRAM CODE	
2611	006350	012500		RELOC:	MOV	(R5)+,R0	;GET FROM ADDRESS
2612	006352	011502			MOV	(R5),R2	;GET TO ADDRESS
2613	006354	010203			MOV	R2,R3	
2614	006356	062703	017776		ADD	#17776,R3	;MOVES 4K
2615	006362	012737	006432	000004	MOV	#4\$,@#ERRVEC	;SET TIME OUT TRAP
2616	006370	005004			CLR	R4	;CLEAR RELOCATION SUCCESSFUL INDICATOR
2617	006372	005723			TST	(R3)+	;CHECK IF MEMORY IS AVAILABLE
2618	006374	012022		1\$:	MOV	(R0)+,(R2)+	;RELOCATE
2619	006376	020203			CMP	R2,R3	;RELOCATION COMPLETE?
2620	006400	001375			BNE	1\$	
2621	006402	011503			MOV	(R5),R3	
2622	006404	020203		2\$:	CMP	R2,R3	
2623	006406	001413			BEQ	5\$;BRANCH IF DONE
2624	006410	024042			CMP	-(R0),-(R2)	;CHECK THAT DATA WAS RELOCATED PROPERLY
2625	006412	001774			BEQ	2\$	
2626	006414	005703			TST	R3	;CHECK IF RELOCATING BACK TO 000000
2627	006416	001403			BEQ	3\$	
2628	006420	104400			HLT		;ERROR! CANNOT RELOCATE PROGRAM CODE


```

2685 006622 000 PEFLG: .BYTE 0 ;NOT 0/0 =PAR ERR/NO PAR ERR
2686 006623 000 PENFLG: .BYTE 0 ;NOT 0/0=PAR ERR DETECTED/NOT DETECTED ON SCAN
2687 006624 012737 006672 000114 MOV #25,2#PARVEC ;SET PARITY ERROR TRAP
2688 006632 012737 006730 000004 MOV #45,2#ERRVEC ;SET TIME OUT TRAP VECTOR
2689 006640 005002 CLR R2
2690 006642 005767 172104 TST MAVA ;CHECK IF MEM MGMT IS AVAILABLE
2691 006646 001407 BEQ 1$ ;BRANCH IF NOT AVAILABLE
2692 006650 004767 000272 JSR PC,LDMMO ;SET UP MEM MGMT
2693 006654 105237 172301 INCB 2#KIPDR0+1 ;ALLOW FULL 4K PAGE ADDRESSING
2694 006660 012737 007244 000250 MOV #MMABTO,2#MMVEC ;SET MEM MGMT ABORT TRAP VECTOR
2695 006666 012200 1$: MOV (R2)+,R0 ;SCAN ALL ADDRESSES
2696 006670 000776 BR 1$
2697 006672 110667 177724 2$: MOVA SP,PEFLG ;SET PARITY ERROR FOUND INDICATOR
2698 006676 010003 MOV R0,R3
2699 006700 104400 HLT ;PARITY ERROR! ADDRESS+2 IS IN R2 DATA
2700 ;IS IN R0
2701 006702 000002 RTI ;CONTINUE SCAN
2702 006704 000240 3$: NOP ;INSERT HALT INST TO EXAMINE PARITY REGS
2703 006706 005067 177710 CLR PEFLG ;CLEAR PARITY ERROR INDICATORS
2704 006712 012706 000500 MOV #STKPTR,SP ;RESET STACK PTR
2705 006716 000005 RESET
2706 006720 004767 000122 JSR PC,MAMF ;GO ENABLE PARITY ERROR DETECTION
2707 006724 000177 173432 JMP 2#PERSTRT ;RESTART SELECTED PROGRAM
2708
2709 ;SERVICE ROUTINE IF PARITY ERROR NOT DETECTED ON SCAN
2710 006730 105767 177666 4$: TSTB PEFLG ;BRANCH IF PARITY ERROR WAS
2711 006734 001363 BNE 3$ ;DETECTED ON SCAN
2712 006736 016602 000004 MOV 4(SP),R2 ;GET PC AT TIME OF ERROR
2713 006742 162702 000002 SUB #2,R2 ;BACK IT UP
2714 006746 110667 177651 MOVB SP,PENFLG ;SET IND = NO PAR ERROR DETECTED ON SCAN
2715 006752 004567 172002 JSR R5,SPRINT ;GO TO PRINT ROUTINE
2716 006756 007021 NOFIND
2717 006760 104400 HLT ;ERROR! PARITY ERROR NOT DETECTED ON SCAN
2718 006762 000750 BR 3$
2719 ;THE BELOW 6 WORDS CONTAINS THE SAVED CONTENTS OF R0-R5 WHEN THE
2720 ;PARITY ERROR OCCURRED
2721 006764 000000 SAVR0: .WORD 0
2722 006766 000000 SAVR1: .WORD 0
2723 006770 000000 SAVR2: .WORD 0
2724 006772 000000 SAVR3: .WORD 0
2725 006774 000000 SAVR4: .WORD 0
2726 006776 000000 SAVR5: .WORD 0
2727
2728 007000 005015 040520 044522 PARERR: .ASCIZ <15><12>'PARITY ERROR'<15><12>
2729 007006 054524 042440 051122
2730 007014 051117 005015 000
2731 007021 116 052117 043040 NOFIND: .ASCIZ 'NOT FOUND ON SCAN'<15><12>
2732 007026 052517 042116 047440
2733 007034 020116 041523 047101
2734 007042 005015 000
2735 007046 .EVEN
2736
2737 ;ROUTINE TO ENABLE PARITY ERROR ACTION ON MA/MF PARITY MEMORIES
2738 172100 PARCSR=172100 ;ADDRESS OF FIRST PARITY REGISTER
2739 000114 PARVEC=114 ;PARITY ERROR INTERRUPT VECTOR ADDRESS
2740

```

```

2741 007046 032737 000040 177570 .MAMF: BIT #40,2#SWR ;CHECK IF PARITY ERROR DETECTION IS TO
2742 007054 001033 BNE DISPAR ;BE ENABLED. BRANCH IF NOT TO BE ENABLED
2743 007056 013746 000004 MOV 2#ERRVEC, -(SP) ;SAVE ERROR TRAP VECTOR
2744 007062 012737 000006 000004 MOV #ERRVEC+2,2#ERRVEC ;SET TIME OUT TRAP TO RETURN (VIA RTI)
2745 007070 012737 006570 000114 MOV #PARSRV,2#PARVEC ;SET PARITY ERROR TRAP VECTOR
2746 007076 012737 000340 000116 MOV #340,2#PARVEC+2 ;PRIORITY LEVEL 7 ON TRAP
2747 007104 012700 172100 MOV #PARCSR,RO ;GET FIRST ADDRESS OF PARITY REGISTER
2748 007110 012702 000001 MOV #1,R2
2749 007114 005027 CLR (PC)+ ;CLEAR AVAILABILITY INDICATOR
2750 007116 000000 PARAVA: .WORD 0 ;CONTAINS AVAILABILITY INDICATOR
2751
2752 ;ENABLE ALL AVAILABLE PARITY REGISTERS
2753 007120 000262 1S: SEV ;SET TIME OUT INDICATOR
2754 007122 012720 000001 MOV #1,(RO)+ ;SET ACTION ENABLE IF AVAILABLE
2755 007126 102402 BVS 2$ ;BRANCH IF NO PARITY AVAILABLE
2756 007130 050267 177762 BIS R2,PARAVA ;SET AVAILABILITY INDICATOR
2757 007134 006302 2S: ASL R2 ;SHIFT INDICATOR
2758 007136 103370 BCC 1$
2759 007140 012637 000004 MOV (SP)+,2#ERRVEC ;RESTORE ERROR TRAP VECTOR
2760 007144 000207 DISPAR: RTS PC ;RETURN
2761
2762 .SBTTL MEM MGMT ROUTINES
2763 ;ROUTINE TO INITIALIZE MEMORY MANAGEMENT REGISTERS
2764 007146 000240 LDMMO: NOP
2765 007150 005767 171576 TST MMAVA
2766 007154 001432 BEQ 1$
2767 007156 012737 077006 172300 MOV #177*256.-400+UP+RW,2#KIPDR0 ;SET KIPDR0=RW UP 177 BLOCKS
2768 007164 012737 077406 172302 MOV #200*256.-400+UP+RW,2#KIPDR1 ;SET KIPDR1=RW UP 200 BLOCKS
2769 007172 005037 172304 CLR 2#KIPDR2
2770 007176 012737 000000 172344 MOV #0,2#KIPAR2
2771 007204 012737 077406 172316 MOV #200*256.-400+UP+RW,2#KIPDR7 ;SET KIPDR7=RW UP 200 BLOCKS
2772 007212 005037 172340 CLR 2#KIPAR0
2773 007216 012737 000200 172342 MOV #200,2#KIPAR1
2774 007224 012737 007600 172356 MOV #7600,2#KIPAR7
2775 007232 012737 000001 177572 MOV #1,2#SRO ;ENABLE MEM MGMT
2776 007240 000240 NOP
2777 007242 000207 1S: RTS PC
2778
2779 ;MEMORY MANAGEMENT ABORT ROUTINE FOR WRITE UP
2780 007244 012702 020000 MMABTO: MOV #20000,R2 ;RESET R2
2781 007250 062737 000200 172342 ADD #200,2#KIPAR1 ;ADVANCE TO NEXT 4K
2782 007256 013716 177576 MOV 2#SR2,(SP) ;RETURN TO INSTRUCTION THAT
2783 007262 005037 177572 CLR 2#SRO ;DISABLE MEM MGMT
2784 007266 012737 000001 177572 MOV #1,2#SRO ;ENABLE MEM MGMT
2785 007274 000002 RTI ;CAUSED THE ABORT
2786
2787 ;MEM MGMT ABORT SERVICE FOR WRITE DOWN
2788 007276 012702 040000 MMABT1: MOV #40000,R2 ;RESET R2
2789 007302 162737 000200 172342 SUB #200,2#KIPAR1
2790 007310 001406 BEQ 2$
2791 007312 013716 177576 MOV 2#SR2,(SP)
2792 007316 012737 000001 177572 MOV #1,2#SRO ;ENABLE MEM MGMT
2793 007324 000002 RTI
2794
2795 2S: CLR 2#SRO ;DISABLE MEM MGMT
2796 007332 052766 000002 000002 BIS #V,2(SP)
    
```

```

2797 007340 000002 RTI
2798
2799 :ROUTINE TO SET UP MEMORY MANAGEMENT FOR PATTERN TESTS
2800 007342 005702 STMM2: TST R2 ;CHECK IF TESTING BANK # 0
2801 007344 001442 BEQ 2$ ;EXIT IF BANK # 0
2802 007346 005767 171400 TST MMVA
2803 007352 001005 BNE 1$ ;BRANCH IF MEM MGMT AVAILABLE
2804 007354 006002 ROR R2 ;ADJUST ADDRESS
2805 007356 006002 ROR R2
2806 007360 006002 ROR R2
2807 007362 006002 ROR R2
2808 007364 000207 RTS PC ;RETURN
2809
2810 007366 004767 177554 1$: JSR PC,LDMMO ;GO MAKE INITIAL SET UP
2811 007372 000302 SWAB R2
2812 007374 006002 ROR R2
2813 007376 010237 172344 MOV R2,@#KIPAR2
2814 007402 062702 000200 ADD #200,R2
2815 007406 010237 172346 MOV R2,@#KIPAR3
2816 007412 012737 077406 172304 MOV #200*256.-400+UP+RW,@#KIPDR2 ;SET KIPDR2=RW UP 200 BLOCKS
2817 007420 012737 077406 172306 MOV #200*256.-400+UP+RW,@#KIPDR3 ;SET KIPDR3=RW UP 200 BLOCKS
2818 007426 005037 172310 CLR @#KIPDR4
2819 007432 012702 040000 MOV #40000,R2
2820 007436 012737 007454 000250 MOV #MMABT2,@#MMVEC
2821 007444 012737 000001 177572 MOV #1,@#SR0 ;ENABLE MEM MGMT
2822 007452 000207 2$: RTS PC
2823
2824 :ROUTINE TO SERVICE 8 XOR 13 ABORTS
2825 007454 000240 MMABT2: NOP
2826 007456 012702 040000 MOV #40000,R2
2827 007462 062737 000400 172344 ADD #400,@#KIPAR2
2828 007470 062737 000400 172346 ADD #400,@#KIPAR3
2829 007476 013716 177576 MOV @#SR2,(SP) ;SET RETURN TO INSTRUCTION THAT ABORTED
2830 007502 012737 000001 177572 MOV #1,@#SR0 ;ENABLE MEM MGMT
2831 007510 000002 RTI
2832
2833 .SBTTL 1 XOR 8 ROUTINES
2834 :ROUTINE TO WRITE 1 XOR 8 WORST CASE NOISE PATTERN
2835 :CALL: MOV BANK #,-(SP) ;PUSH STARTING BANK # ON THE STACK
2836 : MOV BLKCNT,-(SP) ;PUSH 128. WORD BLOCK COUNT ON THE STACK
2837 : JSR PC,.1X8
2838
2839 007512 016603 000002 .1X8: MOV 2(SP),R3 ;GET # OF 128. WORD BLOCKS TO WRITE
2840 007516 016602 000004 MOV 4(SP),R2 ;GET STARTING BANK #
2841 007522 004767 177614 JSR PC,STMM2 ;GO SET UP MEM MGMT
2842 007526 012700 177777 1$: MOV #-1,R0 ;SET UP DATA REGISTERS
2843 007532 010005 MOV R0,R5
2844 007534 005105 COM R5
2845
2846 007536 005100 2$: COM R0
2847 007540 005105 COM R5
2848 007542 012704 000010 MOV #8,R4 ;SET 128. WORD COUNTER
2849 007546 010022 3$: MOV R0,(R2)+ ;WRITE 128. WORDS
2850 007550 010522 MOV R5,(R2)+
2851 007552 010022 MOV R0,(R2)+
2852 007554 010522 MOV R5,(R2)+

```

```

2853
2854 007556 010022      MOV      R0,(R2)+
2855 007560 010522      MOV      R5,(R2)+
2856 007562 010022      MOV      R0,(R2)+
2857 007564 010522      MOV      R5,(R2)+
2858
2859 007566 010022      MOV      R0,(R2)+
2860 007570 010522      MOV      R5,(R2)+
2861 007572 010022      MOV      R0,(R2)+
2862 007574 010522      MOV      R5,(R2)+
2863
2864 007576 010022      MOV      R0,(R2)+
2865 007600 010522      MOV      R5,(R2)+
2866 007602 010022      MOV      R0,(R2)+
2867 007604 010522      MOV      R5,(R2)+
2868
2869 007606 005304      DEC      R4          ;DECREMENT 128. WORD COUNTER
2870 007610 001356      BNE     3$
2871 007612 005303      DEC      R3          ;DECREMENT BLOCK COUNT
2872 007614 001350      BNE     2$
2873 007616 012616      MOV      (SP)+,(SP) ;ADJUST STACK
2874 007620 012616      MOV      (SP)+,(SP)
2875 007622 000207      RTS      PC          ;RETURN TO CALLER
2876
2877          ;ROUTINE TO CHECK 1 XOR 8 PATTERN WRITTEN ABOVE
2878          ;CALL: MOV      BANK #,-(SP) ;PUSH STARTING BANK # ON THE STACK
2879          ;      MOV      BLKCNT,-(SP) ;PUSH 128. WORD BLOCK COUNT ON STACK
2880          ;      JSR      PC,..1XB
2881
2882 007624 000240      ..1XB: NOP
2883 007626 004767 002120      JSR      PC,CKSMR   ;GO CHECK SWITCH REGISTER
2884 007632 016667 000002 171116 10$: MOV      2(SP),COUNT ;GET BLOCK COUNT
2885 007640 016602 000004      MOV      4(SP),R2   ;GET STARTING BANK #
2886 007644 004767 177472      JSR      PC,STAM2   ;GO SET UP MEM MGMT
2887 007650 005000      1$: CLR      R0          ;CLEAR TEST WORD
2888 007652 005767 171066      TST      ICOUNT     ;IF BIT 15 OF ICOUNT =1 THEN PATTERN
2889 007656 100401      BMI     .+4         ;IS COMPLEMENTED
2890 007660 005100      COM      R0          ;COMPLEMENT TEST WORD
2891 007662 012705 000040      2$: MOV      #32.,R5   ;SET 128. WORD COUNTER
2892
2893          3$: COM      R0
2894 007670 012203      MOV      (R2)+,R3   ;GET TEST DATA
2895 007672 020003      CMP      R0,R3      ;COMPARE WITH CHECK WORD
2896 007674 001403      BEQ     .+10
2897 007676 005046      CLR     -(SP)       ;PUSH FAKE STATUS ON THE STACK
2898 007700 004767 171270      JSR      PC,ERROR   ;ERROR! MEM DATA (R3) NOT = TEST DATA
2899          ;(R0), ADDRESS=(R2)-2
2900
2901 007704 005100      COM      R0
2902 007706 012203      MOV      (R2)+,R3   ;GET TEST DATA
2903 007710 020003      CMP      R0,R3      ;COMPARE WITH CHECK WORD
2904 007712 001403      BEQ     .+10
2905 007714 005046      CLR     -(SP)       ;PUSH FAKE STATUS ON THE STACK
2906 007716 004767 171252      JSR      PC,ERROR   ;ERROR! MEM DATA (R3) NOT = TEST DATA
2907          ;(R0), ADDRESS=(R2)-2
2908

```

```

2909 007722 005100 COM RO
2910 007724 012203 MOV (R2)+,R3 ;GET TEST DATA
2911 007726 020003 CMP RO,R3 ;COMPARE WITH CHECK WORD
2912 007730 001403 BEQ .+10
2913 007732 005046 CLR -(SP) ;PUSH FAKE STATUS ON THE STACK
2914 007734 004767 171234 JSR PC,ERROR ;ERROR! MEM DATA (R3) NOT = TEST DATA
2915 ;(RO), ADDRESS=(R2)-2
2916
2917 007740 005100 COM RO
2918 007742 012203 MOV (R2)+,R3 ;GET TEST DATA
2919 007744 020003 CMP RO,R3 ;COMPARE WITH CHECK WORD
2920 007746 001403 BEQ .+10
2921 007750 005046 CLR -(SP) ;PUSH FAKE STATUS ON THE STACK
2922 007752 004767 171216 JSR PC,ERROR ;ERROR! MEM DATA (R3) NOT = TEST DATA
2923 ;(RO), ADDRESS=(R2)-2
2924
2925 007756 005305 DEC R5 ;DECREMENT 128. WORD COUNTER
2926 007760 001342 BNE 3$
2927 007762 005100 COM RO ;COMPLEMENT CHECK WORD
2928 007764 005367 170766 DEC COUNT ;DECREMENT BLOCK COUNT
2929 007770 001334 BNE 2$
2930 007772 016602 000004 MOV 4(SP),R2 ;GET BANK #
2931 007776 004767 177340 JSR PC,STMM2
2932 010002 016667 000002 170746 4$: MOV 2(SP),COUNT ;GET # OF 128. WORD BLOCKS TO COMPLEMENT
2933 010010 006367 170730 ASL ICOUNT
2934 010014 102306 BVC 10$
2935 010016 012705 000040 50$: MOV #32.,R5
2936 010022 005122 5$: COM (R2)+ ;COMPLEMENT PATTERN
2937 010024 005122 COM (R2)+
2938 010026 005122 COM (R2)+
2939 010030 005122 COM (R2)+
2940 010032 005305 DEC R5
2941 010034 001372 BNE 5$
2942 010036 005367 170714 DEC COUNT
2943 010042 001365 BNE 50$
2944 010044 005767 170674 TST ICOUNT
2945 010050 001270 BNE 10$
2946 010052 012616 MOV (SP)+,(SP)
2947 010054 012616 MOV (SP)+,(SP)
2948 010056 000207 RTS PC
2949
2950 .SBTTL 3 XOR 9 ROUTINES
2951 ;ROUTINE TO WRITE 3XOR9 WORST CASE NOISE TEST PATTERN
2952 ;CALL: MOV BANK #,-(SP) ;PUSH STARTING BANK # ON STACK
2953 ; MOV BLKCNT,-(SP) ;PUSH 256. WORD BLOCK COUNT ON STACK
2954 ; JSR PC,.3X9 ;CALL ROUTINE
2955
2956 010060 016602 000004 .3X9: MOV 4(SP),R2 ;GET STARTING BANK #
2957 010064 004767 177252 JSR PC,STMM2
2958 010070 005000 CLR RO
2959 010072 010003 MOV RO,R3
2960 010074 005103 COM R3 ;RO (0) AND R3 (-1) IS THE DATA WRITTEN
2961 010076 005767 173260 TST PARPAT ;BRANCH IF PARITY MEMORY PATTERN IS
2962 010102 001402 BEQ 1$ ;NOT TO BE WRITTEN
2963
2964 010104 012700 000401 MOV #401,RO ;WRITE PARITY 3X9 PATTERN

```

```

2965 010110 012704 000020      1$:  MOV      #16.,R4          ;EACH LOOP WRITES 256. WORDS
2966
2967 010114 010022      2$:  MOV      R0,(R2)+
2968 010116 010022      MOV      R0,(R2)+
2969 010120 010022      MOV      R0,(R2)+
2970 010122 010022      MOV      R0,(R2)+
2971
2972 010124 010322      MOV      R3,(R2)+
2973 010126 010322      MOV      R3,(R2)+
2974 010130 010322      MOV      R3,(R2)+
2975 010132 010322      MOV      R3,(R2)+
2976
2977 010134 010022      MOV      R0,(R2)+
2978 010136 010022      MOV      R0,(R2)+
2979 010140 010022      MOV      R0,(R2)+
2980 010142 010022      MOV      R0,(R2)+
2981
2982 010144 010322      MOV      R3,(R2)+
2983 010146 010322      MOV      R3,(R2)+
2984 010150 010322      MOV      R3,(R2)+
2985 010152 010322      MOV      R3,(R2)+
2986
2987 010154 005304      DEC      R4
2988 010156 001356      BNE     2$
2989 010160 005100      COM     R0
2990 010162 005103      COM     R3
2991 010164 005767 173172      TST     PARPAT          ;BRANCH IF PARITY MEMORY PATTERN IS
2992 010170 001402      BEQ     3$              ;NOT TO BE WRITTEN
2993
2994 010172 004767 000014      JSR     PC,XOR39        ;GO GET CONSTANTS
2995 010176 005366 000002      3$:  DEC     2(SP)         ;DECREMENT 256. WORD BLOCK COUNT
2996 010202 001342      BNE     1$
2997 010204 012616      MOV     (SP)+,(SP)      ;ADJUST STACK
2998 010206 012616      MOV     (SP)+,(SP)
2999 010210 000207      RTS     PC
3000
3001      ;ROUTINE TO SET CONSTANTS FOR WRITING/CHECKING 3 XOR PATTERN WITH
3002      ;PARITY.
3003 010212 032702 000010      .XOR39: BIT     #10,R2          ;CHECK BIT 3
3004 010216 001404      BEQ     .3I$0           ;BRANCH IF BIT 3 = 0
3005 010220 032702 001000      .3I$1: BIT     #1000,R2       ;CHECK BIT 9
3006 010224 001404      BEQ     .3NOT9         ;BRANCH IF BIT 9 =0

```


3007	010226	000407			BR	.3IS9	
3008	010230	032702	001000	.3IS0:	BIT	#1000,R2	;CHECK BIT 9
3009	010234	001404			BEQ	.3IS9	;BRANCH IF 0
3010	010236	005767	170502	.3NOT9:	TST	ICOUNT	;CHECK IF NORMAL OR COMPLEMENT DATA
3011	010242	100004			BPL	LDCOMP	;GO LOAD COMPLEMENT CONSTANTS
3012	010244	100410			BMI	LDNORM	;GO LOAD NORMAL CONSTANTS
3013	010246	005767	170472	.3IS9:	TST	ICOUNT	;CHECK IF NORMAL OR COMPLEMENT DATA

3014	010252	100005		BPL	LDNORM		;GO LOAD NORMAL CONSTANTS
3015	010254	012700	177777	LDCOMP: MOV	#-1,RO		;SET COMPLEMENT CONSTANTS
3016	010260	012703	000401		MOV	#401,R3	
3017	010264	000207			RTS	PC	;RETURN
3018	010266	012700	000401	LDNORM: MOV	#401,RO		;LOAD NORMAL CONSTANTS
3019	010272	012703	177777		MOV	#-1,R3	
3020	010276	000207			RTS	PC	
3021							
3022				:ROUTINE TO CHECK 3 XOR 9 WORST	CASE NOISE PATTERN		
3023				:CALL: MOV	BANK#,-(SP)		;PUSH STARTING BANK # ONTO STACK
3024					MOV	BLKCNT,-(SP)	;AND 256. WORD BLOACK COUNT
3025					JSR	PC,..3X9	;CALL ROUTINE

J06

TEST DDQAB-A 0-124K MEMORY EXERCISER
DDQABA.P11 3 XOR 9 ROUTINES

MACY11 27(732) 10-SEP-76 10:35 PAGE 74

3026
3027
3028
3029
3030

010300 000240
010302 004767 001444

..3X9: NOP
JSR PC,CKSWR ;GO CHECK SWITCH REGISTER
;CHECK WORST CASE PATTERN

K06

TEST DDQAB-A 0-124K MEMORY EXERCISER
DDQABA.P11 3 XOR 9 ROUTINES

MACY11 27(732) 10-SEP-76 10:35 PAGE 75

3031 010306 016604 000002

1\$: MOV 2(SP),R4 ;GET 256. BLOCK WORD COUNT

L06

TEST DDQAB-A 0-124K MEMORY EXERCISER
DDQABA.P11 3 XOR 9 ROUTINES

MACY11 27(732) 10-SEP-76 10:35 PAGE 76

3032 010312 016602 000004

MOV 4(SP),R2 ;GET FIRST BANK #

M06

TEST DDQAB-A 0-124K MEMORY EXERCISER
DDQABA.P11 3 XOR 9 ROUTINES

MACY11 27(732) 10-SEP-76 10:35 PAGE 77

3033 010316 004767 177020
3034 010322 005000
3035 010324 005767 170414

JSR PC,STMM2
CLR RO
TST ICOUNT

;GO SET UP MEM MGMT
;SET CHECK WORD
;IF ICOUNT IS NEG AM CHECKING COMP-

TEST DDQAB-A 0-124K MEMORY EXERCISER
DDQABA.P11 3 XOR 9 ROUTINES

MACY11 27(732) 10-SEP-76 10:35 PAGE 78

3036	010330	100001			BPL	.+4		;LEMMENTED PATTERN
3037	010332	005100			COM	RD		;50 COMPLEMENT CHECK WORD
3038	010334	012705	000100	2\$:	MOV	#64.,R5		;SET 256. WORD COUNTER
3039								
3040	010340	005767	173016	3\$:	TST	PARPAT		;BRANCH IF PARITY MEMORY PATTERN IS
3041	010344	001402			BEQ	30\$;NOT TO BE CHECKED

```

3042
3043 010346 004767 177640
3044 010352
3045 010352 012203
3046 010354 020003
3047 010356 001403
3048 010360 005046
3049 010362 004767 170606
3050
3051
3052 010366 012203
3053 010370 020003
3054 010372 001403
3055 010374 005046
3056 010376 004767 170572
3057
3058
3059 010402 012203
3060 010404 020003
3061 010406 001403
3062 010410 005046
3063 010412 004767 170556
3064
3065
3066 010416 012203
3067 010420 020003
3068 010422 001403
3069 010424 005046
3070 010426 004767 170542
3071
3072
3073
3074 010432 005100
3075 010434 005305
3076 010436 001340
3077 010440 005100
3078 010442 005304
3079 010444 001333
3080
3081 010446 032737 040000 177570
3082 010454 001314
3083 010456 016667 000002 170272 40$:
3084 010464 016602 000004
3085 010470 004767 176646
3086
3087
3088 010474 005000
3089 010476 005767 170242
3090 010502 100001
3091 010504 005100
3092 010506 012704 000100 4$:
3093 010512 012705 000004 5$:
3094 010516 005767 172640 6$:
3095 010522 001402
3096 010524 004767 177462
3097 010530 012203 60$:

```

30\$: JSR PC, .XOR39 ;GO GET CONSTANT
MOV (R2)+,R3 ;GET TEST DATA
CMP R0,R3 ;COMPARE WITH CHECK WORD
BEQ .+10
CLR -(SP) ;PUSH FAKE STATUS ON THE STACK
JSR PC,ERROR ;ERROR! MEM DATA (R3) NOT = TEST DATA
;(R0), ADDRESS=(R2)-2

MOV (R2)+,R3 ;GET TEST DATA
CMP R0,R3 ;COMPARE WITH CHECK WORD
BEQ .+10
CLR -(SP) ;PUSH FAKE STATUS ON THE STACK
JSR PC,ERROR ;ERROR! MEM DATA (R3) NOT = TEST DATA
;(R0), ADDRESS=(R2)-2

MOV (R2)+,R3 ;GET TEST DATA
CMP R0,R3 ;COMPARE WITH CHECK WORD
BEQ .+10
CLR -(SP) ;PUSH FAKE STATUS ON THE STACK
JSR PC,ERROR ;ERROR! MEM DATA (R3) NOT = TEST DATA
;(R0), ADDRESS=(R2)-2

MOV (R2)+,R3 ;GET TEST DATA
CMP R0,R3 ;COMPARE WITH CHECK WORD
BEQ .+10
CLR -(SP) ;PUSH FAKE STATUS ON THE STACK
JSR PC,ERROR ;ERROR! MEM DATA (R3) NOT = TEST DATA
;(R0), ADDRESS=(R2)-2

COM R0 ;COMPLEMENT CHECK WORD
DEC R5 ;DECREMENT 256. WORD COUNTER
BNE 3\$
COM R0 ;COMPLEMENT CHECK WORD
DEC R4 ;DECREMENT BLOCK COUNTER
BNE 2\$

BIT #40000, 3\$SWR ;LOOP ON TEST?
BNE 1\$;BRANCH IF LOOP ON TEST DESIRED
MOV 2(SP),COUNT ;GET # OF 256. WORD BLOCKS TO CHECK
MOV 4(SP),R2 ;GET STARTING BANK #
JSR PC,STMM2 ;GO SET UP MEM MGMT IF REQUIRD

;CHECK WORST CASE BIT COMPLEMENT PATTERN
CLR R0
TST ICOUNT ;CHECK IF COMPLEMENT PATTERN
BPL .+4
COM R0 ;COMPLEMENT CHECK WORD
MOV #64, R4 ;SET 256. WORD COUNTER
MOV #4, R5 ;SET 4 WORD COUNTER
TST PARPAT ;BRANCH IF PARITY MEMORY PATTERN IS
BEQ 60\$;NOT TO BE CHECKED
JSR PC, .XOR39
MOV (R2)+,R3 ;GET DATA

3098	010532	020003				CMP	R0, R3		;CHECK DATA
3099	010534	001403				BEQ	.+10		
3100	010536	005046				CLR	-(SP)		
3101	010540	004767	170430			JSR	PC, ERROR		
3102	010544	005100				COM	R0		;COMPLEMENT CHECK WORD
3103	010546	005142				COM	-(R2)		;COMPLEMENT TEST DATA
3104	010550	012203				MOV	(R2)+, R3		;GET DATA
3105	010552	020003				CMP	R0, R3		;CHECK
3106	010554	001403				BEQ	.+10		
3107	010556	005046				CLR	-(SP)		;PUSH FAKE STATUS ON THE STACK
3108	010560	004767	170410			JSR	PC, ERROR		
3109	010564	005100				COM	R0		;COMPLEMENT CHECK WORD
3110	010566	005162	177776			COM	-2(R2)		;RESTORE DATA
3111	010572	005305				DEC	R5		;DECREMENT 4 WORD COUNTER
3112	010574	001350				BNE	6\$		
3113	010576	005100				COM	R0		;COMPLEMENT CHECK WORD
3114	010600	005304				DEC	R4		;DECREMENT 256. WORD COUNTER
3115	010602	001343				BNE	5\$		
3116	010604	005100				COM	R0		;COMPLEMENT CHECK WORD
3117	010606	005367	170144			DEC	COUNT		;DECREMENT BLOCK COUNTER
3118	010612	001335				BNE	4\$		
3119									
3120	010614	016602	000004			MOV	4(SP), R2		;GET BANK #
3121	010620	004767	176516			JSR	PC, STMM2		
3122	010624	016603	000002			MOV	2(SP), R3		;GET BLOCK COUNT
3123	010630	032737	040000	177570		BIT	#40000, 2#SWR		;LOOP ON TEST
3124	010636	001307				BNE	40\$;BRANCH IF LOOP ON TEST
3125	010640	006367	170100			ASL	ICOUNT		
3126	010644	102220				BVC	1\$		
3127	010646	012705	000040		7\$:	MOV	#32, R5		;COMPLEMENT PATTERN
3128	010652	011200			10\$:	MOV	(R2), R0		;GET FIRST DATA WORD
3129	010654	016204	000010			MOV	10(R2), R4		;GET FIFTH DATA WORD
3130	010660	110422				MOVB	R4, (R2)+		;SWAP WORDS 1-4
3131	010662	110422				MOVB	R4, (R2)+		;WITH 5-8

```

3132 010664 110422          MOVB   R4,(R2)+
3133 010666 110422          MOVB   R4,(R2)+
3134 010670 110422          MOVB   R4,(R2)+
3135 010672 110422          MOVB   R4,(R2)+
3136 010674 110422          MOVB   R4,(R2)+
3137 010676 110422          MOVB   R4,(R2)+
3138 010700 110022          MOVB   R0,(R2)+      ;AND VICE VERSA
3139 010702 110022          MOVB   R0,(R2)+
3140 010704 110022          MOVB   R0,(R2)+
3141 010706 110022          MOVB   R0,(R2)+
3142 010710 110022          MOVB   R0,(R2)+
3143 010712 110022          MOVB   R0,(R2)+
3144 010714 110022          MOVB   R0,(R2)+
3145 010716 110022          MOVB   R0,(R2)+
3146 010720 005305          DEC    R5
3147 010722 001353          BNE   10$
3148 010724 005303          DEC    R3
3149 010726 001347          BNE   7$
3150
3151 010730 005767 170010          TST   ICOUNT
3152 010734 001402          BEQ   11$
3153 010736 000167 177344          JMP   1$
3154 010742 012616          11$: MOV   (SP)+,(SP)
3155 010744 012616          MOV   (SP)+,(SP)
3156 010746 000207          RTS   PC
3157
3158          ;ROUTINE TO WRITE 8 XOR 13 WORST CASE NOISE TEST PATTERN
3159          .SBTTL 8 XOR 13 ROUTINES
3160          ;CALL: MOV   BANK #,-(SP)
3161          ;      MOV   #4KBANKS,-(SP)
3162          ;      JSR   PC,.8X13
3163
3164 010750 016604 000002          .8X13: MOV   2(SP),R4      ;GET BANK COUNT
3165 010754 016602 000004          MOV   4(SP),R2      ;GET FIRST BANK #
3166 010760 004767 176356          JSR   PC,STMM2     ;GO SET MEM MGMT
3167 010764 005000          1$: CLR   R0
3168 010766 012705 000040          2$: MOV   #32.,R5   ;EACH LOOP WRITES 4K WORDS
3169 010772 005100          COM   R0
3170 010774 012703 000200          3$: MOV   #128.,R3  ;EACH SMALL LOOP WRITES 128 WORDS
3171 011000 005100          COM   R0
3172 011002 010022          4$: MOV   R0,(R2)+  ;WRITE INTO MEMORY ADDRESSES
3173 011004 005303          DEC   R3            ;DECREMENT WORD COUNT
3174 011006 001375          BNE   4$
3175 011010 005305          DEC   R5            ;DECREMENT 128. WORD COUNT
3176 011012 001370          BNE   3$
3177 011014 005304          DEC   R4            ;DECREMENT 4K BANK COUNT
3178 011016 001363          BNE   2$           ;LOOP UNTIL DONE
3179 011020 012616          MOV   (SP)+,(SP)   ;ADJUST STACK
3180 011022 012616          MOV   (SP)+,(SP)
3181 011024 000207          RTS   PC
3182
3183          ;ROUTINE TO CHECK 8 XOR 13 WORST CASE NOISE TEST PATTERN
3184          ;CALL:
3185          ;      MOV   BANK #,-(SP)      ;PUSH FIRST BANK # ON THE STACK
3186          ;      MOV   #BANKS,-(SP)     ;PUSH # OF 4K BANKS TO CHECK ON THE STACK
3187          ;      JSR   PC,..8X13        ;CALL ROUTINE

```

3188								
3189	011026	000240		..BX13:	NOP			
3190	011030	004767	000716		JSR	PC,CKSWR		;CO CHECK SWITCH REGISTER
3191	011034	012700	177777		MOV	#-1,R0		;SET TEST DATA WORD
3192	011040	016602	000004	10\$:	MOV	4(SP),R2		;GET BANK #
3193	011044	004767	176272		JSR	PC,STMM2		;GO SET MEM MGMT IF REQUIRED
3194	011050	016667	000002	167700	MOV	2(SP),COUNT		;GET # OF 4K BANKS TO CHECK
3195								
3196	011056	012704	000040	1\$:	MOV	#32.,R4		;SET 4K WORD COUNTER
3197	011062	005100		2\$:	COM	R0		;COMPLEMENT TEST WORD
3198	011064	012705	000100		MOV	#64.,R5		;SET 128 WORD COUNTER
3199								
3200	011070			3\$:				
3201	011070	012203			MOV	(R2)+,R3		;GET TEST DATA
3202	011072	020003			CMP	R0,R3		;COMPARE WITH CHECK WORD
3203	011074	001403			BEQ	+.10		
3204	011076	005046			CLR	-(SP)		;PUSH FAKE STATUS ON THE STACK
3205	011100	004767	170070		JSR	PC,ERROR		;ERROR! MEM DATA (R3) NOT = TEST DATA
3206								; (R0), ADDRESS=(R2)-2
3207								
3208	011104	012203			MOV	(R2)+,R3		;GET TEST DATA
3209	011106	020003			CMP	R0,R3		;COMPARE WITH CHECK WORD
3210	011110	001403			BEQ	+.10		
3211	011112	005046			CLR	-(SP)		;PUSH FAKE STATUS ON THE STACK
3212	011114	004767	170054		JSR	PC,ERROR		;ERROR! MEM DATA (R3) NOT = TEST DATA
3213								; (R0), ADDRESS=(R2)-2
3214								
3215	011120	005305			DEC	R5		;DECREMENT 128 WORD COUNTER
3216	011122	001362			BNE	3\$		
3217	011124	005304			DEC	R4		;DECREMENT 4096. WORD COUNTER
3218	011126	001355			BNE	2\$		
3219	011130	005100			COM	R0		
3220	011132	005367	167620		DEC	COUNT		;ALL 4K BANKS CHECKED?
3221	011136	001347			BNE	1\$		
3222								
3223	011140	016602	000004		MOV	4(SP),R2		;GET FIRST BANK ADDRESS
3224	011144	004767	176172		JSR	PC,STMM2		;GO SET UP MEM MGMT IF REQUIRED
3225	011150	016604	000002		MOV	2(SP),R4		;GET # OF 4K BANKS
3226	011154	006367	167564		ASL	ICOUNT		;SHIFT ITERATION PATTERN
3227	011160	001401			BEQ	+.4		
3228	011162	102326			BVC	10\$		
3229	011164	012705	004000	40\$:	MOV	#2048.,R5		;SET 4096. WORD COUNTER
3230	011170	005122		4\$:	COM	(R2)+		;COMPLEMENT TEST PATTERN
3231	011172	005122			COM	(R2)+		
3232	011174	005305			DEC	R5		
3233	011176	001374			BNE	4\$		
3234	011200	005304			DEC	R4		
3235	011202	001370			BNE	40\$		
3236	011204	005100			COM	R0		;COMPLEMENT TEST WORD
3237	011206	005767	167532		TST	ICOUNT		
3238	011212	001312			BNE	10\$		
3239	011214	012616			MOV	(SP)+,(SP)		
3240	011216	012616			MOV	(SP)+,(SP)		
3241	011220	000207			RTS	PC		;RETURN
3242								
3243								

.SBTTL ROTATING 1'S & 0'S ROUTINES

```

3244      ;ROUTINE TO CHECK ROTATING '0' BIT THROUGH FIELD OF 1'S
3245      ;CALL:  MOV   BANK#,-(SP)      ;SET STARTING BANK #
3246      ;       MOV   BLKCNT,-(SP)     ;SET 256. WORD BLOCK COUNT
3247      ;       JSR   PC,.ROT0        ;CALL ROUTINE
3248
3249      .ROT0: JSR   PC,CKSWR          ;GO CHECK SWITCHES
3250      ;       MOV   2(SP),R4         ;GET 256. WORD BLOCK COUNT
3251      ;       MOV   4(SP),R2         ;GET FIRST BANK #
3252      ;       JSR   PC,STMM2        ;GO SET UP MEM MGMT (IF AVAIL)
3253      ;       MOV   #-1,R0          ;SET CHECK WORD
3254
3255      1$:   MOV   #256.,R5           ;SET 256. WORD COUNT
3256      2$:   CLC                       ;CLEAR CARRY BIT IN PSW
3257      ;       JSR   PC,ROTATE        ;
3258      ;       MOV   -2(R2),R3        ;GET RESULT
3259      ;       BCS   3$              ;BRANCH IF 'C' BIT WAS SET
3260      ;       CMP   R0,R3           ;CHECK RESULT
3261      ;       BEQ   4$              ;
3262      3$:   CLR   -(SP)              ;ERROR! COULD NOT ROTATE '0' BIT
3263      ;       JSR   PC,ERROR         ;THROUGH ADDRESS IN R2
3264      4$:   DEC   R5                 ;DECREMENT 256. WORD COUNT
3265      ;       BNE   2$              ;LOOP UNTIL DONE
3266      ;       DEC   R4               ;DECREMENT 256. WORD BLOCK COUNT
3267      ;       BNE   1$              ;LOOP UNTIL DONE
3268      ;       MOV   (SP)+,(SP)       ;POP CONSTANTS OFF THE STACK
3269      ;       MOV   (SP)+,(SP)       ;
3270      ;       RTS   PC               ;RETURN TO CALLER
3271
3272      ;ROUTINE TO CHECK ROTATING '1' BIT THROUGH A FIELD OF 0'S
3273      ;CALL:  MOV   BANK#,-(SP)      ;SET STARTING BANK #
3274      ;       MOV   BLKCNT,-(SP)     ;SET # OF 256. WORD BLOCKS TO CHECK
3275      ;       JSR   PC,.ROT1        ;CALL ROUTINE
3276
3277      .ROT1: JSR   PC,CKSWR          ;GO CHECK SWITCHES
3278      ;       MOV   2(SP),R4         ;GET # OF 256. WORD BLOCKS TO CHECK
3279      ;       MOV   4(SP),R2         ;GET STARTING BANK #
3280      ;       JSR   PC,STMM2        ;GO SET UP MEM MGMT (IF AVAIL)
3281      ;       CLR   R0              ;SET CHECK WORD
3282
3283      1$:   MOV   #256.,R5           ;SET 256. WORD COUNTER
3284      2$:   SEC                       ;SET 'C' BIT IN PSW
3285      ;       JSR   PC,ROTATE        ;GO ROTATE '1' BIT
3286      ;       MOV   -2(R2),R3        ;GET RESULT
3287      ;       BCC   3$              ;BRANCH IF 'C' IS CLEAR
3288      ;       CMP   R0,R3           ;CHECK RESULT
3289      ;       BEQ   .+4              ;
3290      3$:   HLT                       ;ERROR! COULD NOT ROTATE '1' BIT
3291      ;       ;THROUGH ADDRESS IN R2
3292      ;       DEC   R5                 ;DECREMENT 256. WORD COUNT
3293      ;       BNE   2$              ;
3294      ;       DEC   R4               ;DECREMENT 256. WORD BLOCK COUNT
3295      ;       BNE   1$              ;
3296      ;       MOV   (SP)+,(SP)       ;ADJUST RETURN ADDRESS
3297      ;       MOV   (SP)+,(SP)       ;
3298      ;       RTS   PC               ;RETURN TO CALLER
3299

```

```

3300          ;ROUTINE TO ROTATE 'C' BIT THROUGH A MEMORY LOCATION.
3301 011404 106112 ROTATE: ROLB (R2) ;(R2)=177776 OR 000001
3302 011406 106112          ROLB (R2) ;(R2)=177775 OR 000002
3303 011410 106112          ROLB (R2) ;(R2)=177773 OR 000004
3304 011412 106112          ROLB (R2) ;(R2)=177767 OR 000010
3305 011414 106112          ROLB (R2) ;(R2)=177757 OR 000020
3306 011416 106112          ROLB (R2) ;(R2)=177737 OR 000040
3307 011420 106112          ROLB (R2) ;(R2)=177677 OR 000100
3308 011422 106112          ROLB (R2) ;(R2)=177777 OR 000000
3309 011424 106122          ROLB (R2)+ ;(R2)=177577 OR 000200
3310 011426 106112          ROLB (R2) ;(R2)=177377 OR 000400
3311 011430 106112          ROLB (R2) ;(R2)=176777 OR 001000
3312 011432 106112          ROLB (R2) ;(R2)=175777 OR 002000
3313 011434 106112          ROLB (R2) ;(R2)=173777 OR 004000
3314 011436 106112          ROLB (R2) ;(R2)=167777 OR 010000
3315 011440 106112          ROLB (R2) ;(R2)=157777 OR 020000
3316 011442 106112          ROLB (R2) ;(R2)=137777 OR 040000
3317 011444 106112          ROLB (R2) ;(R2)=077777 OR 100000
3318 011446 106122          ROLB (R2)+ ;(R2)=177777 OR 000000
3319 011450 000207          RTS PC ;RETURN
3320
3321          ;ROUTINE TO WRITE USER SLECTED PATTERN INTO MEMORY
3322          ;CALL: MOV BANK#,-(SP) ;PUSH STARTING BANK # ONTO STACK
3323          ;MOV BLKCNT,-(SP) ;AND 128. WORD BLOCK COUNT
3324          ;JSR PC,..USER ;CALL ROUTINE
3325
3326 011452 016604 000002 .USER: MOV 2(SP),R4 ;GET BLOCK COUNT
3327 011456 016602 000004          MOV 4(SP),R2 ;GET STARTING BANK #
3328 011462 004767 175654          JSR PC,STMM2 ;GO SET UP MEM MGMT
3329 011466 016700 174012          MOV .CONST,R0 ;GET USER CONSTANT
3330 011472 012703 000100          1$: MOV #64.,R3 ;SET 256. WORD COUNTER
3331 011476 010022          2$: MOV R0,(R2)+ ;WRITE 256. WORDS
3332 011500 010022          MOV R0,(R2)+
3333 011502 010022          MOV R0,(R2)+
3334 011504 010022          MOV R0,(R2)+
3335 011506 005303          DEC R3 ;DECREMENT 256. WORD COUNTER
3336 011510 001372          BNE 2$ ;LOOP UNTIL 256. WORDS HAVE BEEN WRITTEN
3337 011512 005304          DEC R4 ;DECREMENT BLOCK COUNT
3338 011514 001366          BNE 1$
3339 011516 012616          MOV (SP)+,(SP) ;ADJUST STACK
3340 011520 012616          MOV (SP)+,(SP)
3341 011522 000207          RTS PC
3342
3343          .SBTTL USER PATTERN ROUTINE
3344          ;ROUTINE TO CHECK USER SELECTED PATTERN
3345          ;CALL: MOV BANK#,-(SP) ;PUSH STARTING BANK # ONTO STACK
3346          ;MOV BLKCNT,-(SP) ;AND 256. WORD BLOCK COUNT
3347          ;JSR PC,..USER ;CALL ROUTINE
3348
3349 011524 004767 000222 ..USER: JSR PC,CKSWR ;GO CHECK SWITCH REGISTER
3350 011530 016700 173750          MOV .CONST,R0 ;GET USER CONSTANT
3351 011534 016604 000002          1$: MOV 2(SP),R4 ;GET # OF 256. WORD BLOCKS
3352 011540 016602 000004          MOV 4(SP),R2 ;GET STARTING BANK #
3353 011544 004767 175572          JSR PC,STMM2 ;GO SET UP MEM MGMT IF REQUIRED
3354
3355 011550 012705 000100          2$: MOV #64.,R5 ;SET WORD COUNT

```

```

3356 011554          335:  MOV      (R2)+,R3      ;GET TEST DATA
3357 011554 012203  CMP      R0,R3        ;COMPARE WITH CHECK WORD
3358 011556 020003  BEQ      .+10         ;
3359 011560 001403  CLR      -(SP)        ;PUSH FAKE STATUS ON THE STACK
3360 011562 005046  JSR      PC,ERROR     ;ERROR! MEM DATA (R3) NOT = TEST DATA
3361 011564 004767 167404 ;(R0), ADDRESS=(R2)-2
3362
3363
3364 011570 012203  MOV      (R2)+,R3      ;GET TEST DATA
3365 011572 020003  CMP      R0,R3        ;COMPARE WITH CHECK WORD
3366 011574 001403  BEQ      .+10         ;
3367 011576 005046  CLR      -(SP)        ;PUSH FAKE STATUS ON THE STACK
3368 011600 004767 167370 ;ERROR! MEM DATA (R3) NOT = TEST DATA
3369 ;(R0), ADDRESS=(R2)-2
3370
3371 011604 012203  MOV      (R2)+,R3      ;GET TEST DATA
3372 011606 020003  CMP      R0,R3        ;COMPARE WITH CHECK WORD
3373 011610 001403  BEQ      .+10         ;
3374 011612 005046  CLR      -(SP)        ;PUSH FAKE STATUS ON THE STACK
3375 011614 004767 167354 ;ERROR! MEM DATA (R3) NOT = TEST DATA
3376 ;(R0), ADDRESS=(R2)-2
3377
3378 011620 012203  MOV      (R2)+,R3      ;GET TEST DATA
3379 011622 020003  CMP      R0,R3        ;COMPARE WITH CHECK WORD
3380 011624 001403  BEQ      .+10         ;
3381 011626 005046  CLR      -(SP)        ;PUSH FAKE STATUS ON THE STACK
3382 011630 004767 167340 ;ERROR! MEM DATA (R3) NOT = TEST DATA
3383 ;(R0), ADDRESS=(R2)-2
3384
3385 011634 005305  DEC      R5            ;DECREMENT WORD COUNT
3386 011636 001346  BNE     3385          ;
3387 011640 005304  DEC      R4            ;DECREMENT BLOCK COUNT
3388 011642 001342  BNE     2385          ;
3389
3390 011644 032737 040000 177570 BIT      #40000,2#SWR  ;CHECK LOOP SWITCH
3391 011652 001330  BNE     13            ;LOOP CHECKING THIS PATTERN
3392 011654 006367 167064  ASL     ICOUNT        ;SHIFT PATTERN INDICATOR
3393 011660 001325  BNE     13            ;
3394 011662 012616  MOV     (SP)+,(SP)    ;ADJUST STACK
3395 011664 012616  MOV     (SP)+,(SP)    ;
3396 011666 000207  RTS     PC            ;RETURN TO CALLER
3397
3398
3399
3400
3401
3402
3403 011670          .SBTTL GET TTY INPUT ROUTINE
3404 011670 004767 166410 ;ROUTINE TO GET ASCII INPUT FROM TTY,AND CONVERT TO OCTAL.
3405 011674 004767 002172 ;ROUTINE LEAVES THE FIRST 16 BITS IN ADDRESS FOLLOWING THE CALL
3406 011700 010267 000042 ;AND THE LAST 2 BITS IN .1617 BELOW.
3407 011704 010367 000040 ;CALL: JSR PC,RECD
3408 011710 004767 166414 RECD: JSR PC,$SAVR ;GO SAVE REGISTERS ON THE STACK
3409 011714 011667 000024 JSR PC,INUM
3410 011720 016777 000024 MOV R2,TEMP2
3411 011726 016767 000014 MOV R3,TEMP3
                                MOV R3,$RESTR ;RESTORE REGISTERS FROM STACK
                                MOV (SP),TEMP1
                                MOV TEMP3,2TEMP1
                                MOV TEMP2,.1617

```

```

3412 011734 062716 000002
3413 011740 000207
3414 011742 000000
3415 011744 000000
3416 011746 000000
3417 011750 000000
3418
3419
3420
3421
3422 011752 042767 017777 166770
3423 011760 032737 000400 177570
3424 011766 001402
3425 011770 004767 000464
3426 011774 032737 001000 177570
3427 012002 001404
3428 012004 056767 166736 166736
3429 012012 000403
3430 012014 056767 166722 166726
3431 012022 016737 166722 177570
3432 012030 012767 040177 166706
3433 012036 032737 004000 177570
3434 012044 001402
3435 012046 105067 166672
3436 012052 000207
3437
3438
3439 012054 005015 047524 051040
3440 012062 051505 047524 042522
3441 012070 046040 040517 042504
3442 012076 051522 051440 040524
3443 012104 052122 040440 020124
3444 012112 033061 006462 000012
3445 012120 005015 047105 041101
3446 012126 042514 050040 051101
3447 012134 052111 037531 030440
3448 012142 030057 054475 051505
3449 012150 047057 020117 000
3450 012155 015 051412 040524
3451 012162 052122 047111 020107
3452 012170 040502 045516 021440
3453 012176 034050 037451 000040
3454 012204 005015 020043 043117
3455 012212 032040 020113 040502
3456 012220 045516 020123 047524
3457 012226 052040 051505 024124
3458 012234 024470 020077 000
3459 012241 015 050012 052101
3460 012246 042524 047122 021440
3461 012254 020077 000
3462 012257 015 037412 000
3463 012263 015 052012 050131
3464 012270 020105 047503 051516
3465 012276 040524 052116 000
3466 012303 015 044412 050116
3467 012310 052125 021440 047440

```

```

ADD #2,(SP)
RTS PC
.1617: .WORD 0
TEMP1: .WORD 0
TEMP2: .WORD 0
TEMP3: .WORD 0

;ROUTINE TO CHECK THE SWITCH REGISTER
;CHECK SWITCH 9: IF SET, LOAD ERROR COUNT INTO THE DISPLAY REGISTER;
;IF NOT SET, LOAD PASS COUNT INTO THE DISPLAY REGISTER
CKSWR: BIC #17777,LDISP ;SAVE RELOCATION BITS
        BIT #BIT8,#SWR ;CHECK SWITCH 8
        BEQ 10$ ;BRANCH IF SET
        JSR PC,REL24K ;GO RELOCATE PROGRAM BACK TO 4K AND STOP
10$: BIT #BIT9,#SWR ;SWITCH 9 SET ?
        BEQ 1$
        BIS ERCNT,LDISP ;LOAD ERROR COUNT
2$: BR 2$
1$: BIS ICNT,LDISP ;LOAD PASS COUNT
2$: MOV LDISP,#DISPLAY ;LOAD THE DISPLAY REGISTER
        MOV #040177,ICOUNT ;LOAD ITERATION COUNT WORD
        BIT #4000,#SWR ;CHECK SW11
        BEQ +6
        CLRB ICOUNT ;ICOUNT =040000 IF SW11 =1
        RTS PC

;MESSAGES
RESLDR: .ASCIZ <15><12>'TO RESTORE LOADERS START AT 162'<15><12>'
PARITY: .ASCIZ <15><12>'ENABLE PARITY? 1/0=YES/NO '
STBANK: .ASCIZ <15><12>'STARTING BANK #(8)? '
BANKS: .ASCIZ <15><12>'# OF 4K BANKS TO TEST(8)? '
PAT: .ASCIZ <15><12>'PATTERN #'
QUEST: .ASCIZ <15><12>'?'
CONST: .ASCIZ <15><12>'TYPE CONSTANT'
PRG3M: .ASCIZ <15><12>'INPUT # OF 256. WORD BLOCKS TO TEST INSTEAD OF'

```

```

3468 012316 020106 032462 027066
3469 012324 053440 051117 020104
3470 012332 046102 041517 051513
3471 012340 052040 020117 042524
3472 012346 052123 044440 051516
3473 012354 042524 042101 047440
3474 012362 000106
3475 012364 005015 054524 042520
3476 012372 040440 042104 042522
3477 012400 051523 000
3478 012403 015 052012 020117
3479 012410 042522 052123 051117
3480 012416 020105 051120 043517
3481 012424 040522 020115 052123
3482 012432 051101 020124 052101
3483 012440 000040
3484 012442 000052
3485 012444 042104 040521 020102
3486 012452 047504 042516 000041
3487
3488
3489
3490 012460 010700
3491 012462 042700 017777
3492 012466 010067 000004
3493 012472 004567 173652
3494 012476 000000
3495 012500 000000
3496 012502 012706 000500
3497 012506 042737 100000 000750
3498 012514 013737 000750 177570
3499 012522 005037 000754
3500 012526 000005
3501 012530 005037 000176
3502 012534 000137 000162
3503
3504
3505
3506
3507
3508
3509
3510
3511
3512
3513
3514
3515
3516
3517
3518
3519
3520
3521
3522
3523

```

PRG4M: .ASCIZ <15><12>'TYPE ADDRESS'

RELOCM: .ASCIZ <15><12>'TO RESTORE PROGRAM START AT '

ASTERISK: .ASCIZ '*'
ENDMSG: .ASCIZ 'DDQAB DONE!'

.EVEN

:ROUTINE TO RELOCATE PROGRAM BACK TO 0

```

REL24K: MOV PC,RO ;FORM BASE ADDRESS WHERE CODE
        BIC #17777,RO ;IS RELOCATED
        MOV RO,1$ ;PUT FROM ADDRESS INTO SUBROUTINE CALL
        JSR RS,RELOC ;RELOCATE CODE TO
1$:      0 ;LOWEST 4K
        0
        MOV #STKPTR,SP ;SET STACK PTR
        BIC #100000,2#LDDISP ;CLEAR RELOCATION INDICATOR
        MOV 2#LDDISP,2#DISPLAY ;LOAD DISPLAY REGISTER
        CLR 2#RELOCF ;CLEAR RELOCATION FACTOR
        RESET ;DISABLE MEM MGMT
        CLR 2#176 ;PUT A HALT AT 176
        JMP 2#162 ;RESTORE LOADERS & HALT AT 176

```

.SBTTL BRANCH GOBBLE MOS MEMORY TEST

*****PROGRAM DESCRIPTION*****

```

;THIS IS A PSEUDO-MODIFIED VERSION OF THE BRANCH GOBBLE
;MOS MEMORY EXERCISER. PSEUDO-MODIFIED BECAUSE THE
;ORIGINAL CODE, TAKEN FROM THE DZQKA-A INSTRUCTION
;EXERCISER, WHICH IS BRANCH GOBBLE IS INCLUDED
;HERE IN ITS ORIGINAL FORM, BUT MEMORY MANAGEMENT
;CAPABILITIES HAVE BEEN ADDED TO GIVE IT OPERATING
;ABILITIES IN A 0-128K MEMORY ENVIRONMENT.

```

*****OPERATING PROCEDURE*****

```

;WHEN LOADED THIS PROGRAM'S STARTING ADDRESS IS XXXXXX.
;WHEN RUNNING THE FOLLOWING STEPS ARE TAKEN:
;1.) A PROGRAM ID IS TYPED ON THE TTY:
;    BRANCH GOBBLE MOS TEST
;1.5) THE PROGRAM DETERMINES IF THERE IS MOS PARITY. IF YES IT IS ENABLED

```


3524
3525
3526
3527
3528
3529
3530
3531
3532
3533
3534
3535
3536
3537
3538
3539
3540
3541
3542
3543
3544
3545
3546
3547
3548
3549
3550
3551
3552
3553
3554
3555
3556
3557
3558
3559
3560
3561
3562
3563
3564
3565
3566
3567
3568
3569
3570
3571
3572
3573
3574
3575
3576
3577
3578
3579

AND THE USER IS TOLD.
2.) THE USER IS ASKED:
USE MEMORY MANAGEMENT?(Y OR N)
)
IF THE USER TYPES Y, THE MEMORY MANAGEMENT
WILL BE USED TO RUN THE TEST. IF HE TYPES
N THEN MEMORY MANAGEMENT WILL NOT BE USED
IN EITHER CASE THE ACTUAL TEST WILL BE
PERFORMED BY THE UNMODIFIED ORIGINAL VERSION
OF BRANCH GOBBLE.
NOTE THAT WHEN THE TEST OF MEMORY
LOCATED IN UNIBUS ADDRESSES HIGHER THAN
177777 IS DESIRED, THE ENABLING OF MEMORY
MANAGEMENT IN THIS PROGRAM IS MANDATORY.
NOTE ALSO THAT WHEN THE TEST IS TO BE
IN THE 0 TO 177777 RANGE OF UNIBUS ADDRESSES
IT IS RECOMMENDED THAT MEMORY MANAGEMENT
BE DISABLED.
3.) THE PROGRAM WILL THEN ASK THE USER
FOR THE HIGH ADDRESS LIMIT FOR THE TEST:
WHAT IS THE HIGH LIMIT:
)
AND THEN FOR THE LOW LIMIT:
WHAT IS THE LOW LIMIT:
)
BOTH OF THE ADDRESSES SHOULD BE SPECIFIED IN
OCTAL USING THE FORM XXXX00, THAT IS THE
ADDRESSES MUST BE THE BEGINNING OF 100 BYTE
BLOCKS OF MEMORY. IF THEY ARE NOT THEN THEY
WILL BE TRUNCATED!
THE ADDRESSES WILL BE INTERPRETED AS FULL 18-BIT
UNIBUS ADDRESSES.
VALID ADDRESSES MEET THE FOLLOWING CONDITIONS:
1. THE SPECIFIED SPAN OF THE TEST
SHOULD NOT ENCOMPASS THE ACTUAL
MEMORY LOCATIONS OCCUPIED BY THIS
PROGRAM. THIS PROGRAM IS RELOCATABLE
AT LOADING TIME, SO THAT NO LIMITATIONS
ARE THUS IMPOSED.
2. THE HIGH LIMIT SHOULD BE GREATER
THAN THE LOW LIMIT.
3. THE NUMBER MUST BE SPECIFIED BY
OCTAL DIGITS.
4. IF THE USER HAS DISABLED MEMORY
MANAGEMENT THE ADDRESSES SHOULD BE
IN LOW MEMORY. I.E. LESS THAN 177777.
IF ANY OF THESE CONDITIONS IS NOT MET
THE USER WILL BE ASKED TO INPUT ANOTHER
ADDRESS.
NOTE THAT IF ANY OF THE ADDRESSES IN THE TEST
SPAN IS A NON-EXISTANT MEMORY LOCATION
A TIME OUT ERROR WILL OCCUR FROM WHICH
NO RECOVERY CAN BE MADE EXCEPT TO RESTART
AT THE STARTING ADDRESS.
4.) WHEN THE ABOVE INFORMATION HAS BEEN
SUCCESSFULLY GATHERED FROM THE USER, THE

```

3580
3581
3582
3583
3584
3585
3586
3587
3588
3589
3590
3591
3592
3593
3594
3595
3596
3597
3598
3599
3600
3601 012540
3602
3603 077406
3604
3605
3606
3607
3608
3609
3610
3611 012540 000000
3612
3613
3614 012542 005067 165352
3615 012546 005067 166200
3616 012552 004567 166202
3617 012556 015310
3618 012560 004767 167254
3619 012564 004767 001566
3620 012570
3621 012570 004567 166164
3622 012574 015243
3623
3624 012576 105737 177560
3625 012602 100375
3626 012604 113746 177562
3627 012610 042716 177600
3628 012614 004767 001520
3629 012620 005726
3630 012622 022766 000131 177776
3631 012630 001513
3632
3633 012632 022766 000116 177776
3634 012640 001406
3635 012642 012746 000077

```

```

TEST WILL BEGIN. IF BRANCH GOBBLE ENCOUNTERS
A MEMORY FAULT DURING THE TEST THE
PROCESSOR WILL BE HALTED AT THE "LOCATION"
OF THE MEMORY FAULT.
5.) IF THE TEST IS COMPLETE WITHOUT AN
ENCOUNTER WITH A MEMORY FAULT ANY WHERE
IN THE TESTED SPAN, THEN THE TEST
WILL BE REPEATED BY RETURNING TO STEP 4.
6.) IF THE USER WISHES TO STOP THE TEST IN PROGRESS AND START
ANOTHER WITH A DIFFERENT RANGE THEN HE SHOULD HIT THE HALT
SWITCH AND START THE TEST AGAIN AT 260.

TOP:
;CONSTANTS:
KPDR=077406
;THIS ROUTINE TAKES CARE OF THE IDENTIFICATION,
;ASK THE USER IF MEMORY MANAGEMENT SHOULD BE
;ENABLED, AND IF NOT DOES THE SET UP FOR THE
;ACTUAL TEST. IF MEMORY MANAGEMENT IS
;DESIRED THE ROUTINE YMMBGO IS GIVEN CONTROL.

LODFLG: .WORD 0

BRANCH: CLR RELFL ;INITIALIZE THE RELOCATION INDICATOR.
CLR MMAVA ;INITIALIZE THE MEM. MANAGEMENT FLAG.
JSR RS,$PRINT ;GO TO PRINT ROUTINE
.WORD IDMESS
JSR PC,$LDR
15$: JSR PC,MOSPAR
1$: JSR RS,$PRINT ;GO TO PRINT ROUTINE
.WORD MMESS ;MEMORY MANAGEMENT SHOULD
;BE ENABLED
2$: TST @#TKS ;WAIT FOR A CHARACTER.
BPL 2$
MOVB @#TKB,-(SP) ;GET THE CHARACTER.
BIC #177600,(SP)
JSR PC,TYPIT ;ECHO THE CHARACTER.
TST (SP)+ ;RESET THE STACK.
CMP #'Y,-2(SP) ;IF IT IS Y, THEN GO
BEQ YMMBGO ;TO YMMBGO TO ENABLE
;MEMORY MANAGEMENT
CMP #'N,-2(SP) ;IS IT N?
BEQ 3$
MOV #'?,-(SP) ;IF IT WAS NIETHER

```

```

3636 012646 004767 001466 JSR PC,TYPIT ;Y OR N THEN ASK
3637 012652 005726 TST (SP)+ ;THE USER AGAIN.
3638 012654 000745 BR 1$
3639 012656 004767 001066 3$: JSR PC,LIMITS ;GO GET THE LIMITING
3640 ;ADDRESSES FOR THE TEST.
3641 ;THEY WILL BE LEFT AS
3642 ;BLOCK NUMBERS IN LOLIM
3643 ;AND HILIM.
3644 012662 022767 001600 001172 SPOT: CMP #1600,HILIM
3645 012670 002010 BGE SPOT2
3646 012672 012700 177770 MOV #SPOT--,RO
3647 012676 060700 ADD PC,RO
3648 012700 062700 177772 ADD #-6,RO
3649 012704 010046 MOV RO,-(SP)
3650 012706 000167 001140 JMP LIMERR
3651 012712 005046 SPOT2: CLR -(SP)
3652 012714 012746 002502 MOV #FIRST1--,-(SP)
3653 012720 060716 ADD PC,(SP)
3654 012722 062716 177772 ADD #-6,(SP)
3655 012726 004767 000774 JSR PC,LOSEG4
3656 012732 004767 000436 JSR PC,LOSEG1
3657 012736 012746 000052 REPET1: MOV #*,-(SP)
3658 012742 004767 001372 JSR PC,TYPIT
3659 012746 005726 TST (SP)+
3660 012750 022767 000200 001104 CMP #200,HILIM
3661 012756 002026 BGE REPET3
3662 012760 016700 001076 MOV HILIM,RO
3663 012764 004767 000054 4$: JSR PC,ROT
3664 012770 010067 002556 MOV RO,HI ;SET THE PARAMETERS
3665 ;IN THE ACTUAL TEST
3666 ;ROUTINE.
3667 012774 016700 001064 MOV LOLIM,RO ;DO THE SAME FOR THE
3668 ;LOW ADDRESS LIMIT.
3669 013000 004767 000040 JSR PC,ROT
3670 013004 010067 002544 MOV RO,LO
3671 013010 005037 000036 CLR #36 ;SET UP THE VECTORS
3672 013014 012704 000020 MOV #REPET3--,R4 ;FOR AN INTERRUPT
3673 013020 060704 ADD PC,R4 ;FROM A TRAP INSTRUCTION
3674 013022 062704 177772 ADD #-6,R4 ;WHICH WILL BE USED TO
3675 013026 010437 000034 MOV R4,#34 ;RETURN FROM THE TEST
3676 ;ROUTINE WHEN IT IS DONE.
3677 013032 000002 RTI ;START THE TEST.
3678 013034 004767 000404 REPET3: JSR PC,LOSEG2
3679 013040 000167 177672 JMP REPET1
3680 ;
3681 ;THIS ROUTINE IS CALLED TO SHIFT RO TO THE LEFT SIX BITS.
3682 013044 012701 177772 ROT: MOV #-6,R1
3683 013050 006300 1$: ASL RO
3684 013052 005201 INC R1
3685 013054 002775 BLT 1$
3686 013056 000207 RTS PC
3687 ;
3688 ;YMMBGO SETS UP FOR USING MEMORY MANAGEMENT TO
3689 ;DO THE MOS TEST.
3690 ;ALL THE MEMORY MANAGEMENT REGISTERS WHICH ARE
3691 ;TO REMAIN STATIC FOR THE TESTS DURATION ARE SET.

```

```

3692 ; THE LIMITS ARE THEN GOTTEN AND CHECKED FOR VALIDITY.
3693 ; THE TRAP INTERRUPT VECTORS ARE SET AND YMMBG1
3694 ; IS CALLED. YMMBG1 IS A ROUTINE THE SETS THOSE
3695 ; MEMORY MANAGEMENT REGISTERS WHICH NEED TO
3696 ; BE CHANGED DYNAMICALLY DURING THE TEST.
3697
3698 013060 012767 177777 165664 YMMBG0: MOV #-1,MMAVA
3699 013066 005037 177572 CLR @#SRO ;SET ALL THE STATIC
3700 013072 012700 172340 MOV #KIPARO,R0 ;REGISTERS.
3701 013076 012701 172300 MOV #KIPDRO,R1
3702 013102 005003 CLR R3
3703 013104 012704 177770 MOV #-10,R4
3704 013110 010320 1$: MOV R3,(R0)+
3705 013112 062703 000200 ADD #200,R3
3706 013116 012721 077406 MOV #KPDR,(R1)+
3707 013122 005204 INC R4
3708 013124 001371 BNE 1$
3709 013126 004767 000616 JSR PC,LIMITS ;GET THE LIMITS FOR THE PENDING
3710 ;TEST. THEY ARE LEFT IN BLOCK NUMBER
3711 ;FORM IN HILIM AND LOLIM.
3712 013132 004767 000570 JSR PC,LOSEG4 ;SEE IF PERMANENT RELOCATION IS
3713 ;APPROPRIATE FOR THIS TEST SPAN.
3714 013136 012737 007600 172356 MOV #7600,@#KIPAR7 ;MAP THE UNIBUS DEVICE PAGE INTO
3715 ;INTO HIGH VIRTUAL MEMORY.
3716 013144 005046 REPET2: CLR -(SP)
3717 013146 012746 002250 MOV #FIRST1-.,-(SP)
3718 013152 060716 ADD PC,(SP)
3719 013154 062716 177772 ADD #-6,(SP) ;SET UP THE STACK
3720 ;TO SIMULATE THE OCCURRENCE OF AN
3721 ;AN INTERRUPT SO THAT THE TEST CAN
3722 ;BE STARTED USING AN RTI.
3723 013160 016767 000704 000674 MOV HISAV,HILIM
3724 013166 016767 000674 000670 MOV LOSAV,LOLIM
3725 013174 004767 000174 JSR PC,LOSEG1
3726 013200 012746 000052 MOV #*,-(SP)
3727 013204 004767 001130 JSR PC,TYPIT
3728 013210 005726 TST (SP)+
3729 013212 012737 013224 000034 MOV #YMMBG1,@#34
3730 013220 005037 000036 CLR @#36 ;SET UP THE TRAP INTERRUPT VECTOR
3731 ;WHICH WILL BE USED TO RETURN FROM THE
3732 ;TESTING ROUTINE.
3733
3734 ; YMMBG1 IS USED TO DYNAMICALLY ALLOCATE MEMORY UNDER MEMRY MANAGEMENT
3735 ; WHILE A TEST IS IN PROGRESS. WORKING UPWARDS FROM THE LOLIM
3736 ; MEMORY MANAGEMENT IR SET TO ENABLE BRGOB TO WORK THROUGH AS
3737 ; MUCH OF THE TEST SPAN AS POSSIBLE IN A SINGLE MANAGEMENT SET UP
3738 ; BEFORE HAVING TO RESET THE MANAGEMENT REGISTERS.
3739 ; BRGOB ALWAYS IS IN LOW VIRTUAL MEMORY AND UPPER VIRTUAL
3740 ; ADDRESSES ARE ALWAYS MAPPED INTO UNIBUS DEVICE ADDRESSES.
3741
3742 013224 005037 177572 YMMBG1: CLR @#SRO
3743 013230 026767 000626 000626 CMP HILIM,LOLIM ;IS THE TEST DONE?
3744 013236 101451 BLOS DONIT ;YES THEN BRANCH.
3745 013240 012700 172342 MOV #KIPARI,R0 ;ELSE GET READY TO SET
3746 013244 016705 000614 MOV LOLIM,R5 ;THE KERNAL PAGE ADDRESS REGISTERS.
3747 013250 012701 177772 MOV #-6,R1
    
```

```

3748 013254 012767 020000 002272          MCV      #20000,LO
3749 013262 010520          1$:      MOV      RS,(R0)+      ;RESET THE KIPAR'S
3750 013264 062705 000200          2$:      ADD      #200,RS
3751 013270 026705 000566          25$:     CMP      HILIM,RS      ;REACHED HILIM?
3752 013274 101407          BLOS     3$          ;YES, GOTO 3$.
3753 013276 005201          INC      R1          ;NO, INCREMENT R1 AND SEE IF ALL THE
3754          KIPAR'S HAVE BEEN SET.
3755 013300 002770          BLT      1$          ;ALL THE KIPAR'S HAVE NOT BEEN SET SO
3756          LOOP TO GET THE NEXT ONE.
3757 013302 010567 002244          MOV      RS,HI      ;DO THIS IS ALL THE TEST SPAN HAS NOT
3758          BEEN ALLOCATED TO SOME VIRTUAL ADDRESSES
3759          IS THE KERNAL INSTRUCTION SPACE.
3760 013306 162705 000002          SUB      #2,RS
3761 013312 000403          BR       4$
3762 013314 016767 000542 002230 3$:     MOV      HILIM,HI      ;DO THIS IF ALL THE TEST SPAN HAS BEEN
3763          ALLOCATED TO THE VIRTUAL KERNAL SPACE
3764          JUST ALLOCATED.
3765 013322 166767 000536 002222 4$:     SUB      LOLIM,HI      ;COMPUTE THE VIRTUAL LIMIT
3766          OF THE TEST SPAN.
3767 013330 016700 002216          MOV      HI,R0
3768 013334 004767 177504          JSR      PC,ROT
3769 013340 062700 020000          ADD      #20000,R0
3770 013344 010067 002202          MOV      R0,HI
3771 013350 010567 000510          MOV      RS,LOLIM
3772 013354 005237 177572          INC      #SR0
3773 013360 000002          RTI
3774          ;TURN ON MEMORY MANAGEMENT.
3775          ;RETURN TO BRG0B TO
3776          ;PERFORM THE TEST IN
3777          ;THE SPAN INDICATED
3778          ;BY THE RESULT OF THE
3779          ;ABOVE
3778 013362 004767 000056          DONIT:   JSR      PC,LOSEG2
3779 013366 022626          CMP      (SP)+,(SP)+
3780 013370 000167 177550          JMP      REPET2
3781          ;TEST COMPLETED, SO
3782          ;RESTART
3783          ;
3784          ;LOSEG1 IS CALLED TO DECIDE WHETHER OR NOT THE LIMITS ARE SUCH THAT
3785          ;THE FIRST 4K OF MEMORY WILL HAVE TO BE CHECKED IN THE TEST. THAT
3786          ;IS DO THE LIMITS INCLUDE ADDRESSES WHICH LIEM IN THE FIRST 4K BLOCK
3787          ;OF MEMORY THUS REQUIRING THAT THE CONTENTS OF THIS FIRST BLOCK OF
3788          ;MEMORY BE MOVED INTO THE SECOND 4K BLOCK SO THAT THE TEST CAN BE
3789          ;RUN THROUGH THE FIRST 4K BLOCK. IF RELOCATION IS NECESSARY LOSEG1
3790          ;SETS LOSFL TO -1 AND RESETS THE LIMITS, LOLIM AND HILIM,
3791          ;APPROPRIATELY.
3792 013374 005067 000324          LOSEG1: CLR      LOSFL          ;INITIALIZE.
3793 013400 026727 000462 000200          CMP      LOSAV,#200      ;SEE IF THE LOW LIMIT OR THE HIGH LIMIT
3794 013406 103011          BHIS     2$          ;LIE IN THE FIRST 4K BLOCK OF MEMORY.
3795 013410 005367 000310          DEC      LOSFL
3796 013414 022767 000200 000446          CMP      #200,HISAV
3797 013422 103004          BHIS     3$
3798 013424 012767 000200 000432 1$:     MOV      #200,LOLIM
3799 013432 000207          2$:     RTS      PC
3800 013434 012767 000200 000420 3$:     MOV      #200,HILIM
3801 013442 000770          BR       1$
3802          ;
3803          ;LOSEG2 IS CALLED TO DO THE ACTUAL RELOCATION OF THE FIRST 4K MEMORY
    
```

```

3804
3805
3806
3807
3808 013444 005767 000254
3809 013450 100401
3810 013452 000207
3811 013454 012667 000242
3812 013460 005737 000120
3813 013464 100423
3814 013466 004567 172656
3815 013472 000000
3816 013474 020000
3817 013476 012737 177777 000120
3818 013504 012701 020000
3819 013510 060106
3820 013512 060116
3821 013514 060107
3822 013516 060137 000114
3823 013522 060167 000174
3824 013526 012767 177777 164364
3825 013534 016700 000326
3826 013540 004767 177300
3827 013544 020027 000320
3828 013550 002002
3829 013552 012700 000320
3830 013556 010067 001772
3831 013562 016700 000302
3832 013566 022700 000200
3833 013572 002002
3834 013574 012700 000200
3835 013600 020027 000004
3836 013604 003002
3837 013606 000167 000034
3838 013612 004767 177226
3839 013616 010067 001730
3840
3841
3842 013622 012701 000024
3843 013626 060701
3844 013630 062701 177772
3845 013634 010137 000034
3846 013640 005037 000036
3847 013644 000002
3848
3849
3850
3851 013646 016746 000050
3852 013652 005767 000042
3853 013656 100417
3854 013660 004567 172464
3855 013664 020000
3856 013666 000000
3857 013670 005037 000120
3858 013674 012701 020000
3859 013700 160106

```

```

;BANK INTO THE SECOND 4K MEMORY BANK, THEN RUN THE TEST
;THROUGH THE DESIGNATED PARTS OF THE FIRST BANK AND THEN RESTORE
;THE CONTENTS OF THE FIRST BANK BY MOVING THE SECOND BANK'S
;CONTENTS BACK INTO THE FIRST BANK.
LOSEG2: TST LOSFL ;SEE IF RELOCATION IS NECESSARY.
        BMI 1$ ;IF NOT RETURN.
        RTS PC
1$: MOV (SP)+,SAVPC
      TST @#120 ;SEE IF THE PROGRAM IS ALREADY RELOCATED
      BMI 14$
      JSR R5,RELOC
      .WORD 0
      .WORD 20000
      MOV @-1,@#120
      MOV @20000,R1
      ADD R1,SP
      ADD R1,(SP)
      ADD R1,PC
      ADD R1,@#114
      ADD R1,SAVPC
14$: MOV @-1,RELFL ;ESTABLISH VALID LIMITS FOR THE TEST
      MOV LOSAV,RO ;THROUGH THE FIRST 4K MEMORY BANK.
      JSR PC,ROT
      CMP RO,@#320
      BGE 15$
      MOV @#320,RO
15$: MOV RO,LO
      MOV HISAV,RO
      CMP @#200,RO
      BGE 2$
      MOV @#200,RO
2$: CMP RO,@#4
      BGT 3$
      JMP LOSEG3
3$: JSR PC,ROT
      MOV RO,HI
      ;
      ;
      MOV @LOSEG3--,R1
      ADD PC,R1
      ADD @-6,R1
      MOV R1,@#34
      CLR @#36 ;PERFORM THE TEST
      RTI
      ;
      ;
;LOSEG3 RELOCATES BACK INTO THE FIRST 4K MEMORY BANK.
LOSEG3: MOV SAVPC,-(SP)
        TST PERRFL
        BMI 1$
        JSR R5,RELOC
        .WORD 20000
        .WORD 0
        CLR @#120
        MOV @20000,R1
        SUB R1,SP

```

```

3860 013702 160116
3861 013704 160137 000114
3862 013710 160107
3863 013712 160166 000002
3864 013716 000207
3865 013720 000000
3866 013722 000000
3867 013724 000000
3868
3869
3870 013726 005067 177766
3871 013732 026727 000132 000200
3872 013740 101002
3873 013742 005367 177752
3874 013746 000207
3875
3876
3877
3878
3879
3880
3881
3882
3883
3884
3885
3886
3887 013750
3888 013750 004567 165004
3889 013754 015206
3890 013756 004767 000110
3891 013762 004767 000334
3892 013766 004767 000330
3893 013772 010367 000064
3894 013776 004567 164756
3895 014002 015226
3896 014004 004767 000062
3897 014010 004767 000306
3898 014014 004767 000302
3899 014020 010367 000040
3900 014024 026767 000032 000032
3901 014032 003407
3902
3903 014034 016767 000022 000026 2$:
3904 014042 016767 000016 000016
3905 014050 000207
3906 014052
3907 014052 004567 164702
3908 014056 015273
3909 014060 000733
3910
3911 014062 000000
3912 014064 000000
3913
3914 014066 000000
3915 014070 000000

```

```

SUB R1,(SP)
SUB R1,20114
SUB R1,PC
SUB R1,2(SP)
RTS PC
PERRFL: .WORD 0
SAVPC: .WORD 0
LOSFL: .WORD 0
:
LOSEG4: CLR PERRFL
CMP HISAV,#200
BHI 1$
DEC PERRFL
RTS PC
1$:
:

```

```

: LIMITS IS CALLED TO ASK THE USER FOR BOTH
: THE HIGH AND LOW UNIBUS ADDRESS LI,ITS FOR
: THE IMPENDING TEST. THE TWO LIMITS ARE LEFT IN
: BLOCK NUMBER FORM AT LOCATIONS HILIM AND
: LOLIM (THEY ARE ALSO PUT IN LOSAV AND HISAV FOR
: LATER USE BY THE ROUTINE DONE). A VALIDITY CHECK
: IS MADE TO MAKE SURE THE INDICATED SPAN
: IS A VALID TEST SPAN.

```

```

LIMITS:
JSR R5,$PRINT ;GO TO PRINT ROUTINE
.WORD HIMESS
JSR PC,INUM ;ASSEMBLE THIS NUMBER.
JSR PC,THRR
JSR PC,THRR
MOV R3,HILIM
JSR R5,$PRINT ;GO TO PRINT ROUTINE
.WORD LOMESS
JSR PC,INUM ;ASSEMBLE THIS NUMBER
JSR PC,THRR
JSR PC,THRR
MOV R3,LOLIM
CMP HILIM,LOLIM ;IF LOLIM IS GREATER
BLE LIMERR ;THAN HILIM THEN GOTO
;LIMERR, ERROR
2$: MOV HILIM,HISAV ;STORE THE LIMITS IN
MOV LOLIM,LOSAV ;SAVE REGISTERS.
RTS PC ;RETURN
LIMERR: JSR R5,$PRINT ;GO TO PRINT ROUTINE
.WORD ERMESS ;WRITE AN ERROR MESSAGE
BR LIMITS ;AND TRY AGAIN.
;
HILIM: .WORD 0
LOLIM: .WORD 0
; THESE ARE INTERMEDIATE STORGE REGISTERS:
LOSAV: .WORD 0
HISAV: .WORD 0

```

```

3916
3917
3918
3919
3920
3921
3922
3923
3924
3925
3926
3927
3928
3929
3930
3931
3932
3933 014072 005046
3934 014074 005002
3935 014076 005003
3936 014100 012705 177771
3937 014104 005737 177562
3938 014110 012746 000076
3939 014114 004767 000220
3940 014120 005726
3941 014122 105737 177560
3942 014126 100375
3943 014130 013746 177562
3944 014134 042715 177600
3945 014140 022716 000177
3946 014144 001011
3947 014146 005726
3948 014150 005716
3949
3950
3951 014152 001763
3952
3953
3954
3955
3956 014154 012716 000134
3957 014160 004767 000154
3958 014164 005726
3959 014166 000755
3960 014170 004767 000144
3961
3962
3963 014174 022716 000015
3964 014200 001350
3965
3966 014202 012716 000012
3967 014206 004767 000126
3968 014212 005726
3969 014214 005716
3970 014216 001415
3971

```

: THIS ROUTINE IS CALLED TO ASSEMBLE AN 18-BIT
: NUMBER FROM THE TTY AND TRUNCATE IT DOWN TO
: 12-BITS
: A CALL IS MADE THUS:
: JMP PC, INUM
: RES: .WORD 0
: THE NUMBER IS ASSEMBLED AND THE RESULTING 12-BIT
: TRUNCATED NUMBER IS LEFT IN RES. WHEN AND
: RTS RETURN IS MADE.
: NOTE THAT THE NUMBER SHOULD BE SPECIFIED
: IN OCTAL DIGITS. AN CHARACTERS WHICH DO NOT
: MEET THIS SPECIFICATION IN THE INPUT STRING
: WILL CAUSE AN ERROR WHICH WILL BE SIGNALLED BY
: A ? ON THE TTY FOLLOWED BY A RETRY.

```

:INUM:  CLR     -(SP)               :PUT A ZERO MARKER ON
          CLR     R2                :SET UP THE TEMPORARY
          CLR     R3                :STORAGE AND COUNTER
          MOV     #-7, R5           :REGISTERS.
          TST     #@TKB
          MOV     #') -(SP)
          JSR     PC, TYPIT
          TST     (SP)+
1$:     TSTB     #@TKS               :WAIT FOR A CHARACTER
          BPL     1$
          MOV     #@TKB, -(SP)       :GET IT ONTO THE
          BIC     #177600, (SP)     :STACK
          CMP     #177, (SP)        :IS IT RUBOUT?
          BNE     2$                :IF NOT GOTO 2$
          TST     (SP)+             :IF IT WAS A RUBOUT
          TST     (SP)               :FIRST SEE IF THEE
                  :IS A PREVIOUS
                  :CHARACTER ON THE STACK.
                  :IF THERE WAS NO PREVIOUS
                  :CHARACTER TAKE NO
                  :RUBOUT ACTION AND
                  :GO WAIT AT 1$ FOR
                  :THE NEXT CHARACTER
                  :IF THERE WAS
                  :A PREVIOUS CHARACTER
                  :PRINT A SLASH
          BR     1$
2$:     JSR     PC, TYPIT            :IF THE LAST INPUT
                  :CHARACTER WAS NOT
                  :RUBOUT ECHO IT
          CMP     #15, (SP)         :IS IT CR.
          BNE     1$                :NO, BRANCH TO 1$ FOR
                  :NEXT CHARACTER.
          MOV     #12, (SP)         :YES, PRINT A LF
          JSR     PC, TYPIT
          TST     (SP)+
3$:     TST     (SP)                :START TO ASSEMBLE
          BEQ     4$                :THE NUMBER. IF THE
                  :STACK IS AT THE

```



```

3972
3973
3974 014220 012604          MOV      (SP)+,R4
3975 014222 062704 177710   ADD      #-70,R4
3976 014226 002022          BGE     INERR
3977 014230 062704 000010   ADD      #10,R4
3978 014234 002417          BLT     INERR
3979 014236 005205          INC     R5
3980 014240 001415          BEQ     INERR
3981 014242 004767 000054   JSR     PC,THRR
3982
3983
3984
3985 014246 010402          MOV     R4,R2
3986
3987 014250 000761          BR      3$
3988
3989 014252 005205          4$: INC     R5
3990 014254 001403          BEQ     5$
3991 014256 004767 000040   JSR     PC,THRR
3992 014262 000773          BR      4$
3993 014264 004767 000022   5$: JSR     PC,ONER
3994 014270 005726          TST     (SP)+
3995 014272 000207          RTS     PC
3996
3997
3998
3999 014274
4000 014274 004567 164460   ;ERROR HANDLER FOR THE INUM ROUTINE.
4001 014300 015237          ;RETURNS TO THE CALLING ROUTINE, LIMITS, TO ASK
4002 014302 005726          ;FOR THE PARAMETER AGAIN.
4003 014304 001376          INERR: JSR     R5,SPRINT
4004 014306 000167 177560   ;GO TO PRINT ROUTINE
4005 014312 000241          .WORD  INAMES
4006 014314 006002          1$: TST     (SP)+
4007 014316 006003          BNE     1$
4008 014320 000207          JMP     INUM ;THE ROUTINE LIMITS.
4009
4010 014322 004767 177764   ONER: CLC
4011 014326 004767 177760   ROR     R2
4012 014332 004767 177754   ROR     R3
4013 014336 000207          RTS     PC
4014 014340 105737 177564   THRR: JSR     PC,ONER
4015 014344 100375          JSR     PC,ONER
4016 014346 116637 000002 177566   JSR     PC,ONER
4017 014354 000207          RTS     PC
4018
4019
4020
4021
4022
4023
4024 014356 172100          TYPIT: TSTB   @#TPS
4025 014362 004767 000454   BPL     TYPIT
4026 014362 012700 172100   MOV     2(SP),@#TPB
4027
;TYPIT TAKES THE
;WORD 2 BYTES UP IN
;THE STACK AND "PRINTS"
;IT ON THE TTY
;MOSPAR IS CALLED TO CHECK OUT THE POSSIBILITY OF TURNING ON MOS
;PARITY DURING THE BRANCH GOBBLE TEST. FIRST MOSPAR SEES WHAT
;MOS PARITY REGISTERS EXIST AND THEN IFOME ARE FOUND THEY
;ARE ENABLED AND THE INTERRUPT VECTOR IS SET TO TRAP TO PARERR A ROUTINE
;WHICH WILL NOTIFY THE USER OF THE ERROR AND ITS LOCATION.
;
;PAREGS=172100
MOSPAR: JSR     PC,MPVECT
MOV     #PAREGS,R0
;SET THE PARITY ERROR TRAP VECTOR.
;GET READY TO LOOK AT THE POSSIBLE
;PARITY REGISTERS PRESENT.

```

```

4028 014366 012701 177762
4029 014372 012737 014454 000004
4030 014400 005037 000006
4031 014404 005067 000110
4032
4033
4034
4035
4036
4037
4038 014410 005710
4039
4040
4041 014412 005767 000102
4042 014416 100403
4043 014420 004567 164334
4044 014424 015102
4045
4046 014426 010046
4047 014430 004767 165306
4048 014434 004567 164320
4049 014440 015122
4050 014442 005367 000052
4051 014446 012710 000001
4052 014452 000401
4053
4054
4055 014454 022626
4056 014456 062700 000002
4057 014462 005201
4058 014464 002751
4059 014466 005767 000026
4060
4061 014472 100403
4062 014474 004567 164260
4063 014500 015131
4064 014502 012737 001116 000004
4065 014510 012737 000002 000006
4066 014516 000207
4067 014520 000000
4068
4069
4070
4071
4072
4073
4074
4075
4076
4077
4078
4079
4080
4081
4082 014522
4083 014522 004567 164232
    
```

```

MOV #16,R1
MOV #MP2,2#4
CLR 2#6
CLR MPFL
;THE REAL REGISTERS ARE LOCATED USING A TIME OUT PLAN WHERE BY THE
;POSSIBILITIES ARE REFERENCED AND IF A TIME OUT OCCURS THEY ARE NONEXISTENT
;OR IF NO TIME OUT OCCURS THEN THE REGISTER IS REAL. WHEN A REAL
;REGISTER IS FOUND IT IS WRITTEN INTO AND READ TO DETERMINE
;WHAT KIND OF PARITY REGISTER IT IS, CORE OR MOS. IF IT IS MOS THEN THE
;REGISTER IS SET TO ENABLE PARITY.
MP1: TST (R0) ;IF THIS INSTRUCTION TIMES OUT THEN
;THERE IS NO PARITY REGISTER AT THE
;ADDRESS IN R0.
;SEE IF THE TABLE HEADING HAS BEEN OUTPUT.
TST MPFL
BMI 1$
JSR R5,$PRINT ;GO TO PRINT ROUTINE
.WORD MPMS
!$: MOV R0,-(SP) ;OUTPUT AN ENTRY INTO THAT TABLE.
JSR PC,02A
JSR R5,$PRINT ;GO TO PRINT ROUTINE
.WORD $CRLF
DEC MPFL
MOV #1,(R0)
BR MP25
;IF A TIME OCCURS COME HERE. OR IF THE REGISTER WAS NOT MOS PARITY.
MP2: CMP (SP)+,(SP)+
MP25: ADD #2,R0
INC R1
BLT MP1 ;BRANCH IF NOT DONE.
TST MPFL ;SEE IF ANY MOS PARITY REGISTERS HAVE
;BEEN FOUND.
;IF NOT DON'T OUT PUT THE NO PARITY MESSAGE.
BMI MP3 ;GO TO PRINT ROUTINE
JSR R5,$PRINT
.WORD NOMPAR
MP3: MOV #ERRTRP,2#4
MOV #2,2#6
RTS PC
MPFL: .WORD 0
;IF A PARITY ERROR IS DETECTED THEN A TRAP IS MADE THROUGH LOCATION
;114 TO THIS ROUTINE. HERE THE USER IS TOLD OF THE PARITY ERROR AND THE
;LOCATION PLUS 2 OF THE INSTRUCTION WHICH CAUSED THE ERROR TO COME OUT.
;THEN A SCAN IS MADE THROUGH MEMORY. IF THE ERROR DOESN'T COME UP DURING
;THE SCAN THEN THE USER IS TOLD THAT THE ERROR WAS NOT FOUND ON THE SCAN.
;IF THE ERROR IS DETECTED ON THE SCAN THEN THE USER IS TOLD WHAT LOCATION
;CAUSED THE ERROR AND WHETHER OR NOT MEMORY MANAGEMENT WAS ON DURING THE
;SCAN. IF IT WAS THEN THE PAR INVOLVED IN RELOCATING THE BAD LOCATION'S
;ADDRESS IS ALSO GIVEN TO THE USER SO HE CAN TAKE THE GIVEN
;ADDRESS AND RELOCATE IT USING THE PAR GIVEN TO FIND THE REAL MEMORY
;ADDRESS CAUSING THE PARITY ERROR. WHEN THIS HAS BEEN DONE THE TEST WHICH
;WAS IN PROGRESS WHEN THE ERROR WAS ENCOUNTERED IS RESTARTED, USING
;THE PARAMETERS WHICH THE USER LAST INPUT TO THE PROGRAM.
PARER2: JSR R5,$PRINT ;GO TO PRINT ROUTINE
    
```

```

4084 014526 007000          .WORD  PARERR          ; TELL THE USER A PARITY ERROR OCCURRED.
4085 014530 004567 164224 JSR    R5,$PRINT      ; GO TO PRINT ROUTINE
4086 014534 015125          .WORD  PERMES        ; TELL THE USER WHAT INSTRUCT CAUSED THE ERROR.
4087 014536 004767 165200 JSR    PC,02A
4088 014542 004567 164212 JSR    R5,$PRINT      ; GO TO PRINT ROUTINE
4089 014546 015122          .WORD  $CRLF
4090
4091 014550 012700 000052   ; MOV    #PARR3-.,R0    ; SET THE TIME AND TRAP VECTORS SO
4092 014554 060700          ADD    PC,R0          ; THAT THE SCAN CAN BE MADE
4093 014556 062700 177772   ADD    #-6,R0
4094 014562 010037 000114   MOV    R0,#PARVEC
4095 014566 005037 000116   CLR   #PARVEC+2
4096 014572 012700 000176   MOV    #PARR4-.,R0
4097 014576 060700          ADD    PC,R0
4098 014600 062700 177772   ADD    #-6,R0
4099 014604 010037 000004   MOV    R0,#ERRVEC
4100 014610 005037 000006   CLR   #ERRVEC+2
4101 014614 005003          CLR   R3
4102
4103 014616          ; CONT:
4104 014616 012301 1$:    MOV    (R3)+,R1      ; PERFORM THE SCAN. EITHER THIS INSTRUCTION.
4105 014620 000776          BR     1$           ; WILL TIME OUT OR THE PARITY ERROR WILL
4106                                     ; ONCE AGAIN OCCUR SO THAT CONTROL WILL
4107                                     ; BE TRANSFERRED OUT OF THIS LOOP ONE WAY
4108                                     ; OR ANOTHER.
4109
4110   ; IF THE PARITY ERROR IS AGAIN ENCOUNTERED THEN THIS PROGRAM WILL
4111   ; RECIEVE CONTROL THROUGH A TRAP THROUGH VECTOR 114. HERE THE USER
4112   ; IS GIVEN THE ADDRESS OF THE LOCATION WHICH CAUSED THE PARITY ERROR
4113   ; DURING THE SCAN. THE USER IS ALSO TOLD WHETHER OR NOT MEMORY MANAGEMENT
4114   ; IS ENABLED OR NOT. IF IT IS ENABLED THEN THE PAR INVOLVED WITH
4115   ; THE ADDRESS RELOCATION IS ALSO GIVEN TO THE USER.
4116 014622 062703 177776   PARR3: ADD    #-2,R3      ; R3 CONTAINS THE ADDRESS PLUS 2
4117 014626 010316          MOV    R3,(SP)       ; OF THE LOCATION CAUSING THE ERROR.
4118 014630 062703 000002   ADD    #2,R3
4119 014634 010367 000126   MOV    R3,SAVPER
4120 014640 004767 165076   JSR    PC,02A      ; GIVE THE USER THIS ADDRESS.
4121 014644 004567 164110   JSR    R5,$PRINT    ; GO TO PRINT ROUTINE
4122 014650 015147          .WORD  LOCBAD        ; TELL THE USER THIS IS THE ADDRESS AND
4123 014652 004567 164102   JSR    R5,$PRINT    ; GO TO PRINT ROUTINE
4124 014656 001502          .WORD  RECDAT
4125 014660 010116          MOV    R1,(SP)      ; GIVE HIM THE BAD DATA.
4126 014662 004767 165054   JSR    PC,02A
4127
4128 014666 033727 177572 000001 ; BIT    #SRO,#1      ; SEE IF MEMORY MANAGEMENT WAS USED
4129 014674 001423          BEQ   2$            ; DURING THE SCAN THROUGH MEMORY.
4130 014676 004767 177420   1$:    JSR    PC,THRR     ; IF IT WAS THEN ESTABLISH WHICH KIPAR
4131 014702 004767 177414   JSR    PC,THRR     ; IS INVOLVED WITH THE RELOCATION OF
4132 014706 004767 177410   JSR    PC,THRR     ; THIS BAD ADDRESS.
4133 014712 004767 177404   JSR    PC,THRR
4134 014716 042703 177761   BIC   #177761,R3
4135 014722 062703 172340   ADD    #KIPAR,R3
4136 014726 011316          MOV    (R3),(SP)
4137 014730 004567 164024   JSR    R5,$PRINT    ; GO TO PRINT ROUTINE
4138 014734 015154          .WORD  KPARM
4139 014736 004767 165000   JSR    PC,02A
    
```

4140	014742	000403		BR	RETPR	;GO RESTART THE TEST WHICH WAS IN PROGRESS.
4141						
4142	014744			2s:		
4143	014744	004567	164010		JSR R5,SPRINT	;GO TO PRINT ROUTINE
4144	014750	015173			.WORD NOKT11	;THE SCAN SO TELL
4145	014752	004567	164002	RETPR:	JSR R5,SPRINT	
4146	014756	015122			.WORD \$CRLF	
4147	014760	016703	000002		MOV SAVPER,R3	
4148	014764	000714			BR CONT	
4149						;THE ADDRESS GIVEN FOR THE ERROR, THEN
4150						;RESTART THE TEST WHICH WAS IN PROGRESS
4151						;WHEN THE ERROR OCCURRED.
4152	014766	000000		SAVPER:	.WORD 0	
4153						
4154	014770			PARR4:		
4155	014770	004567	163764		JSR R5,SPRINT	;GO TO PRINT ROUTINE
4156	014774	015062			.WORD NOTIND	;TELL THE USER THAT IS THE CASE AND
4157						;RESTART THE SCAN WHICH WAS IN PROGRESS
4158						;WHEN THE ERROR WAS ORIGINALLY
4159						;ENCOUNTERED.
4160						
4161	014776	012706	000500		MOV #500,SP	;RESTART THE TEST WHICH WAS INPROGRESS
4162	015002	000005			RESET	;WHEN THE ORIGINAL PARITY ERROR WAS FIRST
4163	015004	004737	000124		JSR PC,@WHERE	;ENCOUNTERED. SEE IF RELOCATION INTO THE
4164	015010	012707	015014		MOV #1\$,PC	;FISRT 4K BANK IS NECESSARY.
4165						
4166	015014	004767	177336	1s:	JSR PC,MOSPAR	;GO RESET THE PARITY REGISTERS BEFORE

```

4167 015020 005767 163726      TST      MMAVA      ;STARTING EITHER A MEMORY MANAGED
4168 015024 001402                BEQ      2$          ;OR NON MEMORY MANAGED TEST.
4169 015026 000167 176112      JMP      REPET2
4170 015032 000167 175654      2$:      JMP      SPOT2
4171
4172
4173
4174
4175
4176
4177 015036 012700 177464      ;ROUTINE USED TO SET THE TRAP VECTOR 114.
4178 015042 060700      MPVECT: MOV      #PARER2-.,RO
4179 015044 062700 177772      ADD      PC,RO
4180 015050 010037 000114      ADD      #-6,RO
4181 015054 005037 000116      MOV      RO,#114
4182 015060 000207      CLR      #116
4183
4184
4185 015062 041523 047101 041440      ;MESSAGES USED FOR THESE PARITY ROUTINES.
4186 015070 046517 046120 052105      NOTIND: .ASCIZ  'SCAN COMPLETE'<15><12>
4187 015076 006505 000012
4188 015102 005015 040520 044522      MPMES:  .ASCII  <15><12>'PARITY ENABLED'
4189 015110 054524 042440 040516
4190 015116 046102 042105
4191 015122 005015 000
4192 015125 120 036503 000      $CRLF:  .ASCIZ  <15><12>
4193 015131 015 047012 020117      PERMES:  .ASCIZ  'PC='
4194 015136 040520 044522 054524      NOMPAR:  .ASCIZ  <15><12>'NO PARITY'<15><12>
4195 015144 005015 000
4196
4197
4198
4199 015147 040 040510 000104      ;THESE ARE MESSAGES USED FOR COMMUNICATIONS
4200 015154 005015 052113 030461      ;ON THE TTY BY THE PROGRAM.
4201 015162 047440 020116 040520      LOCBAD:  .ASCIZ  'HAD'
4202 015170 036522 000      KPARAM:  .ASCIZ  <15><12>'KT11 ON PAR='
4203 015173 015 045412 030524      NOKT11:  .ASCIZ  <15><12>'KT11 OFF'
4204 015200 020061 043117 000106
4205 015206 005015 044510 044107      HIMESS:  .ASCIZ  <15><12>'HIGH LIMIT?'<15><12>
4206 015214 046040 046511 052111
4207 015222 006477 000012
4208 015226 047514 020127 044514      LOMESS:  .ASCII  'LOW LIMIT'
4209 015234 044515 124
4210 015237 077 005015 000      INRMES:  .ASCIZ  '?'<15><12>
4211 015243 015 052412 042523      MMESS:  .ASCII  <15><12>'USE KT11? (Y OR N)'<15>
4212 015250 045440 030524 037461
4213 015256 024040 020131 051117
4214 015264 047040 006451
4215 015270 037012 000
4216 015273 116 052117 053040      ERRMES:  .ASCIZ  <12>'>'
4217 015300 046101 042111 006441      'NOT VALID!'<15><12>
4218 015306 000012
4219 015310 005015 051102 047101      IDMESS:  .ASCIZ  <15><12>'BRANCH GOBBLE'<15><12>
4220 015316 044103 043440 041117
4221 015324 046102 006505 000012
4222
    .EVEN
    
```

```

4223
4224
4225
4226
4227 015332 125252
4228 015334 000401
4229 015336 000000
4230 015340 010703
4231 015342 162703 000004
4232 015346 010304
4233 015350 005204
4234 015352 005013
4235 015354 000261
4236 015356 105513
4237 015360 100402
4238 015362 105214
4239 015364 000773
4240 015366 102401
4241 015370 000000
4242 015372 000242
4243 015374 105214
4244 015376 103402
4245 015400 102001
4246 015402 100401
4247 015404 000000
4248 015406 000137 015474
4249 015412
4250 015412 000000
4251 015414 000027
4252 015416 016700 000130
4253 015422 012701 177770
4254 015426 060701
4255 015430 062701 177772
4256 015434 012703 000040
4257 015440 060703
4258 015442 062703 177772
4259 015446 010367 177736
4260 015452 016702 177736
4261 015456 014140
4262 015460 005302
4263 015462 001375
4264 015464 010067 177722
4265 015470 000177 177716
4266 015474 016700 177712
4267 015500 162767 000002 177704
4268 015506 026767 177700 000040
4269 015514 101414
4270 015516 016701 177672
4271 015522 011060 177776
4272 015526 005720
4273 015530 005301
4274 015532 001373
4275 015534 016737 177652 177570
4276 015542 000177 177644
4277 015546 104400
4278 015550 000722
    
```

: THE FOLLOWING IS THE CODE TAKEN DIRECTLY FROM
 : THE PDP-11 FAMILY INSTRUCTION EXERCISER DZQKA-A.

```

MARKER: .WORD 125252
FIRST: BR .+4
        .WORD 0
        MOV PC,R3
        SUB #4,R3
        MOV R3,R4
        INC R4
        CLR (R3)
1$: SEC
        ADCB (R3)
        BMI 2$
        INCB (R4)
        BR 1$
2$: BVS .+4
        HALT
        CLV
        INCB (R4)
        BCS INCB1
        BVC INCB1
        BMI .+4
INCB1: HALT
RTAD: JMP @RELO
LAST:
STRTAD: .WORD 0
LENGTH: .WORD 1+LAST-FIRST/2
FIRST1: MOV HI,R0
        MOV #LAST-.,R1
        ADD PC,R1
        ADD #-6,R1
        MOV #RELO-.,R3
        ADD PC,R3
        ADD #-6,R3
        MOV R3,RTAD+2
        MOV LENGTH,R2
ABC: MOV -(R1),-(R0)
        DEC R2
        BNE ABC
        MOV R0,STRTAD
        JMP @STRTAD
RELO: MOV STRTAD,R0
        SUB #2,STRTAD
        CMP STRTAD,L0
        BLOS RET
        MOV LENGTH,R1
RELO1: MOV (R0),-2(R0)
        TST (R0)+
        DEC R1
        BNE RELO1
        MOV STRTAD,@#177570
        JMP @STRTAD
RET: TRAP
        BR FIRST1
    
```

TEST DDQAB-A 0-124K MEMORY EXERCISER MACY11 27(732) 10-SEP-76 10:35 PAGE 102
DDQABA.P11 BRANCH GOBBLE MOS MEMORY TEST

4279	015552	000000	HI:	.WORD	0
4280	015554	000000	LO:	.WORD	0
4281			:		
4282			:		
4283			:		
4284	015556		LODAR:		
4285		000001		.END	

LOLIM	014064	3667	3724*	3743	3746	3765	3771*	3798*	3899*	3900	3904	3912*		
LOMESS	015226	3895	4208*											
LOSAY	014066	3724	3793	3825	3904*	3914*								
LOSEG1	013374	3656	3725	3792*										
LOSEG2	013444	3678	3778	3808*										
LOSEG3	013646	3837	3842	3851*										
LOSEG4	013726	3655	3712	3870*										
LOSFL	013724	3792*	3795*	3808	3867*									
LST	002242	1794*	1860											
LSTLOC	002164	1758*	1774*											
MARKER	015332	4227*												
MMABTO	007244	1850	1919	1937	1985	2694	2780*							
MMABT1	007276	1902	1969	2788*										
MMABT2	007454	2820	2825*											
MMAVA	000752	1461	1481	1519*	1668	1836*	1841*	1890	1916	2220	2245	2326*	2336*	2590
		2765	2802	3615*	3698*	4167								
MMESS	015243	3622	4211*											
MMVEC =	000250	1281*	1850*	1902*	1919*	1937*	1969*	1985*	2694*	2820*				
MOSPAR	014356	3619	4025*	4166										
MPFL	014520	4031*	4041	4050*	4059	4067*								
MPHES	015102	4044	4188*											
MPVECT	015036	4025	4177*											
MP1	014410	4038*	4058											
MP2	014454	4029	4055*											
MP2S	014456	4052	4056*											
MP3	014502	4061	4064*											
N =	000010	1255*												
NOFIND	007021	2716	2731*											
NOKT11	015173	4144	4203*											
NOMPAR	015131	4063	4193*											
NOTIND	015062	4156	4185*											
ONER	014312	3993	4005*	4010	4011	4012								
O2A	001742	1628	1633	1716*	2594	2663	4047	4087	4120	4126	4139			
PARAVA	007116	1493	2066	2184	2750*	2756*								
PARCSA=	172100	2738*	2747											
PARCS=	172100	4024*	4026											
PARERR	007000	2683	2728*	4084										
PARER2	014522	4082*	4177											
PARITY	012120	2352	3445*											
PARPAT	003362	2039*	2068	2070*	2167*	2186	2188*	2340*	2526*	2961	2991	3040	3094	
PARR3	014622	4091	4116*											
PARR4	014770	4096	4154*											
PARTAB	001722	1678	1704*											
PARVEC=	000114	2687*	2739*	2745*	2746*	4094*	4095*							
PAT	012241	2372	3459*											
PC =	%000007	1243*	1376*	1395*	1402*	1406*	1407*	1410*	1413*	1416*	1422*	1425*	1438*	1450*
		1460*	1473*	1495*	1497*	1500*	1531*	1558*	1566*	1572*	1579	1584*	1606*	1612*
		1618*	1628*	1633*	1644*	1662*	1699*	1702*	1717*	1736*	1738*	1745*	1760*	1765*
		1773	1778*	1820*	1828*	1842*	1848	1849*	1858*	1865	1870*	1885	1915	1935
		1936*	1951	1952*	1968	1983	1984*	2019*	2020*	2024	2027*	2032	2036*	2038*
		2047	2051*	2057*	2060	2063*	2076	2079*	2083	2090*	2106*	2116	2121*	2123
		2128*	2132	2148	2157*	2168	2172	2175*	2178	2181*	2191	2194*	2197	2200*
		2207	2218	2222*	2259*	2260	2263*	2270*	2271	2274*	2285*	2286	2304*	2306*
		2321*	2346*	2349*	2353*	2357*	2361*	2365*	2369*	2373*	2376*	2382*	2404*	2406*
		2410*	2424*	2426*	2431*	2448*	2451*	2462*	2472*	2474*	2477*	2493*	2496*	2499*
		2513*	2516*	2519*	2536*	2551*	2554*	2561*	2571*	2572*	2573*	2582*	2594*	2663*

		2967*	2968*	2969*	2970*	2972*	2973*	2974*	2975*	2977*	2978*	2979*	2980*	2982*
		2983*	2984*	2985*	3003	3005	3008	3032*	3045	3052	3059	3066	3084*	3097
		3103*	3104	3110*	3120*	3128	3129	3130*	3131*	3132*	3133*	3134*	3135*	3136*
		3137*	3138*	3139*	3140*	3141*	3142*	3143*	3144*	3145*	3165*	3172*	3192*	3201
		3208	3223*	3230*	3231*	3251*	3258	3279*	3286	3301*	3302*	3303*	3304*	3305*
		3306*	3307*	3308*	3309*	3310*	3311*	3312*	3313*	3314*	3315*	3316*	3317*	3318*
		3327*	3331*	3332*	3333*	3334*	3352*	3357	3364	3371	3378	3406	3934*	3985*
		4006*	4260*	4262*										
R3	=:X000003	1239*	1457*	1472*	1485*	1487*	1632	1664*	1681*	1685*	1687*	1691*	1696*	1719*
		1734*	1754*	1755*	1758	1852*	1853	1854*	1872*	1873	1892*	1893*	1894*	1895*
		1896*	1897*	1898*	1901*	1905*	1906*	1907*	1926*	1927	1957*	1958	1990*	1991
		1998*	1999	2034*	2035	2236*	2237	2564*	2567	2575	2577	2580*	2583	2587
		2601*	2602	2613*	2614*	2617	2619	2621*	2622	2626	2679	2698*	2839*	2871*
		2894*	2895	2902*	2903	2910*	2911	2918*	2919	2959*	2960*	2972	2973	2974
		2975	2982	2983	2984	2985	2990*	3016*	3019*	3045*	3046	3052*	3053	3059*
		3060	3066*	3067	3097*	3098	3104*	3105	3122*	3148*	3170*	3173*	3201*	3202
		3208*	3209	3258*	3260	3286*	3288	3330*	3335*	3357*	3358	3364*	3365	3371*
		3372	3378*	3379	3407	3702*	3704	3705*	3893	3899	3935*	4007*	4101*	4104
		4116*	4117	4118*	4119	4134*	4135*	4136	4147*	4230*	4231*	4232	4234*	4236*
		4256*	4257*	4258*	4259									
R4	=:X000004	1240*	1663*	1768*	1770	1941*	1943*	1956*	1961*	1973*	1978*	1987	1994*	1997*
		2002*	2086*	2087*	2089	2102	2154	2227*	2229	2230	2235	2565*	2579*	2616*
		2636*	2680	2848*	2869*	2965*	2987*	3031*	3078*	3092*	3114*	3129*	3130	3131
		3132	3133	3134	3135	3136	3137	3164*	3177*	3196*	3217*	3225*	3234*	3250*
		3266*	3278*	3294*	3326*	3337*	3351*	3387*	3672*	3673*	3674*	3675	3703*	3707*
		3974*	3975*	3977*	3985	4232*	4233*	4238*	4243*					
R5	=:X000005	1241*	1397*	1504*	1528	1533*	1585*	1587*	1613*	1615*	1619*	1625*	1630*	1635*
		1639*	1666*	1667	1683*	1684	1692*	1694*	1725*	1766*	1770*	1773*	1775*	1821*
		1859*	1861*	2133*	2151*	2208*	2228*	2231*	2234*	2242*	2291*	2298*	2351*	2359*
		2367*	2371*	2444*	2460*	2538*	2540*	2552*	2559*	2595*	2611	2612	2621	2639
		2640	2656*	2659*	2681	2682*	2715*	2843*	2844*	2847*	2850	2852	2855	2857
		2860	2862	2865	2867	2891*	2925*	2935*	2940*	3038*	3075*	3093*	3111*	3127*
		3146*	3168*	3175*	3198*	3215*	3229*	3232*	3255*	3264*	3283*	3292*	3355*	3385*
		3493*	3616*	3621*	3746*	3749	3750*	3751	3757	3760*	3771	3814*	3854*	3888*
		3894*	3907*	3936*	3979*	3989*	4000*	4043*	4048*	4062*	4083*	4085*	4088*	4121*
		4123*	4137*	4143*	4145*	4155*								
		3811*	3823*	3851	3866*									
		1380*	1396*	1400										
		4119*	4147	4152*										
		2675*	2676	2721*										
		2722*												
		2723*												
		2724*												
		2725*												
		2726*												
SAVPC	013722	3811*	3823*	3851	3866*									
SAVPC2	000122	1380*	1396*	1400										
SAVPER	014766	4119*	4147	4152*										
SAVR0	006764	2675*	2676	2721*										
SAVR1	006766	2722*												
SAVR2	006770	2723*												
SAVR3	006772	2724*												
SAVR4	006774	2725*												
SAVR5	006776	2726*												
SCOPE	= 104000	1337*												
SLR	= 177774	1285*												
SM	= 040000	1260*												
SP	=:X000006	1242*	1396	1400*	1405*	1409*	1412*	1415*	1421*	1424*	1431	1432*	1433*	1434*
		1435*	1436*	1437*	1443	1444	1445	1446	1447	1448	1449	1459*	1463*	1464*
		1468*	1471*	1473	1480*	1486	1489	1491	1492	1498	1530*	1548*	1549	1550*
		1552*	1554	1555	1559	1561*	1564*	1571	1582	1583	1607	1617	1627*	1632*
		1718	1737*	1750	1819*	1826*	1857*	1884*	1899*	1900*	1901	1947	1964	2006
		2018*	2025*	2026*	2031*	2033*	2035*	2046*	2049*	2050*	2055	2059*	2061*	2062*
		2070	2074*	2077*	2078*	2082*	2085*	2089*	2098*	2107*	2119*	2120*	2126*	2127*
		2147*	2158*	2171*	2172*	2179*	2180*	2188	2192*	2193*	2198*	2199*	2212*	2252*

.XOR39	010212	2994	3003#	3043	3096
..USER	011524	2477	3349#		
..1X8	007624	2036	2128	2410	2882#
..3X9	010300	2063	2181	2431	3027#
..8X13	011026	2090	2200	2451	3189#
.1X8	007512	2027	2121	2406	2839#
.1617	011742	2556	3411*	3414#	
.3ISO	010230	3004	3008#		
.3IS1	010220	3005#			
.3IS9	010246	3007	3009	3013#	
.3NOT9	010236	3006	3010#		
.3X9	010060	2051	2175	2426	2956#
.8X13	010750	2079	2194	2448	3164#

\$TYPE 1201*

ADC	1685	2598													
ADCB	4236														
ADD	1529	1550	1600	1646	1660	1661	1684	1723	1854	1871	1901	1907	1924	2106	2107
	2157	2158	2250	2379	2381	2597	2614	2639	2649	2662	2665	2668	2781	2814	2827
	2828	3412	3647	3648	3653	3654	3673	3674	3705	3718	3719	3750	3769	3819	3820
	3821	3822	3823	3843	3844	3975	3977	4056	4092	4093	4097	4098	4116	4118	4135
	4178	4179	4254	4255	4257	4258									
ASL	1680	1686	1690	1893	1894	1895	1896	1897	1898	2145	2146	2206	2378	2397	2400
	2401	2402	2403	2420	2421	2422	2423	2468	2469	2470	2471	2489	2490	2491	2492
	2509	2510	2511	2512	2757	2933	3125	3226	3392	3683					
ASR	2579														
BCC	2592	2652	2758	3287											
BCS	2335	2558	2570	3259	4244										
BEQ	1462	1482	1494	1599	1602	1638	1669	1671	1744	1874	1891	1917	1928	1959	1977
	1989	1992	2000	2008	2067	2088	2096	2103	2155	2185	2205	2221	2238	2246	2282
	2290	2303	2342	2345	2356	2442	2522	2603	2623	2625	2627	2691	2766	2790	2801
	2896	2904	2912	2920	2962	2992	3004	3006	3009	3041	3047	3054	3061	3068	3095
	3099	3106	3152	3203	3210	3227	3261	3289	3359	3366	3373	3380	3424	3427	3434
	3631	3634	3951	3970	3980	3990	4129	4168							
BGE	3645	3661	3828	3833	3976										
BGT	3836														
BHI	2576	3872													
BHIS	3794	3797													
BIC	1603	1672	1683	1700	1701	1900	2087	2139	2149	2213	2584	3422	3491	3497	3627
	3944	4134													
BIS	1604	2108	2159	2585	2590	2756	2796	3428	3430						
BIT	1601	1610	1637	1670	1837	2281	2331	2341	2441	2741	3003	3005	3008	3081	3123
	3390	3423	3426	3433	4128										
BLE	3901														
BLOS	2568	3744	3752	4269											
BLT	1565	3685	3755	3978	4058										
BMI	1394	2889	3012	3809	3813	3853	4042	4061	4237	4246					
BNE	1553	1560	1581	1611	1622	1624	1693	1698	1735	1757	1764	1772	1838	1911	1944
	1962	1979	1995	2003	2069	2187	2232	2243	2280	2332	2348	2364	2399	2413	2419
	2434	2438	2454	2467	2488	2502	2508	2566	2620	2711	2742	2803	2870	2872	2926
	2929	2941	2943	2945	2988	2996	3076	3079	3082	3112	3115	3118	3124	3147	3149
	3174	3176	3178	3216	3218	3221	3233	3235	3238	3265	3267	3293	3295	3336	3338
	3386	3388	3391	3393	3708	3946	3964	4003	4263	4274					
BPL	1503	1570	1577	1642	2010	2301	2480	3011	3014	3036	3090	3625	3942	4015	
BR	1567	1689	1749	1855	1883	1903	1930	1945	1963	1980	2004	2071	2189	2249	2251
	2327	2350	2414	2435	2455	2482	2503	2574	2586	2599	2606	2631	2634	2696	2718
	3007	3429	3638	3761	3801	3909	3959	3987	3992	4052	4105	4140	4148	4228	4239
	4278														
BVC	2934	3126	3228	4245											
BVS	1909	1975	2755	4240											
CLC	3256	4005													
CLR	1401	1500	1591	1664	1696	1720	1727	1777	1823	1824	1827	1830	1831	1833	1836
	1840	1939	1954	1971	2026	2038	2050	2078	2119	2126	2167	2171	2179	2192	2198
	2227	2267	2283	2317	2320	2321	2326	2338	2339	2340	2515	2548	2616	2684	2689
	2703	2749	2769	2772	2783	2795	2818	2887	2897	2905	2913	2921	2958	3034	3048
	3055	3062	3069	3088	3100	3107	3167	3204	3211	3262	3281	3360	3367	3374	3381
	3499	3501	3614	3615	3651	3671	3699	3702	3716	3730	3742	3792	3846	3857	3870
	3933	3934	3935	4030	4031	4095	4100	4101	4181	4234					
CLRB	3435														
CLV	4242														
CMP	1598	1750	1873	1910	1927	1947	1958	1964	1976	1987	1991	1999	2006	2204	2237

	2289	2567	2575	2602	2619	2622	2624	2635	2895	2903	2911	2919	3046	3053	3060
	3067	3098	3105	3202	3209	3260	3288	3358	3365	3372	3379	3630	3633	3644	3660
	3743	3751	3779	3793	3796	3827	3832	3835	3871	3900	3945	3963	4055	4268	
CMPB	1559														
COM	1841	1906	1923	2336	2636	2844	2846	2847	2890	2893	2901	2909	2917	2927	2936
	2937	2938	2939	2960	2989	2990	3037	3074	3077	3091	3102	3103	3109	3110	3113
	3116	3169	3171	3197	3219	3230	3231	3236							
DEC	1692	1697	1734	1756	1759	1771	1943	1961	1972	1978	2002	2231	2242	2279	2869
	2871	2925	2928	2940	2942	2987	2995	3075	3078	3111	3114	3117	3146	3148	3173
	3175	3177	3215	3217	3220	3232	3234	3264	3266	3292	3294	3335	3337	3385	3387
	3795	3873	4050	4262	4273										
DECB	1564														
EMT	1337														
HALT	1372	1408	1476	1578	1589	1643	2343	2630	2632	4241	4247				
INC	1502	1940	1955	1994	1996	2247	2248	2288	2411	2432	2452	2478	2500	2520	3684
	3707	3753	3772	3979	3989	4057	4233								
INCB	2223	2693	4238	4243											
JMP	1411	1414	1417	1423	1426	1592	2097	2105	2136	2156	2211	2293	2310	2446	2523
	2527	2531	2542	2707	3153	3502	3650	3679	3780	3837	4004	4169	4170	4248	4265
	4276														
JSR	1397	1406	1407	1410	1413	1416	1422	1425	1460	1495	1497	1504	1531	1558	1566
	1584	1585	1587	1606	1612	1613	1615	1618	1619	1625	1628	1630	1633	1635	1639
	1644	1662	1699	1717	1725	1736	1775	1820	1821	1842	1849	1858	1859	1861	1870
	1936	1952	1984	2019	2020	2027	2036	2051	2063	2079	2090	2099	2121	2128	2133
	2151	2175	2181	2194	2200	2208	2222	2259	2263	2270	2274	2285	2291	2298	2304
	2306	2346	2349	2351	2353	2357	2359	2361	2365	2367	2369	2371	2373	2376	2406
	2410	2426	2431	2444	2448	2451	2460	2462	2474	2477	2496	2499	2516	2519	2538
	2540	2552	2554	2559	2561	2571	2572	2573	2582	2594	2595	2656	2659	2663	2682
	2692	2706	2715	2810	2841	2883	2886	2898	2906	2914	2922	2931	2957	2994	3028
	3033	3043	3049	3056	3063	3070	3085	3096	3101	3108	3121	3166	3190	3193	3205
	3212	3224	3249	3252	3257	3263	3277	3280	3285	3328	3349	3353	3361	3368	3375
	3382	3404	3405	3408	3425	3493	3616	3618	3619	3621	3628	3636	3639	3655	3656
	3658	3663	3669	3678	3709	3712	3725	3727	3768	3778	3814	3826	3838	3854	3888
	3690	3891	3892	3894	3896	3897	3898	3907	3939	3957	3960	3967	3981	3991	3993
	4000	4010	4011	4012	4025	4043	4047	4048	4062	4083	4085	4087	4088	4120	4121
	4123	4126	4130	4131	4132	4133	4137	4139	4143	4145	4155	4163	4166		
MOV	1396	1400	1405	1409	1412	1415	1421	1424	1431	1432	1433	1434	1435	1436	1437
	1438	1443	1444	1445	1446	1447	1448	1449	1450	1459	1463	1464	1465	1466	1467
	1468	1470	1471	1473	1475	1480	1483	1484	1485	1486	1488	1489	1491	1492	1498
	1499	1528	1530	1548	1549	1555	1561	1582	1583	1605	1607	1608	1617	1627	1632
	1645	1663	1666	1667	1678	1679	1688	1694	1718	1719	1724	1737	1746	1747	1752
	1753	1754	1755	1758	1766	1768	1769	1770	1773	1818	1819	1825	1826	1828	1832
	1839	1847	1848	1850	1851	1852	1853	1857	1865	1866	1867	1868	1872	1884	1885
	1892	1899	1902	1905	1908	1915	1918	1919	1920	1921	1922	1926	1934	1935	1937
	1938	1941	1942	1950	1951	1953	1956	1957	1968	1969	1973	1974	1982	1983	1985
	1986	1990	1997	1998	2011	2018	2021	2024	2025	2030	2031	2032	2033	2035	2046
	2047	2048	2049	2054	2055	2057	2059	2060	2061	2062	2070	2074	2075	2076	2077
	2082	2083	2084	2085	2089	2098	2109	2116	2120	2123	2127	2132	2137	2138	2140
	2141	2143	2147	2148	2150	2160	2168	2172	2178	2180	2188	2191	2193	2197	2199
	2203	2207	2212	2214	2218	2219	2224	2225	2226	2228	2229	2230	2234	2235	2236
	2252	2253	2256	2257	2258	2260	2261	2262	2268	2269	2271	2272	2273	2277	2284
	2286	2287	2302	2319	2324	2325	2337	2375	2377	2380	2382	2395	2396	2404	2408
	2409	2416	2417	2424	2429	2430	2439	2440	2449	2450	2464	2465	2472	2475	2476
	2485	2486	2493	2495	2497	2498	2505	2506	2513	2517	2518	2526	2530	2535	2536
	2547	2549	2551	2556	2563	2564	2565	2577	2578	2583	2587	2588	2589	2593	2600
	2601	2611	2612	2613	2615	2618	2621	2638	2640	2647	2648	2653	2655	2661	2664

.MCALL	1201														
.NLIST	7	1197	1198												
.REM	8														
.SBTTL	1203	1453	1513	1594	1804	2014	2216	2312	2313	2532	2544	2608	2609	2671	2762
	2833	2950	3159	3243	3343	3398	3504								
.TITLE	1202														
.WORD	1358	1359	1361	1362	1364	1365	1367	1369	1379	1380	1398	1399	1419	1420	1474
	1501	1515	1516	1521	1522	1532	1546	1547	1580	1739	1741	1774	1780	1803	1829
	2039	2058	2173	2295	2322	2354	2362	2370	2374	2385	2386	2387	2388	2389	2390
	2391	2392	2405	2425	2463	2473	2494	2514	2537	2555	2562	2607	2658	2667	2721
	2722	2723	2724	2725	2726	2750	3414	3415	3416	3417	3611	3617	3622	3815	3816
	3855	3856	3865	3866	3867	3889	3895	3908	3911	3912	3914	3915	4001	4044	4049
	4063	4067	4084	4086	4089	4122	4124	4138	4144	4146	4152	4156	4227	4229	4250
	4251	4279	4280												

ERRORS DETECTED: 0
 DEFAULT GLOBALS GENERATED: 0

*DDQABA, DDQABA, SEQ/SOL/CRF/DS:ERFZ/EN:ABS=DSKM:DDQABA.P11
 RUN-TIME: 21 25 5 SECONDS
 RUN-TIME RATIO: 131/52=2.4
 CORE USED: 10K (20 PAGES)