

This microfiche card contains a grid of 60 frames of control logic test data, arranged in 10 rows and 6 columns. Each frame contains a small table or diagram with various alphanumeric characters and symbols, representing test results or configurations for the MD-11-DZTEB-A system. The data is organized into columns, with some frames containing headers or sub-headers. The overall layout is a structured grid of test data.

16

B01

EOF1DZTEFASQ

00010000

770608

PDP10 411

HDR1DZTEBASEQ

00010000

770608

.REM %

IDENTIFICATION

PRODUCT CODE: MAINDEC-11-DZTEB-A-D
PRODUCT NAME. TM03/TE16 CONTROL LOGIC TEST PART II
DATE CREATED: 21 FEB 77
MAINTAINER: DIAGNOSTIC ENGINEERING
AUTHOR: J. G. ADAMS

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS MANUAL.

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED TO THE PURCHASER UNDER A LICENSE FOR USE ON A SINGLE COMPUTER SYSTEM AND CAN BE COPIED (WITH INCLUSION OF DIGITAL'S COPYRIGHT NOTICE) ONLY FOR USE IN SUCH SYSTEM, EXCEPT AS MAY OTHERWISE BE PROVIDED IN WRITING BY DIGITAL.

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

COPYRIGHT (c) 1977, BY DIGITAL EQUIPMENT CORPORATION

TABLE OF CONTENTS

PARAGRAPH	SUBJECT	PAGE
1.	ABSTRACT	3
2.	REQUIREMENTS	3
3.	LOADING PROCEDURE	3
4.	STARTING PROCEDURE	3
5.	SWITCH SETTINGS	5
6.	ERROR PRINTOUTS	5
7.	OPERATION	5
8.	SUBTEST SUMMARIES	8
9.	LISTING	15

1. ABSTRACT

THIS PROGRAM IS DESIGNED TO SEQUENTIALLY TEST THE DATA FORMATTING FUNCTIONALITY OF THE TMO3 FORMATTER. EACH TEST WILL ATTEMPT TO ISOLATE FAILURES TO THE MODULE LEVEL AND PROVIDE PRINTOUT INFORMATION WHICH WILL IDENTIFY THE FAILING MODULE. THE LEVEL OF FAULT ISOLATION IS POSSIBLE BECAUSE OF TMO3 THE STRUCTURE AND ITS MAINTAINENCE MODES.

2. REQUIREMENTS (HARDWARE)

- A. ANY PDP-11 PROCESSOR
- B. 8K OF CORE
- C. CONSOLE TTY
- D. TMO3 MAGTAPE CONTROLLER
- E. MASSBUS CONTROLLER (RH)
- F. TE16 MAGTAPE TRANSPORT

3. LOADING PROCEDURE

USE STANDARD PROCEDURE FOR LOADING BINARY PAPER TAPE.

4. STARTING PROCEDURE

THERE ARE TWO (2) STARTING ADDRESSES THAT MAY BE USED:
200(8) AND 210(8).

- A. 200(8): STARTING AT THIS ADDRESS WILL CAUSE A PROGRAM IDENTIFICATION HEADER TO BE PRINTED BEFORE TESTING IS BEGUN.
- B. 210(8): STARTING AT THIS ADDRESS WILL NOT PRINT THE IDENTIFICATION HEADER AND IS THEREFORE GENERALLY TO BE USED FOR RESTARTS RATHER THAN INITIAL START

** NOTE: SEE ALSO SEC 5. CONSOLE SWITCH SETTINGS
** TYPE ↑C TO RESTART PROGRAM (2200)

4.1 AUTOMATIC MODE OPERATION

IF THIS PROGRAM IS LOADED AND RUN IN AUTOMATIC (CHAIN) MODES
 DEFAULT RESPONSES TO OPERATOR REQUESTS ARE USED. THE SOFTWARE
 SWR IS INVOKED WITH A SWITCH SETTING OF 10000 (HALT ON ERROR)
 IF IN ACT11 CHAIN MODE. NO OPERATOR INTERVENTION IS REQUIRED.

**EXCEPTION: IF THIS PROGRAM IS LOADED VIA TMDP CHAIN MODE THE
 PROGRAM WILL NOT TEST TMD3 DRIVE #0, TE16 SLAVE #0.

4.2 SAMPLE START AT 200

NOTE: DEFAULT RESPONSES ARE SHOWN IN ANGLE BRACKETS (< >),
 OPERATOR RESPONSES ARE SHOWN IN PARENTHESES (') AND
 MEMORY LOCATIONS CONTAINING THE DEFAULT ARE SHOWN IN
 SQUARE BRACKETS [].

PARAMETER REQUEST: <DEFAULT> (RESPONSE) [LOCATION:]

TMD3-TE16 CONTROL LOGIC TEST PART II (DZTEB-A)
 ASSURE TAPE IS AT BOT
 TYPE ↑C TO RESTART

REGISTER START: <172440> (CR)	[REGS:]
VECTOR ADDRESS: <224> (CR)	[VECT:]
TMD3 DRIVE: <0> (CR)	[DRVN:]
TE16 SLAVE: <0> (CR)	[SLVN:]
IF THE SOFTWARE SWR IS INVOKED:	
SWR = <00000> NEW = (CR)	[SWREG:]

5. CONSOLE SWITCH SETTINGS

CONTROL:

- 1) CONTROL G (↑G):
SELECTS THE SOFTWARE SWR AND ALLOWS NEW SWITCH SETTINGS.

THE MACHINE WILL THEN TYPE: SWR=XXXXXXXXNEW=
WHERE: XXXXXX IS THE OCTAL CONTENTS OF THE SOFTWARE SWR.
AFTER 'NEW=' HAS BEEN TYPED THEN THE OPERATOR CAN DO ONE
OF THE FOLLOWING AT THE TTY:
A) TYPE AN OCTAL NUMBER TO BE LOADED INTO THE SOFTWARE SWR.
B) IF A (CR) IS THE FIRST KEY DEPRESSED THE SOFTWARE SWITCH
REGISTER CONTENTS WILL NOT BE CHANGED.
- 2) CONTROL A (↑A):
ALTERNATES THE SWITCH REGISTER FROM HARDWARE TO SOFTWARE & VICE VERSA.
- 3) CONTROL C (↑C):
RESTART PROGRAM AT 200
- 4) CONTROL U (↑U):
DELETES ALL CHARACTERS TYPED IN RESPONSE TO A REQUEST.

ALL SWITCHES ARE USED (0-15) AND THE NORMAL, OR DEFAULT, RUN
IS DONE WITH ALL SWITCHES SET TO ZERO (0).
ALL SWITCHES ARE DYNAMIC AND MAY BE CHANGED AT ANY TIME.

SW15: 1=HALT ON ERROR
0=CONTINUE
SW14: 1=LOOP ON ERROR (SCOPE)
0=CONTINUE
SW13: 1=DO NOT PRINT ERRORS
0=PRINT ALL ERRORS
SW12: 1=DO CONTINUOUS CYCLE
0=HALT AT END OF PASS
SW11: 1=INHIBIT ITERATIONS
0=ITERATE EACH TEST ITS ASSIGNED AMOUNT
SW10: 1=HALT AT END OF CURRENT TEST
0=CONTINUE TO NEXT TEST
SW8: 1=INHIBIT WRAP AROUND DATA CHECK
0=DO DATA CHECKS
SW7: 1=INHIBIT WRAP AROUND STATUS CHECK
0=DO STATUS CHECK
SW6: 1=SELECTABLE WRAP DATA PATTERN (IN SINGLE TEST)
0=AUTO PATTERN
SW5-0: SELECT INDIVIDUAL TEST ** 00=DO ALL TESTS

6. ERROR PRINTOUTS

ERROR PRINTOUTS WILL APPEAR IN TWO FORMS, ONE FOR THE CONTROL LOGIC TESTS AND ANOTHER FOR THE DATA TESTS.

CONTROL LOGIC PRINTOUTS WILL CONTAIN A HEADER WHICH CALLS OUT THE TEST NUMBER, FUNCTION BEING TESTED, AND THE SUSPECT MODULE, OR MODULES ON THE FIRST LINE. THE SECOND LINE WILL CONTAIN INFORMATION AS TO THE ACTUAL ERROR. BOTH THE EXPECTED RESULT AND THE ACTUAL RESULT OF THE TEST WILL BE GIVEN. LINE THREE WILL SHOW THE CONTENTS OF THE MAJOR REGISTERS AT THE TIME OF THE ERROR AND LINE FOUR WILL PRINT THE ITERATION NUMBER WHEN APPLICABLE.

DATA TESTS WILL PRINT A HEADER CONTAINING THE TEST NUMBER, AND A DESCRIPTION OF THE WRAP AROUND FUNCTION UNDER TEST. FOLLOWING THE HEADER WILL BE A LIST OF THE MAJOR REGISTERS WITH THE EXPECTED AND ACTUAL VALUES. ANY BAD DATA WILL BE PRINTED (PER CHARACTER) FOLLOWING THE REGISTER INFORMATION OR FOLLOWING THE HEADER IF NO STATUS ERRORS WERE ENCOUNTERED.

5. THE FOLLOWING ARE TWO EXAMPLES OF ERRORS DETECTED BY THE WRAP AROUND DATA TESTS. NOTE THAT EACH WRAP AROUND TEST MAY BE ACCOMPANIED BY EITHER A STATUS ERROR OF A DATA ERROR OR BOTH.

LOGIC TEST 1: WRAP 3, NRZ, NORMAL, ODD
 BAD STATUS
 CS1 EXPT 004270 RCVD 144270
 CS2 EXPT 000100 RCVD 000100
 DS EXPT 010600 RCVD 150600
 ER EXPT 000000 RCVD 000100

THIS MESSAGE INDICATES BAD STATUS OF VPE (BIT 6 OF ER)

LOGIC TEST 3: WRAP 2, NRZ, NORMAL, ODD
 BAD DATA
 CN:0
 G: 11111111
 B: 11111011
 CN:10
 G: 00000000
 B: 00001000

THIS MESSAGE SHOWS THAT DATA RECEIVED WAS NOT AS EXPECTED. CHARACTER ZERO (CN: 0) SHOWS THAT BIT TWO (2) WAS DROPPED, WHILE CHARACTER TEN (CN: 10) SHOWS BIT THREE (3) HAS BEEN PICKED UP
 G: = EXPECTED DATA (GOOD)
 B: = ACTUAL DATA (BAD)

7. OPERATION

THE PROCEDURES FOR OPERATING THIS PROGRAM ARE QUITE SIMPLE AND REQUIRE ONLY A FEW STEPS:

1. LOAD ADDRESS 200 OR 210
2. SET SWITCHES FOR DESIRED TEST CYCLE
3. PRESS START

ALL CONSOLE SWITCHES ARE DYNAMIC AND MAY BE CHANGED AT ANY TIME. THE NORMAL OPERATING SEQUENCE IS ALL SWITCHES DOWN (0). THE TEST WILL TAKE APPROXIMATELY 3 MINUTES TO RUN; HOWEVER, IF ITERATIONS ARE INHIBITED (SW11=1) THE TEST WILL RUN IN ABOUT 30 SECONDS. THE END OF PASS IS NOTED BY A PRINTOUT STATING END OF PASS, AND THE NUMBER OF THAT PASS.

SINGLE TEST SELECTION: (SMD-SM5)

WHEN SMD-SM5 ARE SET TO ZERO (00), THE SCHEDULAR WILL EXECUTE ALL TESTS IN SEQUENCE. IF SMD-SM5 ARE SET TO SOME SPECIFIC TEST NUMBER THEN THAT PARTICULAR TEST ONLY WILL BE EXECUTED UNTIL THE TEST SELECT NUMBER IS CHANGED. WHEN YOU WISH TO SELECT A PARTICULAR TEST, SET SW10 TO A ONE (1) IN ORDER TO STOP AT THE END OF THE CURRENT TEST BEFORE SELECTING A DIFFERENT TEST NUMBER. YOU MAY SELECT THAT NUMBER IN ANY DIRECTION (HIGHER OR LOWER) BECAUSE EACH TEST IS SELF CONTAINED.

WRAP AROUND DATA PATTERNS MAY BE SELECTED VIA SW6 WHEN IN SINGLE TEST MODE. A TELETYPE REQUEST IS MADE FOR THE DESIRED DATA PATTERN WHENEVER SWITCH TEN (SW10) AND SWITCH SIX (SW6) ARE SET TO A ONE (1) WHILE ONE OF THE WRAP TESTS IS SELECTED IN SMD-SM5.

8. SUBTEST SUMMARIES

NOTE: FOR TESTS 1-15

FOR THE MOST PART, THIS DIAGNOSTIC TESTS PARTICULAR AREAS OF THE TMD3 LOGIC INDEPENDENT OF THE TE16. HOWEVER THERE ARE A FEW SIGNALS WHICH ARE REQUIRED FROM THE TE16 TO COMPLETE THE TESTS, AND AT LEAST ONE CASE WHERE TE16 FAILURES INTERFERE WITH THE TESTS. THE KNOWN CASES ARE LISTED HERE AND SHOULD BE CHECKED AS PART OF THE DEBUGGING.

1. MOL(SB)L: REQUIRED TO ENABLE CLOCK
2. CLOCK(SB)L: REQUIRED TO GENERATE ACCELERATION AND SHUTDOWN.
3. WRITE CLOCK(SB)L: USED IN WAMP TO GENERATE DATA AND REC(SB)L
4. RSDO(SB)L: SHOULD NOT OCCUR DURING WRAP AROUND TESTS, BUT WILL INTERFERE WITH THEIR OPERATION IF CAUSED BY A FAILURE SUCH AS A GROUNDED OUTPUT FROM THE G056.

LOGIC TEST 1: WRP3, NRZ, NORMAL, 000 (BIT FIDDLER READ)

PROGRAMMED SEQUENCE:

TAPE CONTROL REGISTER IS LOADED WITH DENSITY 3, FORMAT 14, 000 PARITY WRP3 IS LOADED IN MAINT. REGISTER. READ FUNCTION IS LOADED. EXECUTING WRP3 CONSISTS LOADING DATA CHARACTERS INTO MAINT. REGISTER DATA FIELD, WHERE THERE ARE MULTI- PLEXERS TO BIT FIDDLER, MM CLK IS TOGGLED TO CREATE RDS. THE BIT FIDDLER TRANSMIT DATA ACCESS MASSBUS DATA LINES. WHEN ALL THE DATA HAS BEEN TRANSMITTED AN EOR CLK IS TRANSMITTED TO N REGISTER WHICH BRINGS OPERATION TO A CLOSE.

LIKELY FAULT LOCATIONS: M8906, M8905, MASSBUS P-LINES

CIRCUITS

PRINT REFERENCES

MASSBUS CHAR. ASSEMBLE
 CLK. GENERATOR
 MAINT. REGISTER DATA FIELD
 RDS GENERATION

BFS
 BF2
 MR2, MR3
 MRS

LOGIC TEST 2: WARP3, PE, NORMAL, ODD

JUST LIKE TEST 1 EXCEPT FOR DENSITY BITS.

LOGIC TEST 3: WRAP2, NRZ, NORMAL, ODD

PROGRAMMED SEQUENCE:

WRAP2 IS BIT FIDDLER WRITE. MM CLOCK IS MULTIPLEXED INTO WRT CLK SO THAT IT FORMS WRT STROBE. THE OUTPUT OF THE BIT FIDDLER IS CLOCKED INTO THE DATA FIELD OF THE MAINTENANCE REGISTER. SET UP CONSISTS OF MOVING NRZ, NORMAL FORMAT, ODD PARITY TO UNIT DESCRIPTION MAINT. REGISTER IS LOADED WITH WRAP2 WRITE COMMAND IS ISSUED. AFTER THE ACCELERATION DELAY, MM CLOCK ARE GENERATED UNTIL ALL THE DATA HAS BEEN CLOCKED. SE JENCE IS COMPLETED BY LOADING MAINTENANCE REGISTER WITH EOR CLR. THE SEQUENCE IS REPEATED WITH VARYING DATA PATTERNS.

LIKELY FAULT LOCATIONS: M8906, M8905, M8903

CIRCUITS

PRINT REFERENCES

BIT FIDDLER CHAR UNPACK
BIT FIDDLER DATA REQUEST
WRT STRB.
MAINT. REG. DATA FIELD

BF4
BF2
TCCM4
MR2, MR3

LOGIC TEST 4: WRP2, PE, NORMAL, 000

THE TEST IS EXACTLY LIKE TEST 43 EXCEPT THAT PE WRT CLK ENBL L MUST BE ASSERTED BY M8902 TO ENABLE WR TO STROBE. THIS DOES NOT HAPPEN UNTIL THE PE WRITE CONTROL CIRCUIT HAS CLOCKED THROUGH THE PREAMBLE.

CIRCUITS PRINT REFERENCES

(IN ADDITION TO TEST 44)
PE WRITE CONTROL TCPE3

LOGIC TEST 5: WRP1, NRZ, NORMAL, 000

THIS TEST IS EXACTLY LIKE TEST 43 EXCEPT THE WRITE BUFFER (TCCM2) IS MULTIPLEXED TO THE MAINTENANCE REGISTER.

LIKELY FAULT LOCATIONS: M8903, M8904 (CRC GENERATOR)

CIRCUITS PRINT REFERENCES

WRITE BUFFER TCCM2
CRC GENERATOR CNRZ2

LOGIC TEST 6: WRAP1, PE, NORMAL, 000

IN PE MODE BOTH THE PREAMBLE AND POSAMBLE ARE CLOCKED THROUGH THE WRITE BUFFER IN ADDITION TO PHASE ENCODED DATA.

LIKELY FAULT LOCATIONS: M8902 (WRITE CONTROL STATES), M8903

CIRCUITS PRINT REFERENCE

WRITE BUFFER TCCM2
WRITE CONTROL TCPE3

LOGIC TEST 7: WRAP0, NORMAL, ODD

WRAP 0 IS THE MOST COMPLETE OF THE TMO3 WRAPAROUND DATA PATH. IT CONSISTS OF A WRITE OPERATION IN WHICH THE OUTPUT OF THE WRITE DATA BUFFER IS MULTIPLEXED TO THE READ DATA INPUTS, CHECKED AND LOADED INTO THE MAINTENANCE REGISTER FOR RETRIEVAL BY THE PROCESSOR. THE WHOLE OPERATION USES THE TYPE SYSTEM CLOCKS AND HAPPENS AT THE PROPER DATA RATES. MM CLK SERVES AS A FLAG ANNOUNCING WHEN A NEW CHARACTER HAS BEEN LOADED INTO THE MAINTENANCE REGISTER. IN PE MODE EVERY OTHER CHARACTER IS READ TO ALLOW SUFFICIENT PROCESSOR LOOP TIME. IN NRZ WRAP 0 IS EXPECTED TO PRODUCE LRC ERRORS BECAUSE THE TMO3 DOES NOT WRITE THE LRC CHARACTER.

LIKELY FAULT LOCATIONS: M8904, M8903

CIRCUITS
-----PRINT REFERENCES

CRC GENERATOR	CNR22
CRC CHECKOUT	CNR23
CRC CRC STROBE	TCCM4
READ LINE MULTIPLEXERS	TCCM6
MM CLK	MRS
CRC READ TIMING	CNR24
SHUTDOWN CIRCUITRY	TCCM5

LOGIC TEST 10: WRPO, PE, NORMAL, ODD

REPEAT OF TEST 7 IN PE MODE.

LIKELY FAULT LOCATIONS: M8901, M8902, M8903

CIRCUITS
-----PRINT REFERENCES

DATA DISCRIMINATOR	DS2, DS4, DS6
PHASE LOCKED CLOCK	DS3, DS5, DS7
SKREW BUFFER	DS3, DS5, DS7
PE WRITE MAJOR STATES	TCPE3
PE READ MAJOR STATES	TCPE5
WRAP 0 CIRCUIT TO BLOCK RLT RDS	TCPE3
DESKEW BUFFER READ COUNTER	TCPE4

NO1

LOGIC TEST 11: CORE DUMP WRITE, WAM2

REPEAT OF TEST 3 EXCEPT BIT FIDDLER OPERATES IN CORE DUMP
MODE!

LIKELY FAULT LOCATION: M8906

LOGIC TEST 12: CORE DUMP READ, WAM3

REPEAT OF TEST 1 EXCEPT BIT FIDDLER OPERATES IN CORE DUMP
MODE!

LIKELY FAULT LOCATION: M8906

LOGIC TEST 13: EVEN PARITY WRITE - WAM1

REPEAT OF TEST 5 EXCEPT EVEN PARITY IS SPECIFIED.

LIKELY FAULT LOCATION: M8903

LOGIC TEST 14: EVEN PARITY READ: WAM0,

REPEAT OF TEST 7 EXCEPT EVEN PARITY IS USED.

LIKELY FAULT LOCATIONS: M8903, M8904

LOGIC TEST 15: READ REVERSE, WAM3 (M8906)

REPEAT OF TEST 2 EXCEPT READ REVERSE COMMAND IS ISSUED.

LIKELY FAULT LOCATIONS: M8908, M8909

LOGIC TEST 16: CRC ERROR CORRECTION

THIS TEST SIMULATES A BAD TRACK ON TAPE RESULTING IN A CRC ERROR &
SUBSEQUENT CORRECTION OF DATA IN THE FAILING TRACK.
THE TEST PROCEEDS THROUGH THE FOLLOWING STEPS:

A: WRITE DATA USING WRAP 0
B: REWRITE DATA WITH DATA BITS IN ONE TRACK ALTERED USING WRAP 4
C: READ REVERSE USING WRAP 3
D: REWRITE DATA AS IN STEP B USING WRAP 4
AT THIS POINT THE DATA READ BACK HAS BEEN CORRECTED TO MATCH
THE DATA WRITTEN IN STEP A
E: REPEAT STEPS A-D ABOVE FOR EACH TRACK
F: REPEAT STEPS A-E ABOVE FOR ALL 1'S, ALL 0'S &
125125 DATA PATTERNS.

523

%

.LIST BIN,LOC,SEQ

524
525
526
527
528
529
530
531
532
533
534
535
536
537
538
539
540
541
542
543
544
545
546
547
548
549
550
551
552
553
554
555

```
.TITLE TM03/TE16 CONTROL LOGIC TEST-PART II
:MAINDEC-11-DZTEB-A-D
:FEB 77
:R. BARNES
:MCALL .SACT11,.SEOP,$CATCH,$SAVE,$RESTORE,$CHAIN,$CHNMODE
:MLIST MC
:LIST ME
:ENABLE ABS,AMA
```

:CONSOLE SWITCHES*****

```
:SW15: 1=HALT ON ERROR
:      0=CONTINUE
:SW14: 1=LOOP ON ERROR
:      0=CONTINUE
:SW13: 1=DO NOT PRINT ERRORS
:      0=PRINT ERRORS
:SW12: 1=HALT AT END OF PASS
:      0=CONTINUOUS CYCLE
:SW11: 1=INHIBIT ITERATIONS
:      0=DO ITERATIONS
:SW10: 1=HALT AT END OF EACH TEST
:      0=CONTINUE
:SW8:  1=NO WRAP DATA CHECK
:      0=DO WRAP DATA CHECK
:SW7:  1=NO WRAP STATUS CHECK
:      0=DO WRAP STATUS CHECK
:SW6:  1=SELECTABLE WRAP DATA PATTERN (IN SINGLE TEST)
:      0=AUTO PATTERNS
:SW0-5: SELECT TEST NUMBER :: 00=ALL TESTS
```

;IF HARDWARE SWR <15::00> = 177777 OR NOT AVAILABLE USE SOFTWARE SWR


```

602                                     ;REGISTER EQUIVS*****
603
604                                     R0=%0
605                                     R1=%1
606                                     R2=%2
607                                     R3=%3
608                                     R4=%4
609                                     R5=%5
610                                     SP=%6
611                                     PC=%7
612
613
614
615                                     ;ACT11 HOOK *****
616                                     $SVPC=.                               ;SAVE CURRENT LOCATION CTR
617                                     .=46
618 000046 002310                       .WORD SENDAD                       ;SET LOCATION 46
619                                     .=52
620 000052 000000                       .WORD 0                               ;SET LOCATION 52 = 0
621                                     .=$SVPC                               ;RESTORE LOCATION CTR
622
623                                     ;TTY INTERRUPT VECTOR*****
624
625                                     .=60
626 000060 012250                       .WORD TTINT                          ;TTY INTERRUPT HANDLER ADDRESS
627 000062 000340                       .WORD 340                            ;PRIORITY LEVEL 7
628
629                                     ;SOFTWARE SWITCH REGISTER*****
630                                     ;USED IF HARDWARE SWR = 177777, OR NOT AVAIL.
631                                     .=176
632 000176 000000                       SWREG: .WORD 0
633
634
635                                     ;START ADDRESS*****
636                                     .=200
637 000200 000137 001200               JMP START ;PROGRAM START
638
639                                     ;RESTART ADDRESS*****
640                                     .=210
641 000210 000137 001670               JMP ST2
642
643                                     ;TMO3 INTERRUPT VECTOR*****
644
645                                     .=224
646 000224 012240                       MTINT                                ;TAPE INTERRUPT HANDLER ADDRESS
647 000226 000340                       340
648

```

649				
650		000510		.=510
651				; MASS BUS REGISTER EQUIVS*****
652				
653	000510	172440	CI:	172440
654	000512	172442	WC:	172442
655	000514	172444	BA:	172444
656	000516	172446	FC:	172446
657	000520	172450	CS:	172450
658	000522	172452	DS:	172452
659	000524	172454	ER:	172454
660	000526	172456	AS:	172456
661	000530	172460	CC:	172460
662	000532	172462	DB:	172462
663	000534	172464	MA:	172464
664	000536	172466	DT:	172466
665	000540	172470	SN:	172470
666	000542	172472	TC:	172472
667				
668				; ILLEGAL FUNCTION CODES
669				
670	000544	005405	ILFT:	5405
671	000546	007415		7415
672	000550	016423		16423
673	000552	020437		20437
674	000554	022443		22443
675	000556	025447		25447
676	000560	031455		31455
677	000562	033465		33465
678	000564	036473		36473
679				
680				; CONSTANTS*****
681				
682	000566	177776	PSM:	177776
683	000570	177570	SMR:	177570
684	000572	177560	TKS:	177560
685	000574	177562	TKB:	177562
686	000576	177564	TPS:	177564
687	000600	177566	TPB:	177566
688	000602	177777	SERNUM:	177777
689	000604	000011	DRVTP:	011
690	000606	000020	ITAMT:	20
691	000610	000224	VECT:	224
692	000612	172440	REGS:	172440

; PROCESSOR STATUS
 ; SWITCH REGISTER
 ; TTY READER STATUS
 ; TTY READ BUFFER
 ; TTY PUNCH STATUS
 ; TTY PUNCH BUFFER
 ; SERIAL NUMBER
 ; DRIVE TYPE
 ; ITERATION AMOUNT
 ; INTERRUPT VECTOR(RH)
 ; STARTING REGISTER ADDRESS

693
694
695
696
697
698 000614
699 000614 000000
700 000616 000000
701 000620 000000
702 000622 000000
703 000624 000000
704 000626 000000
705 000630 000000
706 000632 000000
707 000634 000000
708 000636 000000
709 000640 000000
710 000642 000000
711 000644 000000
712 000646 000000
713 000650 000000
714 000652 000000
715 000654 000000
716 000656 000000
717 000660 000700
718 000662 000000
719 000664 000000
720 000666 000000
721 000670 000000
722 000672 000000
723 000674 000000
724 000676 000000
725 000700 000000
726 000702 000000
727 000704 000000
728 000706 000000
729 000710 000000
730 000712 000000
731 000714 000000
732 000716 000000
733 000720 000000
734 000722 000000
735 000724 000000
736 000726 000000
737 000730 000000
738 000732 000000
739 000734 000000
740 000736 000000
741 000740 000000
742 000742 000000
743 000744 000000
744 000746 000000
745 000750 000000
746 000752 000000
747 000754 000000
748 000756 000000

```

; FLAGS AND COUNTERS*****
; NOTE ALL FLAGS AND COUNTERS ARE CLEARED ON STARTUP. PUT ANY
; ADDITIONAL FLAGS BETWEEN STFLGS (START OF FLAGS) AND ENDFLG
; (END OF FLAGS)

STFLGS:
T08: 0
TIB: 00
HORFL: 000
EMADDR: 00000
DRVN: 00000
TRO0: 00000
TRO1: 00000
TRO2: 00000
TRO3: 00000
TRO4: 00000
TRO5: 00000
TRO6: 00000
TRO7: 00000
TR10: 00000
TR11: 00000
TR12: 00000
TR13: 00000
TR14: 00000
TR15: 00000
NRZOF: 00000
SLVN: 00000
PFLG: 00000
RTRN: 00000
ERADD: 00000
TEMP1: 00000
TEMP2: 00000
TEMP3: 00000
ITCNT: 00000
SAV1: 00000
SAV2: 00000
SAV3: 00000
SCOLP: 00000
ITRLP: 00000
EXFL: 00000
ATAF: 00000
SLAF: 00000
SSCF: 00000
ERRF: 00000
ASF: 00000
SCF: 00000
TREF: 00000
PEXFL: 00000
STFLG: 00000
LTADD: 00000
T24FL: 00000
ADDFL: 00000
WAM: 00000
FUN: 00000
DATC: 00000
WTAD: 0

```

749 000760 000000
 750 000762 000000
 751 000764 000000
 752 000766 000000
 753 000770 000000
 754 000772 000000
 755 000774 000000
 756 000776 000000
 757 001000 000000
 758 001002 000000
 759 001004 000000
 760 001006 000000
 761 001010 000000
 762 001012 000000
 763 001014 000000
 764 001016 000000
 765 001020 000000
 766 001022 000000
 767 001024
 768
 769
 770
 771 001024 000000
 772 001026 000000
 773 001030 000000
 774 001032 000000
 775
 776
 777
 778 001034
 779 001034 005076
 780 001036 005116
 781 001040 005122
 782 001042 005130
 783
 784
 785
 786 001044 000005
 787 001046 000005
 788 001050 000012
 789 001052 000012
 790 001054 000000
 791 001056 000017
 792 001060 000017
 793 001062 000017
 794 001064 000017
 795 001066 000000

DATA0: 0
 ROAD: 00
 W2FLG: 00
 DERFL: 00
 PREFL: 00
 SERFL: 00
 CRCNT: 00
 UDES: 00
 WPGFL: 00
 PATRN: 00
 STATF: 00
 RDRVF: 00
 RCDP: 00
 STATC: 00
 SKAT: 00
 PCNTR: 0 ;PASS COUNTER
 DCHKFL: .WORD 0 ;DATA CHECK FLAG 0/1 = CHECK/DO NOT CHECK
 CRCFLG: .WORD 0 ;CRC CORRECTION TEST IN PROGRESS
 ENDFLG:

 ;EXPT WRAP STATUS*****
 WCS1: 0
 WCS2: 0
 WDS: 0
 WER: 0

 ;DATA PATTERN GENERATORS*****
 DATBL:
 DATA0: DAT1 ;ALL ONE BITS
 DATA1: DAT2 ;ALL ZERO BITS
 DATA2: DAT3 ;ALTERNATING ONE/ZERO BITS
 DATA3: DAT4 ;ALTERNATING PARITY CHARACTERS

 ;CORE DUMP PATTERNS*****
 WCDP2: 5
 5
 12
 12
 0
 WCDPO: 17
 17
 17
 17
 0

796
797
798
799 001070 000000
800 001072 000000
801 001074 002352
802 001076 002352
803 001100 002464
804 001102 002464
805 001104 002536
806 001106 002536
807 001110 002644
808 001112 002644
809 001114 002716
810 001116 002716
811 001120 003024
812 001122 003024
813 001124 003102
814 001126 003102
815 001130 003210
816 001132 003210
817 001134 003262
818 001136 003262
819 001140 003374
820 001142 003374
821 001144 003522
822 001146 003522
823 001148 003572
824 001150 003572
825 001154 003642
826 001156 003642
827 001160 003724
828 001162 003724
829 001164 004312
830 001166 004312
831 001170 004624
832 001172 004624
833 001174 002244
834 001176 000020

;LOGIC TEST ENTRY TABLE*****

TSTTBL: 0
0
LT1
LT1
LT2
LT2
LT3
LT3
LT4
LT4
LT5
LT5
LT6
LT6
LT7
LT7
LT10
LT10
LT11
LT11
LT12
LT12
LT13
LT13
LT14
LT14
LT15
LT15
LT16
LT16
LT17
LT17
LT20
LT20

TADX: .WORD TEND
TLAST: .WORD 20

;CONTAINS # OF TESTS

```

835 .EVEN
836 ;PROGRAM START AND HOUSEKEEPING*****
837
838 001200 012706 000500 START: MOV #500,SP ;SET STACK POINTER
839 001204 013746 000004 MOV #204,-(SP) ;SAVE ERROR TRAP
840 001210 013746 000006 MOV #206,-(SP)
841 001214 012737 001240 000004 MOV #18,204 ;SET TIME OUT TRAP TO GO TO 1$
842 001222 005037 000006 CLR #206
843 001226 022777 177777 177334 CMP #177777,206 ;USE SOFTWARE SWITCH IF SWR = 177777
844 001234 001402 BEQ 206 ;OR TIMES OUT
845 001236 000404 BR 30 ;OTHERWISE USE HARDWARE SWR
846 001240 022626 1$: CMP (SP)+,(SP)+ ;RESET STACK
847 001242 012737 000176 000570 2$: MOV #SWREG,SWR ;SET SWR = TO ADDRESS OF SOFTWARE SWR
848 001250 012637 000006 3$: MOV (SP)+,206 ;RESTORE ERROR TRAP
849 001254 012637 000004 MOV (SP)+,204
850 001260 005027 CLR (PC)+ ;CLEAR CHAIN INDICATOR
851 001262 000000 CHNFLG: .WORD 0 ;CHAIN MODE INDICATOR
852 ;1/0 = CHAIN/NOT CHAIN MODE
853 001264 022737 002310 000042 CMP #SENDAD,2042 ;BRANCH IF LOADED VIA ACT11 CHAIN MODE
854 001272 001404 BEQ 50$
855 001274 005737 000042 TST #2042 ;BRANCH IF IN DUMP MODE
856 001300 001413 BEQ 52$
857 001302 000406 BR 51$
858 001304 012737 000176 000570 50$: MOV #SWREG,SWR ;INVOKE SOFTWARE SWR
859 001312 012777 100000 177250 MOV #100000,206 ;WITH HALT ON ERROR SET
860 001320 005237 001262 51$: INC CHNFLG ;SET CHNFLG = CHAIN MODE
861 001324 000137 001714 JMP TSCD ;GO TO CHAIN ADDRESS
862 001330 52$:
863 001330 122737 000006 000041 4$: CMPB #6,2041 ;BRANCH IF NOT LOADED VIA TMDP
864 001336 001004 BNE 5$
865 001340 012704 014433 MOV #MSG62,R4 ;ADVISE USER TO REMOVE MEDIA FROM UUT
866 001344 004737 012714 JSR PC,TTOUT
867 001350 012704 013636 5$: MOV #MSG1,R4
868 001354 004737 012714 JSR PC,TTOUT ;PRINT TITLE
869 001360 112737 000043 013636 MOVB #' MSG1 ;DO NOT PRINT TITLE ON RESTART
870 001366 012704 014327 MOV #MSG44,R4
871 001372 004737 012714 JSR PC,TTOUT ;REQUEST REGISTER ADDRESS
872 001376 013703 000612 MOV REGS,R3
873 001402 004737 013042 JSR PC,OCTP ;PRINT CURRENT ADDRESS
874 001406 012705 000612 MOV #REGS,R5 ;SET ADDRESS SAVE LOC
875 001412 012701 000007 MOV #7,R1 ;SET SIZE OF RESPONSE
876 001416 012702 176400 MOV #176400,R2 ;SET UPPER LIMIT
877 001420 012703 172300 MOV #172300,R3 ;SET LOWER LIMIT
878 001424 004737 012372 JSR PC,TTR ;GO GET RESPONSE
879 001428 012704 014351 MOV #MSG45,R4 ;REQUEST VECTOR
880 001436 004737 012714 JSR PC,TTOUT
881 001442 013703 000610 MOV VECT,R3 ;PRINT CURRENT VECTOR
882 001446 004737 013042 JSR PC,OCTP ;SET ADDRESS SAVE LOC
883 001452 012705 000610 MOV #VECT,R5 ;SET SIZE OF RESPONSE
884 001456 012701 000004 MOV #4,R1 ;SET UPPER LIMIT
885 001462 012702 000224 MOV #224,R2 ;SET LOWER LIMIT
886 001466 012703 000150 MOV #150,R3 ;GO GET RESPONSE
887 001472 004737 012372 JSR PC,TTR ;GET VECTOR
888 001476 013700 000610 MOV VECT,R0 ;LOAD INTERRUPT ADDRESS IN VECTOR
889 001502 012720 012240 MOV #MTINT,(R0)+ ;LOAD PRIORITY
890 001506 012710 000340 MOV #340,(R0)

```

891	001512	013700	000612	MOV	REGS,R0	;GET START OF REGS
892	001516	012701	000016	MOV	#16,R1	;SET NUMBER OF REGS
893	001522	012702	000510	MOV	#C1,R2	;GET START OF TABLE
894	001526	010022		65: MOV	R0,(R2)+	;BUILD TABLE
895	001530	062700	000002	ADD	#2,R0	;BUMP ADDRESS
896	001534	005301		DEC	R1	;SEE IF DONE
897	001536	001373		BNE	65	;IF NOT: BR
898	001540	012702	000614	MOV	#STFLGS,R2	
899	001544	012700	000210	MOV	#ENDFLG-STFLGS,R0	;GET # OF FLAGS TO CLEAR
900	001550	006200		ASR	R0	;FORM COUNT
901	001552	005022		75: CLR	(R2)+	;CLEAR FLAGS + COUNTERS
902	001554	005300		DEC	R0	
903	001556	001375		BNE	75	
904	001560	012704	014373	MOV	#MSG57,R4	;REQUEST TMO3 DRIVE #
905	001564	004737	012714	JSR	PC,TTOU	
906	001570	013703	000624	MOV	DRVN,R3	;GET CURRENT DRIVE
907	001574	004737	013042	JSR	PC,OCTP	;AND TYPE IT
908	001600	012705	000624	MOV	#DRVN,R5	;TTR ROUTINE RETURNS DRIVE TO (R5)
909	001604	012701	000002	MOV	#2,R1	;LIMIT RESPONSE TO 1 CHARACTER
910	001610	012702	000007	MOV	#7,R2	;BETWEEN 0 AND 7
911	001614	012703	000000	MOV	#0,R3	
912	001620	004737	012372	JSR	PC,TTR	;GET RESPONSE & PUT IN DRVN
913	001624	012704	014411	MOV	#MSG58,R4	;REQUEST SLAVE #
914	001630	004737	012714	JSR	PC,TTOU	
915	001634	013703	000664	MOV	SLVN,R3	;GET CURRENT SLAVE #
916	001640	004737	013042	JSR	PC,OCTP	;AND TYPE IT
917	001644	012705	000664	MOV	#SLVN,R5	;TTR ROUTINE RETURNS REPONSE TO (R5)
918	001650	012701	000002	MOV	#2,R1	;LIMIT RESPONSE TO 1 CHARACTER
919	001654	012702	000007	MOV	#7,R2	;BETWEEN 0-7
920	001660	012703	000000	MOV	#0,R3	
921	001664	004737	012372	JSR	PC,TTR	;GET RESPONSE & PUT IT IN SLVN
922						
923				:START 210		
924	001670	012706	000500	5T2: MOV	#500,SP	;SET STACK PTR
925	001674	005037	001006	CLR	RDRVF	;CLEAR READ REVERSE FLAG
926	001700	005037	001016	CLR	PCNTR	
927	001704	005037	001022	CLR	CRCFLG	;SET CRC FLAG = CRC NOT IN PROGRESS
928	001710	004737	013474	JSR	PC,GTSWR	;GET SOFTWARE SWITCHES

;TEST SCHEDULAR**'.*****

```

939
940
941
942
943
944
945
946
947
948
949
950
951
952
953
954
955
956
957
958
959
960
961
962
963
964
965
966
967
968
969
970
971
972
973
974
975
976
977
978
979
980
981
982
983
984
001714 052777 000100 176650 TSCD: BIS #100,@TKS ;SET KEYBOARD IE BIT
001722 005037 001000 CLR WPGFL ;CLEAR WRAP PATRN FLAG
001726 005037 000740 CLR STFLG ;CLEAR SINGLE TEST FLAG
001732 017700 176632 MOV @SWR,RO
001736 042700 177700 BIC #177700,RO ;BRANCH IF SINGLE TEST SELECTED
001742 001122 BNE STSCD ;GO SELECT SINGLE TEST
001744 005737 001262 TST CHNFLG ;BRANCH IF NOT IN CHAIN MODE
001750 001457 BEQ TSCDA
001754 012737 177777 000624 MOV #-1,DRVN ;INITIALIZE DRIVE #
001758 012737 177777 000664 NXTDRV: MOV #-1,SLVN ;INITIALIZE SLAVE #
001764 012777 000040 176524 IS: MOV #40,@CS ;INIT CONTROLLER
001774 005237 000624 INC DRVN ;STEP DRIVE #
002000 022737 000010 000624 CMP #10,DRVN ;EXIT IF ALL DRIVES TESTED
002006 001521 BEQ $NONE ;FOR AVAILABILITY
002010 013777 000624 176502 MOV DRVN,@CS ;LOAD DRIVE #
002016 005777 176466 TST @C1 ;ACCESS DRIVE
002022 032777 010000 176470 BIT #10000,@CS ;BRANCH IF DRIVE NON EXISTANT
002030 001356 BNE IS ;(MED = 1)
002032 005237 000664 NXTSLV: INC SLVN ;STEP SLAVE # AND BRANCH
002036 001011 BNE IS ;IF NOT SLAVE 0
002040 005737 000624 TST DRVN ;BRANCH IF NOT DRIVE # 0
002044 001006 BNE IS
002046 122737 000006 000041 CMPB #6,@#41 ;BRANCH IF NOT THDP
002054 001002 BNE IS
002056 005237 000664 INC SLVN ;STEP TO SLAVE # 1
002062 022737 000010 000664 IS: CMP #10,SLVN ;BRANCH IF ALL SLAVES TESTED
002070 001733 BEQ NXTDRV ;FOR AVAILABILITY
002072 013777 000664 176442 MOV SLVN,@C ;LOAD SLAVE UNIT #
002100 032777 002000 176430 BIT #2000,@C ;BRANCH IF SLAVE NOT
002106 001751 BEQ NXTSLV ;PRESENT (SPR = 0)
002110 012737 001070 000742 TSCDA: MOV #TSTTBL,LTADD
002116 062737 000004 000742 TSCD0: ADD #4,LTADD
002124 013737 000742 000714 TSCD1: MOV LTADD,ITRLP
002132 062737 000002 000714 ADD #2,ITRLP ;SET ITERATION ADDRESS
002140 005037 000620 CLR WPGFL ;CLEAR PRINT HEADER FLAG
002144 017700 176572 MOV @LTADD,RO ;SET POINTER TO TEST
002150 000110 JMP (RO) ;GO TO TEST
002152 032777 002000 176410 TSCD2: BIT #2000,@SWR ;SEE IF HALT ON TEST
002160 001403 BEQ TSCD3 ;IF NOT: BR
002162 000000 HALT
002164 005037 001000 CLR WPGFL ;CLEAR WRAP DATA GENERATOR FLAG
002170 005737 000740 TSCD3: TST STFLG ;SE IF SINGLE TEST
002174 001750 BEQ TSCD0 ;IF NOT: BR
002176 017700 176366 MOV @SWR,RO
002202 042700 177700 BIC #177700,RO ;MASK TEST NUMBER
002206 001642 BEQ TSCD ;IF SO: BR
002210 012737 000001 000740 STSCD: MOV #1,STFLG ;SET SINGLE TEST FLAG
002216 023700 001176 CMP TLAST,RO ;SEE IF EXCEEDED TESTS
002222 002410 BLT TEND ;IF SO: BR
002224 006300 RO
002226 006100 RO ;SET TABLE MODIFIER
002230 012737 001070 000742 MOV #TSTTBL,LTADD
002236 060037 000742 ADD RO,LTADD ;SET TEST POINTER

```

985	002242	000730			BR	TSCD1	
986	002244	005737	001262		TEND: TST	CHNFLG	;BRANCH IF IN CHAIN MODE
987	002250	001270			BNE	NXTSLV	
988	002252	012704	014310		SDONE: MOV	#MSG41, R4	
989	002256	004737	012714		JSR	PC, TOUT	;PRINT END OF PASS
990	002262	013703	001016		MOV	PCNTR, R3	
991	002266	004737	013042		JSR	PC, OCTP	;PRINT PASS NUMBER
992	002272	005000			CLR	RO	
993	002274	005300			IS:	RO	;DELAY WAITING FOR
994	002276	001376			BNE	IS	;TTY TO FINISH
995	002300	013700	000042		MOV	@#42, RO	;GET ACT11 RETURN ADDRESS
996	002304	001405			BEQ	HERE	;BRANCH IF NOT ACT11
997	002306	000005			RESET		
998	002310	004710			SENDAD: JSR	PC, (RO)	
999	002312	000240			NOP		
1000	002314	000240			NOP		
1001	002316	000240			NOP		
1002	002320	000240			HERE: NOP		
1003	002322	005737	001262		TST	CHNFLG	;BRANCH IF IN CHAIN MODE
1004	002326	001005			BNE	TENOX	
1005	002330	032777	010000 176232		BIT	#10000, @SWR	;SEE IF HALT ON PASS
1006	002336	001001			BNE	TENOX	;IF NOT: BR
1007	002340	000000			HALT		
1008	002342	005237	001016		TENDX: INC	PCNTR	;BUMP PASS COUNTER
1009	002346	000137	001714		JMP	TSCD	;RESTART
1010							

```

1011 ;THESE TESTS CHECK DATA FORMATTING
1012 ;AND TRANSFER THROUGH THE TMO3 WRAP AROUND MODES
1013
1014 ;LOGIC TEST 1: WRAP 3, NRZ, NORMAL ODD *****
1015
1016 002352 012737 004270 001024 LT1: MOV #4270,WCS1 ;SET EXPT CS1
1017 002360 012737 000100 001026 MOV #100,WCS2 ;SET EXPT CS2
1018 002366 012737 010600 001030 MOV #10600,WDS ;SET EXPT DS
1019 002374 012737 000000 001032 MOV #0,WER ;SET EXPT WER
1020 002402 012737 014527 000622 MOV #MSLT1,EMADDR ;SET HEADER
1021 002410 012737 001700 000776 MOV #1700,UDES ;SET NRZ,NORMAL,ODD
1022 002416 005037 001002 LT1A: CLR PATRN ;POINT TO PATTERN 0
1023 002422 012737 002430 000712 MOV #LT1B,SCOLP ;SET SCOPE ADDRESS
1024 002430 004737 005256 LT1B: JSR PC,WAM3 ;GO DO WRAP 3
1025 002434 005237 001002 INC PATRN ;BUMP PATTERN POINTER
1026 002440 032737 000004 001002 BIT #4,PATRN ;SEE IF DONE
1027 002446 001770 BEQ LT1B ;IF NOT: BR
1028 002450 004737 012014 JSR PC,ITER ;GO SEE IF ITERATIONS
1029 002454 005037 001006 CLR RDARF ;CLEAR READ REVERSE FLAG
1030 002460 000137 002152 JMP TSCD2 ;RETURN TO SCHEDULAR
1031
1032 ;LOGIC TEST 2: WRAP 3, PE, NORMAL, ODD*****
1033
1034 002464 000240 LT2: NOP
1035 002466 012737 004270 001024 LT2A: MOV #4270,WCS1 ;SET EXPT CS1
1036 002474 012737 000100 001026 MOV #100,WCS2 ;SET EXPT CS2
1037 002502 012737 010640 001030 MOV #10640,WDS ;SET EXPT DS
1038 002510 012737 000000 001032 MOV #0,WER ;SET EXPT WER
1039 002516 012737 014575 000622 MOV #MSLT2,EMADDR ;SET HEADER
1040 002524 012737 002300 000776 MOV #2300,UDES ;SET PE,NORMAL,ODD
1041 002532 000137 002416 JMP LT1A ;EXECUTE TEST SEQUENCE
1042
1043 ;LOGIC TEST 3: WRAP 2, NRZ, NORMAL, ODD*****
1044
1045 002536 012737 004260 001024 LT3: MOV #4260,WCS1 ;SET EXPT CS1
1046 002544 012737 000100 001026 MOV #100,WCS2 ;SET EXPT CS2
1047 002552 012737 010600 001030 MOV #10600,WDS ;SET EXPT DS
1048 002560 012737 000000 001032 MOV #0,WER ;SET EXPT WER
1049 002566 012737 014642 000622 MOV #MSLT3,EMADDR ;SET HEADER
1050 002574 012737 001700 000776 MOV #1700,UDES ;SET TO NRZ,NORMAL,ODD
1051 002602 005037 001002 LT3A: CLR PATRN ;POINT TO PATTERN 0
1052 002606 012737 002614 000712 MOV #LT3B,SCOLP ;SET SCOPE ADDRESS
1053 002614 004737 005212 LT3B: JSR PC,WAM2 ;GO DO WRAP 2
1054 002620 005237 001002 INC PATRN ;BUMP POINTER
1055 002624 032737 000004 001002 BIT #4,PATRN ;SEE IF DONE
1056 002632 001770 BEQ LT3B ;IF NOT: BR
1057 002634 004737 012014 JSR PC,ITER ;GO SEE IF ITERATIONS
1058 002640 000137 002152 JMP TSCD2 ;RETURN TO SCHEDULAR

```

```

1059
1060 ;LOGIC TEST 4: WRAP 2, PE, NORMAL, 000*****
1061
1062 002644 000240 LT4: NOP
1063 002646 012737 004260 001024 LT4A: MOV #4260,WCS1 ;SET EXPT CS1
1064 002654 012737 000100 001026 MOV #100,WCS2 ;SET EXPT CS2
1065 002662 012737 010640 001030 MOV #10640,WDS ;SET EXPT DS
1066 002670 012737 000000 001032 MOV #0,WER ;SET EXPT WER
1067 002676 012737 014710 000622 MOV #MSLT4,EMADDR ;SET HEADER
1068 002704 012737 002300 000776 MOV #2300,UDES ;SET PE, NORMAL, 000
1069 002712 000137 002602 JMP LT3A ;GO EXECUTE TEST SEQUENCES
1070
1071 ;LOGIC TEST 5: WRAP 1, NRZ, NORMAL, 000*****
1072
1073 002716 012737 004260 001024 LT5: MOV #4260,WCS1 ;SET EXPT CS1
1074 002724 012737 000100 001026 MOV #100,WCS2 ;SET EXPT CS2
1075 002732 012737 010600 001030 MOV #10600,WDS ;SET EXPT DS
1076 002740 012737 000000 001032 MOV #0,WER ;SET EXPT WER
1077 002746 012737 014755 000622 MOV #MSLT5,EMADDR ;SET HEADER
1078 002754 012737 001700 000776 MOV #1700,UDES ;SET NRZ, NORMAL, 000
1079 002762 005037 001002 LT5A: CLR PATRN ;POINT TO PATTERN ZERO
1080 002766 012737 002774 000712 MOV #LTSB,SCOLP ;SET SCOPE ADDRESS
1081 002774 004737 005202 LT5B: JSR PC,WAM1 ;GO DO WRAP 1
1082 003000 005237 001002 INC PATRN ;BUMP POINTER
1083 003004 032737 000004 001002 BIT #4,PATRN ;SEE IF DONE
1084 003012 001770 BEQ LTSB ;IF NOT: BR
1085 003014 004737 012014 JSR PC,ITER ;GO SEE IF ITERATIONS
1086 003020 000137 002152 JMP TSCD2 ;RETURN TO SCHEDULAR
1087
1088 ;LOGIC TEST 6: WRAP 1, PE, NORMAL, 000*****
1089
1090 003024 000240 LT6: NOP
1091 003026 004737 011512 LT6A: JSR PC,PPGEN ;GO GENERATE PRE/POSTAMBLE
1092 003032 012737 004260 001024 MOV #4260,WCS1 ;SET EXPT CS1
1093 003040 012737 000100 001026 MOV #100,WCS2 ;SET EXPT CS2
1094 003046 012737 010640 001030 MOV #10640,WDS ;SET EXPT DS
1095 003054 012737 000000 001032 MOV #0,WER ;SET EXPT WER
1096 003062 012737 015023 000622 MOV #MSLT6,EMADDR ;SET HEADER
1097 003070 012737 002300 000776 MOV #2300,UDES ;SET PE, NORMAL, 000
1098 003076 000137 002762 JMP LT5A ;GO EXECUTE TEST SEQUENCE

```

```

1099
1100 ;LOGIC TEST 7: WRAP 0, NRZ,NORMAL, ODD*****
1101
1102 003102 012737 144260 001024 LT7: MOV #144260,WCS1 ;SET EXPT CS1
1103 003110 012737 000100 001026 MOV #100,WCS2 ;SET EXPT CS2
1104 003116 012737 150600 001030 MOV #150600,WDS ;SET EXPT DS
1105 003124 012737 000200 001032 MOV #200,WER ;SET EXPT ER
1106 003132 012737 015070 000622 MOV #MSLT7,EMADDR ;SET HEADER
1107 003140 012737 001700 000776 MOV #1700,UDES ;SET NRZ, NORMAL, ODD
1108 003146 005037 001002 LT7A: CLR PATRN ;POINT TO PATTERN 0
1109 003152 012737 003160 000712 MOV #LT7B,SCOLP ;SET SCOPE ADDRESS
1110 003160 004737 005136 LT7B: JSR PC,WANO ;GO DO WRAP 0
1111 003164 005237 001002 INC PATRN ;BUMP POINTER
1112 003170 032737 000004 001002 BIT #4,PATRN ;SEE IF DONE
1113 003176 001770 BEQ LT7B ;IF NOT: BR
1114 003200 004737 012014 JSR PC,ITER ;GO SEE IF ITERATIONS
1115 003204 000137 002152 JMP TSC02 ;RETURN TO SCHEDULAR
1116
1117 ;LOGIC TEST 10: WRAP 0, PE, NORMAL, ODD*****
1118
1119 003210 000240 LT10: NOP
1120 003212 012737 004260 001024 LT10A: MOV #4260,WCS1 ;SET EXPT CS1
1121 003220 012737 000100 001026 MOV #100,WCS2 ;SET EXPT CS2
1122 003226 012737 010640 001030 MOV #10640,WDS ;SET EXPT DS
1123 003234 012737 000000 001032 MOV #0,WER ;SET EXPT ER
1124 003242 012737 015136 000622 MOV #MSLT10,EMADDR ;SET HEADER
1125 003250 012737 002300 000776 MOV #2300,UDES ;SET PE, NORMAL, ODD
1126 003256 000137 003146 JMP LT7A ;GO EXECUTE TEST SEQUENCE

```

```

1127 ;LOGIC TEST 11: CORE DUMP WRITE, WAM2*****
1128
1129 003262 012737 004260 001024 LT11: MOV #4260,WCS1 ;SET EXPT CS1
1130 003270 012737 000100 001026 MOV #100,WCS2 ;SET EXPT CS2
1131 003276 012737 010600 001030 MOV #10600,WDS ;SET EXPT DS
1132 003304 012737 000000 001032 MOV #0,WER ;SET EXPT ER
1133 003312 012737 015204 000622 MOV #MSLT11,EMADDR ;SET HEADER
1134 003320 012737 001720 000776 MOV #1720,UDES ;SET NRZ, CORE DUMP, 000
1135 003326 005037 001002 CLR PATRN ;POINT TO PATTERN 0
1136 003332 012737 003340 000712 MOV #LT11A,SCOLP ;SET SCOPE ADDRESS
1137 003340 004737 005212 LT11A: JSR PC,WAM2 ;GO DO WAM 2
1138 003344 022737 000002 001002 CMP #2,PATRN ;SEE IF DONE
1139 003352 001404 BEQ LT11X ;IF SO: BR
1140 003354 012737 000002 001002 MOV #2,PATRN ;SELECT PATTERN 2
1141 003362 000766 BR LT11A ;CONTINUE
1142 003364 004737 012014 LT11X: JSR PC,ITER ;GO SEE IF ITERATIONS
1143 003370 000137 002152 JMP TSCD2 ;RETURN TO SCHEDULES
1144
1145 ;LOGIC TEST 12: CORE DUMP READ, WAM 3*****

```

```

1146
1147 003374 012737 004270 001024 LT12: MOV #4270,WCS1 ;SET EXPT CS1
1148 003402 012737 000100 001026 MOV #100,WCS2 ;SET EXPT CS2
1149 003410 012737 010600 001030 MOV #10600,WDS ;SET EXPT DS
1150 003416 012737 000000 001032 MOV #0,WER ;SET EXPT ER
1151 003424 012737 015255 000622 MOV #MSLT12,EMADDR ;SET HEADER
1152 003432 012737 001720 000776 MOV #1720,UDES ;SELECT NRZ, CORE DUMP, 000
1153 003440 005037 001002 CLR PATRN ;SELECT PATTERN 0
1154 003444 012737 003460 000712 MOV #LT12A,SCOLP ;SET SCOPE ADDRESS
1155 003452 012737 001056 001010 MOV #WCDP0,RCDP ;POINT TO PATTERN 0
1156 003460 004737 005256 LT12A: JSR PC,WAM3 ;GO DO WAM3
1157 003464 022737 000002 001002 CMP #2,PATRN ;SEE IF DONE
1158 003472 001407 BEQ LT12X ;IF SO: BR
1159 003474 012737 000002 001002 MOV #2,PATRN ;SELECT PATTERN 2
1160 003502 012737 001044 001010 MOV #WCDP2,RCDP ;POINT TO PATTERN 2
1161 003510 000763 BR LT12A ;CONTINUE
1162 003512 004737 012014 LT12X: JSR PC,ITER ;GO SEE IF ITERATION
1163 003516 000137 002152 JMP TSCD2 ;RETURN TO SCHEDULE

```

E03

TMO3/TE16 CONTROL LOGIC TEST-PART II
DZTEBA.P11 31-MAR-77 17:30

MACY11 27(1006) 31-MAR-77 17:30 PAGE 29

```

1164
1165                                     ;LOGIC TEST 13: EVEN PARITY WRITE: WAM 1(M8903)*****
1166
1167 003522 012737 004260 001024 LT13: MOV #4260,WCS1 ;SET EXPT CS1
1168 003530 012737 000100 001026 MOV #100,WCS2 ;SET EXPT CS2
1169 003536 012737 010600 001030 MOV #10600,WDS ;SET EXPT DS
1170 003544 012737 000000 001032 MOV #0,WER ;SET EXPT ER
1171 003552 012737 015325 000622 MOV #MSLT13,EMADDR ;SET HEADER
1172 003560 012737 001710 000776 MOV #1710,UDES ;SET NRZ, NORMAL, EVEN
1173 003566 000137 002762 JMP LT5A ;GO EXECUTE WAM 1
1174
1175                                     ;LOGIC TEST 14: EVEN PARITY READ: WAM 0(M8903 M8904)*****
1176
1177 003572 012737 144260 001024 LT14: MOV #144260,WCS1 ;SET EXPT CS1
1178 003600 012737 000100 001026 MOV #100,WCS2 ;SET EXPT CS2
1179 003606 012737 150600 001030 MOV #150600,WDS ;SET EXPT DS
1180 003614 012737 000200 001032 MOV #200,WER ;SET EXPT ER
1181 003622 012737 015406 000622 MOV #MSLT14,EMADDR ;SET HEADER
1182 003630 012737 001710 000776 MOV #1710,UDES ;SET NRZ, NORMAL, EVEN
1183 003636 000137 003146 JMP LT7A ;GO DO WAM 0
1184
1185                                     ;LOGIC TEST 15: READ REVERSE: WAM 3(M8906)*****
1186
1187 003642 012737 004276 001024 LT15: MOV #4276,WCS1 ;SET EXPT CS1
1188 003650 012737 000100 001026 MOV #100,WCS2 ;SET EXPT CS2
1189 003656 012737 010640 001030 MOV #10640,WDS ;SET EXPT DS
1190 003664 012737 000000 001032 MOV #0,WER ;SET EXPT ER
1191 003672 012737 015465 000622 MOV #MSLT15,EMADDR ;SET HEADER
1192 003700 012737 002300 000776 MOV #2300,UDES ;SELECT PE,NORMAL,ODD
1193 003706 000240 NOP
1194 003710 000240 NOP
1195 003712 012737 000001 001006 MOV #1,RDRVF ;SET READ REVERSE FLAG
1196 003720 000137 002416 JMP LT1A ;GO DO WAM 3, REVERSE
1197

```

1199
1199
1200
1201
1202
1203
1204
1205
1206
1207
1208
1209
1210
1211
1212
1213
1214
1215
1216
1217
1218
1219
1220
1221
1222
1223
1224
1225
1226
1227
1228
1229
1230
1231
1232
1233
1234
1235
1236
1237
1238
1239
1240
1241
1242
1243
1244
1245
1246
1247
1248
1249
1250
1251
1252
1253

```

003724 005037 001002
003730 012737 000401 004302
003736 012737 015532 000622
003744 012737 003752 000712
003752 012737 144260 001024
003760 012737 000100 001026
003766 012737 150600 001030
003774 012737 000200 001032
004002 012737 001700 000776
004010 005037 001022
004014 004737 005136
004020 012737 000001 001022
004026 013737 017276 004304
004034 013737 004304 004306
004042 013737 004302 004310
004050 043737 004302 004306
004056 043737 004304 004310
004064 053737 004310 004306
004072 013737 004306 004304
004100 012737 144260 001024
004106 012737 000110 001026
004114 012737 150600 001030
004122 012737 100300 001032
004130 004737 005364
004134 000240
004136 012737 000001 001006
004144 012737 144276 001024
004152 012737 000110 001026
004160 012737 150600 001030
004166 012737 001000 001032
004174 004737 005256
004200 000240
    
```

```

; LOGIC TEST 16: CRC CORRECTION-SINGLE TRACK, EVERY FRAME
; THIS IS A TEST OF THE CRC CORRECTION LOGIC. THE TEST WRITES
; A KNOWN PATTERN (ALL 1'S, ALL 0'S & 125252) WITH A DATA BIT
; ALTERED IN EACH OF THE DATA TRACKS. THIS TEST INSURES THAT A
; CRC CORRECTABLE ERROR IS CORRECTED.
; THE TEST PROCEEDS AS FOLLOWS:
    
```

```

; STEP A WRITE A KNOWN PATTERN USING WRAP AROUND MODE 0
;
; STEP B REWRITE THE PATTERN ABOVE WITH DATA BIT(S) MODIFIED
; IN TRACKS SPECIFIED BY CRCPAT USING WRAP AROUND MODE 4
; THIS WILL GENERATE A CRC ERROR
;
; STEP C EXECUTE A READ REVERSE USING WRAP AROUND MODE 3
;
; STEP D REPEAT STEP B ABOVE. UPON COMPLETION THE DATA READ
; BACK WILL MATCH THE DATA WRITTEN IN STEP A.
    
```

```

LT16: CLR PATRN ;SELECT PATTERN # 0 (ALL 1'S)
      MOV #401,CRCPAT ;SELECT BITS TO BE ALTERED (TRACK 1)
      MOV #MSLT16,EMADDR ;SET ERROR MESSAGE HEADER
      MOV #LT16A,SCOLP ;SET SCOPE LOOP

LT16A: MOV #144260,WCS1 ;SET EXPECTED VALUES UPON COMPLETION
      MOV #100,WCS2
      MOV #150600,WDS
      MOV #200,WER
      MOV #1700,UDES ;SET UNIT DESCRIPTION-NRZ,800BPI,000
; PARITY & POPI1 NORMAL MODE
      CLR CRCFLG ;CLEAR CRC CORRECTION FLAG
      JSR PC,WAM0 ;DO A WRAP 0 --- STEP A
      MOV #1,CRCFLG ;SET CRC ERROR CORRECTION IN PROGRESS
      MOV #BUFF,CRCDAT ;GET DATA WRITTEN BY WRAP 0
; XOR CRCPAT WITH CRCDAT
      MOV CRCDAT,XORDAT ;GET DATA TO BE MODIFIED
      MOV CRCPAT,XORPAT ;GET MODIFIER
      BIC CRCPAT,XORDAT ;CLEAR SET BITS IN DATA TO BE MODIFIED
      BIC CRCDAT,XORPAT ;CLEAR SETTING BITS
      BIS XORPAT,XORDAT ;SET CLEAR BITS IN DATA TO BE MODIFIED
      MOV XORDAT,CRCDAT ;RESTORE MODIFIED DATA

      MOV #144260,WCS1 ;SET EXPECTED VALUES UPON COMPLETION
      MOV #110,WCS2 ;OF WRAP 4
      MOV #150600,WDS
      MOV #100300,WFR
      JSR PC,WAM4 ;DO A WRAP 4 --- STEP B
      NOP
      MOV #1,RORVF ;SET TO READ REVERSE
      MOV #144276,WCS1 ;SET EXPECTED VALUES UPON COMPLETION
      MOV #110,WCS2
      MOV #150600,WDS
      MOV #1000,WER
      JSR PC,WAM3 ;DO A WRAP 3 --- STEP C
      NOP
    
```


G03

TMO3/TE16 CONTROL LOGIC TEST-PART II MACY11 27(1006) 31-MAR-77 17:30 PAGE 31
 DZTEBA.P11 31-MAR-77 17:30

1254	004202	012737	004260	001024	MOV	#4260, WCS1	
1255	004210	012737	000110	001026	MOV	#110, WCS2	
1256	004216	012737	010600	001030	MOV	#10600, WDS	
1257	004224	012737	000000	001032	MOV	#0, WER	
1258	004232	005037	001022		CLR	CRCFLG	; CLEAR CRC CORRECTION IN PROGRESS FLAG
1259	004236	004737	005364		JSR	PC, WRAP4	; GO TO WRAP 4 --- STEP D
1260							
1261	004242	006337	004302		ASL	CRCPAT	; SELECT NEXT TRACK TO BE ALTERED
1262	004246	103241			BCC	LT16A	; CONTINUE FOR ALL TRACKS
1263	004250	012737	000401	004302	MOV	#401, CRCPAT	; RESET BITS TO TRACK 1
1264	004256	005237	001002		INC	PATRN	; SELECT NEXT PATTERN
1265	004262	022737	000003	001002	CMP	#3, PATRN	; BRANCH IF NOT DONE
1266	004270	001230			BNE	LT16A	
1267	004272	004737	012014		JSR	PC, ITER	; ITERATION LOOP
1268	004276	000137	002152		JMP	TSCD2	; RETURN TO SCHEDULER
1269							
1270							
1271	004302	000000			CRCPAT: .WORD	0	; CONTAINS BITS TO BE ALTERED
1272	004304	000000			CRCDAT: .WORD	0	; CONTAINS DATA TO BE WRITTEN BY WRAP4
1273	004306	000000			XORDAT: .WORD	0	; TEMPRARY STORAGE FOR XOR
1274	004310	000000			XORPAT: .WORD	0	; TEMPARY STORAGE FOR XOR
1275							

H03

TMO3/TE16 CONTROL LOGIC TEST-PART II
DZTEBA.P11 31-MAR-77 17:30

MACY11 27(1006) 31-MAR-77 17:30 PAGE 32

1276
1277
1278
1279
1280
1281
1282
1283
1284
1285
1286
1287
1288
1289
1290
1291
1292
1293
1294
1295
1296
1297
1298
1299
1300
1301
1302
1303
1304
1305
1306
1307
1308
1309
1310
1311
1312
1313
1314
1315
1316
1317
1318
1319
1320
1321

```

004312 012737 000002 001002
004320 012737 001001 004302
004326 012737 015622 000622
004334 012737 004342 000712
004342 012737 144260 001024
004350 012737 000100 001026
004356 012737 150600 001030
004364 012737 000200 001032
004372 012737 001700 000776
004400 005037 001022
004404 004737 005136
004410 000240
004412 012737 000002 001022
004420 013737 017276 004304
004426 043737 004302 004304
004434 012737 144260 001024
004442 012737 000110 001026
004450 012737 150600 001030
004456 012737 100300 001032
004464 004737 005364
004470 000240
004472 012737 000001 001006
004500 012737 144276 001024
004506 012737 000110 001026
004514 012737 150600 001030
004522 012737 001000 001032
004530 004737 005256
004534 000240
004536 012737 144260 001024
004544 012737 000110 001026
004552 012737 150600 001030
004560 012737 100100 001032
004566 005037 001022
004572 013701 004304
004576 012703 017276
004602 004737 005102
004606 004737 005364
004612 000240
004614 004737 012014
004620 000137 002152
    
```

```

; LOGIC TEST 17: CRC CORRECTION - MULTIPLE BAD TRACKS
; THIS TEST CHECKS THAT CRC ERROR CORRECTION IS NOT PERFORMED WHEN
; MULTIPLE BAD TRACKS ARE DETECTED.

LT17:  MOV      #2,PATRN      ; SELECT PATTERN #2 (125125)
      MOV      #1001,CRCPAT  ; SELECT 2 BAD TRACKS
      MOV      #MSLT17,EMADDR ; SET ERROR MESSAGE HEADER
      MOV      #LT17A,SCOLP  ; SET SCOPE LOOP ADDRESS
LT17A: MOV      #144260,WCS1  ; SET EXPECTED VALUES ON COMPLETION
      MOV      #100,WCS2     ; OF WRAP 0 BELOW
      MOV      #150600,WDS
      MOV      #200,WER
      MOV      #1700,UDES    ; SET UNIT DESCRIPTION
      CLR      CRCFLG       ; SET CRC CORRECTION NOT IN PROGRESS
      JSR     PC,WAMP       ; DO A WRAP 0 --- STEP A
      NOP
      MOV      #2,CRCFLG    ; SET CRC CORRECTION IN PROGRESS
      MOV      #WBUFF,CRCDAT ; GET DATA TO BE WRITTEN
      BIC     CRCPAT,CRCDAT  ; MODIFY DATA TO BE WRITTEN
      MOV      #144260,WCS1  ; SET EXPECTED VALUES ON COMPLETION
      MOV      #110,WCS2     ; OF WRAP 4 BELOW
      MOV      #150600,WDS
      MOV      #100300,WER
      JSR     PC,WAMP       ; DO A WRAP 4 --- STEP B
      NOP
      MOV      #1,RDARVF    ; SET READ REVERSE FLAG
      MOV      #144276,WCS1  ; SET EXPECTED VALUES ON COMPLETION
      MOV      #110,WCS2     ; OF WRAP 3 BELOW
      MOV      #150600,WDS
      MOV      #1000,WER
      JSR     PC,WAMP       ; DO A WRAP 3 --- STEP C
      NOP
      MOV      #144260,WCS1  ; SET EXPECTED VALUES ON COMPLETION
      MOV      #110,WCS2     ; OF WRAP 4 BELOW
      MOV      #150600,WDS
      MOV      #100100,WER
      CLR     CRCFLG       ; CLEAR CRC IN PROGRESS FLAG
      MOV     CRCDAT,R1     ; GET DATA THAT WAS WRITTEN IN STEP B
      MOV     #WBUFF,R3    ; SET START OF WRITE BUFFER
      JSR     PC,DAT1A     ; GO SET WRITE BUFFER
      JSR     PC,WAMP       ; GO DO A WRAP 4 --- STEP D
      NOP
      JSR     PC,ITER      ; ITERATE TEST
      JMP     TSCD2       ; RETURN TO SCHEDULER
    
```

1322
1323
1324
1325
1326
1327
1328
1329
1330
1331
1332
1333
1334
1335
1336
1337
1338
1339
1340
1341
1342

; LOGIC TEST 20: READ REVERSE NRZ WRAP 3
; THIS TEST TESTS THAT A CRC ERROR OCCURS AFTER A READ REVERSE USING
; WRAP AROUND MODE 3 IN NRZ MODE

004624 005037 001002
004630 012737 144276 001024
004636 012737 000100 001026
004644 012737 150600 001030
004652 012737 100000 001032
004660 012737 015706 000622
004666 012737 001700 000776
004674 012737 004702 000712
004702 012737 000001 001006
004710 012737 000001 001020
004716 004737 005256
004722 005037 001006
004726 005037 001020
004732 004737 012014
004736 000137 002152

LT20: CLR PATRN ; SET PATTERN # 0 (ALL 1'S)
MOV #144276, WCS1 ; SET EXPECTED VALUES ON COMPLETION
MOV #100, WCS2
MOV #150600, WDS
MOV #100000, WER
MOV #MSLT20, EMADDR ; SET ERROR MESSAGE ADDRESS
MOV #1700, UDES ; SET UNIT DESCRIPTION
MOV #LT20A, SCOLP ; SET SCOPE LOOP ADDRESS
LT20A: MOV #1, RDRVF ; SET READ REVERSE FLAG
MOV #1, DCHKFL ; SET DATA CHECK FLAG TO NOT CHACK DATA
JSR PC, WAM3
CLR RDRVF ; CLEAR READ REVERSE FLAG
CLR DCHKFL ; CLEAR DATA CHECK FLAG
JSR PC, ITER
JMP TSCD2 ; RETURN TO SCHEDULER

1343
1344
1345
1346
1347
1348
1349
1350
1351
1352
1353
1354
1355
1356
1357
1358
1359
1360
1361
1362
1363
1364
1365
1366
1367
1368
1369
1370
1371
1372
1373
1374
1375
1376
1377
1378
1379
1380
1381
1382
1383
1384
1385
1386
1387
1388
1389
1390
1391
1392
1393
1394
1395
1396
1397
1398

004742 005737 000740
004746 001434
004750 032777 000100 173612
004756 001430
004760 012704 016416
004764 004737 012714
004770 013703 001002
004774 004737 013042
005000 012705 001002
005004 012701 000002
005010 012702 000003
005014 012703 000000
005020 004737 012372
005024 112737 000001 001001
005032 113737 001002 001000
005040 012703 017276
005044 013701 001002
005050 006301
005052 004771 001034
005056 012702 000202
005062 012701 017710
005066 005021
005070 005302
005072 001375
005074 000207

005076 012701 177777
005102 012702 000202
005106 010123
005110 005302
005112 001375
005114 000207

005116 005001
005120 000770

005122 012701 125125

```
*****  
: DATA SETUP ROUTINE:  
: THIS ROUTINE IS USED TO GENERATE THE DATA PATTERNS  
: THE PATTERN TO BE WRITTEN IS SPECIFIED BY:  
: PATRN =0 ALL 1'S  
: =1 ALL 0'S  
: =2 ALTERNATE 1'S & 0'S (125252)  
: =3 ALTERNATING PARITY (177377)  
*****  
DSUP: TST STFLG ;SEE IF SINGLE TEST  
BEQ DSO ;IF NOT: BR  
BIT #100,DSWR ;SEE IF SELECT PATTERN  
BEQ DSO ;IF NOT: BR  
MOV #MSG3,R4  
JSR PC,TOUT ;REQUEST PATTERN NUMBER  
MOV PATRN,R3  
JSR PC,OCIP ;PRINT PATTERN NUMBER  
MOV #PATRN,R5 ;GET ADDRESS OF PATRN ENTRY  
MOV #2,R1 ;SET SIZE OF ENTRY  
MOV #3,R2 ;SET UPPER LIMIT  
MOV #0,R3 ;SET LOWER LIMIT  
JSR PC,TTR ;GO GET PATTERN NUMBER  
MOVB #1,MPGFL+1 ;SET FLAG  
MOVB PATRN,MPGFL ;SET PATTERN NUMBER  
DSO: MOV #RBUF,R3 ;R3 = ADDR OF WRITE BUFFER  
MOV PATRN,R1 ;R1 = PATTERN SELECTOR  
ASL R1 ;MAKE PATTERN SELECTOR EVEN  
JSR PC,DATA(BL(R1)) ;GO GENERATE PATTERN  
DS3: MOV #202,R2 ;R2=BUFFER SIZE +2  
MOV #RBUF,R1 ;R1=READ DATA START  
DS4: CLR (R1)+ ;CLEAR BUFFER  
DEC R2 ;SEE IF DONE ALL  
BNE DS4 ;IF NOT: BR  
RTS PC ;EXIT  
  
; ALL ONES*****  
DAT1: MOV #-1,R1 ;R1=DATA  
DAT1A: MOV #202,R2 ;R2=WORD COUNT +2  
IS: MOV R1,(R3)+ ;LOAD BUFFER  
DEC R2 ;SEE IF DONE  
BNE IS ;IF NOT: BR  
RTS PC ;RETURN TO CALLER  
  
; ALL ZEROS*****  
DAT2: CLR R1 ;R1=DATA  
BR DAT1A ;LOAD BUFFER  
  
; ONE/ZERO IN ALTERNATING CHARACTERS*****  
DAT3: MOV #125125,R1 ;R1=DATA
```

K03

TMO3/TE16 CONTROL LOGIC TEST-PART II
DZTEBA.P11 31-MAR-77 17:30

MACY11 27(1006) 31-MAR-77 17:30 PAGE 35

1399 005126 000765
1400
1401
1402
1403 005130 012701 177377
1404 005134 000762
1405

BR DATA ;LOAD BUFFER

;ALTERNATING PARITY CHARACTERS*****

DATA: MOV #177377,R1 ;R1=ALTERNATING PARITY DATA
BR DATA ;GO LOAD BUFFER

```

1406
1407 ;WRAP AROUND MODE 0 GLOBAL*****
1408
1409 005136 012737 000006 000750 WAM0: MOV #6,WAM ;SET WAM NUMBER
1410 005144 012737 000060 000752 WAM01: MOV #60,FUN
1411 005152 005037 000754 CLR DATC
1412 005156 012737 017276 000760 MOV #WBUF,DATD ;SET BUFFER ADDRESS
1413 005164 012737 017710 000762 MOV #RBUF,ROAD ;SET POINTER TO READ BUFFER
1414 005172 004737 005430 JSR PC,SETUP ;GO SET UP
1415 005176 000137 006010 JMP EXEC
1416
1417 ;WRAP AROUND MODE 1 WRITE BUFFER*****
1418
1419 005202 012737 000010 000750 WAM1: MOV #10,WAM
1420 005210 000755 BR WAM01
1421
1422 ;WRAP AROUND MODE 2 BIT FIDDLER WRITE*****
1423
1424 005212 012737 000012 000750 WAM2: MOV #12,WAM
1425 005220 012737 000060 000752 MOV #60,FUN
1426 005226 005037 000754 CLR DATC
1427 005232 012737 017276 000760 MOV #WBUF,DATD
1428 005240 012737 017710 000762 MOV #RBUF,ROAD
1429 005246 004737 005430 WAM2A: JSR PC,SETUP
1430 005252 000137 006010 JMP EXEC
1431
1432 ;WRAP AROUND MODE 3 BIT FIDDLER READ*****
1433
1434 005256 012737 000014 000750 WAM3: MOV #14,WAM ;SET WAM NUMBER
1435 005264 012737 000070 000752 MOV #70,FUN ;SET FUNCTION
1436 005272 012737 017710 000760 MOV #RBUF,DATD ;SET BUFFER ADDRESS
1437 005300 012737 017276 000756 MOV #WBUF,WTAD ;SET POINTER TO WRITE BUFFER
1438 005306 005737 001006 TST RDRVF
1439 005312 001411 BEQ WAM3A
1440 005314 062737 000376 000760 ADD #376,DATD
1441 005322 062737 000377 000756 ADD #377,WTAD
1442 005330 012737 000076 000752 MOV #76,FUN ;SET READ REVERSE CODE
1443 005336 032737 000020 000776 WAM3A: BIT #20,UDES
1444 005344 001403 BEQ WAM3B
1445 005346 013737 001010 000756 WAM3B: MOV RCDP,WTAD
1446 005354 004737 005430 JSR PC,SETUP ;GO SET UP
1447 005360 000137 006010 JMP EXEC ;GO EXECUTE
1448
1449 ;WRAP AROUND MODE 4 CRC CORRECTION
1450 ;CALL: JSR PC,WAM4
1451
1452 005364 012737 000030 000750 WAM4: MOV #30,WAM ;SET MAINTENANCE MODE FUNCTION = WRAP 4
1453 005372 012737 000060 000752 MOV #60,FUN ;SET TAPE FUNCTION = WRITE FWD
1454 005400 005037 000754 CLR DATC
1455 005404 012737 004304 000760 MOV #CRCDAT,DATD ;SET ADRS OF WRITE BUFFER
1456 005412 012737 017710 000762 MOV #RBUF,ROAD ;SET READ BUFFER ADDRESS
1457 005420 004737 005430 JSR PC,SETUP ;GO SETUP REGISTERS
1458 005424 000137 006010 JMP EXEC ;GO EXECUTE

```

M03

TMO3/TE16 CONTROL LOGIC TEST-PART II
DZTEBA.P11 31-MAR-77 17:30

MACY11 27(1006) 31-MAR-77 17:30 PAGE 37

```

;REGISTER SETUP ROUTINE*****
1459
1460
1461 005430 005737 001022 SETUP: TST CRCFLG ;DO NOT DO DATA SETUP NOR INIT
1462 005434 001004 BNE IS ;IF CRC CORRECTION IS IN PROGRESS
1463 005436 022737 000030 000750 CMP #30,WAM ;DO NOT INIT IF DOING WAM 4 --- STEP 0
1464 005444 001004 BNE 2S
1465 01446 012777 000011 173034 1S: MOV #11,DC1 ;DO DRIVE CLEAR IF WAM4---STEP 0
1466 005454 000412 BR SET1A
1467 005456 005737 000740 2S: TST STFLG ;SEE IF SINGLE TEST
1468 005462 001403 BEQ SET0 ;IF NOT: BR
1469 005464 005737 001000 TST WPGFL ;SEE IF HAVE SELECTED PATTERN
1470 005470 001002 BNE SET1 ;IF SO: BR
1471 005472 004737 004742 SET0: JSR PC,DSUP ;GO DO DATA SETUP
1472 005476 004737 012064 SET1: JSR PC,INIT ;INIT CONTROLLER,SELECT UNIT & DRIVE
1473 ;LOAD SLAVE DESC AND MOVE OFF BOT
1474 005502 012777 177400 173006 SET1A: MOV #400,DFC ;SET FC=WCX2
1475 005510 032737 000020 000776 BIT #20,UDES ;SEE IF CORE DUMP
1476 005516 001403 BEQ SET2 ;IF NOT: BR
1477 005520 012777 177000 172770 MOV #1000,DFC ;SET FC=WCX4
1478 01436 012777 177600 172756 SET2: MOV #200,DFC ;SET MC
1479 01434 013777 000760 172752 MOV DATAD,DR ;SET BUS ADDRESS
1480 005542 032777 010000 172750 BIT #10000,DCS ;ASSURE DRIVE THERE
1481 005550 001417 BEQ SPI ;IF SO: BR
1482 005552 032777 020000 173010 BIT #20000,DSWR ;SEE IF PRINT ERRORS
1483 005560 001004 BNE SPO1 ;IF NOT: BR
1484 005562 012704 016437 MOV #MSG4,R4
1485 005566 004737 012714 JSR PC,TOUT ;PRINT NON-EXISTANT DRIVE
1486 005572 032777 100000 172770 SPO1: BIT #100000,DSWR ;SEE IF HALT ON ERROR
1487 005600 001401 BEQ SPO ;IF NOT: BR
1488 005602 000000 HALT
1489 005604 000137 005476 SPO: JMP SET1 ;RESETUP
1490 005610 022737 000014 000750 SPI: CMP #14,WAM ;SEE IF WAM 3
1491 005616 001031 BNE SPIB ;IF NOT: BR
1492 005620 117737 173132 000754 MOVB #DATAD,DATC ;GET FIRST CHAR
1493 005626 042737 177400 000754 BIC #177400,DATC
1494 005634 000337 000754 SWAB DATC
1495 005640 052737 000200 000754 BIS #200,DATC ;SET PARITY
1496 005646 005737 001006 TST RORVF ;SEE IF READ REVERSE
1497 005652 001403 BEQ SPIA ;IF NOT: BR
1498 005654 005337 000756 DEC WTAD ;DECREMENT POINTER
1499 005660 000410 BR SPIB
1500 005662 005237 000756 SPIA: INC WTAD ;BUMP POINTER
1501 005666 032737 000020 000776 BIT #20,UDES ;SEE IF CORE DUMP
1502 005674 001402 BEQ SPIB ;IF NOT: BR
1503 005676 005237 000756 INC WTAD ;BUMP POINTER AGAIN
1504 005702 053777 000776 172632 SPIB: BIS UDES,DFC ;SET UNIT DESCRIPTION (DEN,PAR,FMT)
1505 005710 052777 000001 172616 BIS #1,DFR ;SET MAINT MODE
1506 005716 053777 000750 172610 BIS WAM,DFR ;SET WAM
1507 005724 053777 000754 172602 BIS DATC,DFR ;SET DATA
1508 005732 013777 000752 172550 MOV FUN,DC1 ;SET FUNCTION
1509 005740 032777 040000 172554 BIT #40000,DCS ;ASSURE NO ERROR
1510 005746 001002 BNE SP3 ;IF ERROR: BR
1511 005750 000240 NOP
1512 005752 000207 RTS PC ;RETURN
1513 005754 032777 020000 172606 SP3: BIT #20000,DSWR ;SEE IF PRINT ERRORS
1514 005762 001004 BNE SP4 ;IF NOT: BR

```

```
1515 005764 012704 016400      MOV      #WMSG2,R4
1516 005770 004737 012714      JSR      PC,TOUT
1517 005774 032777 Y00000 172566 SP4:  BIT      #100000,SWR ;PRINT SETUP ERROR
1518 006002 001401      BEQ      SPS ;SEE IF HALT ON ERROR
1519 006004 000000      HLT
1520 006006 000207      RTS      PC ;IF NOT: BR
                                ;RETURN
```



```

;EXECUTE WAM ROUTINE*****
1521
1522
1523 006010 000240 EXEC: NOP
1524 006012 000240 NOP
1525 006014 032777 000040 172512 BIT #40,2MR
1526 006022 001403 BEQ EX0 ;ASSURE MAINT CLOCK IS ZERO
1527 006024 042777 000040 172502 BIC #40,2MR ;IF NOT: CLEAR IT
1528 006032 022737 000010 000750 EX0: CMP #10,WAM ;SEE IF WAM 1 OR 2 OR 3
1529 006040 003402 BLE 2$
1530 006042 000137 006416 1$: JMP EX12 ;GO DO WAM 0
1531 006046 022737 000030 000750 2$: CMP #30,WAM ;BRANCH IF WRAP AROUND MODE 4
1532 006054 001772 BEQ 1$
1533 006056 052777 000001 172424 EX1: BIS #1,@C1 ;SET GO BIT
1534 006064 005000 CLR R0
1535 006066 012701 000002 MOV #2,R1 ;SET DELAY
1536 006072 032777 100000 172442 EX1A: BIT #100000,@TC ;SEE IF ALPHA
1537 006100 001404 BEQ EX2 ;IF 50: BR
1538 006102 005300 DEC R0
1539 006104 001372 BNE EX1A ;AWAIT ALPHA
1540 006106 005301 DEC R1
1541 006110 001370 BNE EX1A
1542 006112 005077 172450 EX2: CLR @PSW
1543 006116 012701 000400 MOV #400,R1 ;SET NUMBER OF CLKS
1544 006122 032737 000020 000776 BIT #20,UDES ;SEE IF CORE DUMP
1545 006130 001402 BEQ EX3 ;IF NOT: BR
1546 006132 012701 001000 MOV #1000,R1 ;SET CLOCKS LMCX4
1547 006136 022737 000014 000750 EX3: CMP #14,WAM ;SEE IF WAM 3
1548 006144 001412 BEQ EX5A ;IF 50: BR
1549 006146 032737 002000 000776 BIT #2000,UDES ;SEE IF PE
1550 006154 001404 BEQ EX5 ;IF NOT PE: BR
1551 006156 006301 ASL R1
1552 006160 062701 000246 ADD #246,R1 ;SET TO ALLOW FOR PRE/POSTAMBLE
1553 006164 000402 BR EX5A
1554 006166 062701 000010 000750 EX5: ADD #10,R1 ;ADD CLOCKS FOR CRC AND LRC
1555 006172 022737 000014 000750 EX5A: CMP #14,WAM ;SEE IF WAM 3
1556 006200 001053 BNE EX5C ;IF NOT: BR
1557 006202 117700 172550 MOVB @MTAD,R0
1558 006206 042700 177400 BIC #177400,R0
1559 006212 005737 001006 TST R0RVF ;SEE IF REVERSE
1560 006216 001403 BEQ EX5A1 ;IF NOT: BR
1561 006220 005337 000756 DEC @TAD ;DEC POINTER
1562 006224 000416 BR EX5B
1563 006226 005237 000756 EX5A1: INC @TAD
1564 006232 032737 000020 000776 BIT #20,UDES ;SEE IF CORE DUMP
1565 006240 001410 BEQ EX5B ;IF NOT: BR
1566 006242 005237 000756 INC @TAD ;BUMP POINTER
1567 006246 005777 172504 TST @TAD ;SEE IF END
1568 006252 001003 BNE EX5B ;IF NOT: BR
1569 006254 162737 000010 000756 SUB #10,@TAD ;RESTORE POINTER
1570 006262 052777 000040 172244 EX5B: BIS #40,2MR ;CLOCK UP
1571 006270 017702 172240 MOV 2MR,R2 ;READ MR
1572 006274 042702 177600 BIC #177600,R2 ;MASK OUT DATA
1573 006300 000300 SWAB R0 ;POSITION DATA
1574 006302 022700 177000 CMP #177000,R0 ;SEE IF PATTERN 3
1575 006306 001404 BEQ 2$ ;IF 50: BR
1576 006310 000240 NOP
  
```

1577	006312	000240				NOP		
1578	006314	052700	000200		1S:	BIS	#200, R0	; SET ODD PARITY
1579	006320	050002			2S:	BIS	R0, R2	; LOAD NEW DATA
1580	006322	010277	172206			MOV	R2, 2MR	; CLOCK DOWN AND LOAD NEW DATA
1581	006326	000426				BR	EX50	
1582	006330	052777	000040	172176	EX5C:	BIS	#40, 2MR	; CLOCK UP
1583	006336	042777	000040	172170		BIC	#40, 2MR	; CLOCK DOWN
1584	006344	017700	172164			MOV	2MR, R0	; GET MR
1585	006350	000300				SWAB	R0	
1586	006352	032737	000010	000776		BIT	#10, UDES	; SEE IF EVEN PAR
1587	006360	001405				BEQ	EX5C0	; IF NOT: BR
1588	006362	010077	172374			MOV	R0, 2ROAD	
1589	006366	005237	000762			INC	ROAD	
1590	006372	000402				BR	EX5C1	
1591	006374	110077	172362		EX5C0:	MOVB	R0, 2ROAD	; PUT CHAR IN CORE
1592	006400	005237	000762		EX5C1:	INC	ROAD	
1593	006404	000240			EX50:	NOP		
1594	006406	005301				DEC	R1	; SEE IF DONE CLKS
1595	006410	001270				BNE	EX5A	; IF NOT: BR
1596	006412	000137	011570			JMP	EORP	; GO DO EOR

```

1597                                     ;EXECUTE WAM 0*****
1598
1599 006416 000240                                EXW2:  NOP
1600 006420 012737 006604 000670                MOV     #EXW2H,RTRN      ;SET INTERRUPT RETURN ADDRESS
1601 006426 012701 000200                        MOV     #200,R1          ;SET NUMBER OF CLOCKS = FC/2
1602 006432 032737 002000 000776                BIT     #2000,UDES       ;SEE IF PE
1603 006440 001402                                BEQ     EXW2A            ;IF NOT: BR
1604 006442 012701 000100                        MOV     #100,R1         ;ELSE SET CLKS = FC/4
1605 006446 012702 017710                        EXW2A: MOV     #RBUF,R2      ;SET BUFFER ADDRESS
1606 006452 022737 000030 000750                CMP     #30,WAM         ;BRANCH IF NOT WRAP 4
1607 006460 001003                                BNE     IS              ;
1608 006462 052777 000010 172030                BIS     #10,ACS         ;SET INHIBIT BUS ADDRESS INCREMENT
1609 006470 012777 000161 172012  IS:         MOV     #161,AC1        ;SET WRITE COMMAND AND GO
1610 006476 005077 172064                        CLR     #PSW            ;ALLOW INTERRUPT
1611 006502 032777 000040 172024  EXW2B:  BIT     #40,AMR
1612 006510 001774                                BEQ     EXW2B            ;AWAIT CLOCK UP
1613 006512 017722 172016                        MOV     AMR,(R2)+       ;GET DATA
1614 006516 032777 000040 172010  EXW2C:  BIT     #40,AMR
1615 006524 001374                                BNE     EXW2C            ;AWAIT CLOCK DOWN
1616 006526 017722 172002                        MOV     AMR,(R2)+       ;GET DATA
1617 006532 005301                                DEC     R1              ;SEE IF DONE ALL
1618 006534 001362                                BNE     EXW2B            ;IF NOT: BR
1619 006536 012701 000003  EXW2E:  MOV     #3,R1
1620 006542 005000                                CLR     R0              ;SET DELAY
1621 006544 005300  EXW2F:  DEC     R0
1622 006546 001376                                BNE     EXW2F
1623 006550 005301                                DEC     R1
1624 006552 001374                                BNE     EXW2F            ;DELAY
1625 006554 032777 020000 172006                BIT     #20000,ASWR     ;SEE IF ERROR PRINT
1626 006562 001004                                BNE     EXW2G            ;IF NOT: BR
1627 006564 012704 016642                        MOV     #MSG24,R4
1628 006570 004737 012714                        JSR     PC,TTOUT        ;PRINT NO INTERRUPT
1629 006574 005777 171770  EXW2G:  TST     ASWR
1630 006600 100001                                BPL     EXW2H            ;SEE IF HALT ON ERROR
1631 006602 000000                                HALT
1632 006604 000240                                EXW2H:  NOP
1633 006606 012701 017710                        MOV     #RBUF,R1        ;GET START OF READ BUFFER
1634 006612 012700 000400                        MOV     #400,R0         ;SET SIZE
1635 006616 010102                                MOV     R1,R2
1636 006620 012203  EXW2J:  MOV     (R2)+,R3
1637 006622 000303                                SWAB   R3
1638 006624 032737 000010 000776                BIT     #10,UDES        ;SEE IF EVEN PAR
1639 006632 001402                                BEQ     EXW2JO           ;IF NOT: BR
1640 006634 010321                                MOV     R3,(R1)+       ;SAVE PAR + DATA
1641 006636 000401                                BR     EXW2J1
1642 006640 110321  EXW2JO: MOVB   R3,(R1)+   ;ASSEMBLE DATA IN BYTES
1643 006642 005300  EXW2J1: DEC     R0
1644 006644 001365                                BNE     EXW2J           ;CONTINUE FOR ALL
1645 006646 032777 000200 171714                BIT     #200,ASWR       ;SEE IF STATUS CHECK
1646 006654 001002                                BNE     EXW2K            ;IF NOT: BR
1647 006656 004737 006704                        JSR     PC,WSTCK        ;ELSE GO CHECK STATUS
1648 006662 000240                                EXW2K:  NOP
1649 006664 032777 000400 171676                BIT     #400,ASWR       ;SEE IF DATA CHECK
1650 006672 001002                                BNE     EXW2X            ;IF NOT: BR
1651 006674 004737 007274                        JSR     PC,DCHK         ;ELSE GO CHECK DATA
1652 006700 000240                                EXW2X:  NOP

```

E04

TMO3/TE16 CONTROL LOGIC TEST-PART II
DZTEBA.P11 31-MAR-77 17:30

MACY11 27(1006) 31-MAR-77 17:30 PAGE 42

1653 006702 000207

RTS PC

;EXIT

```

1654
1655 ;WRAP AROUND STATUS CHECK ROUTINE*****
1656
1657 006704 000240 WSTCK: NOP
1658 006706 005037 000772 CLR SERFL ;CLEAR ERROR FLAG
1659 006712 005037 000620 CLR HDRFL ;CLEAR HEADER FLAG
1660 006716 022737 014575 000622 CMP #MSLT2,EMADDR ;SEE IF TEST 2
1661 006724 001404 BEQ 2$ ;IF SO: BR
1662 006726 022737 015465 000622 CMP #MSLT15,EMADDR ;SEE IF TEST 15
1663 006734 001025 BNE 5$ ;IF NOT: BR
1664 006736 005737 001000 2$: TST WPGFL ;SEE IF SINGLE PATTERN
1665 006742 001405 BEQ 3$ ;IF NOT: BR
1666 006744 122737 000003 001000 CMPB #3,WPGFL ;SEE IF PATTERN 3
1667 006752 001016 BNE 5$ ;IF NOT: BR
1668 006754 000404 BR 4$ ;ELSE GO DO EXPT CHANGE
1669 006756 022737 000003 001002 3$: CMP #3,PATRN ;SEE IF PATTERN 3
1670 006764 001011 BNE 5$ ;IF NOT: BR
1671 006766 052737 140000 001024 4$: BIS #140000,WCS1
1672 006774 052737 140000 001030 BIS #140000,WDS
1673 007002 052737 000100 001032 BIS #100,WER ;SET EXPT PARITY ERROR
1674 007010 012737 016464 000672 5$: MOV #MSG6,ERADD ;SET CODE=CS1
1675 007016 017702 171466 MOV @C1,R2 ;GET RCVD CS1
1676 007022 013705 001024 MOV WCS1,R5 ;GET EXPT CS1
1677 007026 004737 007150 JSR PC,WSTG ;GO CHK
1678 007032 012737 016511 000672 MOV #MSG6D,ERADD ;SET CODE=CS2
1679 007040 017702 171454 MOV @C5,R2 ;SET RCVD CS2
1680 007044 013705 001026 MOV WCS2,R5 ;GET EXPT CS2
1681 007050 053705 000624 BIS DAVN,R5 ;SET DRIVE NUMBER IN EXPT CS2
1682 007054 004737 007150 JSR PC,WSTG ;GO CHK
1683 007060 012737 016517 000672 MOV #MSG6E,ERADD ;SET CODE=DS
1684 007066 017702 171430 MOV @D5,R2 ;SET RCVD DS
1685 007072 013705 001030 MOV WDS,R5 ;GET EXPT DS
1686 007076 004737 007150 JSR PC,WSTG ;GO CHK
1687 007102 012737 016524 000672 1$: MOV #MSG6F,ERADD ;SET CODE=ER
1688 007110 017702 171410 MOV @ER,R2 ;GET RCVD ER
1689 007114 000240 NOP
1690 007116 000240 NOP
1691 007120 013705 001032 MOV WER,R5 ;GET EXPT ER
1692 007124 004737 007150 JSR PC,WSTG ;GO CHK
1693 007130 005737 000772 TST SERFL ;SEE IF ANY ERRORS
1694 007134 001456 BEQ WSTX ;IF NOT: BR
1695 007136 005777 171426 TST @SWR ;SEE IF HALT ON ERROR
1696 007142 100053 BPL WSTX ;IF NOT: BR
1697 007144 000000 HALT
1698 007146 000451 BR WSTX ;CONTINUE
1699 007150 000240 WSTG: NOP
1700 007152 020205 CMP R2,R5 ;SEE IF EXPT=RCVD
1701 007154 001446 BEQ WSTX ;IF SO: BR
1702 007156 005237 000772 INC SERFL ;SET ERROR FLAG
1703 007162 032777 020000 171400 BIT #20000,@SWR ;SEE IF PRINT ERRORS
1704 007170 001040 BNE WSTX ;IF NOT: BR
1705 007172 005737 000620 TST HDRFL ;SEE IF DONE HEADER
1706 007176 001010 BNE WSTG ;IF SO: BR
1707 007200 013704 000622 MOV EMADDR,R4 ;PRINT TEST HEADER
1708 007204 004737 012714 JSR PC,TTOUT
1709 007210 012704 016626 MOV #MSG23,R4

```

1710	007214	004737	012714		JSR	PC, TTOUT	;PRINT STATUS TAG
1711	007220	012737	000001	000620	WSTGO:	MOV #1, HORFL	;SET HEADER FLAG
1712	007226	013704	000672		MOV	ERADD, R4	
1713	007232	004737	012714		JSR	PC, TTOUT	;PRINT CODE
1714	007236	012704	014165		MOV	MSG12, R4	
1715	007242	004737	012714		JSR	PC, TTOUT	;PRINT EXPT TAG
1716	007246	010503			MOV	R5, R3	
1717	007250	004737	013042		JSR	PC, OCTP	;PRINT EXPT STATUS
1718	007254	012704	014174		MOV	MSG13, R4	
1719	007260	004737	012714		JSR	PC, TTOUT	;PRINT RCVD TAG
1720	007264	010203			MOV	R2, R3	
1721	007266	004737	013042		JSR	PC, OCTP	;PRINT RCVD STATUS
1722	007272	000207			WSTX:	RTS	;RETURN
1723							

```

1724
1725
1726
1727 007274 000240
1728 007276 005737 001022
1729 007302 001402
1730 007304 000137 010134
1731 007310 005737 001020
1732 007314 001373
1733 007316 005037 000620
1734 007322 005037 000766
1735 007326 005037 000774
1736 007332 032737 000010 000776
1737 007340 001402
1738 007342 000137 010156
1739 007346 022737 000010 000750 DCHKAD:
1740 007354 001006
1741 007356 032737 002000 000776
1742 007364 001402
1743 007366 000137 010660
1744 007372 012700 177400
1745 007376 022737 000012 000750 DCHKA:
1746 007404 001006
1747 007406 032737 000020 000776
1748 007414 001402
1749 007416 012700 177000
1750 007422 022737 000030 000750 DCHKA1:
1751 007430 001404
1752 007432 022737 000006 000750
1753 007440 001007
1754 007442 012700 177744
1755 007446 012701 017306
1756 007452 005037 000766
1757 007456 000431
1758 007460 022737 000012 000750 DCHKA2:
1759 007466 001021
1760 007470 032737 002000 000776
1761 007476 001415
1762 007500 012700 177653
1763 007504 012737 000001 000764
1764 007512 004737 007532
1765 007516 004737 011160
1766 007522 005037 000764
1767 007526 000137 010116
1768 007532 005037 000766 DCHKB:
1769 007536 012701 017276
1770 007542 012702 017710 DCHKBO:
1771 007546 032737 000020 000776
1772 007554 001416
1773 007556 022737 000012 000750
1774 007564 001011
1775 007566 005737 001002
1776 007572 001003
1777 007574 012701 001056
1778 007600 000404
1779 007602 012701 001044 DCHKC:
  
```

;DATA CHECK ROUTINE*****

```

DCHK: NOP
TST CRCFLG ;DO NOT DO A DATA CHACK
BEQ ZS ;IF CRC CORRECTION IN PROGRESS
1S: JMP DCHKX1
2S: TST DCHKFL ;BRANCH IF DATA IS NOT TO BE CHECKED
BNE 1S
CLR MOREL ;CLEAR HEADER FLAG
CLR DERFL ;CLEAR DATA ERROR FLAG
CLR CRCNT ;CLEAR CHAR CNTR
BIT #10,UDES ;SEE IF EVEN PARITY
BEQ DCHKAD ;IF NOT: BR
JMP DCHKE ;ELSE GO CHECK EVEN
DCHKAD: CMP #10,WAM ;SEE IF WAM 1
BNE DCHKA ;IF NOT: BR
BIT #2000,UDES ;SEE IF PE
BEQ DCHKA ;IF NOT: BR
JMP PRCHK ;GO CHK DATA
DCHKA: MOV #400,R0 ;SET NUMBER OF CHARACTERS
CMP #12,WAM
BNE DCHKA1 ;IF NOT WRAP 2: BR
BIT #20,UDES
BEQ DCHKA1 ;IF NOT CORE DUMP: BR
MOV #1000,R0
DCHKA1: CMP #30,WAM ;BRANCH IF WRAP 4
BEQ 1S
CMP #6,WAM ;SEE IF WRAP 0
BNE DCHKA2 ;IF NOT: BR
1S: MOV #34,R0 ;SET NUMBER OF CHARACTERS READ
MOV #BUBFF+10,R1 ;SET POINTER
CLR DERFL ;CLEAR DATA ERROR FLAG
BR DCHKBO
DCHKA2: CMP #12,WAM ;SEE IF WRAP 2
BNE DCHKB ;IF NOT: BR
BIT #2000,UDES ;SEE IF PE
BEQ DCHKB ;IF NOT: BR
MOV #125,R0 ;POINT TO START OF DATA
MOV #1,W2FLG ;SET WRAP 2 FLAG
JSR PC,DCHKB ;GO CHECK DATA
JSR PC,WIDCHK ;GO CHECK WRAP 1 DATA
CLR W2FLG
JMP DCHKX
DCHKB: CLR DERFL
MOV #BUBFF,R1 ;SET GOOD POINTER
DCHKBO: MOV #BUBFF,R2 ;SET READ POINTER
BIT #20,UDES ;SEE IF CORE DUMP
BEQ DCHKO ;IF NOT: BR
CMP #12,WAM ;SEE IF WAM 2
BNE DCHKD ;IF NOT: BR
TST PATRN ;SEE IF PATTERN 0
BNE DCHKC ;IF NOT: BR
MOV #WCDP0,R1 ;SET CORE DUMP PATTERN 0
BR DCHKO ;GO CHECK DATA
DCHKC: MOV #WCDP2,R1 ;SET CORE DUMP WRITE PATTERN 2
  
```

1780	007606	000401				BR	DCHK0		;GO CHECK DATA
1781	007610	000240				DCHK0: NOP			
1782	007612	121112				DCHK0: CMPB	(R1) (R2)		; SEE IF DATA OK
1783	007614	001466				BEQ	DCHK2		; IF SO: BR
1784	007616	032777	020000	170744		BIT	#20000, JSWR		; SEE IF PRINT ERRORS
1785	007624	001062				BNE	DCHK2		; IF NOT: BR
1786	007626	005737	000620			TST	HDRFL		; SEE IF DONE HEADER
1787	007632	001004				BNE	DCHK1		; IF SO: BR
1788	007634	013704	000622			MOV	EMADR, R4		
1789	007640	004737	012714			JSR	PC, TTOUT		; PRINT HEADER
1790	007644	005737	000766			DCHK1: TST	DERFL		; SEE IF FIRST ERROR
1791	007650	001014				BNE	DCHK1A		; IF NOT: BR
1792	007652	012704	016574			MOV	#MSG16, R4		
1793	007656	004737	012714			JSR	PC, TTOUT		; PRINT DATA ERROR TAG
1794	007662	012704	017021			MOV	#MSG32, R4		
1795	007666	004737	012714			JSR	PC, TTOUT		; PRINT PATRN TAG
1796	007672	013703	001002			MOV	PATRN, R3		
1797	007676	004737	013042			JSR	PC, OCTP		; PRINT PATTERN NUMBER
1798	007702	012737	000001	000620		DCHK1A: MOV	#1, HDRFL		; SET HEADER FLAG
1799	007710	012737	000001	000766		MOV	#1, DERFL		; SET DATA ERROR FLAG
1800	007716	012704	016620			MOV	#MSG21, R4		
1801	007722	004737	012714			JSR	PC, TTOUT		; PRINT CHARACTER NUMBER TAG
1802	007726	013703	000774			MOV	CRCNT, R3		
1803	007732	004737	013042			JSR	PC, OCTP		; PRINT CHARACTER NUMBER
1804	007736	012704	016606			MOV	#MSG17, R4		
1805	007742	004737	012714			JSR	PC, TTOUT		; PRINT GOOD TAG
1806	007746	111103				MOVB	(R1), R3		
1807	007750	004737	013270			JSR	PC, DOUT		; PRINT GOOD DATA
1808	007754	012704	016613			MOV	#MSG20, R4		
1809	007760	004737	012714			JSR	PC, TTOUT		; PRINT BAD TAG
1810	007764	111203				MOVB	(R2), R3		
1811	007766	004737	013270			JSR	PC, DOUT		; PRINT BAD DATA
1812	007772	005737	000764			DCHK2: TST	W2FLG		; SEE IF WRAP 2 NRZ
1813	007776	001020				BNE	DCHK2B		; IF SO: BR
1814	010000	005201				INC	R1		; BUMP POINTER
1815	010002	032737	000020	000776		BIT	#20, UDES		; SEE IF CORE DUMP
1816	010010	001413				BCQ	DCHK2B		; IF NOT: BR
1817	010012	022737	000012	000750		CMP	#12, WAM		; SEE IF WAM 2
1818	010020	001006				BNE	DCHK2A		; IF NOT: BR
1819	010022	005201				INC	R1		; BUMP POINTER
1820	010024	005711				TST	(R1)		; SEE IF END OF PATTERN
1821	010026	001004				BNE	DCHK2B		; IF NOT: BR
1822	010030	162701	000010			SUB	#10, R1		; RESET POINTER TO START OF PATTERN
1823	010034	000401				BR	DCHK2B		; CONTINUE CHECK
1824	010036	000240				DCHK2A: NOP			
1825	010040	005202				DCHK2B: INC	R2		
1826	010042	022737	000030	000750		CMP	#30, WAM		; BRANCH IF WAM 4
1827	010050	001404				BEQ	1\$		
1828	010052	022737	000006	000750		CMP	#6, WAM		; SEE IF WAM 0
1829	010060	001002				BNE	DCHK3		; IF NOT: BR
1830	010062	062701	000010			ADD	#10, R1		; BUMP POINTER
1831	010066	005237	000774			DCHK3: INC	CRCNT		; BUMP CHAR CNTR
1832	010072	032777	000400	170470		BIT	#400, JSWR		; SEE IF CONT DATA CHK
1833	010100	001006				BNE	DCHKX		; IF NOT: BR
1834	010102	005200				INC	R0		; SEE IF DONE
1835	010104	001242				BNE	DCHK0		; IF NOT: BR

1836	010106	005737	000764
1837	010112	001401	
1838	010114	000207	
1839	010116	005777	170446
1840	010122	100004	
1841	010124	005737	000766
1842	010130	001401	
1843	010132	000000	
1844	010134	005037	000774
1845	010140	005037	000620
1846	010144	005037	000756
1847	010150	005037	000770
1848	010154	000207	

	TST	W2FLG	
	BEQ	DCHKX	
	RTS	PC	
DCHKX:	TST	25HR	;SEE IF HALT ON ERROR
	BPL	DCHKX1	;IF NOT: BR
	TST	DERFL	;SEE IF DATA ERROR OCCURED
	BEQ	DCHKX1	;IF NOT: BR
	HALT		
DCHKX1:	CLR	CRCNT	;CLEAR CHAR CNTR
	CLR	HDRFL	;CLEAR HEADER FLAG
	CLR	DERFL	;CLEAR DATA ERROR FLAG
	CLR	PREFL	;CLEAR PREAMBLE FLAG
	RTS	PC	;RETURN

```

1849
1850
1851
1852
1853 010156 000240
1854 010160 022737 000006 000750
1855 010166 001005
1856 010170 012700 177744
1857 010174 012701 017306
1858 010200 000404
1859 010202 012700 177400
1860 010206 012701 017276
1861 010212 012702 017710
1862 010216 111105
1863 010220 005003
1864 010222 012704 000010
1865 010226 032705 000001
1866 010232 001401
1867 010234 005203
1868 010236 005304
1869 010240 001402
1870 010242 006005
1871 010244 000770
1872 010246 000240
1873 010250 111105
1874 010252 042705 177400
1875 010256 005703
1876 010260 001003
1877 010262 012705 100020
1878 010266 000405
1879 010270 032703 000001
1880 010274 001402
1881 010276 052705 100000
1882 010302 042712 077400
1883 010306 020512
1884 010310 001477
1885 010312 032777 020000 170250
1886 010320 001073
1887 010322 005737 000620
1888 010326 001004
1889 010330 013704 000622
1890 010334 004737 012714
1891 010340 005737 000766
1892 010344 001014
1893 010346 012704 016574
1894 010352 004737 012714
1895 010356 012704 017021
1896 010362 004737 012714
1897 010366 013703 001002
1898 010372 004737 013042
1899 010376 000240
1900 010400 012737 000001 000766
1901 010406 012737 000001 000620
1902 010414 012704 016620
1903 010420 004737 012714
1904 010424 013703 000774
1905 010430 004737 013042
;EVEN PARITY DATA CHECK*****
DCKE:  NOP
      CMP      #6, WAM      ;SEE IF WRAP 0
      BNE     18      ;IF NOT: BR
      MOV     #34, R0      ;SET NUMBER OF CHARACTERS READ
      MOV     #BUFF+10, R1 ;SET POINTER
      BR     28
18:   MOV     #400, R0      ;SET NUMBER OF CHARACTERS
      MOV     #WUFF, R1     ;R1=START OF WRITE BUFFER
28:   MOV     #RUFF, R2     ;R2=START OF READ BUFFER
DCKE0: MOVVB   (R1), R5     ;GET EXPT DATA
      CLR     R3
      MOV     #10, R4      ;SET NUMBER OF BITS
DCKE1: BIT     #1, R5      ;SEE IF ONE BIT
      BEQ     DCKE2      ;IF NOT: BR
      INC     R3          ;COUNT ONE BITS FOR PARITY CHECK
DCKE2: DEC     R4          ;SEE IF DONE
      BEQ     DCKE3      ;IF SO: BR
      ROR     R5          ;POINT TO NEXT BIT
      BR     DCKE1
DCKE3: NOP
      MOVVB   (R1), R5     ;GET EXPT DATA
      BIC     #177400, R5  ;MASK DATA FIELD
      TST     R3
      BNE     DCKE4      ;IF NO ONE BITS SET: BR
      MOV     #100020, R5
      BR     DCKE5
DCKE4: BIT     #1, R3      ;SEE IF ODD NUMBER OF ONE BITS
      BEQ     DCKE5      ;IF NOT: BR
      BIS     #100000, R5  ;SET EVEN PARITY BIT=1
DCKE5: BIC     #77400, (R2) ;MASK DATA FIELD
      CMP     R5, (R2)    ;SEE IF DATA + PARITY GOOD
      BEQ     DCKE10     ;IF SO: BR
      BIT     #20000, #SWR ;SEE IF ERROR PRINT
      BNE     DCKE10     ;IF NOT: BR
      TST     #ORFL      ;SEE IF DONE HEADER
      BNE     DCKE6      ;IF SO: BR
      MOV     #EMR00R, R4
      JSR     PC, TTOUT   ;PRINT HEADER
DCKE6: TST     #ERFL      ;SEE IF FIRST BAD CHAR
      BNE     DCKE7      ;IF NOT: BR
      MOV     #MSG16, R4
      JSR     PC, TTOUT   ;PRINT BAD DATA TAG
      MOV     #MSG32, R4
      JSR     PC, TTOUT   ;PRINT PATTERN TAG
      MOV     #PATRN, R3
      JSR     PC, OCTP    ;PRINT PATTERN NUMBER
DCKE7: NOP
      MOV     #1, #ERFL   ;SET DATA ERROR FLAG
      MOV     #1, #ORFL   ;SET HEADER FLAG
      MOV     #MSG21, R4
      JSR     PC, TTOUT   ;PRINT CHAR NUMBER TAG
      MOV     #CRNT, R3
      JSR     PC, OCTP    ;ORINT CHAR NUMBER
  
```

1905	010434	012704	016606		MOV	#MSG17,R4	
1906	010440	004737	012714		JSR	PC,TTOUT	;PRINT GOOD DATA TAG
1907	010444	110503			MOVB	R5,R3	
1908	010446	004737	013270		JSR	PC,DOUT	;PRINT EXPT DATA
1909	010452	010503			MOV	R5,R3	
1910	010454	004737	010564		JSR	PC,DCKEP	;GO PRINT PARITY BIT
1911	010460	000240			NOP		
1912	010462	012704	016613		MOV	#MSG20,R4	
1913	010466	004737	012714		JSR	PC,TTOUT	;PRINT BAD TAG
1914	010472	111203			MOVB	(R2),R3	
1915	010474	004737	013270		JSR	PC,DOUT	;PRINT BAD DATA
1916	010500	011203			MOV	(R2),R3	
1917	010502	004737	010564		JSR	PC,DCKEP	;GO PRINT PARITY BIT
1918	010506	000240			NOP		
1919	010510	005201			INC	R1	
1920	010512	032737	000006	000750	DCKE10: CMP	#6,WAM	;SEE IF WRAP 0
1921	010520	001002			BNE	IS	;IF NOT: BR
1922	010522	062701	000010		ADD	#10,R1	;BUMP POINTER
1923	010526	005722			IS: TST	(R2)+	;BUMP POINTERS
1924	010530	005237	000774		INC	CRCNT	;BUMP CHAR CNTR
1925	010534	032777	000400	170026	BIT	#400,JSWR	;SEE IF CONTINUE DATA CHECK
1926	010542	001402			BEQ	DCKE11	;IF SO: BR
1927	010544	000137	010116		JMP	DCHKX	;GO TO END OF DATA CHECK
1928	010550	005200			DCKE11: INC	R0	;SEE IF DONE
1929	010552	001402			BEQ	DCKE12	;IF SO: BR
1930	010554	000137	010216		JMP	DCKE0	;ELSE CONTINUE
1931	010560	000137	010116		DCKE12: JMP	DCHKX	;GO TO END OF DATA CHECK
1932	010564	000240			DCKEP: NOP		
1933	010566	012737	000240	000614	MOV	#240,TOB	
1934	010574	004737	013014		JSR	PC,TOG	;SPACE
1935	010600	012737	000260	000614	MOV	#260,TOB	;SET PAR=0
1936	010606	005703			TST	R3	;SEE IF PARITY REALLY=0
1937	010610	100002			BPL	DCKEPO	;IF SO: BR
1938	010612	005237	000614		INC	TOB	;ELSE SET TO 1
1939	010616	004737	013014		DCKEPO: JSR	PC,TOG	;PRINT PARITY BIT
1940	010622	000207			RTS	PC	;RETURN
1941							

```

1942
1943
1944
1945 010624 012700 000051 PSCHK: MOV #51,R0 ;SET SIZE OF POSTAMBLE
1946 010630 012701 017154 MOV #POST,R1 ;SET POINTER TO POSTAMBLE
1947 010634 005037 000620 CLR HDRFL ;CLEAR HEADER FLAG
1948 010640 005037 000774 CLR CRCNT ;CLEAR CHAR CNTR
1949 010644 005037 000766 CLR DERFL ;CLEAR DATA ERROR FLAG
1950 010650 000240 NOP
1951 010652 000240 NOP
1952 010654 000137 010676 JMP P00 ;GO CHECK POSTAMBLE
1953
1954 010660 012700 000051 PRCHK: MOV #51,R0 ;SET SIZE OF PREAMBLE
1955 010664 012701 017032 MOV #PRE,B1 ;SET POINTER TO PREAMBLE
1956 010670 012702 017710 MOV #RBUF,R2 ;SET POINTER TO START OF READ BUFFER
1957 010674 022122 CMP (R1)+,(R2)+ ;BUMP ADDRESS POINTERS
1958 010676 121112 P00: CMPB (R1),(R2) ;CHECK DATA
1959 010700 001004 BNE P01 ;IF NOT GOOD: BR
1960 010702 126162 000001 000001 CMPB 1(R1),1(R2) ;COMPARE COMPLIMENT BYTE
1961 010710 001477 BEQ P05 ;IF GOOD: BR
1962 010712 032777 020000 167650 P01: BIT #20000,#SWR ;SEE IF PRINT INHIBIT
1963 010720 001073 BNE P05 ;IF SO: BR
1964 010722 005737 000620 TST HDRFL ;SEE IF DONE HEADER
1965 010726 001020 BNE P04 ;IF SO: BR
1966 010730 013704 000622 MOV EMADDR,R4
1967 010734 004737 012714 JSR PC,TOUT ;PRINT TEST HEADER
1968 010740 005737 000770 TST PRFL ;SEE IF PREAMBLE CHECK
1969 010744 001403 BEQ P02 ;IF NOT: BR
1970 010746 012704 016745 MOV #MSG29,R4 ;SET POSTAMBLE HEADER
1971 010752 000402 BR P03
1972 010754 012704 016727 P02: MOV #MSG28,R4 ;SET PREAMBLE HEADER
1973 010760 004737 012714 P03: JSR PC,TOUT ;PRINT HEADER
1974 010764 005237 000620 INC HDRFL
1975 010770 012704 016620 P04: MOV #MSG21,R4
1976 010774 004737 012714 JSR PC,TOUT ;PRINT CHAR NUMBER TAG
1977 011000 013703 000774 MOV CRCNT,R3
1978 011004 004737 013042 JSR PC,OCIP ;PRINT CHAR NUMBER
1979 011010 012704 016606 MOV #MSG17,R4
1980 011014 004737 012714 JSR PC,TOUT ;PRINT GOOD TAG
1981 011020 116103 000001 MOVB 1(R1),R3
1982 011024 004737 013270 JSR PC,DOUT ;PRINT GOOD CHAR
1983 011030 012737 000240 000614 MOV #240,T0B
1984 011036 004737 013014 JSR PC,T0G
1985 011042 111103 MOVB (R1),R3
1986 011044 004737 013270 JSR PC,DOUT ;PRINT COMPLIMENT
1987 011050 012704 016613 MOV #MSG20,R4
1988 011054 004737 012714 JSR PC,TOUT ;PRINT BAD TAG
1989 011060 116203 000001 MOVB 1(R2),R3
1990 011064 004737 013270 JSR PC,DOUT ;PRINT BAD CHAR
1991 011070 012737 000240 000614 MOV #240,T0B
1992 011076 004737 013014 JSR PC,T0G
1993 011102 111203 MOVB (R2),R3
1994 011104 004737 013270 JSR PC,DOUT ;PRINT COMPLIMENT
1995 011110 022122 P05: CMP (R1)+,(R2)+ ;BUMP ADDRESS POINTERS
1996 011112 005237 000774 INC CRCNT ;BUMP CHAR NUMBER
1997 011116 005300 DEC R0 ;SEE IF DONE
    
```

1998	011120	001266	
1999	011122	005737	000770
2000	011126	001402	
2001	011130	000137	010116
2002	011134	005237	000770
2003	011140	005037	000620
2004	011144	005037	000774
2005	011150	005037	000766
2006	011154	000137	011160
2007			

PD6:

BNE	PD0
TST	PREFL
BEQ	PD6
JMP	DCHKX
INC	PREFL
CLR	HDRFL
CLR	CRCNT
CLR	DERFL
JMP	WIDCHK

```

: IF NOT: BR
: SEE IF PREAMBLE
: IF SO: BR
: GO TO EXIT ROUTINE
: SET PREAMBLE FLAG
: CLEAR HEADER FLAG
: CLEAR CHAR CNTR
: CLEAR DATA ERROR FLAG
: GO CHECK WRAP I DATA

```

```

2008
2009
2010 ;WAM 1 PE DATA CHECK*****
2011 011160 012700 177400 WIDCHK: MOV #400,R0 ;SET NUMBER OF CHAR TO CHECK
2012 011164 012701 017276 MOV #RBUF,R1 ;SET WRITE DATA POINTER
2013 011170 012702 017710 MOV #RBUF,R2 ;SET READ DATA POINTER
2014 011174 062702 000124 ADD #124,R2 ;POINT TO START OF DATA
2015 011200 005737 000764 TST W2FLG ;SEE IF WRAP 2
2016 011204 001401 BEQ W1D0 ;IF NOT WAM 2: BR
2017 011206 005302 DEC R2 ;RESET POINTER
2018 011210 111105 W1D0: MOVB (R1),R5
2019 011212 120512 CMPB R5,(R2) ;CHECK DATA
2020 011214 001007 BNE W1D1 ;IF NOT GOOD:BR
2021 011216 005737 000764 TST W2FLG ;SEE IF WRAP 2
2022 011222 001001 BNE W1D0A ;IF SO: BR
2023 011224 105105 COMB R5 ;COMPLIMENT EXPT DATA
2024 011226 120562 000001 W1D0A: CMPB R5,1(R2) ;CHECK COMPLIMENT DATA
2025 011232 001510 BEQ W1D3 ;IF GOOD: BR
2026 011234 032777 020000 167326 W1D1: BIT #20000,2SWR ;SEE IF PRINT INHIBIT
2027 011242 001104 BNE W1D3 ;IF SO: BR
2028 011244 005737 000620 TST WDRFL ;SEE IF DONE HEADER
2029 011250 001020 BNE W1D2 ;IF SO: BR
2030 011252 013704 000622 MOV EMADR,R4
2031 011256 004737 012714 JSR PC,TTOUT ;PRINT TEST HEADER
2032 011262 012704 016574 MOV #MSG16,R4
2033 011266 004737 012714 JSR PC,TTOUT ;PRINT BAD DATA TAG
2034 011272 012704 017021 MOV #MSG32,R4
2035 011276 004737 012714 JSR PC,TTOUT ;PRINT PATRN TAG
2036 011302 013703 001002 MOV PATRN,R3
2037 011306 004737 013042 JSR PC,OC1P ;PRINT PATTERN NUMBER
2038 011312 012737 000001 000620 W1D2: MOV #1,WDRFL ;SET HEADER FLAG
2039 011320 012704 016620 MOV #MSG21,R4
2040 011324 004737 012714 JSR PC,TTOUT ;PRINT CHAR NUMBER TAG
2041 011330 013703 000774 MOV CRCNT,R3
2042 011334 004737 013042 JSR PC,OC1P ;PRINT CHAR NUMBER
2043 011340 012704 016606 MOV #MSG17,R4
2044 011344 004737 012714 JSR PC,TTOUT ;PRNT GOOD TAG
2045 011350 111105 MOVB (R1),R5
2046 011352 110503 MOVB R5,R3 ;GET GOOD CHAR
2047 011354 005737 000764 TST W2FLG ;SEE IF WRAP 2
2048 011360 001001 BNE W1D2A ;IF SO: BR
2049 011362 105103 COMB R3 ;ELSE COMPLIMENT CHAR
2050 011364 004737 013270 W1D2A: JSR PC,DOUT ;PRINT CHARACTER
2051 011370 012737 000240 000614 MOV #240,T0B
2052 011376 004737 013014 JSR PC,T0G ;SPACE
2053 011402 110503 MOVB R5,R3
2054 011404 004737 013270 JSR PC,DOUT ;PRINT CHAR
2055 011410 012704 016613 MOV #MSG20,R4
2056 011414 004737 012714 JSR PC,TTOUT ;PRINT BAD TAG
2057 011420 116203 000001 MOVB 1(R2),R3
2058 011424 004737 013270 JSR PC,DOUT ;PRINT BAD CHAR
2059 011430 012737 000240 000614 MOV #240,T0B
2060 011436 004737 013014 JSR PC,T0G ;SPACE
2061 011442 111203 MOVB (R2),R3
2062 011444 004737 013270 JSR PC,DOUT ;PRINT CHAR
2063 011450 005237 000766 INC DERFL ;SET DATA ERROR FLAG

```

2064	011454	122122	
2065	011456	105722	
2066	011460	005237	000774
2067	011464	000406	
2068	011466	005737	000764
2069	011472	001401	
2070	011474	000207	
2071	011476	000137	010624
2072	011502	005200	
2073	011504	001770	
2074	011506	000137	011210
2075			
2076			
2077			
2078	011512	000240	
2079	011514	012700	000050
2080	011520	012701	017032
2081	011524	005721	
2082	011526	012721	177400
2083	011532	005300	
2084	011534	001374	
2085	011536	012701	017154
2086	011542	012700	000050
2087	011546	012721	000377
2088	011552	012721	177400
2089	011556	005300	
2090	011560	001374	
2091	011562	000207	

```

W103:  CMPB  (R1)+,(R2)+  ;BUMP ADDRESS
        TSTB  (R2)+      ;BUMP ADDRESS
        INC   CRCNT      ;BUMP CHAR CNTR
        BR    W105
W104:  TST   W2FLG      ;SEE IF WRAP 2
        BEQ   W104A     ;IF NOT: BR
        RTS   PC        ;ELSE RETURN
W104A: JMP   PSCHK      ;GO CHECK POSTAMBLE
W105:  INC   RO
        BEQ   W104
        JMP   W100

;PREAMBLE/POSTAMBLE GENERATE SUBROUTINE*****

PPGEN: NOP
        MOV   #50,RO    ;SET SIZE OF PREAMBLE
        MOV   #PRE,R1
        TST  (R1)+
        MOV   #177400,(R1)+ ;SET ADDRESS OF PRE
        DEC  RO        ;FILL TABLE
        BNE  1$       ;SEE IF DONE
        MOV   #POST,R1 ;IF NOT: BR
        MOV   #50,RO   ;SET ADDRESS OF POST
        DEC  RO        ;SET SIZE OF POST
        BNE  2$       ;SET SYNC CHAR
        MOV   #377,(R1)+ ;FILL TABLE
        DEC  RO        ;SEE IF DONE
        BNE  2$       ;IF NOT: BR
        RTS  PC        ;RETURN
1$:
2$:

```

```

2092
2093
2094
2095 011564 005237 000676
2096 011570 017700 166740
2097 011574 042700 000036
2098 011600 052700 000024
2099 011604 010077 166724
2100 011610 042777 000037 166716
2101 011616 005000
2102 011620 012701 000002
2103 011624 032777 000001 166656 EORP1:
2104 011632 001427
2105 011634 005300
2106 011636 001372
2107 011640 005301
2108 011642 001370
2109 011644 032777 020000 166716
2110 011652 001017
2111 011654 005737 000620
2112 011660 001004
2113 011662 013704 000622
2114 011666 004737 012714
2115 011672 012704 016764 EORP1A:
2116 011676 004737 012714
2117 011702 005777 166662
2118 011706 100001
2119 011710 000000
2120 011712 000240 EORP2:
2121 011714 005737 000676
2122 011720 001015
2123 011722 032777 000200 166640
2124 011730 001002
2125 011732 004737 006704
2126 011736 000240 EORP3:
2127 011740 032777 000400 166622
2128 011746 001002
2129 011750 004737 007274
2130 011754 000240 EORPX:
2131 011756 005037 000676
2132 011762 000207
2133
  
```

;END OF RECORD FORCE SUBROUTINE*****

```

EORPA: INC TEMP2 ;SET WRAP FLAG
EORP: MOV @MR,RO ;GET MAINT REG
      BIC #36,RO ;CLEAR CURRENT OP CODE
      BIS #24,RO ;SET EOR CLEAR OP CODE
      MOV RO,@MR ;DO EOR
      BIC #37,@MR ;CLEAR EOR AND MM
      CLR RO
      MOV #2,R1
EORP1: BIT #1,@C1 ;SEE IF GO GONE
      BEQ EORP2 ;IF SO: BR
      DEC RO ;AWAIT GO RESET
      BNE EORP1
      DEC R1
      BNE EORP1
      BIT #20000,@SWR ;SEE IF ERROR PRINT INHIBIT
      BNE EORP2 ;IF SO: BR
      TST HDRFL ;SEE IF DONE HEADER
      BNE EORP1A ;IF SO: BR
      MOV @MADR,R4
      JSR PC,TTOUT ;PRINT HEADER
EORP1A: MOV #MMSG31,R4
      JSR PC,TTOUT ;PRINT EOR GO BIT ERROR
      TST @SWR ;SEE IF HALT ON ERROR
      BPL EORP2 ;IF NOT: BR
      HALT
EORP2: NOP
      TST TEMP2 ;SEE IF WAM
      BNE EORPX ;IF NOT: BR
      BIT #200,@SWR ;SEE IF STATUS CHECK
      BNE EORP3 ;IF NOT: BR
      JSR PC,WSTCK ;ELSE GO CHECK STATUS
EORP3: NOP
      BIT #400,@SWR ;SEE IF DATA CHECK
      BNE EORPX ;IF NOT: BR
      JSR PC,DCHK ;ELSE GO CHECK DATA
EORPX: NOP
      CLR TEMP2 ;CLEAR FLAG
      RTS PC ;RETURN
  
```


E05

TM03/TE16 CONTROL LOGIC TEST-PART II
 DZTEBA.P11 31-MAR-77 17:30

MACY11 27(1006) 31-MAR-77 17:30 PAGE 55

```

2134
2135
2136
2137 011764 000240
2138 011766 032777 040000 166574
2139 011774 001001
2140 011776 000207
2141 012000 000240
2142 012002 005726
2143 012004 000240
2144 012006 000240
2145 012010 000177 166676
2146
2147
2148
2149 012014 032777 004000 166546
2150 012022 001403
2151 012024 005037 000702
2152 012030 000207
2153 012032 005737 001016
2154 012036 001772
2155 012040 005237 000702
2156 012044 023737 000702 000606
2157 012052 001764
2158 012054 005726
2159 012056 017700 166632
2160 012062 000110
2161

```

```

;SCOPE LOOP ON ERROR SUBROUTINE*****
SCOPE: NOP
BIT #40000, @SWR ;SEE IF LOOP ON ERROR
BNE 1$ ;IF SO: BR
RTS PC ;ELSE EXIT
1$: NOP
TST (SP)+ ;RESET STACK
NOP
NOP
JMP @SCOLP ;LOOP ON ERROR
;TEST ITERATION SUBROUTINE*****
ITER: BIT #4000, @SWR ;SEE IF ITERATIONS
BEQ 2$ ;IF SO: BR
1$: CLR ITCNT ;CLEAR ITERATION COUNTER
RTS PC ;ELSE EXIT
2$: TST @PCNTR ;DO SINGLE SUBTEST ITERATION
BEQ 1$ ;ON FIRST PASS
INC ITCNT ;BUMP COUNTER
CMP ITCNT, ITAMT ;SEE IF DONE ALL
BEQ 1$ ;IF SO: BR
TST (SP)+ ;RESET STACK
MOV @ITRLP, R0 ;SET ITERATION POINTER
JMP (R0) ;GO ITERATE

```

```

2162
2163 ;INITIALIZE SUBROUTINE*****
2164
2165 012064 012777 000040 166426 INIT: MOV #40,ACS ;INIT
2166 012072 013777 000624 166420 MOV DRVN,ACS ;SELECT DRIVE
2167 012100 013777 000664 166434 MOV SLVN,ATC ;SELECT SLAVE
2168 012106 013746 000776 MOV UDES,-(SP) ;GET TEST'S UNIT DESCRIPTION
2169 012112 042716 174377 BIC #174377,(SP) ;CLEAR ALL BUT DENSITY SELECT BITS
2170 012116 022726 001400 CMP #1400,(SP)+ ;BRANCH IF NOT NRZ (800 BPI)
2171 012122 001005 BNE 1$
2172 012124 032777 000040 166370 BIT #40,ADS ;BRANCH IF SLAVE IS IN NRZ MODE
2173 012132 001420 BEQ 4$ ;(PES = 0)
2174 012134 000404 BR 2$ ;GO CHANGE DENSITY
2175 012136 032777 000040 166356 1$: BIT #40,ADS ;BRANCH IF SLAVE IS IN PE MODE
2176 012144 001013 BNE 4$ ;(PES = 1)
2177 012146 012777 000007 166334 2$: MOV #7,AC1 ;REWIND SLAVE
2178 012154 032777 000200 166340 20$: BIT #200,ADS ;WAIT FOR READY
2179 012162 001774 BEQ 20$
2180 012164 032777 020000 166330 3$: BIT #20000,ADS ;LOOP UNTIL REWIND IS COMPLETE
2181 012172 001374 BNE 3$ ;(PIP = 0)
2182 012174 053777 000776 166340 4$: BIS UDES,ATC ;LOAD UNIT DESCRIPTION
2183 012202 032777 000002 166312 BIT #2,ADS ;BRANCH IF NOT AT BOT
2184 012210 001407 BEQ 6$
2185 012212 012777 000025 166270 MOV #25,AC1 ;ERASE TO GET OFF BOT
2186 012220 032777 000200 166274 5$: BIT #200,ADS ;LOOP UNTIL DONE
2187 012226 001774 BEQ 5$
2188 012230 012777 000011 166252 6$: MOV #11,AC1 ;DO A DRIVE CLEAR
2189 012236 000207 RTS PC ;RETURN TO CALLER
2190
2191 ;MAG TAPE INTERRUPT HANDLER*****
2192
2193 012240 000240 MTINT: NOP
2194 012242 013716 000670 MOV RTRN,(SP) ;SET RETURN TO (RTRN)
2195 012246 000002 RTI ;RETURN
2196
2197 ;TTY INTERRUPT HANDLER*****
2198
2199 012250 017746 166320 TTINT: MOV #ATKB,-(SP) ;GET CHARACTER
2200 012254 042716 000200 BIC #200,(SP) ;CLEAR PARITY BIT
2201 012260 122716 000003 CMPB #3,(SP) ;BRANCH IF NOT CONTROL C
2202 012264 001006 BNE 1$
2203 012266 005737 001262 TST CHNFLAG ;INHIBIT ↑C IF CHAIN MODE
2204 012272 001003 BNE 1$
2205 012274 000005 RESET
2206 012276 000137 000200 JMP #200 ;RESTART PROGRAM
2207 012302 122716 000001 1$: CMPB #1,(SP) ;BRANCH IF NOT ↑A
2208 012306 001017 BNE 2$
2209 012310 022737 000176 000570 CMP #SWREG,SWR ;BRANCH IF HARDWARE SWR INVOKED
2210 012316 001016 BNE 3$
2211 012320 012737 177570 000570 MOV #177570,SWR ;INVOKE HARDWARE SWR
2212 012326 004737 013572 JSR PC,SAVE ;SAVE REGISTERS ON THE STACK
2213 012332 012704 014501 MOV #MSG63,R4 ;TYPE 'HARDWARE SWR IN USE'
2214 012336 004737 012714 JSR PC,TTOUT
2215 012342 004737 013614 JSR PC,RESTORE ;RESTORE REGISTERS
2216 012346 022716 000007 2$: CMP #7,(SP) ;BRANCH IF NOT ↑G
2217 012352 001005 BNE 4$

```



```

2223 :*****
2224 :TTY ENTRY SUBROUTINE:
2225 :
2226 :THIS SUBROUTINE IS USED BY THE TEST CONDITION
2227 :ENTRY ROUTINE TO READ THE RESPONSE ENTERED
2228 :AT THE TTY AND CHECK THEM FOR LEGALITY AND
2229 :LIMITS. ALL RESPONSE MUST BE TYPED IN OCTAL
2230 : (0-7) AND MUST FALL WITHIN THE LIMITS SET BY
2231 :THE CALLING ROUTINE.
2232 :IF AN ENTRY IS ILLEGAL OR OUTSIDE THE LIMITS,
2233 :A QUESTION MARK IS TYPED (?) AND THE RESPONSE
2234 :MAY BE REENTERED.
2235 :ENTRIES MAY NOT EXCEED SIX (6) CHARACTERS AND
2236 :MAY BE TERMINATED AT LESS THAN SIX BY TYPING A
2237 :CARRIAGE RETURN
2238 :*****
2239
2240 012372 010146 TTR: MOV R1, -(SP) ;SAVE CHAR COUNT
2241 012374 011601 10$: MOV (SP), R1 ;RESET CHAR COUNT (FOR ↑U)
2242 012376 005037 000674 CLR TEMP1 ;CLEAR FIRST CHARACTER FLAG
2243 012402 005000 CLR R0
2244 012404 004737 012652 1$: JSR PC, TTIN ;GO READ CHARACTER
2245 012410 122737 000003 000616 CMPB #3, TIB ;BRANCH IF NOT ↑C
2246 012416 001003 BNE I1$
2247 012420 000005 RESET
2248 012422 000137 000200 JMP #200 ;RESTART AT 200
2249 012426 122737 000015 000616 11$: CMPB #15, TIB ;SEE IF CR
2250 012434 001004 BNE 2$ ;IF NOT: BR
2251 012436 005737 000674 TST TEMP1 ;SEE IF FIRST CHARACTER
2252 012442 001471 BEQ 9$ ;IF SO: BR
2253 012444 000457 BR 6$ ;ELSE GO LOAD VALUE
2254 012446 122737 000025 000616 2$: CMPB #25, TIB ;BRANCH IF NOT CONTROL U
2255 012454 001005 BNE 21$
2256 012456 012704 014427 MOV #MSG59, R4 ;TYPE <CR><LF>
2257 012462 004737 012714 JSR PC, TOUT
2258 012466 000742 BR 10$
2259 012470 122737 000177 000616 21$: CMPB #177, TIB ;BRANCH IF NOT 'RUBOUT'
2260 012476 001012 BNE 3$
2261 012500 000241 CLC ;REMOVE LAST TYPED CHAR
2262 012502 006000 ROR R0
2263 012504 006200 ASR R0
2264 012506 006200 ASR R0
2265 012510 012704 014431 MOV #MSG60, R4 ;TYPE '\ '
2266 012514 004737 012714 JSR PC, TOUT
2267 012520 005201 INC R1 ;DECREMENT CHAR RECEIVED COUNT
2268 012522 000730 BR 1$ ;GET NEXT CHAR
2269 012524 122737 000060 000616 3$: CMPB #60, TIB ;SEE IF CHAR IS LESS THAN 0
2270 012532 101402 BLOS 4$ ;IF NOT: BR
2271 012534 000137 012632 JMP TNER ;ELSE GO TO ERROR
2272 012540 122737 000070 000616 4$: CMPB #70, TIB ;SEE IF CHAR IS GREATER THAN 7
2273 012546 10.002 BHI 5$ ;IF NOT: BR
2274 012550 000137 012632 JMP TNER ;ELSE GO TO ERROR
2275 012554 005237 000674 5$: INC TEMP1 ;SET FIRST CHARACTER FLAG
2276 012560 006300 ASL R0
2277 012562 006300 ASL R0 ;SHIFT 3 LEFT
2278 012564 006300 ASL R0

```

2279	012566	042737	177770	000616		BIC	#177770,T1B	:STRIP ASCII
2280	012574	053700	000616			BIS	T1B,R0	:LOAD CHARACTER
2281	012600	005301				DEC	R1	:SEE IF DONE
2282	012602	001300				BNE	1\$:IF NOT: BR
2283	012604	020002			6\$:	CMP	R0,R2	:SEE IF EXCEEDED MAXIMUM LIMIT
2284	012606	101402				BLOS	7\$:IF NOT: BR
2285	012610	000137	012632			JMP	T1NER	:ELSE GO TO ERROR
2286	012614	020300			7\$:	CMP	R3,R0	:SEE IF BELOW MINIMUM LIMIT
2287	012616	101402				BLOS	8\$:IF NOT: BR
2288	012620	000137	012632			JMP	T1NER	:ELSE GO TO ERROR
2289	012624	010015			8\$:	MOV	R0,(R5)	:LOAD VALUE
2290	012626	005726			9\$:	TST	(SP)+	:POP CHAR COUNT OFF STACK
2291	012630	000207				RTS	PC	:EXIT

```

2292
2293 ;TTY ENTRY ERROR SUBROUTINE*****
2294
2295 012632 012704 014304 T1NER: MOV #MSG40,B4
2296 012636 004737 012714 JSR PC,T1OUT ;PRINT?
2297 012642 005726 TST (SP)+ ;POP CHAR COUNT OFF STACK
2298 012644 162716 000020 SUB #20,(SP) ;RESET SP TO START OF VALUE ROUTINE
2299 012650 000207 RTS PC ;REDO VALUE ENTRY
2300
2301 ;TTY READ SUBROUTINE*****
2302
2303 012652 005277 165714 T1IN: INC @TKS
2304 012656 105777 165710 1$: TSTB @TKS
2305 012662 100375 BPL 1$
2306 012664 017737 165704 MOV @TKB,T1B 000616
2307 012672 042737 000200 BIC #200,T1B 000616
2308 012700 013737 000616 MOV T1B,T0B ;MOVE CHAR TO TTY OUPUT BFR
2309 012706 004737 013014 JSR PC,T0G ;ECHO CHARACTER
2310 012712 000207 RTS PC
2311
2312 ;TTY OUTPUT SUBROUTINE*****
2313
2314 012714 112437 000614 T1OUT: MOVB (R4)+,T0B
2315 012720 122737 000043 000614 CMPB #43,T0B
2316 012726 001440 BEQ TEX
2317 012730 122737 000045 000614 CMPB #45,T0B
2318 012736 001403 BEQ 1$
2319 012740 004737 013014 JSR PC,T0G
2320 012744 000763 BR T1OUT
2321 012746 112737 000015 000614 1$: MOVB #15,T0B
2322 012754 004737 013014 JSR PC,T0G
2323 012760 012703 000004 MOV #4,R3
2324 012764 005037 000614 2$: CLR T0B
2325 012770 004737 013014 JSR PC,T0G
2326 012774 005303 DEC R3
2327 012776 001372 BNE 2$ ;DO FILLERS
2328 013000 112737 000012 000614 MOVB #12,T0B
2329 013006 004737 013014 JSR PC,T0G
2330 013012 000740 BR T1OUT
2331 013014 105777 165556 T0G: TSTB @TPS
2332 013020 100375 BPL T0G
2333 013022 113777 000614 165550 MOVB T0B,@TPB
2334 013030 000207 TEX: RTS PC
2335
2336 ;OCTAL OUTPUT SUBROUTINE*****
2337
2338
2339 013032 012737 000001 013266 OCTPE: MOV #1,OFL
2340 013040 000402 BR OCTPE1
2341 013042 005037 013266 OCTP: CLR OFL ;CLEAR FLAG FOR LEADING ZERO
2342 013046 010304 OCTPE1: MOV R3,R4 ;SEE IF NUMBER IS ZERO
2343 013050 001007 BNE OCTPO ;IF NOT ZERO: BR
2344 013052 005737 013266 TST OFL ;SEE IF PRINT ALL 0
2345 013056 001004 BNE OCTPO ;IF SO: BR
2346 013060 004737 013246 JSR PC,OCTPG1 ;ELSE PRINT ZERO
2347 013064 000137 013210 JMP OCTP3 ;SPACE AND EXIT

```

```

2348 013070 032704 100000      OCTP0:  BIT      #100000,R4      ;SEE IF MS0 = 1
2349 013074 001406                      BEQ      OCTP1          ;IF NOT: BR
2350 013076 012704 000001      MOV      #1,R4
2351 013102 004737 013224      JSR      PC,OCTPG      ;PRINT 1
2352 013106 000137 013120      JMP      OCTP2
2353 013112 005004      OCTP1:  CLR      R4
2354 013114 004737 013224      JSR      PC,OCTPG      ;PRINT 0
2355 013120 010304      OCTP2:  MOV      R3,R4
2356 013122 006004                      ROR      R4
2357 013124 006004                      ROR      R4
2358 013126 006004                      ROR      R4          ;POSITION DIGIT
2359 013130 006004                      ROR      R4
2360 013132 000304                      SWAB
2361 013134 004737 013224      JSR      PC,OCTPG      ;PRINT DIGIT 2
2362 013140 010304                      MOV      R3,R4
2363 013142 006004                      ROR      R4
2364 013144 000304                      SWAB
2365 013146 004737 013224      JSR      PC,OCTPG      ;PRINT DIGIT 3
2366 013152 010304                      MOV      R3,R4
2367 013154 006104                      ROL      R4
2368 013156 006104                      ROL      R4
2369 013160 000304                      SWAB
2370 013162 004737 013224      JSR      PC,OCTPG      ;PRINT DIGIT 4
2371 013164 010304                      MOV      R3,R4
2372 013170 006004                      ROR      R4
2373 013172 006004                      ROR      R4
2374 013174 006004                      ROR      R4
2375 013176 004737 013224      JSR      PC,OCTPG
2376 013202 010304                      MOV      R3,R4
2377 013204 004737 013224      JSR      PC,OCTPG      ;PRINT DIGIT 5
2378 013210 012737 000240 000614  OCTP3:  MOV      #240,T08
2379 013216 004737 013014      JSR      PC,T0G        ;PRINT SPACE
2380 013222 000207                      RTS      PC            ;EXIT
2381 013224 042704 177770      OCTPG:  BIC      #177770,R4
2382 013230 001004                      BNE     OCTPG0
2383 013232 005737 013266      TST     OFL
2384 013236 001001                      BNE     OCTPG0
2385 013240 000207                      RTS      PC
2386
2387 013242 005237 013266      OCTPG0: INC     OFL
2388 013246 052704 000260      OCTPG1: BIS     #260,R4
2389 013252 010437 000614      MOV     R4,T08
2390 013256 004737 013014      JSR     PC,T0G
2391 013262 010304                      MOV     R3,R4
2392 013264 000207                      RTS
2393 013266 000000      OFL:    0
2394

```

;FIRST CHAR FLAG

```

2395
2396
2397
2398 013270 012704 000010      ;DATA CHARACTER OUTPUT SUBROUTINE*****
2399 013274 110337 000614      DOUT:  MOV    #10,R4          ;SET NUMBER TO PRINT
2400 013300 105777 165272      1$:   MOVB   R3,T0B
2401 013304 100375              TSTB  #TPS
2402 013306 132737 000200 000614 BPL   1$
2403 013314 001404              BITB  #200,T0B
2404 013316 012777 000061 165254 BEQ   2$
2405 013324 000403              MOV   #061,#TPB
2406 013326 012777 000060 165244 BR    3$
2407 013334 006337 000614      2$:   MOV   #060,#TPB
2408 013340 005304              3$:   ASL   T0B
2409 013342 001356              DEC   R4
2410 013344 000207              BNE  1$
2411
2412 013346 013703 000700      DOUTD: MOV   TEMP3,R3
2413 013352 000303              SWAB R3
2414 013354 004737 013270      JSR   PC,DOUT
2415 013360 013703 000700      MOV   TEMP3,R3
2416 013364 004737 013270      JSR   PC,DOUT
2417 013370 000207              RTS   PC
2418
2419
2420      ;TE16 SERIAL NUMBER PRINT SUBROUTINE*****
2421 013372 010304      SNPT:  MOV   R3,R4
2422 013374 000304              SWAB R4
2423 013376 006004              ROR  R4
2424 013400 006004              ROR  R4
2425 013402 006004              ROR  R4
2426 013404 006004              ROR  R4          ;GET FIRST DIGIT
2427 013406 004737 013450      JSR   PC,SNPG    ;PRINT
2428 013412 010304              MOV   R3,R4
2429 013414 000304              SWAB R4          ;GET SECOND DIGIT
2430 013416 004737 013450      JSR   PC,SNPG    ;PRINT
2431 013422 010304              MOV   R3,R4
2432 013424 006004              ROR  R4
2433 013426 006004              ROR  R4
2434 013430 006004              ROR  R4
2435 013432 006004              ROR  R4
2436 013434 004737 013450      JSR   PC,SNPG    ;PRINT THIRD DIGIT
2437 013440 010304              MOV   R3,R4
2438 013442 004737 013450      JSR   PC,SNPG    ;PRINT FOURTH DIGIT
2439 013446 000207              RTS   PC          ;EXIT
2440 013450 012737 000260 000614 SNPG: MOV   #260,T0B    ;SET BASE = 0
2441 013456 042704 177760      BIC  #177760,R4  ;MASK DIGIT
2442 013462 050437 000614      BIS  R4,T0B      ;SET ASCII
2443 013466 004737 013014      JSR   PC,TOG     ;TYPE DIGIT
2444 013472 000207              RTS   PC          ;RETURN

```


M05

TM03/TE16 CONTROL LOGIC TEST-PART II
 0ZTEBA.P11 31-MAR-77 17:30

MACY11 27(1006) 31-MAR-77 17:30 PAGE 63

```

2475
2476
2477
2478
2479 013474 022737 000176 000570 GTSWR:  CMP      #SWREG,SWR      ;BRANCH IF SOFTWARE SWR NOT
2480 013502 001032                       BNE      1$          ;INVOKED
2481 013504 004737 013572          JSR      PC,SAVE    ;SAVE REGISTERS ON THE STACK
2482 013510 012704 015757          MOV      #SWR,R4    ;TYPE 'SWR = '
2483 013514 004737 012714          JSR      PC,TTOUT   ;
2484 013520 017703 165044          MOV      #SWR,R3    ;GET CURRENT SETTING
2485 013524 004737 013032          JSR      PC,OCPE    ;AND TYPE THEM
2486 013530 012704 015767          MOV      #SWNEW,R4 ;TYPE 'NEW = '
2487 013534 004737 012714          JSR      PC,TTOUT   ;
2488 013540 013705 000570          MOV      SWR,R5     ;TTR ROUTINE RETURN NEW VALUE TO (R5)
2489 013544 012701 000007          MOV      #7,R1      ;LIMIT RESPONSE TO 7 CHARS
2490 013550 012702 177777          MOV      #177777,R2 ;BETWEEN 0 AND 177777
2491 013554 012703 000000          MOV      #0,R3
2492 013560 004737 012372          JSR      PC,TTR     ;GET RESPONSE
2493 013564 004737 013614          JSR      PC,.RESTORE ;RESTORE REGISTERS
2494 013570 000207          RTS      PC         ;RETURN TO CALLER

2495
2496
2497
2498
2499
2500
2501
2502
2503
2504
2505
2506
2507
2508
2509
2510
2511
2512
2513
2514
2515
2516
2517
2518
2519
2520
2521
2522
2523
2524
2525
2526
2527
2528
2529
2530
2531
2532
2533
2534
2535
2536
2537
2538
2539
2540
2541
2542
2543
2544
2545
2546
2547
2548
2549
2550
2551
2552
2553
2554
2555
2556
2557
2558
2559
2560
2561
2562
2563
2564
2565
2566
2567
2568
2569
2570
2571
2572
2573
2574
2575
2576
2577
2578
2579
2580
2581
2582
2583
2584
2585
2586
2587
2588
2589
2590
2591
2592
2593
2594
2595
2596
2597
2598
2599
3000

;: THIS ROUTINE GETS THE NEW VALUE FOR THE SOFTWARE SWITCH REG

;: ROUTINE TO SAVE REGISTERS ON THE STACK
SAVE:  MOV      %5,-(SP)      ;: R5 IS SAVED AT 12(SP)
      MOV      %4,-(SP)      ;: R4 IS SAVED AT 10(SP)
      MOV      %3,-(SP)      ;: R3 IS SAVED AT 6(SP)
      MOV      %2,-(SP)      ;: R2 IS SAVED AT 4(SP)
      MOV      %1,-(SP)      ;: R1 IS SAVED AT 2(SP)
      MOV      %0,-(SP)      ;: R0 IS SAVED AT (SP)
      MOV      14(SP),-(SP)  ;: PUSH RETURN PC ON THE STACK
      RTS      PC           ;: RETURN TO CALLER

;: ROUTINE TO RESTORE REGISTERS SAVED ON THE STACK
RESTORE:MOV      (SP)+,14(SP) ;: STORE RETURN PC ON STACK
      MOV      (SP)+,%0
      MOV      (SP)+,%1
      MOV      (SP)+,%2
      MOV      (SP)+,%3
      MOV      (SP)+,%4
      MOV      (SP)+,%5
      RTS      PC           ;: RETURN
  
```

013636
013644
013652
013660
013756
013674
013702
013710
013716
013717
013724
013732
013740
013746
013753
013760
013766
013774
014002
014010
014016
014024
014032
014036
014042
014050
014054
014062
014070
014072
014100
014106
014114
014122
014130
014136
014140
014146
014154
014162
014166
014172
014174
014202
014203
014210
014216
014220
014226
014234
014236
014244
014246

022445
052055
047503
020114
020103
050040
044511
052132
051
045
051523
040524
020123
052117
045
036040
047524
041513
051040
041516
041536
042322
021524
043
050130
020124
021504
041522
042126
042440
050130
047117
052123
042526
040505
052116
050040
051101
044522
047117
020123
040520
043
054105
052120
053103
020104
051115
020123
021460
046445
030440
020122
044502
026465
042524
035122
020103
044502

```
;MESSAGE TABLE*****
MSG1: .ASCII/%:TM03-TE16 CONTROL LOGIC TEST PART II (DZTEB-A)/

.ASCII /%***ASSURE TAPE IS AT BOT***/
1

.ASCII /%TYPE <CR> TO TERMINATE RESPONSE & ^C TO RESTART%/

MSG6: .ASCII /EXPT-NOT RECVD#/

MSG7: .ASCII /RCVD-NOT EXPT#/

MSG9: .ASCII /%NON-EXIST SLAVE #/

MSG10: .ASCII /%READ CONT BUS PAR #/

MSG11: .ASCII /%WRITE CONT BUS PAR #/

MSG12: .ASCII / EXPT #/

MSG13: .ASCII / RCVD #/

MSG14: .ASCII /%MR BITS 4-0#/

MSG15: .ASCII /%MR BITS 15-7#/

MSG16: .ASCII /%ITER: #/

MSG18: .ASCII /%TC BITS 12-0 #/
```

2571	014254	051524	030440	026462	
2572	014255	020060	043		
2573	014255	045	041506	041040	MSG19: .ASCII /*FC BITS 15-0 */
2574	014272	052111	020123	032461	
2575	014300	030055	021440		MSG40: .ASCII / ? */
2576	014304	037440	021440		MSG41: .ASCII /*END OF PASS */
2577	014310	022445	047105	020104	
2578	014316	043117	050040	051501	
2579	014324	020123	043		
2580	014327	045	042522	044507	MSG44: .ASCII /*REGISTER START: */
2581	014334	052123	051105	051440	
2582	014342	040524	052122	020072	
2583	014350	043			
2584	014351	045	042526	052103	MSG45: .ASCII /*VECTOR ADDRESS: */
2585	014356	051117	040440	042104	
2586	014364	042522	051523	020072	
2587	014372	043			
2588	014373	045	046524	031460	MSG57: .ASCII /*TMD3 DRIVE: */
2589	014400	042040	044522	042526	
2590	014406	020072	043		
2591	014411	045	042524	033061	MSG58: .ASCII /*TE16 SLAVE: */
2592	014416	051440	040514	042526	
2593	014424	020072	043		
2594	014427	045	043		MSG59: .ASCII /* */
2595	014431	134	043		MSG60: .ASCII /\ */
2596	014433	045	042522	047515	MSG62: .ASCII /*REMOVE TMDP FROM SLAVE TO BE TESTED*/
2597	014440	042526	052040	042115	
2598	014446	020120	051106	046517	
2599	014454	051440	040514	042526	
2570	014462	052040	020117	042502	
2571	014470	052040	051505	042524	
2572	014476	022504	043		
2573	014501	045	040510	042122	MSG63: .ASCII /*HARDWARE SWR IN USE*/
2574	014506	040527	042522	051440	
2575	014514	051127	044440	020116	
2576	014522	051525	022505	043	

;TEST HEADER*****

2577					
2578					
2579	014527	045	046045	043517	MSLT1: .ASCII /%%LOGIC TEST 1: WRAP 3,NRZ,NORMAL,000#/ 014534 041511 052040 051505
2580	014542	020124	035061	053440	
2581	014550	040522	020120	026063	
2582	014556	051116	026132	047516	
2583	014564	046522	046101	047454	
2584	014572	042104	043		
2585	014575	045	046045	043517	MSLT2: .ASCII /%%LOGIC TEST 2: WRAP 3,PE,NORMAL,000#/ 014602 041511 052040 051505
2586	014610	020124	035062	053440	
2587	014616	040522	020120	026063	
2588	014624	041511	047054	051117	
2589	014632	040515	026114	042117	
2590	014640	021504			
2591	014642	032445	047514	044507	MSLT3: .ASCII /%%LOGIC TEST 3: WRAP 2,NRZ,NORMAL,000#/ 014650 020103 042524 052123
2592	014650	020103	042524	052123	
2593	014656	031440	020072	051127	
2594	014664	050101	031040	047054	
2595	014672	055122	047054	051117	
2596	014700	040515	026114	042117	
2597	014706	021504			
2598	014710	022445	047514	044507	MSLT4: .ASCII /%%LOGIC TEST 4: WRAP 2,PE,NORMAL,000#/ 014716 020103 042524 052123
2599	014716	020103	042524	052123	
2600	014724	032040	020072	051127	
2601	014732	050101	031040	050054	
2602	014740	026105	047516	046522	
2603	014746	046101	047454	042104	
2604	014754	043			
2605	014755	045	046045	043517	MSLT5: .ASCII /%%LOGIC TEST 5: WRAP 1,NRZ,NORMAL,000#/ 014762 041511 052040 051505
2606	014762	041511	052040	051505	
2607	014770	020124	035065	053440	
2608	014776	040522	020120	026061	
2609	015004	051116	026132	047516	
2610	015012	046522	046101	047454	
2611	015020	042104	043		
2612	015023	045	046045	043517	MSLT6: .ASCII /%%LOGIC TEST 6: WRAP 1,PE,NORMAL,000#/ 015030 041511 052040 051505
2613	015030	041511	052040	051505	
2614	015036	020124	035066	053440	
2615	015044	040522	020120	026061	
2616	015052	042520	047054	051117	
2617	015060	040515	026114	042117	
2618	015066	021504			
2619	015070	022445	047514	044507	MSLT7: .ASCII /%%LOGIC TEST 7: WRAP 0,NRZ,NORMAL,000#/ 015076 020103 042524 052123
2620	015076	020103	042524	052123	
2621	015104	030440	020072	051127	
2622	015112	050101	030040	047054	
2623	015120	055122	047054	051117	
2624	015126	040515	026114	042117	
2625	015134	021504			
2626	015136	022445	047514	044507	MSLT10: .ASCII /%%LOGIC TEST 10: WRAP 0,PE,NORMAL,000#/ 015144 020103 042524 052123
2627	015136	022445	047514	044507	
2628	015144	020103	042524	052123	
2629	015152	030440	035060	053440	
2630	015160	040522	020120	026060	
2631	015166	042520	047054	051117	
2632	015166	042520	047054	051117	

2633	015174	040515	026114	042117
2634	015174	021504		
2635	015204	022445	047514	044507
2636	015212	020103	042524	052123
2637	015220	030440	035061	041440
2638	015228	051117	020105	052504
2639	015234	050115	053440	044522
2640	015242	042524	024040	034115
2641	015250	030071	024466	043
2642	015258	045	046045	043517
2643	015266	041511	052040	051505
2644	015274	020124	031061	020072
2645	015282	047503	042522	042040
2646	015304	046525	020120	042522
2647	015312	042101	024040	034115
2648	015320	030071	024466	043
2649	015328	045	046045	043517
2650	015336	041511	052040	051505
2651	015344	020124	031461	020072
2652	015346	053105	047105	050040
2653	015354	051101	052111	020131
2654	015362	051127	052111	020105
2655	015370	046450	034470	031460
2656	015376	046440	034470	032060
2657	015404	021451		
2658	015406	022445	047514	044507
2659	015414	020103	042524	052123
2660	015422	030440	035064	042440
2661	015430	042526	020116	040520
2662	015436	044522	054524	051040
2663	015444	040505	024104	034115
2664	015452	030071	020063	034115
2665	015460	030071	024464	043
2666	015465	045	046045	043517
2667	015472	041511	052040	051505
2668	015500	020124	032461	020072
2669	015506	042522	042101	051040
2670	015514	053105	051105	042523
2671	015522	046450	034470	033060
2672	015530	021451		
2673	015532	022445	047514	044507
2674	015540	020103	042524	052123
2675	015546	030440	035066	041440
2676	015554	041522	041440	051117
2677	015562	042522	052103	047511
2678	015570	020116	044523	043516
2679	015576	042514	052040	040522
2680	015604	045503	040454	046114
2681	015612	043040	040522	042515
2682	015620	021523		
2683	015622	022445	047514	044507
2684	015630	020103	042524	052123
2685	015636	030440	035067	041440
2686	015644	041522	041440	051117
2687	015652	042522	052103	047511
2688	015660	020116	052515	052114

MSLT11: .ASCII /%%LOGIC TEST 11: CORE DUMP WRITE (M8906)*/

MSLT12: .ASCII /%%LOGIC TEST 12: CORE DUMP READ (M8906)*/

MSLT13: .ASCII /%%LOGIC TEST 13: EVEN PARITY WRITE (M8903 M8904)*/

MSLT14: .ASCII /%%LOGIC TEST 14: EVEN PARITY READ(M8903 M8904)*/

MSLT15: .ASCII /%%LOGIC TEST 15: READ REVERSE(M8906)*/

MSLT16: .ASCII /%%LOGIC TEST 16: CRC CORRECTION SINGLE TRACK, ALL FRAMES*/

MSLT17: .ASCII /%%LOGIC TEST 17: CRC CORRECTION MULTIPLE BAD TRACKS*/

2689	015666	050111	042514	041040
2690	015674	042101	052040	040522
2691	015702	045503	021523	
2692	015706	022445	047514	044507
2693	015714	020103	042524	052123
2694	015722	031040	035060	051040
2695	015730	040505	020104	042522
2696	015736	042526	051522	026105
2697	015744	051116	026132	051127
2698	015752	050101	031440	043

MSLT20: .ASCII /%LOGIC TEST 20: READ REVERSE, NRZ, WRAP 3# /

```

2699
2700 ;TAG MESSAGE
2701
2702 015757 045 053523 020122 SMSMR: .ASCII /%SMR = #/
2703 015764 020075 043
2704 015767 040 042516 020127 SMNEW: .ASCII / NEW = #/
2705 015774 020075 043
2706
2707 016000 ;EVEN
2708 ;WRITE BUFFER
2709
2710 016000 000100 WDATA:
2711 016000 177777 -1
2712 016002 177777 -1
2713 016004 177777 -1
2714 016006 177777 -1
2715 016010 177777 -1
2716 016012 177777 -1
2717 016014 177777 -1
2718 016016 177777 -1
2719 016020 177777 -1
2720 016022 177777 -1
2721 016024 177777 -1
2722 016026 177777 -1
2723 016030 177777 -1
2724 016032 177777 -1
2725 016034 177777 -1
2726 016036 177777 -1
2727 016040 177777 -1
2728 016042 177777 -1
2729 016044 177777 -1
2730 016046 177777 -1
2731 016050 177777 -1
2732 016052 177777 -1
2733 016054 177777 -1
2734 016056 177777 -1
2735 016060 177777 -1
2736 016062 177777 -1
2737 016064 177777 -1
2738 016066 177777 -1
2739 016070 177777 -1
2740 016072 177777 -1
2741 016074 177777 -1
2742 016076 177777 -1
2743 016100 177777 -1
2744 016102 177777 -1
2745 016104 177777 -1
2746 016106 177777 -1
2747 016110 177777 -1
2748 016112 177777 -1
2749 016114 177777 -1
2750 016116 177777 -1
2751 016120 177777 -1
2752 016122 177777 -1
2753 016124 177777 -1
2754 016126 177777 -1

```

2755	016130	177777	-1
2756	016132	177777	-1
2757	016134	177777	-1
2758	016136	177777	-1
2759	016140	177777	-1
2760	016142	177777	-1
2761	016144	177777	-1
2762	016146	177777	-1
2763	016150	177777	-1
2764	016152	177777	-1
2765	016154	177777	-1
2766	016156	177777	-1
2767	016160	177777	-1
2768	016162	177777	-1
2769	016164	177777	-1
2770	016166	177777	-1
2771	016170	177777	-1
2772	016172	177777	-1
2773	016174	177777	-1
2774	016176	177777	-1

2775			
2776			
2777			
2778			

;READ BUFFER

RDATA:

2779	016200	000100	0
2780	016200	000000	0
2781	016202	000000	0
2782	016204	000000	0
2783	016206	000000	0
2784	016210	000000	0
2785	016212	000000	0
2786	016214	000000	0
2787	016216	000000	0
2788	016220	000000	0
2789	016222	000000	0
2790	016224	000000	0
2791	016226	000000	0
2792	016230	000000	0
2793	016232	000000	0
2794	016234	000000	0
2795	016236	000000	0
2796	016240	000000	0
2797	016242	000000	0
2798	016244	000000	0
2799	016246	000000	0
2800	016250	000000	0
2801	016252	000000	0
2802	016254	000000	0
2803	016256	000000	0
2804	016260	000000	0
2805	016262	000000	0
2806	016264	000000	0
2807	016266	000000	0
2808	016270	000000	0
2809	016272	000000	0
2810	016274	000000	0

ADDFL	000746	DCKE2	010236	EXSC	006330	MSG10	014114	PATRN	001002
AS	000526	DCKE3	010246	EXSC0	006374	MSG11	014140	PCNTR	001016
ASF	000730	DCKE4	010270	EXSC1	006400	MSG12	014165	P00	010676
ATAF	000720	DCKE5	010302	EXS0	006404	MSG13	014174	P01	010712
BA	000514	DCKE6	010340	FC	000516	MSG14	014203	P02	010754
CC	000530	DCKE7	010376	FUN	000752	MSG15	014220	P03	010760
CHNFLG	001262	DERFL	000766	GTSWR	013474	MSG16	014236	P04	010770
CRCDAT	004304	DOUT	013270	HDRFL	000620	MSG18	014246	P05	011110
CRCFLG	001022	DOUTD	013346	HERE	002320	MSG19	014265	P06	011134
CRCNT	000774	DRVN	000624	ILFT	000544	MSG40	014304	PEXFL	000736
CRCPAT	004302	DRVTP	000604	INIT	012064	MSG41	014310	PFLG	000666
CS	000520	DS	000522	ITANT	000606	MSG44	014327	POST	017154
C1	000510	DSUP	004742	ITCNT	000702	MSG45	014351	PPGEN	011512
DATAD	000760	DS0	005040	ITER	012014	MSG57	014373	PRCHK	010660
DATAD	001034	DS3	005056	ITRLP	000714	MSG58	014411	PRE	017032
DAT1	001036	DS4	005066	LTA00	000742	MSG59	014427	PREFL	000770
DAT2	001040	DT	000536	LT1	002352	MSG6	014035	PSCHK	010624
DAT3	001042	EMADDR	000622	LT1A	002416	MSG60	014431	PSW	000566
DATBL	001034	ENDFLG	001024	LT1B	002430	MSG62	014433	RBUFF	017710
DATC	000754	EORP	011570	LT10	003210	MSG63	014501	RCOP	001010
DAT1	005076	EORPA	011564	LT10A	003212	MSG7	014054	ROAD	000762
DAT1A	005102	EORPX	011754	LT11	003262	MSG9	014072	RDATA	016200
DAT2	005116	EORP1	011624	LT11A	003340	MSLT1	014527	RDRVF	001006
DAT3	005122	EORP1A	011672	LT11X	003364	MSLT10	015136	REGS	000612
DAT4	005130	EORP2	011712	LT12	003374	MSLT11	015204	RTRN	000670
DB	000532	EORP3	011736	LT12A	003460	MSLT12	015255	SAV1	000704
DCHK	007274	ER	000524	LT12X	003512	MSLT13	015325	SAV2	000706
DCHKA	007372	ERADD	000672	LT13	003522	MSLT14	015406	SAV3	000710
DCHKAD	007346	ERRF	000726	LT14	003572	MSLT15	015465	SCF	000732
DCHKAI	007422	EXEC	006010	LT15	003642	MSLT16	015532	SCOLP	000712
DCHKAR	007460	EXFL	000716	LT16	003724	MSLT17	015622	SCOPE	011764
DCHKB	007532	EXW2	006416	LT16A	003752	MSLT2	014575	SERFL	000772
DCHKBO	007542	EXW2A	006446	LT17	004312	MSLT20	015706	SERNUM	000602
DCHKC	007602	EXW2B	006502	LT17A	004342	MSLT3	014642	SETUP	005430
DCHKD	007610	EXW2C	006516	LT2	002464	MSLT4	014710	SET0	005472
DCKE	010156	EXW2E	006536	LT2A	002466	MSLT5	014755	SET1	005476
DCHKFL	001020	EXW2F	006544	LT20	004624	MSLT6	015023	SET1A	005502
DCHKX	010116	EXW2G	006574	LT20A	004702	MSLT7	015070	SET2	005526
DCHKX1	010134	EXW2H	006604	LT3	002536	MTINT	012240	SKAT	001014
DCHK0	007612	EXW2J	006620	LT3A	002602	NRZOF	000662	SLAF	000722
DCHK1	007644	EXW2JO	006640	LT3B	002614	NXTDRV	001760	SLVN	000664
DCHK1A	007702	EXW2J1	006642	LT4	002644	NXTSLV	002032	SN	000540
DCHK2	007772	EXW2K	006662	LT4A	002646	OCTP	013042	SNPG	013450
DCHK2A	010036	EXW2X	006700	LT5	002716	OCTPE	013032	SNPT	013372
DCHK2B	010040	EX0	006032	LT5A	002762	OCTPE1	013046	SPO	005604
DCHK3	010066	EX1	006056	LT5B	002774	OCTPG	013224	SPO1	005572
DCKEP	010564	EX1A	006072	LT6	003024	OCTPG0	013242	SPI	005610
DCKEPO	010616	EX2	006112	LT6A	003026	OCTPG1	013246	SPIA	005662
DCKED	010216	EX3	006136	LT7	003102	OCTPO	013070	SPIB	005702
DCKE1	010226	EX5	006166	LT7A	003146	OCTP1	013112	SP3	005754
DCKE10	010510	EX5A	006172	LT7B	003160	OCTP2	013120	SP4	005774
DCKE11	010550	EX5A1	006226	MR	000534	OCTP3	013210	SP5	006006
DCKE12	010560	EX5B	006262	MSG1	013636	OFL	013266	SSCF	000724

START	001200	TR00	000626	VECT	000610	WMSG25	016660	WSTX	007272
STATC	001012	TR01	000630	WAM	000750	WMSG26	016675	WTAO	000756
STATF	001004	TR02	000632	WAM0	005136	WMSG27	016714	W10CHK	011160
STFLG	000740	TR03	000634	WAM01	005144	WMSG28	016727	W100	011210
STFLGS	000614	TR04	000636	WAM1	005202	WMSG29	016745	W100A	011226
STSCO	002210	TR05	000640	WAM2	005212	WMSG3	016416	W101	011234
ST2	001670	TR06	000642	WAM2A	005246	WMSG31	016764	W102	011312
SWR	000570	TR07	000644	WAM3	005256	WMSG32	017021	W102A	011364
SWREG	000176	TR10	000646	WAM3A	005336	WMSG4	016437	W103	011454
TAOX	001174	TR11	000650	WAM3B	005354	WMSG6	016464	W104	011466
TC	000542	TR12	000652	WAM4	005364	WMSG6A	016472	W104A	011476
TEMP1	000674	TR13	000654	WBUFF	017276	WMSG6B	016477	W105	011502
TEMP2	000676	TR14	000656	WC	000512	WMSG6C	016504	W2FLG	000764
TEMP3	000700	TR15	000660	WCDP0	001056	WMSG6D	016511	XORDAT	004306
TEND	002244	TSC0	001714	WCDP2	001044	WMSG6E	016517	XORPAT	004310
TENDX	002342	TSC0A	002110	WCS1	001024	WMSG6F	016524	SOONE	002252
TEX	013030	TSC00	002116	WCS2	001026	WMSG6G	016531	SENDAD	002310
TIB	000616	TSC01	002124	WDATA	016000	WMSG6H	016536	SHNEW	015767
TINER	012632	TSC02	002152	WOS	001030	WMSG6I	016543	SHSWR	015757
TKB	000574	TSC03	002170	WER	001032	WMSG6J	016550	SSVPC =	000764
TKS	000572	TSTIBL	001070	WMSG16	016574	WMSG6K	016555	. =	017712
TLAST	001176	TTIN	012652	WMSG17	016606	WMSG6L	016562	.RESTO	013614
T08	000614	TTINT	012250	WMSG2	016400	WMSG6M	016567	.SAVE	013572
TOG	013014	TTOUT	012714	WMSG20	016613	WPGFL	001000		
TPB	000600	TTR	012372	WMSG21	016620	WSTCK	006704		
TPS	000576	T24FL	000744	WMSG23	016626	WSTG	007150		
TREF	000734	UDES	000776	WMSG24	016642	WSTGO	007220		

. ABS. 017712 000

ERRORS DETECTED: 0
 DEFAULT GLOBALS GENERATED: 0

DZTEBA,DZTEBA/SOL+DZTEBA.P11
 RUN-TIME: 3 5 .4 SECONDS
 RUN-TIME RATIO: 33/9=3.6
 CORE USED: 6K (11 PAGES)