ISDM™ SYSTEM DEBUG MONITOR


 Supports Target System Debugging for iSBC® 8086, 8088, 80186, 80188, 80286 and 80386 Based Applications

int

- Provides Interactive Debugging Commands Including Single-Step Code Execution and Symbolic Displays of Results
- Supports 8087 Numeric Processor Extension (NPX) for High-Speed Math Applications
- Allows Building of Custom Commands Through the Command Extension Interface (CEI)

- Supports Application Access to ISIS-II Files
- Provides Program Load Capability from an Intellec[®] Development System and from iSBC 8086, 8088, 80186, 80188, 80286 and 80836 iRMX[®] 86 and 286 Development System
- Contains Configuration Facilities which Allow an Applications Bootstrap from iRMX[®] File Compatible Peripherals
- Modular to Allow Use from an Intellec[®] Development System, from a Stand-Alone Terminal or from iRMX 86 or iRMX 286 Based Systems

The Intel iSDM™ System Debug Monitor package contains the necessary hardware, software, cables, EPROMs and documentation required to interface, through a serial or parallel connection, an iSBC 86/05, 86/12A, 86/14, 86/30, 88/25, 88/40, 88/45, 186/03, 186/51, 188/48, 286/10, 286/10A, 286/12, 386/2X, or 8086, 8088, 80186 or 80188, 80286 and 80386 target system to an MDS 800, Series II, Series III, or Series IV Intellec® Microcomputer Development System or iRMX 86 or 286 Based System for execution and interactive debugging of applications software on the target system. The Monitor can: load programs into the target system; execute the programs instruction by instruction or at full speed; set breakpoints; and examine/modify CPU registers, memory content, and other crucial environmental details. Additional custom commands can be built using the Command Extension Interface (CEI). The Monitor supports the OEM's choice of the iRMX 86 Operating System, the iRMX 88 Real-Time Multi-Tasking Executive or a custom system for the target application system or have full access to the ISIS-II files of the Intellec System or the iRMX file system.



230882-1

2-1

FUNCTIONAL DESCRIPTION

Overview

The iSDM Monitor extends the software development capabilities of the Intellec system so the user can effectively develop applications to ensure timely product availability.

The iSDM package consists of four parts:

- The loader program
- The iSDM Monitor
- The Command Extension Interface (CEI)
- The ISIS-II Interface

The user can use the iSDM package to load programs into the target system from the development system, execute programs in an instruction-by-instruction manner, and add custom commands through the command extension interface. The user also has the option of using just the iSDM Monitor and the CEI in a stand-alone application, without the use of a development system.

Powerful Debugging Commands

The iSDM Monitor contains a powerful set of commands to support the debugging process. Some of the features included are: bootstrap of application software; selective execution of program modules based on breakpoints or single stepping requests; examination, modification and movement of memory contents; examination and modification of CPU registers, including NPX registers. All results are displayed in clearly understandable formats. Refer to Table 1 for a more detailed list of the iSDM monitor commands.

Numeric Data Processor Support

Arithmetic applications utilizing the 8087 or 80287 Numeric Processor Extension (NPX) are fully supported by the iSDM Monitor. In addition to executing applications with the full NPX performance, users may examine and modify the NPX's registers using decimal and real number format.

This feature allows the user to feel confident that correct and meaningful numbers are entered for the application without having to encode and decode complex real, integer, and BCD hexadecimal formats.

Command Extension Interface (CEI)

The Command Extension Interface (CEI) allows the addition of custom commands to the iSDM Monitor commands. The CEI consists of various procedures that can be used to generate custom commands. Up to three custom commands (or sets of commands) can be added to the monitor without programming new EPROMs or changing the monitor's source code.

Command	Function	
B	Bootstrap application program from target system peripheral device	
С	Compare two memory blocks	
D	Display contents of memory block	
E*	Exit from loader program to ISIS-II Interface	
F	Find specified constant in a memory block	
G	Execute application program	
1 State of the second secon	Input and display data obtained from input port	
L*	Load absolute object file into target system memory	
M	Move contents of memory block to another location	
N	Display and execute single instruction	
O	Output data to output port	
P	Print values of literals	
R*	Load and execute absolute object file in target system memory	
S	Display and (optionally) modify contents of memory	
T*	Transfer block of memory to file	
U, V, W	User defined custom commands extensions	
X	Examine and (optionally) modify CPU and NPX registers	

Table 1. Monitor Commands

*Commands require an attached development system.

ISIS-II Interface

The ISIS-II interface consists of libraries which contain interfaces to ISIS-II I/O calls. A program running on an 8086, 8088, 80186, or 80188-based system can use the ISIS-II interface and access the individual ISIS-II I/O calls. The interface allows the inclusion of these calls into the program; however, most of the calls require a Series II/Series III system. Table 2 contains a summary of the major I/O calls and parameters.

Program Load Capability

The iSDM loader allows the loading of 8086, 8088, 80186, 80188, 80286 or 80386-based programs into the target system. It executes on a development system and communicates with the target system through a serial or a parallel load interface.

Configuration Facility

The monitor contains a full set of configuration facilities which allows it to be carefully tailored to the requirements of the target system. Pre-configured EPROM-resident monitors are supplied by Intel for the iSBC 86/05A, 86/14, 86/30, 86/35, 88/25, 88/10A, 88/45, 186/03A, 186/51, 188/48, 188/56, 286/10A, 286/12, 286/100, 386/2X, and 386/100 boards. The monitor must be configured by the user for the iSBC 86/12A board and for other 8086, 8088, 80186, or 80188 applications. iRMX 86 and iRMX 286 system users may use the configuration facilities to include the Bootstrap Loader (V5.0 or newer) in the monitor.

Variety of Connections Available

The physical interface between the development system and the target system can be established in one of three ways. The systems can be connected via a serial link, a parallel link or a fast parallel link. The cabling arrangement is different depending upon the development system being used.

The iSDM Monitor does not require the use of a development system. The monitor can be used by simply attaching a stand-alone terminal to the target system.

Routine	Target System Function	
ATTRIB	Changes to ISIS-II file attribute	
CI	Returns a character input from the console	
CO	Transfers a character for console output	
CLOSE	Closes an opened file	
DELETE	Deletes the specified file	
DQ\$CFG	Returns information about monitor's communication link and type	
ERROR	Displays an error message on the console	
EXIT	Exits to the target system monitor	
LOAD	Loads target system memory with object code file	
OPEN	Opens a file for access	
READ	Reads up to 4096 bytes from a file to memory	
RENAME	Renames a disk file	
SEEK	Seeks to the specified file location	
WRITE	Writes up to 4096 bytes from memory to a file	

Table 2. Routines for Services Available to Target System Applications

intel

SPECIFICATIONS

Hardware

- Supported iSBC Microcomputers: iSBC 86/05 Single Board Computer **iSBC 86/12A** Single Board Computer iSBC 86/14 Single Board Computer iSBC 86/30 Single Board Computer iSBC 88/25 Single Board Computer iSBC 88/40 Single Board Computer iSBC 88/45 Single Board Computer iSBC 186/30 Single Board Computer iSBC 186/51 Single Board Computer iSBC 188/48 Single Board Computer iSBC 186/56 Single Board Computer iSBC 86/35 Single Board Computer iSBC 88/40A Single Board Computer iSBC 816/03A Single Board Computer iSBC 286/10A Single Board Computer iSBC 286/12 Single Board Computer / iSBC 286/100 Single Board Computer iSBC 386/2X Single Board Computer iSBC 386/100 Single Board Computer
- Supported iSBX MULTIMODULE Boards: iSBX 350 Parallel I/O MULTIMODULE Board iSBX 351 Serial I/O MULTIMODULE Board

iSDM™ 86 Package Contents

Cables:

1—Parallel I/O Cable (upload/download) 4—RS232 Cable Assemblies Hardware package for the cable assemblies

Interface and Execution Software Diskettes:

2-SSIDD, ISIS 11-Format 8"

2—DSIDD, iRMX-Format 51/4"

2-SSIDD, iRMX-Format 8"

System Monitor EPROMs:

Intel Board	EPROM Description
iSBC 86/05A iSBC 86/14 iSBC 86/30 iSBC 86/35	Two 27128 EPROMs
iSBC 86/12A*	SUBMIT Files on the Release Diskette

System Monitor EPROMs: (Continued)

EPROM Description
Two 27128 EPROMs
Two 27256 EPROMs
Two 27256 EPROMs

Reference Manual (Supplied):

iSDM System Debug Monitor Installation and Configuration

iSDM System Debug Monitor User's Guide

ORDERING INFORMATION

Part Number Description

iSDM RO Object Software

Intellec to target system interface and target system monitor, suitable for use on iSBC 86, 88, 186, 188, 286, 386 computers, or other iAPX 86, 88, 186, 188, 286, 386 microcomputers. Package includes cables, EPROMs, software and reference manual.

The OEM license option listed here allows users to incorporate iSDM into their applications. Each use requires payment of an Incorporation Fee.

The iSDM package also includes 90 days of support services that include Software Program Report Services.

As with all Intel Software, purchase of any of these options requires execution of a standard Intel Software License Agreement.