
Z-29 Terminal

ROM Source Listing

This binder contains the source listing of the code in your
Z-29 Terminal ROM.

595-3053
Copyright 1983
Zenith Data Systems Corporation
All Rights Reserved
First Printing
Printed in the
United States of America

 **data
systems**

```
1          ;;;          Z-29 Terminal Firmware Version 1.03
2          ;
3          ;
4          ;          Written by R. Nick K. Boland   February 10, 1983
5          ;
6          ;          Copyright (C) 1983
7          ;          Zenith Data Systems
8          ;          Saint Joseph, Michigan
9          ;
10         ;
11         ;          Initial consultation by Tom Bles
12         ;          Initial hardware by Michael Gorbutt
13         ;          Hardware finished by Anthony M. Olson
14         ;
15         ;
16         ;          Many things have been used to compact the program. Look
17         ;          for these situations. The most common are where subroutines
18         ;          use parts of other subroutines. Other instances are where
19         ;          a single LJMP could be used and many AJMP's used to reference
20         ;          the long jump.
21         ;
22         ;
23         ;          ENABL  LC
24         ;          NLIST  TOC
25         ;          NAME   Z29ROM
26         ;          SBTTL  *** Z-29 Computer Terminal Firmware Version 1.03 ***
```

```
1          ; ASCII character equivalences
2          ;
3          0000      NULL      EQU      00000000B      ; Null
4          0007      BELL      EQU      00001111B      ; Bell
5          0008      BS       EQU      00001000B      ; Backspace
6          0009      HT       EQU      00001001B      ; Horizontal tab
7          000A      LF       EQU      00001010B      ; Line feed
8          000D      CR       EQU      00001101B      ; Carriage return
9          0011      XON      EQU      00010001B      ; DC1 (XON)
10         0013      XOFF     EQU      00010011B      ; DC3 (XOFF)
11         0018      CAN      EQU      00011000B      ; Cancel
12         001B      ESC      EQU      00011011B      ; Escape
13         007F      RUBOUT   EQU      01111111B      ; Rubout / delete
14
15         ;
16         ; Constants
17         ;
18         0018      MAXLINE  EQU      24             ; Max number of lines is 0..24
19         0019      NUMLINES EQU      25             ; Number of lines is 1..25
20         004F      MAXCHAR  EQU      79             ; Max number of chars/line 0..79
21         0050      NUMCHARS EQU      80             ; Number of characters is 1..80
22
23         ;
24         ;
25         ;: 8051 processor constants
26         ;
27         0000      BANK0    EQU      00000000B      ; Select register bank 0
28         0008      BANK1    EQU      00001000B      ; Bank 1
29         0023      ITMOD    EQU      00100011B      ; Init value for -TMOD-
30         005A      ISCON    EQU      01011010B      ; Init value for -SCON-
31         0003      IPINIT   EQU      00000011B      ; Init value for interrupt priorities
32         0095      IEINIT   EQU      10010101B      ; Init value for interrupts
33         0082      IEDMA    EQU      10000010B      ; Init value for interrupts during DMA
```

```

1          ;;          Keyboard data
2          ;
3          ;          Data from the keyboard other than ASCII data is in the format
4          ;          of 'iscXXXXXB' where 's' = shift status, 'c' = control status and
5          ;          the rest of the word defines the function. Exceptions to this
6          ;          are the access function, power up function and ID number.
7          ;
8          ;          0aaaaaaaaB          ASCII data to be transmitted
9          ;
10         0040          KB_SHFT          EQU          01000000B          ; Keyboard shift mask
11         0020          KB_CNTR          EQU          00100000B          ; Keyboard control mask
12
13
14         0080          KB_UP            EQU          10000000B          ; UP arrow key
15         0081          KB_DOWN          EQU          10000001B          ; Down arrow key
16         0082          KB_LEFT          EQU          10000010B          ; Left arrow key
17         0083          KB_RIGHT          EQU          10000011B          ; Right arrow key
18         0084          KB_HOME          EQU          10000100B          ; Home key
19         0085          KB_ERASE          EQU          10000101B          ; Erase key
20         0086          KB_HELP          EQU          10000110B          ; Help key
21         0087          KB_SCROLL          EQU          10000111B          ; Scroll key
22         0088          KB_SETUP          EQU          10001000B          ; Setup key
23         0089          KB_BREAK          EQU          10001001B          ; Break key
24         008A          KB_CAPS          EQU          10001010B          ; Caps lock key
25         008B          KB_TAB           EQU          10001011B          ; Tab key
26         008C          KB_SPACE          EQU          10001100B          ; Space bar
27
28         008F          KB_POWER          EQU          10001111B          ; Keyboard Just powered up
29
30         0090          KB_0             EQU          10010000B          ; Numeric keypad 0 key
31         0091          KB_1             EQU          10010001B          ; Numeric keypad 1 key
32         0092          KB_2             EQU          10010010B          ; Numeric keypad 2 key
33         0093          KB_3             EQU          10010011B          ; Numeric keypad 3 key
34         0094          KB_4             EQU          10010100B          ; Numeric keypad 4 key
35         0095          KB_5             EQU          10010101B          ; Numeric keypad 5 key
36         0096          KB_6             EQU          10010110B          ; Numeric keypad 6 key
37         0097          KB_7             EQU          10010111B          ; Numeric keypad 7 key
38         0098          KB_8             EQU          10011000B          ; Numeric keypad 8 key
39         0099          KB_9             EQU          10011001B          ; Numeric keypad 9 key
40         009A          KB_DEC           EQU          10011010B          ; Numeric keypad decimal point key
41         009B          KB_ENT           EQU          10011011B          ; Numeric keypad enter key
42         009C          KB_DASH          EQU          10011100B          ; Numeric keypad dash key
43         009D          KB_COMMA          EQU          10011101B          ; Numeric keypad comma key

```

```

1.          ;          Access code and keys that follow
2.          ;
3.          ;          The access code from the keyboard is very much like an escape
4.          ;          character. It indicates that the second character from the
5.          ;          keyboard will be the data with the following definitions.
6.          ;
7.          009F          KB_ACC          EQU          10011111B          ; Access code
8.
9.          0080          KB_F1          EQU          10000000B          ; Function key #1
10         0081          KB_F2          EQU          10000001B          ; Function key #2
11         0082          KB_F3          EQU          10000010B          ; Function key #3
12         0083          KB_F4          EQU          10000011B          ; Function key #4
13         0084          KB_F5          EQU          10000100B          ; Function key #5
14         0085          KB_F6          EQU          10000101B          ; Function key #6
15         0086          KB_F7          EQU          10000110B          ; Function key #7
16         0087          KB_F8          EQU          10000111B          ; Function key #8
17         0088          KB_F9          EQU          10001000B          ; Function key #9
18
19         0098          KB_ID          EQU          10011000B          ; ID number 10011xxxB
20
21
22
23
24         ;;          Keyboard commands
25         ;
26         ;          These are commands that are sent from the terminal to the
27         ;          keyboard. They tell the keyboard to enter and exit different
28         ;          modes and to perform different functions.
29         ;
30         0080          KBC_ID          EQU          10000000B          ; Send keyboard ID number
31         0081          KBC_BELL          EQU          10000001B          ; Ring bell
32         0082          KBC_LEC          EQU          10000010B          ; Enable key click
33         0083          KBC_DC          EQU          10000011B          ; Disable key click
34         0084          KBC_EL          EQU          10000100B          ; Enter caps locked
35         0085          KBC_XL          EQU          10000101B          ; Exit caps locked
36         0086          KBC_LER          EQU          10000110B          ; Enable auto repeat mode
37         0087          KBC_DR          EQU          10000111B          ; Disable auto repeat mode
38         0088          KBC_DK          EQU          10001000B          ; Disable keyboard
39         0089          KBC_EK          EQU          10001001B          ; Enable keyboard
40         008A          KBC_OFFLN          EQU          10001010B          ; Turn on offline LED
41         008B          KBC_ONLN          EQU          10001011B          ; Turn off offline LED

```


*** Z-29 COMPUTER TERMINAL FIRMWARE VERSION 1.03 ***

```

1          ;:          External memory address map
2          ;
3          2000      DDATREG      EQU      8*1024      ; 8275 data register
4          2001      DCMDBREG     EQU      8*1024 + 1   ; 8275 command register
5          2001      DSTAREG      EQU      8*1024 + 1   ; 8275 status register
6
7          3000      MLATCH        EQU      12*1024     ; Memory latch
8
9          4000      ATRIBMEM      EQU      16*1024     ; Attribute memory
10
11         5000      CHARMEM       EQU      20*1024     ; Character memory
12         5780      L25MEM        EQU      20*1024 + 1920 ; Line 25 memory
13
14         57D0      IBUF          EQU      20*1024 + 2000 ; Input buffer 32 bytes
15         0009      ILO           EQU      ?           ; Input queue lo water mark
16         0015      IHI           EQU      21         ; Input queue hi water mark
17         0020      ILEN          EQU      32         ; Input queue length
18
19         57F0      OBUF          EQU      20*1024 + 2032 ; Output buffer 8 bytes
20         57F7      OLEN          EQU      OBUF + 7     ; Output queue length
21
22         57F8      PMBUF         EQU      20*1024 + 2040 ; ANSI parameter buffer 8 bytes
23
24         6000      DMAMEM        EQU      24*1024     ; DMA memory
25
26         7000      EAROM         EQU      28*1024     ; EAROM memory
27
28
29         ;          External memory constants
30         ;
31         00EF      ATRANL        EQU      11101111B   ; Mask -CHARMEM- to -ATRIEMEM-
32         00CF      DMAANL        EQU      11001111B   ; Mask -DMAMEM- to -ATRIEMEM-
33         0010      CHRORL        EQU      00010000B   ; Mask -ATRIEMEM- to -CHARMEM-
34         0020      DMAORL        EQU      00100000B   ; Mask -ATRIEMEM- to -DMAMEM-

```

```
1          ;;          Internal RAM memory setup
2          ;
3
4
5          ;          Register bank #0 used in background jobs
6          ;
7          REG        PTR1          EQU    R0          ; Work pointer #1          (R0)
8          0000       PTR1A        EQU    00H         ; Address of -PTR1-
9          REG        PTR2          EQU    R1          ; Work pointer #2          (R1)
10         0001       PTR2A        EQU    01H         ; Address of -PTR2-
11         REG        INDX1         EQU    R2          ; Index register 1        (R2)
12         0002       INDX1A       EQU    02H         ; Address of -INDX1-
13         REG        INDX2         EQU    R3          ; Index register 2        (R3)
14         0003       INDX2A       EQU    03H         ; Address of -INDX2-
15         REG        WORK         EQU    R4          ; Work register           (R4)
16         0004       WORKA        EQU    04H         ; Address of -WORK-
17         REG        TEMP         EQU    R5          ; Temporary holding register (R5)
18         0005       TEMP        EQU    05H         ; Address of -TEMP-
19         REG        WORK1        EQU    R6          ; Work register 1         (R6)
20         0006       WORK1A       EQU    06H         ; Address of -WORK1-
21         REG        WORK2        EQU    R7          ; Work register 2         (R7)
22         0007       WORK2A       EQU    07H         ; Address of -WORK2-
23
24
25         ;          Register bank #1 used in DMA routine
26         ;
27         REG        DMPTR        EQU    R0          ; Pointer into line order (R0)
28         0008       DMPTRA       EQU    08H         ; Address of -DMPTR-
29         REG        DMLN         EQU    R1          ; Current DMA line number (R1)
30         0009       DMLNA        EQU    09H         ; Address of -DMLN-
```


*** Z-29 COMPUTER TERMINAL FIRMWARE VERSION 1.03 ***

```

1          ;
2          ;          Class that define byte 20H
3          0020      XLATCH      EQU      20H          ; External latch byte
4
5          0000      EAROMSAVE   BIT      00H          ; 0 = save EAROM          1 = normal
6          0001      BLINKF      BIT      01H          ; 0 = blink chars on    1 = blanked
7          0002      PORTF       BIT      02H          ; 0 = main port         1 = auxiliary
8          0003      EAROMRCALL  BIT      03H          ; 0 = recall            1 = normal
9
10         ;
11         ;          Class that define byte 21H
12         ;
13         0021      ATTRIBUTES  EQU      21H          ; Attribute byte
14
15         0008      RVVA        BIT      08H          ; Reverse video attribute
16         0009      UNDLNA      BIT      09H          ; Underline attribute
17         000A      BLINKA      BIT      0AH          ; Blink attribute
18         000B      HALFIA      BIT      0BH          ; Half intensity attribute
19         000C      ALTCHARA    BIT      0CH          ; Alternate character set attribute
20         000D      GRPH       BIT      0DH          ; 0 = no graphics      1 = graphics
21         000E      PROTECT    BIT      0EH          ; 0 = no protected    1 = protected
22         000F      ALTGRPH     BIT      0FH          ; 0 = no alt graphics  1 = alt graphic set
23
24         ;
25         ;          Class that define byte 22H
26         ;
27         0010      XOFFSENT    BIT      10H          ; 0 = no terminal XOFF  1 = term XOFF
28         0011      UXOFFSENT   BIT      11H          ; 0 = no user XOFF     1 = user XOFF
29         0012      GSEL       BIT      12H          ; 0 = G0 selected     1 = G1 selected
30         0013      OKTRANS    BIT      13H          ; 0 = do not transmit  1 = ok to trans
31         0014      DX         BIT      14H          ; 0 = no X-pos change  1 = changes
32         0015      L25EN      BIT      15H          ; 0 = line 25 disabled  1 = 25 enabled
33         0016      XOFFRCVED   BIT      16H          ; 0 = no XOFF received 1 = received
34
35         ;
36         ;          Class that define byte 23H
37         ;
38         0018      PSDF       BIT      18H          ; Indicates if *PSD* has been done once
39         0019      GNPF       BIT      19H          ; Indicates if *GNP* has been done once
40         001A      ENBLCUR    BIT      1AH          ; 0 = cursor disabled  1 = enabled
41         001B      ERM        BIT      1BH          ; 0 = erase all data    1 = only unprotected
42         001C      SHIFTF     BIT      1CH          ; shift data from keyboard
43         001D      CONTLF     BIT      1DH          ; control data from keyboard
44         001E      ACCESSF    BIT      1EH          ; 0 = no access from kb 1 = in progress
45         001F      KBDISF    BIT      1FH          ; 0 = keyboard enabled  1 = disabled
46
47         ;
48         ;          Class that define byte 24H
49         ;
50         0020      CLRFLG     BIT      20H          ; Used in screen DMA must allays be 0!
51         0021      ICMODEF    BIT      21H          ; 0 = not insert char  1 = IC mode on
52         0022      HSSTOPF    BIT      22H          ; 0 = dont hold screen 1 = stop screen
53         0023      PRNTF     BIT      23H          ; 0 = not printing    1 = printing
54         0024      VSPF      BIT      24H          ; 0 = suppress video   1 = normal
55         0025      GATM      BIT      25H          ; 0 = trans all data   1 = only unprotected

```

```

1          ;          ;          ;          ;          ;          ;          ;          ;          ;          ;
2          ;          ;          ;          ;          ;          ;          ;          ;          ;          ;
3          ;          ;          ;          ;          ;          ;          ;          ;          ;          ;
4          0028      PRTYENA      BIT      28H      ; 0 = no parity      1 = ok parity
5          0029      PRTYSTK      BIT      29H      ; 0 = normal parity  1 = stick
6          002A      PRTYEVN      BIT      2AH      ; 0 = odd parity     1 = even parity
7          002B      AUTOWRAP     BIT      2BH      ; 0 = no auto wrap   1 = wrap around
8          002C      AUTOCR      BIT      2CH      ; 0 = no auto CR on LF 1 = auto CR
9          002D      AUTOLF      BIT      2DH      ; 0 = no auto LF on CR 1 = auto LF
10         002E      ONLINE      BIT      2EH      ; 0 = off line      1 = on line
11         002F      FULLDPLX     BIT      2FH      ; 0 = half duplex   1 = full duplex
12
13         ;          ;          ;          ;          ;          ;          ;          ;          ;          ;
14         ;          ;          ;          ;          ;          ;          ;          ;          ;          ;
15         0030      KPADSHTF     BIT      30H      ; 0 = keypad ordinary 1 = shifted
16         0031      KPADALTF     BIT      31H      ; 0 = keypad ordinary 1 = alternate
17         0032      CRUL        BIT      32H      ; 0 = block cursor   1 = underline
18         0033      CLKF        BIT      33H      ; 0 = no key click   1 = click
19         0034      REPF        BIT      34H      ; 0 = no auto repeat 1 = auto repeat
20         0035      CAPLOCKF     BIT      35H      ; 0 = caps unlocked  1 = locked
21         0036      HSMODEF     BIT      36H      ; 0 = not hold screen 1 = hold screen
22         0037      L250N       BIT      37H      ; 0 = status line off 1 = status on
23
24
25         ;          ;          ;          ;          ;          ;          ;          ;          ;          ;
26         ;          ;          ;          ;          ;          ;          ;          ;          ;          ;
27         0038      CRNBK       BIT      38H      ; 0 = blinking cursor 1 = non blink
28         0039      FREQ        BIT      39H      ; 0 = 50 Hz          1 = 60 Hz
29         003A      MONITOR     BIT      3AH      ; 0 = not monitor mode 1 = monitor
30         003B      SCRNSAVE     BIT      3BH      ; 0 = no screen saver 1 = saver on
31         003C      PRPF2       BIT      3CH      ; 0 = main port      1 = auxiliary
32         003D      ACHR2       BIT      3DH      ; 0 = normal char set 1 = alternate
33         003E      HNDSHK      BIT      3EH      ; 0 = software       1 = hardware
34
35
36         ;          ;          ;          ;          ;          ;          ;          ;          ;          ;
37         ;          ;          ;          ;          ;          ;          ;          ;          ;          ;
38         0028      MODE        EQU      28H      ; Mode terminal is in
39
40         0040      ANSI        BIT      40H      ; 0 = other modes    1 = ANSI mode
41         0041      ZDS        BIT      41H      ; 0 = other modes    1 = ZDS mode
42         0042      ADMS       BIT      42H      ; 0 = other modes    1 = ADM 3 mode
43         0043      HAZ        BIT      43H      ; 0 = other modes    1 = Haz 1500
44
45
46         ;          ;          ;          ;          ;          ;          ;          ;          ;          ;
47         ;          ;          ;          ;          ;          ;          ;          ;          ;          ;
48         0029      TABTAB     EQU      29H      ; Variable tab table 10 bytes to 32H

```

```

1          ;
2          ;           General use variables from 33H to 46H
3          0033      BAUDRATE      EQU    33H      ; Serial port baud rate
4          0034      NVRSUM       EQU    34H      ; Non-Volatile RAM checksum
5
6          0035      XXPOS        EQU    35H      ; Saved X-position
7          0036      XYPOS        EQU    36H      ; Saved Y-position
8
9          0037      BLNKRATE     EQU    37H      ; Blinking rate of screen
10         0038      BLNKCNT      EQU    38H      ; Running count for blink rate
11
12         0039      AUTOCNT      EQU    39H      ; Auto off timer count
13
14         003A      TCNT         EQU    3AH      ; Running clock count
15         003B      TSEC        EQU    3BH      ; Seconds counter
16         003C      TMIN        EQU    3CH      ; Minute counter
17         003D      THOUR       EQU    3DH      ; Hour counter
18
19         003E      DISPSEC     EQU    3EH      ; Last count of seconds displayed
20
21         003F      PFIELD      EQU    3FH      ; Protected fields byte
22         0040      ERRORS      EQU    40H      ; Powerup diagnostic error flag
23
24
25         ;           Screen line table
26         ;
27         0047      LORDER      EQU    47H      ; Line order list      25 bytes to 5FH
28
29
30         ;           Stack area
31         ;
32         005F      STACK       EQU    5FH      ; Stack pointer address 32 bytes to 7FH
33
34
35         ;           8051 processor bit port defines
36         ;
37         0090      KBOUT       BIT    P1.0     ; Keyboard output line
38         0091      KBIN       BIT    P1.1     ; Keyboard input line
39         0092      VSP        BIT    P1.2     ; 0 = normal video      1 = suppressed
40         0093      SETLCK     BIT    P1.3     ; 0 = setup mode locked 1 = normal
41         0094      DTR        BIT    P1.4     ; Data terminal ready
42         0095      RTS        BIT    P1.5     ; Ready to send
43         ;           BIT    P1.6     ; Expansion socket
44         0097      CLKRUN     BIT    P1.7     ; Clock run for CRT controller
45
46         ;TXD        BIT    P3.1     ; Predefined serial port transmit pin
47         00B4      DMATYPE    BIT    P3.4     ; 0 = clear memory      1 = DMA CRTC
48         00B5      CTS        BIT    P3.5     ; Clear to send

```

```
1 ..... ; ROM.#2 VECTORS .....
2 ..... ;
3 ..... ; These locations are provided to facilitate future modifications
4 ..... ; without a change to the masked processor. Each location is
5 ..... ; accessed with a -CALL- and control is gained back with a -RET-.
6 ..... ;
7 ..... ;
8 ..... ; Initialization of internal RAM and any other devices that
9 ..... ; may be added.
10 ..... ;
11 ..... 1000 ..... R2_IN ..... EQU ..... 1000H .....
12 ..... ;
13 ..... ; Same as R2_IN but does not destroy current settings
14 ..... ; such as CAPS LOCK, ON/OFF LINE, TIME on clock, etc.
15 ..... ;
16 ..... ;
17 ..... 1003 ..... R2_IN2 ..... EQU ..... 1003H .....
18 ..... ;
19 ..... ;
20 ..... ; Start DMA hook. This is jumped to at the beginning of each
21 ..... ; DMA request from the CRTIC.
22 ..... ;
23 ..... 1006 ..... R2_STARTDMA ..... EQU ..... 1006H .....
24 ..... ;
25 ..... ;
26 ..... ; Stop DMA hook. This is jumped to at the beginning of each
27 ..... ; timer 0 interrupt.
28 ..... ;
29 ..... 1009 ..... R2_STOPDMA ..... EQU ..... 1009H .....
30 ..... ;
31 ..... ;
32 ..... ; Fill screen hook. This is jumped to start the fill screen
33 ..... ; DMA feature. A check for protected fields is made.
34 ..... ;
35 ..... 100C ..... R2_FILL ..... EQU ..... 100CH .....
36 ..... ;
37 ..... ;
38 ..... ; IRQ hook. This is jumped to at the beginning of each IRQ.
39 ..... ;
40 ..... 100F ..... R2_IRQ ..... EQU ..... 100FH .....
41 ..... ;
42 ..... ;
43 ..... ; Serial hook. This is jumped to at the beginning of each
44 ..... ; serial interrupt.
45 ..... ;
46 ..... 1012 ..... R2_SERIAL ..... EQU ..... 1012H .....
```

```
1 ; Transmit hook. This performs the transmit character
2 ; function of the terminal for the serial port.
3 ;
4 1015 R2_XMT EQU 1015H
5
6
7 ; Send an XON to the host.
8 ;
9 1018 R2_XON EQU 1018H
10
11
12 ; Initialize the cursor format.
13 ;
14 101B R2_ICUR EQU 101BH
15
16
17 ; Initialize the keyboard
18 ;
19 101E R2_IKB EQU 101EH
20
21
22 ; SETUP mode vector
23 ;
24 1021 R2_SETUP EQU 1021H
25
26
27 ; Background loop hook. This is called once every time through
28 ; the main background loop.
29 ;
30 1024 R2_BACK EQU 1024H
31
32
33 ; Keyboard input hook. This is called once before a character
34 ; is received from the keyboard.
35 ;
36 1027 R2_KY1 EQU 1027H
37
38
39 ; Keyboard output hook. This is called once at the beginning
40 ; of each transfer to the keyboard.
41 ;
42 102A R2_KY2 EQU 102AH
43
44
45 ; Escape parsing hook. This is called after an -ESC- is
46 ; received.
47 ;
48 102D R2_ESC EQU 102DH
```

```
1 ; Transmit character. This performs the function of
2 ; transmitting the character at the current position.
3 ;
4 1030 R2_TC EQU 1030H
5
6
7 ; Transmit line. This performs the function of transmitting
8 ; the line at the current position.
9 ;
10 1033 R2_TL EQU 1033H
11
12
13 ; Transmit page. This performs the function of transmitting
14 ; the page to the port that is not selected.
15 ;
16 1036 R2_TP EQU 1036H
17
18
19 ; Transmit 25th line. This performs the function of transmitting
20 ; the 25th line to the port that is not selected.
21 ;
22 1039 R2_T25L EQU 1039H
23
24
25 ; Print page. This performs the function of transmitting the
26 ; page to the opposite port in a form proper for printing (uses
27 ; CR, LF at the end of each line).
28 ;
29 103C R2_PRNT EQU 103CH
30
31
32 ; Display clock. This updates the time on the 25th line.
33 ;
34 103F R2_DCLK EQU 103FH
35
36
37 ; Display 25th status line. This displays the system status
38 ; on the 25th line if the option is enabled and the user does
39 ; not have the 25th line enabled.
40 ;
41 1042 R2_DISP EQU 1042H
```

```

1
2          ;          INTERRUPT VECTORS
3          ;
4
5
6          ;          RESET vector
7          ;
8          0000          ORG    0000H
9 0000    80    2E          SJMP  START          ; Start of program
10
11
12          ;          External interrupt request 0
13          ;
14          0003          ORG    0003H
15 0003    30    AF    02          JNB   EA, I1          ; Double check
16 0006    80    22          SJMP  IEXTI0         ; Start DMA transfer
17 0008    D2    89          SETB  TCON.1
18 000A    32          RETI
19
20
21          ;          Timer 0 interrupt vector
22          ;
23          000B          ORG    000BH
24 000B    30    AF    02          JNB   EA, I2          ; Double check
25 000E    80    1D          SJMP  ITMRO         ; stop DMA transfer
26 0010    D2    8D          SETB  TCON.5
27 0012    32          RETI
28
29
30          ;          External interrupt request 1
31          ;
32          0013          ORG    0013H
33 0013    30    AF    03          JNB   EA, I3          ; Double check
34 0016    02    100F          LJMP  R2_IRQ         ; Interrupt request
35 0019    D2    8B          SETB  TCON.3
36 001B    32          RETI
37
38
39          ;          Serial port interrupt vector
40          ;
41          0023          ORG    0023H
42 0023    30    AF    03          JNB   EA, I5          ; Double check
43 0026    02    1012          LJMP  R2_SERIAL      ; Serial port
44 0029    32          RETI
45
46
47          ;          Jumps to other locations
48          ;
49 002A    02    1006          IEXTI0: LJMP  R2_STARTDMA    ; Start DMA jump
50 002D    02    1009          ITMRO:  LJMP  R2_STOPDMA     ; Stop DMA jump

```



```

1          ;?          Initialize system
2          ;
3          ;          Set stack pointer and call routine to set up everything
4
5          0030          ORG          30H          ; Somewhat arbitrary
6
7 0030     75     81     5F     START:  MOV     SP, #STACK          ; Initialize stack pointer
8 0033     12     1000          LCALL   R2_LIN          ; Initialize everything else
9
10
11
12
13         ;?          MAIN - main control loop
14         ;
15         ;          *MAIN* is in charge of giving control to the proper routine
16         ;          whenever there is a character present in one of the FIFOs.
17
18
19 0036     12     1024          MAIN:    LCALL   R2_BACK          ; Background hook
20
21 0039     20     22     06          JB     HSSTOP, MN1          ; IF not hold screen THEN
22 003C     31     F6          ACALL   FCIF          ; fetch char from input FIFO
23 003E     40     02          JC     MN1          ; IF character THEN
24 0040     11     79          ACALL   IFCP          ; processes character
25
26 0042     30     2E     20          MN1:    JNB     ONLINE, MN2          ; IF online AND
27 0045     30     13     1D          JNB     OKTRANS, MN2          ; IF output port free THEN
28 0048     20     02     03          JB     PORTF, MN1A          ; IF auxiliary port OR
29 004B     30     3E     03          JNB     HNSHK, MN1B          ; IF hardware handshake THEN
30 004E     20     B5     14          MN1A:  JB     CTS, MN2          ; IF not CTS THEN skip
31 0051     20     16     11          MN1B:  JB     XOFFRCVD, MN2          ; IF not -XOFF- received THEN
32 0054     51     4C          ACALL   FCOF          ; fetch char from output FIFO
33 0056     40     0D          JC     MN2          ; IF character THEN
34 0058     B4     13     02          CJNE   A, #XOFF, MN1C          ; IF char = xoff THEN
35 005B     D2     11          SETB   UXOFFSENT          ; flag user xoff sent
36 005D     B4     11     02          MN1C:  CJNE   A, #XON, MN1D          ; IF char = xon THEN
37 0060     C2     11          CLR     UXOFFSENT          ; clear user xoff sent
38 0062     12     1015          MN1D:  LCALL   R2_XMT          ; transmit character
39
40 0065     20     1F     06          MN2:    JB     KBDISF, MN3          ; IF keyboard enabled THEN
41 0068     51     B6          ACALL   FCKB          ; fetch char from keyboard
42 006A     40     02          JC     MN3          ; IF keyboard data THEN
43 006C     51     EE          ACALL   KBCP          ; process keyboard data
44
45 006E     30     37     C5          MN3:    JNB     L25ON, MAIN          ; IF 25th status enabled AND
46 0071     20     15     C2          JB     L25EN, MAIN          ; IF 25th line disabled THEN
47 0074     12     103F          LCALL   R2_DCLK          ; display clock every second
48
49 0077     80     BD          SJMP   MAIN          ; Go forever

```

*** Z-29 COMPUTER TERMINAL FIRMWARE VERSION 1.03 ***

```

1      ;:          IFCP - input FIFO character processor
2      ;
3      ;          *IFCP* interprets characters which have been received (or
4      ;          struck on the keyboard if off-line or keyed as a local
5      ;          function).  If the character is part of an escape sequence
6      ;          then control is given directly to that routine by means of
7      ;          the -dispatch address-.  If it is a control character then it
8      ;          is looked up in *CTLTAB*.  If found the program jumps to the
9      ;          appropriate routine, otherwise the character is discarded.  If
10     ;          it is a displayable character it is placed on the screen
11     ;          after checking for graphics mode, attributes, etc.
12     ;
13     ;
14     ;          ENTRY   (A) = character from input FIFO
15     ;
16     ;          EXIT    none
17     ;
18     ;          USES    all
19     ;
20     ;
21 0079  B4    18    06    IFCP:   CJNE   A, #CAN, IFPA      ; IF canceled AND
22 007C  20    43    03          JB     HAZ, IFPA        ; IF not Haz mode THEN
23 007F  12    082F          LCALL  SETNORM         ; Restore dispatch address
24     ;
25 0082  C0    16          IFPA:   PUSH   DSADRL          ; Jump to the
26 0084  C0    15          PUSH   DSADRH          ; -dispatch address-
27 0086  22          RET
28     ;
29 0087  B4    0D    12    NORM:   CJNE   A, #CR, IFP1     ; IF carriage return THEN
30 008A  30    36    0F          JNB   HSMODEF, IFP1    ; IF hold screen mode THEN
31 008D  E5    12          MOV   A, YPOS
32 008F  04          INC   A                ; set y-pos to check
33 0090  B5    18    00          CJNE   A, BFIX, NRM0   ; with bottom fixed region
34 0093  40    05          JC    NRM1            ; IF ypos >= bottom THEN
35 0095  D5    1E    02          DJNZ  HSLINE, NRM1    ; decrement line
36 0098  D2    22          SETB  HSSTOPF        ; IF zero THEN stop disp
37 009A  74    0D          NRM1:  MOV   A, #CR          ; restore carriage return
38     ;
39     ;          Check for monitor mode and control characters
40     ;
41 009C  30    3A    0D    IFP1:   JNB   MONITOR, IFP1B  ; IF monitor THEN
42 009F  C2    08          CLR   RVVA           ; start with normal display
43 00A1  B4    20    00          CJNE   A, #1, IFP1A   ;
44 00A4  50    5E          IFP1A: JNC   IFP6           ; IF control character THEN
45 00A6  D2    08          SETB  RVVA           ; make it reverse video
46 00A8  44    40          ORL   A, #01000000B  ; convert to ordinary char
47 00AA  80    58          SJMP  IFP6           ; skip ahead
48     ;
49 00AC  B4    20    00    IFP1B: CJNE   A, #1, IFP1C   ; Normal place to jump to
50 00AF  40    03    IFP1C: JC    IFP2           ; IF control character OR
51 00B1  B4    7F    21    CJNE   A, #RUBOUT, IFP3 ; IF /rubout/ THEN
52     ;
53     ;          Character is a control character
54     ;
55 00B4  75    F0    08    IFP2:  MOV   B, #CTAB1L      ; Get table info
56 00B7  90    0119          MOV   DPTR, #CTAB1
57 00BA  20    40    12          JB    ANSI, IFP2A    ; IF not ANSI mode OR

```

*** Z-29 COMPUTER TERMINAL FIRMWARE VERSION 1.03 ***

```

1 00BD 20 41 0F JB ZDS, IFF2A ; IF not ZDS mode THEN
2 00C0 75 F0 0E MOV B, #CTAB2L ; set other table info
3 00C3 90 0107 MOV DPTR, #CTAB2
4 00C6 20 42 06 JB ADM3, IFF2A ; IF not ADM 3 mode THEN
5 00C9 75 F0 06 MOV B, #CTAB3L ; set other table info
6 00CC 90 0128 MOV DPTR, #CTAB3
7 00CF 31 3A IFF2A: ACALL STAB ; Search the table
8
9 ;
10 ; Control character found in table, go to associated address.
11 ; Subroutine return will cause return to main idle loop
12 00D1 40 33 JC IFFRET ; IF found THEN
13 00D3 E4 CLR A
14 00D4 73 JMP @A+DPTR ; Jump to address in (DPTR)
15
16 ; Character is a displayable character
17 ;
18 00D5 30 43 06 IFF3: JNB HAZ, IFF3A ; IF Hazeltine mode AND
19 00D8 B4 7E 03 CJNE A, #22, IFF3A ; IF char = 22 THEN
20 00DB 02 067B LJMP ESCCODE ; do escape stuff
21 00DE 30 0D 13 IFF3A: JNB GRPH, IFF5 ; IF in graphics mode THEN
22 00E1 B4 5E 06 CJNE A, #5EH, IFF4
23 00E4 20 0F 0D JB ALTGRPH, IFF5 ; IF alternate THEN dont map
24 00E7 74 7F MOV A, #7FH ; IF 5EH THEN map to 7FH
25 00E9 D3 SETB C
26 00EA 40 08 IFF4: JC IFF5 ; IF in graphics range THEN
27 00EC 54 1F ANL A, #00011111B ; mask to graphic character
28 00EE 30 0F 03 JNB ALTGRPH, IFF5 ; IF alt graphic set THEN
29 00F1 D3 SETB C ; set carry and
30 00F2 80 02 SJMP IFF5A ; place into alt mode
31
32
33 ; Check for insert character mode
34 ;
35 00F4 A2 0C IFF5: MOV C, ALTCHARA ; Get alt char mode
36 00F6 92 E7 IFF5A: MOV ACC.7, C ; Place into data byte
37
38 00F8 30 21 09 JNB ICMODEF, IFF6 ; IF insert character mode THEN
39 00FB C0 E0 PUSH ACC ; save character
40 00FD 31 A9 ACALL SPF ; skip protected fields
41 00FF 12 0DC1 CALL PIC ; insert blank character
42 0102 D0 E0 POP ACC ; restore character
43
44 0104 31 57 IFF6: ACALL PUTCHR ; Put character onto screen
45 0106 22 IFFRET: RET

```

```

1          ;;          CTAB1/2/3 - control character tables
2          ;
3          ;          *CTAB1* contains all control codes for the ANSI and ZDS
4          ;          emulation modes.
5          ;
6          ;          *CTAB2* contains all control codes for the ADM 3 emulation
7          ;          mode.
8          ;
9          ;          *CTAB3* contains all control codes for the Hazeltine 1500
10         ;          emulation mode.
11         ;
12         ;          Table entries are: The control character followed by the
13         ;          address of the routine which performs the requested function.
14         ;
15
16         0107          CTAB2          EQU          $
17
18         0107          0B          DB          OBH          ; Vertical tab
19         0108          0C8D          DW          CUP          ; Cursor up
20
21         010A          0C          DB          OCH          ; Form feed
22         010B          0C64          DW          CRT          ; Cursor right
23
24         010D          0E          DB          OEH          ; Shift out
25         010E          0FB3          DW          EKI          ; Enable keyboard input
26
27         0110          0F          DB          OFH          ; Shift in
28         0111          0FB9          DW          DKI          ; Disable keyboard input
29
30         0113          1A          DB          1AH          ; Substitute
31         0114          0BAC          DW          CLRS          ; Clear screen
32
33         0116          1E          DB          1EH          ; Record separator
34         0117          0C36          DW          SCH          ; Set cursor home
35
36         0119          CTAB1          EQU          $
37
38         0119          1B          DB          ESC          ; Escape
39         011A          067B          DW          ESCCODE          ; Escape code processor
40
41         011C          08          DB          BS          ; Backspace
42         011D          0C3D          DW          PBS          ; Perform backspace
43
44         011F          09          DB          HT          ; Horizontal tabulation
45         0120          05C1          DW          TAB          ; Tab to next column
46
47         0122          0E          DB          OEH          ; Shift out
48         0123          0F81          DW          G1PICK          ; Pick G1 character set
49
50         0125          0F          DB          OFH          ; Shift in
51         0126          0F7B          DW          G0PICK          ; Pick G0 character set
52
53         0128          CTAB3          EQU          $
54
55         0128          0A          DB          LF          ; Line feed
56         0129          0555          DW          PLFCR          ; Perform LF and/or CR
57

```



```

1          ;|          STAB - search table
2          ;
3          ;          *STAB* searches tables of specified length for a match
4          ;          with the first character in an entry.
5          ;
6          ;
7          ;          ENTRY (A) = character to match
8          ;          (B) = table length in number of entries
9          ;          (DPTR) = table address
10         ;
11         ;          EXIT (A) = original character
12         ;          (B) = number of entries left to search + 1
13         ;          (DPTR) = first address after character match
14         ;          'C' = set if no match, clear otherwise
15         ;
16         ;          USES A, B, DPTR, WORK
17
18
19 013A    FC          STAB:    MOV    WORK, A          ; Save character to match
20
21 013B    E4          ST1:     CLR    A                ; REPEAT
22 013C    93          MOV    A, @A+DPTR          ; set character from table
23 013D    A3          INC    DPTR                ; bump to address high byte
24 013E    B5    04    OE     CJNE   A, WORKA, ST2        ; compare char with work
25 0141    E4          CLR    A                ; IF character = work THEN
26 0142    93          MOV    A, @A+DPTR          ; set address high byte
27 0143    C0    E0     PUSH   ACC                ; save on stack
28 0145    A3          INC    DPTR                ; bump to address low byte
29 0146    E4          CLR    A                ;
30 0147    93          MOV    A, @A+DPTR          ; set address low byte
31 0148    F5    82     MOV    DPL, A            ; save address low byte
32 014A    D0    83     POP    DPH                ; POP address high byte
33 014C    EC          MOV    A, WORK            ; restore original character
34 014D    C3          CLR    C                ; clear 'C' for ok
35 014E    22          RET                     ; return
36
37 014F    A3          ST2:     INC    DPTR                ; bump to address low byte
38 0150    A3          INC    DPTR                ; bump to next entry if any
39 0151    D5    F0    E7     DJNZ   B, ST1          ; UNTIL #entries = 0
40
41 0154    EC          MOV    A, WORK            ; Restore original character
42 0155    D3          SETB   C                ; Flag 'C' for no match
43 0156    22          RET

```

*** Z-29 COMPUTER TERMINAL FIRMWARE VERSION 1.03 ***

```

1          ; ; PUTCHR - put character onto screen
2          ;
3          ; *PUTCHR* puts the character onto the screen and checks for
4          ; wrap around at the end of a line for auto CR or LF.
5          ;
6          ;
7          ; ENTRY (A) = character
8          ;
9          ; EXIT none
10         ;
11         ; USES A, B, DPTR, TEMP, PTR1
12
13
14 0157 D2 14 PUTCHR: SETB DX ; Flag that cursor moved
15
16 0159 C0 E0 PUSH ACC ; Save character
17
18 015B 31 A9 ACALL SPF ; Skip any protected fields
19
20 015D 85 14 82 MOV DPL, LINADL ; Get line address
21 0160 85 13 83 MOV DPH, LINADH
22 0163 53 83 EF ANL DPH, #ATRANL ; Mask to attribute memory
23 0166 E5 21 MOV A, ATTRIBUTES
24 0168 F0 MOVX @DPTR, A ; Output current attributes
25 0169 43 83 10 ORL DPH, #CHRORL ; Mask to character memory
26 016C D0 E0 POP ACC ; Restore character
27
28 016E F0 MOVX @DPTR, A ; Store into screen memory
29
30 016F E5 11 MOV A, XPOS
31 0171 B4 4F 09 CJNE A, #MAXCHAR, PU1 ; IF cursor at end of line AND
32 0174 30 2B 0F JNE AUTOWRAP, PU2 ; IF auto wrap on THEN
33 0177 B1 5C ACALL PCR ; perform carriage return
34 0179 B1 61 ACALL PLF ; perform line feed
35 017B 80 09 SJMP PU2 ; exit out
36
37 017D 05 11 PU1: INC XPOS ; Bump -XPOS-
38 017F A3 INC DPTR ; Bump location in memory
39 0180 85 82 14 MOV LINADL, DPL ; Save new line address
40 0183 85 83 13 MOV LINADH, DPH
41
42 0186 21 A9 PU2: AJMP SPF ; Skip any protected fields

```

*** Z-29 COMPUTER TERMINAL FIRMWARE VERSION 1.03 ***

```

1          ;;          CPF - check protected fields
2          ;
3          ;          *CPF* checks to see if the current position is protected.
4          ;          If so it returns a value in the carry flag.
5          ;
6          ;
7          ;          ENTER XPOS and YPOS at position
8          ;
9          ;          EXIT (C) = set if protected, clear otherwise
10         ;
11         ;          USES A, B, DPTR, TEMP, WORK, PTR1
12
13
14 0188    E5    3F          CPF:      MOV    A, PFIELD          ; Get protected fields
15 018A    70    02          ;          JNZ    CPF1             ; IF none protected THEN
16 018C    C3          CPF1:    CLR    C              ; clear carry
17 018D    22          ;          RET                    ; and return
18
19 018E    FC          CPF1:    MOV    WORK, A          ; Save value
20 018F    E5    11          MOV    A, XPOS
21 0191    85    12    F0    MOV    B, YPOS
22 0194    B1    03          ACALL   CLA              ; Calculate line address
23
24 0196    53    83    EF    ANL    DPH, #ATRANL      ; Mask to attribute memory
25 0199    E0          MOVX   A, @DPTR        ; Get current attribute
26 019A    54    0F          ANL    A, #00001111B    ; Mask to set only attributes
27
28 019C    70    05          JNZ    CPF2             ; IF no attributes set THEN
29 019E    BC    80    EB    CJNE   WORK, #80H, CPF1     ; IF not protected THEN return
30 01A1    80    04          SJMP  CPF2             ; ELSE return protected
31 01A3    5C          CPF2:    ANL    A, WORK        ; ELSE mask with protected
32 01A4    B5    04    E5    CJNE   A, WORKA, CPF1     ; IF no match THEN return
33
34 01A7    D3          CPF2:    SETB   C              ; Set carry
35 01A8    22          RET                    ; Return

```



```

1 ..... ;: ..... SPF - skip over protected fields .....
2 ..... ; .....
3 ..... ; ..... *SPF* checks to see if the current position is protected, .....
4 ..... ; ..... If so then the cursor is moved to the next unprotected .....
5 ..... ; ..... character position on the screen. If there are no unprotected .....
6 ..... ; ..... positions from the current cursor position to the end of the .....
7 ..... ; ..... screen then the cursor is moved to the HOME position. ....
8 ..... ; ..... The screen address is only updated if the cursor position .....
9 ..... ; ..... changes. ....
10 ..... ; .....
11 ..... ; .....
12 ..... ; ..... ENTRY none .....
13 ..... ; .....
14 ..... ; ..... EXIT none .....
15 ..... ; .....
16 ..... ; .....
17 ..... ; ..... USES A, B, DPTR, WORK, TEMP, PTR1 .....
18 ..... ; .....
19 01A9 31 88 SPF: ACALL CPF ; Check protected fields .....
20 01AB 40 01 JC SPO ; IF not protected THEN .....
21 01AD 22 RET ; return .....
22 ..... ; .....
23 01AE E5 11 SPO: MOV A, XPOS .....
24 01B0 B4 4F 11 CJNE A, #MAXCHAR, SP2 ; IF end of line THEN .....
25 01B3 75 11 00 MOV XPOS, #0 ; beginning of line .....
26 01B6 E5 12 MOV A, YPOS .....
27 01B8 B4 17 05 CJNE A, #MAXLINE-1, SP1 ; IF end of screen THEN .....
28 01BB 75 12 00 MOV YPOS, #0 ; beginning of screen .....
29 01BE 81 EA AJMP BLINAD ; new address and return .....
30 ..... ; .....
31 01C0 05 12 SP1: INC YPOS ; ELSE bump line number .....
32 01C2 80 02 SJMP SP3 ; calc address and go .....
33 ..... ; .....
34 01C4 05 11 SP2: INC XPOS ; ELSE bump column number .....
35 01C6 91 EA SP3: ACALL BLINAD ; calc new address .....
36 01C8 80 DF SJMP SPF ; keep on going .....

```

```

1          ;;          PCIF - place character in input FIFO
2          ;
3          ;          *PCIF* places a single character into the input FIFO.
4          ;
5          ;
6          ;          ENTRY (A) = character
7          ;
8          ;          EXIT (A) = character
9          ;          'C' = set if no room, clear otherwise
10         ;          'FO' = set if 'XOFF' is needed, clear otherwise
11         ;
12         ;          USES A B, DPTR
13
14
15 01CA    C2    AF          PCIF:    CLR    EA          ; Lock out entries
16 01CC    75    83    57    MOV    DPH, #HIGH (IBUF)
17 01CF    85    0C    82    MOV    DPL, ISTORE          ; Load input buffer pointer
18 01D2    F0          MOVX   @DPTR, A          ; Write character into FIFO
19 01D3    F5    F0          MOV    B, A          ; Save temporary
20
21 01D5    E5    0E          MOV    A, ICOUNT
22 01D7    B4    20    03    CJNE   A, #ILEN, PI1          ; IF queue is full THEN
23 01DA    D3          SETB   C          ; set 'C' for no room
24 01DB    80    14          SJMP  PIR          ; and exit out
25
26 01DD    C2    D5          PI1:    CLR    FO          ; No -XOFF- until otherwise
27 01DF    B4    15    02    CJNE   A, #IHI, PI2          ; IF queue at XOFF point THEN
28 01E2    D2    D5          SETB   FO          ; flag that -XOFF- is needed
29
30 01E4    05    0E          PI2:    INC    ICOUNT          ; Bump count
31 01E6    05    0C          INC    ISTORE          ; Bump store and check wrap
32 01E8    E5    0C          MOV    A, ISTORE
33 01EA    B4    F0    03    CJNE   A, #LOW (IBUF+ILEN), PI3
34 01ED    75    0C    D0    MOV    ISTORE, #LOW (IBUF)
35
36 01F0    C3          PI3:    CLR    C          ; Flag everything OK
37 01F1    D2    AF    PIR:    SETB   EA          ; Enable entries
38 01F3    E5    F0          MOV    A, B          ; Restore character
39 01F5    22          RET

```

```

1          ;:          FCIF = fetch character from input FIFO
2          ;
3          ;          *FCIF* is used to fetch a single character from the input
4          ;          FIFO if any are available.
5          ;
6          ;
7          ;          ENTRY none
8          ;
9          ;          EXIT (A) = character if available
10         ;          'C' = set if no character, clear otherwise
11         ;
12         ;          USES A, B, DPTR
13
14
15 01F6    E5    0E          FCIF:    MOV    A, ICOUNT
16 01F8    70    02          JNZ    F11          ; IF no data in queue THEN
17 01FA    D3          SETB   C          ; set carry and return
18 01FB    22          RET
19
20 01FC    B4    09    03    F11:    CJNE   A, #ILO, F12          ; IF low water mark THEN
21 01FF    12    1018    LCALL  R2_XON          ; send -XON- now
22
23 0202    C2    AF          F12:    CLR    EA          ; Lock out entries
24 0204    75    83    57    MOV    DPH, #HIGH (IBUF)
25 0207    85    0D    82    MOV    DPL, IFETCH          ; Load input buffer pointer
26 020A    E0          MOVX  A, @DPTR          ; Read character from FIFO
27 020B    F5    F0          MOV    B, A          ; Save temporary
28
29 020D    05    0D          INC    IFETCH          ; Bump fetch and check wrap
30 020F    E5    0D          MOV    A, IFETCH
31 0211    B4    F0    03    CJNE   A, #LOW (IBUF+ILEN), F13
32 0214    75    0D    D0    MOV    IFETCH, #LOW (IBUF) ; Reset value of fetch pointer
33
34 0217    15    0E          F13:    DEC    ICOUNT          ; Decrement count
35 0219    21    F0          AJMP  P13          ; Return (saves ROM)

```

```

1          ;:          LCIF - look at next character on input FIFO
2          ;
3          ;          *LCIF* returns the next character from the input FIFO if there
4          ;          is one but does not take it off the FIFO. This is needed for
5          ;          'look ahead' applications.
6          ;
7          ;
8          ;          ENTRY   none
9          ;
10         ;          EXIT   (A) = character if available
11         ;          'C' = set if no character, clear otherwise
12         ;
13         ;          USES   A, DPTR
14
15
16 021B    E5    0E          LCIF:    MOV    A, ICOUNT
17 021D    70    02          ;          JNZ    LI1          ; IF no data in queue THEN
18 021F    D3          ;          SETB   C          ; set carry and return
19 0220    22          ;          RET
20
21 0221    75    83    57    LI1:    MOV    DPH, #HIGH (IBUF)
22 0224    85    0D    82          ;          MOV    DPL, IFETCH          ; Load input buffer pointer
23 0227    E0          ;          MOVX   A, @DPTR          ; Read character from FIFO
24 0228    C3          ;          CLR    C          ; Flag everything ok
25 0229    22          ;          RET

```

```

1      ;:          PCOF - place character in output FIFO
2      ;
3      ;          *PCOF* places a single character into the output FIFO and
4      ;          checks for online and half duplex.
5      ;
6      ;
7      ;          ENTRY (A) = character
8      ;
9      ;          EXIT (A) = character
10     ;          'C' = set if no room in FIFO, clear otherwise
11     ;
12     ;          USES A, B, DPTR
13     ;
14     ;
15 022A 20 2E 02 PCOF: JB ONLINE, P01 ; IF offline THEN
16 022D 80 9B SJMP PCIF ; place on input and return
17
18 022F 20 2F 02 P01: JB FULLDPLX, P02 ; IF in half duplex mode THEN
19 0232 31 CA ACALL PCIF ; place on input also
20
21 0234 F5 F0 P02: MOV B, A ; Save temporary
22 0236 E5 0F MOV A, @STORE
23 0238 B4 F7 04 CJNE A, #LOW (OLEN), P03 ; IF store = queue length THEN
24 023B D3 SETB C ; set 'C' for full
25 023C E5 F0 MOV A, B ; restore char and return
26 023E 22 RET
27
28 023F C3 P03: CLR C ; ELSE clear 'C'
29 0240 75 83 57 MOV DPH, #HIGH (OBUF) ; set up the output
30 0243 85 0F 82 MOV DPL, @STORE ; buffer pointer
31 0246 E5 F0 MOV A, B ; restore character
32 0248 F0 MOVX @DPTR, A ; write character to buffer
33 0249 05 0F INC @STORE ; bump store and return
34 024B 22 RET

```

*** Z-29 COMPUTER TERMINAL FIRMWARE VERSION 1.03 ***

```

1          ;;;          FCOF - fetch character from output FIFO
2          ;
3          ;          *FCOF* fetches a character from the output FIFO if any
4          ;          are available.
5          ;
6          ;
7          ;          ENTRY  none
8          ;
9          ;          EXIT  (A) = character if available
10         ;          'C' = set if no characters, clear otherwise
11         ;
12         ;          USES  A, B, DPTR
13         ;
14         ;
15 024C    E5    OF          FCOF:    MOV    A, OSTORE
16 024E    B5    10    02    CJNE   A, OFETCH, F01    ; IF store = fetch THEN
17 0251    D3          SETB   C          ; set 'C' and return
18 0252    22          RET
19
20 0253    75    83    57    F01:    MOV    DPH, #HIGH (OBUF)
21 0256    85    10    82    MOV    DPL, OFETCH    ; Load output buffer pointer
22 0259    E0          MOVX   A, @DPTR    ; Get character from buffer
23 025A    F5    F0          MOV    B, A          ; Save temporary
24 025C    C2    AF          CLR    EA          ; Lock out entries
25 025E    05    10          INC    OFETCH    ; Bump fetch pointer
26 0260    E5    OF          MOV    A, OSTORE
27
28 0262    B5    10    06    CJNE   A, OFETCH, F0R    ; IF store = fetch THEN
29 0265    75    10    F0    MOV    OFETCH, #LOW (OBUF) ; reset the values of
30 0268    75    OF    F0    MOV    OSTORE, #LOW (OBUF) ; fetch and store
31
32 026B    21    F0          F0R:    AJMP   P13          ; Return (saves ROM)

```

```

1      ;:          PCKB - place character out to the keyboard
2      ;
3      ;          *PCKB* outputs bytes to the keyboard using a special handshake.
4      ;
5      ;
6      ;          ENTRY  (A) = byte to output
7      ;
8      ;          EXIT   none
9      ;
10     ;          USES   A, B, WORK
11
12
13 026D 12      102A      PCKB:      LCALL  R2_KY2      ; Keyboard hook
14
15 0270 30      91      0C      JNB    KBIN, PK1      ; IF data THEN
16 0273 C0      E0      PUSH   ACC          ; save byte
17 0275 51      B6      ACALL  FCKB      ; fetch char from keyboard
18 0277 40      02      JC     PK0          ; IF none now THEN exit
19 0279 51      EE      ACALL  KBCP      ; ELSE process character
20 027B D0      E0      POP    ACC          ;
21 027D 80      EE      SJMP   PCKB      ; and try again
22
23 027F C2      AF      CLR    EA          ; Disable interrupts
24 0281 C2      90      CLR    KBOUT      ; Request keyboard attention
25 0283 75      F0      MOV    B, #8      ; Initialize index for 8 bits
26
27 0286 30      91      06      JNB    KBIN, PK1A    ; IF contention THEN
28 0289 D2      AF      SETB  EA          ; enable interrupts
29 028B D2      90      SETB  KBOUT      ; wipe out request
30 028D 80      DE      SJMP   PCKB      ; try again
31
32 028F D2      AF      PK1A:   SETB  EA          ; Enable interrupts
33
34 0291 13      00      PK1:   RRC    A          ; REPEAT rotate next bit in
35 0292 7C      00      MOV    WORK, #0      ; init count for safety check
36 0294 20      91      0E      PK2:   JB     KBIN, PK3      ; REPEAT wait for request
37 0297 51      B5      ACALL  PKDLY      ; delay some time
38 0299 51      B5      ACALL  PKDLY
39 029B 51      B5      ACALL  PKDLY
40 029D 51      B5      ACALL  PKDLY
41 029F 51      B5      ACALL  PKDLY
42 02A1 DC      F1      DJNZ  WORK, PK2      ; UNTIL check is done
43 02A3 80      0E      SJMP  PKR
44
45 02A5 92      90      PK3:   MOV    KBOUT, C      ; output data
46 02A7 7C      00      MOV    WORK, #0      ; init count for safety check
47 02A9 30      91      04      PK4:   JNB    KBIN, PK5      ; REPEAT wait for signal
48 02AC DC      FB      DJNZ  WORK, PK4      ; UNTIL safety check done
49 02AE 80      03      SJMP  PKR
50
51 02B0 D5      F0      DE      PK5:   DJNZ  B, PKL        ; UNTIL all 8 bits are done
52
53 02B3 D2      90      PKR:   SETB  KBOUT      ; Restore status
54 02B5 22      PKDLY: RET

```

```

1          ;:          FCKB - fetch character from keyboard
2          ;:
3          ;:          *FCKB* takes characters from the keyboard using a special
4          ;:          handshaking.
5          ;:
6          ;:
7          ;:          ENTRY   none
8          ;:
9          ;:          EXIT    (A) = character if available
10         ;:          'C' = set if no character, clear otherwise
11         ;:
12         ;:          USES   A, B, DPTR
13         ;:
14         ;:
15 02B6     12      1027      FCKB:      LCALL   R2_KY1          ; Keyboard hook
16         ;:
17 02B9     20      91       02          JB      KBIN, FK1          ; IF no data THEN
18 02BC     D3          ;          SETB   C              ; set carry and return
19 02BD     22          ;          RET
20         ;:
21 02BE     75      39       00      FK1:      MOV     AUTOCNT, #0
22 02C1     D2      24          ;          SETB   VSPF          ; Toggle screen saver
23         ;:
24 02C3     E4          ;          CLR     A              ; Init receiving byte
25 02C4     75      F0       08          MOV     B, #8            ; Init index counter
26         ;:
27 02C7     C2      90          ;          FKL:      CLR     KBOUT          ; REPEAT request data
28 02C9     51      E1          ;          ACALL  FKDLY          ; delay 200 usec
29 02CB     51      E1          ;          ACALL  FKDLY
30 02CD     A2      91          ;          MOV     C, KBIN          ; set data bit
31 02CF     D2      90          ;          SETB   KBOUT          ; data received
32 02D1     92      E7          ;          MOV     ACC,7, C          ; place data into word
33 02D3     D5      F0       02          ;          DJNZ   B, FK2          ; IF all 8 bits THEN
34 02D6     80      05          ;          SJMP  FKR           ; exit out
35         ;:
36 02D8     03      E1          ;          FK2:      RR      A              ; rotate to next bit
37 02D9     51      E1          ;          ACALL  FKDLY          ; delay 100 usec
38 02DB     80      EA          ;          SJMP  FKL           ; UNTIL forever
39         ;:
40 02DD     51      E1          ;          FKR:      ACALL  FKDLY          ; Delay last time to let clear
41 02DF     C3          ;          CLR     C              ; Clear 'C' for ok
42 02E0     22          ;          RET
43         ;:
44         ;:          Delay routine
45         ;:
46 02E1     75      83      1E      FKDLY:      MOV     DPH, #30          ; Delay of 100 usec
47 02E4     D5      83      FD      FKDLY1:     DJNZ   DPH, FKDLY1
48 02E7     22          ;          RET

```



```

1      ;:          LKB = look at keyboard
2      ;
3      ;          *LKB* looks at keyboard to see if it has any data it wants
4      ;          to send to the host
5      ;
6      ;
7      ;          ENTRY  none
8      ;
9      ;          EXIT   (C) = set if no character, clear otherwise
10     ;
11     ;          USES   none
12     ;
13     ;
14 02E8  C3          LKB:      CLR   C
15 02E9  20  91  01    JB     KBIN, LKBR      ; IF no data THEN
16 02EC  D3          SETB   C                ; set carry and return
17 02ED  22          LKBR:     RET

```

*** Z-29 COMPUTER TERMINAL FIRMWARE VERSION 1.03 ***

```

1          ;|          KBCP - keyboard character Processor
2          ;
3          ;          *KBCP* processes any characters received from the keyboard.
4          ;
5          ;
6          ;          ENTRY   (A) = byte from keyboard
7          ;
8          ;          EXIT    none
9          ;
10         ;          USES   all
11
12
13 02EE    20    E7    03    KBCP:    JB      ACC.7, KPO          ; IF ASCII character THEN
14 02F1    41    2A          AJMP   PCOF          ; output char and return
15 02F3    22          KPR:    RET
16
17 02F4    A2    E6          KPO:    MOV    C, ACC.6
18 02F6    92    1C          MOV    SHIFT, C          ; Save shift value
19 02F8    A2    E5          MOV    C, ACC.5
20 02FA    92    1D          MOV    CONTLF, C          ; Save control value
21 02FC    54    9F          ANL   A, #10011111B      ; Mask off shift and control
22 02FE    30    1E    02    JNB   ACCESSF, KP1      ; IF access in progress THEN
23 0301    61    CD          AJMP   KPA          ; do a long jump
24
25
26         ;          No access in progress
27
28 0303    75    F0    09    KP1:    MOV    B, #KBDTL          ; (B) = table length
29 0306    90    044B      MOV    DPTR, #KBDT      ; (DPTR) = keyboard data table
30 0309    31    3A          ACALL STAB          ; Search the table
31 030B    40    02          JC    KP2          ; IF found THEN
32
33
34         ;          Command from keyboard
35
36 030D    E4          CLR   A
37 030E    73          JMP   @A+DPTR          ; Jump to routine
38
39
40         ;          Cursor keys
41
42 030F    FD          KP2:    MOV    TEMP, A
43 0310    E5    0F          MOV    A, DSTORE      ; IF output FIFO not empty THEN
44 0312    B5    10    DE    CJNE  A, DFETCH, KPR      ; loose character and return
45 0315    ED          MOV    A, TEMP
46
47 0316    75    F0    07    MOV    B, #KBCRTL      ; (B) = table length
48 0319    90    0466      MOV    DPTR, #KBCRT    ; (DPTR) = kb cursor table
49 031C    31    3A          ACALL STAB          ; Search the table
50 031E    40    2F          JC    KP6          ; IF found THEN
51 0320    20    42    D0    JB    ADM3, KPR        ; IF ADM.3 mode THEN exit
52 0323    20    43    CD    JB    HAZ, KPR         ; IF Haz mode THEN exit
53 0326    C0    82          PUSH  DPL          ; save values
54 0328    C0    83          PUSH  DPH
55 032A    74    1B          MOV    A, #ESC
56 032C    91    14          ACALL KPCOF          ; output escape
57 032E    30    40    04    JNB   ANSI, KP3        ; IF in ANSI mode THEN

```

*** Z-29 COMPUTER TERMINAL FIRMWARE VERSION 1.03 ***

```

1 0331 74 5B
2 0333 91 14
3 0335 D0 E0 KP3:
4 0337 60 12
5 0339 30 1C 0F
6 033C 30 40 06
7 033F 74 32
8 0341 91 14
9 0343 80 06
10 0345 F5 82 KP5:
11 0347 D0 E0
12 0349 C0 82
13 034B D0 E0 KP4:
14 034D 81 14
15
16
17 ;
18 ; Numeric keypad key
19 034F A2 1C KP6:
20 0351 30 30 01
21 0354 B3
22 0355 92 1C KP7:
23 0357 92 E6
24 0359 75 F0 1C
25 035C 90 047B
26 035F 31 3A
27 0361 50 02
28 0363 80 8E
29
30 0365 20 1C 22 KP16:
31
32 0368 20 31 06
33 036B E5 83 KP16A:
34 036D 81 14
35 036F 80 82
36
37 0371 20 42 F7 KP9:
38 0374 20 43 F4
39 0377 C0 82
40 0379 74 1B
41 037B 91 14
42 037D 74 4F
43 037F 20 40 02
44 0382 74 3F
45 0384 91 14 KP11:
46 0386 D0 E0
47 0388 81 14
48
49
50 ;
51 ; Insert mode key
52 038A 20 42 DE KP8:
53 038D 20 43 DB
54 0390 B4 D7 21
55 0393 74 1B
56 0395 91 14
57

```

```

1 0397 20 40 09 JB ANSI, KP13 ; IF in ZDS mode THEN
2 039A 74 40 MOV A, #'e'
3 039C 30 21 02 JNB ICMODEF, KP14 ; check if in IC mode
4 039F 74 4F MOV A, #'D'
5 03A1 81 14 KP14: AJMP KPCOF ; output char and return
6
7 03A3 74 5B KP13: MOV A, #'I' ; IF in ANSI mode THEN
8 03A5 91 14 ACALL KPCOF ; output 'I'
9 03A7 74 34 MOV A, #'4'
10 03A9 91 14 ACALL KPCOF ; output '4'
11 03AB 74 68 MOV A, #'h'
12 03AD 30 21 02 JNB ICMODEF, KP15 ; IF in IC mode THEN
13 03B0 74 6C MOV A, #'1'
14 03B2 81 14 KP15: AJMP KPCOF ; output char and return
15
16
17 ; Numeric keypad shifted
18 ;
19 03B4 FD KP12: MOV TEMP, A
20 03B5 AC 82 MOV WORK, DPL ; Save second char
21 03B7 E5 83 MOV A, DPH
22 03B9 91 14 ACALL KPCOF ; Output first key
23 03BB EC MOV A, WORK
24 03BC 60 55 JZ KPR2 ; IF second char not null THEN
25 03BE 30 40 0A JNB ANSI, KP10
26 03C1 74 5B MOV A, #'I'
27 03C3 91 14 ACALL KPCOF ; IF ANSI THEN output 'I'
28 03C5 EC MOV A, WORK
29 03C6 B4 4E 02 CJNE A, #'N', KP10 ; IF delete THEN
30 03C9 74 50 MOV A, #'P' ; change it for ANSI mode
31 03CB 81 14 KP10: AJMP KPCOF ; output second char & return
32
33
34 ; Access code in progress
35 ;
36 03CD C2 1E KPA: CLR ACCESSF ; Take out of access mode
37 03CF FD MOV TEMP, A ; Save for a while
38 03D0 54 F8 ANL A, #1111000B ; Mask for keyboard ID number
39 03D2 B4 98 06 CJNE A, #KB_ID, KPB ; IF ID number THEN
40 03D5 ED MOV A, TEMP ; get original data
41 03D6 54 07 ANL A, #00000111B ; mask for ID number
42 03D8 F5 1D MOV KBIDNUM, A ; save ID number
43 03DA 22 RET
44
45
46 ; Function key
47 ;
48 03DB 20 42 35 KPB: JB ADM3, KPR2 ; IF ADM 3 mode OR
49 03DE 20 43 32 JB HAZ, KPR2 ; IF Haz mode THEN exit
50
51 03E1 ED MOV A, TEMP ; Get original character back
52
53 03E2 75 F0 09 MOV B, #KBFNTL ; (B) = table length
54 03E5 90 04CF MOV DPTR, #KBFNT ; (DPTR) = function key table
55 03E8 31 3A ACALL STAB ; Search the table
56 03EA 40 27 JC KPR2 ; IF found THEN
57 03EC C0 82 PUSH DPL ; save values returned

```

*** Z-29 COMPUTER TERMINAL FIRMWARE VERSION 1.03 ***

```

1 03EE C0 83          PUSH  DPH
2 03F0 74 1B          MOV   A, #ESC
3 03F2 91 14          ACALL KPCOF          ; output an ESC
4 03F4 30 40          JNB  ANSI, KPC      ; IF in ANSI mode THEN
5 03F7 74 4F          MOV   A, #'0'
6 03F9 91 14          ACALL KPCOF          ; output '0'
7 03FB D0 E0          POP  ACC
8 03FD 91 14          ACALL KPCOF          ; output next character
9 03FF D0 E0          POP  ACC
10 0401 22           RET
11
12 0402 D0 E0          POP  ACC          KPC:      ; IF in ZDS mode THEN
13 0404 D0 E0          POP  ACC          ; set proper char
14 0406 30 E7          JNB  ACC.7, KPCOF   ; IF high bit set THEN
15 0409 C2 E7          CLR  ACC.7         ; clear high bit
16 040B FD           MOV  TEMP, A
17 040C 74 30          MOV  A, #'0'
18 040E 91 14          ACALL KPCOF          ; output '0'
19 0410 ED           MOV  A, TEMP
20 0411 81 14          AJMP KPCOF          ; output next character
21 0413 22           RET          KPR2:
22
23
24           ; Check if local function and execute proper routine
25           ;
26 0414 20 1D          JB   CONTLF, KPC1   ; IF control not pressed THEN
27 0417 41 2A          AJMP PCOF           ; output char and return
28
29 0419 21 CA          AJMP PCIF           ; ELSE do local and return

```

*** Z-29 COMPUTER TERMINAL FIRMWARE VERSION 1.03 ***

```

1      ; ;          KBTAB - keyboard tab routine
2      ;
3      ;          *KBTAB* checks to see if the SHIFT key is down.  If it is
4      ;          down then it checks for ZDS or ANSI mode.  If it is in one
5      ;          of those modes then the sequence to for backtab is sent.
6      ;
7      ;
8      ;          ENTRY   none
9      ;
10     ;          EXIT    none
11     ;
12     ;          USES    all
13     ;
14
15 041B 30 1C 0F KBTAB: JNB  SHIFTF, KT1      ; IF not SHIFT THEN just TAB
16 041E 90 0431 MOV   DPTR, #KTM1      ; set ANSI sequence
17 0421 20 40 06 JB   ANSI, KTO      ; IF ANSI mode THEN do it
18 0424 30 41 06 JNB  ZDS, KT1      ; IF not ZDS THEN just TAB
19 0427 90 0434 MOV   DPTR, #KTM2      ; ELSE set ZDS sequence
20 042A 02 0E6D KTO:  LJMP  P0DF      ; output back tab sequence
21
22 042D 74 09      KTI:  MOV   A, #HT
23 042F 41 2A      AJMP  PCDF      ; ELSE output horizontal tab
24
25 0431 1B 5B DA KTM1: DB   ESC, (^I), (^Z)+80H ; ESC I Z
26 0434 1B AD      KTM2: DB   ESC, (^-)+80H  ; ESC -
27
28
29
30
31     ; ;          KBSPACE - keyboard space routine
32     ;
33     ;          *KBSPACE* outputs a space unless the control key is down
34     ;          in which case it outputs a null character.
35     ;
36     ;
37     ;          ENTRY   none
38     ;
39     ;          EXIT    none
40     ;
41     ;          USES    all
42     ;
43
44 0436 74 20      KBSPACE: MOV  A, #
45 0438 30 1D 01 JNB  CONTLF, KBS1      ; IF control space THEN
46 043B E4      CLR  A      ; output a null
47 043C 41 2A      KBS1: AJMP  PCDF      ; Output character and return

```

*** Z-29 COMPUTER TERMINAL FIRMWARE VERSION 1.03 ***

```

1          ;:          KBENT - keyboard enter routine
2          ;
3          ;          *KBENT* outputs a carriage return unless the shift key is
4          ;          down in which case it does the print page function.
5          ;
6          ;
7          ;          ENTRY   none
8          ;
9          ;          EXIT    none
10         ;
11         ;          USES    all
12         ;
13
14 043E    20    1D    04    KBENT:    JB     CONTLF, KBE1    ; IF no control THEN
15 0441    74    9B                    ; set keypad enter key
16 0443    61    0F                    ; enter back into code
17 0445    02    103C    KBE1:    JMP    R2_PRNT    ; ELSE do print page function
18
19
20
21
22         ;:          KBACC - keyboard access routine
23         ;
24         ;          *KBACC* is run whenever the access character is received
25         ;          from the keyboard.
26         ;
27         ;
28         ;          ENTRY   none
29         ;
30         ;          EXIT    none
31         ;
32         ;          USES    none
33         ;
34
35 0448    D2    1E    KBACC:    SETB   ACCESSF    ; Flag access received
36 044A    22                    RET

```

*** Z-29 COMPUTER TERMINAL FIRMWARE VERSION 1.03 ***

```
1          ;:          KBDT - keyboard data table
2          ;
3          ;          *KBDT* contains the commands received from the keyboard
4          ;
5          ;          Table entries are: Keyboard data word followed by the
6          ;          address of the routine which performs the requested function.
7
8
9          044B          KBDT          EQU          $
10
11 044B          8B          DB          KB_TAB          ; Tab key
12 044C          041B          DW          KBTAB
13
14 044E          8C          DB          KB_SPACE          ; Space bar
15 044F          0436          DW          KBSPACE
16
17 0451          9F          DB          KB_ACC          ; Access code
18 0452          0448          DW          KBACC
19
20 0454          8F          DB          KB_POWER          ; Keyboard just powered up
21 0455          101E          DW          R2_IKB
22
23 0457          89          DB          KB_BREAK          ; Break pressed
24 0458          0FCC          DW          KBBREAK
25
26 045A          8A          DB          KB_CAPS          ; Caps locked mode
27 045B          0F8F          DW          KBCPLK
28
29 045D          87          DB          KB_SCROLL          ; Scroll key pressed
30 045E          0FE3          DW          KBSCROLL
31
32 0460          88          DB          KB_SETUP          ; Setup key pressed
33 0461          1021          DW          R2_SETUP
34
35 0463          9B          DB          KB_ENT          ; Enter key pressed
36 0464          043E          DW          KBENT
37
38          0009          KBDTL          EQU          ($-KBDT)/3          ; Table length
```


*** Z-29 COMPUTER TERMINAL FIRMWARE VERSION 1.03 ***

```

1
2          ;:          KBCRT - keyboard cursor table
3          ;
4          ;          *KBCRT* contains the ASCII values to be transmitted by the
5          ;          terminal when received from the keyboard.
6          ;
7          ;          Table entries are: Keyboard data word followed by the
8          ;          ASCII character to be transmitted if in shift mode followed by
9          ;          the ASCII character to be transmitted always. The special case
10         ;          here is the erase and shift erase function key.
11
12
13         0466          KBCRT          EQU          $
14
15         0466          80          DB          KB_UP          ; Up arrow key
16         0467          00          41          DB          0, 'A'
17
18         0469          81          DB          KB_DOWN        ; Down arrow key
19         046A          00          42          DB          0, 'B'
20
21         046C          82          DB          KB_LEFT        ; Left arrow key
22         046D          00          44          DB          0, 'D'
23
24         046F          83          DB          KB_RIGHT       ; Right arrow key
25         0470          00          43          DB          0, 'C'
26
27         0472          84          DB          KB_HOME        ; Home key
28         0473          00          48          DB          0, 'H'
29
30         0475          86          DB          KB_HELP        ; Help key
31         0476          00          7E          DB          0, '~'
32
33         0478          85          DB          KB_ERASE       ; Erase key
34         0479          45          4A          DB          'E', 'J'
35
36         0007          KBCRTL        EQU          ($-KBCRT)/3 ; Table length

```

```

1          ;: KBPDT - keyboard key pad table
2          ;
3          ; *KBPDT* contains the ASCII values to be transmitted by the
4          ; terminal when received from the keyboard.
5          ;
6          ; Table entries are: Keyboard data word followed by the
7          ; ASCII character to be transmitted if in unshifted followed
8          ; by the ASCII character to be transmitted if in any mode.
9          ; The shifted key format uses keyboard data + shift function
10         ; followed by the escape sequence or ASCII character to be
11         ; transmitted. The exception to this is the insert character
12         ; key. In this case the first character is the character for
13         ; entering IC mode and the second is for leaving IC mode.
14         ;
15
16         047B          KBPDT          EQU          $
17
18         047B          90          DB          KB_0          ; Keypad 0 key
19         047C          30          70          DB          '0', 'P'
20
21         047E          91          DB          KB_1          ; Keypad 1 key
22         047F          31          71          DB          '1', 'q'
23
24         0481          92          DB          KB_2          ; Keypad 2 key
25         0482          32          72          DB          '2', 'r'
26
27         0484          93          DB          KB_3          ; Keypad 3 key
28         0485          33          73          DB          '3', 's'
29
30         0487          94          DB          KB_4          ; Keypad 4 key
31         0488          34          74          DB          '4', 't'
32
33         048A          95          DB          KB_5          ; Keypad 5 key
34         048B          35          75          DB          '5', 'u'
35
36         048D          96          DB          KB_6          ; Keypad 6 key
37         048E          36          76          DB          '6', 'v'
38
39         0490          97          DB          KB_7          ; Keypad 7 key
40         0491          37          77          DB          '7', 'w'
41
42         0493          98          DB          KB_8          ; Keypad 8 key
43         0494          38          78          DB          '8', 'x'
44
45         0496          99          DB          KB_9          ; Keypad 9 key
46         0497          39          79          DB          '9', 'y'
47
48         0499          9A          DB          KB_DEC          ; Keypad decimal point key
49         049A          2E          6E          DB          '.', 'n'
50
51         049C          9B          DB          KB_ENT          ; Keypad enter key
52         049D          0D          4D          DB          CR, 'M'
53
54         049F          9C          DB          KB_DASH          ; Keypad dash (minus) key
55         04A0          2D          6D          DB          '-', 'm'
56
57         04A2          9D          DB          KB_COMMA          ; Keypad comma key

```

*** Z-29 COMPUTER TERMINAL FIRMWARE VERSION 1.03 ***

```

1 04A3 2C 6C DB ' ', '1'
2
3 04A5 D0 DB KB_0 + KB_SHFT ; Keypad 0 key shifted
4 04A6 30 00 DB '0', NULL
5
6 04A8 D1 DB KB_1 + KB_SHFT ; Keypad 1 key shifted
7 04A9 1B 4C DB ESC, 'L'
8
9 04AB D2 DB KB_2 + KB_SHFT ; Keypad 2 key shifted
10 04AC 1B 42 DB ESC, 'B'
11
12 04AE D3 DB KB_3 + KB_SHFT ; Keypad 3 key shifted
13 04AF 1B 4D DB ESC, 'M'
14
15 04B1 D4 DB KB_4 + KB_SHFT ; Keypad 4 key shifted
16 04B2 1B 44 DB ESC, 'D'
17
18 04B4 D5 DB KB_5 + KB_SHFT ; Keypad 5 key shifted
19 04B5 1B 48 DB ESC, 'H'
20
21 04B7 D6 DB KB_6 + KB_SHFT ; Keypad 6 key shifted
22 04B8 1B 43 DB ESC, 'C'
23
24 04BA D7 DB KB_7 + KB_SHFT ; Keypad 7 key shifted
25 04BB 1B 40 DB ESC, '@'
26
27 04BD D8 DB KB_8 + KB_SHFT ; Keypad 8 key shifted
28 04BE 1B 41 DB ESC, 'A'
29
30 04C0 D9 DB KB_9 + KB_SHFT ; Keypad 9 key shifted
31 04C1 1B 4E DB ESC, 'N'
32
33 04C3 DA DB KB_DEC + KB_SHFT ; Keypad decimal key shifted
34 04C4 2E 00 DB ' ', NULL
35
36 04C6 DB KB_ENT + KB_SHFT ; Keypad enter key shifted
37 04C7 0D 00 DB CR, NULL
38
39 04C9 DC DB KB_DASH + KB_SHFT ; Keypad dash key shifted
40 04CA 2D 00 DB '-', NULL
41
42 04CC DD DB KB_COMMA + KB_SHFT ; Keypad comma key shifted
43 04CD 2C 00 DB ' ', NULL
44
45 001C KBPDTL EQU ($-KBPDT)/3 ; Table length

```

```

1      ; ; KBFNT - keyboard function table
2      ;
3      ; *KBFNT* contains the ASCII values to be transmitted by the
4      ; terminal when received from the keyboard.
5      ;
6      ; Table entries are: Keyboard data word followed by the
7      ; ASCII character to be transmitted if in ANSI mode followed
8      ; by the ASCII character to be transmitted in any other mode.
9
10
11      04CF      KBFNT      EQU      $
12
13      04CF      80          DB      KBLF1      ; Function key #1
14      04D0      53      53      DB      'S', 'S'      ; ESC O S, ESC S
15
16      04D2      81          DB      KBLF2      ; Function key #2
17      04D3      54      54      DB      'T', 'T'      ; ESC O T, ESC T
18
19      04D5      82          DB      KBLF3      ; Function key #3
20      04D6      55      55      DB      'U', 'U'      ; ESC O U, ESC U
21
22      04D8      83          DB      KBLF4      ; Function key #4
23      04D9      56      56      DB      'V', 'V'      ; ESC O V, ESC V
24
25      04DB      84          DB      KBLF5      ; Function key #5
26      04DC      57      57      DB      'W', 'W'      ; ESC O W, ESC W
27
28      04DE      85          DB      KBLF6      ; Function key #6 (blue)
29      04DF      50      50      DB      'P', 'P'      ; ESC O P, ESC P
30
31      04E1      86          DB      KBLF7      ; Function key #7 (red)
32      04E2      51      51      DB      'Q', 'Q'      ; ESC O Q, ESC Q
33
34      04E4      87          DB      KBLF8      ; Function key #8 (gray)
35      04E5      52      52      DB      'R', 'R'      ; ESC O R, ESC R
36
37      04E7      88          DB      KBLF9      ; Function key #9
38      04E8      58      C9      DB      'X', ('I'+80H)      ; ESC O X, ESC O I
39
40      0009      KBFNTL     EQU      ($-KBFNT)/3      ; Table length

```

*** Z-29 COMPUTER TERMINAL FIRMWARE VERSION 1.03 ***

```

1          ;|          BLINAD - build line address
2          ;
3          ;          *BLINAD* calculates character memory addresses using -XPOS-
4          ;          and -YPOS- and places the result into -LINADH/L-.
5          ;
6          ;
7          ;          ENTRY   none
8          ;
9          ;          EXIT    none
10         ;
11         ;          USES   A, PTR1
12         ;
13
14 04EA    C0    F0          BLINAD:    PUSH    B          ; Save register
15 04EC    74    47          MOV     A, #LORDER ; Get base of table
16 04EE    25    12          ADD     A, YPOS    ; Add in offset
17 04F0    F8          MOV     PTR1, A    ; Place into pointer
18 04F1    E6          MOV     A, @PTR1   ; Fetch pointer
19 04F2    75    F0    50    MOV     B, #NUMCHARS ; Set up for multiply
20 04F5    A4          MUL     AB          ; Do it
21 04F6    25    11          ADD     A, XPOS    ; Add in XPOS offset
22 04F8    F5    14          MOV     LINADL, A ; Save low order byte
23 04FA    E5    F0          MOV     A, B      ; Get high byte
24 04FC    34    50          ADDC   A, #HIGH (CHARMEM) ; Add carry and offset
25 04FE    F5    13          MOV     LINADH, A ; Save high order byte
26 0500    D0    F0          POP     B          ; Restore
27 0502    22          RET

```

```

1          ;;          CLA - calculate line address
2          ;
3          ;          *CLA* inputs line coordinates and calculates the current
4          ;          address of that coordinate to character memory.
5          ;
6          ;
7          ;          ENTRY   (A) = X-position
8          ;          (B) = Y-position
9          ;
10         ;          EXIT    (DPTR) = current address
11         ;
12         ;          USES    A, B, DPTR, TEMP, PTR1
13         ;
14
15 0503    FD          CLA:      MOV    TEMP, A          ; Save -XPOS-
16 0504    74    47    MOV    A, #LORDER      ; Get base of table
17 0506    25    F0    ADD    A, B           ; Add in -YPOS- offset
18 0508    F8    MOV    PTR1, A             ; Move into pointer
19 0509    E6    MOV    A, @PTR1           ; Get value from table
20 050A    75    F0    50    MOV    B, #NUMCHARS ; Set up for multiply
21 050D    A4    MUL    AB                 ; Do it
22 050E    2D    ADD    A, TEMP            ; Add in -XPOS- offset
23 050F    F5    82    MOV    DPL, A       ; Save low byte
24 0511    E5    F0    MOV    A, B        ; Get high byte
25 0513    34    50    ADDC   A, #HIGH (CHARMEM) ; Add memory offset and carry
26 0515    F5    83    MOV    DPH, A      ; Save high byte
27 0517    22    RET

```

```

1          ;:          PRLF - perform a reverse line feed
2          ;
3          ;          *PRLF* moves the cursor up one line in the video memory.
4          ;          If the cursor was already on the top line of the display,
5          ;          the display is scrolled down and the new line is filled
6          ;          with spaces.
7          ;
8          ;
9          ;          ENTRY   none
10         ;
11         ;          EXIT    none
12         ;
13         ;          USES   all
14         ;
15
16 0518    E5    12          PRLF:    MOV    A, YPOS          ; Get Y-position
17 051A    B5    17    2B    CJNE   A, TSCROLL, RL1        ; IF top of scroll region THEN
18 051D    85    18    F0    MOV    B, BFIX          ; clear bottom line
19 0520    15    F0    DEC    B          ; of the scrolling region
20 0522    12    0B9%    LCALL  CLRLINE
21 0525    74    47    MOV    A, #LORDER          ; Get top of table
22 0527    25    18    ADD    A, BFIX          ; Add in offset
23 0529    14    DEC    A
24 052A    F8    MOV    PTR1, A
25 052B    F9    MOV    PTR2, A
26 052C    19    DEC    PTR2
27 052D    86    05    MOV    TEMP, @PTR1          ; Save bottom to put on top
28 052F    E5    18    MOV    A, BFIX
29 0531    95    17    SUBB   A, TSCROLL
30 0533    14    DEC    A          ; Calc # times through loop
31 0534    FC    MOV    WORK, A
32 0535    C2    AF    CLR    EA          ; Disable for flicker
33 0537    E7          RLL:    MOV    A, @PTR2          ; REPEAT
34 0538    F6    MOV    @PTR1, A          ; exchange values
35 0539    18    DEC    PTR1
36 053A    19    DEC    PTR2          ; bump down
37 053B    DC    FA    DJNZ   WORK, RLL          ; UNTIL work = 0
38
39 053D    A6    05    MOV    @PTR1, TEMP          ; Put last value in
40 053F    D2    AF    SETB   EA          ; Enable interrupts again
41 0541    E5    12    MOV    A, YPOS          ; Keep same position
42 0543    F5    12          RLR:    MOV    YPOS, A
43 0545    91    EA    ACALL  BLINAD          ; Build line address
44 0547    22    RET          ; Return
45 0548    B4    00    01    RLI:    CJNE   A, #0, RL1A          ; IF top of screen THEN
46 054B    22    RET          ; return
47 054C    14          RLI1A:  DEC    A          ; ELSE bump up
48 054D    80    F4    SJMP   RLR          ; and return

```

```

1          ; ;          PCRLF - perform carriage return and/or line feed
2          ;
3          ;          *PCRLF* performs a carriage return and then performs
4          ;          a line feed if the auto line feed function is selected.
5          ;
6          ;
7          ;          ENTRY   none
8          ;
9          ;          EXIT    none
10         ;
11        ;          USES    A, B, DPTR, TEMP, PTR1
12        ;
13        ;
14 054F    B1    5C          PCRLF:    ACALL   PCR          ; Perform carriage return
15 0551    20    2D    0D          JB     AUTO LF, PLF      ; IF auto LF THEN do *PLF*
16 0554    22          RET          ; ELSE return
17
18
19
20
21         ; ;          PLFCR - perform line feed and/or carriage return
22         ;
23         ;          *PLFCR* performs a carriage return prior to performing a
24         ;          line feed if the auto carriage return function is selected.
25         ;
26         ;
27         ;          ENTRY   none
28         ;
29         ;          EXIT    none
30         ;
31        ;          USES    A, B, DPTR, TEMP, PTR1
32        ;
33        ;
34 0555    30    2C    09          PLFCR:    JNB     AUTO CR, PLF      ; IF no auto CR THEN do *PLF*
35 0558    B1    5C          ACALL   PCR          ; ELSE do carriage return
36 055A    80    05          SJMP    PLF          ; line feed and return

```



```
1      ; ; PCR - perform carriage return
2      ;
3      ; *PCR* moves the cursor to the beginning of the current line.
4      ;
5      ;
6      ; ENTRY none
7      ;
8      ; EXIT none
9      ;
10     ; USES A
11     ;
12     ;
13 055C 75 11 00 PCR: MOV XPOS, #0 ; Return to beginning of line
14 055F 81 EA AJMP BLINAD ; Build line address and return
```

```

1          ;:          PLF - perform line feed
2          ;
3          ;
4          ;          *PLF* moves the cursor down one line in the display memory.
5          ;          Cursor never moves out of the top fixed region. The display
6          ;          is scrolled up one line if cursor is just above the bottom
7          ;          fixed region. The cursor never moves into the 25th line.
8          ;
9          ;          ENTRY   none
10         ;
11         ;          EXIT   none
12         ;
13         ;          USES   all
14
15
16 0561    E5    12          PLF:      MOV     A, YPOS      ; Get Y-Position
17 0563    B4    18    01          CJNE   A, #MAXLINE, PLF1    ; IF on 25th line THEN
18 0566    22          RET          ; return
19 0567    04          PLF1:      INC     A          ; ELSE bump value
20 0568    B5    18    02          CJNE   A, BFIX, PLF2    ; IF bottom scroll region THEN
21 056B    80    04          SJMP    PLF3          ; scroll as usual
22 056D    B4    18    24          PLF2:      CJNE   A, #MAXLINE, PLFRET    ; IF not 24th line THEN bump
23 0570    22          RET          ; ELSE return
24 0571    85    17    F0          PLF3:      MOV     B, TSCROLL    ; Set up to clear
25 0574    12    0B96          LCALL  CLRLINE    ; Top line of scroll region
26 0577    74    47          MOV     A, #LORDER    ; Calculate pointers needed
27 0579    25    17          ADD     A, TSCROLL    ; For adjusting -LORDER-
28 057B    F8          MOV     PTR1, A
29 057C    F9          MOV     PTR2, A
30 057D    09          INC     PTR2
31 057E    86    05          MOV     TEMPA, @PTR1    ; Save top value for later
32 0580    E5    18          MOV     A, BFIX
33 0582    95    17          SUBB   A, TSCROLL    ; Calc number of times
34 0584    14          DEC     A          ; To go through loop
35 0585    FC          MOV     WORK, A
36 0586    C2    AF          CLR     EA          ; Stops any blinking
37
38 0588    E7          PLFLP:      MOV     A, @PTR2    ; REPEAT
39 0589    F6          MOV     @PTR1, A    ; switch entries
40 058A    08          INC     PTR1
41 058B    09          INC     PTR2    ; bump pointers
42 058C    DC    FA          DJNZ   WORK, PLFLP    ; UNTIL work = 0
43
44 058E    A6    05          MOV     @PTR1, TEMPA    ; Place last value
45 0590    D2    AF          SETB   EA          ; Enable interrupts
46 0592    E5    12          MOV     A, YPOS    ; Keep same position
47 0594    F5    12          PLFRET: MOV     YPOS, A    ; Update -YPOS-
48 0596    81    EA          AJMP   BLINAD    ; Build line address and return

```

```

1          ;:          CLR TABS - clear all tabs
2          ;
3          ;          *CLR TABS* clears all tab settings.
4          ;
5          ;
6          ;          ENTRY  none
7          ;
8          ;          EXIT   none
9          ;
10         ;          USES   A, PTR1, INDX1
11
12
13 0598    78    29          CLR TABS:    MOV    PTR1, #TABTAB    ; Init pointer to tab table
14 059A    E4          CLR    A          ; Init value to place in table
15 059B    7A    0A          MOV    INDX1, #10        ; Ten bytes in the tab table
16
17 059D    F6          CLR TB:    MOV    @PTR1, A          ; REPEAT zero byte
18 059E    08          INC    PTR1        ; bump pointer
19 059F    DA    FC          DJNZ  INDX1, CLR TB    ; UNTIL index = 0
20 05A1    22          RET

```

```

1          ; ;          SETTAB - change tab settings
2          ;
3          ;          *SETTAB* sets or clears a tab position depending on the
4          ;          values passed to it.
5          ;
6          ;
7          ;          ENTRY   (A) = tab position from 0..79
8          ;          'F0' = value to place into tab position
9          ;
10         ;          EXIT   none
11         ;
12         ;          USES   A, B, PTR1, WORK, INDX1
13
14
15 05A2    F5    F0          SETTAB:    MOV    B, A          ; Save position to set/clear
16 05A4    54    F8          ANL    A, #11111000B      ; Make it a multiple of 8
17 05A6    FC          MOV    WORK, A          ; Save as a start for counting
18 05A7    03          RR    A          ; Divide by 8
19 05A8    03          RR    A
20 05A9    03          RR    A
21 05AA    24    29          ADD    A, #TABTAB      ; Add offset to tab table
22 05AC    F8          MOV    PTR1, A          ; Init pointer
23 05AD    E6          MOV    A, @PTR1        ; Get tab byte
24 05AE    7A    08          MOV    INDX1, #8      ; Loop through all 8 bits
25 05B0    C5    F0          STB1:    XCH    A, B          ; Get count and save byte
26 05B2    B5    04    04    CJNE   A, WORKA, STB2      ; If position if found
27 05B5    A2    D5          MOV    C, F0          ; Get value desired
28 05B7    92    F7          MOV    B.7, C        ; Place into tab byte
29 05B9    C5    F0          STB2:    XCH    A, B          ; Change back
30 05BB    23          RL    A          ; Rotate to next tab position
31 05BC    0C          INC    WORK          ; Bump count
32 05BD    DA    F1          DJNZ  INDX1, STB1      ; Until all 8 bits done
33 05BF    F6          MOV    @PTR1, A        ; Replace the tab byte
34 05C0    22          RET

```

```

1          ;:          TAB - horizontal tab routine
2          ;
3          ;          *TAB* gets current position and then does a search for the
4          ;          next tab stop. If none is found then the default is the last
5          ;          column position.
6          ;
7          ;
8          ;          ENTRY   none
9          ;
10         ;          EXIT    none
11         ;
12         ;          USES   A, B, PTR1, WORK, TEMP, INDX1/2
13         ;
14
15 05C1     E5     11          TAB:      MOV     A, XPOS          ; Get current position
16 05C3     FD          MOV     TEMP, A      ; Save position to tab from
17 05C4     54     F8          ANL     A, #11111000B      ; Make a multiple of 8
18 05C6     FC          MOV     WORK, A     ; Save as a start for count
19 05C7     03          RR      A          ; Divide by 8
20 05C8     03          RR      A
21 05C9     03          RR      A
22 05CA     F5     F0          MOV     B, A          ; Save temporary byte offset
23 05CC     24     29          ADD     A, #TABTAB      ; Add offset to tab table
24 05CE     F8          MOV     PTR1, A     ; Initialize pointer
25 05CF     74     0A          MOV     A, #10
26 05D1     95     F0          SUBB   A, B          ; Calc # times needed in loop
27 05D3     FA          MOV     INDX1, A    ; Place into index
28 05D4     C2     D5          CLR     F0          ; F0 = hunting for current PoD
29
30 05D6     EA          TBL1:    MOV     A, @PTR1      ; REPEAT set tab byte
31 05D7     30     D5     02    JNB    F0, TB6      ; IF not looking for position
32 05DA     60     17          JZ     TB1          ; quick check to exit
33 05DC     7B     08          MOV     INDX2, #8    ; look through the 8 bits
34          ;          REPEAT
35 05DE     20     D5     09    TBL2:    JB     F0, TB3      ; IF looking for current
36 05E1     CD          XCH     A, TEMP      ; set original position
37 05E2     B5     04     02    CJNE   A, WORKA, TB4 ; IF equal to original
38 05E5     D2     D5          SETB   F0          ; flag it
39 05E7     CD          XCH     A, TEMP      ; set current position
40 05E8     80     03          SJMP  TB2          ; ELSE looking for tab
41 05EA     20     E7     0F    TBL3:    JB     ACC.7, TBR   ; IF tab set THEN exit
42 05ED     23          TBL2:    RL      A          ; rotate to next
43 05EE     0C          INC     WORK        ; bump count
44 05EF     DB     ED          DJNZ  INDX2, TBL2   ; UNTIL bit count = 0
45
46 05F1     80     04          SJMP  TB5          ; IF need to bump by eight
47 05F3     74     08          TBL4:    MOV     A, #8
48 05F5     2C          ADD     A, WORK      ; bump count by eight
49 05F6     FC          MOV     WORK, A
50 05F7     08          TBL5:    INC     PTR1        ; bump pointer to next byte
51 05F8     DA     DC          DJNZ  INDX1, TBL1   ; UNTIL table is done
52
53 05FA     7C     4F          MOV     WORK, #MAXCHAR ; Default value if not found
54
55 05FC     8C     11          TBR:    MOV     XPOS, WORK ; Set next tab position
56 05FE     91     EA          ACALL BLINAD      ; Build new address
57 0600     21     A9          JMP     SPF        ; Skip any protected fields

```

```

1          ; ;          BTAB - horizontal back tab routine
2          ;
3          ;          *BTAB* gets current position and then does a search for the
4          ;          previous tab stop. If none is found then the default is the
5          ;          first column position.
6          ;
7          ;
8          ;          ENTRY   none
9          ;
10         ;          EXIT   none
11         ;
12         ;          USES   A, B, PTR1, WORK, TEMP, INDX1/2
13         ;
14
15 0602     E5     11          BTAB:     MOV     A, XPOS          ; Position to compare with
16 0604     60     19          JZ      BTR          ; IF first column THEN exit
17 0606     14          DEC     A          ; Decrement for compare
18 0607     75     11     00     MOV     XPOS, #0        ; Start looking from first pos
19
20 060A     85     11     F0     BTL:     MOV     B, XPOS          ; REPEAT save previous position
21 060D     C0     E0          PUSH    ACC          ; save compare value
22 060F     C0     F0          PUSH    B          ; save previous position
23 0611     B1     C1          ACALL   TAB          ; tab to next stop
24 0613     D0     F0          POP     B          ; restore previous position
25 0615     D0     E0          POP     ACC          ; restore compare value
26 0617     B5     11     00     CJNE   A, XPOS, BTL1
27 061A     50     EE          BTL1:     JNC     BTL          ; UNTIL next >= current pos
28
29 061C     85     F0     11     MOV     XPOS, B          ; Get previous position
30 061F     81     EA          BTR:     JMP     BLINAD         ; Calc new address and return

```

*** Z-29 COMPUTER TERMINAL FIRMWARE VERSION 1.03 ***

```

1      ;:          HTS - horizontal tab set
2      ;
3      ;          *HTS* sets tab at current position.
4      ;
5      ;
6      ;          ENTRY   none
7      ;
8      ;          EXIT    none
9      ;
10     ;          USES    all
11     ;
12     ;
13 0621  D2    D5      HTS:      SETB   F0          ; Set tab
14 0623  E5    11      HTS1:     MOV    A, XPOS       ; Get position
15 0625  A1    A2      ;          AJMP   SETTAB        ; Execute and return
16     ;
17     ;
18     ;
19     ;
20     ;:          HTC - Horizontal tab clear
21     ;
22     ;          *HTC* Clears tab at current position.
23     ;
24     ;
25     ;          ENTRY   none
26     ;
27     ;          EXIT    none
28     ;
29     ;          USES    all
30     ;
31     ;
32 0627  C2    D5      HTC:      CLR    F0          ; Clear tab
33 0629  80    F8      ;          SJMP   HTS1         ; Execute and return
34     ;
35     ;
36     ;
37     ;
38     ;:          ATBC - ANSI tabulation clear
39     ;
40     ;          *ATBC* performs the specified tab controls.
41     ;
42     ;
43     ;          ENTRY   none
44     ;
45     ;          EXIT    none
46     ;
47     ;          USES    all
48     ;
49     ;
50 062B  12    09D1    ATBC:     LCALL  GNP          ; Get parameter
51 062E  60    F7      ;          JZ     HTC          ; IF 0 THEN hor tab clear
52 0630  B4    03    02      ;          CJNE  A, #3, AT2       ; ELSE IF 3 THEN
53 0633  A1    98      ;          AJMP  CLRTABS        ; clear all tabs
54 0635  22      AT2:     RET          ; ELSE return

```

*** Z-29 COMPUTER TERMINAL FIRMWARE VERSION 1.03 ***

```

1          ;;          HTAB - Hazeltine tab routine
2          ;
3          ;          *HTAB* performs the Hazeltine tab function.
4          ;
5          ;
6          ;          ENTRY   none
7          ;
8          ;          EXIT    none
9          ;
10         ;          USES   all
11         ;
12         ;
13 0636    C2    D5          HTAB:    CLR    F0          ; Flag = FALSE
14 0638    E5    11          MOV    A, XPOS
15 063A    25    12          ADD    A, YPOS          ; Check for home position
16
17 063C    70    02          JNZ    HT0          ; IF home position THEN
18 063E    D2    D5          SETB   F0          ; flag = TRUE
19
20 0640    C0    11          HT0:    PUSH   XPOS          ; Save current position
21 0642    C0    12          PUSH   YPOS
22 0644    75    3F    80    MOV    PFIELD, #10000000B ; Make normal protected
23 0647    31    A9          ACALL  SPF          ; Skip over foreground
24 0649    E5    11          MOV    A, XPOS
25 064B    25    12          ADD    A, YPOS          ; Check for home position
26
27 064D    70    03          JNZ    HT1          ; IF home position AND
28 064F    30    D5    09    JNB    F0, HT2          ; IF that is old pos THEN
29 0652    75    3F    08    HT1:    MOV    PFIELD, #00001000B ; make half protected
30 0655    31    A9          ACALL  SPF          ; skip over background
31 0657    E5    11          MOV    A, XPOS
32 0659    25    12          ADD    A, YPOS          ; check for home position
33
34 065B    75    3F    00    HT2:    MOV    PFIELD, #0          ; Clear protected fields
35
36 065E    60    05          JZ     HT3          ; IF position not home THEN
37 0660    D0    E0          POP    ACC          ; remove old position
38 0662    D0    E0          POP    ACC          ; and return
39 0664    22          RET
40
41 0665    D0    12          HT3:    POP    YPOS          ; ELSE
42 0667    D0    11          POP    XPOS          ; use previous position
43 0669    81    EA          AJMP  BLINAD          ; update and return

```



```

1 ..... ;:..... RING = ring bell .....
2 ..... ;
3 ..... ; *RING* rings the bell on the keyboard. If the input FIFO
4 ..... ; has a bell as the next character it is dropped. This is
5 ..... ; so that the terminal can keep up with multiple bells and
6 ..... ; communicate to the keyboard.
7 ..... ;
8 ..... ;
9 ..... ; ENTRY none .....
10 ..... ;
11 ..... ; EXIT none .....
12 ..... ;
13 ..... ; USES none .....
14 ..... ;
15 ..... ;
16 066B 74 81 RING: MOV A, #KBC_BELL .....
17 066D 51 6D ACALL PCKB ; Output command to ring bell .....
18 ..... ;
19 066F 51 1B RGL: ACALL LCIF ; REPEAT set next input char .....
20 0671 40 07 JC RGR ; IF no character THEN exit .....
21 0673 B4 07 04 CJNE A, #BELL, RGR ; IF character = bell THEN .....
22 0676 31 F6 ACALL FCIF ; fetch character and drop .....
23 0678 80 F5 SJMP RGL ; UNTIL char = bell .....
24 067A 22 RGR: RET

```

*** Z-29 COMPUTER TERMINAL FIRMWARE VERSION 1.03 ***

```

1          ; ;          ESCCODE - escape code received
2          ;
3          ;          *ESCCODE* determines which mode the terminal is in and
4          ;          sets the dispatch address to the proper routine.
5          ;
6          ;
7          ;          ENTRY   none
8          ;
9          ;          EXIT    none
10         ;
11        ;          USES    none
12        ;
13        ;
14 067B    12      102D      ESCCODE:      LCALL   R2_ESC          ; Escape hook
15
16 067E    75      16       97          MOV     DSADRL, #LOW (ANSIESC) ; ANSI dispatch address
17 0681    75      15       06          MOV     DSADRH, #HIGH (ANSIESC)
18
19          IFC     NE, HIGH(ANSIESC)-HIGH(ZDSESC)
20          ERROR  ; 'ZDSESC' IS NOT THE SAME AS 'ANSIESC'
21          ENDC
22          IFC     NE, HIGH(ANSIESC)-HIGH(ADM3ESC)
23          ERROR  ; 'ADM3ESC' IS NOT THE SAME AS 'ANSIESC'
24          ENDC
25          IFC     NE, HIGH(ANSIESC)-HIGH(HAZESC)
26          ERROR  ; 'HAZESC' IS NOT THE SAME AS 'ANSIESC'
27          ENDC
28
29 0684    20      40       0F          JB     ANSI, ESECRET          ; IF not ANSI mode THEN
30 0687    75      16       B8          MOV     DSADRL, #LOW (ZDSESC) ; ZDS dispatch address
31
32 068A    20      41       09          JB     ZDS, ESECRET          ; IF not ZDS mode THEN
33 068D    75      16       A7          MOV     DSADRL, #LOW (ADM3ESC) ; ADM 3 dispatch address
34
35 0690    20      42       03          JB     ADM3, ESECRET         ; IF not ADM 3 mode THEN
36 0693    75      16       B0          MOV     DSADRL, #LOW (HAZESC) ; Hazeltine dispatch address
37 0696    22          ECRET:      RET     ; return

```

Z-29 COMPUTER TERMINAL FIRMWARE VERSION 1.03.

```

1 ..... ;: ANSIESC - ANSI escape parser
2 ..... ;
3 ..... ; *ANSIESC# parses the first character following an ESC when
4 ..... ; in the ANSI mode.
5 ..... ;
6 ..... ;
7 ..... ; ENTRY (A) = character to parse
8 ..... ;
9 ..... ; EXIT none
10 ..... ;
11 ..... ; USES all
12 .....
13 .....
14 0697 C2 18 ANSIESC: CLR PSDF ; Flag first time through *PSD*
15 0698 C2 19 CLR GNP# ; Flag first time through *GNP*
16 069B 75 F0 0C MOV B, #ANSITL ; ANSI mode table parameters
17 069E 90 0798 MOV DPTR, #ANSIT
18 .....
19 06A1 12 082F AESC1: LCALL SETNORM ; Restore dispatch address
20 06A4 02 0836 LJMPL STJMP ; Jump to any routine
21 .....
22 .....
23 .....
24 .....
25 ..... ;: ADM3ESC - ADM 3 escape parser
26 ..... ;
27 ..... ; *ADM3ESC# parses the character received to do the proper
28 ..... ; routine, if any, for ADM 3 mode.
29 ..... ;
30 ..... ;
31 ..... ; ENTRY (A) = first character after ESC sequence
32 ..... ;
33 ..... ; EXIT none
34 ..... ;
35 ..... ; USES all
36 .....
37 .....
38 06A7 12 082F ADM3ESC: LCALL SETNORM ; Restore dispatch address
39 .....
40 06AA B4 3D 31 CJNE A, #'=', ZE2 ; IF not '=' THEN return
41 06AD 02 0CD6 LJMPL CUA ; ELSE same as cursor address

```

*** Z-29 COMPUTER TERMINAL FIRMWARE VERSION 1.03 ***

```
1          ; ; HAZESC - Hazeltine 1500 escape (tilde) parser
2          ;
3          ; *HAZESC* parses the character received to do the proper
4          ; routine, if any, for Hazeltine 1500 mode.
5          ;
6          ;
7          ; ENTRY (A) = first character after ESC (tilde) sequence
8          ;
9          ; EXIT none
10         ;
11        ; USES all
12
13
14 0&B0    75    F0    10    HAZESC:    MOV    B, #HAZTL    ; Hazeltine table parameters
15 0&B3    90    0768    MOV    DPTR, #HAZT
16 0&B6    80    E9    SJMP   AESC1    ; Look through table
```

```

1      ; ; ZDSESC - ZDS escape sequence
2      ;
3      ; *ZDSESC* parses the character received to do the proper ZDS
4      ; routine if any.
5      ;
6      ;
7      ; ENTRY (A) = first character after ESC sequence
8      ;
9      ; EXIT none
10     ;
11     ; USES all
12
13
14 06B8 12 082F ZDSESC: LCALL SETNORM ; Restore dispatch address
15
16 06BB B4 23 03 CJNE A, #'%', ZE1A ; IF transmit Pape THEN
17 06BE 02 1036 JMP R2_TP ; do it
18 06C1 B4 2D 02 ZE1A: CJNE A, #'-', ZE1B ; IF back tab THEN
19 06C4 C1 02 AJMP BTAB ; do it
20 06C6 B4 2E 03 ZE1B: CJNE A, #'./', ZE1C ; IF tab functions THEN
21 06C9 02 0ED3 JMP ZTAB ; do it
22
23 06CC C3 ZE1C: CLR C ; Set up to
24 06CD 94 3C SUBB A, #'<' ; Normalize into ranse
25 06CF 40 0D JC ZE2 ; IF out of ranse THEN return
26
27 06D1 23 RL A ; ELSE mult by 2
28 06D2 FD MOV TEMP, A ; save value
29 06D3 24 0A ADD A, #10 ; add code offset to low
30 06D5 83 MOVC A, @A+PC ; set low byte
31 06D6 C0 E0 PUSH ACC ; put onto stack
32 06D8 ED MOV A, TEMP ; set value back
33 06D9 24 03 ADD A, #3 ; add code offset to high
34 06DB 83 MOVC A, @A+PC ; set high byte
35 06DC C0 E0 PUSH ACC ; put onto stack
36 06DE 22 ZE2: RET ; Jump to address
37
38 IFC NE, ZDST-#
39 ERROR ;TABLE 'ZDST' MUST FOLLOW
40 ENDC

```

1	;	;	ZDST - ZDS escape table
2	;	;	
3	;	;	
4	;	;	*ZDST* contains the second character in the range of
5	;	;	all escape sequences the Z-29 will respond to.
6	;	;	
7	;	;	Table entries are: Address of routine which performs the
8	;	;	requested operation in order of their ASCII sequence.
9	;	;	
10	06DF	0B03	ZDST: DW EAM ; < enter ANSI mode
11	06E1	0B4E	DW EKAM ; = enter alt keypad mode
12	06E3	0B51	DW XPAM ; > exit alt keypad mode
13	06E5	0767	DW UNDEF ; ? undefined
14	06E7	0B54	DW EICM ; @ enter insert char mode
15	06E9	0C8D	DW CUP ; A cursor up
16	06EB	0CA8	DW CDN ; B cursor down
17	06ED	0C64	DW CRT ; C cursor right
18	06EF	0C3D	DW CLFT ; D cursor left
19	06F1	0BAC	DW CLRS ; E clear entire display
20	06F3	0F39	DW EGM ; F enter graphic mode
21	06F5	0F3C	DW XGM ; G exit graphic mode
22	06F7	0C36	DW SCH ; H set cursor home
23	06F9	0518	DW PRLF ; I reverse index
24	06FB	0C08	DW EED ; J erase cursor to EOS
25	06FD	0BE0	DW EOL ; K erase cursor to EOL
26	06FF	0D47	DW PIL ; L perform insert line
27	0701	0D88	DW PDL ; M perform delete line
28	0703	0DF4	DW PDC ; N delete char
29	0705	0B58	DW XICM ; O exit insert char mode
30	0707	0767	DW UNDEF ; P undefined (blue)
31	0709	0767	DW UNDEF ; Q undefined (red)
32	070B	0767	DW UNDEF ; R undefined (gray)
33	070D	0767	DW UNDEF ; S undefined (F1)
34	070F	0767	DW UNDEF ; T undefined (F2)
35	0711	0767	DW UNDEF ; U undefined (F3)
36	0713	0767	DW UNDEF ; V undefined (F4)
37	0715	0767	DW UNDEF ; W undefined (F5)
38	0717	0767	DW UNDEF ; X undefined
39	0719	0CD6	DW CUA ; Y VT52 cursor addr. (param)
40	071B	0EAB	DW IDT ; Z VT52 identify
41	071D	0B3C	DW EHSM ; [Enter hold screen mode
42	071F	0B43	DW XHSM ; \ Exit hold screen mode
43	0721	1039	DW R2_T25L ;] xmit 25th line
44	0723	1033	DW R2_TL ; ^ transmit line
45	0725	1030	DW R2_TC ; _ transmit character
46	0727	103C	DW R2_PRNT ; \ print page
47	0729	0767	DW UNDEF ; a undefined
48	072B	0BF1	DW EBD ; b erase display to cursor
49	072D	0767	DW UNDEF ; c undefined
50	072F	0767	DW UNDEF ; d undefined
51	0731	0767	DW UNDEF ; e undefined
52	0733	0767	DW UNDEF ; f undefined
53	0735	0767	DW UNDEF ; g undefined
54	0737	0767	DW UNDEF ; h undefined
55	0739	0EB3	DW IDTT ; i identify terminal type
56	073B	0EE8	DW SCP ; j save cursor position
57	073D	0EF4	DW USCP ; k restore cursor position

*** Z-29 COMPUTER TERMINAL FIRMWARE VERSION 1.03 ***

1	073F	0BDB	DW	EEL	; l	erase entire line
2	0741	0767	DW	UNDEF	; m	undefined
3	0743	0E83	DW	CPR	; n	cursor position report
4	0745	0BCB	DW	EBL	; o	erase line to cursor
5	0747	0F33	DW	ERVLM	; p	enter reverse video mode
6	0749	0F36	DW	XRVM	; q	exit reverse video mode
7	074B	0E3D	DW	ZDSSBR	; r	modify baud rate (param)
8	074D	0F08	DW	ZATR	; s	set video attributes
9	074F	0B48	DW	EKSM	; t	enter keypad shifted mode
10	0751	0B4B	DW	XKSM	; u	exit keypad shifted mode
11	0753	0AFD	DW	WEOL	; v	enter wrap around mode
12	0755	0B00	DW	DEOL	; w	exit wrap around mode
13	0757	0BE7	DW	SMS	; x	set modes (param)
14	0759	092C	DW	RMS	; y	reset modes (param)
15	075B	0AFA	DW	RAMP	; z	reset to power up
16	075D	0FB3	DW	EKI	; (enable keyboard
17	075F	0767	DW	UNDEF	;)	undefined
18	0761	0FB9	DW	DKI	;)	disable keyboard
19	0763	0767	DW	UNDEF	; .	undefined
20	0765	0767	DW	UNDEF	; DEL	undefined
21						
22						
23						
24						
25			;;	UNDEF - undefined escape sequence		
26			;			
27			;	*UNDEF* is used in ZDS escape parsing for undefined entries		
28			;			
29			;			
30			;	ENTRY	none	
31			;			
32			;	EXIT	none	
33			;			
34			;	USES	none	
35						
36						
37	0767	22	UNDEF:	RET		; Undefined ESC sequence

```

1          ;;          HAZT - Hazeltine 1500 escape (tilde) table
2          ;
3          ;          *HAZT* contains the second character of the Hazeltine
4          ;          escape (tilde) table.
5          ;
6          ;          Table entries are: The second character of the Hazeltine
7          ;          escape (tilde) sequence followed by the address of the routine
8          ;          which performs the requested function.
9
10
11         0768          HAZT          EQU          $
12
13 0768     12          DB          12H          ; ~ DC2
14 0769     0C36       DW          SCH          ; Set cursor home
15
16 076B     0C          DB          0CH          ; ~ FF
17 076C     0C8D       DW          CUP          ; Cursor UP
18
19 076E     0B          DB          0BH          ; ~ VT
20 076F     0CA8       DW          CDN          ; Cursor down
21
22 0771     1C          DB          1CH          ; ~ FS
23 0772     0BAC       DW          CLRS         ; Clear screen and home
24
25 0774     1D          DB          1DH          ; ~ GS
26 0775     0BC2       DW          CLFO         ; Clear foreground
27
28 0777     0F          DB          0FH          ; ~ SI
29 0778     0BE0       DW          EOL          ; Erase to end of line
30
31 077A     18          DB          18H          ; ~ CAN
32 077B     0C08       DW          EED          ; Erase to end of display
33
34 077D     17          DB          17H          ; ~ ETB
35 077E     0C19       DW          HEED         ; Erase to eod (with backward)
36
37 0780     15          DB          15H          ; ~ NAK
38 0781     0FB9       DW          DKI          ; Disable keyboard input
39
40 0783     06          DB          06H          ; ~ ACK
41 0784     0FB3       DW          EKI          ; Enable keyboard input
42
43 0786     1A          DB          1AH          ; ~ SUB
44 0787     0D47       DW          PIL          ; Perform insert line
45
46 0789     13          DB          13H          ; ~ DC3
47 078A     0D88       DW          PDL          ; Perform delete line
48
49 078C     19          DB          19H          ; ~ EM
50 078D     0F2A       DW          EHALF        ; Enter half intensity
51
52 078F     1F          DB          1FH          ; ~ US
53 0790     0F26       DW          XATR          ; Exit attributes
54
55 0792     11          DB          11H          ; ~ DC1 <col> <row>
56 0793     0CD6       DW          CUA          ; Cursor address
57

```


*** Z-29 COMPUTER TERMINAL FIRMWARE VERSION 1.03 ***

1	0795	05	DB	05H	; ~ ENG
2	0796	0E83	DW	CPR	; Cursor position report
3					
4	0010	HAZTL	EQU	(\$-HAZT)/3	; Table length

```

1          ;:          ANSIT - ANSI escape table
2          ;
3          ;          *ANSIT* contains the second character of the ANSI escape table
4          ;
5          ;          Table entries are: The second character of the ANSI escape
6          ;          sequence followed by the address of the routine which performs
7          ;          the requested function.
8          ;
9
10         0798          ANSIT          EQU          $
11
12 0798          5B          DB          ^[          ; ESC [
13 0799          07BC          DW          ELB          ; Escape left bracket
14
15 079B          28          DB          ^([          ; ESC (
16 079C          0F3F          DW          GODES          ; GO designator
17
18 079E          29          DB          ^)          ; ESC )
19 079F          0F47          DW          GIDES          ; GI designator
20
21 07A1          37          DB          ^_          ; ESC _
22 07A2          0EE8          DW          SCP          ; Save cursor position
23
24 07A4          38          DB          ^8          ; ESC 8
25 07A5          0EF4          DW          USCP          ; Unsave cursor position
26
27 07A7          3D          DB          ^=          ; ESC =
28 07A8          0B4E          DW          EKAM          ; Enter keypad alternate mode
29
30 07AA          3E          DB          ^>          ; ESC >
31 07AB          0B51          DW          XKAM          ; Exit keypad alternate mode
32
33 07AD          4D          DB          ^M          ; ESC M
34 07AE          0518          DW          PRLF          ; Reverse index (rev line feed)
35
36 07B0          63          DB          ^c          ; ESC c
37 07B1          0AF6          DW          ARAMP          ; ANSI reset to power up
38
39 07B3          44          DB          ^D          ; ESC D
40 07B4          0561          DW          PLF          ; Perform line feed
41
42 07B6          48          DB          ^H          ; ESC H
43 07B7          0621          DW          HTS          ; Horizontal tab set
44
45 07B9          23          DB          ^#          ; ESC #
46 07BA          0ADF          DW          APRNT          ; Print page
47
48         000C          ANSITL          EQU          ($-ANSIT)/3          ; Table length

```

```

1          ;: ELB - escape left bracket
2          ;
3          ;
4          ; *ELB* is a continuation of the escape sequence processing
5          ; for ANSI escape sequences. The final character of the
6          ; sequence is decoded with or without a preceding parameter
7          ; string and control is passed on to the associated routine.
8          ;
9          ; ENTRY none
10         ;
11         ; EXIT to requested routine
12         ;
13         ; USES all
14
15
16 07BC    12    082A    ELB:    LCALL  SETDISP    ; Set dispatch and return
17
18 07BF    12    0971    LCALL  PSD      ; Get parameter string
19 07C2    50    78      JNC    STRET    ; IF not done THEN return
20 07C4    12    082F    LCALL  SETNORM  ; ELSE restore dispatch address
21 07C7    75    F0      MOV    R, #ELBTL ; (R) = table length
22 07CA    90    07D0    MOV    DPTR, #ELBT ; (DPTR) = ESC I table
23 07CD    02    0836    LJMP  SJMP     ; Jump to any routine

```

```

1          ;:          ELBT - escape left bracket table
2          ;
3          ;
4          ;          *ELBT* contains the third and/or final character of the
5          ;          ANSI escape sequence for ESC [ Pn F
6          ;
7          ;          Table entries are: Final character of ESC [ Pn F sequence
8          ;          followed by address of the routine which performs the
9          ;          requested function.
10         ;
11         07D0          ELBT          EQU          $
12
13 07D0      3E          DB          '<>'          ; ESC [ > Ps F
14 07D1      0898      DW          A2M          ; ANSI set mode #2
15
16 07D3      3F          DB          '<?'        ; ESC [ ? Ps F
17 07D4      0880      DW          A1M          ; ANSI set mode #1
18
19 07D6      41          DB          '<A'        ; ESC [ Pn A
20 07D7      0C9D      DW          ACUP        ; ANSI cursor up
21
22 07D9      42          DB          '<B'        ; ESC [ Pn B
23 07DA      0CBB      DW          ACDN        ; ANSI cursor down
24
25 07DC      43          DB          '<C'        ; ESC [ Pn C
26 07DD      0C6E      DW          ACRT        ; ANSI cursor right
27
28 07DF      44          DB          '<D'        ; ESC [ Pn D
29 07E0      0C46      DW          ACLFT       ; ANSI cursor left
30
31 07E2      48          DB          '<H'        ; ESC [ Pn ; Pn H
32 07E3      09FA      DW          APCA        ; ANSI perform cursor address
33
34 07E5      4A          DB          '<J'        ; ESC [ Ps J
35 07E6      0A1A      DW          EID        ; Erase in display
36
37 07E8      4B          DB          '<K'        ; ESC [ Ps K
38 07E9      0A2B      DW          EIL        ; Erase in line
39
40 07EB      4C          DB          '<L'        ; ESC [ Pn L
41 07EC      0D7D      DW          APIL        ; ANSI perform insert line
42
43 07EE      4D          DB          '<M'        ; ESC [ Pn M
44 07EF      0DB6      DW          APDL        ; ANSI perform delete line
45
46 07F1      50          DB          '<P'        ; ESC [ Pn P
47 07F2      0E32      DW          APDC        ; ANSI perform delete char
48
49 07F4      5A          DB          '<Z'        ; ESC [ Pn Z
50 07F5      0CC6      DW          APBT        ; ANSI perform back tab
51
52 07F7      63          DB          '<c'        ; ESC [ Pn c
53 07F8      0EC3      DW          ADA        ; ANSI device attributes
54
55 07FA      66          DB          '<f'        ; ESC [ Pn ; Pn f
56 07FB      09FA      DW          APCA        ; ANSI perform cursor address
57

```

1	07FD	67	DB	'g'	; ESC [Ps g
2	07FE	062B	DW	ATBC	; ANSI tabulation clear
3					
4	0800	68	DB	'h'	; ESC [Ps h
5	0801	083D	DW	ASM	; ANSI set mode
6					
7	0803	6C	DB	'l'	; ESC [Ps l
8	0804	085F	DW	ARM	; ANSI reset mode
9					
10	0806	6D	DB	'm'	; ESC [Ps m
11	0807	0A3B	DW	ASGM	; ANSI set graphics mode
12					
13	0809	6E	DB	'n'	; ESC [Pn n
14	080A	0AAF	DW	ACPR	; ANSI cursor position report
15					
16	080C	70	DB	'p'	; ESC [P
17	080D	1030	DW	R2_TC	; Transmit page
18					
19	080F	72	DB	'r'	; ESC [Pn ; Pn r
20	0810	0D24	DW	DSR	; ANSI define scrolling region
21					
22	0812	73	DB	's'	; ESC [s
23	0813	0EEF	DW	ASCP	; ANSI save cursor position
24					
25	0815	75	DB	'u'	; ESC [u
26	0816	0F03	DW	AUSCP	; ANSI unsave cursor position
27					
28	0818	76	DB	'v'	; ESC [Pn v
29	0819	0F96	DW	SBLR	; Set blink rate
30					
31	081B	77	DB	'w'	; ESC [Pn w
32	081C	0AEA	DW	ASBR	; ANSI set baud rate
33					
34	081E	7A	DB	'z'	; ESC [Pn z
35	081F	0AF6	DW	ARAMP	; ANSI reset to power up
36					
37	0821	7B	DB	'{'	; ESC [Ps {
38	0822	0B7A	DW	PCLK	; Program clock
39					
40	0824	7D	DB	'}'	; ESC [Ps }
41	0825	0A65	DW	ASPF	; Set protected fields
42					
43	0827	40	DB	'@'	; ESC [Pn @
44	0828	0DE9	DW	APIC	; ANSI perform insert character
45					
46	001E	ELBTL	EQU	(\$-ELBT)/3	; Table length

```
1          ;;          SETDISP - set dispatch address
2          ;
3          ;          *SETDISP* sets the dispatch address to the address just
4          ;          following the call to this routine. This routine then
5          ;          executes a -RET-. Be carefull with this. A call to this
6          ;          routine does not return to back to the routine that called
7          ;          this one.
8          ;
9          ;
10         ;          ENTRY   none
11         ;
12         ;          EXIT    none
13         ;
14         ;          USES    none
15
16
17 082A    D0    15          SETDISP:    POP    DSADRH          ; Get high byte of data
18 082C    D0    16          POP    DSADRL          ; Get low byte of data
19 082E    22
20
21
22
23
24         ;;          SETNORM - set dispatch normal
25         ;
26         ;          *SETNORM* sets the dispatch address for processing characters
27         ;          back to the 'normal' address.
28         ;
29         ;
30         ;          ENTRY   none
31         ;
32         ;          EXIT    none
33         ;
34         ;          USES    none
35
36
37 082F    75    16    87          SETNORM:    MOV    DSADRL, #LOW (NORM)      ; Restore dispatch address
38 0832    75    15    00          MOV    DSADRH, #HIGH (NORM)
39 0835    22    RET
```

```

1 ..... ; ; STJMP = search table and jump
2 ..... ; ; STCALL = jump to routine in (DPTR)
3 ..... ; ;
4 ..... ; ; *STJMP* does a search table operation. If the data was found
5 ..... ; ; it does a jump to the address in the (DPTR), otherwise it
6 ..... ; ; does a return.
7 ..... ; ;
8 ..... ; ; *STCALL only does a jump to the address in the (DPTR).
9 ..... ; ;
10 ..... ; ;
11 ..... ; ; ENTRY (DPTR) = address to jump to
12 ..... ; ;
13 ..... ; ; EXIT none
14 ..... ; ;
15 ..... ; ; USES A
16 ..... ; ;
17 ..... ; ;
18 0834 31 F7 STJMP: ACALL XSTAB ; Search the table
19 0838 40 02 JC STRET ; IF carry is set THEN return
20 ..... ; ;
21 083A E4 STCALL: CLR A
22 083B 73 JMP @A+DPTR ; ELSE jump to address
23 ..... ; ;
24 083C 22 STRET: RET ; Return

```

```

1      ; ASM - ANSI set mode sequence
2      ;
3      ; *ASM* set the specified mode(s).
4      ;
5      ;
6      ; ENTRY none
7      ;
8      ; EXIT none
9      ;
10     ; USES all
11     ;
12     ;
13 083D 31 D1 ASM: ACALL GNP ; Get next (or first) parameter
14 083F 40 OE JC ASMR ; IF parameter THEN
15 0841 75 F0 MOV B, #ASMTL ; (B) = table length
16 0844 90 0850 MOV DPTR, #ASMT ; (DPTR) = "ESC [ Pn h" table
17 0847 31 F7 ACALL XSTAB ; search table
18 0849 40 04 JC ASMR ; IF found THEN
19 084B 11 3A ACALL STCALL ; jump to routine
20 084D 80 EE SJMP ASM ; and keep going
21     ;
22 084F 22 ASMR: RET
23     ;
24     ;
25     ;
26     ;
27     ; ASMT - ANSI set mode sequence table
28     ;
29     ; *ASMT* contains valid parameters for "ESC [ Pn h" sequence.
30     ;
31     ;
32     0850 ASMT EQU $
33     ;
34 0850 01 DB 1 ; ESC [ 1 h
35 0851 0B6E DW EGATM ; Enter expanded area transfer
36     ;
37 0853 02 DB 2 ; ESC [ 2 h
38 0854 0FB9 DW DKI ; Disable keyboard input
39     ;
40 0856 04 DB 4 ; ESC [ 4 h
41 0857 0B54 DW EICM ; Enter insert character mode
42     ;
43 0859 06 DB 6 ; ESC [ 6 h
44 085A 0B74 DW EERM ; Enter erasure mode
45     ;
46 085C 14 DB 20 ; ESC [ 20 h
47 085D 0B62 DW EACR ; Enable auto CR on LF
48     ;
49     0005 ASMTL EQU ($-ASMT)/3 ; Table length

```



```

1          ;:          ARM - ANSI reset mode sequence
2          ;
3          ;          *ARM* reset the specified mode(s).
4          ;
5          ;
6          ;          ENTRY   none
7          ;
8          ;          EXIT    none
9          ;
10         ;          USES   all
11        ;
12
13 085F    31    D1          ARM:    ACALL   GNP          ; REPEAT get parameter
14 0861    40    EC          JC       ASMR          ; IF no parameter THEN return
15 0863    75    F0    05   MOV     B, #ARMTL      ; (B) = table length
16 0866    90    0871      MOV     DPTR, #ARMT   ; (DPTR) = "ESC [ Pn ]" table
17 0869    31    F7          ACALL   XSTAB        ; search table
18 086B    40    E2          JC       ASMR          ; IF not found THEN return
19 086D    11    3A          ACALL   STCALL       ; call routine
20 086F    80    EE          SJMP    ARM          ; UNTIL forever
21
22
23
24
25         ;:          ARMT - ANSI reset mode sequence table
26         ;
27         ;          *ARMT* contains valid parameters for "ESC [ Pn ]" sequence
28
29
30         0871          ARMT      EQU     $
31
32 0871    01          DB       1          ; ESC [ 1 ]
33 0872    0B71      DW       XGATM       ; Exit guarded area transfer
34
35 0874    02          DB       2          ; ESC [ 2 ]
36 0875    0FB3      DW       EKI        ; Enable keyboard input
37
38 0877    04          DB       4          ; ESC [ 4 ]
39 0878    0B58      DW       XICM       ; Exit insert character mode
40
41 087A    06          DB       6          ; ESC [ 6 ]
42 087B    0B77      DW       XERM       ; Exit erasure mode
43
44 087D    14          DB       20         ; ESC [ 20 ]
45 087E    0B65      DW       XACR       ; Disable auto CR on LF
46
47         0005          ARMTL      EQU     ($-ARMT)/3      ; Table length

```

*** Z-29 COMPUTER TERMINAL FIRMWARE VERSION 1.03 ***

```

1          ;:          A1M - ANSI mode #1
2          ;
3          ;          *A1M* inputs the parameter string and final character for
4          ;          the ESC [ ? Pn F sequence.
5          ;
6          ;
7          ;          ENTRY   none
8          ;
9          ;          EXIT    none
10         ;
11         ;          USES   all
12
13
14 0880    C2    18          A1M:    CLR    PSDF          ; Clear *PSD* flag
15 0882    11    2A          ACALL  SETDISP       ; Set dispatch and return
16
17 0884    31    71          ACALL  PSD          ; Get parameter string
18 0886    50    C7          JNC    ASMR          ; IF not done THEN return
19 0888    11    2F          ACALL  SETNORM       ; ELSE restore dispatch
20 088A    75    F0    02    MOV    B, #EQMTL     ; (B) = table length
21 088D    90    0892       MOV    DPTR, #EQMT     ; (DPTR) = ESC [ ? table
22 0890    01    36          AJMP   STJMP        ; Jump to any routine
23
24
25
26
27         ;:          EQMT - escape [ ? Pn Ps table
28         ;
29         ;          *EQMT* contains the fourth and/or final character
30
31
32         0892          EQMT    EQU    $
33
34 0892    68          DB    'h'          ; ESC [ ? Pn h
35 0893    08B0       DW    A1SM         ; ANSI set mode #1
36
37 0895    6C          DB    'l'          ; ESC [ ? Pn l
38 0896    08CC       DW    AIRM        ; ANSI reset mode
39
40         0002          EQMTL    EQU    ($-EQMT)/3 ; Table length

```

*** Z-29 COMPUTER TERMINAL FIRMWARE VERSION 1.03 ***

```

1      ;:      A2M - ANSI mode #2
2      ;
3      ;      *A2M* inputs the parameter strings and final character for
4      ;      the ESC [ > Pn Ps sequence.
5      ;
6      ;
7      ;      ENTRY none
8      ;
9      ;      EXIT none
10     ;
11     ;      USES all
12
13
14 0898 C2 18 A2M: CLR PSDF ; Clear *PSD* flag
15 089A 11 2A ACALL SETDISP ; Set dispatch and return
16
17 089C 31 71 ACALL PSD ; Get parameter strings
18 089E 50 22 JNC AISR ; IF not done THEN return
19 08A0 11 2F ACALL SETNORM ; ELSE restore dispatch
20 08A2 75 F0 02 MOV B, #EGTTL ; (B) = table length
21 08A5 90 08AA MOV DPTR, #EGTI ; (DPTR) = ESC [ > table
22 08A8 01 36 AJMP STJMP ; Jump to any routine
23
24
25
26
27 ;:      EGTT - escape [ > Pn Ps table
28 ;
29 ;      *EGTT* contains the fourth and/or final character.
30
31
32 08AA EGTT EQU $
33
34 08AA 68 DB 'h' ; ESC [ > Pn h
35 08AB 08FF DW A2SM ; ANSI set mode #1
36
37 08AD 6C DB 'l' ; ESC [ > Pn l
38 08AE 0944 DW A2RM ; ANSI reset mode
39
40 0002 EGTTL EQU ($-EGTT)/3 ; Table length

```

*** Z-29 COMPUTER TERMINAL FIRMWARE VERSION 1.03 ***

```

1      ; ; AISM - ANSI mode #1 set mode sequence
2      ; ;
3      ; ; *AISM* set the specified mode(s).
4      ; ;
5      ; ;
6      ; ; ENTRY none
7      ; ;
8      ; ; EXIT none
9      ; ;
10     ; ; USES A, B, DPTR
11     ; ;
12     ; ;
13 08B0 31 D1 AISM: ACALL GNP ; Get next (or first) parameter
14 08B2 40 0E JC AISR ; IF parameter THEN
15 08B4 75 F0 03 MOV B, #A1STL ; (B) = table length
16 08B7 90 08C3 MOV DPTR, #A1ST ; (DPTR) = ESC [ ? Pn h table
17 08BA 31 F7 ACALL XSTAB ; Search table
18 08BC 40 04 JC AISR ; IF found THEN
19 08BE 11 3A ACALL STCALL ; Jump to routine
20 08C0 80 EE SJMP AISM ; and keep going
21     ; ;
22 08C2 22 AISR: RET
23     ; ;
24     ; ;
25     ; ;
26     ; ;
27     ; ; A1ST - ANSI mode #1 set mode table
28     ; ;
29     ; ; *A1SMT* contains valid parameters for ESC [ ? Pn h sequence.
30     ; ;
31     ; ;
32     08C3 A1ST EQU $
33     ; ;
34 08C3 02 DB 2 ; ESC [ ? 2 h
35 08C4 0B07 DW EZM ; Enter ZDS mode
36     ; ;
37 08C6 03 DB 3 ; ESC [ ? 3 h
38 08C7 0BAC DW CLRS ; Enter 132 column mode
39     ; ;
40 08C9 07 DB 7 ; ESC [ ? 7 h
41 08CA 0AED DW WEOL ; Wrap at end of line
42     ; ;
43     0003 A1STL EQU ($-A1ST)/3 ; Table length

```

*** Z-29 COMPUTER TERMINAL FIRMWARE VERSION 1.03 ***

```

1          ;:          AIRM - ANSI mode #1 reset mode sequence
2          ;
3          ;          *AIRM* resets the specified mode(s).
4          ;
5          ;
6          ;          ENTRY   none
7          ;
8          ;          EXIT    none
9          ;
10         ;          USES   A, B, DPTR
11
12
13 08CC    31    D1          AIRM:          ACALL  GNP          ; REPEAT set parameter
14 08CE    40    F2          JC          AIRS          ; IF no parameter THEN exit
15 08D0    75    F0    03    MOV        B, #AIRTL        ; (B) = table length
16 08D3    90    08DE      MOV        DPTR, #AIRT        ; (DPTR) = ESC [ ? Pn ] table
17 08D6    31    F7          ACALL  XSTAB          ; Search table
18 08D8    40    E8          JC          AIRS          ; IF found THEN
19 08DA    11    3A          ACALL  STCALL         ; jump to routine
20 08DC    80    EE          SJMP   AIRM          ; UNTIL forever
21
22
23
24
25         ;:          AIRT - ANSI mode #1 reset mode table
26         ;
27         ;          *AIRMT* contains valid parameters for ESC [ ? Pn ] sequence.
28
29
30         08DE          AIRT          EQU    $
31
32 08DE    02          DB          2          ; ESC [ ? 2 ]
33 08DF    0B07      DW          EZM         ; Enter VT52 mode
34
35 08E1    03          DB          3          ; ESC [ ? 3 ]
36 08E2    0BAC      DW          CLRS        ; Enter 80 column mode
37
38 08E4    07          DB          7          ; ESC [ ? 7 ]
39 08E5    0B00      DW          DEOL        ; Discard past end of line
40
41         0003          AIRTL          EQU    ($-AIRT)/3          ; Table length

```

*** Z-29 COMPUTER TERMINAL FIRMWARE VERSION 1.03 ***

```

1          ;|          SMS - set mode sequence
2          ;|
3          ;|          *SMS* sets the mode specified by the last character in the
4          ;|          sequence.
5          ;|
6          ;|
7          ;|          ENTRY   none
8          ;|
9          ;|          EXIT    none
10         ;|
11         ;|          USES   all
12         ;|
13
14 08E7    11    2A          SMS:      ACALL   SETDISP      ; Set dispatch and return
15
16 08E9    11    2F          ACALL   SETNORM      ; Restore dispatch address
17 08EB    C3          CLR      C
18 08EC    94    31          SUBB   A, #1      ; Subtract offset
19 08EE    40    0E          JC      SMSRET      ; Check for lower bounds
20 08F0    B4    09    00    CJNE   A, #(''-0'), SMS1
21 08F3    50    09          JNC    SMSRET      ; Check for upper bounds
22 08F5    04          INC     A      ; Bump up into range
23 08F6    75    F0    09    MOV    B, #SMSTL      ; (B) = table length
24 08F9    90    0911    MOV   DPTR, #SMST      ; (DPTR) = ESC x Pn table
25 08FC    01    36          AJMP  STJMP      ; Jump to any routine
26
27 08FE    22          SMSRET:    RET

```

```

1          ;:          A2SM - ANSI mode #2 set mode sequence
2          ;
3          ;          *A2SM* set the specified mode(s).
4          ;
5          ;
6          ;          ENTRY   none
7          ;
8          ;          EXIT    none
9          ;
10         ;          USES   A, B, DPTR
11
12
13 08FF    31    D1    A2SM:    ACALL  GNP          ; Get next (or first) parameter
14 0901    40    FB          JC      SMSRET       ; IF parameter THEN
15 0903    75    F0    09      MOV     B, #SMSTL     ; (B) = table length
16 0906    90    0911      MOV     DPTR, #SMST   ; (DPTR) = ESC [ > Pn h table
17 0909    31    F7          ACALL  XSTAB        ; Search table
18 090B    40    F1          JC      SMSRET       ; IF found THEN
19 090D    11    3A          ACALL  STCALL       ; jump to routine
20 090F    80    EE          JMP     A2SM          ; and keep going
21
22
23
24
25         ;:          SMST - set mode sequence table
26         ;
27         ;          *SMST* contains valid parameters for ESC x Pn sequence
28         ;          and ESC [ > Pn h sequence
29
30
31         0911    SMST      EQU     $
32
33 0911    01          DB      1          ; ESC x 1 ESC [ > 1 h
34 0912    0B0B      DW      E25L        ; Enable 25th line
35
36 0914    02          DB      2          ; ESC x 2 ESC [ > 2 h
37 0915    0B2D      DW      NKC         ; No keyboard click
38
39 0917    03          DB      3          ; ESC x 3 ESC [ > 3 h
40 0918    0B3C      DW      EHSM        ; Enter hold screen mode
41
42 091A    04          DB      4          ; ESC x 4 ESC [ > 4 h
43 091B    0B33      DW      SBC         ; Set "block" cursor
44
45 091D    05          DB      5          ; ESC x 5 ESC [ > 5 h
46 091E    0B5F      DW      DC         ; Disable cursor
47
48 0920    06          DB      6          ; ESC x 6 ESC [ > 6 h
49 0921    0B48      DW      EKSM        ; Enter keypad shifted mode
50
51 0923    07          DB      7          ; ESC x 7 ESC [ > 7 h
52 0924    0B4E      DW      EKAM        ; Enter keypad alternate mode
53
54 0926    08          DB      8          ; ESC x 8 ESC [ > 8 h
55 0927    0B68      DW      EALF        ; Enable auto LF on CR
56
57 0929    09          DB      9          ; ESC x 9 ESC [ > 9 h

```

1	092A	0B62	DW	EACR	: Enable auto CR on LF
2					
3	0009	SMSTL	EQU	(%-SMST)/3	: Table length


```

1 .....:; ..... RMS - reset mode sequence .....
2 .....:; .....
3 .....:; ..... *RMS* resets the mode specified by the last character in the
4 .....:; ..... sequence.
5 .....:; .....
6 .....:; .....
7 .....:; ..... ENTRY none
8 .....:; .....
9 .....:; ..... EXIT none
10 .....:; .....
11 .....:; ..... USES all
12 .....:; .....
13 .....:; .....
14 092C 11 2A RMS: ACALL SETDISP ; Set dispatch and return
15 .....:; .....
16 092E 11 2F ACALL SETNORM ; Restore dispatch address
17 0930 C3 CLR C
18 0931 94 31 SUBB A, #'1' ; Subtract offset
19 0933 40 0E JC RMSRET ; Check for lower bounds
20 0935 B4 09 00 CJNE A, #'9'-'0'), RMS1
21 0938 50 09 RMS1: JNC RMSRET ; Check for upper bounds
22 093A 04 INC A ; Bump up into range
23 093B 75 F0 09 MOV B, #RMSTL ; (B) = table length
24 093E 90 0956 MOV DPTR, #RMST ; (DPTR) = ESC y Pn table
25 0941 01 36 AJMP STJMP ; Jump to any routine
26 .....:; .....
27 0943 22 RMSRET: RET

```

```

1          ;|          A2RM - ANSI mode #2 reset mode sequence
2          ;|
3          ;|          *A2RM* reset the specified mode(s).
4          ;|
5          ;|
6          ;|          ENTRY   none
7          ;|
8          ;|          EXIT    none
9          ;|
10         ;|          USES   A, B, DPTR
11
12
13 0944    31    D1          A2RM:    ACALL  GNP          ; Get next (or first) parameter
14 0946    40    FB          JC      RMSRET         ; IF parameter THEN
15 0948    75    F0    09    MOV     B, #RMSTL        ; (B) = table length
16 094B    90    0956      MOV     DPTR, #RMST      ; (DPTR) = ESC [ > Pn ] table
17 094E    31    F7          ACALL  XSTAB         ; Search table
18 0950    40    F1          JC      RMSRET         ; IF found THEN
19 0952    11    3A          ACALL  STCALL        ; ... jump to routine
20 0954    80    EE          SJMP   A2RM          ; and keep going
21
22
23
24
25         ;|          RMST - ANSI reset mode sequence table
26         ;|
27         ;|          *RMST* contains valid parameters for ESC [ > Pn ] sequence.
28
29
30         0956          RMST      EQU     $
31
32 0956    01          DB      1          ; ESC y 1 ESC [ > 1 ]
33 0957    0B15      DW      D25L        ; Disable 25th line
34
35 0959    02          DB      2          ; ESC y 2 ESC [ > 2 ]
36 095A    0B26      DW      EKC         ; Enable keyboard click
37
38 095C    03          DB      3          ; ESC y 3 ESC [ > 3 ]
39 095D    0B43      DW      XHSM        ; Exit hold screen mode
40
41 095F    04          DB      4          ; ESC y 4 ESC [ > 4 ]
42 0960    0B37      DW      SUC         ; Set "underscore" cursor
43
44 0962    05          DB      5          ; ESC y 5 ESC [ > 5 ]
45 0963    0B5C      DW      EC         ; Enable cursor
46
47 0965    06          DB      6          ; ESC y 6 ESC [ > 6 ]
48 0966    0B4B      DW      XKSM        ; Exit keypad shifted mode
49
50 0968    07          DB      7          ; ESC y 7 ESC [ > 7 ]
51 0969    0B51      DW      XKAM        ; Exit keypad alternate mode
52
53 096B    08          DB      8          ; ESC y 8 ESC [ > 8 ]
54 096C    0B6B      DW      XALF        ; Disable auto LF on CR
55
56 096E    09          DB      9          ; ESC y 9 ESC [ > 9 ]
57 096F    0B65      DW      XACR        ; Disable auto CR on LF

```

1
2

0009

RMSTL

EQU

(\$-RMST)/3

; Table length

*** Z-29 COMPUTER TERMINAL FIRMWARE VERSION 1.03 ***

```

1          ;;          PSD - parameter string decoder
2          ;
3          ;          *PSD* inputs a parameter string of decimal numbers separated
4          ;          by a semicolon (to a maximum of 8) until the final character
5          ;          of the escape sequence (non decimal and not a semicolon) is
6          ;          inputed.
7          ;
8          ;
9          ;          ENTRY (A) = next parameter character
10         ;
11         ;          EXIT (A) = last character inputed (Ps usually)
12         ;          'C' = set if done decoding, clear otherwise
13         ;
14         ;          USES A, B, DPTR, TEMP
15
16
17 0971    20    18    0E    PSD:    JB    PSDF, PSDB          ; IF first time through THEN
18 0974    D2    18          SETB   PSDF          ; toggle flag
19 0976    75    1A    F8    MOV    PMADRL, #LOW (PMBUF) ; set parameter pointer
20 0979    75    19    57    MOV    PMADRH, #HIGH (PMBUF)
21 097C    75    1B    FF    MOV    PMNUM, #-1          ; init number of parameters
22
23 097F    75    1C    00    MOV    PMVALUE, #0        ; init parameter value
24
25 0982    B4    3A    00    PSDB:   CJNE   A, #'9'+1, PSDB1
26 0985    50    1B          PSDB1:  JNC    PSDE          ; IF below upper range AND
27 0987    B4    30    00    PSDB2:  CJNE   A, #'0', PSDB2
28 098A    40    16          PSDB2:  JC     PSDE          ; IF above lower range THEN
29
30 098C    94    30          SUBB   A, #'0'        ; remove ASCII offset
31 098E    C5    1C          XCH   A, PMVALUE    ; set previous value
32 0990    75    F0    0A    MOV    B, #10
33 0993    A4          MUL   AB          ; value := value * 10
34 0994    25    1C          ADD   A, PMVALUE    ; value := value + newparm
35 0996    F5    1C          MOV   PMVALUE, A    ; save new parameter value
36 0998    E5    1B          MOV   A, PMNUM
37 099A    B4    FF    03    CJNE   A, #-1, PSD1   ; IF parmnum = -1 THEN
38 099D    75    1B    00    MOV   PMNUM, #0     ; parmnum := 0
39 09A0    C3          CLR   C          ; flag = still parsing string
40 09A1    22          RET
41
42 09A2    85    1A    82    PSDE:   MOV    DPL, PMADRL   ; ELSE set parameter address
43 09A5    85    19    83    MOV    DPH, PMADRH
44 09A8    FD          MOV   TEMP, A       ; save character temporary
45 09A9    E5    1C          MOV   A, PMVALUE    ; set current parameter value
46 09AB    F0          MOVX  @DPTR, A       ; save in parameter buffer
47 09AC    A3          INC   DPTR          ; bump parameter address
48 09AD    E5    82          MOV   A, DPL        ; set low byte address to
49 09AF    B4    00    05    CJNE   A, #LOW(PMBUF+8), PSD2 ; IF overflow THEN
50 09B2    75    1B    08    MOV   PMNUM, #8     ; give max number of parameters
51 09B5    80    08          SJMP  PSD3          ; and skip
52 09B7    85    82    1A    PSD2:   MOV    PMADRL, DPL   ; ELSE replace
53 09BA    85    83    19    MOV    PMADRH, DPH   ; parameter address
54 09BD    05    1B          INC   PMNUM         ; bump number of parameters
55 09BF    ED          MOV   A, TEMP       ; restore original character
56 09C0    B4    3B    0C    CJNE   A, #';', PSDRET ; IF ';' THEN
57 09C3    75    1C    00    MOV   PMVALUE, #0   ; reset parameter value

```

1	09C6	AD	1B		MOV	TEMP, PMNUM	
2	09C8	BD	00	02	CJNE	TEMP, #0, PSD4	; check for ; as first char
3	09CB	05	1B		INC	PMNUM	; IF so THEN adjust number
4	09CD	C3		PSD4:	CLR	C	; flag = still parsing string
5	09CE	22			RET		
6	09CF	D3		PSDRET:	SETB	C	; Flag = finished parsing
7	09D0	22			RET		

```

1          ; ; GNP - set next parameter
2          ;
3          ; *GNP* sets the next (or first) parameter from the parameter
4          ; buffer.
5          ;
6          ;
7          ; ENTRY none
8          ;
9          ; EXIT (A) = next (or first) parameter, 0 if no more
10         ; 'C' = set if no parameters left, clear otherwise
11         ;
12         ; USES A, DPTR
13
14
15 09D1 20 19 08 GNP: JB GNPFL, GNP1 ; IF first time since ESC THEN
16 09D4 D2 19 SETB GNPFL ; toggle flas
17 09D6 75 1A F8 MOV PMADRL, #LOW (PMBUF) ; set parameter address
18 09D9 75 19 57 MOV PMADRH, #HIGH (PMBUF)
19
20 09DC 85 1A 82 GNP1: MOV DPL, PMADRL ; Get pointer to next parameter
21 09DF 85 19 83 MOV DPH, PMADRH
22 09E2 E5 1B MOV A, PMNUM ; Get number of Parameters 0..7
23 09E4 70 02 JNZ GNP2 ; IF no more or none at all
24 09E6 D3 SETB C ; 'C' = no more left
25 09E7 22 RET
26 09E8 E0 GNP2: MOVX A, @DPTR ; ELSE set parameter
27 09E9 A3 INC DPTR ; bump pointer
28 09EA 85 82 1A MOV PMADRL, DPL ; and save
29 09ED 85 83 19 MOV PMADRH, DPH
30 09F0 15 1B DEC PMNUM ; dec number of parameters
31 09F2 C3 CLR C ; 'C' = parameter available
32 09F3 22 RET
  
```

```
1      ;: XBLINAD - build line address
2      ;
3      ; *XBLINAD* is a jump to the routine *BLINAD*. It is used to
4      ; save bytes so that routines may use a short jump to here
5      ; instead of a long jump to the other routine.
6
```

```
7
8 09F4 02 04EA XBLINAD: LJMPL BLINAD
9
```

```
10
11
12
13     ;: XSTAB - search table
14     ;
15     ; *XSTAB* is a jump to the routine *STAB*. It is used to
16     ; save bytes so that routines may use a short jump to here
17     ; instead of a long jump to the other routine.
18
```

```
19
20 09F7 02 013A XSTAB: LJMPL STAB
```

*** Z-29 COMPUTER TERMINAL FIRMWARE VERSION 1.03 ***

```

1      ;:          APCA - ANSI perform cursor addressing
2      ;
3      ;          *APCA* checks to see that the line and column values are legal
4      ;          and sets the cursor to the requested address.  If the values
5      ;          are out of range, the old line number remains and/or the cursor
6      ;          goes to the last column on the line.
7      ;
8      ;
9      ;          ENTRY   none
10     ;
11     ;          EXIT    none
12     ;
13     ;          USES    all
14     ;
15     ;
16 09FA 31    D1    APCA:    ACALL  GNP          ; Get next parameter
17 09FC 60    0A          JZ     ACA2          ; IF non-zero THEN
18 09FE 14          DEC     A                  ; bring into range 0..24
19 09FF B4    18    04    CJNE  A, #MAXLINE, ACA1 ; check range
20 0A02 30    15    05    JNB   LZ5EN, ACA3     ; IF line 25 disbl'd THEN skip
21 0A05 D3          SETB  C                  ; trick ckeck below
22 0A06 50    02    ACA1:   JNC   ACA3          ; IF in range THEN
23 0A08 F5    12    ACA2:   MOV   YPOS, A      ; set Y-position
24     ;
25 0A0A 31    D1    ACA3:   ACALL  GNP          ; Get next parameter
26 0A0C 60    08          JZ     ACAS          ; IF non-zero THEN
27 0A0E 14          DEC     A                  ; bring into range 0..79
28 0A0F B4    50    00    CJNE  A, #MAXCHAR+1, ACA3A ; check range
29 0A12 40    02    ACA3A:  JC     ACAS          ; IF not in range THEN
30 0A14 74    4F          MOV   A, #MAXCHAR ; go to end of line
31 0A16 F5    11    ACA5:   MOV   XPOS, A      ; Set X-position
32 0A18 21    F4          AJMP  XBLINAD      ; Update and return

```



```
1 ; EID = erase in display
2 ;
3 ; *EID* erases the amount of the screen specified by Pn.
4 ;
5 ;
6 ; ENTRY none
7 ;
8 ; EXIT none
9 ;
10 ; USES all
11
12
13 0A10 31 D1 EID: ACALL GNP ; Get parameter
14 0A1C 70 02 JNZ EID1 ; IF zero THEN
15 0A1E 81 08 AJMP EED ; erase to eos and return
16
17 0A20 14 EID1: DEC A
18 0A21 70 02 JNZ EID2 ; IF one THEN
19 0A23 61 F1 AJMP EBD ; erase from beginning & ret
20
21 0A25 14 EID2: DEC A
22 0A26 70 02 JNZ EIR ; IF two THEN
23 0A28 61 AC AJMP CLRS ; erase screen and return
24
25 0A2A 22 EIR: RET
```

```

1          ;:          EIL - erase in line
2          ;
3          ;          *EIL* erases the portion of the current line as specified
4          ;          by Pn.
5          ;
6          ;
7          ;          ENTRY  none
8          ;
9          ;          EXIT   none
10         ;
11         ;          USES   all
12         ;
13
14 0A2B    31    D1          EIL:          ACALL  GNP          ; Get parameter
15 0A2D    70    02          JNZ      EIL1          ; IF zero THEN
16 0A2F    61    E0          AJMP    EOL          ; erase to eol and return
17
18 0A31    14          EIL1:          DEC      A
19 0A32    70    02          JNZ      EIL2          ; IF one THEN
20 0A34    61    CB          AJMP    EBL          ; erase from beginning & ret
21
22 0A36    14          EIL2:          DEC      A
23 0A37    70    F1          JNZ      EIR          ; IF two THEN
24 0A39    61    DB          AJMP    EEL          ; erase entire line and ret

```

```

1          ;:          ASGM - ANSI set graphics mode
2          ;
3          ;          *ASGM* sets or resets any or all of the attributes and
4          ;          graphics modes.
5          ;
6          ;
7          ;          ENTRY none
8          ;
9          ;          EXIT none
10         ;
11         ;          USES all
12
13
14 0A3B 31 D1          ASGM:          ACALL  GNP          ; Get first parameter
15
16 0A3D 75 F0 07      ASG1:          MOV     B, #ASGMTL          ; (B) = table length
17 0A40 90 0A50      MOV     DPTR, #ASGMT          ; (DPTR) = set mode table
18 0A43 31 F7        ACALL  XSTAB          ; Search table
19 0A45 40 02        JC     ASGO          ; IF found THEN
20 0A47 51 4E        ACALL  ASGO          ; call the routine
21 0A49 31 D1        ASGO:          ACALL  GNP          ; Get next parameter
22 0A4B 50 F0        JNC   ASG1          ; IF done THEN return
23 0A4D 22          RET          ; ELSE keep looping
24
25 0A4E E4          ASGO:          CLR    A
26 0A4F 73          JMP    @A+DPTR          ; Jump to routine

```

```
1      ; ; ASGMT - ANSI set graphics mode table
2      ;
3      ; *ASGMT* contains the address of the routines which set the
4      ; requested attribute or graphic mode.
5      ;
6      ; Table entries are: The third character of the ANSI escape
7      ; sequence followed by the address of the routine which performs
8      ; the requested function.
9
10
11      0A50      ASGMT      EQU      $
12
13      0A50      00          DB      0          ; ESC [ 0 m
14      0A51      0F26      DW      XATR        ; Exit all attributes
15
16      0A53      02          DB      2          ; ESC [ 2 m
17      0A54      0F2A      DW      EHALF       ; Enter half intensity mode
18
19      0A56      04          DB      4          ; ESC [ 4 m
20      0A57      0F2D      DW      EUNDL      ; Enter underline mode
21
22      0A59      05          DB      5          ; ESC [ 5 m
23      0A5A      0F30      DW      EBLNK      ; Enter blink mode
24
25      0A5C      07          DB      7          ; ESC [ 7 m
26      0A5D      0F33      DW      ERVM      ; Enter reverse video mode
27
28      0A5F      0A          DB      10         ; ESC [ 10 m
29      0A60      0F39      DW      EGM       ; Enter graphics mode
30
31      0A62      0B          DB      11         ; ESC [ 11 m
32      0A63      0F3C      DW      XGM       ; Exit graphics mode
33
34      0007      ASGMTL     EQU      ($-ASGMT)/3 ; Table length
```

```

1      ;: ASPF - ANSI set protected fields
2      ;:
3      ;: *ASPF* selects the attributes which imply protection. Multiple
4      ;: attributes may be selected in a single sequence. This sequence
5      ;: does not change any attributes of the characters displayed on
6      ;: the screen or of the characters received. The sequence merely
7      ;: changes the way the characters with the specified attributes
8      ;: are interpreted by the different modes.
9      ;:
10     ;:
11     ;: ENTRY none
12     ;:
13     ;: EXIT none
14     ;:
15     ;: USES all
16     ;:
17
18 0A65 75 F0 00 ASPF: MOV B, #0 ; Initialize byte
19
20 0A68 31 D1 ASPF1: ACALL GNP ; Get next Parameter
21 0A6A 40 22 JC ASPF2 ; Exit when done
22 0A6C B4 00 03 CJNE A, #0, ASPF1A
23 0A6F 75 F0 00 MOV B, #0 ; None protected
24 0A72 B4 02 02 ASPF1A: CJNE A, #2, ASPF1B
25 0A75 D2 F3 SETB B,3 ; Half intensity
26 0A77 B4 04 02 ASPF1B: CJNE A, #4, ASPF1C
27 0A7A D2 F1 SETB B,1 ; Under line
28 0A7C B4 05 02 ASPF1C: CJNE A, #5, ASPF1D
29 0A7F D2 F2 SETB B,2 ; Blink
30 0A81 B4 07 02 ASPF1D: CJNE A, #7, ASPF1E
31 0A84 D2 F0 SETB B,0 ; Reverse video
32 0A86 B4 FE 03 ASPF1E: CJNE A, #254, ASPF1F
33 0A89 75 F0 80 MOV B, #10000000B ; No attributes are protected
34 0A8C 80 DA ASPF1F: SJMP ASPF1
35
36 0A8E 85 F0 3F ASPF2: MOV PFIELD, B ; Final change
37 0A91 22 RET

```

```
1      ;;          CBA - convert byte to ASCII
2      ;
3      ;          *CBA* converts a byte into its ASCII equivalent.
4      ;
5      ;
6      ;          ENTRY   (A) = byte to convert
7      ;
8      ;          EXIT    (B) = hundreds digit
9      ;                  (DPH) = tens digit
10     ;                  (DPL) = ones digit
11     ;
12     ;          USES    A, B, DPTR
13     ;
14
15 0A92 75 F0 64 CBA: MOV B, #100
16 0A95 84 DIV AB
17 0A96 C0 E0 PUSH ACC ; Save hundreds amount
18 0A98 E5 F0 MOV A, B
19 0A9A 75 F0 0A MOV B, #10
20 0A9D 84 DIV AB ; (A) = tens (B) = ones
21 0A9E 24 30 ADD A, #'0' ; Make tens digit ASCII
22 0AA0 F5 83 MOV DPH, A ; Save it
23 0AA2 E5 F0 MOV A, B
24 0AA4 24 30 ADD A, #'0' ; Make ones digit ASCII
25 0AA6 F5 82 MOV DPL, A ; Save it
26 0AA8 D0 E0 POP ACC
27 0AAA 24 30 ADD A, #'0' ; Make hundreds digit ASCII
28 0AAC F5 F0 MOV B, A ; Save it
29 0AAE 22 RET
```

```

1      ;!          ACPR - ANSI cursor position report
2      ;
3      ;          *ACPR* outputs the current cursor position in the ANSI form
4      ;          of ESC [ P1 ; Pc R   Please note the tricky code to save a
5      ;          few bytes of code.
6      ;
7      ;
8      ;          ENTRY   none
9      ;
10     ;          EXIT    none
11     ;
12     ;          USES    all
13
14
15 OAAF  31      D1      ACPR:      ACALL  GNP          ; Get parameter
16 OAB1  B4      06      35      CJNE   A, #6, APR      ; IF not 6 THEN return
17 OAB4  74      1B      MOV     A, #ESC             ;
18 OAB6  51      CC      ACALL  ACP3             ; Output an ESC
19 OAB8  74      5B      MOV     A, #'I'           ;
20 OABA  51      CC      ACALL  ACP3             ; Output a 'I'
21 OABC  E5      12      MOV     A, YPOS          ;
22 OABE  04      INC     A                          ; Bump to normalize
23 OABF  51      CF      ACALL  ACP1             ; Output Y-position
24 OAC1  74      3B      MOV     A, #';'           ;
25 OAC3  51      CC      ACALL  ACP3             ; Output separator
26 OAC5  E5      11      MOV     A, XPOS          ;
27 OAC7  04      INC     A                          ; Bump to normalize
28 OAC8  51      CF      ACALL  ACP1             ; Output X-position
29 OACA  74      52      MOV     A, #'R'           ;
30
31 OACC  02      022A     ACP3:      LJMPL PCDF          ; Output 'R' and return
32
33 OACF  51      92      ACP1:      ACALL  CBA          ; Convert position to ASCII
34 OAD1  AD      82      MOV     TEMP, DPL         ; Save one's digit
35 OAD3  E5      83      MOV     A, DPH          ; Get ten's digit
36 OAD5  B4      00      CJNE   A, #'1', ACP1A     ;
37 OAD8  40      02      ACP1A:     JC     ACP2          ; IF not zero THEN
38 OADA  51      CC      ACALL  ACP3             ; output ten's digit
39 OADC  ED      ACP2:      MOV     A, TEMP        ;
40 OADD  80      ED      SJMPL ACP3             ; Output one's digit and return

```

```

1          ;:          APRNT - ANSI print page
2          ;
3          ;          *APRNT* prints the page to the opposite port.
4          ;
5          ;
6          ;          ENTRY   none
7          ;
8          ;          EXIT    none
9          ;
10         ;          USES   all
11
12
13 OADF    11    2A          APRNT:          ACALL   SETDISP          ; Set dispatch and return
14
15 OAE1    11    2F          ACALL   SETNORM          ; Restore dispatch address.
16 OAE3    B4    37    03          CJNE    A, #7, APR          ; IF ESC # 7 THEN
17 OAE6    02    103C          JMP     R2, PRNT          ; print page
18 OAE9    22          APR:          RET
19
20
21
22
23         ;:          ASBR - ANSI set baud rate
24         ;
25         ;          *ASBR* sets the baud rate to that specified by Pn.
26         ;
27         ;
28         ;          ENTRY   none
29         ;
30         ;          EXIT    none
31         ;
32         ;          USES   all
33
34
35 OAEA    31    D1          ASBR:          ACALL   GNP          ; Get parameter
36 OAEC    50    01          JNC     ASBR1          ; IF no parameter THEN
37 OAEE    04          INC     A          ; default to 1
38 OAEF    B4    0E    00          ASBR1:          CJNE    A, #14, ASBR2
39 OAF2    50    F5          ASBR2:          JNC     APR          ; IF in range (0..13) THEN
40 OAF4    C1    4B          AJMP   SBR          ; set baud rate and return

```


*** Z-29 COMPUTER TERMINAL FIRMWARE VERSION 1.03 ***

```
1 ;: ARAMP - ANSI reset all modes to power up configuration
2 ;
3 ; RAMP - reset all modes to power up configuration
4 ;
5 ;
6 ; *ARAMP* and *RAMP* resets all flags etc. to the configuration
7 ; on power up.
8 ;
9 ;
10 ; ENTRY none
11 ;
12 ; EXIT none
13 ;
14 ; USES all
15 ;
16 ;
17 0AF6 31 D1 ARAMP: ACALL GNP ; Get any parameter
18 0AF8 50 EF JNC APR ; IF no parameters THEN
19 0AFA 02 1003 RAMP: JMP R2_IN2 ; reset and return
```

```

1      ;!      WEOL - wrap at end of line
2      ;
3      ;      *WEOL* sets the flag which causes the terminal to perform
4      ;      a carriage return and line feed immediatly after the 80th
5      ;      character before a line is displayed.
6      ;
7      ;
8      ;      ENTRY   none
9      ;
10     ;      EXIT    none
11     ;
12     ;      USES    none
13     ;
14     ;
15     0AFD    D2    2B      WEOL:      SETB    AUTOWRAP      ; Flag auto wrap
16     0AFF    22      RET
17
18
19
20
21     ;!      DEOL - discard at end of line
22     ;
23     ;      *DEOL* resets the wrap around at end of line flag.
24     ;      characters past column 79 are placed in column 79 until
25     ;      a carriage return is received.
26     ;
27     ;
28     ;      ENTRY   none
29     ;
30     ;      EXIT    none
31     ;
32     ;      USES    none
33     ;
34     ;
35     0B00    C2    2B      DEOL:      CLR     AUTOWRAP      ; Clear auto wrap
36     0B02    22      RET

```

```
1          ;;          EAM - enter ANSI mode.
2          ;
3          ;          *EAM* places the terminal in the ANSI mode for escape codes.
4          ;
5          ;
6          ;          ENTRY   none
7          ;
8          ;          EXIT    none
9          ;
10         ;          USES   none
11
12
13 0B03    75    28    01    EAM:    MOV    MODE, #00000001B    ; Place in ANSI mode
14 0B06    22
15
16
17
18
19         ;;          EZM - enter ZDS mode
20         ;
21         ;          *EZM* takes the terminal out of ANSI mode and into ZDS mode.
22         ;
23         ;
24         ;          ENTRY   none
25         ;
26         ;          EXIT    none
27         ;
28         ;          USES   none
29
30
31 0B07    75    28    02    EZM:    MOV    MODE, #00000010B    ; Take out of ANSI mode
32 0B0A    22    RTI:    RET
```

```

1          ;:          E25L - enable 25th line
2          ;
3          ;          *E25L* enables the display of the 25th line only if it has
4          ;          not been previously enabled. The 25th line is cleared at
5          ;          the time it is enabled.
6          ;
7          ;
8          ;          ENTRY   none
9          ;
10         ;          EXIT    none
11        ;
12        ;          USES    A, B, DPTR, TEMP, PTR1
13        ;
14        ;
15        ;          15      20      15      FC      E25L:      JB      L25EN, RT1      ; IF enabled THEN return
16        ;          16      0B0E  D2      15          SETB   L25EN      ; ELSE enable 25th line
17        ;          17      0B10  75      F0      18          MOV    B, #MAXLINE
18        ;          18      0B13  61      96          AJMP  CLRLINE      ; Clear 25th line
19        ;
20        ;
21        ;
22        ;
23        ;:          D25L - disable 25th line
24        ;
25        ;          *D25L* disables the display of the 25th line and clears it.
26        ;          If the cursor is on the 25th line then it is sent to the
27        ;          home position.
28        ;
29        ;
30        ;          ENTRY   none
31        ;
32        ;          EXIT    none
33        ;
34        ;          USES    A, B, DPTR, TEMP, PTR1
35        ;
36        ;
37        ;          37      0B15  C2      15          D25L:      CLR    L25EN      ; Disable 25th line
38        ;          38      0B17  75      F0      18          MOV    B, #MAXLINE
39        ;          39      0B1A  71      96          ACALL CLRLINE      ; Clear 25th line
40        ;          40      0B1C  E5      12          MOV    A, YPOS
41        ;          41      0B1E  B4      18      02          CJNE  A, #MAXLINE, XR2_DISP ; IF cursor on 25th line THEN
42        ;          42      0B21  91      36          ACALL SCH      ; set cursor home
43        ;
44        ;          44      0B23  02      1042      XR2_DISP: LJMP  R2_DISP      ; Display any status

```

```

1      ; ; EKC - enable keyboard click
2      ; ;
3      ; ; *EKC* resets the flag that disables keyboard click and
4      ; ; outputs the command to the keyboard.
5      ; ;
6      ; ;
7      ; ; ENTRY none
8      ; ;
9      ; ; EXIT none
10     ; ;
11     ; ; USES all
12     ; ;
13     ; ;
14     0B26 D2 33 EKC: SETB CLKF ; Turn on key click
15     0B28 74 82 MOV A, #KBC_EC
16     0B2A 02 026D XPCKB: JMP PCKB ; Output command and return
17
18
19
20
21     ; ; NKC - no keyboard click
22     ; ;
23     ; ; *NKC* sets the flag that disables keyboard click and
24     ; ; outputs the command to the keyboard.
25     ; ;
26     ; ;
27     ; ; ENTRY none
28     ; ;
29     ; ; EXIT none
30     ; ;
31     ; ; USES all
32     ; ;
33     ; ;
34     0B2D C2 33 NKC: CLR CLKF ; Turn off key click
35     0B2F 74 83 MOV A, #KBC_DC
36     0B31 80 F7 SJMP XPCKB ; Output command and return

```

```
1          ;;          SBC - set block cursor
2          ;
3          ;          *SBC* programs the CRTC to display a block cursor.
4          ;
5          ;
6          ;          ENTRY none
7          ;
8          ;          EXIT none
9          ;
10         ;          USES A, B, DPTR
11         ;
12         ;
13 0B33 C2 32 SBC: CLR CRUL ; Clear underline flag
14 0B35 80 02 SUMP SUC1 ; Initialize cursor format
15
16
17
18
19         ;;          SUC - set underscore cursor
20         ;
21         ;          *SUC* programs the CRTC to display an underline cursor.
22         ;
23         ;
24         ;          ENTRY none
25         ;
26         ;          EXIT none
27         ;
28         ;          USES A, B, DPTR
29         ;
30         ;
31 0B37 D2 32 SUC: SETB CRUL ; Set underline flag
32
33 0B39 02 101B SUC1: JMP R2_ICUR ; Initialize cursor format
```

```

1          ; ; EHSM - enter hold screen mode
2          ; ;
3          ; ; *EHSM* sets the hold screen mode flag.
4          ; ;
5          ; ;
6          ; ; ENTRY none
7          ; ;
8          ; ; EXIT none
9          ; ;
10         ; ; USES none
11
12
13 OB3C D2 36 EHSM: SETB HSMODEF ; Enter mode
14 OB3E 75 1E 01 MOV HSLINE, #1 ; Set number of lines
15 OB41 80 02 SJMP XHSM1 ; Clear stop display and return
16
17
18
19
20         ; ; XHSM - exit hold screen mode
21         ; ;
22         ; ; *XHSM* clear hold screen mode flag.
23         ; ;
24         ; ;
25         ; ; ENTRY none
26         ; ;
27         ; ; EXIT none
28         ; ;
29         ; ; USES none
30
31
32 OB43 C2 36 XHSM: CLR HSMODEF ; Exit mode
33
34 OB45 C2 22 XHSM1: CLR H$STOPF ; Clear stop display flag
35 OB47 22 RET

```

```
1 ; ; EKSM - enter keypad shifted mode
2 ; ;
3 ; ; *EKSM* places the numeric keypad into the shifted mode.
4 ; ;
5 ; ;
6 ; ; ENTRY none
7 ; ;
8 ; ; EXIT none
9 ; ;
10 ; ; USES none
11 ; ;
12 ; ;
13 OB48 D2 30 EKSM: SETB KPADSHTF ; Set keypad shifted
14 OB4A 22 RET
15 ; ;
16 ; ;
17 ; ;
18 ; ;
19 ; ; XKSM - exit keypad shifted mode
20 ; ;
21 ; ; *XKSM* takes the numeric keypad out of the shifted mode.
22 ; ;
23 ; ;
24 ; ; ENTRY none
25 ; ;
26 ; ; EXIT none
27 ; ;
28 ; ; USES none
29 ; ;
30 ; ;
31 OB4B C2 30 XKSM: CLR KPADSHTF ; Clear keypad shifted
32 OB4D 22 RET
```


*** Z-29 COMPUTER TERMINAL FIRMWARE VERSION 1.03 ***

```
1      ;;          EKAM - enter keypad alternate mode
2      ;
3      ;          *EKAM* places the numeric keypad into the alternate mode.
4      ;
5      ;
6      ;          ENTRY   none
7      ;
8      ;          EXIT    none
9      ;
10     ;          USES    none
11     ;
12     ;
13     OB4E   D2   31      EKAM:   SETB   KPADALTF      ; Set keypad alternate
14     OB50   22
15     ;
16     ;
17     ;
18     ;
19     ;;          XKAM - exit keypad alternate mode
20     ;
21     ;          *XKAM* takes the numeric keypad out of the alternate mode.
22     ;
23     ;
24     ;          ENTRY   none
25     ;
26     ;          EXIT    none
27     ;
28     ;          USES    none
29     ;
30     ;
31     OB51   C2   31      XKAM:   CLR    KPADALTF      ; Clear keypad alternate
32     OB53   22
RET
```

*** Z-29 COMPUTER TERMINAL FIRMWARE VERSION 1.03 ***

```
1          ;;          EICM - enter insert character mode
2          ;
3          ;          *EICM* places terminal into insert character mode.
4          ;
5          ;
6          ;          ENTRY   none
7          ;
8          ;          EXIT    none
9          ;
10         ;          USES    all
11         ;
12         ;
13 0B54    D2    21          EICM:    SETB    ICMODEF    ; Set insert mode flas
14 0B56    61    23          AJMP    XR2_DISP    ; Display any change in status
15
16
17
18
19         ;;          XICM - exit insert character mode
20         ;
21         ;          *XICM* takes terminal out of the insert character mode.
22         ;
23         ;
24         ;          ENTRY   none
25         ;
26         ;          EXIT    none
27         ;
28         ;          USES    all
29         ;
30         ;
31 0B58    C2    21          XICM:    CLR     ICMODEF    ; Clear insert mode flas
32 0B5A    61    23          AJMP    XR2_DISP    ; Display any change in status
```

```
.....
1 ..... ;; EC - enable cursor.....
2 ..... ;
3 ..... ; *EC* enables the display of the cursor.
4 ..... ;
5 ..... ;
6 ..... ; ENTRY none
7 ..... ;
8 ..... ; EXIT none
9 ..... ;
10 ..... ; USES none
11 ..... ;
12 ..... ;
13 OB5C D2 1A EC: SETB ENBLCUR ; Enable display of cursor
14 OB5E 22 RET
15 ..... ;
16 ..... ;
17 ..... ;
18 ..... ;
19 ..... ;; DC - disable cursor.....
20 ..... ;
21 ..... ; *DC* disables the display of the cursor.
22 ..... ;
23 ..... ;
24 ..... ; ENTRY none
25 ..... ;
26 ..... ; EXIT none
27 ..... ;
28 ..... ; USES none
29 ..... ;
30 ..... ;
31 OB5F C2 1A DC: CLR ENBLCUR ; Disable display of cursor
32 OB61 22 RET
.....
```

```
1      ;|      EACR - enable auto carriage return
2      ;
3      ;|      *EACR* enables the terminal to perform an automatic carriage
4      ;|      return upon receipt of a line feed character.
5      ;
6      ;
7      ;|      ENTRY   none
8      ;
9      ;|      EXIT    none
10     ;
11     ;|      USES   none
12     ;
13     ;
14     OB62   D2   2C      EACR:      SETB   AUTOCR      ; Enter auto CR mode
15     OB64   22
16
17
18
19
20     ;|      XACR - exit auto carriage return
21     ;
22     ;|      *XACR* clears the auto carriage return flag.
23     ;
24     ;
25     ;|      ENTRY   none
26     ;
27     ;|      EXIT    none
28     ;
29     ;|      USES   none
30     ;
31     ;
32     OB65   C2   2C      XACR:      CLR    AUTOCR      ; Exit auto CR mode
33     OB67   22
```

```
1      ;:      EALF - enable auto line feed
2      ;
3      ;      *EALF* enables the terminal to perform an automatic
4      ;      line feed upon receipt of a carriage return.
5      ;
6      ;
7      ;      ENTRY  none
8      ;
9      ;      EXIT   none
10     ;
11     ;      USES   none
12     ;
13     ;
14     OB68    D2    2D      EALF:      SETB    AUTOLF      ; Enter auto LF mode
15     OB6A    22
16     ;
17     ;
18     ;
19     ;
20     ;:      XALF - exit auto line feed mode
21     ;
22     ;      *XALF* clears the auto line feed mode flag.
23     ;
24     ;
25     ;      ENTRY  none
26     ;
27     ;      EXIT   none
28     ;
29     ;      USES   none
30     ;
31     ;
32     OB6B    C2    2D      XALF:      CLR     AUTOLF      ; Exit auto LF mode
33     OB6D    22
RET
```

```
1          ;|          EGATM - enter guarded area transfer mode
2          ;|
3          ;|          *EGATM* places the terminal in a mode such that all data
4          ;|          is to be transmitted in a data stream such as transmit page.
5          ;|
6          ;|
7          ;|          ENTRY   none
8          ;|
9          ;|          EXIT    none
10         ;|
11         ;|          USES   none
12         ;|
13         ;|
14 0B6E    C2    25          EGATM:          CLR    GATM          ; Clear guarded area transfer
15 0B70    22
16
17
18
19
20         ;|          XGATM - exit guarded area transfer mode
21         ;|
22         ;|          *XGATM* places the terminal in a mode such that only
23         ;|          unprotected data is to be transmitted in a data stream
24         ;|          such as transmit page.
25         ;|
26         ;|
27         ;|          ENTRY   none
28         ;|
29         ;|          EXIT    none
30         ;|
31         ;|          USES   none
32         ;|
33         ;|
34 0B71    D2    25          XGATM:          SETB   GATM          ; Set guarded area transfer
35 0B73    22
RET
```

```

1 ..... ; EERM - enter erasure mode .....
2 ..... ; .....
3 ..... ; *EERM* places the terminal in a mode such that all data is .....
4 ..... ; erased in functions such as erase screen.
5 ..... ; .....
6 ..... ; .....
7 ..... ; ENTRY none .....
8 ..... ; .....
9 ..... ; EXIT none .....
10 ..... ; .....
11 ..... ; USES none .....
12 ..... ; .....
13 ..... ; .....
14 0B74 C2 1B EERM: CLR ERM ; Clear erasure mode
15 0B76 22 RET .....
16 ..... ; .....
17 ..... ; .....
18 ..... ; .....
19 ..... ; .....
20 ..... ; XERM - exit erasure mode .....
21 ..... ; .....
22 ..... ; *XERM* places the terminal in a mode such that only .....
23 ..... ; unprotected data is erased in functions such as erase .....
24 ..... ; screen.
25 ..... ; .....
26 ..... ; .....
27 ..... ; ENTRY none .....
28 ..... ; .....
29 ..... ; EXIT none .....
30 ..... ; .....
31 ..... ; USES none .....
32 ..... ; .....
33 ..... ; .....
34 0B77 D2 1B XERM: SETB ERM ; Set erasure mode
35 0B79 22 RET .....

```

```
1          ;;          PCLK - Program clock
2          ;
3          ;          *PCLK* sets the internal clock.
4          ;
5          ;
6          ;          ENTRY   none
7          ;
8          ;          EXIT    none
9          ;
10         ;          USES   A, DPTR
11
12
13 0B7A    31    D1          PCLK:      ACALL  GNP          ; Get hour parameter
14 0B7C    B4    18    00    CJNE   A, #24, PCL1A
15 0B7F    50    14          PCL1A:    JNC    PCL2          ; IF bad parameter THEN exit
16 0B81    F5    3D    MOV    THOUR, A
17 0B83    31    D1          ACALL  GNP          ; Get minutes parameter
18 0B85    B4    3C    00    CJNE   A, #60, PCL1B
19 0B88    50    0B          PCL1B:    JNC    PCL2          ; IF bad parameter THEN exit
20 0B8A    F5    3C    MOV    TMIN, A
21 0B8C    31    D1          ACALL  GNP          ; Get seconds parameter
22 0B8E    B4    3C    00    CJNE   A, #60, PCL1C
23 0B91    50    02          PCL1C:    JNC    PCL2          ; IF bad parameter THEN exit
24 0B93    F5    3B    MOV    TSEC, A
25 0B95    22          PCL2:      RET
```



```

1          ;|          CLRLINE - clear line completely.....
2          ;|
3          ;|          *CLRLINE* writes spaces into the entire line indicated and.....
4          ;|          ignores any settings of protected fields.
5          ;|
6          ;|
7          ;|          ENTRY   (B) = line number to erase
8          ;|
9          ;|          EXIT    none
10         ;|
11         ;|          USES   A, B, DPTR, TEMP, PTR1, WORK2, INDX2
12         ;|
13
14 0B96    C0    3F          CLRLINE:    PUSH    PFIELD          ; Save protected fields
15 0B98    75    3F    00    MOV     PFIELD, #0      ; Make everything unprotected
16 0B9B    71    A0          ACALL   CLRL             ; Clear line
17 0B9D    D0    3F          POP     PFIELD         ; Restore protected fields
18 0B9F    22
19
20
21
22
23         ;|          CLRL - clear line
24         ;|
25         ;|          *CLRL* writes spaces into the entire line indicated.
26         ;|
27         ;|
28         ;|          ENTRY   (B) = line number to erase
29         ;|
30         ;|          EXIT    none
31         ;|
32         ;|          USES   A, B, DPTR, TEMP, PTR1, WORK2, INDX2
33
34
35 0BA0    E4          CLRL:          CLR     A
36 0BA1    12    0503    LCALL  CLA             ; Calculate address
37 0BA4    74    50      MOV    A, #NUMCHARS   ; 80 characters
38 0BA6    75    F0    00    MOV    B, #0          ; No attributes
39 0BA9    02    100C    LJMP  R2_FILL        ; Fill with spaces and return

```

```

1          ;;          CLRS - clear screen
2          ;
3          ;
4          ;          *CLRS* clears entire display except the 25th line.  IF cursor
5          ;          is on the 25th line then just the 25th line is cleared.
6          ;
7          ;          ENTRY   none
8          ;
9          ;          EXIT    none
10         ;
11         ;          USES   all
12         ;
13
14  OBAC    E5    12          CLRS:    MOV    A, YPOS
15  OBAE    B4    18    04          CJNE   A, #MAXLINE, CS1    ; IF ypos = 25th line THEN
16  OBB1    F5    F0          MOV    B, A                ; setup for subroutine
17  OBB3    80    EB          SJMP   CLRL                ; clear line and return
18
19  OBB5    7C    18          CS1:    MOV    WORK, #NUMLINES-1    ; Get number of lines
20  OBB7    7A    00          MOV    INDX1, #0        ; Index for -LORDER-
21
22  OBB9    8A    F0          CS2:    MOV    B, INDX1        ; REPEAT setup for call
23  OBBB    71    A0          ACALL  CLRL                ; to clear a line
24  OBBD    0A          INC    INDX1        ; bump indx1
25  OBBE    DC    F9          DJNZ  WORK, CS2        ; UNTIL work = 0
26
27  OBC0    81    36          AJMP  SCH                ; Set cursor home and return
28
29
30
31
32         ;;          CLFD - clear foreground
33         ;
34         ;          *CLFD* clears entire display except for half intensity spaces.
35         ;
36         ;
37         ;          ENTRY   none
38         ;
39         ;          EXIT    none
40         ;
41         ;          USES   all
42         ;
43
44  OBC2    75    3F    08          CLFD:    MOV    PFIELD, #00001000B    ; Make half intensity protected
45  OBC5    71    AC          ACALL  CLRS                ; Clear screen
46  OBC7    75    3F    00          MOV    PFIELD, #0        ; Make nothing protected
47  OBCA    22          RET

```

```

1          ;:          EBL - erase from beginning of line
2          ;
3          ;          *EBL* erases from the beginning of the current line to the
4          ;          cursor.  Cursor position does not change.
5          ;
6          ;
7          ;          ENTRY  none
8          ;
9          ;          EXIT   none
10         ;
11         ;          USES   A, B, DPTR, TEMP, PTR1, WORK2, INDX2
12
13
14 OBCB    E4          EBL:      CLR    A
15 OBCC    85          .12      F0    MOV    B, YPOS          ; Calc address for (0,YPOS)
16 OBCF    12          0503     LCALL  CLA              ; Calc address for (0,YPOS)
17 OBD2    E5          .11      MOV    A, XPOS          ; Get number of characters
18 OBD4    04          INC     A              ; to erase
19 OBD5    75          F0       00    MOV    B, #0           ; Clear attributes
20 OBD8    02          100C     LJMP   R2_FILL         ; Clear and return
21
22
23
24
25         ;:          EEL - erase entire line
26         ;
27         ;          *EEL* clears the entire line where the cursor resides.
28         ;          Cursor position does not change.
29         ;
30         ;
31         ;          ENTRY  none
32         ;
33         ;          EXIT   none
34         ;
35         ;          USES   A, B, DPTR, TEMP, PTR1, WORK2, INDX2
36
37
38 OBDB    85          12      F0    EEL:      MOV    B, YPOS          ; Get current position
39 OBDE    80          C0      SJMP   CLR_L              ; Clear line and return

```

```

1          ;;          EOL - erase to end of line
2          ;
3          ;          *EOL* erases from the cursor to the end of the current line.
4          ;          Cursor position does not change.
5          ;
6          ;
7          ;          ENTRY none
8          ;
9          ;          EXIT none
10         ;
11         ;          USES A, B, DPTR, TEMP, PTR1, WORK2, INDX2
12
13
14 OBE0    75    F0    00    EOL:      MOV    B, #0          ; Clear attributes
15
16 OBE3    74    50          EOL1:    MOV    A, #NUMCHARS ; Calculate number to erase
17 OBE5    C3          CLR    C
18 OBE6    95    11          SUBB   A, XPOS
19 OBE8    85    14    82      MOV    DPL, LINADL   ; Get line address
20 OBE8    85    13    83      MOV    DPH, LINADH
21 OBE8    02    100C      LJMP   R2-FILL      ; Erase to end and return
22
23
24
25
26         ;;          EBD - erase from beginning of display
27         ;
28         ;          *EBD* clears the screen from 'HOME' position to the current
29         ;          cursor position. The exception is the 25th line. Cursor
30         ;          position does not change.
31         ;
32         ;
33         ;          ENTRY none
34         ;
35         ;          EXIT none
36         ;
37         ;          USES A, B, DPTR, TEMP, PTR1, INDX1, WORK2, INDX2
38
39
40 OBF1    E5    12          EBD:      MOV    A, YPOS
41 OBF3    B4    18    02      CJNE   A, #MAXLINE, EB1 ; IF 25th line THEN
42 OBF6    80    D3          SJMP   EBL          ; erase just this line
43
44 OBF8    7A    00          EB1:      MOV    INDX1, #0     ; Start at top
45 OBF8    E5    12          EB2:      MOV    A, YPOS      ; REPEAT
46 OBF8    B5    02    02      CJNE   A, INDX1A, EB3 ; IF index = current THEN
47 OBF8    80    CA          SJMP   EBL          ; erase up to cursor
48
49 OC01    8A    F0          EB3:      MOV    B, INDX1     ; ELSE set up and
50 OC03    71    A0          ACALL  CLRL         ; clear entire line
51 OC05    0A          INC    INDX1        ; bump index counter
52 OC06    80    F2          SJMP   EB2         ; UNTIL forever

```

*** Z-29 COMPUTER TERMINAL FIRMWARE VERSION 1.03 ***

```

1          ;;          EED - erase to end of display
2          ;
3          ;          *EED* clears the screen from the current cursor position to
4          ;          the end of the screen.  Cursor position does not change.
5          ;
6          ;
7          ;          ENTRY  none
8          ;
9          ;          EXIT   none
10         ;
11         ;          USES   A, B, DPTR, TEMP, PTR1, INDX1, WORK2, INDX2
12         ;
13
14 0C08    71    E0          EED:          ACALL  EOL          ; Clear to end of line
15 0C0A    AA    12          MOV    INDX1, YPOS      ; Set loop counter
16 0C0C    0A          EE1:          INC    INDX1          ; REPEAT bump to next line
17 0C0D    BA    18    00    CJNE   INDX1, #MAXLINE, EE1A
18 0C10    50    06          EE1A:         JNC   EER            ; IF end of disp THEN exit
19 0C12    8A    F0          MOV    B, INDX1        ; set line to clear
20 0C14    71    A0          ACALL  CLRRL         ; clear line
21 0C16    80    F4          SJMP  EE1            ; UNTIL forever
22 0C18    22          EER:          RET
23
24
25
26
27         ;;          HEED - Hazeltine erase to end of display (with background)
28         ;
29         ;          *HEED* clears the screen from the current cursor position
30         ;          to the end of the screen with half intensity spaces.  The
31         ;          cursor position does not change.
32         ;
33         ;
34         ;          ENTRY  none
35         ;
36         ;          EXIT   none
37         ;
38         ;          USES   A, B, DPTR, TEMP, PTR1, INDX1, WORK2, INDX2
39
40
41 0C19    75    F0    08    HEED:         MOV    B, #00001000B  ; Get half intensity
42 0C1C    71    E3          ACALL  EOL1         ; Clear to end of line
43
44 0C1E    AA    12          MOV    INDX1, YPOS      ; Set loop counter
45 0C20    0A          HEE1:          INC    INDX1          ; REPEAT bump to next line
46 0C21    BA    18    00    CJNE   INDX1, #MAXLINE, HEE1A
47 0C24    50    F2          HEE1A:        JNC   EER            ; IF end of disp THEN exit
48 0C26    E4          CLR    A
49 0C27    8A    F0          MOV    B, INDX1        ; set line to clear
50 0C29    12    0503       LCALL  CLA           ; calculate line address
51 0C2C    74    50          MOV    A, #NUMCHARS   ; complete line
52 0C2E    75    F0    08    MOV    B, #00001000B  ; set half intensity
53 0C31    12    100C       LCALL  R2_FILL       ; fill with spaces
54 0C34    80    EA          SJMP  HEE1            ; UNTIL forever

```

```

1          ;:          SCH - set cursor home
2          ;
3          ;
4          ;          *SCH* places the cursor at line zero, column zero.
5          ;
6          ;
7          ;          ENTRY   none
8          ;
9          ;          EXIT    none
10         ;
11         ;          USES   A, DPTR, PTR1
12         ;
13 0C36     E4          SCH:      CLR    A
14 0C37     F5         11        MOV    XPOS, A          ; Zero X-position
15 0C39     F5         12        MOV    YPOS, A          ; Zero Y-position
16 0C3B     21         F4        AJMP   XBLINAD          ; Update address and return
17
18
19
20
21         ;:          PBS - perform back space
22         ;
23         ;          CLFT - cursor left
24         ;
25         ;          *PBS* - *CLFT* steps the cursor one position to the left, but
26         ;          does not wrap around to the previous line after reaching
27         ;          column zero.
28         ;
29         ;          ENTRY   none
30         ;
31         ;          EXIT    none
32         ;
33         ;          USES   A, DPTR, PTR1
34         ;
35
36         ;          0C3D     PBS   EQU    $
37         ;          0C3D     CLFT  EQU    $
38 0C3D     E5         11        MOV    A, XPOS          ; Get X-position
39 0C3F     70         01        JNZ    PBS1          ; IF -XPOS- is zero THEN
40 0C41     22          RET          ; return
41
42 0C42     15         11        PBS1:  DEC    XPOS          ; ELSE decrement -XPOS-
43 0C44     21         F4        AJMP   XBLINAD          ; build address and return

```

```

1      ;:      ACLFT - ANSI cursor left
2      ;
3      ;
4      ;      *ACLFT* moves the cursor towards the beginning of a line
5      ;      the specified Pn number of times.
6      ;
7      ;
8      ;      ENTRY   none
9      ;
10     ;
11     ;      EXIT    none
12     ;
13     ;      USES   A, DPTR, INDX1, PTR1
14     OC46  31    D1      ACLFT:  ACALL  GNP          ; Get parameter
15     OC48  70    01      ;      JNZ   ACLO        ; IF no parameters or 0 THEN
16     OC4A  04          ;      INC   A            ; bump to 1
17
18     OC4B  FA          ;      MOV   INDX1, A       ; Set up index
19     OC4C  91    3D      ACL:    ACALL  CLFT        ; REPEAT move cursor left one
20     OC4E  DA    FC      ;      DJNZ  INDX1, ACL    ; UNTIL count = 0
21     OC50  22          ;      RET
22
23
24
25
26     ;:      HCLFT - Hazeltine cursor left
27     ;
28     ;
29     ;      *HCLFT* steps the cursor one position to the left and wraps
30     ;      around to the previous line after reaching column zero.
31     ;
32     ;
33     ;      ENTRY   none
34     ;
35     ;
36     ;      EXIT    none
37     ;
38     ;      USES   A, DPTR, PTR1, TEMP
39     OC51  E5    11      HCLFT:  MOV   A, XPOS      ; Get X-position
40     OC53  70    E8      ;      JNZ   CLFT        ; IF not zero THEN use *CLFT*
41     OC55  AD    12      ;      MOV   TEMP, YPOS    ; Save Y-position
42     OC57  91    8D      ;      ACALL  CUP         ; Move cursor up
43     OC59  E5    12      ;      MOV   A, YPOS
44     OC5B  B5    05    01  ;      CJNE  A, TEMP, HCLFT1 ; IF Ypos did not change THEN
45     OC5E  22          ;      RET            ; do nothing
46
47     OC5F  75    11    4F  HCLFT1: MOV   XPOS, #MAXCHAR ; ELSE move to end of line
48     OC62  21    F4      ;      AJMP  XBLINAD    ; update and return

```

*** Z-29 COMPUTER TERMINAL FIRMWARE VERSION 1.03 ***

```

1          ;;          CRT - cursor right
2          ;
3          ;          *CRT* moves the cursor right one column.  If the cursor is in
4          ;          the last column then the cursor will not be advanced.
5          ;
6          ;
7          ;          ENTRY   none
8          ;
9          ;          EXIT    none
10         ;
11         ;          USES   A, DPTR
12
13
14 0C64     E5     11          CRT:      MOV     A, XPOS          ; Get X-position
15 0C66     B4     4F     01          CJNE   A, #MAXCHAR, CRT1    ; IF end of line THEN
16 0C69     22                      RET                     ; return
17
18 0C6A     05     11          CRT1:     INC     XPOS          ; ELSE bump position
19 0C6C     21     F4          AJMP   XLINAD          ; update and return
20
21
22
23
24         ;;          ACRT - ANSI cursor right
25         ;
26         ;          *ACRT* moves the cursor towards the end of the line
27         ;          the specified Pn number of times.
28         ;
29         ;
30         ;          ENTRY   none
31         ;
32         ;          EXIT    none
33         ;
34         ;          USES   A, DPTR, INDX1
35
36
37 0C6E     31     D1          ACRT:     ACALL  GNP             ; Get parameter
38 0C70     70     01          JNZ    ACR1          ; IF no parameter or 0 THEN
39 0C72     04          INC     A             ; bump to 1
40
41 0C73     FA          ACR1:     MOV     INDX1, A        ; Set up index
42 0C74     91     64          ACR:     ACALL  CRT             ; REPEAT cursor right one
43 0C76     DA     FC          DJNZ   INDX1, ACR    ; UNTIL count = 0
44 0C78     22          RET

```


*** Z-29 COMPUTER TERMINAL FIRMWARE VERSION 1.03 ***

```

1          ;: HCRT - Hazeltine cursor right
2          ;
3          ; *HCRT* moves the cursor right one column. If the cursor is
4          ; in the last column then the cursor moves to the beginning of
5          ; the next line.
6          ;
7          ;
8          ; ENTRY none
9          ;
10         ; EXIT none
11        ;
12        ; USES A, DPTR, PTR1
13
14
15 0C79    E5    11          HCRT:    MOV    A, XPOS          ; Get X-position
16 0C7B    B4    4F    E6    CJNE   A, #MAXCHAR, CRT    ; IF not eol THEN use *CRT*
17 0C7E    AD    12          MOV    TEMP, YPOS      ; Save Y-position
18 0C80    91    A8          ACALL  CDN              ; Move cursor down
19 0C82    E5    12          MOV    A, YPOS
20 0C84    B5    05    01    CJNE   A, TEMP, HCRT1    ; IF xpos did not change THEN
21 0C87    22          RET                    ; do nothing
22
23 0C88    75    11    00    HCRT1:   MOV    XPOS, #0        ; ELSE move to beginning
24 0C8B    21    F4          AJMP  XBLINAD        ; update and return

```

```

1      ; ; CUP - cursor up
2      ;
3      ; *CUP* moves the cursor up one line on the display. The
4      ; cursor may move out of but not into fixed regions and
5      ; never past line zero.
6      ;
7      ;
8      ; ENTRY none
9      ;
10     ; EXIT none
11     ;
12     ; USES A, DPTR, PTR1
13     ;
14     ;
15 0C8D E5 12 CUP: MOV A, YPOS ; Get Y-position
16 0C8F 60 03 JZ CUP1 ; IF top of screen THEN return
17 0C91 B5 17 01 CJNE A, TSCROLL, CUP1A ; IF top of scroll region THEN
18 0C94 22 RET ; return
19
20 0C95 B4 18 01 CUP1A: CJNE A, #MAXLINE, CUP1B ; IF 25th line THEN
21 0C98 22 RET ; return
22
23 0C99 15 12 CUP1B: DEC YPOS ; ELSE dec position
24 0C9B 21 F4 AJMP XBLINAD ; update and return
25
26
27
28
29     ; ; ACUP - ANSI cursor up
30     ;
31     ; *ACUP* moves the cursor toward the top of the display
32     ; the specified Pn number of times.
33     ;
34     ;
35     ; ENTRY none
36     ;
37     ; EXIT none
38     ;
39     ; USES A, DPTR, INDX1, PTR1
40
41
42 0C9D 31 D1 ACUP: ACALL GNP ; Get parameter
43 0C9F 70 01 JNZ ACU1 ; IF no parameter or 0 THEN
44 0CA1 04 INC A ; bump to 1
45
46 0CA2 FA ACU1: MOV INDX1, A ; Set up index
47 0CA3 21 8D ACU: ACALL CUP ; REPEAT cursor up one line
48 0CA5 DA FC DJNZ INDX1, ACU ; UNTIL count = 0
49 0CA7 22 RET

```

*** Z-2? COMPUTER TERMINAL FIRMWARE VERSION 1.03 ***

```

1          ;;          CDN - cursor down
2          ;
3          ;          *CDN* moves the cursor down one line on the display. The
4          ;          cursor may move out of but not into fixed regions and
5          ;          never past line 24.
6          ;
7          ;
8          ;          ENTRY   none
9          ;
10         ;          EXIT    none
11         ;
12         ;          USES    A, DPTR, PTR1
13
14
15 OCB8     E5     12          CDN:      MOV     A, YPOS          ; Get Y-position
16 OCAA     B4     18     01      CJNE    A, #MAXLINE, CDN1 ; IF 25th line THEN return
17 OCAD     22
18
19 OCAE     B4     17     01      CDN1:    CJNE    A, #MAXLINE-1, CDN2 ; IF 24th line THEN return
20 OCB1     22
21
22 OCB2     04          CDN2:      INC     A                ; Bump value
23 OCB3     B5     18     01      CJNE    A, BFIX, CDN3    ; IF scroll region THEN return
24 OCB6     22
25
26 OCB7     05     12          CDN3:    INC     YPOS            ; ELSE bump position
27 OCB9     21     F4          AJMP    XLINAD           ; Update and return
28
29
30
31
32         ;;          ACDN - ANSI cursor down
33         ;
34         ;          *ACDN* moves the cursor toward the bottom of the display
35         ;          the specified Pn number of lines.
36         ;
37         ;
38         ;          ENTRY   none
39         ;
40         ;          EXIT    none
41         ;
42         ;          USES    A, DPTR, INDX1, PTR1
43
44
45 OCB8     31     D1          ACDN:      ACALL   GNP                ; Get parameter
46 OCB0     70     01          JNZ    ACD1            ; IF no parameters or 0 THEN
47 OCBF     04
48
49 OCC0     FA          ACD1:      MOV     INDX1, A        ; Set up index
50 OCC1     91     A8          ACD:      ACALL   CDN          ; REPEAT cursor down one line
51 OCC3     DA     FC          DJNZ   INDX1, ACD      ; UNTIL count = 0
52 OCC5     22
RET

```

```
1          ;;          APBT - ANSI perform back tab
2          ;
3          ;          *APBT* moves the cursor back the number of tab stops indicated.
4          ;
5          ;
6          ;          ENTRY   none
7          ;
8          ;          EXIT    none
9          ;
10         ;          USES   all
11
12
13 OCC6    31    D1          APBT:          ACALL   GNP          ; Get parameter
14 OCC8    70    01          JNZ     APBT1         ; IF no parameter or 0 THEN
15 OCCA    04          INC     A          ; bump to 1
16
17 OCCB    C0    E0          APBT1:         PUSH   ACC          ; REPEAT
18 OCCD    12    0602       LCALL  BTAB         ; perform back tab
19 OCCD0   D0    E0          POP     ACC
20 OCD2    D5    E0    F6    DJNZ   ACC, APBT1        ; UNTIL count = 0
21 OCD5    22          RET
```

```

1 ..... ; ..... CUA = cursor addressing routine .....
2 ..... ; .....
3 ..... ; ..... *CUA* does direct cursor addressing for a few emulation modes.
4 ..... ; .....
5 ..... ; .....
6 ..... ; ..... ENTRY none
7 ..... ; .....
8 ..... ; ..... EXIT none
9 ..... ; .....
10 ..... ; ..... USES all
11 .....
12 .....
13 OCD6 11 2A CUA: ACALL SETDISP ; Set dispatch and return
14 .....
15 OCD8 75 16 04 MOV DSADR1, #LOW (CUC) ; Next dispatch address
16 OCDB 75 15 0D MOV DSADRH, #HIGH (CUC)
17 OCDE 30 43 11 JNB HAZ, CUB0 ; IF Hazeltine THEN
18 OCE1 B4 60 00 CJNE A, #96, CUA1
19 OCE4 40 02 CUA1: JC CUA2 ; IF value >= 96 THEN
20 OCE6 94 60 SUBB A, #96 ; subtract offset
21 OCE8 B4 50 00 CUA2: CJNE A, #NUMCHARS, CUA2A
22 OCEB 40 02 CUA2A: JC CUA3 ; IF value >= numchars THEN
23 OCED 74 4F MOV A, #MAXCHAR ; move to end of line
24 OCEF 80 2F CUA3: SJMP CUR2 ; update and return
25 .....
26 OCF1 22 CUR: RET
27 .....
28 OCF2 C3 CUB0: CLR C
29 OCF3 94 20 SUBB A, #1 ; ELSE subtract offset
30 OCF5 40 FA JC CUR ; check for lower bounds
31 OCF7 B4 18 04 CJNE A, #MAXLINE, CUB1 ; check for upper bounds
32 OCFA 30 15 F4 JNB L25EN, CUR ; IF 25th disabled THEN ret
33 OCFD D3 SETB C ; ELSE fall through
34 OCFE 50 F1 CUB1: JNC CUR ; IF upper bounds ok THEN
35 OD00 F5 12 CUR1: MOV YPOS, A ; replace Y-position
36 OD02 21 F4 AJMP XBLINAD ; build line address
37 .....
38 OD04 11 2F CUC: ACALL SETNORM ; Next dispatch address
39 OD06 30 43 0B JNB HAZ, CUC0 ; IF Hazeltine THEN
40 OD09 54 1F ANL A, #00011111B ; do mod function
41 OD0B B4 18 00 CJNE A, #MAXLINE, CUC1
42 OD0E 40 02 CUC1: JC CUC1A ; IF value >= 24 THEN
43 OD10 74 17 MOV A, #MAXLINE-1 ; move to last line
44 OD12 80 EC CUC1A: SJMP CUR1 ; update and return
45 .....
46 OD14 C3 CUC0: CLR C
47 OD15 94 20 SUBB A, #1 ; Subtract offset
48 OD17 40 05 JC CUC2 ; Check for lower bounds
49 OD19 B4 50 00 CJNE A, #NUMCHARS, CUC0A
50 OD1C 40 02 CUC0A: JC CUR2 ; Check for upper bounds
51 OD1E 74 4F CUC2: MOV A, #MAXCHAR ; IF bad range THEN move to end
52 OD20 F5 11 CUR2: MOV XPOS, A ; Replace X-position
53 OD22 21 F4 AJMP XBLINAD ; Build line address and return

```

```

1          ; ; DSR - define scrolling region
2          ;
3          ;
4          ; *DSR* defines the scrolling regions top and bottom line.
5          ; The region must be at least two lines long and can not include
6          ; the 25th line.
7          ;
8          ;
9          ; ENTRY none
10         ;
11         ;
12         ; EXIT none
13         ;
14         ;
15         ; OD24 31 D1 DSR: ACALL GNP ; Get first parameter
16         ; OD26 60 01 JZ DSRO ; IF parameter and not 0 THEN
17         ; OD28 14 DEC A ; normalize to 0..24
18         ;
19         ; OD29 B4 17 00 DSRO: CJNE A, #MAXLINE-1, DSROA
20         ; OD2C 50 02 DSROA: JNC DSR1 ; IF top >= 22 THEN
21         ; OD2E F5 17 MOV TSCROLL, A ; change value
22         ;
23         ; OD30 31 D1 DSR1: ACALL GNP ; Get next parameter
24         ; OD32 60 01 JZ DSR1A ; IF parameter and not 0 THEN
25         ; OD34 14 DEC A ; normalize to 0..24
26         ;
27         ; OD35 B5 17 01 DSR1A: CJNE A, TSCROLL, DSR2
28         ; OD38 D3 SETB C ; IF bottom = top OR
29         ;
30         ; OD39 40 05 DSR2: JC DSRERR ; IF bottom < top OR
31         ; OD3B B4 18 00 CJNE A, #MAXLINE, DSR2A
32         ; OD3E 40 02 DSR2A: JC DSROK ; IF bottom >= 25 THEN error
33         ;
34         ; OD40 74 17 DSRERR: MOV A, #MAXLINE-1 ; Default error value
35         ; OD42 04 INC A ; Bump for top of bottom fixed
36         ; OD43 F5 18 MOV BFIX, A ; Save value
37         ; OD45 81 36 AJMP SCH ; Set cursor home and return

```

```

1          ;;          PIL - perform insert line
2          ;
3          ;          *PIL* inserts a blank line at the cursor position after
4          ;          moving the remaining lines down one line. Everything is
5          ;          done relative to the region the cursor is in, top fixed,
6          ;          bottom fixed, 25th line, or scrolling region. No region
7          ;          outside of the current region is effected. The cursor is
8          ;          moved to the beginning of the current line.
9          ;
10         ;
11         ;          ENTRY  none
12         ;
13         ;          EXIT   none
14         ;
15         ;          USES   all
16         ;
17
18 0D47 C0 12          PIL:  PUSH  YPOS          ; Save values
19 0D49 C0 17          PUSH  TSCROLL
20 0D4B C0 18          PUSH  BFIX
21 0D4D E5 12          MOV   A, YPOS          ; Get position
22 0D4F B5 17 00      CJNE  A, TSCROLL, PILA    ; IF upper fixed region THEN
23 0D52 40 21          JC    PILRT1          ; Just return
24 0D54 15 18          DEC   BFIX
25 0D56 B5 18 07      CJNE  A, BFIX, PIL1    ; IF last line scrolling region
26 0D59 85 12 F0      MOV   B, YPOS
27 0D5C 71 96          PILO: ACALL CLRLINE    ; Just clear the line
28 0D5E 80 12          SJMP  PILRET
29
30 0D60 40 08          PIL1: JC    PIL2          ; IF lower fixed THEN
31
32 0D62 B4 18 10      CJNE  A, #MAXLINE, PILRT1    ; IF not 25th line THEN return
33 0D65 75 F0 18      MOV   B, #MAXLINE    ; ELSE clear 25th line
34 0D68 80 F2          SJMP  PILO          ; and return
35
36 0D6A 05 18          PIL2: INC   BFIX
37 0D6C 85 12 17      MOV   TSCROLL, YPOS    ; Insert line uses
38 0D6F 12 0518      CALL  PRLF          ; Reverse line feed routine
39
40 0D72 75 11 00      PILRET: MOV  XPOS, #0          ; Move to beginning of line
41 0D75 D0 18          PILRT1: POP  BFIX          ; Restore values
42 0D77 D0 17          POP  TSCROLL
43 0D79 D0 12          POP  YPOS
44 0D7B 21 F4          AJMP  XBLINAD        ; Build line address and return

```

```

1      ;
2      ;
3      ;
4      ;
5      ;
6      ;
7      ;
8      ;
9      ;
10     ;
11     ;
12     ;
13     ;
14 0D7D 31 D1 APIL: ACALL GNP ; Get next Parameter
15 0D7F 70 01 JNZ APILO ; IF no parameter or 0 THEN
16 0D81 04 INC A ; bump to 1
17
18 0D82 FA MOV INDX1, A ; Set up index
19 0D83 B1 47 APIL1: ACALL PIL ; REPEAT insert one line
20 0D85 DA FC DJNZ INDX1, APIL1 ; UNTIL count = 0
21 0D87 22 RET

```



```

1      ;:          PDL = perform delete line.
2      ;
3      ;          *PDL* moves the remaining lines of the current region UP
4      ;          one line, clears the last line of the region, and moves
5      ;          the cursor to the beginning of the current line.
6      ;
7      ;
8      ;          ENTRY   none
9      ;
10     ;          EXIT    none
11     ;
12     ;          USES    all
13     ;
14     ;
15     OD88    C0    12          PDL:      PUSH    YPOS          ; Save values.
16     OD8A    C0    17          PUSH    TSCROLL
17     OD8C    C0    18          PUSH    BFIX
18     OD8E    E5    12          MOV     A, YPOS          ; Get current position
19     OD90    F5    F0          MOV     B, A            ; Save it in (B) also
20     OD92    B5    17    00          CJNE   A, TSCROLL, PDLA ; IF upper fixed THEN
21     OD95    40    DE          PDLA:     JC     PILRT1          ; just return
22     OD97    04          INC     A
23     OD98    B5    18    04          CJNE   A, BFIX, PDL1    ; IF last line of scroll THEN
24     OD9B    71    96          PDL0:     ACALL  CLRLINE         ; clear current line
25     OD9D    80    D3          SJMP   PILRET          ; and return
26     ;
27     OD9F    40    08          PDL1:     JC     PDL2          ; IF bottom fixed THEN
28     ODA1    B4    19    D1          CJNE   A, #NUMLINES, PILRT1 ; IF 25th line THEN
29     ODA4    75    F0    18          MOV     B, #MAXLINE    ; clear 25th line
30     ODA7    80    F2          SJMP   PDL0          ; and return
31     ;
32     ODA9    85    18    12          PDL2:     MOV    YPOS, BFIX    ; Put cursor above fixed
33     ODAC    15    12          DEC    YPOS
34     ODAE    85    F0    17          MOV    TSCROLL, B     ; Get saved current line
35     ODB1    12    0561          LCALL  PLF            ; Line feed to simulate delete
36     ODB4    A1    72          AJMP  PILRET          ; Return

```

```

1          ;;          APDL - ANSI perform delete line
2          ;
3          ;          *APDL* deletes the specified Pn number of lines at and
4          ;          following the cursor position.
5          ;
6          ;
7          ;          ENTRY   none
8          ;
9          ;          EXIT    none
10         ;
11         ;          USES    A, B, DPTR, INDX1
12
13
14 ODB6    31    D1    APDL:    ACALL  GNP          ; Get parameter
15 ODB8    70    01    APDL:    JNZ   APDLO       ; IF no parameter or 0 THEN
16 ODBA    04    APDL:    INC   A              ; bump to 1
17
18 ODBB    FA    APDLO:   MOV   INDX1, A        ; Set up index
19 ODBC    B1    88    APDL1:  ACALL  PDL        ; REPEAT delete one line
20 ODBE    DA    FC    APDL1:  DJNZ  INDX1, APDL1 ; UNTIL count = 0
21 ODC0    22    APDL1:  RET
  
```

```

1          ; PIC - perform insert character
2          ;
3          ; *PIC* move all characters that are at and to the right of the
4          ; cursor one column to the right.  Cursor position does not
5          ; change.
6          ;
7          ;
8          ; ENTRY none
9          ;
10         ; EXIT none
11        ;
12        ; USES all
13
14
15 ODC1    74    50          PIC:    MOV    A, #NUMCHRS    ; Calc number of moves to make
16 ODC3    C3
17 ODC4    95    11
18 ODC6    FA
19
20 ODC7    E5    11          MOV    A, XPOS    ; Get current address
21 ODC9    85    12    F0    MOV    B, YPOS
22 ODCC    12    0503      LCALL  CLA
23
24 ODCF    78    20          MOV    PTR1, #
25 ODD1    79    00          MOV    PTR2, #0    ; Init value for 1st slot
26
27 ODD3    E0          PIC1:    MOVX   A, @DPTR
28 ODD4    FC          MOV    WORK, A    ; Save lower character
29 ODD5    53    83    EF    ANL    DPH, #ATRANL
30 ODD8    E0          MOVX   A, @DPTR
31 ODD9    FD          MOV    TEMP, A    ; Save lower attribute
32
33 ODDA    E9          MOV    A, PTR2
34 ODDB    F0          MOVX   @DPTR, A    ; Write lower attribute
35 ODDC    43    83    10    ORL    DPH, #CHRORL
36 ODDF    E8          MOV    A, PTR1
37 ODE0    F0          MOVX   @DPTR, A    ; Write lower character
38
39 ODE1    A8    04          MOV    PTR1, WORKA    ; Exchange character
40 ODE3    A9    05          MOV    PTR2, TEMPA    ; Exchange attribute
41
42 ODE5    A3          INC    DPTR    ; Bump up
43 ODE6    DA    EB          DJNZ  INDX1, PIC1    ; UNTIL all done
44 ODES    22          RET

```

```
1          ;:          APIC - ANSI perform insert character
2          ;
3          ;          *APIC* inserts the specified number of characters into
4          ;          the line.
5          ;
6          ;
7          ;          ENTRY none
8          ;
9          ;          EXIT none
10         ;
11         ;          USES all
12
13
14 ODE9    31    D1          APIC:          ACALL    GNP          ; Get parameter
15 ODEB    70    01          ;          JNZ     APICO         ; IF no parameter or 0 THEN
16 ODED    04          ;          INC     A          ; bump to i
17
18 ODEE    FB          APIC0:          MOV     INDX2, A      ; Setup index
19 ODEF    B1    C1          APIC1:          ACALL    PIC          ; REPEAT perform insert char
20 ODF1    DB    FC          ;          DJNZ   INDX2, APIC1     ; UNTIL count = 0
21 ODF3    22          ;          RET
```

*** Z-29 COMPUTER TERMINAL FIRMWARE VERSION 1.03 ***

```

1 ..... ; PDC - perform delete character .....
2 ..... ; .....
3 ..... ; .....
4 ..... ; *PDC* deletes the character at the cursor position by moving .....
5 ..... ; the remaining characters on the line to the left one column .....
6 ..... ; and inserting a space in the last column on the line. Cursor .....
7 ..... ; position does not change.
8 ..... ; .....
9 ..... ; ENTRY none .....
10 ..... ; .....
11 ..... ; EXIT none .....
12 ..... ; .....
13 ..... ; USES all .....
14 ..... ; .....
15 ..... ; .....
16 0DF4 74 4F PDC: MOV A, #MAXCHAR ; Calc number of moves
17 0DF6 C3 CLR C .....
18 0DF7 95 11 SUBB A, XPOS .....
19 0DF9 FA MOV INDX1, A .....
20 ODFA 74 4F MOV A, #MAXCHAR ; Get address at end of line
21 ODFC 85 12 F0 MOV B, YPOS .....
22 0DFF 12 0503 LCALL CLA .....
23 0E02 E0 MOVX A, @DPTR .....
24 0E03 F8 MOV PTR1, A ; Save upper character
25 0E04 74 20 MOV A, #' ' .....
26 0E06 F0 MOVX @DPTR, A ; Clear last character
27 0E07 53 83 EF ANL DPH, #ATRANL .....
28 0E0A E0 MOVX A, @DPTR .....
29 0E0B F9 MOV PTR2, A ; Save upper attribute
30 0E0C E4 CLR A .....
31 0E0D F0 MOVX @DPTR, A ; Clear last attribute
32 0E0E EA MOV A, INDX1 .....
33 0E0F 60 20 JZ PDC2 ; Exit out if last column
34 ..... ; .....
35 0E11 E5 82 PDC1: MOV A, DPL ; Decrement DPTR without
36 0E13 24 FF ADD A, #-1 ; Using a "-CLR C"
37 0E15 F5 82 MOV DPL, A ; Instruction to save
38 0E17 E5 83 MOV A, DPH ; Every bit of time
39 0E19 34 FF ADDC A, #-1 .....
40 0E1B F5 83 MOV DPH, A .....
41 ..... ; .....
42 0E1D E0 MOVX A, @DPTR .....
43 0E1E FD MOV TEMP, A ; Save lower attribute
44 0E1F 43 83 10 ORL DPH, #CHRORL .....
45 0E22 E0 MOVX A, @DPTR .....
46 0E23 FC MOV WORK, A ; Save lower character
47 ..... ; .....
48 0E24 E8 MOV A, PTR1 .....
49 0E25 F0 MOVX @DPTR, A ; Write character
50 0E26 53 83 EF ANL DPH, #ATRANL .....
51 0E29 E9 MOV A, PTR2 .....
52 0E2A F0 MOVX @DPTR, A ; Write attribute
53 ..... ; .....
54 0E2B A8 04 MOV PTR1, WORKA ; Exchange character
55 0E2D A9 05 MOV PTR2, TEMPA ; Exchange attribute
56 0E2F DA E0 DJNZ INDX1, PDC1 ; UNTIL all done
57 0E31 22 PDC2: RET .....

```

```
1          ; APDC - ANSI perform delete character
2          ;
3          ; *APDC* deletes the specified number of characters from the
4          ; line.
5          ;
6          ;
7          ; ENTRY none
8          ;
9          ; EXIT none
10         ;
11         ; USES all
12
13
14 0E32 31 D1 APDC: ACALL GNP ; Get parameter
15 0E34 70 01 JNZ APDC0 ; IF no parameter or 0 THEN
16 0E36 04 INC A ; bump to 1
17
18 0E37 FB APDC0: MOV INDX2, A ; Setup index
19 0E38 B1 F4 APDC1: ACALL PDC ; REPEAT perform delete char
20 0E3A DB FC DJNZ INDX2, APDC1 ; UNTIL count = 0
21 0E3C 22 RET
```

*** Z-29 COMPUTER TERMINAL FIRMWARE VERSION 1.03 ***

```

1          ;:          ZDSSBR - ZDS set baud rate.
2          ;
3          ;          *ZDSSBR* sets the baud rate of the UART built into the 8051.
4          ;
5          ;
6          ;          ENTRY   none
7          ;
8          ;          EXIT    none
9          ;
10         ;          USES   all
11
12
13 0E3D    11    2A          ZDSSBR:      ACALL   SETDISP          ; Set dispatch and return.
14
15 0E3F    11    2F          ACALL   SETNORM          ; Restore dispatch address.
16 0E41    C3          CLR     C
17 0E42    94    40          SUBB   A, #'@'          ; Subtract offset.
18 0E44    40    18          JC     SBRET          ; Check for lower bounds.
19 0E46    B4    0E    00          CJNE  A, #'(N'-'@)', ZDS0 ; Check for upper bounds.
20 0E49    50    13          ZDS0:  JNC     SBRET
21
22          IFC     NE, SBR-$
23          ERROR  ;ROUTINE 'SBR' MUST FOLLOW.
24          ENDC
25
26
27
28
29          ;:          SBR - set baud rate
30          ;
31          ;          *SBR* selects a baud rate given the value of which rate to
32          ;          select.
33          ;
34          ;
35          ;          ENTRY   (A) = which baud rate (0..13)
36          ;
37          ;          EXIT    none
38          ;
39          ;          USES   A, DPTR
40
41
42 0E4B    90    0E5F          SBR:      MOV    DPTR, #BRTAB          ; Point to baud rate table
43 0E4E    93          MOV    A, @A+DPTR          ; Get value from table
44 0E4F    60    0D          JZ     SBRET          ; IF zero THEN exit
45 0E51    F5    33          MOV    BAUDRATE, A          ; Save baud rate.
46 0E53    F5    8D          MOV    TH1, A          ; Change baud rate
47 0E55    C2    9F          CLR    SMO          ; Place UART into mode 1
48 0E57    B4    53    00          CJNE  A, #83, SBRO
49 0E5A    50    02          SBRO:  JNC     SBRET          ; IF baud <= 300 THEN
50 0E5C    D2    9F          SETB  SMO          ; place UART into mode 3
51 0E5E    22          SBRET:  RET

```

```

1          ;;          BRTAB - baud rate table
2          ;
3          ;
4          ;          *BRTAB* contains the timer values for baud rates
5
6          OE5F          BRTAB          EQU          $
7
8  OE5F          01          DB          1          ; 75 baud
9  OE60          52          DB          82          ; 110 baud
10 OE61          80          DB          128         ; 150 baud
11 OE62          C0          DB          192         ; 300 baud
12 OE63          E0          DB          224         ; 600 baud
13 OE64          F0          DB          240         ; 1200 baud
14 OE65          F5          DB          245         ; 1800 baud
15 OE66          00          DB          0          ; 2000 baud (not available)
16 OE67          F8          DB          248         ; 2400 baud
17 OE68          00          DB          0          ; 3600 baud (not available)
18 OE69          FC          DB          252         ; 4800 baud
19 OE6A          00          DB          0          ; 7200 baud (not available)
20 OE6B          FE          DB          254         ; 9600 baud
21 OE6C          FF          DB          255         ; 19200 baud

```



```

1          ;:          PSOF - put string in output FIFO
2          ;
3          ;          *PSOF* places the character string pointed to by DPTR into
4          ;          the output FIFO.  Final character has bit seven set.
5          ;
6          ;
7          ;          ENTRY (DPTR) = start of string
8          ;
9          ;          EXIT none
10         ;
11         ;          USES A, B, DPTR
12
13
14 0E6D    E4          PSOF:          CLR    A          ; REPEAT
15 0E6E    93          MOV    A, @A+DPTR ; set character
16 0E6F    20    E7    OD          JB    ACC.7, SOR ; IF bit 7 set THEN exit
17 0E72    C0    82          PUSH   DPL          ; save DPTR
18 0E74    C0    83          PUSH   DPH
19 0E76    D1    A6          ACALL  CPR2          ; place character on FIFO
20 0E78    D0    83          POP    DPH          ; restore DPTR
21 0E7A    D0    82          POP    DPL
22 0E7C    A3          INC    DPTR          ; bump pointer
23 0E7D    80    EE          SJMP  PSOF          ; UNTIL done
24
25 0E7F    54    7F          SOR:          ANL    A, #7FH          ; Mask off 7th bit
26 0E81    80    23          SJMP  CPR2          ; Place last char on FIFO

```

```

1          ; ;          CPR - cursor position report
2          ;
3          ; ;          *CPR* outputs the cursor position in the format of the mode
4          ; ;          currently set.
5          ;
6          ;
7          ; ;          ENTRY none
8          ;
9          ; ;          EXIT none
10         ;
11        ; ;          USES all
12
13
14 0E83 30 43 11 CPR: JNB HAZ, CPR1 ; IF Hazeltine THEN
15 0E86 E5 11 MOV A, XPOS ; set -xpos-
16 0E88 B4 20 00 CJNE A, #32, CPRO ;
17 0E8B 50 02 CPRO: JNC CPROA ; IF value < 32 THEN
18 0E8D 24 60 ADD A, #96 ; normalize
19 0E8F D1 A6 CPROA: ACALL CPR2 ; output value
20 0E91 E5 12 MOV A, YPOS ; set -ypos-
21 0E93 24 60 ADD A, #96 ; normalize
22 0E95 80 0F SJMP CPR2 ; output value and return
23
24 0E97 90 0EA9 CPR1: MOV DPTR, #CPRM ; ELSE
25 0E9A D1 6D ACALL PSOF ; output ESC.Y
26 0E9C E5 12 MOV A, YPOS ; set line number
27 0E9E 24 20 ADD A, # ;
28 0EA0 D1 A6 ACALL CPR2 ; output it
29 0EA2 E5 11 MOV A, XPOS ; set column number
30 0EA4 24 20 ADD A, # ; convert to ASCII
31 0EA6 02 022A CPR2: JMP PCOF ; output it and return
32
33 0EA9 1B D9 CPRM: DB ESC, ('Y'+80H) ; ESC.Y

```

*** Z-29 COMPUTER TERMINAL FIRMWARE VERSION 1.03 ***

```

1      ; ; IDT - identify terminal
2      ;
3      ;
4      ; *IDT* identifies the terminal as a DEC VT52 so that existing
5      ; DEC software which interrogates the console type will operate
6      ; as it would with a VT52.
7      ;
8      ;
9      ; ENTRY none
10     ;
11     ; EXIT none
12     ;
13     ; USES all
14     ;
15 OEAB 90 OEBO IDT: MOV DPTR, #IDTM
16 OEAE C1 6D AJMP PSOF ; Output string and return
17
18 OEBO 1B 2F CB IDTM: DB ESC, '?', ('K'+80H) ; ESC / K
19
20
21
22
23     ; ; IDTT - identify terminal type
24     ;
25     ;
26     ; *IDTT* identifies the terminal as a Z-29 so that future
27     ; software can interrogate the console type and see what
28     ; version of the terminal is running.
29     ;
30     ;
31     ; ENTRY none
32     ;
33     ; EXIT none
34     ;
35     ; USES all
36     ;
37 OEB3 11 2A IDTT: ACALL SETDISP ; Set dispatch and return
38
39 OEB5 11 2F ACALL SETNORM ; Restore dispatch address
40 OEB7 B4 30 6B CJNE A, #'0', ZAR ; IF not '0' THEN return
41 OEBA 90 OEBF MOV DPTR, #IDTTM
42 OEBD C1 6D AJMP PSOF ; Output string and return
43
44 OEBF 1B 69 42 IDTTM: DB ESC, 'iB', ('0'+80H) ; ESC i B 0
45 OEC2 B0

```

```

1          ;;          ADA - ANSI device attributes
2          ;
3          ;
4          ;          *ADA* identifies the terminal as a DEC VT100 so that existing
5          ;          DEC software which interrogates the console type will operate
6          ;          as it would with a VT100.
7          ;
8          ;          ENTRY none
9          ;
10         ;          EXIT none
11        ;
12        ;          USES all
13
14
15 OEC3    31    D1          ADA:          ACALL  GNP          ; Get parameter
16 OEC5    70    5E          ;          JNZ   ZAR          ; IF no Parameter or 0 THEN
17 OEC7    90    OECC       ;          MOV   DPTR, #ADAM
18 OECA    C1    6D          ;          AJMP  PSOF          ; output string and return
19
20 OEEC    1B    5B    3F    ADAM:        DB    ESC, '[?1;2', ('c'+80H)
    OECF    31    3B    32
    OED2    E3

```

```

1 .....:; .....ZTAB - ZDS mode tab functions .....
2 .....:; .....
3 .....:; .....*ZTAB* does the tab function requested.....
4 .....:; .....
5 .....:; .....
6 .....:; .....ENTRY none .....
7 .....:; .....
8 .....:; .....EXIT none .....
9 .....:; .....
10 .....:; .....USES all .....
11 .....:; .....
12 .....:; .....
13 0ED3 ..... 11 ..... 2A ..... ZTAB: ..... ACALL SETDISP ..... ; Get dispatch address and return .....
14 .....:; .....
15 0ED5 ..... 11 ..... 2F ..... ACALL SETNORM ..... ; Restore dispatch address .....
16 0ED7 ..... 75 ..... F0 ..... 03 ..... MOV B, #ZTABTL .....
17 0EDA ..... 90 ..... 0EDF ..... MOV DPTR, #ZTAB .....
18 0EDD ..... 01 ..... 36 ..... AJMP STJMP ..... ; Jump to any routine .....
19 .....:; .....
20 .....:; .....
21 .....:; .....
22 .....:; .....
23 .....:; .....ZTABT - ZDS mode tab table .....
24 .....:; .....
25 .....:; .....*ZTABT* contains valid parameters for the set/clear tab .....
26 .....:; .....functions in ZDS mode. ....
27 .....:; .....
28 .....:; .....
29 ..... 0EDF ..... ZTABT ..... EQU # .....
30 .....:; .....
31 0EDF ..... 30 ..... DB '0' ..... ; ESC . 0 .....
32 0EE0 ..... 0627 ..... DW HTC ..... ; Horizontal tab clear .....
33 .....:; .....
34 0EE2 ..... 33 ..... DB '3' ..... ; ESC . 3 .....
35 0EE3 ..... 0598 ..... DW CLR TABS ..... ; Clear all tabs .....
36 .....:; .....
37 0EE5 ..... 38 ..... DB '8' ..... ; ESC . 8 .....
38 0EE6 ..... 0621 ..... DW HTS ..... ; Horizontal tab set .....
39 .....:; .....
40 ..... 0003 ..... ZTABTL ..... EQU ($-ZTABT)/3 ..... ; Table length .....

```

```
1          ;;          SCP - save cursor position
2          ;
3          ;          *SCP* saves current cursor position.
4          ;
5          ;
6          ;          ENTRY none
7          ;
8          ;          EXIT none
9          ;
10         ;          USES none
11
12
13 0EE8 85 11 35 SCP: MOV XXPOS, XPOS ; Save values
14 0EEB 85 12 36 MOV XYPOS, YPOS
15 0EEE 22 RET
16
17
18
19
20         ;;          ASCP - ANSI save cursor position
21         ;
22         ;          *ASCP* saves current position and attributes.
23         ;
24         ;
25         ;          ENTRY none
26         ;
27         ;          EXIT none
28         ;
29         ;          USES all
30
31
32 0EEF 31 D1 ASCP: ACALL GNP ; Get parameter if any
33 0EF1 40 F5 JC SCP ; IF no parameter THEN ok
34 0EF3 22 RET
```

*** Z-29 COMPUTER TERMINAL FIRMWARE VERSION 1.03 ***

```

1      ; ; USCP - unsave cursor position
2      ; ;
3      ; ; *USCP* returns to position saved with the use of *SCP*.
4      ; ;
5      ; ;
6      ; ; ENTRY none
7      ; ;
8      ; ; EXIT none
9      ; ;
10     ; ; USES all
11
12
13 0EF4 85 35 11 USCP: MOV XPOS, XXPOS ; Restore values
14 0EF7 E5 36 MOV A, XYPOS
15 0EF9 B4 18 03 CJNE A, #MAXLINE, USCP1 ; IF on 25th line THEN
16 0EFC 30 15 02 JNB L25EN, USCP2 ; IF not enabled THEN exit
17 0EFF F5 12 USCP1: MOV YPOS, A ; ELSE set position
18 0F01 21 F4 USCP2: AJMP XBLINAD ; build address and return
19
20
21
22
23     ; ; AUSCP - ANSI unsave cursor position
24     ; ;
25     ; ; *AUSCP* returns to position saved with the use of *SPCP*.
26     ; ;
27     ; ;
28     ; ; ENTRY none
29     ; ;
30     ; ; EXIT none
31     ; ;
32     ; ; USES all
33
34
35 0F03 31 D1 AUSCP: ACALL GNP ; Get parameter if any
36 0F05 40 ED JC USCP ; IF no parameters THEN ok
37 0F07 22 RET

```

```

1          ;:          ZATR - ZDS select attributes
2          ;
3          ;          *ZATR* selects which attributes are to be turned on or off
4          ;          using the configuration of the lower 5 bits of the character.
5          ;
6          ;
7          ;          ENTRY   none
8          ;
9          ;          EXIT    none
10         ;
11         ;          USES   all
12         ;
13         ;
14 0F08    11    2A          ZATR:    ACALL  SETDISP          ; Set dispatch and return
15         ;
16 0F0A    11    2F          ACALL  SETNORM          ; Restore dispatch address
17 0F0C    C3          CLR      C
18 0F0D    94    30          SUBB   A, #10
19 0F0F    40    14          JC     ZAR          ; IF below range THEN exit
20 0F11    B4    20    00          CJNE  A, #32, ZATRO
21 0F14    50    0F          ZATRO:  JNC   ZAR          ; IF above range THEN exit
22 0F16    13          RRC     A          ; Get reverse video
23 0F17    92    08          MOV   RVVA, C
24 0F19    13          RRC     A          ; Get blinking
25 0F1A    92    0A          MOV   BLINKA, C
26 0F1C    13          RRC     A          ; Get half intensity
27 0F1D    92    0B          MOV   HALFIA, C
28 0F1F    13          RRC     A          ; Get underline
29 0F20    92    09          MOV   UNDLNA, C
30 0F22    13          RRC     A          ; Get alternate char set
31 0F23    92    0C          MOV   ALTCHARA, C
32 0F25    22          ZAR:    RET
33         ;
34         ;
35         ;
36         ;
37         ;:          XATR - exit all attributes
38         ;
39         ;          *XATR* turns off all attributes so that none are active.
40         ;
41         ;
42         ;          ENTRY   none
43         ;
44         ;          EXIT    none
45         ;
46         ;          USES   none
47         ;
48         ;
49 0F26    53    21    F0      XATR:    ANL   ATTRIBUTES, #0F0H          ; Mask off all attributes
50 0F29    22          RET

```



```

1          ;;          EHALF - enter half intensity mode
2          ;
3          ;          *EHALF* places the terminal into half intensity mode.
4          ;
5          ;
6          ;          ENTRY none
7          ;
8          ;          EXIT none
9          ;
10         ;          USES none
11        ;
12        ;
13 0F2A    D2    0B          EHALF:          SETB    HALFIA          ; Set half intensity attribute
14 0F2C    22
15
16
17
18
19        ;;          EUNDL - enter underline mode
20        ;
21        ;          *EUNDL* places the terminal into underline mode.
22        ;
23        ;
24        ;          ENTRY none
25        ;
26        ;          EXIT none
27        ;
28        ;          USES none
29        ;
30
31 0F2D    D2    09          EUNDL:          SETB    UNDLNA          ; Set underline attribute
32 0F2F    22
33
34
35
36
37        ;;          EBLNK - enter blink mode
38        ;
39        ;          *EBLNK* places the terminal into blink mode
40        ;
41        ;
42        ;          ENTRY none
43        ;
44        ;          EXIT none
45        ;
46        ;          USES none
47        ;
48
49 0F30    D2    0A          EBLNK:          SETB    BLINKA          ; Set blink attribute
50 0F32    22

```

```
1 ; ; ERVM - enter reverse video mode
2 ; ;
3 ; ; *ERVM* places the terminal into reverse video mode.
4 ; ;
5 ; ;
6 ; ; ENTRY none
7 ; ;
8 ; ; EXIT none
9 ; ;
10 ; ; USES none
11 ; ;
12 ; ;
13 0F33 D2 08 ERVM: SETB RVVA ; Set reverse video attribute
14 0F35 22 RET
15 ; ;
16 ; ;
17 ; ;
18 ; ;
19 ; ; XRVM - exit reverse video mode
20 ; ;
21 ; ; *XRVM* removes the terminal from reverse video mode.
22 ; ;
23 ; ;
24 ; ; ENTRY none
25 ; ;
26 ; ; EXIT none
27 ; ;
28 ; ; USES none
29 ; ;
30 ; ;
31 0F36 C2 08 XRVM: CLR RVVA ; Clear reverse video attribute
32 0F38 22 RET
```

*** Z-29 COMPUTER TERMINAL FIRMWARE VERSION 1.03 ***

```
.....
1      ;:      EGM - enter graphics mode.....
2      ;
3      ;      *EGM* places terminal into graphics mode.....
4      ;
5      ;
6      ;      ENTRY   none.....
7      ;
8      ;      EXIT    none.....
9      ;
10     ;      USES   none.....
11     ;
12     ;
13     OF39   D2     OD     EGM:      SETB   GRPH      ; Set graphics mode.....
14     OF3B   22
15     ;
16     ;
17     ;
18     ;
19     ;:      XGM - exit graphic mode.....
20     ;
21     ;      *XGM* exits the terminal out of graphic character mode.....
22     ;
23     ;
24     ;      ENTRY   none.....
25     ;
26     ;      EXIT    none.....
27     ;
28     ;      USES   none.....
29     ;
30     ;
31     OF3C   C2     OD     XGM:      CLR    GRPH      ; Clear graphic mode.....
32     OF3E   22
```

```

1          ; ;          GODES - G0 designator
2          ; ;          GIDES - G1 designator
3          ; ;
4          ; ;          *GODES* and *GIDES* assign a graphic character set to be
5          ; ;          associated with itself.  If the character set is not found
6          ; ;          then no action is taken.  The values returned for the
7          ; ;          different character sets are as follows:
8          ; ;
9          ; ;          Character | Internal
10         ; ;          received | value and meaning
11         ; ;          -----
12         ; ;          A         | 0 = United States (should be United Kingdom)
13         ; ;          B         | 0 = United States
14         ; ;          0         | 1 = United States with alternate graphic characters
15         ; ;          1         | 2 = Alternate character set
16         ; ;          2         | 3 = Alternate with alternate graphic characters
17         ; ;
18         ; ;
19         ; ;          ENTRY none
20         ; ;
21         ; ;          EXIT  none
22         ; ;
23         ; ;          USES  all
24         ; ;
25
26 0F3F    11    2A          GODES:    ACALL  SETDISP          ; Set dispatch and return
27
28 0F41    11    2F          ACALL  SETNORM          ; Restore dispatch address
29 0F43    C2    D5          CLR    FO              ; Flag for GODES
30 0F45    80    08          SJMP  GDES            ; Do the stuff
31
32
33
34
35 0F47    11    2A          GIDES:    ACALL  SETDISP          ; Set dispatch and return
36
37 0F49    11    2F          ACALL  SETNORM          ; Restore dispatch address
38 0F4B    D2    D5          SETB  FO              ; Flag for GIDES
39 0F4D    80    00          SJMP  GDES            ; Do the stuff
40
41
42
43
44 0F4F    B4    41    03    GDES:    CJNE  A, #'A', GDES1          ; IF char = 'A' THEN
45 0F52    E4          GDES0:    CLR    A              ; ...value of zero
46 0F53    80    10          SJMP  GDES3
47
48 0F55    B4    42    02    GDES1:    CJNE  A, #'B', GDES2          ; IF char = 'B' THEN
49 0F58    80    F8          SJMP  GDES0
50
51 0F5A    C3          GDES2:    CLR    C
52 0F5B    94    30          SUBB  A, #'0'          ; Subtract offset
53 0F5D    40    1B          JC    GDESR           ; IF out of bounds THEN return
54 0F5F    B4    03    00          CJNE  A, #3, GDES2A
55 0F62    50    16          GDES2A: JNC   GDESR           ; IF out of bounds THEN return
56 0F64    04          INC   A              ; Bump into range
57

```



```

1          ;
2          ;
3          ;
4          ;
5          ;
6          ;
7          ;
8          ;
9          ;
10         ;
11         ;
12         ;
13         ;
14         ;
15         ;
16 0F7B    C2    12          GOPICK:    CLR    GSEL          ; Clear select flag
17 0F7D    E5    1F          MOV    A, GSET        ; Get graphic set chosen
18 0F7F    80    05          SJMP   GPICK
19
20 0F81    D2    12          GIPICK:   SETB   GSEL          ; Set select flag
21 0F83    E5    1F          MOV    A, GSET        ; Get graphic set chosen
22 0F85    C4
23
24 0F86    53    21    4F    GPICK:    ANL    ATTRIBUTES, #01001111B ; Clean different modes out
25
26 0F89    54    0F          ANL    A, #00001111B  ; Mask to set number of set
27
28 0F8B    90    0F92       MOV    DPTR, #GPICKT ; Get address of table
29 0F8E    93          MOV    A, @A+DPTR    ; Get value from table
30 0F8F    42    21          ORL    ATTRIBUTES, A ; Set as indicated by table
31 0F91    22
32
33
34
35
36         ;
37         ;
38         ;
39         ;
40         ;
41         ;
42         ;
43         ;
44         ;
45 0F92    00          DB     00000000B    ; 0 - norm char
46
47 0F93    A0          DB     10100000B    ; 1 - norm char and alt graphic set
48
49 0F94    10          DB     00010000B    ; 2 - alt char set
50
51 0F95    B0          DB     10110000B    ; 3 - alt char and graphic set

```

```

1      ;: SBLR - set blink rate
2      ;
3      ;
4      ; *SBLR* sets the blink rate in increments of 1/30 second. The
5      ; default value is 32/30 second. If a value of 255 is received
6      ; then all blinking data is suppressed. If a value of 0
7      ; is received then all blinking data is continuously on.
8      ;
9      ;
10     ; ENTRY none
11     ;
12     ;
13     ; EXIT none
14     ;
15     ;
16     ; USES all
17     ;
18     ;
19     ;
20     ;
21     ;
22     ;
23     ;
24     ;
25     ;
26     ;
27     ;
28     ;
29     ;
30     ;
31     ;
32     ;
33     ;
34     ;

```

16	0F96	31	D1	SBLR:	ACALL	GNP		
17	0F98	50	02		JNC	SB1		; IF no parameter THEN
18	0F9A	74	20		MOV	A, #32		; set to default value
19								
20	0F9C	F5	37	SB1:	MOV	BLNKRATE, A		; Set blink rate
21	0F9E	60	06		JZ	SB2		; IF not zero THEN
22	0FA0	B4	FF		CJNE	A, #255, SBRT		; IF max value THEN
23	0FA3	D3			SETB	C		; flag off and
24	0FA4	80	01		SJMP	SB3		; set output
25								
26	0FA6	C3		SB2:	CLR	C		; ELSE IF zero THEN flag on
27								
28	0FA7	92	01	SB3:	MOV	BLINKF, C		; Set output of blink
29	0FA9	E5	20		MOV	A, XLATCH		
30	0FAB	90	3000		MOV	DPTR, #MLATCH		
31	0FAE	F0			MOVX	@DPTR, A		; Set latch
32								
33	0FAF	75	38	SBRT:	MOV	BLNKCNT, #0		; Zero count and return
34	0FB2	22			RET			

```
1 ; ; EKI - enable keyboard input
2 ; ;
3 ; ; *EKI* resets the flag which disables input from the keyboard.
4 ; ;
5 ; ;
6 ; ; ENTRY none
7 ; ;
8 ; ; EXIT none
9 ; ;
10 ; ; USES all
11 ; ;
12 ; ;
13 0FB3 C2 1F EKI: CLR KBDISF
14 0FB5 74 89 MOV A, #KBC_EK ; Enable keyboard
15 0FB7 61 2A AJMP XPCKB ; Output and return
16 ; ;
17 ; ;
18 ; ;
19 ; ;
20 ; ; DKI - disable keyboard input
21 ; ;
22 ; ; *DKI* sets the flag which disables input from the keyboard.
23 ; ;
24 ; ;
25 ; ; ENTRY none
26 ; ;
27 ; ; EXIT none
28 ; ;
29 ; ; USES all
30 ; ;
31 ; ;
32 0FB9 D2 1F DKI: SETB KBDISF
33 0FBB 74 88 MOV A, #KBC_DK ; Disable keyboard
34 0FBD 61 2A AJMP XPCKB ; Output and return
```



```

1 .....:;:.....KBCPLK = keyboard.caps.lock.routine.....
2 .....:;:
3 .....:;:.....*KBCPLK* toggles the keyboard into and out of the caps.....
4 .....:;:.....locked mode.
5 .....:;:
6 .....:;:
7 .....:;:.....ENTRY none.....
8 .....:;:
9 .....:;:.....EXIT none.....
10 .....:;:
11 .....:;:.....USES A, DPTR
12 .....:;:
13 .....:;:
14 OFBF B2 35 KBCPLK: CPL CAPLOCKF ; Toggle caps locked flas
15 OFC1 74 84 MOV A, #KBC_EL
16 OFC3 20 35 02 JB CAPLOCKF, KC1
17 OFC6 74 85 MOV A, #KBC_XL
18 OFC8 71 2A KC1: ACALL XPCKB ; Output command to keyboard
19 OFCA 61 23 AJMP XR2_DISP ; Display status line & return

```

```

1          ; KBBREAK - keyboard break key
2          ;
3          ; *KBBREAK* indicates that the break key on the keyboard has
4          ; been depressed. The terminal should then hold the serial
5          ; output line low for a length of time.
6          ;
7          ;
8          ; ENTRY none
9          ;
10         ; EXIT none
11        ;
12        ; USES all
13
14
15 OFCC    C2    B1          KBBREAK: CLR    TXD          ; Set break
16 OFCE    7A    00          MOV    INDX1, #0
17 OFD0    7B    50          MOV    INDX2, #80
18 OFD2    12    02B6       BR1:    LCALL  FCKB          ; REPEAT look at keyboard
19 OFD5    40    05          JC     BR2
20 OFD7    B4    89    02    CJNE  A, #KB_BREAK, BR2      ; IF another break THEN
21 OFDA    80    F0          SJMP  KBBREAK        ; start again
22 OFDC    DA    F4          BR2:    DJNZ  INDX1, BR1      ; UNTIL done
23 OFDE    DB    F2          DJNZ  INDX2, BR1      ; UNTIL all done
24 OFE0    D2    B1          SETB  TXD          ; Back to normal
25 OFE2    22          RET

```

.Z-29.COMPUTER.TERMINAL.FIRMWARE.VERSION.1.03.

```

1          ;:          KBSCROLL = keyboard "NO SCROLL" key
2          ;
3          ;          *KBSCROLL* indicates that the "NO SCROLL" key on the
4          ;          keyboard has been depressed.
5          ;
6          ;
7          ;          ENTRY none
8          ;
9          ;          EXIT none
10         ;
11         ;          USES all
12         ;
13
14 0FE3    20    36    0A    KBSCROLL:    JB    HSMODEF, KBSCR2    ; IF not hold screen mode THEN
15 0FE6    74    13          MOV    A, #XOFF        ; start with XOFF
16 0FEB    30    11    02    JNB   UXOFFSENT, KBSCR1 ; IF user XOFF last sent THEN
17 0FEB    74    11          MOV    A, #XON         ; send an XON now instead
18
19 0FED    02    022A    KBSCR1:    LJMPL PCOF          ; place in output FIFO and return
20
21 0FF0    C2    22          KBSCR2:    CLR    HSSTOFF       ; ELSE allow screen to run
22 0FF2    05    1E          INC    HSLINE        ; bump line count
23 0FF4    30    1C    07    JNB   SHIFTF, KSR     ; IF shift down THEN
24 0FF7    E5    18          MOV    A, BFIX       ; calculate number
25 0FF9    C3    C          CLR    C             ; between pages
26 0FFA    95    17          SUBB  A, TSCROLL
27 0FFC    F5    1E          MOV    HSLINE, A
28 0FFE    22          KSR:    RET

```

1

```

1          ;!          ROM #2 vectors
2          ;
3          ;          These locations are provided to facilitate future modifications
4          ;          without a change to the masked processor. Each location is
5          ;          accessed with a -CALL- and control is gained back with a -RET-.
6          ;
7          ;
8          ;          Initialization of terminal.
9          ;
10         1000          ORG      R2_IN
11 1000 02 10AF        JMP      ALLINIT
12
13
14         ;          Soft initialization of terminal.
15         ;
16         1003          ORG      R2_IN2
17 1003 02 10E4        JMP      SOFTINIT
18
19
20         ;          Start DMA routine.
21         ;
22         1006          ORG      R2_STARTDMA
23 1006 02 11DC        LJMP     STARTDMA
24
25
26         ;          Stop DMA routine.
27         ;
28         1009          ORG      R2_STOPDMA
29 1009 02 11FD        LJMP     STOPDMA
30
31
32         ;          Fill screen routine.
33         ;
34         100C          ORG      R2_FILL
35 100C 02 1262        LJMP     STFILL
36
37
38         ;          Interrupt request.
39         ;
40         100F          ORG      R2_IRQ
41 100F 02 1329        LJMP     IRQ
42
43
44         ;          Serial interrupt.
45         ;
46         1012          ORG      R2_SERIAL
47 1012 02 12CB        LJMP     SERIAL
48
49
50         ;          Transmit character from serial port.
51         ;
52         1015          ORG      R2_XMT
53 1015 02 139B        LJMP     TRANSMIT
54
55         ;          Send XON to host
56         ;
57         1018          ORG      R2_XON

```

```
1 1018 02 13D5 LJMP DOXON
2
3
4 ; Initialize the cursor format.
5 ;
6 101B ORG R2_ICUR
7 101B 02 117B LJMP SETCF
8
9
10 ; Initialize the keyboard
11 ;
12 101E ORG R2_IKB
13 101E 02 119E LJMP INITKB
14
15
16 ; Setup mode vector
17 ;
18 1021 ORG R2_SETUP
19 1021 02 1417 LJMP SETUP
20
21
22 ; Background loop hook.
23 ;
24 1024 ORG R2_BACK
25 1024 22 RET
26
27
28 ; Keyboard input hook.
29 ;
30 1027 ORG R2_KY1
31 1027 22 RET
32
33
34 ; Keyboard output hook.
35 ;
36 102A ORG R2_KY2
37 102A 22 RET
38
39
40 ; Escape parsing hook.
41 ;
42 102D ORG R2_ESC
43 102D 22 RET
44
45
46 ; Transmit character.
47 ;
48 1030 ORG R2_TC
49 1030 02 1D8B LJMP SXMTC
50
51
52 ; Transmit line.
53 ;
54 1033 ORG R2_TL
55 1033 02 1DA8 LJMP SXMTL
56
57
```

```
1 ; Transmit page.
2 ;
3 1036
4 1036 02 1DAC ORG R2_TP
5 LUMP XMTF
6
7 ; Transmit 25th line.
8 ;
9 1039
10 1039 02 1DC6 ORG R2_T25L
11 LUMP XMT25
12
13 ; Print page.
14 ;
15 103C
16 103C 02 1DD2 ORG R2_PRNT
17 LUMP PRINT
18
19 ; Display clock.
20 ;
21 103F
22 103F 02 1E1F ORG R2_DCLK
23 LUMP DCLK
24
25 ; Display status.
26 ;
27 1042
28 1042 02 1E69 ORG R2_DISP
LUMP DISPSTAT
```

```

1          ;;          INIT - initialize terminal
2          ;
3          ;          *INIT* sets up internal RAM from the ROM and EAROM, reconfigures
4          ;          screen tables and initializes processor bytes.
5          ;
6          ;
7          ;          ENTRY none
8          ;
9          ;          EXIT none
10         ;
11         ;          USES all
12         ;
13         ;
14 1045    75    D0    00    INIT:    MOV    PSW, #BANK0    ; Select bank 0
15
16 1048    78    0C
17 104A    90    1FD1
18 104D    7A    19
19
20 104F    11    A7
21         ACALL   INMOV    ; Move data
22 1051    78    35
23 1053    7A    0B
24
25 1055    11    A7
26         ACALL   INMOV    ; Move data
27         ;
28         ;          Recall from EAROM
29 1057    C2    03
30 1059    12    1E18
31 105C    D2    03
32 105E    12    1E18
33
34 1061    78    25
35 1063    90    7000
36 1066    7A    10
37
38 1068    E0
39 1069    54    0F    IN3:    MOVX   A, @DPTR    ; REPEAT set upper nibble
40 106B    C4
41         SWAP   A
42 106C    FD
43         MOV    TEMP, A    ; save upper nibble
44 106D    A3
45         INC   DPTR    ; bump EAROM pointer
46 106E    E0
47         MOVX   A, @DPTR    ; get lower nibble
48 106F    54    0F
49         ANL   A, #0FH    ; mask data
50
51 1071    4D
52         ORL   A, TEMP    ; combine upper and lower
53 1072    F6
54         MOV   @PTR1, A    ; place into internal RAM
55 1073    A3
56         INC   DPTR    ; bump EAROM pointer
57 1074    08
58         INC   PTR1    ; bump internal RAM pointer
59 1075    DA    F1
60         DJNZ  INDX1, IN3    ; UNTIL done
61
62 1077    C2    8C
63 1079    75    89    23
64 107C    75    98    5A
65         MOV   TMO, #ITMOD    ; Initialize values
66         MOV   SCON, #1SCON    ; Place UART into mode 1
67
68 107F    E5    33
69 1081    F5    8D
70 1083    B4    53    00
71         MOV   A, BAUDRATE    ; Get baud rate
72         MOV   TH1, A    ; Initialize baud rate
73         CJNE  A, #93, IN3B

```


*** Z-29 COMPUTER TERMINAL FIRMWARE VERSION 1.03 ***

```

.....
1 1084 50 02          IN3B:      JNC     IN3A          ; IF baud <= 300 THEN
2 1088 D2 9F          SETB    SMO          ; place UART into mode 3
3 108A D2 8E          IN3A:      SETB    TR1         ; Turn on baud rate timer
4
5 108C A2 3C          MOV     C, PRTF2
6 108E 92 02          MOV     PORTF, C     ; Initialize port direction
7 1090 12 1E18       CALL    WLATCH
8 1093 A2 3D          MOV     C, ACHR2    ; Get alternate char set flas
9 1095 92 0C          MOV     ALTCHARA, C  ; Place in attributes
10
11 1097 30 43 02     JNB     HAZ, IN4     ; IF Hazeltine mode THEN
12 109A 31 D4        ACALL   HAZINIT     ; initialize for Hazeltine
13
14 109C 12 1F22     CALL    NVRCHK      ; Checksum the NVRAM
15 109F B5 34 01     CJNE   A, NVRSUM, IN5 ; IF same THEN
16 10A2 22          RET                ; return
17 10A3 43 40 10     IN5:      ORL     ERRORS, #00010000B ; ELSE error #4
18 10A6 22          RET
19
20
21          ;
22          ;           Move from ROM to RAM using DPTR, PTR1, and INDX1
23          ;
24
25 10A7 E4          INMOV:   CLR     A           ; REPEAT
26 10A8 93          MOV     A, @A+DPTR  ; load constant
27 10A9 F6          MOV     @PTR1, A    ; place into internal RAM
28 10AA A3          INC     DPTR        ; bump ROM pointer
29 10AB 08          INC     PTR1        ; bump RAM pointer
30 10AC DA F9       DJNZ   INDX1, INMOV ; UNTIL done
31 10AE 22          RET
.....

```

```

1      ; ; ALLINIT - initialize all of terminal
2      ;
3      ; ; *ALLINIT* initializes everything including the CRTC.
4      ; ;
5      ; ;
6      ; ; ENTRY none
7      ; ;
8      ; ; EXIT none
9      ; ;
10     ; ; USES all
11     ; ;
12     ; ;
13 10AF C2 AF ALLINIT: CLR EA ; Disable interrupts
14     ; ;
15 10B1 75 90 CF MOV P1, #11001111B ; Initialize port #1
16     ; ;
17 10B4 75 40 00 MOV ERRORS, #0 ; Initialize errors here
18 10B7 12 1ED4 CALL KBCHK ; Check keyboard first (timing)
19     ; ;
20 10BA 11 45 ACALL INIT ; Initialize everything
21     ; ;
22 10BC E4 CLR A
23 10BD 78 47 MOV PTR1, #LORDER ; Setup to initialize
24 10BF 7A 19 MOV INDX1, #NUMLINES ; the -LORDER- table entries
25     ; ;
26 10C1 F6 ALLI1: MOV @PTR1, A ; REPEAT place entry into table
27 10C2 08 INC PTR1 ; bump RAM pointer
28 10C3 04 INC A ; bump count
29 10C4 DA FB DJNZ INDX1, ALLI1 ; UNTIL done
30     ; ;
31 10C6 75 B8 03 MOV IP, #IPINIT ; Interrupt priorities
32     ; ;
33 10C9 31 1E ACALL INTCRT ; Start CRT controller
34 10CB 12 1ED9 CALL ROMCHK ; Check ROM
35 10CE 12 1EF1 CALL RAMCHK ; Check RAM
36     ; ;
37 10D1 75 A8 95 MOV IE, #IEINIT ; Enable interrupts
38     ; ;
39 10D4 12 0BAC CALL CLRS ; Clear screen
40 10D7 75 F0 18 MOV B, #MAXLINE
41 10DA 12 0B96 CALL CLRLINE ; Clear 25th line
42 10DD D2 24 SETB VSPF ; Flash screen to be turned on
43 10DF 12 1F2C CALL ERROR ; Display any errors
44 10E2 21 9E AJMP INITKB ; Initialize keyboard & return

```

*** Z-29 COMPUTER TERMINAL FIRMWARE VERSION 1.03 ***

```

1          ;:.....SOFTINIT - soft initialize terminal.....
2          ;
3          ;
4          ;
5          ;
6          ;
7          ;
8          ;
9          ;
10         ;
11         ;
12         ;
13         ;
14         ;
15 10E4    C0      3A          SOFTINIT:    PUSH    TCNT          ; Save clock information
16 10E6    C0      3B          PUSH    TSEC
17 10E8    C0      3C          PUSH    TMIN
18 10EA    C0      3D          PUSH    THOUR
19 10EC    A2      2E          MOV     C, ONLINE
20 10EE    92      E0          MOV     ACC.0, C          ; Save online flas
21 10F0    A2      35          MOV     C, CAPLOCKF
22 10F2    92      E1          MOV     ACC.1, C          ; Save caps locked flas
23 10F4    C0      E0          PUSH    ACC
24         ;
25 10F6    75      90      CB          MOV     P1, #11001011B    ; Initialize port #1
26         ;
27 10F9    11      45          ACALL  INIT              ; Initialize everything
28         ;
29 10FB    D0      E0          POP     ACC
30 10FD    A2      E1          MOV     C, ACC.1
31 10FF    92      35          MOV     CAPLOCKF, C      ; Restore caps locked flas
32 1101    A2      E0          MOV     C, ACC.0
33 1103    92      2E          MOV     ONLINE, C        ; Restore online flas
34 1105    D0      3D          POP     THOUR            ; Restore clock information
35 1107    D0      3C          POP     TMIN
36 1109    D0      3B          POP     TSEC
37 110B    D0      3A          POP     TCNT
38         ;
39 110D    31      7B          ACALL  SETCF             ; Set cursor format
40         ;
41 110F    12      0BAC         CALL    CLRS              ; Clear screen
42 1112    20      37      06          JB     L25ON, SOFTI1     ; IF 25th line is off THEN
43 1115    75      F0      18          MOV     B, #MAXLINE
44 1118    02      0B96         JMP     CLRLINE          ; clear 25th line
45         ;
46 111B    02      1E69         SOFTI1:    JMP     DISPSTAT        ; ELSE display status info

```

```

1          ; ;          INITCRT - initialize CRT controller
2          ; ;
3          ; ;          *INITCRT* does everything needed to set the CRT controller
4          ; ;          up and running properly.
5          ; ;
6          ; ;
7          ; ;          ENTRY   none
8          ; ;
9          ; ;          EXIT    none
10         ; ;
11         ; ;          USES   A, DPTR
12         ; ;
13
14 111E    C0    A8          INITCRT:    PUSH    IE          ; Save interrupt setup
15 1120    C2    AF          CLR      EA          ; Disable interrupts
16
17 1122    75    09    02    MOV      DMLNA, #2          ; Start at first line to DMA
18 1125    75    0B    A0    MOV      DMADRL, #LOW (DMAMEM+160)
19 1128    75    0A    60    MOV      DMADRH, #HIGH (DMAMEM+160)
20
21 112B    D2    97          SETB   CLKRUN          ; Let the clock run
22
23 112D    31    52          ACALL  SETCRT          ; Set CRT controller
24
25 112F    D2    88          SETB   ITO          ; Int 0 transition activated
26 1131    53    88    D1    ANL     TCON, #11010001B ; Clear IT1, IE0, IE1, TFO
27
28 1134    90    2001      MOV     DPTR, #DCMDREG
29 1137    74    E0      MOV     A, #CSET
30 1139    F0          MOVX  @DPTR, A          ; Preset counters
31
32 113A    C2    97          CLR     CLKRUN          ; Turn off clock
33
34 113C    74    20      MOV     A, #CSTRT
35 113E    F0          MOVX  @DPTR, A          ; Start CRT controller
36
37 113F    D2    97          SETB   CLKRUN          ; Start clock
38
39 1141    74    A0      MOV     A, #CINT
40 1143    F0          MOVX  @DPTR, A          ; Enable VRTC interrupts
41
42          IFC     NE, DSTAREG-DCMDREG
43          ERROR  ; 'DSTAREG' and 'DCMDREG' are different
44          ENDC
45
46          ;          MOV     DPTR, #DSTAREG
47
48 1144    E0          MOVX  A, @DPTR          ; Get status register
49 1145    44    B3      ORL   A, #10110011B ; Fill in dont cares
50 1147    64    08      XRL  A, #00001000B ; Toggle proper positions
51 1149    F4          CPL   A
52 114A    60    03      JZ    IC1          ; IF not zero THEN
53 114C    43    40    04    ORL   ERRORS, #00000100B ; flag error #2
54
55 114F    D0    A8          IC1:    POP    IE          ; Enable old interrupt status
56 1151    22          RET

```

*** Z-29 COMPUTER TERMINAL FIRMWARE VERSION 1.03 ***

```

1          ;:          SETCRT - set CRT controller (reset 8276)
2          ;
3          ;
4          ;          *SETCRT* initializes the CRT controller screen parameter bytes.
5          ;
6          ;          ENTRY   none
7          ;
8          ;          EXIT    none
9          ;
10         ;          USES   A, DPTR
11
12
13 1152    90    2001    SETCRT:    MOV    DPTR, #DSTAREG
14 1155    E0                                MOVX   A, @DPTR          ; Clear status register
15
16                                IFC    NE,DCMDREG-DSTAREG
17                                ERROR   ;'DCMDREG' and 'DSTAREG' are different
18                                ENDC
19
20         ;          MOV    DPTR, #DCMDREG
21
22 1156    74    00                                MOV    A, #CRESET
23 1158    F0                                MOVX   @DPTR, A          ; Reset and stop display
24
25 1159    90    2000    MOV    DPTR, #DDATREG
26 115C    74    4F                                MOV    A, #SCRN1
27 115E    F0                                MOVX   @DPTR, A          ; Output screen parameter bytes
28
29 115F    74    98                                MOV    A, #SCRN2A
30 1161    20    39    02    JB     FREQ, SC1          ; Check for 50/60 Hz
31 1164    74    DC                                MOV    A, #SCRN2B
32 1166    F0                                MOVX   @DPTR, A
33
34 1167    74    99                                MOV    A, #SCRN3
35 1169    F0                                MOVX   @DPTR, A
36
37 116A    74    4E                                MOV    A, #SCRN4A
38 116C    20    39    02    JB     FREQ, SC2          ; Check for 50/60 Hz
39 116F    74    4F                                MOV    A, #SCRN4B
40 1171    A2    38    SC2:    MOV    C, CRNBK          ; Get cursor no blink flag
41 1173    92    E5                                MOV    ACC.5, C
42 1175    A2    32                                MOV    C, CRUL          ; Get cursor underline flag
43 1177    92    E4                                MOV    ACC.4, C
44 1179    F0                                MOVX   @DPTR, A
45 117A    22                                RET

```

```
1          ;;          SETCF - set cursor format
2          ;
3          ;          *SETCF* initializes the CRT controller for the cursor format
4          ;          indicated.
5          ;
6          ;
7          ;          ENTRY none
8          ;
9          ;          EXIT none
10         ;
11         ;          USES A, DPTR
12
13
14 117B    31    52          SETCF:          ACALL  SETCRT          ; Initialize screen registers
15
16 117D    90    2001        MOV     DPTR, #DCMDREG
17 1180    74    20          MOV     A, #CSTRT
18 1182    F0          MOVX   @DPTR, A          ; Start CRT controller
19
20 1183    22          RET
```

*** Z-27 COMPUTER TERMINAL FIRMWARE VERSION 1.03 ***

```

1          ;:          CURSOR - update cursor position
2          ;
3          ;          *CURSOR* sends the current cursor address to the CRTC and
4          ;          disables cursor if data is > 600 baud or display of cursor
5          ;          is disabled.
6          ;
7          ;
8          ;          ENTRY   none
9          ;
10         ;          EXIT    none
11         ;
12         ;          USES    A, DPTR
13         ;
14         ;
15 1184    90      2001      CURSOR:    MOV    DPTR, #DCMDREG
16 1187    74      80              MOV    A, #CCRSR
17 1189    F0              MOVX   @DPTR, A          ; Load cursor position
18
19 118A    90      2000      MOV    DPTR, #DDATREG
20 118D    E5      11              MOV    A, XPOS
21 118F    F0              MOVX   @DPTR, A          ; Load cursor X-position
22
23 1190    E5      12              MOV    A, YPOS
24 1192    30      1A      03      JNB   ENBLCUR, CR1      ; IF cursor display disabled OR
25 1195    30      14      02      JNB   DX, CR2          ; IF char rcvd since last time
26 1198    74      1A      CR1:    MOV    A, #NUMLINES + 1 ; put in non-existing region
27 119A    F0      CR2:    MOVX   @DPTR, A          ; ELSE put cursor Y-position
28
29 119B    C2      14          CLR   DX          ; and clear -DX-
30 119D    Z2          RET

```

```

1          ;;          INITKB - initialize keyboard
2          ;
3          ;          *INITKB* resets the keyboard to whatever settings the terminal
4          ;          has at the current moment.
5          ;
6          ;
7          ;          ENTRY none
8          ;
9          ;          EXIT none
10         ;
11         ;          USES all
12
13
14 119E          INITKB:      IFC    NE,KBC_XL - KBC_EL - 1
15                ERROR    ;'This code will not work'
16                ENDC
17 119E    74    84          MOV    A, #KBC_EL
18 11A0    20    35    01    JB    CAPLOCKF, IKB1      ; IF not caps locked THEN
19 11A3    04          INC    A                          ; output caps unlocked
20 11A4    31    C8    IKB1: ACALL  IKB6                  ; (save bytes this way)
21
22                IFC    NE,KBC_ONLN - KBC_OFFLN - 1
23                ERROR    ;'This code will not work'
24                ENDC
25 11A6    74    8A          MOV    A, #KBC_OFFLN
26 11A8    30    2E    01    JNB   ONLINE, IKB2      ; IF on line THEN
27 11AB    04          INC    A                          ; output on line command
28 11AC    31    C8    IKB2: ACALL  IKB6
29
30                IFC    NE,KBC_EK - KBC_DK - 1
31                ERROR    ;'This code will not work'
32                ENDC
33 11AE    74    88          MOV    A, #KBC_DK
34 11B0    20    1F    01    JB    KBDISF, IKB3      ; IF keyboard disabled THEN
35 11B3    04          INC    A                          ; enable keyboard
36 11B4    31    C8    IKB3: ACALL  IKB6
37
38                IFC    NE,KBC_DC - KBC_EC - 1
39                ERROR    ;'This code will not work'
40                ENDC
41 11B6    74    82          MOV    A, #KBC_EC
42 11B8    20    33    01    JB    CLKF, IKB4      ; IF key click disabled THEN
43 11BB    04          INC    A                          ; output no key click
44 11BC    31    C8    IKB4: ACALL  IKB6
45
46                IFC    NE,KBC_DR - KBC_ER - 1
47                ERROR    ;'This code will not work'
48                ENDC
49 11BE    74    86          MOV    A, #KBC_ER
50 11C0    20    34    01    JB    REPF, IKB5      ; IF auto repeat disabled THEN
51 11C3    04          INC    A                          ; no auto repeat
52 11C4    31    C8    IKB5: ACALL  IKB6
53
54 11C6    74    80          MOV    A, #KBC_ID      ; Have it send it's ID number
55 11C8    02    026D    IKB6: JMP    PCKB

```



```

1      ; ; TERMINIT - terminal initialization
2      ; ;
3      ; ; *TERMINIT* initializes the terminal for ZDS and ANSI
4      ; ; emulation mode. This places the terminal in whatever mode
5      ; ; the terminal must be in to emulate those modes.
6      ; ;
7      ; ;
8      ; ; ENTRY none
9      ; ;
10     ; ; EXIT none
11     ; ;
12     ; ; USES all
13     ; ;
14     ; ;
15 11CB 53 21 FO TERMINIT: ANL ATTRIBUTES, #OF0H ; Clear attributes
16 11CE D2 1B SETB ERM ; Set erasure mode
17 11D0 D2 25 SETB GATM ; Set guarded area xmt mode
18 11D2 80 04 SJMP HIR ; Clear protected and return
19
20
21
22
23     ; ; HAZINIT - Hazeltine initialization
24     ; ;
25     ; ; *HAZINIT* initializes the terminal for the Hazeltine 1500
26     ; ; emulation mode. This places the terminal in whatever mode
27     ; ; the terminal must be in to emulate the Hazeltine 1500.
28     ; ;
29     ; ;
30     ; ; ENTRY none
31     ; ;
32     ; ; EXIT none
33     ; ;
34     ; ; USES all
35     ; ;
36     ; ;
37 11D4 D2 0B HAZINIT: SETB HALFIA ; Starts in background
38 11D6 D2 1B SETB ERM ; Reset erasure mode
39 11D8 75 3F 00 HIR: MOV PFIELD, #0 ; No protected fields
40 11DB 22 RET
  
```

```

1          ; STARTDMA - start psuedo DMA transfer
2          ;
3          ; *STARTDMA* can only be interrupted by the stop DMA routine.
4          ; It is initiated by pushing the address to start DMA onto the
5          ; stack and executing a -RET-. The hardware takes over and
6          ; executes an instruction that is hard wired to the data bus
7          ; and initiates reads from the video memory to the CRT controller.
8          ;
9          ;
10         ; ENTRY none
11         ;
12         ; EXIT none
13         ;
14         ; USES none
15
16
17 11DC    C0    D0          STARTDMA:    PUSH    PSW          ; Save processor status
18 11DE    C0    E0          PUSH    ACC
19 11E0    C0    F0          PUSH    B
20
21 11E2    75    A8    82          MOV     IE, #IEDMA          ; Select interrupts for DMA
22 11E5    D2    B4          SETB   DMATYPE          ; Set type for DMA transfer
23
24 11E7    E5    09          MOV     A, DMLNA
25 11E9    70    05          JNZ    SD1              ; IF DMA for line #0 THEN
26 11EB    30    24    02          JNB    VSPF, SD1        ; IF no suppression THEN
27 11EE    C2    92          CLR    VSP              ; always turn video on
28
29 11F0    C0    0B          SD1:    PUSH   DMADRL          ; Push DMA start address
30 11F2    C0    0A          PUSH   DMADRH          ; onto the stack
31 11F4    75    8C    FF          MOV    TH0, #0FFH      ; Initialize timer values
32 11F7    75    8A    D6          MOV    TLO, #0D6H      ; For 80 characters
33 11FA    D2    8C          SETB   TR0              ; Start timer running
34 11FC    32          RETI              ; Start psuedo DMA

```

```

1          ;:          STOPDMA - stop psuedo DMA transfer.
2          ;
3          ;          *STOPDMA* is the other half of the DMA transfer routine.
4          ;          It stops the timer, cleans the stack, sets -DMATYPE- to it's
5          ;          normal value, and enables interrupts.  If it was filling memory
6          ;          then it finishes up that otherwise it continues and calculates
7          ;          the next line number, address, and indexes for DMA.
8          ;
9          ;
10         ;          ENTRY   none
11         ;
12         ;          EXIT    none
13         ;
14         ;          USES    none
15         ;
16         ;
17 11FD    C2      8C          STOPDMA:    CLR    TRO          ; Stop timer
18 11FF    75      A8      95          MOV    IE, #IEINIT    ; Reset interrupt enables
19
20 1202    20      B4      20          JB     DMATYPE, DM1    ; IF filling memory THEN
21 1205    D2      B4          SETB   DMATYPE        ; set -DMATYPE- to normal
22 1207    D0      83          POP    DPH           ; set last address from
23 1209    D0      82          POP    DPL           ; the stack
24 120B    AD      F0          MOV    TEMP, B       ; set remainder
25 120D    BD      00      01          CJNE   TEMP, #0, FILL ; IF nothing left THEN
26 1210    32          RETI          ; return
27 1211    74      20          FILL:    MOV    A, #1         ; ELSE set up and
28 1213    53      83      CF          ANL   DPH, #DMAANL   ;
29 1216    43      83      10          ORL   DPH, #CHRORL   ; mask into char memory
30 1219    A3          INC    DPTR          ; REPEAT bump position
31 121A    F0          MOVX   @DPTR, A       ; fill with spaces
32 121B    53      83      EF          ANL   DPH, #ATRANL   ; mask into attribute mem
33 121E    F0          MOVX   @DPTR, A       ; clear attributes
34 121F    43      83      10          ORL   DPH, #CHRORL   ; mask into char memory
35 1222    DD      F5          DJNZ   TEMP, FL1     ; UNTIL index1 = 0
36 1224    32          RETI          ; Return
37
38
39 1225    75      D0      08          DM1:    MOV    PSW, #BANK1   ; ELSE select bank #1
40 1228    D0      E0          POP    ACC          ; clean off stack
41 122A    D0      E0          POP    ACC
42
43 122C    09          INC    DMLN         ; bump current DMA line
44
45 122D    20      39      13          JB     FREQ, DM1A    ; IF 50 Hz THEN
46 1230    B9      1D      02          CJNE   DMLN, #29, DM1B ; IF line 29 THEN
47 1233    80      13          SJMP   DM2          ; wrap around
48 1235    B9      19      00          DM1B:  CJNE   DMLN, #NUMLINES, DM1C ; ELSE IF line <= 25 THEN
49 1238    40      10          DM1C:  JC     DM3          ; do usual stuff
50 123A    B9      1A      00          CJNE   DMLN, #NUMLINES+1, DM1D ;
51 123D    40      1C          DM1D:  JC     DM4          ; ELSE IF line >= 26 THEN
52 123F    D2      92          SETB   VSP          ; begin blanking
53 1241    80      18          SJMP   DM4
54
55 1243    B9      19      00          DM1A:  CJNE   DMLN, #NUMLINES, DM1E ; Check for wrap around
56 1246    40      02          DM1E:  JC     DM3          ; IF line > 25 THEN
57 1248    79      00          DM2:   MOV    DMLN, #0     ; wrap around

```

```
1
2 124A 74 47 DM3: MOV A, #LORDER ; ELSE set base of table
3 124C 29 ADD A, DMLN ; add in offset
4 124D F8 MOV DMPTR, A ; move it into pointer
5 124E E6 MOV A, @DMPTR ; set value from table
6
7 124F 75 F0 50 MOV B, #NUMCHARS ; set up for multiply
8 1252 A4 MUL AB ; do it
9 1253 F5 MOV DMADRL, A ; save low order byte
10 1255 E5 MOV A, B ; set high order byte
11 1257 24 60 ADD A, #HIGH (DMAMEM) ; add offset
12 1259 F5 MOV DMADRH, A ; save high order byte
13
14 125B D0 F0 DM4: POP B ; Restore registers and return
15 125D D0 E0 POP ACC
16 125F D0 D0 POP PSW
17 1261 32 RETI
```

```

1          ;:          STFILL - start filling with spaces
2          ;
3          ;          *STFILL* takes the number of characters and location in
4          ;          screen memory and fills them with 20H and places the
5          ;          attribute given into attribute memory. It takes into
6          ;          account the mode that ERM is in.
7          ;
8          ;
9          ;          ENTRY (A) = number of characters less than 127
10         ;          (B) = attribute to write
11         ;          (DPTR) = character memory address to start from
12         ;
13         ;          EXIT none
14         ;
15         ;          USES A, B, DPTR, WORK2, TEMP, INDX2, TIMER 0
16
17
18 1262    FB          STFILL:    MOV     INDX2, A          ; Save count
19 1263    AF          F0          MOV     WORK2, B         ; Save attributes
20
21 1265    BF          00          3D          CJNE   WORK2, #0, SFB    ; IF attributes THEN special
22
23 1268    30          1B          04          JNB    ERM, SFA         ; IF not erasure mode THEN
24
25 126B    E5          3F          MOV     A, PFIELD      ; IF protected fields THEN
26 126D    70          36          JNZ    SFB             ; special
27
28 126F    53          83          EF          SFA:    ANL    DPH, #ATRANL    ; convert to DMA memory
29 1272    43          83          20          ORL    DPH, #DMAORL
30 1275    EB          MOV     A, INDX2      ; set count back
31 1276    23          RL          ; multiply by 2
32 1277    75          F0          03          MOV     B, #3          ; set up for divide by 3
33 127A    84          DIV     AB           ; place remainder in (B)
34 127B    C5          F0          XCH    A, B           ; switch to work with (B)
35 127D    B4          02          06          CJNE   A, #2, SF1     ; IF remainder = 2 THEN
36 1280    05          F0          INC     B             ; bump clock value
37 1282    74          00          MOV     A, #0         ; remainder := 0
38 1284    80          07          SJMP   SF2           ; ELSE
39
40 1286    B4          00          04          SF1:    CJNE   A, #0, SF2     ; IF remainder = 0 THEN
41 1289    74          02          MOV     A, #2         ; remainder := 2
42 128B    15          F0          DEC     B             ; decrement clock count
43 128D    C5          F0          SF2:    XCH    A, B           ; switch back
44 128F    F4          CPL     A             ; take 2's complement of (A)
45 1290    04          INC     A
46
47 1291    C2          AF          CLR     EA           ; disable interrupts
48 1293    00          NOP                    ; give time to clear
49 1294    75          A8          82          MOV     IE, #IEDMA    ; init for DMA
50 1297    C2          B4          CLR     DMATYPE      ; set type for clear memory
51 1299    C0          82          PUSH   DPL           ; push DMA start address
52 129B    C0          83          PUSH   DPH           ; onto the stack
53 129D    75          8C          FF          MOV     TH0, #OFFH    ; set timer 0
54 12A0    F5          8A          MOV     TLO, A        ; for number of characters
55 12A2    D2          8C          SETB   TRO           ; start timer running
56 12A4    22          RET                    ; start DMA
57

```

```

1 12A5 E5 3F SFB: MOV A, PFIELD ; ELSE set protected fields
2 12A7 B4 FE 01 CJNE A, #254, SF3 ; ELSE IF none protected THEN
3 12AA E4 CLR A ; set for none
4 12AB FD SF3: MOV TEMP, A ; save value in -TEMP-
5
6 12AC 53 83 EF SFL: ANL DPH, #ATRANL ; REPEAT mask to attribute
7 12AF E0 MOVX A, @DPTR ; set current attribute
8 12B0 54 0F ANL A, #00001111B ; mask data
9 12B2 70 05 JNZ SF4 ; IF no attributes THEN
10 12B4 BD 80 08 CJNE TEMP, #80H, SF5 ; IF protected THEN skip
11 12B7 80 0E SJMP SF6 ; ELSE
12 12B9 5D SF4: ANL A, TEMP ; mask with protected
13 12BA B5 05 02 CJNE A, TEMPA, SF5 ; IF protected THEN
14 12BD 80 08 SJMP SF6 ; skip
15
16 12BF EF SF5: MOV A, WORK2 ; set attribute to write
17 12C0 F0 MOVX @DPTR, A ; write attribute out
18 12C1 43 83 10 ORL DPH, #CHRORL ; mask to character memory
19 12C4 74 20 MOV A, # ; set space to write
20 12C6 F0 MOVX @DPTR, A ; clear character
21 12C7 A3 SF6: INC DPTR ; bump pointer
22 12C8 DB E2 DJNZ INDX2, SFL ; UNTIL done
23 12CA 22 RET

```

*** Z-29 COMPUTER TERMINAL FIRMWARE VERSION 1.03 ***

```

1 .....:;..... SERIAL = serial port interrupt routine.....
2 .....:;.....
3 .....:;..... *SERIAL* processes all serial port interrupts.....
4 .....:;.....
5 .....:;.....
6 .....:;..... ENTRY none
7 .....:;.....
8 .....:;..... EXIT none
9 .....:;.....
10 .....:;..... USES none
11 .....:;.....
12 .....:;.....
13 12CB C0 D0 SERIAL: PUSH PSW ; Save registers
14 12CD C0 E0 PUSH ACC
15 12CF C0 F0 PUSH B
16 12D1 C0 82 PUSH DPL
17 12D3 C0 83 PUSH DPH
18 12D5 20 98 05 JB RI, SERIN ; Check receiver interrupt
19 12D8 20 99 38 JB TI, SEROUT ; Check transmit interrupt
20 12DB 80 3A SJMP SRT ; This should never happen
21 .....:;.....
22 12DD 75 39 00 SERIN: MOV AUTOCNT, #0
23 12E0 D2 24 SETB VSPF ; Change auto off
24 12E2 C2 98 CLR RI ; Clear receiver int flas
25 12E4 E5 99 MOV A, SBUF ; Get character
26 12E6 54 7F ANL A, #01111111B ; Mask off parity
27 12E8 20 43 02 JB HAZ, SIO ; IF not Hazeltine THEN
28 12EB 60 2A JZ SRT ; IF null THEN exit
29 .....:;.....
30 12ED 20 23 03 SIO: JB PRNTF, S11 ; IF not printing THEN
31 12F0 30 2E 24 JNB ONLINE, SRT ; IF offline THEN exit
32 12F3 B4 13 08 S11: CJNE A, #XOFF, S12 ; IF -XOFF- received THEN
33 12F6 20 23 06 JB PRNTF, S11A ; IF not printing THEN
34 12F9 20 42 05 JB ADM3, S12 ; IF ADM 3A THEN skip
35 12FC 20 43 02 JB HAZ, S12 ; IF Hazeltine THEN skip
36 12FF D2 16 S11A: SETB XOFFRCVED ; flas for XOFF
37 1301 B4 11 02 S12: CJNE A, #XON, S13 ; IF -XON- received THEN
38 1304 C2 16 CLR XOFFRCVED ; flas for no XOFF
39 1306 20 23 0E S13: JB PRNTF, SRT ; IF printing THEN exit
40 1309 12 01CA LCALL PCIF ; Put character in input FIFO
41 130C 30 D5 08 JNB F0, SRT ; IF -XOFF- needed THEN
42 130F 71 C4 ACALL DOXOFF ; send an -XOFF- and exit
43 1311 80 04 SJMP SRT
44 .....:;.....
45 1313 C2 99 SEROUT: CLR TI ; Clear transmit int flas
46 1315 D2 13 SETB OKTRANS ; Set ok to transmit
47 .....:;.....
48 1317 D0 83 SRT: POP DPH ; Restore registers
49 1319 D0 82 POP DPL
50 131B D0 F0 POP B
51 131D D0 E0 POP ACC
52 131F D0 D0 POP PSW
53 1321 71 26 ACALL SRT1 ; Double check
54 1323 D2 AF SETB EA
55 1325 22 RET
56 1326 C2 AF SRT1: CLR EA
57 1328 32 RETI ; And return

```

```

1          ;:          IRQ - interrupt request
2          ;
3          ;
4          ;          *IRQ* is executed when the CRTC starts to display the 25th
5          ;          line. At this point the DMA line number must have been set
6          ;          to zero or some error has occurred. This routine is a safety
7          ;          check for any such errors and will take at most one frame to
8          ;          straighten out any such errors. It also takes care of any
9          ;          clock timings and blinkins.
10         ;
11         ;          ENTRY   none
12         ;
13         ;          EXIT    none
14         ;
15         ;          USES    none
16         ;
17         ;
18 1329    C0    D0          IRQ:    PUSH    PSW          ; Save registers
19 132B    C0    E0          PUSH    ACC
20 132D    C0    F0          PUSH    B
21 132F    C0    82          PUSH    DPL
22 1331    C0    83          PUSH    DPH
23         ;
24 1333    75    09    00          MOV     DMLNA, #0          ; Safety check
25         ;
26 1336    31    84          ACALL  CURSOR          ; Display cursor
27         ;
28 1338    90    2001          MOV     DPTR, #DSTAREG
29 133B    E0          MOVX   A, @DPTR          ; Clear any CRTC flags
30         ;
31 133C    05    38          INC     BLNKCNT          ; Bump blink count
32 133E    E5    37          MOV     A, BLNKRATE
33 1340    40    10          JZ     IRQ2          ; IF not zero OR
34 1342    B4    FF    02          CJNE  A, #0FFH, IRQ1    ; IF not full count THEN
35 1345    80    0B          SJMP  IRQ2
36 1347    B5    38    0B    IRQ1: CJNE  A, BLNKCNT, IRQ2    ; IF time to blink THEN
37 134A    75    38    00          MOV     BLNKCNT, #0    ; reset count
38 134D    B2    01          CPL    BLINKF          ; toggle blink flag
39 134F    12    1E18          CALL  WLATCH
40         ;
41 1352    05    3A          IRQ2: INC     TCNT          ; Bump time count
42 1354    E5    3A          MOV     A, TCNT
43 1356    20    39    05          JB     FREQ, IRQ3    ; IF 50 Hz AND 1 second OR
44 1359    B4    32    34          CJNE  A, #50, IRQ5
45 135C    80    03          SJMP  IRQ4          ; IF 60 Hz AND 1 second THEN
46 135E    B4    3C    2F    IRQ3: CJNE  A, #60, IRQ5
47 1361    75    3A    00    IRQ4: MOV     TCNT, #0    ; initialize count
48 1364    05    3B          INC     TSEC          ; bump seconds
49 1366    E5    3B          MOV     A, TSEC
50 1368    B4    3C    25          CJNE  A, #60, IRQ5    ; IF one minute THEN
51 136B    30    3B    0B          JNB   SCRNSAVE, IRQ4A ; IF screen saver THEN
52 136E    05    39          INC     AUTOCNT          ; bump auto off
53 1370    E5    39          MOV     A, AUTOCNT
54 1372    B4    0F    04          CJNE  A, #15, IRQ4A    ; IF saver time up THEN
55 1375    C2    24          CLR    VSPF          ; flag it is off
56 1377    D2    92          SETB  VSP          ; and turn off display
57         ;

```


*** Z-29 COMPUTER TERMINAL FIRMWARE VERSION 1.03 ***

```

1 1379 75 3B 00 IRQ4A: MOV TSEC, #0 ; initialize seconds
2 137C 05 3C INC TMIN ; bump minutes
3 137E E5 3C MOV A, TMIN
4 1380 B4 3C 0D CJNE A, #60, IRQ5 ; IF one hour THEN
5 1383 75 3C 00 MOV TMIN, #0 ; initialize minutes
6 1386 05 3D INC THOUR ; bump hours
7 1388 E5 3D MOV A, THOUR
8 138A B4 18 03 CJNE A, #24, IRQ5 ; IF 24 hours THEN
9 138D 75 3D 00 MOV THOUR, #0 ; initialize hours
10
11 1390 D0 83 IRQ5: POP DPH ; Restore registers and return
12 1392 D0 82 POP DPL
13 1394 D0 F0 POP B
14 1396 D0 E0 POP ACC
15 1398 D0 D0 POP PSW
16 139A 32 RETI
    
```

```

1          ; ; TRANSMIT - transmit to host
2          ;
3          ; *TRANSMIT* waits for an empty output holding register, sets
4          ; parity, and outputs the character to the serial port.
5          ;
6          ;
7          ; ENTRY (A) = character to output
8          ;
9          ; EXIT (A) = character with correct parity
10         ;
11         ; USES A
12
13
14 139B 20 16 FD TRANSMIT: JB XOFFRCVD, TRANSMIT ; Wait until no -XOFF-
15
16 139E C3 TRANS: CLR C ; Start with no parity
17 139F 30 28 0A JNB PRTYENA, TRA ; IF parity enabled THEN
18 13A2 D3 SETB C ; do set parity
19 13A3 20 29 06 JB PRTYSTK, TRA ; IF not stick parity THEN
20 13A6 A2 D0 00 MOV C, P ; do even parity
21 13A8 20 2A 01 JB PRTYEVN, TRA ; IF not even parity THEN
22 13AB B3 CPL C ; do odd parity
23 13AC 92 E7 TRA: MOV ACC, 7, C ; Put in parity bit
24
25 13AE 20 13 03 TRW: JB OKTRANS, TROK ; IF ok to transmit OR
26 13B1 30 99 FA JNB TI, TRW ; IF transmit buffer empty THEN
27 13B4 20 02 03 TROK: JB PORTF, TROK1 ; IF auxiliary port OR
28 13B7 30 3E 03 JNB HNDSHK, TROK2 ; IF hardware handshake THEN
29 13BA 20 B5 F1 TROK1: JB CTS, TRW ; IF not CTS THEN do again
30
31 13BD C2 99 TROK2: CLR TI ; clear buffer empty flag
32 13BF C2 13 CLR OKTRANS ; make not ok to transmit
33 13C1 F5 99 MOV SBUF, A ; output data
34 13C3 22 RET

```

```

1      ;
2      ;
3      ; DOXOFF - do send XOFF to host
4      ;
5      ; *DOXOFF* preempts outgoing data and outputs an XOFF to host
6      ; setting the proper flags.
7      ;
8      ; ENTRY none
9      ;
10     ;
11     ; EXIT none
12     ;
13     ;
14     ; USES A
15     ;
16     ;
17     ; DOXOFF:
18     ; JB XOFFSENT, SXR ; IF XOFF already sent THEN exit
19     ; SETB XOFFSENT ; Flag that handshake was done
20     ;
21     ;
22     ;
23     ; *DOXOFF* preempts outgoing data and outputs an XOFF to host
24     ; checking that it does not override any user XOFF.
25     ;
26     ;
27     ; ENTRY none
28     ;
29     ; EXIT none
30     ;
31     ; USES A
32     ;
33     ;
34     ; DOXON - do send XON to host
35     ;
36     ; *DOXON* preempts outgoing data and outputs an XON to host
37     ; checking that it does not override any user XOFF.
38     ;
39     ;
40     ; ENTRY none
41     ;
42     ; EXIT none
43     ;
44     ; USES A
45     ;
46     ; DOXON:
47     ; JNB XOFFSENT, SXR ; IF no XOFF sent THEN exit
48     ; CLR XOFFSENT ; Clear flag on handshake
49     ;
50     ;
51     ;
52     ;
53     ;
54     ; ENTRY none
55     ;
56     ; EXIT none
57     ;
58     ; USES A
59     ;
60     ;
61     ; DOXON:
62     ; JNB XOFFSENT, SXR ; IF hardware handshake THEN
63     ; CLR RTS ; clear handshake lines
64     ; CLR DTR
65     ; RET
66     ;
67     ;
68     ;
69     ;
70     ;
71     ;
72     ;
73     ;
74     ;
75     ;
76     ;
77     ;
78     ;
79     ;
80     ;
81     ;
82     ;
83     ;
84     ;
85     ;
86     ;
87     ;
88     ;
89     ;
90     ;
91     ;
92     ;
93     ;
94     ;
95     ;
96     ;
97     ;
98     ;
99     ;
100    ;

```

```

1      ;:      LOOKUP - table lookup and jump
2      ;
3      ;      *LOOKUP* looks for the entry in the table passed to it. If
4      ;      found the return address is removed and control given to the
5      ;      routine. If not found then the main table is searched. If
6      ;      found the return address is removed and control given to the
7      ;      routine. If not found then control is given back to the
8      ;      calling routine.
9      ;
10     ;
11     ;      ENTRY   (B) = table length
12     ;              (DPTR) = beginning of table
13     ;
14     ;      EXIT   return if not found in tables
15     ;
16     ;      USES   all
17     ;
18
19 13E9  91    04      LOOKUP:  ACALL  XSTABX      ; Search users table
20 13EB  50    0B      JNC   LKUP1      ; IF not found THEN
21 13ED  75    F0     13    MOV   B, #LOTL
22 13F0  90    1432    MOV   DPTR, #LOT
23 13F3  91    04      ACALL  XSTABX      ; search main table
24 13F5  50    01      JNC   LKUP1      ; IF not found THEN
25 13F7  22      RET      ; return
26
27 13F8  D0    E0      LKUP1:  POP   ACC      ; ELSE found THEN
28 13FA  D0    E0      POP   ACC      ; remove return address
29 13FC  E4      CLR   A
30 13FD  73      JMP   EA+DPTR   ; jump to routine

```

*** Z-29 COMPUTER TERMINAL FIRMWARE VERSION 1.03 ***

```

1      ;:          XSTX - transmit string to line 25 following CALL
2      ;
3      ;          *XSTX* is a jump to the routine *XST*. It is used to save
4      ;          bytes so that routines may use a short jump to here instead
5      ;          of a long jump to the other routine.
6
7
8 13FE  02  1B9D  XSTX:      LJMP  XST          ; Jump to routine
9
10
11
12
13      ;:          XSTATX - transmit string to line 25
14      ;
15      ;          *XSTATX* is a jump to the routine *XSTAT*. It is used to
16      ;          save bytes so that routines may use a short jump to here
17      ;          instead of a long jump to the other routine.
18
19
20 1401  02  1B8B  XSTATX:    LJMP  XSTAT          ; Jump to routine
21
22
23
24
25      ;:          XSTABX - search table
26      ;
27      ;          *XSTABX* is a jump to the routine *STAB*. It is used to
28      ;          save bytes so that routines may use a short jump to here
29      ;          instead of a long jump to the other routine.
30
31
32 1404  02  013A  XSTABX:    LJMP  STAB          ; Jump to routine
33

```

```
1          ;|          SFCKB - setup fetch character from keyboard
2          ;|
3          ;|          *SFCKB* waits for characters from the keyboard. It does
4          ;|          not return until a character is returned. All access codes
5          ;|          and the characters that follow are dropped.
6          ;|
7          ;|
8          ;|          ENTRY   none
9          ;|
10         ;|          EXIT    (A) = character from keyboard
11         ;|
12         ;|          USES    A, B, DPTR
13         ;|
14         ;|
15 1407    12    02B6    SFCKB:    CALL    FCKB          ; Wait for key
16 140A    40    FB      JC        SFCKB
17 140C    B4    9F      07      CJNE   A, #KB_ACC, SFCKB2    ; IF access code THEN
18 140F    12    02B6    SFCKB1:  CALL    FCKB          ; drop next character
19 1412    40    FB      JC        SFCKB1
20 1414    80    F1      SJMP   SFCKB          ; and keep on going
21 1416    22          SFCKB2:  RET          ; ELSE return
```

```

1 ..... ; ; SETUP1 = setup mode line #1
2 ..... ;
3 ..... ; *SETUP1* runs the terminal setup mode program.
4 ..... ;
5 ..... ;
6 ..... ; ENTRY none
7 ..... ;
8 ..... ; EXIT none
9 ..... ;
10 ..... ; USES all
11 .....
12 .....
13 1417 20 93 01 SETUP: JB SETLCK, SETUP0 ; Check for locked setup
14 141A 22 RET
15 .....
16 141B 12 1B2C SETUP0: CALL SCLRRLR ; Setup clear line reverse
17 .....
18 141E 91 6E SETUP1: ACALL L1 ; Display first line
19 1420 91 07 STP1A: ACALL SFCKB ; Fetch character from keyboard
20 1422 75 F0 01 MOV B, #L1L
21 1425 90 146B MOV DPTR, #L1L
22 1428 71 E9 ACALL LOOKUP ; Lookup command
23 142A 80 F4 SJMP STP1A ; Keep on going
24 .....
25 .....
26 ..... ; Tossle on/off line
27 ..... ;
28 142C B2 2E STP1B: CPL ONLINE ; Tossle on/off line
29 142E 31 9E CALL INITKB ; Reconfigur keyboard
30 1430 80 EC SJMP SETUP1
31 .....
32 .....
33 .....
34 .....
35 ..... ; ; LOT = every line table
36 ..... ;
37 ..... ; *LOT* contains the jump table for every line.
38 .....
39 1432 LOT EQU $
40 .....
41 1432 0D DB CR
42 1433 141E DW SETUP1 ; Main setup line
43 .....
44 1435 61 DB 'a'
45 1436 141E DW SETUP1 ; Main setup line
46 .....
47 1438 41 DB 'A'
48 1439 141E DW SETUP1 ; Main setup line
49 .....
50 143B 74 DB 't'
51 143C 14D7 DW SETUP2 ; Set tabs
52 .....
53 143E 54 DB 'T'
54 143F 14D7 DW SETUP2 ; Set tabs
55 .....
56 1441 62 DB 'b'
57 1442 1542 DW SETUP3 ; Protocol #1

```

```

1
2 1444 42 DB 'B'
3 1445 1542 DW SETUP3 ; Protocol #1
4
5 1447 63 DB 'c'
6 1448 16B0 DW SETUP4 ; Protocol #2
7
8 144A 43 DB 'C'
9 144B 16B0 DW SETUP4 ; Protocol #2
10
11 144D 64 DB 'd'
12 144E 1795 DW SETUP5 ; Misc #1
13
14 1450 44 DB 'D'
15 1451 1795 DW SETUP5 ; Misc #1
16
17 1453 65 DB 'e'
18 1454 1865 DW SETUP6 ; Keyboard
19
20 1456 45 DB 'E'
21 1457 1865 DW SETUP6 ; Keyboard
22
23 1459 66 DB 'f'
24 145A 18F4 DW SETUP7 ; Misc #2
25
26 145C 46 DB 'F'
27 145D 18F4 DW SETUP7 ; Misc #2
28
29 145F 67 DB 'e'
30 1460 19DD DW SETUP8 ; Misc #3
31
32 1462 47 DB 'G'
33 1463 19DD DW SETUP8 ; Misc #3
34
35 1465 88 DB KB_SETUP ; Setup key
36 1466 1AF6 DW SETUPRET ; Return
37
38 1468 C8 DB KB_SETUP + KB_SHFT ; Shift setup key
39 1469 1B02 DW SETUPSAVE ; Save and return
40
41 0013 L0TL EQU ($-L0T)/3 ; Table #0 length
42
43
44
45
46 ;; L1T - line #1 table
47 ;
48 ; *L1T* contains the JUMP table for line #1 in setup mode.
49 ;
50 146B L1T EQU $
51
52 146B 31 DB '1' ; Option #1
53 146C 142C DW STP1B ; Toggle on/off line
54
55 0001 L1TL EQU ($-L1T)/3 ; Table length
56
57

```



```

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15 146E E4 L1: CLR A ; Position
16
17 146F 71 FE ACALL XSTX
18 1471 2A 2A 20 DB '*** SETUP MENU A ** (Ver 1.03) 1.', (''+80H)
1474 53 45 54
1477 55 50 20
147A 4D 45 4E
147D 55 20 41
1480 20 2A 2A
1483 20 20 28
1486 56 65 72
1489 20 31 2E
148C 30 33 29
148F 20 20 20
1492 31 2E A0
19
20 1495 90 14C7 MOV DPTR, #LN1B1
21 1498 20 2E 03 JB ONLINE, L1A ; Get proper message for
22 149B 90 14CF MOV DPTR, #LN1B2 ; on/off line
23 149E 91 01 L1A: ACALL XSTATX ; Next part
24
25 14A0 71 FE ACALL XSTX
26 14A2 20 20 20 DB ' MENUS -A- to -G- or -T- for TAB', ('S'+80H)
14A5 20 4D 45
14A8 4E 55 53
14AB 20 2D 41
14AE 2D 20 74
14B1 6F 20 2D
14B4 47 2D 20
14B7 6F 72 20
14BA 2D 54 2D
14BD 20 66 6F
14C0 72 20 54
14C3 41 42 D3
27
28 14C6 22 RET
29
30 ; Line #1 setup mode messages
31 ;
32 14C7 6F 6E 20 LN1B1: DB 'on line', (''+80H)
14CA 6C 69 6E
14CD 65 A0
33 14CF 6F 66 66 LN1B2: DB 'off lin', ('e'+80H)

```

*** Z-29 COMPUTER TERMINAL FIRMWARE VERSION 1.03 ***

14D2	20	6C	69
14D5	6E	E5	

```

1          ;:          SETUP2 - setup mode line #2
2          ;
3          ;          *SETUP2* is the setup mode line for set/clear tabs.
4          ;          -PTR2- is used as the cursor position.
5          ;
6          ;
7          ;          ENTRY   none
8          ;
9          ;          EXIT    none
10         ;
11         ;          USES   all
12         ;
13         ;
14 14D7    79    00          SETUP2:  MOV    PTR2, #0          ; -PTR2- is cursor position
15 14D9    B1    0D          STP2A:  ACALL  L2          ; Display line #2
16 14DB    91    07          STP2B:  CALL  SFCKB         ; Fetch character from keyboard
17 14DD    75    F0    04          MOV    B, #L2TL
18 14E0    90    1501        MOV    DPTR, #L2T
19 14E3    71    E9          ACALL  LOOKUP        ; Look up command
20 14E5    80    F4          SJMP  STP2B         ; Keep on going
21
22
23         ;          Move left
24         ;
25 14E7    19          STP2C:  DEC    PTR2          ; Decrement
26 14E8    B9    FF    01        CJNE  PTR2, #(0-1), STP2C1 ; IF wrap around THEN
27 14EB    09          INC    PTR2          ; bump back up
28 14EC    80    EB          STP2C1: SJMP  STP2A         ; keep going
29
30
31         ;          Move right
32         ;
33 14EE    09          STP2D:  INC    PTR2          ; Bump
34 14EF    B9    50    01        CJNE  PTR2, #80, STP2D1 ; IF wrap around THEN
35 14F2    19          DEC    PTR2          ; bump back down
36 14F3    80    E4          STP2D1: SJMP  STP2A         ; keep going
37
38
39         ;          Set tab
40         ;
41 14F5    D2    D5          STP2E:  SETB  F0
42 14F7    80    02          SJMP  STP2F1        ; Set tab
43
44
45         ;          Clear tab
46         ;
47 14F9    C2    D5          STP2F:  CLR    F0
48 14FB    E9          STP2F1: MOV    A, PTR2        ; Get position
49 14FC    12    05A2        CALL  SETTAB        ; Set/clear tab
50 14FF    80    D8          SJMP  STP2A         ; Keep going
51
52
53
54
55         ;:          L2T - line #2 table
56         ;
57         ;          *L2T* contains the jump table for line #2 in setup mode.

```

*** Z-29 COMPUTER TERMINAL FIRMWARE VERSION 1.03 ***

```

1
2      1501      L2T      EQU      $
3
4      1501      82      DB      KB_LEFT      ; Cursor left
5      1502      14E7    DW      STP2C      ; Move left
6
7      1504      83      DB      KB_RIGHT     ; Cursor right
8      1505      14EE    DW      STP2D      ; Move right
9
10     1507      80      DB      KB_UP        ; Cursor up
11     1508      14F5    DW      STP2E      ; Set tab
12
13     150A      81      DB      KB_DOWN     ; Cursor down
14     150B      14F9    DW      STP2F      ; Clear tab
15
16     0004      L2TL     EQU      ($-L2T)/3   ; Table length
17
18
19
20
21     ;;          L2 - line #2
22     ;
23     ;          *L2* displays setup information for line #2 set/clear tabs.
24     ;
25     ;
26     ;          ENTRY   none
27     ;
28     ;          EXIT    none
29     ;
30     ;          USES    all
31
32
33     150D      90      5780    L2:      MOV      DPTR, #L25MEM      ; Work with 25th line
34     1510      7D      00      MOV      TEMP, #0        ; Counter variable
35     1512      78      29      MOV      PTR1, #TABTAB    ; Point to tab table
36     1514      7A      0A      MOV      INDX1, #10      ; 10 bytes
37     1516      E6      L2A:     MOV      A, @PTR1        ; REPEAT set byte
38     1517      7B      08      MOV      INDX2, #8       ; 8 bits
39     1519      FE      MOV      WORK1, A        ; save value for later
40     151A      ED      L2B:     MOV      A, TEMP        ; REPEAT
41     151B      04      INC      A            ; set and adjust position
42     151C      75      F0      0A     MOV      B, #10        ; calculate character
43     151F      84      DIV      AB
44     1520      E5      F0      MOV      A, B
45     1522      24      30      ADD      A, #'0'        ; convert to ASCII
46     1524      FF      MOV      WORK2, A        ; and save it
47
48     1525      ED      MOV      A, TEMP
49     1526      B5      01      02     CJNE     A, PTR2A, L2C    ; IF cursor = position THEN
50     1529      7F      09      MOV      WORK2, #09H    ; change to cursor char
51
52     152B      EE      L2C:     MOV      A, WORK1        ; restore tab table value
53     152C      33      RLC      A
54     152D      FE      MOV      WORK1, A        ; replace new value
55     152E      50      08      JNC     L2D            ; IF tab is set here THEN
56     1530      7F      00      MOV      WORK2, #00H    ; change to tab char
57     1532      ED      MOV      A, TEMP

```

*** Z-29 COMPUTER TERMINAL FIRMWARE VERSION 1.03 ***

```

1 1533 B5 01 02 CJNE A, PTR2A, L2D ; IF cursor = position THEN
2 1536 7F 02 MOV WORK2, #02H ; change to both char
3 1538 EF L2D: MOV A, WORK2 ; set final character
4 1539 F0 MOVX @DPTR, A ; place into memory
5 153A A3 INC DPTR ; bump pointer
6 153B 0D INC TEMP ; bump count
7 153C DB DC DJNZ INDX2, L2B ; UNTIL all bits
8 153E 08 INC PTR1 ; bump tab table pointer
9 153F DA D5 DJNZ INDX1, L2A ; UNTIL all bytes
10 1541 22 RET

```

```

1          ; ;          SETUP3 - setup mode line #3
2          ;
3          ;          *SETUP3* runs the terminal setup mode to change baud rate,
4          ;          parity, duplex, and handshake.
5          ;
6          ;
7          ;          ENTRY none
8          ;
9          ;          EXIT none
10         ;
11         ;          USES all
12
13
14 1542 B1 98          SETUP3: ACALL L3          ; Display third line
15 1544 91 07          STP3A: ACALL SFCKB       ; Fetch character from keyboard
16 1546 75 F0 04      MOV B, #L3TL
17 1549 90 158C      MOV DPTR, #L3T
18 154C 71 E9          ACALL LOOKUP          ; Look up command
19 154E 80 F4          SJMP STP3A          ; Keep on going
20
21
22         ;          Chane baud rate
23         ;
24 1550 E5 33          STP3B: MOV A, BAUDRATE      ; Search for current baud rate
25 1552 75 F0 0E      MOV B, #L3ATL
26 1555 90 161E      MOV DPTR, #L3AT
27 1558 91 04          ACALL XSTABX
28 155A 40 06          JC STP3B1          ; IF found THEN
29 155C E5 F0          MOV A, B          ; set count + 1
30 155E B4 0E 01      CJNE A, #L3ATL, STP3B1 ; IF time for wrap THEN
31 1561 E4          CLR A          ; zero
32 1562 12 0E4B      STP3B1: CALL SBR          ; Set baud rate
33 1565 80 DB          SJMP SETUP3
34
35
36         ;          Chane parity
37         ;
38 1567 20 28 08      STP3C: JB PRTYENA, STP3C1 ; IF disabled THEN
39 156A D2 28          SETB PRTYENA ; enable parity
40 156C C2 29          CLR PRTYSTK ; normal parity
41 156E C2 2A          CLR PRTYEVN ; odd parity
42 1570 80 D0          SJMP SETUP3
43 1572 20 29 07      STP3C1: JB PRTYSTK, STP3C2 ; IF normal parity AND
44 1575 20 2A 08      JB PRTYEVN, STP3C3 ; IF odd parity THEN
45 1578 D2 2A          SETB PRTYEVN ; make even parity
46 157A 80 C6          SJMP SETUP3
47 157C C2 28          STP3C2: CLR PRTYENA ; IF stick THEN disable parity
48 157E 80 C2          SJMP SETUP3
49 1580 D2 29          STP3C3: SETB PRTYSTK ; IF even THEN stick parity
50 1582 80 BE          SJMP SETUP3
51
52
53         ;          Toggle duplex
54         ;
55 1584 B2 2F          STP3D: CPL FULLDPLX ; Toggle full/half duplex
56 1586 80 BA          SJMP SETUP3
57

```

```

1
2 ; Toggle handshake
3 ;
4 1588 B2 3E STP3E: CPL HNDSHK ; Toggle soft/hard handshake
5 158A 80 B6 JUMP SETUP3
6
7
8
9
10 ;; L3T - line #3 table
11 ;
12 ; *L3T* contains the jump table for line #3 in setup mode.
13
14 158C L3T EQU $
15
16 158C 31 DB '1' ; Option #1
17 158D 1550 DW STP3B ; Change baud rate
18
19 158F 32 DB '2' ; Option #2
20 1590 1567 DW STP3C ; Change parity
21
22 1592 33 DB '3' ; Option #3
23 1593 1584 DW STP3D ; Toggle duplex
24
25 1595 34 DB '4' ; Option #4
26 1596 1588 DW STP3E ; Toggle handshake
27
28 0004 L3TL EQU ($-L3T)/3 ; Table length
29
30
31
32
33 ;; L3 - line #3
34 ;
35 ; *L3* displays setup information for line #3.
36 ;
37 ;
38 ; ENTRY none
39 ;
40 ; EXIT none
41 ;
42 ; USES all
43
44
45 1598 E4 L3: CLR A ; Position
46
47 1599 71 FE ACALL XSTX
48 159B 2A 4D 45 DB /*MENU B* 1. BAUD?, (?+80H)
159E 4E 55 20
15A1 42 2A 20
15A4 20 20 31
15A7 2E 20 42
15AA 41 55 44
15AD A0
49
50 15AE E5 33 MOV A, BAUDRATE
51 15B0 75 F0 0E MOV B, #L3ATL

```

*** Z-29 COMPUTER TERMINAL FIRMWARE VERSION 1.03 ***

```

1 15B3 90 161E      MOV    DPTR, #L3AT
2 15B6 91 04        ACALL  XSTABX      ; Search for correct message
3 15B8 50 06        JNC    L3A        ; IF not found THEN
4 15BA 75 33 00     MOV    BAUDRATE, #0 ; clear baud rate
5 15BD 90 167F     MOV    DPTR, #LN3B14 ; error message
6 15C0 74 13      MOV    A, #19      ; Position
7 15C2 91 01      ACALL  XSTATX     ; Baud rate message
8
9 15C4 71 FE      ACALL  XSTX
10 15C6 20 20 32   DB    ' 2. PARITY', ( '/' +80H)
    15C9 2E 20 50
    15CC 41 52 49
    15CF 54 59 A0
11
12 15D2 90 1684     MOV    DPTR, #LN3C1 ; No parity
13 15D5 30 28 0F   JNB    PRTYENA, L3B
14 15D8 90 1689     MOV    DPTR, #LN3C2 ; Stick parity
15 15DB 20 29 09   JB     PRTYSTK, L3B
16 15DE 90 168E     MOV    DPTR, #LN3C3 ; Even parity
17 15E1 20 2A 03   JB     PRTYEVN, L3B
18 15E4 90 1693     MOV    DPTR, #LN3C4 ; Odd parity
19 15E7 91 01      ACALL  XSTATX     ; Parity message
20
21 15E9 71 FE      ACALL  XSTX
22 15EB 20 20 33   DB    ' 3. DUPLEX', ( '/' +80H)
    15EE 2E 20 44
    15F1 55 50 4C
    15F4 45 58 A0
23
24 15F7 90 1698     MOV    DPTR, #LN3E1 ; Full duplex
25 15FA 20 2F 03   JB     FULLDPLX, L3C
26 15FD 90 169C     MOV    DPTR, #LN3E2 ; Half duplex
27 1600 91 01      ACALL  XSTATX     ; Duplex message
28
29 1602 71 FE      ACALL  XSTX
30 1604 20 20 34   DB    ' 4. HANDSHAKE', ( '/' +80H)
    1607 2E 20 48
    160A 41 4E 44
    160D 53 48 41
    1610 4B 45 A0
31
32 1613 90 16A0     MOV    DPTR, #LN3G1 ; Hardware handshake
33 1616 20 3E 03   JB     HNDSHK, L3D
34 1619 90 16A8     MOV    DPTR, #LN3G2 ; Software handshake
35 161C 81 01      AJMP  XSTATX     ; Handshake message and return
36
37
38
39
40 ; L3AT - line #3 table
41 ;
42 ; *L3AT* contains the addresses for the corresponding baud
43 ; rates and the order is used to determine the next baud rate
44 ; when changed.
45
46 161E L3AT EQU $
47

```


1	161E	FF				DB	255		: 19200 baud
2	161F	1648				DW	LN3B		
3									
4	1621	FE				DB	254		: 9600 baud
5	1622	164D				DW	LN3B1		
6									
7	1624	FC				DB	252		: 4800 baud
8	1625	1652				DW	LN3B3		
9									
10	1627	FF				DB	255		: skip 7200 baud
11	1628	167F				DW	LN3B14		
12									
13	162A	F8				DB	248		: 2400 baud
14	162B	1657				DW	LN3B5		
15									
16	162D	FF				DB	255		: skip 3600 baud
17	162E	167F				DW	LN3B14		
18									
19	1630	F5				DB	245		: 1800 baud
20	1631	165C				DW	LN3B7		
21									
22	1633	FF				DB	255		: skip 2000 baud
23	1634	167F				DW	LN3B14		
24									
25	1636	F0				DB	240		: 1200 baud
26	1637	1661				DW	LN3B8		
27									
28	1639	E0				DB	224		: 600 baud
29	163A	1666				DW	LN3B9		
30									
31	163C	C0				DB	192		: 300 baud
32	163D	166B				DW	LN3B10		
33									
34	163F	80				DB	128		: 150 baud
35	1640	1670				DW	LN3B11		
36									
37	1642	52				DB	82		: 110 baud
38	1643	1675				DW	LN3B12		
39									
40	1645	01				DB	1		: 75 baud
41	1646	167A				DW	LN3B13		
42									
43		000E		L3ATL		EQU	(\$-L3AT)/3		: Table length
44									
45									
46									
47									
48				;;			Line #3 setup mode messages		
49				;					
50									
51	1648	31	39	32	LN3B:	DB	'1920', ('0'+80H)		
	164B	30	B0						
52	164D	39	36	30	LN3B1:	DB	'9600', (' '+80H)		
	1650	30	A0						
53	1652	34	38	30	LN3B3:	DB	'4800', (' '+80H)		
	1655	30	A0						
54	1657	32	34	30	LN3B5:	DB	'2400', (' '+80H)		

165A 30 A0


```

1          ;
2          ;
3          ;
4          ; *SETUP4* runs the terminal setup mode to chause port, mode
5          ; hold screen mode, and monitor mode.
6          ;
7          ; ENTRY none
8          ;
9          ; EXIT none
10         ;
11        ; USES all
12
13
14 16B0 D1 F8 SETUP4: ACALL L4 ; Display fourth line
15 16B2 91 07 STP4A: CALL SFCKB ; Fetch character from keyboard
16 16B4 75 F0 04 MOV B, #L4TL
17 16B7 90 16EC MOV DPTR, #L4T
18 16BA 71 E9 CALL LOOKUP ; Look up command
19 16BC 80 F4 SJMP STP4A ; Keep on going
20
21
22 ;
23 ; Tossle main port
24 16BE 12 1E0F STP4B: CALL CMPORT ; Tossle port
25 16C1 80 ED SJMP SETUP4
26
27
28 ;
29 ; Tossle ANSI/ZDS/ADM 3/Hazeltine mode
30 16C3 E5 28 STP4C: MOV A, MODE ; Get current mode
31 16C5 FD MOV TEMP, A ; Save it
32 16C6 53 05 F0 ANL TEMP, #11110000B ; Mask off mode portion
33 16C9 23 RL A ; Rotate to next mode
34 16CA 54 0E ANL A, #00001110B ; Mask off extra stuff
35 16CC 70 01 JNZ STP4C1 ; IF zero THEN
36 16CE 04 INC A ; bump to one
37 16CF 4D STP4C1: ORL A, TEMP ; Combine both halves
38 16D0 F5 28 MOV MODE, A ; Save new current mode
39 16D2 31 CB ACALL TERMINIT ; Initialize for any terminal
40 16D4 30 43 02 JNB HAZ, STP4C2 ; IF Hazeltine THEN
41 16D7 31 D4 ACALL HAZINIT ; initialize for Hazeltine
42 16D9 80 D5 STP4C2: SJMP SETUP4
43
44
45 ;
46 ; Tossle hold screen mode
47 16DB 30 36 05 STP4D: JNB HSMODEF, STP4D1
48 16DE 12 0B43 CALL XHSM ; IF hold screen THEN exit
49 16E1 80 CD SJMP SETUP4
50 16E3 12 0B3C STP4D1: CALL EHSM ; ELSE enter hold screen
51 16E6 80 C8 SJMP SETUP4
52
53
54 ;
55 ; Tossle monitor mode
56 16E8 B2 3A STP4E: CPL MONITOR ; Tossle monitor mode
57 16EA 80 C4 SJMP SETUP4

```

```

1
2
3
4
5          ;:          L4T - Line #4 table
6          ;
7          ;          *L4T* contains the jump table for line #4 in setup mode
8
9          16EC          L4T          EQU          $
10
11 16EC          31          DB          '1'
12 16ED          16BE          DW          STP4B          ; Toggle ports
13
14 16EF          32          DB          '2'
15 16F0          16C3          DW          STP4C          ; Toggle mode
16
17 16F2          33          DB          '3'
18 16F3          16DB          DW          STP4D          ; Toggle hold screen
19
20 16F5          34          DB          '4'
21 16F6          16E8          DW          STP4E          ; Toggle monitor mode
22
23          0004          L4TL          EQU          ($-L4T)/3          ; Table length
24
25
26
27
28          ;:          L4 - line #4
29          ;
30          ;          *L4* displays setup information for line #4.
31          ;
32          ;
33          ;          ENTRY none
34          ;
35          ;          EXIT none
36          ;
37          ;          USES all
38
39
40 16F8          E4          L4:          CLR          A
41 16F9          71          FE          ACALL         XSTX
42 16FB          2A          4D          45          DB          '*MENU C* 1. PORT', (/' +80H)
43          16FE          4E          55          20
44          1701          43          2A          20
45          1704          20          20          31
46          1707          2E          20          50
47          170A          4F          52          54
48          170D          A0
49
50 170E          90          1769          MOV          DPTR, #LN4B1          ; Normal
51 1711          30          02          03          JNB          PORTF, L4A
52 1714          90          176F          MOV          DPTR, #LN4B2          ; Auxiliary
53 1717          91          01          L4A:          ACALL         XSTATX          ; Port message
54
55 1719          71          FE          ACALL         XSTX
56 171B          20          20          20          DB          ' 2. MODE', (/' +80H)
57 171E          32          2E          20

```

*** Z-29 COMPUTER TERMINAL FIRMWARE VERSION 1.03 ***

1721	4D	4F	44
1724	45	A0	

```

1
2 1726 .90 1775 MOV DPTR, #LN4D1 ; ANSI mode
3 1729 .20 40 0F JB ANSI, L4B
4 172C 90 177D MOV DPTR, #LN4D2 ; ZDS mode
5 172F 20 41 09 JB ZDS, L4B
6 1732 90 1785 MOV DPTR, #LN4D3 ; ADM 3 mode
7 1735 20 42 03 JB ADM3, L4B
8 1738 90 178D MOV DPTR, #LN4D4 ; Hazeltine mode
9 173B 91 01 L4B: ACALL XSTATX ; ANSI/ZDS/ADM 3/Haz message
10
11 173D 71 FE ACALL XSTX
12 173F 20 20 20 DB ' 3. HOLD SCRN', (''+80H)
1742 33 2E 20
1745 48 4F 4C
1748 44 20 53
174B 43 52 4E
174E A0
13
14 174F A2 36 MOV C, HSMODEF
15 1751 12 1BBF LCALL XLONOFF ; Hold on/off message
16
17 1754 71 FE ACALL XSTX
18 1756 20 20 20 DB ' 4. MONITOR', (''+80H)
1759 34 2E 20
175C 4D 4F 4E
175F 49 54 4F
1762 52 A0
19
20 1764 A2 3A MOV C, MONITOR
21 1766 02 1BBF LJMP XLONOFF ; Monitor mode on/off and return
22
23
24
25
26 ; ; Line #4 setup mode messages
27 ; ;
28
29 1769 6E 6F 72 LN4B1: DB 'norma', (''+80H)
176C 6D 61 75 EC
30 176F 61 75 78 LN4B2: DB 'auxil', (''+80H)
1772 69 6C A0
31 1775 61 6E 73 LN4D1: DB 'ansi', (''+80H)
1778 69 20 20
177B 20 A0
32 177D 7A 65 6E LN4D2: DB 'zenith', (''+80H)
1780 69 74 68
1783 20 A0
33 1785 61 64 6D LN4D3: DB 'adm 3a', (''+80H)
1788 20 33 61
178B 20 A0
34 178D 68 61 7A LN4D4: DB 'haz 150', (''+80H)
1790 20 31 35
1793 30 B0

```

```

1          ;          SETUP5 - setup mode line #5
2          ;
3          ;
4          ;          *SETUP5* runs the terminal setup mode to change set clock,
5          ;          toggle status line, setup wrap around, and screen saver.
6          ;
7          ;          ENTRY   none
8          ;
9          ;          EXIT    none
10         ;
11         ;          USES    all
12         ;
13
14 1795     12     1808     SETUP5:    CALL    L5          ; Display fifth line
15 1798     91     07          STP5A:    CALL    SFCKB       ; Fetch character from keyboard
16 179A     75     F0     04     MOV     B, #L5TL
17 179D     90     17FC     MOV     DPTR, #L5T
18 17A0     71     E9          CALL    LOOKUP      ; Look up command
19 17A2     80     F4          SJMP   STP5A       ; Keep on going
20
21
22         ;          Set clock
23         ;
24 17A4     12     1B2C     STP5B:    CALL    SCLRLR     ; Setup clear line reverse
25 17A7     E4          CLR     A
26
27 17A8     71     FE          ACALL   XSTX
28 17AA     45     6E     74     DB      'Enter hours ', (>'+80H)
29         17AD     65     72     20
30         17B0     68     6F     75
31         17B3     72     73     20
32         17B6     BE
33
34 17B7     74     0E          MOV     A, #14
35 17B9     12     1B45     CALL    GETNUM      ; Get number
36 17BC     BF     00     02     CJNE   WORK2, #0, STP5B1 ; IF zero THEN skip
37 17BF     80     D4          SJMP   SETUP5
38 17C1     B4     18     00     STP5B1:  CJNE   A, #24, STP5B2
39 17C4     50     CF     STP5B2:  JNC    SETUP5      ; IF number <= 24 THEN
40 17C6     F5     3D          MOV     THOUR, A
41 17C8     12     1B2C     CALL    SCLRLR     ; Setup clear line reverse
42 17CB     E4          CLR     A
43
44 17CC     71     FE          ACALL   XSTX
45 17CE     45     6E     74     DB      'Enter minutes ', (>'+80H)
46 17D1     65     72     20
47 17D4     6D     69     6E
48 17D7     75     74     65
49 17DA     73     20     BE
50
51 17DD     74     10          MOV     A, #16
52 17DF     12     1B45     CALL    GETNUM      ; set number
53 17E2     B4     3C     00     CJNE   A, #60, STP5B3
54 17E5     50     3E     STP5B3:  JNC    SETUP5      ; IF number <= 59 THEN
55 17E7     F5     3C          MOV     TMIN, A
56
57 17E9     E4          CLR     A

```


*** Z-29 COMPUTER TERMINAL FIRMWARE VERSION 1.03 ***

```

1 17EA F5 3B MOV TSEC, A ; clear seconds
2 17EC F5 3A MOV TCNT, A ; and count
3 17EE 80 A5 SJMP SETUP5
4
5
6 ;
7 ; Tossle 25th status line
8 17F0 B2 37 STP5C: CPL L25ON ; Tossle status line
9 17F2 80 A1 SJMP SETUP5
10
11
12 ;
13 ; Tossle wrap
14 17F4 B2 2B STP5D: CPL AUTOWRAP ; Tossle auto wrap
15 17F6 80 9D SJMP SETUP5
16
17
18 ;
19 ; Tossle screen saver mode
20 17F8 B2 3B STP5E: CPL SCRNSAVE ; Tossle screen saver
21 17FA 80 99 SJMP SETUP5
22
23
24
25
26 ;
27 ; L5T - line #5 table
28 ;
29 ; *L5T* contains the jump table for line #5 in setup mode.
30 17FC L5T EQU $
31
32 17FC 31 DB '1'
33 17FD 17A4 DW STP5B ; Set clock
34
35 17FF 32 DB '2'
36 1800 17F0 DW STP5C ; Tossle status line
37
38 1802 33 DB '3'
39 1803 17F4 DW STP5D ; Tossle wrap around
40
41 1805 34 DB '4'
42 1806 17F8 DW STP5E ; Tossle screen saver
43
44 0004 L5TL EQU ($-L5T)/3 ; Table length
45
46
47
48
49 ;
50 ; L5 - line #5
51 ;
52 ; *L5* displays setup information for line #5.
53 ;
54 ;
55 ; ENTRY none
56 ;
57 ; EXIT none

```

```

1          ;          USES    all
2
3
4 1808     E4          L5:     CLR    A
5
6 1809     71          9D          ACALL  XST
7 180B     2A          4D          45          DB    /*MENU D*  1. SET CLOCK  2. STATUS LINE', (/*+80H)
   180E     4E          55          20
   1811     44          2A          20
   1814     20          20          31
   1817     2E          20          53
   181A     45          54          20
   181D     43          4C          4F
   1820     43          4B          20
   1823     20          20          32
   1826     2E          20          53
   1829     54          41          54
   182C     55          53          20
   182F     4C          49          4E
   1832     45          A0
8
9 1834     A2          37          MOV    C, L250N
10 1836     12          1BBF     LCALL  XLONOFF          ; Status line on/off
11
12 1839     71          9D          ACALL  XST
13 183B     20          20          20          DB    /* 3. WRAP', (/*+80H)
   183E     33          2E          20
   1841     57          52          41
   1844     50          A0
14
15 1846     A2          2B          MOV    C, AUTOWRAP
16 1848     12          1BBF     LCALL  XLONOFF          ; Wrap around on/off
17
18 184B     71          9D          ACALL  XST
19 184D     20          20          20          DB    /* 4. SCREEN SAVER', (/*+80H)
   1850     34          2E          20
   1853     53          43          52
   1856     45          45          4E
   1859     20          53          41
   185C     56          45          52
   185F     A0
20
21 1860     A2          3B          MOV    C, SCRNSAVE
22 1862     02          1BBF     LCALL  XLONOFF          ; Screen saver on/off and return

```

```

1      ;:          SETUP6 = setup.mode.line.#6
2      ;
3      ;          *SETUP6* runs the terminal setup mode to change keypad shift,
4      ;          keypad alternate, auto repeat, and key click.
5      ;
6      ;
7      ;          ENTRY   none
8      ;
9      ;          EXIT    none
10     ;
11     ;          USES   all
12
13
14 1865  11   97          SETUP6:  ACALL  L6          ; Display sixth line
15 1867  12  1407       STP6A:    CALL   SFCKB       ; Fetch character from keyboard
16 186A  75   F0   04    MOV     B, #L6TL
17 186D  90  188B       MOV     DPTR, #L6T
18 1870  12  13E9       CALL   LOOKUP      ; Look up command
19 1873  80   F2       SUMP   STP6A          ; Keep on going
20
21
22     ;          ;          Toggle keypad shifted
23     ;
24 1875  B2   30       STP6B:    CPL    KPDSHTF      ; Toggle keypad shifted
25 1877  80   EC       SUMP   SETUP6
26
27
28     ;          ;          Toggle keypad alternate
29     ;
30 1879  B2   31       STP6C:    CPL    KPADALTF     ; Toggle keypad alternate
31 187B  80   E8       SUMP   SETUP6
32
33
34     ;          ;          Toggle auto repeat
35     ;
36 187D  B2   34       STP6D:    CPL    REPF        ; Toggle auto repeat
37 187F  12  119E       CALL   INITKB      ; Reconfigure keyboard
38 1882  80   E1       SUMP   SETUP6
39
40
41     ;          ;          Toggle key click
42     ;
43 1884  B2   33       STP6E:    CPL    CLKF        ; Toggle key click
44 1886  12  119E       CALL   INITKB      ; Reconfigure keyboard
45 1889  80   DA       SUMP   SETUP6
46
47
48
49
50     ;:          ;:          L6T - line #6 table
51     ;
52     ;          ;          *L6T* contains the jump table for line #6 in setup mode.
53     ;
54     ;          188B     L6T     EQU    $
55
56 188B  31          DB    '1'
57 188C  1875       DW    STP6B          ; Toggle keypad shifted

```

```

1
2 188E 32          DB  '2'
3 188F 1879       DW  STP6C          ; Toggle keypad alternate
4
5 1891 33          DB  '3'
6 1892 187D       DW  STP6D          ; Toggle auto repeat
7
8 1894 34          DB  '4'
9 1895 1884       DW  STP6E          ; Toggle key click
10
11          0004          L6TL          EQU  ($-L6T)/3          ; Table length
12
13
14
15
16          ;          L6 - line #6
17          ;
18          ;          *L6* displays setup information for line #6
19          ;
20          ;
21          ;          ENTRY  none
22          ;
23          ;          EXIT   none
24          ;
25          ;          USES   all
26
27
28 1897  E4          L6:          CLR  A          ; Position
29
30 1898  71          9D          ACALL  XST
31 189A  2A          4D          45          DB  ' *MENU E*  1. KEYPAD SHFT', ( '+' +80H)
   189D  4E          55          20
   18A0  45          2A          20
   18A3  20          20          31
   18A6  2E          20          4B
   18A9  45          59          50
   18AC  41          44          20
   18AF  53          48          46
   18B2  54          A0
32
33 18B4  A2          30          MOV   C, KPADSHFT
34 18B6  71          BF          ACALL XLONOFF          ; Keypad shifted on/off
35
36 18B8  71          9D          ACALL  XST
37 18BA  20          20          20          DB  ' 2. KEYPAD ALT', ( '+' +80H)
   18BD  32          2E          20
   18C0  4B          45          59
   18C3  50          41          44
   18C6  20          41          4C
   18C9  54          A0
38
39 18CB  A2          31          MOV   C, KPADALTF
40 18CD  71          BF          ACALL XLONOFF          ; Keypad alternate on/off
41
42 18CF  71          9D          ACALL  XST
43 18D1  20          20          20          DB  ' 3. REPEAT', ( '+' +80H)
   18D4  33          2E          20

```

*** Z-29 COMPUTER TERMINAL FIRMWARE VERSION 1.03 ***

18D7	52	45	50
18DA	45	41	54
18DD	A0		

.....1

.....2 18DE A2 34

.....MOV C, REPF

.....3 18E0 71 BF

.....ACALL XLONOFF

.....; Auto repeat on/off

.....4

.....5 18E2 71 9D

.....ACALL XST

.....6 18E4 20 20 20

.....DB 4, 'CLICK', (0+80H)

.....18E7 34 2E 20

.....18EA 43 4C 49

.....18ED 43 4B A0

.....7

.....8 18F0 A2 33

.....MOV C, CLKF

.....9 18F2 61 BF

.....AJMP XLONOFF

.....; Key click on/off and Return

```

1          ;:          SETUP7 - setup mode line #7
2          ;
3          ;          *SETUP7* runs the terminal setup mode to change auto carriage
4          ;          return, auto line feed, cursor, and frequency.
5          ;
6          ;
7          ;          ENTRY   none
8          ;
9          ;          EXIT    none
10         ;
11         ;          USES    all
12         ;
13
14 18F4    31    3F          SETUP7:    ACALL   L7          ; Display seventh line
15 18F6    12    1407      STP7A:    CALL    SFCKB      ; Fetch character from keyboard
16 18F9    75    F0    04    MOV     B, #L7TL
17 18FC    90    1933      MOV     DPTR, #L7T
18 18FF    12    13E9      CALL   LOOKUP      ; Look up command
19 1902    80    F2          SJMP   STP7A        ; Keep on going
20
21
22         ;          Tossle auto carriage return
23         ;
24 1904    B2    2C          STP7B:    CPL     AUTO CR      ; Tossle auto CR
25 1906    80    EC          SJMP   SETUP7
26
27
28         ;          Tossle auto line feed
29         ;
30 1908    B2    2D          STP7C:    CPL     AUTO LF      ; Tossle auto LF
31 190A    80    E8          SJMP   SETUP7
32
33
34         ;          Tossle cursor
35         ;
36 190C    20    38    0D    STP7D:    JB     CRNBK, STP7D2      ; IF blinking AND
37 190F    20    32    04    JB     CRUL, STP7D1      ; IF block THEN
38 1912    D2    32          SETB   CRUL          ; set to blink line
39 1914    80    11          SJMP   STP7D4
40
41 1916    C2    32          STP7D1:   CLR     CRUL          ; IF blink line THEN
42 1918    D2    38          SETB   CRNBK        ; set to block
43 191A    80    0B          SJMP   STP7D4
44
45 191C    20    32    04    STP7D2:   JB     CRUL, STP7D3      ; IF block THEN
46 191F    D2    32          SETB   CRUL          ; set to underline
47 1921    80    04          SJMP   STP7D4
48
49 1923    C2    32          STP7D3:   CLR     CRUL          ; IF underline THEN
50 1925    C2    38          CLR     CRNBK        ; set to blink block
51
52 1927    12    117B      STP7D4:   CALL   SETCF        ; Set cursor format
53 192A    80    C8          SJMP   SETUP7
54
55
56         ;          Tossle line frequency
57         ;

```

*** Z-29 COMPUTER TERMINAL FIRMWARE VERSION 1.03 ***

```

1 192C B2 39 STP7E: CPL FREQ ; Toggle frequency
2 192E 12 117B CALL SETCF ; Set cursor format
3 1931 80 C1 SJMP SETUP7
4
5
6
7
8 ; ; L7T - line #7 table
9 ;
10 ; ; *L7T* contains the jump table for line #7 in setup mode.
11
12 1933 L7T EQU $
13
14 1933 31 DB '1'
15 1934 1904 DW STP7B ; Toggle auto carriage return
16
17 1936 32 DB '2'
18 1937 1908 DW STP7C ; Toggle auto line feed
19
20 1939 33 DB '3'
21 193A 190C DW STP7D ; Toggle cursor
22
23 193C 34 DB '4'
24 193D 192C DW STP7E ; Toggle line freq 50/60 Hz
25
26 0004 L7TL EQU (L7T)/3 ; Table length
27
28
29
30
31 ; ; L7 - line #7
32 ; ;
33 ; ; *L7* displays setup information for line #7
34 ; ;
35 ; ;
36 ; ; ENTRY none
37 ; ;
38 ; ; EXIT none
39 ; ;
40 ; ; USES all
41 ; ;
42
43 193F E4 L7: CLR A ; Position
44
45 1940 71 9D ACALL XST
46 1942 2A 4D 45 DB '*MENU F* 1. AUTO CR', (C'+80H)
1945 4E 55 20
1948 46 2A 20
194B 20 20 31
194E 2E 20 41
1951 55 54 4F
1954 20 43 52
1957 A0
47
48 1958 A2 2C MOV C, AUTO CR
49 195A 71 BF ACALL XLONOFF ; Auto CR on/off
50

```



```

1 195C 71 9D ACALL XST
2 195E 20 20 20 DB ' 2. AUTO LF', (''+80H)
   1961 32 2E 20
   1964 41 55 54
   1967 4F 20 4C
   196A 46 A0
3
4 196C A2 2D MOV C, AUTOLF
5 196E 71 BF ACALL XLONOFF ; Auto LF on/off
6
7 1970 71 9D ACALL XST
8 1972 20 20 20 DB ' 3. CURSOR', (''+80H)
   1975 33 2E 20
   1978 43 55 52
   197B 53 4F 52
   197E A0
9
10 197F 20 38 0B JB CRNBK, L7C1
11 1982 90 19B7 MOV DPTR, #LN7D1 ; Blink block
12 1985 30 32 0E JNB CRUL, L7C2
13 1988 90 19C0 MOV DPTR, #LN7D2 ; Blink underline
14 198B 80 09 SJMP L7C2
15 198D 90 19C9 MOV DPTR, #LN7D3 ; Block steady
16 1990 30 32 03 JNB CRUL, L7C2
17 1993 90 19D2 MOV DPTR, #LN7D4 ; Underline steady
18 1996 71 A8 ACALL XSTAT ; Cursor message
19
20 1998 71 9D ACALL XST
21 199A 20 20 20 DB ' 4. FREQ', (''+80H)
   199D 34 2E 20
   19A0 46 52 45
   19A3 51 A0
22
23 19A5 90 19DB MOV DPTR, #LN7F1 ; 50 Hz
24 19A8 30 39 03 JNB FREQ, L7D
25 19AB 90 19DC MOV DPTR, #LN7F2 ; 60 Hz
26 19AE 71 A8 ACALL XSTAT
27
28 19B0 71 9D ACALL XST
29 19B2 30 20 48 DB ' 0 Hz', (''+80H)
   19B5 FA
30
31 19B6 22 RET
32
33
34
35
36 ; Line #7 setup mode messages
37 ;
38
39 19B7 62 6C 6E LN7D1: DB 'blink blk', (''+80H)
   19BA 6B 20 62
   19BD 6C 63 EB
40 19C0 62 6C LN7D2: DB 'blink lin', (''+80H)
   19C3 6B 20 6C
   19C6 69 6E E5
41 19C9 62 6C 6F LN7D3: DB 'block ', (''+80H)

```

*** Z-29 COMPUTER TERMINAL FIRMWARE VERSION 1.03 ***

19CC	63	6B	20
19CF	20	20	A0


```

1          ;;          SETUP8 - setup mode line #8
2          ;
3          ;          *SETUP8* runs the terminal setup mode for simple terminal
4          ;          diagnostics.
5          ;
6          ;
7          ;          ENTRY none
8          ;
9          ;          EXIT none
10         ;
11         ;          USES all
12         ;
13         ;
14 19DD    51    8C          SETUP8:    ACALL    L8          ; Display eighth line
15 19DF    12    1407      STP8A:    CALL     SFCKB       ; Fetch character from keyboard
16 19E2    75    F0      04          MOV     B, #L8TL
17 19E5    90    1A7A      MOV     DPTR, #L8T
18 19E8    12    13E9      CALL    LOOKUP       ; Look up command
19 19EB    80    F2          Sjmp    STP8A        ; Keep on going
20
21
22         ;          Fill screen
23         ;
24 19ED    71    2C          STP8B:    ACALL    SCLRRLR   ; Setup clear line reverse
25 19EF    E4          CLR     A            ; Position
26
27 19F0    71    9D          ACALL    XST
28 19F2    50    72      65          DB     'Press RETURN to exit', ('t'+80H)
29 19F5    73    73      20
30 19F8    52    45      54
31 19FB    55    52      4E
32 19FE    20    74      6F
33 1A01    20    65      78
34 1A04    69    F4
35
36 1A06    74    45          MOV     A, #'E'      ; Display 'E' first time
37 1A08    90    5000      STP8B1:  MOV     DPTR, #CHARMEM ; Point to character memory
38 1A0B    71    21          ACALL    SFILL       ; Fill screen with char
39
40 1A0D    12    1407      CALL    SFCKB       ; Fetch character from keyboard
41 1A10    75    F0      04          MOV     B, #L8TL2
42 1A13    90    1A80      MOV     DPTR, #L8T2
43 1A16    12    013A      CALL    STAB        ; Search the table
44 1A19    40    ED          JC     STP8B1       ; IF not found THEN display it
45 1A1B    E4          CLR     A
46 1A1C    73          JMP     @A+DPTR      ; Jump to routine
47
48 1A1D    74    20          STP8B3:  MOV     A, #' '      ; Change funny space to real
49 1A1F    80    E7          Sjmp    STP8B1     ; Fill screen
50
51
52         ;          Change attribute
53         ;
54 1A21    E5    21          STP8C:    MOV     A, ATTRIBUTES ; Get current attributes
55 1A23    04          INC     A            ; Bump to next attribute
56 1A24    54    0F          ANL    A, #00001111B ; Mask just attributes
57 1A26    53    21      F0          ANL    ATTRIBUTES, #11110000B ; Get attributes ready

```

```

1 1A29 42 21 ORL ATTRIBUTES,A ; Move new attributes in
2 1A2B 90 4000 MOV DPTR, #ATTRIBMEM ; Point to attribute memory
3 1A2E 71 21 ACALL SFILL ; Fill memory with attribute
4 1A30 80 AB SJMP SETUP8
5
6
7 ; Toggle character set
8 ;
9 1A32 B2 3D STP8D: CPL ACHR2 ; Toggle character set
10 1A34 A2 3D MOV C, ACHR2
11 1A36 92 0C MOV ALCHARA, C ; Place into attribute
12 1A38 80 A3 SJMP SETUP8
13
14
15 ; Continuous test
16 ;
17 1A3A 75 40 00 STP8E: MOV ERRORS, #0 ; REPEAT start with no errors
18 1A3D D1 D9 ACALL ROMCHK ; check ROM
19 1A3F D1 F1 ACALL RAMCHK ; check RAM
20 1A41 12 0BAC STP8E0: CALL CLRS ; clear screen
21 1A44 71 2C ACALL SCLRRLR ; setup clear line reverse
22 1A46 E4 CLR A ; position
23
24 1A47 71 9D ACALL XST
25 1A49 43 6F 6E DB 'Continuous tes', (t'+80H)
 1A4C 74 69 6E
 1A4F 75 6F 75
 1A52 73 20 74
 1A55 65 73 F4
26
27 1A58 12 02B6 CALL FCKB ; Get any char from keyboard
28 1A5B 50 80 JNC SETUP8 ; IF any char THEN exit
29 1A5D 12 066B CALL RING ; Ring bell
30
31 1A60 E4 CLR A
32 1A61 90 5000 STP8E1: MOV DPTR, #CHARMEM ; REPEAT point to char memory
33 1A64 71 21 ACALL SFILL ; fill with char
34 1A66 12 02E8 CALL LKB ; look at keyboard
35 1A69 50 D6 JNC STP8E0 ; IF any char THEN exit
36 1A6B 04 INC A ; bump to next char
37 1A6C 70 F3 JNZ STP8E1 ; UNTIL all combinations
38 1A6E E5 40 MOV A, ERRORS
39 1A70 60 C8 JZ STP8E ; UNTIL errors
40 1A72 E1 2C AJMP ERROR ; Jump to error routine
41
42
43
44
45 ;: L8T - line #8 table
46 ;
47 ; *L8T* contains the jump table for line #8 in setup mode.
48
49 1A74 L8T EQU $
50
51 1A74 31 DB '1'
52 1A75 1A32 DW STP8D ; Toggle character set
53

```

*** Z-29 COMPUTER TERMINAL FIRMWARE VERSION 1.03 ***

```

1 1A77 32 DB '2'
2 1A78 19ED DW STP8B ; Fill screen
3
4 1A7A 33 DB '3'
5 1A7B 1A21 DW STP8C ; Change attributes
6
7 1A7D 34 DB '4'
8 1A7E 1A3A DW STP8E ; Continuous test
9 0004 L8TL EQU ($-L8T)/3 ; Table length
10
11
12
13
14 ;: L8T2 - line #8 table 2
15 ;
16 ; *L8T2* contains the jump table for line #8 in fill screen
17 ; option.
18
19 1A80 L8T2 EQU $
20
21 1A80 8C DB KB_SPACE
22 1A81 1A1D DW STP8B3 ; Access code (ignore)
23
24
25 1A83 0D DB CR
26 1A84 19DD DW SETUP8 ; Carriage return
27
28 1A86 88 DB KB_SETUP
29 1A87 1AF6 DW SETUPRET ; Exit setup mode
30
31 1A89 C8 DB KB_SETUP + KB_SHFT
32 1A8A 1B02 DW SETUPSAVE ; Exit setup mode and save
33
34 0004 L8TL2 EQU ($-L8T2)/3 ; Table length
35
36
37
38
39 ;: L8 - line #8
40 ;
41 ; *L8* displays setup information for line #8.
42 ;
43 ;
44 ; ENTRY none
45 ;
46 ; EXIT none
47 ;
48 ; USES all
49 ;
50
51 1A8C E4 L8: CLR A ; Position
52
53 1A8D 71 9D ACALL XST
54 1A8F 2A 4D 45 DB '*MENU G* 1. CHAR SET', (''+80H)
1A92 4E 55 20
1A95 47 2A 20
1A98 20 20 20

```

1A9B	31	2E	20
1A9E	43	48	41
1AA1	52	20	53
1AA4	45	54	A0

```

1
2 1AA7 90 1AE4 MOV DPTR, #LN8B1 ; Primary
3 1AAA 30 3D 03 JNB ACHR2, L8A
4 1AAD 90 1AED MOV DPTR, #LN8B2 ; Auxiliary
5 1AB0 71 A8 L8A: ACALL XSTAT ; Character set
6
7 1AB2 71 9D ACALL XST
8 1AB4 20 20 20 DB 2. FILL SCREEN 3. ATTRIBUTES
1AB7 20 32 2E
1ABA 20 46 49
1ABD 4C 4C 20
1AC0 53 43 52
1AC3 45 45 4E
1AC6 20 20 20
1AC9 20 33 2E
1ACC 20 41 54
1ACF 54 52 49
1AD2 42 55 54
1AD5 45 53
9 1AD7 20 20 20 DB 4. TEST, (''+80H)
1ADA 20 34 2E
1ADD 20 54 45
1AE0 53 54 A0
10
11 1AE3 22 RET
12
13
14
15
16 ; Line #8 setup mode messages
17 ;
18
19 1AE4 6E 6F 72 LN8B1: DB 'normal ', (''+80H)
1AE7 6D 61 6C
1AEA 20 20 A0
20 1AED 61 6C 74 LN8B2: DB 'alternat', ('e'+80H)
1AF0 65 72 6E
1AF3 61 74 E5

```


*** Z-29 COMPUTER TERMINAL FIRMWARE VERSION 1.03 ***

```

1          ;:          SETUPRET - return from setup mode
2          ;
3          ;          *SETUPRET* exits setup mode without permanently saving
4          ;          any values that have changed.
5          ;
6          ;
7          ;          ENTRY   none
8          ;
9          ;          EXIT    none
10         ;
11         ;          USES   none
12         ;
13
14 1AF6    30    37    06    SETUPRET:    JNB    L250N, SRET    ; IF 25th line is on AND
15 1AF9    20    15    03                JB     L25EN, SRET    ; IF not enabled for user THEN
16 1AFC    02    1E69                    JMP    DISPSTAT     ; display stats and return
17 1AFF    E4                                SRET:    CLR    A
18 1B00    80    2C                        SJMP   SCLRL         ; ELSE clear line and return

```

*** Z-29 COMPUTER TERMINAL FIRMWARE VERSION 1.03 ***

```

1          ;;          SETUPSAVE - save setup configuration
2          ;
3          ;          *SETUPSAVE* returns all values back to the EAROM.
4          ;
5          ;
6          ;          ENTRY   none
7          ;
8          ;          EXIT    none
9          ;
10         ;          USES    all
11
12
13 1B02    F1      22          SETUPSAVE:  ACALL  NVRCHK          ; Checksum the NVRAM
14 1B04    F5      34          MOV     NVRSUM, A          ; Update checksum value
15
16 1B06    78      25          MOV     PTR1, #25H          ; EAROM store
17 1B08    90      7000       MOV     DPTR, #EAROM
18 1B0B    7A      10          MOV     INDX1, #16         ; 16 bytes
19
20 1B0D    E6          SAV2:    MOV     A, @PTR1          ; REPEAT
21 1B0E    C4          SWAP    A
22 1B0F    F0          MOVX   @DPTR, A          ; store upper nibble
23 1B10    A3          INC     DPTR
24 1B11    C4          SWAP    A
25 1B12    F0          MOVX   @DPTR, A          ; store lower nibble
26 1B13    A3          INC     DPTR
27 1B14    08          INC     PTR1          ; bump pointers
28 1B15    DA      F6      DJNZ   INDX1, SAV2      ; UNTIL done
29
30 1B17    C2      00          CLR     EAROMSAVE
31 1B19    D1      18          ACALL  WLATCH          ; Save EAROM
32 1B1B    D2      00          SETB   EAROMSAVE
33 1B1D    D1      18          ACALL  WLATCH          ; By toggling flas
34
35 1B1F    41      F6          AJMP   SETUPRET       ; Return from setup mode

```

```
.....
1          ;:          SFILL - screen fill
2          ;
3          ;          *SFILL* fills the complete screen with the data given it
4          ;          into the memory location given it. It does not touch the
5          ;          25th line however.
6          ;
7          ;
8          ;          ENTRY (A) = character to write
9          ;          (DPTR) = memory location to start at
10         ;
11         ;          EXIT none
12         ;
13         ;          USES DPTR, INDX1/2
14
15
16 1B21    7A    18          SFILL:    MOV     INDX1, #MAXLINE    ; Go through all lines
17 1B23    7B    50          SFIL1:    MOV     INDX2, #NUMCHARS    ; REPEAT
18 1B25    F0          SFIL2:    MOVX   @DPTR, A          ; REPEAT write character
19 1B26    A3          ;          INC     DPTR          ; bump pointer
20 1B27    DB    FC          ;          DJNZ   INDX2, SFIL2    ; UNTIL line is done
21 1B29    DA    F8          ;          DJNZ   INDX1, SFIL1    ; UNTIL screen is done
22 1B2B    22          ;          RET
```

```

1          ;
2          ; SCLRLR - setup clear line reverse video
3          ; SCLRL - setup clear line
4          ;
5          ;
6          ; *SCLRLR* clears 25th line with reverse video spaces.
7          ;
8          ; *SCLRL* clears 25th line and places the attributes passed
9          ; to in on that line.
10         ;
11         ; ENTRY (A) = lower four bits used for attributes
12         ;
13         ; EXIT (A) = unchanged
14         ;
15         ; USES all
16         ;
17 1B2C    74    01          SCLRLR:    MOV    A, #00000001B    ; Set for reverse video
18         ;
19 1B2E    C0    E0          SCLRL:     PUSH   ACC            ; Save attributes
20 1B30    75    F0    18    MOV    B, #MAXLINE    ; Clear line before display
21 1B33    12    0B96      CALL   CLRLINE
22 1B36    D0    E0          POP     ACC            ; Restore attributes
23         ;
24 1B38    90    5780      MOV    DPTR, #L25MEM
25 1B3B    53    83    EF    ANL    DPH, #ATRANL    ; Point to attribute memory
26 1B3E    7A    50          MOV    INDX1, #NUMCHARS
27 1B40    F0          SLP:    MOVX   @DPTR, A        ; REPEAT write attribute
28 1B41    A3          INC    DPTR          ; bump RAM pointer
29 1B42    DA    FC          DJNZ  INDX1, SLP     ; UNTIL done
30 1B44    22          RET

```

```

1          ; GETNUM = set number string
2          ;
3          ;
4          ; *GETNUM* sets a number from 0..255 from the keyboard. The
5          ; keys "RETURN" finishes the number and "BACKSPACE" or
6          ; "DELETE" clears the complete number entered. The fourth
7          ; character received automatically makes the routine return.
8          ;
9          ;
10         ; ENTRY (A) = position on 25th line to start
11         ;
12         ; EXIT (A) = number received (0..255)
13         ; (WORK2) = number of characters picked up
14         ;
15         ;
16         ;
17 1B45 FE          GETNUM: MOV WORK1, A          ; Original position
18
19 1B46 7F 00      GNUM0: MOV WORK2, #0         ; Position count
20 1B48 7C 00      MOV WORK, #0                ; Running total
21
22         ;
23         ; Get character
24 1B4A 12 1407   GNUM1: CALL SFCKB           ; Get next character
25
26         ;
27         ; Check for end of line
28 1B4D B4 0D 02   CJNE A, #CR, GNUM2         ; IF carriage return THEN
29 1B50 EC          MOV A, WORK              ; set number and return
30 1B51 22          RET
31
32         ;
33         ; Check for backspace or delete
34 1B52 B4 08 02   GNUM2: CJNE A, #BS, GNUM2A  ; IF backspace OR
35 1B55 80 03      SJMP GNUM2B
36 1B57 B4 7F 0F   GNUM2A: CJNE A, #RUBOUT, GNUM4 ; IF delete THEN
37
38         ;
39         ; Clear current number
40 1B5A EF          GNUM2B: MOV A, WORK2
41 1B5B 60 ED      JZ GNUM1                  ; IF no chars THEN skip it
42 1B5D 1E          GNUM2L: DEC WORK1        ; REPEAT decrement position
43 1B5E DF FD      DJNZ WORK2, GNUM2L        ; UNTIL count = 0
44
45 1B60 EE          MOV A, WORK1              ; set position
46 1B61 71 9D      ACALL XST                 ; wipe out old number
47 1B63 20 20 20   DB ' ', (' '+80H)
48 1B65 A0
49 1B67 80 DD      SJMP GNUM0                ; start over again
50
51         ;
52         ; Check number and position
53 1B69 BF 03 02   GNUM4: CJNE WORK2, #3, GNUM4A ; IF all chars THEN
54 1B6C 80 E2      SJMP GNUMR                ; exit
55 1B6E B4 3A 00   GNUM4A: CJNE A, #'9'+1, GNUM4B
56 1B71 50 D7      GNUM4B: JNC GNUM1         ; Check upper bounds

```

```

1 1B73 B4 30 00 CJNE A, #'0', GNUM4C
2 1B76 40 D2 GNUM4C: JC GNUM1 ; Check lower bounds
3
4 ; Calculate next number and display
5 ;
6 1B78 94 30 SUBB A, #'0' ; Subtract ASCII offset
7 1B7A C0 E0 PUSH ACC ; Save it
8 1B7C CC XCH A, WORK
9 1B7D 75 F0 0A MOV B, #10
10 1B80 A4 MUL AB ; num := num * 10
11 1B81 2C ADD A, WORK
12 1B82 FC MOV WORK, A ; num := num + work
13 1B83 D0 E0 POP ACC ; Restore number
14 1B85 90 1B93 MOV DPTR, #GNUMS
15 1B88 25 82 ADD A, DPL
16 1B8A F5 82 MOV DPL, A ; Bump address (caution)
17 1B8C EE MOV A, WORK1 ; Get position
18 1B8D 71 A8 ACALL XSTAT ; Display
19 1B8F 0E INC WORK1 ; Bump position
20 1B90 0F INC WORK2 ; Bump count
21 1B91 80 B7 SJMP GNUM1 ; UNTIL done
22
23 ; Must not cross any page boundaries
24 ;
25 1B93 B0 B1 B2 GNUMS: DB ('0'+80H), ('1'+80H), ('2'+80H), ('3'+80H), ('4'+80H)
1B96 B3 B4
26 1B98 B5 B6 B7 DB ('5'+80H), ('6'+80H), ('7'+80H), ('8'+80H), ('9'+80H)
1B9B B8 B9
27
28 IFC NE, HIGH($)-HIGH(GNUMS)
29 ERROR ;'GNUMS' crosses a page boundary
30 ENDC

```

```
1          ;:          XST - transmit string to 25th status line
2          ;
3          ;          *XST* places a string of displayable characters that
4          ;          follow the CALL onto the 25th status line of the screen.
5          ;
6          ;
7          ;          ENTRY (A) = position on 25th line
8          ;          String to be sent must immediately follow the call
9          ;          to this routine. Final character must have bit
10         ;          seven set.
11         ;
12         ;          EXIT (A) = next position on 25th line
13         ;
14         ;          USES A, DPTR, PTR1
15         ;
16         ;
17 1B9D    DO    83          XST:    POP    DPH          ; Get return address
18 1B9F    DO    82          POP    DPL
19
20 1BA1    71    A8          ACALL  XSTAT          ; Output string
21
22 1BA3    C0    82          PUSH   DPL          ; Place return address
23 1BA5    C0    83          PUSH   DPH          ; back onto the stack
24 1BA7    22          RET
```

```

1          ;:          XSTAT - transmit string to 25th status line
2          ;
3          ;
4          ;          *XSTAT* places a string of displayable characters onto
5          ;          the 25th status line of the screen.
6          ;
7          ;
8          ;          ENTRY  (A) = position on 25th line
9          ;          (DPTR) = address of string, final character must have
10         ;          bit seven set.
11         ;
12         ;          EXIT  (A) = next position on 25th line
13         ;          (DPTR) = position following string
14         ;
15         ;          USES  A, DPTR, PTR1
16
17 1BA8    75    A0    57    XSTAT:    MOV    P2, #HIGH (L25MEM)    ; Set address of memory
18 1BAB    24    80                    ADD    A, #LOW (L25MEM)     ; Add in offset to low byte
19 1BAD    F8                    MOV    PTR1, A              ; Point to memory
20
21 1BAE    E4                    XSTL:    CLR    A
22 1BAF    93                    MOV    A, @A+DPTR         ; Get data byte
23 1BB0    A3                    INC    DPTR              ; Bump ROM pointer
24 1BB1    20    E7    04        JB    ACC.7, XSTR        ; IF bit set THEN exit out
25 1BB4    F2                    MOVX  @PTR1, A           ; Output data
26 1BB5    08                    INC    PTR1             ; Bump RAM pointer
27 1BB6    80    F6                    SJMP  XSTL              ; Go forever
28
29 1BB8    54    7F    XSTR:    ANL    A, #7FH           ; Mask off high bit
30 1BBA    F2                    MOVX  @PTR1, A         ; Output last data
31 1BBB    E8                    MOV    A, PTR1         ; Get pointer
32 1BBC    24    81                    ADD    A, #-LOW (L25MEM) + 1 ; Subtract offset
33 1BBE    22                    RET

```



```

1 ..... ;: XLONOFF - transmit string "ON" or "OFF" to 25th status line.
2 ..... ;
3 ..... ; *XLONOFF* displays "ON" or "OFF" as indicated by the carry
4 ..... ; flag.
5 ..... ;
6 ..... ;
7 ..... ; ENTRY (A) = position on 25th line
8 ..... ; (c) = 0 indicates "OFF" 1 indicates "ON"
9 ..... ;
10 ..... ; EXIT (A) = next position on 25th line
11 ..... ;
12 ..... ; USES A, DPTR, PTR1
13 ..... ;
14 ..... ;
15 1BBF 90 1BC9 XLONOFF: MOV DPTR, #LNOFF ; Get the "OFF" message
16 1BC2 50 03 JNC XLON1 ; IF carry set THEN
17 1BC4 90 1BCC MOV DPTR, #LNON ; set the "ON" message
18 1BC7 61 A8 XLON1: AJMP XSTAT ; Display message and return
19 ..... ;
20 ..... ;
21 ..... ;
22 ..... ;
23 1BC9 6F 66 E6 LNOFF: DB 'of', ('f'+80H)
24 1BCC 6F 6E A0 LNON: DB 'on', ('n'+80H)

```

```

1          ; ; XMTS - transmit string
2          ; ;
3          ; ;
4          ; ; *XMTS* transmits a string of characters out of the terminal
5          ; ; regardless of whether the terminal is on line or not.
6          ; ;
7          ; ; ENTRY String to be sent must immediately follow the call
8          ; ; to this routine. Final character must have bit
9          ; ; seven set.
10         ; ;
11         ; ; EXIT none
12         ; ;
13         ; ; USES A, DPTR
14         ; ;
15
16 1BCF    D0    83          XMTS:    POP    DPH          ; (DPTR) = first character
17 1BD1    D0    82          POP    DPL
18
19 1BD3    E4          XMTS1:    CLR    A
20 1BD4    93          MOV    A, @A+DPTR          ; REPEAT fetch character
21 1BD5    20    E7    06    JB    ACC.7, XMTS2          ; IF bit 7 set THEN exit
22 1BD8    12    139B    CALL   TRANSMIT          ; transmit character
23 1BDB    A3          INC    DPTR          ; bump pointer
24 1BDC    80    F5    SJMP   XMTS1          ; UNTIL forever
25
26 1BDE    12    139B    XMTS2:    CALL   TRANSMIT          ; Transmit last character
27 1BE1    74    01    MOV    A, #1
28 1BE3    73    JMP    @A+DPTR          ; Return to code after string

```

```

1          ; ; XMTC - transmit character
2          ;
3          ; *XMTC* transmits one character at the current cursor position
4          ; including the appropriate escape sequences for entering and
5          ; exiting the graphics and attribute modes for the mode the
6          ; terminal is in. If the character is protected then no
7          ; action is taken.
8          ;
9          ;
10         ; ENTRY (A) = current transmit mode
11         ; XPOS and YPOS point to screen coordinate
12         ;
13         ; EXIT (A) = current transmit mode (updated)
14         ;
15         ; USES all
16         ;
17
18 1BE4 C0 21 XMTC: PUSH ATTRIBUTES ; Save attribute byte
19 1BE6 C0 E0 PUSH ACC ; Save current attributes
20
21 1BE8 30 25 0A JNB GATM, XLO ; IF not GATM THEN
22 1BEB 12 0188 CALL CPF ; check for protected
23 1BEE 50 05 JNC XLO ; IF protected THEN
24 1BF0 D0 E0 POP ACC ; restore values
25 1BF2 D0 21 POP ATTRIBUTES
26 1BF4 22 RET ; and return
27
28 1BF5 E5 11 XLO: MOV A, XPOS
29 1BF7 85 12 F0 MOV B, YPOS
30 1BFA 12 0503 CALL CLA ; Calculate line address
31
32 1BFD D0 F0 POP B ; Get current attributes
33
34 1BFF 53 83 EF ANL DPH, #ATRANL ; Mask to attribute memory
35 1C02 E0 MOVX A, @DPTR
36 1C03 F5 21 MOV ATTRIBUTES, A ; Get current attributes
37 1C05 43 83 10 ORL DPH, #CHRORL ; Mask to character memory
38 1C08 E0 MOVX A, @DPTR
39 1C09 A2 E7 MOV C, ACC.7 ; Get alt char flag
40 1C0B 92 0C MOV ALTCHARA, C ; Place in proper location
41 1C0D 54 7F ANL A, #7FH ; Mask alternate char set
42 1C0F C2 0D CLR GRPH ; Clear graphic flag
43
44 1C11 B4 20 00 CJNE A, #7Fh, XLOA
45 1C14 40 07 XLOA: JC XL1 ; IF graphic char THEN jump
46 1C16 B4 7F 0F CJNE A, #RUBOUT, XL3 ; IF displayable THEN jump
47
48 ; Character is graphic
49 ;
50 1C19 74 5E MOV A, #7Fh ; Map 7Fh to 5Eh
51 1C1B 80 09 SJMP XL2
52
53 1C1D B4 1F 04 XL1: CJNE A, #1FH, XL1A ; Special case map
54 1C20 74 5F MOV A, #7Fh
55 1C22 80 02 SJMP XL2
56 1C24 44 60 XL1A: ORL A, #01100000B ; Make graphic printable
57

```

```

1 1C26 D2 0D XL2: SETB GRPH ; Set graphic flag
2
3 ;
4 ; Save character to output
5 1C28 C0 E0 XL3: PUSH ACC
6
7 ;
8 ; See if character is graphic character
9 1C2A 20 0D 30 JB GRPH, XL4 ; IF not graphic AND
10
11 1C2D 30 F5 5D JNB B.5, XL7 ; IF previous was graphic THEN
12 1C30 C2 F5 CLR B.5 ; clear graphic flag
13
14 1C32 30 40 22 JNB ANSI, XL3C ; IF ANSI mode THEN
15 1C35 20 F4 13 JB B.4, XL3B ; IF previous not alt THEN
16 1C38 20 0C 09 JB ALTCHARA, XL3A ; IF this not alt THEN
17 1C3B 71 CF ACALL XMTS ; transmit "EXIT GRAPHIC MODE"
18 1C3D 1B 5B 31 DB ESC, '[11', ('m'+80H)
19 1C40 31 ED
20 1C42 80 49 SUMP XL7
21 1C44 71 CF XL3A: ACALL XMTS ; ELSE this is alt THEN
22 1C46 1B 28 B1 DB ESC, '('', ('1'+80H) ; transmit "ENTER ALT MODE"
23 1C49 80 2E SUMP XL4SET ; flag in alt now
24
25 1C4B 20 0C F6 XL3B: JB ALTCHARA, XL3A ; ELSE IF this not alt THEN
26 1C4E 71 CF ACALL XMTS ; transmit "ENTER NORMAL"
27 1C50 1B 28 C2 DB ESC, '(', ('B'+80H)
28 1C53 C2 F4 CLR B.4 ; flag in normal now
29 1C55 80 36 SUMP XL7
30
31 1C57 71 CF XL3C: ACALL XMTS ; ELSE transmit in ZDS mode
32 1C59 1B C7 DB ESC, ('G'+80H)
33 1C5B 80 30 SUMP XL7
34
35 1C5D 20 F5 2D XL4: JB B.5, XL7 ; IF previous not graphic THEN
36 1C60 D2 F5 SETB B.5 ; flag changes
37
38 1C62 30 40 24 JNB ANSI, XL4C ; IF ANSI mode THEN
39 1C65 20 F4 15 JB B.4, XL4B ; IF previous normal THEN
40 1C68 20 0C 09 JB ALTCHARA, XL4A ; IF not alt char THEN
41 1C6B 71 CF XL4AA: ACALL XMTS ; transmit "ENTER GRAPHIC"
42 1C6D 1B 5B 31 DB ESC, '[10', ('m'+80H)
43 1C70 30 ED
44 1C72 80 19 SUMP XL7
45 1C74 71 CF XL4A: ACALL XMTS ; ELSE
46 1C76 1B 28 B0 DB ESC, '('', ('O'+80H) ; transmit "ENTER ALT GRAPHIC"
47 1C79 D2 F4 XL4SET: SETB B.4 ; flag in alt now
48 1C7B 80 10 SUMP XL7
49
50 1C7D 20 0C F4 XL4B: JB ALTCHARA, XL4A ; ELSE this is normal THEN
51 1C80 71 CF ACALL XMTS ; transmit "ENTER NORMAL"
52 1C82 1B 28 C2 DB ESC, '(', ('B'+80H)
53 1C85 C2 F4 CLR B.4 ; flag in normal now
54 1C87 80 E2 SUMP XL4AA ; and place into graphic
55

```

*** Z-29 COMPUTER TERMINAL FIRMWARE VERSION 1.03 ***

```

1 1C89 71 CF XL4C: ACALL XMTS ; ELSE transmit in ZDS mode
2 1C8B 1B C6 DB ESC, ('F'+80H)
3
4 ; See if character is in reverse video
5 ;
6 1C8D C2 D5 XL7: CLR F0 ; Clear "CHANGE" flas
7
8 1C8F 20 08 0E JB RVVA, XL8 ; IF current not rev video AND
9 1C92 30 F0 1B JNB B.0, XL9 ; IF previous was rev video THEN
10 1C95 C2 F0 CLR B.0 ; clear rev video
11
12 1C97 20 40 14 JB ANSI, XL8A ; IF ZDS mode THEN
13 1C9A 71 CF ACALL XMTS ; output "EXIT REV VIDEO"
14 1C9C 1B F1 DB ESC, ('P'+80H)
15 1C9E 80 10 SJMP XL9
16
17 1CA0 20 F0 0D XL8: JB B.0, XL9 ; IF previous not rev video THEN
18 1CA3 D2 F0 SETB B.0 ; set rev video
19
20 1CA5 20 40 06 JB ANSI, XL8A ; IF ZDS mode THEN
21 1CA8 71 CF ACALL XMTS ; output "ENTER REV VIDEO"
22 1CAA 1B F0 DB ESC, ('P'+80H)
23 1CAC 80 02 SJMP XL9
24
25 1CAE D2 D5 XL8A: SETB F0 ; ELSE flas changes
26
27 ; See if character is underline
28 ;
29 1CB0 20 09 07 XL9: JB UNDLNA, XL10 ; IF not underline AND
30
31 1CB3 30 F1 0B JNB B.1, XL11 ; IF previous was underline THEN
32 1CB6 C2 F1 CLR B.1 ; clear underline flas
33 1CB8 80 05 SJMP XL10A ; flas changes
34
35 1CBA 20 F1 04 XL10: JB B.1, XL11 ; IF previous not underline
36 1CBD D2 F1 SETB B.1 ; flas changes
37 1CBF D2 D5 XL10A: SETB F0
38
39 ; See if character is blinking
40 ;
41 1CC1 20 0A 07 XL11: JB BLINKA, XL12 ; IF not blinking AND
42
43 1CC4 30 F2 0B JNB B.2, XL13 ; IF previous was blinking THEN
44 1CC7 C2 F2 CLR B.2 ; clear blinking flas
45 1CC9 80 05 SJMP XL12A ; flas changes
46
47 1CCB 20 F2 04 XL12: JB B.2, XL13 ; IF previous not blinking THEN
48 1CCE D2 F2 SETB B.2 ; flas changes
49 1CD0 D2 D5 XL12A: SETB F0
50
51 ; See if character is half intensity
52 ;
53 1CD2 20 0B 07 XL13: JB HALFIA, XL14 ; IF not half AND
54
55 1CD5 30 F3 0B JNB B.3, XL15 ; IF previous was half THEN
56 1CD8 C2 F3 CLR B.3 ; clear half flas
57 1CDA 80 05 SJMP XL14A ; flas changes

```

```

1
2 1CDC 20 F3 04 XL14: JB B.3, XL15 ; IF previous not half THEN
3 1CDF D2 F3 SETB B.3 ; flag changes
4 1CE1 D2 D5 XL14A: SETB F0
5
6 ;
7 ; See if character is alternate graphic
8 1CE3 20 0C 19 XL15: JB ALTCHARA, XL16 ; IF not alt AND
9
10 1CE6 30 F4 31 JNB B.4, XL17 ; IF previous was alt THEN
11 1CE9 C2 F4 CLR B.4 ; clear alt flag
12
13 1CEB 30 40 2A JNB ANSI, XL16B ; IF ANSI mode THEN
14 1CEE 71 CF ACALL XMTS ; transmit "EXIT EVERYTHING"
15 1CF0 1B 28 C2 DB ESC, (('', ('B'+80H)
16
17 1CF3 30 F5 24 JNB B.5, XL17 ; IF graphics mode THEN
18 1CF6 71 CF ACALL XMTS ; transmit "ENTER GRAPHIC MODE"
19 1CF8 1B 5B 31 DB ESC, '['10', ('m'+80H)
20 1CFB 30 ED
21 20 1CFD 80 1B SJMP XL17
22 1CFF 20 F4 18 XL16: JB B.4, XL17 ; IF previous not alt THEN
23 1D02 D2 F4 SETB B.4 ; flag changes
24
25 1D04 30 40 11 JNB ANSI, XL16B ; IF ANSI mode THEN
26 1D07 20 F5 07 JB B.5, XL16A ; IF no graphics THEN
27 1D0A 71 CF ACALL XMTS ; transmit "ENTER ALT MODE"
28 1D0C 1B 28 B1 DB ESC, (('', ('1'+80H)
29 1D0F 80 09 SJMP XL17
30
31 1D11 71 CF XL16A: ACALL XMTS ; ELSE transmit "ENTER ALT GRAPHIC"
32 1D13 1B 28 B0 DB ESC, (('', ('0'+80H)
33 1D16 80 02 SJMP XL17
34
35 1D18 D2 D5 XL16B: SETB F0
36
37 ;
38 ; Transmit any changes
39 1D1A 30 D5 46 XL17: JNB F0, XL20 ; IF no changes THEN skip
40
41 1D1D 20 40 1F JB ANSI, XL18 ; Check for mode
42
43 ;
44 ; ZDS mode changes
45 1D20 71 CF ACALL XMTS ; set attributes
46 1D22 1B F3 DB ESC, (('s'+80H)
47 1D24 C0 F0 PUSH B ; save attributes
48 1D26 E5 F0 MOV A, B ; reorder bits
49 1D28 13 RRC A ; set reverse video
50 1D29 13 RRC A ; set underline
51 1D2A 92 F3 MOV B.3, C ; put in position
52 1D2C 13 RRC A ; set blink
53 1D2D 92 F1 MOV B.1, C ; put in position
54 1D2F 13 RRC A ; set half intensity
55 1D30 92 F2 MOV B.2, C ; put in position
56 1D32 E5 F0 MOV A, B

```

```

1 1D34 54 1F ANL A, #00011111B ; mask proper bits
2 1D36 24 30 ADD A, #'0' ; add offset for sequence
3 1D38 12 139B CALL TRANSMIT ; output attribute data
4 1D3E D0 F0 POP B ; restore attributes
5 1D3D 80 24 S JMP XL20
6
7 ;
8 ; ANSI mode changes
9 1D3F 71 CF XL18: ACALL XMTS ; clear any prev attributes
10 1D41 1B 5B B0 DB ESC, '[' , ('0'+80H)
11
12 1D44 30 F3 04 JNB B.3, XL18B ; IF half intensity THEN
13 1D47 71 CF ACALL XMTS
14 1D49 3B B2 DB '[' , ('2'+80H)
15
16 1D4B 30 F1 04 XL18B: JNB B.1, XL18C ; IF underline THEN
17 1D4E 71 CF ACALL XMTS
18 1D50 3B B4 DB '[' , ('4'+80H)
19
20 1D52 30 F2 04 XL18C: JNB B.2, XL18D ; IF blinking THEN
21 1D55 71 CF ACALL XMTS
22 1D57 3B B5 DB '[' , ('5'+80H)
23
24 1D59 30 F0 04 XL18D: JNB B.0, XL18E ; IF reverse video THEN
25 1D5C 71 CF ACALL XMTS
26 1D5E 3B B7 DB '[' , ('7'+80H)
27
28 1D60 71 CF XL18E: ACALL XMTS ; output last character
29 1D62 ED DB ('m'+80H)
30
31 1D63 D0 E0 XL20: POP ACC
32 1D65 12 139B CALL TRANSMIT ; Output character
33
34 1D68 53 F0 3F ANL B, #00111111B ; Mask previous
35 1D6B E5 21 MOV A, ATTRIBUTES
36 1D6D 54 3F ANL A, #00111111B ; Mask current
37 1D6F 45 F0 ORL A, B ; Combine to make new previous
38 1D71 D0 21 POP ATTRIBUTES ; Restore true attributes
39 1D73 22 RET

```

```

1          ; XMTL - transmit line
2          ; XMTL1 - entry to transmit line
3          ;
4          ; *XMTL* transmits the entire contents of the line as defined
5          ; by transmit character *XMTC*.
6          ;
7          ; *XMTL1* needs a current transmit mode.
8          ;
9          ;
10         ; ENTRY (A) = current transmit mode (*XMTL1*)
11         ; YPOS points to screen line
12         ;
13         ; EXIT (A) = current transmit mode (updated)
14         ;
15         ; USES all
16
17
18 1D74    E4          XMTL:    CLR    A          ; Start with no attributes
19 1D75    C0          XMTL1:   PUSH   XPOS       ; Save current position
20 1D77    75          11      00    MOV    XPOS, #0    ; Start at beginning of line
21 1D7A    71          E4          XML2:   ACALL  XMTC     ; REPEAT transmit character
22 1D7C    05          11          INC    XPOS       ; bump position
23 1D7E    AC          11          MOV    WORK, XPOS
24 1D80    BC          50      F7    CJNE  WORK, #NUMCHARS, XML2 ; UNTIL done
25 1D83    D0          11          POP    XPOS       ; Restore position
26 1D85    FC          12          MOV    WORK, A    ; Save (A)
27 1D86    1C          04EA       CALL  BLINAD     ; Update address
28 1D89    EC          12          MOV    A, WORK   ; Restore (A)
29 1D8A    22          12          RET

```



```

1          ;:          SXMTC - special transmit character
2          ;
3          ;
4          ;          *SXMTC* transmits the character at the current cursor
5          ;          position as defined by transmit character *XMT*.
6          ;
7          ;          ENTRY   none
8          ;
9          ;          EXIT    none
10         ;
11         ;          USES   all
12         ;
13
14 1D8B    30    40    OF    SXMTC:    JNB    ANSI, SXC1    ; IF ANSI mode THEN
15 1D8E    12    09D1    CALL    GNP                ; set parameter
16 1D91    60    19    JZ     XMTF                ; IF zero THEN xmt page
17 1D93    14    DEC    A
18 1D94    60    12    JZ     SXMTL                ; IF one THEN xmt line
19 1D96    14    DEC    A
20 1D97    60    04    JZ     SXC1                ; IF two THEN xmt character
21 1D99    14    DEC    A
22 1D9A    60    2A    JZ     XMT25                ; IF three THEN xmt 25th line
23 1D9C    22    RET
24
25 1D9D    C0    3F    SXC1:    PUSH    PFIELD                ; Save protected fields
26 1D9F    75    3F    00    MOV    PFIELD, #0                ; Make none protected
27 1DA2    E4    CLR    A                        ; No attributes set
28 1DA3    71    E4    ACALL  XMTC                ; Transmit character
29 1DA5    D0    3F    POP    PFIELD                ; Restore protected fields
30 1DA7    22    RET

```

```
1 ; ; SXMTL - special transmit line
2 ;
3 ;
4 ; *SXMTL* transmits the entire contents of the line as defined
5 ; by transmit character *XMTC*. The end of the line is signaled
6 ; by a carriage return.
7 ;
8 ; ENTRY none
9 ;
10 ; EXIT none
11 ;
12 ; USES all
13 ;
14
15 IDAS B1 74 SXMTL: ACALL XMTL ; Transmit line
16 IDAA 80 14 SJMP XMP3 ; Send CR, bell, and return
```

*** Z-29 COMPUTER TERMINAL FIRMWARE VERSION 1.03 ***

```

1          ;:          XMTP - transmit page
2          ;
3          ;          *XMTP* transmits the entire contents of the page (excluding
4          ;          25th line) as defined by transmit character *XMTC*. The end
5          ;          of the page is signaled by a carriage return.
6          ;
7          ;
8          ;          ENTRY   none
9          ;
10         ;          EXIT    none
11        ;
12        ;          USES    all
13
14
15 1DAC    E4          XMTP:    CLR    A          ; Start with no attributes set
16 1DAD    C0          12          PUSH   YPOS          ; Save current position
17 1DAF    75          12          00          MOV    YPOS, #0
18 1DB2    B1          75          XMP1:    ACALL  XMTL1          ; REPEAT transmit line
19 1DB4    05          12          INC    YPOS          ; ... bump position
20 1DB6    AC          12          MOV    WORK, YPOS
21 1DB8    BC          18          F7          CJNE   WORK, #MAXLINE, XMP1 ; UNTIL done
22
23 1DBB    D0          12          XMP2:    POP    YPOS          ; Restore position
24 1DBD    12          04EA        CALL   BLINAD          ; Update address
25
26 1DC0    71          CF          XMP3:    ACALL  XMTS          ; Send CR to terminate page
27 1DC2    8D          DB          (CR+80H)
28
29 1DC3    02          066B        JMP    RING          ; Signal done to user

```

```
1          ;|          XMT25 - transmit 25th line
2          ;
3          ;          *XMT25* transmits the 25th line in the same manner as *XMTL*
4          ;          but only if the 25th line is enabled. The end of the line
5          ;          is signaled by a carriage return.
6          ;
7          ;
8          ;          ENTRY   none
9          ;
10         ;          EXIT   none
11        ;
12        ;          USES   all
13
14
15 1DC6    30    15    F7    XMT25:    JNB    L25EN, XMP3    ; IF 25th line enabled THEN
16 1DC7    C0    12
17 1DCB    75    12    18
18 1DCE    B1    74
19 1DD0    80    E9
          SJMP   XMP2    ; restore, update, return
```

*** Z-29 COMPUTER TERMINAL FIRMWARE VERSION 1.03 ***

```

1          ;:          PRINT - print page
2          ;
3          ;          *PRINT* acts exactly like *XMTP* (transmit page) except that
4          ;          the data goes out to the opposite port and every line ends with
5          ;          a carriage return and line feed.
6          ;
7          ;
8          ;          ENTRY   none
9          ;
10         ;          EXIT    none
11         ;
12         ;          USES   all
13         ;
14         ;
15 1DD2   D2   23          PRINT:   SETB   PRNPF          ; Flag printing
16
17 1DD4   12   13C4       LCALL   DOXOFF         ; Output an XOFF
18
19 1DD7   D1   0F          ACALL   CMPORT          ; Toggle port
20
21 1DD9   C0   3F          PUSH   PFIELD          ; Save protected fields
22 1DDB   75   3F   00     MOV    PFIELD, #0      ; Make all unprotected
23
24 1DDE   E4          CLR    A          ; Start with no attributes set
25 1DDF   C0   12          PUSH  YPOS          ; Save current position
26 1DE1   75   12   00     MOV    YPOS, #0
27
28 1DE4   B1   75          PRNT1:   ACALL  XMTL1          ; REPEAT transmit line
29 1DE6   C0   E0          PUSH  ACC          ; save attributes
30 1DE8   71   CF          ACALL XMTS          ; transmit CR and LF
31 1DEA   0D   8A          DB    CR, (LF+80H)
32 1DEC   D0   E0          POP   ACC          ; restore attributes
33
34 1DEE   05   12          INC   YPOS          ; bump position
35 1DF0   AC   12          MOV   WORK, YPOS
36 1DF2   BC   18   EF     CJNE  WORK, #MAXLINE, PRNT1 ; UNTIL done
37
38 1DF5   D0   12          POP   YPOS          ; Restore position
39 1DF7   12   04EA       LCALL BLINAD        ; Update address
40
41 1DFA   D0   3F          POP   PFIELD        ; Restore protected fields
42
43 1DFC   D1   0F          ACALL CMPORT        ; Toggle port again
44
45 1DFE   20   22   03     JB    HSSTOPF, PRNT2 ; IF not hold screen THEN
46 1E01   12   13D5       LCALL DOXON         ; output an -XON-
47
48 1E04   C2   23          PRNT2:   CLR    PRNPF        ; Flag done printing
49
50 1E08   12   02E8       LCALL LKB           ; Look at keyboard
51 1E09   50   03          JNC   PRNT3         ; IF no keyboard data THEN
52
53 1E0B   02   066B       LJMPL RING          ; signal done to user
54 1E0E   22          PRNT3:   RET

```

```
1      ; ;          CMPORT - complement port
2      ;
3      ;          *CMPORT* toggles direction of the I/O port.
4      ;
5      ;
6      ;          ENTRY   none
7      ;
8      ;          EXIT    none
9      ;
10     ;          USES   A, DPTR
11     ;
12     ;
13 1E0F    30    13    FD    CMPORT:    JNB    OKTRANS, CMPORT    ; Wait until transmitter empty
14 1E12    B2    02    FD    CMPORT:    CPL    PORTF          ; Toggle port flag
15 1E14    B2    3C    FD    CMPORT:    CPL    PRTF2         ; Toggle EAROM flag
16 1E16    C2    16    FD    CMPORT:    CLR    XOFFRCVED      ; Clear any received -XOFF-
17     ;
18     ;          SJMP   WLATCH          ; Write and return
19     ;
20     ;
21     ;
22     ;
23     ; ;          WLATCH - write latch
24     ;
25     ;          -WLATCH- writes the current value of the byte *XLATCH* out
26     ;          to the memory mapped latch.
27     ;
28     ;
29     ;          ENTRY   none
30     ;
31     ;          EXIT    none
32     ;
33     ;          USES   A, DPTR
34     ;
35     ;
36 1E18    E5    20    WLATCH:    MOV    A, XLATCH        ; Get byte
37 1E1A    90    3000  WLATCH:    MOV    DPTR, #MLATCH     ; Get address
38 1E1D    F0    WLATCH:    MOVX   @DPTR, A          ; Output data to latch
39 1E1E    22    WLATCH:    RET
```

```

1          ; DCLK - Display clock
2          ;
3          ; DCLKO - always display clock
4          ;
5          ; *DCLK* displays the current settings of the clock on the 25th
6          ; line once every second only.
7          ;
8          ; *DCLKO* always displays the current settings of the clock on
9          ; the 25th line.
10         ;
11         ;
12         ;
13         ; ENTRY none
14         ;
15         ; EXIT none
16         ;
17         ; USES A, B, DPTR
18         ;
19         ;
20 1E1F    E5    3E          DCLK:    MOV    A, DISPSEC
21 1E21    B5    3B    01    CJNE   A, TSEC, DCLKO    ; IF no change in seconds THEN
22 1E24    22          RET          ; exit
23
24 1E25    85    3B    3E    DCLKO:   MOV    DISPSEC, TSEC    ; Init *DISPSEC*
25 1E28    E5    3D          MOV    A, THOUR
26 1E2A    12    0A92      CALL   CBA              ; Convert hours to ASCII
27 1E2D    C0    82          PUSH   DPL              ; Save ones digit
28 1E2F    E5    83          MOV    A, DPH          ; Get tens digit
29 1E31    B4    30    02    CJNE   A, #'0', DCLK1    ; IF tens digit = '0' THEN
30 1E34    74    20          MOV    A, #'/'        ; suppress leading digit
31 1E36    90    57C8      DCLK1:  MOV    DPTR, #L25MEM+72
32 1E39    F0          MOVX  @DPTR, A          ; Place on screen
33 1E3A    D0    E0          POP    ACC
34 1E3C    A3          INC    DPTR
35 1E3D    F0          MOVX  @DPTR, A          ; Place on screen
36 1E3E    74    3A          MOV    A, #'/'
37 1E40    A3          INC    DPTR
38 1E41    F0          MOVX  @DPTR, A          ; Place ':' on screen
39 1E42    E5    3C          MOV    A, TMIN
40 1E44    12    0A92      CALL   CBA              ; Convert minutes to ASCII
41 1E47    C0    82          PUSH   DPL              ; Save ones digit
42 1E49    E5    83          MOV    A, DPH
43 1E4B    90    57CB      MOV    DPTR, #L25MEM+75
44 1E4E    F0          MOVX  @DPTR, A          ; Place tens digit on screen
45 1E4F    D0    E0          POP    ACC
46 1E51    A3          INC    DPTR
47 1E52    F0          MOVX  @DPTR, A          ; Place ones digit on screen
48 1E53    74    3A          MOV    A, #'/'
49 1E55    A3          INC    DPTR
50 1E56    F0          MOVX  @DPTR, A          ; Place ':' on screen
51 1E57    E5    3B          MOV    A, TSEC
52 1E59    12    0A92      CALL   CBA              ; Convert seconds to ASCII
53 1E5C    C0    82          PUSH   DPL              ; Save ones digit
54 1E5E    E5    83          MOV    A, DPH
55 1E60    90    57CE      MOV    DPTR, #L25MEM+78
56 1E63    F0          MOVX  @DPTR, A          ; Place tens digit on screen
57 1E64    D0    E0          POP    ACC

```

```
1 1E66 A3 INC DPTR
2 1E67 F0 MOVX @DPTR, A ; Place ones digit on screen
3 1E68 22 RET
```



```

1          ;:          DISPSTAT - display status line
2          ;
3          ;          *DISPSTAT* displays everything that can be displayed onto
4          ;          the 25th line if the option is enabled. This includes
5          ;          clock, caps locked, on/off line indicators, and insert
6          ;          character mode.
7          ;
8          ;
9          ;          ENTRY   none
10         ;
11         ;          EXIT   none
12         ;
13         ;          USES   all
14         ;
15
16 1E69    30    37    03    DISPSTAT:    JNB    L25ON, DSPR    ; IF line 25 off OR
17 1E6C    30    15    01          JNB    L25EN, DSPO    ; IF line 25 enabled THEN
18 1E6F    22          DSPR:    RET          ; return
19
20 1E70    74    08          DSP0:    MOV    A, #00001000B
21 1E72    71    2E          ACALL   SCLRL    ; Clear with half intensity
22
23 1E74    D1    25          ACALL   DCLK0    ; Display clock
24
25 1E76    E4          CLR    A
26 1E77    90    1E94        MOV    DPTR, #MSGCL    ; Caps locked
27 1E7A    30    35    02          JNB    CAPLOCKF, DSP1
28 1E7D    71    A8          ACALL   XSTAT
29
30 1E7F    74    10          DSP1:    MOV    A, #16
31 1E81    90    1EA5        MOV    DPTR, #MSGOL    ; Offline
32 1E84    20    2E    02          JB     ONLINE, DSP2
33 1E87    71    A8          ACALL   XSTAT
34
35 1E89    74    1D          DSP2:    MOV    A, #29
36 1E8B    90    1EB3        MOV    DPTR, #MSGIC    ; Insert character
37 1E8E    30    21    02          JNB    ICMODEF, DSP3
38 1E91    71    A8          ACALL   XSTAT    ; Output
39
40 1E93    22          DSP3:    RET

```

```
1 ; Caps locked message
2 ;
3 1E94 00 20 20 MSGCL: DB 00H, ' CAPS LOCKED ', (00H+80H)
  1E97 43 41 50
  1E9A 53 20 4C
  1E9D 4F 43 4B
  1EA0 45 44 20
  1EA3 20 80
```

```
4
5 ; Off line message
6 ;
7
8 1EA5 00 20 20 MSGOL: DB 00H, ' OFF LINE ', (00H+80H)
  1EA8 4F 46 46
  1EAB 20 4C 49
  1EAE 4E 45 20
  1EB1 20 80
```

```
9
10 ; Insert character message
11 ;
12
13 1EB3 00 20 20 MSGIC: DB 00H, ' INSERT MODE ', (00H+80H)
  1EB6 49 4E 53
  1EB9 45 52 54
  1EBC 20 4D 4F
  1EBF 44 45 20
  1EC2 20 80
```

```

1          ;: KBCHK - keyboard check
2          ;
3          ;
4          ; *KBCHK* waits for the keyboard to send -KB_POWER- within
5          ; 75 ms. If it is not found then an error condition exists.
6          ; This routine must only be done after a hardware reset so that
7          ; it is known that the keyboard is going to send the data.
8          ;
9          ; ENTRY none
10         ;
11         ; EXIT none
12         ;
13         ; USES all
14         ;
15
16 1EC4 7A 0D KBCHK: MOV INDX1, #13
17 1EC6 7B 00 KBC0: MOV INDX2, #0 ; REPEAT init count
18 1EC8 12 02B6 KBC1: CALL FCKB ; REPEAT set any data
19 1ECB 40 04 JC KBC2 ; IF data AND
20 1ECD B4 8F F8 CJNE A, #KB_POWER, KBC1 ; IF power up THEN
21 1ED0 22 RET ; return
22 1ED1 DB F5 KBC2: DJNZ INDX2, KBC1 ; UNTIL done
23 1ED3 DA F1 DJNZ INDX1, KBC0 ; UNTIL all done
24
25 1ED5 43 40 08 ORL ERRORS, #00001000B ; ELSE error #3
26 1ED8 22 RET
    
```

```

1          ;;          ROMCHK - ROM checksum
2          ;
3          ;          -ROMCHK- does a checksum on the ROM and compares it with
4          ;          the known value in ROM.
5          ;
6          ;
7          ;          ENTRY   none
8          ;
9          ;          EXIT    none
10         ;
11         ;          USES    all
12         ;
13
14 1ED9    7C    00          ROMCHK:    MOV    WORK, #0          ; Init checksum
15 1EDB    90    0000      MOV    DPTR, #0         ; Init pointer
16 1EDE    7A    20          MOV    INDX1, #20H      ; First index
17 1EE0    7B    00          MOV    INDX2, #00H     ; Init count
18
19 1EE2    E4          RMC1:    CLR    A                ; REPEAT
20 1EE3    93          MOV    A, @A+DPTR      ; set ROM byte
21 1EE4    2C          ADD    A, WORK        ; add to previous amount
22 1EE5    FC          MOV    WORK, A        ; replace
23 1EE6    A3          INC    DPTR           ; bump pointer
24 1EE7    DB    F9      DJNZ  INDX2, RMC1     ; UNTIL done
25 1EE9    DA    F7      DJNZ  INDX1, RMC1     ; UNTIL all done
26
27 1EEB    60    03      JZ    RMC2            ; IF error THEN
28 1EED    43    40    01  ORL    ERRORS, #00000001B ; error #0
29 1EF0    22          RMC2:    RET

```

```

1          ;: RAMCHK - RAM check
2          ;
3          ;
4          ; -RAMCHK- checks the RAM for any failures. It writes two
5          ; different values into character and attribute RAM and reads
6          ; them back. Any errors are flagged.
7          ;
8          ; ENTRY none
9          ;
10         ; EXIT none
11        ;
12        ; USES a'i
13
14
15 1EF1 90 5000 RAMCHK: MOV DPTR, #CHARMEM ; Point to character RAM
16 1EF4 7C 55 MOV WORK, #01010101B ; First pattern
17
18 1EF6 7A 08 RAM0: MOV INDX1, #08H ; First index
19 1EF8 7B 00 MOV INDX2, #00H ; Second index
20
21 1EFA EC RAM1: MOV A, WORK ; REPEAT
22 1EFB F0 MOVX @DPTR, A ; write pattern
23 1EFC 53 83 EF ANL DPH, #ATRANL ; move to attribute RAM
24 1EFF F0 MOVX @DPTR, A ; write pattern
25 1F00 E0 MOVX A, @DPTR ; read pattern
26 1F01 54 0F ANL A, #0FH ; mask
27 1F03 FD MOV TEMP, A ; save
28 1F04 EC MOV A, WORK ; set original pattern
29 1F05 54 0F ANL A, #0FH ; mask it also
30 1F07 B5 05 14 CJNE A, TEMP, RAMERR ; IF error THEN exit
31 1F0A 43 83 10 ORL DPH, #CHRORL ; move to character RAM again
32 1F0D E0 MOVX A, @DPTR ; read pattern
33 1F0E B5 04 0D CJNE A, WORK, RAMERR ; IF error THEN exit
34 1F11 A3 INC DPTR ; bump pointer
35 1F12 DB E6 DJNZ INDX2, RAM1 ; UNTIL done
36 1F14 DA E4 DJNZ INDX1, RAM1 ; UNTIL all done
37
38 1F16 BC 55 04 CJNE WORK, #01010101B, RAM2 ; IF pattern is original THEN
39 1F19 7C AA MOV WORK, #10101010B ; change to second pattern
40 1F1B 80 D9 SJMP RAM0 ; and do it again
41
42 1F1D 22 RAM2: RET ; IF no error THEN return
43
44 1F1E 43 40 02 RAMERR: ORL ERRORS, #00000010B ; ELSE flag error #1 and return
45 1F21 22 RET

```

```
1          ;|          NVRCHK - non-volatile RAM checksum
2          ;|
3          ;|          *NVRCHK* does a checksum on the NVRAM and returns the value.
4          ;|
5          ;|
6          ;|          ENTRY   none
7          ;|
8          ;|          EXIT    (A) = checksum value of NVRAM
9          ;|
10         ;|          USES   A, WORK, INDX1, PTR1
11
12
13 1F22     E4          NVRCHK:   CLR    A          ; Init for checksum
14 1F23     78      25    MOV    PTR1, #25H
15 1F25     7A      0F    MOV    INDX1, #15
16
17 1F27     26          NVR1:    ADD    A, @PTR1   ; REPEAT add next value
18 1F28     08          INC    PTR1      ; bump RAM pointer
19 1F29     DA      FC    DJNZ   INDX1, NVR1   ; UNTIL done
20 1F2B     22          RET
```

*** Z-29 COMPUTER TERMINAL FIRMWARE VERSION 1.03 ***

```

1          ; ; ERROR - diagnostic error
2          ;
3          ; -ERROR- outputs the error messages for any errors that
4          ; may have been flagged in the -ERRORS- byte. The status
5          ; line is displayed if there are no errors... A bell is
6          ; given when finished and no errors occurred.
7          ;
8          ; Format of the error byte is as follows:
9          ;
10         ; BIT      0 = ROM checksum error
11         ;          1 = RAM error
12         ;          2 = CRTIC error
13         ;          3 = Keyboard error
14         ;          4 = Non-volatile RAM checksum error
15         ;
16         ;
17         ; ENTRY   none
18         ;
19         ; EXIT    none
20         ;
21         ; USES   all
22         ;
23
24 1F2C    E5    40          ERROR:    MOV     A, ERRORS
25 1F2E    70    05          ;         JNZ     ERRO          ; IF no errors THEN
26 1F30    D1    69          ;         ACALL  DISPSTAT ; display status
27 1F32    02    066B       ;         LJMP   RING     ; ring bell and return
28
29 1F35    E4          ERROR:    CLR     A
30 1F36    71    2E          ;         ACALL  SCLRL   ; Clear line full intensity
31 1F38    D1    25          ;         ACALL  DCLKO  ; Display clock
32 1F3A    D1    0F          ;         ACALL  CMPORT ; Change ports
33
34 1F3C    85    40    F0    MOV     B, ERRORS          ; Get errors
35
36 1F3F    71    CF          ;         ACALL  XMTS   ; Output message
37 1F41    45    52    52    ERM1:    DB     'ERROR -', (''+80H)
38 1F44    4F    52    20
39 1F47    2D    A0
40
41 1F49    E4          CLR     A
42 1F4A    90    1F41       MOV     DPTR, #ERM1
43 1F4D    71    A8          ;         ACALL  XSTAT   ; Output to 25th line
44
45 1F4F    30    F0    17    ;         JNB     B.0, ERR1 ; IF ROM checksum error THEN
46 1F52    FF          ;         MOV     WORK2, A
47 1F53    71    CF          ;         ACALL  XMTS   ; output message
48 1F55    52    4F    4D    ERM2:    DB     'ROM checksum ', (''+80H)
49 1F58    20    63    68
50 1F5B    65    63    68
51 1F5E    73    75    6D
52 1F61    20    A0
53
54 1F63    EF          MOV     A, WORK2
55 1F64    90    1F55       MOV     DPTR, #ERM2
56 1F67    71    A8          ;         ACALL  XSTAT   ; output to 25th line
57
58
59
60 1F69    30    F1    14    ERM1:    JNB     B.1, ERR2          ; IF RAM error THEN

```

```

1 1F6C FF MOV WORK2, A
2 1F6D 71 CF ACALL XMTS ; output message
3 1F6F 52 41 4D ERM3: DB 'RAM fault ', (''+80H)
   1F72 20 66 61
   1F75 75 6C 74
   1F78 20 A0
4 1F7A EF MOV A, WORK2
5 1F7B 90 1F6F MOV DPTR, #ERM3
6 1F7E 71 A8 ACALL XSTAT ; output to 25th line
7
8 1F80 30 F2 15 ERR2: JNB B.2, ERR3 ; IF CRTC error THEN
9 1F83 FF MOV WORK2, A
10 1F84 71 CF ACALL XMTS ; output message
11 1F86 43 52 54 ERM4: DB 'CRTC error ', (''+80H)
   1F89 43 20 65
   1F8C 72 72 6F
   1F8F 72 20 A0
12 1F92 EF MOV A, WORK2
13 1F93 90 1F86 MOV DPTR, #ERM4
14 1F96 71 A8 ACALL XSTAT ; output to 25th line
15
16 1F98 30 F3 13 ERR3: JNB B.3, ERR4 ; IF keyboard error THEN
17 1F9B FF MOV WORK2, A
18 1F9C 71 CF ACALL XMTS ; output message
19 1F9E 4B 65 79 ERM5: DB 'Keyboard ', (''+80H)
   1FA1 62 6F 61
   1FA4 72 64 20
   1FA7 A0
20 1FA8 EF MOV A, WORK2
21 1FA9 90 1F9E MOV DPTR, #ERM5
22 1FAC 71 A8 ACALL XSTAT ; output to 25th line
23
24 1FAE 30 F4 18 ERR4: JNB B.4, ERR5 ; IF NVRAM error THEN
25 1FB1 FF MOV WORK2, A
26 1FB2 71 CF ACALL XMTS ; output message
27 1FB4 4E 56 52 ERM6: DB 'NVRAM checksum', (''+80H)
   1FB7 41 4D 20
   1FBA 63 68 65
   1FBD 63 68 73
   1FC0 75 6D A0
28 1FC3 EF MOV A, WORK2
29 1FC4 90 1FB4 MOV DPTR, #ERM6
30 1FC7 71 A8 ACALL XSTAT ; output to 25th line
31
32 1FC9 71 CF ERR5: ACALL XMTS ; Output CR, LF's
33 1FCB 0D 0A 0D DB CR, LF, CR, (LF+80H)
   1FCE 8A
34
35 1FCF C1 0F AJMP CMPORT ; Change ports back

```


*** Z-29 COMPUTER TERMINAL FIRMWARE VERSION 1.03 ***

```

1          ;:          RAMCONST - RAM constants
2          ;
3          ;          *RAMCONST* is the table with all of the RAM constants that
4          ;          the terminal will power up with.
5          ;
6 1FD1    DO          RAMCONST:    DB      LOW (IBUF)      ; ISTORE
7 1FD2    DO          DB          LOW (IBUF)      ; IFETCH
8 1FD3    00          DB          0              ; ICOUNT
9
10 1FD4    FO          DB          LOW (OBUF)      ; OSTORE
11 1FD5    FO          DB          LOW (OBUF)      ; OFETCH
12
13 1FD6    00          DB          0              ; XPOS
14 1FD7    00          DB          0              ; YPOS
15 1FD8    50          DB          HIGH (CHARMEM)   ; LINADH
16 1FD9    00          DB          LOW (CHARMEM)   ; LINADL
17
18 1FDA    00          DB          HIGH (NORM)     ; DSPADH
19 1FDB    87          DB          LOW (NORM)     ; DSPADL
20
21 1FDC    00          DB          0              ; TSCROLL
22 1FDD    18          DB          MAXLINE        ; BFIX
23
24 1FDE    00          DB          0              ; PMADRH
25 1FDF    00          DB          0              ; PMADRL
26 1FE0    00          DB          0              ; PMNUM
27 1FE1    00          DB          0              ; PMVALUE
28
29 1FE2    00          DB          0              ; KBIDNUM
30 1FE3    01          DB          1              ; HSLINE
31 1FE4    00          DB          0              ; GSET
32
33 1FE5    39          DB          00111001B      ; XLATCH      bits #1
34 1FE6    00          DB          00000000B      ; ATTRIBUTES  bits #2
35 1FE7    08          DB          00001000B      ; Bits #3
36 1FE8    0C          DB          00001100B      ; Bits #4
37 1FE9    30          DB          00110000B      ; Bits #5
38
39 1FEA    00          DB          0              ; XXPOS
40 1FEB    00          DB          0              ; XYPOS
41
42 1FEC    20          DB          32              ; BLNKRATE
43 1FED    00          DB          0              ; BLNKCOUNT
44 1FEE    00          DB          0              ; AUTOCNT
45
46 1FEF    00          DB          0              ; TCNT
47 1FF0    00          DB          0              ; TSEC
48 1FF1    00          DB          0              ; TMIN
49 1FF2    00          DB          0              ; THOUR
50
51 1FF3    FF          DB          255            ; DISPSEC
52
53 1FF4    00          DB          0              ; PFIELD

```

*** Z-29 COMPUTER TERMINAL FIRMWARE VERSION 1.03 ***

```
1          ;;          CHKS - check sum
2          ;
3          ;          -CHKS- is the checksum byte for the terminal ROM. It is
4          ;          chosen so that the total sum of all the bytes gives a value
5          ;          of zero.
6          ;
7          1FFF          ORG          1FFFH
8
9 1FFF    D6          CHKS:    DB          0D6H          ; Checksum byte
10
11          END
```

SYMBOL TABLE

AC	%00D6	01	ACA1	0A06	03	ACA2	0A08	03	ACA3	0A0A	03	ACA3A	0A12	03
ACAS	0A16	03	ACC	%00E0	00	ACCESS	001E	01	ACD	0CC1	03	ACDN	0CBB	03
ACD1	0CC0	03	ACHR2	003D	01	ACL	0C4C	03	ACLFT	0C46	03	ACLO	0C4B	03
ACPR	0AAF	03	ACF1	0ACF	03	ACP1A	0AD8	03	ACP2	0ADC	03	ACP3	0ACC	03
ACR	0C74	03	ACRT	0C6E	03	ACR1	0C73	03	ACU	0CA3	03	ACUP	0C9D	03
ACU1	0CA2	03	ADA	0EC3	03	ADAM	0ECC	03	ADM3	0042	01	ADM3ES	0A67	03
AESC1	06A1	03	ALLINI	10AF	03	ALLI1	10C1	03	ALTCHA	000C	01	ALTGRP	000F	01
ANSI	0040	01	ANSIES	0697	03	ANSIT	= 0798	03	ANSITL	= 000C	00	APBT	0CC6	03
APBT1	0CCB	03	APCA	09FA	03	APDC	0E32	03	APDC0	0E37	03	APDC1	0E38	03
APDL	0DB6	03	APDLO	0DBB	03	APDL1	0DBC	03	APIC	0DE9	03	APICO	0DEE	03
APIC1	0DEF	03	APIL	0D7D	03	APILO	0D82	03	APIL1	0D83	03	APR	0AE9	03
APRNT	0ADF	03	ARAMP	0AF6	03	ARM	085F	03	ARMT	= 0871	03	ARMTL	= 0005	00
ASBR	0AEA	03	ASBR1	0AEF	03	ASBR2	0AF2	03	ASCP	0EEF	03	ASGM	0A3B	03
ASGMT	= 0A50	03	ASGMTL	= 0007	00	ASGO	0A4E	03	ASG0	0A49	03	ASG1	0A3D	03
ASM	083D	03	ASMR	084F	03	ASMT	= 0850	03	ASMTL	= 0005	00	ASPF	0A65	03
ASPF1	0A68	03	ASPF1A	0A72	03	ASPF1B	0A77	03	ASPF1C	0A7C	03	ASPF1D	0A81	03
ASPF1E	0A86	03	ASPF1F	0A8C	03	ASPF2	0A8E	03	ATBC	062B	03	ATRANL	= 00EF	
ATTRIBM	= 4000		ATTRIB	= 0021		AT2	0635	03	AUSCP	0F03	03	AUTOCN	= 0039	
AUTOGR	002C	01	AUTOLF	002D	01	AUTQWR	002B	01	A1M	0880	03	A1RM	08CC	03
AIRT	= 08DE	03	AIRTL	= 0003	00	A1SM	08B0	03	A1SR	08C2	03	A1ST	= 08C3	03
A1STL	= 0003	00	A2M	0898	03	A2RM	0944	03	A2SM	08FF	03	B	%00F0	00
BANK0	= 0000		BANK1	= 0008		BAUDRA	= 0033		BELL	= 0007		BFIX	= 0018	
BLINAD	04EA	03	BLINKA	000A	01	BLINKF	0001	01	BLNKCN	= 0038		BLNKRA	= 0037	
BRTAB	= 0E5F	03	BR1	0FD2	03	BR2	0FDC	03	BS	= 0008		BTAB	0602	03
BTL	060A	03	BTL1	061A	03	BTR	061F	03	CAN	= 0018		CAPLOC	0035	01
CBA	0A92	03	CCRSR	= 0080		CDN	0CA8	03	CDN1	0CAE	03	CDN2	0CB2	03
CDN3	0CB7	03	CHARME	= 5000		CHKS	1FFF	03	CHRORL	= 0010		CINT	= 00A0	
CLA	0503	03	CLFO	0BC2	03	CLFT	= 0C3D	03	CLKF	0033	01	CLKRUN	0097	01
CLRFLG	0020	01	CLRL	0BA0	03	CLRLIN	0B96	03	CLRS	0BAC	03	CLRTAB	0598	03
CLRTB	059D	03	CMPORT	1E0F	03	CONTLF	001D	01	CPF	0188	03	CPFR1	018C	03
CPFR2	01A7	03	CPF1	018E	03	CPF2	01A3	03	CPR	0E83	03	CPRM	0EA9	03
CPR0	0E8B	03	CPR0A	0E8F	03	CPR1	0E97	03	CPR2	0EA6	03	CR	= 000D	
CRESET	= 0000		CRNBK	0038	01	CRT	0C64	03	CRT1	0C6A	03	CRUL	0032	01
CR1	1198	03	CR2	119A	03	CSET	= 00E0		CSTOP	= 0040		CSTRT	= 0020	
CS1	0BB5	03	CS2	0BB9	03	CTAB1	= 0119	03	CTAB1L	= 0008	00	CTAB2	= 0107	03
CTAB2L	= 000E	00	CTAB3	= 0128	03	CTAB3L	= 0006	00	CTS	00B5	01	CJA	0CD6	03
CUA1	0CE4	03	CUA2	0CE8	03	CUA2A	0CEB	03	CUA3	0CEF	03	CUB0	0CF2	03
CUB1	0CFE	03	CUC	0D04	03	CUC0	0D14	03	CUC0A	0D1C	03	CUC1	0D0E	03
CUC1A	0D12	03	CUC2	0D1E	03	CUP	0C8D	03	CUP1	0C94	03	CUP1A	0C95	03
CUP1B	0C99	03	CUR	0CF1	03	CURSOR	1184	03	CUR1	0D00	03	CUR2	0D20	03
CY	%00D7	01	DC	0B5F	03	DCLK	1E1F	03	DCLK0	1E25	03	DCLK1	1E36	03
DCMDRE	= 2001		DDATRE	= 2000		DEOL	0B00	03	DISPSE	= 003E		DISPST	1E69	03
DKI	0FB9	03	DMAANL	= 00CF		DMADRH	= 000A		DMADRL	= 000B		DMAMEM	= 6000	
DMAORL	= 0020		DMATYP	00B4	01	DMLN	%0001		DMLNA	= 0009		DMPTR	%0000	
DMPTRA	= 0008		DM1	1225	03	DM1A	1243	03	DM1B	1235	03	DM1C	1238	03
DM1D	123D	03	DM1E	1246	03	DM2	1248	03	DM3	124A	03	DM4	125B	03
DOXOFF	13C4	03	DOXON	13D5	03	DPH	%0083	00	DPL	%0082	00	DSADRH	= 0015	
DSADRL	= 0016		DSPR	1E6F	03	DSP0	1E70	03	DSP1	1E7F	03	DSP2	1E89	03
DSP3	1E93	03	DSR	0D24	03	DSRERR	0D40	03	DSR0K	0D42	03	DSRO	0D29	03
DSR0A	0D2C	03	DSR1	0D30	03	DSR1A	0D35	03	DSR2	0D39	03	DSR2A	0D3E	03
DSTARE	= 2001		DTR	0094	01	DX	0014	01	D25L	0B15	03	EA	%00AF	01
EACR	0B62	03	EALF	0B68	03	EAM	0B03	03	EAROM	= 7000		EAROMR	0003	01
EAROMS	0000	01	EBD	0BF1	03	EBL	0BCB	03	EBLNK	0F30	03	EB1	0BF8	03
EB2	0BFA	03	EB3	0C01	03	EC	0B5C	03	EED	0C08	03	EEL	0BDB	03
EER	0C18	03	EERM	0B74	03	EE1	0C0C	03	EE1A	0C10	03	EGATM	0B6E	03
EGM	0F39	03	EGTT	= 08AA	03	EGTTL	= 0002	00	EHALF	0F2A	03	EHSM	0B3C	03
EICM	0B54	03	EID	0A1A	03	EID1	0A20	03	EID2	0A25	03	EIL	0A2B	03

SYMBOL TABLE

EIL1	0A31	03	EIL2	0A36	03	EIR	0A2A	03	EKAM	0B4E	03	EKC	0B26	03
EKI	0FB3	03	EKSM	0B48	03	ELB	07BC	03	ELBT	= 07D0	03	ELBTL	= 001E	00
ENBLCU	001A	01	EOL	0BE0	03	EOL1	0BE3	03	EQMT	= 0892	03	EQMTL	= 0002	00
ERM	001B	01	ERM1	1F41	03	ERM2	1F55	03	ERM3	1F6F	03	ERM4	1F86	03
ERM5	1F9E	03	ERM6	1FB4	03	ERROR	1F2C	03	ERRORS	= 0040		ERRO	1F35	03
ERR1	1F69	03	ERR2	1F80	03	ERR3	1F98	03	ERR4	1FAE	03	ERR5	1FC9	03
ERVM	0F33	03	ES	%00AC	01	ESC	= 001B		ESCCOD	067B	03	ESCRET	0696	03
ET0	%00A9	01	ET1	%00AB	01	EUNDL	0F2D	03	EX0	%00A8	01	EX1	%00AA	01
EZM	0B07	03	E25L	0B0B	03	FCIF	01F6	03	FCKB	02B6	03	FCOF	024C	03
FILL	1211	03	FII	01FC	03	FI2	0202	03	FI3	0217	03	FKDLY	02E1	03
FKDLY1	02E4	03	FKL	02C7	03	FKR	02DD	03	FK1	02BE	03	FK2	02D8	03
FL1	1219	03	F0R	026B	03	F01	0253	03	FREQ	0039	01	FULLDP	002F	01
FO	%00D5	01	GATM	0025	01	GDES	0F4F	03	GDESR	0F7A	03	GDES0	0F52	03
GDES1	0F55	03	GDES2	0F5A	03	GDES2A	0F62	03	GDES3	0F65	03	GDES3A	0F71	03
GETNUM	1B45	03	GNP	09D1	03	GNPF	0019	01	GNP1	09DC	03	GNP2	09E8	03
GNUMR	1B50	03	GNUMS	1B93	03	GNUM0	1B46	03	GNUM1	1B4A	03	GNUM2	1B52	03
GNUM2A	1B57	03	GNUM2B	1B5A	03	GNUM2L	1B5D	03	GNUM4	1B69	03	GNUM4A	1B6E	03
GNUM4B	1B71	03	GNUM4C	1B76	03	GPICK	0F86	03	GPICKT	= 0F92	03	GRPH	000D	01
GSEL	0012	01	GSET	= 001F		GODES	0F3F	03	GOPICK	0F7B	03	GIDES	0F47	03
GPICK	0F81	03	HALFIA	000B	01	HAZ	0043	01	HAZESC	06B0	03	HAZINI	11D4	03
HAZT	= 0768	03	HAZTL	= 0010	00	HCLFT	0C51	03	HCLFT1	0C5F	03	HCRT	0C79	03
HCRT1	0C88	03	HEED	0C19	03	HEE1	0C20	03	HEE1A	0C24	03	HIR	11D8	03
HNDSHK	003E	01	HSLINE	= 001E		HSMODE	0036	01	HSSTOP	0022	01	HT	= 0009	
HTAB	0636	03	HTC	0627	03	HTS	0621	03	HTS1	0623	03	HTO	0640	03
HT1	0652	03	HT2	065B	03	HT3	0665	03	IBUF	= 57D0		ICMODE	0021	01
ICOUNT	= 000E		ICI	114F	03	IDT	0EAB	03	IDTM	0EB0	03	IDTT	0EB3	03
IDTTM	0EBF	03	IE	%00A8	00	IEDMA	= 0082		IEINIT	= 0095		IEXTI0	002A	03
IE0	%0089	01	IE1	%008B	01	IFCP	0079	03	IFETCH	= 000D		IFPA	0082	03
IFPRET	0106	03	IFP1	009C	03	IFP1A	00A4	03	IFP1B	00AC	03	IFP1C	00AF	03
IFP2	00B4	03	IFP2A	00CF	03	IFP3	00D5	03	IFP3A	00DE	03	IFP4	00EA	03
IFP5	00F4	03	IFP5A	00F6	03	IFP6	0104	03	IHI	= 0015		IKB1	11A4	03
IKB2	11AC	03	IKB3	11B4	03	IKB4	11BC	03	IKB5	11C4	03	IKB6	11C8	03
ILEN	= 0020		ILO	= 0009		INDX1	%0002		INDX1A	= 0002		INDX2	%0003	
INDX2A	= 0003		INIT	1045	03	INITCR	111E	03	INITKB	119E	03	INMOV	10A7	03
INT0	%00B2	01	INT1	%00B3	01	IN3	1068	03	IN3A	108A	03	IN3B	1086	03
IN4	109C	03	INS	10A3	03	IP	%00B8	00	IPINIT	= 0003		IRQ	1329	03
IRQ1	1347	03	IRQ2	1352	03	IRQ3	135E	03	IRQ4	1361	03	IRQ4A	1379	03
IRQ5	1390	03	ISCON	= 005A		ISTORE	= 000C		ITMOD	= 0023		ITMRO	002D	03
IT0	%0088	01	IT1	%008A	01	I1	0008	03	I2	0010	03	I3	0019	03
I5	0029	03	KBACC	0448	03	KBBREA	0FCC	03	KBCHK	1EC4	03	KBCP	02EE	03
KBCPLK	0FBF	03	KBCRT	= 0466	03	KBCRTL	= 0007	00	KBC_BE	= 0081		KBC_DC	= 0083	
KBC_DK	= 0088		KBC_DR	= 0087		KBC_EC	= 0082		KBC_EK	= 0089		KBC_EL	= 0084	
KBC_ER	= 0086		KBC_ID	= 0080		KBC_OF	= 008A		KBC_ON	= 008B		KBC_XL	= 0085	
KBC0	1EC6	03	KBC1	1EC8	03	KBC2	1ED1	03	KBDISF	001F	01	KBDT	= 044B	03
KBDTL	= 0009	00	KBENT	043E	03	KBE1	0445	03	KBFNT	= 04CF	03	KBFNTL	= 0009	00
KBIDNU	= 001D		KBIN	0091	01	KBOUT	0090	01	KBPDIT	= 047B	03	KBPDTL	= 001C	00
KBSCRO	0FE3	03	KBSCR1	0FED	03	KBSCR2	0FF0	03	KBSPAC	0436	03	KBS1	043C	03
KBTAB	041B	03	KB_ACC	= 009F		KB_BRE	= 0089		KB_CAP	= 008A		KB_CNT	= 0020	
KB_COM	= 009D		KB_DAS	= 009C		KB_DEC	= 009A		KB_DOW	= 0081		KB_ENT	= 009B	
KB_LERA	= 0085		KB_F1	= 0080		KB_F2	= 0081		KB_F3	= 0082		KB_F4	= 0083	
KB_F5	= 0084		KB_F6	= 0085		KB_F7	= 0086		KB_F8	= 0087		KB_F9	= 0088	
KB_HEL	= 0086		KB_HOM	= 0084		KB_ID	= 0098		KB_LLEF	= 0082		KB_POW	= 008F	
KB_RIG	= 0083		KB_SCR	= 0087		KB_SET	= 0088		KB_SHF	= 0040		KB_SPA	= 008C	
KB_TAB	= 008B		KB_UP	= 0080		KB_L0	= 0090		KB_L1	= 0091		KB_L2	= 0092	
KB_L3	= 0093		KB_L4	= 0094		KB_L5	= 0095		KB_L6	= 0096		KB_L7	= 0097	
KB_L8	= 0098		KB_L9	= 0099		KC1	0FC8	03	KPA	03CD	03	KPADAL	0031	01
KPADSH	0030	01	KPB	03DB	03	KPC	0402	03	KPCOF	0414	03	KPC1	0419	03

SYMBOL TABLE

KPR	02F3	03	KPR2	0413	03	KP0	02F4	03	KP1	0303	03	KP10	03CB	03
KP11	0384	03	KP12	03B4	03	KP13	03A3	03	KP14	03A1	03	KP15	03B2	03
KP16	0365	03	KP16A	036B	03	KP2	030F	03	KP3	0335	03	KP4	034B	03
KP5	0345	03	KP6	034F	03	KP7	0355	03	KP8	038A	03	KP9	0371	03
KSR	0FFE	03	KTM1	0431	03	KTM2	0434	03	KT0	042A	03	KT1	042D	03
LCIF	021B	03	LF	= 000A		LINADH=	0013		LINADL=	0014		LI1	0221	03
LKB	02E8	03	LKBR	02ED	03	LKUP1	13F8	03	LN0FF	1BC9	03	LNCN	1BCC	03
LN1B1	14C7	03	LN1B2	14CF	03	LN3B	1648	03	LN3B1	164D	03	LN3B10	166B	03
LN3B11	1670	03	LN3B12	1675	03	LN3B13	167A	03	LN3B14	167F	03	LN3B3	1652	03
LN3B5	1657	03	LN3B7	165C	03	LN3B8	1661	03	LN3B9	1666	03	LN3C1	1684	03
LN3C2	1689	03	LN3C3	168E	03	LN3C4	1693	03	LN3E1	1698	03	LN3E2	169C	03
LN3G1	16A0	03	LN3G2	16A8	03	LN4B1	1769	03	LN4B2	176F	03	LN4D1	1775	03
LN4D2	177D	03	LN4D3	1785	03	LN4D4	178D	03	LN7D1	19B7	03	LN7D2	19C0	03
LN7D3	19C9	03	LN7D4	19D2	03	LN7F1	19DB	03	LN7F2	19DC	03	LN8B1	1AE4	03
LN8B2	1AED	03	LOOKUP	13E9	03	LORDER=	0047		LOT	= 1432	03	LOTL	= 0013	00
L1	146E	03	L1A	149E	03	LIT	= 146B	03	L1TL	= 0001	00	L2	150D	03
L2A	1516	03	L2B	151A	03	L2C	152B	03	L2D	1538	03	L2T	= 1501	03
L2TL	= 0004	00	L25EN	0015	01	L25MEM=	5780		L25ON	0037	01	L3	1598	03
L3A	15C0	03	L3AT	= 161E	03	L3ATL	= 000E	00	L3B	15E7	03	L3C	1600	03
L3D	161C	03	L3T	= 158C	03	L3TL	= 0004	00	L4	16F8	03	L4A	1717	03
L4B	173B	03	L4T	= 16EC	03	L4TL	= 0004	00	L5	1808	03	L5T	= 17FC	03
L5TL	= 0004	00	L6	1897	03	L6T	= 188B	03	L6TL	= 0004	00	L7	193F	03
L7C1	198D	03	L7C2	1994	03	L7D	19AE	03	L7T	= 1933	03	L7TL	= 0004	00
L8	1A8C	03	L8A	1AB0	03	L8T	= 1A74	03	L8TL	= 0004	00	L8TL2	= 0004	00
L8T2	= 1A80	03	MAIN	0036	03	MAXCHA=	004F		MAXLIN=	0018		MLATCH=	3000	
MN1	0042	03	MN1A	004E	03	MN1B	0051	03	MN1C	005D	03	MN1D	0062	03
MN2	0065	03	MN3	006E	03	MODE	= 0028		MONITD	003A	01	MSGCL	1E94	03
MSGIC	1EB3	03	MSGOL	1EA5	03	NKC	0B2D	03	NORM	0087	03	NRMO	0093	03
NRM1	009A	03	NULL	= 0000		NUMCHA=	0050		NUMLIN=	0019		NVRCHK	1F22	03
NVRSUM=	0034		NVR1	1F27	03	OBUF	= 57F0		OFETCH=	0010		OKTRAN	0013	01
OLEN	= 57F7		ONLINE	002E	01	OSTORE=	000F		OV	%00D2	01	P	%00D0	01
PBS	= 0C3D	03	PBS1	0C42	03	PCIF	01CA	03	PCKB	026D	03	PCLK	0B7A	03
PCL1A	0B7F	03	PCL1B	0B88	03	PCL1C	0B91	03	PCL2	0B95	03	PCOF	022A	03
PCR	055C	03	PCRLF	054F	03	PDC	0DF4	03	PDC1	0E11	03	PDC2	0E31	03
PDL	0D88	03	PDLA	0D95	03	PDL0	0D9B	03	PDL1	0D9F	03	PDL2	0DA9	03
PFIELD=	003F		PIC	0DC1	03	PIC1	0DD3	03	PIL	0D47	03	PILA	0D52	03
PILRET	0D72	03	PILRT1	0D75	03	PILO	0D5C	03	PIL1	0D60	03	PIL2	0D6A	03
PIR	01F1	03	PII	01DD	03	PI2	01E4	03	PI3	01F0	03	PKDLY	02B5	03
PKL	0291	03	PKR	02B3	03	PK0	027B	03	PK1	027F	03	PK1A	028F	03
PK2	0294	03	PK3	02A5	03	PK4	02A9	03	PK5	02B0	03	PLF	0561	03
PLFCR	0555	03	PLFLP	0588	03	PLFRET	0594	03	PLF1	0567	03	PLF2	056D	03
PLFS	0571	03	PMADRHE	0019		PMADRLE	001A		PMBUF	= 57F8		PMNUM	= 001B	
PMVALU=	001C		PORTF	0002	01	PO1	022F	03	PO2	0234	03	PO3	023F	03
PRINT	1DD2	03	PRLF	0518	03	PRNTF	0023	01	PRNT1	1DE4	03	PRNT2	1E04	03
PRNT3	1E0E	03	PROTEC	000E	01	PRTF2	003C	01	PRTYEN	0028	01	PRTYEV	002A	01
PRTYST	0029	01	PS	%00BC	01	PSD	0971	03	PSDB	0982	03	PSDB1	0985	03
PSDB2	098A	03	PSDE	09A2	03	PSDF	0018	01	PSDRET	09CF	03	PSD1	09A0	03
PSD2	09B7	03	PSD3	09BF	03	PSD4	09CD	03	PSDF	0E6D	03	PSW	%00D0	00
PTR1	%0000		PTR1A	= 0000		PTR2	%0001		PTR2A	= 0001		PTO	%00B9	01
PT1	%00BB	01	PUTCHE	0157	03	PU1	017D	03	PU2	0186	03	PX0	%00B8	01
PX1	%00BA	01	PO	%0080	00	P1	%0090	00	P2	%00A0	00	P3	%00B0	00
RAMCHK	1EF1	03	RAMCON	1FD1	03	RAMERR	1F1E	03	RAMP	0AFA	03	RAM0	1EF6	03
RAM1	1EFA	03	RAM2	1FD0	03	RBB	%009A	01	RD	%00B7	01	REN	%009C	01
REPF	0034	01	RGL	066F	03	RGR	067A	03	RI	%0098	01	RING	066B	03
RLL	0537	03	RLR	0543	03	RL1	0548	03	RL1A	054C	03	RMC1	1EE2	03
RMC2	1EF0	03	RMS	092C	03	RMSRET	0943	03	RMST	= 0956	03	RMSTL	= 0009	00
RMS1	0938	03	ROMCHK	1ED9	03	RS0	%00D3	01	RS1	%00D4	01	RTS	0095	01

SYMBOL TABLE

RT1	0B0A	03	RUBOUT=	007F	RVVA	0008	01	RXD	%00B0	01	R2_BAC=	1024		
R2_DCL=	103F		R2_DIS=	1042	R2_ESC=	102D		R2_FIL=	100C		R2_ICU=	101B		
R2_IKB=	101E		R2_IN =	1000	R2_IN2=	1003		R2_IRQ=	100F		R2_KY1=	1027		
R2_KY2=	102A		R2_PFN=	103C	R2_SER=	1012		R2_SET=	1021		R2_STA=	1006		
R2_STO=	1009		R2_TC =	1030	R2_TL =	1033		R2_TP =	1036		R2_T25=	1039		
R2_XMT=	1015		R2_XDN=	1018	SAV2	1B0D	03	SBC	0B33	03	SBLR	0F96	03	
SBR	0E4B	03	SBRET	0E5E	03	SBRT	0FAF	03	SBRO	0E5A	03	SBUF	%0099	00
SB1	0F9C	03	SB2	0FA6	03	SB3	0FA7	03	SCH	0C36	03	SCLRL	1B2E	03
SCLRLR	1B2C	03	SCON	%0098	00	SCP	0EE8	03	SCRNSA	003B	01	SCRN1 =	004F	
SCRN2A=	0098		SCRN2B=	00DC		SCRN3 =	0099		SCRN4A=	004E		SCRN4B=	004F	
SC1	1164	03	SC2	1171	03	SD1	11F0	03	SERIAL	12CB	03	SERIN	12DD	03
SEROUT	1313	03	SETCF	117B	03	SETCRT	1152	03	SETDIS	082A	03	SETLCK	0093	01
SETNOR	082F	03	SETTAB	05A2	03	SETUP	1417	03	SETUPR	1AF6	03	SETUPS	1B02	03
SETUP0	141B	03	SETUP1	141E	03	SETUP2	14D7	03	SETUP3	1542	03	SETUP4	16B0	03
SETUP5	1795	03	SETUP6	1865	03	SETUP7	18F4	03	SETUP8	19DD	03	SFA	126F	03
SFB	12A5	03	SFCKB	1407	03	SFCKB1	140F	03	SFCKB2	1416	03	SFILL	1B21	03
SFIL1	1B23	03	SFIL2	1B25	03	SFL	12AC	03	SF1	1286	03	SF2	128D	03
SF3	12AB	03	SF4	12B9	03	SF5	12BF	03	SF6	12C7	03	SHIFTF	001C	01
SIO	12ED	03	SII	12F3	03	SIIA	12FF	03	S12	1301	03	S13	1306	03
SLP	1B40	03	SMS	08E7	03	SMSRET	08FE	03	SMST =	0911	03	SMSTL =	0009	00
SMS1	08F3	03	SM0	%009F	01	SM1	%009E	01	SM2	%009D	01	SOFTIN	10E4	03
SOFTI1	111B	03	SDR	0E7F	03	SP	%0081	00	SPF	01A9	03	SPO	01AE	03
SP1	01C0	03	SP2	01C4	03	SP3	01C6	03	SRET	1AFF	03	SRT	1317	03
SRT1	1326	03	STAB	013A	03	STACK =	005F		START	0030	03	STARTD	11DC	03
STB1	05B0	03	STB2	05B9	03	STCALL	093A	03	STFILL	1262	03	STJMP	0936	03
STOPDM	11FD	03	STP1A	1420	03	STP1B	142C	03	STP2A	14D9	03	STP2B	14DB	03
STP2C	14E7	03	STP2C1	14EC	03	STP2D	14EE	03	STP2D1	14F3	03	STP2E	14F5	03
STP2F	14F9	03	STP2F1	14FB	03	STP3A	1544	03	STP3B	1550	03	STP3B1	1562	03
STP3C	1567	03	STP3C1	1572	03	STP3C2	157C	03	STP3C3	1580	03	STP3D	1584	03
STP3E	1588	03	STP4A	16B2	03	STP4B	16BE	03	STP4C	16C3	03	STP4C1	16CF	03
STP4C2	16D9	03	STP4D	16DB	03	STP4D1	16E3	03	STP4E	16E8	03	STP5A	1798	03
STP5B	1744	03	STP5B1	17C1	03	STP5B2	17C4	03	STP5B3	17E5	03	STP5C	17F0	03
STP5D	17F4	03	STP5E	17F8	03	STP6A	1867	03	STP6B	1875	03	STP6C	1879	03
STP6D	187D	03	STP6E	1884	03	STP7A	18F6	03	STP7B	1904	03	STP7C	1908	03
STP7D	190C	03	STP7D1	1916	03	STP7D2	191C	03	STP7D3	1923	03	STP7D4	1927	03
STP7E	192C	03	STP8A	19DF	03	STP8B	19ED	03	STP8B1	1A08	03	STP8B3	1A1D	03
STP8C	1A21	03	STP8D	1A32	03	STP8E	1A3A	03	STP8E0	1A41	03	STP8E1	1A61	03
STRET	083C	03	ST1	013B	03	ST2	014F	03	SUC	0B37	03	SUC1	0B39	03
SXC1	1D9D	03	SXMTC	1D88	03	SXMTL	1DA8	03	SXON1	13E2	03	SXR	13E1	03
TAB	05C1	03	TABTAB=	0029		TBL1	05D6	03	TBL2	05DE	03	TBR	05FC	03
TB1	05F3	03	TB2	05ED	03	TB3	05EA	03	TB4	05E7	03	TB5	05F7	03
TB6	05DC	03	TB8	%009B	01	TCNT =	003A		TCON	%0088	00	TEMP	%0005	
TEMPA =	0005		TERMIN	11CB	03	TF0	%008D	01	TF1	%008F	01	THOUR =	003D	
THO	%008C	00	TH1	%008D	00	TI	%0099	01	TLO	%008A	00	TL1	%008B	00
TMIN =	003C		TMOD	%0082	00	TRA	13AC	03	TRANS	139E	03	TRANSM	137B	03
TROK	13B4	03	TROK1	13BA	03	TROK2	13BD	03	TRW	13AE	03	TRO	%008C	01
TR1	%008E	01	TSCRUL=	0017		TSEC =	003B		TXD	%00B1	01	TO	%00B4	01
T1	%0085	01	UNDEF	0767	03	UNDLNA	0009	01	USCP	0EF4	03	USCP1	0EFF	03
USCP2	0F01	03	UXOFFS	0011	01	VSP	0092	01	VSPF	0024	01	WEOL	0AFD	03
WLATCH	1E18	03	WORK	%0004		WORKA =	0004		WORK1	%0006		WORK1A=	0006	
WORK2	%0007		WORK2A=	0007		WR	%00B6	01	XACR	0B65	03	XALF	0B6B	03
XATR	0F26	03	XBLINA	09F4	03	XERM	0B77	03	XGATM	0B71	03	XGM	0F3C	03
XHSM	0B43	03	XHSM1	0B45	03	XICM	0B58	03	XKAM	0B51	03	XKSM	0B4B	03
XLATCH=	0020		XLONOF	1BBF	03	XLON1	1BC7	03	XLO	1BF5	03	XLOA	1C14	03
XL1	1E1D	03	XL1A	1C24	03	XL10	1CBA	03	XL10A	1CBF	03	XL11	1CC1	03
XL12	1CCB	03	XL12A	1CD0	03	XL13	1CD2	03	XL14	1CDC	03	XL14A	1CE1	03
XL15	1CE3	03	XL16	1CFF	03	XL16A	1D11	03	XL16B	1D18	03	XL17	1D1A	03

SYMBOL TABLE

XL18	1D3F	03	XL18B	1D4B	03	XL18C	1D52	03	XL18D	1D59	03	XL18E	1D60	03
XL2	1C26	03	XL20	1D63	03	XL3	1C28	03	XL3A	1C44	03	XL3B	1C4B	03
XL3C	1C57	03	XL4	1C5D	03	XL4A	1C74	03	XL4AA	1C6B	03	XL4B	1C7D	03
XL4C	1C89	03	XL4SET	1C79	03	XL7	1C8D	03	XL8	1CA0	03	XL8A	1CAE	03
XL9	1CB0	03	XML2	1D7A	03	XMP1	1DB2	03	XMP2	1DBB	03	XMP3	1DC0	03
XMTC	1BE4	03	XMTL	1D74	03	XMTL1	1D75	03	XMTP	1DAC	03	XMTS	1BCF	03
XMTS1	1BD3	03	XMTS2	1BDE	03	XMTXDF	13D1	03	XMTXON	13E5	03	XMT25	1DC6	03
XOFF	= 0013		XOFFRC	0016	01	XOFFSE	0010	01	XON	= 0011		XPCKB	0B2A	03
XPQS	= 0011		XRYM	0F36	03	XR2_DI	0B23	03	XST	1B9D	03	XSTAB	09F7	03
XSTABX	1404	03	XSTAT	1BA8	03	XSTATX	1401	03	XSTL	1BAE	03	XSTR	1BB8	03
XSTX	13FE	03	XXPOS	= 0035		XYPOS	= 0036		YPOS	= 0012		ZAR	0F25	03
ZATR	0F08	03	ZATRO	0F14	03	ZDS	0041	01	ZDSESC	06B8	03	ZDSSBR	0E3D	03
ZDST	06DF	03	ZDSO	0E49	03	ZE1A	06C1	03	ZE1B	06C6	03	ZE1C	06CC	03
ZE2	06DE	03	ZTAB	0ED3	03	ZTABT	= 0EDF	03	ZTABTL	= 0003	00			

***DSG 0000 00
 ***BSG 00B5 01
 ***XSG 0000 02
 ***CSG 2000 03

MODULE: Z29ROM
 ERRORS DETECTED: 0

FREE CORE: 10574. WORDS
 B: Z29, B: Z29=A: Z29/E: ABS/E: LC/C

DMAMEM	6-24#	163-18	163-19	171-11					
DMAORL	6-34#	172-29							
DMATYP	11-47#	169-22*	170-20	170-21*	172-50*				
DMLN	7-29#	170-43	170-46	170-48	170-50	170-55	170-57	171-3	
DMLNA	7-30#	163-17*	169-24	175-24*					
DMPTR	7-27#	171-4	171-5						
DMPTRA	7-28#								
DOXOFF	174-42	178-14#	230-17						
DOXON	157-1	178-41#	230-46						
DSADRH	8-19#	17-26	57-17*	69-17*	69-38*	124-16*			
DSADRL	8-20#	17-25	57-16*	57-30*	57-33*	57-36*	69-18*	69-37*	124-15*
DSPO	234-17	234-20#							
DSP1	234-27	234-30#							
DSP2	234-32	234-35#							
DSP3	234-37	234-40#							
DSPR	234-16	234-18#							
DSR	125-20	125-15#							
DSRO	125-16	125-19#							
DSROA	125-19	125-20#							
DSR1	125-20	125-23#							
DSRIA	125-24	125-27#							
DSR2	125-27	125-30#							
DSR2A	125-31	125-32#							
DSRERR	125-30	125-34#							
DSROK	125-32	125-35#							
DSTARE	6-5#	163-42	164-13	164-16	175-28				
DTR	11-41#	178-19*	178-46*						
DX	9-31#	22-14*	166-25	166-29*					
E25L	78-34	99-15#							
EACR	71-47	79-1	107-14#						
EALF	78-55	108-14#							
EAM	61-10	98-13#							
EAROM	6-26#	159-35	211-17						
EAROMR	9-8#	159-29*	159-31*						
EAROMS	9-5#	211-30*	211-32*						
EB1	115-41	115-44#							
EB2	115-45#	115-52							
EB3	115-46	115-49#							
EBD	61-48	88-19	115-40#						
EBL	62-4	89-20	114-14#	115-42	115-47				
EBLNK	91-23	144-49#							
EC	81-45	106-13#							
EE1	116-16#	116-21							
EE1A	116-17	116-18#							
EED	61-24	63-32	88-15	116-14#					
EEL	62-1	89-24	114-38#						
EER	116-18	116-22#	116-47						
EERM	71-44	110-14#							
EGATM	71-35	109-14#							
EGM	61-20	91-29	146-13#						
EGTT	74-21	74-32#	74-40						
EGTTL	74-20	74-40#							
EHALF	63-50	91-17	144-13#						
EHSM	61-41	78-40	102-13#	193-50					
EICM	61-14	71-41	105-13#						
EID	67-35	88-13#							
EIDI	88-14	88-17#							

CROSS REFERENCE TABLE (CREF.V01-05.)

HT0	55-17	55-20#												
HT1	55-27	55-29#												
HT2	55-28	55-34#												
HT3	55-36	55-41#												
HTAB	20-17	55-13#												
HTC	54-32#	54-51	140-32											
HTS	54-13#	65-43	140-38											
HTS1	54-14#	54-33												
I1	15-15	15-17#												
I2	15-24	15-26#												
I3	15-33	15-35#												
I5	15-42	15-44#												
IBUF	6-14#	25-16	25-33	25-34	26-24	26-31	26-32	27-21	242-6	242-7				
IC1	163-52	163-55#												
ICMODE	9-51#	18-38	35-3	35-12	105-13*	105-31*	234-37							
ICOUNT	8-8#	25-21	25-30*	26-15	26-34*	27-16								
IDT	61-40	138-15#												
IDTM	138-15	138-18#												
IDTT	61-55	138-37#												
IDTTM	138-41	138-44#												
IEDMA	2-33#	169-21	172-49											
IEINIT	2-32#	161-37	170-18											
IEXTIO	15-16	15-49#												
IFCP	16-24	17-21#												
IFETCH	8-7#	26-25	26-29*	26-30	26-32*	27-22								
IFF1	17-29	17-30	17-41#											
IFF1A	17-43	17-44#												
IFF1B	17-41	17-49#												
IFF1C	17-49	17-50#												
IFF2	17-50	17-55#												
IFF2A	17-57	18-1	18-4	18-7#										
IFF3	17-51	18-18#												
IFF3A	18-18	18-19	18-21#											
IFF4	18-22	18-26#												
IFF5	18-21	18-23	18-26	18-28	18-35#									
IFF5A	18-30	18-36#												
IFF6	17-44	17-47	18-38	18-44#										
IFPA	17-21	17-22	17-25#											
IFPRET	18-12	18-45#												
IHI	6-16#	25-27												
IKB1	167-18	167-20#												
IKB2	167-26	167-28#												
IKB3	167-34	167-36#												
IKB4	167-42	167-44#												
IKB5	167-50	167-52#												
IKB6	167-20	167-28	167-36	167-44	167-52	167-55#								
ILEN	6-17#	25-22	25-33	26-31										
ILO	6-15#	26-20												
IN3	159-38#	159-49												
IN3A	160-1	160-3#												
IN3B	159-57	160-1#												
IN4	160-11	160-14#												
INS	160-15	160-17#												
INDX1	7-11#	50-15	50-19	51-24	51-32	52-27	52-51	113-20	113-22	113-24	115-44	115-49	115-51	116-15
	116-16	116-17	116-19	116-44	116-45	116-46	116-49	118-18	118-20	119-41	119-43	121-46	121-48	122-49
	122-51	127-18	127-20	129-18	129-20	130-18	130-43	132-19	132-32	132-56	153-16	153-22	159-18	159-23
	159-36	159-49	160-30	161-24	161-29	186-36	187-9	211-18	211-28	212-16	212-21	213-26	213-29	236-16

L6T	199-17	199-54#	200-11		
L6TL	199-16	200-11#			
L7	202-14	203-43#			
L7C1	204-10	204-15#			
L7C2	204-12	204-14	204-16	204-18#	
L7D	204-24	204-26#			
L7T	202-17	203-12#	203-26		
L7TL	202-16	203-26#			
L8	206-14	208-51#			
L8A	209-3	209-5#			
L8T	206-17	207-49#	208-9		
L8T2	206-36	208-19#	208-34		
L8TL	206-16	208-9#			
L8TL2	206-35	208-34#			
LCIF	27-16#	56-19			
LF	2-7#	19-55	230-31	241-33	241-33
LI1	27-17	27-21#			
LINADH	8-16#	22-21	22-40#	44-25#	115-20
LINADL	8-17#	22-20	22-39#	44-22#	115-19
LKB	32-14#	207-34	230-50		
LKBR	32-15	32-17#			
LKUP1	179-20	179-24	179-27#		
LN1B1	184-20	184-32#			
LN1B2	184-22	184-33#			
LN3B	191-2	191-51#			
LN3B1	191-5	191-52#			
LN3B10	191-32	192-4#			
LN3B11	191-35	192-5#			
LN3B12	191-38	192-6#			
LN3B13	191-41	192-7#			
LN3B14	190-5	191-11	191-17	191-23	192-8#
LN3B3	191-8	191-53#			
LN3B5	191-14	191-54#			
LN3B7	191-20	192-1#			
LN3B8	191-26	192-2#			
LN3B9	191-29	192-3#			
LN3C1	190-12	192-9#			
LN3C2	190-14	192-10#			
LN3C3	190-16	192-11#			
LN3C4	190-18	192-12#			
LN3E1	190-24	192-13#			
LN3E2	190-26	192-14#			
LN3G1	190-32	192-15#			
LN3G2	190-34	192-16#			
LN4B1	194-44	195-29#			
LN4B2	194-46	195-30#			
LN4D1	195-2	195-31#			
LN4D2	195-4	195-32#			
LN4D3	195-6	195-33#			
LN4D4	195-8	195-34#			
LN7D1	204-11	204-39#			
LN7D2	204-13	204-40#			
LN7D3	204-15	204-41#			
LN7D4	204-17	205-1#			
LN7F1	204-23	205-2#			
LN7F2	204-25	205-3#			
LN8B1	209-2	209-19#			

CROSS REFERENCE TABLE (CREF.V01-05.)

STP2C1	185-26	185-28#		
STP2D	185-33#	186-8		
STP2D1	185-34	185-36#		
STP2E	185-41#	186-11		
STP2F	185-47#	186-14		
STP2F1	185-42	185-48#		
STP3A	188-15#	188-19		
STP3B	188-24#	189-17		
STP3B1	188-28	188-30	188-32#	
STP3C	188-38#	189-20		
STP3C1	188-38	188-43#		
STP3C2	188-43	188-47#		
STP3C3	188-44	188-49#		
STP3D	188-55#	189-23		
STP3E	189-4#	189-26		
STP4A	193-15#	193-19		
STP4B	193-24#	194-12		
STP4C	193-30#	194-15		
STP4C1	193-35	193-37#		
STP4C2	193-40	193-42#		
STP4D	193-47#	194-18		
STP4D1	193-47	193-50#		
STP4E	193-56#	194-21		
STP5A	196-15#	196-19		
STP5B	196-24#	197-33		
STP5B1	196-32	196-34#		
STP5B2	196-34	196-35#		
STP5B3	196-45	196-46#		
STP5C	197-8#	197-36		
STP5D	197-14#	197-39		
STP5E	197-20#	197-42		
STP6A	199-15#	199-19		
STP6B	199-24#	199-57		
STP6C	199-30#	200-3		
STP6D	199-36#	200-6		
STP6E	199-43#	200-9		
STP7A	202-15#	202-19		
STP7B	202-24#	203-15		
STP7C	202-30#	203-18		
STP7D	202-36#	203-21		
STP7D1	202-37	202-41#		
STP7D2	202-36	202-45#		
STP7D3	202-45	202-49#		
STP7D4	202-39	202-43	202-47	202-52#
STP7E	203-1#	203-24		
STP8A	206-15#	206-19		
STP8B	206-24#	208-2		
STP8B1	206-31#	206-38	206-43	
STP8B3	206-42#	208-22		
STP8C	206-48#	208-5		
STP8D	207-9#	207-52		
STP8E	207-17#	207-39	208-8	
STP8E0	207-20#	207-35		
STP8E1	207-32#	207-37		
STRET	66-19	70-19	70-24#	
SUC	81-42	101-31#		
SUC1	101-14	101-33#		

CROSS REFERENCE TABLE (CREF.V01-05.)

##INIT 0-0#