

UNIVERSAL ASSEMBLER VERSION 1.2 JANUARY 4, 1978 (IN-HOUSE)

CONFIDENTIAL PROPRIETARY INFORMATION

THIS ITEM IS THE PROPERTY OF DATAPoint CORPORATION, SAN ANTONIO, TEXAS, AND CONTAINS CONFIDENTIAL AND TRADE SECRET INFORMATION. THIS ITEM MAY NOT BE TRANSFERRED FROM THE CUSTODY OR CONTROL OF DATAPoint EXCEPT AS AUTHORIZED BY DATAPoint AND THEN ONLY BY WAY OF LOAN FOR LIMITED PURPOSES. IT MUST NOT BE REPRODUCED IN WHOLE OR IN PART AND MUST BE RETURNED TO DATAPoint UPON REQUEST AND IN ALL EVENTS UPON COMPLETION OF THE PURPOSE OF THE LOAN.

NEITHER THIS ITEM NOR THE INFORMATION IT CONTAINS MAY BE USED OR DISCLOSED TO PERSONS NOT HAVING A NEED FOR SUCH USE OR DISCLOSURE CONSISTENT WITH THE PURPOSE OF THE LOAN, WITHOUT THE PRIOR WRITTEN CONSENT OF DATAPoint.

COMMAND LINE WAS: SNAP3 1800MACR,,,1800MACR/APLX

INCLUSION A: 1800/MAC
 INCLUSION B: MDEF1800/TXT
 INCLUSION C: BDEF1800/TXT
 INCLUSION D: ODEF1800/TXT
 INCLUSION E: STRUCT/TXT
 INCLUSION F: 1800REST/TXT
 INCLUSION G: 1800BOOT/TXT
 INCLUSION H: 1800DIAG/TXT
 INCLUSION I: 1800DSKR/TXT
 INCLUSION J: 1800DEBUG/TXT
 INCLUSION K: 1800DSPR/TXT
 INCLUSION L: 1800MOVI/TXT

PROGRAM NAME: 1800MACR

PROGRAM ADDRESS BLOCKS:	170000	/ABSOLUTE/	SIZE=000000	(ABS)
	167400	/SYSIVR/	SIZE=000400	(ABS)
	170000	/SYSROM/	SIZE=000047	(ABS)
	153600	/SDBGWS/	SIZE=000051	(ABS)
	156600	/SDATAS/	SIZE=000063	(ABS)

PRIMARY TRANSFER ADDRESS: 170000

FIXED ENTRY POINTS:

\$MACROM	000011	\$MACVER	000040	\$DISKBUF	154000	\$DOSEXT	156000
\$DATAS	156600	\$LOGDRV	156617	\$SECTOR	156620	\$TRACK	156621
\$DEVADR	156622	\$DRVNUM	156623	\$DRVTAB	156624	\$KEYCHAR	170055
\$KBDSINI	170060	\$CHARLOD	170063	\$DSPINIT	170066	\$DISPLAY	170071
\$DISPDOS	170074	DSCBL	170077	DSCURSES	170102	D\$BLNKDE	170105
D\$BLINK	170110	D\$FNC60	170113	D\$FNC61	170116	D\$FNC62	170121
D\$FNC63	170124	D\$FNC64	170127	D\$FNC65	170132	D\$FNC66	170135
D\$FNC67	170140	D\$FNC68	170143	D\$FNC69	170146	D\$FNC6A	170151
D\$FNC68	170154	D\$FNC6C	170157	\$SEEK	170162	\$STEP	170165
\$READ	170170	\$WRITE	170173	\$ONLINE	170176	\$RESTORE	170201
\$DOSDRIV	170204	\$DOIO	170207	\$BUFIO	170212	\$STATUS	170215
\$FDSTAT	170220	\$NS	000203	\$ES	000003	\$HD	000224
\$VA	000213	\$CK	000207	\$EQ	000022	\$BP	000007
\$OI	000200	\$H	000011	\$V	000013	\$EL	000015
\$EOF	000021	\$RU	000023	\$RD	000024	\$F	000033
\$HA	000211	\$NL	000215	\$HU	000223	\$O	000233
\$OS	000100	\$OW	000040	\$MACVRS	177777		

UNUSED LABELS:

KEYINF

```

1,
2,
3,
4, 000011
5, 000040
6,
7,
8,
9,
10,
11,
12,
13,
14,
15,
16,
17,
18, 000002
19,
20,
21,
22,
23, 000000
24, 000000
25, 000000
26,
27, 000002
28,
29,
30,
31, 000000
32,
33,
34,
35,
36, 000000
37,
38,
39,
40, 000013
41, 000000
42,
43, 000106
44, 000052

```

```

*
* 1800 MACRO ROM PROGRAM - MAIN MODULE      JUN 14, 1978   12:05   HSP/HJS
*
$MACROM* EQU      9      MACRO ROM VERSION NUMBER
$MACVER* EQU     ' '      MACRO ROM REVISION LETTER
*
. 9      HJS      20 JUL 78   VERSION 9 FINAL RELEASE
. 9,J    HJS      21 JUN 78   FIX TWO RESTART BUGS (STL & BETA)
. 9,I    HJS      14 JUN 78   FIX BUGS & ADD MORE SPACE IN CODE
. 9,H    HJS      10 MAY 78   CORRECT BUGS & SETUP CRC FOR RELEASE
. 9,G    HJS      24 MAR 78   ADD RIM BUFFER TEST
. 9,F    HJS      20 MAR 78   ALLOW ROM TYPE 2 (3800) CODE GENERATION
. 9,E    HJS      16 MAR 78   ADD NEW VECTOR, DISKETTE LOCKUP CONDITION
. 9,C    HJS      13 FEB 78   FIX 'UNI=KEY' UP & COMMENTS
. 9,B    HJS       4 FEB 78   CORRECT AND INSERT 'UNIVERSAL KEYBOARD'
. 9,A    HJS      30 JAN 78   DISPLAY AND POR FIXUPS
*
PN1800   EQU      2      1800 PROCESSOR NUMBER (FROM INFO)
*
          SNAPOPT   6      INSURE 6600 CODE AVAILABLE
          LIST     F
*
ASCII    EQU      0      NON-ZERO -> ASCII KEYIN IN DEBUG
ORIGINI  EQU      0      NON-ZERO -> ORIGIN CAPABILITIES IN DEBUG
STACKP   EQU      0      NON-ZERO -> STACK PUSH/POP OP'S IN DEBUG
*
RAMROM   EQU      2      ZERO -> ROM IN RAM AT 0010000
          *              ONE  -> ROM IN RAM AT 0120000
          *              TWO  -> ROM IN ROM AT 0170000
*
ROMTYPE  EQU      0      ZERO -> 1800 STANDARD MACRO-ROM
          *              ONE  -> APF SPECIAL VERSION
          *              TWO  -> RIMDLL VERSION (3800)
          *              THREE-> CYNTHIA &/OR RIM BOOT
*
ROMCRC   EQU      0      SET THIS EQU TO THE CRC OF BYTES 0170000
          *              TO 0177774, STARTING FROM AN INITIAL -1
          *              PUT THE CRC IN BYTES 0177775 & 6 (MSB/LSB)
*
BL       EQU      11     NUMBER OF BOTTOM LINE FOR DOS FUNCTION 6
LC       EQU      0      NUMBER OF LEFT COLUMN FOR DOS FUNCTION 6
*
NECP     EQU      70     'NO ENTRY' CURSOR POSITION FOR DEBUG
OPCODEBP EQU     052     BREAK POINT OPCODE

```

45.
46.
47.
48.
49.
50.
51.
52.
53.

*
• GET ALL THE DEFINITIONS
•
INC 1800/MAC INSTRUCTION DEFINITIONS
INC MDEF1800 MEMORY AND BIT DEFINITIONS
INC ODEF1800 DISKETTE DEFINITIONS
LIST -I
INC STRUCT STRUCTURED ASSEMBLER MACROS (FOR RIMDLL)
LIST I


```

56,
57,
58,
59, 153600
60, 153600
61,
62, 153600
63, 153602
64, 153603
65, 153604
66, 153606
67,
68, 153607
69, 153611
70,
71,
72, 000012
73,
74,
75,
76,
77, 000003
78, 153613
79, 153651
80,
81,
82,
83,
84,
85,
86,
87,
88,
89,
90,
91,
92,
93,
94,
95,
96,
97, 154000
98,
99, 156000
    
```

```

*
. DEFINE THE DEBUG WORKING STORAGE LOCATIONS
.
SDBGWS   ORG       SDBGWS
USE      USE      SDBGWS

.
CURADR   SK       2      LAST MEMORY LOCATION ADDRESSED
CUROUT   SK       1      LAST CHARACTER WRITTEN TO DEVICE
CURSTA   SK       1      LAST STATUS FROM A DEVICE
MODVAL   SK       2      LAST 'MODIFY' VALUE GIVEN
KEYINF   SK       1      ASCII KEYIN MODE FLAG (0=>NORMAL)

.
OLDTOS   SKIP     2      OLD TOP OF STACK
OLDREGS  SKIP     2      POINTER TO ALPHA OR BETA REGISTERS

.
BPTLN    IFC      ORIGINI
EQU      EQU      10     MAXIMUM NUMBER OF BREAKPOINTS
XIF

.
BPTLN    IFS      ORIGINI
EQU      EQU      6      MAXIMUM NUMBER OF BREAKPOINTS
XIF

.
BPTES    EQU      3      THERE ARE (3) BYTES PER ENTRY
BPTABL   SK       BPTLN*BPTES
BPTABE   SK       BREAK POINT TABLE
END OF BREAKPOINT TABLE

.
OTABLN   IFS      ORIGINI
EQU      EQU      6      MAXIMUM NUMBER OF ORIGINS
CURORG   SKIP     2      CURRENT ORIGIN VALUE
CUROSN   SKIP     1      CURRENT ORIGIN SELECT NUMBER
OTABL    SKIP     OTABLN*2
OPTABE   SK       ORIGIN TABLE
END OF ORIGIN TABLE
XIF

*
. THE REST OF THE PAGE IS USED FOR DEBUG'S REGISTERS AND STACK
.
IFGE     $,SDBGWS+(SESAB,AND,0177)
ERR      DEBUG WORKING STORAGE AREA TOO LARGE!
XIF

*
. PUT THE DATA AREA DEFINITIONS INTO THE ENTRY POINT TABLE
.
$DISKBUF* EQU      DOSBUF      DOS LF0-LF3
$DOSEXT*  EQU      DOSEXT      DOS EXTENSION AREA
    
```

```

100,
101,
102,
103, 156600
104, 156600
105,
106, 156600
107, 156600
108, 156603
109, 156605
110, 156616
111, 156607
112, 156617
113,
114,
115,
116, 156620
117, 156621
118,
119, 156622
120, 156623
121,
122, 156624
123,
124,
125,
126, 000007
127,
128,
129, 000044
130,
131,
132,
133, 156644
134, 156662
135, 156653
136,
137,
138,
139,
140,
141,
    
```

```

*
. DEFINE THE DISK WORKING STORAGE MEMORY LOCATIONS
.
$DATAS      ORG          DOSEXT+0600
            USE          $DATAS

$DATAS*     EQU          $          DEFINE CURRENT DATAPAGE
            SKIP        3          * NOT USED *
$SAVXA      SKIP        2          TEMP HOLD FOR (XA)
$SAVBC      SKIP        2          TEMP HOLD FOR (BC)
$DSKREGS    EQU          $+7       DISK DRIVER REGISTER SAVE AREA
            SKIP        8
$LOGDRV*    SKIP        1          CURRENT DOS LOGICAL DRIVE (INIT =1)
*
. THE FOLLOWING TWO VARIABLES ARE ORDER DEPENDENT
.
$SECTOR*    SKIP        1          CURRENT SECTOR (ORDER DEPENDENT)
$STRACK*    SKIP        1          CURRENT TRACK (ORDER DEPENDENT)
.
$DEVADR*    SKIP        1          FLOPPY PHYSICAL DEVICE ADDRESS
$DRVNUM*    SKIP        1          FLOPPY LOGICAL DRIVE (FODR0/FODR1)
*
$DRVTAB*
.
. CURRENT SECTOR/TRACK FOR EACH DOS LOGICAL DRIVE $SECTOR/$STRACK
.
$DRVTBLN    EQU          7          .AND. MASK FOR MAX # DOS DRIVES
            RPT          $DRVTBLN+1 LOGICAL DRIVES 0-7
            SKIP        2
$DATAL      EQU          $=$DATAS  LENGTH OF VARIABLES TO BE INITIALIZED.
*
. DISPLAY DRIVER SCRIBBLE AREAS
.
ROWS        SKIP        7          "CHARLOD" WORKING AREA
DSPREGSA    EQU          $+7       DISPLAY INTERFACE REG SAVE AREA
            SKIP        8
*
. --- THE REST OF THE PAGE IS NOT USED ---
.
LIST        I
.
INC         1800REST
    
```

3, F
 4, F
 5, F
 6, F
 7, F
 8, F
 9, F
 10, F
 11, F
 12, F
 13, F
 14, F
 15, F
 16, F
 17, F
 18, F
 19, F
 20, F
 21, F
 22, F
 23, F
 24, F
 25, F
 26, F
 27, F
 28, F
 29, F
 30, F
 31, F
 32, F
 33, F
 34, F
 35, F
 36, F
 37, F
 38, F
 39, F
 40, F
 41, F
 42, F
 43, F
 44, F
 45, F
 46, F
 47, F
 48, F
 49, F
 50, F
 51, F
 52, F
 53, F
 54, F

170000
 170000
 170000 104 266 363
 170003 104 002 364
 170006 036 357
 170010 343
 170011 174 065
 170013 046 274 036 361
 170017 104 005 373
 170022 111 153
 170024 104 000 357
 170027 253
 170030 210 254 360
 170033 111 153
 170035 104 074 357
 170040 111 050 000 000

. 1800 MACRO ROM RESTART MODULE JUN 20, 1978 13:20 HSP/HJS
 . PHYSICALLY LOCATE THE CODE FOR THE ROM MAKING PROGRAM
 . IFEQ RAMROM,0
 SET 010000
 LOC SYSROM
 IFEQ ROMTYPE,2
 ERR RIM=DLL MODULE WILL CAUSE ASSEMBLY ERRORS
 XIF
 . IFEQ RAMROM,1
 SET 0120000
 LOC SYSROM
 IFEQ ROMTYPE,2
 ERR RIM=DLL MODULE WILL CAUSE ASSEMBLY ERRORS
 XIF
 . IFEQ RAMROM,2
 SET 0170000
 XIF
 . MACROM
 .SRPOWER JUMP POWERUP POWER=UP ENTRYPOINT BY JUMP!
 .SRRSTRT JUMP RESTART RESTART ENTRYPOINT BY JUMP!
 .SRSYSMF
 . LD SESTACK>8
 LED
 . SYSMOV DE
 DE SYSPAT
 JMP MTSETX
 .SRMEMPE CLICKR MEMORY PARITY ERROR CAUSES CLICK
 JMP SVMEMP THEN JUMP TO THE RAM VECTOR
 .SRCLICKR ACLATT 3 SET LOUDNESS TO MAXIMUM AND
 ACJUMP CLICKROM GO TO CLICK ROM CODE
 .SRSTPE CLICKR
 JMP SVSTPAR SECTOR TABLE PARITY ERROR CAUSES CLICK
 THEN JUMP TO THE RAM VECTOR
 . ONEMSA EJMP 0 RAM SERVICE INTERRUPT DOES EI AND JUMP
 (USE WASTED SPACE)
 .SRTMOUT JMP TIMEOUT I=DECODE PROCESSOR TIMEOUT ERROR
 IFNE \$+3,SRNEXTAL

55.F
56.F
57.F
58.F 170044 106 242 372
59.F 170047 066 014
60.F 170051 104 055 362

	ERR		ROM VECTOR ADDRESSING MIS-MATCH ERROR
	XIF		
TIMOUT	CALL	SSTATE	(PUT HERE TO FILL THE SPACE)
	LL	TIMOUTM	GET ADDRESS OF MESSAGE
	JMP	ERROR	(USING WASTED SPACE)

63	F								
64	F	170054	000		DC	0		* NOT USED *	
65	F								
66	F				IFNE	\$,0170055		* MAGIC NUMBER *	
67	F				ERR			JUMP VECTOR ADDRESSING ERROR !	
68	F				XIF				
69	F								
70	F								
71	F								
72	F								
73	F								
74	F	170055	104 143 373		SKEYCHAR*	JUMP	DOSF62N	DOSFUNC 6 SUB 2 WITHOUT BLINK 'DE'	
75	F	170060	104 117 362		SKBDSINI*	JUMP	KBDSPINI	INIT DISPLAY AND KEYBOARD CONTROL INFO	
76	F								
77	F	170063	104 207 362		SCHARLOD*	JUMP	CHARLOD	LOAD CHARACTER SET SUBROUTINE	
78	F	170066	104 004 374		SDSPINIT*	JUMP	DSPINIT	INITIALIZE THE DISPLAY	
79	F	170071	104 341 374		SDISPLAY*	JUMP	DISPLAY	1800/1500 DISPLAY ROUTINE	
80	F	170074	104 337 374		SDISPDOS*	JUMP	DISPDOS	DOS COMPATIBLE DISPLAY ROUTINE	
81	F								
82	F	170077	104 312 374		DSCBL*	JUMP	DSPCBL	COMPUTE A DISPLAY BUFFER LOCATION	
83	F	170102	104 237 374		DSCURSES*	JUMP	CURSES	SUSPEND THE CURSOR	
84	F	170105	104 221 373		DSBLNKDE*	JUMP	BLINKDE	BLINK THE CURSOR AT (DE)	
85	F	170110	104 244 373		DSBLINK*	JUMP	BLINK	BLINK THE CURSOR AT "SECPOS"	
86	F								
87	F	170113	104 077 373		DOSFNC60*	JUMP	DOSF60	DOS FUNCTION 6 SUBFUNCTION 0	
88	F	170116	104 125 373		DOSFNC61*	JUMP	DOSF61	DOS FUNCTION 6 SUBFUNCTION 1	
89	F	170121	104 140 373		DOSFNC62*	JUMP	DOSF62	DOS FUNCTION 6 SUBFUNCTION 2	
90	F	170124	104 171 373		DOSFNC63*	JUMP	DOSF63	DOS FUNCTION 6 SUBFUNCTION 3	
91	F	170127	104 177 373		DOSFNC64*	JUMP	DOSF64	DOS FUNCTION 6 SUBFUNCTION 4	
92	F	170132	104 204 373		DOSFNC65*	JUMP	DOSF65	DOS FUNCTION 6 SUBFUNCTION 5	
93	F	170135	104 211 373		DOSFNC66*	JUMP	DOSF66	DOS FUNCTION 6 SUBFUNCTION 6	
94	F	170140	104 345 373		DOSFNC67*	JUMP	DOSF67	DOS FUNCTION 6 SUBFUNCTION 7	
95	F	170143	104 046 374		DOSFNC68*	JUMP	DOSF68	DOS FUNCTION 6 SUBFUNCTION 8	
96	F	170146	104 105 374		DOSFNC69*	JUMP	DOSF69	DOS FUNCTION 6 SUBFUNCTION 9	
97	F	170151	104 144 374		DOSFNC6A*	JUMP	DOSF610	DOS FUNCTION 6 SUBFUNCTION 10	
98	F	170154	104 204 374		DOSFNC6B*	JUMP	DOSF611	DOS FUNCTION 6 SUBFUNCTION 11	
99	F	170157	104 216 374		DOSFNC6C*	JUMP	DOSF612	DOS FUNCTION 6 SUBFUNCTION 12 * NEW *	

MACRO-PROCESSOR SYSTEM MACRO ROM CODE - HSP/HJS - 78JUL20 11:44
 - JUMP VECTORS TO EXTERNALLY USABLE ROUTINES AND ADDRESSES OF USEABLE TABLES -

100,F
 101,F
 102,F
 103,F
 104,F
 105,F 170162 104 201 365
 106,F 170165 104 252 365
 107,F 170170 104 071 366
 108,F 170173 104 025 366
 109,F 170176 104 373 365
 110,F 170201 104 230 366
 111,F 170204 104 310 366
 112,F
 113,F 170207 104 135 366
 114,F 170212 104 117 366
 115,F 170215 104 327 365
 116,F 170220 143
 117,F 170221 007
 118,F 170222 300
 119,F
 120,F
 121,F
 122,F
 123,F
 124,F
 125,F
 126,F
 127,F
 128,F
 129,F
 130,F
 131,F
 132,F
 133,F
 134,F
 135,F
 136,F
 137,F

```

*
      IFLE      ROMTYPE,1
.
. JUMP VECTOR TO EXTERNALLY USABLE DISKETTE ROUTINES
.
$SEEK*   JUMP      $$SEEK      SEEK TO THE TRACK IN (D)
$STEP*   JUMP      $$STEP      STEP IN OR OUT 1 TRACK
$READ*   JUMP      $$READ      READ A SECTOR
$WRITE*   JUMP      $$WRITE     WRITE A SECTOR
$ONLINE*  JUMP      $$ONLINE    SEE IF DRIVE IS ON LINE
$RESTORE* JUMP      $$RESTORE   SEEK TRACK 0
$DOSDRIV* JUMP      $$DOSDRIV   CONVERT DOS DRIVE TO MICRO BUS DRIVE
.
$DOIO*   JUMP      $$DOIO      - NOT USED BY DOS -
$BUFIO*  JUMP      $$BUFIO     - NOT USED BY DOS -
$STATUS* JUMP      $$STATUS    - NOT USED BY DOS -
$FDSTAT* FDSTAT    - NOT USED BY DOS - (INLINE CAUSE SMALL)
      RET
      NOP
      XIF
      (FILL TO 3 BYTE ENTRY)
*
      IFGE      ROMTYPE,2
.
. JUMP VECTOR TO ERROR ROUTINE, NO USEABLE DISKETTE ROUTINES
.
$SEEK*   JUMP      ROMVERR     SEEK TO THE TRACK IN (D)
$STEP*   JUMP      ROMVERR     STEP IN OR OUT 1 TRACK
$READ*   JUMP      ROMVERR     READ A SECTOR
$WRITE*   JUMP      ROMVERR     WRITE A SECTOR
$ONLINE*  JUMP      ROMVERR     SEE IF DRIVE IS ON LINE
$RESTORE* JUMP      ROMVERR     SEEK TRACK 0
$DOSDRIV* JUMP      ROMVERR     CONVERT DOS DRIVE TO MICRO BUS DRIVE
.
$DOIO*   JUMP      ROMVERR     - NOT USED BY DOS -
$BUFIO*  JUMP      ROMVERR     - NOT USED BY DOS -
$STATUS* JUMP      ROMVERR     - NOT USED BY DOS -
$FDSTAT* JUMP      ROMVERR     - NOT USED BY DOS -
      XIF
    
```



```

166,F
167,F 170270
168,F
169,F
170,F
171,F 170270 104 331 361
172,F 170273 104 331 361
173,F 170276 104 370 361
174,F 170301 104 370 361
175,F 170304 104 000 362
176,F 170307 104 000 362
177,F 170312 104 010 362
178,F 170315 104 010 362
179,F 170320 104 020 362
180,F 170323 104 020 362
181,F 170326 104 030 362
182,F 170331 104 030 362
183,F 170334 104 040 360
184,F 170337 104 040 360
185,F 170342 104 050 362
186,F 170345 104 050 362
187,F 170350 104 045 367
188,F 170353 104 045 367
189,F 170356 104 040 362
190,F 170361 104 040 362
191,F 170364 104 321 361
192,F 170367 104 321 361
193,F
194,F
195,F
196,F 170372 007
197,F 170373 000 000
198,F 170375 007
199,F 170376 000 000
200,F
201,F 170400 252
202,F 170401 210 223 360
203,F 170404 000 000
204,F
205,F 170406 252
206,F 170407 210 252 360
207,F 170412 000 000
208,F
209,F 000124
    
```

```

*
VECTI
.
. VERSION 2, 2200 COMPATIBLE INTERRUPT VECTOR INITIALIZATION VALUES
.
    
```

```

        JUMP      MEMPAT      MEMORY PARITY ERROR
        JUMP      MEMPAT      MEMORY PARITY ERROR
        JUMP      INPART      INPUT PARITY ERROR
        JUMP      INPART      INPUT PARITY ERROR
        JUMP      OUTPAT      OUTPUT PARITY ERROR
        JUMP      OUTPAT      OUTPUT PARITY ERROR
        JUMP      WVIOLT      WRITE VIOLATION
        JUMP      WVIOLT      WRITE VIOLATION
        JUMP      AVIOLT      ACCESS VIOLATION
        JUMP      AVIOLT      ACCESS VIOLATION
        JUMP      IVIOLT      INSTRUCTION VIOLATION
        JUMP      IVIOLT      INSTRUCTION VIOLATION
        JUMP      ONEMSA      ONE MILLISECOND
        JUMP      ONEMSA      ONE MILLISECOND
        JUMP      SYSCAT      SYSTEM CALL
        JUMP      SYSCAT      SYSTEM CALL
        JUMP      BRKPNR      BREAK POINT
        JUMP      BRKPNR      BREAK POINT
        JUMP      UAINST      UNASSIGNED INSTRUCTION
        JUMP      UAINST      UNASSIGNED INSTRUCTION
        JUMP      STPART      SECTOR TABLE PARITY ERROR
        JUMP      STPART      SECTOR TABLE PARITY ERROR
    
```

```

*
. ADDITIONAL VECTOR INITIALIZATION VALUES
.
    
```

```

        RET      SVDISKWS = DISK WAITS
        DA      0
        RET      SVDISPWS = DISPLAY WAITS
        DA      0
.
        ACLATT   2          SVBEEP = BEEP (0151)
        ACJUMP   BEEPCODE
        DA      0          PAD OUT TO 6 BYTES
.
        ACLATT   2          SVCLICK = CLICK (0153)
        ACJUMP   CLIKCODE
        DA      0          PAD OUT TO 6 BYTES
    
```

```

.
VECTIL EQU $-VECTI
    
```



```

212,F
213,F 170414
214,F
215,F
216,F
217,F
218,F
219,F
220,F 170414 052 105 124 040 124
221,F 170432 052 105 060 040 123
222,F
223,F 170453 052 105 071 040 123
224,F 170470 052 105 061 040 115
225,F 170505 052 105 062 040 111
226,F 170521 052 105 063 040 117
227,F 170533 040 120 101 122 111
228,F
229,F 170545 052 105 064 040 127
230,F 170561 052 105 065 040 101
231,F 170573 040 120 122 117 124
232,F
233,F 170606 052 105 066 203 225
234,F 170614 052 105 067 203 225
235,F 170622 052 105 070
236,F 170625 040 111 116 123 124
237,F 170641 040 105 122 122 117
238,F
239,F 170652 052 105 115 040 115
240,F
241,F
242,F
243,F
244,F
245,F
246,F
247,F
248,F
249,F
250,F
251,F 170674
252,F
253,F
254,F
255,F
256,F 170674 111 153
257,F 170676 353
258,F 170677 364
259,F 170700 026 254
260,F 170702 250
261,F 170703 310
262,F 170704 035
263,F 170705 021
    
```

```

*
ERRORM
.
. ERROR MESSAGES
.
    IFGE      ROMTYPE,2
    ROMVERM   DC      '*EV ROM VECTOR',SNS,*MERROR
    XIF
    TIMOUTM   DC      '*ET TIMEOUT',SNS,*MERROR
    SYSPRM    DC      '*E0 SYSTEM RAM',SNS,*MERROR
.
    STPARM    DC      '*E9 SECTOR',SNS,*MPARIT
    MEMPAM    DC      '*E1 MEMORY',SNS,*MPARIT
    INPAM     DC      '*E2 INPUT',SNS,*MPARIT
    OUTPAM    DC      '*E3 OUTPUT'
    MPARIT    DC      ' PARITY',SNS,*MERROR
.
    WVIOLM    DC      '*E4 WRITE',SNS,*MPROTE
    AVIOLM    DC      '*E5 ACCESS'
    MPROTE    DC      ' PROTECT',SNS,*MERROR
.
    IVIOLM    DC      '*E6',SNS,*MINSTE
    SYSCAM    DC      '*E7',SNS,*MINSTE
    UAINTM    DC      '*E8'
    MINSTE    DC      ' INSTRUCTION'
    MERROR    DC      ' ERROR* ',SES (AT LEAST 1 BLANK AFTER THE *, NO EOL)
.
    MERXMSG   DC      '*EM MEMORY TEST',SNS,*MERROR  USED BY 1800MOVI IF FATAL
                                                    ERROR HAS OCCURED WHEN SHOULDN'T
.
    IFNE      ERRORM>8,$>8
    ERR       ERROR MESSAGE ADDRESSING PROBLEMS
    XIF
*
,ONEMSA
.
. ONE MILLISECOND - RE-ENABLE INTERRUPTS AND JUMP TO LOGICAL LOCATION ZERO
.
    EJMP      0 (AT 0170037 TO SAVE SPACE)
*
SYSPAT
.
. SYSTEM RAM FAILURE - MUST FINISH CLEARING MEMORY AND RE-INITING TABLES
.
. BEFORE CAN DISPLAY ERROR MESSAGE
.
    CLICKR   MAKE NOISE THAT ERROR HAPPENED
    LHD
    LLE      DE = SVMEMP + VECTIL
    LC       256-VECTIL
    XRA
    LBA     ZERO OUT THE REST OF SYSTEM RAM (167400)
    DECP    HL
    BT      (ASSUME CAN READ WHAT WRITTEN)
    
```


307	F					*			
308	F	171010	106	242	372	WVIOLT	CALL	SSTATE	(SECTOR TABLE) WRITE VIOLATION
309	F	171013	066	145			LL	WVIOLM	
310	F	171015	104	055	362		JMP	ERROR	
311	F					*			
312	F	171020	106	242	372	AVIOLT	CALL	SSTATE	(SECTOR TABLE) ACCESS VIOLATION
313	F	171023	066	161			LL	AVIOLM	
314	F	171025	104	055	362		JUMP	ERROR	
315	F					*			
316	F	171030	106	242	372	IVIOLT	CALL	SSTATE	PRIV'D INSTRUCTION VIOLATION
317	F	171033	066	206			LL	IVIOLM	
318	F	171035	104	055	362		JUMP	ERROR	
319	F					*			
320	F	171040	106	242	372	UAINST	CALL	SSTATE	UN-IMPLEMENTED INSTRUCTION VIOLATION
321	F	171043	066	222			LL	UAINTM	
322	F	171045	104	055	362		JUMP	ERROR	
323	F					*			
324	F	171050	106	242	372	SYSCAT	CALL	SSTATE	SYSTEM CALL VIOLATION
325	F	171053	066	214			LL	SYSCAM	
326	F						JUMP	ERROR	
327	F					*			
328	F					.TIMOUT	CALL	SSTATE	I-DECODE PROCESSOR TIMEOUT ERROR
329	F						LL	TIMOUTM	(MOVED TO VECTOR POINT 0170044)
330	F						JUMP	ERROR	
331	F					*			
332	F	171055				ERROR			
333	F					.			
334	F					. ERROR DISPLAY			
335	F					.			
336	F	171055	056	361			LH	MEMPAM>8	DISPLAY ERROR MESSAGE
337	F	171057	046	013			LE	BL	ON THE BOTTOM LINE
338	F	171061	036	050			LD	40	STARTING ON COLUMN 40
339	F						LB	SOW	WRITE BLANKS & DO NOT WAIT ON DISPLAY KEY
340	F	171063	313				LBD		(SAVE A BYTE)
341	F	171064	106	341	374		CALL	DISPLAY	DISPLAY THE MESSAGE
342	F	171067	076	327			LX	CURADR>8	
343	F	171071	113	144	207		DPL	DE,OLDTOS	CAUSE TOP STACK ENTRY
344	F	171074	104	120	367		JMP	BRKPN	TO BE DISPLAYED

```

347,F
348,F
349,F
350,F
351,F
352,F 171077 060 061 062 063 064
353,F 171107 010
354,F 171110 070 071
355,F 171112 030
356,F 171113 010
357,F 171114 015
358,F 171115 056
359,F 171116 040
360,F 000020
361,F
362,F
363,F
364,F
365,F
366,F
367,F 171117
368,F
369,F
370,F
371,F 171117 066 150 056 357
372,F 171123 250
373,F 171124 340
374,F 171125 330
375,F 171126 027
376,F
377,F 171127 310
378,F 171130 026 020
379,F 171132 066 077 056 362
380,F 171136 036 334
381,F 171140 340
382,F 171141 021
383,F 171142 066 077
384,F 171144 026 020
385,F 171146 021
386,F 171147 353
387,F 171150 364
388,F 171151 376
389,F 171152 174 015
390,F 171154 006 001
391,F 171156 026 137
392,F 171160 021
393,F
394,F 171161 106 004 374
395,F
396,F 171164 250
397,F 171165
398,F 171165 066 216 056 363
    
```

```

*
* UNIVERSAL KEYBOARD TRANSLATE TABLE (WILL WORK ON 3600 KEYBOARD AS WELL)
*
*          000 TO 017          020 TO 037 IN TABLE
*          UNSHIFTED KEYS      SHIFTED KEYS
*          0-7 NUMBER PAD      0-7 NUMBER PAD
*          <BSP>                * UNDEFINED *
*          8,9 NUMBER PAD      8,9 NUMBER PAD
*          <CAN> = SHIFTED     <CAN> = UNSHIFTED
*          * UNDEFINED *      * UNDEFINED *
*          <ENT>                <ENT>
*          ". " NUMBER PAD     ". " NUMBER PAD
*          * UNDEFINED *      * UNDEFINED *
*          <0> (SP)
*
UTRANT    DC      '01234567'
          DC      BSP
          DC      '89'
          DC      CAN
          DC      BSP
          DC      ENTER
          DC      ". ."
          DC      ". ."
UTRANTL   EQU      $-UTRANT
          *
          IFNE      $+1>8,UTRANT>8
          ERR      TABLE IS NOT TO CROSS PAGE BOUNDARIES
          XIF
*
* KBDSPINI
*
* KEYBOARD DISPLAY INITIALIZATION ROUTINE - INITS THE WHOLE KBD/DSP SYSTEM
*
          HL      SEKBS2
          XRA
          LEA
          LDA
          DS      DE,HL
          *
          LBA
          LC      UTRANTL
          HL      UTRANT
          LD      SEKTRAN>8
          LEA
          BT
          LL      UTRANT
          LC      UTRANTL
          BT
          LHD
          LLE
          LML
          INCP    DE
          LA      1
          LC      128-UTRANTL-UTRANTL-1
          BT
          *
          CALL    DSPINIT
          *
          XRA
          *
          KBDSPILP
          HL      TRIANGLE
    
```

ZERO OUT THE KEYBOARD CONTROL BYTES
(SEKBS2 & SEKBS1)

INIT THE TRANSLATE TABLE
NO AUTO INCREMENT OR STOP
SIZE OF UTRANT
USE LOWER 040 TRANSLATE TABLE
TO INIT THE KEYBOARD TRANSLATE TABLE

AND AGAIN (FOR SECOND HALF)

* CODE FOR SPACE (040) IS ONE-TO ONE *
REST OF TABLE IS ONE TO ONE
DO IT THE SIMPLEST WAY
FOR THE REMAINDER

INIT THE DISPLAY POINTERS AND CONTROLS

INIT THE DISPLAY FONT CODES

FILL THE DISPLAY FONT MEMORY


```

410,F
411,F 171207
412,F
413,F
414,F
415,F
416,F
417,F
418,F
419,F
420,F
421,F
422,F
423,F
424,F
425,F
426,F
427,F
428,F
429,F
430,F
431,F
432,F
433,F
434,F 171207 307
435,F 171210 054 200
436,F 171212 053
437,F
438,F 171213 046 005
439,F 171215 160 223 362
440,F
441,F 171220 310
442,F 171221 015
443,F
444,F 171222 307
445,F 171223 070
446,F 171224 066 244 056 335
447,F
448,F 171230 012
449,F 171231 327
450,F 171232 062 212
451,F 171234 372
452,F 171235 015
453,F 171236 176 074 253
454,F 171241 110 230 362
455,F
456,F 171244 060
457,F 171245 015
458,F 171246 174 024 001
459,F 171251 110 222 362
460,F
461,F 171254 070
    
```

```

*
CHARLOD
.
. ENTER: HL => LIST OF CHARACTER FONTS TO BE LOADED
.
. THE BYTES MATCH SPECIFICATIONS FOR BYTES ON THE 5500 AND THE ROUTINE
. AUTOMATICALLY CONVERTS THEM INTO THE 1800 LODCF INSTRUCTION FORMAT.
. THIS IS A LIST OF GROUPS OF FIVE BYTES EACH SPECIFYING A COLUMN OF
. THE FONT MATRIX.
. THE FONT ENTRIES MUST HAVE THE MSBIT CLEAR ON THE FIRST OF THE FIVE
. COLUMN FONT BYTES.
. THE ASCII CODE THE FIVE BYTES REPRESENT MUST PRECEED THEM AND THE HIGH
. ORDER BIT MUST BE SET TO MARK WHICH ASCII CODE IS BEING SPECIFIED.
. IF THE FIRST ENTRY IN THE LIST DOES NOT HAVE AN ASCII CODE, THE VALUE
. IN THE B-REG IS USED.
. IF THE ASCII CHARACTER IS THE NEXT ONE IN SEQUENCE, IT MAY BE LEFT OUT.
. THE LIST IS TERMINATED BY A 0200.
. THEREFORE, THE ONLY WAY TO LOAD CODE 000 IS IF IT THE FIRST ENTRY IN THE LIST
. AND THE B-REG IS ZERO.
.
. EXIT: ALL REGISTERS USED EXCEPT X-REG
. ONE STACK POSITION IN ADDITION TO THE CALL USED
. ZERO CONDITION TRUE
.
CHRLOP   LAM           GET THE LIST ENTRY
         XR            0200   CLEAR HIGH BIT IF SET (OR SET IT)
         RTZ          STOP IF TERMINATOR (0200) REACHED
.
         LE            5      SET THE COLUMN COUNT
         JTS          CHRGO   START CONVERSION IF FONT BIT NOW SET
.
         LBA          ELSE SAVE ASCII CHAR IN THE B-REG
         INCP         HL      POINT HL TO THE NEXT COLUMN BYTE
.
CHRCOL   LAM           GET THE COLUMN FONT BYTE
CHRGO    PUSH         HL      SAVE THE TABLE POINTER
         HL           ROWS   POINT TO TEMP GENERATION AREA
.
CHRROW   SRC          SET CARRY FROM LSB
         LCM
         ACCC        SHIFT CARRY BIT IN
         LMC
         INCP         HL      POINT TO THE NEXT ROW
         CPL          ROWS+7
         JFZ         CHRROW  CONTINUE FOR 7 ROWS
.
         POP         HL      HL => NEXT COLUMN FONT BYTE
         INCP         HL
         SUE         1
         JFZ         CHRCOL  LOOP UNTIL 5 COLUMNS DONE
.
         PUSH        HL      SAVE THE TABLE POINTER
    
```

```

462,F 171255 066 244 056 335
463,F 171261 301
464,F 171262 155
465,F 171263 060
466,F 171264 111 004 001
467,F 171267 104 207 362
468,F
469,F
470,F 171272
471,F
472,F
473,F
474,F 171272 177 177 177 177 177
475,F 171277 240
476,F 171300 000 000 000 000 000
477,F 171305 252
478,F 171306 024 010 076 010 024
479,F 171313 255
480,F 171314 010 010 010 010 010
481,F 171321 272
482,F 171322 000 021 000 000 000
483,F 171327 260
484,F 171330 076 105 111 121 076
485,F 171335 021 041 177 001 001
486,F 171342 043 105 105 111 061
487,F 171347 102 101 111 125 042
488,F 171354 014 024 044 177 004
489,F 171361 162 121 121 121 116
490,F 171366 036 051 111 111 106
491,F 171373 100 107 110 120 140
492,F 171400 066 111 111 111 066
493,F 171405 061 111 111 112 074
494,F 171412 301
495,F 171413 077 110 110 110 077
496,F 171420 177 111 111 111 066
497,F 171425 076 101 101 101 042
498,F 171432 177 101 101 042 034
499,F 171437 177 111 111 111 101
500,F 171444 177 110 110 110 100
501,F 171451 076 101 101 111 056
502,F 171456 177 010 010 010 177
503,F 171463 000 101 177 101 000
504,F 171470 006 001 101 176 100
505,F 171475 177 010 024 042 101
506,F 171502 177 001 001 001 001
507,F 171507 177 040 030 040 177
508,F 171514 177 060 010 006 177
509,F 171521 076 101 101 101 076
510,F 171526 177 110 110 110 060
511,F 171533 076 101 105 102 075
512,F 171540 177 110 114 112 061
513,F 171545 061 111 111 111 106

```

```

HL LAB LOAD THE 1800 CHARACTER
LODCF
POP HL RESTORE THE TABLE POINTER
ADB 1 BUMP B-REG TO NEXT ASCII CHAR
JMP CHRLOP GO THROUGH THE LOOP AGAIN
*
*
SPLCS
*
* SPECIAL CHARACTER SET FOR POWER UP INITIALIZATION OF THE RAM DISPLAY
*
DC 0177,0177,0177,0177,0177 000 (CURSOR CHARACTER)
DC ' '+0200
DC 0000,0000,0000,0000,0000 040 (SPACE - BLANK)
DC '*'+0200
DC 0024,0010,0076,0010,0024 *
DC '= '+0200
DC 0010,0010,0010,0010,0010 -
DC ': '+0200
DC 0000,0021,0000,0000,0000 :
DC '!'+0200
DC 0076,0105,0111,0121,0076 0
DC 0021,0041,0177,0001,0001 1
DC 0043,0105,0105,0111,0061 2
DC 0102,0101,0111,0125,0042 3
DC 0014,0024,0044,0177,0004 4
DC 0162,0121,0121,0121,0116 5
DC 0036,0051,0111,0111,0106 6
DC 0100,0107,0110,0120,0140 7
DC 0066,0111,0111,0111,0066 8
DC 0061,0111,0111,0112,0074 9
DC '!A'+0200
DC 0077,0110,0110,0110,0077 A
DC 0177,0111,0111,0111,0066 B
DC 0076,0101,0101,0101,0042 C
DC 0177,0101,0101,0042,0034 D
DC 0177,0111,0111,0111,0101 E
DC 0177,0110,0110,0110,0100 F
DC 0076,0101,0101,0111,0056 G
DC 0177,0010,0010,0010,0177 H
DC 0000,0101,0177,0101,0000 I
DC 0006,0001,0101,0176,0100 J
DC 0177,0010,0024,0042,0101 K
DC 0177,0001,0001,0001,0001 L
DC 0177,0040,0030,0040,0177 M
DC 0177,0060,0010,0006,0177 N
DC 0076,0101,0101,0101,0076 O
DC 0177,0110,0110,0110,0060 P
DC 0076,0101,0105,0102,0075 Q
DC 0177,0110,0114,0112,0061 R
DC 0061,0111,0111,0111,0106 S

```

514.F 171552 100 100 177 100 100
515.F 171557 176 001 001 001 176
516.F 171564 160 014 003 014 160
517.F 171571 177 002 014 002 177
518.F 171576 143 024 010 024 143
519.F 171603 160 010 017 010 160
520.F 171610 103 105 111 121 141
521.F 171615 200
522.F
523.F 171616 037 017 007 003 001
524.F

DC 0100,0100,0177,0100,0100 T
DC 0176,0001,0001,0001,0176 U
DC 0160,0014,0003,0014,0160 V
DC 0177,0002,0014,0002,0177 W
DC 0143,0024,0010,0024,0143 X
DC 0160,0010,0017,0010,0160 Y
DC 0103,0105,0111,0121,0141 Z
DC 0200 =END-OF-LIST=
. TRIANGLE DC 037,017,007,003,001,000,000 TRIANGLE IN 1800 FORMAT
.

527,F
 528,F
 529,F
 530,F
 531,F 171625 014
 532,F 171626 034
 533,F 000002
 534,F
 535,F
 536,F 171627 054
 537,F 171630 074
 538,F 171631 114
 539,F 171632 134
 540,F 171633 154
 541,F 171634 174
 542,F 171635 214
 543,F 171636 234
 544,F 171637 254
 545,F 171640 274
 546,F 171641 314
 547,F 171642 334
 548,F 171643 354
 549,F 000015
 550,F
 551,F
 552,F 171644 015
 553,F 171645 035
 554,F 171646 055
 555,F 171647 075
 556,F 171650 115
 557,F 171651 135
 558,F 171652 155
 559,F 171653 175
 560,F 171654 215
 561,F 171655 235
 562,F 171656 255
 563,F 171657 275
 564,F 171660 315
 565,F 171661 335
 566,F 171662 355
 567,F 171663 375
 568,F
 569,F 000037
 570,F
 571,F
 572,F
 573,F
 574,F
 575,F 171664 054
 576,F 171665 055

*
 . SECTOR TABLE INITIALIZATION VALUES

.
 .
 . SMST DC ENCODED STL VALUE ADDR CARD# CARD#
 S=SMST<4+STAE+STWE 150K = 12K 1 = 32K 1
 SMSTL EQU S=SMSTL 160K = 12K 1 = 32K 1

.
 . UMST DC ENCODED STL VALUE ADDR CARD# CARD#
 S=SMST<4+STAE+STWE 000K = 12K 1 = 32K 1
 DC S=SMST<4+STAE+STWE 010K = 12K 2 = 32K 1
 DC S=SMST<4+STAE+STWE 020K = 12K 2 = 32K 1
 DC S=SMST<4+STAE+STWE 030K = 12K 2 = 32K 1
 DC S=SMST<4+STAE+STWE 040K = 12K 3 = 32K 1
 DC S=SMST<4+STAE+STWE 050K = 12K 3 = 32K 1
 DC S=SMST<4+STAE+STWE 060K = 12K 3 = 32K 2
 DC S=SMST<4+STAE+STWE 070K = 12K 4 = 32K 2
 DC S=SMST<4+STAE+STWE 100K = 12K 4 = 32K 2
 DC S=SMST<4+STAE+STWE 110K = 12K 4 = 32K 2
 DC S=SMST<4+STAE+STWE 120K = 12K 5 = 32K 2
 DC S=SMST<4+STAE+STWE 130K = 12K 5 = 32K 2
 UMSTL EQU S=UMSTL 140K = 12K 5 = 32K 2

.
 . HMST DC ENCODED STL VALUE CARD#
 S=HMST<4+STA16+STAE+STWE = 32K 3
 DC S=HMST<4+STA16+STAE+STWE = 32K 3
 DC S=HMST<4+STA16+STAE+STWE = 32K 3
 DC S=HMST<4+STA16+STAE+STWE = 32K 3
 DC S=HMST<4+STA16+STAE+STWE = 32K 3
 DC S=HMST<4+STA16+STAE+STWE = 32K 3
 DC S=HMST<4+STA16+STAE+STWE = 32K 3
 DC S=HMST<4+STA16+STAE+STWE = 32K 3
 DC S=HMST<4+STA16+STAE+STWE = 32K 3
 DC S=HMST<4+STA16+STAE+STWE = 32K 4
 DC S=HMST<4+STA16+STAE+STWE = 32K 4
 DC S=HMST<4+STA16+STAE+STWE = 32K 4
 DC S=HMST<4+STA16+STAE+STWE = 32K 4
 DC S=HMST<4+STA16+STAE+STWE = 32K 4
 DC S=HMST<4+STA16+STAE+STWE = 32K 4
 DC S=HMST<4+STA16+STAE+STWE = 32K 4
 DC S=HMST<4+STA16+STAE+STWE = 32K 4

. PISTL EQU S=SMST POWER INITIALIZE SECTOR TABLE LENGTH

. IFNE S>8,SMST>8
 ERR SECTOR TABLE ADDRESSING PROBLEMS - PAGE BOUNDARY
 XIF

. WRAPST DC 2<4+STAE+STWE SPECIAL MEMORY SIZE TEST SECTOR TABLE
 DC 2<4+STA16+STAE+STWE

579,F					*			
580,F	171666				POWERUP			
581,F					.			
582,F					.	ZERO ALL OF MEMORY, INITIALIZE THE SECTOR TABLE, ZERO THE BASE REGISTER		
583,F					.	AND LOAD THE RAM DISPLAY WITH NEEDED CHARACTERS.		
584,F					.			
585,F	171666	040				DI		KILL INTERRUPTS
586,F	171667	066	263	056	363	HL	SMST+PISTL=1	START FROM THE LAST (124K) ENTRY
587,F	171673				POWERL1			
588,F	171673	026	001			LC	1	LOAD INTO THE ZEROth SECTOR TABLE
589,F	171675	077				STL		ENTRY, THE VALUE POINTED TO BY HL
590,F					.			
591,F	171676	036	000			LD	0	ZERO THAT SECTOR
592,F	171700	343				LED		
593,F	171701	026	376	016	017	BC	4096=2	4K IS SECTOR LENGTH
594,F	171705				POWERL2			
595,F	171705	174	027			DS	DE,BC	NOTE: ALL MEMORY MUST BE ZEROED
596,F	171707	113	035			DECP	BC,2	BEFORE A STLOAD MOVES THE SYSTEM
597,F	171711	100	305	363		JFC	POWERL2	EMULATION SUPPORT AREA TO MEMORY
598,F					.			WITH BAD PARITY ELSE SYSTEM DIES
599,F					.			
600,F	171714	035				DECP	HL	BACK TO THE NEXT SECTOR TABLE ENTRY
601,F	171715	176	074	225		CPL	SMST	CATCH OFF END OF TABLE
602,F	171720	100	273	363		JFC	POWERL1	
603,F					.			
604,F	171723	066	225			LL	SMST	LOAD THE SYSTEM RAM SECTOR TABLE
605,F	171725	026	322			LC	(SEDSPBF>8,AND,0360)+SMSTL	ENTRIES
606,F	171727	062	077			STLOC		
607,F					.			
608,F	171731	066	300	056	357	HL	SESTACK	SET UP THE STACK POSITION
609,F	171735	176	065			SYSMOV	HL	
610,F	171737	106	045	373		CALL	SETUP	NOW SET UP EVERYTHING ELSE
611,F					.			
612,F	171742	106	117	362		CALL	KBDSPINI	INIT KEYBOARD & DISPLAY INFORMATION
613,F					.			
614,F	171745	250				XRA		GO TO DEBUG IF NOT 1800 PROCESSOR
615,F	171746	111	010			INFO		
616,F	171750	074	002			CP	PN1800	NO MESSAGE? CALL SSTATE & CALL IDENT MAYBE
617,F	171752	110	127	367		JFZ	DEBUG	
618,F					.			
619,F						IFLE	ROMTYPE,1	
620,F	171755	046	000			LE	0	TURN OFF ALL THE DRIVE LIGHTS
621,F					.			
622,F	171757	036	001		POWERDCL	LD	FDDR0	
623,F	171761	106	264	366		CALL	TOFFTLDE	TURN OFF THE LIGHT IN DRIVE 0
624,F	171764	036	002			LD	FDDR1	
625,F	171766	106	264	366		CALL	TOFFTLDE	TURN OFF THE LIGHT IN DRIVE 1
626,F	171771	174	004	001		ADE	1	INCREMENT THE DRIVE NUMBER
627,F	171774	174	044	003		NDE	\$DRVTLN>1	CATCH ALL DRIVES DONE
628,F	171777	110	357	363		JFZ	POWERDCL	
629,F					.	XIF		
630,F					.			FALLS THROUGH INTO THE RESTART CODE

3, G
 4, G
 5, G
 6, G 172064
 7, G
 8, G
 9, G
 10, G
 11, G
 12, G
 13, G
 14, G
 15, G
 16, G
 17, G
 18, G
 19, G
 20, G
 21, G
 22, G
 23, G
 24, G
 25, G
 26, G
 27, G
 28, G
 29, G
 30, G
 31, G
 32, G
 33, G
 34, G
 35, G
 36, G
 37, G
 38, G
 39, G
 40, G
 41, G
 42, G
 43, G
 44, G 172064 250
 45, G 172065 076 335
 46, G
 47, G 172067
 48, G 172067 106 115 364
 49, G
 50, G
 51, G
 52, G
 53, G 172072 106 102 373
 54, G 172075 130 064 364

```

    . 1800 DISKETTE IPL RESTART ROUTINE      MAR 20, 1978      16:00      HSP/HJS
    .
    RESTIPL
    .
    . RESTART IPL BLOCK LOAD ROUTINE
    .
    .         IFEQ      ROMTYPE,3
    . IF THE KEYBOARD KEY IS DOWN AND THERE IS A RIM ON THE I/O BUS
    . THEN LOAD THE RIM-DLL CODE INTO LOW MEMORY AND GO TO IT, ELSE
    .         XIF
    . SCAN THROUGH THE DRIVES WAITING FOR ONE ON WITH A DISK ON LINE,
    . CONTROLLER READY, AND THE DISK NOT BUSY. IF NOTHING
    . WILL LOAD FROM THE CURRENT DRIVE, CHECK THE KEYBOARD STATUS
    . FOR THE DISPLAY KEY BEING DEPRESSED.
    . IF NOT DOWN, RESTART FROM THE TOP ALL OVER AGAIN.
    . IF DOWN, SCAN TO THE NEXT DRIVE IN SEQUENCE UNTIL ALL DRIVES SCANNED.
    . IF ALL DRIVES SCANNED, RESTART FROM THE TOP ALL OVER AGAIN.
    .
    .         IFEQ      ROMTYPE,3
    .         CALL      DOSF60N
    .         JFS       RESTNRIM      KEYBOARD KEY DOWN?
    .         JFP       RESTNRIM      DISPLAY KEY DOWN ALSO?
    .
    RIMLOOP  MLA      *RIMDLLS+RIMADRL CHECK THE RIM'S TO SEE IF ANY THERE
    .         EX       ADR
    .         IN
    .         ORA
    .         JFZ      RIMBOOT      THERE IS AT LEAST ONE AT ITS ADDRESS
    .
    .         INCP     HL
    .         LAM
    .         ORA
    .         JFZ      RIMLOOP     CONTINUE TILL ALL RIMS TRIED
    .
    RIMWAIT  CALL     DOSF60N      WAIT FOR BOTH KEYS COMING UP
    .         JTS      RIMWAIT
    .         JTP      RIMWAIT
    .         XIF
    .
    .         IFNE     ROMTYPE,2
    RESTNRIM XRA
    .         LX       $DATAS>8      SET UP THE PAGE REGISTER
    .
    .
    RESTLOOP CALL     LOADIPL      TRY TO LOAD THE IPL BLOCK ON DRIVE (A)
    .         IFEQ     ROMTYPE,3
    .         CALL     BOOTCYN     TRY TO BOOT THE CYNTHIA DISK
    .         XIF
    .         IFNE     ROMTYPE,2
    .         CALL     DOSF60N      (X & B REGS NOT DESTROYED)
    .         JFP      RESTIPL     'DSP KEY' NOT DOWN, TRY DRIVE ZERO
    
```

55.G
56.G 172100 105 217
57.G 172102 004 001
58.G 172104 074 010
59.G 172106 140 067 364
60.G
61.G 172111 153
62.G 172112 104 064 364

• PL A,SLOGDRV
AD 1 TRY THE NEXT LOGICAL DRIVE
CP \$DRVTBLN+1 IF NOT ALL TRIED
JTC RESTLOOP
• EX CLICK
JMP RESTIPL IF ALL TRIED, THEN START ALL OVER AGAIN

63,G										
64,G	172115									
65,G										
66,G										
67,G										
68,G										
69,G	172115	106	310	366						
70,G	172120	111	143							
71,G	172122	106	373	365						
72,G	172125	043								
73,G										
74,G	172126	106	230	366						
75,G	172131	043								
76,G										
77,G	172132	036	000							
78,G	172134	046	001							
79,G	172136	363								
80,G	172137	056	330							
81,G	172141	106	071	366						
82,G	172144	153								
83,G	172145	043								
84,G										
85,G	172146	047								
86,G	172147	117	015							
87,G	172151	111	047							
88,G	172153	117	015							
89,G	172155	062	254							
90,G	172157	111	253							
91,G	172161	062	015							
92,G	172163	003								
93,G										
94,G	172164	307								
95,G	172165	260								
96,G	172166	013								
97,G										
98,G	172167	105	217							
99,G	172171	370								
100,G	172172	174	070							
101,G	172174	026	373							
102,G	172176	250								
103,G	172177	310								
104,G	172200	021								
105,G	172201	060								
106,G	172202	015								
107,G	172203	070								
108,G	172204	007								
109,G										
110,G										
111,G										
112,G										

```

+
LOADIPL
.
. LOAD THE DISK IPL BLOCK (TRACK 0 PHYSICAL SECTOR 1) FROM DRIVE (A-REG)
. AND EXECUTE IF GOOD FORMAT (LSB,MSB,-LSB,-MSB,0)
.
CALL    $$DOSDRIV    SELECT THE LOGICAL DRIVE GIVEN IN A-REG
FDSCLR    MASTER CLEAR ANY DRIVE IN USE ***
CALL    $$ONLINE    EXIT IF DRIVE NOT ON LINE
RTC      AND READY TO GO
.
CALL    $$RESTORE    TRY TO RESTORE THAT DRIVE
RTC      EXIT IF NOT ON LINE
.
LD      0            IPL BLOCK ON TRACK 0
LE      1            SECTOR 1
LLD    HL => PAGE WHERE IPL IS TO BE READ
LW     $DISKBUF>8
CALL   $$READ        READ THE IPL BLOCK
EX     CLICK        CLICK EACH ATTEMPTED READ
RTC    EXIT IF BAD READ
.
DL     DE,HL        ELSE GET THE STARTING ADDRESS
INCP   HL,2
DL     BC,HL        AND THE 1'S COMPLEMENT
INCP   HL,2
XREC
XRDB
INCP   BC
RFC    IF BC IS -1 (SHOULD BE) WILL SET CARRY
EXIT IF BAD IPL FORMAT
.
LAM
ORA
RFZ    THE 5TH BYTE MUST BE ZERO
EXIT IF BAD IPL FORMAT
.
PL     A,$LOGDRV    ELSE STORE DRIVE NUMBER THERE
LMA
PUSH  DE
LC     251          SAVE THE DESTINATION ADDRESS
XRA   FROM THE DISK BUFFER TO
LBA   THE STARTING ADDRESS
BT
POP   HL           START EXECUTING THE IPL
INCP  HL           AFTER THE DRIVE NUMBER
PUSH  HL
RET
.
IFEQ   ROMTYPE,3
INC    1800BCYN
XIF
    
```

113, G
 114, G
 115, G
 116, G
 117, G
 118, G
 119, G
 120, G
 121, G
 122, G
 123, G
 124, G
 125, G
 126, G
 127, G
 128, G
 129, G
 149, G
 150, G
 151, G
 152, G
 153, G
 154, G
 155, G
 156, .

```

*
RIMBOOT    IFGE      ROMTYPE,2
           DI
           XRA
           LBA
           LC        RIMDLLNL    THE DLL CODE IS MOVED TO BOTTOM MEMORY
           LEA
           LDA
           HL        RIMDLLS     FROM ITS COPY IN ROM
           BT
           JMP      000000      AND THEN JUMPED TO, NEVER TO RETURN
           .
RIMDLLS    EQU      $          RIM DOWN LINE LOAD ROUTINE
           LOC      0
           INC      RIMDLL
           LOC      *
           XIF
           XIF
           .
           IFEQ     ROMTYPE,1
           INC      1800BAPF    (ABOVE WARNING HOLDS FOR THIS MODULE TOO!)
           XIF
           .
           IFEQ     ROMTYPE,0
           INC      1800DIAG
    
```


55	H	172341	140	013	365	JTC	FSEEK	2 => SEEK BETWEEN TRACKS 2 AND 1
56	H	172344	150	001	365	JTZ	FFIND	3 => FIND TRACK 38 & DD READ IT
57	H							
58	H	172347	074	004		CP	4	
59	H	172351	110	213	364	JFZ	FDIAGDR	>4 TRY ANOTHER NUMBER
60	H					JTZ	FALIGN	4 => SEEK TO TRACK 38
61	H							
62	H	172354				FALIGN		
63	H							
64	H							
65	H							
66	H	172354	036	046		LD	38	STEP TO CORRECT ALIGNMENT TRACK
67	H	172356	046	000		LE	0	(ASSUMING TRACK ZERO FLAG CORRECT)
68	H	172360	106	201	365	CALL	SSSEEK	
69	H							
70	H	172363	016	000		FALoop	LB	READ (ACCEPT ANY DATA)
71	H	172365	076	335		LX	\$DATAS>8	(FROM THE CORRECT PAGE IN MEMORY)
72	H	172367	106	135	366	CALL	SSDOIO	
73	H	172372	106	102	373	CALL	DOSF60N	TEST THE KEYBOARD KEY
74	H	172375	120	363	364	JFS	FALoop	TO KNOW WHEN TO END
75	H							
76	H	172400	007			RET		
77	H							
78	H	172401				FFIND		
79	H							
80	H							
81	H							
82	H	172401	036	046		LD	38	
83	H	172403	046	000		LE	0	ANY SECTOR WILL DO
84	H	172405	106	125	365	CALL	FCHECKR	CHECK AND READ THE SECTOR
85	H	172410	104	001	365	JMP	FFIND	CONTINUE TILL STOPPED
86	H							
87	H	172413				FSEEK		
88	H							
89	H							
90	H							
91	H	172413	340			LEA		SAVE 2 OR 1 AS MARKER OF SEEK TYPE
92	H	172414	334			FSEEK1	LDE	TRACK 2 OR 1 SECTOR 2 OR 1
93	H	172415	106	125	365	CALL	FCHECKR	CHECK AND READ A SECTOR
94	H	172420	113	024	001	SUD	1	TRACK 1 OR 0 SECTOR 2 OR 1
95	H	172423	106	125	365	CALL	FCHECKR	READ THE OTHER TRACK/SECTOR
96	H	172426	104	014	365	JUMP	FSEEK1	

139	H									
140	H	172525								
141	H									
142	H									
143	H									
144	H	172525	106	102	373					
145	H	172530	170	125	365					
146	H	172533	160	112	365					
147	H									
148	H	172536	106	373	365					
149	H	172541	140	112	365					
150	H									
151	H	172544	106	201	365					
152	H									
153	H									
154	H	172547	056	320						
155	H	172551	106	071	366					
156	H	172554	003							
157	H	172555	153							
158	H	172556	007							
159	H									
160	H	172557	060							
161	H	172560	106	337	374					
162	H	172563	070							
163	H	172564	106	303	375					
164	H	172567	024	060						
165	H	172571	007							
166	H									
167	H	172572	007	052	105	122	122			
168	H									
157	H									
158	H									
159	H									
160	H									
161	H									
162	H									
163	H									
164	H									

```

*
FCHECKR
.
. READ A SECTOR (IF ABLE TO) ROUTINE
.
.      CALL      DOSF60N      TEST KBD/DSP KEYS (NO CURSOR TO BLINK)
.      JTP       FCHECKR     DSP KEY MEANS 'HOLD IT'
.      JTS       FDIAGEX     KBD KEY MEANS 'THAT'S ALL, FOLKS!'
.
.      CALL      $$ONLINE     SEE IF DISK IS STILL ON=LINE
.      JTC       FDIAGEX     IT ISN'T, JUST RETURN
.
.      CALL      $$SEEK       SEEK TO THE TRACK IN THE D-REGISTER
.                               BECAUSE OF CALL RESTDSK WILL DO RESTORE
.                               INITIALLY (AND ALWAYS)
.      LH        SEDSPBF>8    READ A SECTOR INTO THE DISPLAY
.      CALL      $$READ       BUFFER (MUST START ON A PAGE)
.      RFC
.      EX        CLICK       NOTE THAT ERROR WAS FOUND (OF SOME SORT)
.      RET
*
FGETRSP  POP      HL          HL => MESSAGE
        CALL     DISPDOS     DISPLAY IT
        PUSH    HL          PUT RETURN ADDRESS BACK ON STACK
        CALL     KEYCHAR     AND GET RESPONSE
        SU      '0'         UNBIAS ASCII DIGIT
        RET
*
FAUTOMSG DC      $BP,'*ERR*',SES
.
.      XIF
.
.      IFEQ     ROMTYPE,2
.      INC     1800RIMT
.      XIF
.
.      IFLE     ROMTYPE,1
.      INC     1800DSKR
    
```

3,I
 4,I
 5,I
 6,I 172601
 7,I
 8,I
 9,I
 10,I
 11,I
 12,I
 13,I
 14,I
 15,I
 16,I
 17,I
 18,I
 19,I 172601 106 371 366
 20,I 172604 105 221
 21,I 172606 074 377
 22,I 172610 110 220 365
 23,I
 24,I 172613 106 233 366
 25,I
 26,I
 27,I 172616 043
 28,I
 29,I 172617 250
 30,I 172620 223
 31,I 172621 053
 32,I
 33,I 172622 320
 34,I 172623 136 221
 35,I 172625 006 040
 36,I 172627 120 237 365
 37,I
 38,I 172632 250
 39,I
 40,I 172633 222
 41,I
 42,I 172634 320
 43,I 172635 006 020
 44,I
 45,I 172637 106 252 365
 46,I 172642 043
 47,I
 48,I 172643 062 024 001
 49,I 172646 110 237 365
 50,I
 51,I 172651 007

. 1800 DISKETTE INTERFACE ROUTINES MAY 10, 1978 12:13 HSP/HJS
 . \$\$SEEK
 . SEEK (MOVE HEAD) TO A TRACK
 .
 . ENTRY: D = DESIRED TRACK NUMBER (0=76)
 . STRACK = CURRENT TRACK NUMBER (ASSUMED TO BE ACCURATE)
 .
 . EXITS: ALL REGISTERS PRESERVED
 . STRACK = NEW CURRENT TRACK # (ASSUMING ENTRY VALUE ACCURATE)
 . (TC) = DRIVE OFF LINE OR RESTORE UNSUCCESSFUL
 . (FC) = SEEK COMPLETED
 . 5 EXTRA STACK LEVELS USED (MAX)
 .
 . CALL \$DSKSAVR SAVE ALL REGISTERS AND LOAD X
 . PL A,STRACK PICK UP LAST-KNOWN TRACK
 . CP =1 JUMP IF TRACK IS KNOWN
 . JFZ \$\$SEEKOK
 .
 . CALL \$RESTORX ELSE RESTORE (DON'T SAVE REGS AGAIN)
 . NOTE: THIS CALL HAS CALL BACK TO SEEK
 . AT LABEL SEEKOUT
 . RTC CATCH DRIVE OFF LINE OR BAD RESTORE
 .
 . XRA ELSE SET THE TRACK TO ZERO
 . SUD (ACTUAL)-(DESIRED)
 . RTZ DISK IS ALREADY THERE
 .
 . LCA SAVE THE DIFFERENCE
 . PS D,STRACK SAVE THE DESIRED TRACK NUMBER
 . LA FOMVOT MOVE OUT TOWARD THE RIM
 . JFS \$\$SEEKLOP IF DIFFERENCE POSITIVE
 .
 . XRA ELSE GET 2'S COMP OF NEG DIFFERENCE
 .
 . \$\$SEEKOUT SUC - ENTER HERE FROM \$\$RESTORE -
 . 5 EXTRA STACK LEVELS USED (MAX) & WAIT OVERHEAD
 .
 . LCA
 . LA FOMVIN AND MOVE IN TOWARD THE CENTER
 .
 . \$\$SEEKLOP CALL \$\$STEP STEP IN OR OUT BASED ON A-REG
 . RTC EXIT IF DRIVE OFF LINE
 .
 . SUC 1 ELSE DECREMENT THE DISTANCE TO GO
 . JFZ \$\$SEEKLOP KEEP STEPPING IF NOT ZERO
 .
 . RET ELSE RESTORE REGISTERS AND RETURN

```

52,I
53,I 172652
54,I
55,I
56,I
57,I
58,I
59,I
60,I
61,I
62,I
63,I
64,I
65,I
66,I
67,I
68,I 172652 107 203
69,I 172654 116 206
70,I 172656 114 223
71,I
72,I 172660 111 250
73,I 172662 105 222
74,I 172664 064 220
75,I 172666 145
76,I
77,I 172667 106 102 357
78,I
79,I 172672 105 222
80,I
81,I 172674 111 145
82,I
83,I 172676 301
84,I 172677 044 001
85,I 172701 152 275 366
86,I 172704 140 322 365
87,I
88,I 172707 301
89,I 172710 044 040
90,I 172712 110 267 365
91,I
92,I 172715 301
93,I 172716 044 100
94,I 172720 054 100
95,I
96,I 172722 114 206
97,I 172724 105 203
98,I 172726 007
    
```

```

+
$$STEP
.
. STEP IN OR OUT ONE TRACK
.
. ENTRY: A      = OPERATION (FOMVIN/FOMVOUT)
.          X      = $DATAS>8
.          $DRVNUM = DRIVE NUMBER (FODR0/FODR1)
.          $DEVADR = MICRO-BUS ADDRESS
.
. EXITS: ALL REGISTERS PRESERVED
.          (TC)(FZ) = DRIVE OFF LINE
.          (FC)(TZ) = TRACK 0 DETECTED
.          (FC)(FZ) = TRACK 0 NOT DETECTED
.          1 EXTRA STACK LEVELS USED (MAX) & WAIT OVERHEAD
.
. PS      A,$$AVXA      SAVE THE A-REGISTER
. PS      B,$$AVBC+1    SAVE THE B-REGISTER
. PL      B,$DRVNUM     B = DRIVE SELECT (1 OR 2)
. NDB     =1-FODR0-FODR1 ONLY THE BOTTOM 2 BITS ARE OK
. ORAB
. PL      A,$DEVADR     GET THE MICRO-BUS ADDRESS
. OR      FCOMOD        'OR' IN THE MODE
. UBOUT
.
. *
. $STEPWTL CALL      SVDISKWS      CALL THE "WAIT" ROUTINE
.
. PL      A,$DEVADR     GET THE BUS ADDRESS
. OR      FCINST        INPUT STATUS (= 0)
. UBIN
.
. LAB
. ND      FSONLN        CATCH DRIVE OFF LINE
. CTZ     TOFFTL        TURN OFF THE LIGHT AND SET
. JTC     $$STEPXIT     CARRY TRUE IF OFF LINE
.
. LAB
. ND      FSSTIP        WAIT IF STEP IN PROGRESS
. JFZ     $$STEPWTL
.
. LAB
. ND      FSTRK0        ELSE SEE IF TRACK 0 DETECTED
. XR      FSTRK0        EXIT FALSE CARRY TRUE ZERO IF SO
.
. $STEPXIT PL      B,$$AVBC+1    RESTORE (B)
. PL      A,$$AVXA      RESTORE (A)
. RET
    
```

```

099,I
100,I 172727
101,I
102,I
103,I
104,I
105,I
106,I
107,I
108,I
109,I
110,I
111,I
112,I
113,I 172727 022 070
114,I 172731 076 335
115,I 172733 105 222
116,I
117,I 172735 111 145
118,I 172737 301
119,I 172740 044 003
120,I 172742 074 003
121,I 172744 152 102 357
122,I 172747 150 333 365
123,I
124,I 172752 106 275 366
125,I
126,I 172755 105 222
127,I 172757 064 220
128,I 172761 114 223
129,I 172763 145
130,I 172764 105 222
131,I
132,I 172766 111 145
133,I 172770 022 060
134,I 172772 007
    
```

```

*
$$STATUS
. GET THE DISKETTE STATUS
.
. NOTE: THIS ROUTINE SHOULD NOT BE CALLED IF TRANSFERS ARE STILL
. IN PROGRESS. (NORMALLY DOESN'T HAPPEN, ALL I/O INSIDE $$DIO)
.
. ENTRY: $DEVADR = MICRO-BUS ADDRESS
. $DRVNUM = DRIVE NUMBER (FODR0/FODR1)
.
. EXITS: B = DEVICE STATUS
. 1 EXTRA STACK LEVELS USED (MAX)
.
. PUSH XA SAVE THE XA REGISTER PAIR
. LX $DATAS>8 SET UP THE PAGE REGISTER
. PL A,$DEVADR SEE IF THE CONTROLLER IS IN ACTION
. OR FCINST BY CHECKING ITS STATUS
. UBIN THIS CAUSES A WAIT ON LAST ACTION IF
. LAB ACCIDENTLY ENTER HERE TO CHANGE DRIVES
. ND FSONLN+FSTRIP IF BOTH ONLINE AND TRANSFER IN PROGRESS
. CP FSONLN+FSTRIP ARE SET (SOMETHING GOING ON)
. CTZ SVDISKWS WAIT (CC NOT MODIFIED) AND
. JTZ STATWAIT LOOP TILL ONE GOES AWAY
.
. CALL TOFFTL THIS WILL CLEAR FSTRIP IF STILL SET
.
. PL A,$DEVADR GET THE MICRO-BUS ADDRESS
. OR FCOMOD SET MODE TO SELECT DRIVE
. PL B,$DRVNUM B = DRIVE NUMBER (FODR0/FODR1)
. UBOU SELECT A DRIVE
. PL A,$DEVADR GET THE MICRO-BUS ADDRESS
. OR FCINST INPUT STATUS
. UBIN GET STATUS INTO (B)
. POP XA RESTORE THE XA REGISTER PAIR
. RET
    
```

```

135,I
136,I 172773
137,I
138,I
139,I
140,I
141,I
142,I
143,I
144,I
145,I
146,I
147,I
148,I 172773 022 070
149,I 172775 076 335
150,I 172777 116 206
151,I 173001 106 327 365
152,I 173004 301
153,I 173005 044 001
154,I 173007 152 275 366
155,I 173012 140 020 366
156,I
157,I 173015 111 044 010
158,I 173020 114 206
159,I 173022 022 060
160,I 173024 007
    
```

```

+
$$ONLINE
.
. CHECK FOR DRIVE ON=LINE AND READY
.
. ENTRY: (SAME AS FOR $$STATUS)
.
. EXITS: ALL REGISTERS PRESERVED
. (TC)(FZ) = DRIVE OFF LINE OR NOT READY
. (FC)(TZ) = DRIVE ON LINE AND WRITE ENABLED
. (FC)(FZ) = DRIVE ON LINE AND WRITE PROTECTED
. 3 EXTRA STACK LEVELS USED (MAX)
.
. PUSH XA SAVE (XA)
. LX $DATAS>8
. PS B,$$AVBC+1 SAVE (B)
. CALL $$STATUS GET DISKETTE STATUS
. LAB IN THE A-REGISTER
. ND FSONLN (DRIVE MAY BE CHANGED BY $STATUS CALL)
. CTZ TOFFTL TURN OFF THE LIGHT IF NOT READY
. JTC ONLINXIT JUST EXIT IF NOT ON LINE
.
. ONLINXIT NDB FSPRO SET FALSE ZERO IF FILE PROTECTED
. PL B,$$AVBC+1 RESTORE (B)
. POP XA RESTORE (XA)
. RET
    
```

```

161,I
162,I 173025
163,I
164,I
165,I
166,I
167,I
168,I
169,I
170,I
171,I
172,I
173,I
174,I
175,I
176,I
177,I
178,I 000007
179,I 000006
180,I
181,I 173025 106 371 366
182,I 173030 066 000
183,I 173032 105 222
184,I
185,I 173034 016 060
186,I 173036 141
187,I 173037 043
188,I
189,I 173040 016 050
190,I 173042 141
191,I 173043 043
192,I
193,I 173044 174 134 212
194,I 173047 016 050
195,I 173051 106 135 366
196,I 173054 110 113 366
197,I
198,I 173057 105 211
199,I 173061 074 006
200,I 173063 053
    
```

```

+
SSWRITE
.
. WRITE A SECTOR (DOUBLE DENSITY)
.
. ENTRY: H = MSB OF MEMORY BUFFER
.         D = TRACK TO BE WRITTEN
.         E = SECTOR TO BE WRITTEN
.         A = WRITE/ WRITE=VERIFY CONTROL
.
. EXITS: ALL REGISTERS PRESERVED
.        STRACK = TRACK WRITTEN
.        SSECTOR = SECTOR WRITTEN
.        (TC)   = MISSING D.C. GAP OR CRC ERROR DURING VERIFY
.        (FC)   = DATA WRITTEN FROM THE PAGE POINTED TO BY H-REG
.        3 EXTRA STACK LEVELS USED (MAX)
.
DSKWV EQU 7 DISK WRITE/VERIFY
DSKWRT EQU 6 DISK WRITE = NO VERIFY
.
CALL $DSKSAVR SAVE ALL REGISTERS AND LOAD X
LL 0 INITIALIZE (L) TO 0'ITH BYTE
PL A,$DEVADR GET THE DEVICE ADDRESS
.
LB FDWPI LOAD WRITE PREAMBLE
FDDATA
RTC CATCH OPERATION IN PROGRESS
.
LB FDOTD LOAD BUFFER DOUBLE DENSITY
FDDATA
RTC CATCH OPERATION IN PROGRESS
.
DPLR DE,$DSKREGS-4 RESTORE THE TRACK/SECTOR
LB FFWRITE+FFDBL DO DOUBLE DENSITY WRITE
CALL $$DOIO
JFZ $DSKERR CATCH NO D.C. GAP OR SECTOR NOT FOUND
.
PL A,$DSKREGS-5 GET THE OPERATION CODE
CP DSKWRT JUST EXIT TRUE ZERO FALSE CARRY
RTZ IF NON-VERIFIED WRITE OPERATION
    
```


201,I
 202,I
 203,I
 204,I 173064 006 030
 205,I 173066 104 100 366
 206,I
 207,I 173071
 208,I
 209,I
 210,I
 211,I
 212,I
 213,I
 214,I
 215,I
 216,I
 217,I
 218,I
 219,I
 220,I
 221,I
 222,I 173071 106 371 366
 223,I 173074 066 000
 224,I 173076 006 010
 225,I
 226,I 173100 106 133 366
 227,I 173103 110 113 366
 228,I
 229,I 173106 310
 230,I 173107 105 222
 231,I 173111 141
 232,I 173112 003
 233,I
 234,I 173113 006 200
 235,I 173115 200
 236,I 173116 007
 237,I
 238,I 173117
 239,I
 240,I
 241,I
 242,I
 243,I
 244,I
 245,I
 246,I
 247,I
 248,I
 249,I
 250,I
 251,I
 252,I

```

*
. DO "WRITE-VERIFY" - RE-READ & COMPUTE CRC)
.
.          LA          FDVRD          DO DOUBLE DENSITY READ/VERIFY
.          JMP          READDATA
*
. $SREAD
.
. READ A SECTOR (DOUBLE DENSITY)
.
.          ENTRY: H = MSB OF MEMORY BUFFER
.                  D = TRACK TO BE READ
.                  E = SECTOR TO BE READ
.
.          EXITS: ALL REGISTERS PRESERVED
.                  $TRACK = TRACK READ
.                  $SECTOR = SECTOR READ
.                  (TC) = MISSING D.C. GAP OR CRC ERROR DURING READ
.                  (FC) = DATA READ INTO THE PAGE POINTED TO BY THE H-REG
.                  3 EXTRA STACK LEVELS USED (MAX)
.
.          CALL          $SDKSAVR          SAVE ALL REGISTERS AND LOAD X
.          LL          0          MAKE HL => START OF BUFFER PAGE
.          LA          FDIND          CAUSE INPUT OF DOUBLE DENSITY DATA
.
. READDATA CALL          $$DOIODR          DO DOUBLE DENSITY READ
.          JFZ          $DSKERR          CATCH SOMETHING WRONG
.
.          LBA
.          PL          A,$DEVADR          GET THE DEVICE ADDRESS
.          FDDATA          GET THE DATA CHECKING CRC
.          RFC          EXIT IF DATA READ OR VERIFY OKAY
.
. $DSKERR LA          0200          SET CARRY TRUE
.          ADA
.          RET
*
. $$BUFIO
.
. PERFORM AN FDDATA OPERATION
.
.          ENTRY: B = SUBFUNCTION NUMBER
.                  C = VALUE USED BY FDDATA (IF B = FDOUT)
.                  HL = LOCATION OF DATA AREA IN MEMORY (IF USED)
.                  $DEVADR = MICRO-BUS ADDRESS
.
.          EXITS: X = MSB OF $DATAS
.                  A,C = SCRATCHED
.                  B = CHANGED (LEAST SIGNIFICANT TWO BITS)
.                  2 EXTRA STACK LEVELS USED (MAX)
.
.          NOTE: !! TO MAKE ROOM, MAY WANT TO TRIM THIS ROUTINE DOWN TO
    
```



```

305,I 173203 113 146 220
306,I 173206 062 044 004
307,I
308,I 173211 113 144 205
309,I 173214 124 204
310,I 173216 105 203
311,I 173220 007
312,I
313,I
314,I
315,I 173221 111 143
316,I 173223 064 001
317,I 173225 104 211 366
318,I
319,I 173230
320,I
321,I
322,I
323,I
324,I
325,I
326,I
327,I
328,I
329,I
330,I
331,I 173230 106 371 366
332,I
333,I 173233 250
334,I 173234 107 221
335,I 173236 026 374
336,I 173240 106 233 365
337,I 173243 043
338,I
339,I 173244 026 117
340,I
341,I
342,I 173246 006 040
343,I 173250 106 252 365
344,I 173253 043
345,I 173254 053
346,I
347,I 173255 062 024 001
348,I 173260 100 246 366
349,I
350,I 173263 007
    
```

```

DPS DE,$SECTOR ELSE SAVE THE SECTOR/TRACK USED
NDC FRINDX EXIT TRUE ZERO IF NOT 4 INDEXES
*
$DOIOXIT DPL DE,$SAVBC RESTORE (DE)
PL C,$SAVXA+1 RESTORE (C)
PL A,$SAVXA RESTORE (A)
RET
*
DO A STATUS CLEAR AND CAUSE RETURN FALSE ZERO
*
$DOIOERR FDSCLR
OR 1
JMP $DOIOXIT
*
$SRESTORE
*
SEEK TRACK 0 ON SELECTED DRIVE
*
ENTRY: $DRVNUM = DRIVE NUMBER (FODR0/FODR1)
$DEVADR = PHYSICAL DEVICE ADDRESS
*
EXITS: ALL REGISTERS PRESERVED
(TC) = DRIVE OFF LINE OR TRACK 0 NOT FOUND
(FC) = DISKETTE AT TRACK 0 AND $TRACK = 0
4 EXTRA STACK LEVELS USED (MAX) & WAIT OVERHEAD
*
CALL $DSKSAVR SAVE THE REGISTERS AND SET UP X
*
$RESTORX XRA = ENTERED HERE FROM $$SEEK =
PS A,$TRACK SET THE TRACK NUMBER TO 0
LC =4 CAUSE "SEEK" TO STEP IN 4 TRACKS
CALL $SEEKOUT
RTC CATCH DRIVE OFF LINE
*
LC MAXTRAK+3 THEN STEP OUT UNTIL TRACK 0
OR THE MAXIMUM NUMBER OF TRACKS
(+3 AS A SAFETY OF PAST TRACK 77)
*
$RESTORL LA STEP OUT
CALL FOMVOT
RTC $SSTEP
RTZ CATCH DRIVE OFF LINE
EXIT RESTORING REGS WHEN TRACK 0
*
SUC 1 ELSE DECREMENT TRACK COUNT
JFC $RESTORL KEEP GOING IF NOT OUT OF RANGE
ELSE EXIT TRUE CARRY FALSE ZERO
RET RESTORE REGISTERS AND EXIT
    
```

```

351,I
352,I 173264
353,I
354,I
355,I
356,I
357,I
358,I
359,I
360,I
361,I
362,I
363,I 173264 076 335
364,I 173266 146 222
365,I 173270 304
366,I 173271 064 220
367,I 173273 313
368,I 173274 145
369,I
370,I
371,I 173275
372,I
373,I
374,I
375,I
376,I
377,I
378,I
379,I
380,I
381,I
382,I
383,I 173275 105 222
384,I 173277 064 060
385,I 173301 016 177
386,I 173303 145
387,I 173304 006 201
388,I 173306 200
389,I 173307 007
    
```

```

+
TOFFTLDE
.
.   TURN OFF THE LIGHT IN THE SPECIFIED DRIVE
.
.   ENTRY: D = DRIVE SELECT CODE (1 OR 2)
.           E = DRIVE CONTROLLER NUMBER (0 THRU 3)
.
.   EXITS: X      = $DATAS PAGE
.           $DEVADR = DRIVE CONTROLLER NUMBER
.           A,B    = SCRATCHED
.
.   LX      $DEVADR>8
.   PS      E,$DEVADR      SET THE CONTROLLER ADDRESS
.   LAE     SELECT THE DRIVE IN (D)
.   OR      FCOMOD
.   LBD
.   UBOUT
.
.           FALLS THROUGH INTO "TOFFL"
.
+
TOFFTL
.
.   TURN OFF THE LIGHT AND RETURN TRUE CARRY FALSE ZERO
.   ALSO WILL CLEAR ALL INTERRUPTS PENDING AND
.   RESET THE MASTER READ/WRITE FLIP/FLOPS
.
.   ENTRY: X      = $DATAS PAGE
.           $DEVADR = DEVICE (DRIVE ALREADY SELECTED)
.
.   EXITS: LIGHT TURNED OFF, CLEARED ALL INTERRUPTS & RESET MASTER FLOPS
.           (TC)(FZ)
.
.   PL      A,$DEVADR
.   OR      FCLEAR
.   LB      FKLOFF+FKMAST
.   UBOUT
.   LA      0201
.   ADA
.   RET
    
```

```

390,I
391,I 173310
392,I
393,I
394,I
395,I
396,I
397,I
398,I
399,I
400,I
401,I
402,I
403,I
404,I
405,I 173310 106 371 366
406,I
407,I 173313 105 207
408,I 173315 044 007
409,I 173317 310
410,I
411,I 173320 105 217
412,I 173322 271
413,I 173323 053
414,I
415,I 173324 056 335
416,I 173326 200
417,I 173327 140 343 366
418,I
419,I 173332 044 016
420,I 173334 066 224
421,I 173336 017
422,I 173337 113 144 220
423,I 173342 027
424,I
425,I 173343 116 217
426,I 173345 066 224
427,I 173347 301
428,I 173350 200
429,I 173351 017
430,I 173352 047
431,I 173353 113 146 220
432,I
433,I 173356 111 032
434,I 173360 006 001
435,I 173362 014 000
436,I 173364 107 223
437,I 173366 116 222
438,I 173370 007
    
```

```

+
$$DOSDRIV
.
. SWAP IN DOS LOGICAL DRIVE INFO.
.
. ENTRY: A = DOS LOGICAL DRIVE NUMBER (0-7)
.
. EXITS: ALL REGISTERS PRESERVED
. $LOGDRV = SELECTED LOGICAL DRIVE (0 THRU 7)
. STRACK = CURRENT TRACK FOR THAT DRIVE
. $SECTOR = CURRENT SECTOR FOR THAT DRIVE
. $DRVNUM = DRIVE SELECT CODE (1 OR 2)
. $DEVADR = DRIVE MICRO-BUS ADDRESS (0, 1, 2, OR 3)
. 2 EXTRA STACK LEVELS USED (MAX)
.
CALL $DSKSAVR SAVE THE REGISTERS AND SET UP X
.
PL A,$DSKREGS=7 GET THE A-REGISTER BACK
ND $DRVBLN LIMIT TO THE MAXIMUM DRIVE NUMBER
LBA SAVE THE DRIVE NUMBER IN B-REG
.
PL A,$LOGDRV GET CURRENT DOS LOGICAL DRIVE NUMBER
CPB EXIT RESTORING REGISTERS
RTZ IF SAME DRIVE AS LAST TIME
.
LH $DRVTAB>8 SET UP THE H-REGISTER
ADA GENERATE INDEX INTO $DRVTAB
JTC $DOSDF0 CATCH NO CURRENT DRIVE
.
ND $DRVBLN<1 MAKE SURE $LOGDRV VALUE GOOD
LL $DRVTAB INDEX INTO THE $DRVTAB TABLE
INCP HL,A
DPL DE,$SECTOR GET CURRENT $SECTOR/STRACK
DS DE,HL SAVE IT IN THE $DRVTAB ENTRY
.
$DOSDF0 PS B,$LOGDRV SAVE THE NEW LOGICAL DRIVE NUMBER
LL $DRVTAB INDEX INTO THE $DRVTAB
LAB
ADA
INCP HL,A (CARRY WILL BE CLEAR!! AFTER THIS)
DL DE,HL GET THE $SECTOR/STRACK FOR NEW DRIVE
DPS DE,$SECTOR STORE IT INTO THE CURRENT $SECTOR/STRACK
.
SREB
LA FODR0 DIVIDE IT BY TWO & LSBIT TO CARRY
AC FODR1=FODR1 A = RIGHT HAND DRIVE IF CARRY CLEAR
PS A,$DRVNUM A = LEFT HAND DRIVE IF CARRY SET
PS B,$DEVADR SAVE THE DRIVE SELECT
RET AND SAVE THE MICRO-BUS ADDRESS
RESTORE REGISTERS AND EXIT
    
```

```

439,I
440,I 173371
441,I
442,I
443,I
444,I
445,I 173371 051 216 335
446,I 173374 055
447,I 173375 022 060
448,I 173377 022 060
449,I 173401 051 011 367
450,I 173404 022 070
451,I 173406 076 335
452,I 173410 007
453,I
454,I 173411
455,I
456,I
457,I
458,I 173411 066 216 056 335
459,I 173415 111 055
460,I 173417 007
461,I
462,I 173420
463,I
464,I
465,I
466,I 173420 006 377
467,I 173422 066 200 056 335 370
468,I 173427 335
469,I 173430 046 201
470,I 173432 026 043
471,I 173434 250
472,I 173435 310
473,I 173436 021
474,I 173437 007
165,I
166,I
167,I
168,I
169,I 173440 000 000 000 000 000
170,I
171,I
172,I
173,I
174,I
175,I
176,I
    
```

```

*
SDSKSAVR
.
. DISK ROUTINE REGISTER SAVE AND PAGE REGISTER SET UP
. 1 STACK LEVEL ADDITIONALLY CREATED
.
. PUSH SDSKREGS
. REGS
. POP XA GET RID OF "SDSKREGS" ADR ON THE STACK
. POP XA XA = RETURN ADDRESS
. PUSH SDSKRESR MAKE RETURNS AFTER THIS GO TO "SDSKRESR"
. PUSH XA PUT RETURN ADR BACK ON THE STACK
. LX $DATAS>8 SET UP THE PAGE REGISTER
. RET

*
SDSKRESR
.
. RESTORE THE DISK ROUTINE REGISTERS AND EXIT
.
. HL SDSKREGS
. REGL
. RET

*
RESTDSK
.
. SET ALL DISK CONTROL VARIABLES SO ALL DRIVES MUST BE INITIALIZED (RESTORED)
.
. LA =1 INITIALIZE ALL THE DISK VARIABLES
. MSA *$DATAS TO ALL 1'S
. LDH
. LE $DATAS+1
. LC $DATAL-1
. XRA
. LBA
. BT
. RET
. XIF

.
. IFEQ ROMTYPE,0 (MAKE SPACE HERE SO LAST ROMS THE SAME)
. RPT 05
. DC 0
. XIF
. IFEQ ROMTYPE,2 (MAKE SPACE HERE SO LAST ROMS THE SAME)
. RPT 0330
. DC 0
. XIF

.
. INC 1800DEBUG
    
```

3 J
 4 J
 5 J
 6 J 173445
 7 J
 8 J
 9 J
 10 J 173445 106 242 372
 11 J
 12 J 173450 111 124 207
 13 J 173453 174 047
 14 J 173455 174 035
 15 J 173457 066 211 056 327
 16 J 173463 117 015
 17 J 173465 176 074 251
 18 J 173470 150 120 367
 19 J
 20 J 173473 307
 21 J 173474 015
 22 J 173475 274
 23 J 173476 110 063 367
 24 J
 25 J 173501 307
 26 J 173502 273
 27 J 173503 110 063 367
 28 J
 29 J 173506 015
 30 J 173507 307
 31 J 173510 174 370
 32 J 173512 174 027
 33 J 173514 035
 34 J 173515 006 377
 35 J 173517 370
 36 J 173520 113 146 200
 37 J 173523 151
 38 J 173524 104 133 367
 39 J
 40 J 173527
 41 J
 42 J
 43 J
 44 J 173527 040
 45 J
 46 J 173530 106 242 372

• 1800 DEBUG COMMAND INTERPRETER JUN 14, 1978 12:00 HSP/HJS
 • BRKPNR
 • BREAK POINT EXECUTION ENTRY
 • CALL SSTATE SAVE THE STATE OF THE MACHINE
 LX CURADR>8 INIT THE PAGE REGISTER (BY SSTATE)
 DPL BC,OLDTOS GET THE BREAK POINT ADDRESS
 DL DE,BC
 DECP DE
 HL BPTABL=BPTES+1 SEARCH TABLE FOR ADDRESS
 BRKPNL INCP HL,2 BUMP MEMORY POINTER TO NEXT ENTRY
 CPL BPTABE STOP WHEN AT END OF TABLE
 JTZ BRKPNN
 • LAM HL ELSE SEE IF ADDRESSES MATCH
 INCP HL
 CPE
 JFZ BRKPNL
 • LAM HL
 CPD
 JFZ BRKPNL
 • INCP HL RESTORE CONTENTS IF MATCH FOUND
 LAM HL
 LMA DE
 DS DE,BC UPDATE TOS ENTRY WITH BP LOCATION
 DECP HL CLEAR THE BREAK POINT
 LA -1
 LMA
 BRKPNN DPS DE,CURADR DISPLAY THE POINT AS CURRENT ADDRESS
 EX BEEP MAKE SOME NOISE
 JMP DSPCAD THEN GO TO DEBUG
 *
 DEBUG
 • RETURN FROM DEBUG "CALL" ENTRY
 • DI MAKE SURE INTERRUPTS WON'T BOTHER ME
 INTERRUPTS MAY BE ON AFTER THE 'CALL'
 • CALL SSTATE SAVE THE MACHINE STATE

47 J
48 J 173533
49 J
50 J
51 J
52 J
53 J
54 J
55 J

*
DEBUGI
*
* ENTRY FROM "RESTART" INVOCATION
*

	IFS	ASCII	
	XRA		CLEAR ASCII KEYIN MODE
KEYINS	PS	A,KEYINF	SET ASCII KEYIN MODE FLAG TO A=REG
	XIF		


```

58 J
59 J 173533
60 J
61 J
62 J
63 J 173533 076 327
64 J
65 J
66 J
67 J
68 J
69 J
70 J
71 J
72 J
73 J
74 J
75 J
76 J
77 J
78 J
79 J
80 J 173535 046 010
81 J 173537 111 124 200
82 J 173542 062 070
83 J 173544 106 154 372
84 J 173547 060
85 J 173550 070
86 J 173551 016 040
87 J 173553 327
88 J 173554 046 011
89 J 173556 036 111
90 J 173560 106 312 374
91 J 173563 371
92 J 173564 015
93 J 173565 111 027
94 J 173567 066 003
95 J 173571 106 156 372
96 J 173574 060
97 J 173575 111 047
98 J 173577 046 012
99 J 173601 106 154 372
100 J 173604 051 133 367
    
```

```

*
DSPCAD
*
* PUT UP DEBUG "CURRENT ADDRESS" DISPLAY
*
LX          CURADR>8      SET UP THE PAGE REGISTER (SAFTEY)
IFS         ORIGINI
DPL         DE,CURORG     DE = CURRENT ORIGIN
LAE
ORD
LE          BL=4          ERASE 4TH TO BOTTOM LINE
LD          73            IF ORIGIN IS ZERO
CTZ         D0SF69        (ERASE TO END OF LINE)
DPL         DE,CURORG     DE = CURRENT ORIGIN
DPL         BC,CURADR     BC => CURRENTLY ADDRESSED SLOT
SUEC
SBOB
LAE
ORD
LE          BL=4          DISPLAY THE LOGICAL ADR ON 4TH TO BOTTOM
CFZ         DSPOC6        LINE IF CURRENT ORIGIN IS NOT ZERO
XIF
LE          BL=3          DISPLAY THE PHYSICAL ADDRESS ON
DPL         BC,CURADR     THE 3RD TO THE BOTTOM LINE
PUSH       BC            SAVE THE PHYSICAL ADDRESS
CALL       DSPOC6
POP        HL            RESTORE THE ADDRESS
PUSH       HL            LEAVE IT ON THE STACK
LB         040
LCM
LE          BL=2
LD          73
CALL       DSPCBL        (WRITE CHARACTERS IN BC=REGS)
LMB
INCP       HL
DS         BC,HL        PUT OUT BLANK, CHARACTER, BLANK
LL         3            DISPLAY THE CHARACTER VALUE
CALL       DSPOCR        (B CLOSE ENOUGH TO 0 FOR DSPOCR OF 3)
POP        HL            RESTORE THE ADDRESS OF THE ITEM
DL         BC,HL        DISPLAY THE 6 DIGIT CONTENTS
LE          BL=1          ON THE NEXT TO BOTTOM LINE
CALL       DSPOC6
PUSH       DSPCAD
    
```

```

101 J
102 J 173607
103 J
104 J
105 J
106 J 173607 046 013 036 106
107 J 173613 026 000
108 J 173615 312
109 J 173616 062 070
110 J 173620 106 303 375
111 J 173623 062 060
112 J 173625 076 327
113 J
114 J
115 J
116 J
117 J
118 J
119 J
120 J
121 J
122 J 173627 074 015
123 J 173631 150 247 370
124 J 173634 074 030
125 J 173636 150 207 367
126 J 173641 074 010
127 J 173643 150 131 370
128 J 173646 074 077
129 J 173650 150 071 372
130 J 173653 074 056
131 J 173655 150 340 370
132 J 173660 074 136
133 J 173662 150 324 370
134 J 173665 074 043
135 J 173667 150 066 371
136 J 173672 074 101
137 J 173674 140 150 370
138 J 173677 074 173
139 J 173701 100 150 370
140 J 173704 066 224 056 367
141 J 173710 074 133
142 J 173712 140 326 367
143 J 173715 066 040 056 367
144 J 173721 074 141
145 J 173723 140 150 370
    
```

```

*
GETCMD
. GET THE NEXT COMMAND FROM THE KEYBOARD
.
DE NECP<8+BL GET THE COMMAND LINE CURSOR POSITION
LC 0 ZERO THE COMMAND VALUE ACCUMULATOR
LBC
GETCML PUSH BC SAVE THE COMMAND VALUE SO FAR
CALL KEYCHAR GET CHAR FROM KEYBOARD FLASHING CURSOR
POP BC RESTORE THE COMMAND VALUE SO FAR
LX CURADR>8 SET UP THE PAGE REGISTER (SAFTEY)
.
IFS ASCII
PL L,KEYINF CATCH BEING IN ASCII KEYIN MODE
ORLL
JFZ KEYINA ENTER ASCII CHARACTER IF SO
XIF
*
. CHECK FOR SPECIAL COMMAND CHARACTERS
.
CP ENTER DECODE THE COMMAND
JTZ NEWADR
CP CAN CANCEL COMMAND IF CANCEL KEY
JTZ GETCMD
CP BSP BACKSPACE ONE IF BACKSPACE KEY
JTZ BACKSP
CP '?!' CATCH IDENTIFICATION INQUERY
JTZ IDENT
CP '!!' MODIFY AND INCREMENT
JTZ MODINC
CP '!A' MODIFY AND INCREMENT USING LAST VALUE
JTZ MODAGN
CP '!##' # - CLEAR ALL BREAK POINTS
BPCLR RESTORING VALUES
CP '!A' TRY TO ACCUMULATE OCTALS IF NOT LETTERS
JTC GETDIG
CP '!'+1 (LOWER CASE 'Z')
JFC GETDIG
HL =>'A'<1+CMDTS HL => COMMAND LETTER TABLE
CP '!Z'+1 BASED ON SHIFT CASE
JTC DOCMDL
HL =>'!'+1+CMDTNS (LOWER CASE 'A')
CP '! '
JTC GETDIG
    
```

```

146,J
147,J 173726
148,J
149,J
150,J
151,J
152,J 173726 200
153,J 173727 017
154,J 173730 057
155,J 173731 070
156,J 173732 012
157,J 173733 115 164 211
158,J 173736 113 074 106
159,J 173741 007
160,J
161,J 173742
162,J
163,J
164,J
165,J
166,J 173742 200 371
167,J
168,J
169,J
170,J
171,J 173744 004 371
172,J 173746 360 371
173,J 173750 257 370
174,J 173752 326 371
175,J
176,J 173754 200 371
177,J 173756 200 371
178,J
179,J
180,J
181,J
182,J
183,J
184,J 173760 205 364
185,J
186,J
187,J
188,J
189,J
190,J
191,J
192,J
193,J
194,J
195,J 173762 211 370
196,J 173764 373 371
197,J
    
```

*
 DOCMDL

. INDEX INTO THE ADDRESS TABLE POINTED TO BY (HL)
 . AND JUMP OFF TO THE INDICATED ADDRESS.

ADA		INDEX INTO THE GIVEN TABLE
INCP	HL,A	BY THE COMMAND LETTER
DL	HL,HL	SET UP TO JUMP TO THE COMMAND
PUSH	HL	
SRC		RESTORE THE COMMAND LETTER
DPL	HL,OLDREGS	HL => REGISTER STORAGE
CPD	NECP	SET TRUE ZERO IF NO DIGITS ENTERED
RET		

*
 CMDTNS

. UNSHIFTED COMMAND ROUTINE ADDRESS TABLE

IFNE	ROMTYPE,3	
DA	ADRDEV	A = ADDRESS THE GIVEN OR LAST I/O DEVICE
XIF		
IFEQ	ROMTYPE,3	
DA	GETCME	A = * NOT USED * (5500 I/O BUS)
XIF		
DA	BPSET	B = SET A BREAK POINT AT GIVEN OR CURADR
DA	CALL	C = CALL THE GIVEN OR CURRENT ADDRESS
DA	DECADR	D = DECREMENT THE CURRENT ADDRESS
DA	EXECUT	E = CONTINUE EXECUTION
IFNE	ROMTYPE,3	
DA	ADRDEV	F = FETCH NEXT DATA BYTE FROM CURRENT I/O
DA	ADRDEV	G = GOTO DATA MODE IN THE CURRENT I/O
XIF		
IFEQ	ROMTYPE,3	
DA	GETCME	F = * NOT USED * (5500 I/O BUS)
DA	GETCME	G = * NOT USED * (5500 I/O BUS)
XIF		
IFEQ	ROMTYPE,0	
DA	FDIAG	H = HARDWARE FLOPPY DIAGNOSTIC
XIF		
IFEQ	ROMTYPE,1	
DA	APFDMP	H = APF MEMORY DUMP
XIF		
IFEQ	ROMTYPE,2	
DA	TSTRIM	H = EXTERNAL RIM BUFFER TEST
XIF		
IFEQ	ROMTYPE,3	
DA	GETCME	H = * NOT USED * (HARDWARE DIAGNOSTIC)
XIF		
DA	INCADR	I = INCREMENT THE CURRENT ADDRESS
DA	JUMP	J = JUMP TO THE GIVEN OR CURRENT ADDRESS
IFS	ASCII	

198,J			DA	KEYINM	K = SET ASCII KEYIN MODE
199,J			XIF		
200,J			IFC	ASCII	
201,J	173766	125 370	DA	GETCME	K = * NOT USED * (ASCII KEYIN)
202,J			XIF		
203,J	173770	233 370	DA	LINK	L = LINK TO ADR POINTED TO BY CURADR
204,J	173772	343 370	DA	MODIFY	M = MODIFY THE CURRENT ADDRESS CONTENTS
205,J			IFS	ORIGINI	
206,J			DA	NOSADR	N = SET NON-OFFSET ADDRESS
207,J			DA	ORIGIN	O = CLEAR OR SELECT ORIGIN
208,J			XIF		
209,J			IFC	ORIGINI	
210,J	173774	125 370	DA	GETCME	N = * NOT USED * (ORIGIN OFFSET)
211,J	173776	125 370	DA	GETCME	O = * NOT USED * (ORIGIN SELECT)
212,J			XIF		
213,J			IFNE	ROMTYPE,3	
214,J	174000	133 371	DA	BASSET	P = DISPLAY BASE REGISTER OR LOAD WITH BC = 0100000
215,J					
216,J	174002	160 371	DA	STLOAD	Q = LOAD THE SECTOR TABLE
217,J			XIF		
218,J			IFEQ	ROMTYPE,3	
219,J			DA	GETCME	P = * NOT USED * (BASE REGISTER)
220,J			DA	GETCME	Q = * NOT USED * (SECTOR TABLE)
221,J			XIF		
222,J	174004	120 371	DA	REGMOD	R = SWITCH ALPHA/BETA REGISTER MODE
223,J	174006	357 370	DA	STACKD	S = DISPLAY THE SPECIFIED STACK ITEM
224,J	174010	360 375	DA	TSTMEM	T = START MEMORY TEST ('12345T')
225,J	174012	314 371	DA	EXEUSR	U = USER MODE EXECUTE
226,J			IFNE	ROMTYPE,3	
227,J	174014	273 371	DA	OUTXC4	V = EX COM4 TO LAST I/O DEVICE
228,J	174016	247 371	DA	OUTXWT	W = EX WRITE TO LAST I/O DEVICE
229,J	174020	254 371	DA	OUTXC1	X = EX COM1 TO LAST I/O DEVICE
230,J	174022	261 371	DA	OUTXC2	Y = EX COM2 TO LAST I/O DEVICE
231,J	174024	266 371	DA	OUTXC3	Z = EX COM3 TO LAST I/O DEVICE
232,J			XIF		
233,J			IFEQ	ROMTYPE,3	
234,J			DA	GETCME	V = * NOT USED * (5500 I/O BUS)
235,J			DA	GETCME	W = * NOT USED * (5500 I/O BUS)
236,J			DA	GETCME	X = * NOT USED * (5500 I/O BUS)
237,J			DA	GETCME	Y = * NOT USED * (5500 I/O BUS)
238,J			DA	GETCME	Z = * NOT USED * (5500 I/O BUS)
239,J			XIF		

240 J
 241 J 174026
 242 J
 243 J
 244 J
 245 J 174026 310 370
 246 J 174030 303 370
 247 J 174032 302 370
 248 J 174034 305 370
 249 J 174036 304 370
 250 J 174040 301 370
 251 J 174042 125 370
 252 J 174044 307 370
 253 J 174046 321 371
 254 J 174050 037 372
 255 J 174052 125 370
 256 J 174054 306 370
 257 J 174056 125 370
 258 J 174060 125 370
 259 J
 260 J
 261 J
 262 J
 263 J 174062 125 370
 264 J
 265 J
 266 J 174064 133 371
 267 J
 268 J
 269 J
 270 J
 271 J 174066 125 370
 272 J
 273 J
 274 J
 275 J
 276 J
 277 J 174070 125 370
 278 J 174072 125 370
 279 J
 280 J 174074 125 370
 281 J 174076 125 370
 282 J 174100 125 370
 283 J 174102 125 370
 284 J 174104 311 370
 285 J
 286 J 174106 235 371
 287 J 174110 242 371
 288 J
 289 J
 290 J
 291 J

*
 CMDTS

* SHIFTED COMMAND ROUTINE ADDRESS TABLE

DA	REGA	A = REGISTER DISPLAY
DA	REGB	B = REGISTER DISPLAY
DA	REGC	C = REGISTER DISPLAY
DA	REGD	D = REGISTER DISPLAY
DA	REGE	E = REGISTER DISPLAY
DA	REGF	F = CONDITION FLAGS DISPLAY
DA	GETCME	G = * NOT USED *
DA	REGH	H = REGISTER DISPLAY
DA	EXECUI	I = 'E' COMMAND WITH EI/RET
DA	TSTDSP	J = DISPLAY TEST
DA	GETCME	K = * NOT USED * (KEYBOARD TEST)
DA	REGL	L = REGISTER DISPLAY
DA	GETCME	M = * NOT USED *
DA	GETCME	N = * NOT USED *
IFS	ORIGINI	
DA	ORIGIM	O = MODIFY SELECTED ORIGIN
XIF		
IFC	ORIGINI	
DA	GETCME	Q = * NOT USED * (ORIGIN MODIFY)
XIF		
IFNE	ROMTYPE,3	
DA	BASSET	P = DISPLAY BASE REG OR LOAD WITH C
XIF		
IFEQ	ROMTYPE,3	
DA	GETCME	P = * NOT USED * (BASE REGISTER)
XIF		
DA	GETCME	Q = * NOT USED *
IFS	STACKP	
DA	STACKR	R = STACK ROLL
DA	STACKS	S = STACK STUFF
XIF		
IFC	STACKP	
DA	GETCME	R = * NOT USED * (STACK ROLL)
DA	GETCME	S = * NOT USED * (STACK STUFF)
XIF		
DA	GETCME	T = * NOT USED * (PSEUDO RANDOM MEM TEST)
DA	GETCME	U = * NOT USED *
DA	GETCME	V = * NOT USED *
DA	GETCME	W = * NOT USED *
DA	REGX	X = REGISTER DISPLAY
IFNE	ROMTYPE,3	
DA	OUTXST	Y = EX STATUS
DA	OUTXDA	Z = EX DATA
XIF		
IFEQ	ROMTYPE,3	
DA	GETCME	Y = * NOT USED * (5500 I/O BUS)
DA	GETCME	Z = * NOT USED * (5500 I/O BUS)

292,J					XIF			
293,J					*			
294,J	174112				C12345			
295,J					.			
296,J					. CHECK FOR '12345' FOR COMMAND ENTRY VALUE			
297,J					.			
298,J	174112	062	074	345	CPC	012345	CHECK LSB	
299,J	174115	110	124	370	JFZ	C1234P	ABORT IF NOT RIGHT	
300,J	174120	111	074	024	CPB	012345>8	ELSE CHECK MSB	
301,J	174123	053			RTZ		RETURN IF BOTH CORRECT	
302,J	174124	060			C1234P	POP	ELSE ABORT THE RETURN	
303,J					*			
304,J	174125				GETCME			
305,J					.			
306,J					. COMMAND ERROR			
307,J					.			
308,J	174125	151			EX	BEEP	MAKE NOISE IF BAD COMMAND	
309,J	174126	104	216	367	JMP	GETCML		
310,J					*			
311,J	174131				BACKSP			
312,J					.			
313,J					. BACKSPACE IF NOT AT BEGINNING OF LINE			
314,J					.			
315,J	174131	113	074	106	CPD	NECP	DON'T DO ANYTHING IF AT BEGINNING OF LINE	
316,J	174134	150	207	367	JTZ	GETCMD		
317,J	174137	113	024	001	SUD	1	ELSE DECREMENT THE HORIZONTAL POSITION	
318,J	174142	106	222	372	CALL	SBCRL3	AND SHIFT BC BACK RIGHT THREE PLACES	
319,J	174145	104	216	367	JMP	GETCML	THEN CONTINUE THE COMMAND	
320,J					*			
321,J	174150				GETDIG			
322,J					.			
323,J					. CONVERT OCTAL DIGITS ENTERED BEFORE COMMAND LETTER TO BINARY			
324,J					.			
325,J					.			
326,J	174150	024	060		LLA		SAVE THE CHARACTER ENTERED	
327,J	174152	160	125	370	SU	'0'	SEE IF LEGAL ASCII DIGIT	
328,J	174155	074	010		JTS	GETCME	COMPLAIN IF NOT	
329,J	174157	120	125	370	CP	8		
330,J	174162	062	202		JFS	GETCME		
331,J	174164	111	211		ADCC		ELSE CONVERT TO BINARY	
332,J	174166	062	202		ACBB		BY SHIFTING BC LEFT 3	
333,J	174170	111	211		ADCC			
334,J	174172	062	202		ACBB			
335,J	174174	111	211		ADCC			
336,J	174176	062	260		ACBB			
337,J	174200	113	074	117	ORAC		AND OR'ING IN THE DIGIT	
338,J	174203	113	014	000	CPD	MAXPOS=1		
339,J	174206	104	216	367	ACD	0		
					JMP	GETCML		

```

342 J
343 J
344 J
345 J
346 J
347 J
348 J
349 J
350 J
351 J
352 J
353 J
354 J
355 J
356 J
357 J
358 J
359 J
360 J
361 J
362 J
363 J
364 J
365 J
366 J
367 J
368 J
369 J
370 J
371 J
372 J
373 J
374 J
375 J
376 J
377 J
378 J
379 J
380 J
381 J
382 J
383 J
384 J
385 J
386 J
387 J
388 J
389 J

          IFS      ASCII
*
KEYINM
*
* SET ASCII KEYIN MODE
*
          CALL      C12345      ENTRY MUST BE '12345K'
          HL        KEYMSG      DISPLAY KEYIN MODE MESSAGE
          DE        61<8+BL     POSITION CURSOR FOR MESSAGE
          CALL      DISPLAY     DISPLAY OR CLEAR THE MESSAGE
          LA        0377        SET THE KEYIN MODE FLAG
          POP
          JMP        KEYINS      (KEEP THE STACK CORRECT)
*
KEYINC  HL        KEYMSC      RESET THE KEYIN MODE
          DE        61<8+BL
          CALL      DISPLAY     BLANK THE LINE
          XRA
          POP
          JMP        KEYINS      (KEEP THE STACK CORRECT)
          DONE
*
KEYMSG  DC        ' * ASCII'   KEYIN MODE MESSAGE
KEYMSC  DC
*
KEYINA
*
* PROCESS NEXT CHARACTER IN ASCII KEYIN MODE
*
          CP        CAN        EXIT THE MODE IF CANCEL ENTERED
          JTZ      KEYINC
          CP        BSP        BACK UP ONE LOCATION IF BACKSPACE ENTERED
          JTZ      DECADR
          CP        DEL        GO FORWARD ONE LOCATION IF DEL ENTERED
          JTZ      INCADR
          CP        'A'        ELSE DO SHIFT KEY INVERSION
          JTC      KEYINN
          CP        'Z'+1
          JTC      KEYINV
          CP        ' '
          JTC      KEYINN
          CP        ' '+1
          JFC      KEYINN
KEYINV  XR        040          INVERT SHIFT IF ALPHA CHARACTER
KEYINN  DPL      HL,CURADR     STORE THE ASCII CHAR IN CURRENT ADDRESS
          LMA
          XRA
          EX        CLICK      MAKE SOME NOISE IF ASCII CHARACTER
          XIF
    
```

```

390,J
391,J 174211
392,J
393,J
394,J
395,J 174211 115 164 200
396,J 174214 110 223 370
397,J 174217 026 001 016 000
398,J 174223 176 202
399,J 174225 115 211
400,J 174227 115 166 200
401,J 174232 007
402,J
403,J 174233
404,J
405,J
406,J
407,J 174233 110 241 370
408,J 174236 111 124 200
409,J 174241 174 047
410,J 174243 113 146 200
411,J 174246 007
412,J
413,J 174247
414,J
415,J
416,J
417,J 174247 113 074 106
418,J 174252 053
419,J
420,J
421,J
422,J
423,J
424,J 174253 111 126 200
425,J 174256 007
426,J
427,J 174257
428,J
429,J
430,J
431,J 174257 115 164 200
432,J 174262 110 271 370
433,J 174265 026 001 016 000
434,J 174271 176 222
435,J 174273 115 231
436,J 174275 115 166 200
437,J 174300 007
    
```

```

*
INCADR
.
. INCREMENT THE CURRENT ADDRESS BY ONE OR THE VALUE GIVEN
.
.           DPL           HL,CURADR
.           JFZ           INCADV
.           BC            1
INCADV     ADCL
.           ACBH
MODIFNXT   DPS           HL,CURADR
.           RET

*
LINK
.
. LINK TO THE ADDRESS POINTED TO BY THE CURRENT ADDRESS
.
.           JFZ           LINKADR           USE ADDRESS GIVEN
.           DPL           BC,CURADR        NO, USE CURRENT ADDRESS
LINKADR    DL            DE,BC
.           DPS           DE,CURADR
.           RET

*
NEWADR
.
. SET THE CURRENT ADDRESS
.
.           CPD           NECP             IGNORE ENTER ONLY
.           RTZ
.           IFS           ORIGINI
.           DPL           DE,CURORG        ELSE ADD ON THE CURRENT ORIGIN
.           ADEC
.           ACDB
.           XIF
NOSADR     DPS           BC,CURADR
.           RET

*
DECADR
.
. DECREMENT THE CURRENT ADDRESS BY ONE OR THE VALUE GIVEN
.
.           DPL           HL,CURADR
.           JFZ           DECADV
.           BC            1
DECADV     SUCL
.           SBBH
.           DPS           HL,CURADR
.           RET
    
```


438 J
 439 J
 440 J
 441 J 174301 035
 442 J 174302 035
 443 J 174303 035
 444 J 174304 035
 445 J 174305 035
 446 J 174306 035
 447 J 174307 035
 448 J 174310 035
 449 J 174311 035
 450 J
 451 J 174312 115 166 200
 452 J 174315 113 074 106
 453 J 174320 053
 454 J 174321 104 343 370
 455 J
 456 J 174324
 457 J
 458 J
 459 J
 460 J 174324 113 074 106
 461 J 174327 150 335 370
 462 J 174332 111 126 204
 463 J 174335 111 124 204
 464 J
 465 J 174340
 466 J
 467 J
 468 J
 469 J 174340 051 227 370
 470 J
 471 J 174343
 472 J
 473 J
 474 J
 475 J 174343 115 164 200
 476 J 174346 372
 477 J 174347 015
 478 J 174350 111 261
 479 J 174352 053
 480 J 174353 371
 481 J 174354 015
 482 J 174355 153
 483 J 174356 007
 484 J
 485 J
 486 J
 487 J
 488 J
 489 J

*
 . REGISTER DISPLAYS
 .
 REGF DECP HL
 REGC DECP HL
 REGB DECP HL
 REGE DECP HL
 REGD DECP HL
 REGL DECP HL
 REGH DECP HL
 REGA DECP HL
 REGX DECP HL
 .
 REGDSP DPS HL,CURADR DISPLAY THAT REGISTER CONTENT
 CPD NECP JUST DISPLAY IF NO DIGITS ENTERED
 RTZ
 JMP MODIFY OTHERWISE MODIFY
 *
 MODAGN
 .
 . 'A' MODIFY AND INCREMENT THE ADDRESS USING NEW OR PREVIOUSLY SET VALUE
 .
 CPD NECP CHECK IF DIGITS ARE GIVEN
 JTZ MODIFX
 DPS BC,MODVAL UPDATE TO NEW VALUE GIVEN
 MODIFX DPL BC,MODVAL OR USE OLD VALUES
 *
 MODINC
 .
 . 'I' MODIFY AND INCREMENT THE ADDRESS
 .
 PUSH MODIFNXT RETURN TO SAVE ADDRESS ROUTINE
 *
 MODIFY
 .
 . MODIFY THE CURRENTLY ADDRESSED MEMORY LOCATION
 .
 DPL HL,CURADR STORE LSB WHERE CURRENT ADDRESS POINTS
 LMC HL
 INCP HL (INCREMENT ADDRESS BY ONE - IF NEEDED)
 ORBR
 RTZ THAT'S IT IF MSB IS ZERO
 LMB ELSE STORE MSB IN FOLLOWING LOCATION
 INCP HL (INCREMENT ADDRESS BY TWO - IF NEEDED)
 EX CLICK MAKE NOISE IF TWO BYTES STORED
 RET
 .
 IFS ORIGINI
 +
 ORIGIN
 .
 . SET THE CURRENT ORIGIN TO THE TABLE ENTRY SELECTED

490,J
 491,J
 492,J
 493,J
 494,J
 495,J
 496,J
 497,J
 498,J
 499,J
 500,J
 501,J
 502,J
 503,J
 504,J
 505,J
 506,J
 507,J
 508,J
 509,J
 510,J
 511,J
 512,J
 513,J
 514,J
 515,J
 516,J
 517,J
 518,J
 519,J
 520,J
 521,J
 522,J
 523,J
 524,J
 525,J
 526,J
 527,J
 528,J
 529,J
 530,J
 531,J
 532,J
 533,J
 534,J
 535,J
 536,J
 537,J
 538,J
 539,J
 540,J
 541,J

```

*
      JTZ      ORIGIC      JUST CLEAR ORIGIN IF NO SELECT GIVEN
      LAC
      CP       OTABLN      ELSE MAKE SURE SELECT IS WITHIN RANGE
      JFC      GETCME
      PS       A,CUROSXN
ORIGIØ      ADA           SAVE THE ORIGIN NUMBER
      HL       OTABL       INDEX INTO THE ORIGIN TABLE
      INCP     HL,A
      DL       BC,HL       GET THE NEW ORIGIN VALUE
ORIGIC      DPS          SET THE CURRENT ORIGIN TO THAT VALUE
      BC       CURORG      DISPLAY THE SELECTED ORIGIN
      DPS          BC,CURADR
      RET
*
ORIGIM
*
      . MODIFY THE CURRENTLY SELECTED ORIGIN TABLE ENTRY
*
      PL       A,CUROSXN   GET THE CURRENT ORIGIN SELECT NUMBER
      JTZ      ORIGIØ     SELECT PREVIOUS ENTRY IF NO DIGITS
      CP       OTABLN     MAKE SURE THE SELECT NUMBER IS WITHIN
      JFC      GETCME     RANGE IF WE'RE GOING TO UPDATE
      ADA           ELSE INDEX INTO ORIGIN TABLE BY
      HL       OTABL     THE CURRENT SELECT NUMBER
      INCP     HL,A
      DS       BC,HL       STORE THE NEW VALUE THERE
      JMP      ORIGIC     AND SAVE AND DISPLAY IT
      XIF
*
      IFS      STACKP
*
STACKR
*
      . ROLL (POP) THE STACK THE NUMBER OF TIMES GIVEN IN THE C-REGISTER
*
      LAC
      JFZ      STACKOV
      LA       1
STACKOV     CP       32-1
      JFC      GETCME     CAN'T POP MORE THAN STACKL/2-1 ENTRIES
      DE       DEBUG
      DPL      HL,OLDTOS
*
STACKOL     DS       DE,HL
      NDL      =1-64
      INCP     HL,2       STACK POPS "UP"
      ORL      64
      SU       1
      JFZ      STACKOL
      JMP      STACKDØ
*
    
```

```

542, J
543, J
544, J
545, J
546, J
547, J
548, J
549, J
550, J
551, J
552, J
553, J
554, J
555, J 174357
556, J
557, J
558, J
559, J 174357 115 164 207
560, J 174362 302
561, J 174363 074 037
562, J 174365 100 125 370
563, J 174370 200
564, J 174371 176 044 277
565, J 174374 017
566, J 174375 176 064 100
567, J 174400 115 166 200
568, J 174403 007
569, J
570, J 174404
571, J
572, J
573, J
574, J 174404 110 012 371
575, J 174407 111 124 200
576, J 174412 062 307
577, J 174414 074 052
578, J 174416 150 062 371
579, J 174421 066 211 056 327
580, J 174425 006 003
581, J 174427 017
582, J 174430 176 074 251
583, J 174433 100 062 371
584, J 174436 307
585, J 174437 074 377
586, J 174441 110 025 371
587, J 174444 035
588, J 174445 111 027
589, J 174447 117 015
590, J 174451 062 307
591, J 174453 370
592, J 174454 006 052
593, J 174456 062 370
    
```

STACKS

* STUFF (PUSH) A VALUE ONTO THE STACK

```

DPL HL,OLDTOS
DECP HL,2 MAKE B.O.S. NEW T.O.S.
ORL 64 STACK GROWS "DOWN"
DS BC,HL
    
```

* STACKD0 LC 0 CAUSE TOP STACK ENTRY TO BE DISPLAYED

```

DPS HL,OLDTOS
XIF
    
```

* STACKD

* DISPLAY A STACK LOCATION

```

DPL HL,OLDTOS (HL)=OLD TOP OF STACK VALUE
LAC (C) IS STACK NUMBER
CP 32=1
JFC GETCME
ADA DOUBLE FOR INDEX
NDL =1-64
INCP HL,A
ORL 64
DPS HL,CURADR
RETURN
    
```

* BPSET

* SET A BREAK POINT AT THE CURRENT OR GIVEN ADDRESS

```

JFZ BPSETG USE CURRENT ADDRESS IF NO DIGITS GIVEN
DPL BC,CURADR
BPSETG LAM BC DON'T ALLOW BP IF BP ALREADY THERE
CP OPCODEBP
JTZ BPTSER
HL BPTABL=BPTES+1 SEARCH THE TABLE FOR AN OPENING
BPSRCH LA BPTES BUMP TO THE NEXT TABLE OPENING
INCP HL,A
CPL BPTABE STOP IF PAST END OF TABLE
JFC BPTSER ERROR IF NO SLOTS AVAILABLE
LAM GET THE MSB OF THE ADDRESS
CP =1 KEEP GOING IF NOT A FREE SLOT
JFZ BPSRCH
DECP HL ELSE STORE THE ADDRESS IN THE TABLE
DS BC,HL THEN SAVE WHAT WAS THERE IN MEMORY
INCP HL,2
LAM BC
LMA OPCODEBP THEN STORE THE BREAK POINT INSTRUCTION
LMA BC
    
```

594,J	174460	153			EX	CLICK	MAKE A LITTLE NOISE
595,J	174461	007			RET		DON'T CHANGE THE CURRENT ADDRESS
596,J					*		
597,J	174462	151			BPTSER	EX	BEEP
598,J	174463	104	253	370	JMP	NOSADR	TELL THAT CAN NOT BREAKPOINT THERE
599,J					*		SHOW BP ALREADY THERE (OR NO TABLE ROOM)
600,J	174466				BPCLR		
601,J					.		
602,J					.	CLEAR ALL THE BREAK POINTS	
603,J					.		
604,J	174466	066	213	056	327	HL	BPTABL
605,J	174472	176	074	251		BPCLRL	BPTABE
606,J	174475	150	060	373			STOP IF AT END OF TABLE
607,J	174500	047			JTZ		
608,J	174501	117	015		DL	DE,HL	ELSE DE => BREAK POINT LOCATION
609,J	174503	307			INCP	HL,2	BUMP THE MEMORY POINTER PAST THE ADDRESS
610,J	174504	015			LAM		GET THE CONTENTS
611,J	174505	113	074	377	INCP	HL	BUMP THE MEMORY POINTER TO NEXT ENTRY
612,J	174510	150	072	371	CPD	=1	SKIP ENTRY IF NOT IN USE
613,J	174513	174	370		JTZ	BPCLRL	
614,J	174515	104	072	371	LMA	DE	ELSE RESTORE THE CONTENTS
615,J					JMP	BPCLRL	AND MOVE ON TO THE NEXT ENTRY
616,J	174520				*		
617,J					REGMOD		
618,J					.		
619,J					.	SWITCH REGISTER MODES (ALPHA/BETA)	
620,J	174520	176	064	077			
621,J	174523	115	166	200	ORL	SEPSWSV,AND,0177	(VALUE 077 OR AN ERROR)
622,J	174526	006	200		DPS	HL,CURADR	DISPLAY THE MODE
623,J	174530	104	311	372	LA	SWALBT	
624,J					JMP	SREGMOD	GO TO SET THE REGISTER MODE
625,J					.		
626,J					IFNE	ROMTYPE,3	
627,J	174533				*		
628,J					BASSET		
629,J					.		
630,J					.	SET OR DISPLAY THE BASE REGISTER	
631,J	174533	066	253	056	357	HL	SEBRLS
632,J	174537	150	154	371		JTZ	BASED
633,J	174542	074	120			CP	'P'
634,J	174544	302				LAC	
635,J	174545	150	153	371		JTZ	BASSES
636,J					.		
637,J	174550	301				LAB	
638,J	174551	024	200			SU	0100000>8
639,J					.		
640,J	174553	072				BASSES	THEN STORE AND UPDATE THE BASE REGISTER
641,J	174554	115	166	200		BASED	CAUSE THE BASE REGISTER STORAGE
642,J	174557	007				RET	TO BE DISPLAYED

```

643 J
644 J 174560
645 J
646 J
647 J
648 J
649 J 174560 106 112 370
650 J 174563 115 164 200
651 J 174566 307
652 J 174567 074 020
653 J 174571 100 125 370
654 J 174574 320
655 J 174575 015
656 J 174576 077
657 J 174577 007
    
```

*
 STLOAD

*
 * LOAD THE SECTOR TABLE - LOAD (N) ENTRIES WHERE (N) IS THE BYTE POINTED TO
 * BY THE CURRENT ADDRESS AND THE ENTRIES FOLLOW THAT LOCATION.
 *

```

CALL C12345 ENTRY MUST BE '123450'
DPL HL,CURADR IF '123450' THEN LOAD FROM CURADR
LAM A = NUMBER OF ENTRIES
CP 16 ERROR IF NUMBER OF ENTRIES >15
JFC GETCME
LCA
INCP HL SET C TO NUMBER OF ENTRIES
STL BUMP HL TO START OF LIST
RET I SURE HOPE EVERYTHING WAS SET UP RIGHT!
    
```

```

658 J
659 J 174600
660 J
661 J
662 J
663 J
664 J
665 J
666 J
667 J 174600 110 210 371
668 J 174603 066 252 056 357 327
669 J 174610
670 J 174610 062 121
671 J 174612 074 141
672 J 174614 150 223 371
673 J
674 J 174617 125
675 J 174620 074 147
676 J 174622 053
677 J
678 J 174623 101
679 J 174624 066 203 056 327 370
680 J 174631 115 166 200
681 J 174634 007
682 J
683 J
684 J
685 J
686 J
687 J 174635 106 300 371
688 J 174640 123
689 J 174641 007
690 J
691 J 174642 106 300 371
692 J 174645 125
693 J 174646 007
694 J
695 J 174647 106 300 371
696 J 174652 127
697 J 174653 007
    
```

```

*
ADRDEV
.
. ADDRESS AN I/O DEVICE AND DISPLAY ITS CURRENT STATUS
.
. NOTE: MINOR DIFFERENCE FROM 5500 VERSION FOR 'F' AND 'G' MODES
. THE FIRST INPUT BY THIS CODE GIVES ACTUAL DATA NOT STATUS.
. DIFFERENCE FOUND BY GADWA'S GROUP
.
. JFZ ADRDE1 ADDRESS IS GIVEN
. MLC *SEXADR USE LAST ADDRESSED DEV IF NOT GIVEN
ADRDE1 . EXC ADR ADDRESS THE DEVICE
. CP ' ' (AUTOMATICALLY SETS LAST ADDRESS GIVEN)
. JTZ GETSTA DO INPUT IF 'A' COMMAND
.
. EX DATA ELSE PUT DEVICE IN DATA MODE
. CP ' ' JUST EXIT IF 'G' COMMAND
. RTZ
.
GETSTA . IN GET THE STATUS OF THAT DEVICE
. MSA *CURSTA
. DPS HL,CURADR CAUSE THE STATUS TO BE DISPLAYED
. RET
*
. ADDRESS THE CURRENTLY ADDRESSED I/O DEVICE AND OUTPUT THE VALUE GIVEN
. OR THE LAST VALUE GIVEN FOR OUTPUT DOING AN I/O STROBE BASED
. UPON THE COMMAND LETTER GIVEN.
.
OUTXST . CALL OUTSETUP ' ' = EX STATUS
. EX STATUS
. RET OFF TO "GETSTA"
*
OUTXDA . CALL OUTSETUP ' ' = EX DATA
. EX DATA
. RET OFF TO "GETSTA"
*
OUTXWT . CALL OUTSETUP 'W' = EX WRITE
. EX WRITE
. RET OFF TO "GETSTA"
    
```

```

698 J
699 J 174654 106 300 371
700 J 174657 131
701 J 174660 007
702 J
703 J 174661 106 300 371
704 J 174664 133
705 J 174665 007
706 J
707 J 174666 106 300 371
708 J 174671 135
709 J 174672 007
710 J
711 J 174673 106 300 371
712 J 174676 137
713 J 174677 007
714 J
715 J 174700
716 J
717 J
718 J
719 J
720 J 174700 060
721 J 174701 051 223 371
722 J 174704 070
723 J 174705 105 202
724 J 174707 053
725 J
726 J 174710 302
727 J 174711 126 202
728 J 174713 007
729 J
    
```

```

*
OUTXC1  CALL  OUTSETUP  'X' = EX COM1
        EX    COM1
        RET   OFF TO "GETSTA"

*
OUTXC2  CALL  OUTSETUP  'Y' = EX COM2
        EX    COM2
        RET   OFF TO "GETSTA"

*
OUTXC3  CALL  OUTSETUP  'Z' = EX COM3
        EX    COM3
        RET   OFF TO "GETSTA"

*
OUTXC4  CALL  OUTSETUP  'V' = EX COM4
        EX    COM4
        RET   OFF TO "GETSTA"

*
OUTSETUP
.
. PUSH "GETSTA" ON THE STACK BELOW THE RETURN ADDRESS AND PUT THE RIGHT
.   VALUE IN THE A-REGISTER FOR THE OUTPUT INSTRUCTION.
.
.
        POP    HL
        PUSH   GETSTA
        PUSH   HL
        PL     A,CUROUT
        RTZ

.
        LAC
        PS    C,CUROUT
        RET
        XIF
    
```



```

782 J
783 J 174776 111 126 200
784 J 175001 022 070
785 J 175003 106 344 372
786 J 175006 022 060
787 J 175010 115 164 207
788 J 175013 111 124 200
789 J 175016 046 127 036 367
790 J 175022 176 065
791 J 175024 074 152
792 J 175026 150 033 372
793 J 175031 174 070
794 J 175033 062 070
795 J 175035 062 030
    
```

```

CALLKA  DPS      BC,CURADR      SET ADDRESS TO CALL (JUMP TO)
        PUSH     XA              (SAVE A = INPUT DEBUG OPERATION)
        CALL     RESTRLOC       CORRECT REGISTER LOCATIONS
        POP      XA
        DPL      HL,OLDTOS
        DPL      BC,CURADR      GET CALL (JUMP) ADDRESS
        DE       DEBUG          GET RETURN ADDRESS (IF CALL)
        SYSMOV   HL             RESTORE USER SYSTEM SAVE AREA
        CP       ' '           JUMP OPERATION?
        JTZ     JUMPIT
        PUSH     DE             NO, 'CALL' SO PUSH RETURN ADDRESS
        PUSH     BC
        SYSRET                    LOAD STATE, REGS, AND RETURN
    
```

796 J
 797 J 175037
 798 J
 799 J
 800 J
 801 J 175037 066 117
 802 J 175041 150 045 372
 803 J 175044 362
 804 J 175045 070
 805 J 175046 106 004 374
 806 J 175051 060
 807 J 175052 316
 808 J 175053 076 357
 809 J 175055 106 053 374
 810 J
 811 J 175060 106 125 373
 812 J 175063 150 060 372
 813 J 175066 104 004 374

```

+
TSTDSP
.
. TEST THE DISPLAY SCREEN BY FILLING IT FULL OF CHARACTERS
.
      LL      '0'      STANDARD CHARACTER
      JTZ     TDSTD
      LLC
      TDSTD   PUSH     HL      WILL NOT BE USED, VALUE ENTERED WILL BE
      CALL    DSPINIT  HL      SAVE IT
      POP     HL      INIT THE DISPLAY AND ITS POINTERS
      LBL
      LX      SEDOPTS>8  PUT IN B THE CODE TO BE DISPLAYED
      CALL    DOSF68LP  CHANGE THE DISPLAY TO ALL 'B'

.
TDWAIT  CALL    DOSF61  WAIT FOR ANY KEYIN
        JTZ     TDWAIT
        JMP     DSPINIT  RE-INIT THE DISPLAY AND RETURN TO GET KEY
    
```

```

814 J
815 J 175071
816 J
817 J
818 J
819 J 175071 066 130 056 372
820 J 175075 106 341 374
821 J
822 J 175100 111 010
823 J 175102 321
824 J 175103 036 017
825 J 175105 106 115 372
826 J
827 J 175110 111 010
828 J 175112 320
829 J 175113 036 013
830 J 175115
831 J 175115 016 000
832 J 175117 066 003
833 J 175121 106 160 372
834 J 175124 006 072
835 J 175126 370
836 J 175127 007
837 J
838 J 175130
839 J
840 J
841 J
842 J 175130 224
843 J 175131 040 115 072
844 J 175134 060
845 J 175135 061
846 J 175136 061
847 J 175137 040
848 J 175140 120
849 J 175141 040 040 040 040
850 J 000013
851 J 175145 040 040 040 040
852 J 000017
853 J 175151 040 040 003
854 J 000012
    
```

```

+
IDENT
. DISPLAY THE MICRO AND MACRO ROM VERSION INFORMATION
.
      HL      IDENTM      DISPLAY THE MACRO ROM VERSION INFORMATION
      CALL    DISPLAY    HOPING B=REG IS ZERO
.
      INFO    C = MICRO-ROM VERSION
      LCB
      LD      IDMIC      DISPLAY IT IN OCTAL
      CALL    IDENT0    (SAVING A LITTLE SPACE)
.
      INFO    C = PROCESSOR TYPE
      LCA
      LD      IDPROC    DISPLAY IT IN OCTAL
IDENT0
      LB      0
      LL      3
      CALL    DSPOCT
      LA      '!'
      LMA
      RET
*
IDENTM
. ROM VERSION IDENTIFICATION MESSAGE
.
IDENTS      DC      $HD
            DC      ' M:'
            DC      $MACROM/64.AND.7+'0'
            DC      $MACROM/8.AND.7+'0'
            DC      $MACROM.AND.7+'0'
            DC      $MACVER      PUT REVISION LETTERS IN MESSAGE
            DC      'P'
            DC      ' '      (INVISIBLE COLON APPEARS WHEN NEEDED)
DSPBLNK     DC      ' '
IDPROC      EQU     $=IDENTS-1
            DC      ' '
IDMIC       EQU     $=IDENTS-1
            DC      ' ',SES
DSPBLN      EQU     $=DSPBLNK-1
    
```

```

857 J
858 J
859 J
860 J
861 J
862 J
863 J
864 J
865 J
866 J
867 J
868 J
869 J
870 J
871 J 175154 066 006
872 J 175156 036 117
873 J
874 J 175160 306
875 J 175161 022 070
876 J 175163 106 312 374
877 J 175166 022 060
878 J
879 J 175170 022 070
880 J 175172 302
881 J 175173 044 007
882 J 175175 004 060
883 J 175177 370
884 J 175200 035
885 J 175201 106 222 372
886 J 175204 113 024 001
887 J 175207 022 060
888 J 175211 024 001
889 J 175213 110 170 372
890 J
891 J 175216 016 040
892 J 175220 371
893 J 175221 007
894 J
895 J 175222
896 J
897 J
898 J
899 J 175222 111 032
900 J 175224 062 032
901 J 175226 111 032
902 J 175230 062 032
903 J 175232 111 032
904 J 175234 062 032
905 J 175236 111 044 037
906 J 175241 007
    
```

```

*
. DISPLAY OCTAL VALUE RIGHT TO LEFT
.
. ENTRY: BC = VALUE TO BE DISPLAYED
.         E = LINE FOR THE DISPLAY (-12 THRU 11)
.         L = NUMBER OF CHARACTERS (IF ENTERED BELOW DSPDC6)
.         D = POSITION OF RIGHT-HAND CHARACTER
.           (IF ENTERED BELOW DSPOCR)
.
. EXITS: BC = SCRATCHED
.         D = POSITION TO LEFT OF MOST SIG. DIGIT (BLANKED)
.         E = ENTRY VALUE
.         HL = SCRATCHED
.
. DSPDC6 LL 6 DISPLAY 6 DIGITS
. DSPOCR LD 79 DISPLAY AT RIGHT OF SCREEN
.
. DSPOCT LAL GET THE COUNT IN THE A-REGISTER
. PUSH XA
. CALL DSPCBL POSITION HL INTO DISPLAY BUFFER
. POP XA
.
. DSPOCL PUSH XA SAVE THE COUNT ON THE STACK
. LAC GET THE LEAST SIGNIFICANT DIGIT
. ND 7 ISOLATE THE OCTAL BITS
. AD '0' CONVERT TO ASCII DIGIT
. LMA DISPLAY THE ASCII DIGIT
. DECP HL
. CALL SBCRL3 SHIFT THE 16-BIT VALUE RIGHT 3 BITS
. SUD 1 DECREMENT THE HORIZONTAL POSITION
. POP XA DECREMENT THE COUNT
. SU 1
. JFZ DSPOCL LOOP IF MORE DIGITS TO GO
.
. LB ' ' THEN BLANK THE POSITION TO THE LEFT
. LMB
. RET
*
. SBCRL3
.
. SHIFT BC RIGHT LOGICALLY 3 BITS
.
. SREB
. SREC
. SREB
. SREC
. SREB
. SREC
. NDB 037
. RET
    
```

```

907 J
908 J 175242
909 J
910 J
911 J
912 J
913 J 175242 062 020
914 J 175244 066 200 056 327
915 J 175250 174 060
916 J 175252 176 065
917 J 175254 174 070
918 J 175256 076 327
919 J 175260 117 275
920 J 175262 053
921 J
922 J 175263 115 166 207
923 J 175266 176 044 300
924 J 175271 117 035
925 J 175273 106 363 372
926 J 175276 035
927 J 175277 106 325 372
928 J 175302 035
929 J 175303 106 325 372
930 J
931 J 175306 176 064 077
932 J 175311 257
933 J 175312 370
934 J 175313 120 321 372
935 J
936 J 175316 006 011
937 J 175320 037
938 J 175321 115 166 211
939 J 175324 007
940 J
941 J 175325
942 J
943 J
944 J
945 J 175325 006 004
946 J
947 J 175327 047
948 J 175330 324
949 J 175331 343
950 J 175332 332
951 J 175333 027
952 J 175334 117 035
953 J 175336 024 001
954 J 175340 110 327 372
955 J
956 J 175343 007
    
```

```

+
SSTATE
*
* SAVE THE STATE OF THE MACHINE AND SWAP AROUND THE REGISTERS
* SO THE DEBUG DISPLAY WILL SHOW PAIR VALUES AS WELL.
*
SYSSAV          SAVE CURRENT MODE OF REGISTERS
HL              POINT TO NEW STACK AREA
POP            DE (RETURN ADDRESS)
SYSMOV        HL MOVE SYSTEM SAVE AREA
PUSH          DE (TO NEW STACK)
LX            SDBGWS>8
CPHX
RTZ           IS STACK THE DEBUG STACK ?
              YES, DONE.
*
DPS          HL,OLDTOS
NDL          0300
DECP        HL,2    POINT TO ALPHA (F)
CALL       SWITZAF
DECP        HL      POINT TO ALPHA (AX)
CALL       RSWAP
DECP        HL      POINT TO BETA AX
CALL       RSWAP    (RETURNS A=0)
*
SREGMOD      ORL     SEPSWSV.AND.0177 BACK UP TO PSW
              XRM     HL      GET PSW (SETTING NEW MODE IF REGMOD)
              LMA     HL
              JFS     SSTAT1
*
LA           9      WANT BETA REGS
DECP        HL,A
SSTAT1      DPS     HL,OLDREGS
RET
*
RSWAP
*
* SWAP THE LOCATIONS OF LSB AND MSB REGISTERS IN PAIRS IN MEMORY
*
LA           4
*
RSWL        DL      DE,HL
              LCE
              LED
              LDC
              DS      DE,HL
              DECP   HL,2
              SU      1
              JFZ    RSWL
*
RETURN
    
```

957 J
 958 J 175344
 959 J
 960 J
 961 J
 962 J
 963 J
 964 J
 965 J 175344 176 064 077
 966 J 175347 117 035
 967 J 175351 106 325 372
 968 J 175354 035
 969 J 175355 106 325 372
 970 J 175360 006 022
 971 J 175362 017
 972 J
 973 J
 974 J 175363
 975 J
 976 J
 977 J
 978 J
 979 J 175363 006 011
 980 J 175365 337
 981 J 175366 037
 982 J 175367 111 047
 983 J 175371 037
 984 J 175372 015
 985 J 175373 347
 986 J 175374 372
 987 J 175375 035
 988 J 175376 017
 989 J 175377 027
 990 J 175400 017
 991 J 175401 371
 992 J 175402 007

*
 RESTRL0C
 .
 . HL POINTS INTO REG-SAVE AREA (OR PSW) ON ENTRY
 .
 . RESTORE THE LOCATIONS OF THE REGISTERS TO THEIR NORMAL
 . PLACES IN THE STATE STORAGE AREA IN MEMORY.
 .
 . ORL SEPSWSV.AND.0177 (VALUE SHOULD BE 077 OR AN ERROR)
 . DECP HL,2 POINT TO ALPHA XA PAIR SWAPPED
 . CALL RSWAP
 . DECP HL
 . CALL RSWAP
 . LA 18
 . INCP HL,A
 .
 . FALLS THROUGH INTO SWITZAF
 *
 SWITZAF
 .
 . SWITCH THE A REGISTER AND FLAGS IN MEMORY FOR BOTH MODES
 . ON ENTRY, MUST POINT TO ALPHA FLAGS (TO BECOME A-REG AS IT WAS)
 .
 . LA 9
 . LDM D = ALPHA FLAGS
 . DECP HL,A
 . DL BC,HL BC = ALPHA A-REG AND BETA FLAGS
 . DECP HL,A
 . INCP HL
 . LEM E = BETA A-REG
 . LMC STORE BETA FLAGS THERE
 . DECP HL
 . INCP HL,A
 . DS DE,HL STORE BETA A-REG AND ALPHA FLAGS
 . INCP HL,A
 . LMB STORE ALPHA A-REG
 . RET

```

993,J
994,J 175403
995,J
996,J
997,J
998,J
999,J 175403 174 060
1000,J 175405 066 227 056 363
1001,J 175411 026 015
1002,J 175413 077
1003,J 175414 066 225 056 363
1004,J 175420 026 322
1005,J 175422 062 077
1006,J 175424 250
1007,J 175425 072
1008,J 175426 174 070
1009,J
1010,J 175430 066 270 056 360
1011,J 175434 046 000 036 357
1012,J 175440 026 124
1013,J
1014,J 175442 310
1015,J 175443 021
1016,J 175444 007
1017,J
1018,J 175445
1019,J
1020,J
1021,J
1022,J
1023,J
1024,J
1025,J
1026,J
1027,J 175445 106 003 373
1028,J 175450 060
1029,J 175451 046 300 036 357
1030,J 175455 174 065
1031,J 175457 070
1032,J
1033,J
1034,J
1035,J
1036,J
1037,J
1038,J
1039,J
1040,J
1041,J
1042,J
1043,J
1044,J
    
```

```

*
MTSETUP
.
. INITIALIZE: THE SECTOR TABLE, THE BASE REGISTER TO ZERO, AND
. THE INTERRUPT VECTOR TO THE INTERNAL TRAP MESSAGES.
.
.
.
MTSETX POP DE ** INSURE CALLER GETS RETURNED TO
HL UMST INIT THE SECTOR TABLE FOR USER
LC UMSTL MEMORY SECTORS
STL
HL SMST INIT THE SECTOR TABLE FOR SYSTEM
LC (SEDSPBF>8,AND,0360)+SMSTL MEMORY SECTORS
STLOC
XRA ZERO THE BASE REGISTER
BRL
PUSH DE ** IF THE STACK GETS MOVED (1800MOVI)
.
HL VECTI INIT THE INTERRUPT VECTOR
DE SVMEMP
LC VECTIL MOVE THE WHOLE TABLE
XRA NO BIAS ON THE BLOCK TRANSFER
LBA DON'T CHECK FOR ANY CHARACTERS
BT TRANSFER THE ENTRIES TO MEMORY
RET
*
SETUP
.
. INITIALIZE: THE SECTOR TABLE, THE BASE REGISTER TO ZERO, THE INTERRUPT
. VECTOR TO THE INTERNAL TRAP MESSAGES, THE STACK AREA TO
. THE "NORMAL" SYSTEM RAM AREA, THE ORIGIN TABLE TO
. ALL ZEROS, AND THE BREAK POINT TABLE TO ALL FREE ENTRIES.
. WARNING: IF SECTOR TABLE MOVES, ROUTINE MTSETUP STOPS RETURN TO CALLER.
.
.
CALL MTSETUP
POP HL SAVE THE RETURN ADDRESS IN HL
DE SESTACK MOVE THE STACK AREA TO THE
SYSMOV DE "NORMAL" SYSTEM RAM AREA
PUSH HL RESTORE THE RETURN ADDRESS
*
IFS ORIGINI
ORGCLR
.
. CLEAR ALL ORIGIN TABLE ENTRIES
.
HL CURORG
XRA
OTCLOP LMA HL
INCP HL
CPL OPTABE
JFZ OTCLOP
XIF
    
```

1045 J
 1046 J 175460
 1047 J
 1048 J
 1049 J
 1050 J 175460 066 213 056 327
 1051 J 175464 006 377
 1052 J 175466 370
 1053 J 175467 015
 1054 J 175470 176 074 251
 1055 J 175473 110 066 373
 1056 J 175476 007
 177
 178

*
 BPTCLR
 .
 . FREE ALL BREAK POINT ENTRIES
 .
 . HL BPTABL
 . LA =1
 BPTCLL LMA
 . INCP HL
 . CPL BPTABE
 . JFZ BPTCLL
 . RET
 .
 . INC 1800DSPR

3, K
 4, K
 5, K
 6, K
 7, K
 8, K
 9, K
 10, K
 11, K
 12, K
 13, K
 14, K
 15, K
 16, K
 17, K
 18, K
 19, K
 20, K
 21, K
 22, K
 23, K
 24, K
 25, K
 26, K
 27, K
 28, K
 29, K
 30, K
 31, K
 32, K
 33, K
 34, K
 35, K
 36, K
 37, K
 38, K
 39, K
 40, K
 41, K
 42, K
 43, K
 44, K
 45, K
 46, K
 47, K
 48, K
 49, K
 50, K
 51, K
 52, K
 53, K
 54, K

. 1800 DISPLAY INTERFACE ROUTINES JUNE 8, 1978 11:53 HSP/HJS

. GENERAL NOTES ON THE FOLLOWING ROUTINES:

. THE FLASHING OF THE CURSOR IS CONTROLLED BY THE "CURNOFF" AND
 . "CURINBUF" BITS IN THE "SECFLAGS" BYTE. THE POSITION OF THE
 . CURSOR IS DETERMINED BY THE TWO BYTES IN "SECPOS" (VERTICAL)
 . AND "SECPOS"+1 (HORIZONTAL).

. WHEN THE "CURNOFF" BIT IS A ZERO, THE CURSOR IS NOT FLASHED,
 . OTHERWISE, WHEN THE "SELFREQ" BIT IN THE "CURINBUF" BIT POSITION
 . IS DIFFERENT FROM THE "CURINBUF" BIT, THE CURSOR IS EITHER:
 . 1) TURNED ON IF THE "SELFREQ" BIT IS NOW A ONE OR 2) TURNED OFF
 . IF THE "SELFREQ" BIT IS NOW A ZERO. WHEN THE CURSOR IS TURNED ON,
 . THE CHARACTER AT THE CURSOR POSITION IS FIRST SAVED INTO
 . "SECHIDE" AND THE CHARACTER AT "SECCHAR" IS STORED WHERE THE
 . CURSOR POSITION DIRECTS, PUTTING IT "IN THE BUFFER".

. WHEN THE CURSOR IS TURNED OFF, IF THE CHARACTER AT "SECCHAR"
 . IS NOT THE SAME AS THAT WHERE THE CURSOR POSITION DIRECTS
 . IT IS ASSUMED THAT THE CURSOR WAS OVERWRITTEN BY SOME ROUTINE
 . AND THE CHARACTER AT "SECHIDE" IS NOT RESTORED AS IS NORMALLY
 . DONE.

. WHEN THE "CURINBUF" BIT IS A ONE, THE CHARACTER IN THE CURSOR
 . POSITION IS THE CURSOR CHARACTER. OTHERWISE, IT IS THE
 . CHARACTER THAT IS TO NORMALLY BE DISPLAYED IN THAT POSITION.
 . THE EXCEPTION TO THIS RULE IS WHEN THE CURSOR POSITION IS NOT
 . WITHIN THE CONFINES OF THE SCREEN (-12 TO +11 VERTICALLY AND
 . 0 TO 79 HORIZONTALLY), THE CURSOR IS NOT FLASHED.

. BEFORE MANY OF THE FOLLOWING ROUTINES WRITE TO THE SCREEN, THE
 . CURSOR IS SUSPENDED. TO SUSPEND THE CURSOR, NO ACTION IS
 . REQUIRED IF THE "CURINBUF" BIT IS A ZERO BECAUSE THE CURSOR CHARACTER
 . IS NOT ON THE SCREEN. OTHERWISE, THE "CURNOFF" BIT IS RESET TO
 . ZERO AND THE CHARACTER AT "SECHIDE" IS STORED WHERE THE CURSOR
 . POSITION DIRECTS IF THE CURSOR CHARACTER "SECCHAR" WAS THERE.

. WARNING: THE FOLLOWING ROUTINES THAT CALL 'BLINK' OR 'CURSES' ARE NOT
 . RE-ENTRANT. I.E. THEY CAN NOT BE USED IN A MULTI-TASKING ENVIRONMENT
 . UNLESS ALL OF THEM ARE IN THE SAME TASK (ALL FOREGROUND OR ALL
 . BACKGROUND). IF THIS IS NOT DONE, THE CHARACTER AT THE CURSOR
 . POSITION CAN GET PERMANENTLY CHANGED TO THE CURSOR CHARACTER.
 . THIS IS NOT DESIRABLE. (DISPLAY IS INCLUDED IN THIS RESTRICTION)

. ALSO: THE ROUTINES THAT CALL 'CURSESRS' STORE REGISTERS IN A FIXED STORAGE
 . AREA. IF THESE ROUTINES ARE RE-ENTERED, THE REGISTERS AS STORED FROM
 . THE FIRST CALL WILL BE LOST. THE BASIC DEBUG ROUTINES (IN THE ROM)
 . HAVE BEEN MODIFIED SO THAT THIS WILL NOT NORMALLY HAPPEN DUE TO A
 . DEBUG ENTRY. BUT, NOT ALL ROUTINES COULD BE MODIFIED SO,
 . KNOWLEDGE & CARE MUST BE TAKEN IN USING THE DEBUGGER.

57,K
 58,K
 59,K
 60,K
 61,K
 62,K
 63,K
 64,K
 65,K
 66,K
 67,K
 68,K
 69,K
 70,K
 71,K
 72,K
 73,K
 74,K
 75,K
 76,K
 77,K
 78,K
 79,K 175477
 80,K
 81,K
 82,K
 83,K
 84,K
 85,K
 86,K
 87,K
 88,K
 89,K
 90,K
 91,K
 92,K 175477 106 244 373
 93,K 175502
 94,K 175502 066 151 056 357 307
 95,K 175507 044 003
 96,K 175511 004 121
 97,K 175513 360
 98,K 175514 056 373
 99,K 175516 307
 100,K 175517 200
 101,K 175520 007

*
 . DOS FUNCTION 6
 .
 . SUBFUNCTION: 0 - RETURN KBD/DSP KEY STATUS
 . 1 - CHECK FOR CHARACTER READY
 . 2 - GET A BYTE FROM THE KEYBOARD
 . 3 - WRITE THE BYTE IN (B) TO THE SCREEN
 . 4 - RETURN HOME-UP POSITION IN (DE)
 . 5 - RETURN HOME-DOWN POSITION IN (DE)
 . 6 - TURN CURSOR ON
 . 7 - ROLL UP SCREEN
 . 8 - ERASE FROM CURSOR TO END OF FRAME
 . 9 - ERASE FROM CURSOR TO END OF LINE
 . 10 - ROLL DOWN SCREEN
 . 11 - TURN CURSOR OFF
 . 12 - RETURN FUNCTION KEY & KEYBOARD STATUS
 . DSPCBL - CONVERT CURSOR TO BUFFER POSITION
 . CURSES - SUSPEND THE CURSOR (REMOVE IT FROM BUFFER)
 . BLINK - BLINK THE CURSOR
 . BLINKDE - MOVE CURSOR TO DE AND BLINK IT THERE
 . 62N - DOS FUNC 6 SUB 2 WITHOUT "DE" AND CURSOR BLINK

DOSF60

. DOS FUNCTION: 6 SUBFUNCTION: 0
 . - RETURN THE STATES OF THE "KEYBOARD" AND "DISPLAY" KEYS -
 .
 . ENTRY: N/A
 .
 . EXITS: SIGN TRUE IF "KEYBOARD" KEY IS DOWN
 . PARITY TRUE IF "DISPLAY" KEY IS DOWN
 . B & X ONLY REGISTERS SAVED
 . 2 EXTRA STACK LEVELS USED (MAX)

DOSF60N CALL BLINK BLINK THE CURSOR WHERE IT WAS
 (SPECIAL - MACRO-ROM NON BLINK ENTRY)
 MLA *SEKBS1 GET KEYBOARD STATUS 1 INTO (A)
 ND SEDSPKY,OR,SEKBDKY
 AD CCTAB60 INDEX INTO THE TABLE OF BYTES
 LLA WHICH WILL GIVE THE CORRECT
 LH CCTAB60>8 CONDITION CODE WHEN ADDED
 LAM TO THEMSELVES.
 ADA SET THE CONDITION CODE
 RET

102,K
 103,K
 104,K
 105,K
 106,K
 107,K
 108,K
 109,K
 110,K 175521 003
 111,K 175522 002
 112,K 175523 101
 113,K 175524 100
 114,K
 115,K 175525
 116,K
 117,K
 118,K
 119,K
 120,K
 121,K
 122,K
 123,K
 124,K
 125,K
 126,K
 127,K 175525 106 244 373
 128,K 175530 066 151 056 357 307
 129,K 175535 044 004
 130,K 175537 007
 131,K
 132,K 175540
 133,K
 134,K
 135,K
 136,K
 137,K
 138,K
 139,K
 140,K
 141,K
 142,K
 143,K
 144,K
 145,K
 146,K
 147,K
 148,K
 149,K
 150,K 175540 106 221 373
 151,K 175543
 152,K 175543 066 151 056 357 307
 153,K 175550 044 004

*
 . THE CONDITION CODE GENERATION TABLE IS PAGE SENSITIVE
 .
 IFGT (\$,AND,255),252
 RPT =\$,AND,255
 DC 000 PAD TO END OF PAGE
 XIF
 .
 CCTAB60 DC 0003 FALSE SIGN, PARITY & NO KEYS DOWN
 DC 0002 TRUE PARITY & DISPLAY KEY DOWN
 DC 0101 TRUE SIGN & KEYBOARD KEY DOWN
 DC 0100 TRUE SIGN, PARITY & BOTH KEYS DOWN
 *
 DOSF61
 . DOS FUNCTION: 6 SUBFUNCTION: 1
 .
 - CHECK THE KEYBOARD FOR CHARACTER READY -
 .
 ENTRY: N/A
 .
 EXITS: FALSE ZERO IF KEYBOARD HAS A CHARACTER
 B & X ONLY REGISTERS SAVED
 2 EXTRA STACK LEVELS USED (MAX)
 .
 CALL BLINK BLINK THE CURSOR WHERE IT WAS
 MLA *SEKBS1 GET KEYBOARD STATUS 1 INTO (A)
 ND SEKBRDY SET THE ZERO CONDITION FALSE IF
 RET THE KEYBOARD HAS A CHARACTER
 *
 DOSF62
 . DOS FUNCTION: 6 SUBFUNCTION: 2
 .
 - GET A TRANSLATED CHARACTER FROM THE KEYBOARD -
 .
 ENTRY: D = HORIZONTAL CURSOR POSITION
 E = VERTICAL CURSOR POSITION
 D,E NOT USED IN DOSF62N (\$KEYCHAR) ENTRY
 .
 EXITS: ZERO TRUE IF NO CHARACTER READY
 A = CHARACTER, AFTER TRANSLATION
 BC = SCRATCHED (NOT ON DOSF62N = \$KEYCHAR = ENTRY)
 HL = SCRATCHED
 NOTE: L = LOW 7 BITS OF UN-TRANSLATED KEYCODE (IF NEEDED)
 4 EXTRA STACK LEVELS USED (MAX)
 (0 EXTRA STACK LEVELS USED = IN DOSF62N (\$KEYCHAR) ENTRY)
 .
 CALL BLINKDE BLINK THE CURSOR AT (DE)
 DOSF62N
 MLA *SEKBS1 GET KEYBOARD STATUS 1 INTO (A)
 ND SEKBRDY EXIT IF KEYBOARD NOT READY

154,K 175552 053
 155,K
 156,K 175553 257
 157,K 175554 370
 158,K 175555 066 152 367
 159,K 175560 176 044 177
 160,K 175563 056 334
 161,K 175565 307
 162,K 175566 115 265
 163,K 175570 007
 164,K
 165,K 175571
 166,K
 167,K
 168,K
 169,K
 170,K
 171,K
 172,K
 173,K
 174,K
 175,K
 176,K
 177,K
 178,K
 179,K
 180,K
 181,K
 182,K
 183,K
 184,K
 185,K
 186,K
 187,K
 188,K
 189,K 175571 106 312 374
 190,K 175574 043
 191,K
 192,K 175575 371
 193,K 175576 007

```

RTZ
.
XRM                ELSE RESET READY BIT
LMA
MLL                SEKBCH        GET THE CHARACTER
NDL                0177        STRIP OFF THE SIGN BIT
LH                SEKTRAN>8    GENERATING INDEX INTO TRANSLATE TABLE
LAM                GET TRANSLATED CODE
ORHH              INSURE ZERO FLAG IS FALSE
RET

*
DOSF63
.
DOS FUNCTION: 6   SUBFUNCTION: 3
.
- WRITE A BYTE TO THE SCREEN -
.
ENTRY: B = BYTE TO BE WRITTEN
      D = HORIZONTAL CURSOR POSITION
      E = VERTICAL CURSOR POSITION
.
EXITS: IF D OR E OUT OF RANGE:
      CARRY TRUE
      A = SCRATCHED
      IF D AND E WITHIN RANGE:
      A = SCRATCHED
      HL = BUFFER ADDRESS OF BYTE WRITTEN
      1 EXTRA STACK LEVELS USED (MAX)
.
NOTE: THIS ROUTINE CAN OVER-WRITE A BLINKING CURSOR
      BUT THE BLINK ROUTINE IS WRITTEN TO ALLOW IT BY NOT
      RESTORING THE CHARACTER BEHIND THE CURSOR IF THE
      CURSOR IS NOT THERE ANY MORE.
      NOT CHECKED BECAUSE FASTER BY ELIMINATING CALL TO CURSES.
.
CALL                DSPCBL        COMPUTE BUFFER LOCATION
RTC                EXIT IF OUT OF RANGE
.
LMB                ELSE STORE THE BYTE
RET                AND EXIT FALSE CARRY
    
```

194,K
 195,K 175577
 196,K
 197,K
 198,K
 199,K
 200,K
 201,K
 202,K
 203,K
 204,K
 205,K 175577 046 364
 206,K 175601 036 000
 207,K 175603 007
 208,K
 209,K 175604
 210,K
 211,K
 212,K
 213,K
 214,K
 215,K
 216,K
 217,K
 218,K
 219,K 175604 046 013
 220,K 175606 036 000
 221,K 175610 007
 222,K
 223,K 175611
 224,K
 225,K
 226,K
 227,K
 228,K
 229,K
 230,K
 231,K
 232,K
 233,K
 234,K
 235,K
 236,K 175611 066 242 056 357 307
 237,K 175616 064 001
 238,K 175620 370
 239,K

```

*
DOSF64
.
. DOS FUNCTION: 6 SUBFUNCTION: 4
.
. - RETURN HOME UP POSITION IN (DE) -
.
.           EXITS: D = HOME UP HORIZONTAL CURSOR POSITION
.                 E = HOME UP VERTICAL CURSOR POSITION
.                 0 EXTRA STACK LEVELS USED (MAX)
.
.           LE      BL+1=MAXLIN
.           LD      LC
.           RET
*
DOSF65
.
. DOS FUNCTION: 6 SUBFUNCTION: 5
.
. - RETURN HOME DOWN POSITION IN (DE) -
.
.           EXITS: D = HOME DOWN HORIZONTAL CURSOR POSITION
.                 E = HOME DOWN VERTICAL CURSOR POSITION
.                 0 EXTRA STACK LEVELS USED (MAX)
.
.           LE      BL
.           LD      LC
.           RET
*
DOSF66
.
. DOS FUNCTION: 6 SUBFUNCTION: 6
.
. - TURN THE CURSOR ON -
.
.           ENTRY: D = HORIZONTAL CURSOR POSITION
.                 E = VERTICAL CURSOR POSITION
.
.           EXITS: A,B,C,H,L = SCRATCHED
.                 IF D OR E OUT OF RANGE: CURSOR "ON" BUT NOT FLASHING
.                 3 EXTRA STACK LEVELS USED (MAX)
.
.           MLA      *SECFLAGS      SET THE CURSOR ON/OFF SWITCH TO ON
.           OR       CURONOFF
.           LMA
.
.           FALLS THROUGH INTO BLINKDE
    
```

```

240,K
241,K 175621
242,K
243,K
244,K
245,K
246,K
247,K 175621 066 245 056 357
248,K 175625 111 047
249,K 175627 062 254
250,K 175631 111 253
251,K 175633 062 261
252,K 175635 022 070
253,K 175637 112 237 374
254,K 175642 022 060
255,K
256,K 175644
257,K
258,K
259,K
260,K
261,K
262,K
263,K
264,K
265,K
266,K
267,K
268,K
269,K
270,K 175644 066 242 056 357 307
271,K 175651 044 001
272,K 175653 053
273,K 175654 307
274,K 175655 066 153
275,K 175657 257
276,K 175660 044 010
277,K 175662 053
278,K
279,K 175663 066 242
280,K 175665 257
281,K 175666 370
282,K 175667 066 245
283,K 175671 047
284,K 175672 106 312 374
285,K 175675 043
286,K
287,K 175676 022 070
288,K 175700 076 357
289,K 175702 105 242
290,K 175704 044 010
291,K 175706 105 244
    
```

```

*
BLINKDE
.
. IF THE CURSOR POSITION GIVEN IN (DE) IS DIFFERENT FROM THE OLD POSITION,
.   SUSPEND THE CURSOR AND UPDATE THE OLD CURSOR POSITION TO THE NEW.
.   3 EXTRA STACK LEVELS USED (MAX)
.
HL          SECPOS          BC = OLD CURSOR POSITION
DL          BC,HL
XREC
XROB
ORBC
PUSH        XA              SAVE XA IN CASE CURSES IS CALLED
CFZ         CURSES         SUSPEND CURSOR IF BC .NE. DE
POP         XA              RESTORE XA

*
BLINK
.
. IF THE CURSOR ON/OFF SWITCH IS ON AND THE LINE FREQUENCY COUNTER BIT
.   USED FOR FLASHING IS DIFFERENT FROM THE CURSOR "IN BUFF" BIT,
.   UPDATE THE CURSOR "IN BUFF" BIT AND THEN IF THE CURSOR POSITION
.   IS WITHIN THE RANGE OF THE SCREEN, EITHER RESTORE THE HIDDEN
.   CHARACTER INTO THE BUFFER IF THE "IN BUFF" BIT IS NOW A ZERO OR SAVE
.   THE BUFFER LOCATION IN THE HIDDEN CHARACTER AND PUT THE CURSOR
.   CHARACTER IN THE BUFFER IF THE "IN BUFF" BIT IS A ONE.
.   IF ON RESTORING THE HIDDEN CHARACTER IT IS NOTED THAT THE CURSOR
.   CHARACTER IS NOT IN THE BUFFER (OVERWRITTEN) THEN THE CHARACTER IS
.   NOT RESTORED (ALLOWING WRITING IN THE BUFFER ON TOP OF THE CURSOR).
.   1 EXTRA STACK LEVELS USED (MAX)
.
MLA         *SECFLAGS      EXIT IF THE CURSOR IS OFF
ND          CURONOFF
RTZ
LAM
LL          SELFREQ        EXIT IF THE "OFF" BIT EQUALS THE
                           LINE FREQUENCY BIT
XRM
ND          CURINBUF
RTZ

.
LL          SECFLAGS      UPDATE THE "IN BUF" BIT
XRM
LMA
LL          SECPOS        GET THE CURSOR POSITION
DL          DE,HL
CALL        DSPCBL        GET THE MEMORY ADDRESS IN THE BUFFER
RTC         EXIT IF THE CURSOR IS OFF THE SCREEN

.
PUSH        XA              SAVE THE X-REGISTER
LX         SECFLAGS>8     SET UP THE PAGE REGISTER
PL         A,SECFLAGS
ND         CURINBUF       BRANCH ON CURSOR POSITION (IN/OUT BUFFER)
PL         A,SECCHAR      (GET THE CURSOR CHARACTER)
    
```

292.K	175710	150	322	373		JTZ	BLINKOUT	RESTORE CHARACTER IF THE CURSOR WENT OUT
293.K					.			
294.K	175713	327				LCM		ELSE SAVE THE NEW HIDDEN CHARACTER
295.K	175714	126	243			PS	C,SECHIDE	AND PUT THE CURSOR CHARACTER
296.K	175716	370				LMA		INTO THE DISPLAY BUFFER
297.K	175717	022	060			POP	XA	RESTORE THE XA REGISTERS
298.K	175721	007				RET		
299.K					.			
300.K	175722	124	243		BLINKOUT	PL	C,SECHIDE	(GET THE HIDDEN CHARACTER)
301.K	175724	277				CPM		IS THE CURSOR STILL IN MEMORY
302.K	175725	022	060			POP	XA	
303.K	175727	013				RFZ		NO, IT WAS OVERWRITTEN
304.K	175730	372				LMC		YES, RESTORE THE HIDDEN CHARACTER
305.K	175731	007				RET		

306,K
 307,K
 308,K
 309,K 175732 036 000
 310,K 175734 174 004 001
 311,K 175737 174 074 014
 312,K 175742 013
 313,K
 314,K 175743 046 013
 315,K
 316,K
 317,K 175745
 318,K
 319,K
 320,K
 321,K
 322,K
 323,K
 324,K
 325,K
 326,K
 327,K
 328,K
 329,K
 330,K
 331,K
 332,K
 333,K
 334,K
 335,K 175745 106 225 374
 336,K 175750 106 312 374
 337,K 175753 043
 338,K
 339,K 175754 115 164 156
 340,K 175757 115 166 236
 341,K
 342,K 175762 250
 343,K 175763 106 114 374
 344,K
 345,K 175766 046 156 036 357
 346,K 175772 353
 347,K 175773 066 160
 348,K 175775 026 060
 349,K 175777 250
 350,K 176000 310
 351,K 176001 021
 352,K
 353,K 176002 250
 354,K 176003 007

```

+
.
.
DISPNEWL LD          LC          ** MOVED HERE TO SAVE 3 BYTES ***
          ADE          1          ** PART OF THE DISPLAY CODE ***
          CPE          BL+1       RESET THE HORIZONTAL POSITION
          RFZ                                     BUMP THE VERTICAL POSITION
                                               EXIT IF NOT AT BOTTOM OF SCREEN
.
.
          LE          BL          ELSE SET VERT POSITION TO BOTTOM
          JMP          DOSF67       OF SCREEN, ROLL UP, AND RETURN
*
DOSF67
.
DOS FUNCTION: 6  SUBFUNCTION: 7
.
- ROLL THE SCREEN UP ONE LINE -
.
          ENTRY: D = HORIZONTAL CURSOR POSITION
          E = VERTICAL CURSOR POSITION
.
          EXITS: ALL REGISTERS PRESERVED
          IF D OR E OUT OF RANGE:
          CARRY TRUE
          SCREEN IN ORIGINAL POSITION
          IF D AND E BOTH IN RANGE:
          CARRY FALSE
          SCREEN ROLLED ONE LINE
          3 EXTRA STACK LEVELS USED (MAX)
.
          CALL        CURSESRS     SAVE REGISTERS AND SUSPEND CURSOR
          CALL        DSPCBL       SEE IF DE IS WITHIN RANGE
          RTC          RESTORE REGS AND EXIT IF NOT
.
          DPL        HL,SEDLN01    PUT THE ADDRESS OF THE TOP LINE INTO
          DPS        HL,SEDNU8     THE POINTER BELOW THE BOTTOM LINE
.
          XRA
          CALL        BLANKIT      BLANK OUT THE WHOLE LINE
.
          DE        SEDLN01       ROLL UP THE LINE POINTERS
          LHD
          LL        SEDLN01+2
          LC        MAXLIN*2      (ALL THE LINES)
          XRA
          LBA
          BT
.
          XRA          SET CARRY FALSE
          RET         RESTORE THE REGISTERS AND EXIT
    
```


355,K
 356,K 176004
 357,K
 358,K
 359,K
 360,K
 361,K 176004 046 000 036 320
 362,K 176010 066 156 056 357
 363,K 176014 006 120
 364,K
 365,K 176016 027
 366,K 176017 174 017
 367,K 176021 117 015
 368,K 176023 176 074 236
 369,K 176026 110 016 374
 370,K
 371,K 176031 250
 372,K 176032 066 241 370
 373,K
 374,K 176035 066 242 370
 375,K
 376,K 176040 066 244 370
 377,K
 378,K 176043 106 177 373
 379,K
 380,K
 381,K 176046
 382,K
 383,K
 384,K
 385,K
 386,K
 387,K
 388,K
 389,K
 390,K
 391,K
 392,K
 393,K
 394,K
 395,K
 396,K
 397,K
 398,K
 399,K 176046 106 225 374
 400,K 176051 016 040
 401,K
 402,K 176053 106 312 374
 403,K 176056 043
 404,K
 405,K 176057 303
 406,K 176060 331

```

+
DSPINIT
.
. INITIALIZE ALL DISPLAY POINTERS AND CONTROL INFORMATION
.   3 EXTRA STACK LEVELS USED (MAX)
.
DE      SDSPBUF      POINT TO THE SCREEN BUFFER
HL      SEDLN01      POINT TO THE POINTER LIST
LA      MAXPOS       LENGTH OF EACH LINE
.
DSPINITL DS          DE,HL      SET UP A LINE POINTER
          INCP        DE,A       BUMP THE POINTER VALUE
          INCP        HL,2       BUMP THE POINTER ADDRESS
          CPL         SEDLN01+(2*MAXLIN) GO UNTIL ALL LINES DONE
          JFZ         DSPINITL
.
XRA     ZERO THE DISPLAY ROUTINE FLAGS
MSA     SEDOPTS+1    USED BY THE DOS FUNCTIONS
.
MSA     SECFLAGS     SET CURSOR FLAGS TO SUSPENDED
          AND NOT IN THE BUFFER
LA      CURSOR       INITIALIZE THE CHARACTER (ASSUMED ZERO)
MSA     SECCHAR      USED FOR THE CURSOR
.
CALL    DOSF64       GET HOME UP POSITION IN (DE)
JUMP    DOSF68       ERASE THE ENTIRE SCREEN AND EXIT
+
DOSF68
.
. DOS FUNCTION: 6   SUBFUNCTION: 8
.
- ERASE FROM THE CURSOR THRU THE END OF FRAME -
.
ENTRY: D = HORIZONTAL CURSOR POSITION
       E = VERTICAL CURSOR POSITION
.
EXITS: ALL REGISTERS PRESERVED
       IF D OR E OUT OF RANGE:
           CARRY TRUE
           NO LINES ERASED
       IF D AND E BOTH WITHIN RANGE:
           CARRY FALSE
           LINE(S) ERASED
       3 EXTRA STACK LEVELS USED (MAX)
.
CALL    CURSESRS     SAVE REGISTERS AND SUSPEND CURSOR
LB      ' '          STANDARD ERASE CHARACTER
.
DOSF68LP CALL    DSPCBL      COMPUTE THE BUFFER POSITION
          RTC          RESTORE REGS AND EXIT IF DE OUT OF RANGE
.
LAD     BLANK TO THE END OF THAT LINE
LDB     (SAVE THE B-REGISTER)
    
```


459,K	176137	250		XRA	ELSE DO THE BLOCK TRANSFER	
460,K	176140	310		LBA	TO CLEAR THE REST OF THE LINE	
461,K	176141	021		BT		
462,K	176142	250		XRA	EXIT FALSE CARRY	
463,K	176143	007		RET		
464,K						
465,K	176144					
466,K						
467,K						
468,K						
469,K						
470,K						
471,K						
472,K						
473,K						
474,K						
475,K						
476,K						
477,K	176144	106	225 374	CALL	CURSESRS	SAVE REGISTERS AND SUSPEND CURSOR
478,K	176147	106	312 374	CALL	DSPCBL	SEE IF DE WITHIN RANGE
479,K	176152	043		RTC		RESTORE REGS AND EXIT IF NOT
480,K						
481,K	176153	115	164 234	DPL	HL,SEDLBOT	PUT THE ADDRESS OF THE BOTTOM LINE
482,K	176156	115	166 154	DPS	HL,SEDNUL	IN THE POINTER ABOVE THE TOP LINE
483,K						
484,K	176161	250		XRA		
485,K	176162	106	114 374	CALL	BLANKIT	BLANK OUT THE WHOLE LINE
486,K						
487,K	176165	046	235 036 357	DE	SEDLBOT+1	ROLL DOWN THE LINE POINTERS
488,K	176171	353		LHD		
489,K	176172	066	233	LL	SEDLBOT-2+1	
490,K	176174	026	060	LC	MAXLIN*2	(ALL THE LINES)
491,K	176176	250		XRA		
492,K	176177	310		LBA		
493,K	176200	111	021	BTR		
494,K						
495,K	176202	250		XRA	SET CARRY FALSE	
496,K	176203	007		RET	RESTORE THE REGISTERS AND EXIT	
497,K						
498,K	176204					
499,K						
500,K						
501,K						
502,K						
503,K						
504,K						
505,K						
506,K						
507,K						
508,K						
509,K						
510,K						

511,K 176204 106 225 374
512,K 176207
513,K 176207 105 242
514,K 176211 044 376
515,K 176213 107 242
516,K 176215 007
517,K
518,K 176216
519,K
520,K
521,K
522,K
523,K
524,K
525,K
526,K
527,K
528,K
529,K
530,K
531,K
532,K
533,K
534,K 176216 026 150 016 357
535,K 176222 062 047
536,K 176224 007

CALL CURSESRS SAVE REGISTERS AND SUSPEND CURSOR
DOSF611N PL A,SECFLAGS SET THE CURSOR ON/OFF BIT TO "OFF"
ND -1-CURONOFF
PS A,SECFLAGS
RET RESTORE THE REGISTERS AND EXIT

*
DOSF612

. DOS FUNCTION: 6 SUBFUNCTION: 12

. - RETURN FUNCTION KEY AND OTHER STATUS -

. EXITS: ALL REGISTERS PRESERVED
. BC EXCEPTED, THEY CONTAIN THE STATUS BITS
. B = (X, X, X, X, SEKBDWN, SEKBRDY, SEKBDKY, SEDSPKY)
. C = (SEINTKY, SEATTKY, SERSTKY, SEFUNC5, 4, 3, 2, 1)

. 0 EXTRA STACK LEVELS USED (MAX)

. WARNING: CHANGING OF LOCATIONS SEKBS2 OR SEKBS1 WITHOUT DUE REGARD FOR EFFECT
. CAN CAUSE LOSS OF CHARACTERS, FUNCTION KEYS AND AUTO RESTARTS!!!

. BC SEKBS2
. DL BC,BC GET THE STATUS BYTES
. RET

539,K
 540,K 176225
 541,K
 542,K
 543,K
 544,K
 545,K
 546,K 176225 051 271 335
 547,K 176230 055
 548,K 176231 060
 549,K 176232 060
 550,K 176233 051 303 374
 551,K 176236 070
 552,K
 553,K 176237
 554,K
 555,K
 556,K
 557,K
 558,K
 559,K
 560,K
 561,K
 562,K
 563,K
 564,K
 565,K
 566,K
 567,K
 568,K 176237 076 357
 569,K 176241 115 164 245
 570,K 176244 113 146 245
 571,K 176247 105 242
 572,K 176251 044 010
 573,K 176253 053
 574,K
 575,K
 576,K
 577,K
 578,K 176254 105 242
 579,K 176256 044 367
 580,K 176260 107 242
 581,K 176262 346
 582,K 176263 335
 583,K 176264 106 312 374
 584,K 176267 113 144 245
 585,K 176272 043
 586,K
 587,K 176273 105 244
 588,K 176275 277
 589,K 176276 013
 590,K 176277 105 243

*
 CURSESRS
 .
 . SAVE THE REGISTERS AND CAUSE A "RETURN" AFTER THE CALL TO THIS ROUTINE
 . TO TRANSFER CONTROL TO "DSPRESTR". THEN SUSPEND THE CURSOR.
 . 3 EXTRA STACK LEVELS USED (MAX)
 .
 . PUSH DSPREGSA+7 SAVE THE REGISTERS IN THE
 . REGS AREA FOR THE DISPLAY
 . POP HL GET RID OF "DSPREGSA" ADDRESS ON STACK
 . POP HL PUT "DSPRESTR" ON STACK BELOW
 . PUSH DSPRESTR THE RETURN ADDRESS
 . PUSH HL
 *
 CURSES
 .
 . SAVE THE NEW CURSOR POSITION GIVEN IN (DE) IN "SECPOS". THEN, IF
 . THE CURSOR CHARACTER IS IN THE BUFFER, SUSPEND THE CURSOR
 . BY PLACING THE CHARACTER IN "SECHIDE" BACK INTO THE BUFFER
 . AS DIRECTED BY THE OLD CURSOR POSITION BEFORE THIS ROUTINE
 . WAS ENTERED.
 .
 . ENTRY: D = HORIZONTAL CURSOR POSITION
 . E = VERTICAL CURSOR POSITION
 .
 . EXITS: HL,A = SCRATCHED
 . X => SECFLAGS PAGE
 . 1 EXTRA STACK LEVELS USED (MAX)
 .
 . LX SECFLAGS>8
 . DPL HL,SECPOS SAVE THE OLD CURSOR POSITION IN HL
 . DPS DE,SECPOS UPDATE THE CURSOR POSITION TO THAT IN DE
 . PL A,SECFLAGS EXIT IF THE CURSOR CHARACTER IS
 . ND CURINBUF NOT CURRENTLY IN THE BUFFER
 . RTZ (THE "CURIN BUFF" BIT IS A ZERO)
 *
 . CLEAR THE CURSOR ON BIT AND STORE THE HIDDEN CHARACTER IN THE
 . CURSOR POSITION GIVEN IN (HL)
 .
 . PL A,SECFLAGS ELSE CLEAR THE CURSOR IN BUFF BIT
 . ND =1-CURINBUF
 . PS A,SECFLAGS
 . LEL HL => WHERE THE CURSOR WAS
 . LDH
 . CALL DSPCBL
 . DPL DE,SECPOS RESTORE THE NEW CURSOR POSITION IN DE
 . RTC EXIT IF CURSOR WAS OFF THE SCREEN
 .
 . PL A,SECCHAR CHECK IF THE CURSOR IS STILL IN MEMORY
 . CPM IF NOT, DON'T RESTORE THE HIDDEN CHAR
 . RFZ
 . PL A,SECHIDE ELSE, STORE THE HIDDEN CHARACTER

591,K	176301	370	LMA		WHERE THE CURSOR WAS
592,K	176302	007	RET		AND EXIT
593,K			*		
594,K	176303	066 271 056 335	DSPRESTR	HL DSPREGSA+7	RESTORE THE REGISTERS FROM THE
595,K	176307	111 055	REGL		SAVE AREA FOR THE DISPLAY
596,K	176311	007	RET		ROUTINES.
597,K			*		
598,K	176312		DSPCBL		
599,K			.		
600,K			.	COMPUTE DISPLAY BUFFER LOCATION	
601,K			.		
602,K			.	ENTRY: D = HORIZONTAL CURSOR POSITION	
603,K			.	E = VERTICAL CURSOR POSITION	
604,K			.		
605,K			.	EXITS: IF D AND E BOTH WITHIN RANGE:	
606,K			.	CARRY FALSE	
607,K			.	HL = MEMORY LOCATION IN THE SCREEN BUFFER	
608,K			.	A = ZERO	
609,K			.	IF D OR E NOT WITHIN RANGE:	
610,K			.	CARRY TRUE	
611,K			.	A = SCRATCHED	
612,K			.	0 EXTRA STACK LEVELS USED (MAX)	
613,K			.		
614,K	176312	303	LAD		EXIT TRUE CARRY IF D OUT OF RANGE
615,K	176313	004 260	AD	=MAXPOS	
616,K	176315	043	RTC		
617,K			.		
618,K	176316	304	LAE		EXIT TRUE CARRY IF E OUT OF RANGE
619,K	176317	024 014	SU	BL+1	MAKE A = -MAXLIN THRU -1
620,K	176321	074 350	CP	=MAXLIN	
621,K	176323	043	RTC		
622,K			.		
623,K	176324	200	ADA		DOUBLE UNBIASED E VALUE TO GET INDEX
624,K	176325	066 236 056 356	HL	SEDNUB=256	INTO THE LIST OF LINE POINTERS
625,K	176331	017	INCP	HL,A	(256 CORRECTS FOR SINGLE BYTE INCP)
626,K	176332	057	DL	HL,HL	GET POINTER TO BEGINNING OF LINE
627,K	176333	303	LAD		INDEX INTO THE SELECTED LINE
628,K	176334	017	INCP	HL,A	
629,K	176335	250	XRA		EXIT FALSE CARRY
630,K	176336	007	RET		

633, K		*		
634, K		. DISPLAY A STRING ROUTINE		
635, K		.		
636, K		. CONTROL CHARACTERS:		
637, K		.		
638, K	000003	\$ES*	EQU	003
639, K	000007	\$BP*	EQU	007
640, K	000011	\$H*	EQU	011
641, K	000013	\$V*	EQU	013
642, K	000015	\$EL*	EQU	015
643, K	000021	\$EEOF*	EQU	021
644, K	000022	\$EEDL*	EQU	022
645, K	000023	\$RU*	EQU	023
646, K	000024	\$RD*	EQU	024
647, K	000033	\$F*	EQU	033
648, K		.		
649, K	000203	\$NS*	EQU	0203
650, K	000207	\$CK*	EQU	0207
651, K	000211	\$HA*	EQU	0211
652, K	000213	\$VA*	EQU	0213
653, K	000215	\$NL*	EQU	0215
654, K		.	EQU	0221
655, K		.	EQU	0222
656, K	000223	\$HU*	EQU	0223
657, K	000224	\$HD*	EQU	0224
658, K	000233	\$O*	EQU	0233
659, K		.		
660, K	000200	\$OI*	EQU	B7
661, K	000100	\$OS*	EQU	B6
662, K	000040	\$OW*	EQU	B5

END OF DISPLAY STRING
BEEP
NEW DISPLAY COLUMN FOLLOWS
NEW DISPLAY ROW FOLLOWS
ADVANCE TO NEW LINE AND TERMINATE STRING
ERASE TO END OF FRAME
ERASE TO END OF LINE
ROLL UP
ROLL DOWN
FORCE DISPLAY OF NEXT CHARACTER
NEW STRING ADDRESS FOLLOWS (LSB,MSB)
CLICK
DISPLAY COLUMN ADJUSTMENT FOLLOWS
DISPLAY ROW ADJUSTMENT FOLLOWS
ADVANCE TO NEW LINE
* NOT USED *
* NOT USED *
HOME UP (UPPER LEFT-HAND CORNER)
HOME DOWN (LOWER LEFT-HAND CORNER)
NEW OPTIONS FOLLOW
INVERTED VIDEO OPTION
SKIP BLANKS OPTION
INHIBIT WAIT ON DISPLAY KEY OPTION

663,K
 664,K
 665,K
 666,K
 667,K
 668,K
 669,K
 670,K
 671,K
 672,K
 673,K
 674,K
 675,K
 676,K
 677,K
 678,K
 679,K
 680,K
 681,K
 682,K
 683,K
 684,K 176337 016 140
 685,K
 686,K 176341 022 070
 687,K 176343 070
 688,K 176344 106 237 374
 689,K 176347 111 126 240
 690,K
 691,K 176352 060
 692,K 176353 006 377
 693,K 176355 107 246
 694,K
 695,K 176357
 696,K
 697,K
 698,K
 699,K 176357 307
 700,K 176360 015
 701,K
 702,K 176361 310
 703,K 176362 124 241
 704,K
 705,K 176364 074 033
 706,K 176366 150 062 375
 707,K 176371 070
 708,K 176372 140 007 375
 709,K 176375 074 203
 710,K 176377 140 065 375
 711,K 176402 074 234
 712,K 176404 100 065 375
 713,K
 714,K 176407 066 152 056 375

*
 . THE DISPLAY ROUTINE ENTRY POINTS
 .
 . "DISPPOS" INITIALIZES THE OPTIONS IN THE B-REGISTER TO
 . A DOS-COMPATIBLE SET
 . "DISPLAY" STORES THE OPTIONS IN THE B-REGISTER IN "SEDOPTS"
 .
 . ENTRY: B = OPTIONS (UNLESS ENTERING AT DISPPOS)
 . D = HORIZONTAL CURSOR POSITION (0 THRU 79)
 . E = VERTICAL CURSOR POSITION (-12 THRU 11)
 . HL = STRING ADDRESS
 .
 . EXITS: A = ENTRY VALUE
 . B = LAST OPTION VALUE SET
 . C = ENTRY VALUE
 . DE = CURSOR POSITION AFTER LAST CHARACTER DISPLAYED
 . OR CURSOR POSITION WHEN LAST CONTROL EXECUTED
 . HL = ADDRESS OF BYTE AFTER STRING TERMINATOR
 . 6 EXTRA STACK LEVELS USED (MAX)
 . EXCLUDING DISPLAY WAIT VECTOR OVERHEAD (IF USED)
 .
 . DISPPOS LB SOS+SOW SKIP BLANKS AND INHIBIT DSP KEY WAIT
 .
 . DISPLAY PUSH XA SAVE THE X-REGISTER
 . PUSH HL SAVE THE STRING POINTER
 . CALL CURSES MAKE SURE THE CURSOR IS SUSPENDED
 . DPS BC,SEDOPTS SAVE THE BC REGISTER PAIR IN 'SEDOPTS'
 .
 . DISPCPRP POP HL RESTORE THE STRING POINTER
 . DISPCPSL LA =1 CLEAR THE PHYSICAL SCREEN POINTER
 . PS A,SECPOS+1 MSB TO ALL ONES (CAN BE IN ROM!)
 .
 . DISPLANC
 .
 . DISPLAY THE NEXT CHARACTER IN THE STRING POINTED TO BY (HL)
 .
 . LAM GET THE NEXT STRING CHARACTER
 . INCP HL BUMP THE STRING POINTER
 .
 . LBA SAVE THE CHARACTER IN THE B-REG
 . PL C,SEDOPTS+1 C = DISPLAY OPTION BITS
 .
 . CP SF FALL THROUGH IF THE CHARACTER
 . JTZ DISPFORC (SPECIAL HANDLING)
 . PUSH HL (SAVE THE STRING POINTER)
 . JTC DISPFUNC CANNOT BE A CONTROL
 . CP SNS
 . JTC DISPOUT
 . CP SO+1
 . JFC DISPOUT
 .
 . DISPFUNC HL DISPFTAB-2 SEE IF FUNCTION IN TABLE

715	K	176413	117	015	DISPFCLP	INCP	HL,2		
716	K	176415	307			LAM			
717	K	176416	260			ORA			
718	K	176417	150	065 375		JTZ	DISPOUT	WRITE CHAR IF TERMINATOR REACHED	
719	K				.				
720	K	176422	015			INCP	HL	HL => FUNCTION EXECUTION ADDRESS	
721	K	176423	271			CPB		SEE IF CONTROL CHARACTER DESIRED	
722	K	176424	110	013 375		JFZ	DISPFCLP	KEEP SCANNING IF NOT	
723	K				.				
724	K	176427	302			LAC		SEE IF THE "INHIBIT WAIT BEFORE CONTROL"	
725	K	176430	044	040		ND	\$0W	OPTION BIT IS SET	
726	K	176432	110	047 375		JFZ	DISPDOCC	JUST DO CONTROL FUNCTION IF IT IS	
727	K				.				
728	K	176435	106	105 357	DISPDSPW	CALL	SVDISPWS	CALL THE DISPLAY WAIT ROUTINE	
729	K				.			(WILL ALWAYS DO IT ONCE IF ENABLED!!)	
730	K	176440	105	151		PL	A,SEKBS1	ELSE SEE IF THE DISPLAY KEY IS DOWN	
731	K	176442	044	001		ND	SEDSPKY		
732	K	176444	110	035 375		JFZ	DISPDSPW	WAIT ON IT IF IT IS	
733	K				.				
734	K	176447	062	060	DISPDOCC	POP	BC	PUT STRING POINTER INTO BC FOR A WHILE	
735	K	176451	051	353 374		PUSH	DISPCPSL	PUT NEXT CHAR RETURN ADR ON THE STACK	
736	K	176454	057			DL	HL,HL	GET THE CONTROL ROUTINE ADDRESS	
737	K	176455	070			PUSH	HL	AND PUT THAT ON THE STACK	
738	K	176456	362			LLC		MAKE HL => NEXT STRING CHARACTER	
739	K	176457	351			LHB			
740	K	176460	250			XRA		MAKE A = 0 FOR SH AND SV	
741	K	176461	007			RET		OFF TO THE CONTROL ROUTINE	
742	K				*				
743	K	176462	317		DISPFORC	LBM		FORCE THE NEXT CHARACTER	
744	K	176463	015			INCP	HL	TO BE DISPLAYED REGARDLESS OF ITS	
745	K	176464	070			PUSH	HL	VALUE	
746	K				.	JUMP	DISPOUT	NOTE: SPECIAL HANDLING OF THIS SF CODE	
747	K				*				
748	K	176465	302		DISPOUT	LAC		ISOLATE THE VIDEO INVERSION OPTION BIT	
749	K	176466	044	200		ND	B7	AND INVERT THE SIGN BIT OF THE	
750	K	176470	111	250		XRAB		CHARACTER TO BE WRITTEN IF SET	
751	K	176472	115	164 245		DPL	HL,SECPOS	GET THE PHYSICAL SCREEN POSITION	
752	K	176475	305			LAH		COMPUTE THE PHYSICAL LOCATION	
753	K	176476	004	001		AD	1	IF IT IS NOT KNOWN (IN ROM!)	
754	K	176500	142	312 374		CTC	DSPCBL		
755	K	176503	140	146 375		JTC	DISPOFFS	CATCH OFF THE SCREEN	
756	K				.				
757	K	176506	006	177		LA	0177	CATCH WRITING SPACES	
758	K	176510	241			NDB			
759	K	176511	074	040		CP	1 1		
760	K	176513	110	124 375		JFZ	DISPWRT	JUST WRITE IF NOT	
761	K				.				
762	K	176516	302			LAC		ELSE SEE IF SPACES ARE TO BE SKIPPED	
763	K	176517	044	100		ND	B6		
764	K	176521	110	125 375		JFZ	DISPSKIP	DON'T WRITE IF SO	
765	K				.				
766	K	176524	371		DISPWRT	LMB		ELSE STORE THE BYTE ON THE SCREEN	

```

767,K 176525 015
768,K 176526 115 166 245
769,K 176531 060
770,K 176532 113 004 001
771,K 176535 113 074 120
772,K 176540 140 357 374
773,K
774,K 176543 104 353 374
775,K
776,K 176546 113 004 001
777,K 176551 104 352 374
778,K
779,K 176554
780,K
781,K
782,K
783,K 176554 011 254 375
784,K 176557 013 261 375
785,K 176562 211 253 375
786,K 176565 213 260 375
787,K 176570 215 332 373
788,K 176573 203 240 375
789,K 176576 223 177 373
790,K 176601 224 204 373
791,K
792,K 176604 233 242 375
793,K 176607 023 345 373
794,K 176612 024 144 374
795,K 176615 022 105 374
796,K 176620 021 046 374
797,K 176623 007 247 375
798,K 176626 207 251 375
799,K 176631 015 265 375
800,K 176634 003 270 375
801,K 176637 000
802,K
803,K 176640 057
804,K 176641 007
805,K
806,K 176642 307
807,K 176643 015
808,K 176644 107 241
809,K 176646 007
    
```

```

DISPSKIP INCP HL INCREMENT THE PHYSICAL SCREEN POSITION
          DPS HL,SECPOS SAVE THE PHYSICAL SCREEN POSITION
          POP HL RESTORE THE STRING POINTER
          ADD 1 INCREMENT THE CURSOR POSITION
          CPD MAXPOS ON TO THE NEXT STRING CHARACTER
          JTC DISPLANC IF CURSOR STILL ON THE SCREEN
          *
          JMP DISPCPSL ELSE CLEAR THE PHYSICAL SCREEN LOCATION
          *
DISPOFFS ADD 1 INCREMENT THE CURSOR POSITION AND
          JMP DISPCPRP ON TO THE NEXT STRING CHARACTER
          *
DISPFTAB
          *
          . DISPLAY FUNCTION TABLE
          *
          DC $H,*DISPHCOL
          DC $V,*DISPVCOL
          DC $HA,*DISPHADJ
          DC $VA,*DISPVADJ
          DC $NL,*DISPNEWL
          DC $NS,*DISPGNSA
          DC $HU,*DOSF64
          DC $HD,*DOSF65
          DC $F,*DISPFORC (SPECIAL HANDLING)
          DC $O,*DISPGOPT
          DC $RU,*DOSF67
          DC $RD,*DOSF610
          DC $EOL,*DOSF69
          DC $EOF,*DOSF68
          DC $BP,*DISPBEEP
          DC $CK,*DISPCLIK
          DC $EL,*DISPENDL
          DC $ES,*DISPEXIT
          DC 0 TERMINATOR
          *
DISPGNSA DL HL,HL GET NEW STRING ADDRESS
          RET
          *
DISPGOPT LAM GET THE NEW OPTIONS
          INCP HL INCREMENT THE STRING POINTER
          PS A,SEDOPTS+1 STORE THE NEW OPTIONS
          RET
    
```

810,K							
811,K	176647	151		*	DISPBEEP	EX	BEEP
812,K	176650	007				RET	
813,K				*			
814,K	176651	153		*	DISPCLIK	EX	CLICK
815,K	176652	007				RET	
816,K				*			
817,K	176653	303		*	DISPHADJ	LAD	CAUSE HORIZONTAL ADJUSTMENT
818,K							WHEN ENTERED HERE
819,K	176654	207		*	DISPHCOL	ADM	A = ZERO WHEN ENTERED HERE
820,K	176655	330				LDA	SO D = STRING VALUE
821,K	176656	015				INCP	
822,K	176657	007				RET	HL
823,K				*			
824,K	176660	304		*	DISPVADJ	LAE	CAUSE VERTICAL ADJUSTMENT
825,K							WHEN ENTERED HERE
826,K	176661	207		*	DISPVCOL	ADM	A = ZERO WHEN ENTERED HERE
827,K	176662	340				LEA	SO E = STRING VALUE
828,K	176663	015				INCP	
829,K	176664	007				RET	HL
830,K				*			
831,K	176665	106	332	373	DISPENDL	CALL	DISPNEWL
832,K	176670	062	060		DISPEXIT	POP	BC
833,K	176672	111	124	240		DPL	BC,SEDOPTS
834,K	176675	250				XRA	RESTORE C-REG AND LAST OPTIONS IN B-REG
835,K	176676	107	241			PS	CLEAR THE OPTIONS
836,K	176700	022	060			POP	A,SEDOPTS+1
837,K	176702	007				RET	XA
							RESTORE THE XA REGISTER PAIR
							FINALLY, EXIT THE DISPLAY ROUTINE

```

838,K
839,K 176703
840,K
841,K
842,K
843,K
844,K
845,K
846,K
847,K
848,K
849,K 176703 066 141 056 372
850,K 176707 016 040
851,K 176711 106 341 374
852,K 176714 113 024 012
853,K 176717 106 211 373
854,K 176722 106 140 373
855,K 176725 150 322 375
856,K
857,K 176730 310
858,K 176731 106 171 373
859,K 176734 076 357
860,K 176736 106 207 374
861,K 176741 301
862,K 176742 007
179,
180,
    
```

```

*
KEYCHAR
.
. GET A KEYBOARD CHARACTER
.
. ENTRY: DE = CURSOR POSITION TO BE FLASHED WHILE WAITING
.
. EXITS: A AND B = KEYBOARD CHARACTER
. C,H,L = SCRATCHED
. 5 STACK LEVELS USED (MAX) * LESS? *
.
HL      DSPBLNK
LB      SOW          BLANK OUT SOME SPACE FOR THE KEYIN
CALL   DISPLAY     WITHOUT USING DOSF69 (BECAUSE OF CURSESRS)
SUD    DSPBLN      CORRECT FOR UPDATING OF THE D-REGISTER
CALL   DOSF66      TURN ON THE CURSOR
KEYCHARW CALL DOSF62  WAIT FOR A CHARACTER TO BE INPUT
JTZ    KEYCHARW
.
LBA
CALL   DOSF63      ECHO THE CHARACTER
LX     SECFLAGS>8
CALL   DOSF611N   TURN THE CURSOR OFF (OVERWRITTEN BY 63)
LAB
RET
.
INC     1800MOVI
    
```

```

3,L
4,L
5,L
6,L 000004
7,L 040000
8,L
9,L
10,L 176743 022 040 061 062 070
11,L 176752 040 066 064 003
12,L 176756 060 064
13,L
14,L 176760
15,L 176760 106 112 370
16,L 176763 106 045 373
17,L 176766 106 004 374
18,L 176771 020
19,L 176772 036 007
20,L 176774 056 000
21,L 176776 365
22,L 176777 030
23,L 177000 046 000 036 100
24,L 177004 104 114 377
25,L
26,L 177007
27,L
28,L
29,L
30,L 177007 174 070
31,L 177011 046 006 036 111
32,L 177015 066 343 056 375
33,L 177021 106 337 374
34,L 177024 036 114
35,L 177026 106 312 374
36,L 177031 070
37,L
38,L 177032 066 264 056 363
39,L 177036 026 002
40,L 177040 077
41,L
42,L 177041 066 001 056 357
43,L 177045 046 215 036 377
44,L 177051 027
45,L
46,L 177052 076 000
47,L 177054 046 264
48,L 177056 250
49,L
50,L 177057 066 377 056 020
51,L 177063 376
52,L 177064 107 377
53,L 177066 277
54,L 177067 110 110 376
    
```

```

* 1800 MOVING INVERSIONS MEMORY TEST
*
MAXSTLS EQU 4 16K BLOCKS TESTED PER PASS
MAXSZ EQU MAXSTLS<12 MEMORY SIZE BEING TESTED (POWER OF 2)
MUST ALLOW 8K SPACE WITH MIN. MEMORY SIZE
*
MTMSG128 DC $E0L,' 128K',SES
MTMSG64 DC ' 64',SES
MTINC DC '04' STEPS IN 4K CHUNCKS
*
TSTMEM
CALL C12345 SEE IF ENTERED MEMORY TEST LEGALLY
CALL SETUP
CALL DSPINIT INITIALIZE THE WORLD
BETA
LD 8-1 DISPLAY ERROR ADDRESS POINTER (HORIZ)
LH 0
LLH INITIALIZE THE PASS NUMBER
ALPHA
DE MAXSZ START INITIAL STEPSIZE AS 1
JMP MSTART FINISH INIT AS IF ENDED A PASS
*
MTSIZE
*
SIZE CALCULATION DONE PER PASS
*
PUSH DE SAVE THE INCREMENT SIZE
DE 73<8+BL=5 POINT TO MEMORY LOCATION FOR 'K' COUNTER
HL MTMSG128
CALL DISPDOS DISPLAY THE INITIAL MESSAGE
LD 76
CALL DSPCBL GET ADDRESS OF THE COUNTER IN DISPLAY RAM
PUSH
*
HL WRAPST SPECIAL WRAP AROUND MEMORY TEST
LC 2
STL
*
HL SVMEMP+1
DE MTSIZMPF SET INTERRUPT VECTOR FOR SIZE CALCULATION
DS DE,HL
*
LX 0>8 POINTER NEEDED LATER
LE SMST+PISTL ASSUME MEMORY OVER 64K BOUNDARY
XRA
*
HL 010377 SET 72K PHYS. TO ALL ONES
LML (OR 8K PHYS. IF WRAPPED)
PS A,000377 SET 8K PHYS. TO ZEROS
CPM READ 72K PHYS. (OR 8K) TO SEE IF NON-ZERO
JFZ MTSIZ32S NO WRAP AROUND, USING 32K CARDS
    
```

JAN 30, 1978 14:43 HJS

55,L											
56,L	177072	310				LBA				SET OPTIONS - DO BLANKS & WAIT ON DISPLAY	
57,L	177073	046	006	036	112	DE	74<8+BL-5			WRAPPED AROUND, USING 12K CARDS	
58,L	177077	066	352	056	375	HL	MTMSG64				
59,L	177103	106	341	374		CALL	DISPLAY			SO CHANGE THE MESSAGE	
60,L	177106	046	244			LE	SMST+SMSTL+UMSTL			AND START MEMORY SIZE TEST FROM THERE	
61,L											
62,L	177110	364				MTSIZ32S	LLE			MOVE SIZE START TO L	
63,L						*					
64,L	177111					MTSIZLP					
65,L	177111	174	060			POP	DE			GET MEMORY POINTER	
66,L	177113	174	070			PUSH	DE			AND KEEP IT THERE	
67,L	177115	070				PUSH	HL			SAVE THE TABLE POINTER	
68,L	177116	066	357	056	375	HL	MTINC+1				
69,L	177122	250				XRA				(CLEAR CARRY)	
70,L	177123	026	002			LC	2				
71,L	177125	016	060			LB	'0'			UPDATE THE 'K' COUNTER IN FOUR'S	
72,L	177127	062	041			DFSB					
73,L	177131	100	140	376		JFC	MTSIZLP0			WILL NOT GET CARRY UNLESS CROSS 100K	
74,L	177134	006	040			LA	' '				
75,L	177136	174	370			LMA	DE			DONE FOR COSMETIC REASONS ONLY	
76,L											
77,L	177140	060				MTSIZLP0	POP	HL			
78,L	177141	056	363			LH	SMST>8			(SAFETY, DON'T TRUST MEMORY)	
79,L	177143	035				DECP	HL			TRY THE NEXT STL ENTRY	
80,L	177144	176	074	233		CPL	SMST+6			MINIMAL SIZE AT 24K	
81,L	177147	140	173	376		JTC	MTSIZIT				
82,L											
83,L	177152	026	001			LC	1				
84,L	177154	077				STL					
85,L											
86,L	177155	016	377			LB	0377			LOAD NON-ZERO IN SOME MEMORY	
87,L	177157	321				LCB					
88,L	177160	111	126	000		DPS	BC,0			TO SEE IF IT IS THERE	
89,L	177163	111	124	000		DPL	BC,0			(X-REG IS ZERO FROM ABOVE)	
90,L	177166	062	261			ORBC				IF ZERO, NOT FOUND ANY YET	
91,L	177170	150	111	376		JTZ	MTSIZLP				
92,L											
93,L	177173	015				MTSIZIT	INCP	HL		CORRECT POINTER TO FIRST MISSING SECTOR	
94,L	177174	306				LAL					
95,L	177175	046	201	036	377	DE	MERX				
96,L	177201	066	001	056	357	HL	SVMEMP+1			SET THE VECTOR FOR THE MEMORY TEST	
97,L	177205	027				DS	DE,HL				
98,L	177206	060				POP				DON'T NEED THE DISPLAY POINTER	
99,L	177207	174	060			POP	DE			RESTORE INCREMENT SIZE	


```

147,L
148,L 177307 106 102 373
149,L 177312 160 366 377
150,L
151,L 177315 250
152,L 177316 310
153,L 177317 320
154,L 177320 066 376 056 077
155,L 177324 111 027
156,L 177326 117 035
157,L 177330 100 324 376
158,L
159,L 177333 026 240 016 377
160,L 177337 066 001 056 357
161,L 177343 111 027
162,L 177345 310
163,L
164,L 177346 026 001
165,L 177350 360
166,L 177351 350
167,L
168,L
169,L
170,L
171,L
172,L
    
```

```

*
CALL      DOSF60N      SHOULD THE MEMORY TEST BE ENDED?
JTS       MTEND       YES, JUST END IT HERE

.
XRA
LBA
LCA
HL        MAXSZ=2
MTMNX0   DS          BC,HL      INITIALLY, THE MEMORY MUST BE ZERO
          DECP       HL,2
          JFC        MTMNX0

.
BC        MERPRF
HL        SVMEMP+1    SET AN ADDRESS FOR PARITY ERRORS IN MEMORY
DS        BC,HL
LBA

.
MFNXZ    LC          1
MFNXB    LLA
          LHA

.
NOW: HL, B, AND A ARE ZERO
. C IS INITIALIZED TO FIRST BIT TO TEST
. X IS STL TABLE POINTER
. DE IS INCREMENT
.
    
```



```

173,L
174,L 177352
175,L
176,L
177,L
178,L
179,L
180,L
181,L
182,L
183,L
184,L
185,L
186,L
187,L
188,L
189,L
190,L
191,L
192,L
193,L
194,L 177352 307
195,L 177353 271
196,L 177354 112 237 377
197,L 177357 252
198,L 177360 370
199,L 177361 277
200,L 177362 112 237 377
201,L
202,L 177365 176 204
203,L 177367 115 213
204,L 177371 115 074 100
205,L 177374 140 352 376
206,L 177377 015
207,L 177400 115 044 077
208,L 177403 115 273
209,L 177405 110 352 376
210,L 177410 174 276
211,L 177412 110 352 376
212,L
213,L 177415 250
214,L 177416 111 252
215,L 177420 062 202
216,L 177422 110 350 376
217,L 177425 153
218,L 177426 111 261
219,L 177430 160 346 376
220,L
    
```

```

+
MFWDLP
.
. ASCENDING THROUGH THE MEMORY PART OF THE MEMORY TEST
. NOTE:
.   FORWARD ADDRESS SEQUENCE IS:
.   0, 1, 2, 3, 4, ... -2, -1. (ACTUALLY IN 'DE' STEPS)
. NOTE:
.   IT ALWAYS STARTS AT ZERO AND ENDS WHEN REACHS 'DE' WITH OVERFLOW
.
. INTERNALLY:
. ALPHA  A      WORK REGISTER
.         B      EXPECTED DATA
.         C      BIT UNDER TEST
.         DE     ADDRESS INCREMENT
.         HL     CURRENT ADDRESS BEING TESTED
.         X      STL SEGMENT BEING TESTED
.
. BETA   HL     PASS COUNTER
.         D      ADDRESS ERROR DISPLAY POINTER (HORIZ POSN)
.
.         LAM    GET THE DATA (CAN CREATE PARITY FAULT)
.         CPB
.         CFZ    MERONG      WRONG, DATA CHANGED
.         XRC    SET BIT BEING TESTED
.         LMA
.         CPM    STILL SET? (PARITY FAULT POSSIBLE)
.         CFZ    MERONG      NO, DATA CHANGED RATHER QUICKLY
.
MFWDNXT
. ADEL     ERRORS CONTINUE FROM HERE
. ACDH     UPDATE HL USING DE
. CPH      MAXSZ>8      WRAP AROUND?
. JTC      MFWOLP      NO, GO BACK FOR MORE
. INCP     HL          CARRY WRAPAROUND FROM MSB
. NDH      MAXSZ-1>8   AND KEEP THE ADDRESS IN RANGE
. CPDH
. JFZ      MFWDLP      MSB DOESN'T MATCH STEP SIZE, NOT THE END
. CPLE
. JFZ      MFWDLP      LSB DOESN'T MATCH STEP SIZE, NOT THE END
.
. XRA      RESET THE ADDRESS TO ZERO
. XRCB     SET THE BIT FOR THE NEXT SUB-PASS
. ADCC     SHIFT FOR NEXT BIT (SAFER THAN SHIFT)
. JFZ      MFNXB      CONTINUE TILL ALL BITS
. EX       CLICK
. ORBR
. JTS      MFNXZ      GO FROM 0 TO 1 AND BACK TO ZERO
.                    (SAFER THAN JFZ)
    
```


273	,L	177550	174	204	ADEF		
274	,L	177552	210		ACA		GET NEXT ASCENDING STEP SIZE
275	,L	177553	004	300	AD	MAXSZ=1,XOR,(-1)>8	GENERATE CORRECT NUMBER FOR CARRY AROUND
276	,L	177555	174	014 000	ACE	0	
277	,L	177560	044	077	ND	MAXSZ=1>8	
278	,L	177562	330		LDA		
279	,L	177563	350		LHA		
280	,L	177564	364		LLE		DOUBLE CHECK THAT ONLY ONE BIT SET
281	,L	177565	035		DECP	HL	HL SHOULD BECOME (POWER OF 2) - 1
282	,L	177566	140	201 377	JTC	MERX	CATCH DE BECOMING ZERO AS A FATAL ERROR
283	,L	177571	176	244	NDEL		
284	,L	177573	115	243	NDDH		SHOULD RESULT IN ZERO IF WAS POWER OF 2
285	,L	177575	035		DECP	HL	SHOULD SET CARRY IF WAS ZERO
286	,L	177576	140	007 376	JTC	MTSIZE	OK, RE-CALCULATE MEMORY SIZE FOR NEXT PASS
287	.L						** ERROR, WAS NOT POWER OF 2 **

```

288,L
289,L
290,L
291,L 177601 151
292,L
293,L 177602 106 003 373
294,L 177605 106 242 372
295,L 177610 066 252
296,L 177612 104 055 362
297,L
298,L 177615 174 060
299,L 177617 174 060
300,L 177621 104 173 376
301,L
302,L 177624 302
303,L 177625 062 060
304,L 177627 062 060
305,L 177631 320
306,L 177632 250
307,L 177633 310
308,L 177634 104 100 377
309,L
310,L
311,L
312,L 177637 070
313,L
314,L 177640 070
315,L 177641 022 070
316,L 177643 020
317,L 177644 062 060
318,L 177646 301
319,L 177647 062 060
320,L 177651 070
321,L 177652 056 363
322,L 177654 360
323,L
324,L 177655 301
325,L 177656 044 360
326,L 177660 111 250
327,L 177662 012 012 012 012
328,L 177666 074 004
329,L 177670 100 201 377
330,L
331,L 177673 017
332,L 177674 307
333,L 177675 044 360
334,L 177677 111 260
335,L 177701 307
336,L 177702 002
337,L 177703 044 003
338,L 177705 004 060
339,L 177707 022 070
    
```

```

+
. ERROR PROCESSING ROUTINES
.
MERX      EX      BEEP      EXCEPTIONAL MEMORY ERROR THAT DESTROYED
.                                     OPERATION OF THE MEMORY TEST HAPPENED
.                                     CALL      MTSETUP
.                                     CALL      SSTATE      RESTORE STATE TO GOOD VALUES (I HOPE)
.                                     LL        MERXMSG    POINT TO MESSAGE (WITH OTHER MESSAGES)
.                                     JMP       ERROR
*
MTSIZMPF  POP      DE        SKIP P-COUNTER
.                                     POP      DE        AND ERROR LOCATION
.                                     JMP      MTSIZIT   BUT KEEP TRYING
*
MTDONMPF  LAC      BC        INTO A SAFE PLACE
.                                     POP      BC        GET WASTED INFO OUT OF THE WAY
.                                     POP      BC
.                                     LCA
.                                     XRA
.                                     LBA
.                                     JMP      MTMD0    AND TRY TO RECOVER
*
. ERROR IN DATA OR A PARITY FAULT WHILE ACTUALLY DOING MEMORY TEST OPERATIONS
.
MERONG    PUSH     WRONG DATA, CORRECT STACK TO MATCH PARITY
.
MERPRF    PUSH     HL        COPY REAL ADDRESS OVER TO BETA REGS
.                                     PUSH     XA        AND THE STL TABLE POINTER
.                                     BETA
.                                     POP      BC
.                                     LAB      NOW HAVE TABLE POINTER (FROM ALPHA = X)
.                                     POP      BC        AND ADDRESS TO CALCULATE PHYSICAL ADDRESS
.                                     PUSH     HL        SAVE PASS COUNTER
.                                     LH       SMST>8
.                                     LLA     GET STL TABLE POINTER
.
.                                     LAB
.                                     ND      0360    GET STL INDEX BITS
.                                     XRAB   CLEAR THEM OUT OF THE ADDRESS
.                                     SRN    4
.                                     CP     MAXSTLS
.                                     JFC    MERX
.                                     GOT ERROR OUTSIDE OF MEMORY BEING TESTED?
.
.                                     INCP   HL,A
.                                     LAM
.                                     ND      0360    GET STL ENTRY THAT IN ERROR AREA
.                                     ORAB   GENERATED PHYSICAL ADDRESS (LS15 BITS)
.                                     LAM
.                                     SLC
.                                     ND      3
.                                     AD     '0'
.                                     PUSH   XA
.                                     GET BITS 16 & 17 OF PHYSICAL ADDRESS
    
```

340,L	177711	046	013		LE	BL	
341,L	177713	066	005		LL	5	OUTPUT 5 LS DIGITS OF THE PHYSICAL ADDRESS
342,L	177715	106	160	372	CALL	DSPOCT	
343,L	177720	022	060		POP	XA	
344,L	177722	370			LMA		AND THE MS DIGIT ALSO
345,L							
346,L	177723	113	004	015	ADD	5+8	5 FOR DSPOCT & 8 FOR NEXT POSN
347,L	177726	113	074	107	CPD	80-8-1	GO TO NEXT DISPLAY POSITION
348,L	177731	140	347	377	JTC	MERR1	
349,L							
350,L	177734	106	102	373	MERR0	CALL	DOSF60N
351,L	177737	170	334	377	JTP	MERR0	WAIT FOR THE DISPLAY KEY TO BE UP
352,L	177742	106	345	373	CALL	DOSF67	ROLL UP
353,L	177745	036	007		LD	8-1	POSITION FOR NEXT ERROR ADDRESS
354,L							
355,L	177747	060			MERR1	POP	RESTORE PASS COUNTER
356,L	177750	062	060		POP	BC	IGNORE P-COUNTER
357,L	177752	062	060		POP	BC	DISCARD LOCATION OF FAULT
358,L	177754	030			ALPHA		GO BACK TO NORMAL REGISTERS
359,L	177755	115	044	077	NDH	MAXSZ-1>8	AFTER BEING IN MEMORY, MAKE IT IN RANGE AS A MINIMAL ASSURANCE OF ACCURACY
360,L							
361,L	177760	301			LAB		
362,L	177761	252			XRC		
363,L	177762	370			LMA		
364,L	177763	104	365	376	JMP	MFWDNXT	SET MEMORY LOCATION TO WHAT IT SHOULD BE AND RETURN FROM THE ERROR
365,L							
366,L	177766	106	003	373	MTEND	CALL	MTSETUP
367,L	177771	104	127	367	JMP	DEBUG	RESTORE THE SECTOR TABLE TO NORMAL STATE
181.							

184,
185,
186,
187,
188,
189,
190,
191,
192,
193,
194,
195, 177774 000
196, 177775 000 000
197, 177777 011
198,
199, 170000

```

*           IFNE      $>8,0177777>8      (CHECK IF LOADED TO LAST PAGE)
           ERR        MACRO ROM NOT CORRECT SIZE, TOO BIG OR TOO SMALL
           XIF

*
* PAD TO THE END OF THE PAGE WITH ZEROS AND PUT THE VERSION OF THE MACRO
* ROM IN THE LAST BYTE IN THE PAGE AND
* THE ROM TYPE IN THE SECOND LAST BYTE
           LIST        =G
           RPT         =S-4,AND,255
           DC          000
           DC          ROMTYPE
           DA          *ROMCRC
SMACVRS*  DC          $MACROM
*
           END        MACROM

```


177777	\$MACVRS	*197												
000215	\$NL	*653:K	787:K											
000203	\$NS	*649:K	220:F	221:F	223:F	224:F	225:F	227:F	229:F	231:F	233:F	234:F	239:F	
		709:K	788:K											
000233	\$O	*658:K	711:K	792:K										
000200	\$OI	*660:K	450:K											
170176	\$ONLINE	*109:F												
000100	\$OS	*661:K	684:K											
000040	\$OW	*662:K	684:K	725:K	850:K									
000024	\$RD	*646:K	794:K											
170170	\$READ	*107:F												
170201	\$RESTORE	*110:F												
173246	\$RESTORL	*342:I	348:I											
173233	\$RESTORX	*333:I	24:I											
000023	\$RU	*645:K	793:K											
156605	\$SAVBC	*109	69:I	96:I	150:I	158:I	283:I	308:I						
156603	\$SAVXA	*108	68:I	97:I	281:I	282:I	309:I	310:I						
156620	\$SECTOR	*116	305:I	422:I	431:I									
170162	\$SEEK	*105:F												
172637	\$SEEKLOP	*45:I	36:I	49:I										
172620	\$SEEKOK	*30:I	22:I											
172633	\$SEEKOUT	*40:I	336:I											
170215	\$STATUS	*115:F												
170165	\$STEP	*106:F												
172667	\$STEPWTL	*77:I	90:I											
172722	\$STEPXIT	*96:I	86:I											
156621	\$TRACK	*117	136:H	20:I	34:I	334:I								
000013	\$V	*641:K	784:K											
000213	\$VA	*652:K	38:H	786:K										
170173	\$WRITE	*108:F												
000000	\$SL	*23:E												
000000	\$SN	*22:E												
000140	\$SRFC	*30:E												
000150	\$SRFE	*32:E												
000170	\$SRFP	*34:E												
000160	\$SRFS	*33:E												
000150	\$SRFZ	*31:E												
000100	\$SRTC	*25:E												
000110	\$SRTE	*27:E												
000130	\$SRTP	*29:E												
000120	\$SRTS	*28:E												
000110	\$SRTZ	*26:E												
174610	\$ADRDE1	*669:J	667:J											
174600	\$ADRDEV	*659:J	166:J	176:J	177:J									
000000	\$ASCII	*23	52:J	114:J	197:J	200:J	342:J							
170561	\$AVIOLM	*230:F	313:F											
171020	\$AVIOLT	*312:F	179:F	180:F										
000001	\$B0	*6:0	17:0	37:0	59:0	72:0	88:0	100:0	111:0	86:0	97:0	111:0	127:0	
		167:0												
000002	\$B1	*7:0	18:0	38:0	60:0	73:0	101:0	112:0	87:0	98:0	112:0	128:0	168:0	
000004	\$B2	*8:0	39:0	61:0	74:0	102:0	113:0	88:0	99:0	113:0	129:0	169:0		
000010	\$B3	*9:0	21:0	40:0	51:0	75:0	91:0	103:0	114:0	89:0	100:0	114:0	130:0	

172354	FALIGN	*62:H					
172363	FALoop	*70:H	74:H				
172431	FAUTO	*98:H	52:H	127:H			
172433	FAUTO0	*104:H	125:H				
172435	FAUTO1	*110:H	117:H	120:H			
172476	FAUTOER	*129:H	112:H				
172572	FAUTOMSG	*167:H	129:H				
172525	FCHECKR	*140:H	84:H	93:H	95:H	111:H	145:H
000040	FCINDP	*66:D					
000020	FCINDT	*65:D					
000000	FCINST	*64:D					
000060	FCLEAR	*67:D	384:I				
000260	FCOINT	*75:D					
000220	FCOMOD	*73:D	74:I	127:I	366:I		
000160	FCOSYL	*71:D					
000140	FCOSYM	*70:D					
000100	FCOTDP	*68:D					
000120	FCOTUP	*69:D					
000240	FCOUTC	*74:D					
000300	FCRHDR	*76:D					
000320	FCRTIM	*77:D					
000200	FCWDCG	*72:D					
000360	FCWDGP	*79:D					
000340	FCWRN	*78:D					
000010	FDDBL	*192:D					
172205	FDIAG	*6:H	184:J				
172213	FDIAGDR	*36:H	42:H	46:H	59:H		
172512	FDIAGEX	*134:H	146:H	149:H			
000010	FDIND	*183:D	224:I				
000000	FDINS	*182:D					
000004	FDLTD	*180:D					
000070	FDMASK	*195:D					
000040	FDNINV	*194:D					
000020	FDNOT	*193:D					
000050	FDOOTD	*187:D	189:I				
000040	FDOOTS	*186:D					
000070	FDOUIT	*189:D					
000003	FDSMSK	*191:D					
000030	FDVRD	*185:D	204:I				
000020	FDVRS	*184:D					
000060	FDWPI	*188:D	185:I				
000010	FFDBL	*204:D	194:I	279:I			
172401	FFIND	*78:H	56:H	85:H			
000070	FFMASK	*209:D					
000020	FFRDLT0	*200:D					
000000	FFREAD	*199:D	70:H	279:I			
000040	FFRMSK	*210:D					
000000	FFSGL	*203:D					
000010	FFSMSK	*212:D					
000070	FFSYNC	*207:D					
000060	FFWDCG	*206:D					
000020	FFWMSK	*211:D					

000040	FFWRITE	*201:D	194:I	
172557	FGETRSP	*160:H	37:H	48:H
000017	FIADR	*135:D		
000060	FIINDX	*138:D		
000160	FINUM	*136:D		
000160	FIPNTR	*142:D		
000100	FISTEP	*139:D		
000140	FITRER	*141:D		
000120	FITROK	*140:D		
000001	FKINDX	*111:D	120:D	
000100	FKLOFF	*117:D	385:I	
000200	FKLON	*118:D		
000077	FKMAST	*120:D	385:I	
000020	FKPNTR	*115:D	120:D	
000040	FKRWMF	*116:D	120:D	
000002	FKSTEP	*112:D	120:D	
000010	FKTRER	*114:D	120:D	
000004	FKTROK	*113:D	120:D	
000001	FMINDX	*127:D		
000020	FMPNTR	*131:D		
000002	FMSTEP	*128:D		
000010	FMRER	*130:D		
000004	FMTROK	*129:D		
000200	F043GT	*104:D	106:D	107:D
000100	F043LE	*103:D	107:D	
177524	F043MGC	*106:D		
000300	F043MSK	*107:D		
000001	FODR0	*97:D	622:F	434:I
000002	FODR1	*98:D	624:F	435:I
000004	F0LOAD	*99:D		
000020	F0MVIN	*101:D	43:I	
000040	F0MVOT	*102:D	35:I	342:I
000010	FOUNLD	*100:D		
000400	FPLDTA	*154:D	157:D	
000016	FPLHDR	*150:D		
000406	FPLRDTA	*157:D	160:D	
000424	FPLWDBL	*160:D	163:D	
000430	FPLWSGL	*163:D		
000200	FPTDTA	*153:D	156:D	
000000	FPTHDR	*149:D	151:D	
000176	FPTRDTA	*156:D	159:D	
000002	FPTRKH	*151:D		
000162	FPTWDBL	*159:D	162:D	
000156	FPTWSGL	*162:D		
000002	FRBUSY	*168:D	302:I	
000001	FRDRV	*167:D		
000004	FRINDX	*169:D	306:I	
000100	FRIXCT	*174:D		
000200	FRIXCX	*176:D		
172413	FSEEK	*87:H	55:H	
172414	FSEEK1	*92:H	96:H	
000010	FSFPRO	*89:D	157:I	

000020	FSGAP	*90:ID												
000200	FSNSYN	*93:ID												
000001	FSONLN	*86:ID	84:I	119:I	120:I	153:I	297:I							
000040	FSSTIP	*91:ID	89:I											
000002	FSTRIP	*87:ID	119:I	120:I										
000100	FSTRK0	*92:ID	93:I	94:I										
000004	FSWDIS	*88:ID												
173607	GETCMD	*102:J	125:J	316:J										
174125	GETCME	*304:J	201:J	210:J	211:J	251:J	255:J	257:J	258:J	263:J	271:J	277:J	278:J	
		280:J	281:J	282:J	283:J	327:J	329:J	562:J	653:J					
173616	GETCML	*109:J	309:J	319:J	339:J									
174150	GETDIG	*321:J	137:J	139:J	145:J									
174623	GETSTA	*678:J	672:J	721:J										
171644	HMST	*552:F	552:F	553:F	554:F	555:F	556:F	557:F	558:F	559:F	560:F	561:F	562:F	
		563:F	564:F	565:F	566:F	567:F								
175071	IDENT	*815:J	129:J											
175115	IDENT0	*830:J	825:J											
175130	IDENTM	*838:J	819:J											
175131	IDENTS	*843:J	850:J	852:J										
000017	IDMIC	*852:J	824:J											
000013	IDPROC	*850:J	829:J											
174211	INCADR	*391:J	195:J											
174223	INCADV	*398:J	396:J											
170505	INPARM	*225:F	301:F											
170770	INPART	*300:F	173:F	174:F										
170606	IVIOLM	*233:F	317:F											
171030	IVIOLT	*316:F	181:F	182:F										
174773	JUMP	*776:J	196:J											
175033	JUMPIT	*794:J	792:J											
171165	KBDSPILP	*397:F	402:F											
171117	KBDSPINI	*367:F	75:F	265:F	612:F	665:F								
176703	KEYCHAR	*839:K	163:H	110:J										
176722	KEYCHARW	*854:K	855:K											
153606	KEYINF	*66												
000000	LC	*41	130:H	206:K	220:K	309:K	411:K							
174233	LINK	*403:J	203:J											
174241	LINKADR	*409:J	407:J											
172115	LOADIPL	*64:G	48:G											
170000	MACROM	*26:F	199											
000030	MAXLIN	*83:C	99:B	205:K	348:K	368:K	490:K	620:K						
000120	MAXPOS	*84:C	337:J	363:K	447:K	615:K	771:K							
000032	MAXSECT	*27:D	116:H	119:H										
000004	MAXSTLS	*6:L	7:L	108:L	119:L	136:L	145:L	328:L						
040000	MAXSZ	*7:L	23:L	154:L	204:L	207:L	275:L	277:L	359:L					
000114	MAXTRAK	*26:D	124:H	339:I										
170470	MEMPAM	*224:F	279:F	336:F										
170731	MEMPAT	*278:F	171:F	172:F										
177637	MERONG	*312:L	196:L	200:L										
177640	MERPRF	*314:L	159:L											
177734	MERR0	*350:L	351:L											
177747	MERR1	*355:L	348:L											
170641	MERROR	*237:F	220:F	221:F	227:F	231:F	239:F							

177601	MERX	*291:L	95:L	228:L	257:L	282:L	329:L											
170652	MERXMSG	*239:F	295:L															
177350	MFNXB	*165:L	216:L															
177346	MFNXZ	*164:L	219:L															
177352	MFWOLP	*174:L	205:L	209:L	211:L													
177365	MFWONXT	*202:L	364:L															
170625	MINSTE	*236:F	233:F	234:F														
174324	MODAGN	*456:J	133:J															
174227	MODIFNXT	*400:J	469:J															
174335	MODIFX	*463:J	461:J															
174343	MODIFY	*471:J	204:J	454:J														
174340	MODINC	*465:J	131:J															
153604	MODVAL	*65	462:J	463:J														
170533	MPARIT	*227:F	223:F	224:F	225:F													
170573	MPROTE	*231:F	229:F															
177514	MSTART	*256:L	24:L															
170736	MSTPAT	*281:F	276:F															
177624	MTDONMPF	*302:L	239:L															
177766	MTEND	*366:L	149:L															
176756	MTINC	*12:L	68:L															
177211	MTMAINLP	*101:L																
177500	MTMD0	*250:L	252:L	308:L														
177433	MTMDON	*222:L																
177211	MTMNBK	*108:L	236:L															
177324	MTMNX0	*155:L	157:L															
177275	MTMNXT	*141:L	111:L	115:L														
176743	MTMSG128	*10:L	32:L															
176752	MTMSG64	*11:L	58:L															
177252	MTMSP0	*131:L	133:L															
167534	MTRFLG	*71:B																
167535	MTRLEN	*72:B																
167536	MTRPNT	*73:B																
175403	MTSETUP	*994:J	1027:J	253:L	293:L	366:L												
175405	MTSETX	*1000:J	39:F															
177110	MTSIZ32S	*62:L	54:L															
177007	MTSIZE	*26:L	286:L															
177173	MTSIZIT	*93:L	81:L	300:L														
177111	MTSIZLP	*64:L	91:L															
177140	MTSIZLP0	*77:L	73:L															
177615	MTSIZMPF	*298:L	43:L															
167531	MTTFLG	*68:B																
167532	MTTLEN	*69:B																
167533	MTTPNT	*70:B																
000106	NECP	*43	106:J	158:J	315:J	417:J	452:J	460:J	774:J									
174247	NEWADR	*413:J	123:J															
174253	NOSADR	*424:J	598:J															
153611	OLDREGS	*69	157:J	938:J														
153607	OLDTOS	*68	281:F	343:F	12:J	559:J	751:J	761:J	787:J	922:J								
170040	ONEMSA	*50:F	183:F	184:F														
173020	ONLIXIT	*158:I	155:I															
000052	OPCODEBP	*44	577:J	592:J														
000000	ORIGINI	*24	71	74	81	64:J	205:J	209:J	259:J	262:J	419:J	485:J	1033:J					

175363	SWITZAF	*974:J	925:J						
000040	SWRPT	*64:IC	68:IC						
000045	SWSCF	*68:IC							
000020	SWSTDY	*63:IC							
000004	SWUSER	*61:IC	68:IC	735:J	772:J				
000010	SXABCL	*40:IC							
000002	SXADLO	*38:IC							
000004	SXADSC	*39:IC							
000001	SXAPND	*37:IC							
000200	SXAPWR	*44:IC							
000327	SXCLK	*37:ID							
147543	SXCRC	*39:ID							
000040	SXDRCQ	*31:IC							
000020	SXDPR	*30:IC							
000374	SXDTA	*36:ID							
173572	SXDUAL	*38:ID							
000040	SXMCD	*53:IC							
000010	SXMCTS	*51:IC							
000020	SXMDSR	*52:IC							
000100	SXMRNG	*54:IC							
000002	SXSDTR	*18:IC							
000010	SXSNSY	*21:IC							
000020	SXSRDY	*22:IC							
000001	SXSRQS	*17:IC							
170614	SYSCAM	*234:F	325:F						
171050	SYSCAT	*324:F	185:F	186:F					
157000	SYSCOM	*34:IB							
167400	SYSESR	*31:IB	32:IB						
167400	SYSIVR	*32:IB	44:IB	128:IB					
170674	SYSPAT	*251:F	38:F						
170432	SYSPRM	*221:F	268:F						
160000	SYSRAM	*33:IB							
170000	SYSROM	*30:IB	134:IB						
175045	TDSTD	*804:J	802:J						
175060	TDWAIT	*811:J	812:J						
170044	TIMOUT	*58:F							
170414	TIMOUTM	*220:F	59:F						
173275	TOFFTL	*371:I	85:I	124:I	154:I				
173264	TOFFTLDE	*352:I	623:F	625:F					
171616	TRIANGLE	*523:F	398:F						
175037	TSTDSP	*797:J	254:J						
176760	TSTMEM	*14:L	224:J						
171040	UAINST	*320:F	189:F	190:F					
170622	UAINTM	*235:F	321:F						
171627	UMST	*536:F	549:F	1000:J	110:L	113:L	114:L	235:L	
000015	UMSTL	*549:F	1001:J	60:L					
171077	UTRANT	*352:F	360:F	362:F	379:F	383:F			
000020	UTRANTL	*360:F	378:F	384:F	391:F				
170270	VECTI	*167:F	209:F	1010:J					
000124	VECTIL	*209:F	259:F	1012:J					
171664	WRAPST	*575:F	38:L						
170545	WVIDLM	*229:F	309:F						

171010 WVIDLT

*308IF

177IF

178IF