

DZ11

OVERLAY INTERPRO  
CZDZBCO

AH-9031C-MC  
FICHE 1 OF 1

JUL 1982  
COPYRIGHT © 76-82  
MADE IN USA



DZ11 ITEP OVERLAY MACY11 30A(1052) 10-NOV-81 11:23 PAGE 2  
CZDZBC.P11 10-NOV-81 11:13

**IDENTIFICATION**  
-----

PRODUCT CODE: AC-8785C-MC

PRODUCT NAME: CZDZBC0 DZ11 OVERLAY FOR INTERPROCESSOR TEST PROGRAM

PROGRAM DATE: FEBRUARY 1982

MAINTAINER: DIAGNOSTICS

AUTHORS: R A JONES  
JOHN EGOLF  
JERRYL PAYNE

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS DOCUMENT.

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED UNDER A LICENSE AND MAY ONLY BE USED OR COPIED IN ACCORDANCE WITH THE TERMS OF SUCH LICENSE.

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

COPYRIGHT (C) 1976, 1982 BY DIGITAL EQUIPMENT CORPORATION

CZDZBC.P11

10-NOV-81 11:13

## 1.0 ABSTRACT.

THIS PROGRAM IS DESIGNED AS A MAINTENANCE AID FOR FIELD SERVICE PERSONEL. IT WILL VERIFY THE PROPER OPERATION OF A COMPLETE COMMUNICATION LINK FROM ONE PDP-11 SYSTEM TO ANOTHER OR TO A COMMUNICATION TEST CENTER.

THIS PROGRAM MUST BE USED IN CONJUNCTION WITH THE INTERPROCESSOR TEST PROGRAM(DZITP) ON A PDP-11 SYSTEM WITH A DL-11 INTERFACE.

## 2.0 REQUIREMENTS.

## 2.1 EQUIPMENT

- A. PDP-11 SYSTEM WITH 4K OF CORE.
- B. A DZ11 COMMUNICATION INTERFACE.

## 2.2 STORAGE.

4K OF CORE

## 3.0 LOADING PROCEDURE

THIS PROGRAM IS IN ABSOLUTE FORMAT.  
THE ABS LOADER MUST BE USED TO LOAD THE PROGRAM.

## 4.0 OPERATING PROCEDURES.

- A. TWO METHODS OF ENTERING PARAMETERS ARE PROVIDED
    - 1. LOAD ADDRESS 200 AND START TO ENTER PARAMS FROM CONSOLE TTY, PROCEED TO SECTION B.
    - 2. LOAD ADDRESS 200 AND SET SWITCH REGISTER BIT 15 BEFORE STARTING TO ENTER PARAMS FROM CONSOLE SWITCHES, PROCEED TO SECTION C.
- \*THE PROGRAM MAY BE RESTARTED AT LOC 204 (ONCE PARAMETERS HAVE ALREADY BEEN SELECTED)

## B. CONSOLE DIALOGUE PARAMETER INPUT (CURRENT VALUES FOR PARAMETERS ARE FOUND IN OVERLAY)

- 1. THE PROGRAM WILL TYPEOUT THE NAME OF THE VARIABLE OVERLAY.
  - A. IF YOU WISH TO SETUP JUST THE INDICATED OVERLAY, TYPE A CARAGE RETURN
  - B. IF YOU WISH TO SETUP A DN11, TYPE IN DN.
  - C. IF YOU WISH TO SETUP A DM11BB, TYPE IN DMB.

IF DN OR DMB WAS TYPED IN STEP 1 ABOVE THEN THE BUS ADDRESS, VECTOR ETC. REFERED TO IN STEPS 2 THRU 7, PERTAIN TO THE DN11 OR DMBB.

- 2. THE PROGRAM WILL TYPE THE DEFAULT BUS ADDRESS OF THE INTERFACE UNDER TEST.
  - A. TYPE A CAR. RETURN TO USE DEFAULT BUS ADDRESS
  - B. TYPEIN ACTUAL BUS ADDRESS
- 3. THE PROGRAM WILL TYPE OUT THE DEFAULT VECTOR ADDRESS
  - A. TYPE A CAR. RETURN TO USE DEFAULT ADDRESS
  - B. TYPEIN ACTUAL VECTOR ADDRESS
- 4. THE PROGRAM WILL TYPE OUT THE DEFAULT INTERFACE PRIORITY  
NOTE: 200=PRIO 4, 240=PRIO 5, 300=PRIO 6, ETC.

CZDZBC.P11

10-NOV-81 11:13

- A. TYPE A CAR. RETURN TO USE DEFAULT VALUE
  - B. TYPEIN ACTUAL VALUE
5. THE PROGRAM WILL TYPEOUT THE DEFAULT VALUE OF PARAM#1  
IF REQUIRED BY THE ISR. (SEE SECT. 10.0 IN OVERLAY LISTING FOR PARAMETER DESCRIPTION)
- A. TYPE A CAR. RETURN TO USE DEFAULT VALUE
  - B. TYPEIN ACTUAL VALUE
6. THE PROGRAM WILL TYPEOUT THE DEFAULT VALUE OF PARAM#2  
IF REQUIRED BY THE ISR.
- A. TYPE A CAR. RETURN TO USE DEFAULT VALUE
  - B. ENTER ACTUAL VALUE
7. THE PROGRAM WILL TYPEOUT THE DEFAULT VALUE OF PARAM#3  
IF REQUIRED BY THE OVERLAY.
- A. TYPE A CAR. RETURN TO USE DEFAULT VALUE  
THE DN-11 WILL USE PARAM #3 AS THE # TO DIAL.  
IF USING A MODEM WITHOUT AUTOMATIC HANDSHAKING,  
THE NUMBER MUST TERMINATE WITH A  
'END-OF-NUMBER' CHARACTER (:).
  - B. ENTER ACTUAL VALUE.
8. THE PROGRAM WILL RETURN TO STEP B1 IF THIS SETUP  
WAS FOR DN11 OR DM11BB.
9. THE PROGRAM WILL REQUEST THAT SWITCH REGISTER BE SET.
- A. SETUP SWITCH REGISTER AS SPECIFIED IN STEP D.  
AND TYPE A CAR. RETURN.

NOTE: IF ANY OF THE ABOVE ITEMS 2 THRU 7 WERE CHANGED BY ENTERING  
NEW VALUES, THE NEW VALUE BECOMES THE DEFAULT VALUE FOR SUBSEQUENT  
RESTARTS OF THE PROGRAM.

CZDZBC.P11

10-NOV-81 11:13

- C. MANUAL PARAMETER INPUT FROM SWITCH REGISTER
1. THE PROGRAM HALTS FOR ISR (INTERFACE SERVICE ROUTINE) SPECIFICATION  
SWR14=SETUP DM-11B ISR  
SWR13=SETUP DN-11 ISR  
SWR=000000=SETUP VARIABLE ISR
  2. THE FOLLOWING HALTS ARE REPEATED FOR EACH ISR SPECIFIED.  
SETUP SEQUENCE IS: DN11, DM11-BB THEN VARIABLE OVERLAY. (EACH ENTRY SET SWITCHES THEN HIT CONTINUE.)
    - A. HALT FOR BUS ADDRESS OF INTERFACE
    - B. HALT FOR VECTOR ADDRESS OF INTERFACE
    - C. HALT FOR PRIORITY OF INTERFACE
    - D. HALT FOR INTERFACE PARAM #1 (SEE SECT. 10.0 IN OVERLAY LISTING FOR PARAMETER DESCRIPTION)
    - E. HALT FOR INTERFACE PARAM #2 (DN11 AND DMBB PARAMETERS ARE DISCUSSED IN SECT. 10.0 OF THE MONITOR.)
    - F. GO BACK TO STEP A IF THIS SETUP WAS FOR DN OR DMB.
  3. HALT FOR OPERATIONAL SWITCH SETTINGS. (SEE STEP D.)
    - A. PRESS CONTINUE TO START TESTING

BEFORE ATTEMPTING TO RUN THIS PROGRAM, THE OPERATOR MUST ACCERTAIN THE COMPLETE COMMUNICATION LOOP AND PROCEEDURES TO BE USED, INCLUDING THE TYPE OF MODEMS, THE TYPE OF INTERFACE BEING USED AT THE OTHER CPU AND THE MODES OF OPERATION, DATA AND PARAMETERS TO BE USED AT EACH CPU.

THIS WILL REQUIRED VOCAL COMMUNICATION WITH THE OPERATOR AT THE OTHER CPU UNLESS ITS CONFIGURATION AND OPERATION ARE FIXED AS A TEST CENTER.

AFTER DETERMINING THAT THE EQUIPMENTS ARE COMPATIBLE AND AGREEING ON THE MODE AND VARIABLE PARAMETERS TO BE USED, THE SYSTEM WHICH IS TO RECEIVE DATA FIRST SHOULD BE LOADED AND STARTED. IF THE MODEM BEING USED ON THIS SYSTEM HAS AN AUTOMATIC ANSWER FEATURE, IT SHOULD BE ENABLED.

THE SYSTEM WHICH IS TO TRANSMIT FIRST SHOULD THEN BE LOADED AND STARTED AND THE CONNECTION ESTABLISHED EITHER MANUALLY OR AUTOMATICALLY (VIA DN-11).

CZDZBC.P11

10-NOV-81 11:13

## D. OPERATIONAL SWITCH SETTINGS.

SW15=1 HALT ON ERROR

SW14=1 SINGLE PASS

SW14 HAS NO EFFECT IF SW04=0

SW13=1 INHIBIT ERROR TYPEOUTS

SW12=1 INHIBIT ALL TYPEOUTS EXCEPT ERRORS

IF SW12=0 AND SW04=1 END PASS IS TYPED  
AND TRANSMITTED/RECEIVED DATA IS TYPED.

SW11=1 USE PREVIOUSLY SPECIFIED DATA

SW10=1 DATA SELECT (WITH SW09)

SW09=1 DATA SELECT (WITH SW10)

00=1 GET DATA FROM OPERATOR

01=1 TEST MESSAGE #1 (\$A QUICK BROWN FOX)

10=1 TEST MESSAGE #2 (\$B NUMERICS)

11=1 TEST MESSAGE #3 (\$C COMTEST/QUICK BROWN FOX/NUMERICS)

SW08=1 TRANSMIT RECEIVED DATA (INTERNAL LOOPBACK MODE)

SW07=1 DO NOT TEST RECEIVED DATA

SW06=1 MONITOR TRANSMITTED DATA ON CONSOLE TTY.\*

SW05=1 MONITOR RECEIVED DATA ON CONSOLE TTY.\*

\* IN MANY CASES, NOT ALL DATA WILL APPEAR ON THE CONSOLE  
TTY. THIS IS ESPECIALLY TRUE WHEN THE COMM INTERFACE IS  
RUNNING AT A FASTER BAUD THAN THE CONSOLE, BUT EVEN AT EQUAL  
OR SLOWER BAUDS, ALL CHARACTERS MAY NOT APPEAR ON THE CONSOLE.

SW04=1 RETURN TO MONITOR FOR END PASS

WHEN SW04=0 PROGRAM LOOPS IN THE OVERLAY NEVER RETURNING TO THE MONITOR.

SW03=1 INTERNAL LOOPBACK MODE

SW02=1 EXTERNAL LOOPBACK MODE

SW01=1 ONE-WAY-IN MODE

SW00=1 ONE-WAY-OUT MODE

THIS PROGRAM HAS BEEN MODIFIED TO RUN ON A PROCESSOR WITH OR WITHOUT A HARDWARE SWITCH REGISTER. WHEN FIRST EXECUTED THE PROGRAM TESTS THE EXISTENCE OF A HARDWARE SWITCH REGISTER. IF NOT FOUND A SOFTWARE SWITCH REGISTER LOCATION (SWREG=LOC. 176 ) IS DEFAULTED TO. IF THIS IS THE CASE, UPON EXECUTION THE CONTENTS OF THE SWREG ARE DUMPED IN OCTAL ON THE CONSOLE TTY AND ANY CHANGES ARE REQUESTED

(IE) SWR=XXXXXX NEW=

POSSIBLE RESPONSES ARE:

1. <CR> IF NO CHANGES ARE TO BE MADE
2. 6 DIGITS 0-7 TO REPRESENT IN OCTAL THE NEW SWITCH REGISTER VALUE ;LAST DIGIT FOLLOWED BY <CR>.
3. ^U TO ALLOW REENTERING VALUE IF ERROR IS COMMITTED KEYING IN SWREG VALUE.

BUILT INTO THE PROGRAM IS THE ABILITY TO DYNAMICALLY CHANGE THE CONTENTS OF SWREG DURING PROGRAM EXECUTION. BY STRIKING ^G (CNTL G) ON CONSOLE TTY THE OPERATOR SETS A REQUEST FLAG TO CHANGE THE CONTENTS OF SWREG, WHICH IS PROCESSED IN KEY AREAS OF THE PROGRAM CODE (IE) ERROR ROUTINES, AFTER HALTS END OF PASS, AND OTHER APPLICABLE AREAS.

IF OPERATOR SPECIFIED DATA WAS INDICATED, THE PROGRAM WILL TYPE A REQUEST FOR THE DATA. DATA MAY BE ENTERED AS ASCII CHARACTERS OR OCTAL CODE. TYPE IN THE DATA TERMINATED WITH A CR. OCTAL CODE MAY BE ENTERED BY TYPING AN ^ (UP ARROW) FOLLOWED BY THE OCTAL CODE (IN THE RANGE 000 TO 377) SEPERATED BY SPACES AND TERMINATED BY ^ (UP ARROW).  
I.E. ABCD^ 000 123 377^ EFG (CAR.RETURN)

A TYPICAL SWITCH SETTING FOR HALF-DUPLEX=003150 THIS SETTING USES INTERNAL LOOPBACK MODE, LOOPS IN OVERLAY, MONITORS TRANSMITTED AND RECEIVED DATA ON THE CONSOLE TTY, AND TESTS RECEIVED DATA USING TEST MESSAGE #3.

A TYPICAL SWITCH SETTING FOR FULL-DUPLEX=003144 THIS SETTING IS THE SAME AS ABOVE EXCEPT IT USES THE EXTERNAL LOOPBACK MODE.

ALL STANDARD MESSAGES (TEST MESSAGES 1-3) ARE PRECEDED BY 2 FILL CHARACTERS (177), AND ARE FOLLOWED BY A CR (015), LF (012), RECEIVE TERMINATING CHARACTER (001), 4 FILLS (177), AND A TRANSMIT TERMINATING CHARACTER (000). DURING TRANSMISSION, WHEN A 000 CHARACTER IS SEEN THE TRANSMISSION IS STOPPED. DURING RECEPTION, WHEN A 001 CHARACTER IS RECEIVED, THE RECEIVER IS SHUT OFF. IF THE MESSAGE WAS INPUTED BY THE OPERATER, THE TERMINATING CHARACTERS ARE ADDED.

## TEST MODES

## INTERNAL LOOPBACK MODE

1. THE OVERLAY WAITS TO RECEIVE A MESSAGE (TERMINATED BY <001>)
2. VERIFIES THE DATA AGAINST THE DATA SELECTED BY SW09 AND SW10 (SW7=0)
3. TRANSMIT THE DATA SELECTED BY SW09 AND SW10 (SW8=0) OR TRANSMIT THE RECEIVED DATA (SW8=1)
4. RETURNS TO MONITOR FOR 'END PASS' (SW4=1) OR GO TO STEP 1. (SW4=0)

## EXTERNAL LOOPBACK MODE

1. THE OVERLAY SETS REQUEST TO SEND
2. WAIT FOR CLEAR TO SEND
3. TRANSMITS THE SELECTED DATA
4. RESETS REQUEST TO SEND
5. WAIT FOR MESSAGE TO BE RECEIVED
6. VERIFIES THE DATA (SW07=0)
7. RETURNS TO MONITOR FOR 'END PASS'. (SW04=1) OR GO TO STEP 1 (SW04=0)

## ONE-WAY-IN MODE

1. THE OVERLAY WAITS FOR MESSAGE TO BE RECEIVED.
2. VERIFIES THE DATA (SW07=0)
3. RETURNS TO MONITOR FOR 'END PASS' (SW04=1) OR GO TO STEP 1 (SW04=0)

## ONE-WAY-OUT MODE

1. THE OVERLAY SETS REQUEST TO SEND
2. WAITS FOR CLEAR TO SEND
3. TRANSMITS SELECTED DATA
4. RETURNS TO MONITOR FOR 'END PASS'. (SW04=1) OR GO TO STEP 1 (SW04=0)

- E. THE OVERLAY IS THEN ENTERED AND A CONNECTION ESTABLISHED EITHER MANUALLY OR AUTOMATICALLY.

IF ONE-WAY-IN OR INTERNAL LOOPBACK MODES ARE SELECTED.  
THE OVERLAY WILL SET DATA TERMINAL READY AND WAIT FOR DATA.

IF ONE-WAY-OUT OR EXTERNAL LOOPBACK MODES WERE SELECTED.  
THE OVERLAY WILL SET DATA TERMINAL READY AND REQUEST TO SEND.  
THE OVERLAY WILL THEN WAIT FOR CLEAR TO SEND BEFORE ATTEMPTING TO TRANSMIT DATA.

THE PROGRAM WILL PRINTOUT A 'WAITING FOR CLEAR TO SEND'  
MESSAGE AND THE CONTENTS OF THE XMIT CSR EVERY 60 SECS.  
UNTIL CLEAR TO SEND IS ASSERTED.



CZDZBC.P11

10-NOV-81 11:13

F. IF SW04=0 THE OVERLAY WILL CONTINUE TO TRANSMIT/RECEIVE DATA.

IF SW04=1 THE OVERLAY WILL RETURN TO THE MONITOR AND TYPE 'END PASS'.

IF BOTH SW04=1 AND SW14=1, THE PROGRAM WILL REQUEST NEW INTERFACE PARAMS AFTER ONE PASS OF THE SELECTED TEST MODE.

TEST EXECUTION MAY BE INTERRUPTED BY TYPING THE FOLLOWING CHARACTERS ON THE CONSOLE TTY.

LINE FEED = RESTART PROGRAM AT LOCATION 200.

QUESTION MARK = PRINTOUT FIRST 8 WORDS OF INPUT BUFFER.(ASCII)

THEN TYPE EITHER:

\*WXXXXXX TO PRINTOUT THE 8 WORDS AT LOC XXXXXX.

\*BXXXXXX TO PRINTOUT THE 16 BYTES AFTER LOC XXXXXX.

\*C TO CONTINUE

PROGRAM MUST BE RESTARTED AT 200 AFTER PRINTING.  
CARRIAGE RETURN = RESTART AT REQUEST FOR NEW OPERATIONAL SWITCHES.

## 5.0 PROGRAM AND/OR OPERATOR ACTION

IF THE OPERATOR WISHES TO MANUALLY EXAMINE THE TRANSMIT OR RECEIVE BUFFERS, DO THE FOLLOWING: TO FIND THE STARTING ADDRESS OF THE RECEIVE BUFFER, LOAD ADDRESS 11020 AND EXAMINE. TO FIND THE STARTING ADDRESS OF THE TRANSMIT BUFFER, LOAD ADDRESS 11022 AND EXAMINE.

## 5.1 NORMAL HALTS SEE SECTION 4.

## 6.0 ERRORS

### 6.1 ERROR REPORTING

THE ONLY ERROR REPORT FROM THE CONTROL PROGRAM OCCURS IF THE INTERFACE SPECIFIED IS NOT LOADED.

IF DATA IS RECEIVED AND SWITCH 7 (NO DATA COMPARE) IS RESET, THE DATA WILL BE COMPARED AGAINST THE PRESELECTED DATA AFTER A LINE FEED CHARACTER IS RECEIVED. IF THERE IS A MISMATCH, THE FOLLOWING ERROR REPORT IS PRINTED:

RECEIVED DATA=RRRRRR  
DATA SHOULD BE TTTTTT  
DATA COMPARE ERROR; BAD DATA=BBB GOOD DATA=GGG

CZDZBC.P11

10-NOV-81 11:13

WHERE RRRRRR IS THE RECEIVE BUFFER (UP TO 512 CHARACTERS)  
 TTTTTT IS THE TRANSMIT BUFFER (UP TO 512 CHARACTERS)  
 BBB IS THE BAD DATA CHARACTER  
 GGG IS THE GOOD DATA CHARACTER

IF THE INTERFACE DETECTS A DATA ERROR, THE FOLLOWING  
 WILL BE PRINTED BEFORE THE DATA IS COMPARED:

THERE WAS A RECEIVER ERROR. RECEIVER DATA REGISTER =XXXXXX

WHERE XXXXXX IS THE CONTENTS OF THE RECEIVER DATA REGISTER  
 THE LOW BYTE IS THE DATA, AND THE HIGH BYTE IS THE ERROR BITS.

IF A RECEIVE TERMINATING CHARACTER<001> IS NOT DETECTED  
 WITHIN 512 CHARACTERS A 'BUFFER FULL' PRINTOUT WILL OCCUR.

## 7.0

## RESTRICTIONS

THE OPERATION OF THIS PROGRAM REQUIRES COORDINATION BETWEEN  
 THE OPERATOR AND THE OPERATOR OF ANOTHER PDP-11 SYSTEM  
 UNLESS ONE OF THE SYSTEMS IS ALWAYS OPERATING IN A FIXED  
 MODE. THE FOLLOWING TABLE LISTS THE VALID COMBINATIONS:

CPU #1	CPU #2
ONE-WAY-OUT	ONE-WAY-IN
ONE-WAY-IN	ONE-WAY-OUT
EXTERNAL-LOOPBACK	INTERNAL-LOOPBACK
INTERNAL-LOOPBACK	EXTERNAL-LOOPBACK
EXTERNAL-LOOPBACK	EXTERNAL-LOOPBACK (FULL DUPLEX)

WHEN THE COMMUNICATION LINK INVOLVES MODEMS THE FOLLOWING  
 RESTRICTION APPLY:

IF RUNNING IN FULL DUPLEX MODE BOTH SYSTEMS  
 MUST BE IN EXTERNAL LOOP BACK MODE.

BOTH SYSTEMS SHOULD BE RUNNING IDENTICAL ROUTINES.

EXAMPLE:  
 SWITCHES 14,13,7,4 SHOULD BE THE SAME  
 ON BOTH CPU S

IF PROGRAM IS WAITING IN A SCAN ROUTINE AND TYPES OUT  
 A 'WAITING MESSAGE', IF AN INCOMING MESSAGE STARTS DURING  
 THE TYPE OUT, IT WILL BE LOST BECAUSE THE TYPEOUT PRIORITY  
 IS AT LEVEL 7. THIS WILL RESULT IN OVERRUN OR SILO OVER-  
 RUN ERRORS, DEPENDING ON THE DEVICE. TO AVOID THIS SITUATION  
 RUN WITH SWITCH 13 UP. IF OVERRUN DOES OCCURE DURING A  
 TYPEOUT THE PROGRAM SHOULD BE RESTARTED.

IF USING AN ASYNCHRONOUS DEVICE, MODEMS AND THE  
 MAYNARD TEST STATION AND INITIALIZE DOES NOT CLEAR THE  
 CONNECTION (EXAMPLE THE DJ11) IF THE PROGRAM IS RESTARTED  
 IN THE MIDDLE OF A MESSAGE AT LOC 204 OR BY HITTING CR  
 AN IMMEDIATE ERROR MESSAGE FROM MAYNARD WILL BE RE-

CZDZBC.P11 10-NOV-81 11:13

CEIVED. THIS IS BECAUSE THE TEST STATION IS STILL LOOKING FOR THE REST OF THE INTERRUPTED MESSAGE. TO AVOID THIS ERROR, RESTART PROGRAM ONLY AT THE END OF THE MESSAGE CURRENTLY BEING TRANSMITTED.

## 8.0 MISCELLANEOUS

ITEP WAS CHECKED OUT USING THE FOLLOWING BELL TELEPHONE MODEMS.  
201A (HALF-DUPLEX SYNCHRONOUS 2000 BAUD)  
202C (HALF-DUPLEX ASYNCHRONOUS 1200 BAUD)  
103A (FULL-DUPLEX ASYNCHRONOUS 110 BAUD)

## 9.0 PROGRAM DESCRIPTION

9.1 THE DZ11 INTERFACE SERVICE PARAMS ARE SETUP, AS SPECIFIED BY THE OPERATOR, BY THE ITEP CONTROL PROGRAM.

TIME: PROVIDES A MEANS OF MEASURING ELAPSED TIME. IT IS INCREMENTED EVERY SECOND BY A CLOCK INTERRUPT ROUTINE IN ITEP.

9.2 WHEN THE OVERLAY IS FIRST ENTERED BY ITEP AT LOCATION START:, THE CONTENTS OF THE SWITCH REGISTER ARE STORED IN REGISTER 0. THE MODE AND DATA SELECTIONS ARE FIXED AT THIS TIME AND CANNOT BE ALTERED WITHOUT RETURNING TO THE CONTROL PROGRAM. THE INTERRUPT VECTORS AND VARIABLES ARE THEN SETUP. THE SELECTED ROUTINE DETERMINED BY THE MODE IS THEN ENTERED

9.3 THE OVERLAY THEN LOOPS IN ROUTINES: \$OWI, IF "ONE WAY IN" MODE WAS SELECTED. \$OWO, IF "ONE WAY OUT" MODE WAS SELECTED. \$ILB, IF "INTERNAL LOOP BACK" MODE WAS SELECTED. \$XLB, IF "EXTERNAL LOOP BACK" WAS SELECTED.

9.31 \$OWI: IN THIS ROUTINE THE RECEIVER IS INITIALIZED AND PROGRAM LOOPS WAITING FOR THE RECEIVER TO FINISH. IF NOTHING IS RECEIVED FOR 60 SECS A "WAITING" MESSAGE IS TYPED. WHEN THE RECEIVER IS DONE, THE PROGRAM CHECKS DATA IF SWITCHES PERMIT, AND TYPES END PASS DEPENDING ON SWITCH SETTINGS.

9.32 \$OWO: THE TRANSMITTER IS INITIALIZED AND PROGRAM LOOPS WAITING FOR TRANSMITTER TO FINISH. A "WAITING" MESSAGE IS TYPED EVERY 60 SECS IF THERE IS NO ACTION. WHEN THE TRANSMITTER IS DONE, THE PROGRAM EITHER LOOPS BACK TO \$OWO OR TYPES END PASS DEPENDING ON SWITCH SETTINGS.

9.33 \$ILB: THE RECEIVER IS INITIALIZED AND PROGRAM LOOPS WAITING FOR RECEIVER TO FINISH. A "WAITING" MESSAGE IS TYPED EVERY 60 SEC IF NO ACTION. WHEN RECEIVER IS DONE PROGRAM CHECKS DATA IF SWITCH SETTINGS PERMIT, AND END PASS IS TYPED IF SWITCH SETTINGS PERMIT. THEN THE TRANSMITTER IS INITIALIZED, A "WAITING" MESSAGE IS TYPED EVERY 60 SEC IF NO ACTION. WHEN TRANSMITTER IS DONE PROGRAM RETURNS TO START OF ROUTINE. (\$ILB)

9.34 \$XLB: IF IN HALF DUPLEX THE TRANSMITTER IS INITIALIZED, A "WAITING MESSAGE IS TYPED EVERY 60 SEC IF THERE IS NO ACTION

CZDZBC.P11

10-NOV-81 11:13

WHEN THE TRANSMITTER IS DONE THE RECEIVER IS INITIALIZED  
A 'WAITING' MESSAGE IS TYPED EVERY 60 SEC IF THERE IS NO ACTION.  
WHEN THE RECEIVER IS DONE, DATA IS CHECKED IF SWITCH SETTINGS  
PERMIT AND END PASS IS TYPED IF SWITCHES ALLOW. THE PROGRAM NOW  
REPEATS CYCLE STARTING AT \$XLB.

IF IN FULL DUPLEX THE RECEIVER AND TRANSMITTER ARE INITIALIZED  
A 'WAITING' MESSAGE IS TYPED EVERY 60 SEC IF THERE IS NO  
ACTION. WHEN BOTH THE RECEIVER AND TRANSMITTER ARE DONE, DATA IS  
CHECKED, END PASS IS TYPED AND PROGRAM LOOPS TO \$XLB DEPENDING  
ON THE SWITCH SETTINGS.

- 9.4 THE RETURN TO MONITOR ROUTINE FOR END PASS AT EOP:  
LOCKS OUT INTERRUPTS AND SAVES THE TRANSMITTER INTERRUPT ENABLE  
BIT AND ALL GENERAL REGISTERS. IT THEN RETURNS TO THE MONITOR  
TO TYPE 'END PASS'. THE MONITOR CHECKS SW14 IF UP IT RETURNS  
TO ENTER:, OTHERWISE IT RESTARTS THE PROGRAM.
- 9.5 ENTER: IS ENTERED FROM THE MONITOR AFTER TYPEING 'END PASS',  
IT RESTORES THE GENERAL REGISTERS AND THE TRANSMITTER CSR  
AS SAVED IN EOP. THE DELAY FLAG IS SET AND PROGRAM RETURNS TO  
THE SCAN ROUTINE(OWO,OWI,ILB,XLB) WHERE IT CAME FROM.
- 9.6 THE INITIALIZE TRANSMIT SUBROUTINE AT STARTX:  
SETS UP THE INTERFACE AND POINTERS NECESSARY TO  
INITIATE A TRANSMIT OPERATION.  
AFTER SETTING 'DATA TERMINAL READY' AND 'REQUEST TO SEND' A CHECK  
IS MADE ON PARAM2 TO DETERMINE IF HALF DUPLEX OPERATION  
WAS SELECTED BY THE OPERATOR. IF IT WAS, THE  
SUBROUTINE WAITS FOR CLEAR TO SEND.  
A 'WAITING FOR CLEAR TO SEND' PRINTOUT OCCURS  
EVERY 30 SECONDS UNTIL CLEAR TO SEND IS ASSERTED.
- 9.7 THE INITIALIZE RECEIVED SUBROUTINE AT STARTR:  
SETS UP THE INTERFACE AND POINTERS NECESSARY TO  
RECEIVE A MESSAGE.
- 9.8 THE TRANSMIT INTERRUPT SERVICE ROUTINE,  
AT XISR:, IS ENTERED VIA TRANSMIT INTERRUPTS  
FROM THE INTERFACE.  
A TEST IS MADE TO SEE IF THE LAST CHARACTER  
TRANSMITTED WAS A NULL (ALL ZEROS) CHARACTER.  
IF IT WAS; THE TRANSMIT LOGIC IN THE INTERFACE  
IS RESET AND THE TRANSMIT COMPLETE FLAG IS SET.  
AT XISR1: THE NEXT CHARACTER IS TRANSMITTED  
AND PRINTED ON THE TTY IF THE MONITOR TRANSMIT  
SWITCH IS SET.
- 9.9 THE RECEIVE INTERRUPT SERVICE ROUTINE  
AT RISR:, IS ENTERED VIA RECEIVER INTERRUPTS  
FROM THE INTERFACE.  
THE RECEIVED CHARACTER IS STORED IN  
THE INPUT BUFFER AND PRINTED ON THE TTY IF  
THE MONITOR RECEIVER SWITCH IS SET.  
IF THE INPUT BUFFER IS FULL, A 'BUFFER FULL'  
PRINTOUT WILL OCCUR. THIS INDICATES THAT A  
LINE FEED CHARACTER WAS NOT RECOGNIZED

CZDZBC.P11

10-NOV-81 11:13

IN THE RECEIVED DATA (WITHIN 1000 CHARACTERS).  
 IF THE RECEIVED CHARACTER IS A LINE FEED,  
 THE RECEIVED LOGIC IS RESET AND THE  
 RECEIVE COMPLETE FLAG IS SET.  
 IF A 'RECEIVE ERROR' IS DETECTED AT RISR:, THE  
 CSR AND DBR WILL BE SAVED AND PRINTED OUT  
 AFTER THE COMPLETE MESSAGE HAS BEEN RECEIVED.

- 9.10 THE DATA TEST SUBROUTINE AT TESTD: IS  
 ENTERED AFTER A COMPLETE MESSAGE HAS BEEN  
 RECEIVED.  
 IF A 'RECEIVE ERROR' HAD BEEN DETECTED,  
 THE CONTENTS OF THE 'RECEIVE BUFFER' AT THE  
 TIME THE ERROR OCCURRED WILL BE PRINTED.  
 THE DATA IS COMPARED UNTIL A 'ALL ZEROS'  
 CHARACTER IS RECOGNIZED. 'FILL' (ALL ONES)  
 CHARACTERS ARE IGNORED. IF A MISMATCH  
 IS DETECTED, THE COMPLETE CONTENTS OF THE  
 INPUT BUFFER AND GOOD DATA IS PRINTED.

#### 10.0 PARAMETERS FOR THE DZ11

PARAM#1 IS LOADED INTO THE LINE PARAMETER REGISTER(DZLPR)  
 BITS 0-2 LINE NUMBER BEING USED, DEFAULT = LINE 0  
 BITS 3,4 CHARACTER LENGTH, DEFAULT = EIGHT BITS  
 BIT 5 STOP BIT COUNT, DEFAULT IS TWO STOP BITS  
 BITS 6,7 PARITY ENABLE AND SELECT, DEFAULT IS NO PARITY  
 BITS 8-11 BAUD RATE SELECT, DEFAULT IS 110 BAUD  
 BIT 12 RECEIVER ON (THIS SHOULD ALWAYS BE SET)

PARAM#2 IS NOT USED AT THIS POINT IN TIME

PARAM#3 IS NOT USED(177777).

#### DZ11 RESTRICTIONS

THE RTS MODEM SIGNAL ON THE DZ11 IS JUMPER SELECTABLE  
 AT THE TERMINATION PANEL. IT IS EITHER ALWAYS ASSERTED OR  
 ASSERTED WHEN DATA TERMINAL READY (DTR) IS SET.  
 CONSEQUENTLY, AT THIS POINT IN TIME, DZ11 ITEP CAN NOT BE USED  
 WITH SERIRES 200 AND OTHER HALF DUPLEX MODEMS. ALL ITEP  
 MODES ARE VALID WITH FULL DUPLEX MODEMS, AND ALL MODES  
 MAY BE USED TO TERMINALS (ONLY ONE WAY OUT AND IN ARE  
 RECOMMENDED HERE, HOWEVER).

CZDZBC.P11 10-NOV-81 11:13

```

588
589
590
591
592      011000
593 011000 055104 000040
594 011004 160010
595 011006 000300
596 011010 000240
597 011012 011070
598 011014 177777
599 011016 177777
600 011020 000000
601 011022 000000
602 011024 000000
603 011026 000000
604 011030 000000
605 011032 000000
606 011034 000000
607 011036 011102
608 011040
609 011040      000
610 011041
611 011041      001
612 011042 000000
613 011044 177570
614 011046 177570
615
616
617
618
619      000000
620      100000
621      040000
622      020000
623      020000
624
625 011050 000000
626 011052 000000
627 011054 000000
628 011056 000000
629 011060 000000
630
631 011062 000000
632 011064 000000
633 011066 000000
634 011070 000000
635
636 011072 177560
637 011074 177562
638 011076 177564
639 011100 177566
640
641      000001

```

```

*****
: DZ11 INTERFACE SERVICE PARAMS
*****

```

```

DZ11:  =11000
      .ASCIZ /DZ /
BA:    160010
RIV:   300
PRIOR: 240
PARAM1: 11070
PARAM2: 177777
PARAM3: 177777
IRDA:  .WORD 0
IXDA:  .WORD 0
SETTLE: .WORD 0
      .WORD 0
B2016: .WORD 0
TIME:  .WORD 0
      .WORD 0
      .WORD START
TX.TERM: .BYTE 000
RX.TERM: .BYTE 001
FLAG:   .WORD 0
SWR:    177570
DISPLAY:177570

```

```

:ISR NAME
:BUS ADDRESS
:VECTOR ADDRESS
:PRIORITY
:PARAM #1
:PARAM #2
:PARAM #3
:INITIAL READ DATA ADDRESS
:INITIAL XMIT DATA ADDRESS
:LINE SETTLE DELAY FLAG
:
:ADDR OF BIN TO OCT TYPE ROUTINE
:TIMER
:
:ADDR OF START OF PROGRAM
:TRANSMITTER TERMINATING CHAR.
:RECEIVER TERMINATING CHAR.

```

```

*****
: CONSTANTS + WORKING STORAGE
*****

```

```

STAT=R0
XFLG=100000
RFLG=40000
DSFLG=20000
BIT13=20000
SXCSR: 0
SRCSR: 0
ERCSR: 0
ERDBR: 0
DSSTAT: 0
XCC: 0
RCC: 0
RDA: 0
XDA: 0
TKS: 177560
TKB: 177562
TPS: 177564
TPB: 177566
FULL.DUPLEX=000001

```

```

:XMIT COMPLETE FLAG
:RCV COMPLETE FLAG
:DATA SET STATUS CHANGE FLAG
:INHIBIT PRINTOUTS
:SAVED XMIT CSR
:SAVED RCV CSR
:RCV CSR SAVED ON ERROR
:RCV DATA REG SAVED ON ERROR
:RCV CSR SAVED ON DS CHANGE
:XMIT CHAR COUNT
:RCV CHAR COUNT
:RCV DATA ADDR.
:XMIT DATA ADDR.

```

CZDZBC.P11 10-NOV-81 11:13

```

642
643
644
645 011102 000240
646 011104 017700 177734
647 011110 042700 177400
648 011114 013702 011006
649 011120 012722 013666
650 011124 013722 011010
651 011130 012722 013354
652 011134 013722 011010
653 011140 013704 011004
654 011144 013714 011012
655 011150 013702 011014
656 011154 042702 000001
657 011160 010264 000000
658 011164 052714 000020
659 011170 032714 000020
660 011174 001375
661 011176 013737 011012 013512
662 011204 042737 010000 013512
663 011212 013764 013512 000002
664 011220 010046
665 011222 012700 000001
666 011226 013701 011012
667 011232 042701 177770
668 011236 001403
669 011240 006300
670 011242 005301
671 011244 000774
672 011246 010037 013516
673 011252 012600
674 011254 113764 013516 000005
675
676
677
678
679
680
681
682 011262 005037 011032
683 011266 005037 013152
684 011272 005037 013156
685 011276 032700 000001
686 011302 001402
687 011304 000137 011460
688 011310 032700 000002
689 011314 001402
690 011316 000137 011352
691 011322 032700 000010
692 011326 001402
693 011330 000137 011556
694 011334 032700 000004
695 011340 001402
696 011342 000137 012006
697 011346 000000

```

```

*****
: DZ11-X INTERFACE SERVICE ROUTINE
*****
START: NOP
MOV @SWR, R0 ;SETUP MODE IN R0
BIC #177400, R0 ;STRIP JUNK
MOV RIV, R2 ;SETUP
MOV #RISR, (R2)+ ;INTERRUPT
MOV PRIOR, (R2)+ ;VECTORS
MOV #XISR, (R2)+
MOV PRIOR, (R2)+
MOV BA, R4 ;SETUP BUS ADDR INDEX
MOV PARAM1, @RCSR ;SETUP VARIABLES
MOV PARAM2, R2
BIC #0001, R2
MOV R2, XCSR(R4) ;IN CSR'S
BIS #DCLR, @RCSR ;CLEAR SILO+UARTS
1$: BIT #DCLR, @RCSR ;CLEAR PULSE DONE?
BNE 1$ ;BR IF NO
2$: MOV PARAM1, TEMP1
BIC #RCVON, TEMP1 ;DON'T TURN ON RECEIVER YET
MOV TEMP1, LPR(R4) ;LOAD LINE NUMBER AND PARAMETERS
3$: MOV R0, -(SP) ;SAVE R0
MOV #1, R0
MOV PARAM1, R1
BIC #^C<7>, R1 ;ISOLATE THE LINE NUMBER
4$: BEQ 5$ ;CALCULATE TCR BIT
ASL R0
DEC R1
BR 4$
5$: MOV R0, TCRTMP ;SAVE THE ACTIVE TCR BIT
MOV (SP)+, R0
MOVB TCRTMP, TCR+1(R4) ;SET DATA TERMINAL READY

```

```

*****
: ROUTINE USED TO GOTO
: SUBROUTINE DEPENDENT
: ON MODE SELECTED.
*****

```

```

GO: CLR TIME
CLR DELAY
CLR STOP
BIT #OWO, MODE
BEQ 1$
JMP $OWO
1$: BIT #OWI, MODE
BEQ 2$
JMP $OWI
2$: BIT #ILB, MODE
BEQ 3$
JMP $ILB
3$: BIT #XLB, MODE
BEQ 4$
JMP $XLB
4$: HALT

```

CZDZBC.P11 10-NOV-81 11:13

698 011350 000776

BR .-2

699  
700  
701  
702  
703  
704  
705  
706  
707  
708  
709  
710  
711  
712

```

*****
ROUTINE USED IF 'ONE WAY IN' MODE WAS SELECTED.
NOTE THAT WHEN IN THIS MODE HALF DUPLEX IS THE
ONLY MODE AVAILABLE.
'ONE WAY IN' MEANS THAT ONLY THE RECEIVER IS
ENABLED. THE TRANSMITTER IS NEVER 'TURNED ON'.
*****

```

713 011352 104416  
714 011354 004737 013524  
715 011360 032700 040000  
716 011364 001013  
717 011366 023727 011032 000100  
718 011374 103771  
719 011376 011402  
720 011400 016403 000000  
721 011404 104001  
722 011406 005037 011032  
723 011412 000762  
724  
725 011414 032777 000200 177422  
726 011422 001002  
727 011424 004737 012376  
728 011430 042700 040000  
729 011434 032777 000020 177402  
730 011442 001405  
731 011444 012737 011456 013154  
732 011452 000137 012236  
733 011456 000735

```

SOWI:  KBDIN
      JSR  PC,STARTR
1$:    BIT  #RFLG,STAT
      BNE  2$
      CMP  TIME,#100
      BLO  1$
      MOV  @RCSR,R2
      MOV  XCSR(R4),R3
      HLT  1
      CLR  TIME
      BR   1$

2$:    BIT  #NODAT,@SWR
      BNE  3$
      JSR  PC,TESTD
3$:    BIC  #RFLG,STAT
      BIT  #LOOP,@SWR
      BEQ  4$
      MOV  #4$,BACK
      JMP  EOP
4$:    BR   SOWI

```

734  
735  
736  
737  
738  
739  
740  
741  
742  
743

```

*****
ROUTINE USED IF 'ONE WAY OUT' WAS SELECTED.
NOTE THAT WHEN IN THIS MODE HALF DUPLEX IS THE ONLY
MODE AVAILABLE.
'ONE WAY OUT' MEANS THAT ONLY THE TRANSMITTER IS
ENABLED. THE RECEIVER IS NEVER 'TURNED ON'.
*****

```

744 011460 104416  
745 011462 004737 013160  
746 011466 005037 011032  
747 011472 032700 100000  
748 011476 001013  
749 011500 023727 011032 000100  
750 011506 103771  
751 011510 011402  
752 011512 016403 000000  
753 011516 104001

```

SOWO:  KBDIN
      JSR  PC,STARTX
      CLR  TIME
1$:    BIT  #XFLG,STAT
      BNE  2$
      CMP  TIME,#100
      BLO  1$
      MOV  @RCSR,R2
      MOV  XCSR(R4),R3
      HLT  1

```



CZDZBC.P11 10-NOV-81 11:13

754	011520	005037	011032			CLR	TIME
755	011524	000762				BR	1\$
756	011526	042700	100000		2\$:	BIC	#XFLG,STAT
757	011532	032777	000020	177304		BIT	#LOOP,@SWR
758	011540	001405				BEQ	3\$
759	011542	012737	011554	013154		MOV	#3\$,BACK
760	011550	000137	012236			JMP	EOP
761	011554	000741			3\$:	BR	SOWO
762							
763							
764							

CZDZBC.P11 10-NOV-81 11:13

```

765
766
767
768
769
770
771
772
773
774
775
776 011556 104416
777 011560 004737 013524
778 011564 005037 011032
779 011570 032700 040000
780 011574 001013
781 011576 023727 011032 000100
782 011604 103771
783 011606 011402
784 011610 016403 000000
785 011614 104001
786 011616 005037 011032
787 011622 000762
788 011624 032777 000200 177212
789 011632 001002
790 011634 004737 012376
791 011640 042700 040000
792 011644 032777 000020 177172
793 011652 001405
794 011654 012737 011666 013154
795 011662 000137 012236
796 011666 032777 000400 177150
797 011674 001416
798 011676 013702 011020
799 011702 013703 011022
800 011706 010337 011070
801 011712 112223
802 011714 001376
803 011716 112743 000177
804 011722 005203
805 011724 112723 000177
806 011730 105023
807 011732 005037 011032
808 011736 004737 013160
809 011742 032700 100000
810 011746 001013
811 011750 023727 011032 000100
812 011756 103771
813 011760 011402
814 011762 016403 000000
815 011766 104001
816 011770 005037 011032
817 011774 000762
818 011776 042700 100000
819 012002 000137 011556

```

```

*****
ROUTINE USED IF INTERNAL LOOP BACK" WAS SELECTED.
NOTE THAT WHEN IN THIS MODE; HALF DUPLEX IS THE
ONLY MODE AVAILABLE.
"INTERNAL LOOP BACK" MEANS THAT THE RECEIVER IS "TURNED ON"
AND A COMPLETE MESSAGE IS RECEIVED. IF DATA IS TO BE CHECKED
IT IS; IF "END PASS" IS DESIRED; IT IS GIVEN.
THEN THE TRANSMITTER IS ENABLED. AFTER THE WHOLE MESSAGE
IS TRANSMITTED; THE CYCLE IS REPETED AS ABOVE.
*****

```

```

$ILB:  KBDIN
      JSR  PC,STARTR
      CLR  TIME
1$:   BIT  #RFLG,STAT
      BNE  2$
      CMP  TIME,#100
      BLO  1$
      MOV  @RCSR,R2
      MOV  XCSR(R4),R3
      HLT  1
      CLR  TIME
      BR   1$
2$:   BIT  #NODAT,@SWR
      BNE  3$
      JSR  PC,TESTD
3$:   BIC  #RFLG,STAT
      BIT  #LOOP,@SWR
      BEQ  4$
      MOV  #4$,BACK
      JMP  EOP
4$:   BIT  #400, @SWR      ;USE EXTERNAL DATA?
      BEQ  7$            ;BR IF NO
      MOV  IRDA, R2      ;SET POINTER
      MOV  IXDA, R3      ;SET POINTER
      MOV  R3, XDA       ;SETUP XMIT DATA ADDR
      MOVB (R2)+, (R3)+ ;MOVE INPUT TO OUTPUT
      BNE  -2            ;LOOP IF NOT ZERO CHAR
      MOVB #177, -(R3)   ;INSERT A FILL CHAR
      INC  R3            ;BUMP ADDRESS
      MOVB #177, (R3)+   ;INSERT ANOTHER FILL
      CLRB (R3)+        ;INSERT ZERO CHAR
7$:   CLR  TIME
5$:   JSR  PC,STARTX
      BIT  #XFLG,STAT
      BNE  6$
      CMP  TIME,#100
      BLO  5$
      MOV  @RCSR,R2
      MOV  XCSR(R4),R3
      HLT  1
      CLR  TIME
6$:   BR   5$
      BIC  #XFLG,STAT
      JMP  $ILB

```

CZDZBC.P11 10-NOV-81 11:13

```

820
821
822
823
824
825
826
827
828
829
830
831
832
833 012006 104416
834 012010 032737 000001 011014
835 012016 001402
836 012020 004737 013524
837 012024 004737 013160
838 012030 005037 011032
839 012034 032700 100000
840 012040 001016
841 012042 032700 040000
842 012046 001024
843 012050 023727 011032 000100
844 012056 103766
845 012060 011402
846 012062 016403 000000
847 012066 104001
848 012070 005037 011032
849 012074 000757
850 012076 032737 000001 011014
851 012104 001356
852 012106 042700 100000
853 012112 004737 013524
854 012116 000746
855 012120 032737 000001 011014
856 012126 001420
857 012130 032700 100000
858 012134 001013
859 012136 023727 011032 000100
860 012144 103765
861 012146 011402
862 012150 016403 000000
863 012154 104001
864 012156 005037 011032
865 012162 000756
866 012164 042700 100000
867 012170 042700 040000
868 012174 005037 011032
869 012200 032777 000200 176636
870 012206 001002
871 012210 004737 012376
872 012214 032777 000020 176622
873 012222 001671
874 012224 012737 012006 013154
875 012232 000137 012236

```

```

*****
ROUTINE USED IF "EXTERNAL LOOP BACK" WAS SELECTED.
EITHER HALF OR FULL DUPLEX MAY BE SELECTED IN THIS MODE.
"EXTERNAL LOOP BACK" MEANS THAT THE TRANSMITTER IS FIRST
TURNED ON (IF HALF DUPLEX) AND THE WHOLE MESSAGE IS TRANSMITTED;
THEN THE RECEIVER IS ENABLED. AFTER THE WHOLE MESSAGE IS RECEIVED
DATA WILL THEN BE CHECKED IF DESIRED AND END PASS WILL
BE GIVEN IF DESIRED. THEN THE CYCLE IS REPEATED
AS ABOVE. IF RUNNING IN FULL DUPLEX THE PROGRAM
WAITS FOR BOTH THE RECEIVER AND TRANSMITTER TO
FINISH THEN RESTARTS THE RECEIVER AND TRANSMITTER.
*****

```

```

$XLB:  KBDIN
      BIT    #FULL.DUPLEX,PARAM2
      BEQ    1$
      JSR    PC,STARTR
1$:    JSR    PC,STARTX
      CLR    TIME
2$:    BIT    #XFLG,STAT
      BNE    3$
7$:    BIT    #RFLG,STAT
      BNE    4$
      CMP    TIME,#100
      BLO   2$
      MOV    @RCSR,R2
      MOV    XCSR(R4),R3
      HLT    1
      CLR    TIME
      BR     2$
3$:    BIT    #FULL.DUPLEX,PARAM2
      BNE    7$
      BIC    #XFLG,STAT
      JSR    PC,STARTR
      BR     2$
4$:    BIT    #FULL.DUPLEX,PARAM2
      BEQ    8$
      BIT    #XFLG,STAT
      BNE    6$
      CMP    TIME,#100
      BLO   4$
      MOV    @RCSR,R2
      MOV    XCSR(R4),R3
      HLT    1
      CLR    TIME
      BR     4$
6$:    BIC    #XFLG,STAT
8$:    BIC    #RFLG,STAT
      CLR    TIME
      BIT    #NODAT,@SWR
      BNE    5$
      JSR    PC,TESTD
5$:    BIT    #LOOP,@SWR
      BEQ    $XLB
      MOV    #$XLB,BACK
      JMP    EOP

```

CZDZBC.P11 10-NOV-81 11:13

```

876
877
878
879
880
881
882 012236
883 012236 104414 000340
884 012242 016437 000000 012374
885 012250 042737 137777 012374
886 012256 042764 040000 000000
887 012264 012766 012324 000002
888 012272 010037 013136
889 012276 010137 013140
890 012302 010237 013142
891 012306 010337 013144
892 012312 010437 013146
893 012316 010537 013150
894 012322 000207
895
896 012324
897 012324 013700 013136
898 012330 013701 013140
899 012334 013702 013142
900 012340 013703 013144
901 012344 013704 013146
902 012350 013705 013150
903 012354 012737 177777 013152
904 012362 053764 012374 000000
905 012370 000177 000560
906 012374 000000
907
908
909
910
911
912
913
914 012376 013746 011056
915 012402 001413
916 012404 032777 020000 176432
917 012412 001007
918 012414 104400 012576
919 012420 004077 176404
920 012424 005746
921 012426 104400 012657
922 012432 013701 011022
923 012436 013702 011020
924 012442 122122
925 012444 001776
926 012446 123741 011040
927 012452 001447
928 012454 122742 000002
929 012460 001005
930 012462 010237 012470
931 012466 104400

```

```

:*****
:ROUTINE TO RETURN
:TO MONITOR FOR
:END PASS.
:*****

```

```

EOP:
STPS,PRTY7 ;SET PS PRIORITY TO 7
MOV XCSR(R4),QTPIE ;SAVE TX CSR
BIC #*C<TIE>,QTPIE ;CLEAR ALL BUT TX IE.
BIC #TIE,XCSR(R4) ;CLEAR TX IE (EVEN IF IT WASN'T SET)
MOV #ENTER,2(SP) ;SET FOR RETURN IF SW 14=1
MOV R0,SAVR0 ;SAVE REGISTER 0
MOV R1,SAVR1 ;SAVE REGISTER 1
MOV R2,SAVR2 ;SAVE REGISTER 2
MOV R3,SAVR3 ;SAVE REGISTER 3
MOV R4,SAVR4 ;SAVE REGISTER 4
MOV R5,SAVR5 ;SAVE REGISTER 5
RTS PC ;RETURN TO CONTROL PROGRAM

```

```

ENTER:
MOV SAVR0,R0 ;RESTORE R0
MOV SAVR1,R1 ;RESTORE R1
MOV SAVR2,R2 ;RESTORE R2
MOV SAVR3,R3 ;RESTORE R3
MOV SAVR4,R4 ;RESTORE R4
MOV SAVR5,R5 ;RESTORE R5
MOV #-1,DELAY
BIS QTPIE,XCSR(R4) ;IF ORGINALLY SET; SET TX IE
JMP @BACK
QTPIE: 000000

```

```

:*****
:SUBROUTINE TO CHECK
:RECEIVER DATA.
:*****
TESTD: MOV ERDBR, -(SP) ;WAS THERE A RECEIVE ERROR?
BEQ TSTDAT ;BR IF NO
BIT #BIT13,@SWR ;INHIBIT PRINTOUTS?
BNE TSTDAT ;BR IF YES
TYPE ,MSG0 ;<15><12>THERE WAS A RECEIVE ERROR. RBUF=
JSR R0,@B2016 ;PRINT CONTENTS OF RBUF
TST -(SP)
TYPE ,MSG1 ;<15><12>
TSTDAT: MOV IXDA, R1 ;SETUP XMIT DATA ADDR
MOV IRDA, R2 ;SETUP RCV DATA ADDR
SCAN4: CMPB (R1)+, (R2)+ ;DATA OK ?
BEQ SCAN4 ;BR IF OK
CMPB TX.TERM,-(R1) ;IS IT END OF DATA
BEQ TESTDX ;BR IF YES
CMPB #002,-(R2)
BNE 2$
MOV R2,1$
TYPE

```

CZDZBC.P11 10-NOV-81 11:13

```

932 012470 000000 1$: .WORD 0
933 012472 000437 BR TESTDX
934 012474 2$: TSTB (R2)
935 012474 105712 BEQ TESTDX ;BR IF YES
936 012476 001435 CMPB #177, (R1)+ ;IS IT FILL CHAR?
937 012500 122721 000177 BEQ SCAN4 ;BR IF YES
938 012504 001756 DEC R1 ;BACKUP
939 012506 005301 CMPB #177, (R2)+ ;IS IT FILL?
940 012510 122722 000177 BEQ SCAN4 ;BR IF YES
941 012514 001752 SCANS: NOP ;DATA ERROR
942 012516 000240 BIT #BIT13,@SWR ;INHIBIT PRINTOUTS
943 012520 032777 020000 176316 BNE DERR ;BR IF YES
944 012526 001016 TYPE ,MSG2 ;<15><12>RECEIVED DATA = <15><12>
945 012530 104400 012662 012544 MOV IRDA, RDAX ;SETUP DATA ADDRESS
946 012534 013737 011020 012544 TYPE ;PRINT RECEIVED DATA
947 012542 104400 RDAX: 0 ;RECEIVED DATA ADDR.
948 012544 000000 TYPE ,MSG3 ;<15><12>DATA SHOULD BE<15><12>
949 012546 104400 012707 012562 MOV IXDA, .+10 ;SETUP ADDR.
950 012552 013737 011022 012562 TYPE ;PRINT GOOD DATA
951 012560 104400 IXDA DERR: MOVB (R1),R3 ;SETUP XMIT DATA
952 012562 011022 MOVB -(R2),R2 ;SETUP RCV DATA
953 012564 111103 HLT+7 ;DATA ERROR HALT
954 012566 114202 TESTDX: TST (SP)+ ;POP STACK
955 012570 104007 RTS PC ;RETURN FROM SUB/ROUT
956 012572 005726
957 012574 000207
958
959 012576 005015 044124 051105 MSG0: .ASCIZ <15><12>/THERE WAS A RECEIVER ERROR. REGISTER (SEL 2) =/
(1) 012657 015 000012 MSG1: .ASCIZ <15><12>
(1) 012662 005015 042522 042503 MSG2: .ASCIZ <15><12>/RECEIVED DATA = /<15><12>
(1) 012707 015 042012 052101 MSG3: .ASCIZ <15><12>/DATA SHOULD BE/<15><12>
(1) 012732 005015 046120 040505 MSG4: .ASCII <15><12>/PLEASE MAKE CONNECTION (DIAL NUMBER)./
(1) 013001 015 053412 042510 .ASCIZ <15><12>/WHEN CONNECTION COMPLETE; HIT CONTINUE SWITCH./<15><12>
(1) 013064 005015 046120 040505 MSG5: .ASCIZ <15><12>/PLEASE MAKE CONNECTION (DIAL NUMBER)./<15><12>
(1)
(1) 013136 000000 .EVEN
960 013140 000000 SAVR0: 0
961 013142 000000 SAVR1: 0
962 013144 000000 SAVR2: 0
963 013146 000000 SAVR3: 0
964 013150 000000 SAVR4: 0
965 013152 000000 SAVR5: 0
966 013154 000000 DELAY: 0
967 013156 000000 BACK: 0
968 STOP: 0

```

CZDZBC.P11 10-NOV-81 11:13

```

969
970
971
972
973 013160 005737 013152
974 013164 001415
975 013166 005037 013512
976 013172 012737 000007 013514
977 013200 005237 013512
978 013204 001375
979 013206 005337 013514
980 013212 001372
981 013214 005037 013152
982 013220 042700 100000
983 013224 013737 011022 011070
984 013232 005737 013156
985 013236 001020
986 013240 104400 012732
987 013244 000000
988 013246 005137 013156
989 013252 005037 013512
990 013256 012737 000030 013514
991 013264 005237 013512
992 013270 001375
993 013272 005337 013514
994 013276 001372
995 013300 113764 013516 000004 2$:
996
997
998 013306 113764 013516 000005
999 013314 032700 000004
1000 013320 001412
1001 013322 012737 177777 013522
1002 013330 052714 040040
1003 013334 000001
1004 013336 000240
1005 013340 005737 013520
1006 013344 001375
1007 013346 052714 040040 3$:
1008 013352 000207
1009
1010 013354 127737 175510 011040 XISR:
1011 013362 001005
1012 013364 052700 100000
1013 013370 042714 040000
1014 013374 000440
1015 013376 116405 000001 XISR1:
1016 013402 042705 177770
1017 013406 013701 011012
1018 013412 042701 177770
1019 013416 120501
1020 013420 001407
1021 013422 011402
1022 013424 005003
1023 013426 104010
1024 013430 104400 014107

```

```

*****
: TRANSMITTER INITIALIZATION SUBROUTINE
*****
STARTX: TST DELAY ;IF SW04=1 & SW14=0 DELAY
        BEQ 1$ ;NO DELAY START TRANSMITTER
        CLR TEMP1 ;PREPARE FOR DELAY
        MOV #7,TEMP2
        INC TEMP1 ;INCREMENT DELAY
        BNE -4
        DEC TEMP2
        BNE -12
        CLR DELAY
1$: BIC #XFLG,STAT
    MOV IXDA,XDA ;SET UP XMIT DATA ADD
    TST STOP ;FIRST TIME HERE?
    BNE 2$ ;NO
    TYPE ,MSG4 ;MAKE CONNECTION
    COM STOP ;COMPLEMENT STOP
    CLR TEMP1 ;YES PREPARE FOR DELAY
    MOV #14*2,TEMP2
    INC TEMP1 ;INCREMENT DELAY
    BNE -4
    DEC TEMP2
    BNE -12
2$: MOVB TCRTMP,TCR(R4) ;SET LINE # IN TCR - CHANGE IN REV C TO A 'MOVB' TO
    ;CORRECT AN AIDS REPORT (HH0001070) - PROBLEM OCCURED
    ;WHEN DTR WAS DROPPED ON A DF03.
    MOVB TCRTMP,TCR+1(R4) ;SET DATA TERMINAL READY
    BIT #XLB,MODE ;XLB MODE?
    BEQ 3$ ;BR IF NO
    MOV #-1,TRNFLG ;SET FLAG
    BIS #TIE+MSENAB,@RCSR ;SET INTERRUPT ENABLE
    WAIT
    NOP
    TST SNCFLG ;FIRST CHAR RECEIVED YET?
    BNE -4 ;BR IF NO
3$: BIS #TIE+MSENAB,@RCSR ;SET INTERRUPT ENABLE,SCAN ENABLE
    RTS PC

XISR: CMPB @XDA,TX.TERM ;IS CHAR TRANSMITTER TERMINATION CHAR
      BNE XISR1 ;BR IF NO
      BIS #XFLG,STAT ;SET XMIT DONE FLAG
      BIC #TIE,@RCSR ;CLEAR ENABLES
      BR XISR3
XISR1: MOVB 1(R4),R5 ;GET LINE NUMBER OF READY LINE
       BIC #^C<7>,R5 ;ISOLATE THE LINE NUMBER
       MOV PARAM1,R1 ;GET THE EXPECTED LINE NUMBER
       BIC #^C<7>,R1 ;ISOLATE IT
       CMPB R5,R1 ;ARE THEY EQUAL?
       BEQ XISR2 ;IF SO, GO TRANSMIT A CHARACTER
       MOV @RCSR,R2 ;SET UP R2 WITH CSR CONTENTS
       CLR R3
       HLT 10 ;ERROR WRONG LINE
       TYPE ,SCANE ;TYPE ERROR MESSAGE

```

CZDZBC.P11 10-NOV-81 11:13

1025	013434	000000					HALT		:HALT
1026	013436	000776					BR		
1027	013440	117764	175424	00C006	XISR2:		MOV B	:-2	
1028	013446	032777	000100	175370			BIT	@XDA,TDR(R4)	:TRANSMIT DATA
1029	013454	001406					BEQ	#100,@SWR	:MONITOR TX DATA?
1030	013456	105777	175414				BPL	NOXMON	:BR IF NO
1031	013462	100003					TSTB	@TPS	:TTY READY?
1032	013464	117777	175400	175406			BPL	NOXMON	:BR IF NO
1033	013472	005237	011070		NOXMON:		MOV B	@XDA,@TPB	:TYPE CHAR
1034	013476	005037	011032		XISR3:		INC	XDA	:INC TTDR POINTER
1035	013502	005037	013522				CLR	TIME	
1036	013506	000002					CLR	TRNFLG	
1037	013510	000000					RTI		
1038	013512	000000			ERROR1:				
1039	013514	000000			TEMP1:				
1040	013516	000000			TEMP2:				
1041	013520	000000			TCRTMP:				
1042	013522	000000			SNCFLG:				
					TRNFLG:				

CZDZBC.P11 10-NOV-81 11:13

```

1043
1044
1045
1046
1047 013524 005737 013156
1048 013530 001005
1049 013532 104400 012732
1050 013536 005137 013156
1051 013542 000000
1052 013544 032700 000004
1053 013550 001405
1054 013552 005037 013512
1055 013556 005237 013512
1056 013562 001375
1057 013564 042700 040000
1058 013570 013737 011020 011066
1059 013576 012737 001000 011064
1060 013604 012737 177777 013520
1061 013612 005037 011054
1062 013616 005037 011056
1063 013622 005764 000002
1064 013626 100775
1065 013630 013737 011012 013512
1066 013636 052737 010000 013512
1067 013644 013764 013512 000002
1068 013652 113764 013516 000005
1069 013660 052714 000140
1070 013664 000207
1071
1072 013666 105714
1073 013670 100403
1074 013672 011402
1075 013674 005003
1076 013676 104010
1077 013700 016401 000002
1078 013704 100403
1079 013706 011402
1080 013710 005003
1081 013712 104010
1082 013714 042701 000200
1083 013720 032701 070000
1084 013724 001404
1085 013726 011437 011054
1086 013732 010137 011056
1087 013736 110177 175124
1088 013742 032777 000040 175074
1089 013750 001405
1090 013752 105777 175120
1091 013756 100002
1092 013760 110177 175114
1093 013764 005237 011066
1094 013770 105077 175072
1095 013774 005337 011064
1096 014000 001007
1097 014002 000005
1098 014004 005002
    
```

```

*****
: RECEIVER INITIALIZATION SUBROUTINE
*****
STARTR: TST      STOP      :FIRST TIME HERE?
        BNE      1$        :BR IF NO
        TYPE     ,MSG4     :TYPE 'MAKE CONNECTION'
        COM      STOP     :COMPLEMENT STOP
        HALT
1$:     BIT      #XLB,MODE  :XLB MODE?
        BEQ      2$        :BR IF NO
        CLR      TEMP1     :START DELAY
        INC      TEMP1
        BNE      ,-4
2$:     BIC      #RFLG,STAT
        MOV      IRDA,RDA  :SET UP RECEIVER DATA ADD
        MOV      #1000,RCC :SET UP BUFFER LIMIT
        MOV      #-1,SNCFLG
        CLR      ERCSR    :CLEAR ERROR RECORDS
        CLR      ERDBR
3$:     TST      RBUF(R4)  :CLEAR SILO
        BMI      3$        :KEEP CLEARING UNTIL BIT 15 CLEAR
        MOV      PARAM1,TEMP1 :GET READY TO LOAD PARAMETERS
        BIS      #RCVON,TEMP1 :BE SURE TO TURN RECEIVER ON
        MOV      TEMP1,LPR(R4) :LOAD PARAMETERS, ENABLE RECEIVER
        MOVB    TCRTMP,TCR+1(R4) :SET DATA TERMINAL READY
        BIS      #RIE!MSENAB,@RCSR ;SET INTERRUPT ENABLE,RECEIVER ENABLE
        RTS      PC
RISR:   TSTB    @RCSR      :DID RECEIVER DONE SET?
        BMI      1$        :BR IF YES
        MOV      @RCSR,R2  :SAVE CSR
        CLR      R3
        HLT      10        :ERROR RECEIVER INTERRUPTED BUT DONE NOT SET
1$:     MOV      RBUF(R4),R1 :GET CHAR
        BMI      2$        :BR IF YES
        MOV      @RCSR,R2  :SAVE CSR
        CLR      R3
        HLT      10        :ERROR CHAR PRESENT NOT SET
2$:     BIC      #200,R1    :STRIP A BIT
        BIT      #ORUN+FRME+PARE,R1 :CHECK FOR RECEIVER ERRORS
        BEQ      3$        :BR IF NO ERRORS
        MOV      @RCSR,ERCSR :SAVE CSR
        MOV      R1,ERDBR   :SAVE RBUF
        MOVB    R1,@RDA     :STORE CHAR
3$:     BIT      #BITS,@SWR  :MONITOR RXDATA?
        BEQ      NORMON    :BR IF NO
        TSTB    @TPS       :IS TTY READY?
        BPL     NORMON     :BR IF NO
        MOVB    R1,@TPB    :TYPE CHAR
        INC     RBUF        :INC RBUF POINTER
        CLRB   @RDA        :CLEAR NEXT POSITION
        DEC     RCC         :DEC CHAR COUNT
        BNE    1$         :BUFFER FULL YET?
        RESET
        CLR     R2        :STOP THE SHOW,BUFFER OVERFLOWED
NORMON: INC     RDA
        CLRB   @RDA
        DEC     RCC
        BNE    1$
        RESET
        CLR     R2
    
```



CZDZBC.P11 10-NOV-81 11:13

1099	014006	005003				CLR	R3		
1100	014010	104000				HLT	0		
1101	014012	104006				HLT	6		;RECEIVER BUFFER FULL
1102	014014	000000				HALT			
1103	014016	000776				BR	.-2		
1104	014020	123701	011041		1S:	CMPB	RX.TERM,R1		;IS CHAR 001?
1105	014024	001004				BNE	RISR1		;BR IF NO
1106	014026	042714	000100			BIC	#RIE,@RCSR		;CLEAR RECEIVER INTERUPT ENABLE
1107	014032	052700	040000			BIS	#RFLG,STAT		;SET R DONE FLAG
1108	014036	005037	011032		RISR1:	CLR	TIME		
1109	014042	005037	013520			CLR	SNCFLG		
1110	014046	000002				RTI			;GO HOME
1111	014050	005015	042522	042503	MFULL:	.ASCIZ<15><12>/RECEIVER BUFFER FULL ERROR!!!			
	014107	015	042412	051122	SCANE:	.ASCIZ<15><12>/ERROR! TRANSMITTER SCAN STOPPED ON WRONG LINE/			
		014170			.EVEN				
		000001			.END				

CZDZBC.P11

10-NOV-81 11:13

CROSS REFERENCE TABLE -- USER SYMBOLS

BA	011004	594#	653					
BACK	013154	731*	759*	794*	874*	905	966#	
BIT0	= 000001	588#						
BIT1	= 000002	588#						
BIT10	= 002000	588#						
BIT11	= 004000	588#						
BIT12	= 010000	588#						
BIT13	= 020000	588#	623#	916	943			
BIT14	= 040000	588#						
BIT15	= 100000	588#						
BIT2	= 000004	588#						
BIT3	= 000010	588#						
BIT4	= 000020	588#						
BIT5	= 000040	588#	1088					
BIT6	= 000100	588#						
BIT7	= 000200	588#						
BIT8	= 000400	588#						
BIT9	= 001000	588#						
B2016	011030	604#	919					
DCLR	= 000020	588#	658	659				
DELAY	013152	683*	903*	965#	973	981*		
DERR	012564	944	953#					
DISPLA	011046	614#						
DSFLG	= 020000	588#	622#					
DSSTAT	011060	629#						
DZ11	011000	593#						
ENTER	012324	887	896#					
EOP	012236	732	760	795	875	882#		
ERCSR	011054	627#	1061*	1085*				
ERDBR	011056	628#	914	1062*	1086*			
ERROR1	013510	1037#						
FLAG	011042	612#						
FRME	= 020000	588#	1083					
FULL.D	= 000001	641#	834	850	855			
GO	011262	682#						
ILB	= 000010	588#	691					
IRDA	011020	600#	798	923	946	1058		
IXDA	011022	601#	799	922	950	952	983	
KBDIN	= 104416	588#	713	744	776	833		
LOOP	= 000020	588#	729	757	792	872		
LPR	= 000002	588#	663*	1067*				
MFULL	014050	1111#						
MSENAB	= 000040	588#	1002	1007	1069			
MSG0	012576	918	959#					
MSG1	012657	921	959#					
MSG2	012662	945	959#					
MSG3	012707	949	959#					
MSG4	012732	959#	986	1049				
MSG5	013064	959#						
NODAT	= 000200	588#	725	788	869			
NORMON	013764	1089	1091	1093#				
NOXMON	013472	1029	1031	1033#				
ORUN	= 040000	588#	1083					
OWI	= 000002	588#	688					
OWO	= 000001	588#	685					
PARAM1	011012	597#	654	661	666	1017	1065	



CZDZBC.P11 10-NOV-81 11:13

CROSS REFERENCE TABLE -- USER SYMBOLS

TKB	011074	637#													
TKS	011072	636#													
TPB	011100	639#	1032*	1092*											
TPS	011076	638#	1030	1090											
TRNFLG	013522	1001*	1035*	1042#											
TSTDAT	012432	915	917	922#											
TX.TER	011040	608#	926	1010											
TYPE =	104400	588#	918	921	931	945	947	949	951	986	1024	1049			
XCC	011062	631#													
XCSR =	000000	588#	657*	720	752	784	814	846	862	884	886*	904*			
XDA	011070	634#	800*	983*	1010	1027	1032	1033*							
XFLG =	100000	620#	747	756	809	818	839	852	857	866	982	1012			
XISR	013354	651	1010#												
XISR1	013376	1011	1015#												
XISR2	013440	1020	1027#												
XISR3	013476	1014	1034#												
XLB =	000004	588#	694	999	1052										
XWAIT =	104412	588#													
\$ILB	011556	693	776#	819											
\$OWI	011352	690	713#	733											
\$OWO	011460	687	744#	761											
\$XLB	012006	696	833#	873	874										
.	= 014170	592#	698	802	950*	978	980	992	994	1006	1026	1056	1103	1111#	

CZDZBC.P11

10-NOV-81 11:13

CROSS REFERENCE TABLE -- MACRO NAMES

BOX	1#	589	616	642	969	1043								
DCPARM	1#													
DHDOC1	1#													
DHPARM	1#													
DJPARM	1#													
DLPARM	1#													
DPPARM	1#													
DQDOC1	1#													
DQPARM	1#													
DUPARM	1#													
DUPPAR	1#													
DVDOC1	1#													
DVPARM	1#													
DZPARM	1#	560												
HELLO	1#													
HLT	588#	721	753	785	815	847	863	955	1023	1076	1081	1100	1101	
SEQUAT	1#	588												
SINTF	1#	588												
SITEP	1#	675												
SSERV	1#	631												

. ABS. 014170 000

ERRORS DETECTED: 0

CZDZBC,CZDZBC/CRF/SOL/NL:TOC=ITEP1.MAC,CZDZBC.P11  
 RUN-TIME: 3 3 .3 SECONDS  
 RUN-TIME RATIO: 55/7=7.7  
 CORE USED: 16K (31 PAGES)