

Micro Fiche Scan

Name of device(s) tested:

RL01/02,RL11,RLV11/12

Test description:

RL01/02 DRIVE TST 3

MAINDEC Number or Package Identifier (after SEP 1977):

CZRLNC0

Fiche Document Part Number:

AH-F845C-MC

Fiche preparation date unknown, using copyright year:

1985

Image resolution:

8-bit gray levels, max. quality for archiving

COPYRIGHT (C) 1979-85 by d|i|g|i|t|a|l

B1

1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51

.REM @

IDENTIFICATION  
-----

PRODUCT CODE: AC-F843C-MC  
PRODUCT NAME: CZRLNCO RL01/02 DRIVE TEST 3  
DATE CREATED: 05-JAN-1979  
REVISED: 06-JAN-1986  
MAINTAINER: CXO DIAGNOSTIC ENGINEERING  
AUTHORS: D. DEKNIS, C. CAMPBELL  
REVISED BY: M. LEAVITT

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS MANUAL.

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED TO THE PURCHASER UNDER A LICENSE FOR USE ON A SINGLE COMPUTER SYSTEM AND CAN BE COPIED (WITH INCLUSION OF DIGITAL'S COPYRIGHT NOTICE) ONLY FOR USE IN SUCH SYSTEM, EXCEPT AS MAY OTHERWISE BE PROVIDED IN WRITING BY DIGITAL.

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

COPYRIGHT (C) 1979, 1983, 1986 DIGITAL EQUIPMENT CORPORATION

1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35

HISTORY

-----

AUTHOR: DAN DEKMIS           05-JAN-1979           VERSION A0

MODIFIED BY:

                  CHUCK CAMPBELL           1983           VERSION B0  
                  MIKE LEAVITT           06-JAN-1986           VERSION C0

B0 Problem:

          Unknown

          Solution:

          Unknown

C0 Problem:

          Prism Report PR00486. Diagnostic will not read Bad Sector File if TEST 2 is not included in test sequence.

          Solution:

          All tests in the diagnostic which require the bad sec file data, will test to see if the bad sec file had previously been read. If not, the test will read the bad sector file before executing the desired test sequence.

1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52

TABLE OF CONTENTS

-----

1.0	GENERAL INFORMATION
1.1	PROGRAM ABSTRACT
1.1.1	STRUCTURE OF PROGRAM
1.1.2	DIAGNOSTIC INFORMATION
1.1.3	DIAGNOSTIC RUN TIME
1.2	SYSTEM REQUIREMENTS
1.2.1	HARDWARE REQUIREMENTS
1.2.2	SOFTWARE REQUIREMENTS
1.3	RELATED DOCUMENTS AND STANDARDS
1.4	DIAGNOSTIC HIERARCHY PREREQUISITES
1.5	ASSUMPTIONS
2.0	OPERATING INSTRUCTIONS
2.1	HOW TO RUN THIS DIAGNOSTIC
2.1.1	THE FIVE STEPS OF EXECUTION
2.1.2	SAMPLE RUN-THROUGH
2.2	CHAIN MODE OPERATION
2.3	DETAILS OF COMMANDS AND SYNTAX
2.3.1	TABLE OF COMMAND VALIDITY
2.3.2	COMMAND SYNTAX
2.4	EXTENDED P-TABLE DIALOGUE
2.5	HARDWARE PARAMETERS
2.6	SOFTWARE PARAMETERS
3.0	ERROR INFORMATION
3.1	ERROR REPORTING
3.1.2	SPECIFIC RESULT MESSAGES
3.1.3	OTHER MESSAGES
3.2	ERROR HALTS
4.0	PERFORMANCE AND PROGRESS REPORTS
4.1	PERFORMANCE REPORTS
4.2	PROGRESS REPORTS
5.0	DEVICE INFORMATION TABLES
6.0	TEST SUMMARIES

1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56

1.0 GENERAL INFORMATION  
-----

1.1 PROGRAM ABSTRACT  
-----

1.1.1 STRUCTURE OF PROGRAM  
-----

THIS DIAGNOSTIC COMPATIBLE WITH BOTH XXDP+ AND ACT. IT CAN BE RUN STANDALONE UNDER XXDP, AND CAN BE CHAINED UNDER XXDP+, ACT AND APT IN ACT MODE (SEE 2.2 "CHAIN MODE OPERATION" FOR DETAILS OF CHAINING PROCEDURE). IT IS A SINGLE PROGRAM FROM THE STANDPOINT OF THE DIAGNOSTIC USER, WHICH AT RUN TIME IS APPENDED TO A COMMON FRONT-END PIECE OF SUPERVISOR SOFTWARE THROUGH WHICH THE DIAGNOSTIC PROGRAM INTERFACES TO THE ENVIRONMENT AS IT EXECUTES.

WHEN THIS DIAGNOSTIC IS STARTED AT ADDRESS 200, CONTROL GOES FIRST TO THE SUPERVISOR PORTION, WHICH WILL ASK CERTAIN "HARD CORE" QUESTIONS ABOUT THE ENVIRONMENT. THEN IT WILL ENTER COMMAND MODE, INDICATED BY A PROMPT CHARACTER (DR>). AT COMMAND MODE THE OPERATOR MAY ENTER ANY OF SEVERAL COMMANDS AS DESCRIBED IN 2.0 "OPERATING INSTRUCTIONS".

THE DIAGNOSTIC PROGRAM IS LOADED IN THE LOWER 8K OF MEMORY. THE DIAGNOSTIC SUPERVISOR CODING OCCUPIES 6.25K OF THE UPPER PART OF MEMORY JUST BELOW THE XXDP+ MONITOR WHICH RESIDES IN THE UPPERMOST 1.5K OF MEMORY SPACE.

1.1.2 DIAGNOSTIC INFORMATION  
-----

THIS PROGRAM TESTS AND EXERCISES RL01/02 DISK DRIVES RL11/RLV11 CONTROLLERS (4 DRIVES PER CONTROLLER). THE ENTIRE PROGRAM IS RUN ON THE FIRST DRIVE BEFORE STARTING ON THE SECOND. THE PROGRAM STARTS BY TESTING THE SIMPLEST FUNCTIONS FIRST USING THE LOGIC TESTED IN EARLIER TESTS TO TEST MORE COMPLEX FUNCTIONS.

THIS PROGRAM FIRST TESTS THE RL01/02 SEEK TIMING. DATA TRANSFERS ARE DONE AFTER THE SEEK TIMING TEST. THE FIRST DATA TRANSFER IS READING OF THE BAD SECTOR FILES WHICH ARE STORED AND USED LATER TO PREVENT TESTING ON BAD SECTORS. FOLLOWING DATA READ AND WRITE TESTING, THE PROGRAM TESTS FOR OVERWRITE PROBLEMS AND ADJACENT CYLINDER INTERFERENCE.

THE WRITE LOCK DATA PROTECTION TEST IS PERFORMED IF MANUAL INTERVENTION IS REQUESTED.

1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55

1.1.3 DIAGNOSTIC RUN TIME

THIS DIAGNOSTIC TAKES 4 MINUTES TO RUN THE FIRST PASS AND 28.5 MINUTES FOR THE SECOND PASS.

1.2 SYSTEM REQUIREMENTS

1.2.1 HARDWARE REQUIREMENTS

- \* PDP-11/LSI-11 PROCESSOR WITH 16K OR MORE OF MEMORY
- \* CONSOLE DEVICE (LA30,LA36,VT50,ETC.)
- \* 1 OR 2 RL11/RLV11 CONTROLLER(S) WITH:
  - 1 - 8 RL01 DRIVES WITH RL01K CARTRIDGES CONTAINING A 'BAD SECTOR FILE'
  - 1 - 8 RL02 DRIVES WITH RL02K CARTRIDGES CONTAINING A 'BAD SECTOR FILE'
- \* KW11-P CLOCK (REQUIRED TO PERFORM TESTS 1 AND 4)
- \* LINE PRINTER (OPTIONAL)

1.2.2 SOFTWARE REQUIREMENTS

CZRLJ RL01/02 DRIVE TEST PART 2

1.3 RELATED DOCUMENTS AND STANDARDS

RL01/02 DISK SUBSYSTEM USER'S GUIDE (EK-RL01-UG-002)  
XXDP+/SUPERVISOR USER'S MANUAL

1.4 DIAGNOSTIC HIERARCHY PREREQUISITES

THE RL01/02 SUBSYSTEM SHOULD HAVE SUCCESSFULLY RUN THE FOLLOWING PROGRAMS:

- |       |   |
|-------|---|
| CVRLA | RLV11 RL01 DISKLESS TEST (RLV11 ONLY)       |
| CZRLG | RL11/RLV11 RL01/02 CONTROLLER TEST (PART 1) |
| CZRLH | RL11/RLV11 RL01/02 CONTROLLER TEST (PART 2) |
| CZRLI | RL01/02 DRIVE TEST (PART 1)                 |

1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56

1.5            ASSUMPTIONS  
                 -----

THE HARDWARE OTHER THAN THE RL01/02 SUBSYSTEM IS ASSUMED TO WORK PROPERLY. FALSE ERRORS MAY BE REPORTED IF THE PROCESSOR, ETC., DO NOT FUNCTION PROPERLY.

2.0            OPERATING INSTRUCTIONS  
                 -----

2.1            HOW TO RUN THIS DIAGNOSTIC  
                 -----

2.1.1          THE FIVE STEPS OF EXECUTION  
                 -----

THIS DIAGNOSTIC PROGRAM SHOULD BE LOADED AND STARTED USING NORMAL XXDP+ PROCEDURES. START THE EXECUTION OF THE XXDP+ MONITOR BY USING THE APPROPRIATE BOOTSTRAP PROGRAM. THE MONITOR WILL PRINT A MESSAGE IDENTIFYING ITSELF AND REQUESTING THAT THE CURRENT DATE BE ENTERED. AN EXAMPLE OF THIS MESSAGE IS GIVEN BELOW FOR THE XXDP+ MONITOR:

```
CHMDK?? XXDP+ DK MONITOR NNK
BOOTED VIA UNIT 0
ENTER DATE (DD-MMM-YY):
```

TYPE "R" AND THE PROGRAM NAME TO RUN THE PROGRAM. DO NOT TYPE THE EXTENSION.

WHEN THIS DIAGNOSTIC IS STARTED THE FOLLOWING STEPS WILL OCCUR:

```
*****
* STEP 1 *
*****
```

THE DIAGNOSTIC WILL ISSUE THE PROMPT "DR>". FROM THIS POINT UNTIL THE TIME WHEN YOU RESTART XXDP+, YOU WILL BE TALKING TO THE DIAGNOSTIC, NOT XXDP+. WE WILL REFER TO THE PRESENCE OF THIS PROMPT AS BEING IN DIAGNOSTIC COMMAND MODE, AS OPPOSED TO XXDP+ COMMAND MODE.

AT THIS POINT YOU WILL ENTER A "START" COMMAND. THIS IS NOT THE SAME AS THE XXDP+ "START" COMMAND, WHICH YOU ALREADY ISSUED IN RESPONSE TO THE XXDP+ DOT PROMPT. THIS "START" COMMAND CAN TAKE A NUMBER OF SWITCHES AND FLAGS (ALL OPTIONAL) AND THE DETAILS OF THESE ARE SET FORTH IN 2.3 "DETAILS OF COMMANDS AND SYNTAX". HOWEVER, IN ORDER TO USE THE PROGRAM, ALL YOU NEED TO SAY IS SOMETHING LIKE THIS:

1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57

STA/PASS:1/FLAGS:HOE

THINGS TO NOTE HERE:

1. ONLY THE FIRST THREE CHARACTERS OF THIS OR ANY COMMAND AT THE "DR>" LEVEL NEED TO BE TYPED.
2. THE "PASS" SWITCH SPECIFIES HOW MANY PASSES YOU DESIRE. A PASS CONSISTS OF RUNNING THE FULL DIAGNOSTIC AGAINST ALL UNITS BEING TESTED (THIS WILL BE EXPLAINED SHORTLY). ONE PASS IS SPECIFIED IN THE ABOVE EXAMPLE.
3. THE "FLAGS" SWITCH MAY SPECIFY ANY OF A NUMBER OF FLAGS, BUT THE MAIN USEFUL ONES ARE:

PNT	PRINT NUMBER OF TEST BEING EXECUTED
LOE	LOOP ON ERROR
HOE	HALT ON ERROR
IER	INHIBIT ERROR PRINTOUT

THE HOE FLAG IS SPECIFIED IN THE ABOVE EXAMPLE (WE'LL SEE WHY SHORTLY).

\*\*\*\*\*  
\* STEP 2 \*  
\*\*\*\*\*

WHEN YOU HAVE TYPED IN A "START" COMMAND, THE DIAGNOSTIC WILL COME BACK WITH THE QUESTION "# UNITS?" TO WHICH YOU SHOULD RESPOND BY TYPING IN THE NUMBER OF DEVICES YOU WISH TO TEST.

A WORD OF WARNING HERE: THE NUMBER OF UNITS DEPENDS ON THE TARGET DEVICE OF THE DIAGNOSTIC. FOR EXAMPLE, IF THE DIAGNOSTIC IS DIRECTED AT A DISK DRIVE, THEN THE NUMBER OF UNITS WOULD BE THE NUMBER OF DRIVES TO BE TESTED. WHEREAS IF THE DIAGNOSTIC WAS DIRECTED AT THE DISK CONTROLLER, THEN THE NUMBER OF UNITS WOULD BE THE NUMBER OF CONTROLLERS. THE TARGET DEVICE OF A DIAGNOSTIC CAN ALWAYS BE DETERMINED BY INSPECTING THE "HEADER" STATEMENT NEAR THE BEGINNING OF THE SOURCE CODE. ONE OF THE OPERANDS OF THIS "HEADER" STATEMENT SHOULD BE THE DEVICE TYPE OF THE DIAGNOSTIC.

\*\*\*\*\*  
\* STEP 3 \*  
\*\*\*\*\*

WHEN YOU HAVE TYPED IN THE NUMBER OF UNITS TO BE TESTED, THE DIAGNOSTIC WILL ASK YOU THE "HARDWARE QUESTIONS". THE ANSWERS TO THESE QUESTIONS ARE USED TO BUILD TABLES IN CORE, CALLED "HARDWARE P-TABLES". ONE HARDWARE P-TABLE WILL BE BUILT FOR



1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57

EACH UNIT TO BE TESTED.

THERE ARE SEVERAL HARDWARE QUESTIONS AND THE ENTIRE SERIES WILL BE POSED N TIMES, WHERE N IS THE NUMBER OF UNITS.

THIS REPRESENTS A NEW PHILOSOPHY IN DIAGNOSTIC ENGINEERING. DIAGNOSTICS IN THE FUTURE WILL NOT BE WRITTEN TO AUTOSIZE OR ASSUME STANDARD ADDRESSES: INSTEAD, THEY WILL ASK THE OPERATOR FOR ALL THE INFORMATION THEY NEED TO TEST THE DEVICE.

\*\*\*\*\*  
\* STEP 4 \*  
\*\*\*\*\*

AFTER YOU HAVE ANSWERED ALL THE HARDWARE QUESTIONS (SEC 2.5) FOR ALL THE UNITS, YOU WILL BE ASKED "CHANGE SW?" IF YOU WANT TO BE ASKED THE SOFTWARE QUESTIONS THAT DETERMINE THE BEHAVIOR OF THIS PROGRAM, TYPE "Y". IF YOU WANT TO TAKE ALL THE DEFAULTS TO THESE QUESTIONS, TYPE "N". IF YOU TYPE "Y" YOU WILL BE ASKED THE SOFTWARE QUESTIONS (SEC 2.6), AND THE ANSWERS WILL BE PUT INTO THE SOFTWARE P-TABLE IN THE PROGRAM. THE SERIES OF QUESTIONS WILL BE ASKED JUST ONCE, REGARDLESS OF THE NUMBER OF UNITS TO BE TESTED.

\*\*\*\*\*  
\* STEP 5 \*  
\*\*\*\*\*

AFTER YOU HAVE ANSWERED THE SOFTWARE QUESTIONS, THE DIAGNOSTIC WILL BEGIN TO EXECUTE THE HARDWARE TEST CODE. THERE ARE SEVERAL THINGS THAT CAN HAPPEN NEXT, DEPENDING ON WHETHER A HARDWARE ERROR IS ENCOUNTERED AND ALSO ON WHAT SWITCH VALUES YOU SELECTED ON THE START COMMAND. CONSIDER THE POSSIBILITIES:

1. IF NO ERROR IS ENCOUNTERED, THEN THE DIAGNOSTIC WILL SIMPLY EXECUTE THE DESIRED NUMBER OF PASSES AND RETURN TO COMMAND MODE (PROMPT DR>).
2. IF AN ERROR IS ENCOUNTERED, THEN ONE OF THREE THINGS HAPPENS, DEPENDING ON THE SETTINGS OF THE HOE AND LOE FLAGS.

HOE SET: THE ERROR WILL BE REPORTED ON THE CONSOLE AND THE DIAGNOSTIC WILL RETURN TO COMMAND MODE.

LOE SET: THE DIAGNOSTIC WILL LOOP ENDLESSLY ON THE BLOCK OF CODE THAT DETECTED THE ERROR.

NEITHER HOE NOR LOE SET: THE ERROR WILL BE REPORTED ON THE CONSOLE AND NORMAL EXECUTION WILL RESUME AS IF

1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56

NO ERROR HAD OCCURRED.

2.1.2 SAMPLE RUN-THROUGH  
-----

LET'S SEE HOW ALL THIS WORKS IN A REAL SITUATION. RECALL THAT WE ENTERED THE COMMAND "STA/PASS:1/FLAGS:HOE". THIS WOULD BE A VERY TYPICAL WAY TO RUN THE DIAGNOSTIC. IF NO ERRORS ARE ENCOUNTERED, THE SINGLE REQUESTED PASS WILL BE EXECUTED AND THE PROMPT WILL BE RE-ISSUED.

IF AN ERROR IS ENCOUNTERED, THE ERROR WILL BE REPORTED AND THE PROMPT WILL BE REISSUED (BECAUSE THE HOE FLAG IS SET). AT THIS POINT THERE ARE FOUR DIFFERENT WAYS YOU CAN GET THE PROGRAM GOING AGAIN:

1. ISSUE ANOTHER "START" COMMAND (THUS GOING THRU ALL OF STEPS 1, 2, 3, 4, AND 5 AGAIN)
2. ISSUE A "RESTART" COMMAND (SAME AS START COMMAND EXCEPT THAT THE HARDWARE QUESTIONS ARE NOT ASKED)
3. ISSUE A "CONTINUE" COMMAND (EXECUTION WILL RESUME AT THE BEGINNING OF THE PARTICULAR HARDWARE TEST (MOST DIAGNOSTICS CONSIST OF A NUMBER OF THESE) THAT IT WAS IN WHEN THE ERROR HALT OCCURRED. NO QUESTIONS ASKED.
4. ISSUE A "PROCEED" COMMAND: EXECUTION WILL RESUME AT THE INSTRUCTION FOLLOWING THE ERROR REPORT (THIS IS A SPECIAL COMMAND AND CAN BE ISSUED ONLY AT A HALT ON ERROR).

THE MOST TYPICAL THING TO DO HERE IS TO ISSUE THE PROCEED, BUT WITH DIFFERENT FLAG SETTINGS. PROBABLY YOU WOULD WANT TO SAY:

PRO/FLAGS:IER:LOE:HOE=0

THIS WILL DO THE FOLLOWING:

1. TURN ON THE IER (INHIBIT ERROR PRINTOUT) FLAG
2. TURN ON THE LOE FLAG
3. TURN OFF THE HOE FLAG
4. RESUME EXECUTION AT INSTRUCTION AFTER ERROR REPORT

THE DIAGNOSTIC WILL NOW LOOP ON THE BLOCK OF CODE THAT DETECTED AND REPORTED THE ERROR, BUT NO ERROR PRINTOUT WILL OCCUR. THUS YOU CAN STUDY THE ERROR OR SCOPE IT OR WHATEVER.

1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57

WHEN YOU'VE SEEN ENOUGH, YOU MAY HIT CONTROL/C. THIS WILL TAKE YOU OUT OF THE LOOP AND PUT YOU BACK INTO COMMAND MODE.

- 1. START
- 2. RESTART
- 3. CONTINUE

LET'S SAY YOU'VE REPAIRED THE DEFECT FOUND ABOVE AND WANT TO FINISH RUNNING THE DIAGNOSTIC. YOU WOULD TYPE

CON/FLAGS:HOE:IER=0:LOE=0

THIS WILL RESTORE THE FLAGS TO THEIR ORIGINAL VALUES AND RESUME EXECUTION AT THE BEGINNING OF THE HARDWARE TEST YOU WERE IN. IF THE ERROR DOES NOT RECUR, THE EXECUTION WILL FLOW RIGHT ON THRU TO THE NEXT ERROR OR TO END OF PASS.

IF AT END OF PASS YOU WANT TO RUN THE DIAGNOSTIC AGAIN, YOU HAVE TWO CHOICES:

- 1. START
- 2. RESTART

YOU WOULD CHOCSE ONE, DEPENDING ON WHETHER YOU WANTED TO ANSWER THE HARDWARE QUESTIONS AGAIN.

THE FULL PRINT-OUT FROM THE ABOVE DIALOGUE MIGHT LOOK LIKE THIS (O=OPERATOR, D=DIAGNOSTIC):

	BY WHOM ENTERED: -----
.R CZRLN??	O
DRS LOADED	D
DIAG. RUN-TIME SERVICES REV. x mmm-yy	D
CZRLN-?-?	D
CZRLN TESTS SEEK AND ROTATIONAL TIMING & WRITE & READ DATA	D
UNIT IS RL01, RL02	D
DR>STA/PASS:1/FLAGS:HOE	D,O
# UNITS (D) ? 2	D,O
UNIT 0	D
RL11 (L) Y ?	D,O

1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57

```
BUS ADDRESS (0) 174400 ?      D,0
VECTOR (0) 160 ?              D,0
DRIVE (0) 0 ?                  D,0
DRIVE TYPE = RL01 (L) Y ?     D,0
BR LEVEL (0) 5 ?              D,0

UNIT 1                          D
RL11 (L) Y ?                   D,0
BUS ADDRESS (0) 174400 ?      D,0
VECTOR (0) 160 ?              D,0
DRIVE (0) 0 ? 1                D,0
DRIVE TYPE = RL01 (L) ? N     D,0 (N=RL02)
BR LEVEL (0) 5 ?              D,0

CHANGE SW (L) ? Y              D,0

USE ALL CYL (L) N ?            D,0
USE ALL SECT (L) N ?           D,0
DO MANUAL INTERVENTION TEST (L) N ? D,0
LOW SEEK LIMIT (L) N ?         D,0
UPPER SEEK LIMIT (L) N ?       D,0
USE ONLY ONE SURF (L) N ?      D,0
INPUT ERROR LIMIT (D) 20 ?     D,0
DATA CMP ERR LMT (D) 10 ?      D,0
PRINT ERRORS DETECTED WHILE READING BAD SEC FILE (N) ? D,0

CZRLN HRD ERR 00004 TST 003 SUB 002 PC:004130
ERR HLT

DR>PRO/FLAGS:IER:LOE:HOE=0      D,0

*****
AT THIS POINT THE DIAGNOSTIC IS LOOPING ON THE
ERROR WITHOUT PRINTING ANYTHING. YOU CAN SCOPE
THE ERROR UNTIL YOU HAVE LOCATED IT, THEN +C OUT
*****

+C                                0

DR>CON/FLAGS:HOE:IER:LOE=0      D,0

CHANGE SW (L) ? N              D,0

CZRLN EOP 1                      D
+C

DR>RESTART/PASS:1              D,0

CHANGE SW (L) ? N              D,0
-----
-----
-----
-----
```

1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57

2.2 CHAIN MODE OPERATION

CHAIN MODE OPERATION CONSISTS OF THE SEQUENTIAL EXECUTION OF PROGRAMS WITHOUT OPERATOR INTERVENTION. ONLY PROGRAMS THAT HAVE BEEN MODIFIED TO RUN IN CHAIN MODE CAN BE CHAINED. CHAINABLE PROGRAMS ARE IDENTIFIED IN THE DIRECTORY BY A BIC EXTENSION.

TO RUN CHAIN MODE, THE XXDP+ MONITOR USES AN ASCII FILE (KNOWN AS A CHAIN FILE) LISTING THE PROGRAMS TO BE RUN AND THE NUMBER OF PASSES EACH PROGRAM SHOULD RUN. THIS FILE MUST BE ON THE SYSTEM DEVICE.

A CHAIN FILE MAY BE GENERATED BY USE OF THE XTECO TEXT EDITOR. THIS FILE MUST HAVE A CCC EXTENSION. THE CHAIN FILE MAY CONTAIN ANY OF THE COMMANDS SUPPORTED BY THE XXDP+ MONITOR. THE COMMANDS IN THE ASCII FILE ARE EXECUTED IN THE ORDER IN WHICH THEY ARE ENCOUNTERED.

TO EXECUTE A CHAIN FILE THE USER TYPES:

```
C FILNAM <CR> OR
C FILNAM/QV <CR>
```

IN THE FIRST CASE THE PASS COUNT SPECIFIED IN THE CHAIN FILE IS USED BY THE XXDP+ MONITOR TO DETERMINE THE NUMBER OF PASSES TO EXECUTE EACH PROGRAM. IN THE SECOND CASE THE PROGRAM COUNT IS NOT USED AND EACH PROGRAM IS EXECUTED ONLY ONCE. THE /QV SWITCH PROVIDES A SINGLE EXECUTION MODE OF OPERATION OF QUICK VERIFY.

WHEN PROGRAMS ARE RUN IN CHAIN MODE, THE SOFTWARE SWITCH REGISTER SHOULD BE SET TO 000000. THE XXDP+ MONITOR PRINTS EACH COMMAND TAKEN FROM THE CHAIN FILE AND THEN EXECUTES THE COMMAND. WHEN THE LAST COMMAND OTHER THAN ANOTHER C COMMAND HAS BEEN EXECUTED THE XXDP+ MONITOR TERMINATES CHAIN MODE AND TYPES A PROMPT (.). IT IS READY TO ACCEPT ANOTHER COMMAND FROM THE CONSOLE. IF THE LAST COMMAND IS ANOTHER C COMMAND, THE CHAIN MODE WILL CONTINUE AND THE CHAIN FILE SPECIFIED BY THIS NEW C COMMAND WILL BE USED.

IF THE USER WISHES TO TERMINATE CHAIN MODE BEFORE ITS NORMAL TERMINATION HE MAY DO SO BY TYPING A CONTROL/C. HOWEVER, THE MONITOR WILL NOT ABORT THE CHAIN MODE UNTIL IT RECEIVES PROGRAM CONTROL FROM THE PROGRAM CURRENTLY RUNNING.

2.3 DETAILS OF COMMANDS AND SYNTAX

2.3.1 TABLE OF COMMAND VALIDITY

1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57

THERE ARE FOUR WAYS OF ENTERING DIAGNOSTIC COMMAND MODE, AND DIFFERENT SUBSETS OF THE DIAG COMMAND SET ARE AVAILABLE WITH EACH:

HOW ENTERED	LEGAL COMMANDS
-----	-----
1. OPERATOR ENTERED 'RUN DIAG'	START PRINT DISPLAY FLAGS ZFLAGS EXIT
2. DIAGNOSTIC HAS FINISHED ALL ITS REQUESTED PASSES	START RESTART PRINT DISPLAY FLAGS ZFLAGS EXIT
3. OPERATOR INTERRUPTED THE	START PRINT DISPLAY FLAGS ZFLAGS EXIT
4. AN ERROR WAS ENCOUNTERED WITH THE HOE FLAG SET SET	START RESTART CONTINUE PROCEED PRINT DISPLAY FLAGS ZFLAGS EXIT

2.3.2 COMMAND SYNTAX

\*\*\*\*\*  
STA(RT)/TESTS:TEST-LIST/PASS:PASS-CNT/FLAGS:FLAG-LIST/EOP:EOP-INCR  
\*\*\*\*\*

THE DIAGNOSTIC IN CORE IS EXECUTED IN ACCORDANCE WITH THE SWITCHES SPECIFIED. THE MESSAGE "# UNITS?" IS PRINTED. THE START COMMAND MAY BE ISSUED WHEN DIAGNOSTIC COMMAND MODE HAS BEEN ENTERED VIA ONE OF THE FOLLOWING: A) OPERATOR TYPED "RUN DIAGNOSTIC" B) DIAGNOSTIC FINISHED EXECUTING C) ERROR WAS

1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56

ENCOUNTERED WITH HOE FLAG SET D) OPERATOR ENTERED CONTROL/C. AFTER THE OPERATOR RESPONDS TO "# UNITS?", THE HARDWARE DIALOGUE IS INITIATED. WHEN IT IS COMPLETED, THE QUESTIONS "CHANGE SW?" IS ISSUED, AND THE ANSWERS, IF GIVEN, BECOME THE NEW DEFAULTS. THEREFORE IT IS NECESSARY TO RELOAD THE PROGRAM IN ORDER TO RETURN TO THE LOAD DEFAULTS.

THE SWITCH ARGUMENTS ARE AS FOLLOWS:

"TEST-LIST" IS A SEQUENCE OF DECIMAL NUMBERS (1:2 ETC.) OR RANGES OF DECIMAL NUMBERS (1-5:8-10 ETC.) THAT SPECIFY THE TESTS TO BE EXECUTED. THE NUMBERS ARE SEPARATED BY COLONS. THE NUMBERS RANGE FROM 1 TO THE LARGEST TEST NUMBER IN THE DIAGNOSTIC. THEY MAY BE SPECIFIED IN ANY ORDER. TESTS WILL BE EXECUTED IN NUMERICAL ORDER REGARDLESS OF THE ORDER OF SPECIFICATION. THE DEFAULT IS TO EXECUTE ALL TESTS.

"PASS-CNT" IS A DECIMAL NUMBER INDICATING THE DESIRED NUMBER OF PASSES. A PASS IS DEFINED AS THE EXECUTION OF THE FULL DIAGNOSTIC (ALL SELECTED TESTS) AGAINST ALL UNITS SUBMITTED. THE DEFAULT IS NON-ENDING TEST EXECUTION. "FLAG-LIST" IS A SEQUENCE OF ELEMENTS OF THE FORM <FLAG>, <FLAG=1>, OR <FLAG=0>, SEPARATED BY COLONS, WHERE <FLAG> HAS ONE OF THE FOLLOWING VALUES:

HOE HALT ON ERROR, CAUSING COMMAND MODE TO BE ENTERED WHEN AN ERROR IS ENCOUNTERED

LOE LOOP ON ERROR, CAUSING THE DIAGNOSTIC TO LOOP CONTINUOUSLY WITHIN THE SMALLEST DEFINED BLOCK OF CODING (SEGMENT, SUBTEST, OR TEST) CONTAINING THE ERROR

IER INHIBIT ERROR REPORTING

IBE INHIBIT BASIC ERROR REPORTS

IXE INHIBIT EXTENDED ERROR REPORTS

PRI DIRECT ALL MESSAGES TO A LINE PRINTER

PNT PRINT NUMBER OF TEST BEING EXECUTED

BOE BELL ON ERROR

UAM RUN IN UNATTENDED MODE, BYPASSING MANUAL INTERVENTION TESTS

ISR INHIBIT STATISTICAL REPORTS

IDU INHIBIT DROPPING OF UNITS BY DIAGNOSTIC

ADR EXECUTE AUTODROP CODE

1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56

LOT LOOP ON TEST  
EVL EVALUATE

THE FLAGS NAMED OR EQUATED TO 1 ARE SET, THOSE EQUATED TO 0 ARE CLEARED. A FLAG NOT SPECIFIED IS CLEARED. IF THE FLAGS SWITCH IS NOT GIVEN ALL FLAGS ARE CLEARED.

"EOP-INCR" IS A DECIMAL NUMBER INDICATING HOW OFTEN (IN TERMS OF PASSES) IT IS DESIRED THAT THE END OF PASS MESSAGE BE PRINTED. THE DEFAULT IS AT THE END OF EVERY PASS.

\*\*\*\*\*  
RES(TART)/TEST:TEST-LIST/PASS:PASS-CNT/FLAGS:FLAG-LIST/EOP:EOP-INCR/UNITS:UNIT-LIST  
\*\*\*\*\*

THE DIAGNOSTIC IN CORE IS EXECUTED IN ACCORDANCE WITH THE SWITCHES SPECIFIED. HOWEVER, NEW "P-TABLES" ARE NOT BUILT. INSTEAD, THE ONES IN CORE ARE USED.

THE QUESTION "CHANGE SW?" IS ASKED AND THE ANSWERS GIVEN BECOME THE NEW DEFAULTS. THE COMMAND MAY BE ISSUED WHEN COMAND MODE HAS BEEN ENTERED VIA A) DIAGNOSTIC IS FINISHED B) HALT ON ERROR C) CONTROL/C.

THE SWITCH ARGUMENTS ARE AS IN THE START COMMAND EXCEPT:

1. "UNIT-LIST" IS A SEQUENCE OF LOGICAL UNIT NUMBERS RANGING FROM 1 THRU N (N = NUMBER OF UNITS BEING TESTED) SPECIFYING WHICH UNITS ARE TO BE TESTED. THE LOGICAL UNIT NUMBER DESIGNATES THE POSITION OF THE P-TABLE IN CORE, ACCORDING TO THE ORDER IN WHICH THEY WERE BUILT. THE UNITS SPECIFIED MUST NOT HAVE BEEN DROPPED BY THE OPERATOR DROP COMMAND. THE UNIT-LIST DEFAULTS TO "ALL THAT HAVE NOT BEEN DROPPED BY OPERATOR COMMAND". THE EFFECT OF THE UNIT-LIST LASTS UNTIL THE NEXT START (WHERE IT IS AUTOMATICALLY RESET TO "ALL") OR THE NEXT RESTART.
2. ALL UNSPECIFIED FLAG SETTINGS ARE UNCHANGED.

\*\*\*\*\*  
CON(TINUE)/PASS:<PASS-CNT/FLAGS:<FLAG-LIST>  
\*\*\*\*\*

COMMAND MODE MUST HAVE BEEN ENTERED DUE TO A HALT ON ERROR OR A CONTROL/C. THE EFFECT OF THE COMMAND IS TO GO TO THE BEGINNING OF THE TEST THAT WAS BEING EXECUTED WHEN THE HALT OR CONTROL/C TOOK PLACE. SOFTWARE DIALOGUE MAY OPTIONALLY BE RE-EXECUTED. HARDWARE PARAMETERS MAY NOT BE CHANGED.



1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57

THE SWITCH ARGUMENTS ARE AS IN THE START COMMAND EXCEPT:

- 1. DEFAULT FOR PASS-CNT IS THE UNSATISFIED PASS-CNT FROM THE PREVIOUS START OR RESTART
- 2. UNSPECIFIED FLAG SETTINGS ARE UNCHANGED

\*\*\*\*\*  
PROCEED)/FLAGS:<FLAG-LIST>  
\*\*\*\*\*

COMMAND MODE MUST HAVE BEEN ENTERED VIA A HALT ON ERROR. THE EFFECT OF THE COMMAND IS TO BEGIN EXECUTION AT THE LOCATION FOLLOWING THE ERROR CALL. NEITHER HARDWARE NOR SOFTWARE PARAMETERS MAY BE ALTERED.

THE SWITCH ARGUMENTS ARE THE SAME AS THE START COMMAND EXCEPT:

- 1. UNSPECIFIED FLAG SETTINGS ARE UNCHANGED

\*\*\*\*  
EXIT  
\*\*\*\*

RETURN TO XXDP+ PROMPT MODE.

\*\*\*\*\*  
DRO(P)/UNITS:UNIT-LIST  
\*\*\*\*\*

THE UNITS SPECIFIED ARE DROPPED FROM TESTING UNTIL THEY ARE ADDED BACK OR UNTIL A START COMMAND IS GIVEN. A DROP CANNOT BE FOLLOWED BY A PROCEED.

THERE IS ALSO A "DROP" MACRO INTERNAL TO THE DIAGNOSTIC, WHICH GIVES THE FACILITY OF AUTO-DROPPING. THE DURATION OF A PROGRAM DROP, HOWEVER, IS ONLY UNTIL THE NEXT START OR RESTART.

\*\*\*\*\*  
ADD/UNITS:UNIT-LIST  
\*\*\*\*\*

THE UNITS SPECIFIED ARE ADDED BACK (THEY MUST HAVE BEEN PREVIOUSLY DROPPED BY THE DROP COMMAND) TO THE TEST SEQUENCE. AN ADD CANNOT BE FOLLOWED BY A PROCEED.

\*\*\*\*\*  
PRI(NT)

1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57

\*\*\*\*\*

ALL STATISTICS TABLES ACCUMULATED BY THE DIAGNOSTIC ARE PRINTED. THE ISR (INHIBIT STATISTICAL REPORTING) FLAG IS CLEARED.

\*\*\*\*\*  
DIS(PLOY)/UNITS:<UNIT-LIST>  
\*\*\*\*\*

THE HARDWARE P-TABLES FOR ALL UNITS UNDER TEST ARE PRINTED OUT IN THE FORMAT IN WHICH THEY WERE ENTERED. ANY UNITS THAT WERE DROPPED BY THE OPERATOR "DROP" COMMAND ARE SO DESIGNATED.

\*\*\*\*\*  
FLA(GS)  
\*\*\*\*\*

THE CURRENT SETTINGS OF ALL FLAGS ARE PRINTED.

\*\*\*\*\*  
ZFL(AGS)  
\*\*\*\*\*

ALL FLAGS ARE CLEARED.

2.4 EXTENDED P-TABLE DIALOGUE

-----  
THE FULL CAPABILITY OF THE HARDWARE DIALOGUE IS REVEALED BY THE FOLLOWING DISCUSSION OF WHAT HAPPENS INTERNALLY.

AS SOON AS THE QUESTION "# UNITS?" IS ANSWERED (WITH THE NUMBER N), SPACE IN CORE IS ALLOCATED FOR "N" P-TABLES. ALL OF THE P-TABLES ARE OF THE SAME FORMAT, AND THERE IS A ONE-TO-ONE CORRESPONDENCE BETWEEN THE HARDWARE PARAMETER QUESTIONS AND THE SLOTS IN THE P-TABLE FORMAT.

IN GIVING A STRING OF VALUES, COMMAS WITHOUT INTERVENING VALUES MAY BE USED TO INDICATE A REPETITION OF THE LAST NAMED VALUE.

A STRING OF VALUES MAY BE GIVEN AS A RANGE (6-10 FOR EXAMPLE). IF THE VALUES REPRESENT PURE NUMERICAL DATA, THIS SAMPLE RANGE TRANSLATES TO THE STRING 6,7,8,9,10 (AN INCREMENT OF 1). IF THE VALUES ARE ADDRESSES, THE SAMPLE RANGE TRANSLATES TO THE STRING 6,8,10 (AN INCREMENT OF 2).

NOW LET US SEE HOW WE COULD USE THESE CAPABILITIES TO CONSTRUCT A SET OF P-TABLES. ASSUME THAT WE HAVE 8 RL UNITS, AND THAT THERE ARE FIVE (5) HARDWARE PARAMETERS FOR EACH (5

1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56

SLOTS IN THE P-TABLE, 5 HARDWARE QUESTIONS IN THE DIALOGUE).

FOLLOWING IS THE DIALOGUE FOR THIS 8 RLOX DRIVE SYSTEM. THIS SYSTEM HAS TWO (2) RL11 TYPE CONTROLLERS ALL TO BE SET AT "BR LEVEL" 5. THE FIRST 4 DRIVES ARE RL01'S AND THE LAST 4 DRIVES ARE RL02'S (ON THE SECOND CONTROLLER):

# UNITS (D) ? 8

UNIT 0  
RL11 (L) Y ?  
BUS ADDRESS (0) 174400 ?  
VECTOR (0) 160 ?  
DRIVE (0) 0 ? 0-3  
DRIVE TYPE = RL01 (L) Y ?  
BR LEVEL (0) 5 ?

UNIT 4  
RL11 (L) Y ?  
BUS ADDRESS (0) 174400 ? 175400  
VECTOR (0) 160 ? 164  
DRIVE (0) 0 ? 0-3  
DRIVE TYPE = RL01 (L) Y ? N  
BR LEVEL (0) 5 ?

THE FIRST TIME THRU THE P-TABLE QUESTIONS THE DEFAULT VALUES ARE USED FOR THE CONTROLLER TYPE (QUESTION #1), CSR ADDRESS OF THE CONTROLLER (QUESTION #2), THE CONTROLLER VECTOR ASSIGNMENT (QUESTION #3), THE DRIVE TYPE (QUESTION #5), AND THE "BR LEVEL" (QUESTION #6). THE ACTUAL UNIT NUMBERS OF THE RL01'S FOR QUESTION #4 WAS ASSIGNED 0 THRU 3 FOR THE FIRST 4 P-TABLE SLOTS.

THE SECOND TIME THRU THE P-TABLE QUESTIONS (FOR THE RL02 ASSIGNMENT ON THE SECOND CONTROLLER), THE FIRST QUESTION DEFAULTED TO "RL11" TYPE CONTROLLER. THE SECOND QUESTION WAS ANSWERED TO REFLECT THE CHANGE IN CSR ADDRESS FOR THE RL02 CONTROLLER (175400). THE SECOND CONTROLLER'S VECTOR WAS ALSO CHANGED TO 164 IN QUESTION #3. THE RL02 TEST UNIT NUMBERS WERE ASSIGNED VALUES 0 TO 3 IN QUESTION #4 AND THE DRIVE TYPE WAS SET FOR RL02'S FOR THE REMAINING 4 UNITS IN QUESTION #5. THE LAST QUESTION WAS DEFAULTED USING THE "BR LEVEL" FROM THE FIRST PASS.

2.5            HARDWARE PARAMETERS  
-----

THE FOLLOWING QUESTIONS WILL BE ASKED ON A START COMMAND. THE VALUE LOCATED TO THE LEFT OF THE QUESTION MARK IS THE DEFAULT VALUE THAT WILL BE TAKEN ON A CARRIAGE RETURN RESPONSE.

1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56

RL11 (L) Y?

ANSWER YES(Y) IF YOU HAVE AN RL11 CONTROLLER, NO(N) IF YOU HAVE AN RLV11 CONTROLLER.

BUS ADDRESS (O) 174400?

ANSWER WITH THE BUS ADDRESS OF THE CONTROLLER.

VECTOR (O) 160?

ANSWER WITH THE INTERRUPT VECTOR OF THE CONTROLLER.

DRIVE (O) 0?

ANSWER WITH THE DRIVE(S) CONNECTED TO THE CONTROLLER

DRIVE TYPE = RL01 (L) ?

ANSWER NO (N) IF DRIVE IS AN RL02

BR LEVEL (O) 5?

ANSWER WITH THE INTERRUPT PRIORITY OF THE CONTROLLER.

## 2.6 SOFTWARE PARAMETERS

-----

THE FOLLOWING QUESTIONS ARE ASKED IF REQUESTED ON A START, RESTART, OR CONTINUE. THEY ALLOW FLEXIBILITY IN THE WAY THE PROGRAM BEHAVES. THE SOFTWARE PARAMETERS GIVE THE PROGRAM FLEXIBILITY IN THE WAY IT RUNS. THE PARAMETERS CAN BE MODIFIED ON A START, RESTART, OR CONTINUE BY ANSWERING (Y)ES TO THE FOLLOWING QUESTION:

CHANGE S.W. ?

A YES ANSWER WILL ASK THE FOLLOWING SOFTWARE PARAMETER QUESTIONS, WITH THE PRESENT DEFAULT VALUE PRINTED TO THE LEFT OF THE QUESTION MARK. (THE LAST ANSWER GIVEN IS THE DEFAULT) THE DEFAULT IS TAKEN ON A <CR>. CONTROL Z (+Z) WILL DEFAULT ALL REMAINING QUESTIONS AND START THE TEST.

USE ALL CYLINDERS (N)?

IF "YES", THOSE TESTS THAT NORMALLY USE A SELECTED SET OF CYLINDERS WILL TEST EVERY CYLINDER ON THE CARTRIDGE.

USE ALL SECTORS (N)?

IF "YES", THOSE TESTS THAT NORMALLY USE A SINGLE SECTOR TO TEST A GIVEN OPERATION (SUCH AS SEEK DESTINATION) WILL READ AND VERIFY EVERY SECTOR HEADER.

1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57

## EXECUTE MANUAL INTERVENTION TESTS (N)?

IF "YES", SEEK TIMING, ROTATIONAL TIMING, AND WRITE LOCK ERROR AND DATA PROTECTION TESTS ARE EXECUTED. THE ONLY TEST THAT ACTUALLY REQUIRES MANUAL INTERVENTION IS THE WRITE LOCK TEST AND THAT TEST WILL BYPASS AUTOMATICALLY AFTER WAITING 30 SECONDS FOR WRITE LOCK TO BE SET.

## LOWER SEEK LIMIT (N)?

IF "YES", THE NEXT PARAMETER IS REQUESTED.

## ENTER VALUE (DECIMAL) (0)?

THIS LIMIT IS IMPOSED ON ALL SEEK OPERATIONS SUCH THAT TESTING IS NOT DONE BELOW THAT LIMIT. IN ADDITION, SETTING THIS LIMIT (OR THE UPPER LIMIT, SEE BELOW) CAUSES THE FORWARD AND REVERSE OSCILLATING SEEK TESTS TO PERFORM DIFFERENTLY (SEE TEST DESCRIPTION). TESTS THAT REQUIRE ACCESS TO A SPECIFIC CYLINDER THAT FALLS BELOW THE SPECIFIED LIMIT WILL IGNORE THE LIMIT (SEE WRITE/READ TEST PART 1).

## UPPER SEEK LIMIT (N)?

IF "YES", AN UPPER CYLINDER LIMIT IS IMPOSED IN THE SAME MANNER AS THE LOWER SEEK LIMIT. A "YES" RESPONSE WILL CAUSE THE FOLLOWING PARAMETER REQUEST.

## ENTER VALUE (DECIMAL) (255)?

## USE ONLY ONE SURFACE (N)?

IF "YES", THE NEXT PARAMETER IS REQUESTED.

## SPECIFY SURFACE (0 OR 1) (DECIMAL) (0)?

WHICHEVER SURFACE IS SPECIFIED IS THE ONLY SURFACE TESTED IN THE ENTIRE PROGRAM. ANY TEST THAT IS DESIGNED TO TEST THE OTHER SURFACE IS AUTOMATICALLY BYPASSED. THE PROGRAM DOES NOT PRINT ANY INDICATION THAT A TEST IS BYPASSED IN THIS CASE.

## SPECIFY ERROR LIMIT (DECIMAL) (20)?

THIS PARAMETER SPECIFIES THE MAXIMUM NUMBER OF ERRORS ALLOWED. THIS LIMIT IS ON A PER DRIVE BASIS IN A SINGLE PASS. IF THE ERROR LIMIT IS EXCEEDED, THE DRIVE IS DROPPED FROM FURTHER TESTING.

## DATA COMPARE ERROR LIMIT (DECIMAL) (20)?

THIS PARAMETER SPECIFIES THE NUMBER OF DATA COMPARE ERRORS THAT WILL BE LISTED FOR A GIVEN COMPARE OPERATION. AFTER THE LIMIT IS REACHED, THE DATA ERRORS ARE NOT PRINTED BUT THE COMPARE CONTINUES UNTIL THE END OF THE DATA FIELD. A

1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57

TOTAL IS REPORTED AT THE END OF THE COMPARE.

PRINT ERRORS DETECTED WHILE READING BAD SEC FILE (N)?

IF "YES", ALL ERRORS DETECTED WHILE READING THE BAD SECTOR FILE, WILL BE PRINTED TO THE OUTPUT DEVICE. IF "NO", ONLY HARD ERRORS WILL BE PRINTED TO THE OUTPUT DEVICE. THIS IS USEFUL IF THE USER WISHES TO SEE WHAT ERRORS ARE DETECTED IN ANY BAD COPIES OF THE BAD SECTOR FILES.

3.0 ERROR INFORMATION  
-----

ALL ERRORS ARE PRINTED VIA CONSOLE DEVICE. THE ERROR INCLUDES ERROR NUMBER, TYPE AND PROGRAM LOCATION. ERRORS INCLUDE REGISTERS BEFORE AND AT ERROR WITH RELEVANT DATA.

3.1 ERROR REPORTING  
-----

THE OPERATION MESSAGE (LINE 4) IS GENERATED IN A DYNAMIC MANNER BASED ON THE SUBSYSTEM FUNCTION BEING EXECUTED AT THE TIME OF THE ERROR AND THE STATE OF THE FLAGS IN THE LOCATION TAGGED "OPFLAGS". THE POSSIBLE OPERATION MESSAGES ARE GIVEN BELOW.

SEEK - FROM (CYL NUM) DIFF (CYL DIFF) SGN (0 OR 1) HD (0 OR 1) WHERE THE VALUES ARE GIVEN IN OCTAL. THIS MESSAGE IS THE RESULT OF A SEEK OPERATION THAT WAS VERIFIED BY A READ HEADER AND THE HEAD POSITION AFTER A SEEK IS IN ERROR. (THE ACTUAL HEAD POSITION IN THIS ERROR SITUATION IS GIVEN IN THE RESULT LINE, LINE 5.)

READ DATA - IS A READ DATA OPERATION WHERE SOME FORM OF ERROR WAS DETECTED IN THE ACTUAL READ OPERATION. THIS ERROR COULD BE HARDWARE DETECTED SUCH AS DATA CRC, HEADER CRC, HEADER NOT FOUND, ETC. OR A SOFTWARE DETECTED ERROR SUCH AS DRIVE READY RESET AFTER A READ DATA COMPLETED.

READ DATA WITH DATA COMPARE - IS AN ERROR THAT WAS DETECTED AS BAD DATA IN THE BUFFER AFTER

A READ DATA OPERATION. WHEN THIS OPERATION IS REPORTED IT INDICATES THE ACTUAL READ DATA OPERATION COMPLETED WITH NO DETECTED ERRORS BUT THE DATA WAS WRONG.

READ HEADER - READ HEADER FOR 40 HEADERS - READ HEADER FOR 40 HEADERS WITH HEADER COMPARE - HAVE THE SAME GENERAL MEANING AS THE READ DATA AND READ DATA WITH DATA COMPARE. MESSAGES HAVING THE OPERATION OF READ HEADER OR READ HEADER FOR 40 HEADERS ARE THE RESULT OF ERRORS DETECTED IN THE ACTUAL OPERATION WHILE THE READ HEADER FOR 40 HEADERS WITH HEADER

1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57

COMPARE INDICATES NO ERROR IN THE ACTUAL OPERATION BUT THE HEADER DATA ITSELF WAS IN ERROR.

WRITE DATA - RESET - GET STATUS - GET STATUS WITH RESET - ARE ALL BASIC OPERATIONS. AS BEFORE, THE ERROR DETECTION CAN BE EITHER HARDWARE OR SOFTWARE. THE RESULT LINE (LINE 5) WILL DEFINE THE REASON FOR THE REPORT.

LD DRV - UNLD DRV - ARE OPERATION MESSAGES THAT WILL APPEAR IN THE REPORT WHEN THE DRIVE LOAD AND UNLOAD SEQUENCE IS BEING TESTED.

ANOTHER GROUP OF OPERATION QUALIFIERS WILL BE REPORTED FOR OPERATIONS THAT FAIL IN SPECIFIC TESTS. THESE TESTS ARE THE WRITE/READ TEST PART 2, OVERWRITE TEST, AND THE ADJACENT CYLINDER INTERFERENCE TEST.

OPERATION -----	QUALIFIER -----
READ DATA WITH DATA COMPARE	FOL 0 TO CC SEEK
READ DATA	FOL 255 TO CC SEEK
WRITE DATA	FOL WRITE (NO SEEK)
READ HEADER	ADJ. CYL WRITTEN AFTER FWD SK
	ADJ. CYL WRITTEN AFTER REV SK
	SK FWD, WRT-SK REV, OVERWRT
	SK REV, WRT-SK FWD, OVERWRT

THE ABOVE OPERATIONS CAN BE REPORTED WITH ANY OF THE QUALIFIERS. THE QUALIFIERS IN THESE TESTS ARE AN ATTEMPT TO MAKE THE REPORT MORE MEANINGFUL BY PROVIDING INFORMATION ABOUT THE SEQUENCE OF OPERATIONS BEING DONE.

THE QUALIFIERS "FOL 0 TO CC SEEK" AND "FOL 255 TO CC SEEK" INDICATE THAT THE SEQUENCE OF OPERATIONS INCLUDED A SEEK OF A GIVEN DIRECTION TO THE CYLINDER WHERE THE TEST IS BEING PERFORMED.

THE "FOL WRITE (NO SEEK)" QUALIFIER MEANS THAT THE OPERATION WAS DONE AFTER A WRITE WITH NO HEAD MOVEMENT BETWEEN THE WRITE AND READ.

THE QUALIFIER "ADJ CYL WRITTEN AFTER FWD SK" AND "ADJ CYL WRITTEN AFTER REV SK" WILL BE REPORTED ONLY IN THE ADJACENT CYLINDER INTERFERENCE TEST. THESE QUALIFIERS ARE USED WHEN THE ERROR OCCURS ON THE CYLINDER UNDER TEST AND DEFINE THE DIRECTION THE HEADS WERE MOVED WHEN THE ADJACENT CYLINDER WAS WRITTEN.

THE QUALIFIERS "SK FWD, WRT-SK REV, OVERWRT" AND "SK REV, WRT-SK FWD, OVERWRT" WILL BE REPORTED ONLY IN THE OVERWRITE TEST. THESE QUALIFIERS DEFINE THE DIRECTION OF HEAD MOTION BEFORE THE INITIAL WRITE AND THE OVERWRITE.

1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57

THE QUALIFIER "ON BAD SEC FILES" WILL BE REPORTED WITH THE WRITE DATA COMMAND IF THE PROGRAM ABORTS THAT COMMAND BECAUSE THE WRITE WOULD BE ON THE BAD SECTOR FILES.

3.1.2 SPECIFIC RESULT MESSAGES

THE RESULT MESSAGE (LINE 5) IS GENERATED DYNAMICALLY BASED ON THE EXPECTED RESULT OF THE OPERATION BEING TESTED. SINCE OPERATIONS ARE MONITORED DURING EXECUTION THE RESULT MESSAGE MAY REPORT AN ERROR DETECTED DURING THE OPERATION AS WELL AS THE ERRORS SEEN AT THE END OF THE OPERATION. ONLY THE FIRST ERROR SEEN IS REPORTED IN ALL CASES.

THE GENERAL FORMAT FOR THE RESULT LINE IS:

RESULT:(VAR 1) IS (VAR 2) SB (VAR 3) (OPTIONAL QUALIFIER) WHERE VARIABLE 1 CAN BE ONE OF THE FOLLOWING:

- CONT ERR (CONTROLLER ERROR)
- DRV ERR (DRIVE ERROR)
- NON-EXSTNT MEM (NON-EXISTANT MEMORY)
- HDR CRC (HEADER CRC ERROR)
- DATA CRC (HEADER NOT FOUND)
- HDR NOT FND (HEADER NOT FOUND)
- DATA LATE (ALL 3 BITS SET)
- HDR NOT FND/HDR CRC/OPI (DRIVE READY)
- DRV RDY (DRIVE READY)
- SELECTED HEAD (VOLUME CHECK)
- VOL CHK (VOLUME CHECK)
- COVER OPEN (BRUSH HOME)
- BRUSH HME (BRUSH HOME)
- WRT LCK (WRITE LOCK)
- HDS OUT (HEADER OUT)
- DRV SEL ERR (DRIVE SELECT ERROR)
- DRV STATE (DRIVE STATE)
- SPIN TIMEOUT (SPINDLE TIMEOUT SPD ERROR)
- WRT GAT ERR (WRITE GATE ERROR)
- SEEK TIMEOUT (SKTO ERROR)
- CUR HEAD ERR (CURRENT IN HEAD ERROR)
- WRT DAT ERR (WRITE DATA ERROR)
- OP INCOMPLETE (OPI ERROR)
- HDR/DAT ERR (HDR CRC OR DATA CRC EPROR BIT 11 OF CS REGISTER)
- HDR NOT FND/DAT LATE (HDR NOT FOUND OR DATA LATE ERROR BIT 12 OF CS REGISTER)
- CYL (CYLINDER WHEN REPORTING A SEEK ERROR)

VARIABLE 2 WILL BE A VALUE THAT DEFINES WHAT THE RESULT ACTUALLY IS. THIS CAN BE A 1 OR 0 TO INDICATE A SET OF RESULT



1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57

CONDITIONS, A NUMBER 0 TO 7 TO INDICATE THE DRIVE STATE, OR A NUMBER 0 TO 377 (OCTAL) TO IDENTIFY A CYLINDER NUMBER.

VARIABLE 3 DEFINES THAT THE VALUE GIVEN IS VARIABLE 2 SHOULD BE. THE OPTIONAL QUALIFIER IS PROVIDED WHEN IT IS USEFUL TO KNOW WHEN THE ERROR WAS DETECTED IN THE OPERATION BEING PERFORMED. THIS QUALIFIER IS USED TO REPORT RESULTS SUCH AS:

BRUSH HME IS 1 SB 0 IN STATE 2  
HEADS OUT IS 0 SB 1 IN STATE 3  
DRV RDY IS 0 SB 1 IN DATA XFER  
SELECTED HEAD IS 1 SB 0 IN CYCLE UP  
DRV RDY IS 0 SB 1 IN STATE 5  
DRV RDY IS 1 SB 0 IN SEEK W/O MOTION  
DRV RDY IS 0 SB 1 IN 10MS  
DRV RDY IS 0 SB 1 IN 500MS  
DRV RDY IS 0 SB 1 IN 5SECONDS

THESE RESULTS, WHEN SEEN WITH THE OPERATION MESSAGE, WILL BE SELF EXPLANATORY.

OTHER RESULT MESSAGES THAT CAN BE PART OF AN ERROR REPORT ARE:

"INTERRUPT TOO LATE"

WHICH INDICATES THAT THE OPERATION BEING PERFORMED DID NOT COMPLETE IN THE EXPECTED AMOUNT OF TIME. THIS RESULT CAN BE CAUSED BY THE DRIVE LOSING READY BEFORE STARTING A READ HEADER AND THEREFORE NOT COMPLETING THE READ HEADER IN 1MS.

"FAIL TO RELOAD HEADS AFTER ERR CLEAR"

THIS IS REPORTED WHEN AN ERROR CAUSES HEADS TO UNLOAD AND AFTER THE ERROR IS CLEARED THE HEADS DO NOT RELOAD.

"UNKN DRV STATE-NO RDY, NO ERR, HDS OUT"

THIS IS REPORTED WHEN THE PROGRAM CANNOT DETERMINE THE DRIVE STATE OR STATUS.

"WRITE ABORTED"

THIS IS REPORTED WHEN THE PROGRAM ABORTS A WRITE TO PROTECT THE BAD SECTOR FILES.

"COULD NOT RETRIEVE DRIVE STATUS"

THIS IS REPORTED IF THE GET STATUS COMMAND DOES NOT COMPLETE SUCCESSFULLY WHEN THE STATUS IS REQUIRED TO REPORT AN ERROR.

"OPI SET-NO DRIVE RESPONSE"

THIS IS REPORTED AS THE RESULT WHEN THE GET STATUS COMMAND IS TIMED OUT (OPI SETS) WHEN THAT COMMAND IS BEING USED IN THE

1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57

EARLY TESTS TO CHECK THE DRIVE INTERFACE.

"NO INTERRUPT ON CMND COMPLETE"

THIS IS REPORTED WHEN THE COMMAND SUCCESSFULLY COMPLETES BUT THE CONTROLLER HAS NOT GENERATED AN INTERRUPT.

"ERR DID NOT CLEAR"

THIS IS REPORTED WHEN THE RESET COMMAND DOES NOT CLEAR THE CONTROLLER ERRORS. THIS IS A CONTROLLER RELATED PROBLEM BUT IS REPORTED IF SEEN IN THE DRIVE TEST PROGRAMS.

"DRV ERR IS NOT CLEARED"

THIS IS REPORTED WHEN THE GET STATUS W/RESET COMMAND DOES NOT CLEAR ALL DRIVE ERRORS.

"UNEXPECTED ERR"

THIS IS REPORTED WHEN THE CONTROLLER SENSES AN ERROR BUT NO ERROR BITS ARE SET.

"BAD SEC FILE FMT ERR"

THIS IS REPORTED IF THE CONTENTS OF THE FILES DO NOT CORRESPOND TO THE EXPECTED FORMAT. (REFER TO DEC STANDARD 144 FOR FORMAT SPECIFICS.)

3.1.3 OTHER MESSAGES  
-----

OTHER INFORMATION IS REPORTED UNDER VARIOUS CIRCUMSTANCES. THESE ARE:

"\*WARNING\* ALL SECTORS ASSUMED GOOD FOR TESTS REQUIRING BAD SEC DATA"

THIS MESSAGE IS PRINTED WHEN THE BAD SECTOR FILES COULD NOT BE READ OR IF DATA READ IS CORRUPT. THIS WARNING IS TO PRINTED TO LET THE USER KNOW THAT ANY ERRORS COULD BE A RESULT OF TESTING A KNOWN BAD SECTOR.

"ERROR LIMIT EXCEEDED-UNIT DROPPED"

THIS IS REPORTED (WITH THE UNIT NUMBER) WHEN MORE THAN THE SPECIFIED NUMBER OF ERRORS (DEFAULT 20) HAVE OCCURED IN ANY SINGLE PASS.

MOST ERROR REPORTS HAVE THE FOLLOWING FORMAT.

- (1) PROG NAME ERR NUM TEST NUM SUBTEST NUM ERR PC
- (2) ROUTINE TRACE SEQ (IN SEQ CALLED)  
(ADDRESS)

1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57

(ADDRESS)

(ADDRESS)

- (3) TEST DESCRIPTION
- (4) OPERATION:
- (5) RESULT:
- (6) ADDRESS OF UNIT UNDER TEST
- (7) RLCS RLDA RLBA RLMP CYL HD
- (8) OP INIT
- (9) OP DONE
- (10) DRIVE STATUS
- (11) WORD NUM IS (XXXXXX) SB (YYYYYY)
- (12) TOTAL COMPARE ERR'S: (ZZZ) OF (128)

THE ONLY EXCEPTION TO THE ABOVE FORMAT IS PURE DATA COMPARE ERRORS (NOT DETECTED BY READ ERROR). THEN THE FORMAT DOES NOT INCLUDE LINES 5 THROUGH 10.

LINE 1 IS THE ERROR HEADER AND IS PROVIDED BY THE SUPERVISOR. THE PROGRAM IS IDENTIFIED BY NAME WITH THE NUMBER OF TEST AND SUBTEST PRESENTLY BEING EXECUTED.

THE SUBTEST NUMBER IS UNIQUE IN THIS PROGRAM IN THAT IT DOES NOT REFER TO A PHYSICAL SUBTEST WITHIN A GIVEN TEST. RATHER IT REFLECTS THE NUMBER OF TIMES A SUBTEST HAS BEEN EXECUTED WITHIN A TEST. CONSEQUENTLY, ON A TEST THAT TESTS AN INCREMENTAL TYPE OF OPERATION (SUCH A INCREMENTAL SEEKS, READ ALL HEADERS FROM BOTH SURFACES, ETC.) THE SUBTEST WILL BE DESCRIPTIVE OF WHERE IN THE TEST THE ERROR OCCURRED.

THE ERROR PC IS THE PHYSICAL MEMORY LOCATION WHERE THE ERROR REPORT WAS INITIATED. SINCE MANY FUNCTIONS ARE SUBROUTINED, AND ERRORS ARE REPORTED FROM SUBROUTINES, THE ERROR PC IS NOT SUFFICIENT TO IDENTIFY THE LOCATION OF THE ERROR CALL AND THE ROUTINE TRACE SEQUENCE IS PROVIDED.

LINE 2 IS THE ROUTINE TRACE SEQUENCE. IF THE ERROR CALL IS INITIATED FROM WITHIN THE TEST (AS OPPOSED TO WITHIN A ROUTINE), THIS PORTION OF THE REPORT IS OMITTED. IF THE CALL IS INITIATED FROM A ROUTINE (WHICH MAY BE CALLED BY ANOTHER ROUTINE, WHICH MAY BE CALLED BY ANOTHER ROUTINE, ETC. SEVERAL LEVELS DEEP) THE ROUTINE TRACE SEQUENCE PROVIDES A TRAIL TO THE ACTUAL LOCATION WITHIN THE TEST THAT CALLED THE FIRST ROUTINE. THE FIRST ENTRY LISTED IS THE LOCATION WHERE THE FIRST ROUTINE WAS CALLED.

LINE 3 IS THE TEST DESCRIPTION AND IS ROUGHLY IDENTICAL TO THE NAME OF THE TEST BEING PERFORMED.

LINE 4 IDENTIFIES THE ACTUAL HARDWARE FUNCTION THAT IS BEING PERFORMED. ADDITIONAL INFORMATION ON THIS LINE IS DESCRIPTIVE OF SPECIFIC USE OF THE FUNCTION. FOR EXAMPLE, THE OPERATION LINE WILL READ "READ HEADERS FOR 40 HEADERS" WHEN ALL HEADERS

1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57

ARE BEING READ FROM A TRACK.

LINE 5 IDENTIFIES THE ERROR THAT HAS BEEN DETECTED. THE CONTENT OF LINE 5 IDENTIFIES WHAT WAS BEING TESTED (SUCH AS DRIVE READY, CONTROLLER ERROR, DRIVE STATE, ETC.), WHAT IT IS AND WHAT IT SHOULD BE. LINE 5 MAY BE REPEATED IF MORE THAN ONE TESTED ITEM IS FOUND IN ERROR.

IN ADDITION LINE 5 WILL REPORT ANY HARDWARE DETECTED ERRORS SUCH AS OPERATION INCOMPLETE, HEADER CRC, ETC. IN THIS CASE THE FIRST LINE PRINTED AS RESULT WILL BE DETERMINED BY THE THREE ERROR BITS OPI, HNF/DLT, AND HCRC/DCRC. THE LINE WILL BE DETERMINED AS IN THE FOLLOWING TRUTH TABLE:

HNF/DLT	DCRC/HCRC	OPI	MESSAGE
1	1	1	HDR NOT FND/HDR CRC/OPI ERROR
0	1	1	HDR CRC ERROR
1	0	1	HDR NOT FND ERROR
0	1	0	DATA CRC ERROR
1	0	0	DATA LATE ERROR

LINE 6 IDENTIFIES THE PHYSICAL ADDRESS OF THE UNIT UNDER TEST. THIS ADDRESS IS BY UNIBUS ADDRESS OF THE CONTROLLER AND DRIVE NUMBER.

LINE 7 NAMES THE CONTROLLER REGISTERS (AND CYLINDER AND HEAD WHERE THESE ARE APPLICABLE IN THE REPORT) TO BE REPORTED.

LINE 8 PROVIDES THE CONTENTES OF CONTROLLER REGISTERS WHEN THE OPERATION WAS INITIATED.

LINE 9 PROVIDES THE CONTENTS OF THE CONTROLLER REGISTERS WHEN THE ERROR BEING REPORTED WAS DETECTED. FREQUENTLY THE REGISTER CONTENTS OF OP INIT AND OP DONE WILL BE DIFFERENT. OP INIT MAY INDICATE A SEEK WAS BEING PERFORMED BUT OP DONE MAY INDICATE THE ERROR WAS DETECTED BY A READ HEADER. THE REASON IS THAT A SEEK WAS EXECUTED AND DID NOT PROPERLY POSITION HEADS AND WHEN THE READ HEADER WAS DONE THE HEADS WERE ON THE WRONG CYLINDER.

LINE 10 IS THE DRIVE STATUS. THIS LINE IS ONLY REPORTED IF THE RLMP REGISTER DOES NOT CONTAIN THE ACTUAL DRIVE STATUS.

LINE 11 AND LINE 12 ARE REPORTED IF THE ERROR WAS DETECTED AS A COMPARE OPERATION, EITHER DATA OR HEADERS. IN ADDITION, GOOD AND BAD DATA IS REPORTED FOR ALL READ ERRORS.

3.2 ERROR HALTS

ERROR HALTS ARE SUPPORTED PER DESCRIBED IN THE PREVIOUS SECTION WITH /FLAG:HOE. THERE ARE NO OTHER HALTS.

1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57

4.0 PERFORMANCE AND PROGRESS REPORTS  
-----

4.1 PERFORMANCE REPORTS  
-----

THIS PROGRAM WILL NOT GIVE ANY PERFORMANCE REPORTS.

4.2 PROGRESS REPORTS  
-----

THIS PROGRAM WILL NOT GIVE ANY PROGRESS REPORTS.

5.0 DEVICE INFORMATION TABLES  
-----

THE RL11/RLV11 CONTROLLER HAS THE FOLLOWING FOUR(4) REGISTERS FOR CONTROL OF THE SUBSYSTEM.

RLCS - CONTROL AND STATUS REGISTER (XXXXX0)  
-----

- BIT 15 - COMPOSITE ERROR
- BIT 14 - DRIVE ERROR
- BIT 13 - NON EXISTENT MEMORY ERROR
- BIT 12 - HEADER NOT FOUND (WITH BIT 10 SET)  
          - DATA LATE (WITH BIT 10 CLEAR)
- BIT 11 - HEADER CRC (WITH BIT 10 SET)  
          - DATA CRC (WITH BIT 10 CLEAR)
- BIT 10 - OPERATION INCOMPLETE
- BIT 9/8 - DRIVE SELECT (0-3)
- BIT 7 - CONTROLLER READY
- BIT 6 - INTERRUPT ENABLE
- BIT 5 - EXTENDED BUS ADDRESS (BIT 17)
- BIT 4 - EXTENDED BUS ADDRESS (BIT 16)
- BIT 3-1 - FUNCTION CODE
  - 0 - NOP (PDP-11) MAINT (LSI-11)
  - 1 - WRITE CHECK
  - 2 - GET DRIVE STATUS
  - 3 - SEEK
  - 4 - READ HEADER
  - 5 - WRITE DATA
  - 6 - READ DATA
  - 7 - READ WITHOUT HEADER COMPARE

BIT 0 - DRIVE READY

RLBA - BUS ADDRESS REGISTER (XXXXX2)  
-----

1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57

BITS 15-1 BUS ADDRESS OF DATA TRANSFER  
BIT 0 SHOULD BE 0

RLDA - DISK ADDRESS REGISTER (XXXXX4)  
-----

FOR READ/WRITE FUNCTIONS  
-----

BIT 15-7 - CYLINDER ADDRESS FOR TRANSFER  
BIT 6 - SURFACE FOR TRANSFER  
BIT 5-0 - SECTOR FOR TRANSFER (1-40.)

FOR SEEK FUNCTION  
-----

BIT 15-7 - DIFFERENCE TO NEW CYLINDER  
BIT 6-5 - MUST BE ZERO (0)  
BIT 4 - SURFACE (0=UPPER, 1=LOWER)  
BIT 3 - MUST BE ZERO (0)  
BIT 2 - SEEK DIRECTION( 1=IN / 0=OUT )  
BIT 1 - MUST BE ZERO (0)  
BIT 0 - MUST BE ONE (1)

FOR GET STATUS FUNCTION  
-----

BIT 15-4 - IGNORED SHOULD BE ZERO (0)  
BIT 3 - DRIVE RESET  
BIT 2 - MUST BE ZERO (0)  
BIT 1 - MUST BE ONE (1)  
BIT 0 - MUST BE ONE (1)

RLMP - MULTIPURPOSE REGISTER  
-----

FOR READ/WRITE FUNCTION  
-----

BIT 15 - 0 - WORD COUNT (TWO'S COMPLIMENT)

FOR READ HEADER FUNCTION  
-----

BIT 15-0 - DISK HEADER OF SECTOR (FIRST READ)  
- ZERO WORD (SECOND READ)  
- HEADER CRC (THIRD READ)

FOR GET STATUS FUNCTION  
-----

HAS DRIVE STATUS

BIT 15 - WRITE DATA ERROR

1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57

- BIT 14 - CURRENT HEAD ERROR (CHE)
- BIT 13 - WRITE LOCK STATUS (WL)
- BIT 12 - SEEK TIME OUT (SKTO)
- BIT 11 - SPIN ERROR (SPE)
- BIT 10 - WRITE GATE ERROR (WGE)
- BIT 9 - VOLUME CHECK (VC)
- BIT 8 - DRIVE SELECT ERROR (DSE)
- BIT 7 - DRIVE TYPE IS RL02 IF SET
- BIT 6 - SURFACE (0=UPPPER, 1=LOWER)
- BIT 5 - COVER OPEN
- BIT 4 - HEADS HOME
- BIT 3 - BRUSHES HOME
- BIT 2-0 - STATE BITS
  - 0 - LOAD STATE
  - 1 - SPIN UP
  - 2 - BRUSH CYCLE
  - 3 - LOAD HEADS
  - 4 - SEEK - TRACK COUNTING
  - 5 - SEEK - LINEAR MODE
  - 6 - UNLOAD HEADS
  - 7 - SPIN DOWN

6.0 TEST SUMMARIES

TEST 1 SEEK TIMING  
\*\*\*\*\*

(P-CLOCK IS REQUIRED TO PERFORM THIS TEST.)

POSITION HEADS AT CYLINDER 0.

DO 64 SEEKS FROM 0 TO 1 AND 1 TO 0, MEASURING THE SEEK TIME FOR EACH SEEK. AVERAGE THE SEEK TIMES (FORWARD AND REVERSE INDEPENDENTLY) AND REPORT.

REPEAT ABOVE SEEKING BETWEEN CYLINDER 127 TO 128 AND 254 TO 255 FOR RL01 AND 255 TO 256 AND 256 TO 511 FOR RL02.

REPEAT ABOVE SEEKING BETWEEN CYLINDER 0 TO 127 AND 128 TO 256 FOR RL01 AND CYLINDER 0 TO 256 AND 256 TO 511 FOR RL02.

REPEAT ABOVE SEEKING BETWEEN CYLINDER 0 AND 255 FOR RL01 AND 0 TO 511 FOR RL02.

THE SEEK TIMES WILL BE REPORTED AS SHOWN BELOW. THE TIME MEASURED IS FROM START OF SEEK COMMAND UNTIL INTERRUPT IS RECEIVED.

	INNER	MIDDLE	OUTER	MAX TIME
1 CYL FWD	X	X	X	X
1 CYL REV	X	X	X	X

1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57

MID CYL FWD	X		X	X
MID CYL REV	X		X	X
MAX CYL FWD		X		X
MAX CYL REV		X		X

THE X INDICATES WHERE TIME WILL BE REPORTED.

TEST 2 BASIC READ DATA TEST

\*\*\*\*\*

POSITION HEADS AT MAX CYLINDER (BAD SEC FILE).

DO READ DATA ON 1ST COPY OF THE FACTORY BAD SEC FILE (SECTORS 0 & 1, HEAD 1). IF AN ERROR IS DETECTED, PROCEED BY READING THE NEXT COPY OF THE FACTORY BAD SEC FILE UNTIL A GOOD COPY IS FOUND (SECTORS 4 & 5, 8 & 9, 12 & 13, 16 & 17). REPORT ALL ERRORS IF BAD SEC FILE ERROR REPORTING IS ON (SEE SW QUESTIONS), BUT DO NOT INCREMENT ERROR COUNT. IF NO GOOD COPIES CAN BE FOUND, REPORT THAT FACTORY BAD SECTOR FILE CANNOT BE READ, INCREMENT ERROR COUNT AND PROCEED WITH READING FIELD BAD SEC FILE AT SECTOR 20.

DO READ DATA ON 1ST COPY OF THE FIELD BAD SEC FILE (SECTORS 20 & 21, HEAD 1). IF AN ERROR IS DETECTED, PROCEED BY READING THE NEXT COPY OF THE FIELD BAD SEC FILE UNTIL A GOOD COPY IS FOUND (SECTORS 24 & 25, 28 & 29, 32 & 33, 36 & 37). REPORT ALL ERRORS IF BAD SEC FILE ERROR REPORTING IS ON (SEE SW QUESTIONS), BUT DO NOT INCREMENT ERROR COUNT. IF NO GOOD COPIES CAN BE FOUND, REPORT THAT FIELD BAD SECTOR FILE CANNOT BE READ, INCREMENT ERROR COUNT AND EXIT.

UPON FINDING A GOOD COPY OF THE BAD SEC FILE, VERIFY DATA FORMAT (WORD 0 & 1 ARE NOT 0 & NOT NEGATIVE, WORD 2 & 3 ARE 0, WORD 254 & 255 ARE ALL ONE'S, LOCATE 1ST WORD OF ALL ONE'S & MAKE SURE THAT ALL REMAIN WORDS TO WORD 255 ARE ALL 1'S) STORE BAD SECTOR DATA.

NOTE: IF HEAD 1 IS DESELECTED VIA THE SW QUESTIONS, THIS TEST WILL BE BYPASSED AND A MESSAGE PRINTED TO THAT EFFECT.

TEST 3 WRITE/READ DATA TEST (PART 1)

\*\*\*\*\*

READ THE BAD SECTOR FILE IF NCT ALREADY READ.

POSITION HEADS AT CYLINDER 0.

WRITE PATTERN 1 ON HEAD 0, SECTOR 0. CHECK FOR ANY ERROR.

READ HEAD 0, SECTOR 0. CHECK FOR CRC ERROR. COMPARE DATA.

REPEAT FOR OTHER DATA PATTERNS (2 THROUGH 8).



CHECK IF CYLINDER 0, TRACK 1, SECTOR 0 IS LISTED IN BAD SECTOR DATA. IF NOT, REPEAT ABOVE TEST AT CYLINDER 0, TRACK 1, SECTOR 0. IF IT IS LISTED AS BAD, LOCATE FIRST SECTOR 0, TRACK 1 THAT IS GOOD AND DO ABOVE TESTS.

NOTE: CYLINDER LIMITS ARE IGNORED, TESTING IS DONE AT CYLINDER 0. HOWEVER, CHOOSING A SINGLE SURFACE WILL LIMIT TESTING TO THAT SURFACE.

TEST 4 ROTATIONAL TIMING TEST

\*\*\*\*\*

(P-CLOCK IS REQUIRED TO PERFORM THIS TEST.)

POSITION HEADS TO CYLINDER 0.

DO WRITE DATA TO CYLINDER 0, HEAD 0, SECTOR 0. WAIT FOR INTERRUPT.

DO WRITE DATA TO CYLINDER 0, HEAD 0, SECTOR 0. START TIMING. WHEN INTERRUPT OCCURS, STOP TIMING. RESULT IS SPINDLE ROTATION TIME.

REPEAT TEST 64 TIMES. REPORT THE AVERAGE AS SPINDLE ROTATION TIME. THE TIME REPORTED IS IN 100'S OR MICROSECONDS.

TEST 5 WRITE/READ TEST (PART 2)

\*\*\*\*\*

READ THE BAD SECTOR FILE IF NOT ALREADY READ.

CC IS CURRENT CYLINDER SELECTED FROM SET.  
LET SELECTED CYLINDER SET BE AS DEFINED IN PARAGRAPH 4.3.

SEEK FORWARD TO CC. WRITE PATTERNS 1 THROUGH 8 REPEATED 5 TIMES ON HEAD 0. READ/COMPARE ALL DATA.

SEEK REVERSE TO "LOLIMIT". SEEK FORWARD TO CC. READ/COMPARE ALL DATA. SEEK FORWARD TO "HILIMIT". SEEK REVERSE TO CC. READ/COMPARE ALL DATA. REWRITE DATA PATTERNS 1 THROUGH 8 REPEATED 5 TIMES ON HEAD 0. READ COMPARE ALL DATA.

SEEK FORWARD TO "HILIMIT". SEEK REVERSE TO CC. READ/COMPARE ALL DATA. SEEK REVERSE TO "LOLIMIT". SEEK FORWARD TO CC.

READ/COMPARE ALL DATA.

REPEAT ABOVE TEST FOR HEAD 1.

REPEAT ABOVE TESTS FOR ALL CYLINDERS IN SELECTED CYLINDER SET.

NOTE 1: IF ANY OF THE SECTORS IN THE SELECTED CYLINDER SET ARE LISTED AS BAD, THAT SECTOR WILL BE BYPASSED.

1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57

1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57

NOTE 2: IF THE "USE ALL CYLINDERS" PARAMETER IS SPECIFIED AS "Y", THE TEST WILL INCLUDE ALL CYLINDERS IN THE SELECTED PARAMETER SET.

NOTE 3: IN THE FIRST PASS OF THE PROGRAM THIS TEST IS EXECUTED ON ONLY 6 OF THE CYLINDERS LISTED IN THE CYLINDER SET. THOSE USED WILL BE EVERY 8TH ENTRY IN THE TABLE. ON THE SECOND AND SUBSEQUENT PASSES ALL ENTRIES IN THE SELECTED CYLINDER SET ARE USED.

NOTE 4: TESTING WILL BE DONE BETWEEN UPPER AND LOWER LIMITS. CYLINDERS IN THE CYLINDER SET BEYOND THESE LIMITS WILL NOT BE TESTED. CHOOSING A SINGLE SURFACE WILL LIMIT TESTING TO THAT SURFACE.

TEST 6 WRITE LOCK ERROR AND DATA PROTECTION TEST  
\*\*\*\*\*

DO WRITE DATA PATTERN 0 AT SECTOR 0. READ DATA AND VERIFY.

ASK OPERATOR TO WRITE LOCK DRIVE. DO GET STATUS LOOP UNTIL WRITE LOCK IS SET. IF NOT SET IN 30 SECONDS, ABORT THE TEST.

WHEN WRITE LOCK IS SET, DO WRITE DATA PATTERN 1 AT SECTOR 0. REPORT FAILURE IF DRIVE ERROR DOES NOT SET OR IF ANY OTHER ERROR SETS. CLEAR ERROR AND READ DATA AT SECTOR 0. CHECK THAT DATA HAS NOT BEEN DISTURBED.

REQUEST OPERATOR TO RESET WRITE LOCK. DO GET STATUS LOOP UNTIL WRITE LOCK IS RESET. IF NOT RESET IN 30 SECONDS, REPEAT THE REQUEST.

NOTE: THIS TEST IS EXECUTED ONLY IF THE PROGRAM OPERATION MODE 2 IS SELECTED, MANUAL INTERVENTION TESTING IS REQUESTED, AND IS RUN IN FIRST PASS ONLY.

TEST 7 ADJACENT CYLINDER INTERFERENCE TEST  
\*\*\*\*\*

READ THE BAD SECTOR FILE IF NOT ALREADY READ.

CC IS CURRENT CYLINDER SELECTED FROM SET  
LET SELECTED CYLINDER SET BE AS DEFINED IN PARAGRAPH 4.3.  
DATA PATTERN IS 155555.

SEEK FORWARD TO CYLINDER CC. WRITE PATTERN ON TRACK 0, ALL SECTORS. READ/COMPARE DATA.

SEEK FORWARD TO "HILIMIT". SEEK REVERSE TO CC-1. WRITE PATTERN. SEEK FORWARD TO "HILIMIT". SEEK REVERSE TO CC. WRITE PATTERN. (THIS HAS BRACKETED ORIGINAL WRITE WITH WRITES IN ADJACENT CYLINDERS. NOTE ADJACENT CYLINDERS WERE WRITTEN AFTER HEADS CAME ON CYLINDER IN REVERSE DIRECTION WHICH IS

1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57

OPPOSITE OF CENTER CYLINDER.)

SEEK REVERSE TO "LOLIMIT". SEEK FORWARD TO CC. READ/COMPARE DATA FROM ALL SECTORS. ANY ERRORS (READ OR COMPARE) ARE ATTRIBUTED TO ADJACENT CYLINDER INTERFERENCE.

SEEK FORWARD TO "HILIMIT". SEEK REVERSE TO CC. WRITE DATA PATTERN. SEEK REVERSE TO "LOLIMIT". SEEK FORWARD TO CC-1. WRITE PATTERN. SEEK REVERSE TO "LOLIMIT". SEEK FORWARD TO CC+1. WRITE PATTERN. SEEK FORWARD TO "HILIMIT". SEEK REVERSE TO CC. READ/COMPARE DATA IN ALL SECTORS. ANY ERRORS (READ OR COMPARE) ARE ATTRIBUTED TO ADJACENT CYLINDER INTERFERENCE.

REPEAT ABOVE TESTS ON HEAD 1.

NOTE 1: IF ANY SECTOR ON A SELECTED CYLINDER IS LISTED BAD, THAT SECTOR WILL BE BYPASSED.

NOTE 2: IF THE "USE ALL CYLINDERS" PARAMETER IS SPECIFIED AS "Y", THE TEST WILL INCLUDE ALL CYLINDERS (EXCEPT 0 AND MAX CYL) IN THE SELECTED PARAMETER SET.

NOTE 3: IN THE FIRST PASS OF THE PROGRAM THIS TEST IS EXECUTED ON ONLY 3 OF THE CYLINDERS LISTED IN THE CYLINDER SET. THOSE USED WILL BE THE FIRST, TWENTYFIRST, AND FORTYFIRST ENTRIES IN THE TABLE. ON SECOND AND SUBSEQUENT PASSES EVERY FOURTH CYLINDER SET ENTRY WILL BE TESTED.

NOTE 4: TESTING WILL BE DONE BETWEEN UPPER AND LOWER LIMITS. CYLINDERS IN THE CYLINDER SET BEYOND THESE LIMITS WILL NOT BE TESTED. CHOOSING A SINGLE SURFACE WILL LIMIT TESTING TO THAT SURFACE.

TEST 8 OVERWRITE TEST  
\*\*\*\*\*

READ THE BAD SECTOR FILE IF NOT ALREADY READ.

CC IS CURRENT CYLINDER SELECTED FROM SET  
SELECTED CYLINDER SET DEFINED IN PARAGRAPH 4.3.  
PATTERN A = 125252  
PATTERN B = 000000

SEEK FORWARD TO CC. WRITE DATA OF PATTERN A IN ALL SECTORS, HEAD 0. READ/COMPARE DATA.

SEEK FORWARD TO "HILIMIT", SEEK REVERSE TO CC. WRITE PATTERN B. SEEK REVERSE TO "LOLIMIT", SEEK FORWARD TO CC, READ/COMPARE DATA.

SEEK FORWARD TO "HILIMIT", SEEK REVERSE TO CC. WRITE DATA PATTERN A. READ/COMPARE DATA. SEEK REVERSE TO "LOLIMIT",

1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30

SEEK FORWARD TO CC. WRITE PATTERN B. SEEK FORWARD TO "HILIMIT" SEEK REVERSE TO CC. READ/COMPARE DATA.

ANY FAILURES (READ OR COMPARE) ARE ATTRIBUTED TO OVERWRITE PROBLEM.

REPEAT ABOVE TESTS ON HEAD 1.

NOTE 1: IF ANY SECTOR ON A SELECTED CYLINDER IS LISTED AS BAD, THAT SECTOR WILL BE BYPASSED.

NOTE 2: IF THE "USE ALL CYLINDERS" PARAMETER IS SPECIFIED AS "Y" THE TEST WILL INCLUDE ALL CYLINDERS IN THE SELECTED PARAMETER SET.

NOTE 3: IN THE FIRST PASS OF THE PROGRAM THIS TEST IS EXECUTED ON ONLY 3 OF THE CYLINDERS LISTED IN THE CYLINDER SET. THOSE USED WILL BE THE FIRST, TWENTYFIRST, AND FORTYFIRST ENTRIES IN THE TABLE. ON SECOND AND SUBSEQUENT PASSES EVERY FOURTH CYLINDER SET ENTRY WILL BE TESTED.

NOTE 4: TESTING WILL BE DONE BETWEEN UPPER AND LOWER LIMITS. CYLINDERS IN THE CYLINDER SET BEYOND THESE LIMITS WILL NOT BE TESTED. CHOOSING A SINGLE SURFACE WILL LIMIT TESTING TO THAT SURFACE.

@

K3

4		000001		PART2==1
5	000000		.ENABL	LC,AMA,ABS
6			.NLIST	MC,BEX,TOC
7		002000		.=2000
8				.MCALL SVC
9				
11		000000		SVCTST=0
12		000000		SVCSUB=0
13		000001		SVCBGL=1
14		000000		SVCINS=0
15		000000		SVCTAG=0



1  
2  
4  
6  
8  
10  
11  
12

.NLIST CND,MD,ME

002000	103			.ASCII	/C/
002001	132			.ASCII	/Z/
002002	122			.ASCII	/R/
002003	114			.ASCII	/L/
002004	116			.ASCII	/N/
002005	000			.BYTE	0
002006	000			.BYTE	0
002007	000			.BYTE	0
002010	103			.ASCII	/C/
002011	060			.ASCII	/O/
002012	000000			.WORD	0
002014	030000			.WORD	30000
002016	037352			.WORD	L\$HARD
002020	037526			.WORD	L\$SOFT
002022	014462			.WORD	L\$HW
002024	014500			.WORD	L\$SW
002026	040220			.WORD	L\$LAST
002030	000000			.WORD	0
002032	000000			.WORD	0
002034	000000			.WORD	0
002036	000000			.WORD	0
002040	014520			.WORD	L\$DISPATCH
002042	000000			.WORD	0
002044	000000			.WORD	0
002046	000000			.WORD	0
002050	004			.BYTE	C\$REVISION
002051	001			.BYTE	C\$EDIT
002052	000000			.WORD	0
002054	000000			.WORD	0
002056	000000			.WORD	0
002060	002214			.WORD	L\$DVTYP
002062	000000			.WORD	0
002064	000000			.WORD	0
002066	000000			.WORD	0
002070	000000			.WORD	0
002072	016204			.WORD	L\$DU
002074	000000			.WORD	0
002076	002122			.WORD	L\$DESC
002100	104035			EMT	E\$LOAD
002102	000000			.WORD	0
002104	014540			.WORD	L\$INIT
002106	016056			.WORD	L\$CLEAN
002110	015520			.WORD	L\$AUTO
002112	014452			.WORD	L\$PROT
002114	000000			.WORD	0
002116	000000			.WORD	0
002120	000000			.WORD	0
8 002122	103	132	122	.ASCIZ	/CZRLN TESTS SEEK, ROTATIONAL TIMING AND WRITE & READ DATA/
9 002214	122	114	060	.ASCIZ	%RL01,RL02%
				.EVEN	

.SBTTL GLOBAL EQUATE SECTION

14  
 15

```

; BIT DIFINITIONS
100000 BIT15== 100000
040000 BIT14== 40000
020000 BIT13== 20000
010000 BIT12== 10000
004000 BIT11== 4000
002000 BIT10== 2000
001000 BIT09== 1000
000400 BIT08== 400
000200 BIT07== 200
000100 BIT06== 100
000040 BIT05== 40
000020 BIT04== 20
000010 BIT03== 10
000004 BIT02== 4
000002 BIT01== 2
000001 BIT00== 1

;
001000 BIT9== BIT09
000400 BIT8== BIT08
000200 BIT7== BIT07
000100 BIT6== BIT06
000040 BIT5== BIT05
000020 BIT4== BIT04
000010 BIT3== BIT03
000004 BIT2== BIT02
000002 BIT1== BIT01
000001 BIT0== BIT00

; EVENT FLAG DEFINITIONS
; EF32:EF17 RESERVED FOR SUPERVISOR TO PROGRAM COMMUNICATION
;
000040 EF.START== 32. ; BIT POSITION IN SECOND STATUS WORD
000037 EF.RESTART== 31. ; (100000) START COMMAND WAS ISSUED
000036 EF.CONTINUE== 30. ; (040000) RESTART COMMAND WAS ISSUED
000035 EF.NEW== 29. ; (020000) CONTINUE COMMAND WAS ISSUED
000034 EF.PWR== 28. ; (010000) A NEW PASS HAS BEEN STARTED
000033 EF.XM== 27. ; (004000) A POWER-FAIL/POWER-UP OCCURRED
; (002000) Diag is good of extended enviroment

; PRIORITY LEVEL DEFINITIONS
000340 PRI07== 340
000300 PRI06== 300
000240 PRI05== 240
000200 PRI04== 200
000140 PRI03== 140
000100 PRI02== 100
000040 PRI01== 40
000000 PRI00== 0

; OPERATOR FLAG BITS
;
    
```



```

000004      EVL==      4
000010      LOT==     10
000020      ADR==     20
000040      IDU==     40
000100      ISR==    100
000200      UAM==    200
000400      BOE==    400
001000      PNT==   1000
002000      PRI==   2000
004000      IXE==   4000
010000      IBE==  10000
020000      IER==  20000
040000      LOE==  40000
100000      HOE== 100000

16          000000      ;
17          000002      ;
18          000004      ;
19          000006      ;
20          000010      ;
21          000012      ;
22          000014      ;
23          000016      ;
24          000018      ;
25          000020      ;
26          000022      ;
27          000024      ;
28          000026      ;
29          000028      ;
30          000030      ;
31          000032      ;
32          000034      ;
33          000036      ;
34          000038      ;
35          000040      ;
36          000042      ;
37          000044      ;
38          000046      ;
39          000048      ;
40          000050      ;
41          000052      ;
42          000054      ;
43          000056      ;
44          000058      ;
45          000060      ;
46          000062      ;
47          000064      ;
48          000066      ;
49          000068      ;
50          000070      ;
51          000072      ;
52          000074      ;
53          000076      ;
54          000078      ;
55          000080      ;
56          000082      ;
57          000084      ;
58          000086      ;

EVL==      4
LOT==     10
ADR==     20
IDU==     40
ISR==    100
UAM==    200
BOE==    400
PNT==   1000
PRI==   2000
IXE==   4000
IBE==  10000
IER==  20000
LOE==  40000
HOE== 100000

;
; OFFSETS FOR HARDWARE P-TABLE
CSR      =0      ;BUS ADDRESS
VECT     =2      ;VECTOR ADDRESS
PRIOR    =4      ;PRIORITY
TYPDR    =6      ;DRIVE TYPE
DRSB     =10     ;DRIVE SELECT BIT
CNT      =12     ;CONTROLLER TYPE

;
; OFFSET FOR SOFTWARE P-TABLE
MISWI    =0      ;SOFTWARE PARAMETERS SWITCHES
LOLIM    =2      ;CYLINDER LOWER LIMIT
HILIM    =4      ;CYLINDER HIGH LIMIT
HEAD     =6      ;SELECTED HEAD FOR RUNNING TESTS
ERLIM    =10     ;ERROR LIMIT
DCLIM    =12     ;DATA COMPARE ERROR LIMIT
BSERR    =14     ;BAD SEC FILE PRINT ERROR FLAG

;
; BIT ASSIGNMENT FOR SOFTWARE P-TABLE SWITCHES
ALLCYL   =BIT00  ;USE ALL CYLINDERS
ALLSEC   =BIT01  ;USE ALL SECTORS
DRSELT   =BIT02  ;EXECUTE DRIVE SELECT TEST
HDALIGN  =BIT03  ;EXECUTE HEAD ALIGNMENT TEST
HEADLM   =BIT12  ;HEAD LIMIT SPECIFIED FLAG
HICYL    =BIT13  ;HI LIMIT SPECIFIED FLAG
LOCYL    =BIT14  ;LO LIMIT SPECIFIED
MITEST   =BIT15  ;EXECUTE MANUAL INTERVENTION TESTS

;
; SUBSYSTEM FUNCTIONS
CKDATA   =102    ;WRITE CHECK
GTSTAT   =104    ;GET STATUS
SEEK     =106    ;SEEK
RDHEAD   =110    ;READ HEADER
WTDATA   =112    ;WRITE DATA
RDDATA   =114    ;READ DATA
RDNOHR   =116    ;READ DATA, IGNORE HEADERS
NOOP     =100    ;NO OPERATION

;
; OPERATION FLAGS
COMPOP   =777    ;COMPOSITE OPERATION FLAGS
HRCMP    =BIT01  ;HEADER COMPARE OPERATION
DATACMP  =BIT00  ;DATA COMPARE OPERATION
CYLUP    =BIT02  ;CYCLE UP OPERATION
ULOAD    =BIT03  ;UNLOAD OPERATION
    
```

```

59      000020      INOUTS  =BIT04      ;IN-OUT SEEK OPERATION
60      000040      OUTINS  =BIT05      ;OUT-IN SEEK OPERATION
61      000100      FOLWRT =BIT06      ;FOLLOWING WRITE OPERATION
62      000200      REVSKS  =BIT07      ;REV SEEK SEQ (ADJ INTERFERENCE)
63      000400      FWDSKS  =BIT08      ;FWD SEEK SEQ (ADJ INTERFERENCE)
64      001000      REVSKO  =BIT09      ;REV SEEK SEQ (OVERWRITE)
65      002000      FWDSKO  =BIT10      ;FWD SEEK SEQ (OVERWRITE)
66      004000      BADADD  =BIT11      ;BAD DISK ADDRESS
67      010000      SEEKOP  =BIT12      ;SEEK OPERATION
68      020000      RORMOP  =BIT13      ;READ OR WRITE OPERATION
69      040000      RELDWT  =BIT14      ;RELOAD WAIT
70      100000      HDR40   =BIT15      ;40 HEADER OPERATION
71      003760      MQUALS  =OUTINS!INOUTS!FOLWRT!REVSKS!FWDSKS!REVSKO!FWDSKO
72                                     ;MESSAGE QUALIFIER BITS
73
74      ;          ERROR FLAGS FROM SUBROUTINES
75      000001      TOSLOW  =BIT00      ;OPERATION TOOK TOO LONG
76      000002      NOIRPT  =BIT01      ;NO INTERRUPT FROM OPERATION
77      000004      CONHNG  =BIT02      ;CONTROLLER HUNG
78      000010      NOCLR   =BIT03      ;BAD CONTROLLER CLEAR
79
80      000000      RLCS    =0        ;CONTROL AND STATUS REGISTER
81      000002      RLBA    =2        ;BUS ADDRESS REGISTER
82      000004      RLDA    =4        ;DISK ADDRESS REGISTER
83      000006      RLMP    =6        ;MULTI-PURPOSE REGISTER
84
85      ;          REGISTER BIT DEFINITIONS - CONTROL STATUS REGISTER
86      000000      RLCSR   =0        ;CONTROL AND STATUS REGISTER
87      100000      ANYERR  =100000   ;ANY ERROR BIT
88      040000      DRVERR  =40000   ;DRIVE ERROR BIT
89      020000      NXMERR  =20000   ;NON-EXISTENT MEMORY ERROR
90      010000      DLTERR  =10000   ;DATA LATE ERROR
91      010000      HNFERR  =10000   ;HEADER NOT FOUND ERROR
92      004000      DCKERR  =4000    ;DATA CHECK ERROR
93      004000      HCRCERR =4000    ;HEADER CHECK ERROR
94      002000      OPIERR  =2000    ;OPERATION INCOMPLETE ERROR
95      001400      DSMSK   =1400    ;DRIVE SELECT MASK
96      000200      CRDYMSK =200     ;CONTROLLER READY MASK
97      000100      INTEBL  =100     ;INTERRUPT ENABLE MASK
98      000060      BAMSK   =60      ;BUS ADDRESS UPPER MASK
99      000001      DRDYMSK =1        ;DRIVE READY MASK
100
101      ;          REGISTER BIT DEFINITIONS - DISK ADDRESS FOR DATA XFER
102      000077      SAMSK   =77      ;SECTOR ADDRESS MASK
103      000100      HSMASK  =100     ;HEAD SELECT MASK
104
105      ;          REGISTER BIT DEFINITIONS - DISK ADDRESS FOR SEEK
106      000001      MBSETO  =1        ;MUST BE SET, BIT 0
107      000004      DIRBIT  =4        ;DIRECTION BIT
108      000020      HDSEL   =20      ;HEAD SELECT BIT
109
110      ;          REGISTER BIT DEFINITIONS - DISK ADDRESS FOR GET STATUS
111      000003      GETSTAT  =3        ;GET STATUS SETUP
112      000010      DRSET   =10      ;DRIVE RESET MASK
113
114      ;          REGISTER BIT DEFINITIONS - MP FOR DATA XFER
115      017777      WCMSK   =17777   ;WORD COUNT MASK
    
```

```

116      160000      WCRNG      =160000      ;WORD COUNT RANGE MASK
117
118      ; REGISTER BIT DEFINITIONS - MP FOR READ HEADER
119      000077      HDSEC      =77      ;SECTOR MASK
120      000100      HDHSEL      =100     ;HEAD SELECT MASK
121
122      ; REGISTER BIT DEFINITIONS - MP FOR GET STATUS
123      000007      STAMSK      =7      ;STATE MASK
124      000010      BHSTAT      =10     ;BRUSH HOME STATUS
125      000020      HOSTAT      =20     ;HEADS OUT STATUS
126      000040      COSTAT      =40     ;COVER OPEN STATUS
127      000100      HSSTAT      =100    ;HEAD SELECT STATUS
128      000400      DSESTAT      =400   ;DRIVE SELECT ERROR STATUS
129      001000      VCSTAT      =1000  ;VOLUME CHECK STATUS
130      002000      WGESTAT      =2000  ;WRITE GATE ERROR STATUS
131      004000      SPDSTAT      =4000  ;SPIN ERROR STATUS
132      010000      STOSTAT      =10000 ;SEEK TIMEOUT ERROR STATUS
133      020000      WLSTAT      =20000  ;WRITE LOCK STATUS
134      040000      HCESTAT      =40000 ;HEAD CURRENT ERROR STATUS
135      100000      WDESTAT      =100000;WRITE DATA ERROR STATUS
136
137      ; P-CLOCK REGISTERS
138      172540      CLKCSR      =172540  ;CLOCK CONTROL AND STATUS REGISTER
139      172542      CLKCSB      =172542  ;CLOCK COUNT SET BUFFER
140      172544      CLKCTR      =172544  ;CLOCK COUNTER

```

.SBTTL GLOBAL DATA SECTION

; TABLE OF OPERATION MESSAGES

```

149
150 002226 000000 OPMSGS: .WORD 0 ;FILLER
151 002230 005775 .WORD MWRCHK ;MESSAGE FOR WRITE CHECK
152 002232 006020 .WORD MGTSTA ; GET STATUS
153 002234 005750 .WORD MSEEK ;SEEK
154 002236 005765 .WORD MREADH ;READ HEADER
155 002240 006006 .WORD MWRITE ;WRITE DATA
156 002242 005754 .WORD MREAD ;READ DATA
157 002244 006103 .WORD MWRSET ;WITH RESET
158 002246 006032 .WORD MDATCP ;WITH DATA COMPARE
159 002250 006051 .WORD MHDRCP ;WITH HEADER COMPARE
160 002252 006150 .WORD MCYLUP ;LOAD HEADS
161 002254 006137 .WORD MLOAD ;UNLOAD HEADS
162 002256 006177 .WORD MINOUT ;IN-OUT SEQ
163 002260 006160 .WORD MOUTIN ;OUT-IN SEQ
164 002262 006220 .WORD MFOLWRT ;FOLLOWING WRITE
165 002264 006240 .WORD MREVSK ;REV SEEK
166 002266 006271 .WORD MFWSK ;FWD SEEK
167 002270 006356 .WORD MRESKO ;REV SEEK
168 002272 006322 .WORD MFWSKO ;FWD SEEK
169 002274 006412 .WORD MBADAD ;BAD DISK ADD FOR WRITE
170 002276 006067 .WORD M4OHDR ;40 HEADER OPERATION
171
172 002300 000000 T.DRIVE: .WORD 0
173 002302 000000 JUNK: .WORD 0
174 002304 000000 HLMTW: .WORD 0

```

175 002306 000000  
 176 002310 000000  
 177 002312 000000  
 178 002314 000000  
 179 002316 000000  
 180 002320 000000

CLRBYT: .WORD 0  
 NXTHL: .WORD 0  
 GBND: .WORD 0  
 CAMSK: .WORD 0  
 DIRMSK: .WORD 0  
 HDCYL: .WORD 0

181  
 182  
 183 002322 010713  
 184 002324 011024  
 185 002326 011242  
 186 002330 011214  
 187 002332 011177  
 188 002334 011167  
 189 002336 011274  
 190 002340 000000  
 191 002342 011152  
 192 002344 011134  
 193 002346 000000  
 194 002350 011120  
 195 002352 011065  
 196 002354 011103  
 197 002356 000000  
 198 002360 011035

; RESTBL: TABLE OF RESULT NAME MESSAGE ADDRESSES  
 .WORD MCERR ;CONTROLLER ERROR  
 .WORD MDRERR ;DRIVE ERROR  
 .WORD MNEERR ;NON-EXISTANT MEMORY ERROR  
 .WORD MFLERR ;HEADER NOT FOUND-DATA LATE  
 .WORD MHDERR ;HEADER OR DATA ERROR  
 .WORD MOPERR ;OPERATION INCOMPLETE  
 .WORD MNDRST ;NO DRIVE STATUS AVAILABLE  
 .WORD 0  
 .WORD MWDERR ;WRITE DATA ERROR  
 .WORD MHCERR ;HEAD CURRENT ERROR  
 .WORD 0  
 .WORD MSTERR ;SEEK TIMEOUT ERROR  
 .WORD MSPERR ;SPINDLE ERROR  
 .WORD MWGERR ;WRITE GATE ERROR  
 .WORD 0  
 .WORD MDSERR ;DRIVE SELECT ERROR

199  
 200  
 201 002362 005472  
 202 002364 005474  
 203 002366 005534  
 204 002370 005574  
 205 002372 005634  
 206 002374 005642  
 207 002376 005702  
 208 002400 005704  
 209 002402 005744  
 210 002404 005746

; PATTBL: PATTERN TABLE  
 .WORD PAT1  
 .WORD PAT2  
 .WORD PAT3  
 .WORD PAT4  
 .WORD PAT5  
 .WORD PAT6  
 .WORD PAT7  
 .WORD PAT8  
 .WORD PAT9  
 .WORD PAT10

211  
 212  
 213  
 214 002406 000000  
 215 002410 000000  
 216 002412 000000  
 217 002414 000000  
 218 002416 000000  
 219 002420 000000  
 220 002422 000000  
 221 002424 000000  
 222 002426 000000  
 223 002430 000000

; SUBSTK: SUBROUTINE CALLING STACK ;STACK IS 12 WORDS LONG  
 .WORD 0  
 .WORD 0  
 .WORD 0  
 .WORD 0  
 .WORD 0  
 .WORD 0  
 .WORD 0  
 .WORD 0  
 .WORD 0  
 .WORD 0  
 .WORD 0

224  
 225  
 226 002432 000002  
 227 002434 000006  
 228 002436 000011  
 229 002440 000014  
 230 002442 000021  
 231 002444 000026

; RL01 TABLE OF CYLINDERS ;TABLE OF DIFFERENCES  
 ;25TBL: .WORD 2  
 .WORD 6  
 .WORD 9.  
 .WORD 12.  
 .WORD 17.  
 .WORD 22.

232	002446	000033	.WORD	27.
233	002450	000042	.WORD	34.
234	002452	000051	.WORD	41.
235	002454	000200	.WORD	128.
236	002456	000377	.WORD	255.

237				
238				
239	002460	000004	;RL02 TABLE OF CYLINDERS	
240	002462	000014	T25TB2: .WORD	4
241	002464	000022	.WORD	12.
242	002466	000030	.WORD	18.
243	002470	000042	.WORD	24.
244	002472	000054	.WORD	34.
245	002474	000066	.WORD	44.
246	002476	000104	.WORD	54.
247	002500	000122	.WORD	68.
248	002502	000400	.WORD	82.
249	002504	000777	.WORD	256.

250				
251				
252				
253	002506		; TABLE TO BE USED TO BUILD AND STORE THE CYLINDERS	
254	002546		T33TBL: .BLKW	16.
255			TBT: .BLKW	16.

256				
257	002606	002	CYLTBL: .BYTE	2
258	002607	007	.BYTE	7.
259	002610	016	.BYTE	14.
260	002611	024	.BYTE	20.
261	002612	033	.BYTE	27.
262	002613	041	.BYTE	33.
263	002614	046	.BYTE	38.
264	002615	055	.BYTE	45.
265	002616	064	.BYTE	52.
266	002617	072	.BYTE	58.
267	002620	101	.BYTE	65.
268	002621	110	.BYTE	72.
269	002622	115	.BYTE	77.
270	002623	124	.BYTE	84.
271	002624	133	.BYTE	91.
272	002625	141	.BYTE	97.
273	002626	146	.BYTE	102.
274	002627	154	.BYTE	108.
275	002630	161	.BYTE	113.
276	002631	170	.BYTE	120.
277	002632	177	.BYTE	127.
278	002633	206	.BYTE	134.
279	002634	213	.BYTE	139.
280	002635	222	.BYTE	146.
281	002636	230	.BYTE	152.
282	002637	235	.BYTE	157.
283	002640	244	.BYTE	164.
284	002641	252	.BYTE	170.
285	002642	261	.BYTE	177.
286	002643	270	.BYTE	184.
287	002644	275	.BYTE	189.
288	002645	303	.BYTE	195.

;TABLE OF DEFAULT CYLINDERS

289	002646	312	.BYTE	202.
290	002647	317	.BYTE	207.
291	002650	326	.BYTE	214.
292	002651	334	.BYTE	220.
293	002652	343	.BYTE	227.
294	002653	352	.BYTE	234.
295	002654	361	.BYTE	241.
296	002655	367	.BYTE	247.
297	002656	375	.BYTE	253.
298	002657	000	.BYTE	0
299	002660	000401	.WORD	257.
300	002662	000406	.WORD	262.
301	002664	000415	.WORD	269.
302	002666	000423	.WORD	275.
303	002670	000432	.WORD	282.
304	002672	000445	.WORD	293.
305	002674	000454	.WORD	300.
306	002676	000463	.WORD	307.
307	002700	000471	.WORD	313.
308	002702	000500	.WORD	320.
309	002704	000507	.WORD	327.
310	002706	000514	.WORD	332.
311	002710	000523	.WORD	339.
312	002712	000532	.WORD	346.
313	002714	000540	.WORD	352.
314	002716	000545	.WORD	357.
315	002720	000553	.WORD	363.
316	002722	000560	.WORD	368.
317	002724	000567	.WORD	375.
318	002726	000576	.WORD	382.
319	002730	000605	.WORD	389.
320	002732	000612	.WORD	394.
321	002734	000621	.WORD	401.
322	002736	000627	.WORD	407.
323	002740	000634	.WORD	412.
324	002742	000643	.WORD	419.
325	002744	000651	.WORD	425.
326	002746	000660	.WORD	432.
327	002750	000667	.WORD	439.
328	002752	000674	.WORD	444.
329	002754	000702	.WORD	450.
330	002756	000711	.WORD	457.
331	002760	000716	.WORD	462.
332	002762	000725	.WORD	469.
333	002764	000733	.WORD	475.
334	002766	000742	.WORD	482.
335	002770	000751	.WORD	489.
336	002772	000760	.WORD	496.
337	002774	000766	.WORD	502.
338	002776	000774	.WORD	508.
339	003000	000774	.WORD	508.
340	003002	000000	.WORD	0
341	003004	000000	.WORD	0
342				
343				
344	003006	000000	SSIDX: .WORD	0 ;SUBROUTINE STACK INDEX POINTER
345	003010	000000	OPFLAG: .WORD	0 ;OPERATION FLAGS
			DONE: .WORD	0 ;OPERATION COMPLETE FLAG

346	003012	000000	HADONE: .WORD	0	;HEAD ALIGNMENT DONE FLAG
347	003014	000000	ERHEAD: .WORD	0	;ADDRESS OF ERROR HEADER
348	003016	000000	MORECE: .WORD	0	;MORE THAN 1 COMPARE ERROR
349	003020	000000	ERRSWI: .WORD	0	;ERROR RETURN SWITCH
350	003022	000000	BSFLAG: .WORD	0	;BAD SECTOR FLAGS
351	003024	000000	WRTSWI: .WORD	0	;WRITE SWITCH
352	003026	000000	TBLSTR: .WORD	0	;TABLE STORAGE
353					
354	003030	000000	RLBAS: .WORD	0	;RL11 BASE ADDRESS
355	003032	000000	RLVEC: .WORD	0	;RL11 VECTOR ADDRESS
356	C03034	000000	RLDRV: .WORD	0	;DRIVE NUMBER UNDER TEST
357					
358	003036	000000	L.CS: .WORD	0	;CONTROLLER REGISTER STORAGE
359	003040	000000	L.BA: .WORD	0	;BEFORE OPERATION
360	003042	000000	L.DA: .WORD	0	
361	003044	000000	L.MP: .WORD	0	
362	003046	000000	T.CS: .WORD	0	;CONTROLLER REGISTER STORAGE
363	003050	000000	T.BA: .WORD	0	; AFTER OPERATION
364	003052	000000	T.DA: .WORD	0	
365	003054		T.MP:		
366	003054	000000	HDWRD1: .WORD	0	;HEADER WORD STORAGE
367	003056	000000	HDWRD2: .WORD	0	
368	003060	000000	HDWRD3: .WORD	0	
369					
370	003062	000000	T.STAT: .WORD	0	;DRIVE STATE STORAGE
371					
372	003064	000000	RESPARM: .WORD	0	;PARAM BLOCK FOR REASON REPORT
373	003066	000000	.WORD	0	
374	003070	000000	.WORD	0	
375	003072	000000	.WORD	0	
376	003074	000000	.WORD	0	
377					
378	003076	000000	DRVCNT: .WORD	0	;DRIVE COUNT FOR DRIVES UNDER TEST
379	003100	000000	DIFAUG: .WORD	0	;DIFFERENCE AUGMENT FOR SEEK
380	003102	000000	OLDCYL: .WORD	0	;OLD CYLINDER
381	003104	000000	NEWCYL: .WORD	0	;NEW CYLINDER
382	003106	000000	CURCYL: .WORD	0	;CURRENT CYLINDER
383	003110	000000	DESDIF: .WORD	0	;DESIRED DIFFERENCE
384	003112	000000	DESSGN: .WORD	0	;DESIRED SIGN
385	003114	000000	DESHD: .WORD	0	;DESIRED HEAD
386	003116	000000	DESSEC: .WORD	0	;DESIRED SECTOR
387	003120	000000	TEMPO: .WORD	0	;TEMPORARY STORAGE
388	003122	000000	TEMP1: .WORD	0	;TEMPORARY STORAGE
389	003124	000000	TEMP2: .WORD	0	;TEMPORARY STORAGE
390	003126	000000	TEMP3: .WORD	0	;TEMPORARY STORAGE
391	003130	000000	TEMP4: .WORD	0	;TEMPORARY STORAGE
392	003132	000000	TEMP5: .WORD	0	;TEMPORARY STORAGE
393	003134	000000	TEMP6: .WORD	0	;TEMPORARY STORAGE
394	003136	000000	TEMP7: .WORD	0	;TEMPORARY STORAGE
395	003140	000000	TEMP8: .WORD	0	;TEMPORARY STORAGE
397			; TIMER STORAGE		
398	003142	000000	OFIN: .WORD	0	;ONE CYLINDER FORWARD INNER
399	003144	000000	OFINU: .WORD	0	; UPPER
400	003146	000000	OFMID: .WORD	0	;ONE CYLINDER FORWARD MIDDLE
401	003150	000000	OFMIDU: .WORD	0	; UPPER
402	003152	000000	OFOUT: .WORD	0	;ONE CYLINDER FORWARD OUTER
403	003154	000000	OFOUTU: .WORD	0	; UPPER

404	003156	000000	ORIN: .WORD	0	;ONE CYLINDER REVERSE INNER
405	003160	000000	ORINU: .WORD	0	;UPPER
406	003162	000000	ORMID: .WORD	0	;ONE CYLINDER REVERSE MIDDLE
407	003164	000000	ORMIDU: .WORD	0	;UPPER
408	003166	000000	OROUT: .WORD	0	;ONE CYLINDER REVERSE OUTER
409	003170	000000	OROUTU: .WORD	0	;UPPER
410	003172	000000	HFIN: .WORD	0	;128 CYLINDER FORWARD INNER
411	003174	000000	HFINU: .WORD	0	;UPPER
412	003176	000000	HFOUT: .WORD	0	;128 CYLINDER FORWARD OUTER
413	003200	000000	HFOUTU: .WORD	0	;UPPER
414	003202	000000	HRIN: .WORD	0	;128 CYLINDER REVERSE INNER
415	003204	000000	HRINU: .WORD	0	;UPPER
416	003206	000000	HROUT: .WORD	0	;128 CYLINDER REVERSE OUTER
417	003210	000000	HROUTU: .WORD	0	;UPPER
418	003212	000000	AFMID: .WORD	0	;256 CYLINDER FORWARD
419	003214	000000	AFMIDU: .WORD	0	;UPPER
420	003216	000000	ARMID: .WORD	0	;256 CYLINDER REVERSE
421	003220	000000	ARMIDU: .WORD	0	;UPPER
422					
423	003222	000252	EXOCYL: .WORD	170.	;EXPECTED TIME ONE CYLINDER
424	003224	001046	EXHCYL: .WORD	550.	;EXPECTED TIME 128 CYLINDER
425	003226	001750	EXACYL: .WORD	1000.	;EXPECTED TIME 256 CYLINDER
426	003230	000372	EXROT: .WORD	250.	;EXPECTED ROTATION TIME
428	003232	000004	ERRVEC: .WORD	4	;ERROR VECTOR
429					
430					
431	003234	000000	; MISCELLANEOUS COUNTERS		
432	003236	000000	PASCNT: .WORD	0	;PASS COUNTER (LOCAL TO A TEST)
433	003240	000000	COUNT: .WORD	0	;A COUNTER (LOCAL TO A TEST)
434	003242	000000	TSTNM: .WORD	0	;CURRENT TEST NUMBER OF LOCAL TEST
435	003244	000000	ERRPOINT: .WORD	0	;ERROR POINTER
436	003444	000000	ERRCNT: .BLKW	64.	;ERROR COUNTER FOR PROGRAM
437	003446	000000	PASNUM: .WORD	0	;PASS NUMBER FOR PROGRAM
438	003450	000	PSETNM: .WORD	0	;COUNTER FOR PARAMETER SET NUMBER IN USE
439	003451	000	LOCERR: .BYTE	0	;LOCAL ERROR COUNTER
440	003452	000000	NOERCT: .BYTE	0	;INHIBIT ERROR COUNTING FLAG
441	003454	000000	TRPFLG: .WORD	0	;HARDWARE TRAP OCCURANCE
442	003456	000000	PWRFLG: .WORD	0	;POWER FAILURE OCCURANCE
443	003460	000000	XDELAY: .WORD	0	
444	003462	000000	YDELAY: .WORD	0	
445	003464	000000	MININC: .WORD	0	
446	003466	000000	TEMP: .WORD	0	
447	003470	000000	TIM.US: .WORD	0	
448	003472	000000	TAG: .WORD	0	
449	003474	000000	MAJINC: .WORD	0	
450	003476	000000	CLKFLG: .WORD	0	;FLAG INDICATING PRESENCE OF A P-CLOCK
451			CLKADR: .WORD	0	;POINTER TO DIAGNOSTIC MONITOR CLOCK TABLE
452					
453					
454	003500	000000	; BAD SECTOR TABLES AND POINTERS		
455			BSFVAL: .WORD	0	;BAD SECTORS FILES VALID FLAG;
456	003502				; 0=NOT READ, 1=VALID, -1=NOT VALID
457	004074	177777	FCTBSF: .BLKW	125.	;FACTORY BAD SECTOR FILE STORAGE
458	004076		.WORD	-1	;FULL TERMINATE
459	004470	177777	FLDBSF: .BLKW	125.	;FIELD BAD SECTOR FILE STORAGE
460			.WORD	-1	;FULL TERMINATE
461	004472		IBUFF: .BLKW	128.	;INPUT BUFFER (1 sector of data)



462	005072		OBUFF:	.BLKW	128.		;OUTPUT BUFFER	"
463								
464	005472	000000	PAT1:	.WORD	0		;PATTERN 1 (ALL ZEROS)	
465	005474	177772	PAT2:	.WORD	177772			
466	005476	177777		.WORD	177777			
467	005500	177777		.WORD	177777			
468	005502	052525		.WORD	052525			
469	005504	052525		.WORD	052525			
470	005506	052525		.WORD	052525			
471	005510	177777		.WORD	177777			
472	005512	177777		.WORD	177777			
473	005514	052525		.WORD	052525			
474	005516	052525		.WORD	052525			
475	005520	177777		.WORD	177777			
476	005522	052525		.WORD	052525			
477	005524	177252		.WORD	177252			
478	005526	177252		.WORD	177252			
479	005530	172765		.WORD	172765			
480	005532	172765		.WORD	172765			
481								
482	005534	000003	PAT3:	.WORD	000003			
483	005536	000000		.WORD	000000			
484	005540	000000		.WORD	000000			
485	005542	177777		.WORD	177777			
486	005544	177777		.WORD	177777			
487	005546	177777		.WORD	177777			
488	005550	000000		.WORD	000000			
489	005552	000000		.WORD	000000			
490	005554	177777		.WORD	177777			
491	005556	177777		.WORD	177777			
492	005560	000000		.WORD	000000			
493	005562	177777		.WORD	177777			
494	005564	000000		.WORD	000000			
495	005566	177777		.WORD	177777			
496	005570	000000		.WORD	000000			
497	005572	177777		.WORD	177777			
498								
499	005574	025252	PAT4:	.WORD	025252			
500	005576	052525		.WORD	052525			
501	005600	052525		.WORD	052525			
502	005602	125252		.WORD	125252			
503	005604	125252		.WORD	125252			
504	005606	125252		.WORD	125252			
505	005610	052525		.WORD	052525			
506	005612	052525		.WORD	052525			
507	005614	125252		.WORD	125252			
508	005616	125252		.WORD	125252			
509	005620	052525		.WORD	052525			
510	005622	125252		.WORD	125252			
511	005624	052525		.WORD	052525			
512	005626	125252		.WORD	125252			
513	005630	052525		.WORD	052525			
514	005632	125252		.WORD	125252			
515								
516	005634	155555	PAT5:	.WORD	155555			
517	005636	133333		.WORD	133333			
518	005640	066666		.WORD	066666			

519				
520	005642	121105	PAT6:	.WORD 121105
521	005644	150442		.WORD 150442
522	005646	064221		.WORD 064221
523	005650	132110		.WORD 132110
524	005652	055044		.WORD 055044
525	005654	026442		.WORD 026442
526	005656	013211		.WORD 013211
527	005660	105504		.WORD 105504
528	005662	042642		.WORD 042642
529	005664	021321		.WORD 021321
530	005666	110550		.WORD 110550
531	005670	044264		.WORD 044264
532	005672	022132		.WORD 022132
533	005674	011055		.WORD 011055
534	005676	104426		.WORD 104426
535	005700	042213		.WORD 042213

536				
537	005702	177777	PAT7:	.WORD 177777
538				

539	005704	045513	PAT8:	.WORD 045513
540	005706	122645		.WORD 122645
541	005710	151322		.WORD 151322
542	005712	064551		.WORD 064551
543	005714	132264		.WORD 132264
544	005716	055132		.WORD 055132
545	005720	026455		.WORD 026455
546	005722	113226		.WORD 113226
547	005724	045513		.WORD 045513
548	005726	122645		.WORD 122645
549	005730	151322		.WORD 151322
550	005732	064551		.WORD 064551
551	005734	132264		.WORD 132264
552	005736	055132		.WORD 055132
553	005740	026455		.WORD 026455
554	005742	113226		.WORD 113226

555				
556	005744	125252	PAT9:	.WORD 125252
557				

558	005746	155555	PAT10:	.WORD 155555
559				

561				
562			.SBTTL	GLOBAL MESSAGES
563				

565				
568				
569	005750	123	113	040 MSEEK: .ASCIZ /SK /
570	005754	122	104	040 MREAD: .ASCIZ /RD DATA /
571	005765	122	104	040 MREADH: .ASCIZ /RD HDR /
572	005775	127	122	124 MWRCHK: .ASCIZ /WRT CHCK/
573	006006	127	122	124 MWRITE: .ASCIZ /WRT DATA /
574	006020	107	105	124 MGTSTA: .ASCIZ /GET STAT /
575	006032	127	111	124 MDATCP: .ASCIZ /WITH DATA CMP /
576	006051	127	111	124 MHDRCP: .ASCIZ /WITH HDR CMP /
577	006067	106	117	122 M40HDR: .ASCIZ /FOR 40 HDRS/
578	006103	127	111	124 MWRSET: .ASCIZ /WITH RESET /
579	006117	117	120	105 MOPER: .ASCIZ /OPER: /

580	006126	122	105	123	MRSLT: .ASCIZ	/RESULT: /
581	006137	125	116	114	MULOAD: .ASCIZ	/UNLD DRV/
582	006150	114	104	040	MCYLUP: .ASCIZ	/LD DRV /
583	006160	106	117	114	MOUTIN: .ASCIZ	/FOL 0 TO CC SK/
584	006177	106	117	114	MINOUT: .ASCIZ	/FOL 255 TO CC SK/
585	006220	106	117	114	MFOLWRT: .ASCIZ	/FOL WRT (NO SK)/
586	006240	101	104	112	MREVSX: .ASCIZ	/ADJ CYL WRTTN AFT REV SK/
587	006271	101	104	112	MFWD SK: .ASCIZ	/ADJ CYL WRTTN AFT FWD SK/
588	006322	123	113	040	MFWSKO: .ASCIZ	/SK FWD,WRT - SK REV,OVERWRT/
589	006356	123	113	040	MRESKO: .ASCIZ	/SK REV,WRT - SK FWD,OVERWRT/
590	006412	117	116	040	MBADAD: .ASCIZ	/ON BAD SEC FILES/
591	006433	103	101	116	MFBSF: .ASCIZ	/CAN'T FIND GOOD COPY OF FACTORY BAD SEC FILE/
592	006510	103	101	116	MUBSF: .ASCIZ	/CAN'T FIND GOOD COPY OF FIELD BAD SEC FILE/
593	006563	102	101	104	MFMTER: .ASCIZ	/BAD SEC FILE FMT ERR/
594	006610	102	125	123	BASADD: .ASCIZ	/BUS ADD=/
595	006621	104	122	126	DRVNAM: .ASCIZ	/DRV=/
596	006626	116	117	040	DRVNAV: .ASCIZ	/NO DRV FOR TST/
597	006645	104	122	126	NO PWR: .ASCIZ	/DRV DID NOT REC'R FROM PWR FAIL/
598	006705	122	114	103	CSNAM: .ASCIZ	/RLCS/
599	006712	122	114	102	BANAM: .ASCIZ	/RLBA/
600	006717	122	114	104	DANAM: .ASCIZ	/RLDA/
601	006724	122	114	115	MPNAM: .ASCIZ	/RLMP/
602	006731	117	120	040	LAB1: .ASCIZ	/OP INIT = /
603	006744	117	120	040	LAB2: .ASCIZ	/OP DONE = /
604	006757	127	117	122	MWORD: .ASCIZ	/WORD /
605	006765	111	116	124	MTOSLOW: .ASCIZ	/INTRPT TOO LATE/
606	007005	116	117	040	MDRRES: .ASCIZ	/NO DRV RSPNSE/
607	007023	116	117	040	MNOINT: .ASCIZ	/NO INTRPT ON CMND COMPLETE/
608	007056	103	116	124	MCONHNG: .ASCIZ	/CNTLR HUNG /
609	007072	105	122	122	MNOCLR: .ASCIZ	/ERR DID NOT CLR/
610	007112	126	117	114	VCNRST: .ASCIZ	/VOL CHK NOT RSET/
611	007133	125	116	130	UNXERR: .ASCIZ	/UNXPCTED ERR/
612	007150	040	124	105	TSTLAB: .ASCIZ	/TEST/
630	007156	117	125	124	P2T03E: .ASCIZ	/OUT GRD BAND /
631	007174	111	116	103	P2T04E: .ASCIZ	/INC SK FWD HD 0/
632	007214	111	116	103	P2T05E: .ASCIZ	/INC SK REV HD 0/
633	007234	111	116	103	P2T06E: .ASCIZ	/INC SK FWD HD 1/
634	007254	111	116	116	P2T07E: .ASCIZ	/INN GRD BAND /
635	007272	111	116	103	P2T08E: .ASCIZ	/INC SK REV HD 1/
636	007312	123	113	000	P2T09E: .ASCIZ	/SK/
637	007315	106	127	104	P2T10E: .ASCIZ	/FWD OSC SK/
638	007330	122	105	126	P2T11E: .ASCIZ	/REV OSC SK/
639	007343	123	113	040	P2T12E: .ASCIZ	/SK TIMING/
640	007355	102	101	104	P2T13E: .ASCIZ	/BAD SEC FILE RD DATA/
641	007402	127	122	124	P2T14E: .ASCIZ	&WRT/RD DATA (P1)&
642	007423	123	120	111	P2T15E: .ASCIZ	/SPINDLE ROT TIMING/
643	007446	127	122	124	P2T16E: .ASCIZ	&WRT/RD DATA (P2)&
644	007467	127	122	124	P2T17E: .ASCIZ	/WRT LCK ERR AND DATA PROT/
645	007521	101	104	112	P2T18E: .ASCIZ	/ADJ CYL INTERFNCE/
646	007543	117	126	105	P2T19E: .ASCIZ	/OVERWRT/
647	007553	123	113	040	SKTMES: .ASCIZ	/SK TIMES /
648	007565	123	120	111	SRTMES: .ASCIZ	/SPINDLE ROT TIME /
649	007607	050	111	116	VALDES: .ASCIZ	/(IN 100'S OF U-SEC)/
650	007633	101	120	120	MAPROX: .ASCIZ	/APPROX /
651	007643	111	116	116	LABIN: .ASCIZ	/INNER/
652	007651	115	111	104	LABMID: .ASCIZ	/MIDDLE/
653	007660	117	125	124	LABOUT: .ASCIZ	/OUTER/

654	007666	115	101	130	LABEXP: .ASCIZ /MAX TIME/
655	007677	061	040	103	LABOCF: .ASCIZ /1 CYL FWD/
656	007711	061	040	103	LABOCR: .ASCIZ /1 CYL REV/
657	007723	115	111	104	LABHCF: .ASCIZ /MID CYL FWD/
658	007737	115	111	104	LABHCR: .ASCIZ /MID CYL REV/
659	007753	115	101	130	LABACF: .ASCIZ /MAX CYL FWD/
660	007767	115	101	130	LABACR: .ASCIZ /MAX CYL REV/
662	010003	110	104	123	HDMOVF: .ASCIZ /HDS FAILED TO MV IN 10 TRYS/
680	010037	122	105	123	OPR12: .ASCIZ /RESET WRT LCK /
681	010056	117	116	040	OPR1A: .ASCIZ /ON /
682	010062	117	116	040	OPR1B: .ASCIZ /ON DRV /
683	010072	125	116	104	UNDTST: .ASCIZ /UNDER TEST/
684	010105	123	105	124	OPR004: .ASCIZ /SET WRT LCK /
685	010122	104	111	106	DIFWD: .ASCIZ /DIFF /
686	010130	123	107	116	SGNWD: .ASCIZ /SGN /
687	010135	110	104	040	HDWD: .ASCIZ /HD /
688	010141	123	105	103	SECWD: .ASCIZ /SEC /
689	010146	103	131	114	CYLWD: .ASCIZ /CYL /
690	010153	106	122	117	FRMWD: .ASCIZ /FROM /
691	010161	040	102	131	BYPNM: .ASCIZ / BYPASSED /
692	010174	122	117	125	SEQMES: .ASCIZ /ROUTINE TRACE SEQ:/
693	010217	104	122	126	STAMES: .ASCIZ /DRV STAT/
694	010230	124	117	124	TCERR: .ASCIZ /TOTAL CMP ERRS: /
695	010251	104	122	111	NOCTLR: .ASCIZ /DRIVE DROPPED - NO CONTROLLER/
696	010307	104	122	111	NOTRDY: .ASCIZ /DRIVE DROPPED - DID NOT RESPOND WITH "READY"/
697	010364	045	116	045	NOTST: .ASCIZ /*N%ATEST *D2%A CANNOT BE PERFORMED...P-CLOCK NOT AVAILABLE/<CR><LF>
LF 698	010461	045	116	045	NOHD1: .ASCIZ /*N%ATEST *D2%A CANNOT READ BAD SEC FILE...HD 1 DISABLED BY SW QUESTION/<CR><
699	010572	045	116	045	BSFNOT: .ASCIZ /*N%A*WARNING* ALL SECTORS ASSUMED GOOD FOR TESTS REQUIRING BAD SEC DATA/
700					
701					
702	010702	104	122	126	MDRDY: .ASCIZ /DRV RDY /
703	010713	103	117	116	MCERR: .ASCIZ /CONT ERR /
704	010725	110	104	122	MHCRC: .ASCIZ /HDR CRC/
705	010735	104	101	124	MDCRC: .ASCIZ /DATA CRC/
706	010746	110	104	122	MHNF: .ASCIZ /HDR NOT FND/
707	010762	104	101	124	MDLT: .ASCIZ /DATA LATE/
708	010774	110	104	122	MHFCRC: .ASCIZ &HDR NOT FND/HDR CRC/OPI&
709	011024	104	122	126	MDRERR: .ASCIZ /DRV ERR /
718	011035	104	122	126	MDSERR: .ASCIZ /DRV SEL ERR /
719	011052	104	122	126	MDRVST: .ASCIZ /DRV STATE /
720	011065	123	120	111	MSPERR: .ASCIZ /SPIN TIMEOUT /
721	011103	127	122	124	MWGERR: .ASCIZ /WRT GAT ERR /
722	011120	123	113	040	MSTERR: .ASCIZ /SK TIMEOUT /
723	011134	110	105	101	MHCERR: .ASCIZ /HEAD CUR ERR /
724	011152	127	122	124	MWDERR: .ASCIZ /WRT DAT ERR /
725	011167	117	120	122	MOPERR: .ASCIZ /OPR-INC/
726	011177	110	104	122	MHDERR: .ASCIZ &HDR/DAT ERR &
727	011214	110	104	122	MFLERR: .ASCIZ &HDR NOT FND/DAT LATE &
728	011242	116	117	116	MNEERR: .ASCIZ /NON-EXISTENT MEMORY /
729	011267	103	131	114	MCYLOC: .ASCIZ /CYL /
730	011274	103	101	116	MNDRST: .ASCIZ /CAN'T GET DRV STAT/
731	011317	125	116	113	MUNDEF: .ASCIZ /UNKN DRV STATE-NO RDY,NO ERR,HDS OUT/
732	011364	106	101	111	MRLFAL: .ASCIZ /FAIL TO RELD HDS AFTER ERR CLR/
733	011423	127	122	124	MWRTAB: .ASCIZ /WRT ABRTO/
734	011435	040	117	126	MEXERS: .ASCIZ / OVR ERR LIMIT - UNIT DRPPD /
735	011472	040	105	122	MERRS: .ASCIZ / ERR/
736	011477	207	377	377	BELL: .ASCIZ <207><377><377>

Line	Code	Value 1	Value 2	Value 3	Label	Result	Settings
737							
738							
739	011503	111	123	040	RESE3:	.ASCIZ	/IS /
740	011507	040	123	102	RESE4:	.ASCIZ	/ SB /
741							
742							
743	011514	040	111	116	RESE5:	.ASCIZ	/ IN /
744	011521	040	117	106	RESE6:	.ASCIZ	/ OF /
745	011526	123	124	101	STATE2:	.ASCIZ	/STATE 2/
746	011536	123	124	101	STATE3:	.ASCIZ	/STATE 3/
747	011546	123	124	101	STATE5:	.ASCIZ	/STATE 5/
751	011556	061	123	124	C10MS:	.ASCIZ	/1ST 3 MS/
752	011567	065	060	060	C500MS:	.ASCIZ	/500MS/
753	011575	103	131	103	CCYLP:	.ASCIZ	/CYC UP/
754	011604	104	101	124	CAFDT:	.ASCIZ	/DATA XFR/
755	011615	065	040	123	C5SEC:	.ASCIZ	/5 SEC/
756							
757	C11623	045	116	000	CRLF:	.ASCIZ	/N/
758	011626	045	124	000	FMTXT:	.ASCIZ	/T/
759	011631	045	116	045	FMTOP1:	.ASCIZ	/N#T#N#T#T#06#S#T#01#N/
760	011660	045	116	045	FMTOP2:	.ASCIZ	/N#T#01#S1#T#01#N/
761	011702	045	116	045	FMTOP3:	.ASCIZ	/N#T#01#S1#T#T#N/
762	011723	045	124	045	FMT1:	.ASCIZ	/T#T/
763	011730	045	116	045	FMT2:	.ASCIZ	/N#T#T/
764	011737				FMT3:		;unused
765	011737	045	116	045	FMT4:	.ASCIZ	/N#T#T#N/
766	011750	045	116	045	FMT5:	.ASCIZ	/N#T#06#S1#T#01/
767	011770	045	116	045	FMT6:	.ASCIZ	/N#S11#T#S4#T#S4#T#S4#T#S4#T#S2#T/
768	012032	045	116	045	FMT7:	.ASCIZ	/N#T#06#S2#06#S2#06#S2#06#S3#03#S2#01#N/
769	012102	045	116	045	FMT8:	.ASCIZ	/N#T#06#S2#06#S2#06#S2#06/
770	012134	045	116	045	FMT9:	.ASCIZ	/N#T/
771	012141				FMT10:		;unused
772	012141	045	124	045	FMT11:	.ASCIZ	/T#01/
773	012147	045	124	045	FMT12:	.ASCIZ	/T#03/
774	012155	045	116	045	FMT13:	.ASCIZ	/N#S11#T#03#S1#T#03#S1#T#01#S1#T#01/
775	012221	045	116	045	FMT14:	.ASCIZ	/N#T#T#D3#S1#T#06#S1#T#06/
776	012253	045	116	045	FMT15:	.ASCIZ	/N#S11#T#D3#S1#T#06#S1#T#06/
777	012307	045	116	045	FMT16:	.ASCIZ	/N#S5#06/
778	012320	045	123	061	FMT17:	.ASCIZ	/S10#T#N#S11#06#N/
779	012342	045	116	045	FMT18:	.ASCIZ	/N#S15#T#S5#T#S4#T#S5#T#N/
780	012374	045	124	045	FMT19:	.ASCIZ	/T#S4#D6#S4#D6#S4#D6#S4#D6#N/
781	012431	045	124	045	FMT20:	.ASCIZ	/T#S2#D6#S14#D6#S4#D6#N/
782	012461	045	124	045	FMT21:	.ASCIZ	/T#S12#D6#S14#D6#N/
783	012504	045	116	045	FMT22:	.ASCIZ	/N#S11#T#C3#S1#T#01#S1#T#02/
784	012540	045	124	045	FMT23:	.ASCIZ	/T#T#T#01#N/
785	012554	045	116	045	FMT24:	.ASCIZ	/N#T/
786	012561	045	116	045	FMT25:	.ASCIZ	/N#D2#T/
787	012571	045	116	045	FMT26:	.ASCIZ	/N#S1#T#D4#T#T#D3#N/
788	012615	045	116	045	FMT27:	.ASCIZ	/N#T#D3#T#D3#N/
789	012634	045	116	045	FMT28:	.ASCIZ	/N#T#T#T/
790							.EVEN
792							

1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45

```

.SBTTL  ERROR MESSAGES
:
:  ERR1  R3 POINTS TO RESULT MESSAGE
:        RESULT: (R3)
:
:  ERR2  R3 POINTS TO RESULT NAME
:        RESULT: (R3) IS 1 SB 0
:
:  ERR3  R3 POINTS TO RESULT NAME
:        RESULT: (R3) IS 0 SB 1
:
:  ERR4  R3 POINTS TO RESULT NAME
:        R4 POINTS TO RESULT CONDITIONS
:        RESULT: (R3) IS 1 SB 0 (R4)
:
:  ERR5  R3 POINTS TO RESULT NAME
:        R4 POINTS TO RESULT CONDITIONS
:        RESULT: (R3) IS 0 SB 1 (R4)
:
:  ERR6  RESULT ROUTINE DETERMINES WHICH ERROR(S) ARE SET AND
:        REPORTS ALL
:        RESULT: "ERROR" IS 1 SB 0
:
:  ERR7  DRIVE STATE ERROR REPORT
:        R3 CONTAINS EXPECTED STATE
:        T.STAT CONTAINS BAD STATE
:        RESULT: DRIVE STATE IS (T.STAT) SB (R3)
:
:  ERR8  HEAD POSITIONING ERROR REPORT
:        NEWCYL CONTAINS EXPECTED CYLINDER
:        HDWRD1 CONTAINS BAD CYLINDER
:        RESULT: CYLINDER IS (HDWRD1) SB (NEWCYL)
:
:  ERR9  UTILITY RESULT REPORT
:        R3 POINTS TO RESULT NAME
:        R4 POINTS TO VALUE 1
:        R5 POINTS TO VALUE 2
:        RESULT: (R3-NAME) IS (R4-VALUE 1) SB (R5-VALUE 2)
:
:  ERR10 COMPARE ERROR REPORT
:        R3 CONTAINS THE BAD WORD NUMBER
:        R4 POINTS TO BAD WORD
:        R5 POINTS TO GOOD WORD
:        RESULT: WORD (R3) IS (R4) SB (R5)

```

2	012646	105737	003451	TSTB	NOERCT	:TEST IF ERROR COUNTING INHIBITED
3	012652	001002		BNE	1\$	:YES - SKIP
4	012654	005277	170362	INC	@ERRPOINT	:ELSE BUMP ERROR COUNT
5	012660	010146		1\$: MOV	R1,-(SP)	:STORE R1
6	012662	004737	026274	JSR	PC,RPTOP	:REPORT OPERATION
7	012666	012721	000001	MOV	#1,(R1)+	:SET PARAM NUMBER
8	012672	010321		MOV	R3,(R1)+	:INSERT MESSAGE ADDRESS POINTER
9	012674	004737	027062	JSR	PC,RPTRES	:REPORT RESULTS
10	012700	004737	027270	JSR	PC,RPTREM	:REPORT REMAINDER
11	012704	012601		MOV	(SP)+,R1	:RESTORE R1
12	012706	004737	016616	JSR	PC,CKERLM	:GO CHECK IF ERROR COUNT EXCEEDED
13	012712			L10000:		
	012712	104423		TRAP	C\$MSG	
14						
16	012714	005277	170322	INC	@ERRPOINT	:BUMP ERROR COUNT
17	012720	010146		MOV	R1,-(SP)	:STORE R1
18	012722	004737	026274	JSR	PC,RPTOP	:REPORT OPERATION
19	012726	012721	000003	MOV	#3,(R1)+	:SET PARAM NUMBER
20	012732	010321		MOV	R3,(R1)+	:INSERT NAME ADD POINTER
21	012734	012721	000001	MOV	#1,(R1)+	:SET IS VALUE
22	012740	005021		CLR	(R1)+	:SET SB VALUE
23	012742	004737	027062	JSR	PC,RPTRES	:REPORT RESULTS
24	012746	004737	027270	JSR	PC,RPTREM	:REPORT REMAINDER
25	012752	012601		MOV	(SP)+,R1	:RESTORE R1
26	012754	004737	016616	JSR	PC,CKERLM	:GO CHECK IF ERROR COUNT EXCEEDED
27	012760			L10001:		
	012760	104423		TRAP	C\$MSG	
28						
30	012762	005277	170254	INC	@ERRPOINT	:BUMP ERROR COUNT
31	012766	010146		MOV	R1,-(SP)	:STORE R1
32	012770	004737	026274	JSR	PC,RPTOP	:REPORT OPERATION
33	012774	012721	000003	MOV	#3,(R1)+	:SET PARAM NUMBER
34	013000	010321		MOV	R3,(R1)+	:INSERT NAME ADD POINTER
35	013002	005021		CLR	(R1)+	:SET IS VALUE
36	013004	012721	000001	MOV	#1,(R1)+	:SET SB VALUE
37	013010	004737	027062	JSR	PC,RPTRES	:REPORT RESULTS
38	013014	004737	027270	JSR	PC,RPTREM	:REPORT REMAINDER
39	013020	012601		MOV	(SP)+,R1	:RESTORE R1
40	013022	004737	016616	JSR	PC,CKERLM	:GO CHECK IF ERROR COUNT EXCEEDED
41	013026			L10002:		
	013026	104423		TRAP	C\$MSG	
42						
44	013030	005277	170206	INC	@ERRPOINT	:BUMP ERROR COUNT
45	013034	010146		MOV	R1,-(SP)	:STORE R1
46	013036	004737	026274	JSR	PC,RPTOP	:REPORT OPERATION
47	013042	012721	000004	MOV	#4,(R1)+	:SET PARAM NUMBER
48	013046	010321		MOV	R3,(R1)+	:INSERT NAME ADD POINTER
49	013050	012721	000001	MOV	#1,(R1)+	:SET IS VALUE
50	013054	005021		CLR	(R1)+	:SET SB VALUE
51	013056	010411		MOV	R4,(R1)	:INSERT ADD OF CONDITION POINTER
52	013060	004737	027062	JSR	PC,RPTRES	:REPORT RESULTS
53	013064	004737	027270	JSR	PC,RPTREM	:REPORT REMAINDER
54	013070	012601		MOV	(SP)+,R1	:RESTORE R1
55	013072	004737	016616	JSR	PC,CKERLM	:GO CHECK IF ERROR COUNT EXCEEDED
56	013076			L10003:		
	013076	104423		TRAP	C\$MSG	
57						

59	013100	005277	170136	INC	@ERRPOINT	:BUMP ERROR COUNT
60	013104	010146		MOV	R1,-(SP)	:STORE R1
61	013106	004737	026274	JSR	PC,RPTOP	:REPORT OPERATION
62	013112	012721	000004	MOV	#4,(R1)+	:SET PARAM NUMBER
63	013116	010321		MOV	R3,(R1)+	:INSERT NAME ADD POINTER
64	013120	005021		CLR	(R1)+	:SET IS VALUE
65	013122	012721	000001	MOV	#1,(R1)+	:SET SB VALUE
66	013126	010411		MOV	R4,(R1)	:INSERT ADD OF CONDITION POINTER
67	013130	004737	027062	JSR	PC,RPTRES	:REPORT RESULTS
68	013134	004737	027270	JSR	PC,RPTREM	:REPORT REMAINDER
69	013140	012601		MOV	(SP)+,R1	:RESTORE R1
70	013142	004737	016616	JSR	PC,CKERLM	:GO CHECK IF ERROR COUNT EXCEEDED
71	013146					
	013146	104423		L10004:	TRAP	C\$MSG
72						
74	013150	105737	003451	TSTB	NOERCT	:TEST IF ERROR COUNTING INHIBITED
75	013154	001002		BNE	2\$	:YES - SKIP
76	013156	005277	170060	INC	@ERRPOINT	:ELSE BUMP ERROR COUNT
77	013162	010146		MOV	R1,-(SP)	:STORE R1
78	013164	010346		MOV	R3,-(SP)	:STORE R3
79	013166	010446		MOV	R4,-(SP)	:STORE R4
80	013170	010546		MOV	R5,-(SP)	:STORE R5
81	013172	004737	026274	JSR	PC,RPTOP	:REPORT OPERATION
82	013176	012721	000003	MOV	#3,(R1)+	:SET PARAM NUMBER
83	013202	012761	000001 000002	MOV	#1,2(R1)	:INSERT IS VALUE
84	013210	005037	003126	CLR	TEMP3	:CLEAR FOR STATUS STORAGE
85	013214	013703	003046	MOV	T,CS,R3	:GET T.CS
86	013220	042703	177761	BIC	#177761,R3	:AND CLEAR ALL BUT FUNCTION
87	013224	022703	000004	CMP	#4,R3	:CHECK IF IT WAS GET STATUS
88	013230	001434		BEQ	1\$	:YES - STATUS IS IN T.MP, SKIP
89	013232	012762	000003 000004	MOV	#GETSTAT,RLDA(R2)	:ELSE DO GET STATUS
90	013240	012703	000004	MOV	#4,R3	
91	013244	053703	003034	BIS	RLDRV,R3	
92	013250	010362	000000	MOV	R3,RLCS(R2)	
93	013254	012737	000012 003456	MOV	#10,XDELAY	:SAVE ARGUMENT
	013262	004737	016210	JSR	PC,TIME	:CALL TIMING ROUTINE
94	013266	032762	000200 000000	BIT	#CRDYMSK,RLCS(R2)	:TEST IF READY
95	013274	001003		BNE	4\$	:YES - SKIP
96	013276	012703	001000	MOV	#BIT9,R3	:ELSE SET NO DRIVE STATUS BIT
97	013302	000413		BR	6\$	:IN MESSAGE WORD AND SKIP
98						
99	013304	016203	000006	MOV	RLMP(R2),R3	:STORE STATUS FOR REPORT
100	013310	010337	003126	MOV	R3,TEMP3	
101	013314	113703	003127	MOVB	TEMP3+1,R3	:GET ERROR BITS IN PROPER POSITION
102	013320	000402		BR	5\$	
103						
104	013322	113703	003055	MOVB	T.MP+1,R3	:GET ERROR BITS FROM MP REG
105	013326	042703	177442	BIC	#177442,R3	:CLEAR UNUSED BITS
106	013332	013704	003046	MOV	T,CS,R4	:GET ERROR BITS FROM CS REG
107	013336	042704	001777	BIC	#1777,R4	:CLEAR UNUSED BITS
108	013342	050403		BIS	R4,R3	:MAKE ONE WORD OF POSSIBLE ERRORS
109	013344	032703	002000	BIT	#OPTERR,R3	:TEST IF OPI SET
110	013350	001442		BEQ	11\$	:NO - SKIP
111	013352	032703	010000	BIT	#HNFERR,R3	:TEST IF HDR NOT FOUND ERROR
112	013356	001026		BNE	9\$	:YES - SKIP
113	013360	032703	004000	BIT	#HRCERR,R3	:TEST IF HDR CRC ERR
114	013364	001020		BNE	8\$	:YES - SKIP



```

115 013366 012704 011167          MOV      #MOPERR,R4      ;SET OPI ALONE MESSAGE
116 013372          7$:      MOV      #MERRS, -(SP)
      013372 012746 011472          MOV      R4, -(SP)
      013376 010446          MOV      #MRSLT, -(SP)
      013400 012746 006126          MOV      #FMT28, -(SP)
      013404 012746 012634          MOV      #4, -(SP)
      013410 012746 000004          MOV      SP,R0
      013414 010600          MOV      C,PNTB
      013416 104414          TRAP
      013420 062706 000012          ADD     #12,SP
117 013424 000430          BR      13$              ;SKIP
118
119 013426 012704 010725          8$:      MOV      #MHCRC,R4      ;HDR CRC MESSAGE
120 013432 000757          BR
121
122 013434 032703 004000          9$:      BIT      #HRCERR,R3      ;TEST IF HCRC WITH HDR NOT FND
123 013440 001003          BNE     10$              ;YES - SKIP
124 013442 012704 010746          MOV      #MHNFR,R4      ;MESSAGE HEADER NOT FOUND
125 013446 000751          BR      7$
126
127 013450 012704 010774          10$:     MOV      #MHFCRC,R4      ;HNF AND HCRC MESSAGE
128 013454 000746          BR      7$              ;SKIP
129
130 013456 032703 004000          11$:     BIT      #DCKERR,R3      ;TEST IF DATA CHECK SET, NOT OPI
131 013462 001403          BEQ     12$              ;NO - SKIP
132 013464 012704 010735          MOV      #MDCRC,R4      ;SET MESSAGE DATA CHECK
133 013470 000740          BR      7$              ;SKIP
134
135 013472 032703 010000          12$:     BIT      #DLTERR,R3      ;TEST IF DATA LATE ERROR
136 013476 001403          BEQ     13$              ;NO - SKIP
137 013500 012704 010762          MOV      #MDLT,R4        ;SET MESSAGE DATA LATE
138 013504 000732          BR      7$              ;SKIP
139
140 013506 012705 100000          13$:     MOV      #BIT15,R5      ;SET BIT POINTER FOR TEST
141 013512 005004          CLR     R4                ;CLEAR R4 FOR TABLE COUNT
142 013514 030503          14$:     BIT      R5,R3        ;TEST IF BIT IS SET
143 013516 001005          BNE     16$              ;YES - SKIP TO REPORT
144 013520 005724          15$:     TST     (R4)+        ;ELSE BUMP TABLE POINTER
145 013522 000241          CLC                    ;CLEAR CARRY
146 013524 006005          ROR     R5                ;SHIFT BIT POINTER TO NEXT BIT
147 013526 001372          BNE     14$              ;LOOP IF NOT 0
148 013530 000405          BR      17$              ;ELSE REPORT REMAINDER
149
150 013532 016411 002322          16$:     MOV      RESTBL(R4),(R1) ;INSERT NAME ADDRESS
151 013536 004737 027062          JSR     PC,RPTRES        ;REPORT RESULTS
152 013542 000766          BR      15$              ;GET NEXT BIT
153
154 013544 004737 027270          17$:     JSR     PC,RPTREM        ;REPORT REMAINDER
155 013550 005737 003126          TST     TEMP3            ;TEST IF ANY NEW STATUS
156 013554 001414          BEQ     18$              ;NO - SKIP
157 013556 013746 003126          MOV      TEMP3, -(SP)
      013562 012746 010217          MOV      #STAMES, -(SP)
      013566 012746 012320          MOV      #FMT17, -(SP)
      013572 012746 000003          MOV      #3, -(SP)
      013576 010600          MOV      SP,R0
      013600 104414          TRAP
      013602 062706 000010          ADD     #10,SP

```

```

158 013606 032737 004000 003046 18$: BIT #DCKERR,T.CS ;TEST IF DATA CHECK ERROR
159 013614 001453 BEQ 22$ ;NO - SKIP
160 013616 032737 002000 003046 BIT #OPIERR,T.CS ;TEST IF OPI SET
161 013624 001047 BNE 22$ ;YES - SKIP
162 013626 005037 003016 CLR MORECE ;CLEAR COMPARE ERROR COUNT
163 013632 012701 000200 MOV #128,R1 ;SET COMPARE LENGTH
164 013636 012703 000001 MOV #1,R3 ;SET WORD COUNT
165 013642 012705 005072 MOV #OBUFF,R5 ;SET GOOD WORD POINTER
166 013646 012704 004472 MOV #IBUFF,R4 ;SET TEST WORD POINTER
167 013652 021514 19$: CMP (R5),(R4) ;CHECK WORD
168 013654 001427 BEQ 21$ ;GOOD - SKIP
169 013656 023727 003016 000012 CMP MORECE,#10. ;TEST IF COMPARE LIMIT REACHED
170 013664 003021 BGT 20$ ;YES - SKIP
171 013666 011546 MOV (R5),-(SP)
013670 012746 011507 MOV #RESE4,-(SP)
013674 011446 MOV (R4),-(SP)
013676 012746 011503 MOV #RESE3,-(SP)
013702 010346 MOV R3,-(SP)
013704 012746 006757 MOV #MWORD,-(SP)
013710 012746 012253 MOV #FMT15,-(SP)
013714 012746 000007 MOV #7,-(SP)
013720 010600 MOV SP,R0
013722 104414 TRAP C$PNTB
013724 062706 000020 ADD #20,SP
172 013730 005237 003016 20$: INC MORECE ;BUMP ERROR COUNTER
173 013734 022524 21$: CMP (R5)+,(R4)+ ;BUMP POINTERS
174 013736 005203 INC R3 ;BUMP COUNTER
175 013740 005301 DEC R1 ;DEC LENGTH COUNT
176 013742 001343 BNE 19$ ;LOOP IF NOT DONE
177 013744 005737 003016 22$: TST MORECE ;TEST IF ANY COMPARE ERRORS
178 013750 001421 BEQ 23$ ;NO - SKIP
179 013752 012701 000200 MOV #128,R1 ;SET COMPARE LENGTH
180 013756 010146 MOV R1,-(SP)
013760 012746 011521 MOV #RESE6,-(SP)
013764 013746 003016 MOV MORECE,-(SP)
013770 012746 010230 MOV #TCERR,-(SP)
013774 012746 012615 MOV #FMT27,-(SP)
014000 012746 000005 MOV #5,-(SP)
014004 010600 MOV SP,R0
014006 104414 TRAP C$PNTB
014010 062706 000014 ADD #14,SP
181 014014 012605 23$: MOV (SP)+,R5 ;RESTORE R5, 4, 3, 1
182 014016 012604 MOV (SP)+,R4
183 014020 012603 MOV (SP)+,R3
184 014022 012601 MOV (SP)+,R1
185 014024 004737 016616 JSR PC,CKERLM ;GO CHECK IF ERROR COUNT EXCEEDED
186 014030 L10005: JSR PC,CKERLM
014030 104423 TRAP C$MSG
187
189 014032 005277 167204 INC @ERRPOINT ;BUMP ERROR COUNT
190 014036 010146 MOV R1,-(SP) ;STORE R1
191 014040 004737 026274 JSR PC,RPTOP ;REPORT OPERATION
192 014044 012721 000003 MOV #3,(R1)+ ;SET PARAM NUMBER
193 014050 012721 011052 MOV #MDRVST,(R1)+ ;INSERT NAME ADD POINTER
194 014054 013721 003062 MOV T,STAT,(R1)+ ;INSERT IS VALUE
195 014060 010311 MOV R3,(R1) ;INSERT SB VALUE
196 014062 004737 027062 JSR PC,RPTRES ;REPORT RESULTS

```

197	014066	004737	027270		JSR	PC,RPTREM	:REPORT REMAINDER
198	014072	012601			MOV	(SP)+,R1	:RESTORE R1
199	014074	004737	016616		JSR	PC,CKERLM	:GO CHECK IF ERROR COUNT EXCEEDED
200	014100			L10006:			
	014100	104423			TRAP	C\$MSG	
201							
203	014102	005277	167134		INC	@ERRPOINT	:BUMP ERROR COUNT
204	014106	010146			MOV	R1,-(SP)	:STORE R1
205	014110	010346			MOV	R3,-(SP)	:STORE R3
206	014112	004737	026274		JSR	PC,RPTOP	:REPORT OPERATION
207	014116	012721	000003		MOV	#3,(R1)+	:SET PARAM NUMBER
208	014122	012721	011267		MOV	#MCYLOC,(R1)+	:INSERT NAME ADD POINTER
209	014126	013711	003054		MOV	HDWRD1,(R1)	:GET HEADER WORD
210	014132	012703	000007		MOV	#7,R3	:SET SHIFT COUNT
211	014136	000241		14\$:	CLC		
212	014140	006011			ROR	(R1)	:ALIGN CHAR FOR PRINTING
213	014142	005303			DEC	R3	: AS IS VALUE
214	014144	001374			BNE	14\$	
215	014146	005721			TST	(R1)+	:BUMP PARAM POINTER
216	014150	013711	003104		MOV	NEWCYL,(R1)	:INSERT SB VALUE
217	014154	004737	027062		JSR	PC,RPTRES	:REPORT RESULTS
218	014160	004737	027270		JSR	PC,RPTREM	:REPORT REMAINDER
219	014164	012603			MOV	(SP)+,R3	:RESTORE R3
220	014166	012601			MOV	(SP)+,R1	:RESTORE R1
221	014170	004737	016616		JSR	PC,CKERLM	:GO CHECK IF ERROR COUNT EXCEEDED
222	014174			L10007:			
	014174	104423			TRAP	C\$MSG	
223							
225	014176	005277	167040		INC	@ERRPOINT	:BUMP ERROR COUNT
226	014202	010146			MOV	R1,-(SP)	:STORE R1
227	014204	004737	026274		JSR	PC,RPTOP	:REPORT OPERATION
228	014210	012721	000003		MOV	#3,(R1)+	:SET PARAM NUMBER
229	014214	010321			MOV	R3,(R1)+	:INSERT NAME ADD POINTER
230	014216	C10421			MOV	R4,(R1)+	:SET IS VALUE
231	014220	010521			MOV	R5,(R1)+	:SET SB VALUE
232	014222	004737	027062		JSR	PC,RPTRES	:REPORT RESULTS
233	014226	004737	027270		JSR	PC,RPTREM	:REPORT REMAINDER
234	014232	012601			MOV	(SP)+,R1	:RESTORE R1
235	014234	004737	016616		JSR	PC,CKERLM	:GO CHECK IF ERROR COUNT EXCEEDED
236	014240			L10010:			
	014240	104423			TRAP	C\$MSG	
237							
239	014242	010146			MOV	R1,-(SP)	:STORE R1
240	014244	005737	003016		TST	MORECE	:TEST IF 2ND BAD LINE
241	014250	001051			BNE	14\$	:YES - SKIP
242	014252	005277	166764		INC	@ERRPOINT	:BUMP ERROR COUNT
243	014256	004737	026274		JSR	PC,RPTOP	:REPORT OPERATION
244	014262	005046			CLR	-(SP)	
	014264	153716	003035		BISB	RLDRV+1,(SP)	
	014270	012746	006621		MOV	#DRVNAM,-(SP)	
	014274	013746	003030		MOV	RLBAS,-(SP)	
	014300	012746	006610		MOV	#BASADD,-(SP)	
	014304	012746	011750		MOV	#FMT5,-(SP)	
	014310	012746	000005		MOV	#5,-(SP)	
	014314	010600			MOV	SP,R0	
	014316	104414			TRAP	C\$PNTB	
	014320	062706	000014		ADD	#14,SP	

245	014324	011546		MOV	(R5),-(SP)	
	014326	012746	011507	MOV	#RESE4,-(SP)	
	014332	011446		MOV	(R4),-(SP)	
	014334	012746	011503	MOV	#RESE3,-(SP)	
	014340	010346		MOV	R3,-(SP)	
	014342	012746	006757	MOV	#MWORD,-(SP)	
	014346	012746	006126	MOV	#MRSLT,-(SP)	
	014352	012746	012221	MOV	#FMT14,-(SP)	
	014356	012746	000010	MOV	#10,-(SP)	
	014362	010600		MOV	SP,R0	
	014364	104414		TRAP	C\$PNTB	
	014366	062706	000022	ADD	#22,SP	
246	014372	000421		BR	15\$	
247						
248	014374					
	014374	011546	14\$:	MOV	(R5),-(SP)	
	014376	012746	011507	MOV	#RESE4,-(SP)	
	014402	011446		MOV	(R4),-(SP)	
	014404	012746	011503	MOV	#RESE3,-(SP)	
	014410	010346		MOV	R3,-(SP)	
	014412	012746	006757	MOV	#MWORD,-(SP)	
	014416	012746	012253	MOV	#FMT15,-(SP)	
	014422	012746	000007	MOV	#7,-(SP)	
	014426	010600		MOV	SP,R0	
	014430	104414		TRAP	C\$PNTB	
	014432	062706	000020	ADD	#20,SP	
249	014436	005237	003016	15\$:	INC	MORECE
250	014442	012601		MOV	(SP)+,R1	:INC COMPARE ERROR COUNT
251	014444	004737	016616	JSR	PC,CKERLM	:RESTORE R1
252	014450					:GO CHECK IF ERROR COUNT EXCEEDED
	014450	104423	L10011:	TRAP	C\$MSG	

```

1
2
3
4 014452 000000
5 014454 177777
6 014456 000011
7
8
9
11 014460 000006
12 014462 174400
13 014464 000160
14 014466 000240
15 014470 000001
16 014472 000000
17 014474 000001
18 014476
19
20
22 014476 000007
23 014500 000000
24
25
26
27
28
29
30
31 014502 000000
32 014504 000377
33 014506 000000
34 014510 000024
35 014512 000012
36 014514 000000
37 014516
38
39
45 014516 000010
    014520 027554
    014522 031474
    014524 031526
    014526 031750
    014530 032564
    014532 033702
    014534 034726
    014536 036150

;LOAD PROTECTION TABLE

        .WORD 0 ;OFFSET OF CSR IN P-TABLE
        .WORD -1 ;NOT A MASS-BUS DRIVE
        .WORD DRSB+1 ;OFFSET OF DRIVE IN P-TABLE
        .EVEN

        .WORD L10013-L$HW/2
        .WORD 174400 ;CSR BASE ADDRESS DEFAULT
        .WORD 160 ;VECTOR DEFAULT
        .WORD 240 ;PRIORITY DEFAULT
        .WORD 1 ;TYPE OF DRIVE
        .WORD 0 ;DRIVE NUMBER DEFAULT
        .WORD 1 ;RL11 CONTROLLER
L10013:

        .WORD L10014-L$SW/2
MISWIW: .WORD 0
;BIT 0 = USE ALL CYLINDERS
;BIT 1 = USE ALL SECTORS
;BIT 2 = EXECUTE DRIVE SELECT TEST
;BIT 3 = EXECUTE HEAD ALIGNMENT
;BIT 12 = HEAD SELECT SUPPLIED FLAG
;BIT 13 = HILIMIT SPECIFIED FLAG
;BIT 14 = LO LIMIT SPECIFIED FLAG
;BIT 15 = DO MANUAL INTERVENTION

        .WORD 0
        .WORD 255.
        .WORD 0
        .WORD 20. ;ERROR LIMIT
        .WORD 10. ;COMPARE ERROR LIMIT
        .WORD 0 ;BSF ERROR OUTPUT FLAG

        .WORD 8
        .WORD T1
        .WORD T2
        .WORD T3
        .WORD T4
        .WORD T5
        .WORD T6
        .WORD T7
        .WORD T8

```

1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50

.SBTTL INITIALIZATION SECTION

;CHECK FOR PRESENCE OF A P-CLOCK

```

CLR    CLKFLG      ;CLEAR CLOCK FLAG
MOV    #'P,RO
TRAP   C$CLK
MOV    RO,CLKADR
BCC    1$
INC    CLKFLG      ;INDICATE PRESENCE OF A P-CLOCK

```

1\$:

```

MOV    #340,RO
TRAP   C$SPRI
TRAP   C$RESET
TRAP   C$MANI
BCS    2$
BIC    #MITEST!DRSELT!HDALIGN,MISWIW ;CLEAR ALL MANUAL
                                           ;INTERVENTION FLAGS

```

2\$:

```

CLR    SSINDX      ;CLEAR SUBROUTINE STACK INDEX
MOV    #EF.PWR,RO
TRAP   C$REFG
BCC    3$
MOV    L$UNIT,PWRFLG ;SET POWER FAIL FLAG
JMP    PWCON       ;GO SERVICE POWER FAIL

```

3\$:

```

MOV    #EF.START,RO
TRAP   C$REFG
BCC    RESTART

```

; ON START INITIALIZE TO START AT FIRST DRIVE, CLEAR INTERNAL  
PASS COUNT, AND ERROR COUNT.

```

RSTRT: MOV    L$UNIT,DRVCNT ;SET UP UNIT COUNT
        CLR    PASNUM      ;CLEAR PASS NUMBER
        MOV    #ERRCNT,RO
        MOV    #64,R1      ;GET A COUNT
        CLR    (RO)+       ;CLEAR AN ERROR COUNTER STORAGE AREA
        DEC    R1
        BNE    1$

```

1\$:

```

        ;LOOP TILL ALL CLEARED
        MOV    #ERRCNT-2,ERRPOINT ;INIT ERROR POINTER
        MOV    #-1,PSETNM ;SET PARAM SELECT TO INITIAL VALUE
        MOV    #-1,HADONE ;PRESET HEAD ALIGN DONE FLAG
        BIT    #LOCYL,MISWIW ;TEST IF LO LIMIT SET
        BNE    2$          ;YES - SKIP
        CLR    LOLIMW      ;ELSE CLEAR LO LIMIT
        BR     SETDON

```

2\$:

```

RESTART: MOV    #EF.RESTART,RO
          TRAP   C$REFG
          BCS    RSTRT

```

CONTINUE:

```

MOV    #EF.CONTINUE,RO
TRAP   C$REFG
BCS    PWCON

```

```

51
52
53 014754 012700 000035 ; ON CONTINUE PICK UP UNIT LAST UNDER TEST
   014760 104447
   014762 103403
54
55
56 014764 005737 003076 NXPAS: TST DRVCNT ;TEST IF ALL UNITS CHECKED
57 014770 001013 BNE SETDON ;NO - SKIP
58
59 014772 005237 003444 PASNEW: INC PASNUM ;ELSE BUMP PASS COUNT
60 014776 012737 003242 003242 MOV #ERRCNT-2,ERRPOINT ;INIT ERROR POINTER
61 015004 013737 002012 003076 MOV L$UNIT,DRVCNT ;GET ALL DRIVES
62 015012 012737 177777 003446 MOV #-1,PSETNM ;SET PARAM SELECT TO INITIAL
63
64 015020 005037 003500 SETDON: CLR BSFVAL ;ENABLE BAD SEC FILE READ
65 015024 005237 003446 INC PSETNM ;NEXT SET OF PARAMETERS
66 015030 005337 003076 DEC DRVCNT ;DOWN COUNT DRIVE TOTAL
67 015034 062737 000002 003242 ADD #2,ERRPOINT ;UPDATE THE ERROR POINTER
68 015042 013700 003446 MOV PSETNM,R0 ;SET UP TO GET PARAMETERS
69 015046 012702 003030 MOV #RLBAS,R2
70 015052 104442 TRAP C$GPHRD
   015054 010001 MOV R0,R1
71 015056 103406 BCS 1$
72 015060 005737 003454 TST PWRFLG ;RECENT POWER FAILURE
73 015064 001737 BEQ NXPAS ;NO
74 015066 005337 003454 DEC PWRFLG ;ACCOUNT FOR DRIVE
75 015072 000734 BR NXPAS
76
77 015074 012122 1$: MOV (R1)+,(R2)+ ;STORE PARAMETERS CSR
78 015076 012122 MOV (R1)+,(R2)+ ; VECTOR
79 015100 005721 TST (R1)+ ;BUMP PAST PRIORITY
80 015102 012137 002300 MOV (R1)+,T.DRIVE
81 015106 012122 MOV (R1)+,(R2)+
82 015110 022737 000001 002300 CMP #1,T.DRIVE ;IS THIS AN RL01 TYPE DRIVE?
83 015116 001426 BEQ 2$ ;BRANCH IF YES, ELSE
84 015120 012737 000776 002310 MOV #510.,NXTHL ;SETUP PARAMETERS FOR AN RL02 DRIVE
85 015126 012737 000777 002304 MOV #511.,HLMTW
86 015134 012737 001000 002312 MOV #512.,GBND
87 015142 012737 177600 002314 MOV #177600,CAMSK
88 015150 012737 177600 002316 MOV #177600,DIRMSK
89 015156 012737 177600 002320 MOV #177600,HDCYL
90 015164 012737 177000 002306 MOV #177000,CLRBYT
91 015172 000425 BR PWCON
92
93 015174 012737 000377 002304 2$: MOV #255.,HLMTW ;SETUP PARAMETERS FOR AN RL01 DRIVE
94 015202 012737 000400 002312 MOV #256.,GBND
95 015210 012737 077600 002314 MOV #77600,CAMSK
96 015216 012737 077600 002316 MOV #77600,DIRMSK
97 015224 012737 077600 002320 MOV #77600,HDCYL
98 015232 012737 000376 002310 MOV #254.,NXTHL
99 015240 012737 177400 002306 MOV #177400,CLRBYT
100
101 015246 032737 020000 014500 PWCON: BIT #HICYL,MISWIW ;SELECT HI CYLINDER ENABLED?
102 015254 001003 BNE 1$ ;BRANCH IF NO
103 015256 013737 002304 014504 MOV HLMTW,HILIMW ;SETUP HI CYLINDER LIMIT WORD
104 015264 1$:
   015264 012746 000340 MOV #340,-(SP)

```

L5

```

015270 012746 016536      MOV      #INTHLR, -(SP)
015274 013746 003032      MOV      RLVEC, -(SP)
015300 012746 000003      MOV      #3, -(SP)
015304 104437                TRAP     C$SVEC
015306 062706 000010      ADD      #10, SP
105 015312 012700 000000      MOV      #0, R0
015316 104441                TRAP     C$SPRI
106 015320 013702 003030      MOV      RLBAS, R2          ;SET RL11 BASE ADDRESS POINTER
116
117                      ;CHECK IF POWER FAILURE WAIT IS NEEDED
118
119 015324 005737 003454      TST      PWRFLG           ;NEEDED???
120 015330 001472                BEQ      3$              ;NO, SKIP
121
122 015332 013705 003034      MOV      RLCRV, R5        ;DRIVE SELECT
123 015336 052705 000200      BIS      #CRDYMSK, R5    ;SET CRDY
124 015342 010562 000000      MOV      R5, RLCS(R2)    ;SELECT DRIVE
125 015346 012701 000170      MOV      #120, R1       ;INITIALIZE WAIT COUNT
126 015352 032762 000001 000000 2$:    BIT      #DRDYMSK, RLCS(R2) ;DRIVE UP YET?
127 015360 001056                BNE      3$              ;YES START TEST
128
129 015362 012737 000012 003460      MOV      #10, YDELAY     ;SAVE ARGUMENT
015370 004737 016354                JSR      PC, XTIME       ;CALL TIMING ROUTINE
130 015374 005301                DEC      R1              ;SIXTY GONE BY
131 015376 001365                BNE      2$              ;NO
132 015400 012746 006645      MOV      #NOPWR, -(SP)
015404 012746 012554      MOV      #FMT24, -(SP)
015410 012746 000002      MOV      #2, -(SP)
015414 010600                MOV      SP, R0
015416 104417                TRAP     C$PNTF
015420 062706 000006      ADD      #6, SP
133 015424 005046                CLR      -(SP)
015426 153716 003035      BISB    RLDRV+1, (SP)
015432 012746 006621      MOV      #DRVNAM, -(SP)
015436 013746 003030      MOV      RLBAS, -(SP)
015442 012746 006610      MOV      #BASADD, -(SP)
015446 012746 011750      MOV      #FMT5, -(SP)
015452 012746 000005      MOV      #5, -(SP)
015456 010600                MOV      SP, R0
015460 104417                TRAP     C$PNTF
015462 062706 000014      ADD      #14, SP
134 015466 012746 011623      MOV      #CRLF, -(SP)
015472 012746 000001      MOV      #1, -(SP)
015476 010600                MOV      SP, R0
015500 104417                TRAP     C$PNTF
015502 062706 000004      ADD      #4, SP
135 015506 013700 003446      MOV      PSETNM, R0
015512 104451                TRAP     C$DODU
136 015514 104444                TRAP     C$DCLN
137
138
139 015516                3$:
015516 104411      L10015: TRAP     C$INIT

```



1  
2  
3  
4  
5  
6  
7  
8  
9

.SBTTL AUTO DROP SECTION

;THE AUTO DROP SECTION IS INVOKED BY THE DIAGNOSTIC SUPERVISOR WHENEVER THE  
;"ADR" FLAG IS SET BY THE OPERATOR. IT IS EXECUTED AFTER THE INITIALIZATION  
;CODE AND CHECKS THE DRIVE TO DETERMINE IF IT IS READY TO RECEIVE A COMMAND.  
;IF THE DRIVE IS NOT READY IT IS DROPPED FROM THE TEST CYCLE AND THE NEXT  
;DRIVE IS ACCESSED. IF THE DRIVE IS READY THE HARDWARE TESTS ARE PERFORMED  
;AFTER WHICH THE NEXT DRIVE IS ACCESSED.

```

11 015520 005037 003452      CLR      TRPFLG      ;CLEAR TRAP FLAG
12 015524 012746 000340      MOV      #340,-(SP)
    015530 012746 016530      MOV      #TRPHAN,-(SP)
    015534 013746 003232      MOV      ERRVEC,-(SP)
    015540 012746 000003      MOV      #3,-(SP)
    015544 104437      TRAP    C$SVEC
    015546 062706 000010      ADD     #10,SP

13                                ;/NON-EXISTENT CONTROLLER
14 015552 013702 003030      MOV      RLBAS,R2      ;GET RL11 BASE ADDRESS
15 015556 005762 000000      TST     RLCS(R2)      ;ACCESS DRIVE CONTROLLER ADDRESS
16 015562 005737 003452      TST     TRPFLG        ;DID TRAP OCCUR?
17 015566 001447      BEQ     1$            ;BRANCH TO CHECK DRIVE IF TRAP DID NOT OCCUR
18 015570 012746 010251      MOV      #NOCTLR,-(SP)
    015574 012746 012554      MOV      #FMT24,-(SP)
    015600 012746 000002      MOV      #2,-(SP)
    015604 010600      MOV     SP,R0
    015606 104417      TRAP    C$PNTF
    015610 062706 000006      ADD     #6,SP
19 015614 005046      CLR     -(SP)
    015616 153716 003035      BISB    RLDV+1,(SP)
    015622 012746 006621      MOV     #DRVNAM,-(SP)
    015626 013746 003030      MOV     RLBAS,-(SP)
    015632 012746 006610      MOV     #BASADD,-(SP)
    015636 012746 011750      MOV     #FMT5,-(SP)
    015642 012746 000005      MOV     #5,-(SP)
    015646 010600      MOV     SP,R0
    015650 104417      TRAP    C$PNTF
    015652 062706 000014      ADD     #14,SP

20                                ;PRINT DRIVE INFORMATION
21 015656 012746 011623      MOV     #CRLF,-(SP)
    015662 012746 000001      MOV     #1,-(SP)
    015666 010600      MOV     SP,R0
    015670 104417      TRAP    C$PNTF
    015672 062706 000004      ADD     #4,SP

22
23 015676 013700 003446      MOV     PSETNM,R0
    015702 104451      TRAP    C$DODU
24 015704 000460      BR     2$            ;BRANCH TO EXIT
25
26 015706 013705 003034      1$: MOV     RLDV,R5      ;ELSE, GET DRIVE NUMBER
27 015712 052705 000200      BIS     #CRDYMSK,R5   ;SET CONTROLLER READY
28 015716 010562 000000      MOV     R5,RLCS(R2)  ;LOAD IN THE DRIVE NUMBER
29 015722 032762 000001 000000  BIT     #DRDYMSK,RLCS(R2) ;IS DRIVE READY?
30 015730 001046      BNE     2$            ;BRANCH TO PERFORM TESTS IF DRIVE IS READY
31 015732 012746 010307      MOV     #NOTRDY,-(SP)
    015736 012746 012554      MOV     #FMT24,-(SP)
    015742 012746 000002      MOV     #2,-(SP)
    015746 010600      MOV     SP,R0

```

	015750	104417		TRAP	C\$PNTF	
	015752	062706	000006	ADD	#6, SP	
32						
33	015756	005046		CLR	-(SP)	;/WITH 'READY' "
	015760	153716	003035	BISB	RLDRV+1, (SP)	
	015764	012746	006621	MOV	#DRVNAM, -(SP)	
	015770	013746	003030	MOV	RLBAS, -(SP)	
	015774	012746	006610	MOV	#BASADD, -(SP)	
	016000	012746	011750	MOV	#FMT5, -(SP)	
	016004	012746	000005	MOV	#5, -(SP)	
	016010	010600		MOV	SP, RO	
	016012	104417		TRAP	C\$PNTF	
	016014	062706	000014	ADD	#14, SP	
34						
35	016020	012746	011623	MOV	#CRLF, -(SP)	;/PRINT DRIVE INFORMATION
	016024	012746	000001	MOV	#1, -(SP)	
	016030	010600		MOV	SP, RO	
	016032	104417		TRAP	C\$PNTF	
	016034	062706	000004	ADD	#4, SP	
36	016040	013700	003446	MOV	PS\$TNM, RO	
	016044	104451		TRAP	C\$DODU	
37	016046					
	016046	013700	003232	MOV	ERRVEC, RO	
	016052	104436		TRAP	C\$CVEC	
38	016054					
	016054	104461		TRAP	C\$AUTO	

2\$:

L10016:

```

1
2
3
4
5 016056 012746 000340      MOV    #340,-(SP)
   016062 012746 016530      MOV    #TRPHAN,-(SP)
   016066 013746 003232      MOV    ERRVEC,-(SP)
   016072 012746 000003      MOV    #3,-(SP)
   016076 104437      TRAP   C#SVEC
   016100 062706 000010      ADD    #10,SP
6 016104 012700 000007      MOV    #7,R0
   016110 104441      TRAP   C#SPRI
7 016112 032752 000200 000000 1$:  BIT    #CRDYMSK,RLCS(R2)      ;TEST IF CONTROLLER READY
8 016120 001407      BEQ    2$                    ;NO LOOP UNTIL READY
9 016122 053762 003034 000000      BIS    RLDRV,RLCS(R2)        ;SET DRIVE NUMBER
10 016130 032762 000001 000000      BIT    #DRDYMSK,RLCS(R2)     ;TEST IF DRIVE BUSY
11 016136 001005      BNE    3$                    ;NO - SKIP
12 016140      MOV    #3,YDELAY            ;SAVE ARGUMENT
   016146 004737 016354 003460      JSR    PC,XTIME              ;CALL TIMING ROUTINE
13 016152      MOV    RLVEC,R0
   016156 013700 003032      TRAP   C#CVEC
14 016160 005737 003454      TST    PWRFLG                ;PWR FAIL SET
15 016164 001402      BEQ    4$                    ;NO
16 016166 005337 003454      DEC    PWRFLG
17 016172      MOV    ERRVEC,R0
   016176 013700 003232      TRAP   C#CVEC
18 016200 104433      TRAP   C#RESET
19 016202      TRAP   C#CLEAN
   016202 104412      L10017:
21 016204 000240      NOP
22 016206 104453      L10020:
   016206      TRAP   C#DU
  
```

```

.SBTTL GLOBAL SUBROUTINES
1
2
4
5 016210 012737 000160 002116 TIME: MOV #160,L$DLY ;GET OUTER DELAY LOOP
6 016216 005237 003466 INC TIM.US ;US-WAIT ROUTINE INDICATOR
7 016222 013737 003456 003462 MOV XDELAY,MININC ;SAVE ORIGINAL US-WAIT
8 016230 005437 003456 NEG XDELAY ;GET RELATIVE OF FACTOR
9 016234 104407 TRAP C$RDBU
10 016236 103420 BCS 2$
11 016240 1$:
11 016240 012727 000001 MOV #1..(PC)+
11 016244 000000 .WORD 0
11 016246 013727 002116 MOV L$DLY,(PC)+
11 016252 000000 .WORD 0
11 016254 005367 177772 DEC -6(PC)
11 016260 001375 BNE -.4
11 016262 005367 177756 DEC -22(PC)
11 016266 001367 BNE -.20
12 016270 005237 003456 INC XDELAY ;WAIT FACTOR EXPIRED?
13 016274 002761 BLT 1$ ;BRANCH - IF NO
14 016276 000422 BR 4$ ;GET TIME
15
16 016300 012737 000065 002116 2$: MOV #65,L$DLY ;GET OUTER DELAY LOOP
17 016306 3$:
17 016306 012727 000001 MOV #1..(PC)+
17 016312 000000 .WORD 0
17 016314 013727 002116 MOV L$DLY,(PC)+
17 016320 000000 .WORD 0
17 016322 005367 177772 DEC -6(PC)
17 016326 001375 BNE -.4
17 016330 005367 177756 DEC -22(PC)
17 016334 001367 BNE -.20
18 016336 005237 003456 INC XDELAY ;WAIT FACTOR EXPIRED?
19 016342 002761 BLT 3$ ;BRANCH - IF NO
20 016344 063737 003462 003120 4$: ADD MININC,TEMPO ;GET TIME EXPIRED
21 016352 000207 RTS PC ;RETURN
22
23 016354 012737 000160 002116 XTIME: MOV #160,L$DLY ;GET OUTER DELAY LOOP
24 016362 005037 003466 CLR TIM.US ;MS. WAIT INDICATOR
25 016366 013737 003460 003472 MOV YDELAY,MAJINC ;SAVE ORIGINAL WAIT MS
26 016374 006337 003460 ASL YDELAY ;MULTIPLY BY FACTOR 4
27 016400 006337 003460 ASL YDELAY ;-----
28 016404 005437 003460 NEG YDELAY ;GET NEGATIVE OF RESULT
29 016410 104407 TRAP C$RDBU
30 016412 103023 BCC 2$
31 016414 012737 000150 002116 MOV #150,L$DLY ;GET OUTER DELAY LOOP
32 016422 1$:
32 016422 012727 000020 MOV #20,(PC)+
32 016426 000000 .WORD 0
32 016430 013727 002116 MOV L$DLY,(PC)+
32 016434 000000 .WORD 0
32 016436 005367 177772 DEC -6(PC)
32 016442 001375 BNE -.4
32 016444 005367 177756 DEC -22(PC)
32 016450 001367 BNE -.20
33 016452 005237 003460 INC YDELAY ;WAIT FACTOR EXPIRED
34 016456 002761 BLT 1$ ;BRANCH - IF NO

```

D6

```

35 016460 000417          BR      3$          ;GET TIME
36
37 016462          2$:
   016462 012727 000010    MOV     #10,(PC)+
   016466 000000          .WORD  0
   016470 013727 002116    MOV     L$DLY,(PC)+
   016474 000000          .WORD  0
   016476 005367 177772    DEC     -6(PC)
   016502 001375          BNE     -4
   016504 005367 177756    DEC     -22(PC)
   016510 001367          BNE     -20
38 016512 005237 003460    INC     YDELAY          ;WAIT FACTOR EXPIRED?
39 016516 002761          BLT     2$             ;BRANCH - IF NO
40 016520 063737 003472 003464 3$:      ADD     MAJINC,TEMP    ;GET EXPIRED TIME
41 016526 000207          RTS     PC             ;RETURN
42
44
45
46          ;TRAP HANDLER INDICATES OCCURRENCE OF A TRAP.
47 016530 005237 003452    TRPHAN: INC     TRPFLG
48
49 016534          L10021:
   016534 000002          RTI
51
52          ;INTERRUPT HANDLER. ABORTS WAIT TIMER AND STORES RL11 REGISTERS.
53
54 016536 012237 003046    INTHLR: MOV     (R2)+,T.CS      ;STORE RL REGISTERS
55 016542 012237 003050          MOV     (R2)+,T.BA
56 016546 012237 003052          MOV     (R2)+,T.DA
57 016552 011237 003054          MOV     (R2)+,T.MP
58 016556 012737 177777 003010    MOV     #-1,DONE        ;SET DONE FLAG
59 016564 013702 003030          MOV     RLBAS,R2       ;RESTORE R2
60 016570 013737 003456 003120    MOV     XDELAY,TEMPO    ;SAVE MICRO-SEC RUN TIME
   016576 013737 003460 003464    MOV     YDELAY,TEMP    ;SAVE MILLI-SEC RUN TIME
   016604 005037 003456          CLR     XDELAY         ;ABORT MICRO-SEC WAIT
   016610 005037 003460          CLR     YDELAY         ;ABORT MILLI-SEC WAIT
61 016614          L10022:
   016614 000002          RTI

```

```

1
2
3
4 016616 027737 164420 014510 CKERLM: CMP @ERRPOINT,ERLIMW ;TEST IF ERROR LIMIT EXCEEDED
5 016624 002453 BLT 1$ ;NO - SKIP
6 016626 104420 TRAP C$INLP
7 016630 103451 BCS 1$
8 016632 012746 011435 MOV #MEXERS,-(SP)
016636 013746 014510 MOV ERLIMW,-(SP)
016642 012746 012561 MOV #FMT25,-(SP)
016646 012746 000003 MOV #3,-(SP)
016652 010600 MOV SP,RO
016654 104417 TRAP C$PNTF
016656 062706 000010 ADD #10,SP
9 016662 005046 CLR -(SP)
016664 153716 003035 BISB RLDRV+1,(SP)
016670 012746 006621 MOV #DRVNAM,-(SP)
016674 013746 003030 MOV RLBAS,-(SP)
016700 012746 006610 MOV #BASADD,-(SP)
016704 012746 011750 MOV #FMT5,-(SP)
016710 012746 000005 MOV #5,-(SP)
016714 010600 MOV SP,RO
016716 104417 TRAP C$PNTF
016720 062706 000014 ADD #14,SP
10 016724 012746 011623 MOV #CRLF,-(SP)
016730 012746 000001 MOV #1,-(SP)
016734 010600 MOV SP,RO
016736 104417 TRAP C$PNTF
016740 062706 000004 ADD #4,SP
11 016744 013700 003446 MOV PSETNM,RO
016750 104451 TRAP C$DODU
12 016752 104444 TRAP C$DCLN
13 016754 000207 1$: RTS PC
14
15
16 ; READ AND STORE ALL RL11 REGISTERS
17 016756 016237 000000 003046 READRL: MOV RLCSR(R2),T,CS ;GET CS REG
18 016764 016237 000002 003050 MOV RLBA(R2),T,BA ;GET BUS ADDRESS REG
19 016772 016237 000004 003052 MOV RLDA(R2),T,DA ;GET DISK ADDRESS
20 017000 016237 000006 003054 MOV RLMP(R2),T,MP ;GET MULTI-PURPOSE REG
21 017006 000207 RTS PC ;RETURN

```

```

1      ;      WAIT FOR CONTROLLER TIMEOUT TO FORCE INTERRUPT ROUTINE
2
3      017010 011646      WAITIN: MOV      (SP),-(SP)      ;MAKE ROOM FOR ERROR POINTER
4      017012 005066      CLR      2(SP)      ;CLEAR FOR POINTER
5      017016 032762 000002 000000      BIT      #CRDYMSK,RLCSR(R2) ;TEST IF CONTROLLER READY
6      017024 001420      BEQ      3$      ;NO - SKIP TO WAIT
7      017026 004737 016756      JSR      PC,READRL ;READ ALL RL REGS
8      017032 005737 003010      TST      DONE      ;TEST IF INTERRUPT OCCURRED
9      017036 001435      BEQ      5$      ;NO - GO SET NO INTERRUPT ERR FLAG
10     017040 012766 006765 000002 1$:  MOV      #MTOSLOW,2(SP) ;ELSE SET TOO SLOW ERROR POINTER
11     017046 032737 002000 003046      BIT      #OPIERR,↑.CS ;TEST IF OPI SET
12     017054 001403      BEQ      2$      ;NO - SKIP
13     017056 012766 007005 000002      MOV      #MDRRES,2(SP) ;SET MESSAGE FOR NO DRIVE RESPONSE
14     017064 000207      RTS      PC      ;RETURN
15     017066      3$:
16     017066 012737 000003 003460      MOV      #3,YDELAY ;SAVE ARGUMENT
17     017074 004737 016354      JSR      PC,XTIME ;CALL TIMING ROUTINE
18     017100 032762 000200 000000      BIT      #CRDYMSK,RLCS(R2) ;TEST IF READY NOW SET
19     017106 001006      BNE      4$      ;YES - SKIP
20     017110 004737 016756      JSR      PC,READRL ;READ RL REGS
21     017114 012766 007056 000002      MOV      #MCONHNG,2(SP) ;SET MESSAGE FOR CONTROLLER HUNG
22     017122 000760      BR      2$      ;SKIP
23     017124 005737 003010      4$:  TST      DONE      ;ELSE CHECK IF INTERRUPT OCCURRED
24     017130 001343      BNE      1$      ;YES - SKIP TO SET TOO SLOW
25     017132 004737 016756      5$:  JSR      PC,READRL ;READ RL REGS
26     017136 012766 007023 000002      MOV      #MNOINT,2(SP) ;ELSE SET NO INTERRUPT FLAG
27     017144 000747      BR      2$      ;GO TO RETURN
28
29     ;      OPERATION AND TEST INITIALIZE ROUTINE
30     017146 005037 003006      TSTINT: CLR      OPFLAG ;CLEAR OPERATION FLAGS
31     017152 105037 003451      CLR      NOERCT ;RESET INHIBIT ERROR COUNTING
32     017156 005037 003016      CLR      MORECE ;RESET MORE COMPARE ERRORS
33     017162 000207      RTS      PC

```

```

1      ; GET STATUS AND GET STATUS WITH RESET ROUTINE
2
3 017164 013746 003130      ;GSTATR: MOV    TEMP4,-(SP)      ;STORE TEMP4
4 017170 012737 000013 003130  MOV    #GETSTAT!DRSET,TEMP4  ;SET FOR RESET
5 017176 000412          BR      GSTATG
6
7 017200 013746 003130      ;GSTATC: MOV    TEMP4,-(SP)      ;STORE TEMP4
8 017204 012737 000003 003130  MOV    #GETSTAT,TEMP4      ;SET FOR NO RESET
9 017212 000404          BR      GSTATG
10
11 017214 013746 003130      ;GSTAT:  MOV    TEMP4,-(SP)      ;STORE TEMP4
12 017220 005037 003130      CLR    TEMP4                ;SET FOR SAVE L. AND T. REGS
13 017224 010346          ;GSTATG: MOV    R3,-(SP)          ;STORE R3
14 017226 013703 003004      MOV    SSINDX,R3           ;GET SUBROUTINE INDEX
15 017232 005723          TST   (R3)+                ;BUMP IT FOR NEXT ENTRY
16 017234 016663 000004 002406  MOV    4(SP),SUBSTK(R3)    ;INSERT THIS CALL
17 017242 162763 000004 002406  SUB   #4,SUBSTK(R3)       ;ADJUST IT TO CALLING LOCATION
18 017250 010337 003004      MOV    R3,SSINDX          ;STORE IT BACK
19 017254 010046          MOV    R0,-(SP)           ;STORE R0
20 017256 010146          MOV    R1,-(SP)           ;STORE R1
21 017260 012737 000002 003020  MOV    #2,ERRSWI          ;SET FOR NO ERROR RETURN
22 017266 032737 000010 003130  BIT   #DRSET,TEMP4        ;TEST IF DRIVE RESET
23 017274 001460          BEQ   4$                  ;NO - SKIP
24 017276 032762 040000 000000  BIT   #DRVERR,RLCS(R2)    ;TEST IF DRIVE ERROR SET
25 017304 001405          BEQ   1$                  ;NO - SKIP
26 017306 012737 000003 003460  MOV    #3,YDELAY          ;SAVE ARGUMENT
   017314 004737 016354      JSR   PC,XTIME            ;CALL TIMING ROUTINE
27 017320 012701 000062          MOV    #50,R1             ;INITIALIZE WAIT COUNT
28 017324 004737 017214          JSR   PC,GSTAT           ;GET DRIVE STATUS
29 017330 020014          ;16$
30 017332 032737 000001 003046  BIT   #DRDYMSK,T.CS       ;TEST IF DRIVE READY
31 017340 001054          BNE   6$                  ;YES - GO DO CLEAR
32 017342 032737 000020 003054  BIT   #HOSTAT,T.MP        ;ELSE TEST IF HEADS OUT
33 017350 001010          BNE   3$                  ;YES - BYPASS RELOAD WAIT FLAG SETTING
34 017352 032737 144000 003054  BIT   #SPDSTAT!HCESTAT!WDESTAT,T.MP ;TEST IF DRIVE HAS ERROR
   ;THAT CAUSED HEADS TO
   ;UNLOAD
35
36
37 017360 001444          BEQ   6$                  ;NO - SKIP
38 017362 052737 040000 003006  BIS   #RELDWT,OPFLAG      ;ELSE SET WAIT FLAG
39 017370 000440          BR    6$                  ;SKIP TO CLEAR
40
41 017372 032737 040000 003046  3$:  BIT   #DRVERR,T.CS       ;TEST IF DRIVE ERROR NOW
42 017400 001034          BNE   6$                  ;YES - SKIP TO CLEAR
43 017402 012737 000001 003460  MOV    #1,YDELAY          ;SAVE ARGUMENT
   017410 004737 016354      JSR   PC,XTIME            ;CALL TIMING ROUTINE
44 017414 005301          DEC   R1                  ;DEC WAIT COUNTER
45 017416 001342          BNE   2$                  ;IF NOT DONE, LOOP
46 017420 012703 011317      MOV    #MUNDEF,R3         ;MESSAGE FOR UNDEFINED STATE
47 017424 104456          TRAP  C$ERHRD
   017426 023421          .WORD 10001
   017430 000000          .WORD 0
   017432 012646          .WORD ERR1
48 017434 000565          BR    15$                 ;EXIT
49
50 017436 005737 003130      4$:  TST   TEMP4              ;TEST IF SAVE REGISTERS
51 017442 001013          BNE   6$                  ;NO SKIP
52 017444 012701 000004      MOV    #4,R1              ;SET SAVE COUNT

```



```

53 017450 012703 003046      MOV      #L.MP+2,R3      ;SET ADDRESS OF FIRST SAVE
54 017454 014346      MOV      -(R3),-(SP)    ;PUT REG ON STACK
55 017456 005301      DEC      R1             ;DEC COUNT
56 017460 001375      BNE     5$             ;LOOP UNTIL ALL SAVED
57 017462 012737 000003 003042  MOV      #GETSTAT,L.DA  ;SET FOR GET STATUS
58 017470 000403      BR      7$             ;SKIP
59
60 017472 013737 003130 003042 6$:  MOV      TEMP4,L.DA     ;INSERT PRESET FOR STATUS
61 017500      7$:
62 017500 005037 003010      CLR      DONE          ;CLEAR INTERRUPT FLAG
63 017504 013737 003034 003036  MOV      RLDRV,L.CS     ;SET UP TO GET STATUS
64 017512 042737 002000 003036  BIC      #BIT10,L.CS    ;CLEAR FOR DRIVE 4 - 7 SPEC'D
65 017520 052737 000104 003036  BIS      #GTSTAT,L.CS
66 017526 013762 003042 000004  MOV      L.DA,RLDA(R2)  ;LOAD RL REGS
67 017534 013762 003036 000000  MOV      L.CS,RLCSR(R2) ;LOAD CS REG
68 017542 012737 000001 003456  MOV      #1,XDELAY     ;SAVE ARGUMENT
017550 004737 016210      JSR      PC,TIME       ;CALL TIMING ROUTINE
69 017554 005737 003010      TST     DONE          ;CHECK IF INTERRUPT OCCURRED
70 017560 001504      BEQ     13$           ;NO - SKIP
71 017562 013737 003054 003062 8$:  MOV      T.MP,T.STAT   ;STORE MP REGISTER
72 017570 042737 177770 003062  BIC      #C<STAMSK>,T.STAT ;CLEAR ALL BUT STATE
73 017576 032737 000010 003042  BIT      #DRSET,L.DA   ;TEST IF RESET WAS SPECIFIED
74 017604 001503      BEQ     16$           ;NO - SKIP TO EXIT
75 017606 032737 040000 003006  BIT      #RELDWT,OPFLAG ;TEST IF RELOAD WAIT FLAG SET
76 017614 001427      BEQ     10$           ;NO - SKIP
77 017616 012701 001130      MOV      #600,R1      ;SET WAIT COUNT FOR 60 SECONDS
78 017622 032762 000001 000000 9$:  BIT      #DRDYMSK,RLCS(R2) ;TEST IF DRIVE NOW READY
79 017630 001021      BNE     10$           ;YES - SKIP
80 017632 012737 000001 003460  MOV      #1,YDELAY     ;SAVE ARGUMENT
017640 004737 016354      JSR      PC,XTIME     ;CALL TIMING ROUTINE
81 017644 005301      DEC      R1           ;DEC COUNT
82 017646 001365      BNE     9$           ;LOOP IF NOT 0
83 017650 004737 017214      JSR      PC,GSTAT     ;GET DRIVE STATUS
84 017654 020014      16$
85 017656 012703 011364      MOV      #MRLFAL,R3   ;SET RESULT MESSAGE POINTER
86 017662 104456      TRAP   C$ERHRD
017664 023423      .WORD 10003
017666 000000      .WORD 0
017670 012646      .WORD ERR1
87 017672 000446      BR      15$           ;GO TO EXIT
88
89 017674      10$:
017674 012737 000012 003456  MOV      #10,XDELAY    ;SAVE ARGUMENT
017702 004737 016210      JSR      PC,TIME     ;CALL TIMING ROUTINE
90 017706 004737 017214      JSR      PC,GSTAT    ;GET DRIVE STATUS
91 017712 020014      16$
92 017714 032737 100000 003046  BIT      #ANYERR,T.CS  ;TEST IF ANY ERROR
93 017722 001434      BEQ     16$           ;NO - SKIP
94 017724 032737 001000 003054  BIT      #VCSTAT,T.MP  ;CHECK IF VOLUME CHECK RESET
95 017732 001403      BEQ     11$           ;YES SKIP
96 017734 012703 007112      MOV      #VCNRST,R3   ;SET REASON POINTER
97 017740 000417      BR      14$           ;EXIT
98
99 017742 032737 040000 003046 11$: BIT      #DRVERR,T.CS  ;CHECK IF DRIVE ERROR
100 017750 001405      BEQ     12$           ;NO - SKIP
101 017752 104456      TRAP   C$ERHRD
017754 023424      .WORD 10004

```

	017756	000000			.WORD	0		
	017760	013150			.WORD	ERR6		
102	017762	000412			BR	15\$		;EXIT
103								
104	017764	012703	007133	12\$:	MOV	#UNXERR,R3		;SET REASON POINTER
105	017770	000403			BR	14\$		;EXIT
106								
107	017772	004737	017010	13\$:	JSR	PC, WAITIN		;WAIT FOR INTERRUPT
108	017776	012603			MOV	(SP)+,R3		;STORE REASON POINTER FOR RETURN
109	020000			14\$:				
	020000	104456			TRAP	C\$ERHRD		
	020002	023422			.WORD	10002		
	020004	000000			.WORD	0		
	020006	012646			.WORD	ERR1		
110	020010	005037	003020	15\$:	CLR	ERRSWI		;CLEAR FOR ERROR RETURN
111	020014	005737	003130	16\$:	TST	TEMP4		;TEST IF REGISTERS WERE SAVED
112	020020	001007			BNE	18\$		;NO - SKIP
113	020022	012703	003036		MOV	#L.CS,R3		;SET POINTER TO RESTORE
114	020026	012701	000004		MOV	#4,R1		;SET REGISTER COUNT
115	020032	012623		17\$:	MOV	(SP)+,(R3)+		;RESTORE REG
116	020034	005301			DEC	R1		;DEC COUNT
117	020036	001375			BNE	17\$		;LOOP UNTIL ALL ARE RESTORED
118	020040	162737	000002 003004	18\$:	SUB	#2,SSINDX		;REMOVE ENTRY FROM SUBROUT STACK
119	020046	012601			MOV	(SP)+,R1		;RESTORE R1
120	020050	012600			MOV	(SP)+,R0		;RESTORE R0
121	020052	012603			MOV	(SP)+,R3		;RESTORE R3
122	020054	012637	003130		MOV	(SP)+,TEMP4		;RESTORE TEMP4
123	020060	005737	003020		TST	ERRSWI		;TEST IF ERROR RETURN
124	020064	001403			BEQ	19\$		;YES - SKIP
125	020066	063716	003020		ADD	ERRSWI,(SP)		;ADD IN ERROR RETURN
126	020072	000207			RTS	PC		
127	020074	017616	000000	19\$:	MOV	@(SP),(SP)		;SET ERROR RETURN ADDRESS
128	020100	000207			RTS	PC		

```

1          ;          SEEK ROUTINE
2
3 020102  012737  177777  003122  XSEEK:  MOV    #-1,TEMP1      ;SET SPECIAL TIMING SEEK FLAG
4 020110  000402                BR          XSEEK1
5
6 020112  005037  003122                XSEEK:  CLR    TEMP1          ;CLEAR SPECIAL SEEK FOR TIMING FLAG
7 020116  010346                XSEEK1:  MOV    R3,-(SP)        ;STORE R3
8 020120  013703  003004                MOV    SSINDX,R3          ;GET SUBROUTINE INDEX
9 020124  005723                TST    (R3)+             ;BUMP IT FOR NEXT ENTRY
10 020126  016663  000002  002406  MOV    2(SP),SUBSTK(R3)  ;INSERT THIS CALL
11 020134  162763  000004  002406  SUB    #4,SUBSTK(R3)    ;ADJUST IT TO CALLING LOCATION
12 020142  010337  003004                MOV    R3,SSINDX        ;STORE IT BACK
13 020146  010046                MOV    R0,-(SP)
14 020150  010146                MOV    R1,-(SP)
15 020152  010546                MOV    R5,-(SP)          ;STORE REG
16 020154  012737  000002  003020  MOV    #2,ERRSWI        ;SET FOR NO ERROR RETURN
17 020162  005037  003100                CLR    DIFAUG           ;CLEAR DIFFERENCE AUGMENT (FOR SEEKING
18                                     ; PAST GUARD BAND)
19 020166  004737  024054                JSR    PC,GETPOS        ;GET PRESENT POSITION
20 020172  020624                12$
21 020174  013737  003106  003102  MOV    CURCYL,OLDCYL    ;MOVE CURRENT TO OLD CYLINDER
22 020202  023737  003104  002304  CMP    NEWCYL,HLMTW     ;TEST IF NEW IS GREATER THAN MAX CYL
23 020210  003427                BLE    1$              ;NO - SKIP
24 020212  163737  002304  003104  SUB    HLMTW,NEWCYL     ;ELSE SUBTRACT MAX CYL.
25 020220  013737  003104  003100  MOV    NEWCYL,DIFAUG    ;STORE DIFFERENCE AS AUGMENT
26 020226  013737  002304  003104  MOV    HLMTW,NEWCYL    ;SET NEWCYL AS MAX CYL.
27 020234  022737  000001  002300  CMP    #1,T.DRIVE
28 020242  001424                BEQ    2$
29 020244  162737  000001  003104  SUB    #1,NEWCYL
30 020252  012737  000001  003112  MOV    #1,DESSGN
31 020260  012737  000001  003110  MOV    #1,DESDIF
32 020266  000451                BR     6$
33
34 020270  005737  003104                1$:  TST    NEWCYL          ;TEST IF NEWCYL HAS NEGATIVE VALUE
35 020274  100007                BPL    2$              ;NO - SKIP
36 020276  005437  003104                NEG    NEWCYL          ;ELSE MAKE IT POSITIVE
37 020302  013737  003104  003100  MOV    NEWCYL,DIFAUG    ;AND STORE IT AS AUGMENT
38 020310  005037  003104                CLR    NEWCYL          ;AND SET NEWCYL TO 0
39 020314  013705  003106                2$:  MOV    CURCYL,R5        ;COMPUTE DIFFERENCE AND NEW CYLINDER
40 020320  163705  003104                SUB    NEWCYL,R5        ;SUB NEWCYL FROM CURCYL
41 020324  100005                BPL    3$              ;IF DIFF IS POSITIVE - SKIP(REV SEEK)
42 020326  012737  000001  003112  MOV    #1,DESSGN        ;ELSE SET SIGN FOR FORWARD
43 020334  005405                NEG    R5               ;MAKE DIFFERENCE POSITIVE
44 020336  000402                BR     4$              ;SKIP
45
46 020340  005037  003112                3$:  CLR    DESSGN          ;SET SIGN FOR REVERSE
47 020344  010537  003110                4$:  MOV    R5,DESDIF        ;STORE DIFFERENCE
48 020350  005737  003100                TST    DIFAUG          ;IS THERE A DIFFERENCE AUGMENT
49 020354  001416                BEQ    6$              ;NO - SKIP
50 020356  023737  003104  002304  CMP    NEWCYL,HLMTW    ;CHECK IF NEW CYL IS MAX CYL.
51 020364  001007                BNE    5$              ;NO - SKIP
52 020366  012737  000001  003112  MOV    #1,DESSGN        ;ELSE FORCE SIGN FOR FORWARD
53                                     ;(INNER GUARD BAND)
54 020374  022737  000001  002300  CMP    #1,T.DRIVE
55 020402  001003                BNE    6$
56 020404  063737  003100  003110  5$:  ADD    DIFAUG,DESDIF
57 020412  012705  003036                6$:  MOV    #L.CS,R5        ;GET L REG ADDRESS

```

```

58 020416 012715 000106      MOV      #SEEK,(R5)      ;SET FOR SEEK
59 020422 053715 003034      BIS      RLDRV,(R5)      ;INSERT DRIVE NUMBER
60 020426 042725 002000      BIC      #BIT10,(R5)+    ;CLEAR IF DRIVE 4 - 7 SPEC'D
61 020432 005025              CLR      (R5)+           ;CLEAR BUS ADDRESS
62 020434 013715 003110      MOV      DESDIF,(R5)     ;LOAD DIFFERENCE
63 020440 012700 000007      MOV      #7,R0          ;SET TO SHIFT DIFFERENCE
64 020444 006315              7$:     ASL      (R5)
65 020446 005300              DEC      R0
66 020450 001375              BNE      7$             ;LOOP UNTIL ALIGNED
67 020452 005737 003112      TST      DESSGN          ;TEST SIGN
68 020456 001402              BEQ      8$             ;SKIP IF 0
69 020460 052715 000004      BIS      #DIRBIT,(R5)    ;ELSE INSERT SIGN
70 020464 005737 003114      8$:     TST      DESHD          ;TEST IF HEAD 0
71 020470 001402              BEQ      9$             ;YES - SKIP
72 020472 052715 000020      BIS      #HSEL,(R5)     ;ELSE SET HEAD BIT
73 020476 052725 000001      9$:     BIS      #MBS0,(R5)+  ;INSERT MARKER BIT
74 020502 004737 021230      JSR      PC,RDYCHK      ;CHECK IF DRIVE READY
75 020506 020624              12$:
76 020510 005037 003010      CLR      DONE           ;CLEAR INTERRUPT FLAG
77 020514 005737 003122      TST      TEMP1          ;CHECK IF SPECIAL SEEK FLAG SET
78 020520 001041              BNE      12$           ;YES - SKIP, DO NOT START SEEK
79 020522 014562 000004      MOV      -(R5),RLDA(R2) ;LOAD RL REGISTERS
80 020526 014562 000002      MOV      -(R5),RLBA(R2)
81 020532 014562 000000      MOV      -(R5),RLCS(R2)
82 020536              10$:
82 020536 012737 000012 003456  MOV      #10,XDELAY     ;SAVE ARGUMENT
82 020544 004737 016210      JSR      PC,TIME        ;CALL TIMING ROUTINE
83 020550 005737 003010      TST      DONE          ;TEST IF INTERRUPT DONE
84 020554 001012              BNE      11$           ;YES - SKIP
85 020556 004737 017010      JSR      PC,WAITIN      ;GO WAIT FOR INTERRUPT
86 020562 012603              MOV      (SP)+,R3       ;GET RESULT MESSAGE POINTER
87 020564 104456              TRAP     C$ERHRD
87 020566 023425              .WORD   10005
87 020570 000000              .WORD   0
87 020572 012646              .WORD   ERR1
88 020574 005037 003020      CLR      ERRSWI        ;CLEAR FOR ERROR RETURN
89 020600 000411              BR       12$
90
91 020602 005737 003046      11$:   TST      T,CS          ;TEST IF ANY ERROR
92 020606 100006              BPL      12$           ;NO - SKIP
93 020610 104456              TRAP     C$ERHRD
93 020612 023426              .WORD   10006
93 020614 000000              .WORD   0
93 020616 013150              .WORD   ERR6
94 020620 005037 003020      CLR      ERRSWI        ;CLEAR FOR ERROR RETURN
95 020624 162737 000002 003004  12$:   SUB      #2,SSINDEX     ;REMOVE ENTRY FROM SUBROUT STACK
96 020632 012605              MOV      (SP)+,R5       ;RESTORE REGISTERS
97 020634 012601              MOV      (SP)+,R1
98 020636 012600              MOV      (SP)+,R0
99 020640 012603              MOV      (SP)+,R3
100 020642 005737 003020      TST      ERRSWI        ;TEST IF ERROR RETURN
101 020646 001403              BEQ      13$           ;YES - SKIP
102 020650 063716 003020      ADD      ERRSWI,(SP)    ;ADD IN ERROR RETURN
103 020654 000207              RTS      PC
104 020656 017616 000000      13$:   MOV      @ (SP),(SP) ;SET ERROR RETURN ADDRESS
105 020662 000207              RTS      PC

```

```

1      ;      POSITION HEADS ROUTINE. POSITIONS HEADS USING 1 CYLINDER SEEKS
2      ;      TO CYLINDER SPECIFIED IN R5 BY THE CALLING ROUTINE
3
4 020664 010346      POSHDS: MOV      R3, -(SP)      ;SAVE REGS
5 020666 013703 003004  MOV      SSINDX,R3      ;GET SUBROUTINE INDEX
6 020672 005723      TST      (R3)+      ;BUMP IT FOR NEXT ENTRY
7 020674 016663 000002 002406  MOV      2(SP), SUBSTK(R3) ;INSERT THIS CALL
8 020702 162763 000004 002406  SUB      #4, SUBSTK(R3) ;ADJUST IT TO CALLING LOCATION
9 020710 010337 003004      MOV      R3, SSINDX      ;STORE IT BACK
10 020714 010346      MOV      R3, -(SP)
11 020716 010446      MOV      R4, -(SP)
12 020720 012737 000002 003020  MOV      #2, ERRSWI      ;SET FOR NO ERROR RETURN
13 020726 004737 024054      JSR      PC, GETPOS      ;GET CURRENT POSITION
14 020732 021172      PH65$
15 020734 012704 000012      MOV      #10, R4      ;SET RETRY COUNT
16 020740 104404      TRAP     C$BSEG
17
18 020742      1$:      TRAP     C$INLP
19 020742 104420      BCC     2$
20 020744 103012      JSR      PC, GETPOS      ;ELSE GET POSITION
21 020746 004737 024054      10$
22 020752 021170      CMP     CURCYL, NEWCYL ;CHECK IF AT INTENDED POSITION
23 020754 023737 003106 003104  BNE     4$              ;NO - SKIP
24 020762 001017      JSR      PC, ONSWAP      ;SWAP OLDCYL AND NEWCYL
25 020764 004737 021570      BR      4$              ;SKIP
26
27 020772 013737 003106 003102 2$:      MOV     CURCYL, OLDCYL ;IN NOT LOOPING, STORE CURCYL AS OLDCYL
28 021000 023705 003106      CMP     CURCYL, R5      ;CHECK IF HDS AT FINAL POSITION
29 021004 001471      BEQ     10$             ;YES - GO TO EXIT
30 021006 003003      BGT     3$              ;IF CURCYL > FINAL POSITION - SKIP
31 021010 005237 003104      INC     NEWCYL          ;ELSE BUMP NEWCYL (MOVE HDS IN)
32 021014 000402      BR      4$              ;SKIP
33
34 021016 005337 003104      3$:      DEC     NEWCYL          ;DEC NEWCYL (MOVE HDS OUT)
35 021022 004737 020112      4$:      JSR      PC, XSEEK      ;DO SEEK
36 021026 021170      10$
37 021030 012701 005670      MOV     #3000, R1      ;SET WAIT COUNT 300 MS
38 021034 004737 023570      JSR      PC, RDYWAIT    ;WAIT FOR DRIVE READY
39 021040 021170      10$
40 021042 005737 003046      TST     T, CS          ;TEST IF ANY ERROR
41 021046 100007      BPL     5$              ;NO - SKIP
42 021050 104456      TRAP     C$ERHRD
43 021052 023430      .WORD   10008
44 021054 000000      .WORD   0
45 021056 013150      .WORD   ERR6
46 021060 005037 003020      CLR     ERRSWI          ;CLEAR FOR ERROR ERROR RETURN
47 021064 000441      BR      10$
48
49 021066 004737 024054      5$:      JSR      PC, GETPOS      ;GET POSITION
50 021072 021170      10$
51 021074 023737 003106 003104  CMP     CURCYL, NEWCYL ;CHECK IF ARRIVED AT DESIRED PLACE
52 021102 001003      BNE     7$              ;NO - SKIP
53 021104 012704 000012      6$:      MOV     #10, R4          ;ELSE INIT RETRY COUNT
54 021110 000714      BR      1$              ;GO DO NEXT SEEK
55
56 021112 005737 003112      7$:      TST     DESSGN          ;TEST IF GOING IN

```

```

54 021116 001017          BNE      9$          ;YES - SKIP
55 021120 023737 003106 003104  CMP      CURCYL,NEWCYL ;CHECK IF HEADS DID NOT MOVE IN
56 021126 003366          BGT      6$          ;YES - SKIP
57 021130 005304          DEC      R4          ;DEC RETRY COUNT
58 021132 001333          BNE      4$          ;DO ANOTHER SEEK IF NOT 0
59 021134 012703 010003  MOV      #HDMOVF,R3   ;ELSE SET RESULT MESSAGE POINTER
60 021140 104456          TRAP    C$ERHRD
    021142 023431          .WORD  10009
    021144 000000          .WORD  0
    021146 012646          .WORD  ERR1
61 021150 005037 003020  CLR      ERRSWI      ;CLEAR FOR ERROR ERROR RETURN
62 021154 000405          BR      10$
63
64 021156 023737 003106 003104 9$:  CMP      CURCYL,NEWCYL ;HDS SHOULD MOVE OUT, CHK THEY DID
65 021164 002747          BLT     6$          ;YES - SKIP
66 021166 000760          BR      8$          ;ELSE GO DEC AND RETRY
67 021170          10$:
    021170          10000$:
    021170 104405          TRAP    C$ESEG
68
69 021172 162737 000002 003004 PH65$: SUB     #2,SSINDX      ;REMOVE ENTRY FROM SUBROUT STACK
70 021200 012604          MOV     (SP)+,R4     ;RESTORE REGISTERS
71 021202 012600          MOV     (SP)+,R0
72 021204 012603          MOV     (SP)+,R3
73 021206 005737 003020  TST     ERRSWI      ;TEST IF ERROR RETURN
74 021212 001403          BEQ    1$          ;YES - SKIP
75 021214 063716 003020  ADD     ERRSWI,(SP) ;ADD IN ERROR RETURN
76 021220 000207          RTS     PC
77 021222 017616 000000  1$:  MOV     @ (SP),(SP) ;SET ERROR RETURN ADDRESS
78 021226 000207          RTS     PC

```

## GLOBAL SUBROUTINES

```

1          ; DRIVE READY TEST ROUTINE. CHECKS DRIVE IS READY. IF NOT, WAIT
2          ; 500MS FOR READY TO SET.
3
4 021230 010346          RDYCHK: MOV R3,-(SP)          ;STORE REGS
5 021232 013703 003004  MOV SSINDEX,R3      ;GET SUBROUTINE INDEX
6 021236 005723          TST (R3)+          ;BUMP IT FOR NEXT ENTRY
7 021240 016663 000002 002406  MOV 2(SP),SUBSTK(R3) ;INSERT THIS CALL
8 021246 162763 000004 002406  SUB #4,SUBSTK(R3)   ;ADJUST IT TO CALLING LOCATION
9 021254 010337 003004          MOV R3,SSINDEX      ;STORE IT BACK
10 021260 010046         MOV R0,-(SP)
11 021262 010146         MOV R1,-(SP)
12 021264 010446         MOV R4,-(SP)
13 021266 012737 000002 003020  MOV #2,ERRSWI      ;SET FOR NO ERROR RETURN
14 021274 012701 011610         MOV #5000,R1        ;SET WAIT COUNT
15 021300 004737 017214          JSR PC,GSTAT      ;GET DRIVE STATUS
16 021304 021440          4$
17 021306 032737 000001 003046  BIT #DRDYMSK,T.CS ;TEST IF DRIVE READY
18 021314 001053         BNE 5$              ;YES - EXIT
19 021316 012737 000001 003456  MOV #1,XDELAY      ;SAVE ARGUMENT
20 021324 004737 016210         JSR PC,TIME        ;CALL TIMING ROUTINE
21 021330 005301         DEC R1              ;DEC WAIT COUNT
22 021332 001362         BNE 1$              ;LOOP IF NOT 0
23 021334 012703 010702         MOV #MDRDY,R3      ;SET RESULT MESSAGE POINTER
24 021340 012704 011567         MOV #C500MS,R4     ;SET CONDITION MESSAGE POINTER
25 021344 104456         TRAP C$ERHRD
26 021346 023432         .WORD 10010
27 021350 000000         .WORD 0
28 021352 013100         .WORD ERR5
29 021354 012701 000062         MOV #50,R1        ;SET WAIT COUNT FOR 5 SECONDS
30 021360 004737 017214          JSR PC,GSTAT      ;GET DRIVE STATUS
31 021364 021440          4$
32 021366 032737 000001 003046  BIT #DRDYMSK,T.CS ;TEST IF DRIVE READY
33 021374 001007         BNE 3$              ;YES - SKIP
34 021376 012737 000001 003460  MOV #1,YDELAY      ;SAVE ARGUMENT
35 021404 004737 016354         JSR PC,XTIME      ;CALL TIMING ROUTINE
36 021410 005301         DEC R1              ;DEC WAIT COUNTER
37 021412 001362         BNE 2$              ;LOOP UNTIL TIME DONE
38 021414 032737 100000 003046  3$: BIT #ANYERR,T.CS ;TEST IF ANYERR SET
39 021422 001406         BEQ 4$              ;NO - SKIP
40 021424 104456         TRAP C$ERHRD
41 021426 023433         .WORD 10011
42 021430 000000         .WORD 0
43 021432 013150         .WORD ERR6
44 021434 C05337 003244         DEC ERRCNT        ;REDUCE ERROR COUNT FOR DUAL ERRORS
45 021440 005037 003020         CLR ERRSWI        ;CLEAR FOR ERROR RETURN
46 021444 162737 000002 003004  5$: SUB #2,SSINDEX    ;REMOVE ENTRY FROM SUBROUT STACK
47 021452 012604         MOV (SP)+,R4      ;RESTORE REGS
48 021454 012601         MOV (SP)+,R1
49 021456 012600         MOV (SP)+,R0
50 021460 012603         MOV (SP)+,R3
51 021462 005737 003020         TST ERRSWI        ;TEST IF ERROR RETURN
52 021466 001403         BEQ 6$              ;YES - SKIP
53 021470 063716 003020         ADD ERRSWI,(SP)   ;ADD IN ERROR RETURN
54 021474 000207         RTS PC
55 021476 017616 000000         MOV #0,(SP),(SP) ;SET ERROR RETURN ADDRESS
56 021502 000207         RTS PC

```

```

50      ;      CHOOSE HEAD ROUTINE. PICKS HEAD 0 UNLESS SPECIFIC HEAD IS
51      ;      SELECTED BY SOFTWARE PARAMETER.
52
53      021504 005037 003114      CHOSHD: CLR      DESHD      ;CLEAR TO HEAD 0
54      021510 032737 010000 014500 BIT      #HEADLM,MISWIW ;TEST IF HEAD SPECIFIED
55      021516 001403              BEQ      1$          ;NO - SKIP
56      021520 013737 014506 003114 MOV      HEADW,DESHD ;INSERT SPECIFIED HEAD
57      021526 000207              RTS      PC
58
59      ;      SWAP HEAD ROUTINE. CHANGES SELECTED HEAD TO HEAD 1
60      ;      UNLESS HEAD 0 SPECIFICALLY SELECTED BY SOFTWARE PARAMETER.
61
62      021530 032737 010000 014500 SWAPHD: BIT      #HEADLM,MISWIW ;TEST IF HEAD SPECIFIED
63      021536 001011              BNE      1$          ;YES - TAKE ABORT EXIT
64      021540 005737 003114              TST      DESHD      ;TEST IF HEAD ONE USED
65      021544 001006              BNE      1$          ;YES - TAKE ABORT EXIT
66      021546 012737 000001 003114 MOV      #1,DESHD    ;ELSE SET FOR HEAD ONE
67      021554 062716 000002              ADD      #2,(SP)     ;BUMP PAST ABORT RETURN
68      021560 000207              RTS      PC          ;RETURN
69      021562 017616 000000              1$: MOV      @ (SP),(SP) ;GET ABORT DESTINATION
70      021566 000207              2$: RTS      PC
71
72      ;      SWAP OLD CYLINDER AND NEW CYLINDER ROUTINE.
73      021570 010046              0NSWAP: MOV      RO,-(SP) ;STORE RO
74      021572 013700 003102              MOV      OLDCYL,RO ;MOVE OLD TO RO
75      021576 013737 003104 003102 MOV      NEWCYL,OLDCYL ;MOVE NEW TO OLD
76      021604 010037 003104              MOV      RO,NEWCYL ;PUT OLD IN NEW
77      021610 012600              MOV      (SP)+,RO ;RESTORE RO
78      021612 000207              RTS      PC

```





53	022072	001052				BNE	9\$		:NO - SKIP
54	022074	021327	177777		3\$:	CMP	(R3), #-1		:TEST IF NEXT WORD IS ALL 1'S
55	022100	001005				BNE	4\$		:NO - SKIP
56	022102	012737	000001	003126		MOV	#1, TEMP3		:ELSE SET 1'S DETECTED FLAG
57	022110	022313				CMP	(R3)+, (R3)		:ADJUST POINTER
58	022112	001420				BEQ	7\$		:BR IF THE SAME
59	022114	005737	003126		4\$:	TST	TEMP3		:TEST IF ONES HAVE BEEN DETECTED
60	022120	001037				BNE	9\$		:YES - SKIP TO FMT ERROR RPT
61	022122	012311				MOV	(R3)+, (R1)		:STORE CYLINDER WORD
62	022124	012705	000007			MOV	#7, R5		:ALIGN IT TO LOOK LIKE HEADER
63	022130	006311			5\$:	ASL	(R1)		
64	022132	005305				DEC	R5		
65	022134	001375				BNE	5\$		
66	022136	032713	000400			BIT	#BIT8, (R3)		:TEST IF HEAD 1
67	022142	001402				BEQ	6\$		:NO - SKIP
68	022144	052711	000100			BIS	#BIT6, (R1)		:INSERT HEAD BIT
69	022150	042713	177400		6\$:	BIC	#177400, (R3)		:CLEAR ALL BUT SECTOR
70	022154	052321			7\$:	BIS	(R3)+, (R1)+		:INSERT SECTOR NUMBER
71	022156	020327	005466			CMP	R3, #IBUFF+508.		:CHECK IF Ibuff EMPTY
72	022162	001344				BNE	3\$		:NO GET NEXT CYLINDER
73	022164	022737	000044	003134		CMP	#36., TEMP6		:DONE CHECKING ALL BSF'S YET?
74	022172	001470				BEQ	15\$		:BRANCH IF YES, ELSE
75	022174	012737	004076	003132	8\$:	MOV	#FLDBSF, TEMP5		:CHANGE POINTERS TO FIELD BS FILE
76	022202	012737	000044	003134		MOV	#36., TEMP6		:MAX SECTOR NUMBER
77	022210	012737	000024	003116		MOV	#20., DESSEC		:SECTOR NUMBER START
78	022216	000670				BR	2\$		:DO READ
79									
80	022220	005737	014514		9\$:	TST	BSERRS		:OUTPUT ALL BSF ERRORS?
81	022224	001413				BEQ	11\$		:BRANCH IF NO
82	022226	012703	006563			MOV	#FMTER, R3		:SET RESULT MESSAGE POINTER
83	022232	104456				TRAP	C\$ERHRD		
	022234	002426				.WORD	1302		
	022236	000000				.WORD	0		
	022240	012646				.WORD	ERR1		
84	022242	005737	014514		10\$:	TST	BSERRS		:OUTPUT ALL BSF ERRORS?
85	022246	001402				BEQ	11\$		:BRANCH IF NO
86	022250	104420				TRAP	C\$INLP		
87	022252	103652				BCS	2\$		
88									
89	022254	023737	003116	003134	11\$:	CMP	DESSEC, TEMP6		:CHECK IF ALL SECTORS READ
90	022262	001026				BNE	13\$		:NO - SKIP
91	022264	105237	003450			INCB	LOCERR		:BUMP LOCAL ERROR COUNTER
92	022270	012703	006433			MOV	#MFBSF, R3		:SET ERROR MESSAGE POINTER
93	022274	022737	004076	003132		CMP	#FLDBSF, TEMP5		:IS THIS FIELD BS FILE?
94	022302	001002				BNE	12\$		:BRANCH IF NO
95	022304	012703	006510			MOV	#MBSF, R3		:SET ERROR MESSAGE POINTER
96	022310	012777	177777	160614	12\$:	MOV	#-1, @TEMP5		:TERMINATE FILE STORAGE
97	022316	104456				TRAP	C\$ERHRD		
	022320	002425				.WORD	1301		
	022322	000000				.WORD	0		
	022324	012646				.WORD	ERR1		
98	022326	022737	004076	003132		CMP	#FLDBSF, TEMP5		:DID WE CHECK FIELD BS FILE YET?
99	022334	001407				BEQ	15\$		:BRANCH IF YES, ELSE
100	022336	000716				BR	8\$		:GO CHECK FIELD BSF
101									
102	022340	062737	000004	003116	13\$:	ADD	#4, DESSEC		:BUMP TO NEXT SECTOR
103	022346	000614				BR	2\$		:GO DO READ

```

104
105 022350 105237 003450 14$: INCB LOCERR ;INC LOCAL ERROR COUNT
106 022354 012737 000002 003020 15$: MOV #2,ERRSWI ;SETUP FOR NO ERROR RETURN
107 022362 012737 000001 003500 MOV #1,BSFVAL ;SET BAD SEC FILE VALID FLAG
108 022370 105737 003450 TSTB LOCERR ;TEST IF LOCAL ERRORS
109 022374 001454 BEQ 17$ ;NO - SKIP
110 022376 005237 003244 INC ERRCNT ;BUMP ERROR COUNT
111 022402 012737 177777 003500 16$: MOV #-1,BSFVAL ;SET BAD READ OR INVALID BAD SEC FILE
112 022410 012746 010572 MOV #BSFNOT, -(SP)
022414 012746 000001 MOV #1, -(SP)
022420 010600 MOV SP,RO
022422 104417 TRAP C$PNTF
022424 062706 000004 ADD #4,SP
113 022430 005046 CLR -(SP)
022432 153716 003035 BISB RLDRV+1,(SP)
022436 012746 006621 MOV #DRVNAM, -(SP)
022442 013746 003030 MOV #RLBAS, -(SP)
022446 012746 006610 MCV #BASADD, -(SP)
022452 012746 011750 MOV #FMT5, -(SP)
022456 012746 000005 MOV #5, -(SP)
022462 010600 MOV SP,RO
022464 104417 TRAP C$PNTF
022466 062706 000014 ADD #14,SP
114 022472 012746 011623 MOV #CRLF, -(SP)
022476 012746 000001 MOV #1, -(SP)
022502 010600 MOV SP,RO
022504 104417 TRAP C$PNTF
022506 062706 000004 ADD #4,SP
115 022512 012737 177777 003502 MOV #-1,FCTBSF ;TERMINATE FACTORY BSF LIST
116 022520 012737 177777 004076 MOV #-1,FLDBSF ;TERMINATE FIELD BSF LIST
117 022526 000207 17$: RTS PC ;RETURN

```

```

1      ;      READ HEADERS ROUTINE.
2
3 022530 012737 000001 003130 XRDHDC: MOV    #1,TEMP4      ;SET FLAG TO BYPASS REG STORAGE
4 022536 000402                BR      XRDHDG      ;GO DO IT
5
6 022540 005037 003130      XRDHD:  CLR    TEMP4      ;SET FLAG TO SAVE T. AMD L. REGS
7 022544 010346                XRDHDG: MOV   R3,-(SP)    ;STORE REGISTERS
8 022546 013703 003004      MOV   SSINDX,R3    ;GET SUBROUTINE INDEX
9 022552 005723                TST   (R3)+        ;BUMP IT FOR NEXT ENTRY
10 022554 016663 000002 002406  MOV   2(SP),SUBSTK(R3) ;INSERT THIS CALL
11 022562 162763 000004 002406  SUB   #4,SUBSTK(R3)  ;ADJUST IT TO CALLING LOCATION
12 022570 010337 003004      MOV   R3,SSINDX    ;STORE IT BACK
13 022574 010046                MOV   R0,-(SP)
14 022576 010146                MOV   R1,-(SP)
15 022600 010446                MOV   R4,-(SP)
16 022602 012737 000002 003020  MOV   #2,ERRSWI    ;SET FOR NO ERROR RETURN
17 022610 005737 003130      TST   TEMP4        ;TEST IF REGISTERS TO BE SAVED
18 022614 001007                BNE   2$           ;NO - SKIP
19 022616 012703 003046      MOV   #L.MP+2,R3   ;SET POINTER FOR REGS
20 022622 012701 000004      MOV   #4,R1        ;SET COUNT
21 022626 014346                1$:  MOV   -(R3),-(SP) ;SAVE REGISTER
22 022630 005301                DEC   R1           ;DEC COUNT
23 022632 001375                BNE   1$          ;LOOP UNTIL ALL ARE SAVED
24 022634 004737 021230      2$:  JSR   PC,RDYCHK   ;CHECK DRIVE READY
25 022640 023110                11$
26 022642 005037 003010      CLR   DONE         ;CLEAR INTERRUPT FLAG
27 022646 012701 003036      MOV   #L.CS,R1     ;GET ADDRESS OF LOAD REGS
28 022652 013711 003034      MOV   RLDRV,(R1)   ;LOAD DRIVE NUMBER
29 022656 042711 002000      BIC   #BIT10,(R1)  ;CLEAR FOR DRIVE 4 - 7 SPEC'D
30 022662 052721 000110      BIS   #RDHEAD,(R1)+ ;INSERT COMMAND
31 022666 005021                CLR   (R1)+        ;CLEAR BA
32 022670 005021                CLR   (R1)+        ;CLEAR DA
33 022672 014162 000004      MOV   -(R1),RLDA(R2) ;LOAD RL11 REGS
34 022676 014162 000002      MOV   -(R1),RLBA(R2)
35 022702 014162 000000      MOV   -(R1),RLCSR(R2)
36 022706                3$:
37 022720 005737 003010      TST   DONE         ;TEST IN INTERRUPT FLAG SET
38 022724 001460                BEQ   9$           ;NO - SKIP
39 022726 032737 000001 003046  4$:  BIT   #DRDYMSK,T.CS ;TEST IF DRIVE READY
40 022734 001035                BNE   7$           ;YES - SKIP
41 022736 012703 010702      MOV   #MDRDY,R3    ;SET NO READY MESSAGE
42 022742 012704 011604      MOV   #CAFDT,R4    ;CONDITION OF AFTER DATA XFER
43 022746 104456      TRAP C$ERHRD
   022750 023441      .WORD 10017
   022752 000000      .WORD 0
   022754 013100      .WORD ERR5
44 022756 012701 000062      MOV   #50,R1       ;SET WAIT COUNT FOR 5 SECONDS
45 022762 004737 017214      5$:  JSR   PC,G$STAT   ;GET STATUS
46 022766 023104                10$
47 022770 032737 000001 003046  BIT   #DRDYMSK,T.CS ;TEST IF DRIVE HAS COME READY
48 022776 001403                BEQ   6$           ;NO - SKIP
49 023000 005037 003020      CLR   ERRSWI      ;CLEAR ERROR SWITCH
50 023004 000411                BR    7$           ;SKIP
51
52 023006 005301                6$:  DEC   R1           ;DEC WAIT COUNT
53 023010 001364                BNE   5$          ;LOOP UNTIL TIME DONE
54 023012 012704 011615      MOV   #C5SEC,R4   ;SET CONDITION AFTER 5 SECONDS

```

55	023016	104456			TRAP	C\$ERHRD		
	023020	023436			.WORD	10014		
	023022	000000			.WORD	0		
	023024	013100			.WORD	ERR5		
56	023026	000426			BR	10\$		;EXIT
57								
58	023030	005737	003046	7\$:	TST	T.CS		;CHECK FOR ANY ERRORS
59	023034	100005			BPL	8\$		;NO - SKIP
60	023036	104456			TRAP	C\$ERHRD		
	023040	023440			.WORD	10016		
	023042	000000			.WORD	0		
	023044	013150			.WORD	ERR6		
61	023046	000416			BR	10\$		
62								
63	023050	012701	003056	8\$:	MOV	#HDWRD2,R1		;GET POINTER
64	023054	016221	000006		MOV	RLMP(R2),(R1)+		;STORE LAST TWO HEADER WORDS
65	023060	016221	000006		MOV	RLMP(R2),(R1)+		
66	023064	000411			BR	11\$		;EXIT
67								
68	023066	004737	017010	9\$:	JSR	PC, WAITIN		;WAIT FOR INTERRUPT
69	023072	012603			MOV	(SP)+, R3		;GET RESULTS
70	023074	104456			TRAP	C\$ERHRD		
	023076	023437			.WORD	10015		
	023100	000000			.WORD	0		
	023102	012646			.WORD	ERR1		
71	023104	005037	003020	10\$:	CLR	ERRSWI		;CLEAR FOR ERROR ERROR RETURN
72	023110	005737	003130	11\$:	TST	TEMP4		;TEST IF REGISTERS WERE SAVED
73	023114	001007			BNE	13\$		;NO - SKIP
74	023116	012703	003036		MOV	#L.CS,R3		;SET POINTER TO RESTORE REGS
75	023122	012701	000004		MOV	#4,R1		;SET COUNT
76	023126	012623		12\$:	MOV	(SP)+,(R3)+		;RESTORE REGISTER
77	023130	005301			DEC	R1		;DEC COUNT
78	023132	001375			BNE	12\$		;LOOP UNTIL ALL ARE RESTORED
79	023134	162737	000002 003004	13\$:	SUB	#2,SSINDX		;REMOVE ENTRY FROM SUBROUT STACK
80	023142	012604			MOV	(SP)+,R4		;RESTORE REGS
81	023144	012601			MOV	(SP)+,R1		
82	023146	012600			MOV	(SP)+,R0		
83	023150	012603			MOV	(SP)+,R3		
84	023152	005737	003020		TST	ERRSWI		;TEST IF ERROR RETURN
85	023156	001403			BEQ	14\$		;YES - SKIP
86	023160	063716	003020		ADD	ERRSWI,(SP)		;ADD IN ERROR RETURN
87	023164	000207			RTS	PC		
88	023166	017616	000000	14\$:	MOV	@(SP),(SP)		;SET ERROR RETURN ADDRESS
89	023172	000207			RTS	PC		

```

1      ;      VERIFY HEADERS ROUTINE. COMPARES 40 HEADERS FOR CONTENT AND
2      ;      SEQUENCE.
3
4 023174 010346      VERHDR: MOV      R3,-(SP)      ;STORE REGS
5 023176 013703 003004  MOV      SSINDX,R3      ;GET SUBROUTINE INDEX
6 023202 005723      TST      (R3)+      ;BUMP IT FOR NEXT ENTRY
7 023204 016663 000002 002406  MOV      2(SP),SUBSTK(R3) ;INSERT THIS CALL
8 023212 162763 000004 002406  SUB      #4,SUBSTK(R3)  ;ADJUST IT TO CALLING LOCATION
9 023220 010337 003004  MOV      R3,SSINDX      ;STORE IT BACK
10 023224 010046      MOV      R0,-(SP)
11 023226 010146      MOV      R1,-(SP)
12 023230 010446      MOV      R4,-(SP)
13 023232 010546      MOV      R5,-(SP)
14 023234 012737 000002 003020  MOV      #2,ERRSWI      ;SET FOR NO ERROR RETURN
15 023242 052737 000002 003006  BIS      #HDCMP,OPFLAG  ;SET HEADER COMPARE FLAG
16 023250 005037 003016      CLR      MORECE        ;CLEAR MORE ERRORS FLAG
17 023254 012704 004472      MOV      #IBUFF,R4     ;SET POINTER TO HEADERS
18 023260 012705 003120      MOV      #TEMPO,R5     ;SET POINTER TO WORK AREA
19 023264 005003      CLR      R3            ;CLEAR FOR WORD COUNTER
20 023266 011415      MOV      (R4),(R5)     ;MOVE HDR WORD TO WORK AREA
21 023270 011401      MOV      (R4),R1       ;PUT WORD IN REG 1
22 023272 042701 000177      BIC      #177,R1 ;CLEAR ALL BUT CYLINDER
23 023276 012700 000007      MOV      #7,R0        ;SET SHIFT COUNT
24 023302 006201      1$:  ASR      R1          ;SHIFT
25 023304 005300      DEC      R0            ;DEC
26 023306 001375      BNE      1$           ;LOOP
27 023310 020137 003104      CMP      R1,NEWCYL     ;CHECK IF CYLINDER PART GOOD
28 023314 001407      BEQ      2$           ;YES - SKIP
29 023316 104456      TRAP    C$ERHRD
      023320 023442      .WORD   10018
      023322 000000      .WORD   0
      023324 014242      .WORD   ERR10
30 023326 005037 003020      CLR      ERRSWI        ;CLEAR FOR ERROR ERROR RETURN
31 023332 000456      BR      8$
32
33 023334 012701 000050      2$:  MOV      #40,R1       ;SET HEADER COUNT
34 023340 042715 000100      BIC      #HDHSEL,(R5)  ;CLEAR HEAD SELECT AND 0 BIT
35 023344 005737 003114      TST      DESHD        ;ARE WE USING HD 0?
36 023350 001402      BEQ      3$           ;YES - SKIP
37 023352 052715 000100      BIS      #HDHSEL,(R5)  ;INSERT HEAD BIT
38 023356 005065 000002      3$:  CLR      2(R5)        ;CLEAR 2ND WORD OF WORK AREA
39 023362 021524      4$:  CMP      (R5),(R4)+    ;TEST FIRST WORD OK
40 023364 001410      BEQ      5$           ;YES - SKIP
41 023366 005744      TST      -(R4)        ;ELSE SET POINTER FOR ERROR
42 023370 104456      TRAP    C$ERHRD
      023372 023442      .WORD   10018
      023374 000000      .WORD   0
      023376 014242      .WORD   ERR10
43 023400 005037 003020      CLR      ERRSWI        ;CLEAR FOR ERROR RETURN
44 023404 005724      TST      (R4)+        ;RESET POINTER
45 023406 005203      5$:  INC      R3            ;BUMP WORD COUNTER
46 023410 005724      TST      (R4)+        ;TEST 2ND WORD IS 0
47 023412 001410      BEQ      6$           ;YES - SKIP
48 023414 022544      CMP      (R5)+,-(R4)  ;ADJUST POINTERS FOR REPORT
49 023416 104456      TRAP    C$ERHRD
      023420 023442      .WORD   10018
      023422 000000      .WORD   0

```

```

023424 014242
50 023426 005037 003020      .WORD  ERR10
51 023432 024524      CLR  ERRSWI      ;CLEAR FOR ERROR RETURN
52 023434 005724      CMP  -(R5),(R4)+ ;RESET POINTERS
53 023436 005203      6$:  TST  (R4)+      ;BUMP PAST ECC WORD
54 023440 005215      INC  R3          ;BUMP WORD COUNTER
55 023442 011500      INC  (R5)        ;BUMP SECTOR OF EXPECTED HEADER
56 023444 042700 177700      MOV  (R5),R0     ;MOVE EXPECTED HDR TO R0
57 023450 022700 000050      BIC  #+CHDSEC,R0 ;CLEAR ALL BUT SECTOR
58 023454 001002      CMP  #40.,R0     ;TEST IF AT SECTOR 40
59 023456 042715 000077      BNE  7$         ;NO - SKIP
60 023462 005203      7$:  BIC  #HDSEC,(R5) ;CLEAR SECTOR TO 0
61 023464 005301      INC  R3          ;BUMP HDR WORD COUNTER
62 023466 001335      DEC  R1          ;DEC HEADER COUNT
63 023470 162737 000002 003004 8$:  BNE  4$         ;LOOP IF NOT YET DONE
64 023476 012605      SUB  #2,SSINDEX ;REMOVE ENTRY FROM SUBROUT STACK
65 023500 012604      MOV  (SP)+,R5    ;RESTORE REGISTERS
66 023502 012601      MOV  (SP)+,R4
67 023504 012600      MOV  (SP)+,R1
68 023506 012603      MOV  (SP)+,R0
69 023510 005737 003020      TST  ERRSWI      ;TEST IF ERROR RETURN
70 023514 001403      BEQ  9$         ;YES - SKIP
71 023516 063716 003020      ADD  ERRSWI,(SP) ;ADD IN ERROR RETURN
72 023522 000207      RTS  PC
73 023524 017616 000000      9$:  MOV  @((SP),(SP) ;SET ERROR RETURN ADDRESS
74 023530 000207      RTS  PC
76
77      ; POSITION HEAD BIT FROM HEADER OR MULTIPURPOSE REGISTER TO LSB.
78
79 023532 013705 003054      POSHW1: MOV  HDWRD1,R5 ;START FOR POSITION HD BIT IN WD 1
80 023536 000402      BR   POSHDO     ;SKIP
81
82 023540 013705 003054      POSHSB: MOV  T.MP,R5 ;START FOR POSITION HD BIT IN MP
83 023544 010146      POSHDO: MOV  R1,-(SP) ;STORE R1
84 023546 042705 177677      BIC  #+CHSSTAT,R5 ;CLEAR ALL BUT HEAD SEL BIT
85 023552 012701 000006      MOV  #6,R1      ;SET SHIFT COUNT
86 023556 006205      1$:  ASR  R5          ;SHIFT FOR RIGHT JUSTIFY
87 023560 005301      DEC  R1
88 023562 001375      BNE  1$
89 023564 012601      MOV  (SP)+,R1   ;RESTORE R1
90 023566 000207      RTS  PC         ;RETURN
91
92      ; WAIT FOR READY ROUTINE. DURATION OF WAIT PASSED TO THE ROUTINE
93      ; FROM THE CALLING ROUTINE IN R1.
94 023570 010346      RDYWAIT: MOV  R3,-(SP) ;STORE R3
95 023572 013703 003004      MOV  SSINDEX,R3 ;GET SUBROUTINE INDEX
96 023576 005723      TST  (R3)+      ;BUMP IT FOR NEXT ENTRY
97 023600 016663 000002 002406      MOV  2(SP),SUBSTK(R3) ;INSERT THIS CALL
98 023606 162763 000004 002406      SUB  #4,SUBSTK(R3) ;ADJUST IT TO CALLING LOCATION
99 023614 010337 003004      MOV  R3,SSINDEX ;STORE IT BACK
100 023620 010046      MOV  R0,-(SP)
101 023622 010146      MOV  R1,-(SP)
102 023624 010446      MOV  R4,-(SP)
103 023626 012737 000002 003020      MOV  #2,ERRSWI  ;SET FOR NO ERROR RETURN
104 023634 004737 017214      1$:  JSR  PC,GSTAT   ;GET DRIVE STATUS
105 023640 024010      6$:
106 023642 032737 000001 003046      BIT  #DRDYMSK,T.CS ;CHECK IF READY

```

```

107 023650 001061      BNE      7$          ;YES - SKIP
108 023652 005301      DEC      R1          ;DEC WAIT COUNT
109 023654 001406      BEQ      2$          ;SKIP IF 0
110 023656 012737 000001 003456      MOV      #1,XDELAY  ;SAVE ARGUMENT
      023664 004737 016210      JSR      PC,TIME    ;CALL TIMING ROUTINE
111 023670 000761      BR       1$
112
113 023672 012703 010702 2$:      MOV      #MDRDY,R3  ;SET NAME MESSAGE PTR
114 023676 104456      TRAP    C$ERHRD
      023700 023444      .WORD   10020
      023702 000000      .WORD   0
      023704 012762      .WORD   ERR3
115 023706 012701 000062      MOV      #50,R1     ;SET WAIT COUNT FOR 5 SECONDS
116 023712 004737 017214 3$:      JSR      PC,GSTAT  ;GET DRIVE STATUS
117 023716 024010      6$
118 023720 032737 000001 003046      BIT      #DRDYMSK,T.CS ;TEST IF DRIVE READY
119 023726 001016      BNE      4$          ;YES - SKIP
120 023730 012737 000001 003460      MOV      #1,YDELAY  ;SAVE ARGUMENT
      023736 004737 016354      JSR      PC,XTIME  ;CALL TIMING ROUTINE
121 023742 005301      DEC      R1          ;DEC WAIT COUNT
122 023744 001362      BNE      3$          ;LOOP UNTIL TIME DONE
123 023746 012704 011615      MOV      #C5SEC,R4  ;SET CONDITION AFTER 5 SECDS
124 023752 104456      TRAP    C$ERHRD
      023754 023445      .WORD   10021
      023756 000000      .WORD   0
      023760 013100      .WORD   ERR5
125 023762 000410      BR       5$          ;EXIT
126
127 023764 032737 100000 003046 4$:      BIT      #ANYERR,T.CS ;TEST IF ANY ERROR SET
128 023772 001406      BEQ      6$          ;NO - SKIP
129 023774 104456      TRAP    C$ERHRD
      023776 023446      .WORD   10022
      024000 000000      .WORD   0
      024002 013150      .WORD   ERR6
130 024004 005337 003244 5$:      DEC      ERRCNT     ;DEC FOR DOUBLE ERROR REPORT
131 024010 005037 003020 6$:      CLR      ERRSWI     ;CLEAR FOR ERROR ERROR RETURN
132 024014 162737 000002 003004 7$:      SUB      #2,SSINDX  ;REMOVE ENTRY FROM SUBROUT STACK
133 024022 012604      MOV      (SP)+,R4   ;RESTORE REGISTERS
134 024024 012601      MOV      (SP)+,R1
135 024026 012600      MOV      (SP)+,R0
136 024030 012603      MOV      (SP)+,R3  ;RESTORE R3
137 024032 005737 003020      TST     ERRSWI     ;TEST IF ERROR RETURN
138 024036 001403      BEQ      8$          ;YES - SKIP
139 024040 063716 003020      ADD     ERRSWI,(SP) ;ADD IN ERROR RETURN
140 024044 000207      RTS     PC
141 024046 017616 000000 8$:      MOV     @ (SP),(SP) ;SET ERROR RETURN ADDRESS
142 024052 000207      RTS     PC
143
144 ;
145 ; GET POSITION ROUTINE. READS A HEADER FROM CURRENT CYLINDER
146 ; (WHERE IT IS PRESENTLY POSITIONED) AND STORES CYLINDER
147 ; NUMBER IN CURCYL.
147 024054 010346      GETPOS: MOV     R3,-(SP)   ;STORE REGISTERS
148 024056 013703 003004      MOV     SSINDX,R3  ;GET SUBROUTINE INDEX
149 024062 005723      TST     (R3)+      ;BUMP IT FOR NEXT ENTRY
150 024064 016663 000002 002406      MOV     2(SP),SUBSTK(R3) ;INSERT THIS CALL
151 024072 162763 000004 002406      SUB     #4,SUBSTK(R3) ;ADJUST IT TO CALLING LOCATION
152 024100 010337 003004      MOV     R3,SSINDX  ;STORE IT BACK
    
```



```

153 024104 010046      MOV      R0,-(SP)
154 024106 010546      MOV      R5,-(SP)
155 024110 004737 022540  JSR      PC,XRDHD      ;DO READ HEADER
156 024114 024144      2$
157 024116 013703 003054  MOV      HDWRD1,R3     ;GET HEADER WORD
158 024122 012705 000007  MOV      #7,R5         ;SET SHIFT COUNT
159 024126 006203      1$:  ASR      R3           ;SHIFT TO RIGHT JUSTIFY
160 024130 005305      DEC      R5
161 024132 001375      BNE     1$
162 024134 042703 177000  BIC     #177000,R3
163 024140 010337 003106  MOV     R3,CURCYL     ;STORE AS CURRENT CYLINDER
164 024144 162737 000002 003004  2$:  SUB     #2,SSINDX     ;REMOVE ENTRY FROM SUBROUT STACK
165 024152 012605      MOV     (SP)+,R5      ;RESTORE REGISTERS
166 024154 012600      MOV     (SP)+,R0
167 024156 012603      MOV     (SP)+,R3
168 024160 005737 003020  TST     ERRSWI        ;TEST IF ERROR RETURN
169 024164 001403      BEQ     3$           ;YES - SKIP
170 024166 063716 003020  ADD     ERRSWI,(SP)   ;ADD IN ERROR RETURN
171 024172 000207      RTS     PC
172 024174 017616 000000  3$:  MOV     @ (SP),(SP)  ;SET ERROR RETURN ADDRESS
173 024200 000207      RTS     PC
175
176 ;
177 ;
178 ;
179 024202 010346      VERPOS: MOV     R3,-(SP)      ;STORE R3
180 024204 013703 003004  MOV     SSINDX,R3     ;GET SUBROUTINE INDEX
181 024210 005723      TST     (R3)+         ;BUMP IT FOR NEXT ENTRY
182 024212 016663 000002 002406  MOV     2(SP),SUBSTK(R3) ;INSERT THIS CALL
183 024220 162763 000004 002406  SUB     #4,SUBSTK(R3) ;ADJUST IT TO CALLING LOCATION
184 024226 010337 003004  MOV     R3,SSINDX     ;STORE IT BACK
185
186 024232 012737 000002 003020  MOV     #2,ERRSWI     ;SET FOR NO ERROR RETURN
187 024240 004737 024054  JSR     PC,GETPOS     ;GET POSITION
188 024244 024272      1$
189 024246 023737 003104 003106  CMP     NEWCYL,CURCYL ;CHECK IF CURRENT CYL IS NEW CYL
190 024254 001406      BEQ     1$           ;YES - SKIP
191 024256 104456      TRAP   C$ERHRD
192 024260 023446      .WORD  10022
193 024262 000000      .WORD  0
194 024264 014102      .WORD  ERR8
195 024266 005037 003020  CLR     ERRSWI        ;CLEAR FOR ERROR RETURN
196 024272 162737 000002 003004  1$:  SUB     #2,SSINDX     ;REMOVE ENTRY FROM SUBROUT STACK
197 024300 012603      MOV     (SP)+,R3      ;RESTORE R3
198 024302 005737 003020  TST     ERRSWI        ;TEST IF ERROR RETURN
199 024306 001403      BEQ     2$           ;YES - SKIP
200 024310 063716 003020  ADD     ERRSWI,(SP)   ;ADD IN ERROR RETURN
201 024314 000207      RTS     PC
202 024316 017616 000000  2$:  MOV     @ (SP),(SP)  ;SET ERROR RETURN ADDRESS
203 024322 000207      RTS     PC
204 ;
205 ;
206 024324 010346      RDALHD: MOV     R3,-(SP)      ;STORE REGISTERS
207 024326 013703 003004  MOV     SSINDX,R3     ;GET SUBROUTINE INDEX
208 024332 005723      TST     (R3)+         ;BUMP IT FOR NEXT ENTRY

```

209	024334	016663	000002	002406	MOV	2(SP),SUBSTK(R3)	:INSERT THIS CALL	
210	024342	162763	000004	002406	SUB	#4,SUBSTK(R3)	:ADJUST IT TO CALLING LOCATION	
211	024350	010337	003004		MOV	R3,SSINDEX	:STORE IT BACK	
212	024354	010046			MOV	R0,-(SP)		
213	024356	010146			MOV	R1,-(SP)		
214	024360	010446			MOV	R4,-(SP)		
215	024362	012737	000002	003020	MOV	#2,ERRSWI	:SET FOR NO ERROR RETURN	
216	024370	012701	000050		MOV	#40,R1	:SET HEADER COUNT	
217	024374	052737	100000	003006	BIS	#HDR40,OPFLAG	:SET 40 HDR OP FLAG	
218	024402	012703	004472		MOV	#IBUFF,R3	:SET POINTER TO STORE HDRS	
219	024406	013704	003030		MOV	RLBAS,R4	:GET BASE ADDRESS	
220	024412	062704	000006		ADD	#RLMP,R4	:MAKE IT POINT TO MP REG	
221	024416	012737	000010	003036	MOV	#10,L.CS	:LOAD FOR READ HEADER, NO INTERRUPT	
222	024424	053737	003034	003036	BIS	RLDRV,L.CS	:INSERT DRIVE NUMBER	
223	024432	042737	002000	003036	BIC	#BIT10,L.CS	:CLEAR FOR DRIVE 4 - 7 SPEC'D	
224	024440	005037	003040		CLR	L.BA	:CLEAR BA	
225	024444	005037	003042		CLR	L.DA	:CLEAR DA	
226	024450	005737	003114		TST	DESHD	:TEST IF HEAD 0	
227	024454	001403			BEQ	1\$	:YES - SKIP	
228	024456	052737	000020	003042	BIS	#HSEL,L.DA	:ELSE INSERT HEAD 0	
229	024464	013762	003042	000004	1\$:	MOV	L.DA,RLDA(R2)	:LOAD RLDA REG
230	024472	013762	003040	000002	MOV	L.BA,RLBA(R2)	:LOAD RLBA	
231	024500	032762	000200	000000	BIT	#CRDYMSK,RLCS(R2)	:TEST IF CONTROLLER READY	
232	024506	001003			BNE	2\$	:YES - SKIP	
233	024510	004737	021230		JSR	PC,RDYCHK	:ELSE CHECK READY	
234	024514	024632			6\$			
235	024516	013762	003036	000000	2\$:	MOV	L.CS,RLCS(R2)	:LOAD RLCS REG
236	024524	012700	077777		MOV	#77777,R0	:SET COUNT FOR WAIT	
237	024530	032762	000200	000000	3\$:	BIT	#CRDYMSK,RLCS(R2)	:CHECK THAT OPERATION COMPLETED
238	024536	001016			BNE	4\$	:YES - SKIP	
239	024540	005300			DEC	R0	:DEC COUNT	
240	024542	001372			BNE	3\$	:SKIP IF NOT YET 0	
241	024544	004737	016756		JSR	PC,READRL	:ELSE GET ALL REGISTERS	
242	024550	004737	017010		JSR	PC,WAITIN	:ELSE WAIT FOR TIMEOUT	
243	024554	012603			MOV	(SP)+,R3	:GET RESULT MESSAGE POINTER	
244	024556	104456			TRAP	C\$ERHRD		
	024560	023451			.WORD	10025		
	024562	000000			.WORD	0		
	024564	012646			.WORD	ERR1		
245	024566	005037	003020		CLR	ERRSWI	:CLEAR FOR ERROR RETURN	
246	024572	000417			BR	6\$		
247								
248	024574	005737	003046	4\$:	TST	T.CS	:TEST FOR ANY ERRORS	
249	024600	100007			BPL	5\$	:NO - SKIP	
250	024602	104456			TRAP	C\$ERHRD		
	024604	023452			.WORD	10026		
	024606	000000			.WORD	0		
	024610	013150			.WORD	ERR6		
251	024612	005037	003020		CLR	ERRSWI	:CLEAR FOR ERROR RETURN	
252	024615	000405			BR	6\$		
253								
254	024620	011423		5\$:	MOV	(R4),(R3)+	:STORE HEADER WORDS	
255	024622	011423			MOV	(R4),(R3)+		
256	024624	011423			MOV	(R4),(R3)+		
257	024626	005301			DEC	R1	:DEC HEADER COUNT	
258	024630	001332			BNE	2\$		
259	024632	162737	000002	003004	6\$:	SUB	#2,SSINDEX	:REMOVE ENTRY FROM SUBROUT STACK

```

260 024640 012604      MOV      (SP)+,R4      ;RESTORE REGISTERS
261 024642 012601      MOV      (SP)+,R1
262 024644 012600      MOV      (SP)+,R0
263 024646 012603      MOV      (SP)+,R3
264 024650 005737 003020  TST      ERRSWI      ;TEST IF ERROR RETURN
265 024654 001403      BEQ      7$,         ;YES - SKIP
266 024656 063716 003020  ADD      ERRSWI,(SP) ;ADD IN ERROR RETURN
267 024662 000207      RTS      PC
268 024664 017616 000000  7$:     MOV      @ (SP),(SP) ;SET ERROR RETURN ADDRESS
269 024670 000207      RTS      PC
271
272 ; GENERATE DATA ROUTINE. PATTERN TO BE GENERATED IS GIVEN
273 ; IN THE WORD FOLLOWING THE CALL. 128 WORDS ARE GENERATED
274 ; IN OBUF.
275
276 024672 010146      DATGEN: MOV      R1,-(SP)      ;STORE REGISTERS
277 024674 010346      MOV      R3,-(SP)
278 024676 010446      MOV      R4,-(SP)
279 024700 012701 005072  MOV      #OBUF,R1      ;SET POINTER TO OBUF
280 024704 012504      MOV      (R5)+,R4      ;GET DATA PATTERN SELECTOR
281 024706 006304      ASL      R4            ;ADJUST IT FOR INDEXING
282 024710 016403 002362  MOV      PATTBL(R4),R3 ;GET ADDRESS OF PATTERN
283 024714 011321      MOV      (R3),(R1)+    ;MOVE FIRST PATTERN WORD
284 024716 001421      BEQ      5$,         ;SKIP IF PATTERN IS 0
285 024720 021327 177777  CMP      (R3),#-1      ;CHECK IF PATTERN IS ALL 1'S
286 024724 001416      BEQ      5$,         ;YES - SKIP
287 024726 020427 000010  CMP      R4,#8.        ;TEST IF PATTERN 5
288 024732 001403      BEQ      3$,         ;YES - SKIP
289 024734 020427 000020  CMP      R4,#16.       ;CHECK IF PATTERN 9 OR 10
290 024740 002413      BLT      6$,         ;NO - SKIP
291 024742 005723      3$:     TST      (R3)+        ;BUMP SOURCE POINTER
292 024744 012321      MOV      (R3)+,(R1)+  ;MOVE TWO MORE WORDS FORM SOURCE
293 024746 012321      MOV      (R3)+,(R1)+
294 024750 012704 000015  MOV      #13,R4        ;SET COUNT
295 024754 012703 005072  MOV      #OBUF,R3      ;RESET POINTER
296 024760 000406      BR      8$,
297
298 024762 012703 005072  5$:     MOV      #OBUF,R3      ;ELSE SET OBUF AS PATTERN SOURCE
299 024766 000401      BR      7$,         ;GO TO FILL
300
301 024770 005723      6$:     TST      (R3)+        ;BUMP SOURCE POINTER
302 024772 012704 000017  7$:     MOV      #15,R4        ;SET MOVE COUNT
303 024776 012321      8$:     MOV      (R3)+,(R1)+  ;MOVE 15 WORDS INTO BUFFER
304 025000 005304      DEC      R4
305 025002 001375      BNE      8$,
306 025004 012703 005072  MOV      #OBUF,R3      ;SET SOURCE TO TOP OF OBUF
307 025010 012704 000160  MOV      #112,R4       ;SET COUNT FOR REST OF BUFFER
308 025014 012321      10$:   MOV      (R3)+,(R1)+  ;REPEAT PATTERN IN BUFFER
309 025016 005304      DEC      R4
310 025020 001375      BNE      10$,
311 025022 012604      MOV      (SP)+,R4      ;RESTORE REGISTERS
312 025024 012603      MOV      (SP)+,R3
313 025026 012601      MOV      (SP)+,R1
314 025030 000205      RTS      R5           ;RETURN

```

```

1      ;      DATA COMPARE ROUTINE. COMPARES THE CONTENTS OF Ibuff AND Obuff.
2      ;      ERROR REPORTING IS LIMITED BY SOFTWARE PARAMETER.
3
4      025032 010346          DATCOM: MOV      R3,-(SP)          ;STORE R3
5      025034 013703 003004  MOV      SSINDX,R3      ;GET SUBROUTINE STACK INDEX
6      025040 005723          TST      (R3)+          ;BUMP INDEX TO NEXT ENTRY
7      025042 016663 000002 002406  MOV      2(SP),SUBSTK(R3) ;INSERT THIS CALL
8      025050 162763 000004 002406  SUB      #4,SUBSTK(R3)   ;ADJUST IT TO CALLING LOCATION
9      025056 010337 003004          MOV      R3,SSINDX      ;STORE IT BACK
10     025062 010146          MOV      R1,-(SP)       ;STORE OTHER REGISTERS
11     025064 010446          MOV      R4,-(SP)
12     025066 010546          MOV      R5,-(SP)
13     025070 052737 000001 003006  BIS      #DATACMP,OPFLAG ;SET DATA COMPARE FLAG
14     025076 005037 003016          CLR      MORECE        ;CLEAR MORE ERROR FLAG
15     025102 012705 005072          MOV      #OBUFF,R5     ;SET POINTERS TO DATA FOR COMPARE
16     025106 012704 004472          MOV      #IBUFF,R4
17     025112 012703 000001          MOV      #1,R3        ;SET WORD COUNTER
18     025116 012701 000200          MOV      #128,R1      ;SET COMPARE COUNT
19     025122 022425          1$:  CMP      (R4)+,(R5)+   ;COMPARE DATA
20     025124 001052          BNE     6$            ;ERROR - SKIP TO REPORT
21     025126 005203          2$:  INC      R3        ;BUMP WORD COUNT
22     025130 005301          DEC      R1          ;DEC COMPARE COUNT
23     025132 001373          BNE     1$            ;LOOP IF NOT 0
24     025134 042737 000001 003006  3$:  BIC      #DATACMP,OPFLAG ;CLEAR DATA COMPARE FLAG
25     025142 005737 003020          TST      ERRSWI        ;TEST IF ANY COMPARE ERRORS
26     025146 001021          BNE     4$            ;NO - SKIP
27     025150 012701 000200          MOV      #128,R1     ;SET REPORT VALUE
28     025154 010146          MOV      R1,-(SP)
29     025156 012746 011521          MOV      #RESE6,-(SP)
30     025162 013746 003016          MOV      MORECE,-(SP)
31     025166 012746 010230          MOV      #TCERR,-(SP)
32     025172 012746 012615          MOV      #FMT27,-(SP)
33     025176 012746 000005          MOV      #5,-(SP)
34     025202 010600          MOV      SP,R0
35     025204 104414          TRAP    C$PNTB
36     025206 062706 000014          ADD      #14,SP
37     025212 162737 000002 003004  4$:  SUB      #2,SSINDX     ;REMOVE ENTRY FROM SUBROUT STACK
38     025220 012605          MOV      (SP)+,R5     ;RESTORE REGS
39     025222 012604          MOV      (SP)+,R4
40     025224 012601          MOV      (SP)+,R1
41     025226 012603          MOV      (SP)+,R3
42     025230 005737 003020          TST      ERRSWI        ;TEST IF ERROR RETURN
43     025234 001403          BEQ     5$            ;YES - SKIP
44     025236 063716 003020          ADD      ERRSWI,(SP)  ;ADD IN ERROR RETURN
45     025242 000207          RTS     PC
46     025244 017616 000000          5$:  MOV      @ (SP),(SP)   ;SET ERROR RETURN ADDRESS
47     025250 000207          RTS     PC
48     025252 023737 003016 014512  6$:  CMP      MORECE,DCLIMW ;TEST IF COMPARE ERRORS LIMIT EXCEEDED
49     025260 002011          BGE     7$            ;YES - SKIP
50     025262 024445          CMP      -(R4),-(R5)  ;SET PTRS BACK TO ERROR WORDS
51     025264 104456          TRAP    C$ERHRD
52     025266 023463          .WORD  10035
53     025270 000000          .WORD  0
54     025272 014242          .WORD  ERR10
55     025274 005037 003020          CLR      ERRSWI        ;CLEAR ERROR SWITCH
56     025300 022425          CMP      (R4)+,(R5)+  ;BUMP PTRS PAST ERROR WORDS
57     025302 000711          BR     2$            ;DO NEXT COMPARE
    
```

B8

```
47  
48 025304 005237 003016      7$:  INC  MORECE      :BUMP ERROR COUNTER  
49 025310 000706              BR   2$           :DO NEXT COMPARE
```

```

1
2
3
4 025312 012737 177777 003122 XWRITT: MOV #1,TEMP1 ;SET SPECIAL WRITE FOR TIMING FLAG
5 025320 000402 BR XWRIT1
6 025322 005037 003122 XWRITE: CLR TEMP1 ;CLEAR SPECIAL WRITE FLAG
7 025326 012737 000112 003136 XWRIT1: MOV #WTDATA,TEMP7 ;SET FOR WRITE
8 025334 023737 002304 003106 CMP HLMTW,CURCYL ;TEST IF CYLINDER MAX (BAD SEC)
9 025342 001006 BNE 1$ ;NO - SKIP
10 025344 005737 003114 TST DESHD ;TEST IF HEAD 1 (BAD SECTOR FILES)
11 025350 001403 BEQ 1$ ;NO - SKIP
12 025352 052737 004000 003006 BIS #BADADD,OPFLAG ;SET BAD ADDRESS FLAG
13 025360 000403 1$: BR XREADG ;SKIP TO EXECUTE
14
15 025362 012737 000114 003136 XREAD: MOV #RDDATA,TEMP7 ;SET FOR READ
16 025370 010346 XREADG: MOV R3,-(SP) ;STORE R3
17 025372 013703 003004 MOV SSINDX,R3 ;SET SUBROUTINE INDEX
18 025376 005723 TST (R3)+ ;BUMP TO NEXT STACK ENTRY
19 025400 016663 000002 002406 MOV 2(SP),SUBSTK(R3) ;INSERT THIS CALL
20 025406 162763 000004 002406 SUB #4,SUBSTK(R3) ;ADJUST TO POINT TO CALL
21 025414 010337 003004 MOV R3,SSINDX ;STORE IT BACK
22 025420 010046 MOV R0,-(SP)
23 025422 010146 MOV R1,-(SP) ;STORE OTHER REGISTERS
24 025424 010446 MOV R4,-(SP)
25 025426 004737 021230 JSR PC,RDYCHK ;CHECK IF DRIVE READY
26 025432 026064 14$
27 025434 012703 003036 MOV #L.CS,R3 ;GET ADDRESS OF LOAD REGS
28 025440 013713 003136 MOV TEMP7,(R3) ;SET COMMAND
29 025444 053713 003034 BIS RLDRV,(R3) ;INSERT DRIVE NUMBER
30 025450 042713 002000 BIC #BIT10,(R3) ;CLEAR FOR DRIVE 4 - 7 SPEC'D
31 025454 032723 000004 BIT #BIT2,(R3)+ ;TEST IF WRITE DATA
32 025460 001403 BEQ 1$ ;YES - SKIP
33 025462 012723 004472 MOV #IBUFF,(R3)+ ;ELSE SET BA FOR READ
34 025466 000402 BR 2$
35
36 025470 012723 005072 1$: MOV #OBUFF,(R3)+ ;SET BA FOR WRITE
37 025474 013713 003106 2$: MOV CURCYL,(R3) ;GET CURRENT CYLINDER
38 025500 012704 000007 MOV #7,R4 ;ALIGN IT IN DA
39 025504 006313 3$: ASL (R3)
40 025506 005304 DEC R4
41 025510 001375 BNE 3$
42 025512 005737 003114 TST DESHD ;TEST IF HEAD 0
43 025516 001402 BEQ 4$ ;YES - SKIP
44 025520 052713 000100 BIS #HMSK,(R3) ;SET FOR HEAD 1
45 025524 053723 003116 4$: BIS DESSEC,(R3)+ ;INSERT DESIRED SECTOR
46 025530 012713 177600 MOV #177600,(R3) ;INSERT WORD COUNT
47 025534 023737 003106 002304 CMP CURCYL,HLMTW ;IS THIS BSF CYLINDER?
48 025542 001004 BNE 5$ ;NO - SKIP
49 025544 005737 003114 TST DESHD ;TEST IF HEAD 1
50 025550 001401 BEQ 5$ ;NO - SKIP
51 025552 006313 ASL (R3) ;MAKE WORD COUNT 2 SECTORS
52 025554 005737 003122 5$: TST TEMP1 ;CHECK IF SPECIAL WRITE FOR TIMING
53 025560 001402 BEQ 6$ ;NO - SKIP
54 025562 012713 177777 MOV #177777,(R3) ;ELSE SET FOR 1 WORD TRANSFER
55 025566 032737 004000 003006 6$: BIT #BADADD,OPFLAG ;TEST IF BAD ADDRESS FLAG SET
56 025574 001414 BEQ 7$ ;NO - SKIP
57 025576 042737 173777 003006 BIC #CBADADD,OPFLAG ;CLEAR ALL BUT THIS FLAG
    
```

```

58 025604 012703 011423      MOV      #MWRTAB,R3      ;SET RESULT MESSAGE POINTER
59 025610 104456      TRAP     C$ERHRD
   025612 023460      .WORD   10032
   025614 000000      .WORD   0
   025616 012646      .WORD   ERR1
60 025620 005037 003006      CLR     OPFLAG          ;CLEAR ALL FLAGS
61 025624 000515      BR      13$
62
63 025626 005037 003010      7$:    CLR     DONE          ;CLEAR INTERRUPT FLAG
64 025632 005737 003122      TST     TEMP1          ;CHECK IF SPECIAL WRITE FLAG SET
65 025636 001112      BNE     14$            ;YES - DO NOT START WRITE
66 025640 011362 000006      MOV     (R3),RLMP(R2)  ;LOAD RL REGS
67 025644 014362 000004      MOV     -(R3),RLDA(R2)
68 025650 014362 000002      MOV     -(R3),RLBA(R2)
69 025654 014362 000000      MOV     -(R3),RLCS(R2)
70 025660
   025660 012737 00567C 003456      8$:    MOV     #3000,XDELAY  ;SAVE ARGUMENT
   025666 004737 016210      JSR     PC,TIME        ;CALL TIMING ROUTINE
71 025672 005737 003010      TST     DONE          ;CHECK IF INTERRUPT
72 025676 001010      BNE     9$            ;YES - SKIP
73 025700 004737 017010      JSR     PC,WAITIN      ;WAIT FOR INTERRUPT
74 025704 012603      MOV     (SP)+,R3       ;GET RESULT MESSAGE
75 025706 104456      TRAP     C$ERHRD
   025710 023456      .WORD   10030
   025712 000000      .WORD   0
   025714 012646      .WORD   ERR1
76 025716 000460      BR      13$
77
78 025720 032737 000001 003046      9$:    BIT     #DRDYMSK,T.CS ;TEST IF DRIVE READY
79 025726 001033      BNE     11$            ;YES - SKIP
80 025730 012703 010702      MOV     #MDRDY,R3     ;SET RESULT MESSAGE
81 025734 012704 011604      MOV     #CAFDT,R4     ;CONDITION AFTER DATA XFER
82 025740 104456      TRAP     C$ERHRD
   025742 023460      .WORD   10032
   025744 000000      .WORD   0
   025746 013100      .WORD   ERR5
83 025750 012701 000062      MOV     #50,R1        ;SET WAIT COUNT FOR 5 SECDS
84 025754 004737 017214      10$:   JSR     PC,G$STAT     ;GET DRIVE STATUS
85 025760 026060      13$
86 025762 032737 000001 003046      BIT     #DRDYMSK,T.CS ;TEST IF DRIVE READY NOW
87 025770 001012      BNE     11$            ;YES - SKIP
88 025772 005301      DEC     R1            ;DEC WAIT COUNT
89 025774 001367      BNE     10$           ;LOOP IF NOT TIME DONE
90 025776 012704 011615      MOV     #C$SEC,R4     ;SET CONDITION 5 SECONDS
91 026002 104456      TRAP     C$ERHRD
   026004 023461      .WORD   10033
   026006 000000      .WORD   0
   026010 013100      .WORD   ERR5
92 026012 005037 003020      CLR     ERRSWI        ;CLEAR ERROR SWITCH
93 026016 005737 003046      11$:   TST     T.CS          ;CHECK IF ANY ERROR
94 026022 100020      BPL     14$            ;NO - SKIP
95 026024 023737 003106 002304      CMP     CURCYL,HLMTW  ;IS THIS BSF CYLINDER?
96 026032 001006      BNE     12$            ;NO - SKIP
97 026034 005737 003114      TST     DESHD        ;TEST IF HEAD 1
98 026040 001403      BEQ     12$            ;NO - SKIP
99 026042 005737 014514      TST     BSERRS       ;OUTPUT ALL BSF ERRORS?
100 026046 001404      BEQ     13$           ;NO - SKIP

```

```

101 026050          12$: TRAP      C$ERHRD
    026050 104456      .WORD    10031
    026052 023457      .WORD    0
    026054 000000      .WORD    ERR6
102 026060 005037 003020 13$: CLR      ERRSWI      ;CLEAR ERROR SWITCH
103 026064 162737 000002 003004 14$: SUB      #2,SSINDX   ;REMOVE ENTRY FROM SUBROUT STACK
104 026072 012604      MOV      (SP)+,R4   ;RESTORE REGISTERS
105 026074 012601      MOV      (SP)+,R1
106 026076 012600      MOV      (SP)+,R0
107 026100 012603      MOV      (SP)+,R3
108 026102 005737 003020  TST      ERRSWI      ;TEST IF ERROR RETURN
109 026106 001403      BEQ      15$        ;YES - SKIP
110 026110 063716 003020  ADD      ERRSWI,(SP) ;ELSE ADD IN ERROR RETURN
111 026114 000207      RTS
112 026116 017616 000000 15$: MOV      @ (SP),(SP) ;ADJUST FOR ERROR RETURN
113 026122 000207      RTS      PC
114
115 ;
116 ; BAD SECTOR CHECK ROUTINE. CHECKS IF SECTOR SPECIFIED IN CURCYL,
117 ; DESHD, AND DESSEC IS LISTED AS BAD IN THE BAD SECTOR FILES.
118 026124 010046      BSCHK: MOV      R0,-(SP)   ;STORE REGISTERS
119 026126 010146      MOV      R1,-(SP)
120 026130 010346      MOV      R3,-(SP)
121 026132 005037 003022  CLR      BSFLAG     ;CLEAR FLAG
122 026136 012703 003502  MOV      #FCTBSF,R3 ;GET POINTER TO FACTORY FILE
123 026142 022713 177777  CMP      #-1,(R3)   ;CHECK IF ALL ONES
124 026146 001005      BNE      2$        ;NO SKIP TO TEST
125 026150 012703 004076 1$: MOV      #FLDBSF,R3 ;ELSE SET POINTER TO FIELD BS FILE
126 026154 022713 177777  CMP      #-1,(R3)   ;CHECK IF ALL ONES
127 026160 001431      BEQ      8$        ;YES - EXIT
128 026162 013700 003104 2$: MOV      NEWCYL,R0 ;BUILD HEADER OF ADDRESS IN QUESTION
129 026166 012701 000007  MOV      #7,R1      ;# OF POSITIONS TO SHIFT CYLINDER
130 026172 006300      3$: ASL      R0      ;SHIFT NUMBER
131 026174 005301      DEC      R1        ;DONE YET?
132 026176 001375      BNE      3$        ;NO, ANOTHER SHIFT PLEASE
133 026200 005737 003114  TST      DESHD     ;CHECK IF HEAD 0
134 026204 001402      BEQ      4$        ;YES - SKIP
135 026206 052700 000100  BIS      #BIT6,R0   ;INSERT HEAD 1
136 026212 053700 003116 4$: BIS      DESSEC,R0 ;INSERT SECTOR
137 026216 022300      5$: CMP      (R3)+,R0 ;DID WE FIND AN ENTRY MATCH?
138 026220 001402      BEQ      6$        ;YES - EXIT
139 026222 101005      BHI      7$        ;NO - FOUND FILE TERMINATOR
140 026224 000774      BR       5$        ;NEITHER TRY NEXT ENTRY...
141
142 026226 012737 000001 003022 6$: MOV      #1,BSFLAG  ;SET ERROR FLAG
143 026234 000403      BR       8$        ;GO TO EXIT
144
145 026236 020327 004076      7$: CMP      R3,#FLDBSF ;DONE BOTH FILES?
146 026242 003742      BLE      1$        ;NO, GO DO FIELD FILE
147 026244 012603      8$: MOV      (SP)+,R3 ;ELSE RESTORE REGISTERS
148 026246 012601      MOV      (SP)+,R1
149 026250 012600      MOV      (SP)+,R0
150 026252 005737 003022  TST      BSFLAG     ;CHECK IF ERROR
151 026256 001003      BNE      9$        ;YES - SKIP
152 026260 062716 000002  ADD      #2,(SP)    ;ELSE BUMP ERROR RETURN
153 026264 000207      RTS      PC

```



```

154 026266 017616 000000 9$: MOV @ (SP), (SP) ;SET FOR ERROR RETURN
155 026272 000207 RTS PC
157
158 ;
159 ; REPORT OPERATION ROUTINE. PRINTS SUBROUTINE TRACE SEQUENCE AND
160 ; OPERATION BEING PERFORMED PORTION OF ALL
161 ; ERROR MESSAGES.
162 026274 010446 RPTOP: MOV R4, -(SP)
163 026276 005737 003004 TST SSINDX ;TEST SUBROUTINE INDEX 0
164 026302 001433 BEQ 2$ ;SKIP IF 0
165 026304 012704 000002 MOV #2, R4 ;SET INDEXER TO FIRST ENTRY
166 026310 012746 010174 MOV #SEQMES, -(SP)
026314 012746 012134 MOV #FMT9, -(SP)
026320 012746 000002 MOV #2, -(SP)
026324 010600 MOV SP, R0
026326 104414 TRAP C$PNTB
026330 062706 000006 ADD #6, SP
167 026334 1$: MOV SUBSTK(R4), -(SP)
026334 016446 002406 MOV #FMT16, -(SP)
026340 012746 012307 MOV #2, -(SP)
026344 012746 000002 MOV SP, R0
026350 010600 TRAP C$PNTB
026352 104414 ADD #6, SP
026354 062706 000006 ADD #2, R4 ;BUMP INDEX
168 026360 062704 000002 CMP R4, SSINDX ;CHECK IF ALL PRINTED
169 026364 020437 003004 BLE 1$ ;LOOP IF NOT ALL PRINTED YET
170 026370 003761 2$: MOV #TSTLAB, -(SP)
171 026372 012746 007150 MOV ERHEAD, -(SP)
026376 013746 003014 MOV #FMT4, -(SP)
026402 012746 011737 MOV #3, -(SP)
026406 012746 000003 MOV SP, R0
026412 010600 TRAP C$PNTB
026414 104414 ADD #10, SP
026416 062706 000010 BIC #SEEKOP!RORWOP, OPFLAG ;CLEAR SK & RD OR WRT FLAG
172 026422 042737 030000 003006 MOV L, CS, R1 ;GET COMMAND EXECUTED
173 026430 013701 003036 BIC #177741, R1 ;STRIP ALL BUT FUNCTION CODE
174 026434 042701 177741 CMP #6, R1 ;TEST IF SEEK OPERATION
175 026440 022701 000006 BNE 3$ ;NO - SKIP
176 026444 001003 BIS #SEEKOP, OPFLAG ;ELSE SET SEEK FLAG
177 026446 052737 010000 003006 3$: CMP #12, R1 ;TEST IF WRITE
178 026454 022701 000012 BNE 4$ ;NO - SKIP
179 026460 001003 BIS #RORWOP, OPFLAG ;SET RD OR WRT FLAG
180 026462 052737 020000 003006 4$: CMP #14, R1 ;TEST IF READ
181 026470 022701 000014 BNE 5$ ;NO - SKIP
182 026474 001003 BIS #RORWOP, OPFLAG ;SET RD OR WRT FLAG
183 026476 052737 020000 003006 5$:
184 026504 MOV OPMSGS(R1), -(SP)
026504 016146 002226 MOV #MOPER, -(SP)
026510 012746 006117 MOV #FMT1, -(SP)
026514 012746 011723 MOV #3, -(SP)
026520 012746 000003 MOV SP, R0
026524 010600 TRAP C$PNTB
026526 104414 ADD #10, SP
026530 062706 000010 CMP R1, #4 ;CHECK IF GET STATUS
185 026534 020127 000004 BNE 6$ ;NO - SKIP
186 026540 001007

```

```

187 026542 032737 000010 003042      BIT      #DRSET,L.DA      ;TEST IF RESET INCLUDED
188 026550 001403                      BEQ      6$            ;NO - SKIP
189 026552 012701 000016      MOV      #16,R1        ;SET TO PRINT WITH RESET
190 026556 000436      BR      10$
191
192 026560 032737 007777 003006 6$:    BIT      #CMPOP,OPFLAG ;TEST IF ANY OTHER OPERATION
193 026566 001424                      BEQ      9$            ;NO - SKIP
194 026570 013704 003006      MOV      OPFLAG,R4     ;SET UP TO DETERMINE WHICH ONE
195 026574 012701 000020      MOV      #20,R1        ;PRESET THE POINTER
196 026600 032704 000001      BIT      #BIT00,R4     ;CHECK THE BIT
197 026604 001003                      BNE      8$            ;IF SET - SKIP
198 026606 005721                      TST     (R1)+          ;BUMP POINTER
199 026610 006204                      ASR     R4
200 026612 000772                      BR      7$
201
202 026614                      8$:
026614 016146 002226      MOV      OPMSG$(R1),-(SP)
026620 012746 011626      MOV      #FMTXT, -(SP)
026624 012746 000002      MOV      #2, -(SP)
026630 010600      MOV      SP,R0
026632 104414      TRAP    C$PNTB
026634 062706 000006      ADD     #6,SP
203 026640 032737 100000 003006 9$:    BIT      #HDR40,OPFLAG ;TEST IF 40 HEADER OPERATION
204 026646 001415                      BEQ     11$           ;NO - SKIP
205 026650 012701 000050      MOV     #50,R1         ;ELSE PRINT IT
206 026654                      10$:
026654 016146 002226      MOV      OPMSG$(R1),-(SP)
026660 012746 011626      MOV      #FMTXT, -(SP)
026664 012746 000002      MOV      #2, -(SP)
026670 010600      MOV      SP,R0
026672 104414      TRAP    C$PNTB
026674 062706 000006      ADD     #6,SP
207 026700 000434                      BR      12$
208
209 026702 032737 010000 003006 11$:   BIT      #SEEKOP,OPFLAG ;TEST IF SEEK
210 026710 001430                      BEQ     12$           ;NO - SKIP
211 026712 013746 003114      MOV     DESHD, -(SP)
026716 012746 010135      MOV     #HDWD, -(SP)
026722 013746 003112      MOV     DESSGN, -(SP)
026726 012746 010130      MOV     #SGNWD, -(SP)
026732 013746 003110      MOV     DESDIF, -(SP)
026736 012746 010122      MOV     #DIFWD, -(SP)
026742 013746 003102      MOV     OLDCYL, -(SP)
026746 012746 010153      MOV     #FRMWD, -(SP)
026752 012746 012155      MOV     #FMT13, -(SP)
026756 012746 000011      MOV     #11, -(SP)
026762 010600      MOV     SP,R0
026764 104414      TRAP    C$PNTB
026766 062706 000024      ADD     #24,SP
212 026772 032737 020000 003006 12$:   BIT      #RORWOP,OPFLAG ;TEST IF READ OR WRITE SET
213 027000 001424                      BEQ     13$           ;NO - SKIP
214 027002 013746 003116      MOV     DESSEC, -(SP)
027006 012746 010141      MOV     #SECWD, -(SP)
027012 013746 003114      MOV     DESHD, -(SP)
027016 012746 010135      MOV     #HDWD, -(SP)
027022 013746 003106      MOV     CURCYL, -(SP)
027026 012746 010146      MOV     #CYLWD, -(SP)

```

```

027032 012746 012504      MOV    #FMT22,-(SP)
027036 012746 000007      MOV    #7,-(SP)
027042 010600              MOV    SP,R0
027044 104414              TRAP  C$PNTB
027046 062706 000020      ADD    #20,SP
215 027052 004737 027524 13$: JSR    PC,CLRPARM      ;CLEAR PARAM TABLE
216 027056 012604              MOV    (SP)+,R4      ;RESTORE R4
217 027060 000207              RTS    PC
218
219
220
221 027062 010146      ; REPORT REASON ROUTINE
222 027064 010346      ; PRINTS REASON PORTION FOR ALL ERROR REPORTS.
223 027066 010446      RPTRES: MOV    R1,-(SP)      ;STORE R1
224 027070 012701 003064      MOV    R3,-(SP)      ;STORE R3
225 027074 012103      MOV    R4,-(SP)      ;STORE R4
226 027076 011146      MOV    #RESPARM,R1    ;GET START OF PARAM
027100 012746 006126      MOV    (R1)+,R3      ;GET NUMBER OF PARAM
027104 012746 011730      MOV    (R1),-(SP)
027110 012746 000003      MOV    #MRSLT,-(SP)
027114 010600              MOV    #3,-(SP)
027116 010446              MOV    SP,R0
027120 062706 000010      TRAP  C$PNTB
227 027124 021127 011274      ADD    #10,SP
228 027130 001453      CMP    (R1),#MNDRST   ;TEST IF MESSAGE IS NO DRV STATUS
229 027132 012704 012141      BEQ    2$             ;YES - SKIP REST OF REPORT
230 027136 022127 011267      MOV    #FMT11,R4     ;PRISET FOR FORMAT 11
231 027142 001002      CMP    (R1)+,#MCYLOC ;CHECK IF REPORTING CYLINDER LOC
232 027144 012704 012147      BNE    1$             ;NO - SKIP
233 027150 005303      1$: DEC    R3         ;ELSE CHANGE TO FORMAT 12
234 027152 001442      BEQ    2$             ;DEC PARAM COUNT
235 027154 012146      MOV    (R1)+,-(SP)   ;IF 0 - EXIT
027156 012746 011503      MOV    #RESE3,-(SP)
027162 010446      MOV    R4,-(SP)
027164 012746 000003      MOV    #3,-(SP)
027170 010600      MOV    SP,R0
027172 104414      TRAP  C$PNTB
236 027174 062706 000010      ADD    #10,SP
027200 012146      MOV    (R1)+,-(SP)
027202 012746 011507      MOV    #RESE4,-(SP)
027206 010446      MOV    R4,-(SP)
027210 012746 000003      MOV    #3,-(SP)
027214 010600      MOV    SP,R0
027216 104414      TRAP  C$PNTB
237 027220 062706 000010      ADD    #10,SP
238 027224 162703 000002      SUB    #2,R3         ;DEC PARAM COUNT
239 027230 001413      BEQ    2$             ;IF 0 - EXIT
027232 012146      MOV    (R1)+,-(SP)
027234 012746 011514      MOV    #RESE5,-(SP)
027240 012746 011723      MOV    #FMT1,-(SP)
027244 012746 000003      MOV    #3,-(SP)
027250 010600      MOV    SP,R0
027252 104414      TRAP  C$PNTB
240 027254 062706 000010      ADD    #10,SP
241 027260 012604      2$: MOV    (SP)+,R4     ;RESTORE REGS
242 027262 012603      MOV    (SP)+,R3
027264 012601      MOV    (SP)+,R1
    
```

```

243 027266 000207          RTS      PC          ;RETURN
244
245
246
247 027270          ;
      :          REPORT PHYSICAL ADDRESS OF DEVICE UNDER TEST
      :          AND ALL REGISTER CONTENTS.
      RPTREM: CLR      -(SP)
      BLSB     RLDRV+1,(SP)
      MOV      #DRVNAM,-(SP)
      MOV      RLBAS,-(SP)
      MOV      #BASADD,-(SP)
      MOV      #FMT5,-(SP)
      MOV      #5,-(SP)
      MOV      SP,RO
      TRAP     C$PNTB
      ADD      #14,SP

248
249
250 027332 012746 010135  ;
      :          REPORT RL11 REGISTERS
      MOV      #HDWD,-(SP)
      MOV      #CYLWD,-(SP)
      MOV      #MPNAM,-(SP)
      MOV      #BANAM,-(SP)
      MOV      #DANAM,-(SP)
      MOV      #CSNAM,-(SP)
      MOV      #FMT6,-(SP)
      MOV      #7,-(SP)
      MOV      SP,RO
      TRAP     C$PNTB
      ADD      #20,SP
      MOV      L.MP,-(SP)
      MOV      L.BA,-(SP)
      MOV      L.DA,-(SP)
      MOV      L.CS,-(SP)
      MOV      #LAB1,-(SP)
      MOV      #FMT8,-(SP)
      MOV      #6,-(SP)
      MOV      SP,RO
      TRAP     C$PNTB
      ADD      #16,SP
      MOV      DESHD,-(SP)
      MOV      CURCYL,-(SP)
      MOV      T.MP,-(SP)
      MOV      T.BA,-(SP)
      MOV      T.DA,-(SP)
      MOV      T.CS,-(SP)
      MOV      #LAB2,-(SP)
      MOV      #FMT7,-(SP)
      MOV      #10,-(SP)
      MOV      SP,RO
      TRAP     C$PNTB
      ADD      #22,SP
      RTS      PC

251 027402 013746 003044
      027406 013746 003040
      027412 013746 003042
      027416 013746 003036
      027422 012746 006731
      027426 012746 012102
      027432 012746 000006
      027436 010600
      027440 104414
      027442 062706 000016
      027446 013746 003114
      027452 013746 003106
      027456 013746 003054
      027462 013746 003050
      027466 013746 003052
      027472 013746 003046
      027476 012746 006744
      027502 012746 012032
      027506 012746 000010
      027512 010600
      027514 104414
      027516 062706 000022
      027522 000207

252
253
254
255
256 027524 010546          CLRPARM: MOV      R5,-(SP)          ;STORE R5
257 027526 012701 003064  MOV      #RESPARM,R1          ;GET ADDRESS OF BLOCK
258 027532 012705 000005  MOV      #5,R5                ;SET COUNT
259 027536 005021          1$: CLR      (R1)+            ;CLEAR WORD
    
```

J8

260 027540 005305  
261 027542 001375  
262 027544 012701 003064  
263 027550 012605  
264 027552 000207  
265

DEC R5 ;DEC COUNT  
BNE 1\$ ;LOOP UNTIL 0  
MOV #RESPARM,R1 ;RESET POINTER  
MOV (SP)+,R5 ;RESTORE R5  
RTS PC

```

1      .TITLE  CZRLNCO RL01/02 DRIVE TEST 3
2
3
4
5      .SBTTL  *TEST 1          **SEEK TIMING
6
7      027554
10     027554  012737  000001  003240  T1::  MOV    #1,TSTNM      ;SAVE TEST NUMBER
11     027562  012737  007343  0C3014  MOV    #P2T12E,ERHEAD ;SET ERROR HEADER
12
13     ;CHECK FOR PRESENCE OF A P-CLOCK...BYPASS TEST IF NOT AVAILABLE
14     027570  005737  003474  TST    CLKFLG        ;P-CLOCK?
15     027574  001014  BNE    1$           ;BRANCH TO PERFORM TEST IF P-CLOCK IS PRESENT
16     027576  013746  003240  MOV    TSTNM,-(SP)
      027602  012746  010364  MOV    #NOTST,-(SP)
      027606  012746  000002  MOV    #2,-(SP)
      027612  010600  MOV    SP,R0
      027614  104417  TRAP   C$PNTF
      027616  062706  000006  ADD    #6,SP
17
18     027622  000137  031472  JMP    20$          ;/P-CLOCK IS NOT AVAILABLE"
19     ;EXIT TEST
20     027626  004737  017146  1$:  JSR    PC,TSTINT    ;INITIALIZE TEST
21     027632  004737  017164  JSR    PC,GSTATR    ;CLEAR DRIVE
22     027636  031472  20$
23     027640  012700  003142  MOV    #OFIN,R0     ;GET ADDRESS OF 1ST TIME VALUE
24     027644  012701  000030  MOV    #24,R1       ;SET COUNT FOR CLEAR
25     027650  005020  2$:  CLR    (R0)+        ;CLEAR TIMER STORAGE
26     027652  005301  DEC    R1
27     027654  001375  BNE    2$
28     027656  005037  003234  CLR    PASCNT       ;CLEAR PASS COUNTER
29     027662  005037  003104  CLR    NEWCYL       ;POSITION HEADS AT 0
30     027666  004737  020112  JSR    PC,XSEEK     ;DO SEEK
31     027672  031472  20$
32     027674  012701  005670  MOV    #3000,R1     ;SET WAIT FOR 300 MS
33     027700  004737  023570  JSR    PC,RDYWAIT   ;WAIT FOR READY
34     027704  031472  20$
35     027706  004737  024202  JSR    PC,VERPOS    ;VERIFY POSITION
36     027712  031472  20$
37     027714  004737  021504  JSR    PC,CHOSHD    ;GO CHOSE HEAD
38     027720  012700  003152  MOV    #OFOUT,R0    ;SET PTRS FOR 1 CYL FWD OUTER TIMER
39     027724  012701  003154  MOV    #OFOUTU,R1
40     027730  012703  003166  MOV    #OROUT,R3
41     027734  012704  003170  MOV    #OROUTU,R4
42     027740  012737  000001  003104  MOV    #1,NEWCYL    ;SET NEWCYL TO CYL 1
43     027746  012737  000200  003236  3$:  MOV    #128,COUNT   ;SET COUNTER FOR SEEK LOOP
44     027754  012737  000110  003140  MOV    #RDHEAD,TEMP8 ;BUILD READ HEADER COMMAND
45     027762  053737  003034  003140  BIS    RLDIV,TEMP8
46     027770  042737  002000  003140  BIC    #BIT10,TEMP8
47     027776  004737  020102  4$:  JSR    PC,XSEEKT   ;DO SEEK BUILD BUT DO NOT START
48     030002  031472  20$
49     030004  013762  003042  000004  MOV    L.DA,RLDA(R2) ;LOAD RL REGISTERS
50     030012  013762  003036  000000  MOV    L.CS,RLCS(R2)
51     030020  010046  MOV    R0,-(SP)     ;STORE R0
52     030034  005737  003010  TST    DONE         ;TEST IF INTERRUPT
53     030040  001011  BNE    5$           ;YES - SKIP
54     030042  004737  017010  JSR    PC,WAITIN    ;WAIT FOR INTERRUPT
55     030046  012603  MOV    (SP)+,R3     ;GET MESSAGE POINTER

```

57	030050	104456			TRAP	C\$ERHRD	
	030052	002261			.WORD	1201	
	030054	000000			.WORD	0	
	030056	012646			.WORD	ERR1	
58	030060	000137	031472		JMP	20\$	
59							
60	030064	005737	003046	5\$:	TST	T.CS	;CHECK IF ANY ERRORS
61	030070	100006			BPL	6\$	;NO - SKIP
62	030072	104456			TRAP	C\$ERHRD	
	030074	002262			.WORD	1202	
	030076	000000			.WORD	0	
	030100	013150			.WORD	ERR6	
63	030102	000137	031472		JMP	20\$	
64							
65	030106	005037	003010	6\$:	CLR	DONE	;CLEAR INTERRUPT FLAG
66	030112	005037	172542		CLR	@#CLKCSB	;CLEAR CLOCK COUNT SET BUFFER
	030116	005037	172544		CLR	@#CLKCTR	;CLEAR CLOCK COUNTER
	030122	012737	000023	172540	MOV	#23,@#CLKCSR	;INITIALIZE CLOCK FOR COUNT-UP MODE, ;/OF TIME INTERVAL
67							
68	030130	013762	003140	000000	MOV	TEMP8,RLCS(R2)	;LOAD RL11 CONTROL AND STATUS REGISTER ;/TO INITIATE SEEK OPERATION
69							
70	030136	012737	003720	003456	MOV	#2000.,XDELAY	;SAVE ARGUMENT
	030144	004737	016210		JSR	PC,TIME	;CALL TIMING ROUTINE
71	030150	013705	172544		MOV	@#CLKCTR,R5	;STORE CLOCK COUNTER CONTENTS
	030154	005037	172540		CLR	@#CLKCSR	;EVENT FINISHED, STOP CLOCK
72	030160	012600			MOV	(SP)+,R0	;RESTORE R0
73	030162	013737	003140	003036	MOV	TEMP8,L.CS	;SET IF ERROR TO REPORT
74	030170	004737	024202		JSR	PC,VERPOS	;VERIFY POSITION
75	030174	031472			20\$		
76	030176	005737	003112		TST	DESSGN	;CHECK WHICH SEEK DIRECTION
77	030202	001403			BEQ	7\$	;REVERSE - SKIP
78	030204	060510			ADD	R5,(R0)	;ADD TO FORWARD TOTAL
79	030206	005511			ADC	(R1)	;ADD IN OVERFLOW
80	030210	000402			BR	8\$	;SKIP
81							
82	030212	060513		7\$:	ADD	R5,(R3)	;ADD TO REVERSE TOTAL
83	030214	005514			ADC	(R4)	;ADD IN OVERFLOW
84	030216	005337	003236	8\$:	DEC	COUNT	;DEC SEEK COUNT
85	030222	001403			BEQ	9\$	;SKIP IF 0
86	030224	004737	021570		JSR	PC,ONSWAP	;ELSE SWAP OLD AND NEW CYL
87	030230	000662			BR	4\$	;REDO SEEK LOOP
88							
89	030232	162710	000470	9\$:	SUB	#312.,(R0)	;SUB CONSTANT FOR READ HEADER TIME
90	030236	162713	000470		SUB	#312.,(R3)	
91	030242	012705	000006		MOV	#6,R5	;SET SHIFT COUNT TO DIVIDE BY 64
92	030246	000241		10\$:	CLC		;DIVIDE BOTH TOTALS BY 64
93	030250	006011			ROR	(R1)	
94	030252	006010			ROR	(R0)	
95	030254	000241			CLC		
96	030256	006014			ROR	(R4)	
97	030260	006013			ROR	(R3)	
98	030262	005305			DEC	R5	
99	030264	001370			BNE	10\$	
100	030266	005237	003234		INC	PASCNT	;BUMP PASS COUNT
101	030272	022737	000001	003234	CMP	#1,PASCNT	;TEST IF PASS 1
102	030300	001051			BNE	13\$	;NO - SKIP
103	030302	012737	000177	003104	MOV	#127.,NEWCYL	;ELSE SET TO POSITION HDS TO 127





161	030632	022737	000004	003234	15:	CMP	#4,PASCNT	:TEST IF PASS 4
162	030640	001041				BNE	17:	:NO - SKIP
163	030642	012737	000252	003104		MOV	#170.,NEWCYL	:ELSE SET UP TO TIME 85 CYL SEEK
164	030650	022737	000001	002300		CMP	#1,T.DRIVE	:RL01?
165	030656	001403				BEQ	16:	:YES
166	030660	012737	000525	003104		MOV	#341.,NEWCYL	:NO - SET FOR RL02
167	030666	004737	020112		16:	JSR	PC,XSEEK	: AT INNER LIMIT
168	030672	031472				20:		
169	030674	012701	005670			MOV	#3000.,R1	:SET WAIT COUNT FOR 300 MS
170	030700	004737	023570			JSR	PC,RDYWAIT	:WAIT FOR READY
171	030704	031472				20:		
172	030706	004737	024202			JSR	PC,VERPOS	:VERIFY POSITION
173	030712	031472				20:		
174	030714	012700	003172			MOV	#HFIN,R0	:SET POINTERS
175	030720	012701	003174			MOV	#HFINU,R1	
176	030724	012703	003202			MOV	#HRIN,R3	
177	030730	012704	003204			MOV	#HRINU,R4	
178	030734	013737	002304	003104		MOV	HLMTW,NEWCYL	:SET NEWCYL TO MAX CYL
179	030742	000434				BR	18:	:DO TIMING LOOP
180								
181	030744	022737	000005	003234	17:	CMP	#5,PASCNT	:TEST IF PASS 5
182	030752	001032				BNE	19:	:NO - SKIP
183	030754	005037	003104			CLR	NEWCYL	:ELSE SET UP TO TIME 256/512 CYL SEEK
184	030760	004737	020112			JSR	PC,XSEEK	: OVER ALL SURFACE
185	030764	031472				20:		
186	030766	012701	005670			MOV	#3000.,R1	:SET WAIT COUNT FOR 300 MS
187	030772	004737	023570			JSR	PC,RDYWAIT	:WAIT FOR DRIVE READY
188	030776	031472				20:		
189	031000	004737	024202			JSR	PC,VERPOS	:VERIFY POSITION
190	031004	031472				20:		
191	031006	012700	003212			MOV	#AFMID,R0	:SET POINTERS
192	031012	012701	003214			MOV	#AFMIDU,R1	
193	031016	012703	003216			MOV	#ARMID,R3	
194	031022	012704	003220			MOV	#ARMIDU,R4	
195	031026	013737	002304	003104		MOV	HLMTW,NEWCYL	:SET NEWCYL
196	031034	000137	027746		18:	JMP	3:	
197								
198	031040				19:			
	031040	012746	007607			MOV	#VALDES,-(SP)	
	031044	012746	007553			MOV	#SKTMES,-(SP)	
	031050	012746	011730			MOV	#FMT2,-(SP)	
	031054	012746	000003			MOV	#3,-(SP)	
	031060	010600				MOV	SP,R0	
	031062	104417				TRAP	C:PNTF	
	031064	062706	000010			ADD	#10,SP	
199	031070	005046				CLR	-(SP)	
	031072	153716	003035			BISB	RLDRV+1,(SP)	
	031076	012746	006621			MOV	#DRVNAM,-(SP)	
	031102	013746	003030			MOV	RLBAS,-(SP)	
	031106	012746	006610			MOV	#BASADD,-(SP)	
	031112	012746	011750			MOV	#FMT5,-(SP)	
	031116	012746	000005			MOV	#5,-(SP)	
	031122	010600				MOV	SP,R0	
	031124	104417				TRAP	C:PNTF	
	031126	062706	000014			ADD	#14,SP	
200	031132	012746	007666			MOV	#LABEXP,-(SP)	
	031136	012746	007660			MOV	#LABOUT,-(SP)	

\*TEST 1

\*\*SEEK TIMING

	031142	012746	007651	MOV	#LABMID,-(SP)
	031146	012746	007643	MOV	#LABIN,-(SP)
	031152	012746	012342	MOV	#FMT18,-(SP)
	031156	012746	000005	MOV	#5,-(SP)
	031162	010600		MOV	SP,RO
	031164	104417		TRAP	C:PNTF
201	031166	062706	000014	ADD	#14,SP
	031172	013746	003222	MOV	EXOCYL,-(SP)
	031176	013746	003152	MOV	OFOUT,-(SP)
	031202	013746	003146	MOV	OFMID,-(SP)
	031206	013746	003142	MOV	OFIN,-(SP)
	031212	012746	007677	MOV	#LABOCF,-(SP)
	031216	012746	012374	MOV	#FMT19,-(SP)
	031222	012746	000006	MOV	#6,-(SP)
	031226	010600		MOV	SP,RO
	031230	104417		TRAP	C:PNTF
202	031232	062706	000016	ADD	#16,SP
	031236	013746	003222	MOV	EXOCYL,-(SP)
	031242	013746	003166	MOV	OROUT,-(SP)
	031246	013746	003162	MOV	ORMID,-(SP)
	031252	013746	003156	MOV	ORIN,-(SP)
	031256	012746	007711	MOV	#LABOCR,-(SP)
	031262	012746	012374	MOV	#FMT19,-(SP)
	031266	012746	000006	MOV	#6,-(SP)
	031272	010600		MOV	SP,RO
	031274	104417		TRAP	C:PNTF
203	031276	062706	000016	ADD	#16,SP
	031302	013746	003224	MOV	EXHCYL,-(SP)
	031306	013746	003176	MOV	HFOUT,-(SP)
	031312	013746	003172	MOV	HFIN,-(SP)
	031316	012746	007723	MOV	#LABHCF,-(SP)
	031322	012746	012431	MOV	#FMT20,-(SP)
	031326	012746	000005	MOV	#5,-(SP)
	031332	010600		MOV	SP,RO
	031334	104417		TRAP	C:PNTF
204	031336	062706	000014	ADD	#14,SP
	031342	013746	003224	MOV	EXHCYL,-(SP)
	031346	013746	003206	MOV	HROUT,-(SP)
	031352	013746	003202	MOV	HRIN,-(SP)
	031356	012746	007737	MOV	#LABHCR,-(SP)
	031362	012746	012431	MOV	#FMT20,-(SP)
	031366	012746	000005	MOV	#5,-(SP)
	031372	010600		MOV	SP,RO
	031374	104417		TRAP	C:PNTF
205	031376	062706	000014	ADD	#14,SP
	031402	013746	003226	MOV	EXACYL,-(SP)
	031406	013746	003212	MOV	AFMID,-(SP)
	031412	012746	007753	MOV	#LABACF,-(SP)
	031416	012746	012461	MOV	#FMT21,-(SP)
	031422	012746	000004	MOV	#4,-(SP)
	031426	010600		MOV	SP,RO
	031430	104417		TRAP	C:PNTF
206	031432	062706	000012	ADD	#12,SP
	031436	013746	003226	MOV	EXACYL,-(SP)
	031442	013746	003216	MOV	ARMID,-(SP)
	031446	012746	007767	MOV	#LABACR,-(SP)
	031452	012746	012461	MOV	#FMT21,-(SP)

C9

	031456	012746	000004		MOV	#4, -(SP)
	031462	010600			MOV	SP, RO
	031464	104417			TRAP	C\$ONTF
	031466	062706	000012		ADD	#12, SP
207	031472					
208	031472			20\$:		
	031472	104401		L10023:	TRAP	C\$ETST

D9

1				.SBTTL	*TEST 2		**BASIC READ DATA (BAD SECTOR FILE)
2							
3	031474			T2::			
6	031474	012737	000002	003240	MOV	#2,TSTNM	;SAVE TEST NUMBER
7	031502	004737	017146		JSR	PC,TSTINT	;INITIALIZE TEST
8	031506	004737	017164		JSR	PC,GSTATR	;CLEAR DRIVE
9	031512	031524			1\$		;ERROR RETURN ADDRESS
10	031514	005037	003500		CLR	BSFVAL	;ENABLE BAD SEC FILE READ
11	031520	004737	021630		JSR	PC,RDBSF	;READ BAD SECTOR FILE
12	031524						
	031524			1\$:			
	031524	104401		L10024:	TRAP	C\$ETST	

```

1
2
3 .SBTTL *TEST 3 **WRITE/READ DATA (PART 1)
4
5
6 031526 012737 000003 003240 T3:: MOV #3,TSTNM ;SAVE TEST NUMBER
7 031526 012737 007402 003014 MOV #P2T14E,ERHEAD ;SET ERROR HEADER
8 031534 004737 017146 JSR PC,TSTINT ;INITIALIZE TEST
9 031542 004737 017146 JSR PC,GSTATR ;CLEAR DRIVE
10 031546 004737 017164 T3065$
11 031552 031746 JSR PC,CKBSVD ;GO CHECK IF BAD SECTOR FILES VALID
12 031554 004737 021614 JSR PC,CHOSHD ;GO CHOSE HEAD
13 031560 004737 021504 CLR DESSEC ; SECTOR 0
14 031564 005037 003116 CLR NEWCYL ; CYLINDER 0
15 031570 005037 003104 CLR T310$ ;CLEAR PATTERN SELECT
16 031574 005037 031640 T306$: JSR PC,XSEEK ;POSITION HEADS
17 031600 004737 020112 T3065$
18 031604 031746 MOV #3000.,R1 ;SET WAIT COUNT FOR 300 MS
19 031606 012701 005670 JSR PC,RDYWAIT ;WAIT FOR READY
20 031612 004737 023570 T3065$
21 031616 031746 JSR PC,VERPOS ;VERIFY POSITION
22 031620 004737 024202 T3065$
23 031624 031746 CLR T310$ ;CLEAR PATTERN SELECTOR
24 031626 005037 031640
25
26
27 031632 T307$:
031632 T3.1:
031632 104402 TRAP C$BSUB
28 031634 004537 024672 JSR R5,DATGEN ;GENERATE DATA
29 031640 000000 T310$: .WORD 0 ;PATTERN SELECT WORD
30 031642 004737 025322 JSR PC,XWRITE ;DO WRITE DATA
31 031646 031664 1$
32 031650 004737 025362 JSR PC,XREAD ;DO READ DATA
33 031654 031664 1$
34 031656 004737 025032 JSR PC,DATCOM ;COMPARE DATA
35 031662 031664 1$
36 031664 012737 000002 003020 1$: MOV #2,ERRSWI ;INIT ERROR SWITCH
37 031672 L10026:
031672 104403 TRAP C$ESUB
38
39 031674 104410 TRAP C$ESCAPE
031676 000050 .WORD L10025-
40 031700 022737 000010 031640 CMP #8.,T310$ ;WAS DATA PAT 8 USED?
41 031706 001403 BEQ 2$ ;YES - SKIP
42 031710 005237 031640 INC T310$ ;ELSE BUMP TO NEXT PATTERN
43 031714 000746 BR T307$ ;DO TEST WITH NEW PATTERN
44
45 031716 004737 021530 2$: JSR PC,SWAPHD ;GO SWAP TO HEAD 1 OR END TEST
46 031722 031746 T3065$ ;ABORT RETURN
47 031724 005037 031640 CLR T310$ ;SET PATTERN SELECT TO 0
48 031730 004737 026124 3$: JSR PC,BSCHK ;CHECK IF SECTOR BAD
49 031734 031740 4$ ;YES RETURN - SKIP TO 4$
50 031736 000720 BR T306$ ;NO RETURN - DO TEST THIS SECTOR
51
52 031740 005237 003104 4$: INC NEWCYL ;BUMP TO NEXT CYLINDER
53 031744 000771 BR 3$ ;CHECK IF THIS ONE BAD
54
55 031746 T3065$:
031746 L10025:
031746 104401 TRAP C$ETST

```

```

1      .SBTTL *TEST 4          **ROTATIONAL TIMING
2
3      031750
6      031750 012737 000004 003240 T4::
7      031756 012737 007423 003014     MOV #4,TSTNM ;SAVE TEST NUMBER
8                                     MOV #P2T15E,ERHEAD ;SET ERROR HEADER
9
10     ;CHECK FOR PRESENCE OF A P-CLOCK...BYPASS TEST IF NOT AVAILABLE
11     031764 005737 003474          TST CLKFLG ;P-CLOCK?
12     031770 001014                  BNE 1$ ;BRANCH TO PERFORM TEST IF P-CLOCK IS PRESENT
13     031772 013746 003240          MOV TSTNM, -(SP)
14     031776 012746 010364          MOV #NOTST, -(SP)
15     032002 012746 000002          MOV #2, -(SP)
16     032006 010600                  MOV SP, R0
17     032010 104417                  TRAP C$PNTF
18     032012 062706 000006          ADD #6, SP
19
20     032016 104432                  TRAP C$EXIT ;/P-CLOCK IS NOT AVAILABLE"
21     032020 000542                  .WORD L10027-.
22
23     1$: CLR R3 ;CLEAR FOR TIMING STORAGE
24     032022 005003                  CLR R4
25     032024 005004                  JSR PC, TSTINT ;INITIALIZE TEST
26     032026 004737 017146          JSR PC, GSTATR ;CLEAR DRIVE
27     032032 004737 017164          8$
28     032036 032554                  JSR R5, DATGEN ;GENERATE DATA
29     032040 004537 024672          0 ;PATTERN 0
30     032044 000000                  CLR DESSEC ;CLEAR TO SECTOR 0
31     032046 005037 003116          JSR PC, CHOSHD ;GO SELECT HEAD
32     032052 004737 021504          MOV LOLIMW, NEWCYL ;SET FOR CYLINDER
33     032056 013737 014502 003104  JSR PC, XSEEK ;DO SEEK
34     032064 004737 020112          8$
35     032070 032554                  MOV #3000, R1 ;SET WAIT FOR 300 MS
36     032072 012701 005670          JSR PC, RDYWAIT ;WAIT FOR READY
37     032076 004737 023570          8$
38     032102 032554                  JSR PC, VERPOS ;VERIFY POSITION
39     032104 004737 024202          8$
40     032110 032554                  MOV #64, R1 ;SET LOOP COUNTER
41     032112 012701 000100          2$: MOV #L.MP, R5 ;SET A POINTER
42     032116 012705 003044          JSR PC, XWRIT ;DO FIRST WRITE
43     032122 004737 025312          8$
44     032126 032554                  MOV (R5), RLMP(R2) ;LOAD RL REGISTERS
45     032130 011562 000006          MOV -(R5), RLDA(R2)
46     032134 014562 000004          MOV -(R5), RLBA(R2)
47     032140 014562 000002          MOV -(R5), RLCS(R2)
48     032144 014562 000000
49     032162 005737 003010          TST DONE ;TEST IF INTERRUPT
50     032166 001011                  BNE 3$ ;YES - SKIP
51     032170 004737 017010          JSR PC, WAITIN ;ELSE WAIT FOR TIMEOUT
52     032174 012603                  MOV (SP)+, R3 ;GET MESSAGE POINTER
53     032176 104456                  TRAP C$ERHRD
54     032200 002735                  .WORD 1501
55     032202 000000                  .WORD 0
56     032204 012646                  .WORD ERR1
57     032206 000137 032554          JMP 8$
58
59     3$: TST T, CS ;TEST IF ANY ERRORS
60     032212 005737 003046          BPL 4$ ;NO - SKIP
61     032216 100006
62     032220 104456                  TRAP C$ERHRD
    
```

```

032222 002736          .WORD 1502
032224 000000          .WORD 0
032226 013150          .WORD ERR6
52 032230 000137 032554 JMP 8$
53
54 032234 012705 003044 4$: MOV #L.MP,R5 ;SET POINTER TO RL LOAD REGS
55 032240 005037 003010 CLR DONE ;CLEAR INTERRUPT INDICATOR
56 032244 005037 172542 CLR @#CLKCSB ;CLEAR CLOCK COUNT SET BUFFER
032250 005037 172544 CLR @#CLKCTR ;CLEAR CLOCK COUNTER
032254 012737 000023 172540 MOV #23,@#CLKCSR ;INITIALIZE CLOCK FOR COUNT-UP MODE,
;OF TIME INTERVAL
57 032262 011562 000006 MOV (R5),RLMP(R2) ;LOAD RL REGISTERS FOR 2ND WRITE
58 032266 014562 000004 MOV -(R5),RLDA(R2)
59 032272 014562 000002 MOV -(R5),RLBA(R2)
60 032276 014562 000000 MOV -(R5),RLCS(R2)
61 032276 014562 000000 MOV #3000,XDELAY ;SAVE ARGUMENT
62 032302 012737 005670 003456 JSR PC,TIME ;CALL TIMING ROUTINE
032310 004737 016210 MOV @#CLKCTR,R0 ;STORE CLOCK COUNTER CONTENTS
63 032314 013700 172544 CLR @#CLKCSR ;EVENT FINISHED, STOP CLOCK
032320 005037 172540 TST DONE ;TEST IF INTERRUPT OCCURRED
64 032324 005737 003010 BNE 5$ ;YES - SKIP
65 032330 001010 JSR PC,WAITIN ;GO WAIT FOR INTERRUPT
66 032332 004737 017010 MOV (SP)+,R3 ;GET MESSAGE POINTER
67 032336 012603 TRAP C$ERHRD
68 032340 104456 .WORD 1503
032342 002737 .WORD 0
032344 000000 .WORD ERR1
032346 012646 BR 8$
69 032350 000501
70
71 032352 005737 003046 5$: TST T.CS ;TEST IF ANY ERROR
72 032356 100005 BPL 6$ ;NO - SKIP
73 032360 104456 TRAP C$ERHRD
032362 002740 .WORD 1504
032364 000000 .WORD 0
032366 013150 .WORD ERR6
74 032370 000471 BR 8$
75
76 032372 060003 6$: ADD R0,R3 ;ADD IN TIME USED
77 032374 005504 ADC R4 ;DOUBLE PRECISION
78 032376 005301 DEC R1 ;DEC LOOP COUNTER
79 032400 001246 BNE 2$ ;LOOP UNTIL 0
80 032402 012701 000006 MOV #6,R1 ;SET DIVIDE COUNT
81 032406 000241 7$: CLC ;CLEAR CARRY FOR DIVIDE
82 032410 006004 ROR R4 ;DIVIDE SUM BY 100(8)
83 032412 006003 ROR R3
84 032414 005301 DEC R1
85 032416 001373 BNE 7$ ;DEC DIVIDE COUNT
86 032420 012746 007607 MOV #VALDES,-(SP) ;LOOP UNTIL DONE
032424 012746 007565 MOV #SRTMES,-(SP)
032430 012746 011730 MOV #FMT2,-(SP)
032434 012746 000003 MOV #3,-(SP)
032440 010600 MOV SP,R0
032442 104417 TRAP C$PNTF
032444 062706 000010 ADD #10,SP
87 032450 005046 CLR -(SP)
032452 153716 003035 BISB RLDRV+1,(SP)
032456 012746 006621 MOV #DRVNAM,-(SP)

```

H9

```

032462 013746 003030      MOV      RLBAS, -(SP)
032466 012746 006610      MOV      #BASADD, -(SP)
032472 012746 011750      MOV      #FMT5, -(SP)
032476 012746 000005      MOV      #5, -(SP)
032502 010600      MOV      SP, R0
032504 104417      TRAP     C$PNTF
88 032506 062706 000014      ADD      #14, SP
032512 013746 003230      MOV      EXROT, -(SP)
032516 012746 007633      MOV      #MAPROX, -(SP)
032522 012746 011507      MOV      #RESE4, -(SP)
032526 010346      MOV      R3, -(SP)
032530 012746 011503      MOV      #RESE3, -(SP)
032534 012746 012571      MOV      #FMT26, -(SP)
032540 012746 000006      MOV      #6, -(SP)
032544 010600      MOV      SP, R0
032546 104417      TRAP     C$PNTF
89 032550 062706 000016      ADD      #16, SP
90 032554 012737 000002 003020 8$:      MOV      #2, ERRSWI      ;INITIALIZE ERROR SWITCH
032562 104401      TRAP     C$ETST
L10027:

```



```

1
2
3
4
5
6 032564 012737 000005 003240 T5:: MOV #5,TSTNM ;SAVE TEST NUMBER
7 032572 012737 007446 003014 MOV #P2T16E,ERHEAD ;SET ERROR HEADER
8 032600 004737 017146 JSR PC,TSTINT ;INITIALIZE TEST
9 032604 004737 017164 JSR PC,GSTATR ;CLEAR DRIVE
10 032610 033700 T3165$
12 032612 004737 021614 JSR PC,CKBSVD ;GO CHECK IF BAD SECTOR FILES VALID
14 032616 005037 003234 CLR PASCNT ;CLEAR PASS TO 0
15 032622 012705 177776 MOV #-2,R5 ;SET
16 032626 005737 003444 TST PASNUM ;TEST IF FIRST PASS (QUICK VERIFY)
17 032632 001006 BNE 1$ ;NO - SKIP
18 032634 032737 000001 014500 BIT #ALLCYL,MISWIW ;TEST IF USE ALL CYLINDERS
19 032642 001002 BNE 1$ ;YES - SKIP
20 032644 012705 177760 MOV #-16.,R5 ;ELSE SET PEOPLE TO NEG 8
21 032650 1$:
22 032650 012701 002506 MOV #T33TBL,R1 ;GET ADDRESS OF WORK TABLE
23 032654 012737 000010 002302 MOV #10,JUNK ;SET CLEAR COUNT
24 032662 013721 014502 2$: MOV LOLIMW,(R1)+ ;CLEAR LOCATIONS TO LO LIMIT
25 032666 005337 002302 DEC JUNK ;DEC COUNT
26 032672 001373 BNE 2$ ;LOOP UNTIL 0
27 032674 013737 014504 002512 MOV HILIMW,T33TBL+4 ;INSERT HILIMIT
28 032702 013737 014504 002514 MOV HILIMW,T33TBL+6 ;INTO APPROPRIATE LOCATIONS
29 032710 013737 014504 002516 MOV HILIMW,T33TBL+10
30
31 032716 062705 000002 T3100$: ADD #2,R5 ;BUMP R5 BY 2
32 032722 032737 000001 014500 BIT #ALLCYL,MISWIW ;TEST IF USE ALL CYLINDERS
33 032730 001031 BNE 5$ ;YES - SKIP
34 032732 005737 003444 TST PASNUM ;TEST IF FIRST PASS (QUICK VERIFY)
35 032736 001002 BNE 1$ ;NO - SKIP
36 032740 062705 000016 ADD #16,R5 ;ELSE BUMP CYLINDER POINTER BY 7
37 032744 022737 000001 002300 1$: CMP #1,T.DRIVE ;RLO1 OR RLO2? THAT IS THE Q
38 032752 001404 BEQ 2$ ;ANS IS RLO1
39 032754 020527 000244 CMP R5,#164.
40 032760 103013 BHIS 4$
41 032762 000403 BR 3$ ;TEST PAST TABLE-YES EXIT
42
43 032764 020527 000122 2$: CMP R5,#82.
44 032770 103007 BHIS 4$ ;TES PAST THE TABLE
45 032772 016537 002606 002302 3$: MOV CYLTBL(R5),JUNK ;GET NEXT TABLE ENTRY
46 033000 043737 002306 002302 BIC CLRBYT,JUNK ;CLEAR UPPER BYTE
47 033006 001007 BNE 6$
48 033010 000137 033700 4$: JMP T3165$ ;EXIT TEST
49
50 033014 023705 014504 5$: CMP HILIMW,R5 ;TEST IF ALL CYLINDERS USED
51 033020 001773 BEQ 4$ ;YES - EXIT TEST
52 033022 010537 002302 MOV R5,JUNK ;USE R5 AS NEXT CYLINDER
53 033026 023737 002302 014502 6$: CMP JUNK,LOLIMW ;CHECK IF LOWER THAN LOLIMIT
54 033034 103730 BLO T3100$ ;YES - SKIP
55 033036 023737 002302 014504 CMP JUNK,HILIMW ;CHECK IF HIGHER THAN HILIMIT
56 033044 101324 BHI T3100$ ;YES - SKIP
57 033046 012703 002546 MOV #TBT,R3
58 033052 013713 002302 MOV JUNK,(R3)
59 033056 013763 002302 000002 MOV JUNK,2(R3)
60 033064 013763 002302 000004 MOV JUNK,4(R3)
61 033072 013763 002302 000006 MOV JUNK,6(R3)

```

```

62 033100 013763 002302 000010      MOV      JUNK,10(R3)
63 033106 013763 002302 000012      MOV      JUNK,12(R3)
64 033114 010337 003026                MOV      R3,TBLSTR      ;STORE TABLE ADDRESS
65 033120 004737 021504                JSR      PC,CHOSHD      ;GO CHOSE HEAD
66
67 033124                T3101$:
033124                T5.1:
033124 104402                TRAP     C$BSUB
68 033126 042737 003760 003006      BIC      #MQUALS,OPFLAG ;CLEAR ALL MESSAGE QUALIFIERS
69 033134 005737 003234                TST      PASCNT        ;TEST IF PASS 0
70 033140 001414                BEQ      2$            ;YES - SKIP
71 033142 023727 003234 000003      CMP      PASCNT,#3     ;TEST IF PASS 3
72 033150 001404                BEQ      1$            ;YES - SKIP
73 033152 002407                BLT      2$            ;CHECK IF LESS THAN 3, IF YES CLEAR TO 0
74 033154 012737 000003 003234      MOV      #3,PASCNT     ;ELSE SET TO 3
75 033162 052737 000020 003006 1$:      BIS      #INOUTS,OPFLAG ;SET MESSAGE QUAL
76 033170 000405                BR       3$            ;SKIP
77
78 033172 005037 003234                CLR      PASCNT        ;SET PASS COUNT TO 0
79 033176 052737 000040 003006      BIS      #OUTINS,OPFLAG ;SET MESSAGE QUAL
80 033204 012737 000003 003024 3$:      MOV      #3,WRTSWI     ;SET READ AND WRITE SWITCH
81 033212 013703 003026                MOV      TBLSTR,R3     ;GET STORED TABLE ADDRESS
82 033216 012701 002506                MOV      #T33TBL,R1
83 033222 012703 002546                MOV      #TBT,R3
84 033226 005037 003116                CLR      DESSEC        ;CLEAR TO SECTOR 0
85 033232 012137 003104                MOV      (R1)+,NEWCYL  ;GET NEXT TABLE ENTRY
86 033236 004737 020112                JSR      PC,X$EEK      ;DO SEEK
87 033242 033606                15$
88 033244 012701 005670                MOV      #3000.,R1     ;SET WAIT COUNT FOR 300 MS
89 033250 004737 023570                JSR      PC,RDYWAIT    ;WAIT FOR READY
90 033254 033606                15$
91 033256 012337 003104                MOV      (R3)+,NEWCYL  ;GET NEXT TABLE ENTRY
92 033262 004737 020112                JSR      PC,X$EEK      ;DO SEEK
93 033266 033606                15$
94 033270 012701 005670                MOV      #3000.,R1     ;SET WAIT COUNT FOR 300 MS
95 033274 004737 023570                JSR      PC,RDYWAIT    ;WAIT FOR READY
96 033300 033606                15$
97 033302 004737 024202                JSR      PC,VERPOS     ;VERIFY POSITION
98 033306 033606                15$
99 033310 004737 026124                JSR      PC,BSCHK      ;CHECK FOR BAD SECTOR
100 033314 033446                9$
101 033316 013737 003116 033336      MOV      DESSEC,6$     ;"YES" RETURN
102 033324 042737 177770 033336      BIC      #177770,6$    ;SET DATA PATTERN = TO SECTOR NUMBER
103 033332 004537 024672                JSR      R5,DATGEN     ;CLEAR ALL BUT LSD
104 033336 000000                .WORD    0             ;GO GENERATE DATA
105 033340 032737 000001 003024 6$:      BIT      #BIT0,WRTSWI  ;TEST IF WRITE THIS PASS
106 033346 001425                BEQ      7$            ;NO - SKIP
107 033350 004737 025322                JSR      PC,XWRITE     ;DO WRITE
108 033354 033606                15$
109 033356 005237 003116                INC      DESSEC        ;INC SECTOR
110 033362 022737 000050 003116      CMP      #40.,DESSEC   ;TEST IF ALL SECTORS USED
111 033370 001347                BNE      5$            ;NO - SKIP
112 033372 042737 000060 003006      BIC      #INOUTS!OUTINS,OPFLAG ;CLEAR QUALIFIERS
113 033400 042737 000001 003024      BIC      #BIT0,WRTSWI  ;CLEAR WRITE REQUIRED SWITCH
114 033406 052737 000100 003006      BIS      #FOLWRT,OPFLAG ;SET FOLLOWING WRITE QUALIFIER
115 033414 005037 003116                CLR      DESSEC        ;CLEAR TO SECTOR 0
116 033420 000733                BR       5$            ;SKIP

```

117										
118	033422	032737	000002	003024	7\$:	BIT	#BIT1,WRTSWI		;TEST IF READ THIS PASS	
119	033430	001414				BEQ	10\$		;NO - SKIP	
120	033432	004737	025362		8\$:	JSR	PC,XREAD		;ELSE DO READ	
121	033436	033606				15\$				
122	033440	001737	025032			JSR	PC,DATCOM		;COMPARE DATA	
123	033444	033606				15\$				
124	033446	005237	003116		9\$:	INC	DESSEC		;BUMP SECTOR	
125	033452	022737	000050	003116		CMP	#40.,DESSEC		;TEST IF ALL SECTORS USED	
126	033460	001313				BNE	5\$		;NO - LOOP	
127	033462	005037	003116		10\$:	CLR	DESSEC		;CLEAR DESIRED SECTOR	
128	033466	005037	003024			CLR	WRTSWI		;CLEAR WRITE/READ SWITCH	
129	033472	005237	003234			INC	PASCNT		;BUMP PASS COUNT	
130	033476	042737	003760	003006		BIC	#MQUALS,OPFLAG		;CLEAR ALL QUALIFIERS	
131	033504	023727	003234	000003		CMP	PASCNT,#3		;TEST IS PASS 3	
132	033512	001435				BEQ	15\$		;YES - SKIP	
133	033514	023727	003234	000006		CMP	PASCNT,#6		;TEST IF PASS 6	
134	033522	001431				BEQ	15\$		;YES - SKIP	
135	033524	012737	000002	003024		MOV	#BIT1,WRTSWI		;SET READ REQUIRED BIT	
136	033532	023727	003234	000001		CMP	PASCNT,#1		;TEST IF PASS 1	
137	033540	001415				BEQ	13\$		;YES - SKIP	
138	033542	023727	003234	000005		CMP	PASCNT,#5		;TEST IF PASS 4	
139	033550	001411				BEQ	13\$		;YES - SKIP	
140	033552	000404				BR	12\$		;SKIP	
141										
142	033554	052737	002000	003006	11\$:	BIS	#FWDSCO,OPFLAG		;SET FWD QUALIFIER	
143	033562	000407				BR	14\$		;GO DO NEXT PASS	
144										
145	033564	052737	000020	003006	12\$:	BIS	#INOUTS,OPFLAG		;SET QUALIFIER	
146	033572	000403				BR	14\$		;SKIP	
147										
148	033574	052737	000040	003006	13\$:	BIS	#OUTINS,OPFLAG		;SET MESSAGE QUALIFIER	
149	033602	000137	033226		14\$:	JMP	4\$		;GO DO NEXT PASS	
150										
151	033606	012737	000002	003020	15\$:	MOV	#2,ERRSWI		;INIT ERROR SWITCH	
152	033614				L10031:					
	033614	104403				TRAP	C\$ESUB			
153										
154	033616	104410				TRAP	C\$ESCAPE			
	033620	000060				.WORD	L10030-			
155	033622	012737	000003	003024		MOV	#3,WRTSWI		;SET FOR READ AND WRITE REQ.	
156	033630	023727	003234	000003		CMP	PASCNT,#3		;TEST IF PASS 3	
157	033636	001004				BNE	16\$		;NO - SKIP	
158	033640	012737	002514	003026		MOV	#T33TBL+6,TBLSTR		;STORE MID POINT IN TABLE	
159	033646	000410				BR	17\$		;GO START PASS 4	
160										
161	033650	005037	003234		16\$:	CLR	PASCNT		;CLEAR TO PASS 0	
162	033654	004737	021530			JSR	PC,SWAPHD		;GO SWAP TO HEAD 1 OR END TEST	
163	033660	032716				T3100\$			;ABORT RETURN	
164	033662	012737	002506	003026		MOV	#T33TBL,TBLSTR		;STORE START OF TABLE	
165	033670	062703	000006		17\$:	ADD	#6,R3			
166	033674	000137	033124			JMP	T3101\$			
167										
168	033700				T3165\$:					
	033700				L10030:					
	033700	104401				TRAP	C\$ETST			

```

1          .SBTTL *TEST 6          **WRITE LOCK ERROR AND DATA PROTECTION
2
3 033702
6 033702 012737 000006 003240 T6:: MOV #6,TSTNM ;SAVE TEST NUMBER
7 033710 005737 003444 TST PASNUM ;TEST IF FIRST PASS
8 033714 001003 BNE 1$ ;NO - SKIP
9 033716 005737 014500 TST MISWIW ;TEST IF RUN MANUAL INTERVENTION
10 033722 100402 BMI 2$ ;YES - SKIP
11 033724 000137 034724 1$: JMP T3265$ ;EXIT TST
12
13 033730 2$:
033730 T6.1:
033730 104402 TRAP C$BSUB
14 033732 012737 007467 003014 MOV #P2T17E,ERHEAD ;SET ERROR HEADER
15 033740 004737 017146 JSR PC,TSTINT ;INITIALIZE TEST
16 033744 004737 017164 JSR PC,GSTATR ;CLEAR DRIVE
17 033750 034572 11$
18 033752 005037 003114 CLR DESHD ;SET TO HEAD 0
19 033756 005037 003116 CLR DESSEC ;SET TO SECTOR 0
20 033762 005037 003104 CLR NEWCYL ;CLEAR TO CYLINDER 0
21 033766 004737 020112 JSR PC,XSEEK ;DO SEEK
22 033772 034572 11$
23 033774 012701 013560 MOV #6000,R1 ;INITIALIZE WAIT COUNT
24 034000 004737 023570 JSR PC,RDYWAIT ;WAIT FOR READY
25 034004 034572 11$
26 034006 004737 024202 JSR PC,VERPOS ;VERIFY POSITION
27 034012 034572 11$
28 034014 032737 020000 003054 BIT #WLSTAT,T.MP ;TEST IF WRITE LOCK SET
29 034022 001116 BNE 4$ ;YES - SKIP
30 034024 004537 024672 JSR R5,DATGEN ;GENERATE DATA
31 034030 000007 7 ;PATTERN 7
32 034032 004737 025322 JSR PC,XWRITE ;WRITE DATA
33 034036 034572 11$
34 034040 004737 025362 JSR PC,XREAD ;READ DATA
35 034044 034572 11$
36 034046 004737 025032 JSR PC,DATCOM ;CHECK DATA
37 034052 034572 11$
38 034054 005046 CLR -(SP)
034056 153716 003035 BISB RLDV+1,(SP)
034062 012746 006621 MOV #DRVNAM,-(SP)
034066 013746 003030 MOV RLBAS,-(SP)
034072 012746 006610 MOV #BASADD,-(SP)
034076 012746 010056 MOV #OPR1A,-(SP)
034102 012746 010105 MOV #OPR004,-(SP)
034106 012746 011631 MOV #FMTOP1,-(SP)
034112 012746 000007 MOV #7,-(SP)
034116 010600 MOV SP,R0
034120 104417 TRAP C$PNTF
034122 062706 000020 ADD #20,SP
39 034126 012701 000024 MOV #20.,R1 ;INITIALIZE WAIT COUNT
40 034132 3$:
41 034144 004737 017164 JSR PC,GSTATR ;GET STATUS
42 034150 034572 11$
43 034152 032737 020000 003054 BIT #WLSTAT,T.MP ;CHECK IF WRITE LOCK SET
44 034160 001037 BNE 4$ ;YES - SKIP
45 034162 012746 011477 MOV #BELL,-(SP)
034166 012746 011626 MOV #FMTXT,-(SP)

```

```

034172 012746 000002      MOV      #2,-(SP)
034176 010600      MOV      SP,R0
034200 104417      TRAP     C$PNTF
034202 062706 000006      ADD      #6,SP
46 034206 005301      DEC      R1          ;DEC COUNT
47 034210 001350      BNE      3$          ;SKIP IF NOT 0
48 034212 005046      CLR      -(SP)
034214 153716 003035      BISB    RLDRV+1,(SP)
034220 012746 010056      MOV      #OPR1A,-(SP)
034224 012746 010151      MOV      #BYP5NM,-(SP)
034230 012746 007467      MOV      #P2T17E,-(SP)
034234 012746 012540      MOV      #FMT23,-(SP)
034240 012746 000005      MOV      #5,-(SP)
034244 010600      MOV      SP,R0
034246 104417      TRAP     C$PNTF
034250 062706 000014      ADD      #14,SP
49 034254 104432      TRAP     C$EXIT
034256 000446      .WORD   L10032-.

50
51 034260 004537 024672      4$:     JSR      R5,DATGEN      ;GENERATE DATA
52 034264 000001      1      ;PATTERN 1
53 034266 012705 003036      MOV      #L_CS,R5      ;GET ADDRESS OF L REGS
54 034272 012715 000112      MOV      #WTDATA,(R5)  ;LOAD WRITE COMMAND
55 034276 053715 003034      BIS      RLDRV,(R5)    ;INSERT DRIVE NUMBER
56 034302 042725 002000      BIC      #BIT10,(R5)+  ;CLEAR FOR DRIVE 4 - 7 SPEC'D
57 034306 012725 005072      MOV      #OBUFF,(R5)+ ;LOAD BUS ADDRESS
58 034312 005025      CLR      (R5)+        ;CYL 0, HD 0, SECTOR 0
59 034314 012725 177600      MOV      #177600,(R5)+ ;128 WORDS
60 034320 012701 000454      MOV      #300.,R1     ;SET WAIT COUNT FOR 30 MS
61 034324 005037 003010      CLR      DONE        ;CLEAR INTERRUPT FLAG
62 034330 014562 000006      MOV      -(R5),RLMP(R2);LOAD RL REGS
63 034334 014562 000004      MOV      -(R5),RLDA(R2)
64 034340 014562 000002      MOV      -(R5),RLBA(R2)
65 034344 014562 000000      MOV      -(R5),RLCS(R2)
66 034350
67 034362 005737 003010      5$:     TST      DONE        ;CHECK IF INTERRUPT
68 034366 001013      BNE      6$          ;YES - SKIP
69 034370 005301      DEC      R1          ;DEC WAIT COUNT
70 034372 001366      BNE      5$          ;LOOP IF NOT 0
71 034374 004737 017010      JSR      PC,WAITIN    ;WAIT FOR INTERRUPT
72 034400 012603      MOV      (SP)+,R3     ;GET RESULT MESSAGE
73 034402 104456      TRAP     C$ERHRD
034404 003245      .WORD   1701
034406 000000      .WORD   0
034410 012646      .WORD   ERR1
74 034412 104432      TRAP     C$EXIT
034414 000164      .WORD   L10033-.
75 034416 004737 017214      6$:     JSR      PC,GSTAT      ;GET STATUS
76 034422 034572      11$
77 034424 032737 040000 003046      BIT      #DRVERR,T.CS ;TEST IF ANY ERROR SET
78 034432 001006      BNE      7$          ;YES - SKIP
79 034434 012703 011024      MOV      #MDRERR,R3  ;SET RESULT MESSAGE POINTER
80 034440 104456      TRAP     C$ERHRD
034442 003246      .WORD   1702
034444 000000      .WORD   0
034446 012762      .WORD   ERR3
81 034450 032737 002000 003054 7$:     BIT      #WGESTAT,T.MP ;TEST IF WGE SET

```

```

82 034456 001006
83 034460 012703 011103
84 034464 104456
   034466 003250
   034470 000000
   034472 012762
85 034474 042737 040000 003046 8$:
86 034502 042737 002000 003054
87 034510 032737 157400 003054
88 034516 001004
89 034520 032737 036000 003046
90 034526 001405
91 034530
   034530 104456
   034532 003247
   034534 000000
   034536 013150
92 034540 000414
93
94 034542 004737 017164
95 034546 034572
96 034550 004537 024672
97 034554 000007
98 034556 004737 025362
99 034562 034572
100 034564 004737 025032
101 034570 034572
102 034572 012737 000002 003020 11$:
103 034600
   034600 104403
104
105 034602 012737 000002 003020 T3204$:
106 034610 005046
   034612 153716 003035
   034616 012746 006621
   034622 013746 003030
   034626 012746 006610
   034632 012746 010056
   034636 012746 010037
   034642 012746 011631
   034646 012746 000007
   034652 010600
   034654 104417
   034656 062706 000020
107 034662 012701 001274
108 034666
109 034700 004737 017164
110 034704 034602
111 034706 032737 020000 003054
112 034714 001403
113 034716 005301
114 034720 001362
115 034722 000727
116
117 034724
   034724
   034724 104401

BNE 8$
MOV #MWGERR,R3
TRAP C$ERHRD
.WORD 1704
.WORD 0
.WORD ERR3
BIC #DRVERR,T,CS
BIC #WGSTAT,T,MP
BIT #157400,T,MP
BNE 9$
BIT #36000,T,CS
BEQ 10$

TRAP C$ERHRD
.WORD 1703
.WORD 0
.WORD ERR6
BR 11$

JSR PC,GSTATR
11$
JSR R5,DATGEN
7
JSR PC,XREAD
11$
JSR PC,DATCOM
11$
MOV #2,ERRSWI
TRAP C$ESUB

MOV #2,ERRSWI
CLR -(SP)
BISB RLDRV+1,(SP)
MOV #DRVNAM,-(SP)
MOV #RLBAS,-(SP)
MOV #BASADD,-(SP)
MOV #OPR1A,-(SP)
MOV #OPR12,-(SP)
MOV #FMTOP1,-(SP)
MOV #7,-(SP)
MOV SP,R0
TRAP C$PNTF
ADD #20,SP
MOV #700.,R1

JSR PC,GSTATR
T3204$
BIT #WLSTAT,T,MP
BEQ T3265$
DEC R1
BNE 1$
BR T3204$

T3265$:
L10032:
TRAP C$ETST

;YES - SKIP
;SET MESSAGE FOR WGE NOT SET

;CLEAR DRIVE ERROR BIT
;CLEAR WGE BIT
;TEST IF ANY OTHER ERRORS
;YES - GO REPORT
;TEST ANY ERRORS IN CS REG
;NO - SKIP

;EXIT TEST

;GET STATUS AND RESET ERROR

;GO GENERATE DATA
;PATTERN 7
;READ DATA

;COMPARE DATA

;INIT ERROR SWITCH

;INIT ERROR SWITCH

;INITIALIZE WAIT COUNT

;GET STATUS
;CHECK IF WRITE LOCK RESET

;DEC WAIT COUNT
;LOOP IF NOT 0
;ELSE REPEAT MESSAGE
  
```

```

1
2
3
4
5
6 034726 012737 000007 003240
7 034726 012737 007521 003014
8 034734 012737 007521 003014
9 034742 004737 017146
10 034746 004737 017164
11 034752 036146
12 034754 004737 021614
14 034760 005037 003234
15 034764 012705 177776
16 034770 005737 003444
17 034774 001007
18 034776 032737 000001 014500
19 035004 001003
20 035006 012705 177730
21 035012 000402
22
23 035014 012705 177770
24 035020 012701 002506
25 035024 012737 000010 002302
26 035032 013721 014502
27 035036 005337 002302
28 035042 001373
29 035044 004537 024672
30 035050 000011
31 035052 013737 014504 002510
32 035060 013737 014504 002512
33 035066 013737 014504 002516
34 035074 013737 014504 002524
35
36 035102 062705 000002
37 035106 032737 000001 014500
38 035114 001034
39 035116 005737 003444
40 035122 001403
41 035124 062705 000006
42 035130 000402
43
44 035132 062705 000044
45 035136 022737 000001 002300
46 035144 001404
47 035146 020537 000244
48 035152 103013
49 035154 000403
50
51 035156 020527 000122
52 035162 103007
53 035164 016537 002606 002302
54 035172 043737 002306 002302
55 035200 001013
56 035202 000137 033700
57
58 035206 005705
59 035210 001002
60 035212 062705 000002
61 035216 023705 002304

.SBTTL *TEST 7 **ADJACENT CYLINDER INTERFERENCE
T7::
MOV #7,TSTNM ;SAVE TEST NUMBER
MOV #P2T18E,ERHEAD ;SET ERROR HEADER
JSR PC,TSTINT ;INITIALIZE TEST
JSR PC,GSTATR ;CLEAR DRIVE
T3365$
JSR PC,CKBSVD ;GO CHECK IF BAD SECTOR FILES VALID
CLR PASCNT ;CLEAR PASS TO 0
MOV #-2,R5 ;SET R5
TST PASNUM ;TEST IF FIRST PASS (QUICK VERIFY)
BNE 1$ ;NO - SKIP
BIT #ALLCYL,MISWIW ;TEST IF USE ALL CYLINDERS
BNE 1$ ;YES - SKIP
MOV #-40.,R5 ;ELSE SET R5 TO NEG 20
BR 2$ ;SKIP

1$: MOV #-10,R5 ;ELSE SET FOR NEG 4
2$: MOV #T33TBL,R1 ;GET ADDRESS OF WORK TABLE
MOV #10,JUNK ;SET CLEAR COUNT
3$: MOV LOLIMW,(R1)+ ;CLEAR LOCATIONS TO LOLIMIT
DEC JUNK ;DEC COUNT
BNE 3$ ;LOOP UNTIL 0
JSR R5,DATGEN ;GO GENERATE DATA
9. ;PATTERN 9
MOV HILIMW,T33TBL+2 ;INSERT HILIMIT
MOV HILIMW,T33TBL+4 ;INTO APPROPRIATE LOCATIONS
MOV HILIMW,T33TBL+10
MOV HILIMW,T33TBL+16

T3300$: ADD #2,R5
BIT #ALLCYL,MISWIW ;TEST IF USE ALL CYLINDERS
BNE 6$ ;YES - SKIP
TST PASNUM ;TEST IF FIRST PASS (QUICK VERIFY)
BEQ 1$ ;NO - SKIP
ADD #6,R5 ;ELSE BUMP CYLINDER POINTER BY 3
BR 2$ ;SKIP

1$: ADD #36.,R5 ;BUMP TO NEXT ENTRY
2$: CMP #1.,T.DRIVE
BEQ 3$
CMP R5,164.
BHIS 5$
BR 4$

3$: CMP R5,#82.
BHIS 5$
4$: MOV CYLTBL(R5),JUNK
BIC CLRBYT,JUNK
BNE 8$
5$: JMP T3165$

6$: TST R5 ;TEST IF R5 0
BNE 7$ ;NO - SKIP
ADD #2,R5
7$: CMP HLMTW,R5 ;TEST IF ALL CYLINDERS USED
  
```

```

62 035222 001767 BEQ 5$ ;YES - EXIT TEST
63 035224 010537 002302 MOV R5,JUNK ;USE R5 AS NEXT CYLINDER
64 035230 023737 002302 014502 8$: CMP JUNK,LOLIMW ;CHECK IF LOWER THAN LOLIMIT
65 035236 103721 BLO T3300$ ;YES - SKIP
66 035240 023737 002302 014504 CMP JUNK,HILIMW ;CHECK IF HIGHER THAN HILIMIT
67 035246 101315 BHI T3300$ ;YES - SKIP
68 035250 012703 002546 MOV #TBT,R3
69 035254 013713 002302 MOV JUNK,(R3)
70 035260 013763 002302 000006 MOV JUNK,6(R3)
71 035266 013763 002302 000010 MOV JUNK,10(R3)
72 035274 013763 002302 000012 MOV JUNK,12(R3)
73 035302 013763 002302 000016 MOV JUNK,16(R3)
74 035310 162737 000001 002302 SUB #1,JUNK
75 035316 013763 002302 000002 MOV JUNK,2(R3)
76 035324 013763 002302 000012 MOV JUNK,12(R3)
77 035332 062737 000002 002302 ADD #2,JUNK
78 035340 013763 002302 000004 MOV JUNK,4(R3)
79 035346 013763 002302 000014 MOV JUNK,14(R3)
80 035354 010337 003026 MOV R3,TBLSTR
81 035360 004737 021504 JSR PC,CHOSHD ;GO CHOSE HEAD
82
83 035364 T3301$:
035364 T7.1:
035364 104402 TRAP C$BSUB
84 035366 042737 003760 003006 BIC #MQUALS,OPFLAG ;CLEAR ALL MESSAGE QUALIFIERS
85 035374 005737 003234 TST PASCNT ;TEST IF PASS 0
86 035400 001414 BEQ 2$ ;YES - SKIP
87 035402 023727 003234 000004 CMP PASCNT,#4 ;TEST IF PASS 4
88 035410 001404 BEQ 1$ ;YES - SKIP
89 035412 002407 BLT 2$ ;CHECK IF LESS THAN 4, IF YES CLEAR TO 0
90 035414 012737 000004 003234 MOV #4,PASCNT ;ELSE SET TO 4
91 035422 052737 000020 003006 1$: BIS #INOJTS,OPFLAG ;SET MESSAGE QUAL
92 035430 000405 BR 3$ ;SKIP
93
94 035432 005037 003234 2$: CLR PASCNT ;SET PASS COUNT TO 0
95 035436 052737 000040 003006 BIS #OUTJNS,OPFLAG ;SET MESSAGE QUAL
96 035444 012737 000003 003024 3$: MOV #3,WRTSWI ;SET READ AND WRITE SWITCH
97 035452 012701 002506 MOV #T33TBL,R1
98 035456 012703 002546 MOV #TBT,R3
99 035462 005037 003116 4$: CLR DESS$C ;CLEAR TO SECTOR 0
100 035466 012137 003104 MOV (R1)+,NEWCYL ;GET NEXT TABLE ENTRY
101 035472 004737 020112 JSR PC,X$EEK ;DO SEEK
102 035476 036054 15$
103 035500 012701 005670 MOV #3000.,R1 ;SET WAIT COUNT FOR 300 MS
104 035504 004737 023570 JSR PC,RDYWAIT ;WAIT FOR READY
105 035510 036054 15$
106 035512 012337 003104 MOV (R3)+,NEWCYL ;GET NEXT TABLE ENTRY
107 035516 004737 020112 JSR PC,X$EEK ;DO SEEK
108 035522 036054 15$
109 035524 012701 005670 MOV #3000.,R1 ;SET WAIT COUNT FOR 300 MS
110 035530 004737 023570 JSR PC,RDYWAIT ;WAIT FOR READY
111 035534 036054 15$
112 035536 004737 024202 JSR PC,VERPOS ;VERIFY POSITION
113 035542 036054 15$
114 035544 004737 026124 5$: JSR PC,BSCHK ;CHECK FOR BAD SECTOR
115 035550 035660 8$ ;"YES" RETURN
116 035552 032737 000001 003024 BIT #BIT0,WRTSWI ;TEST IF WRITE THIS PASS

```



117	035560	001425				BEQ	6\$		:NO - SKIP
118	035562	004737	025322			JSR	PC,XWRITE		:DO WRITE
119	035566	036054				15\$			
120	035570	005237	003116			INC	DESSEC		:INC SECTOR
121	035574	022737	000050	003116		CMP	#40.,DESSEC		:TEST IF ALL SECTORS USED
122	035602	001360				BNE	5\$		:NO - SKIP
123	035604	042737	000060	003006		BIC	#INOUTS,OPFLAG		:CLEAR QUALIFIERS
124	035612	042737	000001	003024		BIC	#BIT0,WRTSWI		:CLEAR WRITE REQUIRED SWITCH
125	035620	052737	000100	003006		BIS	#FOLWRT,OPFLAG		:SET FOLLOWING WRITE QUALIFIER
126	035626	005037	003116			CLR	DESSEC		:CLEAR TO SECTOR 0
127	035632	000744				BR	5\$		:SKIP
128									
129	035634	032737	000002	003024	6\$:	BIT	#BIT1,WRTSWI		:TEST IF READ THIS PASS
130	035642	001414				BEQ	9\$		:NO - SKIP
131	035644	004737	025362		7\$:	JSR	PC,XREAD		:ELSE DO READ
132	035650	036054				15\$			
133	035652	004737	025032			JSR	PC,DATCOM		:COMPARE DATA
134	035656	036054				15\$			
135	035660	005237	003116		8\$:	INC	DESSEC		:BUMP SECTOR
136	035664	022737	000050	003116		CMP	#40.,DESSEC		:TEST IF ALL SECTORS USED
137	035672	001324				BNE	5\$		:NO - LOOP
138	035674	005037	003116		9\$:	CLR	DESSEC		:CLEAR DESIRED SECTOR
139	035700	005037	003024			CLR	WRTSWI		:CLEAR WRITE/READ SWITCH
140	035704	005237	003234			INC	PASCNT		:BUMP PASS COUNT
141	035710	042737	003760	003006		BIC	#MQUALS,OPFLAG		:CLEAR ALL QUALIFIERS
142	035716	023727	003234	000004		CMP	PASCNT,#4		:TEST IS PASS 4
143	035724	001453				BEQ	15\$		:YES - SKIP
144	035726	023727	003234	000010		CMP	PASCNT,#8.		:TEST IF PASS 8.
145	035734	001447				BEQ	15\$		:YES - SKIP
146	035736	023727	003234	000003		CMP	PASCNT,#3		:TEST IF PASS 3
147	035744	001430				BEQ	12\$		:YES - SKIP
148	035746	023727	003234	000007		CMP	PASCNT,#7		:TEST IF PASS 7
149	035754	001430				BEQ	13\$		:YES - SKIP
150	035756	012737	000001	003024		MOV	#BIT0,WRTSWI		:SET WRITE REQUIRED
151	035764	023727	003234	000001		CMP	PASCNT,#1		:TEST IF PASS 1
152	035772	001411				BEQ	11\$		:YES - SKIP
153	035774	023727	003234	000002		CMP	PASCNT,#2		:TEST IF PASS 2
154	036002	001405				BEQ	11\$		:YES - SKIP
155	036004	052737	000040	003006		BIS	#OUTINS,OPFLAG		:SET MESSAGE QUALIFIER
156	036012	000137	035462		10\$:	JMP	4\$		:GO DO NEXT PASS
157									
158	036016	052737	000020	003006	11\$:	BIS	#INOUTS,OPFLAG		:SET MESSAGE QUALIFIER
159	036024	000772				BR	10\$		
160									
161	036026	052737	000200	003006	12\$:	BIS	#REVSKS,OPFLAG		:SET MESSAGE QUALIFIER
162	036034	000403				BR	14\$		
163									
164	036036	052737	000400	003006	13\$:	BIS	#FWDKSKS,OPFLAG		:SET MESSAGE QUALIFIER
165	036044	012737	000002	003024	14\$:	MOV	#BIT1,WRTSWI		:SET READ REQUIRED
166	036052	000757				BR	10\$		
167									
168	036054	012737	000002	003020	15\$:	MOV	#2,ERRSWI		:INIT ERROR SWITCH
169	036062				L10035:	TRAP	C\$ESUB		
170									
171	036064	104410				TRAP	C\$ESCAPE		
	036066	000060				.WORD	L10034-		

E10

172	036070	012737	000003	003024	MOV	#3,WRTSWI	:SET FOR READ AND WRITE REQ.
173	036076	023727	003234	000004	CMP	PASCNT,#4	:TEST IF PASS 4
174	036104	001004			BNE	16\$	:NO - SKIP
175	036106	012737	002516	003026	MOV	#T33TBL+10,TBLSTR	:STORE MID POINT IN TABLE
176	036114	000410			BR	17\$	:GO START PASS 4
177							
178	036116	005037	003234		16\$: CLR	PASCNT	:CLEAR TO PASS 0
179	036122	004737	021530		JSR	PC,SWAPHD	:GO SWAP TO HEAD 1 OR END TEST
180	036126	035102			T3300\$		:ABORT RETURN
181	036130	012737	002506	003026	MOV	#T33TBL,TBLSTR	:STORE START OF TABLE
182							
183	036136	062703	000010		17\$: ADD	#10,R3	
184	036142	000137	035364		JMP	T3301\$	
185							
186	036146				T3365\$:		
	036146				L10034:		
	036146	104401			TRAP	C\$ETST	

\*TEST 8

\*\*OVERWRITE

```

1
2
3 036150
6 036150 012737 000010 003240
7 036156 012737 007543 003014
8 036164 004737 017146
9 036170 004737 017164
10 036174 037346
12 036176 004737 021614
14 036202 005037 003234
15 036206 012705 177776
16 036212 005737 003444
17 036216 001007
18 036220 032737 000001 014500
19 036226 001003
20 036230 012705 177730
21 036234 000402
22
23 036236 012705 177770
24 036242 012701 002506
25 036246 012737 000010 002302
26 036254 013721 014502
27 036260 005337 002302
28 036264 001373
29 036266 013737 014504 002510
30 036274 013737 014504 002514
31 036302 013737 014504 002520
32
33 036310 062705 000002
34 036314 032737 000001 014500
35 036322 001034
36 036324 005737 003444
37 036330 001003
38 036332 062705 000046
39 036336 000402
40
41 036340 062705 000006
42 036344 022737 000001 002300
43 036352 001404
44 036354 020527 000244
45 036360 103013
46 036362 000403
47
48 036364 020527 000122
49 036370 103007
50 036372 016537 002606 002302
51 036400 043737 002306 002302
52 036406 001013
53 036410 000137 037346
54
55 036414 005705
56 036416 001002
57 036420 062705 000002
58 036424 022705 002304
59 036430 001767
60 036432 010537 002302
61 036436 023737 002302 014502

```

.SBTTL \*TEST 8 \*\*OVERWRITE

T8::

```

MOV #10,TSTNM ;SAVE TEST NUMBER
MOV #P2119E,ERHEAD ;SET ERROR HEADER
JSR PC,TSTINT ;INITIALIZE TEST
JSR PC,GSTATR ;CLEAR DRIVE
T3465$
JSR PC,CKBSVD ;GO CHECK IF BAD SECTOR FILES VALID
CLR PASCNT ;CLEAR PASS TO 0
MOV #-2,R5 ;SET R5
TST PASNUM ;TEST IF FIRST PASS (QUICK VERIFY)
BNE 1$ ;NO - SKIP
BIT #ALLCYL,MISWIW ;TEST IF USE ALL CYLINDERS
BNE 1$ ;YES - SKIP
MOV #-40.,R5 ;ELSE SET R5 TO NEG 20
BR 2$ ;SKIP
1$: MOV #-10,R5 ;SET FOR NEXT ENTRY
2$: MOV #T33TBL,R1 ;GET ADDRESS OF WORK TABLE
MOV #10,JUNK ;SET CLEAR COUNT
3$: MOV LOLIMW,(R1)+ ;CLEAR LOCATIONS TO LOLIMIT
DEC JUNK ;DEC COUNT
BNE 3$ ;LOOP UNTIL 0
MOV HILIMW,T33TBL+2 ;INSERT HILIMIT
MOV HILIMW,T33TBL+6 ;INTO APPROPRIATE LOCATIONS
MOV HILIMW,T33TBL+12
T3400$: ADD #2,R5
BIT #ALLCYL,MISWIW ;TEST IF USE ALL CYLINDERS
BNE 6$ ;YES - SKIP
TST PASNUM ;TEST IF FIRST PASS (QUICK VERIFY)
BNE 1$ ;NO - SKIP
ADD #38.,R5 ;ELSE BUMP CYLINDER POINTER BY 19
BR 2$ ;SKIP
1$: ADD #6,R5 ;BUMP CYLINDER POINTER BY 3
2$: CMP #1,T.DRIVE
BEQ 3$
CMP R5,#164.
BHS 5$
BR 4$
3$: CMP R5,#82.
BHS 5$
4$: MOV CYLTBL(R5),JUNK
BIC CLRBYT,JUNK
BNE 8$
5$: JMP T3465$ ;EXIT TEST
6$: TST R5 ;TEST IF R5 0
BNE 7$ ;NO - SKIP
ADD #2,R5
7$: CMP #HMTW,R5 ;TEST IF ALL CYLINDERS USED
BEQ 5$ ;YES - EXIT TEST
MOV R5,JUNK ;USE R5 AS NEXT CYLINDER
8$: CMP JUNK,LOLIMW ;TEST IF PAST LO LIMIT

```

```

62 036444 103721          BLO      T3400$      ;YES - SKIP
63 036446 023737 002302 014504    CMP      JUNK,HILIMW ;TEST IF PAST HILIMIT
64 036454 101315          BHI      T3400$      ;YES - SKIP
65 036456 012703 002546    MOV      #TBT,R3
66 036462 013713 002302    MOV      JUNK,(R3)
67 036466 013763 002302 000002    MOV      JUNK,2(R3)
68 036474 013763 002302 000004    MOV      JUNK,4(R3)
69 036502 013763 002302 000006    MOV      JUNK,6(R3)
70 036510 013763 002302 000010    MOV      JUNK,10(R3)
71 036516 013763 002302 000012    MOV      JUNK,12(R3)
72 036524 010337 003026    MOV      R3,TBLSTR
73 036530 004737 021504    JSR      PC,CHOSHD ;GO CHOSE HEAD
74
75 036534          T3401$:
   036534          T8.1:
   036534 104402          TRAP     C$BSUB
76 036536 042737 003760 003006    BIC      #MQUALS,OPFLAG ;CLEAR ALL MESSAGE QUALIFIERS
77 036544 005737 003234          TST      PASCNT      ;TEST IF PASS 0
78 036550 001414          BEQ      2$          ;YES - SKIP
79 036552 023727 003234 000003    CMP      PASCNT,#3   ;TEST IF PASS 3
80 036560 001404          BEQ      1$          ;YES - SKIP
81 036562 002407          BLT      2$          ;CHECK IF LESS THAN 3, IF YES CLEAR TO 0
82 036564 012737 000003 003234    MOV      #3,PASCNT   ;ELSE SET TO 3
83 036572 052737 000020 003006 1$:     BIS      #INOUTS,OPFLAG ;SET MESSAGE QUAL
84 036600 000405          BR       3$          ;SKIP
85
86 036602 005037 003234          CLR      PASCNT      ;SET PASS COUNT TO 0
87 036606 052737 000040 003006    BIS      #OUTINS,OPFLAG ;SET MESSAGE QUAL
88 036614 012737 000003 003024 3$:     MOV      #3,WRTSWI   ;SET READ AND WRITE SWITCH
89 036622 012701 002506          MOV      #T33TBL,R1
90 036626 012703 002546          MOV      #TBT,R3
91 036632 005037 003116          CLR      DESS$C
92 036636 012137 003104          MOV      (R1)+,NEWCYL ;GET NEXT TABLE ENTRY
93 036642 004737 020112    JSR      PC,X$EEK    ;DO SEEK
94 036646 037254          18$
95 036650 012701 005670          MOV      #3000.,R1   ;SET WAIT COUNT FOR 300 MS
96 036654 004737 023570          JSR      PC,RDYWAIT  ;WAIT FOR READY
97 036660 037254          18$
98 036662 012337 003104          MOV      (R3)+,NEWCYL ;GET NEXT TABLE ENTRY
99 036666 004737 020112    JSR      PC,X$EEK    ;DO SEEK
100 036672 037254          18$
101 036674 012701 005670          MOV      #3000.,R1   ;SET WAIT COUNT FOR 300 MS
102 036700 004737 023570          JSR      PC,RDYWAIT  ;WAIT FOR READY
103 036704 037254          18$
104 036706 004737 024202          JSR      PC,VERPOS   ;VERIFY POSITION
105 036712 037254          18$
106 036714 004737 026124          JSR      PC,BSCHK    ;CHECK FOR BAD SECTOR
107 036720 037070          11$
108 036722 005737 003234          TST      PASCNT      ;"YES" RETURN
109 036726 001407          BEQ      6$          ;TEST IF PASS 0
110 036730 022737 000003 003234    CMP      #3,PASCNT   ;YES - SKIP
111 036736 001403          BEQ      6$          ;TEST IF PASS 3
112 036740 005037 036760          CLR      8$          ;YES - SKIP
113 036744 000403          BR       7$          ;ELSE CLEAR DATA PATTERN SELECTOR
114
115 036746 012737 000010 036760 6$:     MOV      #8.,8$      ;SET DATA PATTERN SELECTOR TO 8
116 036754 004537 024672          JSR      R5,DATGEN   ;GO GENERATE DATA

```

\*TEST 8

\*\*OVERWRITE

117	036760	000000			8\$:	.WORD	0		
118	035762	032737	000001	003024		BIT	#BIT0,WRTSWI	:TEST IF WRITE THIS PASS	
119	036770	001425				BEQ	9\$	:NO - SKIP	
120	036772	004737	025322			JSR	PC,XWRITE	:DO WRITE	
121	036776	037254				18\$			
122	037000	005237	003116			INC	DESSEC	:INC SECTOR	
123	037004	022737	000050	003116		CMP	#40.,DESSEC	:TEST IF ALL SECTORS USED	
124	037012	001340				BNE	5\$	:NO - SKIP	
125	037014	042737	000060	003006		BIC	#INOUTS!OUTINS,OPFLAG	:CLEAR QUALIFIERS	
126	037022	042737	000001	003024		BIC	#BIT0,WRTSWI	:CLEAR WRITE REQUIRED SWITCH	
127	037030	052737	000100	003006		BIS	#FOLWRT,OPFLAG	:SET FOLLOWING WRITE QUALIFIER	
128	037036	005037	003116			CLR	DESSEC	:CLEAR TO SECTOR 0	
129	037042	000724				BR	5\$	:SKIP	
130									
131	037044	032737	000002	003024	9\$:	BIT	#BIT1,WRTSWI	:TEST IF READ THIS PASS	
132	037052	001414				BEQ	12\$	:NO - SKIP	
133	037054	004737	025362		10\$:	JSR	PC,XREAD	:ELSE DO READ	
134	037060	037254				18\$			
135	037062	004737	025032			JSR	PC,DATCOM	:COMPARE DATA	
136	037066	037254				18\$			
137	037070	005237	003116		11\$:	INC	DESSEC	:BUMP SECTOR	
138	037074	022737	000050	003116		CMP	#40.,DESSEC	:TEST IF ALL SECTORS USED	
139	037102	001304				BNE	5\$	:NO - LOOP	
140	037104	005037	003116		12\$:	CLR	DESSEC	:CLEAR DESIRED SECTOR	
141	037110	005037	003024			CLR	WRTSWI	:CLEAR WRITE/READ SWITCH	
142	037114	005237	003234			INC	PASCNT	:BUMP PASS COUNT	
143	037120	042737	003760	003006		BIC	#EQUALS,OPFLAG	:CLEAR ALL QUALIFIERS	
144	037126	023727	003234	000003		CMP	PASCNT,#3	:TEST IS PASS 3	
145	037134	001447				BEQ	18\$	:YES - SKIP	
146	037136	023727	003234	000006		CMP	PASCNT,#6	:TEST IF PASS 6	
147	037144	001443				BEQ	18\$	:YES - SKIP	
148	037146	023727	003234	000001		CMP	PASCNT,#1	:TEST IF PASS 1	
149	037154	001424				BEQ	15\$	:YES - SKIP	
150	037156	023727	003234	000004		CMP	PASCNT,#4	:TEST IF PASS 4	
151	037164	001424				BEQ	16\$	:YES - SKIP	
152	037166	012737	000002	003024		MOV	#BIT1,WRTSWI	:SET WRITE REQUIRED BIT	
153	037174	023727	003234	000002		CMP	PASCNT,#2	:TEST IF PASS 2	
154	037202	001405				BEQ	14\$	:YES - SKIP	
155	037204	052737	001000	003006		BIS	#REVSKO,OPFLAG	:SET REVERSE QUALIFIER	
156	037212	000137	036632		13\$:	JMP	4\$	:GO DO NEXT PASS	
157									
158	037216	052737	002000	003006	14\$:	BIS	#FWDSCO,OPFLAG	:SET FWD QUALIFIER	
159	037224	000772				BR	13\$	:GO DO NEXT PASS	
160									
161	037226	052737	000020	003006	15\$:	BIS	#INOUTS,OPFLAG	:SET QUALIFIER	
162	037234	000403				BR	17\$	:SKIP	
163									
164	037236	052737	000040	003006	16\$:	BIS	#OUTINS,OPFLAG	:SET MESSAGE QUALIFIER	
165	037244	012737	000001	003024	17\$:	MOV	#BIT0,WRTSWI	:SET WRITE REQUIRED BIT	
166	037252	000757				BR	13\$	:GO DO NEXT PASS	
167									
168	037254	012737	000002	003020	18\$:	MOV	#2,ERRSWI	:INIT ERROR SWITCH	
169	037262				L10037:	TRAP	C\$ESUB		
170									
171	037264	104410				TRAP	C\$ESCAPE		
	037266	000060				.WORD	L10036-		

\*TEST 8

\*\*OVERWRITE

172	037270	012737	000003	003024		MOV	#3,WRTSWI	;SET FOR READ AND WRITE REQ.
173	037276	023727	003234	000003		CMP	PASCNT,#3	;TEST IF PASS 3
174	037304	001004				BNE	19\$	;NO - SKIP
175	037306	012737	002514	003026		MOV	#T33TBL+6,TBLSTR	;STORE MID POINT IN TABLE
176	037314	000410				BR	20\$	;GO START PASS 4
177								
178	037316	005037	003234		19\$:	CLR	PASCNT	;CLEAR TO PASS 0
179	037322	004737	021530			JSR	PC,SWAPHD	;GO SWAP TO HEAD ONE OR ABORT TEST
180	037326	036310				T3400\$		;ABORT RETURN
181	037330	012737	002506	003026		MOV	#T33TBL,TBLSTR	;STORE START OF TABLE
182	037336	062703	000006		20\$:	ADD	#6,R3	
183	037342	000137	036534			JMP	T3401\$	
184								
185	037346				T3465\$:			
	037346				L10036:			
	037346	104401				TRAP	C\$ETST	



```

37 037572      1$:      .WORD  T$CODE
    037572      000130      .WORD  HILIMQ
    037574      040002      .WORD  20000
    037576      020000      .WORD  T$CODE
38 037600      .WORD  T$CODE
39 037602      002052      .WORD  T$CODE
    037604      037774      .WORD  LIMVAL
    037606      000777      .WORD  777
    037610      000000      .WORD  T$LOLIM
    037612      000377      .WORD  T$HILIM
40 037614      2$:      .WORD  T$CODE
    037614      000130      .WORD  HEADQ
    037616      040023      .WORD  10000
    037620      010000      .WORD  T$CODE
41 037622      006044      .WORD  T$CODE
42 037624      003052      .WORD  T$CODE
    037626      040045      .WORD  HEADV
    037630      000017      .WORD  17
    037632      000000      .WORD  T$LOLIM
    037634      000001      .WORD  T$HILIM
44 037636      3$:      .WORD  T$CODE
    037636      004052      .WORD  ERLIMQ
    037640      040070      .WORD  377
    037642      000377      .WORD  T$LOLIM
    037644      000000      .WORD  T$HILIM
    037646      000377      .WORD  T$CODE
46 037650      005052      .WORD  T$CODE
    037652      040112      .WORD  DCLIMQ
    037654      000377      .WORD  377
    037656      000001      .WORD  T$LOLIM
    037660      000377      .WORD  T$HILIM
47 037662      006130      .WORD  T$CODE
    037664      040133      .WORD  BSOUTQ
    037666      000001      .WORD  1
49 037670      .EVEN
51 037670      L10041:
52 037670      125      123      105  CYLQ:  .ASCIZ  /USE ALL CYL/
53 037704      125      123      105  SECQ:  .ASCIZ  /USE ALL SECT/
60 037721      104      117      040  MANQ:  .ASCIZ  /DO MANUAL INTERVENTION TEST/
62 037755      114      117      127  LOLIMQ: .ASCIZ  /LOW SEEK LIMIT/
63 037774      126      101      114  LIMVAL: .ASCIZ  /VALUE/
64 040002      125      120      120  HILIMQ: .ASCIZ  /UPPER SEEK LIMIT/
65 040023      125      123      105  HEADQ:  .ASCIZ  /USE ONLY ONE SURF/
66 040045      127      110      101  HEADV:  .ASCIZ  /WHAT SURF (0 OR 1)/
68 040070      111      116      120  ERLIMQ: .ASCIZ  /INPUT ERROR LIMIT/
70 040112      104      101      124  DCLIMQ: .ASCIZ  /DATA CMP ERR LMT/
71 040133      120      122      111  BSOUTQ: .ASCIZ  /PRINT ERRORS DETECTED WHILE READING BAD SEC FILE/
74 040214      000000      .EVEN
    040216      000000      .WORD  0
    040220      .WORD  0
75 000001      L$LAST::
    .END

```



ADR = 000020 G  
 AFMID 003212  
 AFMIDU 003214  
 ALLCYL = 000001  
 ALLSEC = 000002  
 ANYERR = 100000  
 ARMID 003216  
 ARMIDU 003220  
 ASSEMB = 000010  
 BASADD = 004000  
 BAMSK = 000060  
 BANAM 006712  
 BASADD 006610  
 BELL 011477  
 BHSTAT = 000010  
 BIT0 = 000001 G  
 BIT00 = 000001 G  
 BIT01 = 000002 G  
 BIT02 = 000004 G  
 BIT03 = 000010 G  
 BIT04 = 000020 G  
 BIT05 = 000040 G  
 BIT06 = 000100 G  
 BIT07 = 000200 G  
 BIT08 = 000400 G  
 BIT09 = 001000 G  
 BIT1 = 000002 G  
 BIT10 = 002000 G  
 BIT11 = 004000 G  
 BIT12 = 010000 G  
 BIT13 = 020000 G  
 BIT14 = 040000 G  
 BIT15 = 100000 G  
 BIT2 = 000004 G  
 BIT3 = 000010 G  
 BIT4 = 000020 G  
 BIT5 = 000040 G  
 BIT6 = 000100 G  
 BIT7 = 000200 G  
 BIT8 = 000400 G  
 BIT9 = 001000 G  
 BOE = 000400 G  
 BRMSG 037455  
 BSCHK 026124  
 BSERR = 000014  
 BSERRS 014514  
 BSFLAG 003022  
 BSFNOT 010572  
 BSFVAL 003500  
 BSOUTQ 040133  
 BYPSNM 010161  
 CAFDT 011604  
 CAMSK 002314  
 CCYLUP 011575  
 CHOSHD 021504  
 CKBSVD 021614  
 CKDATA = 000102

CKERLM 016616  
 CLKADR 003476  
 CLKCSB = 172542  
 CLKCSR = 172540  
 CLKCTR = 172544  
 CLKFLG 003474  
 CLNCOD 016056 G  
 CLRBYT 002306  
 CLRPAR 027524  
 CNT = 000012  
 CNTYPE 037516  
 COMPOP = 007777  
 CONHNG = 000004  
 CONTIN 014744  
 COSTAT = 000040  
 COUNT 003236  
 CR = 000015  
 CRDYMS = 000200  
 CRLF 011623 G  
 CSNAM 006705  
 CSR = 000000  
 CSRMSG 037432  
 CURCYL 003106  
 CYLQ 037670  
 CYLTBL 002606  
 CYLUP = 000004  
 CYLWD 010146  
 C\$AU = 000052  
 C\$AUTO = 000061  
 C\$BRK = 000022  
 C\$BSEG = 000004  
 C\$BSUB = 000002  
 C\$CLCK = 000062  
 C\$CLEA = 000012  
 C\$CLOS = 000035  
 C\$CLP1 = 000006  
 C\$CPBF = 000074  
 C\$CPME = 000075  
 C\$CVEC = 000036  
 C\$DCLN = 000044  
 C\$DODU = 000051  
 C\$DRPT = 000024  
 C\$DU = 000053  
 C\$EDIT = 000001  
 C\$ERDF = 000055  
 C\$ERHR = 000056  
 C\$ERRO = 000060  
 C\$ERSF = 000054  
 C\$ERSO = 000057  
 C\$ESCA = 000010  
 C\$ESEG = 000005  
 C\$ESUB = 000003  
 C\$ETST = 000001  
 C\$EXIT = 000032  
 C\$FREQ = 000101  
 C\$FRME = 000100  
 C\$GETB = 000026

C\$GETW = 000027  
 C\$GMAN = 000043  
 C\$GPHR = 000042  
 C\$GPRI = 000040  
 C\$INIT = 000011  
 C\$INLP = 000020  
 C\$MANI = 000050  
 C\$MAP = 000102  
 C\$MEM = 000031  
 C\$MMU = 000103  
 C\$MSG = 000023  
 C\$OPNR = 000034  
 C\$OPNW = 000104  
 C\$PNTB = 000014  
 C\$PNTF = 000017  
 C\$PNTS = 000016  
 C\$PNTX = 000015  
 C\$PUTB = 000072  
 C\$PUTW = 000073  
 C\$QIO = 000377  
 C\$RDBU = 000007  
 C\$REFG = 000047  
 C\$REL = 000077  
 C\$RESE = 000033  
 C\$REVI = 000004  
 C\$RFLA = 000021  
 C\$RPT = 000025  
 C\$SEFG = 000046  
 C\$SPRI = 000041  
 C\$SVEC = 000037  
 C\$TOME = 000076  
 C1OMS 011556  
 C5SEC 011615  
 C5OOMS 011567  
 DANAM 006717  
 DATACM = 000001  
 DATCOM 025032  
 DATGEN 024672  
 DCKERR = 004000  
 DCLIM = 000012  
 DCLIMQ 040112  
 DCLIMW 014512  
 DESDIF 003110  
 DESHD 003114  
 DESSEC 003116  
 DESSGN 003112  
 DIAGMC = 000000  
 DIFAug 003100  
 DIFWD 010122  
 DIRBIT = 000004  
 DIRMSK 002316  
 DLTERR = 010000  
 DONE 003010  
 DRDYMS = 000001  
 DRMSG 037510  
 DRSB = 000010  
 DRSELT = 000004

DRSET = 000010  
 DRTYPE 037466  
 DRVCNT 003076  
 DRVERR = 040000  
 DRVNAM 006621  
 DRVNAV 006626  
 DSESTA = 000400  
 DSMSK = 001400  
 DSPCOD 014516 G  
 EF.CON = 000036 G  
 EF.NEW = 000035 G  
 EF.PWR = 000034 G  
 EF.RES = 000037 G  
 EF.STA = 000040 G  
 EF.XM = 000033 G  
 ERHEAD 003014  
 ERLIM = 000010  
 ERLIMQ 040070  
 ERLIMW 014510  
 ERRCNT 003244  
 ERRPOI 003242  
 ERRSWI 003020  
 ERRVEC 003232  
 ERR1 012646 G  
 ERR10 014242 G  
 ERR2 012714 G  
 ERR3 012762 G  
 ERR4 013030 G  
 ERR5 013100 G  
 ERR6 013150 G  
 ERR7 014032 G  
 ERR8 014102 G  
 ERR9 014176 G  
 EVL = 000004 G  
 EXACYL 003226  
 EXHCYL 003224  
 EXOCYL 003222  
 EXROT 003230  
 E\$END = 002100  
 E\$LOAD = 000035  
 FCTBSF 003502  
 FLDBSF 004076  
 FMTOP1 011631  
 FMTOP2 011660  
 FMTOP3 011702  
 FMTXT 011626 G  
 FMT1 011723  
 FMT10 012141  
 FMT11 012141  
 FMT12 012147  
 FMT13 012155  
 FMT14 012221  
 FMT15 012253  
 FMT16 012307  
 FMT17 012320  
 FMT18 012342  
 FMT19 012374

FMT2 011730  
 FMT20 012431  
 FMT21 012461  
 FMT22 012504  
 FMT23 012540  
 FMT24 012554  
 FMT25 012561  
 FMT26 012571  
 FMT27 012615  
 FMT28 012634  
 FMT3 011737  
 FMT4 011737  
 FMT5 011750  
 FMT6 011770  
 FMT7 012032  
 FMT8 012102  
 FMT9 012134  
 FOLWRT = 000100  
 FRMWD 010153  
 FWDSKO = 002000  
 FWDSKS = 000400  
 F\$AU = 000015  
 F\$AUTO = 000020  
 F\$BGN = 000040  
 F\$CLEA = 000007  
 F\$DU = 000016  
 F\$END = 000041  
 F\$HARD = 000004  
 F\$HW = 000013  
 F\$INIT = 000006  
 F\$JMP = 000050  
 F\$MOD = 000000  
 F\$MSG = 000011  
 F\$PROT = 000021  
 F\$PWR = 000017  
 F\$RPT = 000012  
 F\$SEG = 000003  
 F\$SOFT = 000005  
 F\$SRV = 000010  
 F\$SUB = 000002  
 F\$SW = 000014  
 F\$TEST = 000001  
 GBND 002312  
 GETPOS 024054  
 GETSTA = 000003  
 GLBDAT 002226 G  
 GLBEQA 002226 G  
 GLBERR 012646 G  
 GLBSUB 016210 G  
 GLBTXT 005750 G  
 GSTAT 017214  
 GSTATC 017200  
 GSTATG 017224  
 GSTATR 017164  
 GTSTAT = 000104  
 G\$CNT0 = 000200  
 G\$DELM = 000372

G\$DISP=	000003	HSSTAT=	000100	L\$CLEA	016056	G	L10007	014174	MHFCRC	010774
G\$EXCP=	000400	IBE	= 010000	L\$CO	002032	G	L10010	014240	MHNF	010746
G\$HILI=	000002	IBUFF	004472	L\$DEPO	002011	G	L10011	014450	MININC	003462
G\$LOLI=	000001	IDU	= 000040	L\$DESC	002122	G	L10013	014476	MINOUT	006177
G\$NO	= 000000	IER	= 020000	L\$DESP	002076	G	L10014	014516	MISWI	= 000000
G\$OFFS=	000400	INITCO	014540	L\$DEVP	002060	G	L10015	015516	MISWIW	014500
G\$OF SI=	000376	INOUTS=	000020	L\$DISP	014520	G	L10016	016054	MITEST=	100000
G\$PRMA=	000001	INTEBL=	000100	L\$DLY	002116	G	L10017	016202	MINDRST	011274
G\$PRMD=	000002	INTHLR	016536	L\$DTP	002040	G	L10020	016206	MNEERR	011242
G\$PRML=	000000	ISR	= 000100	L\$DTYP	002034	G	L10021	016534	MNOCLR	007072
G\$RADA=	000140	IXE	= 004000	L\$DU	016204	G	L10022	016614	MNOINT	007023
G\$RADB=	000000	I\$AU	= 000041	L\$DUT	002072	G	L10023	031472	MOPEP	006117
G\$RADD=	000040	I\$AUTO=	000041	L\$DVTY	002214	G	L10024	031524	MOPEKR	011167
G\$RADL=	000120	I\$CLN =	000041	L\$EF	002052	G	L10025	031746	MORECE	003016
G\$RADO=	000020	I\$DU =	000041	L\$ENVI	002044	G	L10026	031672	MOUTIN	006160
G\$XFER=	000004	I\$HRD =	000041	L\$ETP	002102	G	L10027	032562	MPNAM	006724
G\$YES =	000010	I\$INIT=	000041	L\$EXP1	002046	G	L10030	033700	MQUALS=	003760
HADONE	003012	I\$MOD =	000041	L\$EXP4	002064	G	L10031	033614	MREAD	005754
HCESTA=	040000	I\$MSG =	000041	L\$EXP5	002066	G	L10032	034724	MREADH	005765
HCR CER=	004000	I\$PROT=	000040	L\$HARD	037352	G	L10033	034600	MRESKO	006356
HDALIG=	000010	I\$PTAB=	000041	L\$HIME	002120	G	L10034	036146	MREVSJ	006240
HDCYL	002320	I\$PWR =	000041	L\$HPCP	002016	G	L10035	036062	MRLFAL	011364
HDHSEL=	000100	I\$RPT =	000041	L\$HPTP	002022	G	L10036	037346	MRSLT	006126
HDMQVF	010003	I\$SEG =	000041	L\$HW	014462	G	L10037	037262	MSEEK	005750
HDRCMP=	000002	I\$SETU=	000041	L\$ICP	002104	G	L10040	037432	MSPERR	011065
HDR40 =	100000	I\$SFT =	000041	L\$INIT	014540	G	L10041	037670	MSTERR	011120
HDSEC =	000077	I\$SRV =	000041	L\$LADP	002026	G	MAJINC	003472	MTOSLO	006765
HDSEL =	000020	I\$SUB =	000041	L\$LAST	040220	G	MANQ	037721	MUBSF	006510
HDWD	010135	I\$TST =	000041	L\$LOAD	002100	G	MAPROX	007633	MULOAD	006137
HDWRD1	003054	JUNK	002302	L\$LUN	002074	G	MBADAD	006412	MUNDEF	011317
HDWRD2	003056	J\$JMP =	000167	L\$MREV	002050	G	MBSETO=	000001	MWDERR	011152
HDWRD3	003060	LABACF	007753	L\$NAME	002000	G	MCERR	010713	MWGERR	011103
HEAD =	000006	LABACR	007767	L\$PRIO	002042	G	MCONHN	007056	MWORD	006757
HEADLM=	010000	LABEXP	007666	L\$PROT	014452	G	MCYLOC	011267	MWRCHK	005775
HEADQ	040023	LABHCF	007723	L\$PRT	002112	G	MCYLUP	006150	MWRITE	006006
HEADV	040045	LABHCR	007737	L\$REPP	002062	G	MDATCP	006032	MWRSET	006103
HEADW	014506	LABIN	007643	L\$REV	002010	G	MDCRC	010735	MWRTAB	011423
HF IN	003172	LABMID	007651	L\$SOFT	037526	G	MDHEDR	002000	M4OHDR	006067
HFINU	003174	LABOCF	007677	L\$SPC	002056	G	MDLT	010762	NEWCYL	003104
HFOUT	003176	LABOCR	007711	L\$SPCP	002020	G	MDRDY	010702	NOCLR =	000010
HFOUTU	003200	LABOUT	007660	L\$SPTP	002024	G	MDRERR	011024	NOCTLR	010251
HICYL =	020000	LAB1	006731	L\$STA	002030	G	MDRRES	007005	NOERCT	003451
HILIM =	000004	LAB2	006744	L\$SW	014500	G	MDRVST	011052	NOHD1	010461
HILIMQ	040002	LF	= 000012	L\$TEST	002114	G	MDSERR	011035	NOIRPT=	000002
HILIMW	014504	LIMVAL	037774	L\$TIML	002014	G	MERRS	011472	NOOP =	000100
HLMTW	002304	LOCERR	003450	L\$UNIT	002012	G	MEXERS	011435	NOPIR	006645
HNERR=	010000	LOCYL =	040000	L\$BA	003040	G	MFBFS	006433	NOTRDY	010307
HOE =	100000	LOE =	040000	L\$CS	003036	G	MFLERR	011214	NOTST	010364
HSTAT=	000020	LOLIM =	000002	L\$DA	003042	G	MFMTERR	006563	NXMERR=	020000
HPTCOD	014460	LOLIMQ	037755	L\$MP	003044	G	MFOLWR	006220	NXTHL	002310
HRDPRM	037350	LOLIMW	014502	L10000	012712	G	MFWSK	006271	NXTPAS	014764
HRDWS	027554	LOT =	000010	L10001	012760	G	MFWSKO	006322	OBUFF	005072
HRIN	003202	L\$ACP	002110	L10002	013026	G	MGTSTA	006020	OFIN	003142
HRINU	003204	L\$APT	002036	L10003	013076	G	MHCERR	011134	OFINU	003144
HROUT	003206	L\$AUT	002070	L10004	013146	G	MHCRC	010725	OFMID	003146
HROUTU	003210	L\$AUTO	015520	L10005	014030	G	MHDERR	011177	OFMIDU	003150
HSMK =	000100	L\$CCP	002106	L10006	014100	G	MHDRCP	006051	OFOUT	003152

Symbol table

OFOUTU	003154	PRI06 =	000300	G	SECWD	010141	T\$GMAN=	000000	T3265\$	034724	
OLDCYL	003102	PRI07 =	000340	G	SEEK	= 000106	T\$HILI=	000377	T33TBL	002506	
ONSWAP	021570	PSETNM	003446		SEEKOP=	010000	T\$LAST=	000001	T3300\$	035102	
OPFLAG	003006	PWCON	015246		SEGMES	010174	T\$LOLI=	000001	T3301\$	035364	
OPERR=	002000	PWRFLG	003454		SETDON	015020	T\$LSYM=	010000	T3365\$	036146	
OPMSG5	002226	P2T03E	007156		SF TPRM	037524	T\$LTNO=	000010	T3400\$	036310	
OPR004	010105	P2T04E	007174		SGNWD	010130	T\$NEST=	177777	T3401\$	036534	
OPR1A	010056	P2T05E	007214		SKTMES	007553	T\$NSO =	000000	T3465\$	037346	
OPR1B	010062	P2T06E	007234		SPDSTA=	004000	T\$NS1 =	000005	T4	031750	G
OPR12	010037	P2T07E	007254		SPTCOD	014476	T\$NS2 =	000002	T5	032564	G
ORIN	003156	P2T08E	007272		SRTMES	007565	T\$PTNU=	000000	T5.1	033124	G
ORINU	003160	P2T09E	007312		SSINDX	003004	T\$SAVL=	177777	T6	033702	G
ORMID	003162	P2T10E	007315		STAMES	010217	T\$SEGL=	177777	T6.1	033730	G
ORMIDU	003164	P2T11E	007330		STAMSK=	000007	T\$SEKO=	010000	T7	034726	G
OROUT	003166	P2T12E	007343		STATE2	011526	T\$SUBN=	000001	T7.1	035364	G
OROUTU	003170	P2T13E	007355		STATE3	011536	T\$TAGL=	177777	T8	036150	G
OUTINS=	000040	P2T14E	007402		STATE5	011546	T\$TAGN=	010042	T8.1	036534	G
O\$APTS=	000000	P2T15E	007423		STOSTA=	010000	T\$TEMP=	000000	UAM	= 000200	G
O\$AU	= 000000	P2T16E	007446		SUBSTK	002406	T\$TEST=	000010	ULOAD =	000010	
O\$BGNR=	000000	P2T17E	007467		SVCBGL=	000001	T\$TSTM=	177777	UNDTST	010072	
O\$BGNS=	000001	P2T18E	007521		SVCGBL=	000000	T\$TSTS=	000001	UNXERR	007133	
O\$DU	= 000001	P2T19E	007543		SVCINS=	000000	T\$A\$AUT=	010016	VALDES	007607	
O\$ERRT=	000000	RDALHD	024324		SVCSUB=	000000	T\$A\$CLE=	010017	VCNRST	007112	
O\$GNSW=	000001	RDBSF	021630		SVCTAG=	000000	T\$A\$DU =	010020	VCSTAT=	001000	
O\$POIN=	000001	RDDATA=	000114		SVCTST=	000000	T\$A\$HAR=	010040	VECMSG	037446	
O\$SETU=	000000	RDHEAD=	000110		SWAPHD	021530	T\$A\$HW =	010013	VECT	= 000002	
PART2 =	000001	RDNOHR=	000116		S\$LSYM=	010000	T\$A\$INI=	010015	VERHDR	023174	
PASCNT	003234	RDYCHK	021230		TAG	003470	T\$A\$MSG=	010011	VERPOS	024202	
PASNEW	014772	RDYWAI	023570		TBLSTR	003026	T\$A\$PRO=	010012	WAITIN	017010	
PASNUM	003444	READRL	016756		TBT	002546	T\$A\$SEG=	010000	WCMSK =	017777	
PATTBL	002362	RELDWT=	040000		TCERR	010230	T\$A\$SOF=	010041	WCRNG =	160000	
PAT1	005472	RESE3	011503		TEMP	003464	T\$A\$SRV=	010022	WDESTA=	100000	
PAT10	005746	RESE4	011507		TEMPO	003120	T\$A\$SUB=	010037	WGESTA=	002000	
PAT2	005474	RESE5	011514		TEMP1	003122	T\$A\$SW =	010014	WLSTAT=	020000	
PAT3	005534	RESE6	011521		TEMP2	003124	T\$A\$TES=	010036	WRTSWI	003024	
PAT4	005574	RESPAR	003064		TEMP3	003126	T.BA	003050	WTDATA=	000112	
PAT5	005634	RESTAR	014734		TEMP4	003130	T.CS	003046	XDELAY	003456	
PAT6	005642	RESTBL	002322		TEMP5	003132	T.DA	003052	XRHD	022540	
PAT7	005702	REVSKO=	001000		TEMP6	003134	T.DRIV	002300	XRHDHC	022530	
PAT8	005704	REVSKS=	000200		TEMP7	003136	T.MP	003054	XRHDHG	022544	
PAT9	005744	RLBA =	000002		TEMP8	003140	T.STAT	003062	XREAD	025362	
PH65\$	021172	RLBAS	003030		TIME	016210	T1	027554	XREADG	025370	
PNT	= 001000	RLCS =	000000		TIM.US	003466	T2	031474	XSEEK	020112	
POSHDS	020664	RLCSR =	000000		TOSLOW=	000001	T25TBL	002432	XSEEKT	020102	
POSHDO	023544	RLDA =	000004		TRPFLG	003452	T25TB2	002460	XSEK1	020116	
POSHS8	023540	RLDRV	003034		TRPHAN	016530	T3	031526	XTLIE	016354	
POSHW1	023532	RLMP =	000006		TSTINT	017146	T3.1	031632	XWRITE	025322	
PRI	= 002000	RLVEC	003032		TSTLAB	007150	T306\$	031600	XWRITT	025312	
PRIOR	= 000004	RORWOP=	020000		TSTNM	003240	T3065\$	031746	XWRIT1	025326	
PRI00	= 000000	RPTOP	026274		TYPDR =	000006	T307\$	031632	X\$ALWA=	000000	
PRI01	= 000040	RPTREM	027270		T\$ARGC=	000007	T310\$	031640	X\$FALS=	000040	
PRI02	= 000100	RPTRES	027062		T\$CODE=	006130	T3100\$	032716	X\$OFFS=	000400	
PRI03	= 000140	RSTRT	014652		T\$ERRN=	003247	T3101\$	033124	X\$TRUE=	000020	
PRI04	= 000200	SAMSK =	000077		T\$EXCP=	000000	T3165\$	033700	YDELAY	003460	
PRI05	= 000240	SECQ	037704		T\$FLAG=	000040	T3204\$	034602			

. ABS. 040220 000 (RW,I,GBL,ABS,OVR)

B11

CZRLNCO RL01/02 DRIVE TEST 3 MACRO V05.03b Monday 06-Jan-86 00:23 Page 66-5  
Symbol table

SEQ 0131

000000 001 (RW,I,LCL,REL,CON)  
Errors detected: 0

\*\*\* Assembler statistics

Work file reads: 964  
Work file writes: 775  
Size of work file: 35176 Words ( 138 Pages)  
Size of core pool: 14080 Words ( 55 Pages)  
Operating system: RT-11 (Under RTEM-11)

Elapsed time: 00:05:26.00  
CZRLNC.BIC,CZRLNC.LST/C=CZRLNC.DOC,CZRLNC.MAC,SVC41R.MLB/M



























































57-206#	57-206#	57-206#	57-206#	57-211	57-211	57-211	57-211	57-211	57-211	57-211	57-211	57-211	57-211	57-211
57-211	57-211	57-211	57-211#	57-211#	57-211#	57-211#	57-211#	57-211#	57-211#	57-211#	57-211#	57-211#	57-211#	57-211#
57-214#	57-214	57-214	57-214#	57-214	57-214	57-214	57-214	57-214	57-214	57-214	57-214	57-214	57-214	57-214#
57-226	57-226#	57-226#	57-226#	57-226#	57-226#	57-226#	57-226#	57-226#	57-226	57-226	57-226	57-226	57-226	57-226
57-235#	57-235#	57-235#	57-235#	57-235#	57-235#	57-235#	57-235#	57-235#	57-235	57-235	57-235	57-235	57-235	57-235
57-236#	57-236#	57-236#	57-236#	57-236#	57-236#	57-236#	57-236#	57-236#	57-236	57-236	57-236	57-236	57-236	57-236#
57-239#	57-239#	57-239#	57-239#	57-239#	57-239#	57-239#	57-239#	57-239#	57-239	57-239	57-239	57-239	57-239#	57-239#
57-247#	57-247#	57-247#	57-247#	57-247#	57-247#	57-247#	57-247#	57-247#	57-247	57-247	57-247	57-247	57-247	57-247
57-250	57-250	57-250	57-250	57-250	57-250#	57-250#	57-250#	57-250#	57-250#	57-250#	57-250#	57-250#	57-250#	57-250#
57-251#	57-251#	57-251#	57-251#	57-251#	57-251#	57-251#	57-251#	57-251#	57-251	57-251	57-251	57-251#	57-251#	57-251#
57-252	57-252	57-252	57-252	57-252	57-252#	57-252#	57-252#	57-252#	57-252	57-252	57-252	57-252	57-252	57-252
57-252#	58-16	58-16	58-16	58-16	58-16	58-16	58-16	58-16	58-16#	58-16#	58-16#	58-16#	58-16#	58-16#
58-57	58-57	58-57#	58-57#	58-57#	58-57#	58-57#	58-57#	58-57#	58-62	58-62	58-62	58-62#	58-62#	58-62#
58-62#	58-62#	58-198	58-198	58-198	58-198	58-198	58-198	58-198	58-198	58-198	58-198#	58-198#	58-198#	58-198#
58-198#	58-199	58-199	58-199	58-199	58-199	58-199	58-199	58-199	58-199	58-199	58-199	58-199#	58-199#	58-199#
58-199#	58-199#	58-199#	58-199#	58-199#	58-199#	58-199#	58-199#	58-199#	58-200	58-200	58-200	58-200	58-200	58-200
58-200#	58-200#	58-200#	58-200#	58-200#	58-200#	58-200#	58-200#	58-200#	58-200	58-200	58-200	58-200	58-200	58-200
58-201	58-201	58-201	58-201	58-201#	58-201#	58-201#	58-201#	58-201#	58-201	58-201	58-201	58-201	58-201	58-201
58-202	58-202	58-202	58-202	58-202	58-202	58-202	58-202	58-202	58-202	58-202	58-202#	58-202#	58-202#	58-202#
58-202#	58-202#	58-202#	58-202#	58-202#	58-202#	58-202#	58-202#	58-202#	58-202	58-202	58-202	58-202#	58-202#	58-202#
58-203#	58-203#	58-203#	58-203#	58-203#	58-203#	58-203#	58-203#	58-203#	58-203	58-203	58-203	58-203	58-203	58-203#
58-204	58-204	58-204#	58-204#	58-204#	58-204#	58-204#	58-204#	58-204#	58-204	58-204	58-204	58-204	58-204	58-204
58-205	58-205	58-205	58-205	58-205#	58-205#	58-205#	58-205#	58-205#	58-205#	58-205#	58-205#	58-205#	58-205#	58-205#
58-206	58-206	58-206	58-206	58-206	58-206#	58-206#	58-206#	58-206#	58-206#	58-206#	58-206#	58-206#	58-206#	58-206#
59-12	59-12#	60-27	60-27#	60-37	60-37#	60-39	60-39	60-39	60-39#	60-39#	60-39#	60-39#	60-55	60-55#
61-12	61-12	61-12	61-12	61-12#	61-12#	61-12#	61-12#	61-12#	61-12#	61-12#	61-12#	61-12#	61-14	61-14
61-46	61-46	61-46	61-46#	61-46#	61-46#	61-46#	61-46#	61-46#	61-51	61-51	61-51	61-51	61-14#	61-14#
61-51#	61-51#	61-51#	61-68	61-68	61-68	61-68	61-68	61-68	61-68#	61-68#	61-68#	61-68#	61-51#	61-51#
61-73	61-73	61-73#	61-73#	61-73#	61-73#	61-73#	61-73#	61-73#	61-86	61-86	61-86	61-86	61-73	61-73
61-86#	61-86#	61-86#	61-86#	61-86#	61-86#	61-86#	61-86#	61-86#	61-87	61-87	61-87	61-87	61-86	61-86
61-87	61-87	61-87#	61-87#	61-87#	61-87#	61-87#	61-87#	61-87#	61-87#	61-87#	61-87#	61-87#	61-87	61-87
61-88	61-88	61-88	61-88	61-88	61-88	61-88	61-88	61-88	61-88#	61-88#	61-88#	61-88#	61-88	61-88
61-88#	61-90	61-90#	62-67	62-67#	62-152	62-152#	62-152#	62-152#	62-154	62-154	62-154#	62-154#	62-168	62-168#
63-13#	63-38	63-38	63-38	63-38	63-38	63-38	63-38	63-38	63-38	63-38	63-38	63-38	63-38	63-38#
63-38#	63-38#	63-38#	63-38#	63-38#	63-38#	63-38#	63-38#	63-38#	63-38	63-38	63-38	63-38	63-38	63-38#
63-45	63-45#	63-45#	63-45#	63-45#	63-45#	63-45#	63-45#	63-45#	63-48	63-48	63-48	63-48	63-45	63-45
63-48	63-48	63-48#	63-48#	63-48#	63-48#	63-48#	63-48#	63-48#	63-48	63-48	63-48	63-48	63-48	63-48
63-73	63-73	63-73	63-73	63-73#	63-73#	63-73#	63-73#	63-73#	63-48	63-48	63-48	63-48	63-49	63-49#
63-80	63-80	63-80	63-80#	63-80#	63-80#	63-80#	63-80#	63-80#	63-73#	63-73#	63-73#	63-73#	63-74	63-74#
63-84#	63-84#	63-84#	63-91	63-91	63-91	63-91	63-91	63-91	63-84	63-84	63-84	63-84	63-74#	63-80
63-106	63-106	63-106	63-106	63-106	63-106	63-106	63-106	63-106	63-84	63-84	63-84	63-84	63-84	63-84#
63-106#	63-106#	63-106#	63-106#	63-106#	63-106#	63-106#	63-106#	63-106#	63-91#	63-91#	63-91#	63-91#	63-84#	63-84#
64-171	64-171	64-171#	64-171#	64-186	64-186#	65-75	65-75#	65-75#	63-106	63-106	63-106	63-106	63-103	63-103#
65-185	65-185#	66-4	66-4#	66-5	66-5	66-5	66-5	66-5	63-117	63-117#	64-83	64-83#	64-169	64-169#
66-7	66-7	66-7	66-7#	66-8	66-8	66-8	66-8	66-8	65-169	65-169#	65-171	65-171	65-171#	65-171#
66-10	66-10	66-10	66-10	66-10	66-10#	66-12	66-12	66-12	66-6	66-6	66-6	66-6	66-6#	66-7
66-26	66-26	66-26	66-26#	66-32	66-32	66-12	66-12#	66-12#	66-8	66-8	66-8	66-8	66-8#	66-9#
66-36	66-36	66-36	66-36	66-36	66-36#	66-32	66-32#	66-32#	66-23	66-23	66-23	66-23	66-23#	66-25#
66-39	66-39	66-39	66-39#	66-40	66-40	66-37	66-37	66-37	66-34	66-34	66-34	66-34	66-34#	66-35#
66-42	66-42#	66-44	66-44	66-44	66-44	66-40	66-40#	66-40#	66-37	66-37	66-37	66-37	66-37#	66-39
66-47	66-47	66-47	66-47#	66-49	66-49#	66-44	66-44#	66-44#	66-41	66-41	66-41	66-41	66-41#	66-42
M\$GNLS	51-67	51-67#	51-67#	51-67#	51-67#	66-46	66-46#	66-46#	66-46	66-46	66-46	66-46	66-46	66-46#
M\$GNSU	60-27	60-27#	62-67	62-67#	63-13	63-13#	64-83	64-83#	66-74	66-74	66-74#	66-74#	66-74#	66-74#
M\$GNIA	41-13	41-13#	41-27	41-27#	41-41	41-41#	41-56	41-56#	65-75	65-75#	41-186	41-186#	41-200	41-200#







	57-211#	57-211#	57-211#	57-211#	57-211#	57-211#	57-211#	57-211#	57-211#	57-211#	57-214	57-214	57-214	57-214
	57-214	57-214	57-214	57-214	57-214	57-214	57-214	57-214	57-214	57-214	57-214	57-214	57-214	57-226
	57-226	57-226	57-226	57-226	57-226	57-226	57-226	57-235	57-235	57-235	57-235	57-235	57-235	57-235
	57-236	57-236	57-236	57-236	57-236	57-236	57-236	57-236	57-239	57-239	57-239	57-239	57-239	57-239
	57-239	57-239	57-247	57-247	57-247	57-247	57-247	57-247	57-247	57-247	57-247	57-247	57-247	57-247
	57-250	57-250	57-250	57-250	57-250	57-250	57-250	57-250	57-250	57-250	57-250	57-250	57-250	57-250
	57-250	57-250	57-251	57-251	57-251	57-251	57-251	57-251	57-251	57-251	57-251	57-251	57-251	57-251
	57-251	57-251	57-252	57-252	57-252	57-252	57-252	57-252	57-252	57-252	57-252	57-252	57-252	57-252
	57-252	57-252	57-252	57-252	57-252	57-252	57-252	58-16	58-16	58-16	58-16	58-16	58-16	58-198
	58-198	58-198	58-198	58-198	58-198	58-198	58-198	58-199	58-199	58-199	58-199	58-199	58-199	58-199
	58-199	58-199	58-199	58-199	58-200	58-200	58-200	58-200	58-200	58-200	58-200	58-200	58-200	58-200
	58-200	58-200	58-201	58-201	58-201	58-201	58-201	58-201	58-201	58-201	58-201	58-201	58-201	58-201
	58-201	58-201	58-202	58-202	58-202	58-202	58-202	58-202	58-202	58-202	58-202	58-202	58-202	58-202
	58-202	58-202	58-203	58-203	58-203	58-203	58-203	58-203	58-203	58-203	58-203	58-203	58-203	58-203
	58-204	58-204	58-204	58-204	58-204	58-204	58-204	58-204	58-204	58-204	58-204	58-204	58-204	58-204
	58-205	58-205	58-205	58-205	58-205	58-205	58-205	58-205	58-205	58-205	58-205	58-205	58-205	58-205
	58-206	58-206	58-206	58-206	58-206	58-206	58-206	58-206	58-206	58-206	58-206	58-206	58-206	58-206
	61-86	61-86	61-86	61-86	61-12	61-12	61-12	61-12	61-12	61-12	61-12	61-12	61-12	61-86
	61-87	61-87	61-88	61-88	61-87	61-87	61-87	61-87	61-87	61-87	61-87	61-87	61-87	61-87
	61-88	61-88	63-38	63-38	61-88	61-88	61-88	61-88	61-88	61-88	61-88	61-88	61-88	61-88
	63-38	63-38	63-38	63-38	63-38	63-38	63-38	63-38	63-38	63-38	63-38	63-38	63-38	63-38
	63-48	63-48	63-48	63-48	63-45	63-45	63-45	63-45	63-45	63-45	63-45	63-45	63-45	63-48
	63-106	63-106	63-106	63-106	63-48	63-48	63-48	63-48	63-48	63-106	63-106	63-106	63-106	63-106
M#RADI	66-5	66-5	66-6	66-6	66-7	66-7	66-8	66-8	66-8	66-9	66-9	66-10	66-10	66-25
	66-26	66-26	66-32	66-32	66-34	66-34	66-36	66-36	66-36	66-37	66-37	66-39	66-39	66-25
	66-42	66-42	66-44	66-44	66-46	66-46	66-47	66-47	66-47	66-47	66-47	66-47	66-47	66-40
M#RNRO	43-9	43-9	43-70	43-70										
M#SETS	39-5	39-5	39-13	39-13	39-146	39-146	39-564	39-564	40-3	40-3	41-1	41-1	41-15	41-15
	41-29	41-29	41-43	41-43	41-58	41-58	41-73	41-73	41-188	41-188	41-202	41-202	41-224	41-224
	41-238	41-238	42-3	42-3	42-10	42-10	42-11	42-11	42-21	42-21	42-22	42-22	42-40	42-40
	43-3	43-3	43-4	43-4	44-10	44-10	45-3	45-3	45-4	45-4	45-20	45-20	46-3	46-3
	46-43	46-43	46-50	46-50	51-16	51-16	51-16	51-16	58-3	58-3	58-7	58-7	59-3	59-3
	60-3	60-3	60-27	60-27	61-3	61-3	62-3	62-3	62-67	62-67	63-3	63-3	63-13	63-13
	64-3	64-3	64-83	64-83	65-3	65-3	65-75	65-75	66-3	66-3	66-4	66-4	66-22	66-22
M#SVC	66-23	66-23												
	41-13	41-13	41-27	41-27	41-41	41-41	41-56	41-56	41-71	41-71	41-116	41-116	41-157	41-157
	41-171	41-171	41-180	41-180	41-186	41-186	41-200	41-200	41-222	41-222	41-236	41-236	41-244	41-244
	41-245	41-245	41-248	41-248	41-252	41-252	43-9	43-9	43-12	43-12	43-13	43-13	43-14	43-14
	43-19	43-19	43-24	43-24	43-46	43-46	43-49	43-49	43-53	43-53	43-70	43-70	43-104	43-104
	43-105	43-105	43-132	43-132	43-133	43-133	43-134	43-134	43-135	43-135	43-136	43-136	43-139	43-139
	44-12	44-12	44-18	44-18	44-19	44-19	44-21	44-21	44-23	44-23	44-31	44-31	44-33	44-33
	44-35	44-35	44-36	44-36	44-37	44-37	44-38	44-38	45-5	45-5	45-6	45-6	45-13	45-13
	45-17	45-17	45-18	45-18	45-19	45-19	45-22	45-22	46-9	46-9	46-29	46-29	47-6	47-6
	47-8	47-8	47-9	47-9	47-10	47-10	47-11	47-11	47-12	47-12	49-47	49-47	49-101	49-101
	50-87	50-93	51-16	51-16	51-18	51-18	51-42	51-60	51-67	51-67	52-24	52-35	53-19	53-19
	53-83	53-86	53-86	53-97	53-112	53-112	53-113	53-113	53-114	53-114	54-43	54-55	54-60	54-70
	55-29	55-42	55-49	55-114	55-124	55-129	55-191	55-244	55-250	56-28	56-28	56-43	57-59	57-75
	57-82	57-91	57-101	57-166	57-166	57-167	57-167	57-171	57-171	57-184	57-184	57-202	57-202	57-206
	57-206	57-211	57-211	57-214	57-214	57-226	57-226	57-235	57-235	57-236	57-236	57-239	57-239	57-247
	57-247	57-250	57-250	57-251	57-251	57-252	57-252	58-16	58-16	58-57	58-62	58-198	58-198	58-199
	58-199	58-200	58-200	58-201	58-201	58-202	58-202	58-203	58-203	58-204	58-204	58-205	58-205	58-206
	58-206	58-208	58-208	59-12	59-12	60-27	60-27	60-37	60-37	60-39	60-39	60-55	60-55	61-12
	61-12	61-14	61-14	61-46	61-51	61-68	61-73	61-86	61-86	61-87	61-87	61-88	61-88	61-90
	61-90	62-67	62-67	62-152	62-152	62-154	62-154	62-168	62-168	63-13	63-13	63-38	63-38	63-45
	63-45	63-48	63-48	63-49	63-49	63-73	63-74	63-74	63-80	63-84	63-91	63-103	63-103	63-106
	63-106	63-117	63-117	64-83	64-83	64-169	64-169	64-171	64-171	64-186	64-186	65-75	65-75	65-169

M\$TLAB	65-169#	65-171	65-171#	65-185	65-185#	41-116#	41-157#	41-171#	41-180#	41-186#	41-200#	41-222#	41-236#	41-244#
	41-13#	41-27#	41-41#	41-56#	41-71#	43-13#	43-14#	43-19#	43-24#	43-46#	43-49#	43-53#	43-70#	43-104#
	41-245#	41-248#	41-252#	43-9#	43-12#	43-13#	43-14#	43-19#	43-24#	43-46#	43-49#	43-53#	43-70#	43-104#
	43-105#	43-132#	43-133#	43-134#	43-135#	43-136#	43-139#	44-12#	44-18#	44-19#	44-21#	44-23#	44-31#	44-33#
	44-35#	44-36#	44-37#	44-38#	45-5#	45-6#	45-13#	45-17#	45-18#	45-19#	45-22#	46-9#	46-29#	47-6#
	47-8#	47-9#	47-10#	47-11#	47-12#	49-47#	49-86#	49-101#	49-109#	50-87#	50-93#	51-16#	51-18#	51-42#
	51-60#	51-67#	52-24#	52-35#	53-19#	53-83#	53-86#	53-97#	53-112#	53-113#	53-114#	54-43#	54-55#	54-60#
	54-70#	55-29#	55-42#	55-49#	55-114#	55-124#	55-129#	55-191#	55-244#	55-250#	56-28#	56-43#	57-59#	57-75#
	57-82#	57-91#	57-101#	57-166#	57-167#	57-171#	57-184#	57-202#	57-206#	57-211#	57-214#	57-226#	57-235#	57-236#
	57-239#	57-247#	57-250#	57-251#	57-252#	58-16#	58-57#	58-62#	58-198#	58-199#	58-200#	58-201#	58-202#	58-203#
	58-204#	58-205#	58-206#	58-208#	59-12#	60-27#	60-37#	60-39#	60-55#	61-12#	61-14#	61-46#	61-51#	61-68#
	61-73#	61-86#	61-87#	61-88#	61-90#	62-67#	62-152#	62-154#	62-168#	63-13#	63-38#	63-45#	63-48#	63-49#
	63-73#	63-74#	63-80#	63-84#	63-91#	63-103#	63-106#	63-117#	64-83#	64-169#	64-171#	64-186#	65-75#	65-169#
	65-171#	65-185#												
M\$TSTL	41-13	41-13#	41-27	41-27#	41-41	41-41#	41-56	41-56#	41-71	41-71#	41-116	41-116#	41-157	41-157#
	41-171	41-171#	41-180	41-180#	41-186	41-186#	41-200	41-200#	41-222	41-222#	41-236	41-236#	41-244	41-244#
	41-245	41-245#	41-248	41-248#	41-252	41-252#	43-9	43-9#	43-12	43-12#	43-13	43-13#	43-14	43-14#
	43-19	43-19#	43-24	43-24#	43-46	43-46#	43-49	43-49#	43-53	43-53#	43-70	43-70#	43-104	43-104#
	43-105	43-105#	43-132	43-132#	43-133	43-133#	43-134	43-134#	43-135	43-135#	43-136	43-136#	43-139	43-139#
	44-12	44-12#	44-18	44-18#	44-19	44-19#	44-21	44-21#	44-23	44-23#	44-31	44-31#	44-33	44-33#
	44-35	44-35#	44-36	44-36#	44-37	44-37#	44-38	44-38#	45-5	45-5#	45-6	45-6#	45-13	45-13#
	45-17	45-17#	45-18	45-18#	45-19	45-19#	45-22	45-22#	46-9	46-9#	46-29	46-29#	47-6	47-6#
	47-8	47-8#	47-9	47-9#	47-10	47-10#	47-11	47-11#	47-12	47-12#	49-47	49-47#	49-47#	49-86
	49-86#	49-86#	49-101	49-101#	49-101#	49-109	49-109#	49-109#	50-87	50-87#	50-87#	50-93	50-93#	50-93#
	51-16	51-16#	51-18	51-18#	51-42	51-42#	51-42#	51-60	51-60#	51-60#	51-67	51-67#	52-24	52-24#
	52-24#	52-35	52-35#	52-35#	53-19	53-19#	53-83	53-83#	53-83#	53-86	53-86#	53-97	53-97#	53-97#
	53-112	53-112#	53-113	53-113#	53-114	53-114#	54-43	54-43#	54-43#	54-55	54-55#	54-55#	54-60	54-60#
	54-60#	54-70	54-70#	54-70#	55-29	55-29#	55-29#	55-42	55-42#	55-42#	55-49	55-49#	55-49#	55-114
	55-114#	55-114#	55-124	55-124#	55-124#	55-129	55-129#	55-129#	55-191	55-191#	55-191#	55-244	55-244#	55-244#
	55-250	55-250#	55-250#	56-28	56-28#	56-43	56-43#	56-43#	57-59	57-59#	57-59#	57-75	57-75#	57-75#
	57-82	57-82#	57-82#	57-91	57-91#	57-91#	57-101	57-101#	57-101#	57-166	57-166#	57-167	57-167#	57-171
	57-171#	57-184	57-184#	57-202	57-202#	57-206	57-206#	57-211	57-211#	57-214	57-214#	57-226	57-226#	57-235
	57-235#	57-236	57-236#	57-239	57-239#	57-247	57-247#	57-250	57-250#	57-251	57-251#	57-252	57-252#	58-16
	58-16#	58-57	58-57#	58-57#	58-62	58-62#	58-62#	58-198	58-198#	58-199	58-199#	58-200	58-200#	58-201
	58-201#	58-202	58-202#	58-203	58-203#	58-204	58-204#	58-205	58-205#	58-206	58-206#	58-208	58-208#	59-12
	59-12#	60-27	60-27#	60-37	60-37#	60-39	60-39#	60-55	60-55#	61-12	61-12#	61-14	61-14#	61-46
	61-46#	61-46#	61-51	61-51#	61-51#	61-68	61-68#	61-68#	61-73	61-73#	61-73#	61-86	61-86#	61-87
	61-87#	61-88	61-88#	61-90	61-90#	62-67	62-67#	62-152	62-152#	62-154	62-154#	62-168	62-168#	63-13
	63-13#	63-38	63-38#	63-45	63-45#	63-48	63-48#	63-49	63-49#	63-73	63-73#	63-73#	63-74	63-74#
	63-80	63-80#	63-80#	63-84	63-84#	63-84#	63-91	63-91#	63-91#	63-103	63-103#	63-106	63-106#	63-117
	63-117#	64-83	64-83#	64-169	64-169#	64-171	64-171#	64-186	64-186#	65-75	65-75#	65-169	65-169#	65-171
	65-171#	65-185	65-185#											
M\$WORD	39-6	39-6#	42-45	42-45	42-45	42-45	42-45	42-45	42-45	42-45	42-45	42-45#	49-47	49-47
	49-47	49-47#	49-86	49-86	49-86	49-86#	49-101	49-101	49-101	49-101#	49-109	49-109	49-109	49-109#
	50-87	50-87	50-87	50-87#	50-93	50-93	50-93	50-93#	51-42	51-42	51-42	51-42#	51-60	51-60#
	51-60	51-60#	52-24	52-24	52-24	52-24#	52-35	52-35	52-35	52-35#	53-83	53-83	53-83	53-83#
	53-97	53-97	53-97	53-97#	54-43	54-43	54-43	54-43#	54-55	54-55	54-55	54-55#	54-60	54-60#
	54-60	54-60#	54-70	54-70	54-70	54-70#	55-29	55-29	55-29	55-29#	55-42	55-42	55-42	55-42#
	55-49	55-49	55-49	55-49#	55-114	55-114	55-114	55-114#	55-124	55-124	55-124	55-124#	55-129	55-129#
	55-129	55-129#	55-191	55-191	55-191	55-191#	55-244	55-244	55-244	55-244#	55-250	55-250	55-250	55-250#
	56-43	56-43	56-43	56-43#	57-59	57-59	57-59	57-59#	57-75	57-75	57-75	57-75#	57-82	57-82#
	57-82	57-82#	57-91	57-91	57-91	57-91#	57-101	57-101	57-101	57-101#	58-57	58-57	58-57	58-57#
	58-62	58-62	58-62	58-62#	61-14#	61-46	61-46	61-46#	61-46#	61-46#	61-51	61-51	61-51#	61-68
	61-68	61-68	61-68#	61-73	61-73	61-73	61-73#	63-49#	63-73	63-73	63-73	63-73#	63-74#	63-80
	63-80	63-80	63-80#	63-84	63-84	63-84	63-84#	63-91	63-91	63-91	63-91#	66-5	66-5#	66-6
	66-6#	66-7	66-7#	66-8	66-8#	66-9	66-9#	66-10	66-10#	66-25	66-25#	66-26	66-26#	66-32

