

# RM03,02

PERFORMANCE EXERCISER  
CZRMBB0

AH-995B-MC

JAN 1978

COPYRIGHT © 1977

**digital**

FICHE 1 OF 2

MADE IN USA

This image shows a microfiche card with a grid of 14 columns and 20 rows of frames. Each frame contains a small, illegible image of a document page, likely a performance exerciser. The frames are arranged in a regular grid pattern across the card.

# RM03,02

PERFORMANCE EXERCISER  
CZRMBB0

AH-995B-MC

COPYRIGHT © 1977

FICHE 2 OF 2

JAN 1978

**digital**

MADE IN USA





103  
104  
105  
106  
107  
108  
109  
110  
111  
112  
113  
114  
115  
116  
117  
118  
119  
120  
121

- 6.3 SECTOR REFORMATTING
- 6.4 BAD TRACK/SECTOR FLAGGING
- 7. ERROR MESSAGES
  - 7.1 ERROR DESCRIPTION LINES
  - 7.2 DETAIL ERROR LINES
- 8. PROGRAM DESCRIPTION
  - 8.1 HOW THE PROGRAM OPERATES
  - 8.2 DUAL PORT OPERATION
  - 8.3 HOW VARIABLES ARE SELECTED FOR EACH OPERATION
  - 8.4 DATA PATTERNS
- 9. RMO3 SOFTWARE DRIVER DOCUMENT

## 1. ABSTRACT

THE RMO3 PERFORMANCE EXERCISER PROGRAM IS DESIGNED TO PERFORM AN INTERACTIVE TEST ON RMO3 DISK DRIVES CONNECTED TO A MASSBUS SUBSYSTEM. THE DRIVES MAY BE CONTROLLED BY EITHER AN RH11 OR AN RH70. IN ADDITION TO PERFORMING AN INTERACTIVE TEST OF THE DISK DRIVES ON THE SUBSYSTEM, THE PROGRAM IS INTENDED TO BE USED TO VERIFY THAT THE DRIVES UNDER TEST ARE PERFORMING TO THEIR DATA ERROR RATE AND SEEK ERROR RATE (SEE ERROR RATE SPECIFICATIONS).

THE RMO3 PERFORMANCE EXERCISER PROGRAM WILL EXERCISE DRIVES CONNECTED AS EITHER SINGLE OR DUAL PORT UNITS. DUAL PORT DRIVES ARE TESTED BY LOADING AND RUNNING THE PROGRAM FROM BOTH CONTROLLING SYSTEMS. THE PROGRAM WILL EXERCISE A MIXED SYSTEM OF DUAL PORT AND SINGLE PORT DRIVES.

TO OBTAIN INTERACTIVE TESTING, OPERATIONS ON THE DRIVES ARE OVERLAPPED (OTHER DRIVES ARE PERFORMING SEEK/SEARCH OPERATIONS WHILE ONE DRIVE IS PERFORMING A DATA TRANSFER OR WRITE CHECK OPERATION). OPERATIONS AMONG THE DRIVES ARE OPTIMIZED SO THAT A HIGH SUBSYSTEM DATA TRANSFER RATE OR A HIGH POSITIONING OPERATION RATE IS MAINTAINED.

THE PERFORMANCE OF EACH DRIVE IS MONITORED BY THE PROGRAM. IF A DRIVE EXCEEDS A PRESET NUMBER OF ERRORS IN ANY OF SEVERAL CATEGORIES, THAT DRIVE IS AUTOMATICALLY DEASSIGNED. (THE OPERATOR MAY OVERRIDE THE AUTOMATIC DEASSIGNMENT FEATURE.) THE PROGRAM REPORTS PERFORMANCE STATISTICS FOR EACH DRIVE BEING EXERCISED ON REQUEST FROM THE OPERATOR OR AUTOMATICALLY AT AN INTERVAL DETERMINED BY THE OPERATOR.

ALL DATA TRANSFER COMMANDS ARE USED (I.E., WRITE DATA, WRITE HEADER & DATA, READ DATA, AND READ HEADER & DATA) AS WELL AS WRITE CHECK DATA AND WRITE CHECK HEADER & DATA COMMANDS. RECALIBRATE AND READ-IN PRESET COMMANDS ARE USED AT STARTUP AND DRIVE INITIALIZATION. RECALIBRATE, OFFSET, AND RETURN-TO-CENTERLINE COMMANDS ARE USED DURING ERROR RECOVERY.

THE DATA TRANSFER COMMANDS ARE SELECTED RANDOMLY EXCEPT FOR THE WRITE CHECK COMMANDS. THE WRITE CHECK COMMANDS ARE USED TO VERIFY A PREVIOUS WRITE OPERATION. THUS, WHEN A WRITE COMMAND IS SELECTED, THE DATA WRITTEN IS VERIFIED BY THE APPROPRIATE WRITE CHECK COMMAND.

DEPENDING UPON WHETHER PROGRAM HAS BEEN LOADED VIA APT AUTOMATIC MODE OR APT DUMP MODE WILL DETERMINE WHETHER PROGRAM/OPERATOR COMMUNICATIONS ARE THROUGH THE KEYBOARD. DYNAMIC PROGRAM OPTIONS ARE SELECTED VIA SWITCH REGISTER SETTINGS AND ERRORS ARE REPORTED ON THE TELETYPE.

ALL COMMANDS, DATA PATTERNS, AND DATA BUFFER SIZES ARE SELECTED RANDOMLY BY THE PROGRAM. ADDITIONALLY THE ADDRESSES (EG, CYLINDER, TRACK, AND SECTOR) FOR EACH OPERATION ARE SELECTED RANDOMLY.

122  
123  
124  
125  
126  
127  
128  
129  
130  
131  
132  
133  
134  
135  
136  
137  
138  
139  
140  
141  
142  
143  
144  
145  
146  
147  
148  
149  
150  
151  
152  
153  
154  
155  
156  
157  
158  
159  
160  
161  
162  
163  
164  
165  
166  
167  
168  
169  
170  
171  
172  
173  
174  
175

176  
177  
178  
179  
180  
181  
182  
183  
184  
185  
186  
187  
188  
189  
190  
191  
192  
193  
194  
195  
196  
197  
198  
199  
200  
201  
202  
203  
204  
205  
206  
207  
208  
209  
210  
211  
212  
213  
214  
215

2. REQUIREMENTS  
-----

2.1 EQUIPMENT

REQUIRED  
-----

PDP-11 PROCESSOR  
16K MEMORY (20K IF THE PROGRAM IS INCLUDED IN AN 'XXDP' CHAIN  
TELETYPE  
PROGRAM LOADING DEVICE  
KW11-L OR KW11-P CLOCK  
RH11 OR RH70 WITH 1 RM03 DISK DRIVE

OPTIONAL  
-----

ADDITIONAL MEMORY TO A MAXIMUM OF 28K  
1 TO 7 ADDITIONAL RM03'S ON THE SAME RH11 OR RH70

2.2 MEDIA

THE RM03 PERFORMANCE EXERCISER PROGRAM REQUIRES FORMATTED DISK  
PACKS GENERATED BY THE RM03, RM02 FORMATTER PROGRAM (CZRMAC0).  
THE PACKS MUST BE FORMATTED IN 32 SECTOR (16 BIT) MODE; THE  
ALTERNATE (30 SECTOR - 18 BIT ) MODE IS NOT SUPPORTED.

2.3 PRELIMINARY PROGRAMS

RM03 DISKLESS DIAGNOSTIC  
RM03 FUNCTIONAL TEST

16  
17  
18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57  
58  
59  
60  
61  
62  
63  
64  
65  
66  
67  
68  
69  
70  
71

3. OPERATING THE PROGRAM  
-----

3.1 THE PROGRAM MAY BE LOADED FROM PAPER TAPE USING THE ABSOLUTE LOADER OR IT MAY BE LOADED FROM THE APPROPRIATE 'XXDP' MEDIA USING THE ASSOCIATED LOADER. THE PROGRAM MAY BE INCLUDED IN AN 'XXDP' CHAIN. IF THE PROGRAM IS BEING RUN ON A PROCESSOR WITH 16K, THE 'XXDP' LOADER WILL NOT BE PRESERVED. THE PROGRAM MUST BE RUN ON A SYSTEM WITH 20K OR MORE TO PRESERVE THE 'XXDP' LOADER. THE 'ABSOLUTE' LOADER WILL BE PRESERVED IN A 16K SYSTEM, HOWEVER.

3.2 THE PROGRAM STARTS AT LOCATION 200(8). PARAMETERS NOT INCLUDED IN THE TELETYPE DIAGLOGUE GROUP MUST BE CHANGED BEFORE THE PROGRAM IS STARTED. THE PROGRAM PERFORMS "TEST" OPERATION TO ALL DRIVES UNDER TESTING AT THE 200(8) STARTING LOCATION AUTOMATICALLY.

3.3 START THE PROGRAM AT LOCATION 204(8) IF THE RH11 OR THE RH70 IS NOT AT ADDRESS 176700.

3.4 PROVIDED THE PROGRAM HAS BEEN LOADED AND STARTED VIA THE APT DUMP MODE OR THE DIAGNOSTIC IS RUNNING IN STAND ALONE PROCESSOR/DRIVE OPERATIONS ARE INITIATED AND CONTROLLED BY KEYBOARD COMMANDS AND SWITCH REGISTER SWITCH SETTINGS. IF THIS IS THE PROGRAM'S FIRST START, THE STATUS OF THE DRIVES ON THE SELECTED MASSBUS SUBSYSTEM WILL BE TYPED OUT. ON SUBSEQUENT STARTS, THIS TYPEOUT MAY BE INHIBITED BY SETTING SW<02>= 1.

HOWEVER, IF THE PROGRAM IS LOADED VIA APT SCRIPT MODE ALL SETUP AND SWITCH REGISTER SETTINGS WILL BE PROVIDED THROUGH THE APT E TABLE. TYPEOUTS FROM THE USER DIAGNOSTIC MAY OR MAYNOT BE INHIBITED DEPENDING UPON WHETHER OR NOT THE APPROPRIATE BIT IN THE E TABLE HAS BEEN SET.

3.5 PASS/TEST TERMINATION

A PASS IS DETERMINED BY EITHER BITS READ OR SEEKS PERFORMED. THE NUMBER OF BITS OR SEEKS REQUIRED FOR A PASS IS DERIVED FROM EITHER THE SOFT ERROR RATE SPECIFICATION OR THE SEEK ERROR RATE SPECIFICATION. THE SPECIFICATIONS FOR THE RMO3'S SPECIFY NO MORE THAN 1 SOFT ERROR (NON-PACK RELATED) IN  $1 \times 10^{19}$  BITS READ OR NO MORE THAN 1 SEEK ERROR IN  $1 \times 10^{16}$  SEEKS. THE NUMBER OF BITS OR SEEKS DETERMINING A PASS WERE SELECTED TO PROVIDE A 90% CONFIDENCE LEVEL THAT THE DRIVE IS PERFORMING TO THE APPLICABLE SPECIFICATION.

3.5.1 PASS TERMINATION

END OF PASS FOR A SINGLE DRIVE MAY BE DETERMINED BY EITHER OF THE FOLLOWING CONDITIONS. THE END OF PASS CONDITION USED IS DETERMINED BY PARAMETER 'ENDING'.

A. IF PARAMETER 'ENDING' IS 1, END OF PASS OCCURS WHEN THE DRIVE HAS READ  $1.875 \times 10^{18}$  WORDS ( $3 \times 10^{19}$  BITS).



272  
273  
274  
275  
276  
277  
278  
279  
280  
281  
282  
283  
284  
285  
286  
287  
288  
289  
290  
291  
292  
293  
294  
295  
296  
297  
298  
299  
300  
301  
302  
303  
304  
305  
306  
307  
308  
309  
310  
311  
312  
313  
314  
315  
316  
317  
318  
319  
320  
321  
322  
323  
324  
325  
326  
327

B. IF PARAMETER 'ENDING' IS 0, END OF PASS OCCURS WHEN THE DRIVE HAS PERFORMED 3 X 10<sup>16</sup> SEEKS.

3.5.2 TEST TERMINATION

THE TEST FOR A DRIVE IS TERMINATED (SW<04> = 0) WHEN:

- A. THE DRIVE HAS COMPLETED THE NUMBER OF PASSES SPECIFIED IN PARAMETER 'PASSES'.
- B. THE TOTAL ERRORS ACCUMULATED EXCEED 100.
- C. A FATAL ERROR OCCURS: EM12 OR EM14.
- D. OPERATOR DEASSIGNS THE DRIVE

3.6 RUN TIME

THE EXERCISER PROGRAM MAY BE RUN IN TWO MODES. THE MODE IS DETERMINED BY THE VALUE IN PARAMETER 'SIZE'. IF 'SIZE' IS ONE SECTOR, THE PROGRAM RUNS IN A SEEK HEAVY MODE; IF 'SIZE' APPROACHES 1/2 TRACK IN SIZE (4096 DECIMAL) THE PROGRAM RUNS IN A DATA TRANSFER HEAVY MODE. THE PROGRAM RUN TIME VARIES GREATLY DEPENDING ON THE OPERATION MODE SELECTED, THE MEMORY AVAILABLE OVER 16K, THE READ/WRITE RATIO PARAMETER - 'RATIO', AND BY SWITCHES 0, 1, & 2.

3.6.1 DATA TRANSFER MODE

- 1 DRIVE - APPROXIMATELY 3.6 HRS (TO REACH 1.875 X 10<sup>18</sup> WORDS)
- TO
- 8 DRIVES - APPROXIMATELY 16 HRS (FOR ALL DRIVES TO REACH 1.875 X 10<sup>18</sup> WORDS)

IF THE PROGRAM IS RUN WITH BOTH SW<00> AND SW<01> SET, THE RUN TIMES SHOULD BE ABOUT 20% FASTER.

3.6.2 SEEK VERIFICATION MODE

PARAMETER 'SIZE' = 1 SECTOR (256 WORDS)  
PARAMETER 'MAXTRK' = 'MINTRK'  
PARAMETER 'MAXSEC' = 'MINSEC'  
SW<00> = 1 (READ ONLY MODE)

- 1 DRIVE - APPROXIMATELY 25 HRS (3 X 10<sup>16</sup> SEEKS)
- TO
- 8 DRIVES - APPROXIMATELY 40 HRS (3 X 10<sup>16</sup> SEEKS FOR ALL DRIVES)

3.7 UNIBUS & VECTOR ADDRESSES

THE PROGRAM ASSUMES THE FOLLOWING UNIBUS AND VECTOR ADDRESSES. (REFER TO SECTION 4.2.2 FOR THE LOCATIONS AT WHICH TO CHANGE THESE ADDRESSES.)

UNIT	UNIBUS ADDRESS	VECTOR ADDRESS
----	-----	-----
RH11 OR RH70	176700	254
TTY PRINTER	177564	NOT USED

TTY KEYBOARD	177560	60
KW11-L	177546	100
KW11-P	172542	104

3.8 DUAL PORT OPERATION

- A. LOAD THE RMO3 PERFORMANCE EXERCISER PROGRAM INTO BOTH PROCESSORS.
- B. SWITCH THE 'CONTROLLER SELECT' SWITCH TO 'A/B' ON EACH DRIVE WHICH IS TO BE TESTED AS A DUAL PORT DRIVE; CYCLE THE DRIVES UP.
- C. START THE PROGRAM IN EACH PROCESSOR. RUN THE PROGRAM AS THOUGH EACH PROCESSOR WERE RUNNING INDEPENDENTLY OF THE OTHER.

3.9 APT

THIS PROGRAM IS APT COMPATIBLE TO THE EXTENT THAT APT HOOKS WILL BE IN THE PROGRAM AND WILL WORK THRU THE 'OPTION INTERFACE'.

FOR OTHER INTERFACES, APT MAY ONLY LOAD AND START THE PROGRAM. I.E. LOAD AND DUMP MODE.

AUTOMATIC MODE (MONITOR)

- 1. THE INPUT DIALOGUE IS BYPASSED.
  - 2. THE BUSS ADDRESS AND CONTROLLER INTERRUPT VECTOR IS DEFAULTED.
- DUMP MODE: INPUT DIALOGUE AFTER PROGRAM STARTS

3.10 APT ETABLE DEFINITIONS

THE FOLLOWING DEFINITIONS ARE VALID FOR SPECIFYING APT ENVIRONMENTAL TABLE (ETABLE) ENTRIES, VIA RUNNING THE APT UTILITY PROGRAM "TSP":

- 1. SOFTWARE ENVIRONMENT:
  - = 1 IF APT SCRIPT MODE
  - = 0 IF STANDLONE MODE
- 2. ENVIRONMENT MODE:
  - BIT 7 = 1 ETABLE DOES SIZING
  - = 0 PROGRAM DOES SIZING
  - BIT 6 = 1 SPOOL MESSAGES TO APT IF SCRIPT MODE
  - = 0 DON'T SPOOL TO APT
  - BIT 5 = 1 SUPPRESS CONSOLE OUTPUT
  - = 0 ALLOW CONSOLE OUTPUT
  - BIT 4 TO BIT 0 ARE NOT USED

328  
329  
330  
331  
332  
333  
334  
335  
336  
337  
338  
339  
340  
341  
342  
343  
344  
345  
346  
347  
348  
349  
350  
351  
352  
353  
354  
355  
356  
357  
358  
359  
360  
361  
362  
363  
364  
365  
366  
367  
368  
369  
370  
371  
372  
373  
374  
375  
376  
377  
378  
379  
380  
381  
382  
383

384  
385  
386  
387  
388  
389  
390  
391  
392  
393  
394  
395  
396  
397  
398  
399  
400  
401  
402  
403  
404  
405  
406  
407  
408  
409  
410  
411  
412  
413  
414  
415  
416  
417  
418  
419  
420  
421  
422  
423  
424  
425  
426  
427  
428  
429  
430  
431  
432  
433  
434  
435  
436  
437  
438  
439  
440  
441  
442  
443  
444  
445  
446  
447  
448  
449  
450  
451  
452  
453  
454  
455  
456  
457  
458  
459  
460  
461  
462  
463  
464  
465  
466  
467  
468  
469  
470  
471  
472  
473  
474  
475  
476  
477  
478  
479  
480  
481  
482  
483  
484  
485  
486  
487  
488  
489  
490  
491  
492  
493  
494  
495  
496  
497  
498  
499  
500

- 3. SWITCH 1 (SOFTWARE SWITCH REGISTER)  
IF ENVIRONMENT MODE BIT 7 (SIZING BIT ) IS SET TO 1,  
THE SOFTWARE SWITCH REGISTER WILL BE USED, INSTEAD  
OF THE HARDWARE CONSOLE SWITCH REGISTER.
- 4. SWITCH 2 (USER SWITCH REGISTER)  
NOT USED
- 5. CPU OPTIONS  
NOT USED
- 6. MEMORY TYPES 1-4 AND MAX MEMORY ADDRESSES  
NOT USED
- 7. INTERRUPT VECTOR 1:  
USED WHEN ENVIRONMENT MODE BIT 7 = 1;DEFAULT = 254
- 8. BUS PRIORITY 1:  
NOT USED.
- 9. INTERRUPT VECTOR 2:  
NOT USED
- 10. BUS PRIORITY 2:  
NOT USED
- 11. BASE ADDRESS:  
USED WHEN ENVIRONMENT MODE BIT 7 = 1;DEFAULT = 176700
- 12. DEVICE MAP:  
NOT USED
- 13. CONTROLLER DESCRIPTOR WORDS:  
NOT USED
- 14. CONTROLLER DESCRIPTOR WORDS:  
NOT USED

4. CONTROLLING THE PROGRAM  
-----

THE FOLLOWING KEYBOARD CONVENTIONS ARE USED BY THE KEYBOARD ENTRY ROUTINES IN THE PROGRAM:

- A. TO DELETE AN INCORRECT CHARACTER FROM AN ENTRY STRING, TYPE A 'RUBOUT' ('RO'). TYPING A 'RO' WILL DELETE SUCESSIVE CHARACTERS FROM THE INPUT.
- B. TO DELETE AN ENTIRE LINE, TYPE A 'CONTROL U' ('↑U').
- C. AN ENTRY MUST BE TERMINATED BY EITHER A 'CARRIAGE RETURN' OR A 'PERIOD'. THE 'PERIOD' TERMINATION IS RECOGNIZED BY THE PROGRAM AS A DEFAULT ENTRY REQUEST. WHEN A LINE IS TERMINATED BY A 'PERIOD' INSTEAD OF A 'CARRIAGE RETURN', THE PROGRAM WILL ACCEPT THE ENTERED VALUE AND WILL DEFAULT TO THE PRELOADED VALUES FOR ANY REMAINING ENTRIES.
- D. IF A 'CONTROL C' IS TYPED DURING KEYBOARD ENTRY, THE PROGRAM WILL RETURN TO THE BEGINNING OF THE GROUP BEING ENTERED.

## 4.1 DATE &amp; OPERATOR IDENTIFICATION

ASSUMING THE DIAGNOSTIC HAS BEEN LOADED BY ANY OTHER MODE OTHER THAN THE APT SCRIPT MODE THE PROGRAM WHEN IT IS INITIALLY STARTED, WILL ASK FOR DATE AND OPERATOR I.D. ENTRIES. (THE REQUEST FOR THESE ENTRIES OCCURS ONLY WHEN THE PROGRAM IS FIRST STARTED AND WILL NOT APPEAR WHEN THE PROGRAM IS RESTARTED.) THESE ENTRIES ARE OPTIONAL AND MAY BE BYPASSED BY ENTERING A 'CARRIAGE RETURN' IN RESPONSE TO THE REQUEST. THE PROGRAM DOES NOT EDIT OR CHECK EITHER ENTRY. UP TO 8 CHARACTERS OF DATE INFORMATION AND UP TO 6 CHARACTERS OF OPERATOR IDENTIFICATION MAY BE ENTERED. BOTH THE DATE AND THE OPERATOR I.D. WILL BE TYPED WHEN THE 'SA' COMMAND IS PREFORMED (SEE SECTION 4.4.3).

## 4.2 PARAMETERS

WHEN THE PROGRAM IS STARTED FROM LOCATION 204, THE OPERATOR WILL BE ASKED TO ENTER PARAMETERS. THE FOLLOWING MESSAGE WILL BE DISPLAYED:

## ENTER PARAMETERS:

THE OPERATOR MUST ENTER A 'Y' TERMINATED BY A CARRIAGE RETURN <CR> IF PARAMETER ENTRIES ARE TO BE MADE. ANY OTHER CHARACTER IS ACCEPTED AS A 'NO' ENTRY. THE PROGRAM WILL IDENTIFY THE PARAMETER BY THE NAME GIVEN BELOW, DISPLAY THE CURRENT VALUE OF THE PARAMETER AND WAIT FOR THE ENTRY. THE PROGRAM WILL TYPE 'INVALID ENTRY' IF THE ENTRY IS NOT CORRECT AND WAIT FOR A CORRECT ENTRY TO BE TYPED.

NOTE: WHEN THE DIAGNOSTIC IS LOADED VIA APT SCRIPT MODE ALL PARAMETERS ARE LOADED FROM THE APT SYSTEM E TABLE. THIS INCLUDES THE SOFTWARE SWITCH REGISTER. THEREFORE A WORST CASE CONDITION WILL BE SET IN THE E TABLE FOR NORMAL AUTOMATIC OPERATION.

425  
426  
427  
428  
429  
430  
431  
432  
433  
434  
435  
436  
437  
438  
439  
440  
441  
442  
443  
444  
445  
446  
447  
448  
449  
450  
451  
452  
453  
454  
455  
456  
457  
458  
459  
460  
461  
462  
463  
464  
465  
466  
467  
468  
469  
470  
471  
472  
473  
474  
475  
476  
477  
478  
479  
480

4.2.1 KEYBOARD ENTRY PARAMETERS

NAME	BASE	DEFAULT VALUE	VALUE RANGE	FUNCTION
SIZE	10	(SEE NOTE)		CONTROLS THE MAXIMUM BUFFER SIZE USED FOR DATA TRANSFERS
PASSES	10	1	1 - 999	NUMBER OF PASSES TO END OF TEST.
MINUTE	10	5	0 - 256	DETERMINES THE INTERVAL (IN MINUTES) BETWEEN AUTOMATIC PERFORMANCE SUMMARY TYPEOUTS
RANDOM	8	000000	0 OR 1	ERRORS PRINTED OUT IF SW<07>=0 IF PARAMETER = 0, THE DATA TRANSFER WORD COUNT IS RANDOMLY SELECTED BETWEEN 4 AND THE VALUE IN 'SIZE'. IF PARAMETER = 1, THE DATA TRANSFER WORD COUNT WILL BE THE VALUE IN 'MAXDL'
ENDING	8	000001	0 OR 1	IF PARAMETER = 1, END OF PASS DETERMINED BY THE 'WORDS READ' COUNT. IF PARAMETER = 0, END OF PASS IS DETERMINED BY THE NUMBER OF SEKS.
FORMAT	8	000001	0 OR 1	IF PARAMETER = 0: DO NOT PERFORM WRITE HEADER & DATA ORDERS; IF PARAMETER > 0 PERFORM WRITE HEADER & DATA ORDERS
RATIO	8	000003	0 - 7	CONTROLS THE APPROXIMATE RATIO OF READ TO WRITE ORDERS.
				VALUE R/W RATIO
				0 15/1
				1 7/1
				2 6/2
				3 5/3
				4 4/4
				5 3/5
				6 2/6
				7 1/7
MESSAGE	8	000001	0 OR 1	IF PARAMETER = 1, DO NOT PRINT ERROR MESSAGES FOR DATA ERRORS OCCURING AT LOCATIONS DEFINED BY THE OPERATOR AS BAD PACK LOCATION. IF PARAMETER = 0, PRINT ERROR MESSAGES ASSOCIATED WITH BAD PACK LOCATIONS.

481  
482  
483  
484  
485  
486  
487  
488  
489  
490  
491  
492  
493  
494  
495  
496  
497  
498  
499  
500  
501  
502  
503  
504  
505  
506  
507  
508  
509  
510  
511  
512  
513  
514  
515  
516  
517  
518  
519  
520  
521  
522  
523  
524  
525  
526  
527  
528  
529  
530  
531  
532  
533  
534  
535  
536

537  
538  
539  
540  
541  
542  
543  
544  
545  
546  
547  
548  
549  
550  
551  
552  
553  
554  
555  
556  
557  
558  
559  
560  
561  
562  
563  
564  
565  
566  
567  
568  
569  
570  
571  
572  
573  
574  
575  
576  
577  
578  
579  
580  
581  
582  
583  
584  
585  
586  
587  
588  
589  
590  
591  
592

PATTERN 10 00000 0 - 15

IF PARAMETER=0, DATA  
 PATTERN IS RANDOMLY  
 SELECTED.  
 IF PARAMETER>0, SPECIFIES  
 ONE OF THE 15 PATTERNS.  
 THE SELECTED DATA PATTERN  
 IS POINTED BY THE PARAMETER  
 "PATTERN".  
 IF PARAMETER=0, RANDOM  
 DATA BLOCK ADDRESS IS  
 USED IN "TEST" COMMAND  
 IF PARAMETER=1, SEQUENTIAL  
 DATA BLOCK IS USED IN  
 "TEST" COMMAND.

HEADER 8 00001 0 OR 1

NOTE: THE PROGRAM WILL SELECT A MAXIMUM BUFFER SIZE WHICH  
 IS DETERMINED BY THE MEMORY AVAILABLE. THE MAXIMUM BUFFER  
 SIZE ASSIGNED BY THE PROGRAM IS 8192 (10) WORDS. THE  
 OPERATOR MAY SPECIFY ANY OTHER MAXIMUM SIZE AS LONG AS THE  
 VALUE SPECIFIED IS AT LEAST 4 WORDS BUT NO LARGER THAN  
 THE INITIAL VALUE OF 'MAXDL' DETERMINED BY THE PROGRAM.

4.2.2 PERIPHERAL ADDRESSES AND OTHER LOCATIONS OF INTEREST

TO ALTER THESE LOCATIONS, THE OPERATOR MUST MAKE MANUAL ENTRIES  
 BEFORE THE PROGRAM IS STARTED. THE KEYBOARD ENTRY ROUTINE DOES  
 NOT PROVIDE ACCESS TO THESE LOCATIONS.

LOC	TAG	CONTENTS	FUNCTION
---	---	-----	-----
1160	\$TKS	177560	TTY KEYBOARD STATUS REGISTER
1162	\$TKB	177562	TTY KEYBOARD BUFFER REGISTER
1164	\$TPS	177564	TTY PRINTER STATUS REGISTER
1166	\$TPB	177566	TTY PRINTER BUFFER REGISTER
1274	\$LKCSR	172540	ADDRESS OF KW11-P STATUS REGISTER
1276	\$LKCSB	172542	ADDRESS OF KW11-P COUNTER BUFFER
1300	\$LPVEC	104	KW11-P VECTOR ADDRESS
1302	\$LKS	177546	ADDRESS OF KW11-L STATUS REGISTER
1304	\$LLVEC	100	KW11-L VECTOR ADDRESS
1312	HZ	74	74 (60 DECIMAL) IF SYSTEM IS 60 HZ; 62 (50 DECIMAL) IF SYSTEM IS 50 HZ.

THE RH11-RH70 ADDRESS AND VECTOR MAY BE CHANGED WHEN THE PROGRAM  
 IS STARTED FROM LOCATION 204(B) OR IF THE PROGRAM DOES NOT RECEIVE  
 A RESPONSE WHEN IT ACCESSES THE DEFAULT RH11-RH70 ADDRESS.

4.2.3 PARAMETERS FOR THE FIRST OPERATION

THE FOLLOWING PARAMETERS ARE USED FOR THE INITIAL OPERATION (IN  
 ADDITION TO THE 'MINIMUM' ADDRESS VALUES).

593  
594  
595  
596  
597  
598  
599  
600  
601  
602  
603  
604  
605  
606  
607  
608  
609  
610  
611  
612  
613  
614  
615  
616  
617  
618  
619  
620  
621  
622  
623  
624  
625  
626  
627  
628  
629  
630  
631  
632  
633  
634  
635  
636  
637  
638  
639  
640  
641  
642  
643  
644  
645  
646  
647  
648

LOC	TAG	INITIAL VALUE	VALUE RANGE	FUNCTION
1514	BEGPAT	10	1 - 15	THE CODE FOR THE STARTING PATTERN. (IF A WRITE ORDER OR A WRITE CHECK ORDER IS SPECIFIED IN 'BEGCOD')
1516	BEGCOD	5	0 - 5	THE INITIAL COMMAND FOR EACH DRIVE EXERCISED. 0 = WRITE CHECK DATA 1 = WRITE CHECK HEADER & DATA 2 = WRITE DATA 3 = WRITE HEADER & DATA 4 = READ DATA 5 = READ HEADER & DATA
1520	BEGSIZ	402	2 - SIZE	THE BUFFER SIZE FOR THE FIRST DATA TRANSFER OPERATION.

4.3 SWITCH REGISTER SETTINGS

- SW <15> = 1 HALT ON ERROR
- SW <13> = 1 INHIBIT ERROR TYPEOUT
- SW <10> = 1 RING THE TELETYPE BELL IF ERROR
- SW <7> = 1 DISPLAY ALL DATA COMPARE ERRORS
- SW <6> = 1 DO NOT ALTER THE CURRENT OPERATION PARAMETERS
- SW <5> = 1 PARTIAL REGISTER DISPLAY IF ERROR; DO NOT DISPLAY ECC CORRECTION RESULTS
- SW <4> = 1 INHIBIT MAXIMUM ERROR COUNT CHECK; DO NOT DEASSIGN DRIVES WHEN NORMAL END OF TEST REACHED.
- SW <3> = 1 DISPLAY THE SECTOR IN ERROR (BEFORE RETRY ATTEMPTS) IF 'DCK', 'DTE', OR 'WCF' ERRORS OR AFTER THE 28TH RETRY IF 'UNCORRECTABLE 'DCK' ERROR. IF DATA COMPARE ERRORS & SW<7> SET, DISPLAY REST OF BUFFER
- SW <2> = 1 INHIBIT SUBSYSTEM STATUS TYPEOUT DURING STARTUP. INHIBIT PERFORMANCE SUMMARY TYPEOUTS.
- SW <1> = 1 INHIBIT DATA COMPARISON AFTER READ ORDERS
- SW <0> = 1 READ ONLY MODE

IF THE PROGRAM IS BEING RUN ON A SWITCHLESS PROCESSOR (I.E. AN 11/34) THE PROGRAM WILL DETERMINE THAT THE HARDWARE SWITCH REGISTER IS NOT PRESENT AND WILL USE A 'SOFTWARE' SWITCH REGISTER. THE 'SOFTWARE' SWITCH REGISTER IS LOCATED AT LOCATION 176 (8). THE SETTINGS OF THE 'SOFTWARE' SWITCHES ARE CONTROLLED THROUGH A KEYBOARD ROUTINE WHICH IS CALLED BY TYPING A 'CONTROL G'. THE PROGRAM WILL RECOGNIZE THE 'CONTROL G' AT ANY TIME EXCEPT WHEN THE PROGRAM IS IN KEYBOARD ENTRY MODE, OR IS AT A HIGHER PRIORITY PROCESSING AN RM03 INTERRUPT. THE 'SOFTWARE' SWITCH VALUES ARE ENTERED AS AN OCTAL NUMBER IN RESPONSE TO THE PROMPT FROM THE SWITCH ENTRY ROUTINE:

'SWR = NNNNNN NEW ='

EACH TIME SWITCH SETTINGS ARE ENTERED, THE ENTIRE SWITCH REGISTER

649  
650  
651  
652  
653  
654  
655  
656  
657  
658  
659  
660  
661  
662  
663  
664  
665  
666  
667  
668  
669  
670  
671  
672  
673  
674  
675  
676  
677  
678  
679  
680  
681  
682  
683  
684  
685  
686  
687  
688  
689  
690  
691  
692  
693  
694  
695  
696  
697  
698  
699  
700  
701  
702  
703  
704

IMAGE MUST BE ENTERED. LEADING ZEROS ARE NOT REQUIRED. 'RUBOUT' AND 'CONTROL U' FUNCTIONS MAY BE USED TO CORRECT TYPING ERRORS DURING SWITCH ENTRY.

ON PROCESSORS WITH HARDWARE SWITCH REGISTERS, THE 'SOFTWARE' SWITCH REGISTER MAY BE USED. IF THE PROGRAM FINDS ALL 16 SWITCHES IN THE 'UP' POSITION, ALL SWITCH REGISTER REFERENCES WILL BE TO THE 'SOFTWARE' REGISTER AND THE PROCEDURES DESCRIBED ABOVE MUST BE FOLLOWED.

4.4 KEYBOARD COMMANDS

NOTE: ALL KEYBOARD COMMANDS WILL BE DISABLED IF DIAGNOSTIC IS RUNNING IN THE APT SCRIPT MODE.

THROUGH THE KEYBOARD COMMANDS, THE OPERATOR MAY ASSIGN DRIVES FOR TEST ('T' COMMAND), WRITE AND CHECK DATA PACKS ('W' COMMAND), PERFORM WRITE DATA AND FOLLOWED BY TEST ('WT' COMMAND), PERFORM A SEQUENTIAL READ OF A PACK ('R' COMMAND), REQUEST A DRIVE PERFORMANCE SUMMARY ('S' COMMAND), OR DEASSIGN A DRIVE WHICH IS BEING TESTED, READING, OR WRITING ('D' COMMAND).

AFTER THE PROGRAM HAS BEEN INITIALIZED, THE FOLLOWING MESSAGE WILL BE TYPED:

'PROGRAM INITIALIZATION COMPLETE  
'TYPE A CONTROL C TO ENTER COMMANDS'

KEYBOARD ENTRIES WILL NOT BE RECOGNIZED UNTIL THE OPERATOR TYPES A 'CONTROL C'. WHEN THE PROGRAM SEES A 'CONTROL C' ENTRY, IT WILL SUSPEND THE SCHEDULING OF FURTHER DEVICE OPERATIONS AND WAIT UNTIL ALL OUTSTANDING ORDERS HAVE TERMINATED. THE PROGRAM WILL ENTER COMMAND ENTRY MODE AND TYPE THE FOLLOWING PROMPTING MESSAGE:

'HH:MM:SS  
'ENTER COMMANDS:'

THE PROGRAM WILL THEN ACCEPT ANY OF THE VALID COMMANDS. AT THE COMPLETION OF A COMMAND, THE PROGRAM WILL EXIT COMMAND MODE; THE OPERATOR MUST TYPE ANOTHER 'CONTROL C' TO RETURN THE PROGRAM TO COMMAND MODE. IF THE COMMAND ENTERED SPECIFIED AN 'A' DRIVE NUMBER, THE PROGRAM WILL REMAIN IN COMMAND MODE UNTIL ALL AVAILABLE DRIVES HAVE BEEN PROCESSED.

THE 'WT', 'T', 'W', AND 'R' COMMANDS REQUIRE ADDRESS LIMITS, DRIVE I.D., AND BAD LOCATION ADDRESS ENTRIES FOR THE DRIVE BEING REFERENCED.

THE PROGRAM WILL FIRST ASK FOR ADDRESS LIMITS WITH THE FOLLOWING TYPEOUT:

'ENTER ADDRESS LIMITS FOR DRV #N / RMO3

THE PROGRAM WILL REQUEST VALUES FOR THE FOLLOWING ADDRESS LIMIT PARAMETERS.

DEFAULT VALUE



705  
706  
707  
708  
709  
710  
711  
712  
713  
714  
715  
716  
717  
718  
719  
720  
721  
722  
723  
724  
725  
726  
727  
728  
729  
730  
731  
732  
733  
734  
735  
736  
737  
738  
739  
740  
741  
742  
743  
744  
745  
746  
747  
748  
749  
750  
751  
752  
753  
754  
755  
756  
757  
758  
759  
760

NAME	BASE	VALUE	RANGE	FUNCTION
MINCYL	10	0	0 - 822	THE MINIMUM CYLINDER ADDRESS
MAXCYL	10	822	0 - 822	THE MAXIMUM CYLINDER ADDRESS
MINTRK	10	0	0 - 4	THE MINIMUM TRACK ADDRESS
MAXTRK	10	4	0 - 4	THE MAXIMUM TRACK ADDRESS
MINSEC	10	0	0 - 31	THE MINIMUM SECTOR ADDRESS
MAXSEC	10	31	0 - 31	THE MAXIMUM SECTOR ADDRESS

NOTE: 1. THE ADDRESS LIMITS ARE IN DECIMAL

2. THE MINIMUM CYLINDER, TRACK, OR SECTOR ADDRESS MAY BE SPECIFIED AS BEING LARGER THAN THE MAXIMUM ADDRESS. WHEN THESE VALUES ARE INVERTED, THE PROGRAM WILL SELECT ADDRESSES BETWEEN THE 'MIN' ADDRESS AND THE UPPER PHYSICAL LIMIT FOR THAT ADDRESS AND BETWEEN '0' AND THE VALUE IN 'MAX'.

EACH COMMAND, EXCEPT THE 'S' AND THE 'D' COMMANDS, WILL ASK FOR A DRIVE IDENTIFICATION ENTRY. THE DRIVE IDENTIFICATION ENTRY REQUEST IS MADE BY THE FOLLOWING MESSAGE:

'ENTER I.D. FOR DRV #N:'

THE OPERATOR MAY ENTER AN I.D. NUMBER FOR THE DRIVE OF UP TO 6 CHARACTERS IN LENGTH. THIS I.D. WILL BE DISPLAYED, ALONG WITH THE DATE AND OPERATOR I.D. ENTRIES (SEE SECTION 4.1), WHEN THE 'SA' COMMAND IS EXECUTED. THE OPERATOR MAY ENTER ANY CHARACTER STRING, TERMINATED BY A 'CARRIAGE RETURN', OR A 'PERIOD' ONLY (NULL ENTRY) IN RESPONSE TO THE I.D. REQUEST.

4.4.1

'T' COMMAND  
USED TO ASSIGN A DRIVE(S) FOR TEST. THIS COMMAND IS REQUIRED TO PERFORM THE TEST OF THE DRIVE(S). THE OTHER COMMANDS ARE CONVICIENCE COMMANDS OR SUPPORT COMMANDS.

FORMAT: TN<CR>

N = DRIVE NUMBER. MAY BE 0 TO 7 OR 'A'. ENTRY MUST BE TERMINIATED BY A CARRIAGE RETURN <CR>.

EXAMPLE: T0<CR> - ASSIGN DRIVE 0 FOR TEST  
TA<CR> - ASSIGN ALL AVAILABLE DRIVES FOR TEST

NOTE: DRIVE OPERATION BEGINS IMMEDIATELY AFTER COMMAND IS ENTERED.

4.4.2

'D' COMMAND

USED TO DEASSIGN A DRIVE(S) BEING EXERCISED.

FORMAT: DN<CR>

761  
762  
763  
764  
765  
766  
767  
768  
769  
770  
771  
772  
773  
774  
775  
776  
777  
778  
779  
780  
781  
782  
783  
784  
785  
786  
787  
788  
789  
790  
791  
792  
793  
794  
795  
796  
797  
798  
799  
800  
801  
802  
803  
804  
805  
806  
807  
808  
809  
810  
811  
812  
813  
814  
815  
816

N = DRIVE NUMBER. MAY BE 0 TO 7 OR 'A'. ENTRY MUST BE TERMINATED BY A CARRIAGE RETURN <CR>.

EXAMPLE: DO<CR> - DEASSIGN DRIVE 0  
DA<CR> - DEASSIGN ALL DRIVES BEING TESTED.

- NOTES:
1. IF THE 'D' COMMAND REFERENCES A DRIVE NOT ASSIGNED THE PROGRAM WILL TYPEOUT '?DRIVE NOT ASSIGNED'
  2. THE DRIVES WILL BE DEASSIGNED AS THEIR OPERATIONS COMPLETE.
  3. IF 'DA' IS USED, ALL DRIVES BEING TESTED WILL BE DEASSIGNED; THE MESSAGE IN (1) WILL BE DISPLAYED FOR ALL DRIVES NOT BEING TESTED.

4.4.3 'S' COMMAND

USED TO REQUEST A PERFORMANCE SUMMARY TYPEOUT FOR THE REFERENCED DRIVE(S).

FORMAT: SN<CR>

N = DRIVE NUMBER. MAY BE 0 TO 7 OR 'A'. ENTRY MUST BE TERMINATED BY A CARRIAGE RETURN <CR>.

EXAMPLE: SO<CR> - TYPEOUT PERFORMANCE SUMMARY FOR DRIVE 0  
SA<CR> - TYPEOUT PERFORMANCE SUMMARY FOR ALL DRIVES BEING TESTED.

- NOTES:
1. IF 'SA' IS USED ONLY DRIVES BEING TESTED WILL BE DISPLAYED.
  2. IF PARAMETER 'MINUTE' IS NOT ZERO, THE PROGRAM WILL AUTOMATICALLY DISPLAY A PERFORMANCE SUMMARY FOR EACH DRIVE BEING TESTED AT A RATE DETERMINED BY 'MINUTE'.
  3. IF THE 'SA' COMMAND IS USED, THE PROGRAM WILL TYPEOUT THE OPERATOR ENTERED DATE, OPERATOR I.D., AND THE DRIVE I.D. FOR EACH DRIVE BEING TESTED. THE DATE AND OPERATOR I.D. WILL NOT BE TYPED OUT IF NO DRIVES ARE BEING TESTED.

4.4.4 'W' COMMAND

USED TO WRITE A DATA PACK WITH DATA ACCEPTABLE TO THE RMO3 PERFORMANCE EXERCISER PROGRAM.

FORMAT: WN<CR>

N = DRIVE NUMBER. MAY BE 0 TO 7 OR 'A'. ENTRY MUST BE TERMINATED BY A CARRIAGE RETURN <CR>.

817  
818  
819  
820  
821  
822  
823  
824  
825  
826  
827  
828  
829  
830  
831  
832  
833  
834  
835  
836  
837  
838  
839  
840  
841  
842  
843  
844  
845  
846  
847  
848  
849  
850  
851  
852  
853  
854  
855  
856  
857  
858  
859  
860  
861  
862  
863  
864  
865  
866  
867  
868  
869  
870  
871  
872

EXAMPLE: WA<CR> - WRITE DATA PACKS ON ALL AVAILABLE DRIVES.  
WD<CR> - GENERATE A DATA PACK ON DRIVE 0.

- NOTES:
1. DATA PATTERNS GENERATED BY THE RMO3 FORMATTER PROGRAM (CZRMAC0) ARE COMPATIBLE.
  2. THE 'W' COMMAND MUST BE USED TO WRITE A NEW PACK UNDER TEST BEFORE OTHER COMMANDS ARE ISSUED; IF THE DISK PACK HAS BEEN WRITTEN BY ANY PROGRAM OTHER THAN THE FORMATTER.
  3. THE 'W' COMMAND PERFORMS A SEQUENTIAL WRITE OF THE PACK USING A 'WRITE DATA' COMMAND. THE DATA PATTERN USED FOR EACH WRITE IS SELECTED RANDOMLY. HOWEVER, THE OPERATION OF THE COMMAND IS SEQUENTIAL, BEGINNING AT 'MINCYL', 'MINTRK' AND CONTINUING TO 'MAXCYL', 'MAXTRK'.
  4. THE 'W' COMMAND DOES NOT WRITE HEADERS AND ASSUMES THAT THE FORMAT OF THE PACK IS GOOD.
  5. THE 'W' COMMAND CANNOT BE STARTED IF SWITCH 0 (READ ONLY MODE) IS SET. IF SWITCH 0 IS SET DURING THE OPERATION OF THE 'W' COMMAND, THE DRIVE PERFORMING THE 'W' COMMAND WILL IGNORE THE SWITCH.

#### 4.4.5 'R' COMMAND

USED TO PERFORM A SEQUENTIAL READ OF THE PACK.

FORMAT: RN<CR>

N = DRIVE NUMBER. MAY BE 0 TO 7 OR 'A'. ENTRY MUST BE TERMINATED BY A CARRIAGE RETURN <CR>.

EXAMPLE: RA<CR> - READ THE PACKS ON ALL OF THE ONLINE DRIVES.  
RD<CR> - READ THE PACK ON DRIVE 0.

- NOTES:
1. THE PROGRAM WILL PERFORM A NORMAL CHECK OF ALL DATA READ. HOWEVER, ALL OPERATIONS WILL BE SEQUENTIAL.
  2. THE PROGRAM WILL READ THE PACK STARTING AT THE ADDRESS SPECIFIED BY 'MINCYL', 'MINTRK' TO THE ADDRESS SPECIFIED BY 'MAXCYL', 'MAXTRK'. THE READ WILL BE SEQUENTIAL.

#### 4.4.6 'WT' COMMAND

USED TO PERFORM A SEQUENTIAL WRITE PACK AND FOLLOWED BY A "TEST" COMMAND

FORMAT: WTN<CR>

873  
874  
875  
876  
877  
878  
879  
880  
881  
882  
883  
884  
885  
886  
887  
888  
889  
890  
891  
892  
893  
894  
895  
896  
897  
898  
899  
900  
901  
902  
903  
904  
905  
906  
907  
908  
909

N= DRIVE NUMBER 0 TO 7 OR "A". ENTRY MUST BE TERMINATED BY A CARRIAGE RETURN <CR>.

EXAMPLE: WTA<CR> -WRITE ALL PACKS AND TEST ALL PACKS  
WTO<CR>-WRITE PACK 0 AND TEST PACK 0

4.4.7 GENERAL COMMAND INFORMATION

- A. CONTROL-C MUST BE ENTERED BEFORE ISSUING ANY COMMAND.
- B. T,R,W AND WT COMMANDS ARE EXCLUSIVE TO ONE ANOTHER ON THE SAME DRIVE UNDER TESTING. D COMMAND MUST BE ENTERED IN ORDER TO SWITCH COMMANDS AMONG T,R,W AND WT .
- C. S COMMAND CAN BE ENTERED ANY TIME DURING THE TEST.
- D. THE ERROR RESPONSES FROM THE PROGRAM ARE AS FOLLOWS

<u>RESPONSE</u>	<u>COMMAND(S)</u>
?UNIT N OFFLINE	T, W, R,WT
?UNIT N NOT ASSIGNED	D, S
?UNIT N ALREADY ASSIGNED	T, W, R,WT
?UNIT N NOT PRESENT	T, W, R,WT
?UNIT N UNSAFE	T, W, R,WT
?UNIT N NOT AN RMO3	T, W, R,WT

910  
911  
912  
913  
914  
915  
916  
917  
918  
919  
920  
921  
922  
923  
924  
925  
926  
927  
928  
929  
930  
931  
932  
933  
934  
935  
936  
937  
938  
939  
940  
941  
942  
943  
944  
945  
946  
947  
948  
949  
950  
951  
952  
953  
954  
955  
956  
957

5. PERFORMANCE SUMMARY TYPEOUT  
-----

5.1 THE PROGRAM WILL DISPLAY A PERFORMANCE SUMMARY FOR THE DRIVES BEING EXERCISED. THIS SUMMARY WILL BE DISPLAYED AUTOMATICALLY IF THE PARAMETER 'INTRVL' IS NOT ZERO OR CAN BE DISPLAYED ON REQUEST BY THE OPERATOR THROUGH THE USE OF THE 'S' COMMAND. THE PERFORMANCE SUMMARY TYPEOUT CONTAINS THE FOLLOWING FIELDS:

'DRV'	THE DRIVE NUMBER
'PASS'	THE PRESENT PASS COUNT FOR THE DRIVE
'ORDERS'	THE NUMBER OF ORDERS PERFORMED BY THE DRIVE
'SEEKS'	THE NUMBER OF SEEK OPERATIONS THE DRIVE PERFORMED
'WRDS XFER'	THE TOTAL NUMBER OF WORDS WRITTEN AND READ BY THE DRIVE
'WRDS READ'	THE TOTAL NUMBER OF WORDS READ BY THE DRIVE
'SOFT'	THE NUMBER OF SOFT DATA ERRORS
'HARD'	THE NUMBER OF HARD DATA ERRORS
'SKI'	THE NUMBER OF 'SKI' ERRORS
'MISP'	THE NUMBER OF POSITIONING ERRORS
'OTHER'	THE TOTAL ERRORS OF OTHER TYPES

NOTE: ERRORS EM1, EM2, EM3, EM4, EM5, & EM10 ARE NOT INCLUDED IN THE 'OTHER' ERROR TOTAL.

5.2 SOFT/HARD ERROR DEFINITIONS

5.2.1 HARD ERRORS

A. A 'DTE' (DRIVE TIMING ERROR) OR A 'DCK' (DATA CHECK ERROR) WHICH OCCURS DURING A READ DATA OR A READ HEADER & DATA OPERATION AND IS NOT CORRECTABLE OR DOES NOT BECOME CORRECTABLE AFTER THE PROGRAM HAS PERFORMED THE COMPLETE RETRY SEQUENCE ON THE BAD SECTOR. THE RETRY SEQUENCE IS 16 RE-READS AT TRACK CENTER AND 2 ATTEMPTS BOTH AT POSITIVE AND NEGATIVE OFFSETS:

5.2.2 SOFT ERRORS

- A. ECC CORRECTABLE 'DCK' ERRORS.
- B. 'DCK' & 'ECH' ERRORS WHICH BECOME ECC CORRECTABLE DURING RETRY OR WHICH ARE READ CORRECTLY DURING RETRY.
- C. HEADER READ ERRORS - READ DATA, READ HEADER & DATA, OR WRITE DATA ORDERS.
- D. 'DTE' ERRORS WHICH ARE CORRECTED OR WHICH BECOME ECC CORRECTABLE 'DCK' ERROR DURING THE RETRY SEQUENCE.

958  
959  
960  
961  
962  
963  
964  
965  
966  
967  
968  
969  
970  
971  
972  
973  
974  
975  
976  
977  
978  
979  
980  
981  
982  
983  
984  
985  
986  
987  
988  
989  
990  
991  
992  
993  
994  
995  
996  
997  
998  
999  
1000  
1001  
1002  
1003  
1004  
1005  
1006  
1007  
1008  
1009  
1010  
1011

6. DATA CHECKING & ERROR RECOVERY  
-----

6.1 DATA COMPARISON

DATA COMPARISON OCCURS AFTER EACH 'RDDAT' (READ DATA) OR 'RDHD' (READ HEADER AND DATA) OPERATION UNDER THE FOLLOWING CONDITIONS:

- A. THE ORDER TERMINATED WITH NO ERROR.
- B. THE OPERATION TERMINATED WITH 'DCK' SET AND THE ERROR IS ECC CORRECTABLE OR THE SECTOR IN ERROR IS READ CORRECTLY AFTER RETRY ATTEMPTS.

6.2 VERIFICATION OF DATA WRITTEN

DATA VERIFICATION IS DONE EITHER THROUGH READING THE WRITTEN DATA BACK AND MATCHING THE DATA WITH ONE OF THE 15 PATTERNS OR THROUGH ISSUING WRITE CHECK COMMANDS.

6.3 SECTOR REFORMATTING

THE PROGRAM WILL REFORMAT AN UNCORRECTABLE ERROR SECTOR IN THE FOLLOWING CASES (PARAMETER 'FORMAT' MUST BE SET AND SW<00> = 0). THIS PREVENTS THE SAME ERROR FROM BEING CONTINUOUSLY REPORTED.

- A. DATA CHECK ERRORS - EM21
- B. HEADER READ ERRORS - EM20, EM24, EM25, EM26, EM27
- C. DRIVE TIMING ERRORS - EM31
- D. OPERATION INCOMPLETE ERRORS - EM32
- E. WRITE CHECK ERRORS - EM22, EM23

6.4 BAD TRACK/SECTOR FLAGGING

SINCE THE RMO3 SUBSYSTEM HAS AN AUTOMATIC BAD TRACK HANDLING CAPABILITY, THE MULTIDRIVE EXERCISER ALLOWS TO IDENTIFY UP TO 16 BAD TRACK/SECTOR LOCATIONS WHEN THE DRIVE IS ASSIGNED FOR TEST. (SEE SECTION 4.4 FOR ADDITIONAL INFORMATION.)

IF ONE OF THE FOLLOWING ERRORS OCCURS AT A LOCATION IDENTIFIED BY THE OPERATOR, THE PROGRAM WILL INHIBIT THE ERROR REPORT FOR THAT ERROR.

DATA CHECK ERRORS ('DCK')  
WRITE CHECK ERRORS ('WCE')  
OPERATION INCOMPLETE ERRORS ('OPI')  
DRIVE TIMING ERRORS ('DTE')  
HEADER READ ERRORS ('FER' & 'HCRC', 'HCE' & 'HCRC', 'HCRC')

OPTIONALLY, THE OPERATOR MAY REQUEST AN ERROR REPORT FOR FLAGGED AREAS. (PARAMETER 'NOTPRT' MUST BE SET TO 0 AT STARTUP.) THE PROGRAM WILL IDENTIFY ERROR MESSAGES ASSOCIATED WITH THE PACK; THESE ERRORS WILL NOT BE ADDED TO THE ERROR TOTALS MAINTAINED BY THE PROGRAM.

7. ERROR MESSAGES  
-----

DRIVE ERRORS ARE REPORTED ON THE TELETYPE OR (IF AVAILABLE) A LINE PRINTER. ALL ERROR CONDITIONS ARE REPORTED IN ERROR MESSAGES; THE PROGRAM CONTAINS NO CODED ERROR HALTS. IF THE PROGRAM HALTS (ASSUMING, OF COURSE, THAT SW<15> IS NOT SET), AN UNRECOVERABLE PROGRAM CONDITION HAS OCCURRED OR A CENTRAL PROCESSOR FAILURE HAS OCCURRED.

ERROR MESSAGES ARE MADE UP OF SEVERAL LINES. EACH TYPE OF ERROR HAS SEVERAL OPTIONAL LINES WHICH MAY APPEAR WITH IT. ALL OF THE POSSIBLE ERROR MESSAGE LINES WHICH MAY APPEAR ARE GIVEN IN THE SECTION DESCRIBING THE PARTICULAR ERROR HEADER.

## 7.1 ERROR DESCRIPTION LINES

MESSAGES EM1, EM2, EM3, EM4, EM5, EM10, EM11, & EM12 ARE ALWAYS DISPLAYED ON THE TTY. THE OTHER MESSAGES ARE DISPLAYED ON EITHER THE LINE PRINTER (IF AVAILABLE) OR THE TTY.

(THE MESSAGE TAGS ARE GIVEN FOR REFERENCE.)

## MESSAGE

TAG	TEXT
---	----

EM1	RH11 INTERRUPT OCCURRED (RMAS=0)
-----	----------------------------------

THE RH11 INTERRUPTED AND THE ATTENTION SUMMARY REGISTER (RMAS) WAS CLEARED.

EM2	UNEXPECTED ATTENTION OCCURRED
-----	-------------------------------

THE INDICATED DRIVE INTERRUPTED BUT THE DRIVE WAS NOT PERFORMING AN OPERATION.

EM3	MASSBUS PARITY ERROR (MCPE=1)
-----	-------------------------------

THE RH11 DETECTED A CONTROL BUS PARITY ERROR WHEN READING THE INDICATED REGISTER FROM THE INDICATED DRIVE.

EM4	MASSBUS PARITY ERROR (PAR=1)
-----	------------------------------

THE INDICATED RM03 DETECTED A CONTROL BUS PARITY ERROR WHEN THE RH11 LOADED THE SPECIFIED REGISTER.

EM5	ADDRESS PLUG CHANGE BIT SET
-----	-----------------------------

THE 'OPE' BIT WAS SET WHEN THE INDICATED DRIVE INTERRUPTED.

EM6	RH11 DIDN'T RESPOND TO ADDRESSING
-----	-----------------------------------

WHEN THE PROGRAM ADDRESSED THE RH11, NO RESPONSE WAS RECEIVED FROM THE INDICATED ADDRESS.

1012  
1013  
1014  
1015  
1016  
1017  
1018  
1019  
1020  
1021  
1022  
1023  
1024  
1025  
1026  
1027  
1028  
1029  
1030  
1031  
1032  
1033  
1034  
1035  
1036  
1037  
1038  
1039  
1040  
1041  
1042  
1043  
1044  
1045  
1046  
1047  
1048  
1049  
1050  
1051  
1052  
1053  
1054  
1055  
1056  
1057  
1058  
1059  
1060  
1061  
1062  
1063  
1064  
1065  
1066  
1067

1068  
1069  
1070  
1071  
1072  
1073  
1074  
1075  
1076  
1077  
1078  
1079  
1080  
1081  
1082  
1083  
1084  
1085  
1086  
1087  
1088  
1089  
1090  
1091  
1092  
1093  
1094  
1095  
1096  
1097  
1098  
1099  
1100  
1101  
1102  
1103  
1104  
1105  
1106  
1107  
1108  
1109  
1110  
1111  
1112  
1113  
1114  
1115  
1116  
1117  
1118  
1119  
1120  
1121  
1122  
1123

EM10 UNCORRECTABLE MASSBUS PARITY ERROR  
THE PROGRAM HAS TRIED 3 TIMES TO READ OR WRITE THE INDICATED REGISTER.

EM11 FATAL MASSBUS PARITY ERROR  
A CONTROL BUS PARITY ERROR OCCURRED WHEN THE RH11 ATTEMPTED TO PROCESS A PREVIOUS, DIFFERENT PARITY ERROR.

EM12 PERSISTENT DEVICE UNSAFE  
THE DRIVE BECAME UNSAFE; DRIVE CLEAR TO THE DRIVE DID NOT CLEAR THE UNSAFE CONDITION. THE PROGRAM WILL AUTOMATICALLY DEASSIGN THE DRIVE. THE DRIVE CANNOT BE EXERCISED UNTIL THE UNSAFE CONDITION HAS BEEN CLEARED BY MANUAL INTERVENTION.

EM13 OPERATION NOT COMPLETED WITHIN TIME LIMIT  
THE DRIVE DID NOT COMPLETE THE OPERATION WITHIN 1 SECOND AFTER THE OPERATION WAS INITIATED.

EM14 UNIT WENT OFFLINE  
THE DRIVE WENT OFFLINE DURING THE INDICATED OPERATION. (THE 'MOL' BIT BECAME ZERO.) THE PROGRAM WILL AUTOMATICALLY DEASSIGN THE DRIVE. THE OPERATOR MUST REASSIGN THE DRIVE WITH THE 'T' COMMAND TO RE-INITIATE TESTING.

EM15 NO RESPONSE TO PORT REQUEST  
THE PROGRAM IS TESTING A DUAL PORT DRIVE WHICH HAS NOT SWITCHED TO THE REQUESTING PORT WITHIN 10 SECONDS AFTER PORT REQUEST TO THE DRIVE FROM THE REPORTING PORT.

EM20 HEADER CRC ERROR  
A HEADER CRC ERROR WAS DETECTED AT THE INDICATED DISK ADDRESS. THE CONTENTS OF THE HEADER ARE DISPLAYED. THE OPERATION WILL BE RETRIED 3 TIMES.

EM21 DATA CHECK ('DCK') ERROR  
A DATA CHECK ERROR WAS DETECTED AT THE INDICATED SECTOR. THE FULL RETRY SEQUENCE (INCLUDING OFFSET) WILL BE INITIATED FOR THE SECTOR IN ERROR IF THE ECC HARD ERROR ('ECH') BIT IS SET.

EM22 WRITE CHECK ERROR - DATA CHECK ('DCK') SET  
A WRITE CHECK ERROR OCCURRED AND THE DATA CHECK ('DCK') BIT WAS SET. IF 'ECH' IS NOT SET, THE OPERATION WILL BE RETRIED UP TO 3 TIMES; IF THE 'ECH' BIT IS SET, THE OPERATION WILL BE RETRIED UP TO 16 TIMES.



1124	EM23	WRITE CHECK ERROR - DATA CHECK ('DCK') NOT SET
1125		A WRITE CHECK ERROR OCCURRED AND 'DCK' WAS NOT SET. THE
1126		WORDS WHICH CAUSED THE ERROR ARE DISPLAYED IN THE ERROR
1127		MESSAGE. THE OPERATION WILL BE RETRIED 3 TIMES.
1128		
1129		
1130	EM24	HEADER READ ERROR - 'FMT' BIT DROPPED
1131		A WRITE DATA, WRITE CHECK DATA, OR A READ DATA WAS BEING
1132		PERFORMED AND A 'FMT' ERROR OCCURRED. THE PROGRAM RE-READ THE
1133		HEADER OF THE ERROR SECTOR AND THE 'HCRC' BIT WAS SET. THE
1134		CONTENTS OF THE HEADER ARE DISPLAYED. THE OPERATION WILL
1135		BE RETRIED 3 TIMES.
1136		
1137		
1138	EM25	HEADER READ ERROR - HEADER COMPARE ('HCE') ERROR
1139		SIMILAR TO EM24, EXCEPT THAT THE 'HCE' ERROR BIT WAS
1140		SET INITIALLY. THE OPERATION WILL BE RETRIED 3 TIMES.
1141		
1142		
1143	EM26	FORMAT ERROR ('FER')
1144		FORMAT ERROR OCCURRED. WHEN THE HEADER WAS RE-READ, THE
1145		'HCRC' BIT WAS NOT SET. THE CONTENTS OF THE HEADER ARE
1146		DISPLAYED. THE OPERATION WILL BE RETRIED 3 TIMES.
1147		
1148		
1149	EM27	HEADER COMPARE ('HCE') ERROR
1150		SIMILAR TO EM26 EXCEPT THAT THE 'HCE' BIT WAS SET INITIALLY.
1151		THE OPERATION WILL BE RETRIED 3 TIMES.
1152		
1153		
1154	EM30	MISCELLANEOUS DRIVE ERROR
1155		THIS MESSAGE IS GIVEN FOR THE FOLLOWING ERROR BITS:
1156		'AOE', 'RMR', 'ILF', OR 'ILR'
1157		
1158		
1159	EM31	OPERATION INCOMPLETE ('OPI') ERROR
1160		AN OPERATION INCOMPLETE ERROR OCCURRED AT THE INDICATED
1161		SECTOR.
1162		
1163		
1164	EM32	DRIVE TIMING ('DTE') ERROR
1165		DRIVE TIMING ERROR OCCURRED ON THE INDICATED SECTOR. THE
1166		OPERATION WILL BE RETRIED 3 TIMES.
1167		
1168		
1169	EM33	PARITY ('PAR') ERROR AFTER OPERATION STARTED
1170		THE 'PAR' BIT WAS SET WHEN THE OPERATION WAS COMPLETED. THE
1171		OPERATION WILL BE RETRIED 3 TIMES.
1172		
1173		
1174	EM34	WRITE CLOCK FAILURE ('WCF')
1175		A WRITE CLOCK FAILURE OCCURRED DURING THE OPERATION. THE
1176		OPERATION WILL BE RETRIED 3 TIMES.
1177		
1178		
1179	EM35	INVALID ADDRESS ('IAE') ERROR

1180  
1181  
1182  
1183  
1184  
1185  
1186  
1187  
1188  
1189  
1190  
1191  
1192  
1193  
1194  
1195  
1196  
1197  
1198  
1199  
1200  
1201  
1202  
1203  
1204  
1205  
1206  
1207  
1208  
1209  
1210  
1211  
1212  
1213  
1214  
1215  
1216  
1217  
1218  
1219  
1220  
1221  
1222  
1223  
1224  
1225  
1226  
1227  
1228  
1229  
1230  
1231  
1232  
1233  
1234  
1235

AN INVALID ADDRESS ERROR OCCURRED DURING THE OPERATION.

EM36 WRITE LOCK ('WLE') ERROR  
A WRITE OPERATION WAS ATTEMPTED BUT THE DRIVE WAS WRITE LOCKED.

EM40 RH11 OR UNIBUS TRANSFER ERROR  
'TRE' IS SET IN THE RH11 CONTROL REGISTER AND NO DRIVE ERROR HAS OCCURRED. THE OPERATION WILL BE RETRIED 3 TIMES IF THE ERROR WAS CAUSED BY 'DLT', 'UPE', 'MXF', OR 'MDPE'.

EM41 BUS ADDRESS OR WORD COUNT INCORRECT  
NO DRIVE ERROR OCCURRED BUT EITHER THE BUS ADDRESS INDICATES THAT AN INCORRECT NUMBER OF WORDS WERE TRANSFERED OR THE WORD COUNT REGISTER IS NOT ZERO.

EM42 DATA COMPARE ERRORS - NO DRIVE ERROR DETECTED  
NO SUBSYSTEM ERROR WAS SIGNALLED; HOWEVER, THE DATA DOES NOT COMPARE.

EM43 CAN'T MATCH DATA READ WITH A PATTERN  
THE DATA IN THE BUFFER DOES NOT MATCH ANY OF THE STANDARD PATTERNS.

EM44 ERROR BIT(S) SET, BUT NO ERROR SIGNALLED BY THE RH11  
THE OPERATION COMPLETED NORMALLY; HOWEVER, THE PROGRAM FOUND EITHER ERROR BITS IN THE RMO3 SET OR ERROR BITS IN THE RH11 SET.

EM45 ECC LOGIC FAILURE  
THE CONTENTS OF EITHER THE ECC POSITION REGISTER (RMEC1) OR THE CONTENTS OF ECC PATTERN REGISTER (RMEC2) ARE NOT VALID. THE POSITION REGISTER IS EITHER '0' OR > 40066 (8) OR THE PATTERN REGISTER CONTAINS ZEROS.

EM46 BUS ADDRESS OR WORD COUNT NOT CONSISTENT  
THE PROGRAM WAS PROCESSING AN ERROR AND FOUND THAT THE NUMBER OF WORDS TRANSFERED AS INDICATED BY THE BUS ADDRESS REGISTER DOES NOT AGREE WITH THE TRANSFER COUNT FROM THE WORD COUNT REGISTER.

EM50 SEEK INCOMPLETE ERROR  
THE DRIVE SIGNALLED EITHER 'SKI' OR 'OCYL' ERROR BITS.

EM51 NOT USED

1236  
1237  
1238  
1239  
1240  
1241  
1242  
1243  
1244  
1245  
1246  
1247  
1248  
1249  
1250  
1251  
1252  
1253  
1254  
1255  
1256  
1257  
1258  
1259  
1260  
1261  
1262  
1263  
1264  
1265  
1266  
1267  
1268  
1269  
1270  
1271  
1272  
1273  
1274  
1275  
1276  
1277  
1278  
1279  
1280  
1281  
1282  
1283  
1284  
1285  
1286  
1287  
1288  
1289  
1290  
1291

EM60 DEVICE UNSAFE

THE INDICATED DRIVE UNSAFE ERROR OCCURRED; THE ERROR WAS  
CLEARED BY A 'DRIVE CLEAR' INSTRUCTION.

7.2 DETAIL ERROR LINES

THE LINE NUMBERS GIVEN BELOW ARE FOR REFERENCE ONLY.

LINE 1  
-----

TT:TT:TT (DESCRIPTION OF ERROR)

'TT:TT:TT' IS THE TIME SINCE THE PROGRAM  
WAS STARTED. TT:TT:TT IS GIVEN IN HOURS:  
MINUTES: SECONDS.

LINE 2  
-----

'PRESENT ORDER = XXXX PREVIOUS ORDER = YYYY'

MNEMONICS USED FOR THE ORDERS ARE DEFINED BELOW:

UNLOAD - UNLOAD (OCTAL 3)  
SEEK - SEEK (OCTAL 5)  
RECAL - RECALIBRATE (OCTAL 7)  
DRVCLR - DRIVE CLEAR (OCTAL 11)  
RELSE - RELEASE (OCTAL 13)  
OFFSET - OFFSET (OCTAL 15)  
RTC - RETURN TO CENTERLINE (OCTAL 17)  
READIN - READIN PRESET (OCTAL 21)  
PACK - PACK ACKNOWLEDGE (OCTAL 23)  
SEARCH - SEARCH (OCTAL 31)  
GETREG - GET REGISTERS (OCTAL 41)  
SETFMT - SET FORMAT (ECI OR HCI) (OCTAL 43)  
SELDRV - SELECT DRIVE (OCTAL 45)  
WCKD - WRITE CHECK DATA (OCTAL 51)  
WCKHD - WRITE CHECK HEADER & DATA (OCTAL 53)  
WRDAT - WRITE DATA (OCTAL 61)  
WRTHD - WRITE CHECK HEADER & DATA (OCTAL 63)  
RDDAT - READ DATA (OCTAL 71)  
RDHD - READ HEADER & DATA (OCTAL 73)

(DISPLAY OF THE RH11/RM03 REGISTERS IN TWO GROUPS:  
RMCS1, RMCS2, RMDS1, RMER1, RMER2, RMER3, RMEC1, & RMEC2 FORM THE FIRST  
GROUP; ALL THE OTHER REGISTERS ARE IN THE SECOND GROUP.  
IF SW(05) IS SET, ONLY THE REGISTERS IN THE FIRST GROUP WILL BE  
DISPLAYED.)

THE ABOVE LINE WILL BE TYPED IF THE ERROR OCCURRED DURING

1292  
1293  
1294  
1295  
1296  
1297  
1298  
1299  
1300  
1301  
1302  
1303  
1304  
1305  
1306  
1307  
1308  
1309  
1310  
1311  
1312  
1313  
1314  
1315  
1316  
1317  
1318  
1319  
1320  
1321  
1322  
1323  
1324  
1325  
1326  
1327  
1328  
1329  
1330  
1331  
1332  
1333  
1334  
1335  
1336  
1337  
1338  
1339  
1340  
1341  
1342  
1343  
1344  
1345  
1346  
1347

THE NON-DATA TRANSFER PART OF THE OPERATION.

'\* ERROR AT BAD TRACK/SECTOR'

THE ABOVE LINE WILL BE PRINTED IF A DATA ERROR OCCURES AT AN ADDRESS ON THE PACK WHICH THE OPERATOR HAS IDENTIFIED AS BEING BAD. PARAMETER 'NOTPRT' MUST BE 0 FOR THE ERROR TO BE REPORTED.

A WORD CALLED 'STATUS' IS DISPLAYED WITH THE RMO3 REGISTERS. THE CONTENTS OF THIS WORD IDENTIFY HOW THE ERROR WAS PROCESSED BY THE RMO3 DRIVE HANDLER ROUTINE. THE BITS IN THIS WORD ARE ENCODED AS FOLLOWS:

BIT #	MEANING IF BIT IS '1'
15	ERROR OCCURRED DONE (BIT07=0), BITS 14-9, 2, 1 SPECIFY TYPE DONE (BIT07=1), BITS 6-3 SPECIFY TYPE
14	DRIVE IS OFFLINE
12	PERSISTENT UNSAFE CONDITION EXISTS
11	UNCORRECTABLE PARITY ERROR OCCURRED
10	FATAL PARITY ERROR OCCURRED. MASSBUS CLEAR WAS PERFORMED
9	OPERATION NOT COMPLETED WITHIN 1 SECOND MASSBUS CLEAR PERFORMED. ALL OTHER OUTSTANDING OPERATIONS WERE RESTARTED.
7	DONE - OPERATION COMPLETED
6	DATA ERROR OCCURRED DURING THE TRANSFER
5	ERROR OCCURRED WHILE SEARCHING FOR THE 'TRANSFER' SECTOR OR DURING RECALIBRATE OR OFFSET COMMANDS
4	CORRECTABLE UNSAFE CONDITION OCCURRED
3	DRIVE ERROR OCCURRED THAT CAUSED AN AUTOMATIC RECALIBRATE SEQUENCE
2	PORT REQUEST TIMEOUT
1	NON-EXISTENT DRIVE REQUESTED

LINE 3

ERROR AT CXXX TYY SZZ PREV ADDR = CUUU TVV SWW

THE ACTUAL ADDRESS OF THE ERROR SECTOR AND THE PREVIOUS DISK ADDRESS ARE GIVEN IN THIS LINE. CYLINDER, TRACK, &

1348  
1349  
1350  
1351  
1352  
1353  
1354  
1355  
1356  
1357  
1358  
1359  
1360  
1361  
1362  
1363  
1364  
1365  
1366  
1367  
1368  
1369  
1370  
1371  
1372  
1373  
1374  
1375  
1376  
1377  
1378  
1379  
1380  
1381  
1382  
1383  
1384  
1385  
1386  
1387  
1388  
1389  
1390  
1391  
1392  
1393  
1394  
1395  
1396  
1397  
1398  
1399  
1400  
1401  
1402  
1403

SECTOR ADDRESSES ARE IN DECIMAL.

LINE 4  
-----

PRESENT ADDR = CXXX TYY SZZ PREV ADDR = CUUU TVV SWW

THIS LINE IDENTIFIES THE ADDRESS WHEN THE ERROR WAS DETECTED;  
THE PREVIOUS ADDRESS IS ALSO GIVEN. CYLINDER, TRACK, & SECTOR  
ADDRESSES ARE GIVEN IN DECIMAL.

LINE 5  
-----

START CYL = XXX END CYL = YYY

THIS LINE IDENTIFIES THE STARTING CYLINDER OR A SEEK (IMPLIED)  
AND THE DESTINATION CYLINDER. CYLINDER ADDRESSES ARE IN  
DECIMAL.

LINE 6  
-----

START CYL = XXX END CYL = YYY ACTUAL CYL = ZZZ

THIS LINE IDENTIFIES THE STARTING CYLINDER OF AN IMPLIED SEEK,  
THE DESTINATION CYLINDER, AND THE CYLINDER THE DISK ACTUALLY  
STOPPED AT. CYLINDER ADDRESSES ARE IN DECIMAL.

LINE 7  
-----

RMBA = XXXX RMWC = YYYY

THIS LINE GIVES THE CONTENTS OF THE RH11 BUFFER ADDRESS  
REGISTER AND THE RH11 WORD COUNT REGISTER. THIS LINE IS  
NOT PRINTED IF SW<05> IS NOT SET.

LINE 8  
-----

START CYL = XXX START TRK = YY START SECTOR = ZZ

THIS LINE IDENTIFIES THE STARTING DISK ADDRESS OF THE PRESENT  
OPERATION. CYLINDER, TRACK, AND SECTOR VALUES ARE DECIMAL.

LINE 9  
-----

RMDA = XXXX RMCA = YYYY

THIS LINE GIVES THE CONTENTS OF THE RMO3 TRACK AND SECTOR  
ADDRESS REGISTER AND THE CONTENTS OF THE DESIRED CYLINDER  
ADDRESS REGISTER. THIS LINE IS NOT PRINTED IF SW<05> IS NOT  
SET.

1404  
1405  
1406  
1407  
1408  
1409  
1410  
1411  
1412  
1413  
1414  
1415  
1416  
1417  
1418  
1419  
1420  
1421  
1422  
1423  
1424  
1425  
1426  
1427  
1428  
1429  
1430  
1431  
1432  
1433  
1434  
1435  
1436  
1437  
1438  
1439  
1440  
1441  
1442  
1443  
1444  
1445  
1446  
1447  
1448  
1449  
1450  
1451  
1452  
1453  
1454  
1455  
1456  
1457  
1458  
1459

LINE 10

-----  
BUFFER ADDR = XXXX SIZE = YYYY ACTUAL NUMBR WRDS XFRD = ZZZZ

THIS LINE GIVES THE STARTING ADDRESS OF THE BUFFER USED FOR THE CURRENT DATA TRANSFER OPERATION, ITS SIZE, AND THE ACTUAL NUMBER OF WORD TRANSFERED. THE STARTING ADDRESS OF THE BUFFER IS IN OCTAL, THE SIZE AND WORD TRANSFERED VALUE ARE IN DECIMAL.

LINE 11

-----  
GOOD DATA = XXXX BAD DATA = YYYY SECT POS = ZZZ

THIS LINE GIVES THE GOOD DATA, THE ACTUAL DATA FROM THE DISK, AND THE LOCATION IN THE SECTOR OF THE ACTUAL DATA. THE SECTOR POSITION IS IN DECIMAL.

LINE 12

-----  
HEADER CONTENTS OF ERROR SECTOR = XXXX XXXX XXXX XXXX

THIS LINE GIVES THE CONTENTS OF THE HEADER OF THE SECTOR WHICH GAVE THE ERROR.

LINE 13

-----  
RMEC1 = XXXX RMEC2 = YYYY

THIS LINE WILL BE PRINTED AFTER A SUCESSFUL RETRY OF A SECTOR WHICH BECAME ECC CORRECTABLE DURING RETRY.

LINE 14

-----  
ECC CORRECTABLE WITHOUT OFFSET

THE SECTOR IN ERROR IS ECC CORRECTABLE; NO RETRY ATTEMPTS ARE NECESSARY.

LINE 15

-----  
READ CORRECTLY AT (NEG OR POS) OFFSET

THE SECTOR IN ERROR WAS READ WITHOUT ERROR AT THE INDICATED OFFSET VALUE.

LINE 16

-----  
ECC CORRECTABLE AT (NEG OR POS) OFFSET

1460  
1461  
1462  
1463  
1464  
1465  
1466  
1467  
1468  
1469  
1470  
1471  
1472  
1473  
1474  
1475  
1476  
1477  
1478  
1479  
1480  
1481  
1482  
1483  
1484  
1485  
1486  
1487  
1488  
1489  
1490  
1491  
1492  
1493  
1494  
1495  
1496  
1497  
1498  
1499  
1500  
1501  
1502  
1503  
1504  
1505  
1506  
1507  
1508  
1509  
1510  
1511  
1512  
1513  
1514  
1515

THE SECTOR IN ERROR BECAME ECC CORRECTABLE AT THE INDICATED OFFSET.

LINE 17

CORRECTED ON X RETRY

THE OPERATION WAS PERFORMED ERROR FREE ON THE INDICATED RETRY ATTEMPT.

LINE 18

UNCORRECTABLE AFTER X RETRIES

THE OPERATION COULD NOT BE PERFORMED CORRECTLY AFTER THE INDICATED NUMBER OF RETRY ATTEMPTS.

LINE 19

DIFFERENT ERROR DURING RETRY

WHILE THE PROGRAM WAS RETRYING THE ERROR, A DIFFERENT OCCURRED. IF THIS LINE IS PRINTED, THE RH11/RMO3 REGISTERS WILL ALSO BE PRINTED (SEE LINE 2).

LINE 20

DATA COMPARISON ERRORS

A PRINTOUT OF THE DATA COMPARISON ERRORS FOLLOW THIS LINE.

LINE 21

TOTAL COMPARE ERRORS = XXXX

THIS LINE GIVES THE TOTAL DATA COMPARISON ERROR COUNT. THE VALUE GIVEN IS IN DECIMAL.

LINE 22

THE DATA COMPARED OK

THIS LINE INDICATES THE RESULTS OF THE DATA COMPARISON FOLLOWING ECC CORRECTION.

LINE 23

ECC CORRECTION RESULTS

1516  
1517  
1518  
1519  
1520  
1521  
1522  
1523  
1524  
1525  
1526  
1527  
1528  
1529  
1530  
1531  
1532  
1533  
1534  
1535  
1536  
1537  
1538  
1539  
1540  
1541  
1542  
1543  
1544  
1545  
1546  
1547  
1548  
1549  
1550  
1551  
1552  
1553  
1554  
1555  
1556  
1557  
1558  
1559  
1560  
1561  
1562  
1563  
1564  
1565  
1566  
1567  
1568  
1569  
1570  
1571

THE PROGRAM PERFORMED ECC CORRECTION AND THE RESULTS ARE REPORTED.  
THE ADDRESS IN MEMORY OF THE WORD(S) IN ERROR ARE GIVEN, THE WORD(S)  
BEFORE CORRECTION AND THE WORD(S) AFTER CORRECTION ARE PRINTED.

LINE 24  
-----

ERROR BURST BEGINS AT WORD XXX IN DATA FIELD OF ERROR SECTOR

THIS IS AN INFORMATIONAL LINE WHICH WILL BE PRINTED FOR 'DCK' ERRORS  
WHICH ARE ECC CORRECTABLE OR WHICH BECOME ECC CORRECTABLE DURING  
RETRY. 'XXX' IS THE WORD OFFSET VALUE FROM 'RMEC1' AND IS IN  
DECIMAL.

LINE 25  
-----

ERROR WAS NOT IN THE DATA READ -  
ECC CORRECTION CAN'T BE PERFORMED

THE DATA ERROR WAS NOT IN DATA TRANSFERED TO MEMORY.

LINE 26  
-----

CONTENTS OF THE ERROR SECTOR (REPORTED ABOVE)

IF SW<03> IS SET, THE SECTOR WHICH GAVE THE 'DCK', 'DTE' OR,  
'WCF' ERROR OR 'HARD' DATA CHECK ERROR IS PRINTED. THE  
CONTENTS OF THE SECTOR FOLLOW THIS LINE.

LINE 27  
-----

ORDERS: WWW ERRORS: X WRDS XFR: YYYY WRDS READ: ZZZZ

THIS IS THE LAST LINE PRINTED FOR ALL NON-POSITIONING  
TYPE ERRORS.

'ORDERS' IS THE TOTAL NUMBER OF COMMANDS GIVEN TO THE DRIVE  
WHICH REPORTED THE ERROR.

'ERRORS' IS THE TOTAL ERROR COUNT FOR THE DRIVE AND INCLUDES  
EVERY ERROR DETECTED, REGARDLESS OF TYPE.

'WRDS XFR' IS THE TOTAL NUMBER OF WORDS WRITTEN AND READ BY  
THE DRIVE.

'WRDS READ' IS THE TOTAL NUMBER OF WORD READ BY THE DRIVE.

LINE 28  
-----

ORDERS: WWW TOTAL SEEKS: XXX TOTAL POS ERR = YYY TOTAL SKI ERR = Z

THIS IS THE LAST LINE PRINTED FOR ALL POSITIONING TYPE ERRORS.



1572  
1573  
1574  
1575  
1576  
1577  
1578  
1579  
1580

'ORDERS' IS THE TOTAL NUMBER OF ORDERS GIVEN TO THE DRIVE WHICH REPORTED THE ERROR.

'TOTAL SEEKS' IS THE TOTAL NUMBER OF SEEK OPERATIONS PERFORMED BY THE DRIVE.

'TOTAL SKI ERR' IS THE TOTAL NUMBER OF 'SKI' ERRORS SIGNALLED BY THE DRIVE.

1581  
1582  
1583  
1584  
1585  
1586  
1587  
1588  
1589  
1590  
1591  
1592  
1593  
1594  
1595  
1596  
1597  
1598  
1599  
1600  
1601  
1602  
1603  
1604  
1605  
1606  
1607  
1608  
1609  
1610  
1611  
1612  
1613  
1614  
1615  
1616  
1617  
1618  
1619  
1620  
1621  
1622  
1623  
1624  
1625  
1626  
1627  
1628  
1629  
1630  
1631  
1632  
1633  
1634  
1635  
1636

8. PROGRAM DESCRIPTION  
-----

8.1 PROGRAM OPERATION

WHEN THE PROGRAM IS STARTED, PROVIDING APT TTY ENABLE BIT IS SET OR DIAGNOSTIC LOADED BY OTHER THAN APT SCRIPT MODE, ALL TABLES AND PARAMETERS ARE CLEARED OR INITIALIZED. THE PARAMETERS WHICH ARE UNDER OPERATOR TTY ENTRY CONTROL ARE CHECKED FOR VALIDITY AND CONSISTENCY. RH11 INTERRUPT ENABLE ('IE') IS SET, TTY KEYBOARD INTERRUPT ENABLE IS SET, AND THE KW11-L OR KW11-P CLOCK IS STARTED. WHEN THESE ACTIONS HAVE BEEN COMPLETED, THE PROGRAM TYPES OUT 'PROGRAM INITIALIZE COMPLETE'. COMMAND ENTRIES WILL NOW BE ACCEPTED BY THE PROGRAM

THE PROGRAM SCANS ITS INTERNAL ASSIGNMENT TABLES, LOOKING FOR:

- 1) DRIVES TO ASSIGN/DEASSIGN
- 2) PERFORMANCE SUMMARY TIMEOUT REQUESTS
- 3) DRIVES REQUIRING COMMAND INITIATION, BUFFER ASSIGNMENT, OR PARAMETER SELECTION.
- 4) DRIVES COMPLETING CURRENT OPERATIONS.

THE PROGRAM CONTINUES SCANNING ITS TABLES UNTIL AN ENTRY IS FOUND. IN THE CASE OF THE PROGRAM AT INITIAL START, THE FIRST ENTRY WILL BE MADE BY THE OPERATOR WHEN A DRIVE IS ASSIGNED ('T' COMMAND).

WHEN A DRIVE IS ASSIGNED, THE KEYBOARD ENTRY ROUTINE VERIFIES THAT THE DRIVE IS PRESENT, IS AN RMO3, AND IS ONLINE. THE ASSIGNMENT ROUTINE THEN ISSUES A 'READIN PRESET' INSTRUCTION, SETS 'FMT22', AND ISSUES A 'RECALIBRATE' INSTRUCTION.

PARAMETERS FOR THE OPERATION ARE SELECTED AND A BUFFER IS ASSIGNED. IF THE OPERATION IS A WRITE OR WRITE CHECK ORDER, THE ASSIGNED BUFFER WILL BE FILLED WITH THE SELECTED PATTERN. (WRITE CHECK ORDERS ARE ISSUED AFTER EACH WRITE ORDER. THE WRITE CHECK ORDER USES THE PARAMETERS SELECTED FOR THE PRECEDING WRITE ORDER.) CONTROL IS THEN PASSED TO THE COMMAND INITIATION ROUTINE.

THE COMMAND INITIATION ROUTINE FIRST LOOKS AT THE CYLINDER ADDRESS OF THE REQUESTED OPERATION. IF THE DRIVE MUST SEEK TO ANOTHER CYLINDER TO PERFORM THE OPERATION, THE PROGRAM ISSUES A SEARCH INSTRUCTION TO THE DRIVE WITH A 'TARGET' SECTOR WHICH IS 8 SECTORS EARLIER THAN THE 'TRANSFER' SECTOR. (THIS ALLOWS THE PROGRAM TO INITIATE OPERATIONS ON ANOTHER DRIVE WHILE THE PRESENT DRIVE, OR OTHER DRIVES, ARE SEARCHING FOR 'TARGET' SECTORS. ALL SEEKS ISSUED BY THE PROGRAM ARE IMPLIED SEEK SEARCH OPERATIONS.) WHEN A SEARCHING DRIVE FINDS THE 'TARGET' SECTOR AND INTERRUPTS, THE PROGRAM READS THE LOOK AHEAD REGISTER (RLA) OF THE INTERRUPTING DRIVE AND COMPARES THE POSITION OF THE DISK WITH THAT OF THE DESIRED SECTOR.

IF OTHER DRIVES ARE WAITING ON CYLINDER, THEY ARE ALSO CHECKED. THE PROGRAM THEN ISSUES THE REQUESTED ORDER TO THE DRIVE NEAREST ITS TRANSFER SECTOR. THE DRIVES NOT SELECTED WILL HAVE ANOTHER SEARCH INITIATED. IF A DRIVE IS NOT SELECTED FOR TRANSFER AFTER THREE REVOLUTIONS OF ITS DISK, IT IS GIVEN PRIORITY OVER DRIVES WHICH HAVE

1637  
1638  
1639  
1640  
1641  
1642  
1643  
1644  
1645  
1646  
1647  
1648  
1649  
1650  
1651  
1652  
1653  
1654  
1655  
1656  
1657  
1658  
1659  
1660  
1661  
1662  
1663  
1664  
1665  
1666  
1667  
1668  
1669  
1670  
1671  
1672  
1673  
1674  
1675  
1676  
1677  
1678  
1679  
1680  
1681  
1682  
1683  
1684  
1685  
1686  
1687  
1688  
1689  
1690  
1691  
1692

NOT BEEN ON CYLINDER AS LONG.

WHEN THE DATA TRANSFER OPERATION IS COMPLETE, THE DRIVE REGISTERS ARE STORED AND A DATA TRANSFER IS INITIATED FOR A WAITING DRIVE.

IF THE OPERATION HAS BEEN COMPLETED NORMALLY, THE SAVED DRIVE REGISTERS ARE CHECKED TO VERIFY THAT NO ERROR BITS ARE SET; THE RH11 BUS ADDRESS AND WORD COUNT ADDRESS REGISTERS ARE CHECKED TO VERIFY THAT THE CORRECT NUMBER OF WORDS HAVE BEEN TRANSFERED AND THAT THE TWO REGISTERS ARE CONSISTENT WITH EACH OTHER; AND IF THE ORDER WAS A READ ORDER, THE DATA BUFFER IS COMPARED. WHEN THIS SEQUENCE IS COMPLETED, THE DRIVE IS RETURNED TO THE ASSIGNED, INACTIVE LIST. THE PROGRAM THEN INITIATES A DATA TRANSFER ON A WAITING DRIVE AND RESELECTS AND REINITIATES ANOTHER OPERATION ON THE RELEASED DRIVE.

ERRORS WHICH OCCUR ARE PROCESSED IN THE FOLLOWING ORDER. MULTIPLE ERRORS WILL BE REPORTED AS THE FIRST ERROR TYPE CHECKED.

A. ERRORS REPORTED FOR OPERATIONS WHICH HAVE NOT COMPLETED NORMALLY.

PERSISTENT UNSAFE CONDITION - EM12  
UNCORRECTABLE MASSBUS PARITY ERROR - EM10  
FATAL MASSBUS PARITY ERROR - EM11  
OPERATION NOT COMPLETED WITHIN TIME LIMIT - EM13  
UNIT WENT OFFLINE - EM14

B. ERRORS REPORTED FOR OPERATIONS WHICH COMPLETE NORMALLY.

CORRECTABLE UNSAFE - EM60  
DRIVE TIMING ERROR - EM32  
DATA CHECK ERROR - EM21  
WRITE CHECK WITH DCK SET - EM22  
HEADER CRC ERRORS - EM20  
FORMAT ERRORS - EM24, EM26  
HEADER COMPARE ERRORS - EM25, EM27  
PROGRAM DETECTED POSITIONING ERROR - EM51  
SEEK INCOMPLETE OR OFF CYLINDER ERROR - EM50  
WRITE CHECK WITHOUT 'DCK' SET - EM23  
RH11 OR UNIBUS TRANSFER ERROR - EM40  
'OPI' ERROR - EM31  
'PAR' ERROR - EM33  
'WCF' ERROR - EM34  
'IAE' ERROR - EM35  
'WLE' ERROR - EM36  
MISCELLANEOUS DRIVE ERROR - EM30

C. ERRORS NOT FLAGGED BY THE HARDWARE ERROR DETECTION LOGIC.

BUS ADDRESS OR WORD COUNT INCORRECT - EM41  
DATA COMPARE ERRORS - NO DRIVE ERROR DETECTED - EM42  
CAN'T MATCH DATA READ WITH A PATTERN - EM43  
ERROR BIT(S) SET, BUT NO ERROR SIGNALLED BY THE RH11 - EM44  
ECC LOGIC FAILURE - EM45  
BUS ADDRESS OR WORD COUNT NOT CONSISTENT - EM46

8.2 DUAL PORT OPERATION

1693  
1694  
1695  
1696  
1697  
1698  
1699  
1700  
1701  
1702  
1703  
1704  
1705  
1706  
1707  
1708  
1709  
1710  
1711  
1712  
1713  
1714  
1715  
1716  
1717  
1718  
1719  
1720  
1721  
1722  
1723  
1724  
1725  
1726  
1727  
1728  
1729  
1730  
1731  
1732  
1733  
1734  
1735  
1736  
1737  
1738  
1739  
1740  
1741  
1742  
1743  
1744  
1745  
1746  
1747  
1748

DUAL PORT OPERATION IS NEARLY IDENTICAL TO THE OPERATION DESCRIBED IN SECTION 8.1. THE DIFFERENCES ARE IN COMMAND SEQUENCE INITIATION AND ORDER TERMINATION.

WHEN THE DUAL PORT HANDLER ROUTINE IN THE EXERCISER PROGRAM RECEIVES A REQUEST FOR A DRIVE, THE PROGRAM VERIFIES THAT THE DRIVE IS ONLINE. THE DRIVE IS SELECTED AND READ THE RMCS1 REGISTER BY TEST THE "DVA" BIT.

IF THE DRIVE IS IN NEUTRAL, THIS WILL SEIZE THE DRIVE. IF THE DRIVE IS SEIZED BY THE OTHER PORT, READING 'RMS1' WILL SET 'PORT REQUEST'. THE PROGRAM CHECKS 'DVA' IN 'RMCS1'. IF THE DRIVE IS AVAILABLE AS INDICATED BY THE 'DVA' BIT, THE COMMAND SEQUENCE WILL BE INITIATED IN THE NORMAL MANNER (SEE SECTION 8.1 ABOVE). IF 'DVA' WAS NOT SET, THE PROGRAM MAKES AN ENTRY FOR THE DRIVE IN AN INTERNAL 'PORT REQUEST PENDING' TABLE AND STARTS A 10 SECOND TIMER FOR THE DRIVE. IF THE DRIVE HAS NOT SWITCHED TO THE REQUESTING SYSTEM WITHIN THE 10 SECOND INTERVAL, THE PROGRAM REPORTS A 'NO RESPONSE TO PORT REQUEST' ERROR. NORMALLY THIS ERROR MESSAGE INDICATES A FAILURE IN THE DUAL PORT CONTROL LOGIC IN THE DRIVE BEING TESTED; HOWEVER, UNDER CERTAIN CONDITIONS (E.G. MASSBUS PARITY ERRORS BEING REPORTED ON THE OTHER SYSTEM ON A MOD33 TTY), THE OTHER PROCESSOR WAS UNABLE TO PROCESS THE DRIVE AFTER IT HAD REQUESTED THE DRIVE. THE OPERATOR MUST BE AWARE OF WHAT THE OTHER SYSTEM IS DOING AT ALL TIMES TO INTERPRET THE PORT RELATED ERROR MESSAGES PROPERLY.

AFTER A DRIVE HAS COMPLETED AN OPERATION, THE PROGRAM WILL STORE THE REGISTERS AND ISSUE A 'RELEASE' TO THE DRIVE. IF THE OPERATION TERMINATED WITH AN ERROR, THE DRIVE WILL NOT BE RELEASED UNTIL ERROR PROCESSING HAS BEEN COMPLETED.

SINGLE PORT DRIVES, DRIVES WHICH ARE IN NEUTRAL BUT NOT BEING EXERCISED BY THE OPPOSITE PORT ARE STILL TREATED AS DUAL PORT DRIVES IN THAT A RELEASE COMMAND IS ISSUED AT THE END OF NORMAL ORDER PROCESSING OR AT THE END OF ERROR PROCESSING. A RELEASE COMMAND ISSUED UNDER THESE CONDITIONS HAS NO FUNCTIONAL EFFECT ON THE OPERATION OF THE DRIVE.

### 8.3 SELECTION OF OPERATION VARIABLES

- A. SECTOR ADDRESS SELECTION IS RANDOM BETWEEN THE VALUES IN 'MINSEC' AND 'MAXSEC'. TRACK ADDRESS SELECTION IS RANDOM BETWEEN THE VALUES IN 'MINTRK' AND 'MAXTRK'. CYLINDER ADDRESS SELECTION IS RANDOM BETWEEN 'MINCYL' AND 'MAXCYL'. IF A MINIMUM ADDRESS IS GREATER THAN THE CORRESPONDING MAXIMUM ADDRESS, THE PROGRAM WILL EXCLUDE ALL ADDRESSES BETWEEN 'MAX' AND 'MIN' FROM THE SELECTION. FOR EXAMPLE: IF 'MINTRK' IS 5 AND 'MAXTRK' IS 2, THEN TRACK ADDRESS SELECTION WILL EXCLUDE TRACKS 3 - 4 FROM THE SELECTION AND SELECT AN ADDRESS FROM AMONG ADDRESSES 5, 0, 1, 2.
- B. THE BUFFER SIZE IS RANDOM SELECTED BETWEEN 4 - AND THE VALUE IN 'SIZE'. THE SIZE SELECTED IS WEIGHTED TO ENSURE THIS IS NECESSARY AS THE PROGRAM REQUIRES 4 LOCATIONS IN THE DATA PORTION OF THE SECTOR TO BE ABLE TO MATCH THE DATA

1749  
1750  
1751  
1752  
1753  
1754  
1755  
1756  
1757  
1758  
1759  
1760  
1761  
1762  
1763  
1764  
1765  
1766  
1767  
1768  
1769  
1770  
1771  
1772  
1773  
1774  
1775  
1776  
1777  
1778  
1779  
1780  
1781  
1782  
1783  
1784  
1785  
1786  
1787  
1788  
1789  
1790  
1791  
1792  
1793  
1794  
1795  
1796  
1797  
1798  
1799  
1800  
1801  
1802  
1803  
1804

TO A PATTERN FOR DATA COMPARISON PURPOSES.

- C. THE DATA WRITTEN IS RANDOMLY SELECTED AMONG THE 15 STANDARD PATTERNS. THE PARAMETER "PATTERN" ENABLES THE RANDOM PATTERN SELECTION, IF THIS PARAMETER IS 0; OTHERWISE, THE DATA PATTERN INDEXED BY THE VALUE "PATTERN" IS SELECTED.
- D. THE ORDERS ARE SELECTED RANDOMLY. WRITE CHECK DATA AND WRITE CHECK HEADER & DATA ORDERS ARE PERFORMED ONLY IF THE PREVIOUS ORDER WAS THE APPROPRIATE DATA ORDER. IF THE 'FORMAT' PARAMETER IS ZERO, THE PROGRAM WILL NOT SELECT WRITE HEADER & DATA (AND WRITE CHECK HEADER & DATA) ORDERS. WHEN THE PROGRAM SELECTS A WRITE HEADER & DATA ORDER, THE BUFFER SIZE IS FORCED TO 258 (10); THE PROGRAM WILL NOT PERFORM A MULTI-SECTOR FORMAT WRITE OPERATION.
- E. THE FIRST ORDER PERFORMED AFTER A UNIT IS ASSIGNED WITH A 'W' OR 'R' COMMAND IS NOT RANDOMLY SELECTED. THE PARAMETERS FOR THE FIRST OPERATION ARE THE MINIMUM OR STARTING VALUES OF THE VARIABLES.

8.4 DATA PATTERNS

THE PROGRAM SELECTS ONE OF THE FOLLOWING DATA PATTERNS TO WRITE WHEN A WRITE ORDER IS SELECTED. THE ENTIRE BUFFER IS FILLED WITH THE SELECTED PATTERN. WHEN DATA IS READ FROM THE DISK, THE PROGRAM COMPARES DATA ON A SECTOR BASIS: FROM THE FIRST 4 DATA WORDS OF EACH SECTOR, THE PROGRAM MATCHES THE DATA TO ONE OF THE FOLLOWING PATTERNS.

PAT 1	PAT 2	PAT 3	PAT 4	PAT 5	PAT 6	PAT 7	PAT 8
000001	177776	000000	133331	052525	155554	026455	066666
000003	177774	000000	133331	052525	155554	026455	066666
000007	177770	000000	133331	052525	155554	026455	066666
000017	177760	177777	133331	125252	155554	151322	066666
000037	177740	177777	133331	125252	155554	151322	066666
000077	177700	177777	133331	125252	155554	151322	066666
000177	177600	000000	133331	052525	155554	026455	066666
000377	177400	000000	133331	052525	155554	026455	066666
000777	177000	177777	133331	125252	155554	151322	066666
001777	176000	177777	133331	125252	155554	151322	066666
003777	174000	000000	133331	052525	155554	026455	066666
007777	170000	177777	133331	125252	155554	151322	066666
017777	160000	000000	133331	052525	155554	026455	066666
037777	140000	177777	133331	125252	155554	151322	066666
077777	100000	000000	133331	052525	155554	026455	066666
177777	000000	177777	133331	125252	155554	151322	066666
PAT 9	PAT 10	PAT 11	PAT 12	PAT 13	PAT 14	PAT 15	
000001	177776	172666	077777	153333	000000	177777	
000002	177775	155555	137777	066667	177777	000000	
000004	177773	172666	157777	153333	177777	000000	
000010	177767	155555	167777	066667	177777	000000	

1805	000020	177757	172666	173777	153333	177777	000000
1806	000040	177737	155555	175777	066667	177777	000000
1807	000100	177677	172666	176777	153333	177777	000000
1808	000200	177577	155555	177377	066667	177777	000000
1809	000400	177377	172666	177577	153333	177777	000000
1810	001000	176777	155555	177677	066667	177777	000000
1811	002000	175777	172666	177737	153333	177777	000000
1812	004000	173777	155555	177757	066667	177777	000000
1813	010000	167777	172666	177767	153333	177777	000000
1814	020000	157777	155555	177773	066667	177777	000000
1815	040000	137777	172666	177775	153333	177777	000000
1816	100000	077777	155555	177776	066667	177777	000000

1817  
1818  
1819  
1820  
1821  
1822  
1823  
1824  
1825  
1826  
1827  
1828  
1829  
1830  
1831  
1832  
1833  
1834  
1835  
1836  
1837  
1838  
1839  
1840  
1841  
1842  
1843  
1844  
1845  
1846  
1847  
1848  
1849  
1850  
1851  
1852  
1853  
1854  
1855  
1856  
1857  
1858  
1859  
1860  
1861  
1862  
1863  
1864  
1865  
1866  
1867  
1868  
1869  
1870  
1871  
1872

9.1 RH70(11)/RMO3 DRIVER  
-----

THIS DOCUMENT IS THE USER'S GUIDE FOR THE RH70/RMO3 DRIVER.

9.2 TO INITIALIZE THE DRIVER:

```
JSR PC,RMINIT  
RETURN
```

UPON RETURN YOU MUST EXAMINE THE "DRVSTA" TABLE TO DETERMINE THE DRIVES THAT ARE ONLINE FOR TESTING. THE 'DRVSTA' TABLE IS EIGHT BYTES; ONE BYTE PER DRIVE. THE STATE OF EACH DRIVE WILL BE INDICATED AS FOLLOWS:

DRVSTA	DRIVE STATE
-----	-----
>0	ONLINE RMO3
=0	OFFLINE RMO3, DRIVE IS NOT AN RMO3, OR NONEXISTENT DRIVE
<0	UNSAFE RMO3

THE DRIVE TYPE IS DEFINED IN AN 8 BYTE LONG TABLE TAGGED 'DRV TYP'. THE TABLE CONTAINS ONE BYTE FOR EACH DRIVE AND IS INDEXED BY THE DRIVE NUMBER. ENTRIES ARE ENCODED AS FOLLOWS:

DRV TYP	CONDITION
-----	-----
0	NONEXISTENT DRIVE
4	RMO3
-1	NOT AN RMO3

THE 'RMINIT' ROUTINE WILL DO A READIN PRESET AND WILL SET FMT22.

9.3 AFTER THE DRIVER HAS BEEN INITIALIZED, IT IS CALLED USING THE FOLLOWING SEQUENCE.

```
CALL: JSR RO,RMO3 ;MAKE THE CALL
PNTDPB ;ADDRESS OF DPB*
RETURN1 ;RETURN IF QUEUE IS FULL
RETURN2 ;RETURN IF REQUEST IS IN
;QUEUE OR THERE IS AN
;ERROR CONDITION
```

\*DPB (DATA PARAMETER BLOCK)

PNTDPB: .BYTE	0	;(0) DRIVE NUMBER
.BYTE	0	;(1) OFFSET VALUE OR FMT22, ECT. AND HCI
.BYTE	0	;(2) COMMAND
.BYTE	0	;(3) PSEL AND A17 AND A16
.WORD	0	;(4) WORD COUNT (MUST BE NEG.)

1873	.WORD	0	: (6) BUFFER ADDRESS OR
1874			: REGISTER TABLE POINTER
1875	.BYTE	0	: (10) SECTOR ADDRESS OR
1876			: FIRST REG. INDEX
1877	.BYTE	0	: (11) TRACK ADDRESS OR
1878			: LAST REG. INDEX
1879	.WORD	0	: (12) CYLINDER ADDRESS
1880	.WORD	0	: (14) ERROR TABLE POINTER
1881			: POINTS TO THE FIRST OF TWENTY
1882			: LOCATIONS OF WHERE THE DRIVER
1883			: IS TO STORE THE RM70/RM03
1884			: REGISTERS ON AN ERROR. IF LEFT
1885			: ZERO REGISTERS ARE NOT SAVED.
1886	.WORD	0	: (16) STATUS/ERROR INDICATOR
1887			: BIT15=1=>ERROR OCCURRED
1888			: BIT07=1=>DONE
1889			: BIT14-BIT09 AND BIT06-BIT03
1890			: INDICATE TYPE OF ERROR

9.4 THE DRIVER PROVIDES A SOFTWARE TIMEOUT CAPABILITY.  
 TO UTILIZE THIS CAPABILITY YOU MUST SUPPLY THE "RM TIMER" ROUTINE  
 WITH THE ELAPSED TIME IN THE FOLLOWING MANNER:

```

MOV    #16.,-(SP)    ;16 MILLISECONDS BETWEEN
                    ;CLOCK TICKS
JSR    PC,RMTMR     ;CALL THE TIMER ROUTINE
  
```

IT SHOULD BE NOTED THAT YOU MUST PROVIDE THE CODE TO DRIVE THE  
 CLOCK. AND THE ELAPSED TIME MUST BE IN MILLISECONDS.  
 THE DRIVER WILL SET THE TIMEOUT TO 1 SECOND FOR ALL POSITIONING  
 AND DATA TRANSFER OPERATIONS AND WILL SET THE TIMOUT TO 30  
 SECONDS FOR ERROR RECOVERY OPERATIONS.

9.4.1 EXAMPLE - WRITE 1000. WORDS

```

1$:    JSR    RO,RM03    ;CALL THE DRIVER
        WRDPB    ;DPB ADDRESS
        BR     1$        ;WAIT FOR QUEUE IF FULL
2$:    TST    WRDPB+16   ;WAIT FOR COMMAND TO COMPLETE
        BEQ    2$
        BMI    ERROR1   ;ERROR OCCURRED
        .
        .
        .
WRDPB: .BYTE    5        ;DRIVE #5
        .BYTE    0
        .BYTE    161    ;WRITE COMMAND
        .BYTE    0
        .WORD    -1000. ;WORD COUNT
        .WORD    WRBUF  ;BUFFER ADDRESS
        .BYTE    3      ;SECTOR
        .BYTE    5      ;TRACK
        .WORD    400    ;CYLINDER
        .WORD    ERRTB5 ;ERROR TABLE
  
```

1873  
1874  
1875  
1876  
1877  
1878  
1879  
1880  
1881  
1882  
1883  
1884  
1885  
1886  
1887  
1888  
1889  
1890  
1891  
1892  
1893  
1894  
1895  
1896  
1897  
1898  
1899  
1900  
1901  
1902  
1903  
1904  
1905  
1906  
1907  
1908  
1909  
1910  
1911  
1912  
1913  
1914  
1915  
1916  
1917  
1918  
1919  
1920  
1921  
1922  
1923  
1924  
1925  
1926  
1927  
1928



1929  
1930  
1931  
1932  
1933  
1934  
1935  
1936  
1937  
1938  
1939  
1940  
1941  
1942  
1943  
1944  
1945  
1946  
1947  
1948  
1949  
1950  
1951  
1952  
1953  
1954  
1955  
1956  
1957  
1958  
1959  
1960  
1961  
1962  
1963  
1964  
1965  
1966  
1967  
1968  
1969  
1970  
1971  
1972  
1973  
1974  
1975  
1976  
1977  
1978  
1979  
1980  
1981  
1982  
1983  
1984

.WORD 0 ;STATUS/ERROR INDICATOR

ALTERNATE DPB SETUP

WRTDPB: .WORD 5 ;THIS SETUP ACHIEVED  
.WORD WRITE ;EVERYTHING THE  
.WORD -1000. ;ABOVE TABLE DID, BUT  
.WORD WRTBUF ;IN A CLEANER FORMAT  
.BYTE 3 5  
.WORD 400,ERRTBS,0

9.5 RH70/RMO3 REGISTERS

MNEMONIC	INDEX
-----	-----
RMCS1	0
RMWC	2
RMBA	4
RMDA	6
RMCS2	10
RMS	12
RMR1	14
RMS	16
RMLA	20
RMDB	22
RMMR1	24
RMDT	26
RMSN	30
RMOF	32
RMDC	34
RMHR	36
RMMR2	40
RMR2	42
RMEC1	44
RMEC2	46

9.6 COMMANDS PERFORMED BY THE DRIVER

COMMAND	CODE	COMMAND TYPE
-----	-----	-----
NO OPERATION	101	N
UNLOAD	103	N
SEEK	105	P
RECALIRATE	107	P
DRIVE CLEAR	111	N
RELEASE	113	N
OFFSET	115	P

1985  
1986  
1987  
1988  
1989  
1990  
1991  
1992  
1993  
1994  
1995  
1996  
1997  
1998  
1999  
2000  
2001  
2002  
2003  
2004  
2005  
2006  
2007  
2008  
2009  
2010  
2011  
2012  
2013  
2014  
2015  
2016  
2017  
2018  
2019  
2020  
2021  
2022  
2023  
2024  
2025  
2026  
2027  
2028  
2029  
2030  
2031  
2032  
2033  
2034  
2035  
2036  
2037  
2038  
2039  
2040

RETURN TO CENTER	117	P
READIN PRESET	121	N
PACK ACKNOWLEDGE	123	N
SEARCH	131	P
GET REGISTER(S)	141	S
SET FORMAT	143	S
SELECT DRIVE	145	S
WRITE CHECK DATA	151	D
WRITE CHECK HEADER AND DATA	153	D
WRITE DATA	161	D
WRITE HEADER & DATA	163	D
READ DATA	171	D
READ HEADER & DATA	173	D

N = HOUSEKEEPING  
P = POSITIONING  
D = DATA TRANSFER  
S = SPECIAL PROVIDED BY THE DRIVER

9.7 DPB STATUS/ERROR INDICATOR WORD

THIS INDICATOR WILL INFORM THE USER OF THE RESULTS OF THE REQUEST.  
THIS IS ACCOMPLISHED BY SETTING VARIES BITS OF THE INDICATOR TO  
A ONE.

<u>BIT NO.</u>	<u>MEANING IF ON A "1"</u>
15	ERROR OCCURRED DONE (BIT07=0); BITS 14-10 SPECIFIES TYPE DONE (BIT07=1); BITS 06-03 SPECIFIES TYPE
14(1)	USER MADE A REQUEST FOR A FUNCTION TO BE PERFORMED ON AN OFFLINE OR UNSAFE DRIVE
13(1)	USER MADE A REQUEST FOR A FUNCTION TO BE PERFORMED ON A DRIVE THAT HAS AN UNLOAD REQUEST IN QUEUE.
12(2)	PERSISTENT UNSAFE CONDITION EXIST.
11(2)	UNCORRECTABLE PARITY ERROR OCCURRED

2041  
2042  
2043  
2044  
2045  
2046  
2047  
2048  
2049  
2050  
2051  
2052  
2053  
2054  
2055  
2056  
2057  
2058  
2059  
2060  
2061  
2062  
2063  
2064  
2065  
2066  
2067  
2068  
2069  
2070  
2071  
2072  
2073  
2074  
2075  
2076  
2077  
2078  
2079  
2080  
2081  
2082  
2083  
2084  
2085  
2086  
2087  
2088  
2089  
2090  
2091  
2092  
2093  
2094  
2095  
2096

10(2)(4)	FATAL PARITY ERROR. A MASSBUS CLEAR WAS PERFORMED, ALL QUEUES WERE EMPTIED, AND ALL DRVACT'S SET TO THE IDLE STATE
9(3)(4)	SOFTWARE TIMEOUT OCCURRED ON THIS DRIVE
8(4)	SOFTWARE TIMEOUT OCCURRED ON ANOTHER DRIVE
7	DONE
6(2)	ERROR OCCURRED DURING AN I/O OPERATION
5(2)	ERROR OCCURRED DURING AN OPERATION OTHER THAN I/O.
4(2)	CORRECTABLE UNSAFE CONDITION OCCURRED
3(2)	DRIVE ERROR OCCURRED THAT CAUSED AN AUTOMATIC "RECALIBRATE" SEQUENCE
2	PORT REQUEST TIMEOUT. THE DRIVER REQUESTED THE DRIVE BUT THE OPPOSITE PORT DID NOT RELEASE THE DRIVE WITHIN 20 SECONDS.
1	NON-EXISTENT DRIVE REQUESTED. USER MADE A REQUEST FOR A NON-EXISTENT DRIVE.
(1) =>	REQUEST WASN'T PUT IN QUEUE. (RH70/RM03 REGISTERS WERE NOT SAVED)
(2) =>	REQUEST QUEUE HAS BEEN EMPTIED. THE DRIVER ISSUED A "DRIVE CLEAR" TO THE DRIVE. NOTE: ALL RH70/RM03 REGISTERS ARE SAVED AS PER DPB+14 BEFORE THE "DRIVE CLEAR".
(3) =>	REQUEST QUEUE HAS BEEN EMPTIED. THE DRIVER ISSUED A MASSBUS INIT. ALL RH70/RM03 REGISTERS FOR THE DRIVE WERE SAVED AS PER DPB+14 BEFORE THE INIT.
(4) =>	A "RECALIBRATE" SHOULD BE ISSUED BEFORE ANY OTHER COMMAND.

9.8 ERROR CALLS MADE BY THE DRIVER.  
THERE ARE A FEW ERRORS THAT CAN OCCUR THAT CAN NOT BE INDICATED IN A DPB.  
WHEN THIS TYPE OF ERROR IS DETECTED BY THE DRIVER IT WILL MAKE AN ERROR CALL OF THE FORM "ERROR N", WHERE "N" IS THE ERROR NUMBER AND THE ERROR WILL BE AN EMT INSTRUCTION.

N	TYPE	DATA AVAILABLE
-	----	-----

2097  
2098  
2099  
2100  
2101  
2102  
2103  
2104  
2105  
2106  
2107  
2108  
2109  
2110  
2111  
2112  
2113  
2114  
2115  
2116  
2117  
2118  
2119  
2120  
2121  
2122  
2123  
2124  
2125  
2126  
2127

- 1 RH70 INTERRUPT OCCURRED (RHAS=0) \*R4= RMCS1'S ADDRESS
- 2 UNEXPECTED ATTENTION OCCURRED R1= DRIVE NUMBER  
R3= ATA BIT  
\*R4= RMCS1'S ADDRESS  
R5= (RMAS)  
RMERRS =RMDS  
RMERRS+2=RMER1  
RMERRS+4=RMER2  
RMERRS+6=RMMR2
- 3 MASSBUS PARITY ERROR (MCPE=1) RD.ADR= ADDRESS OF REG. READ  
RD.WRD= WORD READ
- 4 MASSBUS PARITY ERROR (PAR=1) WRT.AD= ADDRESS OF REG. WRITTEN  
WRT.WD= WORD WRITTEN  
RD.WRD= WORD READ BACK
- 5 ADDRESS PLUG CHANGE BIT SET ('OPE' ERROR) R1= DRIVE NUMBER  
R3= ATA BIT  
\*R4= RMCS1'S ADDRESS  
R5= (RMAS)  
RMERRS =RMDS  
RMERRS+2=RMER1  
RMERRS+4=RMER2  
RMERRS+6=RMMR2

\* THIS IS THE ACTUAL UNIBUS ADDRESS (176700)

Q

2128  
2129  
2130  
2131  
2132  
2133  
2134  
2135  
2136  
2137  
2138  
2139  
2140  
2141  
2142  
2143  
2144  
2145  
2146  
2147  
2148  
2149  
2150  
2151  
2152  
2153  
2154  
2155  
2156  
2157  
2158  
2159  
2160  
2161  
2162  
2163  
2164  
2165  
2166  
2167  
2168  
2169  
2170  
2171  
2172  
2173  
2174  
2175  
2176  
2177  
2178  
2179  
2180  
2181  
2182  
2183

```
.TITLE CZRM880 RM03/2 PERF EXER
.*COPYRIGHT (C) 1977
.*DIGITAL EQUIPMENT CORP.
.*MAYNARD, MASS. 01754
.*
.*PROGRAM BY C. CHEN
.*
.*THIS PROGRAM WAS ASSEMBLED USING THE PDP-11 MAINDEC SYSMAC
.*PACKAGE (MAINDEC-11-DZQAC-C3), JAN 19, 1977.
.*
.SBTTL OPERATIONAL SWITCH SETTINGS
.*
.*      SWITCH      USE
.*      -----      -
.*      15          HALT ON ERROR
.*      13          INHIBIT ERROR TYPEOUTS
.*      10          BELL ON ERROR
.*      7           DISPLAY ALL DATA COMPARE ERRORS
.*      6           DON'T CHANGE PARAMETERS (LOOP ON PRESENT VALUES)
.*      5           A. PARTIAL REGISTER DISPLAY IF ERROR
.*                  B. NO ECC CORRECTION RESULTS DISPLAYED IF ERROR
.*      4           A. DO NOT CHECK FOR MAXIMUM ERROR COUNTS
.*                  B. DO NOT DROP DRIVE WHEN NORMAL END OF TEST REACHED
.*      3           A. DISPLAY ERROR SECTOR IF 'DCK', 'DTE', OR 'WCF' ERROR
.*                  B. DISPLAY SECTOR IF 'DCK' ERR UNCORRECTABLE AFTER
.*                  28TH RETRY
.*                  C. IF DATA COMPARE ERROR & SW7 SET, DISPLAY
.*                      REMAINDER OF BUFFER
.*      2           A. DON'T TYPE SUBSYSTEM STATUS WHEN PROGRAM STARTED
.*                  B. DON'T TYPE PERFORMANCE SUMMARY
.*      1           INHIBIT DATA COMPARISON AFTER READ ORDERS
.*      0           READ ONLY MODE
.*
.SBTTL BASIC DEFINITIONS
.*INITIAL ADDRESS OF THE STACK POINTER *** 1100 ***
STACK= 1100
.EQUIV EMT,ERROR      ;;BASIC DEFINITION OF ERROR CALL
.EQUIV IOT,SCOPE      ;;BASIC DEFINITION OF SCOPE CALL
.*
.*MISCELLANEOUS DEFINITIONS
HT= 11                ;;CODE FOR HORIZONTAL TAB
LF= 12                ;;CODE FOR LINE FEED
CR= 15                ;;CODE FOR CARRIAGE RETURN
CRLF= 200             ;;CODE FOR CARRIAGE RETURN-LINE FEED
PS= 177776           ;;PROCESSOR STATUS WORD
.EQUIV PS,PSW
STKLMT= 177774        ;;STACK LIMIT REGISTER
PIRQ= 177772          ;;PROGRAM INTERRUPT REQUEST REGISTER
DSWR= 177570          ;;HARDWARE SWITCH REGISTER
DDISP= 177570         ;;HARDWARE DISPLAY REGISTER
.*
.*GENERAL PURPOSE REGISTER DEFINITIONS
R0= %0                ;;GENERAL REGISTER
R1= %1                ;;GENERAL REGISTER
R2= %2                ;;GENERAL REGISTER
```

001100

000011  
000012  
000015  
000200  
177776  
  
177774  
177772  
177570  
177570

000000  
000001  
000002

2184	000003	R3=	%3	:: GENERAL REGISTER
2185	000004	R4=	%4	:: GENERAL REGISTER
2186	000005	R5=	%5	:: GENERAL REGISTER
2187	000006	R6=	%6	:: GENERAL REGISTER
2188	000007	R7=	%7	:: GENERAL REGISTER
2189	000006	SP=	%6	:: STACK POINTER
2190	000007	PC=	%7	:: PROGRAM COUNTER
2191				
2192		:*PRIORITY LEVEL DEFINITIONS		
2193	000000	PR0=	0	:: PRIORITY LEVEL 0
2194	000040	PR1=	40	:: PRIORITY LEVEL 1
2195	000100	PR2=	100	:: PRIORITY LEVEL 2
2196	000140	PR3=	140	:: PRIORITY LEVEL 3
2197	000200	PR4=	200	:: PRIORITY LEVEL 4
2198	000240	PR5=	240	:: PRIORITY LEVEL 5
2199	000300	PR6=	300	:: PRIORITY LEVEL 6
2200	000340	PR7=	340	:: PRIORITY LEVEL 7
2201				
2202		:*"SWITCH REGISTER" SWITCH DEFINITIONS		
2203	100000	SW15=	100000	
2204	040000	SW14=	40000	
2205	020000	SW13=	20000	
2206	010000	SW12=	10000	
2207	004000	SW11=	4000	
2208	002000	SW10=	2000	
2209	001000	SW09=	1000	
2210	000400	SW08=	400	
2211	000200	SW07=	200	
2212	000100	SW06=	100	
2213	000040	SW05=	40	
2214	000020	SW04=	20	
2215	000010	SW03=	10	
2216	000004	SW02=	4	
2217	000002	SW01=	2	
2218	000001	SW00=	1	
2219		.EQUIV	SW09,SW9	
2220		.EQUIV	SW08,SW8	
2221		.EQUIV	SW07,SW7	
2222		.EQUIV	SW06,SW6	
2223		.EQUIV	SW05,SW5	
2224		.EQUIV	SW04,SW4	
2225		.EQUIV	SW03,SW3	
2226		.EQUIV	SW02,SW2	
2227		.EQUIV	SW01,SW1	
2228		.EQUIV	SW00,SW0	
2229				
2230		:*DATA BIT DEFINITIONS (BIT00 TO BIT15)		
2231	100000	BIT15=	100000	
2232	040000	BIT14=	40000	
2233	020000	BIT13=	20000	
2234	010000	BIT12=	10000	
2235	004000	BIT11=	4000	
2236	002000	BIT10=	2000	
2237	001000	BIT09=	1000	
2238	000400	BIT08=	400	
2239	000200	BIT07=	200	

2240  
2241  
2242  
2243  
2244  
2245  
2246  
2247  
2248  
2249  
2250  
2251  
2252  
2253  
2254  
2255  
2256  
2257  
2258  
2259  
2260  
2261  
2262  
2263  
2264  
2265  
2266  
2267  
2268  
2269  
2270  
2271  
2272  
2273  
2274  
2275  
2276  
2277  
2278  
2279  
2280  
2281  
2282  
2283  
2284  
2285  
2286  
2287  
2288  
2289  
2290  
2291  
2292  
2293  
2294  
2295

000100  
000040  
000020  
000010  
000004  
000002  
000001  
  
000004  
000010  
000014  
000014  
000014  
000020  
000024  
000030  
000034  
000060  
000064  
000240  
176700  
000254  
  
000100  
000200  
000400  
001000  
002000  
020000  
040000

```
BIT06= 100  
BIT05= 40  
BIT04= 20  
BIT03= 10  
BIT02= 4  
BIT01= 2  
BIT00= 1  
.EQUIV BIT09,BIT9  
.EQUIV BIT08,BIT8  
.EQUIV BIT07,BIT7  
.EQUIV BIT06,BIT6  
.EQUIV BIT05,BIT5  
.EQUIV BIT04,BIT4  
.EQUIV BIT03,BIT3  
.EQUIV BIT02,BIT2  
.EQUIV BIT01,BIT1  
.EQUIV BIT00,BIT0  
  
; *BASIC "CPU" TRAP VECTOR ADDRESSES  
ERRVEC= 4 ; TIME OUT AND OTHER ERRORS  
RESVEC= 10 ; RESERVED AND ILLEGAL INSTRUCTIONS  
TBITVEC= 14 ; "T" BIT  
TRTVEC= 14 ; TRACE TRAP  
BPTVEC= 14 ; BREAKPOINT TRAP (BPT)  
IOTVEC= 20 ; INPUT/OUTPUT TRAP (IOT) **SCOPE**  
PWRVEC= 24 ; POWER FAIL  
EMTVEC= 30 ; EMULATOR TRAP (EMT) **ERROR**  
TRAPVEC= 34 ; "TRAP" TRAP  
TKVEC= 60 ; TTY KEYBOARD VECTOR  
TPVEC= 64 ; TTY PRINTER VECTOR  
PIRQVEC= 240 ; PROGRAM INTERRUPT REQUEST VECTOR  
ABASE=176700  
AVECT1=254  
  
; *****  
.SBTTL RM03 REGISTERS  
; *****  
; CONTROL AND STATUS REGISTER 1 (RMCS1)  
IE= 100 ; INTERRUPT ENABLE (BIT #6)  
RDY= 200 ; READY (BIT #7)  
A16= 400 ; HIGH ORDER BUS ADDRESS BIT (BIT #8)  
A17= 1000 ; HIGH ORDER BUS ADDRESS BIT (BIT #9)  
PSEL= 2000 ; PORT SELECT (BIT #10)  
MCPE= 20000 ; MASSBUSS PARITY ERROR (BIT #13)  
TRE= 40000 ; TRANSFER ERROR (BIT #14)  
; SC= 100000 ; SPECIAL CONDITION (BIT #15)  
  
; WORD COUNT REGISTER (RMWC)  
; (EACH BIT IS CALLED BY BIT NUMBER)  
  
; BUS ADDRESS REGISTER (RMBA)  
; (EACH BIT IS CALLED BY BIT NUMBER)
```

2296  
2297  
2298  
2299  
2300  
2301  
2302  
2303  
2304  
2305  
2306  
2307  
2308  
2309  
2310  
2311  
2312  
2313  
2314  
2315  
2316  
2317  
2318  
2319  
2320  
2321  
2322  
2323  
2324  
2325  
2326  
2327  
2328  
2329  
2330  
2331  
2332  
2333  
2334  
2335  
2336  
2337  
2338  
2339  
2340  
2341  
2342  
2343  
2344  
2345  
2346  
2347  
2348  
2349  
2350  
2351

000001  
000002  
000004  
000010  
000020  
000040  
000100  
000200  
000400  
001000  
002000  
004000  
010000  
020000  
040000  
100000  
  
  
  
  
  
  
  
000001  
000002  
000004  
000010  
000020  
000040  
004000  
  
000001  
000100  
000200  
000400  
001000  
002000  
004000  
010000  
020000  
040000  
100000

```
;CONTROL AND STATUS REGISTER 2 (RMCS2)
US1=      1          ;UNIT SELECT (BIT #0)
US2=      2          ;UNIT SELECT (BIT #1)
US4=      4          ;UNIT SELECT (BIT #2)
BAI=     10          ;BUS ADDRESS INCREMENT INHIBIT (BIT #3)
PAT=     20          ;MASSBUS PARITY TEST (BIT #4)
CLR=     40          ;CLEAR (BIT #5)
IR=     100          ;INPUT READY (BIT #6)
OR=     200          ;OUTPUT READY (BIT #7)
MDPE=   400          ;MASS BUS PARITY ERROR (BIT #8)
MXF=   1000          ;MISSED TRANSFER ERROR (BIT #9)
PGE=   2000          ;PROGRAM ERROR (BIT #10)
NEM=   4000          ;NON EXISTENT MEMORY (BIT #11)
NED=  10000          ;NON EXISTENT DRIVE (BIT #12)
UPE=  20000          ;UNIBUS PARITY ERROR (BIT #13)
WCE=  40000          ;WRITE CHECK ERROR (BIT #14)
DLT= 100000          ;DATA LATE (BIT #15)

;DATA BUFFER REGISTER (RMD8)
;(EACH BIT IS CALLED BY BIT NUMBER)

;;*****

.SBTTL RM03 REGISTERS

;;*****

;CONTROL AND STATUS 1 REGISTER. (#00)
GO=      1          ;GO BIT (BIT #0)
FO=      2          ;FUNCTION CODE BIT #1
F1=      4          ;FUNCTION CODE BIT #2
F2=     10          ;FUNCTION CODE BIT #3
F3=     20          ;FUNCTION CODE BIT #4
F4=     40          ;FUNCTION CODE BIT #5
DVA=   4000          ;DEVICE AVAILABLE (BIT #11)

;DRIVE STATUS REGISTER (RMD51) (#01)
OFFON=   1          ;OFFSET ON (BIT #0)
VV=     100          ;VOLUME VALID (BIT #6)
DRY=     200          ;DRIVE READY (BIT #7)
DPR=     400          ;DRIVE PRESENT (BIT #8)
PGM=    1000          ;PROGRAMABLE (BIT #9)
LBT=    2000          ;LAST SECTOR TRANSFERRED (BIT #10)
WRL=    4000          ;WRITE LOCK (BIT #11)
MOL=   10000          ;MEDIUM ON-LINE (BIT #12)
PIP=   20000          ;POSITIONING OPERATION IN PROGRESS (BIT #13)
ERR=   40000          ;COMPOSITE ERROR (BIT #14)
ATA=  100000          ;ATTENTION ACTIVE (BIT #15)

;ERROR REGISTER #01 (RMER1) (#02)
```



```

2352 000001 ILF= 1 ; ILLEGAL FUNCTION (BIT #0)
2353 000002 ILR= 2 ; ILLEGAL REGISTER (BIT #1)
2354 000004 RMR= 4 ; REGISTER MODIFICATION REFUSED (BIT #2)
2355 000010 PAR= 10 ; PARITY ERROR (BIT #3)
2356 000020 FER= 20 ; FORMAT ERROR (BIT #4)
2357 000040 WCF= 40 ; WRITE CLOCK FAIL (BIT #5)
2358 000100 ECH= 100 ; ECC HARD ERROR (BIT #6)
2359 000200 HCE= 200 ; HEADER COMPARE ERROR (BIT #7)
2360 000400 HCRC= 400 ; HEADER CRC ERROR (BIT #8)
2361 001000 AOE= 1000 ; ADDRESS OVERFLOW ERROR (BIT #9)
2362 002000 IAE= 2000 ; INVALID ADDRESS ERROR (BIT #10)
2363 004000 WLE= 4000 ; WRITE LOCK ERROR (BIT #11)
2364 010000 DTE= 10000 ; DRIVE TIMING ERROR (BIT #12)
2365 020000 OPI= 20000 ; OPERATION INCOMPLETE (BIT #13)
2366 040000 UNS= 40000 ; DRIVE UNSAFE (BIT #14)
2367 100000 DCK= 100000 ; DATA CHECK ERROR (BIT #15)
2368
2369 ; MAINTAINABILITY REGISTER (RMMR1) (#03)
2370
2371
2372 ; ATTENTION SUMMARY PSEUDO-REGISTER (RMAS) (#04)
2373
2374 000001 AT0= 1 ; DEVICE 0 (BIT #0)
2375 000002 AT1= 2 ; DEVICE 1 (BIT #1)
2376 000004 AT2= 4 ; DEVICE 2 (BIT #2)
2377 000010 AT3= 10 ; DEVICE 3 (BIT #3)
2378 000020 AT4= 20 ; DEVICE 4 (BIT #4)
2379 000040 AT5= 40 ; DEVICE 5 (BIT #5)
2380 000100 AT6= 100 ; DEVICE 6 (BIT #6)
2381 000200 AT7= 200 ; DEVICE 7 (BIT #7)
2382
2383 ; DESIRED SECTOR/TRACK ADDRESS REGISTER (RMDA) (#05)
2384
2385
2386 ; DRIVE TYPE REGISTER (RMDT) (#06)
2387
2388 000001 DT00= 1 ; DRIVE TYPE NUMBER BIT 1
2389 000002 DT01= 2 ; DRIVE TYPE NUMBER BIT 2
2390 000004 DT02= 4 ; DRIVE TYPE NUMBER BIT 3
2391 000010 DT03= 10 ; DRIVE TYPE NUMBER BIT 4
2392 000020 DT04= 20 ; DRIVE TYPE NUMBER BIT 5
2393 000040 DT05= 40 ; DRIVE TYPE NUMBER BIT 6
2394 000100 DT06= 100 ; DRIVE TYPE NUMBER BIT 7
2395 000200 DT07= 200 ; DRIVE TYPE NUMBER BIT 8
2396 000400 DT08= 400 ; DRIVE TYPE NUMBER BIT 9
2397 004000 DRQ= 4000 ; DRIVE REQUEST REQUIRED (BIT #11)
2398 020000 MOH= 20000 ; MOVING HEAD (BIT #13)
2399 040000 TAP= 40000 ; TAPE DRIVE (BIT #14)
400 100000 NSA= 100000 ; NOT SECTOR ADDRESSED (BIT #15)
401
402 ; LOOK-AHEAD REGISTER (RMLA) (#07)
403
404 000100 SC1= 100 ; SECTOR COUNT FIELD 0 (BIT #6)
405 000200 SC2= 200 ; SECTOR COUNT FIELD 1 (BIT #7)
406 000400 SC04= 400 ; SECTOR COUNT FIELD 2 (BIT #8)
407 001000 SC10= 1000 ; SECTOR COUNT FIELD 3 (BIT #9)

```

RM03 REGISTERS

```

2408          002000          SC20= 2000          ;SECTOR COUNT FIELD 4 (BIT #10)
2409
2410          ;SERIAL NUMBER REGISTER (RMSN) (#10)
2411          ;(EACH IS CALLED BY BIT NUMBER)
2412          ;OFFSET REGISTER (RMOF) (#11)
2413
2414
2415          000001          OFFDIR= 1          ;RM03 OFFSET DIRECTION
2416          002000          HCI= 2000          ;HEADER COMPARE INHIBIT (BIT #10)
2417          004000          ECI= 4000          ;ERROR CORRECTION CODE INHIBIT (BIT #11)
2418          010000          FMT16= 10000          ;FORMAT BIT (BIT #12)
2419
2420          ;DESIRED CYLINDER ADDRESS (RMDC) (#12)
2421          ;(EACH BIT IS CALLED BY BIT NUMBER)
2422
2423          ;CURRENT CYLINDER ADDRESS (RMCC) (#13)
2424          ;(REGISTER CURRENTLY NOT USED)
2425
2426          ;RM03 ERROR REGISTER #02 (RMER2) (#15)
2427
2428          000010          OPE= 10
2429          000200          DVC= 200
2430          002000          LBC= 2000
2431          004000          LSC= 4000
2432          010000          IVC= 10000
2433          020000          DPE= 20000
2434          040000          SKI= 40000          ;SEEK INCOMPLETE (BIT #14)
2435
2436          ;ECC POSITION REGISTER (RMEC1) (#16)
2437          ;(EACH BIT IS CALLED BY BIT NUMBER)
2438
2439          ;ECC PATTERN REGISTER (RMEC2) (#17)
2440          ;(EACH BIT IS CALLED BY BIT NUMBER)
2441
2442          ;*****
2443          .SBTTL RM03 DRIVER COMMANDS
2444          ;*****
2445
2446          000101          RNOP = 101          ;NO OPERATION
2447          000105          SEEK = 105          ;SEEK
2448          000107          RECAL = 107          ;RECALIBRATE
2449          000111          DRVCLR = 111          ;DRIVE CLEAR
2450          000113          RELSE = 113          ;RELEASE
2451          000115          OFFSET = 115          ;OFFSET
2452          000117          RTC = 117          ;RETURN TO CENTER LINE
2453          000121          READIN = 121          ;READ IN PRESET
2454          000123          ACK = 123          ;PACK ACKNOWLEDGE
2455          000131          SEARCH = 131          ;SEARCH
2456          000141          GETREG = 141          ;GET REGISTERS
2457          000143          SETFMT = 143          ;SET FORMAT (& ECI OR HCI)
2458          000145          SELDRV = 145          ;SELECT DRIVE
2459          000151          WCKD = 151          ;WRITE CHECK DATA
2460          000153          WCKHD = 153          ;WRITE CHECK HEADER & DATA
2461          000161          WRDAT = 161          ;WRITE DATA
2462
2463

```

```

2464      000163      WRTHD      =      163      ;WRITE HEADER & DATA
2465      000171      RDDAT      =      171      ;READ DATA
2466      000173      RDHD       =      173      ;READ HEADER & DATA
2467
2468      .SBTTL TRAP CATCHER
2469
2470      000000      .=0
2471      ;*ALL UNUSED LOCATIONS FROM 4 - 776 CONTAIN A ".+2,HALT"
2472      ;*SEQUENCE TO CATCH ILLEGAL TRAPS AND INTERRUPTS
2473      ;*LOCATION 0 CONTAINS 0 TO CATCH IMPROPERLY LOADED VECTORS
2474
2475      000174      000174      .=174
2476      000176      000000      DISPRG: .WORD 0      ;; SOFTWARE DISPLAY REGISTER
2477      SWREG: .WORD 0      ;; SOFTWARE SWITCH REGISTER
2478      000200      000137      003632      .SBTTL STARTING ADDRESS(ES)
2479      000204      000137      003622      JMP      @#START1      ;; JUMP TO STARTING ADDRESS OF PROGRAM
2480      JMP      @#START      ;; CHANGE THE RM11 UNIBUS ADDRESS
2481      ;AFTER INITIAL START
2482
2483      .SBTTL ACT11 HOOKS
2484
2485      ;*****
2486      ;HOOKS REQUIRED BY ACT11
2487      $SVPC=.      ;SAVE PC
2488      000046      000046      .=46      ;;1)SET LOC.46 TO ADDRESS OF $ENDAD IN .SEOP
2489      000052      000052      $ENDAD      ;;2)SET LOC.52 TO 40000
2490      000052      040000      .=52      ;; RESTORE PC
2491      000210      000210      .WORD 40000
2492      001100      001100      .=$SVPC
2493      .=1100
2494      .SBTTL APT PARAMETER BLOCK
2495
2496      ;*****
2497      ;SET LOCATIONS 24 AND 44 AS REQUIRED FOR APT
2498      ;*****
2499      001100      001100      .SX=.      ;; SAVE CURRENT LOCATION
2500      000024      000024      .=24      ;; SET POWER FAIL TO POINT TO START OF PROGRAM
2501      000044      000044      200      ;; FOR APT START UP
2502      000044      001100      .=44      ;; POINT TO APT INDIRECT ADDRESS PNTR.
2503      001100      001100      $APTHDR      ;; POINT TO APT HEADER BLOCK
2504      001100      001100      .=$X      ;; RESET LOCATION COUNTER
2505      ;*****
2506      ;SETUP APT PARAMETER BLOCK AS DEFINED IN THE APT-PDP11 DIAGNOSTIC
2507      ;INTERFACE SPEC.
2508      001100      001100      $APTHD:
2509      001100      000000      $HIBTS: .WORD 0      ;; TWO HIGH BITS OF 18 BIT MAILBOX ADDR.
2510      001102      001204      $MADR: .WORD $MAIL      ;; ADDRESS OF APT MAILBOX (BITS 0-15)
2511      001104      000264      $STMT: .WORD 180.      ;; RUN TIM OF LONGEST TEST
2512      001106      000264      $PASTM: .WORD 180.      ;; RUN TIME IN SECS. OF 1ST PASS ON 1 UNIT (QUICK VERIFY)
2513      001110      000264      $SUNITM: .WORD 180.      ;; ADDITIONAL RUN TIME (SECS) OF A PASS FOR EACH ADDITIONAL UNIT
2514      001112      000032      .WORD $ETEND-$MAIL/2 ;; LENGTH MAILBOX-ETABLE(WORDS)
2515      001114      TAB.XY=.

```

2516  
2517  
2518  
2519  
2520  
2521  
2522  
2523 001114  
2524 001114 000000  
2525 001116 000  
2526 001117 000  
2527 001120 000000  
2528 001122 000000  
2529 001124 000000  
2530 001126 000000  
2531 001130 000  
2532 001131 001  
2533 001132 000000  
2534 001134 000000  
2535 001136 000000  
2536 001140 000000  
2537 001142 000000  
2538 001144 000000  
2539 001146 000000  
2540 001150 000  
2541 001151 000  
2542 001152 000000  
2543 001154 177570  
2544 001156 177570  
2545 001160 177560  
2546 001162 177562  
2547 001164 177564  
2548 001166 177566  
2549 001170 000  
2550 001171 002  
2551 001172 012  
2552 001173 000  
2553 001174 177607 000377  
2554 001200 077  
2555 001201 015  
2556 001202 000012  
2557  
2558  
2559  
2560  
2561  
2562 001204  
2563 001204 000000  
2564 001206 000000  
2565 001210 000000  
2566 001212 000000  
2567 001214 000000  
2568 001216 000000  
2569 001220 000000  
2570 001222 000000  
2571 001224

.SBTTL COMMON TAGS

\*\*\*\*\*  
: THIS TABLE CONTAINS VARIOUS COMMON STORAGE LOCATIONS  
: USED IN THE PROGRAM.

.=TAB.XY

SCMTAG: ; START OF COMMON TAGS  
: .WORD 0  
\$STNM: .BYTE 000  
\$ERFLG: .BYTE 000  
\$ICNT: .WORD 000  
\$LPADR: .WORD 000  
\$LPERR: .WORD 000  
\$ERTTL: .WORD 000  
\$ITEMB: .BYTE 000  
\$ERMAX: .BYTE 1  
\$ERRPC: .WORD 000  
\$GDADR: .WORD 000  
\$BDADR: .WORD 000  
\$GDDAT: .WORD 000  
\$BDDAT: .WORD 000  
: .WORD 000  
\$AUTOB: .BYTE 000  
\$INTAG: .BYTE 000  
: .WORD 0  
\$SWR: .WORD DSWR  
\$DISPLAY: .WORD DDISP  
\$TKS: 177560  
\$TKB: 177562  
\$TPS: 177564  
\$TPB: 177566  
\$NULL: .BYTE 0  
\$FILLS: .BYTE 2  
\$FILLC: .BYTE 12  
\$TPFLG: .BYTE 0  
\$BELL: .ASCIZ <207><377><377>  
\$QUES: .ASCII /?/  
\$CRLF: .ASCII <15>  
\$LF: .ASCIZ <12>  
\*\*\*\*\*

CONTAINS THE TEST NUMBER  
CONTAINS ERROR FLAG  
CONTAINS SUBTEST ITERATION COUNT  
CONTAINS SCOPE LOOP ADDRESS  
CONTAINS SCOPE RETURN FOR ERRORS  
CONTAINS TOTAL ERRORS DETECTED  
CONTAINS ITEM CONTROL BYTE  
CONTAINS MAX. ERRORS PER TEST  
CONTAINS PC OF LAST ERROR INSTRUCTION  
CONTAINS ADDRESS OF 'GOOD' DATA  
CONTAINS ADDRESS OF 'BAD' DATA  
CONTAINS 'GOOD' DATA  
CONTAINS 'BAD' DATA  
RESERVED--NOT TO BE USED  
AUTOMATIC MODE INDICATOR  
INTERRUPT MODE INDICATOR  
ADDRESS OF SWITCH REGISTER  
ADDRESS OF DISPLAY REGISTER  
TTY KBD STATUS  
TTY KBD BUFFER  
TTY PRINTER STATUS REG. ADDRESS  
TTY PRINTER BUFFER REG. ADDRESS  
CONTAINS NULL CHARACTER FOR FILLS  
CONTAINS # OF FILLER CHARACTERS REQUIRED  
INSERT FILL CHARS. AFTER A "LINE FEED"  
"TERMINAL AVAILABLE" FLAG (BIT<07>=0=YES)  
CODE FOR BELL  
QUESTION MARK  
CARRIAGE RETURN  
LINE FEED

.SBTTL APT MAILBOX-ETABLE

\*\*\*\*\*

.EVEN  
\$MAIL: ; APT MAILBOX  
\$MSGTY: .WORD AMSGTY ; MESSAGE TYPE CODE  
\$FATAL: .WORD AFATAL ; FATAL ERROR NUMBER  
\$TESTN: .WORD ATESTN ; TEST NUMBER  
\$PASS: .WORD APASS ; PASS COUNT  
\$DEVCT: .WORD ADEVCT ; DEVICE COUNT  
\$UNIT: .WORD AUNIT ; I/O UNIT NUMBER  
\$MSGAD: .WORD AMSGAD ; MESSAGE ADDRESS  
\$MSGLG: .WORD AMSGLG ; MESSAGE LENGTH  
\$ETABLE: ; APT ENVIRONMENT TABLE

M04

CZRM880 RMO3/2 PERF EXER  
CZRM88.P11 21-NOV-77 15:34

MACY11 30(1046) 22-NOV-77 10:06 PAGE 52  
APT MAILBOX-ETABLE

SEQ 0051

2572	001224	000			\$ENV: .BYTE	AENV	:: ENVIRONMENT BYTE
2573	001225	000			\$ENVM: .BYTE	AENVM	:: ENVIRONMENT MODE BITS
2574	001226	000000			\$SWREG: .WORD	ASWREG	:: APT SWITCH REGISTER
2575	001230	000000			\$USWR: .WORD	AUSWR	:: USER SWITCHES
2576	001232	000000			\$CPUOP: .WORD	ACPUOP	:: CPU TYPE, OPTIONS
2577					::*		BITS 15-11=CPU TYPE
2578					::*		11/04=01, 11/05=02, 11/20=03, 11/40=04, 11/45=05
2579					::*		11/70=06, PDQ=07, Q=10
2580					::*		BIT 10=REAL TIME CLOCK
2581					::*		BIT 9=FLOATING POINT PROCESSOR
2582					::*		BIT 8=MEMORY MANAGEMENT
2583	001234	000			\$MAMS1: .BYTE	AMAMS1	:: HIGH ADDRESS, M.S. BYTE
2584	001235	000			\$MTYP1: .BYTE	AMTYP1	:: MEM. TYPE, BLK#1
2585					::*		MEM. TYPE BYTE -- (HIGH BYTE)
2586					::*		900 NSEC CORE=001
2587					::*		300 NSEC BIPOLAR=002
2588					::*		500 NSEC MOS=003
2589	001236	000000			\$MADR1: .WORD	AMADR1	:: HIGH ADDRESS, BLK#1
2590					::*		MEM. LAST ADDR.=3 BYTES, THIS WORD AND LOW OF "TYPE" ABOVE
2591	001240	000			\$MAMS2: .BYTE	AMAMS2	:: HIGH ADDRESS, M.S. BYTE
2592	001241	000			\$MTYP2: .BYTE	AMTYP2	:: MEM. TYPE, BLK#2
2593	001242	000000			\$MADR2: .WORD	AMADR2	:: MEM. LAST ADDRESS, BLK#2
2594	001244	000			\$MAMS3: .BYTE	AMAMS3	:: HIGH ADDRESS, M.S. BYTE
2595	001245	000			\$MTYP3: .BYTE	AMTYP3	:: MEM. TYPE, BLK#3
2596	001246	000000			\$MADR3: .WORD	AMADR3	:: MEM. LAST ADDRESS, BLK#3
2597	001250	000			\$MAMS4: .BYTE	AMAMS4	:: HIGH ADDRESS, M.S. BYTE
2598	001251	000			\$MTYP4: .BYTE	AMTYP4	:: MEM. TYPE, BLK#4
2599	001252	000000			\$MADR4: .WORD	AMADR4	:: MEM. LAST ADDRESS, BLK#4
2600	001254	000254			\$VECT1: .WORD	AVECT1	:: INTERRUPT VECTOR#1, BUS PRIORITY#1
2601	001256	000000			\$VECT2: .WORD	AVECT2	:: INTERRUPT VECTOR#2, BUS PRIORITY#2
2602	001260	176700			\$BASE: .WORD	ABASE	:: BASE ADDRESS OF EQUIPMENT UNDER TEST
2603	001262	000000			\$DEVN: .WORD	ADEVN	:: DEVICE MAP
2604	001264	000000			\$CDW1: .WORD	ACDW1	:: CONTROLLER DESCRIPTION WORD#1
2605	001266	000000			\$CDW2: .WORD	ACDW2	:: CONTROLLER DESCRIPTION WORD#2
2606	001270				SETEND:		
2607					.MEXIT		
2608		000015			CR =	15	
2609		000012			LF =	12	
2610	001270	176700			\$RMADR: .WORD	176700	:: FIRST ADDRESS OF RH11/RM03 REGISTERS
2611	001272	000254			\$RMVEC: .WORD	254	:: RM03 VECTOR ADDRESS
2612	001274	172540			\$LKCSR: .WORD	172540	:: ADDR OF KW11-P STATUS REGISTER
2613	001276	172542			\$LKCSB: .WORD	172542	:: ADDR OF KW11-P COUNTER BUFFER
2614	001300	000104			\$LPVEC: .WORD	104	:: ADDR OF KW11-P VECTOR
2615	001302	177546			\$LKS: .WORD	177546	:: ADDR OF KW11-L STATUS REGISTER
2616	001304	000100			\$LLVEC: .WORD	100	:: ADDR OF KW11-L VECTOR
2617	001306	177777			PCLOCK: .WORD	-1	:: '0' IF KW11-P IS ON SYSTEM
2618	001310	177777			CLKFLG: .WORD	-1	:: '0' IF A CLOCK IS AVAILABLE
2619	001312	000074			HZ: .WORD	74	:: 74 (8) IF 60 HZ SYSTEM; 62 (8) IF 50 HZ SYSTEM
2620	001314	000000			STATIN: .WORD	0	:: 'TYPE STATISTICS' INDICATOR
2621	001316	000000			PACK: .WORD	0	:: 'W' COMMAND INDICATOR
2622	001320	000000	000000	000000	DATE: .WORD	0,0,0,0,0	:: OPERATOR ENTERED DATE
2623	001326	000000	000000				
2624	001332	000000	000000	000000	OPERID: .WORD	0,0,0,0	:: OPERATOR ID
2625	001340	000000					
2626		001216			DRIVE =	\$UNIT	:: DRIVE # STORAGE: ERRORS 1-5 & 10
2627	001342	000000			ATTN: .WORD	0	:: ATTN REG STORAGE: ERRORS 1-5 & 10

2628	001344	000000	UNIT:	.WORD	0	: DRIVE # STORAGE FOR PRINTOUT
2629	001346	000000	MASK:	.WORD	0	: ERROR RETRY REGISTER MASK
2630	001350	000	RETRY:	.BYTE	0,0	: ERROR RETRY LIMIT IN THE LOWER BYTE
2631						: RETRY COUNT IN THE UPPER BYTE
2632	001352	000003	FAIRNS:	.WORD	3	: MAXIMUM TIME IN QUEUE VALUE
2633	001354	000000	LSTAD:	.WORD	0	: STORE LAST MEMORY ADDRESS HERE
2634	001356	000000	CHGADR:	.WORD	0	: CHANGE RH11 UNIBUS ADDRESS FLAG
2635	001360	000000	CFLAG:	.WORD	0	: 'CONTROL C' FLAG
2636	001362	000000	BADSEC:	.WORD	0	: BAD SECTOR/TRACK FLAG
2637	001364	000000	HOUR:	.WORD	0	: HOUR COUNT STORED HERE (MAXIMUM - 999.)
2638	001366	000000	MINUTE:	.WORD	0	: MINUTE'S COUNT STORED HERE
2639	001370	000000	SECOND:	.WORD	0	: SECOND'S COUNT STORED HERE
2640	001372	000000	SIXTEE:	.WORD	0	: TIMER ROUTINE COUNTER (FOR ONE SECOND)
2641	001374	177777	ZROIND:	.WORD	-1	: ZERO INDICATOR FOR THE DATA COMPARE ROUTINE
2642	001376	000	FRSTER:	.BYTE	0	: DATA COMPARE ERROR FLAG
2643						: IF > 0, PROCESSING 'DCKER' OR CAN'T MATCH PATTERN
2644						: IF < 0, MISCOMPARISON FOUND
2645	001377	000		.BYTE	0	: MISCOMPARISON OR CAN'T MATCH PATTERN FLAG
2646						: IF < 0, ERROR IN BUFFER
2647	001400	000000	SAVER1:	.WORD	0	: SAVE R1 HERE
2648	001402	000000	SAVERS:	.WORD	0	: GAVE RS HERE
2649	001404	000000	ERCTR:	.WORD	0	: NUMBER OF ERRORS
2650	001406	000000	LIMIT:	.WORD	0	: DISPLAY LIMIT
2651	001410	000000	CMCNT:	.WORD	0	: WORD COUNT
2652	001412	000000	CMCYL:	.WORD	0	: CYLINDER ADDRESS
2653	001414	000	CMSEC:	.BYTE	0	: SECTOR ADDRESS
2654	001415	000	CMTRK:	.BYTE	0	: TRACK ADDRESS
2655	001416	000000	ECBIT:	.WORD	0	: ERROR BURST BIT OFFSET
2656	001420	000000	ECSEC:	.WORD	0	: ERROR BURST WORD OFFSET (RELATIVE TO SECTOR)
2657	001422	000000	ECMSKO:	.WORD	0	: CORRECTION MASK FOR FIRST ERROR WORD
2658	001424	000000	ECMSK1:	.WORD	0	: CORRECTION MASK FOR SECOND ERROR WORD
2659	001426	000000	ECWRD:	.WORD	0	: LOCATION OF FIRST ERROR WORD
2660	001430	000000	ECGD:	.WORD	0	: GOOD DATA, FIRST WORD
2661	001432	000000	ECBADO:	.WORD	0	: BAD DATA, FIRST WORD
2662	001434	000000	ECWRD1:	.WORD	0	: LOCATION OF SECOND ERROR WORD
2663	001436	000000	ECGD1:	.WORD	0	: GOOD DATA, SECOND WORD
2664	001440	000000	ECBAD1:	.WORD	0	: BAD DATA, SECOND WORD
2665	001442	000037	SECLMT:	.WORD	31.	: SECTOR ADDRESS LIMIT
2666	001444	000004	TRKLMT:	.WORD	4.	: TRACK ADDRESS LIMIT
2667	001446	001465	CYLINT:	.WORD	821.	: CYLINDER ADDRESS LIMIT FOR RMO3
2668						
2669						;*****
2670						
2671						.SBTTL COMMON PARAMETERS
2672						
2673						;*****
2674						
2675	001450	002740	ENDCON:	.WORD	002740	: 1.875X10 <sup>18</sup> WORDS (10) [3X10 <sup>19</sup> BITS]
2676	001452	005455		.WORD	005455	: MSW
2677	001454	143300	ENDSEK:	.WORD	143300	: 3 X 10 <sup>16</sup> SEEKS (LSW)
2678	001456	000055		.WORD	55	: MSW
2679	001460	000001	PASCNT:	.WORD	1	: NUMBER OF PASSES TO END OF TEST
2680	001462	000000	MAXDL:	.WORD	0	: MAXIMUM DATA TRANSFER SIZE IN WORDS
2681						: (FILLED BY PROGRAM AT STARTUP OR BY OPERATOR
2682						: DURING PARAMETER ENTRY DIALOG.)
2683	001464	000144	MAXER:	.WORD	100.	: MAXIMUM ERRORS - 100(10)

```

2684 001466 000005 000000      INTRVL: .WORD  5,0
2685
2686
2687
2688 001472 000004      CMLPMT: .WORD  4
2689 001474 000001      FORMAT: .WORD  1
2690
2691 001476 000000      WCSEL:  .WORD  0
2692
2693
2694
2695 001500 000003      RATIO:  .WORD  3
2696
2697
2698
2699
2700
2701
2702
2703
2704 001502 000001      AUTOCK: .WORD  1
2705
2706
2707
2708 001504 000001      NOTPRT: .WORD  1
2709
2710
2711
2712
2713 001506 000001      ENDET:  .WORD  1
2714
2715
2716
2717 001510 000000      PATTEN: .WORD  0
2718
2719
2720 001512 000000      HEADER: .WORD  0
2721
2722
2723
2724
2725
2726
2727
2728
2729
2730
2731 001514 000010      BEGPAT: .WORD 10
2732 001516 000004      BEGCOD: .WORD  4
2733
2734
2735
2736
2737
2738
2739 001520 000400      BEGSIZ: .WORD 400

```

```

:FIRST WORD IS THE PERFORMANCE TYPEOUT INTERVAL
:(IN MINUTES). SECOND WORD IS THE INTERVAL
:COUNTER
:COUNTER. UPPER BYTE IS VALUE.
:NUMBER OF COMPARE ERRORS TYPED OUT
:IF NOT EQ 0, ALLOW WRITE HEADER & DATA ORDERS
:IF EQ 0, DO NOT ALLOW WRITE HEADER & DATA ORDERS
:IF EQ TO 0, GENERATE A RANDOM WORD COUNT
:FOR THE OPERATION.
:IF NOT EQ TO 0, USE THE VALUE IN 'MAXDL' FOR
:THE WORD COUNT
:READ/WRITE RATIO [RANGE 0 - 7]
:0 - 0/8 (READ/WRITE)
:1 - 7/1
:2 - 6/2
:3 - 5/3
:4 - 4/4
:5 - 3/5
:6 - 2/6
:7 - 1/7
:IF NOT EQ 0, DO AN APPROPRIATE WRITE
:CHECK AFTER EACH WRITE ORDER.
:IF EQ 0, SELECT WRITE CHECK ORDERS
:RANDOMLY.
:IF EQ 1, DO NOT PRINT DATA ERROR MESSAGES
:ASSOCIATED WITH OPERATOR SPECIFIED
:BAD PACK AREAS.
:IF NOT EQ 0, PRINT ERROR MESSAGES RELATING TO
:THESE AREAS.
:IF NOT EQ 0, END OF PASS DETERMINED
:BY THE 'WORDS READ' COUNT.
:IF EQ 0, END OF PASS DETERMINED
:BY THE SEEK COUNT.
:IF EQ 0, RANDOMLY SELECT DATA PATTERN
:IF NOT EQ 0, SELECT ONE SET OF PATTERN
:POINTED BY THE "PATTEN".
:IF EQ TO 0, RANDOMLY SELECT DATA BLOCK
:ADDRESS. IF NOT EQU 0, SEQUENTIALLY
:SELECT DATA BLOCK ADDRESS

```

::\*\*\*\*\*

.SBTTL VALUES FOR FIRST OPERATION

::\*\*\*\*\*

```

:STARTING PATTERN CODE [RANGE 1 - 17 (OCTAL)]
:STARTING COMMAND CODE [RANGE 0 - 5]
:0 = WRITE CHECK DATA ('WCKD')
:1 = WRITE CHECK HEADER & DATA ('WCHKHD')
:2 = WRITE DATA ('WRDAT')
:3 = WRITE HEADER & DATA ('WRTHD')
:4 = READ DATA ('RDDAT')
:5 = READ HEADER & DATA ('RDHD')
:STARTING RECORD SIZE [RANGE 4 - MAXMEM]

```

```
2740  
2741 ;*****  
2742 .SBTTL TABLES, CONSTANTS, AND VARIABLE LOCATIONS  
2743 ;*****  
2744  
2745  
2746  
2747 001522 000000 000000 000000 ORDERQ: .WORD 0,0,0,0,0,0,0,0,0 ;LIST OF DRIVES PERFORMING COMMANDS  
2748 001530 000000 000000 000000  
2749 001536 000000 000000 000000  
2750  
2751 001544 000000 ASNLST: .WORD 0 ;A BIT SET IS AN ASSIGNED DRIVE  
2752  
2753 001546 000000 000000 000000 DUNIT: .WORD 0,0,0,0,0,0,0,0,0 ;ADDRESSES OF DRIVES TO BE DEASSIGNED  
2754 001554 000000 000000 000000  
2755 001562 000000 000000 000000  
2756  
2757 001570 000000 000000 000000 NEWUNT: .WORD 0,0,0,0,0,0,0,0,0 ;ADDRESSES OF NEWLY ASSIGNED DRIVES  
2758 001576 000000 000000 000000  
2759 001604 000000 000000 000000  
2760  
2761 001612 000000 000000 000000 AVAIL: .WORD 0,0,0,0,0,0,0,0,0 ;LIST OF DRIVES WAITING FOR BUFFERS/PARAMETERS  
2762 001620 000000 000000 000000  
2763 001626 000000 000000 000000  
2764  
2765 001634 000000 000000 000000 WAIT: .WORD 0,0,0,0,0,0,0,0,C ;LIST OF DRIVES WAITING FOR BUFFERS  
2766 001642 000000 000000 000000  
2767 001650 000000 000000 000000  
2768  
2769 001656 000000 000000 000000 PARQ: .WORD 0,0,0,0,0,0,0,0,0 ;LIST OF DRIVES WAITING FOR NEXT PARAMETERS  
2770 001664 000000 000000 000000  
2771 001672 000000 000000 000000  
2772  
2773 001700 000000 BUFTBL: .WORD 0 ;BUFFER ALLOCATION TABLE ENTRY COUNT  
2774 001702 000000 000000 .WORD 0,0  
2775 001706 000000 000000 .WORD 0,0  
2776 001712 000000 000000 .WORD 0,0  
2777 001716 000000 000000 .WORD 0,0  
2778 001722 000000 000000 .WORD 0,0  
2779 001726 000000 000000 .WORD 0,0  
2780 001732 000000 000000 .WORD 0,0  
2781 001736 000000 000000 .WORD 0,0  
2782 001742 000000 000000 .WORD 0,0  
2783 001746 000000 000000 .WORD 0,0  
2784 001752 000000 000000 .WORD 0,0  
2785 001756 000000 000000 .WORD 0,0  
2786 001762 000000 000000 .WORD 0,0  
2787 001766 000000 000000 .WORD 0,0  
2788 001772 000000 000000 .WORD 0,0  
2789 001776 000000 000000 .WORD 0,0  
2790 002002 000000 000000 .WORD 0,0  
2791 002006 000000 000000 .WORD 0,0  
2792 002012 000000 000000 .WORD 0,0  
2793 002016 000000 000000 .WORD 0,0  
2794 002022 000000 000000 .WORD 0,0  
2795 002026 000000 000000 .WORD 0,0
```



2796	002032	000000	000000		.WORD	0,0	
2797	002036	000000	000000		.WORD	0,0	
2798	002042	000000	000000		.WORD	0,0	
2799	002046	000000	000000		.WORD	0,0	
2800	002052	000000	000000		.WORD	0,0	
2801	002056	000000	000000		.WORD	0,0	
2802	002062	000000	000000		.WORD	0,0	
2803	002066	000000	000000		.WORD	0,0	
2804	002072	000000	000000		.WORD	0,0	
2805	002076	000000	000000		.WORD	0,0	
2806							
2807	002102	043022		BLKADR:	.WORD	DRIVE0	: ADDRESS OF THE PARAMETER BLOCK FOR DRIVE 0
2808	002104	043326			.WORD	DRIVE1	: ADDRESS OF THE PARAMETER BLOCK FOR DRIVE 1
2809	002106	043632			.WORD	DRIVE2	: ADDRESS OF THE PARAMETER BLOCK FOR DRIVE 2
2810	002110	044136			.WORD	DRIVE3	: ADDRESS OF THE PARAMETER BLOCK FOR DRIVE 3
2811	002112	044442			.WORD	DRIVE4	: ADDRESS OF THE PARAMETER BLOCK FOR DRIVE 4
2812	002114	044746			.WORD	DRIVE5	: ADDRESS OF THE PARAMETER BLOCK FOR DRIVE 5
2813	002116	045252			.WORD	DRIVE6	: ADDRESS OF THE PARAMETER BLOCK FOR DRIVE 6
2814	002120	045556			.WORD	DRIVE7	: ADDRESS OF THE PARAMETER BLOCK FOR DRIVE 7
2815							
2816	002122	151		COMTBL:	.BYTE	WCKD	: WRITE CHECK DATA
2817	002123	153			.BYTE	WCKHD	: WRITE CHECK HEADER AND DATA
2818	002124	161			.BYTE	WRDAT	: WRITE DATA
2819	002125	163			.BYTE	WRTHD	: WRITE HEADER AND DATA
2820	002126	171			.BYTE	RDDAT	: READ DATA
2821	002127	173			.BYTE	RDHD	: READ HEADER AND DATA
2822							
2823	002130	002		OPTBL:	.BYTE	2	: UNLOAD
2824	002131	004			.BYTE	4	: SEEK
2825	002132	006			.BYTE	6	: RECAL
2826	002133	010			.BYTE	10	: DRIVE CLEAR
2827	002134	012			.BYTE	12	: RELEASE
2828	002135	014			.BYTE	14	: OFFSET
2829	002136	016			.BYTE	16	: RETURN TO CENTERLINE
2830	002137	020			.BYTE	20	: READIN PRESET
2831	002140	022			.BYTE	22	: PACK ACKNOWLEDGE
2832	002141	030			.BYTE	30	: SEARCH
2833	002142	050			.BYTE	50	: WRITE CHECK DATA
2834	002143	052			.BYTE	52	: WRITE CHECK HEADER AND DATA
2835	002144	060			.BYTE	60	: WRITE DATA
2836	002145	062			.BYTE	62	: WRITE HEADER AND DATA
2837	002146	070			.BYTE	70	: READ DATA
2838	002147	072			.BYTE	72	: READ HEADER AND DATA
2839	002150	377			.BYTE	-1	: TERMINATOR
2840							
2841		002152		.EVEN			
2842							
2843							
2844	002152	047125	047514	042101	MNTBL:	.ASCIZ	/UNLOAD /
2845	002160	000040					
2846	002162	042523	045505	020040		.ASCIZ	/SEEK /
2847	002170	000040					
2848	002172	042522	040503	020114		.ASCIZ	/RECAL /
2849	002200	000040					
2850	002202	051104	041526	051114		.ASCIZ	/DRVCLR /
2851	002210	000040					

2852	002212	042522	051514	020105	.ASCIZ	/RELSE	/
2853	002220	000040					
2854	002222	043117	051506	052105	.ASCIZ	/OFFSET	/
2855	002230	000040					
2856	002232	052122	020103	020040	.ASCIZ	/RTC	/
2857	002240	000040					
2858	002242	042522	042101	047111	.ASCIZ	/READIN	/
2859	002250	000040					
2860	002252	040520	045503	020040	.ASCIZ	/PACK	/
2861	002260	000040					
2862	002262	042523	051101	044103	.ASCIZ	/SEARCH	/
2863	002270	000040					
2864	002272	041527	042113	020040	.ASCIZ	/WCKD	/
2865	002300	000040					
2866	002302	041527	044113	020104	.ASCIZ	/WCKHD	/
2867	002310	000040					
2868	002312	051127	042124	052101	.ASCIZ	/WRTDAT	/
2869	002320	000040					
2870	002322	051127	044124	020104	.ASCIZ	/WRTHD	/
2871	002330	000040					
2872	002332	042122	040504	020124	.ASCIZ	/RDDAT	/
2873	002340	000040					
2874	002342	042122	042110	020040	.ASCIZ	/RDHD	/
2875	002350	000040					
2876	002352	047516	042516	020040	.ASCIZ	/NONE	/
2877	002360	000040					
2878							
2879							

2880	002362	043101	042524	020122	OFMSG0:	.ASCIZ	/AFTER RETRY WITHOUT OFFSET/
2881	002370	042522	051124	020131			
2882	002376	044527	044124	052517			
2883	002404	020124	043117	051506			
2884	002412	052105	000				
2885	002415	101	020124	042516	OFMSG1:	.ASCIZ	/AT NEGATIVE OFFSET/
2886	002422	040507	044524	042526			
2887	002430	047440	043106	042523			
2888	002436	000124					
2889	002440	052101	050040	051517	OFMSG2:	.ASCIZ	/AT POSITIVE OFFSET/
2890	002446	052111	053111	020105			
2891	002454	043117	051506	052105			
2892	002462	000					
2893							

2894		002464			.EVEN		
2895							
2896	002464	000			OFFCOD:	.BYTE	0
2897	002465	001				.BYTE	1
2898	002466	000				.BYTE	0
2899							
2900		002470			.EVEN		
2901							
2902	002470	002362			OFMTBL:	.WORD	OFMSG0
2903	002472	002415				.WORD	OFMSG1
2904	002474	002440				.WORD	OFMSG2
2905							
2906							
2907							

; OFFSET CODE TABLE  
; NUMBER FOR NEGATIVE OFFSET (DIR = OUT)  
; NUMBER FOR POSITIVE OFFSET (DIR = IN)  
; 1ST OFFSET MESSAGE  
; 2ND OFFSET MESSAGE  
; 3RD OFFSET MESSAGE

; \*\*\*\*\*

2908  
2909  
2910  
2911  
2912  
2913 002476 002542  
2914 002500 002602  
2915 002502 002642  
2916 002504 002702  
2917 002506 002742  
2918 002510 003002  
2919 002512 003042  
2920 002514 003102  
2921 002516 003142  
2922 002520 003202  
2923 002522 003242  
2924 002524 003302  
2925 002526 003342  
2926 002530 003402  
2927 002532 003442  
2928 002534 003502  
2929 002536 002542  
2930 002540 003444  
2931  
2932 002542 000000  
2933 002544 000000  
2934 002546 000000  
2935 002550 000000  
2936 002552 000000  
2937 002554 000000  
2938 002556 000000  
2939 002560 000000  
2940 002562 000000  
2941 002564 000000  
2942 002566 000000  
2943 002570 000000  
2944 002572 000000  
2945 002574 000000  
2946 002576 000000  
2947 002600 000000  
2948  
2949 002602 000001  
2950 002604 000003  
2951 002606 000007  
2952 002610 000017  
2953 002612 000037  
2954 002614 000077  
2955 002616 000177  
2956 002620 000377  
2957 002622 000777  
2958 002624 001777  
2959 002626 003777  
2960 002630 007777  
2961 002632 017777  
2962 002634 037777  
2963 002636 077777

.SBTTL DATA PATTERNS

;\*\*\*\*\*

STNDAT: .WORD DATA0 ;STANDARD DATA PATTERN POINTER TABLE

.WORD DATA1  
.WORD DATA1+40  
.WORD DATA1+100  
.WORD DATA1+140  
.WORD DATA1+200  
.WORD DATA1+240  
.WORD DATA1+300  
.WORD DATA1+340  
.WORD DATA1+400  
.WORD DATA1+440  
.WORD DATA1+500  
.WORD DATA1+540  
.WORD DATA1+600  
.WORD DATA1+640  
.WORD DATA1+700  
.WORD DATA0  
.WORD DATA1+642

;ZER0ES  
;ONES

DATA0: .WORD 0 ;DUMMY DATA PATTERN

.WORD 0  
.WORD 0  
.WORD 0  
.WORD 0  
.WORD 0  
.WORD 0  
.WORD 0  
.WORD 0  
.WORD 0  
.WORD 0  
.WORD 0  
.WORD 0  
.WORD 0  
.WORD 0  
.WORD 0  
.WORD 0  
.WORD 0

DATA1: .WORD 000001 ;STANDARD PATTERN 1

.WORD 000003  
.WORD 000007  
.WORD 000017  
.WORD 000037  
.WORD 000077  
.WORD 000177  
.WORD 000377  
.WORD 000777  
.WORD 001777  
.WORD 003777  
.WORD 007777  
.WORD 017777  
.WORD 037777  
.WORD 077777

2964	002640	177777	.WORD	177777	
2965					
2966	002642	177776	.WORD	177776	; STANDARD PATTERN 2
2967	002644	177774	.WORD	177774	
2968	002646	177770	.WORD	177770	
2969	002650	177760	.WORD	177760	
2970	002652	177740	.WORD	177740	
2971	002654	177700	.WORD	177700	
2972	002656	177600	.WORD	177600	
2973	002660	177400	.WORD	177400	
2974	002662	177000	.WORD	177000	
2975	002664	176000	.WORD	176000	
2976	002666	174000	.WORD	174000	
2977	002670	170000	.WORD	170000	
2978	002672	160000	.WORD	160000	
2979	002674	140000	.WORD	140000	
2980	002676	100000	.WORD	100000	
2981	002700	000000	.WORD	000000	
2982					
2983	002702	000000	.WORD	000000	; STANDARD PATTERN 3
2984	002704	000000	.WORD	000000	
2985	002706	000000	.WORD	000000	
2986	002710	177777	.WORD	177777	
2987	002712	177777	.WORD	177777	
2988	002714	177777	.WORD	177777	
2989	002716	000000	.WORD	000000	
2990	002720	000000	.WORD	000000	
2991	002722	177777	.WORD	177777	
2992	002724	177777	.WORD	177777	
2993	002726	000000	.WORD	000000	
2994	002730	177777	.WORD	177777	
2995	002732	000000	.WORD	000000	
2996	002734	177777	.WORD	177777	
2997	002736	000000	.WORD	000000	
2998	002740	177777	.WORD	177777	
2999					
3000	002742	133331	.WORD	133331	; STANDARD PATTERN 4
3001	002744	133331	.WORD	133331	
3002	002746	133331	.WORD	133331	
3003	002750	133331	.WORD	133331	
3004	002752	133331	.WORD	133331	
3005	002754	133331	.WORD	133331	
3006	002756	133331	.WORD	133331	
3007	002760	133331	.WORD	133331	
3008	002762	133331	.WORD	133331	
3009	002764	133331	.WORD	133331	
3010	002766	133331	.WORD	133331	
3011	002770	133331	.WORD	133331	
3012	002772	133331	.WORD	133331	
3013	002774	133331	.WORD	133331	
3014	002776	133331	.WORD	133331	
3015	003000	133331	.WORD	133331	
3016					
3017	003002	052525	.WORD	052525	; STANDARD PATTERN 5
3018	003004	052525	.WORD	052525	
3019	003006	052525	.WORD	052525	

3020	003010	125252	.WORD	125252	
3021	003012	125252	.WORD	125252	
3022	003014	125252	.WORD	125252	
3023	003016	052525	.WORD	052525	
3024	003020	052525	.WORD	052525	
3025	003022	125252	.WORD	125252	
3026	003024	125252	.WORD	125252	
3027	003026	052525	.WORD	052525	
3028	003030	125252	.WORD	125252	
3029	003032	052525	.WORD	052525	
3030	003034	125252	.WORD	125252	
3031	003036	052525	.WORD	052525	
3032	003040	125252	.WORD	125252	
3033					
3034	003042	155554	.WORD	155554	; STANDARD PATTERN 6
3035	003044	155554	.WORD	155554	
3036	003046	155554	.WORD	155554	
3037	003050	155554	.WORD	155554	
3038	003052	155554	.WORD	155554	
3039	003054	155554	.WORD	155554	
3040	003056	155554	.WORD	155554	
3041	003060	155554	.WORD	155554	
3042	003062	155554	.WORD	155554	
3043	003064	155554	.WORD	155554	
3044	003066	155554	.WORD	155554	
3045	003070	155554	.WORD	155554	
3046	003072	155554	.WORD	155554	
3047	003074	155554	.WORD	155554	
3048	003076	155554	.WORD	155554	
3049	003100	155554	.WORD	155554	
3050					
3051	003102	026455	.WORD	026455	; STANDARD PATTERN 7
3052	003104	026455	.WORD	026455	
3053	003106	026455	.WORD	026455	
3054	003110	151322	.WORD	151322	
3055	003112	151322	.WORD	151322	
3056	003114	151322	.WORD	151322	
3057	003116	026455	.WORD	026455	
3058	003120	026455	.WORD	026455	
3059	003122	151322	.WORD	151322	
3060	003124	151322	.WORD	151322	
3061	003126	026455	.WORD	026455	
3062	003130	151322	.WORD	151322	
3063	003132	026455	.WORD	026455	
3064	003134	151322	.WORD	151322	
3065	003136	026455	.WORD	026455	
3066	003140	151322	.WORD	151322	
3067					
3068	003142	066666	.WORD	066666	; STANDARD PATTERN 8
3069	003144	066666	.WORD	066666	
3070	003146	066666	.WORD	066666	
3071	003150	066666	.WORD	066666	
3072	003152	066666	.WORD	066666	
3073	003154	066666	.WORD	066666	
3074	003156	066666	.WORD	066666	
3075	003160	066666	.WORD	066666	

3076	003162	066666	.WORD	066666	
3077	003164	066666	.WORD	066666	
3078	003166	066666	.WORD	066666	
3079	003170	066666	.WORD	066666	
3080	003172	066666	.WORD	066666	
3081	003174	066666	.WORD	066666	
3082	003176	066666	.WORD	066666	
3083	003200	066666	.WORD	066666	
3084					
3085	003202	000001	.WORD	000001	;STANDARD PATTERN 9
3086	003204	000002	.WORD	000002	
3087	003206	000004	.WORD	000004	
3088	003210	000010	.WORD	000010	
3089	003212	000020	.WORD	000020	
3090	003214	000040	.WORD	000040	
3091	003216	000100	.WORD	000100	
3092	003220	000200	.WORD	000200	
3093	003222	000400	.WORD	000400	
3094	003224	001000	.WORD	001000	
3095	003226	002000	.WORD	002000	
3096	003230	004000	.WORD	004000	
3097	003232	010000	.WORD	010000	
3098	003234	020000	.WORD	020000	
3099	003236	040000	.WORD	040000	
3100	003240	100000	.WORD	100000	
3101					
3102	003242	177776	.WORD	177776	;STANDARD PATTERN 10
3103	003244	177775	.WORD	177775	
3104	003246	177773	.WORD	177773	
3105	003250	177767	.WORD	177767	
3106	003252	177757	.WORD	177757	
3107	003254	177737	.WORD	177737	
3108	003256	177677	.WORD	177677	
3109	003260	177577	.WORD	177577	
3110	003262	177377	.WORD	177377	
3111	003264	176777	.WORD	176777	
3112	003266	175777	.WORD	175777	
3113	003270	173777	.WORD	173777	
3114	003272	167777	.WORD	167777	
3115	003274	157777	.WORD	157777	
3116	003276	137777	.WORD	137777	
3117	003300	077777	.WORD	077777	
3118					
3119	003302	172666	.WORD	172666	;STANDARD PATTERN 11
3120	003304	155555	.WORD	155555	
3121	003306	172666	.WORD	172666	
3122	003310	155555	.WORD	155555	
3123	003312	172666	.WORD	172666	
3124	003314	155555	.WORD	155555	
3125	003316	172666	.WORD	172666	
3126	003320	155555	.WORD	155555	
3127	003322	172666	.WORD	172666	
3128	003324	155555	.WORD	155555	
3129	003326	172666	.WORD	172666	
3130	003330	155555	.WORD	155555	
3131	003332	172666	.WORD	172666	

3132	003334	155555	.WORD	155555	
3133	003336	172666	.WORD	172666	
3134	003340	155555	.WORD	155555	
3135					
3136	003342	077777	.WORD	077777	; STANDARD PATTERN 12
3137	003344	137777	.WORD	137777	
3138	003346	157777	.WORD	157777	
3139	003350	167777	.WORD	167777	
3140	003352	173777	.WORD	173777	
3141	003354	175777	.WORD	175777	
3142	003356	176777	.WORD	176777	
3143	003360	177377	.WORD	177377	
3144	003362	177577	.WORD	177577	
3145	003364	177677	.WORD	177677	
3146	003366	177737	.WORD	177737	
3147	003370	177757	.WORD	177757	
3148	003372	177767	.WORD	177767	
3149	003374	177773	.WORD	177773	
3150	003376	177775	.WORD	177775	
3151	003400	177776	.WORD	177776	
3152					
3153	003402	153333	.WORD	153333	; STANDARD PATTERN 13
3154	003404	066667	.WORD	066667	
3155	003406	153333	.WORD	153333	
3156	003410	066667	.WORD	066667	
3157	003412	153333	.WORD	153333	
3158	003414	066667	.WORD	066667	
3159	003416	153333	.WORD	153333	
3160	003420	066667	.WORD	066667	
3161	003422	153333	.WORD	153333	
3162	003424	066667	.WORD	066667	
3163	003426	153333	.WORD	153333	
3164	003430	066667	.WORD	066667	
3165	003432	153333	.WORD	153333	
3166	003434	066667	.WORD	066667	
3167	003436	153333	.WORD	153333	
3168	003440	066667	.WORD	066667	
3169					
3170	003442	000000	.WORD	000000	; STANDARD PATTERN 14
3171	003444	177777	.WORD	177777	
3172	003446	177777	.WORD	177777	
3173	003450	177777	.WORD	177777	
3174	003452	177777	.WORD	177777	
3175	003454	177777	.WORD	177777	
3176	003456	177777	.WORD	177777	
3177	003460	177777	.WORD	177777	
3178	003462	177777	.WORD	177777	
3179	003464	177777	.WORD	177777	
3180	003466	177777	.WORD	177777	
3181	003470	177777	.WORD	177777	
3182	003472	177777	.WORD	177777	
3183	003474	177777	.WORD	177777	
3184	003476	177777	.WORD	177777	
3185	003500	177777	.WORD	177777	
3186					
3187	003502	177777	.WORD	177777	; STANDARD PATTERN 15

3188	003504	000000	.WORD	000000
3189	003506	000000	.WORD	000000
3190	003510	000000	.WORD	000000
3191	003512	000000	.WORD	000000
3192	003514	000000	.WORD	000000
3193	003516	000000	.WORD	000000
3194	003520	000000	.WORD	000000
3195	003522	000000	.WORD	000000
3196	003524	000000	.WORD	000000
3197	003526	000000	.WORD	000000
3198	003530	000000	.WORD	000000
3199	003532	000000	.WORD	000000
3200	003534	000000	.WORD	000000
3201	003536	000000	.WORD	000000
3202	003540	000000	.WORD	000000
3203				



3204  
3205  
3206  
3207  
3208  
3209  
3210  
3211  
3212  
3213  
3214  
3215  
3216  
3217  
3218  
3219  
3220  
3221  
3222  
3223  
3224  
3225  
3226  
3227  
3228  
3229  
3230  
3231  
3232  
3233  
3234  
3235  
3236  
3237  
3238  
3239  
3240  
3241  
3242  
3243  
3244  
3245  
3246  
3247  
3248  
3249  
3250  
3251  
3252  
3253  
3254  
3255  
3256  
3257  
3258  
3259

```

.SBTTL  ERROR POINTER TABLE
; *THIS TABLE CONTAINS THE INFORMATION FOR EACH ERROR THAT CAN OCCUR.
; *THE INFORMATION IS OBTAINED BY USING THE INDEX NUMBER FOUND IN
; *LOCATION $ITEMB. THIS NUMBER INDICATES WHICH ITEM IN THE TABLE IS PERTINENT.
; *NOTE1:      IF $ITEMB IS 0 THE ONLY PERTINENT DATA IS ($ERRPC).
; *NOTE2:      EACH ITEM IN THE TABLE CONTAINS 4 POINTERS EXPLAINED AS FOLLOWS:
; *           EM           ;; POINTS TO THE ERROR MESSAGE
; *           DH           ;; POINTS TO THE DATA HEADER
; *           DT           ;; POINTS TO THE DATA
; *           DF           ;; POINTS TO THE DATA FORMAT

$ERRTB:
; ERROR 1
; ERROR 1
; ERROR 1
; RH70 INTERRUPT OCCURRED (RMAS = 0)
; ERROR 2
; UNEXPECTED ATTENTION OCCURRED
; ERROR 3
; MASSBUS PARITY ERROR (MCPE=1)
; ERROR 4
; MASSBUS PARITY ERROR (PAR=1)
; ERROR 5
; ADDRESS PLUG BIT CHANGED
; ERROR 6
; RH11 DIDN'T RESPOND TO ADDRESSING

```

003542

003542 046152  
003544 050571  
003546 051222  
003550 000000

003552 046221  
003554 050576  
003556 051226  
003560 000000

003562 046257  
003564 050652  
003566 051244  
003570 000000

003572 046315  
003574 050700  
003576 051254  
003600 000000

003602 046352  
003604 050576  
003606 051226  
003610 000000

003612 046406  
003614 050737

EM1  
DH1  
DT1  
0

EM2  
DH2  
DT2  
0

EM3  
DH3  
DT3  
0

EM4  
DH4  
DT4  
0

EM5  
DH2  
DT2  
0

EM6  
DH6

;RH70 INTERRUPT OCCURRED (RMAS = 0)

;UNEXPECTED ATTENTION OCCURRED

;MASSBUS PARITY ERROR (MCPE=1)

;MASSBUS PARITY ERROR (PAR=1)

;ADDRESS PLUG BIT CHANGED

;RH11 DIDN'T RESPOND TO ADDRESSING

```

3260 003616 051266 DT6
3261 003620 000000 0
3262
3263 ;;*****
3264 .SBTTL SETUP AND INITIALIZATION ROUTINE
3265
3266 ; START ADDRESS = 200
3267 ; ADDRESS TO CHANGE RH11 UNIBUS ADDRESS = 204
3268
3269 ;;*****
3270
3271
3272 003622 012737 177777 001356 START: MOV #-1,CHGADR ;SET RH11 ADDRESS CHANGE FLAG
3273 003630 000407 BR START2 ;START THE PROGRAM
3274 003632 012737 000400 001356 START1: MOV #400,CHGADR ;CLEAR THE RH11 ADDRESS CHANGE FLAG
3275 ;;*****
3276 003640 000240 TST1: NOP
3277 003642 012737 000001 001210 MOV #1,STESTN ;SET TEST NUMBER IN APT MAIL BOX
3278 003650 000005 START2: RESET ;CLEAR THE BUS
3279 .SBTTL INITIALIZE THE COMMON TAGS
3280 ;;CLEAR THE COMMON TAGS (SCMTAG) AREA
3281 003652 012706 001114 MOV #SCMTAG,R6 ;FIRST LOCATION TO BE CLEARED
3282 003656 005026 CLR (R6)+ ;CLEAR MEMORY LOCATION
3283 003660 022706 001154 CMP #SWR,R6 ;;DONE?
3284 003664 001374 BNE -6 ;LOOP BACK IF NO
3285 003666 012706 001100 MOV #STACK,SP ;SETUP THE STACK POINTER
3286 ;;INITIALIZE A FEW VECTORS
3287 003672 012737 031176 000030 MOV #ERROR,#EMTVEC ;EMT VECTOR FOR ERROR ROUTINE
3288 003700 012737 000340 000032 MOV #340,#EMTVEC+2 ;LEVEL 7
3289 003706 012737 034364 000034 MOV #STRAP,#TRAPVEC ;TRAP VECTOR FOR TRAP CALLS
3290 003714 012737 000340 000036 MOV #340,#TRAPVEC+2 ;LEVEL 7
3291 003722 012737 032246 000024 MOV #SPWRON,#PWRVEC ;POWER FAILURE VECTOR
3292 003730 012737 000340 000026 MOV #340,#PWRVEC+2 ;LEVEL 7
3293 003736 012737 176543 033750 MOV #176543,#RNUM ;PRIME THE RANDOM NUMBER GENERATOR
3294 003744 012737 123456 033752 MOV #123456,#LNUM ;BOTH HIGH AND LOW WORDS
3295 ;;SIZE FOR A HARDWARE SWITCH REGISTER. IF NOT FOUND OR IT IS
3296 ;;EQUAL TO A "-1" SETUP FOR A SOFTWARE SWITCH REGISTER.
3297 003752 013746 000004 MOV #ERRVEC, -(SP) ;SAVE ERROR VECTOR
3298 003756 012737 004012 000004 MOV #64$,#ERRVEC ;SET UP ERROR VECTOR
3299 003764 012737 177570 001154 MOV #DSWR,SWR ;SETUP FOR A HARDWARE SWICH REGISTER
3300 003772 012737 177570 001156 MOV #DISP,DISPLAY ;AND A HARDWARE DISPLAY REGISTER
3301 004000 022777 177777 175146 CMP #-1,#SWR ;TRY TO REFERENCE HARDWARE SWR
3302 004006 001012 BNE 66$ ;BRANCH IF NO TIMEOUT TRAP OCCURRED
3303 ; AND THE HARDWARE SWR IS NOT = -1
3304 004010 000403 BR 65$ ;BRANCH IF NO TIMEOUT
3305 004012 012716 004020 64$: MOV #65$, (SP) ;SET UP FOR TRAP RETURN
3306 004016 000002 RTI
3307 004020 012737 000176 001154 65$: MOV #SWREG,SWR ;POINT TO SOFTWARE SWR
3308 004026 012737 000174 001156 MOV #DISPREG,DISPLAY
3309 004034 012637 000004 66$: MOV (SP)+,#ERRVEC ;RESTORE ERROR VECTOR
3310
3311 004040 005037 001212 CLR $PASS ;CLEAR PASS COUNT
3312 004044 132737 000200 001225 BITB #APTSIZE,$ENVM ;TEST USER SIZE UNDER APT
3313 004052 001403 BEQ 67$ ;YES,USE NON-APT SWITCH
3314 004054 012737 001226 001154 MOV #SSWREG,SWR ;NO,USE APT SWITCH REGISTER
3315 004062 67$:

```

3316	004062	012737	000240	000032	MOV	#240,3#EMTVEC+2	:CHANGE EMT PRIORITY TO 4
3317	004070	012737	000240	000036	MOV	#240,3#TRAPVEC+2	:CHANGE TRAP PRIORITY TO 4
3318	004076	005227	177777		INC	#-1	:FIRST START ?
3319	004102	001014			BNE	1\$	:BR IF NOT
3320	004104	104401	057512		TYPE	TITLE	:NAME AND MANDEC NUMBER
3321	004110	005737	000042		TST	42	:AUTO ACCEPT OR CHAIN MODE ?
3322	004114	001007			BNE	1\$	:BR IF EITHER
3323	004116	122737	000077	000041	CMPB	#77,41	:LOADED FROM AN RM03 ?
3324	004124	001003			BNE	1\$	:BR IF NOT
3325	004126	104401	057571		TYPE	,LOADRV	:INSTRUCT THE OPERATOR ON HOW TO TEST DRIVE 0
3326	004132	000000			HALT		
3327	004134	004737	030516		1\$: JSR	PC,STKINT	:TURN ON THE KEYBOARD INTERRUPT
3328					.SBTTL GET	VALUE FOR SOFTWARE SWITCH REGISTER	
3329	004140	005737	000042		TST	3#42	:ARE WE RUNNING UNDER XXDP/ACT?
3330	004144	001012			BNE	68\$	:BRANCH IF YES
3331	004146	123727	001224	000001	CMPB	SENV,#1	:ARE WE RUNNING UNDER APT?
3332	004154	001406			BEQ	68\$	:BRANCH IF YES
3333	004156	023727	001154	000176	CMP	SWR,#SWREG	:SOFTWARE SWITCH REG SELECTED?
3334	004164	001005			BNE	69\$	:BRANCH IF NO
3335	004166	104406			GTSWR		:GET SOFT-SWR SETTINGS
3336	004170	000403			BR	69\$	
3337	004172	112737	000001	001150	68\$: MOVB	#1,\$AUTOB	:;SET AUTO-MODE INDICATOR
3338	004200				69\$:		
3339	004200	105737	001224		TSTB	SENV	:RUN UNDER APT MODE
3340	004204	001423			BEQ	4\$	:NO,DONOT BOTHER
3341	004206	105737	001254		TSTB	SVECT1	:NEW VECTOR ?
3342	004212	001403			BEQ	.+10	:NOT LOAD IF = 0
3343	004214	113737	001254	001272	MOVB	SVECT1,\$RMVEC	:NEW VECTOR
3344	004222	005737	001260		TST	\$BASE	:NEW BASE ADDRESS ?
3345	004226	001403			BEQ	.+10	:NO
3346	004230	013737	001260	001270	MOV	\$BASE,\$RMADR	:NEW BASE ADDRESS
3347	004236	013737	001270	034620	MOV	\$RMADR,\$RMADR	:LOAD ADDRESS INTO DRIVER
3348	004244	013737	001272	034622	MOV	\$RMVEC,\$RMVEC	:LOAD VECTOR INTO DRIVER
3349	004252	000420			BR	2\$	
3350	004254	105737	001150		4\$: TSTB	\$AUTOB	:AUTO MODE ?
3351	004260	001015			BNE	2\$	:YES
3352	004262	004737	056240		JSR	PC,BUSADR	:CHECK RH11 BUS ADDRESS
3353	004266	013737	001270	034620	MOV	\$RMADR,\$RMADR	:RH11 ADDRESS
3354	004274	013737	001272	034622	MOV	\$RMVEC,\$RMVEC	:RH11 VECTOR ADDRESS
3355	004302	005227	177777		INC	#-1	:FIRST START ?
3356	004306	001002			BNE	2\$	:BRANCH IF NOT
3357	004310	004737	055752		JSR	PC,OPRDAT	:GET THE DATE AND OPERATOR ID
3358	004314	005037	001314		2\$: CLR	STATIN	:CLEAR PERFORMANCE SUMMARY TYPEOUT FLAG
3359	004320	012705	001522		MOV	#ORDERQ,R5	:START OF AREA TO CLEAR
3360	004324	005025			3\$: CLR	(R5)+	
3361	004326	022705	002102		CMP	#BLKADR,R5	:LOOK FOR END OF CLEAR AREA
3362	004332	001374			BNE	3\$	:BR IF NOT FINISHED
3363	004334	012706	001100		MOV	#STACK,SP	:SETUP THE STACK POINTER
3364	004340	005037	177776		CLR	PS	:CLEAR THE PROCESSOR STATUS WORD
3365	004344	013737	001312	001372	MOV	HZ,SIXTEE	:1/60 TH OR 1/50 TH SECOND COUNTER VALUE
3366	004352	005037	001364		CLR	HOUR	:CLEAR THE HOUR'S COUNTER
3367	004356	005037	001366		CLR	MINUTE	:CLEAR THE MINUTE'S COUNTER
3368	004362	005037	001370		CLR	SECOND	:CLEAR THE SECOND'S COUNTER
3369	004366	005037	001470		CLR	INTRVL+2	:CLEAR INTERVAL COUNTER
3370	004372	005037	001316		CLR	PACK	:CLEAR THE 'R' OR 'W' COMMAND FLAG
3371	004376	005037	001360		CLR	CFLAG	:CLEAR THE 'CONTROL C' FLAG

```

3372 004402 042737 170000 001464      BIC      #170000,MAXER      ;MAKE SURE ERROR LIMITS ARE NOT TOO HIGH
3373                                     ;ROUTINE TO DETERMINE BUFFER AREA SIZE
3374
3375
3376 004410 005227 177777      SIZMEM: INC      #-1      ;SEE IF TIME TO SIZE MEMORY
3377 004414 001005      BNE      1$      ;BR IF NOT
3378 004416 004737 056142      JSR      PC,$SIZE      ;SEE HOW MUCH MEMORY ON SYSTEM
3379 004422 013737 056236 001354      MOV      $LSTAD,LSTAD      ;SAVE THE LAST ADDRESS
3380 004430 012737 000001 001700 1$:      MOV      #1,BUFTBL      ;LOAD NUMBER OF BUFFERS
3381 004436 012737 057512 001702      MOV      #ENDPGM,BUFTBL+2 ;STARTING ADDRESS OF BUFFER
3382 004444 013737 001354 001704      MOV      LSTAD,BUFTBL+4 ;LAST ADDR TO BUFFER ALLOCATION TABLE
3383 004452 023727 001354 160000      CMP      LSTAD,#160000 ;OVER 28K ?
3384 004460 101403      BLOS     2$      ;NO
3385 004462 012737 160000 001704      MOV      #160000,BUFTBL+4 ;XXDP MAX MEMORY 28K
3386 004470 162737 057512 001704 2$:      SUB      #ENDPGM,BUFTBL+4 ;SUBTRACT PROGRAM SPACE
3387 004476 000241      CLC      ;CLEAR THE 'C' BIT
3388 004500 006037 001704      ROR      BUFTBL+4 ;CONVERT TO WORD COUNT
3389 004504 162737 000144 001704      SUB      #100.,BUFTBL+4 ;SAVE ROOM FOR THE 'ABS' LOADER
3390 004512 005737 000042      TST     42 ;LOAD FROM XXDP OR OTHER MONITOR ?
3391 004516 001403      BEQ     3$      ;BR IF LOADED BY PAPER TAPE
3392 004520 162737 002570 001704      SUB      #1400.,BUFTBL+4 ;SUBTRACT 'XXDP' LOADER SIZE
3393 004526 005737 001462      3$:      TST     MAXDL ;VALUE IN 'MAXDL' ?
3394 004532 001003      BNE     4$      ;BR IF VALUE IS
3395 004534 012737 020000 001462      MOV      #8192.,MAXDL ;ASSUME FULL TRACK MAXIMUM
3396 004542 023737 001462 001704 4$:      CMP      MAXDL,BUFTBL+4 ;IS THAT TOO LARGE ?
3397 004550 103403      BLO     5$      ;BR IF NOT
3398 004552 013737 001704 001462      MOV      BUFTBL+4,MAXDL ;USE MAX AVAIL MEMORY AS MAX BUFFER SIZE
3399 004560 013737 001704 054716 5$:      MOV      BUFTBL+4,PARLST+2 ;VALUE FOR THE PARAMETER TABLE
3400
3401                                     ;SEE IF THE OPERATOR WANTS TO CHANGE ANY PARAMETERS
3402
3403 004566 105737 001150      LKPAR: TSTB     $AUTOB ;'XXDP' CHAIN MODE OR 'ACT11' OPERATION ?
3404 004572 001033      BNE     SETVEC ;BR IF YES
3405 004574 022737 007070 001264      CMP      #7070,$CDW1 ;FROM THE POWER FAIL RT. ?
3406 004602 001427      BEQ     SETVEC ;BRANCH IF SO
3407 004604 105737 001224      TSTB     $ENV ;APT STAND ALONE MODE ?
3408 004610 001024      BNE     SETVEC ;NO
3409 004612 104401 001201      TYPE     ,$SCRLF
3410 004616 104401 055012      TYPE     ,ASKPAR ;ASK FOR PARMETERS
3411 004622 104411      RDLIN   ;READ THE ENTRY
3412 004624 012605      MOV      (SP)+,R5 ;ADDRESS OF ENTRY TO R5
3413 004626 122715 000131      CMPB     #'Y',(R5) ;WAS ENTRY A 'Y' (YES)
3414 004632 001013      BNE     SETVEC ;BR IF NOT 'Y'
3415 004634 012703 054714      ENTPR: MOV      #PARLST,R3 ;PARAMETER TABLE ADDRESS
3416 004640 004737 026610      JSR      PC,PARENT ;GET THE PARAMETER ENTRY
3417 004644 023727 001462 000004      CMP      MAXDL,#4 ;IS THE 'MAXDL' VALUE OK ?
3418 004652 103003      BHIS    SETVEC ;BR IF IT IS
3419 004654 012737 000004 001462      MOV      #4,MAXDL ;SET 'MAXDL' TO THE MINIMUM VALUE
3420
3421                                     ;DISPLAY DRIVE STATUS AND SET UP THE OTHER SYSTEM DEVICES THAT
3422                                     ; THE PROGRAM WILL USE
3423
3424 004662 004737 022632      SETVEC: JSR      PC,CKCLK ;START THE CLOCK
3425 004666 004737 034636      JSR      PC,RMINIT ;INITIALIZE THE RMO3 DRIVER
3426 004672 012737 177777 034560      MOV      #-1,SAVEFG ;SET THE SAVE REGISTERS FLAG
3427 004700 062727 177777 000000      ADD      #-1,#0 ;CHECK FOR FIRST START

```

```

3428 004706 103004          BCC      11$      ;BR IF FIRST START
3429 004710 032777 000004 174236    BIT      #SW02,2SWR ;TYPEOUT THE DRIVE STATUS TABLE ?
3430 004716 001071          BNE      10$      ;BR IF NOT
3431 004720 005004          CLR      R4       ;DRIVE TABLE POINTER
3432 004722 104401 001201    TYPE    ,SCRLF    ;CR-LF
3433 004726 104401 053472    TYPE    ,SYSTAT   ;TYPE STATUS HEADING
3434 004732          1$:
3435 004732 010446          MOV      R4,-(SP) ;SAVE R4 FOR TYPEOUT
3436          ;TYPE DRIVE NUMBER
3437 004734 104403          TYPOS    ;GO TYPE--OCTAL ASCII
3438 004736          .BYTE    2       ;TYPE 2 DIGIT(S)
3439 004737          .BYTE    0       ;SUPPRESS LEADING ZEROS
3440 004740 104401 053244    TYPE    ,LIN4SP   ;SPACES
3441 004744 105764 034472    TSTB    DRVSTA(R4);CHECK DRIVE'S STATUS
3442 004750 100416          BMI      4$      ;BR IF UNSAFE
3443 004752 001020          BNE      5$      ;BR IF ONLINE
3444 004754 105764 034502    TSTB    DRVTP(R4);SEE IF OFFLINE OR NONEXISTENT
3445 004760 001404          BEQ      2$      ;BR IF NONEXISTENT
3446 004762 100006          BPL      3$      ;BR IF OFFLINE
3447 004764 104401 053404    TYPE    ,NOTRM    ;DRIVE NOT AN RMO3
3448 004770 000436          BR      9$      ;CHECK NEXT DRIVE
3449 004772 104401 053426    TYPE    ,NOTPRS   ;DRIVE NOT PRESENT
3450 004776 000433          BR      9$      ;CHECK NEXT DRIVE
3451 005000 104401 053313    TYPE    ,UNTOFF   ;DRIVE OFFLINE
3452 005004 000405          BR      6$      ;PRINT DRIVE TYPE
3453 005006 104401 053462    TYPE    ,NOTSAF   ;DRIVE UNSAFE
3454 005012 000402          BR      6$      ;PRINT DRIVE TYPE
3455 005014 104401 053324    TYPE    ,UNTON    ;DRIVE ONLINE
3456 005020 104401 053246    TYPE    ,LINSR    ;SPACES
3457 005024 012737 053512 005064    MOV      #RMO3A,8$;ADDRESS OF RMO3 MESSAGE
3458 005032 122764 000004 034502    CMPB    #4,DRVTP(R4);RMO3 ?
3459 005040 001410          BEQ      7$      ;BRANCH IF SO
3460 005042 012737 053517 005064    MOV      #RMO3B,8$;RMO2 MESSAGE
3461 005050 122764 000005 034502    CMPB    #5,DRVTP(R4);RMO2 DRIVE ?
3462 005056 001401          BEQ      7$      ;BRANCH IF SO
3463 005060 000741          BR      12$     ;OTHERWISE EXIT
3464 005062 104401          7$: TYPE    ;TYPE THE DRIVE TYPE MESSAGE
3465 005064 000000          8$: .WORD    0     ;MESSAGE ADDRESS HERE
3466 005066 104401 001201    9$: TYPE    ,SCRLF  ;CR-LF
3467 005072 005204          INC      R4       ;INCREMENT DRIVE NUMBER/TABLE POINTER
3468 005074 020427 000010    CMP      R4,#8.   ;FINISHED ?
3469 005100 001314          BNE      1$      ;BR IF NOT
3470 005102 104401 001201    10$: TYPE   ,SCRLF  ;CR-LF
3471 005106 005037 177776    CLR      PS      ;SET PRIORITY BACK TO '0'
3472 005112 012706 001100    MOV      #STACK,SP;SET UP STACK POINT
3473
3474          ;SETUP IF 'XXDP' OR 'ACT11' OPERATION
3475
3476 005116 005737 000042    MONTR: TST      42   ;'XXDP' CHAIN MODE OR 'ACT11' AUTO ACCEPT
3477 005122 001405          BEQ      1$      ;BR IF NEITHER
3478 005124 005737 001356    TST      CHGADR   ;200 START ?
3479 005130 003002          BGT      1$      ;YES
3480 005132 004737 024544    JSR      PC,ASGN2;ASSIGN DRIVES
3481 005136 005227 177777    1$: INC      #-1   ;FIRST START ?
3482 005142 001011          BNE      2$      ;BR IF NOT
3483 005144 105737 000041    TSTB    2#41     ;LOADED FROM PAPER TAPE ?

```



```

3540 005420 005737 001360 MAIN: TST CFLAG ;KEYBOARD INTERRUPTED ?
3541 005424 001407 BEQ 3$ ;BRANCH IF NOT
3542 005426 005737 001522 1$: TST ORDERQ ;DON'T DEASSIGN ANY DRIVE,IF SYSTEM NOT IDLE
3543 005432 001402 BEQ 2$ ;
3544 005434 000137 006206 JMP IDLE ;LET ALL DRIVE FINISH ODDER
3545 005440 004737 024130 2$: JSR PC,KSR ;SERVICE THE KEYBOARD
3546 005444 000240 3$: NOP ;EXIT
3547 005446 012703 000010 MAINDA: MOV #8.,R3 ;DRIVE COUNTER
3548 005452 012705 001546 MOV #DUNIT,R5 ;ADDRESS OF 'DROP DRIVE' TABLE
3549 005456 005715 1$: TST (R5) ;SEE IF ENTRY AT PRESENT POSITION
3550 005460 001011 BNE 3$ ;BR IF THERE IS ONE
3551 005462 062705 000002 2$: ADD #2,R5 ;INCREMENT TO NEXT TABLE POSITION
3552 005466 005303 DEC R3 ;DECREMENT DRIVE COUNTER
3553 005470 001372 BNE 1$ ;BR IF MORE TO CHECK
3554 005472 105737 001544 TSTB ASNLST ;ANY DRIVES ACTIVE ?
3555 005476 001036 BNE MAIN1 ;BR IF YES
3556 005500 000137 027440 JMP $GET42 ;CHECK FOR MONITOR RETURN
3557 005504 012701 001612 3$: MOV #AVAIL,R1 ;ADDRESS OF 'AVAILABLE DRIVES' TABLE
3558 005510 005711 4$: TST (R1) ;SEE IF AT END OF TABLE
3559 005512 001405 BEQ 5$ ;BR IF AT END: GO CHECK 'WAIT' TABLE
3560 005514 021115 CMP (R1),(R5) ;IS DRIVE IN 'AVAIL' THE ONE TO BE DROPPED
3561 005516 001414 BEQ 7$ ;BR IF YES
3562 005520 062701 000002 ADD #2,R1 ;INCREMENT 'AVAIL' TABLE ADDRESS
3563 005524 000771 BR 4$ ;CONTINUE LOOKING
3564 005526 012701 001634 5$: MOV #WAIT,R1 ;MOVE THE ADDRESS OF THE BUFFER WAIT TABLE
3565 005532 005711 6$: TST (R1) ;AT THE END OF THE 'WAIT' TABLE ?
3566 005534 001752 BEQ 2$ ;BR IF YES: SEE IF ANY MORE 'DROP' REQUESTS
3567 005536 021115 CMP (R1),(R5) ;DRIVE IN THE 'WAIT' TABLE ?
3568 005540 001403 BEQ 7$ ;BR IF IT IS
3569 005542 062701 000002 ADD #2,R1 ;INCREMENT 'WAIT' TABLE ADDRESS
3570 005546 000771 BR 6$ ;CONTINUE LOOK THROUGH THE 'WAIT' TABLE
3571 005550 011100 7$: MOV (R1),R0 ;PUT THE DRIVE'S BLOCK ADDRESS IN R0
3572 005552 104401 053771 TYPE DEASSG ;TYPE 'DRIVE DEASSIGNED'
3573 005556 004737 023122 JSR PC,TYPEST ;TYPE THE DRIVE'S PERFORMANCE SUMMARY
3574 005562 005015 CLR (R5) ;CLEAR THE 'DROP DRIVE' TABLE ENTRY
3575 005564 005011 CLR (R1) ;REMOVE THE DRIVE FROM THE 'AVAIL' OR 'WAIT' TABLE
3576 005566 004737 017666 JSR PC,COMPRES ;COMPRESS THE RESPECTIVE TABLE
3577 005572 000733 BR 2$ ;SEE IF ANY MORE DRIVES
3578
3579 ;LOOK FOR DRIVES TO BE ASSIGNED
3580
3581 005574 012703 000010 MAIN1: MOV #8.,R3 ;DRIVE COUNT
3582 005600 005002 CLR R2 ;'AVAIL' INDEX
3583 005602 005004 CLR R4 ;ASSIGN LIST INDEX
3584 005604 005005 CLR R5 ;NEW DRIVE INDEX
3585 005606 005765 001570 1$: TST NEWUNT(R5) ;NEW DRIVE IN THIS POSITION
3586 005612 001006 BNE 3$ ;BR IF THERE IS
3587 005614 062705 000002 2$: ADD #2,R5 ;INCREMENT R5
3588 005620 005204 INC R4 ;INCREMENT ASSIGN INDEX
3589 005622 005303 DEC R3 ;DECREMENT DRIVE COUNT
3590 005624 001370 BNE 1$ ;BR IF MORE DRIVES
3591 005626 000430 BR MAIN2 ;START OPERATIONS FOR THE AVAILABLE DRIVES
3592 005630 104401 053305 3$: TYPE UNTMSG ;'DRIVE'
3593 005634 010446 MOV R4,-(SP) ;SAVE R4 FOR TYPEOUT
3594
3595 005636 104403 TYPOS ;TYPE DRIVE NUMBER
;GO TYPE--OCTAL ASCII

```

3596	005640	002			.BYTE	2		:: TYPE 2 DIGIT(S)
3597	005641	000			.BYTE	0		:: SUPPRESS LEADING ZEROS
3598	005642	104401	054041		TYPE	ASGND		:: 'STARTED'
3599	005646	005762	001612	4\$:	TST	AVAIL(R2)		:: AT END OF AVAILABLE TABLE
3600	005652	001403			BEQ	5\$		:: BR IF YES
3601	005654	062702	000002		ADD	#2,R2		:: INCREMENT AVAILABLE TABLE INDEX
3602	005660	000772			BR	4\$		:: CONTINUE LOOKING FOR END OF TABLE
3603	005662	016562	001570	001612	5\$:	MOV	NEWUNT(R5),AVAIL(R2)	:: MOVE ADDR OF DRIVE INTO AVAIL LST
3604	005670	005065	001570		CLR	NEWUNT(R5)		:: TAKE DRIVE OUT OF NEW DRIVE TABLE
3605	005674	156437	034606	001544	BISB	ATABIT(R4),ASNLS		:: SET DRIVE ASSIGNED INDICATOR
3606	005702	062702	000002		ADD	#2,R2		:: INCREMENT AVAILABLE TABLE POINTER
3607	005706	000742			BR	2\$		:: LOOK FOR MORE DRIVES
3608								
3609								:: GET PARAMETERS, BUFFER SPACE, AND START ORDERS FOR DRIVES IN
3610								:: THE 'AVAILABLE' QUEUE
3611								
3612	005710				MAIN2:			
3613					:			SET UP THE WAIT QUEUE FOR
3614					:			ALL THE DRIVES THAT WAITING
3615					:			FOR BUFFER IN THREE TIMES OF
3616					:			SEARCHING
3617	005710	005002			CLR	R2		:: START FROM THE FIRST LOCATION
3618	005712	005762	001634	1\$:	TST	WAIT(R2)		:: WAIT FOR THE BUFFER ?
3619	005716	001437			BEQ	MAIN3		:: EXIT IF NONE
3620	005720	016200	001634		MOV	WAIT(R2),R0		:: LOAD R0 WITH THE DPB ADDRESS
3621	005724	005046			CLR	-(SP)		:: CLEAR THE STACK FOR BUFFER REQ
3622	005726	004737	015630		JSR	PC,GETBUF		:: CALL TO GET THE BUFFER RT.
3623	005732	012660	000006		MOV	(SP)+,\$BUF(R0)		:: IF 0 BUFFER IS STILL NOT AVAILABLE
3624	005736	001421			BEQ	2\$		:: BRANCH IF NO BUFFER AVAILABLE
3625	005740	005060	000072		CLR	\$FAIR(R0)		:: CLEAR THE FAIR FLAG
3626	005744	004737	016214		JSR	PC,FILBUF		:: FILL THE BUFFER
3627	005750	004737	016342		JSR	PC,GODRIV		:: SET COMMAND AND GO
3628	005754	012705	001522		MOV	#ORDERQ,R5		:: PUT THE WAIT QUEUE INTO ORDER QUEUE
3629	005760	005725			TST	(R5)+		:: QUEUE AVAILABLE ?
3630	005762	001376			BNE	-2		:: BRANCH IF NOT
3631	005764	010045			MOV	R0, -(R5)		:: LOAD THE DPB ADDRESS INTO THE ORDER QUEUE
3632	005766	012701	001634		MOV	#WAIT,R1		:: REMOVE THE QUEUE FROM THE WAITING QUEUE
3633	005772	060201			ADD	R2,R1		:: OFFSET THE QUEUE POSITION
3634	005774	004737	017666		JSR	PC,COMPRES		:: COMPRESS THE QUEUE
3635	006000	000744			BR	1\$		:: BRANCH IF DONE
3636	006002	062702	000002	2\$:	ADD	#2,R2		:: CHECK THE NEXT QUEUE
3637	006006	000741			BR	1\$		:: LOOPING BACK
3638	006010	000240			NOP			
3639	006012	000240			NOP			
3640	006014	000240			NOP			
3641	006016				MAIN3:			
3642					:			OUTSTANDING BUFFER REQUESTS
3643					:			BR IF THERE ARE
3644	006016	005002			CLR	R2		:: CLEAR DRIVE TABLE POINTER
3645	006020	005762	001612	1\$:	TST	AVAIL(R2)		:: ANY DRIVES WAITING FOR PARAMETERS
3646	006024	001002			BNE	+6		:: BRANCH IF ANY
3647	006026	000137	006206		JMP	IDLE		:: BRANCH IF NONE
3648	006032	016200	001612		MOV	AVAIL(R2),R0		:: CONTROL BLOCK ADDR IN R0
3649	006036	005760	000104		TST	\$NEXT(R0)		:: PARAMETERS BEEN SELECTED ?
3650	006042	001010			BNE	6\$		:: BR IF THEY HAVE
3651	006044	105760	000026		TSTB	\$PACK(R0)		:: 'R' OR 'W' COMMAND FOR THE DRIVE ?



3652	006050	001403			BEQ	5\$		:BR IF NOT
3653	006052	004737	017704		JSR	PC,WRTPK		:GET DATA PACK PARAMETERS
3654	006056	000404			BR	7\$		:GET THE BUFFER
3655	006060	004737	016420	5\$:	JSR	PC,SELPAR		:SELECT THE PARAMETERS
3656	006064	004737	017374	6\$:	JSR	PC,GETPAR		:LOAD NEW PARAMETERS
3657	006070	005046		7\$:	CLR	-(SP)		:MAKE ROOM ON THE STACK FOR THE BUFFER ADDR
3658	006072	004737	015630		JSR	PC,GETBUF		:GET BUFFER
3659	006076	012660	000006		MOV	(SP)+,\$BUF(RO)		:MOVE BUFFER ADDR TO DPB
3660	006102	001414			BEQ	8\$		:BR IF '0' ADDR (NO BUFFER)
3661	006104	004737	016214		JSR	PC,FILBUF		:FILL THE BUFFER
3662	006110	005060	000072		CLR	\$FAIR(RO)		:CLEAR THE 'FAIRNESS' COUNT
3663	006114	004737	016342		JSR	PC,GODRIV		:PUT CURRENT DPB IN DRIVER
3664	006120	012705	001522		MOV	#ORDERQ,R5		:ADDRESS OF ORDER QUEUE IN R5
3665	006124	005725			TST	(R5)+		:END OF QUEUE ?
3666	006126	001376			BNE	.-2		:BR IF NOT
3667	006130	010045			MOV	RO,-(R5)		:PUT BLOCK ADDRESS INTO QUEUE
3668	006132	000417			BR	10\$		:CONTINUE LOOKING
3669	006134			8\$:				
3670	006134	005260	000072		INC	\$FAIR(RO)		:INCREMENT THE FAIR COUNT
3671	006140	022760	000003	000072	CMP	#3,\$FAIR(RO)		:THREE TIMES,BUFFER IS NOT AVAILABLE?
3672	006146	101006			BHI	9\$		:BRANCH IF NOT OVER THREE TIMES
3673	006150	012705	001634		MOV	#WAIT,R5		:LOAD INTO THE WAIT QUEUE
3674	006154	005725			TST	(R5)+		:AN AVAILABLE LOCATION ?
3675	006156	001376			BNE	.-2		:BRANCH IF NOT
3676	006160	010045			MOV	RO,-(R5)		:LOAD INTO WAIT QUE
3677	006162	000403			BR	10\$		:REMOVE THE DPB FROM AVAILABLE QUE
3678	006164			9\$:				
3679	006164	062702	000002		ADD	#2,R2		:INCREMENT INDEX
3680	006170	000713			BR	1\$		:BRANCH BACK TO FIRE NEXT DRIVE
3681	006172	012701	001612	10\$:	MOV	#AVAIL,R1		: 'AVAILABLE' TABLE ADDRESS
3682	006176	060201			ADD	R2,R1		:FORM ADDRESS OF LAST ENTRY
3683	006200	004737	017666		JSR	PC,CMPRES		:COMPRESS THE TABLE
3684	006204	000705			BR	1\$		:CONTINUE LOOKING
3685								
3686								:GET BUFFER ASSIGNMENTS FOR DRIVES IN THE 'BUFFER WAIT' QUEUE
3687								
3688								
3689								
3690								:WAIT FOR AN ORDER TO FINISH
3691	006206	012701	001522	IDLE:	MOV	#ORDERQ,R1		:ADDRESS OF THE ORDER QUEUE IN R1
3692	006212	012100		1\$:	MOV	(R1)+,RO		:PUT BLOCK ADDRESS INTO RO
3693	006214	001433			BEQ	IDLE1		:BR IF END OF QUEUE
3694	006216	005760	000016		TST	\$STATUS(RO)		:SEE IF DRIVE FINISHED
3695	006222	001773			BEQ	1\$		:BR IF DRIVE NOT FINISHED
3696	006224	162701	000002		SUB	#2,R1		:CORRECT THE QUEUE POINTER
3697	006230	010146			MOV	R1,-(SP)		:SAVE THE QUEUE ADDRESS
3698	006232	004737	015472		JSR	PC,STATIS		:ACCUMULATE STATISTICS FOR DRIVE IN RO
3699	006236	000240			NOP			:DEBUGGING AID
3700	006240	004737	006460		JSR	PC,PROCES		:PROCESS END OF ORDER
3701	006244	005037	001362		CLR	BADSEC		:CLEAR THE BAD TRK/SEC ERROR INDICATOR
3702	006250	004737	027064		JSR	PC,ABNRML		:SEE IF ANY DRIVES HAVE TOO MANY ERRORS
3703	006254	004737	027112		JSR	PC,EOP		:SEE IF ANY DRIVE HAS XFERED 3X10+9 BITS
3704	006260	012601			MOV	(SP)+,R1		:RESTORE THE ORDER TABLE INDEX
3705	006262	012705	001612		MOV	#AVAIL,R5		:FIND THE END OF THE 'AVAILABLE' TABLE
3706	006266	005725		2\$:	TST	(R5)+		:END OF THE TABLE ?
3707	006270	001376			BNE	2\$		:BR IF NOT AT END OF LIST

```

3708 006272 011145          MOV      (R1), -(R5)      ;MOVE THE BLOCK ADDRESS INTO THE TABLE
3709 006274 004737 017666   JSR      PC, CMPRES      ;COMPRESS THE ORDER QUEUE
3710 006300 004737 015764   JSR      PC, RELBUF      ;RESTORE BUFFER
3711 006304                    IDLE1:
3712 006304 032777 000004 172642 1$:  BIT      #SW02, QSWR      ;TYPE PERFORMANCE SUMMARY
3713 006312 001007                    BNE      2$              ;BR IF NOT
3714 006314 005737 001314   TST     STATIN           ;TIME TO TYPE THE PERFORMANCE SUMMARY ?
3715 006320 001404                    BEQ      2$              ;BR IF NOT
3716 006322 005037 001314   CLR     STATIN           ;CLEAR THE INDICATOR
3717 006326 004737 023034   JSR     PC, STATPR       ;TYPE THE SUMMARY
3718 006332 000137 005420   2$:    JMP      MAIN      ;CONTINUE THE LOOP
3719
3720                    ;SETUP TO REFORMAT AN ERROR SECTOR
3721
3722 006336 032777 000001 172610 REFMT:  BIT      #SW0, QSWR      ;READ ONLY SWITCH SET ?
3723 006344 001044                    BNE     REFMTX           ;BR IF IT IS
3724 006346 032777 000200 172600   BIT     #SW7, QSWR      ;SWITCH 7 SET ?
3725 006354 001040                    BNE     REFMTX           ;BR IF IT IS
3726 006356 005737 001474   TST     FORMAT           ;WRITE HEADER & DATA ORDERS ALLOWED ?
3727 006362 001435                    BEQ     REFMTX           ;BR IF NOT
3728 006364 022760 001465 000270   CMP     #821, $RMDC(RO) ;LEGAL VALUE ?
3729 006372 101431                    BLOS   REFMTX           ;NO, NOT FORMAT
3730 006374 004737 022502   JSR     PC, READDR       ;GET CORRECTED SECTOR-TRACK ADDRESSES
3731 006400 012660 000100   MOV     (SP)+, $NCYL(RO) ;CYLINDER
3732 006404 112660 000077   MOVB   (SP)+, $NTRK(RO) ;TRACK ADDR TO DPB
3733 006410 112660 000076   MOVB   (SP)+, $NSEC(RO) ;SECTOR ADDR TO DPB
3734 006414 012760 000402 000102   MOV     #258, $NWRDL(RO) ;WORD COUNT FOR FORMAT
3735 006422 112760 000003 000074 1$:  MOVB   #3, $NCODE(RO)   ;COMMAND CODE
3736 006430 004537 017172   JSR     RS, CHKADR       ;AVOID REFORMAT BAD SPOT
3737 006434 000401                    BR      2$              ;BRANCH IF NOT ON BAD SPOT
3738 006436 000407                    BR      REFMTX          ;BRANCH IF ON BAD SPOT
3739 006440 004737 017332   2$:    JSR     PC, GETPAT   ;GET A PATTERN
3740 006444 110560 000075   MOVB   RS, $NPATC(RO)   ;PATTERN CODE TO CONTROL BLOCK
3741 006450 012760 177777 000104   MOV     #-1, $NEXT(RO)  ;SET PARAMETERS SELECTED INDICATOR
3742 006456 000207 REFMTX: RTS      PC      ;RETURN
3743
3744                    ;PROCESS THE ORDER TERMINATION
3745
3746 006460 111037 001344   PROCES: MOVB   (RO), UNIT ;DRIVE NUMBER FOR ANY ERROR MESSAGES
3747 006464 005760 000016   TST     STATUS(RO)      ;SEE IF DRIVER SIGNALLED AN ERROR
3748 006470 100427                    BMI     ERPROC           ;BR IF ERROR
3749 006472 032760 100000 000234   BIT     #BIT15, $RMCS1(RO) ;SEE IF 'SC' SET
3750 006500 001410                    BEQ     1$              ;BR IF NOT SET
3751 006502 032760 040000 000234   BIT     #BIT14, $RMCS1(RO) ;SEE IF 'TRE' SET
3752 006510 001017                    BNE     ERPROC           ;BR IF SET
3753 006512 032760 040000 000246   BIT     #BIT14, $RMDS(RO) ;SEE IF 'ERR' SET
3754 006520 001013                    BNE     ERPROC           ;BR IF SET
3755 006522 004737 012640   1$:    JSR     PC, CKERR    ;NO ERROR, CHECK ERROR BITS ANYWAY
3756 006526 004737 012732   JSR     PC, CKBUS       ;NO ERROR, CHECK BUS ADDR & WC
3757 006532 032777 000002 172414   BIT     #SW01, QSWR     ;DATA COMPARE ?
3758 006540 001002                    BNE     2$              ;BR IF NOT
3759 006542 004737 013016   JSR     PC, CMPAR       ;NO ERROR, COMPARE DATA
3760 006546 000207   2$:    RTS      PC      ;RETURN
3761
3762                    ;ORDER TERMINATED WITH AN ERROR - PROCESS THE ERROR
3763

```

```

3764 006550 032760 000200 000016 ERPROC: BIT      #BIT07,STATUS(RO) :DONE BIT SET ?
3765 006556 001402          BEQ      ERPRC1      :BR IF ORDER DIDN'T COMPLETE NORMALLY
3766 006560 000137 007204          JMP      DONE      :PROCESS ERROR WITH 'DONE' BIT SET
3767
3768                                     ;PROCESS ORDER COMPLETION WITH 'ERROR' & 'DONE NOT' BITS
3769
3770 006564 032760 010000 000016 ERPRC1: BIT      #BIT12,STATUS(RO) :SEE IF DRIVE WAS UNSAFE
3771 006572 001025          BNE     PUNSAF     :BR IF YES
3772 006574 032760 004000 000016          BIT      #BIT11,STATUS(RO) :PARITY ERROR OCCURRED
3773 006602 001055          BNE     UCPAR     :BR IF IT DID
3774 006604 032760 002000 000016          BIT      #BIT10,STATUS(RO) :FATAL PARITY ERROR?
3775 006612 001056          BNE     FALPAR    :BR IF THERE IS ONE
3776 006614 032760 001000 000016          BIT      #BIT09,STATUS(RO) :TIMEOUT?
3777 006622 001076          BNE     SWTIM     :BR IF YES
3778 006624 032760 040002 000016          BIT      #BIT14:BIT01,STATUS(RO) ;DRIVE WENT OFFLINE ?
3779 006632 001111          BNE     OFLIN    :BR IF IT DID
3780 006634 032760 000004 000016          BIT      #BIT2,STATUS(RO) :PORT REQUEST TIME OUT ?
3781 006642 001141          BNE     PRTIM    :BR IF IT DID
3782 006644 000207          RTS      PC      :ERROR. RETURN
3783
3784                                     ;DRIVE IS PERSISTENTLY UNSAFE
3785
3786 006646 104401 001201          PUNSAF: TYPE    ,SCLRF      :CR-LF
3787 006652 104401 046552          TYPE    ,EM12      :'DRIVE UNSAFE' MESSAGE
3788 006656 104401 054014          TYPE    ,DRNUM     :DRIVE NUMBER
3789 006662 013746 001344          MOV     UNIT,-(SP) :SAVE UNIT FOR TYPEOUT
3790                                     :TYPE DRIVE NUMBER
3791 006666 104403          TYPOS   :GO TYPE--OCTAL ASCII
3792 006670          .BYTE  2         :TYPE 2 DIGIT(S)
3793 006671          .BYTE  0         :SUPPRESS LEADING ZEROS
3794 006672 104401 001201          TYPE    ,SCLRF      :CR-LF
3795 006676 004737 020406          JSR     PC,LINE1   :PRINT LINE 1 OF ERROR MESSAGE
3796 006702 104414 046552          DISPLY  ,EM12      :PERSISTENT DEVICE UNSAFE MESSAGE
3797 006706 004737 020462          JSR     PC,LINE2   :PRINT LINE 2 OF ERROR MESSAGE
3798 006712 004737 021070          JSR     PC,LINE3   :PRINT LINE 3 OF ERROR MESSAGE
3799 006716 004737 021540          JSR     PC,LINE4   :PRINT LINE 4 OF THE ERROR MESSAGE
3800 006722 004737 023644          JSR     PC,INCTOT  :INCREMENT TOTAL ERROR COUNT
3801 006726 004737 022150          JSR     PC,LINE7   :PRINT LINE 7 OF ERROR MESSAGE
3802 006732 000137 026764          JMP     DROP       :DROP THE DRIVE
3803
3804                                     ;UNCORRECTABLE MASSBUS PARITY ERROR OCCURRED
3805
3806 006736 104401 001201          UCPAR: TYPE    ,SCLRF      :CR-LF
3807 006742 104401 046454          TYPE    ,EM10      :'UNCORRECTABLE PARITY ERROR' MESSAGE
3808 006746 000404          BR      FALPR1    :FINISH PROCESSING THE ERROR
3809
3810                                     ;'FATAL' MASSBUS PARITY ERROR OCCURRED
3811
3812 006750 104401 001201          FALPAR: TYPE    ,SCLRF      :CR-LF
3813 006754 104401 046517          TYPE    ,EM11      :'FATAL PARITY ERROR' MESSAGE
3814 006760 104401 054014          FALPR1: TYPE    ,DRNUM     :DRIVE NUMBER
3815 006764 013746 001344          MOV     UNIT,-(SP) :SAVE UNIT FOR TYPEOUT
3816                                     :TYPE DRIVE NUMBER
3817 006770 104403          TYPOS   :GO TYPE--OCTAL ASCII
3818 006772          .BYTE  2         :TYPE 2 DIGIT(S)
3819 006773          .BYTE  0         :SUPPRESS LEADING ZEROS

```

```

3820 006774 104401 001201          TYPE      $SCRLF          ;CR-LF
3821 007000 004737 023644          JSR      PC,INCTOT      ;INCREMENT TOTAL ERROR COUNT
3822 007004 032777 100000 172142  BIT      #SW15,JSWR     ;HALT ON ERROR ?
3823 007012 001401                   BEQ      1$             ;BR IF NOT
3824 007014 000000                   HALT                                ;ERROR HALT
3825 007016 000207          1$:      RTS      PC
3826
3827          ;SOFTWARE TIMEOUT OCCURRED
3828
3829 007020 004737 020406          SWTIM:   JSR      PC,LINE1      ;PRINT LINE 1 OF ERROR MESSAGE
3830 007024 104414 046603          DISPLY   EM13           ;PRINT THE TIME OUT MESSAGE
3831 007030 004737 020462          JSR      PC,LINE2      ;PRINT LINE 2 OF ERROR MESSAGE
3832 007034 004737 021070          JSR      PC,LINE3      ;PRINT LINE 3 OF ERROR MESSAGE
3833 007040 004737 021540          JSR      PC,LINE4      ;PRINT LINE 4 OF ERROR MESSAGE
3834 007044 004737 023644          JSR      PC,INCTOT     ;INCREMENT TOTAL ERROR COUNT
3835 007050 004737 022150          JSR      PC,LINE7      ;PRINT LINE 7 OF ERROR MESSAGE
3836 007054 000207          RTS      PC             ;RETURN
3837
3838          ;DRIVE WENT OFFLINE
3839
3840 007056 104401 001201          OFLIN:   TYPE      $SCRLF          ;CR-LF
3841 007062 104401 046655          TYPE      EM14           ;'DRIVE WENT OFFLINE' MESSAGE
3842 007066 104401 054014          TYPE      DRNUM          ;DRIVE NUMBER
3843 007072 013746 001344          MOV      UNIT,-(SP)     ;SAVE UNIT FOR TYPEOUT
3844          ;TYPE DRIVE NUMBER
3845 007076 104403          TYPOS    2              ;GO TYPE--OCTAL ASCII
3846 007100 002          .BYTE    2              ;TYPE 2 DIGIT(S)
3847 007101 000          .BYTE    0              ;SUPPRESS LEADING ZEROS
3848 007102 104401 001201          TYPE      $SCRLF          ;CR-LF
3849 007106 004737 020406          JSR      PC,LINE1      ;PRINT LINE 1 OF THE ERROR MESSAGE
3850 007112 104414 046655          DISPLY   EM14           ;PRINT OFFLINE MESSAGE
3851 007116 004737 020462          JSR      PC,LINE2      ;PRINT LINE 2 OF THE ERROR MESSAGE
3852 007122 004737 021070          JSR      PC,LINE3      ;PRINT LINE 3 OF THE ERROR MESSAGE
3853 007126 004737 021540          JSR      PC,LINE4      ;PRINT LINE 4 OF THE ERROR MESSAGE
3854 007132 004737 023644          JSR      PC,INCTOT     ;INCREMENT TOTAL ERROR COUNT
3855 007136 004737 022150          JSR      PC,LINE7      ;PRINT LINE 7 OF THE ERROR MESSAGE
3856 007142 000137 026764          JMP      DROP           ;DROP THE DRIVE
3857
3858          ;PORT REQUEST TIMEOUT ERROR
3859
3860 007146 004737 020406          PRTIM:   JSR      PC,LINE1      ;TYPE LINE 1 OF THE ERROR MESSAGE
3861 007152 104414 046700          DISPLY   EM15           ;PRINT PORT TIME OUT MESSAGE
3862 007156 004737 020462          JSR      PC,LINE2      ;TYPE LINE 2 OF THE ERROR MESSAGE
3863 007162 004737 021070          JSR      PC,LINE3      ;TYPE LINE 3 OF THE ERROR MESSAGE
3864 007166 004737 021540          JSR      PC,LINE4      ;TYPE LINE 4 OF THE ERROR MESSAGE
3865 007172 004737 023644          JSR      PC,INCTOT     ;INCREMENT TOTAL ERROR COUNT
3866 007176 004737 022150          JSR      PC,LINE7      ;TYPE LINE 7 OF THE ERROR MESSAGE
3867 007202 000207          RTS      PC             ;RETURN
3868
3869          ;PROCESS ORDER COMPLETION WITH 'ERROR' & 'DONE' BITS SET
3870
3871 007204 032760 000030 000016  DONE:   BIT      #BIT04!BIT03,$STATUS(RO) ;UNSAFE OCCURRED
3872 007212 001402                   BEQ      .+6             ;BR IF NOT
3873 007214 000137 012306                   JMP      UNSAF           ;REPORT UNSAFE
3874 007220 032760 040000 000244  BIT      #BIT14,$RMCS2(RO) ;IS 'WCE' SET ?
3875 007226 001402                   BEQ      .+6             ;BRANCH IF NOT SET

```

```

3876 007230 000137 010166      JMP      WCKER          ;WRITE CHECK ERROR
3877 007234 032760 040000 000246  BIT      #BIT14,$RMDS(RO) ;CHECK 'ERR'
3878 007242 001002          BNE          ;BR IF SET
3879 007244 000137 012052      JMP      TRFER          ;PROCESS 'TRE'
3880 007250 032760 000400 000250 1$:  BIT      #BIT08,$RMER1(RO) ;'HCRC' SET?
3881 007256 001402          BEQ      .+6          ;BR IF NOT
3882 007260 000137 010514      JMP      HCRCER         ;PROCESS 'HCRC'
3883 007264 032760 000020 000250  BIT      #BIT04,$RMER1(RO) ;'FMT' SET?
3884 007272 001402          BEQ      .+6          ;BR IF NOT SET
3885 007274 000137 010712      JMP      CKFMT          ;CHECK FORMAT ERROR
3886 007300 032760 000200 000250  BIT      #BIT07,$RMER1(RO) ;'HCE' SET?
3887 007306 001402          BEQ      .+6          ;BR IF NOT SET
3888 007310 000137 011106      JMP      CKHCE          ;CHECK 'HCE' ERROR
3889 007314 032760 020000 000250  BIT      #BIT13,$RMER1(RO) ;'OPI' SET?
3890 007322 001402          BEQ      .+6          ;BR IF NOT SET
3891 007324 000137 011406      JMP      OPTER          ;REPORT 'OPI'
3892 007330 032760 000010 000250  BIT      #BIT3,$RMER1(RO) ;'PAR' SET?
3893 007336 001402          BEQ      .+6          ;BR IF NOT SET
3894 007340 000137 011540      JMP      PARER          ;REPORT 'PAR'
3895 007344 032760 000040 000250  BIT      #BIT5,$RMER1(RO) ;'WCF' SET?
3896 007352 001402          BEQ      .+6          ;BR IF NOT SET
3897 007354 000137 012210      JMP      WCFER          ;REPORT 'WCF'
3898 007360 032760 002000 000250  BIT      #BIT10,$RMER1(RO) ;'IAE' SET?
3899 007366 001402          BEQ      .+6          ;BR IF NOT SET
3900 007370 000137 011632      JMP      IAEER          ;REPORT 'IAE'
3901 007374 032760 004000 000250  BIT      #BIT11,$RMER1(RO) ;'WLE' SET?
3902 007402 001402          BEQ      .+6          ;BR IF NOT SET
3903 007404 000137 011664      JMP      WLEER          ;REPORT 'WLE'
3904 007410 032760 001000 000250  BIT      #BIT9,$RMER1(RO) ;'AOE' SET?
3905 007416 001405          BEQ      2$          ;BR IF NOT SET
3906 007420 032760 002000 000246  BIT      #BIT10,$RMDS(RO) ;'LST' SET?
3907 007426 001401          BEQ      2$          ;BR IF NOT SET
3908 007430 000207          RTS          ;'AOE' & 'LST' SET, EXIT
3909 007432 032760 010000 000250 2$:  BIT      #BIT12,$RMER1(RO) ;SEE IF 'DTE' SET
3910 007440 001402          BEQ      .+6          ;BR IF NOT
3911 007442 000137 011516      JMP      DTEER          ;REPORT 'DTE' ERROR
3912 007446 005760 000250          TST      $RMER1(RO)    ;SEE IF 'DCK' SET
3913 007452 100002          BPL      .+6          ;BR IF NOT
3914 007454 000137 007512      JMP      DCKER          ;PROCESS 'DCK'
3915 007460 032760 060000 000276  BIT      #BIT14!BIT13,$RMER2(RO) ;'SKI' OR 'OCYL' SET
3916 007466 001006          BNE      3$          ;BRANCH IF SKI, OCYL SET
3917 007470 032760 100000 000276  BIT      #BIT15,$RMER2(RO) ;BAD SPOT ?
3918 007476 001004          BNE      4$          ;BRANCH IF SO (NO, OTHER ERROR)
3919 007500 000137 010660          JMP      DRVER          ;REPORT ERROR
3920 007504 000137 012152          JMP      SKIER          ;REPORT SKI ERROR
3921 007510 000207          RTS          ;EXIT FROM ERROR ANALYSIS ROUT.
3922
3923          ;PROCESS DATA ('DCK') CHECK ERROR
3924
3925 007512 022760 010041 000300  DCKER:  CMP      #10041,$RMEC1(RO) ;VALID POSITION COUNT ?
3926 007520 101407          BLOS     1$          ;BR IF NOT VALID
3927 007522 005760 000300          TST      $RMEC1(RO)  ;POSITION COUNT 0 ?
3928 007526 001404          BEQ      1$          ;BR IF 0'S
3929 007530 005760 000302          TST      $RMEC2(RO)  ;VALUE IN PATTERN REGISTER ?
3930 007534 001027          BNE      4$          ;BR IF YES
3931 007536 000431          BR      6$          ;DATA CHECK ERROR

```

3932	007540	004737	020406		1\$:	JSR	PC,LINE1	:TYPE FIRST LINE OF ERROR MESSAGE
3933	007544	104414	050305			DISPLY	EM45	:TYPE 'ECC LOGIC ERROR'
3934	007550	004737	020462			JSR	PC,LINE2	:TYPE LINE 2 OF ERROR MESSAGE
3935	007554	004737	023644			JSR	PC,INCTOT	:INCREMENT TOTAL ERROR COUNT
3936	007560	012737	000003	001350		MOV	#3,RETRY	:RETRY COUNT
3937	007566	004737	015344			JSR	PC,\$RETRY	:RETRY THE ORDER
3938	007572	000403				BR	2\$	:RETRY WAS NOT SUCCESSFUL
3939	007574	004737	022066			JSR	PC,LINE6C	:TYPE LINE 6C OF ERROR MESSAGE
3940	007600	000402				BR	3\$	:FINISH THE ERROR REPORT
3941	007602	004737	022074		2\$:	JSR	PC,LINE6D	:TYPE LINE 6D OF ERROR MESSAGE
3942	007606	004737	022150		3\$:	JSR	PC,LINE7	:TYPE LINE 7 OF ERROR MESSAGE
3943	007612	000402				BR	5\$	:EXIT
3944	007614	004737	020270		4\$:	JSR	PC,SPOTCK	:SEE IF ERROR AT A BAD SPOT ON THE PACK
3945	007620	000207			5\$:	RTS	PC	:IT IS, DON'T REPORT IT
3946	007622	004737	020406		6\$:	JSR	PC,LINE1	:PRINT LINE 1 OF ERROR MESSAGE
3947	007626	104414	046755			DISPLY	EM21	:DATA CHECK ERROR
3948	007632	004737	020462		DCKER1:	JSR	PC,LINE2	:PRINT LINE 2 OF ERROR MESSAGE
3949	007636	004737	021070			JSR	PC,LINE3	:PRINT LINE 3 OF ERROR MESSAGE
3950	007642	004737	021540			JSR	PC,LINE4	:PRINT LINE 4 OF ERROR MESSAGE
3951	007646	004737	014776			JSR	PC,PRTBAD	:SEE IF BAD SECTOR TO BE PRINTED
3952	007652	012737	110100	001346		MOV	#BIT15!BIT12!BIT06,MASK	:LOAD ERROR MASK
3953	007660	032760	010100	000250		BIT	#BIT12!BIT06,\$RMER1(RO)	:CHECK 'DTE' & 'ECH'
3954	007666	001003				BNE	1\$	:BR IF SET
3955	007670	004737	022040			JSR	PC,LINE6	:PRINT LINE 6 OF ERROR MESSAGE
3956	007674	000477				BR	8\$	:FINISH THE ERROR REPORT
3957	007676	012737	000020	001350	1\$:	MOV	#16.,RETRY	:RETRY COUNT
3958	007704	005001				CLR	R1	:R1 IS OFFSET CODE POINTER
3959								
3960								
3961	007706	004737	016342		2\$:	JSR	PC,GODRIV	:RETRY
3962	007712	005760	000016		3\$:	TST	\$STATUS(RO)	:TEST FOR DONE
3963	007716	001775				BEQ	3\$	:BR IF NOT DONE
3964	007720	100075				BPL	10\$	:BR IF NOT ERROR
3965	007722	032760	000200	000016		BIT	#BIT7,\$STATUS(RO)	:SEE IF ORDER TERMINATED NORMALLY
3966	007730	001006				BNE	14\$	:BR IF NOT
3967	007732	004737	023644			JSR	PC,INCTOT	:INCREMENT TOTAL ERROR COUNT
3968	007736	104414	052433			DISPLY	LINBM	:DIFFERENT ERROR DURING RETRY'
3969	007742	000137	006564			JMP	ERPRC1	:SEE WHICH ERROR
3970	007746	033760	001346	000250	14\$:	BIT	MASK,\$RMER1(RO)	:LOOK AT CURRENT ERROR
3971	007754	001430				BEQ	5\$	:BR IF DIFFERENT ERROR
3972	007756	032760	010100	000250		BIT	#BIT12!BIT6,\$RMER1(RO)	: 'ECH' OR 'DTE' STILL SET ?
3973	007764	001437				BEQ	7\$	:BR IF NEITHER SET
3974	007766	105207	001351			INCB	RETRY+1	:INCREMENT RETRY COUNT
3975	007772	123737	001350	001351		CMPB	RETRY,RETRY+1	:DONE ?
3976	010000	001342				BNE	2\$	:BR IF NOT
3977	010002	005201				INC	R1	:INCREMENT TABLE INDEX
3978	010004	116137	002464	046063		MOVB	OFFCOD(R1),GENDPB+\$FMT	:OFFSET CODE
3979	010012	001435				BEQ	9\$	:BR IF END OF OFFSET TABLE
3980	010014	062737	000002	001350		ADD	#2,RETRY	:NEW RETRY LIMIT
3981	010022	004737	015226			JSR	PC,OFFST	:OFFSET
3982	010026	005737	046100		4\$:	TST	GENDPB+\$STATUS	:SEE IF FINISHED WITH OFFSET
3983	010032	001775				BEQ	4\$	:BR IF NOT
3984	010034	100324				BPL	2\$	:BR IF NO ERROR PERFORMING OFFSET
3985	010036	004737	022416		5\$:	JSR	PC,LINE8	:PRINT LINE 8 OF ERROR MESSAGE
3986	010042	004737	023550		6\$:	JSR	PC,INCHRD	:INCREMENT 'HARD' ERROR COUNT
3987	010046	004737	023644			JSR	PC,INCTOT	:INCREMENT TOTAL ERROR COUNT

```

3988 010052 004737 022150 JSR PC,LINE7 ;PRINT LINE 7 OF ERROR MESSAGE
3989 010056 004737 014776 JSR PC,PRTBAD ;PRINT THE BAD SECTOR
3990 010062 000436 BR 13$ ;CLEAN UP AND RETURN
3991 010064 004737 022060 7$: JSR PC,LINE6B ;PRINT LINE 6B OF ERROR MESSAGE
3992 010070 004737 021776 JSR PC,LINE5B ;PRINT LINE 5B OF THE ERROR MESSAGE
3993 010074 004737 023524 8$: JSR PC,INCSOF ;INCREMENT 'SOFT' ERROR COUNT
3994 010100 004737 014236 JSR PC,ECC ;CORRECT THE ERROR USING ECC AND CHECK IT
3995 010104 000407 BR 11$ ;COMPARE THE BUFFER
3996 010106 004737 022074 9$: JSR PC,LINE6D ;PRINT LINE 6D OF ERROR MESSAGE
3997 010112 000753 BR 6$ ;INCREMENT ERROR COUNT
3998 010114 004737 022052 10$: JSR PC,LINE6A ;PRINT LINE 6A OF ERROR MESSAGE
3999 010120 004737 023524 JSR PC,INCSOF ;INCREMENT 'SOFT' ERROR COUNT
4000 010124 012737 000001 001376 11$: MOV #1,FRSTER ;SET PROCESSING 'DCKER' INDICATOR
4001 010132 004737 013034 JSR PC,CPARD ;COMPARE THE BUFFER
4002 010136 105737 001377 TSTB FRSTER+1 ;ERROR IN COMPARE ?
4003 010142 100406 BMI 13$ ;BRANCH IF ERROR
4004 010144 004737 023644 JSR PC,INCTOT ;INCREMENT TOTAL ERROR COUNT
4005 010150 104414 052633 DISPLY LIN9G ;'DATA COMPARE OK' MESSAGE
4006 010154 004737 022150 12$: JSR PC,LINE7 ;PRINT LINE 7 OF ERROR MESSAGE
4007 010160 004737 006336 13$: JSR PC,REFMT ;REFORMAT THE ERROR SECTOR
4008 010164 000207 RTS PC ;RETURN
4009
4010 ;WRITE CHECK ERROR PROCESSING
4011
4012 010166 032760 100000 000250 WCKER: BIT #BIT15,$RMER1(RO) ;SEE IF 'DCK' SET ALSO
4013 010174 001034 BNE 25$ ;BR IF IT IS
4014 010176 004737 020406 JSR PC,LINE1 ;PRINT LINE 1 OF ERROR MESSAGE
4015 010202 104414 047061 DISPLY EM23 ;PRINT WCE & DCK NOT
4016 010206 005037 001346 CLR MASK ;CLEAR ERROR MASK
4017 010212 004737 020462 JSR PC,LINE2 ;PRINT LINE 2 OF ERROR MESSAGE
4018 010216 004737 021070 JSR PC,LINE3 ;PRINT LINE 3 OF ERROR MESSAGE
4019 010222 004737 021540 JSR PC,LINE4 ;PRINT LINE 4 OF ERROR MESSAGE
4020 010226 004737 021630 JSR PC,LINE5 ;PRINT LINE 5 OF ERROR MESSAGE
4021 010232 004737 023644 JSR PC,INCTOT ;INCREMENT TOTAL ERROR COUNT
4022 010236 012737 000003 001350 MOV #3,RETRY ;RETRY LIMIT
4023 010244 004737 015344 JSR PC,$RETRY ;RETRY THE OPERATION
4024 010250 000403 BR 1$ ;RETRY UNSUCCESSFUL
4025 010252 004737 022066 JSR PC,LINE6C ;PRINT LINE 6C OF ERROR MESSAGE
4026 010256 000502 BR 8$ ;FINISH PROCESSING THE ERROR
4027 010260 004737 022074 1$: JSR PC,LINE6D ;PRINT LINE 6D OF ERROR MESSAGE
4028 010264 000506 BR 10$ ;FINISH PROCESSING THE ERROR
4029 010266 004737 020270 2$: JSR PC,SPOTCK ;SEE IF ERROR AT BAD SPOT ON THE PACK
4030 010272 000507 BR 11$ ;EXIT IF AT BAD SPOT ON PACK
4031 010274 004737 020406 JSR PC,LINE1 ;PRINT LINE 1 OF ERROR MESSAGE
4032 010300 012737 047006 010326 MOV #EM22,13$ ;ASSUME THAT EM22 WILL BE PRINTED
4033 010306 032760 040000 000244 BIT #BIT14,$RMCS2(RO) ;DID 'WCK' ALSO SET ?
4034 010314 001003 BNE 12$ ;BR IF IT DID
4035 010316 012737 047707 010326 MOV #EM37,13$ ;MESSAGE FOR 'DCK' AND 'WCK' NOT DURING
4036 ;WRITE CHECK
4037 010324 104414 12$: DISPLY ;TYPE THE ERROR MESSAGE
4038 010326 000000 13$: .WORD 0 ;MESSAGE ADDRESS GOES HERE
4039 010330 004737 020462 JSR PC,LINE2 ;PRINT LINE 2 OF ERROR MESSAGE
4040 010334 004737 021070 JSR PC,LINE3 ;PRINT LINE 3 OF ERROR MESSAGE
4041 010340 004737 021540 JSR PC,LINE4 ;PRINT LINE 4 OF ERROR MESSAGE
4042 010344 004737 021630 JSR PC,LINE5 ;PRINT LINE 5 OF ERROR MESSAGE
4043 010350 032760 000100 000250 BIT #BIT06,$RMER1(RO) ;ECH SET ALSO ?

```

```

4044 010356 001442          BEQ      8$          ;FINISH PROCESSING THE ERROR
4045 010360 012737 000020 001350 3$:    MOV      816,RETRY ;RETRY LIMIT - 16 (10)
4046 010366 004737 016342          JSR     PC,GODRIV ;RETRY THE ORDER
4047 010372 005760 000016          5$:    TST     STATUS(RO) ;ORDER FINISHED ?
4048 010376 001775          BEQ     5$          ;BR IF NOT
4049 010400 100405          BMI     6$          ;BR IF ERROR ON ORDER
4050 010402 105237 001351          INCB   RETRY+1    ;INCREMENT RETRY COUNT
4051 010406 004737 022066          JSR     PC,LINE6C ;PRINT LINE 6C OF ERROR MESSAGE
4052 010412 000431          BR     9$          ;FINISH ERROR PROCESSING
4053 010414 105237 001351          6$:    INCB   RETRY+1    ;INCREMENT RETRY COUNT
4054 010420 123737 001350 001351  CMPB   RETRY,RETRY+1 ;DONE ?
4055 010426 001714          BEQ     1$          ;BR IF AT RETRY LIMIT
4056 010430 032760 100000 000250  BIT    #BIT15,$RMER1(RO) ;'DCK' SET
4057 010436 001407          BEQ     7$          ;BR IF NOT - DIFFERENT ERROR
4058 010440 032760 000100 000250  BIT    #BIT06,$RMER1(RO) ;'ECH' ALSO SET ?
4059 010446 001347          BNE     4$          ;BR IF IT IS, RETRY ORDER
4060 010450 004737 022066          JSR     PC,LINE6C ;PRINT LINE 6C OF ERROR MESSAGE
4061 010454 000403          BR     8$          ;FINISH PROCESSING ERROR
4062 010456 004737 022416          7$:    JSR     PC,LINE8 ;PRINT LINE 8 - 'DIFFERENT ERROR'
4063 010462 000405          BR     9$          ;FINISH PROCESSING ERROR
4064 010464 004737 023644          8$:    JSR     PC,INCTOT ;INCREMENT TOTAL ERROR COUNT
4065 010470 004737 022150          JSR     PC,LINE7  ;FINISH THE ERROR MESSAGE
4066 010474 000406          BR     11$         ;EXIT
4067 010476 004737 023644          9$:    JSR     PC,INCTOT ;INCREMENT TOTAL ERROR COUNT
4068 010502 004737 022150          10$:   JSR     PC,LINE7  ;FINISH THE ERROR MESSAGE
4069 010506 004737 006336          JSR     PC,REFMT  ;REFORMAT THE SECTOR IN ERROR
4070 010512 000207          11$:   RTS      PC     ;RETURN
4071
4072 ;REPORT 'HCRC' ERROR
4073
4074 010514 004737 020270          HRCRCR: JSR     PC,SPOTCK ;SEE IF ERROR AT PACK BAD SPOT
4075 010520 000456          BR     3$          ;EXIT IF IT IS
4076 010522 004737 022502          JSR     PC,READDR ;READ ERROR SECTOR HEADER
4077 010526 004737 015252          JSR     PC,READHD ;GET THE HEAD INFORMATION
4078 010532 004737 020406          JSR     PC,LINE1  ;PRINT LINE 1 OF ERROR MESSAGE
4079 010536 104414 046734          DISPLY EM20      ;REPORT 'HCRC'
4080 010542 004737 020462          JSR     PC,LINE2  ;PRINT LINE 2 OF ERROR MESSAGE
4081 010546 004737 021070          JSR     PC,LINE3  ;PRINT LINE 3 OF ERROR MESSAGE
4082 010552 004737 021540          JSR     PC,LINE4  ;PRINT LINE 4 OF ERROR MESSAGE
4083 010556 004737 021730          JSR     PC,LINE5A ;PRINT THE HEADER INFORMATION
4084 010562 032760 040000 000244  BIT    #BIT14,$RMCS2(RO) ;'WCE' ERROR ALSO ?
4085 010570 001402          BEQ     1$          ;BR IF NOT
4086 010572 004737 021630          JSR     PC,LINES  ;DISPLAY WORDS WHICH CAUSED 'WCE'
4087 010576 004737 023524          1$:    JSR     PC,INCSOF ;INCREMENT 'SOFT' ERROR COUNT
4088 010602 004737 023644          JSR     PC,INCTOT ;INCREMENT TOTAL ERROR COUNT
4089 010606 012737 000400 001346  MOV     #BIT8,MASK ;SET ERROR MASK
4090 010614 012737 000003 001350  MOV     #3,RETRY  ;RETRY LIMIT
4091 010622 004737 015344          JSR     PC,$RETRY ;RETRY ORDER
4092 010626 000405          BR     2$          ;RETRY NOT SUCCESSFUL
4093 010630 004737 022066          JSR     PC,LINE6C ;PRINT LINE 6C OF ERROR MESSAGE
4094 010634 004737 022150          JSR     PC,LINE7  ;PRINT LINE 7 OF ERROR MESSAGE
4095 010640 000406          BR     3$          ;EXIT
4096 010642 004737 022074          2$:    JSR     PC,LINE6D ;PRINT LINE 6D OF ERROR MESSAGE
4097 010646 004737 022150          JSR     PC,LINE7  ;PRINT LINE 7 OF ERROR MESSAGE
4098 010652 004737 006336          JSR     PC,REFMT  ;REFORMAT THE ERROR SECTOR
4099 010656 000207          3$:    RTS      PC     ;RETURN

```



```

4100
4101 ;REPORT DRIVE ERROR
4102
4103 010660 004737 020406 DRIVER: JSR PC,LINE1 ;PRINT LINE 1 OF ERROR MESSAGE
4104 010664 104414 047351 DISPLY EM30 ;REPORT DRIVE ERROR
4105 010670 004737 020462 JSR PC,LINE2 ;PRINT LINE 2 OF ERROR MESSAGE
4106 010674 004737 021070 JSR PC,LINE3 ;PRINT LINE 3 OF ERROR MESSAGE
4107 010700 004737 023644 JSR PC,INCTOT ;INCREMENT TOTAL ERROR COUNT
4108 010704 004737 022150 JSR PC,LINE7 ;PRINT LINE 7 OF ERROR MESSAGE
4109 010710 000207 RTS PC ;RETURN
4110
4111 ;PROCESS FORMAT ('FER') ERROR
4112
4113 010712 032760 000400 000250 CKFMT: BIT #BIT8,$RMER1(RO) ;'HCRC' SET ON ORIGINAL ERROR ?
4114 010720 001402 BEQ 1$ ;BR IF NOT SET
4115 010722 000137 010514 JMP HRCRCR ;REPORT HCRC ERROR
4116 010726 004737 022502 1$: JSR PC,READR ;GET CORRECTED TRACK & SECTOR ADDRSSES
4117 010732 004737 015252 JSR PC,READHD ;READ HEADER
4118 010736 032737 000400 046116 BIT #BIT8,GENREG+RMER1 ;'HCRC' SET WHEN HEADER READ?
4119 010744 001002 BNE 2$ ;BR IF 'HCRC' SET
4120 010746 000137 011712 JMP FMTR ;NO ERROR IS 'FMT' ONLY
4121 010752 004737 020270 2$: JSR PC,SPOTCK ;SEE IF ERROR AT BAD SPOT ON THE PACK
4122 010756 000452 BR 5$ ;EXIT IF IT IS
4123 010760 004737 020406 JSR PC,LINE1 ;PRINT LINE 1 OF ERROR MESSAGE
4124 010764 104414 047140 DISPLY EM24 ;HEADER READ ERROR - FMT BIT DROPPED UP
4125 010770 004737 020462 JSR PC,LINE2 ;PRINT LINE 2 OF ERROR MESSAGE
4126 010774 004737 021070 JSR PC,LINE3 ;PRINT LINE 3 OF ERROR MESSAGE
4127 011000 004737 021540 JSR PC,LINE4 ;PRINT LINE 4 OF ERROR MESSAGE
4128 011004 032760 040000 000244 BIT #BIT14,$RMCS2(RO) ;'WCE' ERROR ALSO ?
4129 011012 001402 BEQ 3$ ;BR IF NOT
4130 011014 004737 021630 JSR PC,LINES ;DISPLAY WORDS WHICH CAUSED 'WCE'
4131 011020 004737 021730 3$: JSR PC,LINESA ;DISPLAY HEADER
4132 011024 004737 023524 JSR PC,INCSOF ;INCREMENT SOFT ERROR COUNT
4133 011030 004737 023644 JSR PC,INCTOT ;INCREMENT TOTAL ERROR COUNT
4134 011034 012737 000020 001346 MOV #BIT4,MASK ;SET ERROR MASK
4135 011042 012737 000003 001350 MOV #3,RETRY ;RETRY LIMIT
4136 011050 004737 015344 JSR PC,$RETRY ;RETRY THE ORDER
4137 011054 000405 BR 4$ ;RETRY NOT SUCCESSFUL
4138 011056 004737 022066 JSR PC,LINE6C ;PRINT LINE 6C OF ERROR MESSAGE
4139 011062 004737 022150 JSR PC,LINE7 ;PRINT LINE 7 OF ERROR MESSAGE
4140 011066 000406 BR 5$ ;EXIT
4141 011070 004737 022074 4$: JSR PC,LINE6D ;PRINT LINE 6D OF ERROR MESSAGE
4142 011074 004737 022150 JSR PC,LINE7 ;PRINT LINE 7 OF ERROR MESSAGE
4143 011100 004737 006336 JSR PC,REFMT ;REFORMAT THE ERROR SECTOR
4144 011104 000207 5$: RTS PC ;RETURN
4145
4146 ;PROCESS HEADER COMPARE ('HCE') ERROR
4147
4148 011106 032760 000400 000250 CKHCE: BIT #BIT8,$RMER1(RO) ;HCRC SET ON ORIGINAL ERROR ?
4149 011114 001402 BEQ 1$ ;BR IF NOT SET
4150 011116 000137 010514 JMP HRCRCR ;REPORT HEADER CRC ERROR
4151 011122 004737 022502 1$: JSR PC,READR ;GET CURRENT SECTOR & TRACK ADDRS
4152 011126 004737 015252 JSR PC,READHD ;READ HEADER OF CURRENT SECTOR
4153 011132 032737 000400 046116 BIT #BIT8,GENREG+RMER1 ;'HCRC' SET ?
4154 011140 001016 BNE 3$ ;BR IF SET
4155 011142 042737 150000 056512 BIC #150000,CYLDER ;CLEAR FORMAT,MFG,USER BITS FROM HEADER

```

```

4156 011150 026037 000270 056512      CMP      $RMDC(RO),CYLDER      ;CORRECT CYLINDER ?
4157 011156 001402          BEQ      2$                  ;BR IF IT IS
4158 011160 000137 011332      JMP      POSER              ;REPORT POSITIONING ERROR
4159 011164 052737 150000 056512 2$:  BIS      #15000,CYLDER      ;RESTORE THE FORMAT,MFG,USER BITS
4160 011172 000137 011770      JMP      HCEER              ;REPORT 'HCE' ERROR
4161 011176 004737 020270      3$:    JSR      PC,SPOTCK      ;SEE IF ERROR AT BAD SPOT
4162 011202 000452          BR       6$                  ;EXIT IF IT IS
4163 011204 004737 020406      JSR      PC,LINE1          ;PRINT LINE 1 OF ERROR MESSAGE
4164 011210 104414 047206      DISPLY  EM25              ;HEADER READ ERROR - 'HCE' SET
4165 011214 004737 020462      JSR      PC,LINE2          ;PRINT LINE 2 OF ERROR MESSAGE
4166 011220 004737 021070      JSR      PC,LINE3          ;PRINT LINE 3 OF ERROR MESSAGE
4167 011224 004737 021540      JSR      PC,LINE4          ;PRINT LINE 4 OF ERROR MESSAGE
4168 011230 032760 040000 000244  BIT      #BIT14,$RMCS2(RO) ;'WCE' ERROR ALSO ?
4169 011236 001402          BEQ      4$                  ;BR IF NOT
4170 011240 004737 021630      JSR      PC,LINES          ;DISPLAY WORDS WHICH CAUSED 'WCE'
4171 011244 004737 021730      4$:    JSR      PC,LINE5A      ;PRINT LINE 5 OF ERROR MESSAGE
4172 011250 004737 023524      JSR      PC,INCSOF         ;INCREMENT SOFT ERROR COUNT
4173 011254 004737 023644      JSR      PC,INCTOT        ;INCREMENT TOTAL ERROR COUNT
4174 011260 012737 000200 001346  MOV      #BIT7,MASK        ;SET ERROR MASK
4175 011266 012737 000003 001350  MOV      #3,RETRY         ;RETRY LIMIT
4176 011274 004737 015344      JSR      PC,$RETRY        ;RETRY THE ORDER
4177 011300 000405          BR       5$                  ;RETRY NOT SUCCESSFUL
4178 011302 004737 022066      JSR      PC,LINE6C        ;PRINT LINE 6C OF ERROR MESSAGE
4179 011306 004737 022150      JSR      PC,LINE7         ;PRINT LINE 7 OF ERROR MESSAGE
4180 011312 000406          BR       6$                  ;EXIT
4181 011314 004737 022074      5$:    JSR      PC,LINE6D      ;PRINT LINE 6D OF ERROR MESSAGE
4182 011320 004737 022150      JSR      PC,LINE7         ;PRINT LINE 7 OF ERROR MESSAGE
4183 011324 004737 006336      JSR      PC,REFMT         ;REFORMAT THE ERROR SECTOR
4184 011330 000207          RTS      PC                  ;RETURN
4185
4186      ;REPORT POSSIBLE POSITIONING ERROR
4187
4188 011332 004737 015174      POSER:  JSR      PC,RECALT   ;RECALIBRATE
4189 011336 004737 020406      JSR      PC,LINE1         ;PRINT LINE 1 OF ERROR MESSAGE
4190 011342 104414 050503      DISPLY  EM51              ;PROGRAM DETECTED POSITIONING ERROR
4191 011346 004737 020462      JSR      PC,LINE2         ;PRINT LINE 2 OF ERROR MESSAGE
4192 011352 004737 021116      JSR      PC,LINE3C        ;PRINT LINE 3C OF ERROR MESSAGE
4193 011356 052737 150000 056512  BIS      #15000,CYLDER      ;RESTORE THE FORMAT BIT
4194 011364 004737 021730      JSR      PC,LINE5A        ;PRINT LINE 5A OF THE ERROR MESSAGE
4195 011370 004737 023620      JSR      PC,INCMIS        ;INCREMENT MISPOSITIONING COUNT
4196 011374 004737 023644      JSR      PC,INCTOT        ;INCREMENT TOTAL ERROR COUNT
4197 011400 004737 022276      JSR      PC,LINE7A        ;PRINT LINE 7A OF ERROR MESSAGE
4198 011404 000207          RTS      PC                  ;EXIT
4199
4200      ;REPORT 'OPI' ERROR
4201
4202 011406 004737 020270      OPIER:  JSR      PC,SPOTCK   ;SEE IF ERROR AT BAD SPOT
4203 011412 000207          RTS      PC                  ;RETURN IF IT IS
4204 011414 004737 020406      JSR      PC,LINE1         ;PRINT LINE 1 OF ERROR MESSAGE
4205 011420 104414 047403      DISPLY  EM31              ;'OPI' ERROR
4206 011424 004737 020462      JSR      PC,LINE2         ;PRINT LINE 2 OF ERROR MESSAGE
4207 011430 004737 021070      JSR      PC,LINE3         ;PRINT LINE 3 OF ERROR MESSAGE
4208 011434 004737 021540      JSR      PC,LINE4         ;PRINT LINE 4 OF ERROR MESSAGE
4209 011440 004737 023644      JSR      PC,INCTOT        ;INCREMENT TOTAL ERROR COUNT
4210 011444 012737 020000 001346  MOV      #BIT13,MASK      ;ERROR MASK
4211 011452 012737 000003 001350  OPIER1: MOV      #3,RETRY   ;RETRY LIMIT

```

```
4212 011460 004737 015344          JSR    PC,SRETRY          ;RETRY THE ORDER
4213 011464 000405                   BR     1$                 ;RETRY UNSUCCESSFUL
4214 011466 004737 022066          JSR    PC,LINE6C         ;PRINT LINE 6C OF ERROR MESSAGE
4215 011472 004737 022150          JSR    PC,LINE7          ;PRINT LINE 7 OF ERROR MESSAGE
4216 011476 000207                   RTS    PC                 ;EXIT
4217 011500 004737 022074          1$:  JSR    PC,LINE6D         ;PRINT LINE 6D OF ERROR MESSAGE
4218 011504 004737 022150          JSR    PC,LINE7          ;PRINT LINE 7 OF ERROR MESSAGE
4219 011510 004737 006336          JSR    PC,REFMT          ;REFORMAT THE ERROR SECTOR
4220 011514 000207                   RTS    PC                 ;RETURN
4221
4222          ;REPORT 'DTE' ERROR
4223
4224 011516 004737 020270          DTEER: JSR    PC,SPOTCK       ;SEE IF ERROR AT BAD SPOT
4225 011522 000207                   RTS    PC                 ;RETURN IF IT IS
4226 011524 004737 020406          JSR    PC,LINE1         ;PRINT LINE 1 OF ERROR MESSAGE
4227 011530 104414 047446          DISPLY EM32              ;'DTE' ERROR
4228 011534 000137 007632          JMP    DCKER1           ;FINISH PROCESSING THE 'DTE' ERROR
4229
4230          ;REPORT 'PAR' ERROR
4231
4232 011540 004737 020406          PARER: JSR    PC,LINE1         ;PRINT LINE 1 OF ERROR MESSAGE
4233 011544 104414 047501          DISPLY EM33              ;REPORT 'PAR'
4234 011550 004737 020462          JSR    PC,LINE2         ;PRINT LINE 2 OF ERROR MESSAGE
4235 011554 004737 021174          JSR    PC,LINE3E        ;PRINT LINE 3E OF ERROR MESSAGE
4236 011560 004737 021540          JSR    PC,LINE4         ;PRINT LINE 4 OF ERROR MESSAGE
4237 011564 004737 023644          JSR    PC,INCTOT        ;INCREMENT TOTAL ERROR COUNT
4238 011570 012737 000010          MOV    #BIT03,MASK      ;ERROR MASK
4239 011576 012737 000003          MOV    #3,RETRY        ;RETRY LIMIT
4240 011604 004737 015344          JSR    PC,SRETRY        ;RETRY ORDER
4241 011610 000405                   BR     2$                 ;RETRY UNSUCCESSFUL
4242 011612 004737 022066          JSR    PC,LINE6C         ;RETRY SUCCESSFUL
4243 011616 004737 022150          1$:  JSR    PC,LINE7          ;PRINT LINE 7 OF ERROR MESSAGE
4244 011622 000207                   RTS    PC                 ;EXIT
4245 011624 004737 022074          2$:  JSR    PC,LINE6D         ;PRINT LINE 6D OF ERROR MESSAGE
4246 011630 000772                   BR     1$                 ;FINISH ERROR MESSAGE
4247
4248          ;REPORT 'IAE' ERROR
4249
4250 011632 004737 020406          IAEER: JSR    PC,LINE1         ;PRINT LINE 1 OF ERROR MESSAGE
4251 011636 104414 047620          DISPLY EM35              ;REPORT 'IAE'
4252 011642 004737 020462          JSR    PC,LINE2         ;PRINT LINE 2 OF ERROR MESSAGE
4253 011646 004737 021262          JSR    PC,LINE3F        ;PRINT LINE 3F OF ERROR MESSAGE
4254 011652 004737 023644          JSR    PC,INCTOT        ;INCREMENT TOTAL ERROR COUNT
4255 011656 004737 022150          JSR    PC,LINE7          ;PRINT LINE 7 OF ERROR MESSAGE
4256 011662 000207                   RTS    PC                 ;RETURN
4257
4258          ;REPORT 'WLE' ERROR
4259
4260 011664 004737 020406          WLEER: JSR    PC,LINE1         ;PRINT LINE 1 OF ERROR MESSAGE
4261 011670 104414 047656          DISPLY EM36              ;REPORT 'WLE'
4262 011674 004737 020462          JSR    PC,LINE2         ;PRINT LINE 2 OF ERROR MESSAGE
4263 011700 004737 023644          JSR    PC,INCTOT        ;INCREMENT TOTAL ERROR COUNT
4264 011704 004737 022150          JSR    PC,LINE7          ;PRINT LINE 7 OF ERROR MESSAGE
4265 011710 000207                   RTS    PC                 ;RETURN
4266
4267          ;REPORT FORMAT ERROR
```

```

4268
4269 011712 004737 020406 FMTER: JSR PC,LINE1 ;PRINT LINE 1 OF ERROR MESSAGE
4270 011716 104414 047267 DISPLY EM26 ;FORMAT ERROR
4271 011722 004737 020462 JSR PC,LINE2 ;PRINT LINE 2 OF ERROR MESSAGE
4272 011726 004737 021070 JSR PC,LINE3 ;PRINT LINE 3 OF ERROR MESSAGE
4273 011732 004737 021540 JSR PC,LINE4 ;PRINT LINE 4 OF ERROR MESSAGE
4274 011736 032760 040000 000244 BIT #BIT14,$RMCS2(RO) ;'WCE' ERROR ALSO ?
4275 011744 001402 BEQ 1$ ;BR IF NOT
4276 011746 004737 021630 JSR PC,LINE5 ;DISPLAY WORDS WHICH CAUSED 'WCE'
4277 011752 004737 021730 1$: JSR PC,LINE5A ;PRINT LINE 5A OF ERROR MESSAGE
4278 011756 004737 023644 JSR PC,INCTOT ;INCREMENT TOTAL ERROR COUNT
4279 011762 004737 022150 JSR PC,LINE7 ;PRINT LINE 7 OF ERROR MESSAGE
4280 011766 000207 RTS PC
4281
4282 ;REPORT HEADER COMPARE ERROR
4283
4284 011770 004737 020406 HCEER: JSR PC,LINE1 ;PRINT LINE 1 OF ERROR MESSAGE
4285 011774 104414 047314 DISPLY EM27 ;HEADER COMPARE ERROR
4286 012000 004737 020462 JSR PC,LINE2 ;PRINT LINE 2 OF ERROR MESSAGE
4287 012004 004737 021070 JSR PC,LINE3 ;PRINT LINE 3 OF ERROR MESSAGE
4288 012010 004737 021540 JSR PC,LINE4 ;PRINT LINE 4 OF ERROR MESSAGE
4289 012014 032760 040000 000244 BIT #BIT14,$RMCS2(RO) ;'WCE' ERROR ALSO ?
4290 012022 001402 BEQ 1$ ;BR IF NOT
4291 012024 004737 021630 JSR PC,LINE5 ;DISPLAY WORDS WHICH CAUSED 'WCE'
4292 012030 004737 021730 1$: JSR PC,LINE5A ;PRINT LINE 5A OF ERROR MESSAGE
4293 012034 004737 023644 JSR PC,INCTOT ;INCREMENT TOTAL ERROR COUNT
4294 012040 004737 022150 JSR PC,LINE7 ;PRINT LINE 7 OF ERROR MESSAGE
4295 012044 004737 006336 JSR PC,REFMT ;REFORMAT THE ERROR SECTOR
4296 012050 000207 RTS PC
4297
4298 ;PROCESS CONTROL/INTERFACE TRANSFER ERROR
4299
4300 012052 004737 020406 TRFER: JSR PC,LINE1 ;PRINT LINE 1 OF ERROR MESSAGE
4301 012056 104414 047771 DISPLY EM40 ;RH11 OR UNIBUS TRANSFER ERROR
4302 012062 004737 020462 JSR PC,LINE2 ;PRINT LINE 2 OF ERROR MESSAGE
4303 012066 004737 021070 JSR PC,LINE3 ;PRINT LINE 3 OF ERROR MESSAGE
4304 012072 004737 021540 JSR PC,LINE4 ;PRINT LINE 4 OF ERROR MESSAGE
4305 012076 004737 023644 JSR PC,INCTOT ;INCREMENT TOTAL ERROR COUNT
4306 012102 032760 121400 000244 BIT #BIT15!BIT13!BIT9!BIT8,$RMCS2(RO) ;'DLT','UPE','MXF','MDPE' SET ?
4307 012110 001415 BEQ 2$ ;BR IF NONE SET
4308 012112 012737 000003 001350 MOV #3,RETRY ;RETRY LIMIT
4309 012120 005037 001346 CLR MASK ;CLEAR ERROR MASK
4310 012124 004737 015344 JSR PC,$RETRY ;RETRY THE OPERATION
4311 012130 000403 BR 1$ ;RETURN HERE IF RETRY UNSUCCESSFUL
4312 012132 004737 022066 JSR PC,LINE6C ;PRINT LINE 6C OF ERROR MESSAGE
4313 012136 000402 BR 2$ ;FINISH THE ERROR REPORT
4314 012140 004737 022074 1$: JSR PC,LINE6D ;PRINT LINE 6D OF ERROR MESSAGE
4315 012144 004737 022150 2$: JSR PC,LINE7 ;PRINT LINE 7 OF ERROR MESSAGE
4316 012150 000207 RTS PC
4317
4318 ;PROCESS 'SKI' OR 'OCYL' ERRORS
4319
4320 012152 004737 020406 SKIER: JSR PC,LINE1 ;PRINT LINE 1 OF ERROR MESSAGE
4321 012156 104414 050445 DISPLY EM50 ;'SKI' OR 'OCYL' ERROR
4322 012162 004737 020462 JSR PC,LINE2 ;PRINT LINE 2 OF ERROR MESSAGE
4323 012166 004737 021104 JSR PC,LINE3B ;PRINT LINE 3B OF ERROR MESSAGE

```

```

4324 012172 004737 023644 JSR PC,INCTOT ;INCREMENT TOTAL ERROR COUNT
4325 012176 004737 023574 JSR PC,INCKSI ;INCREMENT 'SKI' OR 'OCYL' ERROR COUNT
4326 012202 004737 022276 JSR PC,LINE7A ;PRINT LINE 7A OF ERROR MESSAGE
4327 012206 000207 RTS PC
4328
4329 ;REPORT WRITE CLOCK FAILURE ('WCF')
4330
4331 012210 004737 020406 WCFER: JSR PC,LINE1 ;PRINT LINE 1 OF ERROR MESSAGE
4332 012214 104414 047556 DISPLY EM34 ;REPORT WRITE CLOCK FAILURE
4333 012220 004737 020462 JSR PC,LINE2 ;PRINT LINE 2 OF ERROR MESSAGE
4334 012224 004737 021076 JSR PC,LINE3A ;PRINT LINE 3A OF ERROR MESSAGE
4335 012230 004737 021540 JSR PC,LINE4 ;PRINT LINE 4 OF ERROR MESSAGE
4336 012234 004737 023644 JSR PC,INCTOT ;INCREMENT TOTAL ERROR COUNT
4337 012240 004737 014776 JSR PC,PRTBAD ;SEE IF BAD SECTOR TO BE PRINTED
4338 012244 012737 000003 001350 MOV #3,RETRY ;RETRY COUNT
4339 012252 012737 000040 001346 MOV #BIT05,MASK ;ERROR MASK
4340 012260 004737 015344 JSR PC,$RETRY ;RETRY THE ORDER
4341 012264 000405 BR 2$ ;RETURN HERE IF RETRY UNSUCCESSFUL
4342 012266 004737 022066 JSR PC,LINE6C ;PRINT LINE 6C OF ERROR MESSAGE
4343 012272 004737 022150 1$: JSR PC,LINE7 ;PRINT LINE 7 OF ERROR MESSAGE
4344 012276 000207 RTS PC
4345 012300 004737 022074 2$: JSR PC,LINE6D ;PRINT LINE 6D OF ERROR MESSAGE
4346 012304 000772 BR 1$
4347
4348 ;PROCESS DRIVE UNSAFE ERROR
4349
4350 012306 004737 020406 UNSAF: JSR PC,LINE1 ;PRINT LINE 1 OF ERROR MESSAGE
4351 012312 104414 050546 DISPLY EM60 ;REPORT DRIVE UNSAFE
4352 012316 004737 020462 JSR PC,LINE2 ;PRINT LINE 2 OF ERROR MESSAGE
4353 012322 004737 021070 JSR PC,LINE3 ;PRINT LINE 3 OF ERROR MESSAGE
4354 012326 004737 023644 JSR PC,INCTOT ;INCREMENT TOTAL ERROR COUNT
4355 012332 012737 000003 001350 MOV #3,RETRY ;RETRY COUNT
4356 012340 004737 015344 JSR PC,$RETRY ;RETRY THE ORDER
4357 012344 000403 BR 1$ ;RETRY WAS UNSUCCESSFUL
4358 012346 004737 022066 JSR PC,LINE6C ;PRINT LINE 6C OF ERROR MESSAGE
4359 012352 000402 BR 2$ ;CONTINUE WITH ERROR REPORT
4360 012354 004737 022074 1$: JSR PC,LINE6D ;PRINT LINE 6D OF ERROR MESSAGE
4361 012360 004737 022150 2$: JSR PC,LINE7 ;PRINT LINE 7 OF ERROR MESSAGE
4362 012364 000207 RTS PC ;RETURN
4363
4364 ;REPORT AN 'UNKNOWN' DATA PATTERN
4365
4366 012366 105737 001376 NOMTCH: TSTB FRSTER ;FIRST ERROR IN THE SECTOR ?
4367 012372 001013 BNE 1$ ;BR IF NOT OR IF PROCESSING 'DCKER'
4368 012374 004737 020406 JSR PC,LINE1 ;TYPE LINE 1 OF ERROR MESSAGE
4369 012400 104414 050154 DISPLY EM43 ;'CAN'T MATCH DATA WITH PATTERN'
4370 012404 004737 020462 JSR PC,LINE2 ;PRINT LINE 2 OF ERROR MESSAGE
4371 012410 004737 021076 JSR PC,LINE3A ;PRINT LINE 3A OF ERROR MESSAGE
4372 012414 004737 021540 JSR PC,LINE4 ;PRINT LINE 4 OF ERROR MESSAGE
4373 012420 000404 BR 2$ ;CONTINUE PROCESSING ERROR
4374 012422 104414 050154 1$: DISPLY ,EM43 ;'CAN'T MATCH DATA WITH PATTERN'
4375 012426 104414 001201 DISPLY ,$CRLF ;CR-LF
4376 012432 104414 052563 2$: DISPLY ,LIN9I ;HEADER FOR DATA PRINTOUT
4377 012436 010146 MOV R1,-(SP) ;ADDRESS OF WORD 1
4378 012440 004737 022430 JSR PC,LINOC ;TYPE WORD 1
4379 012444 104414 053246 DISPLY ,LINS ;SPACES

```

```

4380 012450 012146      MOV      (R1)+, -(SP)      ; ADDRESS OF WORD 1
4381 012452 004737 022430 JSR      PC, LINOCT      ; TYPE WORD 1
4382 012456 104414 001201 DISPLY   $CRLF           ; CR-LF
4383 012462 010146      MOV      R1, -(SP)      ; ADDRESS OF WORD 2
4384 012464 004737 022430 JSR      PC, LINOCT      ; TYPE WORD 2
4385 012470 104414 053246 DISPLY   LINSF           ; SPACES
4386 012474 012146      MOV      (R1)+, -(SP)      ; ADDRESS OF WORD 2
4387 012476 004737 022430 JSR      PC, LINOCT      ; TYPE WORD 2
4388 012502 104414 001201 DISPLY   $CRLF           ; CR-LF
4389 012506 010146      MOV      R1, -(SP)      ; ADDRESS OF WORD 3
4390 012510 004737 022430 JSR      PC, LINOCT      ; TYPE WORD 3
4391 012514 104414 053246 DISPLY   LINSF           ; SPACES
4392 012520 012146      MOV      (R1)+, -(SP)      ; ADDRESS OF WORD 3
4393 012522 004737 022430 JSR      PC, LINOCT      ; TYPE WORD 3
4394 012526 104414 001201 DISPLY   $CRLF           ; CR-LF
4395 012532 010146      MOV      R1, -(SP)      ; ADDRESS OF WORD 4
4396 012534 004737 022430 JSR      PC, LINOCT      ; TYPE WORD 4
4397 012540 104414 053246 DISPLY   LINSF           ; SPACES
4398 012544 012146      MOV      (R1)+, -(SP)      ; ADDRESS OF WORD 4
4399 012546 004737 022430 JSR      PC, LINOCT      ; TYPE WORD 4
4400 012552 104414 001201 DISPLY   $CRLF           ; CR-LF
4401 012556 062701 000770 ADD      #(<252.*2.) , R1  ; INCREMENT BUFFER POINTER
4402 012562 162737 000400 SUB      #256, CMCNT      ; ADJUST WORD COUNT FOR MATCH
4403 012570 132760 000001 BITB     #BIT00, $CODE(R0) ; HEADER OPERATION INVOLVED ?
4404 012576 001405      BEQ      3$             ; NO
4405 012600 062701 000004 ADD      #4, R1           ; ADJUST BUFFER ADDRESS
4406 012604 162737 000002 SUB      #2, CMCNT        ; ADJUST WORD COUNT
4407 012612 005002      CLR      R2             ; CLEAR 'WORDS TO COMPARE' COUNT IN R2
4408 012614 112737 000001 MOVB    #1, FRSTER        ; SET 'NOT FIRST ERROR' INDICATOR
4409 012622 112737 177777 MOVB    #-1, FRSTER+1    ; SET ERROR FOUND INDICATOR
4410 012630 013737 001472 MOV      CMLMT, LIMIT     ; RESET THE COMPARE ERROR TYPEOUT LIMIT
4411 012636 000207      RTS      PC             ; RETURN
4412
4413 ;CHECK ERROR BITS IN THE RH11 & RMO3 REGISTERS
4414
4415 012640 032760 060000 000234 CKERR:  BIT      #60000, $RMCS1(R0) ; SEE IF 'TRE' OR 'MCPE' SET
4416 012646 001012      BNE     1$             ; BR IF EITHER SET
4417 012650 032760 177400 000244 BIT      #177400, $RMCS2(R0) ; SEE IF ERROR BITS IN CS2 SET
4418 012656 001006      BNE     1$             ; BR IF ANY SET
4419 012660 005760 000250 TST     $RMER1(R0)      ; ANY BITS SET IN ER1
4420 012664 001003      BNE     1$             ; BR IF ANY SET
4421 012666 005760 000276 TST     $RMER2(R0)      ; ANY BITS SET IN ER2 ?
4422 012672 001416      BEQ     2$             ; BR IF NONE SET
4423 012674 004737 020406 1$:      JSR     PC, LINE1      ; PRINT LINE 1 OF ERROR MESSAGE
4424 012700 104414 050221 DISPLY   EM44           ; ERROR BITS SET, BUT 'SC' OR 'TRE' NOT SET
4425 012704 004737 020462 JSR     PC, LINE2      ; PRINT LINE 2 OF ERROR MESSAGE
4426 012710 004737 021070 JSR     PC, LINE3      ; PRINT LINE 3 OF ERROR MESSAGE
4427 012714 004737 021540 JSR     PC, LINE4      ; PRINT LINE 4 OF ERROR MESSAGE
4428 012720 004737 023644 JSR     PC, INCTOT      ; INCREMENT TOTAL ERROR COUNT
4429 012724 004737 022150 JSR     PC, LINE7      ; PRINT LINE 7 OF ERROR MESSAGE
4430 012730 000207      RTS      PC             ; RETURN
4431
4432 ;CHECK BUS ADDRESS REGISTER & WORD COUNT REGISTER
4433
4434 012732 005760 000236 CKBUS:  TST     $RMWC(R0)  ; CHECK WORD COUNT
4435 012736 001010      BNE     1$             ; BR IF NOT ZERO

```

```

4436 012740 016046 000020      MOV      $WRDL(R0),-(SP)  :WORD LENGTH
4437 012744 006316              ASL      (SP)            :CHANGE INTO BYTE COUNT
4438 012746 066016 000006      ADD      $BUF(R0),(SP)   :ADD THE STARTING LOCATION
4439 012752 022660 000240      CMP      (SP)+,$RMB(A(R0)) :BUFFER ADDRESS PROPER ?
4440 012756 001416              BEQ      2$             :BR IF OK
4441 012760 004737 020406      1$:     JSR      PC,LINE1  :PRINT LINE 1 OF ERROR MESSAGE
4442 012764 104414 050027      DISPLY  EM41           :BUS ADDRESS OR WORD COUNT INCORRECT
4443 012770 004737 020462      JSR      PC,LINE2      :PRINT LINE 2 OF ERROR MESSAGE
4444 012774 004737 021126      JSR      PC,LINE3D     :PRINT LINE 3D OF ERROR MESSAGE
4445 013000 004737 021540      JSR      PC,LINE4      :PRINT LINE 4 OF ERROR MESSAGE
4446 013004 004737 023644      JSR      PC,INCTOT     :INCREMENT TOTAL ERROR COUNT
4447 013010 004737 022150      JSR      PC,LINE7      :PRINT LINE 7 OF ERROR MESSAGE
4448 013014 000207              RTS                    :
4449
4450                               ;COMPARE THE BUFFER
4451
4452 013016 132760 000004 000024  CMPAR:  BITB      #BIT02,$CODE(R0)  :SEE IF READ ORDER
4453 013024 001001              BNE      1$           :BR IF IT IS
4454 013026 000207              RTS                    :RETURN
4455 013030 005037 001376      1$:     CLR      FRSTER   :CLEAR 'FIRST ERROR' INDICATOR
4456 013034 032777 000002 166112  CMPARD: BIT      #SW01,$SWR  :IS SWITCH 1 SET?
4457 013042 001401              BEQ      1$           :BR IF NOT
4458 013044 000207              RTS                    :YES, DON'T COMPARE
4459 013046 005037 001404      1$:     CLR      ERCTR    :CLEAR THE ERROR COUNTER
4460 013052 016001 000006      MOV      $BUF(R0),R1   :BUFFER ADDRESS
4461 013056 016037 000020 001410  MOV      $WRDL(R0),CMCNT :WORD COUNT TO WORKING LOCATION
4462 013064 066037 000236 001410  ADD      $RMC(R0),CMCNT  :CALCULATE ACTUAL WORDS TRANSFERED
4463 013072 016037 000012 001412  MOV      $CYL(R0),CMCYL  :CYLINDER ADDRESS WORKING LOCATION
4464 013100 052737 010000 001412  BIS      #BIT12,CMCYL    :SET FORMAT BIT
4465 013106 052737 140000 001412  BIS      #140000,CMCYL  :SET MFG AND USER BITS
4466 013114 016037 000010 001414  MOV      $SEC(R0),CMSEC  :SECTOR & TRACK ADDRESSES TO WORKING LOCNS
4467 013122 013737 001472 001406  MOV      CMLPMT,LIMIT   :DISPLAY LIMIT
4468 013130 005237 001406      INC      LIMIT         :CONVERT PARAMETER INTO LIMIT VALUE
4469 013134 012737 177777 001374  CMSTR:  MOV      #-1,ZROIND   :CLEAR THE 'ZERO'S' INDICATOR
4470 013142 005037 001400      CLR      SAVER1        :CLEAR THE R1 SAVE WORD
4471 013146 005037 001402      CLR      SAVER5        :CLEAR THE R5 SAVE WORD
4472 013152 023760 001410 000022  CMP      CMCNT,$SSEC(R0) :IS BUFFER SIZE GREATER THAN ONE SECTOR ?
4473 013160 101005              BHI      1$           :BR IF IT IS
4474 013162 013702 001410      MOV      CMCNT,R2      :LESS THAN, USE REMAINING BUFFER
4475 013166 005037 001410      CLR      CMCNT         :SET COUNTER TO 0
4476 013172 000405              BR       2$           :
4477 013174 016002 000022      1$:     MOV      $SSEC(R0),R2 :COMPARE SECTOR
4478 013200 166037 000022 001410  SUB      $SSEC(R0),CMCNT :DECREMENT WORD COUNT
4479 013206 126027 000024 000005  2$:     CMPB     $CODE(R0),#5   :READ HEADER & DATA?
4480 013214 001025              BNE      CMDAT        :BR IF NOT
4481 013216 052711 140000      CMHED:  BIS      #BIT15:BIT14,(R1) :SET BIT14,BIT15 IN CASE BAD SPOT ENCOUNTER
4482 013222 023721 001412      CMP      CMCYL,(R1)+   :CHECK CYLINDER
4483 013226 001402              BEQ      1$           :BR IF COMPARE OK
4484 013230 004737 013256      JSR      PC,CMSTR2     :REPORT ERROR
4485 013234 023721 001414      1$:     CMP      CMSEC,(R1)+ :COMPARE SECTOR & TRACK
4486 013240 001402              BEQ      4$           :BR IF EQ
4487 013242 004737 013256      JSR      PC,CMSTR2     :REPORT ERROR
4488 013246 162702 000002      4$:     SUB      #2,R2       :SUBTRACT HEADER LENGTH FROM SIZE
4489 013252 003566              BLE      CMPRX        :BR IF FINISHED
4490 013254 000405              BR       CMDAT        :COMPARE THE DATA PORTION
4491 013256 005237 001404      CMSTR2: INC      ERCTR    :INCREMENT THE ERROR COUNT

```

4492	013262	004737	013636		JSR	PC,CMPRT	:REPORT THE COMPARISON ERROR
4493	013266	000207			RTS	PC	:CHECK THE REST OF THE HEADER
4494	013270	004737	014160		CMDAT: JSR	PC,MATCH	:FIND THE PATTERN
4495	013274	000403			BR	2\$	:FOUND A PATTERN
4496	013276	004737	012366		JSR	PC,NOMTCH	:RETURN HERE IF NO MATCH WITH PATTERN MADE
4497	013302	000456			BR	8\$	:BYPASS COMPARE ROUTINE
4498	013304	011405			2\$: MOV	(R4),R5	:ADDRESS OF PATTERN ADDRESS IN R4
4499	013306	012703	000020		MOV	#20,R3	:R3 IS PATTERN POS COUNTER
4500	013312	022125			3\$: CMP	(R1)+,(R5)+	:COMPARE BUFFER WITH PATTERN
4501	013314	001016			BNE	5\$	:BR IF NOT EQUAL
4502	013316	005737	001404		TST	ERCTR	:ERRORS DETECTED ?
4503	013322	001406			BEQ	4\$	:BR IF NO ERRORS
4504	013324	032777	000010	165622	BIT	#SW3,JSWR	:SWITCH 3 SET ?
4505	013332	001402			BEQ	4\$	:BR IF NOT SET
4506	013334	004737	013636		JSR	PC,CMPRT	:DISPLAY THE WORD
4507	013340	005302			4\$: DEC	R2	:DECREMENT SIZE COUNT
4508	013342	003436			BLE	8\$	:BR WHEN AT END
4509	013344	005303			DEC	R3	:DECREMENT PATT POS COUNT
4510	013346	001361			BNE	3\$	:BR IF NOT AT END OF PATT
4511	013350	000755			BR	2\$	:RESTART THE PATTERN
4512	013352	005761	177776		5\$: TST	-2(R1)	:IS MISCOMPARED CHARACTER=0
4513	013356	001410			BEQ	6\$	:BR IF YES
4514	013360	012737	177777	001374	MOV	#-1,ZROIND	:SET NON-ZERO MISCOMPARED INDICATOR
4515	013366	005237	001404		INC	ERCTR	:INCREMENT THE ERROR COUNTER
4516	013372	004737	013636		JSR	PC,CMPRT	:REPORT ERROR
4517	013376	000760			BR	4\$	:CONTINUE COMPARE
4518	013400	105737	001376		6\$: TSTB	FRSTER	:FIRST ERROR?
4519	013404	100407			BMI	7\$	:BR IF NOT
4520	013406	005037	001374		CLR	ZROIND	:SET THE ZERO INDICATOR
4521	013412	010137	001400		MOV	R1,SAVER1	:SAVE CURRENT R1
4522	013416	010537	001402		MOV	R5,SAVER5	:SAVE CURRENT R5
4523	013422	000746			BR	4\$	:CONTINUE COMPARE
4524	013424	005737	001374		7\$: TST	ZROIND	:ANY MISCOMPARISONS NOT ZEROS ?
4525	013430	001743			BEQ	4\$	:BR IF NONE-ALL ERRORS=ZERO
4526	013432	004737	013636		JSR	PC,CMPRT	:REPORT ERROR
4527	013436	000740			BR	4\$	:CONTINUE COMPARING
4528	013440	023727	001410	000004	8\$: CMP	CMCNT,#4	:LAST 3 WORDS ?
4529	013446	002470			BLT	CMPRX	:YES
4530	013450	126027	000024	000005	CMPB	\$CODE(RO),#5	:READ HEAD AND DATA ?
4531	013456	001414			BEQ	9\$	:YES
4532	013460	013702	001410		13\$: MOV	CMCNT,R2	:SET COUNTER = REMAIN BUFFER LENGTH
4533	013464	020227	000004		CMP	R2,#4	:LAST 3 WORDS ?
4534	013470	002457			BLT	CMPRX	:YES EXIT
4535	013472	162737	000400	001410	SUB	#256,CMCNT	:GREATER THAN A SECTOR ?
4536	013500	003673			BLE	CMDAT	:NO RETURN TO COMPARE LOOP
4537	013502	012702	000400		MOV	#256,R2	:SET COUNTER =SECTOR SIZE
4538	013506	000670			BR	CMDAT	:RETURN TO COMPARE LOOP
4539	013510	105237	001414		9\$: INCB	CMSEC	:INCREMENT COUNTER
4540	013514	123727	001414	000040	CMPB	CMSEC,#32.	:MAX SECTOR # ?
4541	013522	103421			BLO	10\$	:NO
4542	013524	105037	001414		CLRB	CMSEC	:RESET SECTOR #
4543	013530	105237	001415		INCB	CMTRK	:INCREMENT TRACK #
4544	013534	123727	001415	000005	CMPB	CMTRK,#5	:MAX TRACK # ?
4545	013542	103411			BLO	10\$	:NO
4546	013544	105037	001415		CLRB	CMTRK	:RESET TRACK #
4547	013550	005237	001412		INC	CMCYL	:INCREMENT CYLINDER NUMBER



```

4548 013554 023727 001412 151466      CMP      CMCYL,#150000+822.      ;LAST CYLINDER ?
4549 013562 103401      BLO      10$                    ;NO
4550 013564 000421      BR       CMPRX                  ;NORMAL RETURN,NOT WRAP AROUND
4551 013566 052711 140000      BIS      #BIT15!BIT14,(R1)    ;SET BIT15/14 INCASE BAD SPOT ENCOUNTER
4552 013572 023721 001412      CMP      CMCYL,(R1)+          ;COMPARE 1ST HEADER WORD
4553 013576 001402      BEQ      11$                    ;MATCH
4554 013600 004737 013256      JSR      PC,CMSTR2             ;NOT MATCH
4555 013604 023721 001414      CMP      CMSEC,(R1)+          ;SECOND WORD OF HEADER
4556 013610 001402      BEQ      12$                    ;MATCH
4557 013612 004737 013256      JSR      PC,CMSTR2             ;NOT MATCH
4558 013616 162737 000002 001410 12$:  SUB      #2,CMCNT              ;ADJUST WORD COUNT
4559 013624 003401      BLE      CMPRX                  ;COMPARE IS DONE
4560 013626 000714      BR       13$                    ;RETURN TO COMPARE LOOP
4561
4562 013630 004737 014112      CMPRX:  JSR      PC,ENDCMP      ;PRINT LAST LINE IF ERRORS
4563 013634 000207      RTS      PC
4564
4565 ;TYPE DATA COMPARE ERRORS
4566
4567 013636 005737 001400      CMPRT:  TST      SAVER1          ;PRINT SAVED VALUES ?
4568 013642 001010      BNE      2$                    ;BR IF NOT
4569 013644 105737 001376      TSTB    FRSTER                ;FIRST ERROR?
4570 013650 100402      BMI     1$                    ;BR IF NOT
4571 013652 004737 013732      JSR      PC,4$                 ;PRINT INITIAL MESSAGE INFO
4572 013656 004737 014014      JSR      PC,8$                 ;PRINT REMAINDER OF MESSAGE
4573 013662 000422      BR       3$                    ;EXIT
4574 013664
4575 013664 010146      MOV      R1,-(SP)              ;;PUSH R1 ON STACK
4576 013666 010546      MOV      R5,-(SP)              ;;PUSH R5 ON STACK
4577 013670 013701 001400      MOV      SAVER1,R1             ;DISPLAY SAVED R1
4578 013674 013705 001402      MOV      SAVER5,R5             ;DISPLAY SAVED R5
4579 013700 004737 013732      JSR      PC,4$                 ;PRINT INITIAL MESSAGE INFO
4580 013704 004737 014014      JSR      PC,8$                 ;PRINT SAVED VALUES
4581 013710 005037 001400      CLR      SAVER1                ;CLEAR SAVED REGISTER INDICATORS
4582 013714 005037 001402      CLR      SAVER5                ;CLEAR THE OTHER ONE
4583 013720 012605      MOV      (SP)+,R5              ;;POP STACK INTO R5
4584 013722 012601      MOV      (SP)+,R1              ;;POP STACK INTO R1
4585 013724 004737 014014      JSR      PC,8$                 ;PRINT REMAINDER OF MESSAGE
4586 013730 000207      RTS      PC                    ;RETURN
4587 013732 105737 001376      4$:    TSTB    FRSTER              ;FIRST ERROR ?
4588 013736 100425      BMI     7$                    ;BR IF NOT
4589 013740 001013      BNE     5$                    ;BR IF FIRST ERROR AND PROCESSING 'DCK' ERROR
4590 013742 004737 020406      JSR      PC,LINE1              ;PRINT LINE 1 OF ERROR MESSAGE
4591 013746 104414 050073      DISPLY  EM42                   ;DATA COMPARE ERROR
4592 013752 004737 020462      JSR      PC,LINE2              ;PRINT LINE 2 OF ERROR MESSAGE
4593 013756 004737 021076      JSR      PC,LINE3A             ;PRINT LINE 3A OF ERROR MESSAGE
4594 013762 004737 021540      JSR      PC,LINE4              ;PRINT LINE 4 OF ERROR MESSAGE
4595 013766 000404      BR       6$                    ;GO TO TYPE HEADER
4596 013770 104414 052456      5$:    DISPLY  ,LIN9B              ;HEADER MESSAGE OF PROCESSING 'DCK' ERROR
4597 013774 104414 001201      DISPLY  ,$CRLF                 ;CR-LF
4598 014000 104414 052505      6$:    DISPLY  ,LIN9H              ;DISPLAY HEADER
4599 014004 012737 177777 001376      MOV      #-1,FRSTER            ;SET ERROR FLAG
4600 014012 000207      RTS      PC                    ;RETURN
4601 014014 005737 001406      7$:    TST      LIMIT              ;TYPEOUT LIMIT REACHED ?
4602 014020 001403      BEQ     9$                    ;BR IF IT HAS
4603 014022 005337 001406      DEC     LIMIT                  ;DECREMENT LIMIT COUNTER

```

```

4604 014026 001005
4605 014030 032777 000200 165116 9$: BNE 10$ ;BR IF NOT AT LIMIT
4606 014036 001001 ;PRINT ALL DATA COMPARE ERRORS ?
4607 014040 000207 ;BR IF YES
4608 014042 010146 ;RTS PC ;RETURN
4609 014044 162716 000002 10$: MOV R1, -(SP) ;BUFFER ADDRESS
4610 014050 004737 022430 SUB #2, (SP) ;ADJUST ADDRESS
4611 014054 104414 053246 JSR PC, LINOCT ;TYPE IT
4612 014060 016546 177776 DISPLY , LINSF ;2 SPACES
4613 014064 004737 022430 MOV -2(R5), -(SP) ;PUT GOOD DATA ON THE STACK
4614 014070 104414 053246 JSR PC, LINOCT ;TYPE IT
4615 014074 016146 177776 DISPLY , LINSF ;2 SPACES
4616 014100 004737 022430 MOV -2(R1), -(SP) ;BAD DATA
4617 014104 104414 001201 JSR PC, LINOCT ;TYPE IT
4618 014110 000207 RTS $CRLF ;CR-LF
4619 ;RETURN
4620 ;LAST LINE OF COMPARE ERROR REPORTING
4621
4622 014112 105737 001377 ENDCMP: TSTB FRSTER+1 ;ANY COMPARE ERRORS FOUND ?
4623 014116 001417 BEQ 2$ ;BR IF NOT
4624 014120 005737 001404 TST ERCTR ;SEE HOW MANY ERRORS
4625 014124 001410 BEQ 1$ ;BR IF ONLY CAN'T MATCH PATTERN
4626 014126 104414 052603 DISPLY , LINGE ;'NUMBER OF ERRORS='
4627 014132 013746 001404 MOV ERCTR, -(SP) ;NUMBER OF ERRORS
4628 014136 004737 022462 JSR PC, LINDEC ;TYPE IT
4629 014142 104414 001201 DISPLY $CRLF ;CR-LF
4630 014146 004737 023644 1$: JSR PC, INCTOT ;INCREMENT TOTAL ERROR COUNT
4631 014152 004737 022150 JSR PC, LINE7 ;PRINT LINE 7 OF ERROR MESSAGE
4632 014156 000207 2$: RTS PC ;RETURN
4633
4634 ;ROUTINE TO MATCH THE DATA WITH A PATTERN
4635 ;CALL:
4636 ;
4637 ; MOV #BUFFER, R1 ;BUFFER ADDRESS
4638 ; JSR PC, MATCH
4639 ; RETURN1 ;PATTERN ADDRESS IN R4
4640 ; RETURN2 ;COULDN'T MATCH PATTERN
4641 ;
4642 014160 010146 MATCH: MOV R1, -(SP) ;SAVE R1 ON THE STACK
4643 014162 012704 000044 #4, R4 ;PATTERN TABLE INDEX
4644 014166 011601 1$: MOV (SP), R1 ;RELOAD R1
4645 014170 162704 000002 SUB #2, R4 ;DECREMENT INDEX
4646 014174 001413 BEQ 3$ ;BR IF PATTERN NOT MATCH
4647 014176 016405 002476 MOV STNDAT(R4), R5 ;ADDRESS OF PATTERN ADDRESS
4648 014202 012703 000004 #4, R3 ;NUMBER OF LOCATIONS TO CHECK
4649 014206 022125 2$: CMP (R1)+, (R5)+ ;COMPARE THE BUFFER AGAINST THE PATTERN
4650 014210 001366 BNE 1$ ;BR IF NOT EQUAL, TRY NEXT PATTERN
4651 014212 005303 DEC R3 ;FINISHED CHECKING?
4652 014214 001374 BNE 2$ ;BR IF NOT FINISHED
4653 014216 062704 002476 ADD #STNDAT, R4 ;MAKE PATTERN ADDRESS ABSOLUTE
4654 014222 000403 BR 4$ ;EXIT
4655 014224 062766 000002 3$: ADD #2, 2(SP) ;INCREMENT RETURN ADDRESS
4656 014232 012601 4$: MOV (SP)+, R1 ;RESTORE R1
4657 014234 000207 RTS PC ;RETURN
4658
4659 ;USE ECC TO CORRECT THE DATA ERROR

```



```

4716 014602 000414
4717 014604 017737 164624 001440 5$: BR ECC1 ;PRINT WORD CORRECTED
4718 014612 013746 001424 MOV @EWORD1,ECBAD1 ;SAVE THE SECOND BAD WORD
4719 014616 047716 164612 MOV ECMSK1, -(SP) ;PUT THE UPPER MASK ON THE STACK
4720 014622 043777 001424 BIC @EWORD1, (SP) ;CLEAR ERRONEOUS ONE BITS FROM UPPER MASK
164604 BIC ECMSK1, @EWORD1 ;CLEAR ERRONEOUS ONE BITS FROM DATA WORD
4721 014630 052677 164600 BIS (SP)+, @EWORD1 ;SET DROPPED BITS
4722 014634 104414 053064 ECC1: DISPLY ,LIN10H ;HEADER
4723 014640 013746 001426 MOV EWORD, -(SP) ;PUT EWORD ON THE STACK
4724 014644 004737 022430 JSR PC,LIN0CT ;TYPE EWORD
4725 014650 104414 053246 DISPLY ,LINSF ;SPACES
4726 014654 013746 001432 MOV ECBAD0, -(SP) ;PUT ECBAD0 ON THE STACK
4727 014660 004737 022430 JSR PC,LIN0CT ;TYPE ECBAD0
4728 014664 104414 053246 DISPLY ,LINSF ;SPACES
4729 014670 017746 164532 MOV @EWORD, -(SP) ;PUT @EWORD ON THE STACK
4730 014674 004737 022430 JSR PC,LIN0CT ;TYPE @EWORD
4731 014700 104414 053246 DISPLY ,LINSF ;SPACES
4732 014704 005737 001434 TST EWORD1 ;PRINT THE NEXT WORD ?
4733 014710 001427 BEQ ECCX ;BR IF NOT
4734 014712 104414 001201 DISPLY ,SCLF ;CR-LF
4735 014716 013746 001434 MOV EWORD1, -(SP) ;PUT EWORD1 ON THE STACK
4736 014722 004737 022430 JSR PC,LIN0CT ;TYPE EWORD1
4737 014726 104414 053246 DISPLY ,LINSF ;SPACES
4738 014732 013746 001440 MOV ECBAD1, -(SP) ;PUT ECBAD1 ON THE STACK
4739 014736 004737 022430 JSR PC,LIN0CT ;TYPE ECBAD1
4740 014742 104414 053246 DISPLY ,LINSF ;SPACES
4741 014746 017746 164462 MOV @EWORD1, -(SP) ;PUT @EWORD1 ON THE STACK
4742 014752 004737 022430 JSR PC,LIN0CT ;TYPE @EWORD1
4743 014756 104414 053246 DISPLY ,LINSF ;SPACES
4744 014762 000402 BR ECCX ;EXIT
4745 014764 104414 052757 ECC2: DISPLY ,LIN10C ;ERROR BURST WAS NOT TRANSFERED TO MEMORY
4746 014770 104414 001201 ECCX: DISPLY ,SCLF ;CR-LF
4747 014774 000207 RTS PC ;RETURN
4748
4749 ;ROUTINE TO DISPLAY THE SECTOR WHICH GAVE THE HARD ERROR
4750
4751 014776 032777 000010 164150 PRTBAD: BIT #SW3, @SWR ;PRINT THE BAD SECTOR ?
4752 015004 001460 BEQ 6$ ;BR IF NOT
4753 015006 016001 000240 MOV $RMB0(R0), R1 ;PUT THE END ADDRESS INTO R1
4754 015012 016046 000020 MOV $WRDL(R0), -(SP) ;FIND THE BEGINNING OF THE SECTOR
4755 015016 066016 000236 ADD $RMC(R0), (SP) ;SUBTRACT THE WORDS NOT TRANSFERED
4756 015022 005046 CLR -(SP) ;MAKE THE UPPER DIVIDEND 0
4757 015024 016046 000022 MOV $SSEC(R0), -(SP) ;DIVDE THE WORDS TRANSFERED BY THE SECTOR SIZE
4758 015030 004737 027522 JSR PC,LINKDV ;DIVIDE
4759 015034 005716 TST (SP) ;REMAINDER = 0 ?
4760 015036 001403 BEQ 1$ ;BR IF IT IS - COMPLETE SECTOR TRANSFERED
4761 015040 006316 ASL (SP) ;CONVERT THE RESIDUAL SECTOR SIZE INTO BYTE COUNT
4762 015042 161601 SUB (SP), R1 ;SUBTRACT IT FROM THE END ADDRESS
4763 015044 000410 BR 2$ ;FINISH THE SIZING
4764 015046 162701 001000 1$: SUB #1000, R1 ;SUBTRACT FULL SECTOR SIZE FROM END ADDR
4765 015052 126027 000024 000005 CMPB $CODE(R0), #5 ;WAS OPERATION READ HEADER & DATA ?
4766 015060 001002 BNE 2$ ;BR IF NOT
4767 015062 162701 000004 SUB #4, R1 ;SUBTRACT HEADER SIZE FROM ADDR
4768 015066 062706 000004 2$: ADD #4, SP ;RESTORE THE STACK POINTER
4769 015072 104414 053151 3$: DISPLY ,LIN11H ;PRINT THE HEADER
4770 015076 012702 000007 MOV #7, R2 ;R2 CONTAINS THE WORDS/LINE COUNT
4771 015102 010146 MOV R1, -(SP) ;PUT THE ADDRESS ON THE STACK

```

```

4772 015104 004737 022430
4773 015110 020160 000240
4774 015114 001412
4775 015116 104414 053246
4776 015122 012146
4777 015124 004737 022430
4778 015130 005302
4779 015132 001366
4780 015134 104414 001201
4781 015140 000756
4782 015142 104414 001201
4783 015146 000207
4784
4785
4786
4787
4788
4789
4790
4791 015150 111037 046062
4792 015154 112737 000117 046064
4793 015162 004037 035364
4794 015166 046062
4795 015170 000774
4796 015172 000207
4797
4798
4799
4800
4801
4802
4803
4804
4805
4806
4807
4808
4809
4810
4811 015174 111037 046062
4812 015200 112737 000107 046064
4813 015206 004037 035364
4814 015212 046062
4815 015214 000774
4816 015216 005737 046100
4817 015222 001775
4818 015224 000207
4819
4820
4821
4822
4823
4824
4825
4826
4827 015226 111037 046062

      JSR      PC,LIN0CT      ;TYPE THE ADDRESS
4S:    CMP      R1,$RMB8(R0)  ;PRINTED ALL THE SECTOR ?
      BEQ      5S             ;BR IF ALL PRINTED
      DISPLY   LINSF          ;SPACES
      MOV      (R1)+,-(SP)    ;PUT THE DATA ON THE STACK
      JSR      PC,LIN0CT      ;TYPE THE DATA
      DEC      R2             ;DECREMENT THE HORIZONTAL COUNT
      BNE     4S             ;BR IF NOT AT THE END OF THE LINE
      DISPLY   $SCRLF         ;CR-LF
      BR      3S             ;RESTORE THE WORDS/LINE COUNT
5S:    DISPLY   $SCRLF         ;PRINT WHAT REMAINS IN THE BUFFER
6S:    RTS      PC           ;RETURN

;ROUTINE TO DO AN RTC - DRIVE SELECTED IN R0
;CALL:
      MOV      #DPB,R0        ;DPB ADDRESS
      JSR      PC,RTNCTR
      RETURN

RTNCTR: MOVB    (R0),GENDPB    ;MOVE THE DRIVE # TO THE GENERAL DPB
        MOVB    #RTC,GENDPB+$COMND ;COMMAND CODE
1S:     JSR      R0,RM03      ;DRIVER ENTRANCE
        GENDPB  ;DPB ADDRESS FOR ORDER
        BR      1$          ;DRIVER DIDN'T ACCEPT ORDER
        RTS      PC         ;RETURN

;ROUTINE TO DO A RECALIBRATE - DRIVE SELECTED IN R0
;CALL:
      MOV      #DPB,R0        ;DPB ADDRESS
      JSR      PC,RECALT
      RETURN

;OR
      MOV      #DPB,R0        ;DPB ADDRESS
      MOVB    #DRIVE,GENDPB  ;DRIVE ADDRESS
      JSR      PC,RECALTO
      RETURN

RECALT: MOVB    (R0),GENDPB    ;MOVE THE DRIVE # TO THE GENERAL DPB
RECALO: MOVB    #RECAL,GENDPB+$COMND ;RECALIBRATE COMMAND
1S:     JSR      R0,RM03      ;DRIVER ENTRANCE
        GENDPB  ;DPB ADDRESS FOR ORDER
        BR      1$          ;DRIVER DIDN'T ACCEPT THE ORDER
2S:     TST     GENDPB+$STATUS ;SEE IF FINISHED
        BEQ     2$          ;BR IF NOT FINISHED
        RTS      PC         ;RETURN

;OFFSET THE DRIVE IN R0 (OFFSET CODE PRELOADED INTO 'RM0F')
;CALL:
      MOVB    #OFFSET,GENDPB+$FMT ;OFFSET CODE
      MOV      #DPB,R0        ;DPB ADDRESS
      JSR      PC,OFFST
      RETURN

OFFST:  MOVB    (R0),GENDPB    ;DRIVE # TO GENERAL DPB

```

```

4828 015232 112737 000115 046064      MOVB    #OFFSET,GENDPB+$COMND ;COMMAND
4829 015240 004037 035364      JSR     RO,RM03                ;DRIVER ENTRANCE
4830 015244 046062                GENDPB                          ;DPB ADDRESS FOR ORDER
4831 015246 000774                BR      1$                     ;DRIVER DIDN'T ACCEPT ORDER
4832 015250 000207                RTS     PC
4833
4834      ;UTILITY READ HEADER ROUTINE
4835      ;CALL:
4836      ;      MOV     #DPB,RO      ;DPB ADDRESS
4837      ;      MOV     #SECTOR,-(SP) ;SECTOR ADDRESS
4838      ;      MOV     #TRACK,-(SP)  ;TRACK ADDRESS
4839      ;      MOV     #CYLINDER,-(SP);CYLINDER ADDRESS
4840      ;      JSR     PC,READDR
4841      ;      RETURN
4842
4843 015252 116637 000004 046073 READHD: MOVB    4(SP),GENDPB+$TRK ;TRACK ADDRESS
4844 015260 116637 000006 046072      MOVB    6(SP),GENDPB+$SEC ;SECTOR ADDRESS
4845 015266 016637 000002 046074      MOV     2(SP),GENDPB+$CYL ;CYLINDER ADDRESS
4846 015274 111037 046062      MOVB    (RO),GENDPB        ;DRIVE NUMBER
4847 015300 112737 000173 046064      MOVB    #RDHD,GENDPB+$COMND ;COMMAND
4848 015306 012737 177776 046066      MOV     #-2,GENDPB+$WRDM   ;WORD CTR = 2
4849 015314 004037 035364      JSR     RO,RM03                ;DRIVER ENTRANCE
4850 015320 046062                GENDPB                          ;DPB ADDRESS FOR ORDER
4851 015322 000774                BR      1$                     ;DRIVER DIDN'T ACCEPT COMMAND
4852 015324 005737 046100      2$:    TST     GENDPB+$STATUS ;FINISHED?
4853 015330 001775                BEQ     2$                     ;BR IF NOT
4854 015332 011666 000006      MOV     (SP),6(SP)           ;ADJUST STACK FOR RETURN
4855 015336 062706 000006      ADD     #6,SP                ;ADJUST RETRUN POINTER
4856 015342 000207                RTS     PC                     ;RETURN
4857
4858      ;RETRY THE PRESENT OPERATION
4859      ;CALL:
4860      ;      MOV     #COUNT,RETRY ;RETRY COUNT
4861      ;      JSR     PC,$RETRY
4862      ;      RETURN1
4863      ;      RETURN2
4864      ;      ;RETRY UNSUCCESSFUL
4865      ;      ;SUCCESSFUL RETRY
4866      ;      ;NOTE: IF A DIFFERENT ERROR OCCURS DURING
4867      ;      ;RETRY, THE ROUTINE EXITS TO 'ERPRC1'
4868 015344 004737 016342      $RETRY: JSR     PC,GODRIV          ;RE-START ORDER
4869 015350 005760 000016      1$:    TST     $STATUS(RO)      ;ORDER FINISHED?
4870 015354 001775                BEQ     1$                     ;BR IF NOT
4871 015356 100405                BMI     2$                     ;BR IF ERROR
4872 015360 105237 001351      INCB    RETRY+1              ;INCREMENT RETRY COUNT
4873 015364 062716 000002      ADD     #2,(SP)             ;INCREMENT RETURN
4874 015370 000425                BR      5$                     ;GO TO EXIT
4875 015372 032750 000200 000016      2$:    BIT     #BIT7,$STATUS(RO) ;DID ORDER TERMINATE NORMALLY ?
4876 015400 001430                BEQ     7$                     ;BR IF NOT
4877 015402 005737 001346      TST     MASK                 ;IS ERROR MASK 0 ?
4878 015406 001004                BNE     3$                     ;BR IF NOT
4879 015410 005760 000250      TST     $RMER1(RO)          ;MAKE SURE THAT THE DRIVE ERROR REG IS CLEAR
4880 015414 001014                BNE     6$                     ;BR IF NOT
4881 015416 000404                BR      4$                     ;CONTINUE RETRY
4882 015420 033760 001346 000250      3$:    BIT     MASK,$RMER1(RO) ;SAME ERROR?
4883 015426 001407                BEQ     6$                     ;BR IF NOT
4884 015430 105237 001351      4$:    INCB    RETRY+1              ;INCREMENT RETRY COUNT

```

```

4884 015434 123737 001350 001351      CMPB   RETRY,RETRY+1      ;DONE ?
4885 015442 001340                    BNE    $RETRY            ;BR IF NOT DONE
4886 015444 000207                    RTS    PC                ;RETURN
4887 015446 004737 022416      5$:   JSR    PC,LINE8     ;REPORT DIFFERENT ERROR
4888 015452 004737 022150      6$:   JSR    PC,LINE7     ;PRINT LINE 7
4889 015456 005726                    TST    (SP)+             ;ADJUST STACK POINTER FOR DIRECT RETURN
4890 015460 000207                    RTS    PC                ;RETURN
4891 015462 104414 052433      7$:   DISPLY  LIN8M       ;'DIFFERENT ERROR DURING RETRY'
4892 015466 000137 006564      JMP    ERPRC1           ;REPORT THE ERROR
4893
4894      ;ROUTINE TO UPDATE THE PERFORMANCE SUMMARY STATISTICS
4895      ;CALL:
4896      ;:      MOV    #DPB,RO      ;DPB ADDRESS
4897      ;:      JSR    PC,STATIS
4898      ;:      RETURN
4899
4900 015472 032760 000300 000016  STATIS: BIT    #BIT07!BIT06,$STATUS(RO) ;CHECK FOR DATA TERMINATION
4901 015500 001451                    BEQ    3$                ;BR IF NOT DATA TERMINATION
4902 015502 016037 000240 015626  MOV    $RMB8(RO),FACTOR ;STORE THE FINAL BUFFER ADDRESS
4903 015510 166037 000006 015626  SUB    $BUF(RO),FACTOR  ;SUBTRACT THE INITIAL ADDRESS
4904 015516 001431                    BEQ    2$                ;BR IF NO DATA TRANSFER
4905 015520 006237 015626  ASR    FACTOR            ;CONVERT TO A WORD COUNT
4906 015524 063760 015626 000046  ADD    FACTOR,$TRANS(RO) ;UPDATE WORD COUNT
4907 015532 005560 000050  ADC    $TRANS+2(RO)     ;ADD ANY CARRY
4908 015536 132760 000002 000024  BITB   #BIT01,$CODE(RO) ;SEE IF ORDER READ OR WRITE
4909 015544 001016                    BNE    2$                ;BRANCH IF ORDER WRITE
4910 015546 126027 000024 000001  CMPB   $CODE(RO),#1     ;PRESENT OPERATION AN AUTOMATIC WRITE CHECK ?
4911 015554 101005                    BHI    1$                ;BR IF NOT
4912 015556 066060 000020 000046  ADD    $WRDL(RO),$TRANS(RO) ;ADD WORDS WRITTEN
4913 015564 005560 000050  ADC    $TRANS+2(RO)     ;ADD A CARRY
4914 015570 063760 015626 000052  1$:   ADD    FACTOR,$READ(RO) ;UPDATE THE READ WORD COUNT
4915 015576 005560 000054  ADC    $READ+2(RO)      ;ADD ANY CARRY
4916 015602 026060 000012 000270  2$:   CMP    $CYL(RO),$RMDC(RO) ;DID MID-TRANSFER SEEK OCCUR
4917 015610 001405                    BEQ    3$                ;BR IF NOT
4918 015612 062760 000001 000042  ADD    #1,$POSIT(RO)    ;INCREMENT SEEK COUNT
4919 015620 005560 000044  ADC    $POSIT+2(RO)     ;ADD CARRY TO UPPER WORD
4920 015624 000207                    RTS    PC
4921
4922 015626 000000      FACTOR: .WORD 0          ;USED FOR WORDS TRANSFERED
4923
4924      ;ROUTINE TO GET A BUFFER
4925      ;CALL:
4926      ;:      MOV    #DPB,RO      ;DPB ADDRESS
4927      ;:      CLR    -(SP)         ;CLEAR THE STACK
4928      ;:      JSR    PC,GETBUF
4929      ;:      RETURN
4930      ;:      ;BUFFER ADDRESS WILL BE ON THE STACK
4931      ;:      ;STACK WILL BE ZERO IF NO BUFFER AVAILABLE
4932
4932 015630 010146      GETBUF: MOV    R1,-(SP)      ;SAVE R1
4933 015632 010246      MOV    R2,-(SP)      ;SAVE R2
4934 015634 010346      MOV    R3,-(SP)      ;SAVE R3
4935 015636 013702 001700      MOV    BUFTBL,R2     ;NUMBER OF SEPARATE BUFFERS
4936 015642 001444      BEQ    6$            ;BR IF NONE AVAILABLE
4937 015644 012701 001702      MOV    #BUFTBL+2,R1  ;FIRST ADDRESS OF ALLOCATION TABLE
4938 015650 026061 000020 000002  1$:   CMP    $WRDL(RO),2(R1) ;SEE IF THERE IS A BLOCK LARGE ENOUGH
4939 015656 101405      BLOS   3$            ;BRANCH IF IT IS

```

```

4940 015660 005302          DEC      R2          ; DECREMENT TABLE COUNT
4941 015662 001434          BEQ      6$          ; BR IF THROUGH TABLE
4942 015664 062701 000004    ADD      #4,R1       ; INCREMENT TABLE POINTER
4943 015670 000767          BR       1$          ; CONTINUE LOOKING
4944 015672 011166 000010    MOV      (R1),10(SP) ; BUFFER ADDRESS TO STACK
4945 015676 166061 000020 000002    SUB      $WRDL(RO),2(R1) ; ADJUST BUFFER SIZE
4946 015704 001407          BEQ      4$          ; BR IF DIFFERENCE IS ZERO
4947 015706 006360 000020    ASL      $WRDL(RO)   ; CONVERT # WORDS TO BYTES
4948 015712 066011 000020    ADD      $WRDL(RO),(R1) ; MAKE NEW STARTING ADDRESS
4949 015716 006260 000020    ASR      $WRDL(RO)   ; RETURN # BYTES TO WORDS
4950 015722 000414          BR       6$          ; RETURN
4951 015724 005337 001700    4$:      DEC      BUFTBL ; DECREMENT ENTRIES COUNT
4952 015730 001411          BEQ      6$          ; BR IF ALLOCATION TABLE EMPTY
4953 015732 005302          DEC      R2          ; DECREMENT TABLE COUNT
4954 015734 001407          BEQ      6$          ; BR IF ITEM WERE LAST ENTRY
4955 015736 010103          MOV      R1,R3       ; MOVE TABLE POINTER
4956 015740 062703 000004    ADD      #4,R3       ; POINT TO NEXT ENTRY
4957 015744 012321 5$:      MOV      (R3)+,(R1)+ ; MOVE ITEMS
4958 015746 012321          MOV      (R3)+,(R1)+
4959 015750 005302          DEC      R2          ; DECREMENT TABLE COUNT
4960 015752 001374          BNE      5$          ; CONTINUE IF NOT AT END OF TABLE
4961 015754 012603 6$:      MOV      (SP)+,R3    ; RESTORE R3
4962 015756 012602          MOV      (SP)+,R2    ; RESTORE R2
4963 015760 012601          MOV      (SP)+,R1    ; RESTORE R1
4964 015762 000207          RTS      PC          ; RETURN
4965
4966
4967          ; ROUTINE TO PUT BUFFER BACK IN TABLE
4968          ; CALL:
4969          ;
4970          ;      MOV      #DPB,RO          ; DPB ADDRESS
4971          ;      JSR      PC,RELBUF
4972          ;      RETURN
4973          RELBUF: MOV      R1,-(SP)      ; SAVE R1
4974          MOV      R2,-(SP)      ; SAVE R2
4975          MOV      R4,-(SP)      ; SAVE R4
4976          MOV      R5,-(SP)      ; SAVE R5
4977          MOV      #BUFTBL+2,R1  ; BEGINNING OF TABLE
4978          MOV      BUFTBL,R2    ; ENTRY COUNT
4979          BEQ      2$          ; BR IF EMPTY TABLE
4980          MOV      $WRDL(RO),R3  ; TRIAL ADDRESS
4981          ASL      R3            ; CHANGE TO BYTE COUNT
4982          ADD      $BUF(RO),R3   ; ADDRESS OF HIGHER ADJACENT BLOCK
4983          1$:      CMP      (R1),R3   ; UPPER ADJACENT BLOCK
4984          BEQ      4$          ; BR IF YES
4985          ADD      #4,R1         ; INCREMENT POINTER
4986          DEC      R2           ; DECREMENT ENTRY COUNT
4987          BNE      1$          ; CONTINUE SEARCHING
4988          MOV      $BUF(RO),(R1) ; PUT THE BUFFER BLOCK INTO THE TABLE
4989          MOV      $WRDL(RO),2(R1) ; BLOCK SIZE
4990          INC      BUFTBL       ; INCREMENT ENTRY COUNT
4991          INC      R2           ; INCREMENT R2 FOR USE LATER
4992          BR       5$          ; SEE IF A LOWER ADJACENT BLOCK IS IN THE TABLE
4993          2$:      MOV      $BUF(RO),(R1)+ ; BLOCK ADDRESS TO TABLE
4994          MOV      $WRDL(RO),(R1)+ ; SIZE TO TABLE
4995          INC      BUFTBL       ; INCREMENT ENTRY COUNT

```



```

4996 016072 000443          BR      10$          ;EXIT
4997 016074 016011 000006 4$:      MOV     $BUF(R0), (R1) ;RELEASED BUFFER IS LOWER ADJACENT
4998 016100 066061 000020 000002  ADD     $WORDL(R0), 2(R1) ;INCREMENTED SIZE
4999 016106 010246          5$:      MOV     R2, -(SP)      ;SAVE R2
5000 016110 013702 001700      MOV     BUFTBL, R2     ;ENTRY COUNT
5001 016114 012705 001702      MOV     #BUFTBL+2, R5 ;BEGINNING OF TABLE
5002 016120 016504 000002 6$:      MOV     2(R5), R4     ;BLOCK SIZE (IN WORDS)
5003 016124 006304          ASL     R4             ;CHANGE TO BYTE COUNT
5004 016126 061504          ADD     (R5), R4      ;ADD BLOCK BEGINNING ADDRESS
5005 016130 020411          CMP     R4, (R1)     ;R1 STILL POINTS TO INSERTED ENTRY
5006 016132 001406          BEQ     8$           ;LOWER ADJACENT IN TABLE
5007 016134 062705 000004      ADD     #4, R5        ;INCREMENT POINTER
5008 016140 005302          DEC     R2           ;DECREMENT ENTRY COUNT
5009 016142 001366          BNE     6$          ;CONTINUE LOOKING
5010 016144 005726          TST     (SP)+         ;RESTORE STACK POINTER
5011 016146 000415          BR      10$          ;END
5012 016150 012602          8$:      MOV     (SP)+, R2     ;RESTORE R2
5013 016152 066165 000002 000002  ADD     2(R1), 2(R5)  ;INCREMENT LOWER BLOCK LENGTH
5014 016160 005337 001700      DEC     BUFTBL       ;DECREMENT ENTRY COUNT
5015 016164 010105          MOV     R1, R5        ;GET READY TO COMPRESS
5016 016166 062705 000004      ADD     #4, R5        ;INCREMENT TO NEXT ENTRY
5017 016172 012521          9$:      MOV     (R5)+, (R1)+ ;COMPRESS TABLE
5018 016174 012521          MOV     (R5)+, (R1)+ ;MOVE SIZE FIELD DOWN
5019 016176 005302          DEC     R2           ;DECREMENT ENTRY COUNT
5020 016200 001374          BNE     9$          ;BR IF NOT FINISHED
5021 016202 012605          10$:     MOV     (SP)+, R5     ;RESTORE R5
5022 016204 012604          MOV     (SP)+, R4     ;RESTORE R4
5023 016206 012602          MOV     (SP)+, R2     ;RESTORE R2
5024 016210 012601          MOV     (SP)+, R1     ;RESTORE R1
5025 016212 000207          RTS     PC           ;RETURN
5026
5027
5028
5029          ;FILL THE ASSIGNED BUFFER (IF WRITE OR WRITE CHECK ORDER)
5030          ;CALL:
5031          ;      MOV     #DPB, R0          ;DPB ADDRESS
5032          ;      MOV     #BUFADR, $BUF(R0) ;LOAD BUFFER ADDRESS INTO THE DPB
5033          ;      MOV     #PATTERN, $PATT(R0) ;PATTERN CODE
5034          ;      JSR     PC, FILBUF
5035          ;      RETURN
5036 016214 104412          FILBUF: SAVREG      ;SAVE THE REGISTERS
5037 016216 132760 000004 000024  BITB   #BIT02, $CODE(R0) ;SEE IF READ ORDER
5038 016224 001044          BNE     4$          ;BR IF READ
5039 016226 016001 000006 1$:      MOV     $BUF(R0), R1 ;BUFFER ADDRESS
5040 016232 016002 000020      MOV     $WORDL(R0), R2 ;POSITIVE WORD COUNT
5041 016236 132760 000001 000024  BITB   #BIT00, $CODE(R0) ;SEE IF WRITE HEADER TYPE ORDER
5042 016244 001413          BEQ     2$          ;BR IF NOT
5043 016246 016011 000012      MOV     $CYL(R0), (R1) ;CYLINDER ADDRESS
5044 016252 052711 010000      BIS     #BIT12, (R1)  ;SET FMT22 BIT
5045 016256 052721 140000      BIS     #140000, (R1)+ ;SET MFG AND USER BITS
5046 016262 016021 000010      MOV     $SEC(R0), (R1)+ ;MOVE SECTOR & TRACK
5047 016266 162702 000002      SUB     #2, R2       ;ADJUST THE WORD COUNT
5048 016272 003421          BLE     4$          ;BR IF END OF PATTERN
5049 016274 005004          2$:      CLR     R4          ;CLEAR R4
5050 016276 116004 000030      MOV     $PATT(R0), R4 ;RELATIVE PATTERN ADDRESS
5051 016302 016405 002476      MOV     STNDAT(R4), R5 ;PATTERN ADDRESS

```

```

5052 016306 012703 000020
5053 016312 012521
5054 016314 005302
5055 016316 003407
5056 016320 005303
5057 016322 001373
5058 016324 012703 000020
5059 016330 016405 002476
5060 016334 000766
5061 016336 104413
5062 016340 000207
5063
5064
5065
5066
5067
5068
5069
5070 016342 010046
5071 016344 010037 016354
5072 016350 004037 035364
5073 016354 000000
5074 016356 000000
5075 016360 012600
5076 016362 062760 000001 000036
5077 016370 005560 000040
5078 016374 026060 000034 000012
5079 016402 001405
5080 016404 062760 000001 000042
5081 016412 005560 000044
5082 016416 000207
5083
5084
5085
5086
5087
5088
5089
5090 016420 004737 033652
5091 016424 032777 000001 162522
5092 016432 001012
5093 016434 012705 000010
5094 016440 004737 027474
5095 016444 020537 001500
5096 016450 103003
5097 016452 004737 017276
5098 016456 000410
5099 016460 013705 033752
5100 016464 042705 177776
5101 016470 062705 000004
5102 016474 110560 000074
5103 016500 005737 001512
5104 016504 001425
5105 016506 016060 000242 000076
5106 016514 016060 000270 000100
5107 016522 026060 000100 000106

3$: MOV #20,R3 ;PATTERN COUNT
MOV (R5)+,(R1)+ ;MOVE THE PATTERN INTO THE BUFFER
DEC R2 ;DECREMENT THE WORD COUNT
BLE 4$ ;BR IF DONE (WORD COUNT = 0)
DEC R3 ;DECREMENT THE PATTERN COUNT
BNE 3$ ;BR IF MORE PATTERN
MOV #20,R3 ;RESTORE PATTERN COUNT
MOV STNDAT(R4),R5 ;RESTORE THE ADDRESS
BR 3$ ;CONTINUE DISTRIBUTING THE PATTERN
4$: RESREG ;RESTORE THE REGISTERS
RTS PC ;RETURN

;START THE ORDER FOR THE DPB IN R0
;CALL:
; MOV #DPB,R0 ;DPB ADDRESS
; JSR PC,GODRIV
; RETURN
GODRIV: MOV R0,-(SP) ;SAVE R0
MOV R0,2$ ;CURRENT DPB ADDRESS
1$: JSR R0,RMO3 ;CALL THE DRIVE HANDLER
2$: .WORD 0 ;DRIVE BLOCK ADDRESS GOES HERE
HALT ;DRIVER REJECTED REQUEST
MOV (SP)+,R0 ;RESTORE R0
ADD #1,$OPERC(R0) ;INCREMENT THE OPERATION COUNT
ADC $OPERC+2(R0)
CMP $PREVA+2(R0),$CYL(R0) ;DID ORDER REQUIRE A CYLINDER CHANGE
BEQ 3$ ;BR IF NOT
ADD #1,$POSIT(R0) ;INCREMENT SEEK COUNT
ADC $POSIT+2(R0) ;ADD ANY CARRY
3$: RTS PC

;GENERATE PARAMETERS FOR THE OPERATION
;CALL:
; MOV #DPB,R0 ;DPB ADDRESS
; JSR PC,SELPAR
; RETURN
SELPAR: JSR PC,$RAND ;CYCLE THE RANDOM NUMBER GENERATOR
BIT #SWO,$SWR ;SEE IF SWO SET
BNE 2$ ;BR IF SET - READ ONLY
1$: MOV #10,R5 ;READ/WRITE SELECTION DIVISOR
JSR PC,GETREM ;GET SELECTION VALUE
CMP R5,RATIO ;DETERMINE IF READ OR WRITE
BHS 2$ ;BR IF READ
JSR PC,RANWRT ;SELECT A WRITE ORDER
BR THEAD ;SELECT ADDRESS
2$: MOV $LONUM,R5 ;SELECT READ OPERATION CODE
BIC #C1,R5 ;MASK OUT ALL BUT BIT 0
ADD #4,R5 ;TABLE OFFSET FOR READ CODE
MOVB R5,$NCODE(R0) ;ORDER SELECTION CODE TO CONTROL BLOCK
THEAD: TST HEADER ;ENABLE RANDOM ADDRESS SELECT ?
BEQ RANSEC ;YES
MOV $RMDA(R0),$NSEC(R0) ;SECTOR AND TRACK
MOV $RMDC(R0),$NCYL(R0) ;CYLINDER NUMBER
CMP $NCYL(R0),MAXCYL(R0) ;OVER MAX CYLINDER # ?

```

```

S108 016530 103520          BLO      XWCNT      ;NO
S109 016532 016060 000110 000100  MOV      MINCYL(RO),$NCYL(RO) ;RESET CYLINDER NUMBER
S110 016540 116060 000120 000076  MOVVB   MINSEC(RO),$NSEC(RO) ;RESET SECTOR NUMBER
S111 016546 116060 000114 000077  MOVVB   MINTRK(RO),$NTRK(RO) ;RESET TRACK NUMBER
S112 016554 000137 016772          JMP      XWCNT      ;SELECT BUFFER SIZE
S113
S114          ;GENERATE A RANDOM SECTOR ADDRESS BETWEEN VALUES 'MINSEC' & 'MAXSEC'
S115
S116 016560 016005 000116  RANSEC: MOV      MAXSEC(RO),R5 ;GET MAXIMUM SECTOR ADDRESS
S117 016564 026005 000120      CMP      MINSEC(RO),R5 ;'MINSEC' AND 'MAXSEC' THE SAME ?
S118 016570 001417          BEQ      2$ ;BR IF THEY ARE
S119 016572 166005 000120      SUB      MINSEC(RO),R5 ;SUBTRACT MINIMUM SECTOR ADDRESS
S120 016576 100002          BPL      1$ ;BR IF MAX LARGER THAN MIN
S121 016600 062705 000040      ADD      #32.,R5 ;CORRECT THE NUMBER
S122 016604 005205          1$: INC      R5 ;INCREMENT DIFFERENCE TO USE AS DIVISOR
S123 016606 004737 027474      JSR      PC,GETREM ;GET THE RANDOM AUGMENT
S124 016612 066005 000120      ADD      MINSEC(RO),R5 ;NEW ADDRESS
S125 016616 020527 000037      CMP      R5,#31. ;IS VALUE TOO LARGE ?
S126 016622 101402          BLOS    2$ ;BR IF NOT
S127 016624 162705 000040      SUB      #32.,R5 ;CORRECT VALUE
S128 016630 110560 000076          2$: MOVVB   R5,$NSEC(RO) ;STORE SECTOR ADDRESS IN DPB
S129
S130          ;GENERATE A RANDOM TRACK ADDRESS BETWEEN VALUES 'MINTRK' & 'MAXTRK'
S131
S132 016634 016005 000112  RANTRK: MOV      MAXTRK(RO),R5 ;GET MAXIMUM TRACK ADDRESS
S133 016640 026005 000114      CMP      MINTRK(RO),R5 ;'MINTRK' AND 'MAXTRK' THE SAME ?
S134 016644 001417          BEQ      2$ ;BR IF THEY ARE
S135 016646 166005 000114      SUB      MINTRK(RO),R5 ;SUBTRACT MINIMUM TRACK ADDRESS
S136 016652 100002          BPL      1$ ;BR IF MAX LARGER THAN MIN
S137 016654 062705 000005      ADD      #5.,R5 ;CORRECT THE NUMBER
S138 016660 005205          1$: INC      R5 ;INCREMENT DIFFERENCE TO USE AS DIVISOR
S139 016662 004737 027474      JSR      PC,GETREM ;GET THE RANDOM AUGMENT
S140 016666 066005 000114      ADD      MINTRK(RO),R5 ;NEW TRACK ADDRESS
S141 016672 020527 000004      CMP      R5,#4. ;IS VALUE TOO LARGE ?
S142 016676 101402          BLOS    2$ ;BR IF NOT
S143 016700 162705 000005      SUB      #5.,R5 ;CORRECT VALUE
S144 016704 110560 000077          2$: MOVVB   R5,$NTRK(RO) ;STORE TRACK ADDRESS IN DPB
S145
S146          ;GENERATE A RANDOM CYLINDER ADDRESS BETWEEN VALUES 'MINCYL' & 'MAXCYL'
S147
S148 016710 016037 000106 001446  RANCYL: MOV      MAXCYL(RO),CYLIMT ;ASSUME AN RMO3
S149 016716 016005 000106          MOV      MAXCYL(RO),R5 ;GET MAXIMUM CYLINDER ADDRESS
S150 016722 026005 000110      CMP      MINCYL(RO),R5 ;'MINCYL' AND 'MAXCYL' THE SAME ?
S151 016726 001417          BEQ      2$ ;BR IF THEY ARE
S152 016730 166005 000110      SUB      MINCYL(RO),R5 ;SUBTRACT MINIMUM CYLINDER ADDRESS
S153 016734 100002          BPL      1$ ;BR IF MAX LARGER THAN MIN
S154 016736 063705 001446      ADD      CYLIMT,R5 ;CORRECT THE NUMBER
S155 016742 005205          1$: INC      R5 ;INCREMENT DIFFERENCE TO USE AS DIVISOR
S156 016744 004737 027474      JSR      PC,GETREM ;GET THE RANDOM AUGMENT
S157 016750 066005 000110      ADD      MINCYL(RO),R5 ;NEW CYLINDER ADDRESS
S158 016754 023705 001446      CMP      CYLIMT,R5 ;IS VALUE TOO LARGE ?
S159 016760 003002          BGT      2$ ;BR IF NOT
S160 016762 016005 000110      MOV      MINCYL(RO),R5 ;CORRECT VALUE
S161 016766 010560 000100          2$: MOV      R5,$NCYL(RO) ;STORE CYLINDER ADDRESS IN DPB
S162 016772 132760 000001 000074  XWCNT: BITB   #BIT00,$NCODE(RO) ;HEADER OPERATION INVOLVED ?
S163 017000 001414          BEQ      RANSIZ ;NO

```

```

5164 017002 012760 000402 000102 MOV #258, $NWRDL(RO) ; CHANGE WORD LENGTH TO 258 FOR WRTHD ORDER
5165 017010 122760 000005 0C0074 3$: CMPB #5, $NCODE(RO) ; READ HEADER AND DATA ?
5166 017016 001461 BEQ RANXIT ; YES
5167 017020 004537 017172 JSR R5,CHKADR ; IF WRITE HEAD AND DATA COMMAND
5168 ; AVOID WRITING BAD SPOT HEADER
5169 017024 000452 BR RANPAT ; BRANCH IF NOT ON BAD SPOT
5170 017026 000137 016420 JMP SELPAR ; SELECT THE PARAMETERS AGAIN
5171
5172 ; GENERATE A RANDOM BUFFER LENGTH BETWEEN 4 & THE VALUE IN 'MAXDL'
5173
5174 017032 013705 001462 RANSIZ: MOV MAXDL, R5 ; GET BUFFER SIZE
5175 017036 005737 001476 TST WSEL ; SELECT A RANDOM WORD COUNT ?
5176 017042 001010 BNE 1$ ; BR IF NOT
5177 017044 005205 INC R5 ; INCREMENT THE MAXIMUM SIZE
5178 017046 004737 027474 JSR PC,GETREM ; DIVIDE BY MAX VALUE
5179 017052 005705 TST R5 ; IS THE REMAINDER 0 ?
5180 017054 001003 BNE 1$ ; NOT 0, CONTINUE
5181 017056 004737 033652 JSR PC,$RAND ; CYCLE THE RANDOM NUMBER GENERATOR
5182 017062 000763 BR RANSIZ ; TRY AGAIN
5183 017064 022705 000004 1$: CMP #4, R5 ; LESS THAN 4 ?
5184 017070 003403 BLE 2$ ; NO
5185 017072 012705 000004 MOV #4, R5 ; SET SIZE TO 4
5186 017076 000405 BR 3$
5187 017100 023705 001462 2$: CMP MAXDL, R5 ; LARGE THAN MAX ALLOWED ?
5188 017104 101002 BHI 3$ ; NO
5189 017106 013705 001462 MOV MAXDL, R5 ; RESET COUNTER
5190 017112 132760 000004 000074 3$: BITB #BIT02, $NCODE(RO) ; READ OPERATION ?
5191 017120 001006 BNE 4$ ; YES
5192 017122 042705 000377 BIC #377, R5 ; SECTOR BOUNDARY FOR WRITE OP
5193 017126 005705 TST R5 ; NONE
5194 017130 003002 BGT 4$ ; NO
5195 017132 012705 000400 MOV #400, R5 ; AT LEAST ONE SECTOR
5196 017136 010560 000102 MOV R5, $NWRDL(RO) ; WORD COUNT
5197 017142 132760 000004 000074 4$: BITB #BIT02, $NCODE(RO) ; READ OP ?
5198 017150 001004 BNE RANXIT ; YES
5199 ; GET A RANDOM PATTERN NUMBER
5200
5201 017152 004737 017332 RANPAT: JSR PC,GETPAT ; GET PATTERN CODE
5202 017156 110560 000075 MOVB R5, $NPATC(RO) ; MOVE PATTERN CODE TO CONTROL BLOCK
5203 017162 012760 177777 000104 RANXIT: MOV #-1, $NEXT(RO) ; SET PARAMETERS SELECTED INDICATOR
5204 017170 000207 RTS PC ; RETURN
5205
5206 ; ROUTINE TO CHECK THE SELECTED ADDRESS IS NOT ON THE BAD SPOT
5207 ; CALLING SEQ
5208 ; RO=DPB ADDRESS
5209 ; JSR R5,CHKADR
5210 ; RET1 NORMAL RETURN
5211 ; RET2 ERROR RET
5212
5213 017172
5214 017172 010146 CHKADR: MOV R1, -(SP) ; PUSH R1 ON STACK
5215 017174 010246 MOV R2, -(SP) ; PUSH R2 ON STACK
5216 017176 010346 MOV R3, -(SP) ; PUSH R3 ON STACK
5217 017200 012701 000020 MOV #16, R1 ; TOTAL 16 SETS OF BAD SECTOR ADDRESSES
5218 017204 010002 MOV R0, R2 ; TABLE ADDRESS
5219 017206 062702 000124 ADD # $B0SEC, R2 ; DBP ADDRESS + TABLE ADDRESS OFFSET

```

```

5220 017212 022712 177777      1$:  CMP      #-1,(R2)      ;EMPTY ENTRY ?
5221 017216 001423              BEQ      3$          ;BRANCH IF SO
5222 017220 026012 000100      CMP      $NCYL(RO),(R2) ;ON THE SAME CYLINDER ?
5223 017224 001013              BNE      2$          ;BRANCH IF NOT
5224 017226 126062 000011 000003  CMPB     $TRK(RO),3(R2) ;ON THE SAME TRACK ?
5225 017234 001007              BNE      2$          ;BRANCH IF NOT
5226 017236 126062 000010 000002  CMPB     $SEC(RO),2(R2) ;ON THE SAME SECTOR ?
5227 017244 001003              BNE      2$          ;BRANCH IF NOT
5228 017246 062705 000002      ADD      #2,R5      ;OTHERWISE,TAKE ERROR EXIT
5229 017252 000405              BR       3$          ;EXIT
5230 017254 005301      2$:  DEC      R1          ;ALL 16 BAD SPOT CHECKED ?
5231 017256 003403              BLE      3$          ;BRANCH IF SO
5232 017260 062702 000004      ADD      #4,R2      ;ADJUST TO NEXT TABLE ENTRY
5233 017264 000752              BR       1$          ;LOOP BACK
5234 017266              3$:  MOV      (SP)+,R3    ;:POP STACK INTO R3
5235 017266 012603              MOV      (SP)+,R2    ;:POP STACK INTO R2
5236 017270 012602              MOV      (SP)+,R1    ;:POP STACK INTO R1
5237 017272 012601              RTS      R5          ;:RETRUN
5238 017274 000205
5239
5240 ;ROUTINE TO SELECT A WRITE (OR WRITE HEAD AND DATA) OPERATION
5241
5242 017276 012705 000002  RANWRT: MOV     #2,R5      ;SET WRITE DATA COMMAND
5243 017302 005737 001474      TST     FORMAT      ;ALLOW FORMAT OPERATION ?
5244 017306 001406              BEQ     1$          ;NO
5245 017310 122760 000004 000024  CMPB    #4,$CODE(RO) ;PREVIOUS A READ DATA COMMAND ?
5246 017316 001002              BNE     1$          ;NO
5247 017320 012705 000003      MOV     #3,R5      ;SET A WRITE HEAD AND DATA COMMAND
5248 017324 110560 000074  1$:  MOVB    R5,$NCODE(RO) ;SELECT THE WRITE COMMAND
5249 017330 000207      RTS     PC          ;EXIT
5250
5251 ;ROUTINE TO SELECT A PATTERN
5252
5253 017332 012705 000020  GETPAT: MOV     #20,R5 ;SELECT PATTERN
5254 017336 005737 001510      TST     PATTEN     ;ENABLE RANDOM PATTERN SELECTION ?
5255 017342 001403              BEQ     2$          ;YES
5256 017344 013705 001510      MOV     PATTEN,R5  ;USE INDEXED PATTERN
5257 017350 000407              BR      1$          ;NO
5258 017352 004737 027474  2$:  JSR     PC,GETREM  ;GET CODE
5259 017356 005705              TST     R5          ;WAS PATTERN ZERO SELECTED ?
5260 017360 001003              BNE     1$          ;BR IF NOT ZERO
5261 017362 004737 033652      JSR     PC,$RAND    ;CYCLE THE RANDOM NUMBER GENERATOR
5262 017366 000761              BR      GETPAT     ;TRY AGAIN
5263 017370 006305  1$:  ASL     R5          ;MAKE CODE INTO TABLE INDEX
5264 017372 000207      RTS     PC
5265
5266 ;ROUTINE TO GET THE PREVIOUSLY SELECTED PARAMETER VALUES
5267 ;CALL:
5268 ;
5269 ;
5270 ;
5271 ;
5272 ;
5273 017374 010546 000234 000027  GETPAR: MOV     R5,-(SP) ;SAVE R5
5274 017376 116060 000234 000027  MOVB    $RMC51(RO),$PREV0(RO) ;SAVE CURRENT PARAMETERS
5275 017404 142760 177701 000027  BICB   #1C76,$PREV0(RO) ;STRIP GO,AND IE BITS

```

```

5276 017412 032760 000006 000074 BIT #6,$NCODE(RO) ;SEE IF NEXT OPERATION IS READ OR WRITE
5277 017420 001007 BNE 1$ ;BR IF EITHER
5278 017422 016060 000012 000034 MOV $CYL(RO),$PREVA+2(RO) ;SAVE STARTING CYLINDER
5279 017430 016060 000010 000032 MOV $SEC(RO),$PREVA(RO) ;SAVE STARTING SECTOR AND TRACK
5280 017436 000410 BR 22$
5281 017440 004737 022502 1$: JSR PC,READR ;GET THE DECREMENTED SECTOR AND TRACK ADDRESSES
5282 017444 012660 000034 MOV (SP)+,$PREVA+2(RO) ;CYLINDER ADDRESS
5283 017450 112660 000033 MOV (SP)+,$PREVA+1(RO) ;TRACK ADDRESS
5284 017454 112660 000032 MOV (SP)+,$PREVA(RO) ;SECTOR ADDRESS
5285 MOV $CYL(RO),$PREVA+2(RO) ;CURRENT CYLINDER
5286 017460 032777 000100 161466 22$: BIT #SW06,$SWR ;SWITCH 6 SET ?
5287 017466 001073 BNE 5$ ;BR IF SET
5288 017470 116060 000074 000024 MOV $NCODE(RO),$CODE(RO) ;LOGICAL CODE FOR OPERATION
5289 017476 116005 000074 MOV $NCODE(RO),R5 ;LOAD R5 FOR USE AS TABLE INDEX
5290 017502 116560 002122 000002 MOV COMTBL(R5),$COMND(RO) ;RMO3 COMMAND CODE
5291 017510 122760 000151 000002 CMPB #151,$COMND(RO) ;WRITE CHECK DATA COMMAND ?
5292 017516 001013 BNE 3$ ;NO,DONOT CARE
5293 017520 122760 000060 000027 CMPB #60,$PREVO(RO) ;PREVIOUS A WRITE DATA COMMAND ?
5294 017526 001420 BEQ 4$ ;YES,OK
5295 017530 112760 000171 000002 2$: MOVB #171,$COMND(RO) ;CHANG TO READ DATA COMMAND
5296 017536 112760 000004 000024 MOVB #4,$CODE(RO) ;CODE NUMBER CHANGED TO READ DATA
5297 017544 000411 BR 4$ ;EXIT
5298 017546 122760 000153 000002 3$: CMPB #153,$COMND(RO) ;WRITE CHECK HEAD AND DATA COMMAND ?
5299 017554 001005 BNE 4$ ;NO,THEN EXIT
5300 017556 122760 000062 000027 CMPB #62,$PREVO(RO) ;PREVIOUS A WRITE HEAD AND DATA COMMAND?
5301 017564 001401 BEQ 4$ ;YES,EXIT
5302 017566 000760 BR 2$ ;SET TO READ DATA COMMAND
5303 017570 4$:
5304 017570 116060 000075 000030 MOV $NPATC(RO),$PATTC(RO) ;PATTERN CODE
5305 017576 016060 000076 000010 MOV $NSEC(RO),$SEC(RO) ;TRACK AND SECTOR ADDRESSES
5306 017604 016060 000100 000012 MOV $NCYL(RO),$CYL(RO) ;CYLINDER ADDRESS
5307 017612 016060 000102 000020 MOV $NWRDL(RO),$WRDL(RO) ;BUFFER SIZE
5308 017620 016060 000102 000004 MOV $NWRDL(RO),$WRDM(RO) ;WORD COUNT FOR THE RH11
5309 017626 005460 000004 NEG $WRDM(RO) ;COMPLEMENT IT
5310 017632 012760 000400 000022 MOV #256,$SSEC(RO) ;INITIAL VALUE OF SECTOR SIZE
5311 017640 032760 000001 000024 BIT #1,$CODE(RO) ;HEADER OPERATION ?
5312 017646 001403 BEQ 5$ ;BR IF NOT
5313 017650 062760 000002 000022 ADD #2,$SSEC(RO) ;ADD HEADER SIZE
5314 017656 005060 000104 5$: CLR $NEXT(RO) ;RESET 'PARAMETERS LOADED' INDICATOR
5315 017662 012605 MOV (SP)+,R5 ;RESTORE R5
5316 017664 000207 RTS PC ;RETURN
5317
5318 ;ROUTINE TO COMPRESS A LIST
5319 ;CALL:
5320 ;
5321 ; MOV #ADDRS,R1 ;COMPRESS LIST STARTING AT THIS ADDRESS
5322 ; JSR PC,CMPRES
5323 ; RETURN
5324 017666 016111 000002 CMPRES: MOV 2(R1),(R1) ;COMPRESS THE TABLE IN R1
5325 017672 001403 BEQ 1$ ;BR WHEN ZERO FOUND
5326 017674 062701 000002 ADD #2,R1 ;INCREMENT R1
5327 017700 000772 BR CMPRES ;CONTINUE COMPRESSING TABLE
5328 017702 000207 1$: RTS PC ;RETURN
5329
5330 ;ROUTINE TO SETUP PARAMETERS FOR A SEQUENTIAL READ OR WRITE OF THE DISK
5331 ;CALL:

```

```

5332      :      MOV      #DPB,RO      ;DPB ADDRESS
5333      :      MOV      #-1,$PACK(RO) ;'WRITE PACK' FLAG
5334      :      OR
5335      :      MOV      #1,$PACK(RO)  ;'READ PACK' FLAG
5336      :      JSR      PC,WRTPK
5337      :      RETURN
5338
5339 017704 004737 033652      WRTPK: JSR      PC,$RAND      ;CYCLE THE RANDOM NUMBER GENERATOR
5340 017710 005760 000040      TST      $OPERC+2(RO) ;SEE IF FIRST OPERATION
5341 017714 001007      BNE      WRTPK1      ;BR IF UPPER WORD OF COUNTER NOT ZERO
5342 017716 005760 000036      TST      $OPERC(RO)  ;LOWER WORD ZERO ?
5343 017722 001004      BNE      WRTPK1      ;BR IF NOT 1ST OPERATION
5344 017724 105760 000026      TSTB     $PACK(RO)   ;SEE WHICH - 'R' OR 'W'
5345 017730 100530      BMI      WRTPK3      ;BR IF 'W'
5346 017732 000515      BR       WRTPK2      ;'R' OPERATION
5347 017734 116060 000234 000027 WRTPK1: MOVB     $RMCS1(RO),$PREV0(RO) ;SAVE CURRENT PARAMETERS
5348 017742 004737 022502      JSR      PC,READDR  ;GET THE DECREMENTED SECTOR AND TRACK ADDRESSES
5349 017746 012660 000034      MOV      (SP)+,$PREVA+2(RO) ;CYLINDER ADDRESS
5350 017752 112660 000033      MOVB     (SP)+,$PREVA+1(RO) ;TRACK ADDRESS
5351 017756 112660 000032      MOVB     (SP)+,$PREVA(RO)  ;SECTOR ADDRESS
5352 017762 016060 000242 000010      MOV      $RMDA(RO),$SSEC(RO) ;NEW SECTOR & TRACK ADDRESS
5353 017770 016060 000270 000012      MOV      $RMDC(RO),$CYL(RO) ;NEW CYLINDER ADDRESS
5354 017776 026060 000012 000106      CMP      $CYL(RO),$MAXCYL(RO) ;SEE IF AT END
5355 020004 103436      BLO      2$          ;BR IF LESS THAN 'MAXCYL'
5356 020006 101004      BHI      1$          ;BR IF GREATER THAN 'MAXCYL'
5357 020010 126060 000011 000112      CMPB     $STRK(RO),$MAXTRK(RO) ;SEE IF AT MAX TRACK
5358 020016 103431      BLO      2$          ;BR IF NOT GREATER
5359 020020 116060 000114 000011 1$:      MOVB     $MINTRK(RO),$STRK(RO) ;RESET TRACK ADDRESS
5360 020026 116060 000120 000010      MOVB     $MINSEC(RO),$SSEC(RO) ;RESET SECTOR ADDRESS
5361 020034 016060 000110 000012      MOV      $MINCYL(RO),$CYL(RO) ;RESET CYLINDER ADDRESS
5362 020042 112760 000004 000024      MOVB     #4,$CODE(RO)      ;SET CODE TO READ DATA
5363 020050 122760 177776 000026      CMPB     #-2,$PACK(RO)    ;WT OPERATION IN PROCESSING
5364 020056 001475      BEQ      WRTPK5      ;YES
5365 020060 004737 027166      JSR      PC,EOP2     ;DROP THE DRIVE (NORMAL TERMINATION)
5366 020064 032777 000020 161062      BIT      #SW04,$SWR    ;IS SWITCH 4 SET ?
5367 020072 001003      BNE      2$          ;BR IF SET
5368 020074 005726      TST      (SP)+       ;INCREMENT THE STACK POINTER
5369 020076 000137 005420      JMP      MAIN        ;RETURN DIRECTLY TO 'MAIN'
5370 020102 013760 001462 000020 2$:      MOV      $MAXDL,$WRDL(RO) ;BUFFER SIZE IS MAXIMUM
5371 020110 042760 000377 000020      BIC      #377,$WRDL(RO) ;SECTOR BOUNDARY FOR WRITING
5372 020116 013760 001462 000004      MOV      $MAXDL,$WRDM(RO) ;WORD COUNT
5373 020124 042760 000377 000004      BIC      #377,$WRDM(RO) ;SECTOR BOUNDARY FOR WRITING
5374 020132 005760 000004      TST      $WRDM(RO)    ;SIZE=0 ?
5375 020136 003006      BGT      3$          ;NO
5376 020140 012760 000400 000004      MOV      #400,$WRDM(RO) ;SET TO ONE SECTOR
5377 020146 012760 000400 000020      MOV      #400,$WRDL(RO) ;SET ONE SECTOR
5378 020154 005460 000004 3$:      NEG      $WRDM(RO)    ;CHANGE WORD COUNT TO 2'S COMPLEMENT
5379 020160 105760 000026      TSTB     $PACK(RO)   ;READ OR WRITE ?
5380 020164 100412      BMI      WRTPK3      ;BR IF WRITE
5381 020166 012760 000402 000022 WRTPK2: MOV      #258,$SSEC(RO) ;SECTOR SIZE FOR READ
5382 020174 112760 000005 000024      MOVB     #5,$CODE(RO)  ;CODE FOR READ HEADER & DATA
5383 020202 112760 000173 000002      MOVB     #ROHD,$COMND(RO) ;DRIVE CODE FOR OPERATION
5384 020210 000415      BR       WRTPK4      ;SET UP FOR EXIT
5385 020212 012760 000400 000022 WRTPK3: MOV      #256,$SSEC(RO) ;SECTOR SIZE
5386 020220 112760 000002 000024      MOVB     #2,$CODE(RO)  ;CODE FOR WRTDAT
5387 020226 112760 000161 000002      MOVB     #WRTDAT,$COMND(RO) ;OP CODE

```

```

5388 020234 004737 017332          JSR    PC,GETPAT          ;GET PATTERN CODE
5389 020240 110560 000030          MOV    R5,SPATTC(RO)     ;PATTERN CODE
5390 020244 005060 000104          WRTPK4: CLR    $NEXT(RO)  ;CLEAR 'PARAMETER SELECTED' INDICATOR
5391 020250 000207                    RTS    PC                ;RETURN
5392 020252 005037 001316          WRTPK5: CLR    PACK      ;CLEAR WT FLAG
5393 020256 105060 000026          CLR    SPACK(RO)       ;CLEAR WT FLAG
5394 020262 005726                    TST    (SP)+            ;CLEAR STACK LEVEL
5395 020264 000137 005420          JMP    MAIN             ;JUMP TO MAIN BACKGROUND LOOP
5396
5397          ;ROUTINE TO DETERMINE OF ERROR IS AT A LOCATION ON THE PACK DEFINED
5398          ;IN THE BAD TRACK/SECTOR TABLE FOR THE DRIVE.
5399          ;CALL:
5400          ;
5401          ;          JSR    PC,SPOTCK
5402          ;          RETURN1
5403          ;          RETURN2
5404          ;
5405          SPOTCK:
5406          020270 010146          MOV    R1,-(SP)         ;;PUSH R1 ON STACK
5407          020272 010246          MOV    R2,-(SP)         ;;PUSH R2 ON STACK
5408          020274 012701 000124          MOV    #BADSEC,R1      ;INCREMENT FOR BAD SECTOR TABLE
5409          020300 060001          ADD    RO,R1           ;ADD THE BLOCK'S STARTING ADDRESS
5410          020302 012702 000020          MOV    #16,R2         ;BAD SECTOR TABLE SIZE COUNT
5411          020306 004737 022502          1$: JSR    PC,READDR     ;DECREMENT THE SECTOR/TRACK ADDRESS
5412          020312 021126          CMP    (R1),(SP)+      ;ON THE SAME CYLINDER ?
5413          020314 001007          BNE    2$             ;BRANCH IF NOT
5414          020316 122661 000003          CMPB  (SP)+,3(R1)     ;COMPARE THE TRACK ADDRESS
5415          020322 001005          BNE    3$             ;BR IF IT IS NOT EQUAL
5416          020324 122661 000002          CMPB  (SP)+,2(R1)     ;COMPARE THE SECTOR ADDRESS
5417          020330 001003          BNE    4$             ;BR IF NOT EQUAL
5418          020332 000411          BR     5$             ;CHECK 'NOTPRT'
5419          020334 005726          2$: TST    (SP)+        ;CLEAR OFF THE STACK
5420          020336 005726          3$: TST    (SP)+        ;INCREMENT THE STACK POINTER
5421          020340 062701 000004          4$: ADD    #4,R1       ;GO TO THE NEXT LOCATION IN THE TABLE
5422          020344 005711          TST    (R1)           ;PAST THE TABLE ENTRIES ?
5423          020346 100411          BMI    6$             ;BR IF PAST
5424          020350 005302          DEC    R2             ;DECREMENT THE MAXIMUM ENTRY COUNT
5425          020352 001355          BNE    1$             ;BR IF MORE TO CHECK
5426          020354 000406          BR     6$             ;END, EXIT
5427          020356 005737 001504          5$: TST    NOTPRT      ;PRINT THE ERROR ANYWAY ?
5428          020362 001006          BNE    7$             ;BR IF NOT
5429          020364 012737 177777 001362          MOV    #-1,BADSEC     ;SET THE INDICATOR FOR THE IDENTIFICATION LINE
5430          020372 062766 000002 000004          6$: ADD    #2,4(SP)    ;INCREMENT THE RETURN
5431          020400          7$:
5432          020400 012602          MOV    (SP)+,R2       ;;POP STACK INTO R2
5433          020402 012601          MOV    (SP)+,R1       ;;POP STACK INTO R1
5434          020404 000207          RTS    PC             ;RETURN
5435
5436          ;;*****
5437          .SBTTL  ERROR MESSAGE GENERATION ROUTINES
5438          ;;*****
5439
5440          ;PRINT LINE 1 OF ERROR MESSAGE:
5441          ;'HH:MM:SS'
5442
5443

```



M08

CZRM880 RM03/2 PERF EXER  
CZRM88.P11 21-NOV-77 15:34

MACY11 30(1046) 22-NOV-77 10:06 PAGE 104  
ERROR MESSAGE GENERATION ROUTINES

SEQ 0103

```

5444
5445 020406 032777 002000 160540 LINE1: BIT      #SW10,2SWR      ;SWITCH 10 SET ?
5446 020414 001402                BEQ      1$              ;BR IF NOT
5447 020416 104401 001174                TYPE     #BELL           ;RING THE BELL
5448 020422 032777 020000 160524 1$: BIT      #SW13,2SWR      ;INHIBIT TYPEOUT ?
5449 020430 001407                BEQ      2$              ;BR IF NOT
5450 020432 104414 001201                DISPLY   ,SCRLF         ;CR-LF
5451 020436 104414 001201                DISPLY   ,SCRLF         ;CR-LF
5452 020442 104414 001201                DISPLY   ,SCRLF         ;CR-LF
5453 020446 000404                BR       3$              ;EXIT
5454 020450 004737 023670                JSR      PC,TIME        ;TYPE THE TIME
5455 020454 104414 053247                DISPLY   ,LINSPO        ;SPACES
5456 020460 000207                3$: RTS      PC          ;RETURN & TYPE DESCRIPTION
5457
5458
5459
5460
5461
5462
5463
5464
5465
5466
5467
5468 020462
5469 020462 010346                LINE2: MOV      R3,-(SP)      ;: PUSH R3 ON STACK
5470 020464 010446                MOV      R4,-(SP)      ;: PUSH R4 ON STACK
5471 020466 010546                MOV      R5,-(SP)      ;: PUSH R5 ON STACK
5472 020470 104414 001201                DISPLY   ,SCRLF         ;: CR-LF
5473 020474 005037 020622                CLR      4$            ;: CLEAR MESSAGE ADDRESS STORAGE
5474 020500 005004                CLR      R4            ;: WORKING REGISTER
5475 020502 012737 051352 020622                MOV      #LIN2C,4$     ;: ADDRESS OF 'PRESENT ORDER = ' MSG
5476 020510 116004 000234                MOV      $RMCS1(R0),R4 ;: GET THE OPCODE
5477 020514 042704 177701                BIC      #1C76,R4      ;: SAVE ONLY SIGNIFICANT BITS
5478 020520 004737 020556                JSR      PC,1$         ;: TYPE THE FIRST MNEMONIC
5479 020524 005737 020626                TST      5$            ;: SEE IF MNEMONIC ENTRY FOUND
5480 020530 001440                BEQ      LINE2A        ;: BR IF NOT
5481 020532 012737 051373 020622                MOV      #LIN2P,4$     ;: ADDRESS OF 'PREVIOUS ORDER = ' MSG
5482 020540 116004 000027                MOV      $PREVO(R0),R4 ;: PREVIOUS OPERATION CODE
5483 020544 042704 177701                BIC      #1C76,R4      ;: SAVE ONLY SIGNIFICANT BITS
5484 020550 004737 020556                JSR      PC,1$         ;: TYPE THE PREVIOUS MNEMONIC
5485 020554 000426                BR       LINE2A        ;: CONTINUE
5486 020556 005005                1$: CLR      R5        ;: CLEAR THE TABLE INDEX
5487 020560 126504 002130                2$: CMPB   OPTBL(R5),R4 ;: LOOK FOR THE OPCODE
5488 020564 001405                BEQ      3$            ;: BR WHEN OPCODE COUNT EQUALS OPCODE
5489 020566 105765 002130                TSTB   OPTBL(R5)      ;: LOOK FOR END OF TABLE
5490 020572 100402                3$: BMI   3$            ;: BR IF END
5491 020574 005205                INC     R5            ;: INCREMENT THE POINTER
5492 020576 000770                BR      2$            ;: CONTINUE - NOT END OF TABLE
5493 020600 006305                3$: ASL    R5            ;: SHIFT INDEX
5494 020602 006305                ASL    R5            ;: SHIFT THE INDEX
5495 020604 006305                ASL    R5            ;: SHIFT THE INDEX
5496 020606 012737 002152 020626                MOV      #MNTBL,5$     ;: ADDRESS OF ASCII TEXT TABLE
5497 020614 060537 020626                ADD     R5,5$         ;: ADD THE INDEX
5498 020620 104414                DISPLY   ;: TYPE IT
5499 020622 000000                4$: .WORD 0           ;: ADDRESS OF 'PRESENT' OR 'PREVIOUS' MESSAGE

```

```

5500 020624 104414
5501 020626 000000
5502 020630 000207
5503 020632 005737 001362
5504 020636 001404
5505 020640 104414 001201
5506 020644 104414 051417
5507 020650 104414 001201
5508 020654 104414 050746
5509 020660 104414 053247
5510 020664 013746 001344
5511 020670 004737 022462
5512 020674 104414 053246
5513 020700 012705 051272
5514 020704 004737 021034
5515 020710 032777 000040 160236
5516 020716 001014
5517 020720 104414 051051
5518 020724 012705 051314
5519 020730 004737 021034
5520 020734 104414 051150
5521 020740 012705 051336
5522 020744 004737 021034
5523 020750 032760 000100 000016 1$:
5524 020756 001422
5525 020760 016046 000020
5526 020764 066016 000236
5527 020770 006316
5528 020772 066016 000006
5529 020776 022660 000240
5530 021002 001410
5531 021004 104414 050373
5532 021010 104414 001201
5533 021014 004737 021126
5534 021020 004737 021540
5535 021024
5536 021024 012605
5537 021026 012604
5538 021030 012603
5539 021032 000207
5540 021034 012546
5541 021036 060016
5542 021040 017646 000000
5543 021044 004737 022430
5544 021050 005726
5545 021052 104414 053246
5546 021056 005715
5547 021060 001365
5548 021062 104414 001201
5549 021066 000207
5550
5551
5552
5553
5554 021070 104414 051453
5555 021074 000517

SS: DISPLY ;TYPE THE OPERATION MNEMONIC
.WORD 0 ;ADDRESS OF MESSAGE
RTS PC ;RETURN TO MAIN ROUTINE
LINE2A: TST BADSEC ;PRINT THE BAD SECTOR LINE ?
BEQ LINE2B ;BR IF NOT
DISPLY , $CRLF ;CR-LF
LINE2B: DISPLY , LIN2S ;ERROR ADDRESS DEFINED AS BAD AREA
DISPLY , $CRLF ;CR-LF
DISPLY , DH14 ;STANDARD RMQ3 REGISTER HEADER
DISPLY , LINSPO ;TYPE A SPACE
MOV UNIT, -(SP) ;PUT THE DRIVE NUMBER ON THE STACK
JSR PC, LINDEC ;TYPE DRIVE NUMBER
DISPLY , LINSP ;SPACES
MOV #DT14, R5 ;REGISTER INDEXES
JSR PC, 3$ ;PRINT THE REGISTERS
BIT #SW05, $SWR ;PRINT THE OPTIONAL REGISTERS ?
BNE 1$ ;BR IF NOT
DISPLY , DH15 ;SECOND DATA LINE
MOV #DT15, R5 ;PRINT THEM
JSR PC, 3$
DISPLY , DH16 ;THIRD DATA LINE
MOV #DT16, R5 ;PRINT THE REGISTERS
JSR PC, 3$ ;DATA ERROR ?
BIT #BIT6, $STATUS(R0) ;BR IF NOT
BEQ 2$ ;TRANSFER SIZE
MOV $WRDL(R0), -(SP) ;ADD REMAINING WORD COUNT
ADD $RMWC(R0), (SP) ;CONVERT TO AN BYTE INCREMENT
ASL (SP) ;BUFFER STARTING ADDRESS
ADD $BUF(R0), (SP) ;CORRECT BUFFER ADDRESS ?
CMP (SP)+, $RMB(A(R0)) ;BR IF YES
BEQ 2$ ;'BUS ADDRESS AND WORD COUNT ARE NOT CONSISTENT'
DISPLY , EM46 ;CR-LF
DISPLY , $CRLF ;PRINT LINE 3D OF ERROR MESSAGE
JSR PC, LINE3D ;PRINT LINE 4 OF ERROR MESSAGE
JSR PC, LINE4
2$: MOV (SP)+, R5 ;POP STACK INTO R5
MOV (SP)+, R4 ;POP STACK INTO R4
MOV (SP)+, R3 ;POP STACK INTO R3
RTS PC ;RETURN TO ERROR PROCESSING ROUTINE
3$: MOV (R5)+, -(SP) ;PUT THE REGISTER INDEX ON THE STACK
ADD RD, (SP) ;ADD DRIVE'S TABLE ADDRESS
MOV @($P), -(SP) ;VALUE
JSR PC, LINOCT ;TYPE IT
TST (SP)+ ;CORRECT THE STACK POINTER
DISPLY , LINSP ;PRINT 2 SPACES
TST (R5) ;AT END OF LINE ?
BNE 3$ ;BR IF NOT
4$: DISPLY , $CRLF ;CR-LF
RTS PC ;RETURN

;PRINT LINE 3 OF ERROR MESSAGE
;'ERROR AT CCC TT SS PREVIOUS ADR = CCC TT SS'
LINE3: DISPLY , LINM3 ;LINE 3 ENTRANCE
BR LIN3.1 ;FINISH PRINTOUT

```

5556  
5557  
5558  
5559  
5560  
5561  
5562  
5563  
5564  
5565  
5566  
5567  
5568  
5569  
5570  
5571  
5572  
5573  
5574  
5575  
5576  
5577  
5578  
5579  
5580  
5581  
5582  
5583  
5584  
5585  
5586  
5587  
5588  
5589  
5590  
5591  
5592  
5593  
5594  
5595  
5596  
5597  
5598  
5599  
5600  
5601  
5602  
5603  
5604  
5605  
5606  
5607  
5608  
5609  
5610  
5611

021076 104414 051471  
021102 000514  
  
021104 004737 021442  
021110 104414 001201  
021114 000207  
  
021116 004737 021442  
021122 000137 021474  
  
021126 032777 000040 160020  
021134 001416  
021136 104414 051642  
021142 016046 000240  
021146 004737 022430  
021152 104414 051652  
021156 016046 000236  
021162 004737 022430  
021166 104414 001201  
021172 000207  
  
021174 104414 051536  
021200 016046 000012  
021204 004737 022462  
021210 104414 053246  
021214 104414 051664  
021220 005046  
021222 116016 000011  
021226 004737 022462  
021232 104414 053246  
021236 104414 051701  
021242 005046  
021244 116016 000010  
021250 004737 022462  
021254 104414 001201  
021260 000207

```
;PRINT LINE 3A OF ERROR MESSAGE
;'START CYL = CCC END CYL = CCC'
LINE3A: DISPLY LIN3          ;LINE 3A ENTRANCE
        BR      LIN3.1      ;FINISH ERROR LINE

;PRINT LINE 3B OF ERROR MESSAGE
;'START CYL = CCC END CYL = CCC ACTUAL CYL = CCC'
LINE3B: JSR     PC,LIN3.3    ;LINE 3B ENTRANCE
        DISPLY  $CRLF
        RTS     PC

;PRINT LINE 3C OF ERROR MESSAGE
;'START CYL = CCC END CYL = CCC ACTUAL CYL = CCC TRK = TT'
LINE3C: JSR     PC,LIN3.3    ;LINE 3C ENTRANCE
        JMP     LIN3.4      ;FINISH MESSAGE

;PRINT LINE 3D OF ERROR MESSAGE
;'RMB = XXXXXX RMWC = XXXXXX'
LINE3D: BIT     #SW05,$SWR   ;SWITCH 5 SET ?
        BEQ     1$          ;BR IF IT IS
        DISPLY  LIN3        ;'RMB = '
        MOV     $RMB($RO),-(SP) ;BUFFER ADDR REG CONTENTS
        JSR     PC,LIN3OCT  ;CONVERT TO OCTAL AND TYPE IT
        DISPLY  LIN3        ;' RMWC = '
        MOV     $RMWC($RO),-(SP) ;WORD COUNT REGISTER CONTENTS
        JSR     PC,LIN3OCT  ;CONVERT TO OCTAL AND TYPE IT
        DISPLY  $CRLF
1$:     RTS     PC

;PRINT LINE 3E OF ERROR MESSAGE
;'START CYL = CCC START TRK = TT START SEC = SS'
LINE3E: DISPLY  LINS3        ;'START CYL = '
        MOV     $CYL($RO),-(SP) ;MOVE CYL TO STACK
        JSR     PC,LINDEC   ;TYPE IT IN DECIMAL
        DISPLY  LINS        ;SPACES
        DISPLY  LINST3     ;'START TRK = '
        CLR     -(SP)      ;CLEAR STACK
        MOVB   $TRK($RO),-(SP) ;TRACK TO STACK
        JSR     PC,LINDEC   ;TYPE IT IN DECIMAL
        DISPLY  LINS        ;SPACES
        DISPLY  LINS3      ;'START SEC = '
        CLR     -(SP)      ;CLEAR STACK
        MOVB   $SEC($RO),-(SP) ;SECTOR ADDR TO STACK
        JSR     PC,LINDEC   ;TYPE IT IN DECIMAL
        DISPLY  $CRLF
        RTS     PC

;PRINT LINE 3F OF ERROR MESSAGE
;'RMD = XXXXXX RMCA = XXXXXX'
```

```

5612 021262 032777 000040 157664 LINE3F: BIT      #SWS,JSWR      ;SWITCH 5 SET ?
5613 021270 001420          BEQ      IS          ;BR IF NOT
5614 021272 104414 051632      DISPLY  LINDA3       ;RMDA =
5615 021276 016046 000242      MOV     $RMDA(RO),-(SP) ;PUT SECTOR/TRACK ADDRESS ON THE STACK
5616 021302 004737 022430      JSR     PC,LINOC     ;TYPE IT
5617 021306 104414 053246      DISPLY  LINS3        ;SPACES
5618 021312 104414 051621      DISPLY  LINCA3       ;RMDC =
5619 021316 016046 000270      MOV     $RMDC(RO),-(SP) ;PUT DESIRED CYLINDER ADDRESS ON THE STACK
5620 021322 004737 022430      JSR     PC,LINOC     ;TYPE IT
5621 021326 104414 001201      DISPLY  $CRLF
5622 021332 000207          RTS     PC
5623
5624          ;'CCC TT SS  PREV ADR = CCC TT SS'
5625
5626          ;LIN3.1:
5627 021334 004737 022502      MOV     $RMDC(RO),-(SP) ;PUT CYLINDER ADDR ON STACK
5628 021340 004737 022462      LIN3.1: JSR     PC,READDR ;DECREMENT TRACK AND SECTOR ADDRESS
5629 021344 104414 051466          JSR     PC,LINDEC     ;TYPE IT IN DECIMAL
5630          DISPLY  T          ;PRINT 'T'
5631          ;
5632          JSR     PC,READDR ;DECREMENT TRACK AND SECTOR ADDRESSES
5633          JSR     PC,LINDEC ;TYPE TRACK IN DECIMAL
5634          DISPLY  S          ;PRINT 'S'
5635          JSR     PC,LINDEC ;TYPE SECTOR ADDRESS
5636          DISPLY  LINS3       ;PRINT 'PREV ADDR'
5637          MOV     $PREVA+2(RO),-(SP) ;PREVIOUS CYLINDER
5638          JSR     PC,LINDEC ;TYPE IT IN DECIMAL
5639          DISPLY  T          ;PRINT 'T'
5640          CLR     -(SP)       ;MAKE ROOM ON THE STACK
5641          MOV     $PREVA+1(RO),(SP) ;PREVIOUS TRACK ADDRESS
5642          JSR     PC,LINDEC ;TYPE IT IN DECIMAL
5643          DISPLY  S          ;PRINT 'S'
5644          CLR     -(SP)       ;MAKE ROOM ON THE STACK
5645          MOV     $PREVA(RO),(SP) ;PREVIOUS SECTOR DRESS
5646          JSR     PC,LINDEC ;TYPE IT IN DECIMAL
5647          DISPLY  $CRLF
5648          RTS     PC
5649
5650          ;'START CYL = CCC  END CYL = CCC'
5651          LIN3.3: DISPLY  LINS3 ;LINE '3B & 3C' ENTRANCE
5652          MOV     $PREVA+2(RO),-(SP) ;PREVIOUS CYLINDER
5653          JSR     PC,LINDEC ;TYPE IT IN DECIMAL
5654          DISPLY  LINS3       ;PRINT 'END CYL'
5655          MOV     $RMDC(RO),-(SP) ;PRESENT CYLINDER
5656          JSR     PC,LINDEC ;TYPE IT IN DECIMAL
5657          RTS     PC
5658
5659          ;'ACTUAL CYL = CCC  TRK = TT'
5660          LIN3.4: DISPLY  LINDA3 ;PRINT 'ACTUAL'
5661          MOV     CYLDER, -(SP) ;ACTUAL CYLINDER
5662          BIC     #BIT12,(SP) ;CLEAR THE FORMAT BIT
5663          JSR     PC,LINDEC ;TYPE IT IN DECIMAL
5664          DISPLY  LINT3       ;PRINT TRACK
5665          CLR     -(SP)       ;CLEAR STACK WORD
5666          MOV     $RMDA+1(RO),(SP) ;PUT TRACK ON STACK
5667          JSR     PC,LINDEC ;TYPE IT IN DECIMAL

```

5668 021532 104414 001201  
5669 021536 000207  
5670  
5671  
5672  
5673  
5674 021540 032760 000100  
5675 021546 001427  
5676 021550 104414 051716  
5677 021554 016046 000006  
5678 021560 004737 022430  
5679 021564 104414 051735  
5680 021570 016046 000020  
5681 021574 004737 022462  
5682 021600 104414 051747  
5683 021604 016046 000240  
5684 021610 166016 000006  
5685 021614 006216  
5686 021616 004737 022462  
5687 021622 104414 001201  
5688 021626 000207  
5689  
5690  
5691  
5692  
5693 021630 104414 052002  
5694 021634 162760 000002  
5695 021642 017046 000240  
5696 021646 004737 022430  
5697 021652 104414 052017  
5698 021656 016046 000256  
5699 021662 004737 022430  
5700 021666 016046 000236  
5701 021672 066016 000020  
5702 021676 005046  
5703 021700 016046 000022  
5704 021704 004737 027522  
5705 021710 012616  
5706 021712 104414 052035  
5707 021716 004737 022462  
5708 021722 104414 001201  
5709 021726 000207  
5710  
5711  
5712  
5713  
5714 021730  
5715 021730 104414 052053  
5716 021734 013746 056512  
5717 021740 004737 022430  
5718 021744 104414 053246  
5719 021750 013746 056514  
5720 021754 004737 022430  
5721 021760 104414 053246  
5722 021764 104414 053251  
5723 021770 104414 001201

```
DISPLY $CRLF  
RTS PC  
:PRINT LINE 4 OF ERROR MESSAGE  
: 'BUFFER ADR = XXXXXX SIZE = XXXX ACTUAL NMBR WRDS XFRD = XXX'  
000016 LINE4: BIT #BIT06,STATUS(RO) ;DATA ERROR ?  
BEQ IS ;BR IF NOT  
DISPLY LINM4 ;'PRINT BUFFER'  
MOV $BUF(RO),-(SP) ;BUFFER ADDR ON STACK  
JSR PC,LINOC† ;CONVERT TO OCTAL & PRINT  
DISPLY LINS4 ;PRINT 'SIZE'  
MOV $WRDL(RO),-(SP) ;BUFFER SIZE  
JSR PC,LINDEC ;TYPE IT IN DECIMAL  
DISPLY LINX4 ;'ACTUAL NMBR WRDS XFRD = '  
MOV $RMBA(RO),-(SP) ;VALUE IN BUFFER ADDR REGISTER  
SUB $BUF(RO),(SP) ;SUBTRACT STARTING ADDRESS  
ASR (SP) ;CONVERT INTO A WORD COUNT  
JSR PC,LINDEC ;TYPE IT IN DECIMAL  
DISPLY $CRLF ;CR-LF  
RTS PC ;RETURN  
1$:  
:PRINT LINE 5 OF ERROR MESSAGE  
: 'GOOD DATA = XXXXXX BAD DATA = XXXXXX SECT POS = XXX'  
000240 LINES: DISPLY LINDS ;PRINT 'GOOD DATA'  
SUB #2,$RMBA(RO) ;BACK THE ADDRESS UP  
MOV #2,$RMBA(RO),-(SP) ;'GOOD' DATA - AT THE BUFFER LOCATION  
JSR PC,LINOC† ;TYPE IT  
DISPLY LINBS ;PRINT 'BAD DATA'  
MOV $RMD8(RO),-(SP) ;BAD DATA FROM BUFFER  
JSR PC,LINOC† ;TYPE IT  
MOV $RMWC(RO),-(SP) ;WORD LENGTH ON STACK  
ADD $WRDL(RO),(SP) ;MAKE INTO A POSITIVE NUMBER  
CLR -(SP) ;UPPER DIVIDEND TO ZERO  
MOV $SSEC(RO),-(SP) ;SECTOR SIZE ON THE STACK  
JSR PC,LINKDV ;DIVIDE WORDS XFERED BY SECTOR SIZE  
MOV (SP)+,(SP) ;MOVE REMAINDER UP THE STACK  
DISPLY LINPS ;PRINT 'SECT POS'  
JSR PC,LINDEC ;TYPE THE POSITION  
DISPLY $CRLF  
RTS PC  
:PRINT LINE 5A OF THE ERROR MESSAGE  
: 'HEADER FROM ERROR SECTOR XXXXXX XXXXXX XXXXXX XXXXXX'  
LINESA:  
2$: DISPLY LINS5 ;'HEADER CONTENTS OF ERROR SECTOR'  
MOV CYLDER, -(SP) ;HEADER POSITION  
JSR PC,LINOC† ;TYPE IT  
DISPLY LINSP ;SPACES  
MOV CYLDER+2, -(SP) ;HEADER POSITION +2  
JSR PC,LINOC† ;TYPE IT  
DISPLY LINSP ;SPACES  
DISPLY LINX5 ;APPENDING INFO 1/23/77  
3$: DISPLY $CRLF
```

```

5724 021774 000207
5725
5726
5727
5728
5729 021776 104414 052107
5730 022002 016046 000300
5731 022006 004737 022430
5732 022012 104414 053246
5733 022016 104414 052120
5734 022022 016046 000302
5735 022026 004737 022430
5736 022032 104414 001201
5737 022036 000207
5738
5739
5740
5741
5742 022040 104414 052132
5743 022044 104414 001201
5744 022050 000207
5745
5746
5747
5748
5749 022052 104414 052165
5750 022056 000411
5751
5752
5753
5754
5755 022060 104414 052132
5756 022064 000406
5757
5758
5759
5760
5761 022066 104414 052214
5762 022072 000414
5763
5764
5765
5766
5767 022074 104414 052243
5768 022100 000411
5769
5770
5771
5772 022102 006301
5773 022104 016137 002470 022114
5774 022112 104414
5775 022114 000000
5776 022116 104414 001201
5777 022122 000207
5778
5779

```

```

RTS PC
;PRINT LINE 5B OF ERROR MESSAGE
;'RMEC1 = XXXXXX RMEC2 = XXXXXX'
LINE5B: DISPLY LINEP5 ;'RMEC1 = '
MOV $RMEC1(R0),-(SP) ;PUT REGISTER CONTENTS ON THE STACK
JSR PC,LINOC ;TYPE IT
DISPLY ,LINS ;SPACES
DISPLY ,LINEO5 ;' RMEC2 = '
MOV $RMEC2(R0),-(SP) ;PUT REGISTER CONTENTS ON THE STACK
JSR PC,LINOC ;TYPE IT
DISPLY $CRLF
RTS PC ;RETURN

;PRINT LINE 6 OF ERROR MESSAGE
;'SECTOR IS ECC CORRECTABLE'
LINE6: DISPLY ,LINB6 ;ECC CORRECTABLE
DISPLY $CRLF
RTS PC

;PRINT LINE 6A OF THE ERROR MESSAGE
;'SECTOR READ CORRECTLY AT OFFSET N'
LINE6A: DISPLY ,LINC6 ;PRINT 'READ CORRECTLY AT OFFSET N'
BR LIN6.1 ;TYPE THE REST OF THE LINE

;PRINT LINE 6B OF THE ERROR MESSAGE
;'SECTOR IS ECC CORRECTABLE AT OFFSET N'
LINE6B: DISPLY ,LINB6 ;PRINT 'SECTOR IS ECC CORRECTABLE '
BR LIN6.1

;PRINT LINE 6C OF THE ERROR MESSAGE
;'CORRECTED ON NTH RETRY'
LINE6C: DISPLY ,LING6 ;'CORRECTED ON NTH RETRY'
BR LIN6.2 ;TYPE THE REST OF THE LINE

;PRINT LINE 6D OF THE ERROR MESSAGE
;'UNCORRECTABLE AFTER N RETRIES'
LINE6D: DISPLY ,LINUO6 ;'UNCORRECTABLE AFTER N RETRIES'
BR LIN6.2 ;FINISH

;TYPE THE OFFSET VALUE IN MICRO-INCHES
LIN6.1: ASL R1 ;DOUBLE THE OFFSET TABLE INDEX
MOV OFMTBL(R1),1$ ;ADDRESS OF OFFSET POSITION MESSAGE
DISPLY ;OFFSET VALUE
WORD 0
DISPLY $CRLF
RTS PC

;RETRY COUNT TYPEOUT

```

5780  
5781 022124 005046  
5782 022126 113716 001351  
5783 022132 004737 022462  
5784 022136 104414 052232  
5785 022142 104414 001201  
5786 022146 000207  
5787  
5788  
5789  
5790

LINE6.2: CLR -(SP) ;CLEAR STACK  
MOVB RETRY+1,(SP) ;RETRY COUNT  
JSR PC,LINDEC ;TYPE IT IN DECIMAL  
DISPLY ,LINR6 ;'RETRY'  
DISPLY ,\$CRLF  
RTS PC

;PRINT LINE 7 OF THE ERROR MESSAGE  
;'ORDERS:XXXXX TOTAL ERRORS:XXX WRDS XFRD:XXXXXXX WRDS READ:XXXXXXX'

5791 022150 104414 052316  
5792 022154 012746 000036  
5793 022160 060016  
5794 022162 004737 034050  
5795 022166 004737 030036  
5796 022172 104414 052370  
5797 022176 016046 000056  
5798 022202 004737 022462  
5799 022206 104414 052402  
5800 022212 012746 000046  
5801 022216 060016  
5802 022220 004737 034050  
5803 022224 004737 030036  
5804 022230 104414 052416  
5805 022234 012746 000052  
5806 022240 060016  
5807 022242 004737 034050  
5808 022246 004737 030036  
5809 022252 104414 001201  
5810 022256 104414 001201  
5811 022262 032777 100000 156664  
5812 022270 001401  
5813 022272 000000  
5814 022274 000207  
5815  
5816  
5817  
5818

LINE7: DISPLY LIN70 ;PRINT ORDER COUNT  
MOV \$OPERC,-(SP) ;TO STACK  
ADD RO,(SP) ;ADD THE BASE ADDRESS  
JSR PC,\$DB2D ;CONVERT IT  
JSR PC,\$SUPRS ;PRINT IT  
DISPLY LIN7T ;TOTAL ERRORS  
MOV \$TOTAL(RO),-(SP) ;TO STACK  
JSR PC,LINDEC ;TYPE IT IN DECIMAL  
DISPLY LIN7X ;PRINT 'WRDS XFR'  
MOV \$STRANS,-(SP) ;ADDRESS OF LOW WORD ON STACK  
ADD RO,(SP)  
JSR PC,\$DB2D ;CONVERT  
JSR PC,\$SUPRS ;PRINT  
DISPLY LIN7R ;'BITS READ'  
MOV \$SREAD,-(SP) ;LOW WORD ADDRESS  
ADD RO,(SP)  
JSR PC,\$DB2D ;CONVERT  
JSR PC,\$SUPRS ;PRINT  
DISPLY , \$CRLF  
DISPLY , \$CRLF  
BIT \$SW15,\$SWR ;SEE IF 'HALT ON ERROR' - SWITCH 15  
BEQ IS ;BR IF NOT  
HALT ;SWITCH 15 HALT  
IS: RTS PC

;PRINT LINE 7A OF ERROR MESSAGE  
;'ORDERS:XXXXX TOTAL SEEKS=XXXXX TOTAL MISPOS ERR = XXX TOTAL SKI= XXX'

5819 022276 104414 052316  
5820 022302 012746 000036  
5821 022306 060016  
5822 022310 004737 034050  
5823 022314 004737 030036  
5824 022320 104414 052326  
5825 022324 012746 000042  
5826 022330 060016  
5827 022332 004737 034050  
5828 022336 004737 030036  
5829 022342 104414 052270  
5830 022346 016046 000066  
5831 022352 004737 022462  
5832 022356 104414 052346  
5833 022362 016046 000064  
5834 022366 004737 022462  
5835 022372 104414 001201

LINE7A: DISPLY LIN70 ;'ORDERS = '  
MOV \$OPERC,-(SP) ;ORDER COUNT INCREMENT  
ADD RO,(SP) ;ADD BASE ADDRESS  
JSR PC,\$DB2D ;CONVERT THE COUNT  
JSR PC,\$SUPRS ;PRINT IT  
DISPLY LIN7P ;'TOTAL SEEKS = '  
MOV \$SPOSIT,-(SP) ;TOTAL SEEKS  
ADD RO,(SP) ;DEVICE TABLE ADDRESS  
JSR PC,\$DB2D ;CONVERT THE SEEK COUNT  
JSR PC,\$SUPRS ;PRINT IT  
DISPLY LIN7M ;' TOTAL MISPOS ERR = '  
MOV \$MISPO(RO),-(SP) ;TOTAL ERRORS  
JSR PC,LINDEC ;TYPE IT IN DECIMAL  
DISPLY LIN7S ;' TOTAL SKI,OCYL ERR = '  
MOV \$SKI(RO),-(SP) ;CONVERT & PRINT IT  
JSR PC,LINDEC ;TYPE IT IN DECIMAL  
DISPLY , \$CRLF

```

5836 022376 104414 001201          DISPLY  $CRLF
5837 022402 032777 100000 156544  BIT    #SW15,JSWR ;SEE IF HALT ON ERROR - SWITCH 15 SET
5838 022410 001401          BEQ    1$         ;BR IF NOT
5839 022412 000000          HALT
5840 022414 000207          1$:    RTS      PC ;SWITCH 15 HALT
5841
5842          ;PRINT LINE 8 OF THE ERROR MESSAGE
5843          ;'DIFFERENT ERROR DURING RETRY'
5844
5845 022416 104414 052433          LINE8: DISPLY  LIN8M
5846 022422 004737 020462          JSR    PC,LIN8M ;PRINT LINE 2 OF ERROR MESSAGE
5847 022426 000207          RTS    PC
5848
5849          ;OCTAL TYPEOUT ROUTINE
5850          ;CALL:
5851          ;
5852          ;   MOV    NUM,-(SP) ;PUT THE NUMBER ON THE STACK
5853          ;   JSR    PC,LINOC
5854          ;   RETURN
5855
5855 022430 016646 000002          LINOC: MOV    2(SP),-(SP) ;PUT NUMBER IN PROPER LOCATION ON STACK
5856 022434 004737 030466          JSR    PC,$S820 ;CONVERT THE NUMBER TO OCTAL
5857 022440 012637 022454          MOV    (SP)+,1$ ;GET THE ADDRESS OF THE ASCII STRING
5858 022444 062737 000005 022454  ADD    #5,1$ ;ADDRESS THE LAST 6 ASCII DIGITS
5859 022452 104414          DISPLY
5860 022454 000000          1$:    .WORD 0 ;TYPE IT
5861 022456 012616          MOV    (SP)+,(SP) ;ADDRESS
5862 022460 000207          RTS    PC ;CORRECT THE STACK
5863          ;RETURN
5864
5864          ;ROUTINE TO CONVERT THE INPUT NUMBER TO DECIMAL AND TYPE IT WITH
5865          ;LEADING ZERO SUPPRESSION
5866          ;CALL:
5867          ;
5868          ;   MOV    NUM,-(SP) ;PUT THE NUMBER ON THE STACK
5869          ;   JSR    PC,LINDEC
5870          ;   RETURN
5871
5871 022462 016646 000002          LINDEC: MOV    2(SP),-(SP) ;SET UP STACK FOR CONVERT
5872 022466 004737 030436          JSR    PC,$S82D ;CONVERT IT TO DECIMAL
5873 022472 004737 030036          JSR    PC,$SUPRS ;TYPE IT (WITH LEADING ZEROS SUPRESSED)
5874 022476 012616          MOV    (SP)+,(SP) ;RESTORE STACK POINTER
5875 022500 000207          RTS    PC
5876
5877          ;*****
5878          ;*****
5879          ;.SBTTL GENERAL SUPPORT SUBROUTINES
5880          ;*****
5881          ;*****
5882          ;DECREMENT THE SECTOR-TRACK ADDRESS
5883          ;CALL:
5884          ;
5885          ;   MOV    #DPB,RO ;DPB ADDRESS
5886          ;   JSR    PC,READR
5887          ;   RETURN
5888          ;   (SP) CONTAINS THE CYLINDER ADDRESS
5889          ;   2(SP) CONTAINS THE TRACK ADDRESS
5890          ;   4(SP) CONTAINS THE SECTOR ADDRESS
5891

```



```

5892 022502 162706 000006 READDR: SUB #6,SP ; DECREMENT THE STACK POINTER
5893 022506 016616 000006 MOV 6(SP), (SP) ; MOVE THE RETURN ADDR DOWN THE STACK
5894 022512 005066 000006 CLR 6(SP) ; CLEAR STACK FOR SECTOR
5895 022516 005066 000004 CLR 4(SP) ; CLEAR STACK FOR TRACK
5896 022522 005066 000002 CLR 2(SP) ; CLEAR STACK FOR CYLINDER
5897 022526 116066 000242 000006 MOVB $RMDA(R0), 6(SP) ; SECTOR ON STACK
5898 022534 116066 000243 000004 MOVB $RMDA+1(R0), 4(SP) ; TRACK ADDRESS
5899 022542 016066 000270 000002 MOV $RMDA(R0), 2(SP) ; CYLINDER ADDRESS
5900 022550 005766 000006 TST 6(SP) ; SECTOR 0 ?
5901 022554 001403 BEQ 1$ ; BRANCH IF 0
5902 022556 105366 000006 DECB 6(SP) ; DECREMENT ONE SECTOR
5903 022562 000421 BR 3$ ; BRANCH TO EXIT
5904 022564 005766 000004 1$: TST 4(SP) ; ALSO ON TRACK 0 ?
5905 022570 001406 BEQ 2$ ; BRANCH IF 0
5906 022572 112766 000037 000006 MOVB #31, 6(SP) ; LAST SECTOR
5907 022600 105366 000004 DECB 4(SP) ; DECREMENT ONE TRACK
5908 022604 000410 BR 3$ ; EXIT
5909 022606 112766 000037 000006 2$: MOVB #31, 6(SP) ; LAST SECTOR
5910 022614 112766 000004 000004 MOVB #4, 4(SP) ; LAST TRACK
5911 022622 005366 000002 DEC 2(SP) ; DECREMENT ONE CYLINDER COUNT
5912 022626 000240 3$: NOP ; DONE
5913 022630 000207 RTS PC ; RETURN
5914
5915 ; ROUTINE TO CHECK FOR KW11-L OR KW11-P CLOCKS
5916
5917 022632 012737 177777 001310 CKCLK: MOV # -1, CLKFLG ; CLEAR CLOCK AVAILABILITY FLAG
5918 022640 012737 177777 001306 MOV # -1, PCLOCK ; CLEAR KW11-P CLOCK AVAILABILITY FLAG
5919 022646 012737 022726 000004 MOV # CKCLK1, ERRVEC ; SET UP VECTOR FOR CLOCK CHECK
5920 022654 005037 000006 CLR # ERRVEC+2 ; NEW PSW
5921 022660 005777 156410 TST # $LKCSR ; CHECK FOR KW11-P
5922 022664 005037 001310 CLR CLKFLG ; SET CLOCK AVAILABILITY FLAG
5923 022670 005037 001306 CLR PCLOCK ; SET KW11-P CLOCK FLAG
5924 022674 013701 001300 MOV $LPVEC, R1 ; KW11-P VECTOR ADDRESS
5925 022700 012721 023766 MOV #CLOCK, (R1)+ ; SET UP KW11-P VECTOR
5926 022704 012711 000300 MOV #300, (R1) ; PSW - PRI 6
5927 022710 012777 174575 156360 MOV # -1667, # $LKCSB ; LOAD COUNTER BUFFER WITH 16.67
5928 022716 012777 000131 156350 MOV #131, # $LKCSR ; SET CLOCK - CNT UP, 10US, CONT INT
5929 022724 000437 BR CKCLK3
5930 022726 062706 000004 CKCLK1: ADD #4, SP ; RESTORE THE STACK POINTER
5931 022732 012737 022774 000004 MOV #CKCLK2, #ERRVEC ; CHANGE ERROR VECTOR TO CHECK FOR KW11-L
5932 022740 005777 156336 TST # $LK5 ; LOOK FOR KW11-L
5933 022744 005037 001310 CLR CLKFLG ; SET CLOCK FLAG
5934 022750 013701 001304 MOV $LLVEC, R1 ; KW11-L VECTOR ADDRESS
5935 022754 012721 023766 MOV #CLOCK, (R1)+ ; SET UP KW11-L VECTOR
5936 022760 012711 000300 MOV #300, (R1) ; PSW - PRI 6
5937 022764 012777 000100 156310 MOV #100, # $LK5 ; SET KW11-L INTERRUPT
5938 022772 000414 BR CKCLK3
5939 022774 062706 000004 CKCLK2: ADD #4, SP ; RESTORE THE STACK POINTER
5940 023000 104401 054054 TYPE #, #NEDCLK ; 'P OR L CLOCK MUST BE ON SYSTEM'
5941 023004 005737 000042 TST 42 ; UNDER MONITOR CONTROL ?
5942 023010 001406 BEQ 1$ ; BR IF NOT
5943 023012 000137 027440 JMP $GET42 ; ABORT PROGRAM
5944 023016 000000 1$: HALT ; HALT
5945 023020 000137 003622 JMP ; TRY AGAIN
5946 023024 012737 000006 000004 CKCLK3: MOV #6, #ERRVEC ; RESTORE THE ERROR VECTOR
5947 023032 000207 RTS PC

```

```

5948
5949
5950
5951
5952
5953
5954 023034 010046
5955 023036 010446
5956 023040 005737 001544
5957 023044 001423
5958 023046 004737 023150
5959 023052 005004
5960 023054 006304
5961 023056 016400 002102
5962 023062 006204
5963 023064 136437 034606 001544
5964 023072 001404
5965 023074 004737 023172
5966 023100 104401 001201
5967 023104 005204
5968 023106 020427 000010
5969 023112 001360
5970 023114 012604
5971 023116 012600
5972 023120 000207
5973
5974
5975
5976
5977
5978
5979
5980 023122 010046
5981 023124 010446
5982 023126 004737 023150
5983 023132 005004
5984 023134 111004
5985 023136 004737 023172
5986 023142 012604
5987 023144 012600
5988 023146 000207
5989
5990
5991
5992
5993
5994
5995 023150 004737 023670
5996 023154 004537 030076
5997 023160 001201
5998 023162 004537 030076
5999 023166 053524
6000 023170 000207
6001
6002
6003

;ROUTINE TO DISPLAY STATISTICS FOR ALL DRIVES ASSIGNED
;CALL:
;      JSR      PC,STATPR
;      RETURN
STATPR: MOV      R0,-(SP)      ;SAVE R0
        MOV      R4,-(SP)      ;SAVE R4
        TST      ASNLST        ;ANY DRIVES ASSIGNED ?
        BEQ      3$           ;BR IF NOT
        JSR      PC,SHDTYP     ;TYPE THE HEADING
        CLR      R4           ;CLEAR THE DRIVE INDEX
        ASL      R4           ;CHANGE TO INDEX WORDS
1$:     MOV      BLKADR(R4),R0 ;GET THE DRIVE'S BLOCK ADDRESS
        ASR      R4           ;RESTORE R4
        BITB     ATABIT(R4),ASNLST ;IS THIS DRIVE ASSIGNED ?
        BEQ      2$           ;BR IF NOT
        JSR      PC,SDETAL     ;TYPE THE PERFORMANCE SUMMARY
        TYPE     $CRLF        ;CR-LF
2$:     INC      R4           ;INCREMENT THE INDEX
        CMP      R4,#8        ;FINISHED ?
        BNE     1$           ;BR IF NOT
3$:     MOV      (SP)+,R4      ;RESTORE R4
        MOV      (SP)+,R0      ;RESTORE R0
        RTS      PC          ;RETURN

;ROUTINE TO TYPE STATISTICS FOR AN INDIVIDUAL DRIVE
;CALL:
;      MOV      #DPB,R0      ;DPB ADDRESS
;      JSR      PC,TYPEST
;      RETURN
TYPEST: MOV      R0,-(SP)      ;SAVE R0
        MOV      R4,-(SP)      ;SAVE R4
        JSR      PC,SHDTYP     ;TYPE THE HEADING
        CLR      R4           ;CLEAR R4 FOR DRIVE NUMBER
        MOVB    (R0),R4       ;DRIVE NUMBER
        JSR      PC,SDETAL     ;TYPE THE STATISTICS
        MOV      (SP)+,R4      ;RESTORE R4
        MOV      (SP)+,R0      ;RESTORE R0
        RTS      PC          ;RETURN

;TYPE THE HEADER FOR THE DRIVE PERFORMANCE SUMMARY TYPEOUT
;CALL:
;      JSR      PC,SHDTYP
;      RETURN
SHDTYP: JSR      PC,$TIME      ;TYPE THE TIME OF DAY
        JSR      RS,TYPRI4    ;TYPE AT PRIORITY 4
        $CRLF                ;CR-LF
        JSR      RS,TYPRI4    ;TYPE THE HEADER
        STATHD                ;HEADER
        RTS      PC          ;RETURN

;TYPE THE PERFORMANCE SUMMARY DATE LINE
;CALL:

```

6004				:	MOV	#DRIVE R4	:	DRIVE NUMBER
6005				:	MOV	#DPB,R0	:	DPB ADDRESS
6006				:	RETURN			
6007								
6008	023172	010246		SDETAIL:	MOV	R2,-(SP)	:	SAVE R2
6009	023174	010002			MOV	R0,R2	:	DPB ADDRESS
6010	023176	062702	000036		ADD	#\$OPERC,R2	:	FIRST STATISTICAL FIELD
6011	023202	010446			MOV	R4,-(SP)	:	SAVE R4 FOR TYPEOUT
6012							:	TYPE DRIVE NUMBER
6013	023204	104403			TYPOS		:	GO TYPE--OCTAL ASCII
6014	023206	002			.BYTE	2	:	TYPE 2 DIGIT(S)
6015	023207	000			.BYTE	0	:	SUPPRESS LEADING ZEROS
6016	023210	104401	053246		TYPE	LINSP	:	SPACES
6017	023214	016046	000070		MOV	\$PASSC(R0),-(SP)	:	PUT THE PASS COUNT ON THE STACK
6018	023220	004737	030436		JSR	PC,\$SB20	:	CONVERT IT
6019	023224	004537	027746		JSR	R5,REPLZ	:	TYPE IT
6020	023230	000003			.WORD	3	:	TYPE 3 DIGITS
6021	023232	104401	053246		TYPE	LINSP	:	SPACES
6022	023236	010246			MOV	R2,-(SP)	:	PUT \$OPERC ON THE STACK
6023	023240	004737	034050		JSR	PC,\$DB20	:	CONVERT IT
6024	023244	004537	027746		JSR	R5,REPLZ	:	TYPE \$OPERC
6025	023250	000006			.WORD	6	:	TYPE 6 DIGITS
6026	023252	104401	053246		TYPE	LINSP	:	SPACES
6027	023256	062702	000004		ADD	#4,R2	:	INCREMENT R2
6028	023262	010246			MOV	R2,-(SP)	:	PUT \$POSIT ON THE STACK
6029	023264	004737	034050		JSR	PC,\$DB20	:	CONVERT IT
6030	023270	004537	027746		JSR	R5,REPLZ	:	TYPE \$POSIT
6031	023274	000006			.WORD	6	:	TYPE 6 DIGITS
6032	023276	104401	053246		TYPE	LINSP	:	SPACES
6033	023302	062702	000004		ADD	#4,R2	:	INCREMENT R2
6034	023306	010246			MOV	R2,-(SP)	:	PUT \$TRANS ON THE STACK
6035	023310	004737	034050		JSR	PC,\$DB20	:	CONVERT \$TRANS
6036	023314	004537	027746		JSR	R5,REPLZ	:	TYPE IT
6037	023320	000012			.WORD	10	:	TYPE 10 DIGITS
6038	023322	104401	053246		TYPE	LINSP	:	SPACES
6039	023326	062702	000004		ADD	#4,R2	:	INCREMENT R2
6040	023332	010246			MOV	R2,-(SP)	:	PUT \$READ ON THE STACK
6041	023334	004737	034050		JSR	PC,\$DB20	:	CONVERT \$READ
6042	023340	004537	027746		JSR	R5,REPLZ	:	TYPE IT
6043	023344	000012			.WORD	10	:	TYPE 10 DIGITS
6044	023346	104401	053247		TYPE	LINSP0	:	1 SPACE
6045	023352	062702	000004		ADD	#4,R2	:	INCREMENT R2
6046	023356	062702	000002		ADD	#2,R2	:	INCREMENT R2 AGAIN
6047	023362	012246			MOV	(R2)+,-(SP)	:	PUT \$SOFT ON THE STACK
6048	023364	004737	030436		JSR	PC,\$SB20	:	CONVERT \$SOFT
6049	023370	004537	027746		JSR	R5,REPLZ	:	TYPEOUT \$SOFT
6050	023374	000004			.WORD	4	:	TYPE 4 DIGITS
6051	023376	104401	053247		TYPE	LINSP0	:	SPACES
6052	023402	012246			MOV	(R2)+,-(SP)	:	PUT \$HARD ON THE STACK
6053	023404	004737	030436		JSR	PC,\$SB20	:	CONVERT \$HARD
6054	023410	004537	027746		JSR	R5,REPLZ	:	TYPEOUT \$HARD
6055	023414	000004			.WORD	4	:	TYPE 4 DIGITS
6056	023416	104401	053247		TYPE	LINSP0	:	SPACES
6057	023422	012246			MOV	(R2)+,-(SP)	:	PUT \$SKI ON THE STACK
6058	023424	004737	030436		JSR	PC,\$SB20	:	CONVERT \$SKI
6059	023430	004537	027746		JSR	R5,REPLZ	:	TYPEOUT \$SKI

```

6060 023434 000004          .WORD 4          ;TYPE 4 DIGITS
6061 023436 104401 053247  TYPE      LINSPO    ;SPACES
6062 023442 012246          MOV      (R2)+, -(SP) ;PUT $MISPO ON THE STACK
6063 023444 004737 030436  JSR      PC, $S820   ;CONVERT $MISPO
6064 023450 004537 027746  JSR      RS, REPLZ   ;TYPEOUT $MISPO
6065 023454 000004          .WORD 4          ;TYPE 4 DIGITS
6066 023456 104401 053247  TYPE      LINSPO    ;SPACES
6067 023462 016046 000056  MOV      $TOTAL(R0), -(SP) ;CALCULATE NUMBER OF OTHER ERRORS
6068 023466 166016 000060  SUB      $$SOFT(R0), (SP) ;SUBTRACT $$SOFT FROM $TOTAL
6069 023472 166016 000062  SUB      $SHARD(R0), (SP) ;SUBTRACT $SHARD FROM $TOTAL
6070 023476 166016 000064  SUB      $$SKI(R0), (SP) ;SUBTRACT $$SKI FROM $TOTAL
6071 023502 166016 000066  SUB      $MISPO(R0), (SP) ;SUBTRACT $MISPO FROM $TOTAL
6072 023506 004737 030436  JSR      PC, $S820   ;CONVERT 'OTHER' COUNT
6073 023512 004537 027746  JSR      RS, REPLZ   ;TYPE IT
6074 023516 000004          .WORD 4          ;TYPE 4 DIGITS
6075 023520 005726          TST      (SP)+      ;CLEAR STACK
6076 023522 000207          RTS      PC

6077
6078
6079
6080          ;ROUTINE TO INCREMENT $$SOFT
6081          ;
6082          ;NOTE: $$SOFT WILL NOT BE INCREMENTED BEYOND 9999 (10)
6083
6084 023524 005737 001362  INCSOF: TST      BADSEC ;SEE IF BAD TRK/SEC INDICATOR SET
6085 023530 001006          BNE      1$          ;BR IF IT'S SET, DON'T INCREMENT COUNT
6086 023532 026027 000060 023417  CMP      $$SOFT(R0), #9999. ;IS $$SOFT ALREADY AT MAXIMUM ?
6087 023540 103002          BHIS     1$          ;BR IF IT IS
6088 023542 005260 000060  INC      $$SOFT(R0) ;INCREMENT $$SOFT
6089 023546 000207          1$:     RTS      PC          ;RETURN

6090
6091
6092          ;ROUTINE TO INCREMENT $SHARD
6093          ;
6094          ;NOTE: $SHARD WILL NOT BE INCREMENTED BEYOND 9999 (10)
6095
6096 023550 005737 001362  INCHRD: TST      BADSEC ;SEE IF BAD TRK/SEC INDICATOR SET
6097 023554 001006          BNE      1$          ;BR IF IT'S SET, DON'T INCREMENT COUNT
6098 023556 026027 000062 023417  CMP      $SHARD(R0), #9999. ;IS $SHARD ALREADY AT MAXIMUM ?
6099 023564 103002          BHIS     1$          ;BR IF IT IS
6100 023566 005260 000062  INC      $SHARD(R0) ;INCREMENT $SHARD
6101 023572 000207          1$:     RTS      PC          ;RETURN

6102
6103
6104          ;ROUTINE TO INCREMENT $$SKI
6105          ;
6106          ;NOTE: $$SKI WILL NOT BE INCREMENTED BEYOND 9999 (10)
6107
6108 023574 005737 001362  INCSKI: TST      BADSEC ;SEE IF BAD TRK/SEC INDICATOR SET
6109 023600 001006          BNE      1$          ;BR IF IT'S SET, DON'T INCREMENT COUNT
6110 023602 026027 000064 023417  CMP      $$SKI(R0), #9999. ;IS $$SKI ALREADY AT MAXIMUM ?
6111 023610 103002          BHIS     1$          ;BR IF IT IS
6112 023612 005260 000064  INC      $$SKI(R0) ;INCREMENT $$SKI
6113 023616 000207          1$:     RTS      PC          ;RETURN
6114
6115

```

```

6116 ;ROUTINE TO INCREMENT $MISPO
6117 ;
6118 ;NOTE: $MISPO WILL NOT BE INCREMENTED BEYOND 9999 (10)
6119
6120 023620 005737 001362 INCMIS: TST BADSEC ;SEE IF BAD TRK/SEC INDICATOR SET
6121 023624 001006 023417 BNE 1$ ;BR IF IT'S SET, DON'T INCREMENT COUNT
6122 023626 026027 000066 CMP $MISPO(RO),#9999. ;IS $MISPO ALREADY AT MAXIMUM ?
6123 023634 103002 BHIS 1$ ;BR IF IT IS
6124 023636 005260 000066 INC $MISPO(RO) ;INCREMENT $MISPO
6125 023642 000207 1$: RTS PC ;RETURN
6126
6127
6128 ;ROUTINE TO INCREMENT $TOTAL
6129 ;
6130 ;NOTE: $TOTAL WILL NOT BE INCREMENTED BEYOND 9999 (10)
6131
6132 023644 005737 001362 INCTOT: TST BADSEC ;SEE IF BAD TRK/SEC INDICATOR SET
6133 023650 001006 023417 BNE 1$ ;BR IF IT'S SET, DON'T INCREMENT COUNT
6134 023652 026027 000056 CMP $TOTAL(RO),#9999. ;IS $TOTAL ALREADY AT MAXIMUM ?
6135 023660 103002 BHIS 1$ ;BR IF IT IS
6136 023662 005260 000056 INC $TOTAL(RO) ;INCREMENT $TOTAL
6137 023666 000207 1$: RTS PC ;RETURN
6138
6139
6140 ;ROUTINE TO TYPE THE TIME
6141 ;
6142 023670 005737 001310 $TIME: TST CLKFLG ;CLOCK ON THE SYSTEM ?
6143 023674 001033 BNE 1$ ;BR IF NOT
6144 023676 104401 001201 TYPE $CRLF ;CR-LF
6145 023702 013746 001364 MOV HOUR, -(SP) ;PUT 'HOURS' ON THE STACK
6146 023706 004737 030436 JSR PC, $SB2D ;CONVERT TO DECIMAL
6147 023712 004537 027746 JSR RS, REPLZ ;TYPE IT
6148 023716 000002 .WORD 2 ;TYPE 2 DIGITS
6149 023720 104401 054330 TYPE COLON ;' '
6150 023724 013746 001366 MOV MINUTE, -(SP) ;PUT 'MINUTES' ON THE STACK
6151 023730 004737 030436 JSR PC, $SB2D ;CONVERT TO DECIMAL
6152 023734 004537 027746 JSR RS, REPLZ ;TYPE IT
6153 023740 000002 .WORD 2 ;TYPE 2 DIGITS
6154 023742 104401 054330 TYPE COLON ;' '
6155 023746 013746 001370 MOV SECOND, -(SP) ;PUT SECONDS ON THE STACK
6156 023752 004737 030436 JSR PC, $SB2D ;CONVERT TO DECIMAL
6157 023756 004537 027746 JSR RS, REPLZ ;TYPE IT
6158 023762 000002 .WORD 2 ;TYPE 2 DIGITS
6159 023764 000207 1$: RTS PC
6160
6161 ;CLOCK HANDLER ROUTINE
6162 ;
6163 023766 005337 001372 CLOCK: DEC SIXTEE ;INCREMENT THE 1/60 SECOND COUNTER
6164 023772 001035 BNE 1$ ;BR IF A SECOND NOT COUNTED
6165 023774 013737 001312 001372 MOV HZ, SIXTEE ;RESTORE THE VALUE
6166 024002 005237 001370 INC SECOND ;COUNT THE SECOND
6167 024006 022737 000074 001370 CMP #60., SECOND ;AT MAXIMUM ?
6168 024014 001024 BNE 1$ ;BR IF NOT
6169 024016 005037 001370 CLR SECOND ;CLEAR THE SECOND'S COUNTER
6170 024022 005237 001470 INC INTRVL+2 ;COUNT THE PERFORMANCE SUMMARY INTERVAL
6171 024026 005237 001366 INC MINUTE ;COUNT THE MINUTE

```



```

6228 024276 122765 000123 177777 3$: CMPB #'S,-1(R5) ;EQ TO 'S'
6229 024304 001003 025136 4$: BNE 4$ ;BR IF NOT EQ
6230 024306 004737 025136 JSR PC,SCMND ;TYPE STATISTICS
6231 024312 000452 000127 177777 4$: BR 7$ ;EXIT
6232 024314 122765 000127 177777 4$: CMPB #'W,-1(R5) ;EQ TO 'W'
6233 024322 001007 000001 154622 BNE 5$ ;BR IF NOT EQ
6234 024324 032777 000001 154622 BIT #SW0,ASWR ;IS SWITCH 0 SET?
6235 024332 001040 025370 BNE 6$ ;BR IF SET, CAN'T DO 'W' COMMAND
6236 024334 004737 025370 JSR PC,DATA PK ;WRITE A DATA PACK
6237 024340 000437 000122 177777 5$: BR 7$ ;EXIT
6238 024342 122765 000122 177777 5$: CMPB #'R,-1(R5) ;EQ TO 'R'?
6239 024350 001031 025420 BNE 6$ ;BR IF NOT EQ
6240 024352 004737 025420 JSR PC,REDAPK ;READ A DATA PACK
6241 024356 000430 000127 177777 8$: BR 7$ ;EXIT
6242 024360 122765 000127 177777 8$: CMPB #'W,-1(R5) ;WT COMMAND?
6243 024366 001022 000101 000001 BNE 6$ ;NO
6244 024370 122765 000101 000001 CMPB #'A,1(R5) ;ALL DRIVES?
6245 024376 001413 000001 000067 BEQ 9$ ;YES
6246 024400 126527 000001 000067 CMPB 1(R5),#'7 ;GREAT THAN 7
6247 024406 101012 000001 000000 BHI 6$ ;YES
6248 024410 126527 000001 000000 CMPB 1(R5),#0 ;LESS THAN 0
6249 024416 103406 177770 000001 BLO 6$ ;YES
6250 024420 142765 177770 000001 BICB #'C7,1(R5) ;CHOP OFF THE HIGHER BITS
6251 024426 004737 025402 9$: JSR PC,WATPAK ;ASSIGN DRIVES WITH WT COMMAND
6252 024432 000402 054132 6$: BR 7$ ;TYPE 'INVALID COMMAND' MESSAGE
6253 024434 104401 054132 7$: TYPE ,INVLD ;RESTORE R0 - R5
6254 024440 104413 154514 TST #STKB ;CLEAR THE TTY BUFFER
6255 024442 005777 000100 154504 BIS #BIT06,#STKS ;SET TTY INTERRUPT ENABLE
6256 024446 052777 177776 CLR # ;SET PRIORITY BACK TO ZERO
6257 024454 005037 000207 RTS PC ;RETURN
6258 024460 000207
6259
6260 ;ROUTINE TO PROCESS THE ASSIGN REQUEST ('T', 'R', OR 'W' COMMANDS)
6261
6262 024462 122715 000101 ASSIGN: CMPB #'A,(R5) ;ASSIGN ALL DRIVES?
6263 024466 001426 BEQ ASGN2 ;BR IF ALL DRIVES
6264 024470 111504 ASGN1: MOV (R5),R4 ;PUT DRIVE # IN R4
6265 024472 012737 053356 026754 MOV #UNTASN,ASNMSG ;'DRIVE ASSIGNED' MESSAGE ADDRESS
6266 024500 136437 034606 001544 BITB ATABIT(R4),ASNLST ;DRIVE ALREADY ASSIGNED?
6267 024506 001014 BNE 2$ ;BR IF IT IS
6268 024510 005704 TST R4 ;TRYING TO ASSIGN DRIVE 0?
6269 024512 001007 BNE 1$ ;BR IF NOT
6270 024514 012737 053443 026754 MOV #NOTAVL,ASNMSG ;'NOT AVAILABLE' MESSAGE ADDRESS
6271 024522 122737 000024 000041 CMPB #24,41 ;SEE IF LOADED FROM AN RM03
6272 024530 001403 BEQ 2$ ;BR IF RM03 IS THE LOAD DEVICE
6273 024532 004737 024626 1$: JSR PC,ASGN3 ;SEE IF DRIVE ON THE SYSTEM
6274 024536 000207 RTS PC ;RETURN
6275 024540 000137 026734 2$: JMP ASNERR ;EXIT ERROR
6276 024544 122737 000024 000041 ASGN2: CMPB #24,41 ;LOADED FROM AN RM03?
6277 024552 001003 BNE 1$ ;BR IF NOT
6278 024554 012704 000001 MOV #1,R4 ;START WITH DRIVE 1
6279 024560 000401 BR 2$ ;CONTINUE
6280 024562 005004 1$: CLR R4 ;START WITH DRIVE 0
6281 024564 012737 053356 026754 2$: MOV #UNTASN,ASNMSG ;ERROR MESSAGE
6282 024572 136437 034606 001544 BITB ATABIT(R4),ASNLST ;ALREADY ASSIGNED?
6283 024600 001007 BNE 4$ ;YES

```

```

6284 024602 004737 024626          JSR    PC,ASGN3      ;ASSIGN THE DRIVE
6285 024606 005204          3$:    INC    R4      ;INCREMENT DRIVE #
6286 024610 022704 000007          CMP    #7,R4      ;ALL DRIVE CHECKED ?
6287 024614 002363          BGE    2$         ;NO
6288 024616 000207          RTS    PC         ;YES
6289 024620 004737 026734          4$:    JSR    PC,ASNERR ;ERROR MESSAGE
6290 024624 000770          BR    3$         ;TO LOOP
6291 024626 136437 034606 001544 ASGN3: BITB   ATABIT(R4),ASNLS  ;DRIVE ALREADY ASSIGNED ?
6292 024634 001041          BNE    ASGN4     ;BR IF IT IS
6293          ;1$:    TST   DTUM      ;DATA TRANSFER UNDER WAY ?
6294          ;          BPL   1$      ;BR IF IT IS
6295 024636 110437 046062          MOVB  R4,GENDPB  ;DRIVE NUMBER
6296 024642 004737 015200          JSR    PC,RECALD  ;RECALIBRATE DRIVE
6297 024646 105764 034472          TSTB  DRVSTA(R4) ;DRIVE AVAILABLE?
6298 024652 001440          BEQ   ASGN7     ;BR IF DRIVE OFFLINE OR NONEXISTENT
6299 024654 100432          BMI  ASGN6     ;BR IF DRIVE UNSAFE
6300 024656 006304          ASL   R4        ;MAKE R4 INTO WORD INDEX
6301          ;          MOV   BLKADR(R4),NEWUNT(R4) ;DPB ADDRESS
6302 024660 016400 002102          MOV   BLKADR(R4),RO ;PUT BLOCK'S ADDR INTO RO
6303 024664 004737 025432          JSR   PC,CLADPB  ;CLEAR BLOCK FOR DRIVE JUST ASSIGNED
6304 024670 004737 025632          JSR   PC,DRVPRM  ;GET THE DRIVE'S ADDRESS LIMITS
6305 024674 004737 026044          JSR   PC,GETID   ;GET DRIVE I.D.
6306 024700 004537 026154          JSR   R5,GETADR  ;GET BAD SECTOR ADDRESSES
6307 024704 000414          BR    2$         ;BRANCH IF RETRIEVE FAILS
6308 024706 016464 002102 001570  MOV   BLKADR(R4),NEWUNT(R4) ;DPB ADDRESS
6309 024714 012760 000001 000070  MOV   #1,SPASSC(RO) ;PRESET PASS COUNT TO 1
6310 024722 005737 001316          TST   PACK      ;WRITE DATA PACK ?
6311 024726 001403          BEQ   2$         ;BR IF NOT
6312 024730 113760 001316 000026  MOVB  PACK,$PACK(RO) ;SET READ/WRITE DATA PACK INDICATOR
6313 024736 006204          2$:    ASR   R4      ;RESTORE DRIVE ADDRESS
6314 024740 000207          ASGN4: RTS    PC   ;RETURN
6315 024742 012737 053462 026754  ASGN6: MOV   #NOTSAF,ASNMSG ;'UNSAFE' MESSAGE ADDRESS
6316 024750 000137 026734          JMP   ASNERR    ;TO ERROR ROUTINE
6317 024754 105764 034502          ASGN7: TSTB  DRVSTYP(R4) ;DRIVE PRESENT?
6318 024760 001405          BEQ   1$         ;BR IF NOT
6319 024762 100010          BPL   2$         ;BR IF DRIVE OFFLINE
6320 024764 012737 053404 026754  MOV   #NOTRM,ASNMSG ;ADDRESS OF 'NOT RML3' MSG
6321 024772 000407          BR    3$         ;EXIT
6322 024774 012737 053426 026754  1$:    MOV   #NOTPRS,ASNMSG ;ADDRESS OF 'NOT PRESENT' MSG
6323 025002 000403          BR    3$         ;EXIT
6324 025004 012737 053313 026754  2$:    MOV   #UNTOFF,ASNMSG ;ADDRESS OF 'DRIVE OFFLINE' MESSAGE
6325          ;3$:    RTS    PC   ;ERROR RETURN
6326 025012 000137 026734          3$:    JMP   ASNERR ;TO ERROR ROUTINE
6327
6328          ; 'T' COMMAND (ROUTINE TO ASSIGN A DRIVE)
6329
6330 025016 005037 001316          NEWASN: CLR   PACK   ;CLEAR 'W' COMMAND INDICATOR
6331 025022 000137 024462          JMP   ASSIGN    ;GO TO THE ASSIGN ROUTINE
6332
6333          ; 'D' COMMAND (ROUTINE TO DEASSIGN A DRIVE)
6334
6335 025026 005004          DEASGN: CLR   R4     ;COUNTER
6336 025030 012703 000010          MOV   #8,R3      ;DEASSIGN ALL DRIVES ?
6337 025034 122715 000101          CMPB  #'A',(R5)  ;BR IF YES
6338 025040 001403          BEQ   1$         ;SET R3 FOR ONE UNIT
6339 025042 012703 000001          MOV   #BIT00,R3

```



```

6340 025046 111504          MOVB      (R5),R4          ;GET DRIVE NUMBER
6341 025050 136437 034606 001544 1$: BITB      ATABIT(R4),ASNLST ;DRIVE ASSIGNED ?
6342 025056 001414          BEQ       3$              ;BR IF NOT
6343 025060 146437 034606 001544      BICB      ATABIT(R4),ASNLST ;DELETE THE DRIVE FROM THE ASSIGNED LIST
6344 025066 006304          ASL       R4              ;MAKE ADDR INTO A WORD INDEX
6345 025070 016464 002102 001546      MOV      BLKADR(R4),DUNIT(R4) ;PUT ADDRESS IN DEASSIGN LIST
6346 025076 006204          ASR       R4
6347 025100 005303          2$: DEC      R3              ;ANY MORE DRIVES ?
6348 025102 001412          BEQ       4$              ;BR IF NOT
6349 025104 005204          INC      R4
6350 025106 000760          BR        1$
6351 025110 012737 053334 026754 3$: MOV      #UNTNOT,ASNMSG ;ADDR OF 'NOT ASSIGNED' MESSAGE
6352 025116 004737 026734      JSR      PC,ASNERR      ;REPORT IT
6353 025122 122715 000101      CMPB     #'A',(R5)      ;ALL DRIVE ?
6354 025126 001764          BEQ       2$              ;YES
6355 025130 104401 001201      4$: TYPE     $SCRLF
6356 025134 000207          RTS      PC
6357
6358 ;'S' COMMAND (ROUTINE TO TYPE DRIVE PERFORMANCE SUMMARY)
6359
6360 025136 005004          SCMND:  CLR      R4
6361 025140 012703 000010      MOV      #8,R3          ;COUNTER
6362 025144 122715 000101      CMPB     #'A',(R5)      ;ALL STATISTICS ?
6363 025150 001421          BEQ       3$              ;BR IF YES
6364 025152 111504          MOVB     (R5),R4          ;GET DRIVE NUMBER
6365 025154 136437 034606 001544      BITB     ATABIT(R4),ASNLST ;SEE IF DRIVE ASSIGNED
6366 025162 001406          BEQ       1$              ;BR IF NOT
6367 025164 006304          ASL      R4              ;MAKE DRIVE ADDR INTO WORD INDEX
6368 025166 016400 002102      MOV      BLKADR(R4),R0   ;ADDR OF BLOCK
6369 025172 004737 023122      JSR      PC,TYPEST      ;TYPE DRIVE STATISTICS
6370 025176 000471          BR        8$
6371 025200 012737 053334 026754 1$: MOV      #UNTNOT,ASNMSG ;ADDR OF 'NOT ASSIGNED' MSG
6372 025206 004737 026734      JSR      PC,ASNERR      ;TYPE ERROR MESSAGE
6373 025212 000463          BR        8$
6374 025214 105737 001544      3$: TSTB     ASNLST
6375 025220 001001          BNE      4$              ;ANY DRIVE ASSIGNED ?
6376 025222 000457          BR        8$              ;YES
6377 025224 004737 023034      4$: JSR      PC,STATPR      ;RETURN
6378 025230 105737 001320      TSTB     DATE            ;TYPE ALL STATISTICS
6379 025234 001404          BEQ      11$             ;SEE IF 'DATE' ENTERED
6380 025236 104401 054332          TYPE     'DATE: '
6381 025242 104401 001320          TYPE     'DATE'
6382 025246 105737 001332          11$: TSTB     OPERID         ;THE OPERATOR ENTERED DATE
6383 025252 001404          BEQ      12$             ;SEE IF OPERATOR I.D. ENTERED
6384 025254 104401 054343          TYPE     'OPERATOR I.D.: '
6385 025260 104401 001332          TYPE     'OPERATOR I.D.'
6386 025264 104401 054365          12$: TYPE     'OPERATOR I.D.'
6387 025270 012737 043246 025336      MOV      #DRIVED+$DRVID,6$ ;HEADER LINE
6388 025276 136437 034606 001544 5$: BITB     ATABIT(R4),ASNLST ;DRIVE I.D. FIELD ADDRESS
6389 025304 001417          BEQ      7$              ;SEE IF DRIVE ASSIGNED
6390 025306 010446          MOV      R4,-(SP)        ;BR IF NOT ASSIGNED
6391
6392 025310 104403          TYPOS
6393 025312 002          .BYTE 2
6394 025313 000          .BYTE 0
6395 025314 104401 053244          TYPE     .LIN4SP
;SAVE R4 FOR TYPEOUT
;TYPE DRIVE NUMBER
;GO TYPE--OCTAL ASCII
;TYPE 2 DIGIT(S)
;SUPPRESS LEADING ZEROS
;4 SPACES

```



```

6452 025522 113760 001516 000024      MOV      BEGCD,$CODE(R0)      ;INITIAL COMMAND CODE
6453 025530 013701 001516              MOV      BEGCD,R1           ;GET THE ACTUAL OP CODE
6454 025534 116160 002122 000002      MOV      COMTBL(R1),$COMND(R0) ;OPERATION CODE
6455 025542 113760 001514 000030      MOV      BEGPAT,$PATTTC(R0)  ;PATTERN CODE
6456 025550 106360 000030              ASLB     $PATTTC(R0)        ;CONVERT CODE TO A TABLE INDEX
6457 025554 013760 001520 000020      MOV      BEGSIZ,$SWRDL(R0)   ;BEGINNING RECORD SIZE
6458 025556 013760 001520 000004      MOV      BEGSIZ,$SWRDM(R0)   ;VALUE FOR DATA TRANSFER
6459 025570 005460 000004              NEG      $SWRDM(R0)         ;MAKE IT INTO 2'S COMPLEMENT
6460 025574 012760 000400 000022      MOV      #256,$SSEC(R0)     ;INITIAL VALUE OF SECTOR SIZE
6461 025602 132760 000001 000024      BITB    #1,$CODE(R0)       ;HEADER ORDER ?
6462 025610 001403              BEQ     4$                 ;BR IF NOT
6463 025612 062760 000002 000022      ADD     #2,$SSEC(R0)       ;ADD HEADER SIZE TO SECTOR SIZE
6464 025620              4$:
6465 025620 012605              MOV     (SP)+,R5           ;;POP STACK INTO R5
6466 025622 012604              MOV     (SP)+,R4           ;;POP STACK INTO R4
6467 025624 012603              MOV     (SP)+,R3           ;;POP STACK INTO R3
6468 025626 012601              MOV     (SP)+,R1           ;;POP STACK INTO R1
6469 025630 000207              RTS      PC                ;RETURN
6470
6471 ;ROUTINE TO GET ADDRESS LIMITS FROM THE OPERATOR
6472
6473 025632 010346      DRVPRM: MOV     R3,-(SP)          ;SAVE R3
6474 025634 010446      MOV     R4,-(SP)          ;SAVE R4
6475 025636 005737 000042      TST     42                ;RUNNING UNDER MONITOR CONTROL
6476 025642 001010      BNE     3$                ;BR IF YES
6477 025644 104401 054226      TYPE    'ENTLMT'          ;'ENTER ADDRESSES'
6478 025650 006204      ASR     R4                ;CONVERT INDEX TO DRIVE NUMBER
6479 025652 010446      MOV     R4,-(SP)          ;SAVE R4 FOR TYPEOUT
6480 ;TYPE DRIVE NUMBER
6481 025654 104403      TYPOS   ;GO TYPE--OCTAL ASCII
6482 025656 002          .BYTE   2                ;TYPE 2 DIGIT(S)
6483 025657 000          .BYTE   0                ;SUPPRESS LEADING ZEROS
6484 ;
6485 ;SLASH
6486 ;MOV     #RM03A,2$        ;ADDRESS OF 'RM03' MESSAGE
6487 ;BITB    #BIT02,DRV TYP(R4) ;RM03 ?
6488 ;BNE     1$                ;BR IF YES
6489 ;HALT
6490 ;NOT RM03 PROGRAM SHOULD NOT HAVE
6491 ;REACHED THIS POINT
6492 ;TYPE THE MESSAGE WHICH FOLLOWS
6493 ;MESSAGE ADDRESS
6494 ;1$: TYPE .WORD 0
6495 ;2$: TYPE $CRLF
6496 ;3$: MOV     #821,CYLIMT   ;ASSUME AN RM03
6497 ;BITB    #BIT02,DRV TYP(R4) ;MAKE SURE RM03
6498 ;BNE     4$                ;BR IF RM03
6499 ;HALT
6500 ;4$: MOV     DRV TYP(R4),$RMDT(R0) ;INITIATE $RMDT
6501 ;ADD     #-1,$FIRST(R0)    ;SEE IF FIRST TIME STARTED
6502 ;BCS     5$                ;BR IF NOT
6503 ;MOV     CYLIMT,MAXCYL(R0) ;LOAD MAXIMUM CYLINDER
6504 ;CLR     MINCYL(R0)        ;CLEAR MINIMUM CYLINDER
6505 ;MOV     TRKIMT,MAXTRK(R0) ;LOAD MAXIMUM TRACK
6506 ;CLR     MINTRK(R0)        ;CLEAR MINIMUM TRACK
6507 ;MOV     SECLMT,MAXSEC(R0) ;LOAD MAXIMUM SECTOR
6508 ;CLR     MINSEC(R0)        ;CLEAR MINIMUM SECTOR
6509 ;5$: ASL     R4                ;SETUP TO ADDRESS WORDS
6510 ;MOV     TABLE(R4),R3    ;PARAMETER TABLE ADDRESS

```

```

6508 025766 013763 001446 000002      MOV      CYLIMT,2(R3)      ;LOAD CYLINDER LIMIT FOR LAST CYLINDER
6509 025774 013763 001446 000010      MOV      CYLIMT,10(R3)   ;LOAD CYLINDER LIMIT FOR STARTING CYLINDER
6510 026002 005737 000042      TST      42              ;UNDER MONITOR CONTROL ?
6511 026006 001002 000000      BNE      6$             ;BR IF YES
6512 026010 004737 026610      JSR      PC,PARENT      ;GET THE DRIVE'S PARAMETERS
6513 026014 116060 000120 000010 6$:      MOV      MINSEC(RO),SSEC(RO) ;INITIAL SECTOR VALUE
6514 026022 116060 000114 000011      MOV      MINTRK(RO),STRK(RO) ;INITIAL TRACK VALUE
6515 026030 016060 000110 000012      MOV      MINCYL(RO),SCYL(RO) ;INITIAL CYLINDER VALUE
6516 026036 012604 000000      MOV      (SP)+,R4       ;RESTORE R4
6517 026040 012603 000000      MOV      (SP)+,R3       ;RESTORE R3
6518 026042 000207 000000      RTS      PC             ;RETURN
    
```

;ROUTINE TO GET THE DRIVE I.D. FROM THE OPERATOR

```

6521      GETID:      MOV      R5,-(SP)      ;SAVE R5
6522 026044 010546 000042      TST      42              ;UNDER MONITOR CONTROL ?
6523 026046 005737 000042      BNE      2$             ;BR IF NOT
6524 026052 001036 000000      CLR      CFLAG          ;CLEAR THE 'CONTROL C' FLAG
6525 026054 005037 001360      TYPE    ,ENTDRV        ;'ENTER DRV I.D.:'
6526 026060 104401 054201      CLR      -(SP)         ;CLEAR THE STACK
6527 026064 005046 000000      MOV      (RO),(SP)     ;PUT THE DRIVE NUMBER ON THE STACK
6528 026066 111016 000000      TYPOS   2              ;TYPE THE DRIVE NUMBER
6529 026070 104403 000000      .BYTE   2              ;TYPE 2 DIGITS
6530 026072 002000 000000      .BYTE   0              ;SUPPRESS LEADING ZEROS
6531 026073 000000 000000      TYPE    ,SCRLF        ;CR-LF
6532 026074 104401 001201      RDLIN   (SP)+,R5       ;READ THE ENTRY
6533 026100 104411 000000      MOV      CFLAG          ;GET THE ENTRY ADDRESS
6534 026102 012605 000000      TST      CFLAG         ;'CONTROL C' ENTERED ?
6535 026104 005737 001360      BNE      1$             ;BR IF IT WAS
6536 026110 001361 000000      CMPB    (R5),#'.'     ;PERIOD ENTERED ?
6537 026112 121527 000056      BEQ     2$             ;BR IF YES
6538 026116 001414 000000      MOV      (R5)+,$DRVID(RO) ;STORE THE I.D.
6539 026120 112560 000224      MOV      (R5)+,$DRVID+1(RO) ;STORE THE I.D.
6540 026124 112560 000225      MOV      (R5)+,$DRVID+2(RO) ;STORE THE I.D.
6541 026130 112560 000226      MOV      (R5)+,$DRVID+3(RO) ;STORE THE I.D.
6542 026134 112560 000227      MOV      (R5)+,$DRVID+4(RO) ;STORE THE I.D.
6543 026140 112560 000230      MOV      (R5)+,$DRVID+5(RO) ;STORE THE I.D.
6544 026144 112560 000231      MOV      (SP)+,R5       ;RESTORE R5
6545 026150 012605 000000      RTS      PC             ;RETURN
6546 026152 000207 000000
    
```

;ROUTINE TO GET THE ADDRESSES OF ANY BAD SECTORS (UP TO A MAX OF 16)

```

6548      :CALL SEQ
6549      :JSR      R5,GETADR
6550      :RET1     ERROR RET
6551      :RET2     NORMAL RET
    
```

;RO DPB ADDRESS

```

6552      GETADR:      MOV      R1,-(SP)      ;;PUSH R1 ON STACK
6553 026154 010146 000000      MOV      R2,-(SP)      ;;PUSH R2 ON STACK
6554 026154 010146 000000      MOV      R3,-(SP)      ;;PUSH R3 ON STACK
6555 026156 010246 000000      MOV      R4,-(SP)      ;;PUSH R4 ON STACK
6556 026160 010346 000000      MOV      RO,R1         ;DPB ADDRESS
6557 026162 010446 000000      ADD     #BDSSEC,R1     ;ADDRESS OF BAD SECTOR TABLE
6558 026164 010001 000124      MOV     #32.,R2       ;WORD CTR
6559 026166 062701 000124
6560 026172 012702 000040
    
```



```

6620 026512 104401 053305      TYPE      ,UNMSG      ; ON DRIVE
6621 026516 111046      MOVVB     (RO),-(SP)  ; #
6622 026520 104403      TYPOS
6623 026522      .BYTE      2
6624 026523      .BYTE      0
6625 026524 104401 001201      TYPE      ,SCLF      ; CR-LF
6626 026530 000415      BR       11$
6627 026532 032737 000002 001264 10$:  BIT     #BIT1,$CDW1  ; EXIT
6628 026540 001411      BEQ     11$          ; OVER 16 BAD SECTORS ?
6629 026542 104401 054643      TYPE      ,MERR2    ; BRANCH IF NOT
6630 026546 104401 053305      TYPE      ,UNMSG    ; OVER 16 BAD SECTORS DETECTED
6631 026552 111046      MOVVB     (RO),-(SP) ; ON DRIVE
6632 026554 104403      TYPOS
6633 026556      .BYTE      2
6634 026557      .BYTE      0
6635 026560 104401 001201      TYPE      ,SCLF
6636 026564 005737 001264      11$:  TST     $CDW1      ; ERROR FLAG SET ?
6637 026570 001002      BNE     12$
6638 026572 062705 000002      ADD     #2,R5      ; BRANCH IS SET
6639 026576      12$:  MOV     (SP)+,R4    ; ADJUST FOR NORMAL RET
6640 026576 012604      MOV     (SP)+,R3    ; POP STACK INTO R4
6641 026600 012603      MOV     (SP)+,R2    ; POP STACK INTO R3
6642 026602 012602      MOV     (SP)+,R1    ; POP STACK INTO R2
6643 026604 012601      MOV     (SP)+,R1    ; POP STACK INTO R1
6644 026606 000205      RTS     R5          ; EXIT
6645
6646      ;PARAMETER ENTRY ROUTINE
6647      ;CALL
6648      ;
6649      ;      MOV     #ADR,R3      ;PARAMETER TABLE ADDRESS
6650      ;      JSR     PC,PARENT   ;GET THE PARAMETERS
6651 026610 010346      PARENT: MOV     R3, -(SP)    ;SAVE THE PARAMETER TABLE ADDRESS
6652 026612 005037 001360      CLR     CFLAG        ;CLEAR THE 'CONTROL C' FLAG
6653 026616 012337 026626      1$:  MOV     (R3)+,3$    ;ADDRESS OF PARAMETER NAME
6654 026622 001442      BEQ     9$           ;BR IF AT END OF TABLE
6655 026624 104401      TYPE
6656 026626 000000      .WORD      0        ;TYPE THE PARAMETER NAME
6657 026630 012302      MOV     (R3)+,R2    ;ADDRESS OF PARAMETER NAME TEXT
6658 026632 012305      MOV     (R3)+,R5    ;MAXIMUM PARAMETER VALUE
6659 026634 011546      MOV     (R5),-(SP) ;ADDRESS OF PARAMETER
6660 026636 104405      TYPOS        ;CURRENT VALUE OF PARAMETER
6661 026640 104401 055036      TYPE      ,SLASH   ;TYPE THE CURRENT VALUE OF THE PARAMETER
6662 026644 104411      RDLIN
6663 026646 012601      MOV     (SP)+,R1    ;READ THE KEYBOARD
6664 026650 005737 001360      TST     CFLAG        ;INPUT ASCII STRING ADDRESS
6665 026654 001021      BNE     8$          ;'CONTROL C' ENTERED ?
6666 026656 004537 030300      JSR     R5,CK.DIG   ;BR IF IT WAS
6667 026662 026616      1$
6668 026664 026730      9$
6669 026666 026702      6$
6670 026670 026676      5$
6671 026672 026702      6$
6672 026674 026714      7$
6673 026676 010215      5$:  MOV     R2,(R5)    ;MOVE NEW VALUE TO PARAMETER LOCATION
6674 026700 000746      BR     1$
6675 026702 104401 054417      6$:  TYPE      ,BADENT ;GET MORE PARAMETERS
; 'BAD ENTRY'

```

```

6676 026706 162703 000006          SUB      #6,R3          ;DECREMENT THE TABLE POINTER
6677 026712 000741          BR       1$           ;TRY AGAIN
6678 026714 010215          7$:     MOV      R2,(R5) ;NEW VALUE
6679 026716 000404          BR       9$           ;EXIT
6680 026720 005037 001360          8$:     CLR      CFLAG ;CLEAR THE 'CONTROL C' FLAG
6681 026724 011603          MOV      (SP),R3     ;RELOAD THE PARAMETER TABLE ADDRESS
6682 026726 000733          BR       1$           ;TRY AGAIN
6683 026730 005726          9$:     TST      (SP)+ ;CORRECT THE STACK POINTER
6684 026732 000207          RTS       PC         ;RETURN
6685
6686          ;TYPEOUT ASSIGN/DEASSIGN ERROR MESSAGE
6687          ;CALL
6688          ;
6689          ;
6690          ;
6691          ;
6692 026734 104401 054130          ASNERR: TYPE      ,QUES ;QUESTION MARK
6693 026740 104401 053305          TYPE      'UNTMSG' ;TYPE 'DRIVE'
6694 026744 010446          MOV      R4,-(SP) ;SAVE R4 FOR TYPEOUT
6695          ;
6696 026746 104403          TYPOS ;TYPE DRIVE NUMBER
6697 026750 002          .BYTE 2 ;GO TYPE--OCTAL ASCII
6698 026751 000          .BYTE 0 ;TYPE 2 DIGIT(S)
6699 026752 104401          TYPE ;SUPPRESS LEADING ZEROS
6700 026754 000000          ASNMSG: .WORD 0 ;TYPE SPECIFIC MESSAGE
6701 026756 104401 001201          TYPE      ,%CRLF ;MESSAGE ADDRESS
6702 026762 000207          RTS       PC
6703
6704          ;DEASSIGN DRIVE IF A FATAL ERROR OCCURS
6705          ;CALL
6706          ;
6707          ;
6708          ;
6709 026764 005004          DROP:  CLR      R4 ;CLEAR R4 FOR DRIVE NUMBER
6710 026766 111004          MOVB     (R0),R4 ;MOVE DRIVE NUMBER TO R4
6711 026770 146437 034606 001544          BICB     ATABIT(R4),ASNLS ;REMOVE DRIVE FROM ASSIGNED LIST
6712 026776 006304          ASL      R4 ;MAKE DRIVE NUMBER INTO A TABLE INDEX
6713 027000 010064 001546          MOV      R0,DUNIT(R4) ;PUT DRIVE IN DROP LIST
6714 027004 104401 001201          TYPE      ,%CRLF
6715 027010 104401 001201          TYPE      ,%CRLF
6716 027014 104401 053703          TYPE      ,DROPN ;TYPE 'DROPPING DRIVE'
6717 027020 104401 054014          TYPE      ,DRNUM ;'DRIVE #'
6718 027024 006204          ASR      R4 ;DRIVE NUMBER
6719 027026 010446          MOV      R4,-(SP) ;SAVE R4 FOR TYPEOUT
6720          ;
6721 027030 104403          TYPOS ;TYPE DRIVE NUMBER
6722 027032 002          .BYTE 2 ;GO TYPE--OCTAL ASCII
6723 027033 000          .BYTE 0 ;TYPE 2 DIGIT(S)
6724 027034 104401 001201          TYPE      ,%CRLF ;SUPPRESS LEADING ZEROS
6725 027040 105737 001544          TSTB     ASNLS ;MORE DRIVES ACTIVE
6726 027044 001006          BNE      1$ ;YES
6727 027046 005737 000042          TST      @#42 ;ANY MONITOR ?
6728 027052 001403          BEQ      1$ ;NO
6729 027054 005726          TST      (SP)+ ;CLEAR STACK
6730 027056 000137 027440          JMP      $GET42 ;GIVE CONTROL TO MONITOR
6731 027062 000207          1$:     RTS       PC

```

```

6732
6733 ;ROUTINE TO DEASSIGN DRIVE IF ERRORS BECOMES EXCESSIVE
6734
6735 027064 032777 000020 152062 ABNRML: BIT #SW04,ASWR ;SEE IF SWITCH 4 SET
6736 027072 001006 ;BNE 1$ ;BR IF IT'S SET
6737 027074 023760 001464 000056 CMP MAXER,$TOTAL(RO) ;CHECK TOTAL ERROR VALUE
6738 027102 103002 BHIS 1$ ;BR IF ERRORS DONOT EXCEED MAX
6739 027104 000137 026764 JMP DROP ;DEASSING THE DRIVE
6740 027110 000207 1$: RTS PC ;RETURN
6741
6742 ;ROUTINE TO CHECK FOR END OF PASS AND END OF TEST
6743
6744 .SBTTL END OF PASS ROUTINE
6745
6746 ;*****
6747 ;*INCREMENT THE PASS NUMBER ($PASS)
6748 ;*IF THERES A MONITOR GO TO IT
6749 ;*IF THERE ISN'T JUMP TO FISK
6750
6751 027112 $EOP:
6752 027112 005737 001506 EOP: TST ENDET ;END OF PASS DETERMINED BY SEEKS OR WORDS ?
6753 027116 001412 BEQ EOP1 ;BR IF SEEKS
6754 027120 026037 000054 001452 CMP $READ+2(RO),ENDCON+2 ;CHECK MSW OF WORDS READ COUNT
6755 027126 101017 BHI EOP2 ;BR IF MSW GREATER THAN LIMIT
6756 027130 103527 BLO EOPX ;BR IF MSW LESS THAN LIMIT
6757 027132 026037 000052 001450 CMP $READ(RO),ENDCON ;CHECK LSW AGAINST LIMIT
6758 027140 103012 BHIS EOP2 ;BR IF EQUAL OR GREATER
6759 027142 000522 BR EOPX ;EXIT
6760 027144 026037 000044 001456 EOP1: CMP $POSIT+2(RO),ENDSEK+2 ;CHECK MSW OF SEEK COUNT
6761 027152 101005 BHI EOP2 ;BR IF MSW GREATER THAN LIMIT
6762 027154 103515 BLO EOPX ;EXIT IF MSW LESS THAN LIMIT
6763 027156 026037 000042 001454 CMP $POSIT(RO),ENDSEK ;CHECK LSW OF SEEK COUNT
6764 027164 103511 BLO EOPX ;EXIT IF LSW LESS THAN LIMIT
6765 027166 104401 001201 EOP2: TYPE ,$CRLF ;CR-LF
6766 027172 104401 053737 TYPE ,ENDPAS ;END OF PASS FOR THE DRIVE
6767 027176 016046 000070 MOV $PASSC(RO),-(SP) ;PUT PASS COUNT ON THE STACK
6768 027202 104405 TYPDS ;CONVERT PASS COUNT TO DECIMAL AND TYPE IT
6769 027204 111037 001344 MOV (RO),UNIT ;STORE THE DRIVE NUMBER
6770 027210 032777 000020 151736 BIT #SW04,ASWR ;SWITCH 4 SET ?
6771 027216 001017 BNE 1$ ;BR IF SET
6772 027220 026037 000070 001460 CMP $PASSC(RO),PASCNT ;SEE IF AT END OF TEST
6773 027226 103413 BLO 1$ ;BR IF NOT
6774 027230 104401 053753 TYPE ,ENDTST ;TYPE 'END OF TEST'
6775 027234 104401 054014 TYPE ,DRNUM ;'DRIVE #'
6776 027240 013746 001344 MOV UNIT,-(SP) ;SAVE UNIT FOR TYPEOUT
6777 ;TYPE DRIVE NUMBER
6778 027244 104403 TYPOS ;GO TYPE--OCTAL ASCII
6779 027246 002 .BYTE 2 ;TYPE 2 DIGIT(S)
6780 027247 000 .BYTE 0 ;SUPPRESS LEADING ZEROS
6781 027250 104401 001201 TYPE , $CRLF ;CR-LF
6782 027254 000431 BR 3$ ;DEASSIGN THE DRIVE
6783 027256 104401 054014 1$: TYPE ,DRNUM ;'DRIVE #'
6784 027262 013746 001344 MOV UNIT,-(SP) ;SAVE UNIT FOR TYPEOUT
6785 ;TYPE DRIVE NUMBER
6786 027266 104403 TYPOS ;GO TYPE--OCTAL ASCII
6787 027270 002 .BYTE 2 ;TYPE 2 DIGIT(S)

```



6788	027271	000			.BYTE	0	:: SUPPRESS LEADING ZEROS
6789	027272	104401	001201		TYPE	\$SCRLF	:: CR-LF
6790	027276	004737	023122		JSR	PC,TYPEST	:: TYPE THE DRIVE'S STATISTICS
6791	027302	010346			MOV	R3,-(SP)	:: SAVE R3
6792	027304	010446			MOV	R4,-(SP)	:: SAVE R4
6793	027306	010004			MOV	RO,R4	:: DRIVE'S BLOCK ADDRESS
6794	027310	062704	000036		ADD	#\$OPERC,R4	:: ADD THE STARTING ADDR OF SECTIONS TO CLEAR
6795	027314	012703	000010		MOV	#\$B.,R3	:: NUMBER OF LOCNS TO BE CLEARED (ERROR COUNTERS NOT CLEARED)
6796							
6797	027320	005024		2\$:	CLR	(R4)+	:: CLEAR THE LOCN
6798	027322	005303			DEC	R3	:: DECREMENT THE LOCATION COUNTER
6799	027324	001375			BNE	2\$	:: BR IF MORE TO GO
6800	027326	012604			MOV	(SP)+,R4	:: RESTORE R4
6801	027330	012603			MOV	(SP)+,R3	:: RESTORE R3
6802	027332	005260	000070		INC	\$PASSC(RO)	:: INCREMENT THE PASS COUNT
6803	027336	000424			BR	EOPX	:: EXIT
6804	027340	104401	001201	3\$:	TYPE	\$SCRLF	
6805	027344	005004			CLR	R4	:: CLEAR R4 FOR DRIVE NUMBER
6806	027346	111004			MOVB	(RO),R4	:: MOVE DRIVE NUMBER
6807	027350	146437	034606	001544	BICB	ATABIT(R4),ASNLS	:: DELETE DRIVE FROM ASSIGNED LIST
6808	027356	006304			ASL	R4	:: MAKE DRIVE NUMBER INTO TABLE INDEX
6809	027360	010064	001546		MOV	RO,DUNIT(R4)	:: PUT BLOCK ADDRESS INTO DROP LIST
6810	027364	105737	001544		TSTB	ASNLS	:: ALL DRIVES ARE DESIGNED ?
6811	027370	001007			BNE	EOPX	:: BRANCH IF NOT
6812	027372	005237	001214		INC	\$DEVCT	:: INCREMENT DEVICE COUNT
6813	027376	005237	001212		INC	\$PASS	:: INCREMENT THE PASS NUMBER FOR APT
6814	027402	042737	100000	001212	BIC	#\$100000,\$PASS	:: AVIOD NEGATIVE NUMBER
6815	027410	000207		EOPX:	RTS	PC	:: RETURN
6816	027412	005237	001212		INC	\$PASS	:: INCREMENT THE PASS NUMBER
6817	027416	042737	100000	001212	BIC	#\$100000,\$PASS	:: DON'T ALLOW A NEG. NUMBER
6818	027424	005327			DEC	(PC)+	:: LOOP?
6819	027426	000001		\$EOPCT:	.WORD	1	
6820	027430	003013			BGT	\$DOAGN	:: YES
6821	027432	012737			MOV	(PC)+,2(PC)+	:: RESTORE COUNTER
6822	027434	000001		\$ENDCT:	.WORD	1	
6823	027436	027426			\$EOPCT		
6824	027440	013700	000042	\$GET42:	MOV	2#42,RO	:: GET MONITOR ADDRESS
6825	027444	001405			BEQ	\$DOAGN	:: BRANCH IF NO MONITOR
6826	027446	000005			RESET		:: CLEAR THE WORLD
6827	027450	004710		\$ENDAD:	JSR	PC,(RO)	:: GO TO MONITOR
6828	027452	000240			NOP		:: SAVE ROOM
6829	027454	000240			NOP		:: FOR
6830	027456	000240			NOP		:: ACT11
6831	027460			\$DOAGN:			
6832	027460	000137			JMP	2(PC)+	:: RETURN
6833	027462	027464		\$RTNAD:	.WORD	FISK	
6834	027464	005237	001210	FISK:	INC	\$TESTN	:: INCREMENT THE TEST NUMBER IN THE MAIL BOX
6835	027470	000137	005574		JMP	MAIN1	:: RETURN TO LOOP
6836							
6837							
6838							
6839							
6840							
6841							
6842							
6843	027474	013746	033752	GETREM:	MOV	\$LONUM,-(SP)	:: STORE RANDOM NUMBER ON THE STACK FOR DIVIDE

;ROUTINE TO GET THE REMAINDER OF THE RANDOM NUMBER

;CALL

```

:      MOV    NUMBER,R5      ;DIVISOR INTO R5
:      JSR    PC,GETREM
:      RETURN                ;REMAINDER IS IN R5

```

```

6844 027500 013746 033750      MOV      $HINUM, -(SP)      ;UPPER PART
6845 027504 010546              MOV      R5, -(SP)         ;PUT THE DIVISOR ONTO THE STACK
6846 027506 004737 027522      JSR      PC, LINKDV        ;DIVIDE THE RANDOM NUMBERS
6847 027512 012605              MOV      (SP)+, R5         ;PUT THE REMAINDER INTO R5
6848 027514 005726              TST     (SP)+             ;ADJUST THE STACK POINTER
6849 027516 000240              NOP                      ;FOR DEBUGGING HALT
6850 027520 000207              RTS      PC

;LINK ROUTINE TO THE DIVISION UTILITY SUBROUTINE
;THIS ROUTINE ALLOWS THE 'SYSMAC' DIVIDE ROUTINE
;CALLING SEQUENCE TO BE USED

LINKDV: SAVREG                ;STORE R0 - R5
        MOV      26(SP), R5   ;DIVISOR
        CLR      R4           ;OTHER DIVISOR WORD
        MOV      30(SP), R2   ;UPPER DIVIDEND WORD
        MOV      32(SP), R3   ;LOWER DIVIDEND WORD
        CLR      R0           ;CLEAR OTHER DIVIDEND REGISTERS
        CLR      R1
        JSR      PC, M.DPID   ;GO TO THE DIVIDE ROUTINE
        MOV      R1, 30(SP)   ;REMAINDER ON THE STACK
        MOV      R3, 32(SP)   ;QUOTIENT ON THE STACK
        RESREG                ;RESTORE R0 - R5
        MOV      (SP)+, (SP) ;MOVE RETURN UP THE STACK
        RTS      PC

; DIVISION UTILITY SUBROUTINE
; R0-R1-R2-R3=DIVIDEND
; R4-R5=DIVISOR
; R0-R1=REMAINDER AFTER DIVISION
; R2-R3=QUOTIENT AFTER DIVISION
; ENTER WITH JSR PC, M.DPID

M.DPID: MOV      #40, -(SP)   ;COUNTER FOR DIVISION CYCLES
        MOV      R4, -(SP)   ;HIGH ORDER
        MOV      R5, -(SP)   ;LOW ORDER DIVISOR TO THE STACK
        NEG      2(SP)       ;FORM NEGATIVE
        NEG      @SP         ;VERSION OF THE DIVISOR
        SBC      2(SP)
        ADD      @SP, R1
        ADC      R0           ;PERFORM THE INITIAL SUBTRACTION
        ADD      2(SP), R0
        BCS      M.DP50     ;IF CARRY THEN OVERFLOW HAS OCCURRED
        CLR      -(SP)      ;THIS IS A LONGER LASTING CARRY BIT
M.DP40: ROL      R3
        ROL      R2
        ROL      R1
        ROL      R0
        TST     @SP         ;TEST "CARRY" INDICATOR
        BEQ     M.DP41     ;IF NO "CARRY" THEN ADD ELSE SUBTRACT
        CLR      @SP       ;CLEAR UP FOR NEXT TIME
        ADD      2(SP), R1
        ADC      R0         ;ADD -(DIVISOR)
        ADC      @SP
        ADD      4(SP), R0 ; I ;SET "CARRY"
        BR      M.DP42
    
```

```

6900 027662 060501      M.DP41: ADD    R5,R1
6901 027664 005500      ADC    R0
6902 027666 005516      ADC    @SP      ;ADD +(DIVISOR)
6903 027670 060400      ADD    R4,R0    ;<- I ;SET "CARRY"
6904 027672 005516      M.DP42: ADC    @SP      ;SET "CARRY"
6905 027674 005716      TST    @SP      ;TEST THE UPDATE INDICATOR
6906 027676 001401      BEQ    +4        ;IF ZERO FORGET IT
6907 027700 005203      INC    R3        ;NO CARRY POSSIBLE HERE
6908 027702 005366 000006  DEC    6(SP)     ;<- I ;DECREMENT COUNTER
6909 027706 003347      BGT    M.DP40    ;BRANCH IF MORE TO DO
6910 027710 006003      ROR    R3
6911 027712 103404      BCS    M.DP44
6912 027714 060501      ADD    R5,R1
6913 027716 005500      ADC    R0
6914 027720 060400      ADD    R4,R0
6915 027722 000241      CLC
6916 027724 006103      M.DP44: ROL    R3
6917 027726 062706 000010  ADD    #10,SP    ;ADJUST STACK BY 4 WORDS
6918 027732 000242      CLV
6919 027734 000207      RTS
6920 027736 062706 000006  M.DP50: ADD    #6,SP
6921 027742 000262      SEV
6922 027744 000207      RTS
6923
6924
6925      ;ROUTINE TO REPLACE LEADING ZEROS IN A NUMERIC STRING WITH SPACES
6926      ;CALL
6927      ;      MOV    #ADR, -(SP)      ;ADDRESS OF NUMBER (IN ASCII)
6928      ;      JSR    R5, REPLZ
6929      ;      .WORD  N                ;'N' IS NUMBER OF DIGITS TO BE TYPED
6930
6931 027746 010046      REPLZ: MOV    R0, -(SP)      ;SAVE R0
6932 027750 012746 000012  MOV    #10, -(SP)     ;MAXIMUM NUMBER OF DIGITS TO BE TYPED
6933 027754 162516      SUB    (R5)+, (SP)    ;SUBTRACT DIGITS TO FORM INDEX
6934 027756 016600 000006  MOV    6(SP), R0      ;ADDRESS OF NUMBER TO R0
6935 027762 122710 000060  1$:   CMFB   #'0', (R0)   ;BYTE EQUAL TO ASCII '0' ?
6936 027766 001004      BNE    2$            ;BR IF NOT
6937 027770 112710 000040  MOVB   #40, (R0)     ;REPLACE THE ZERO WITH A SPACE
6938 027774 005200      INC    R0            ;INCREMENT THE BYTE ADDRESS
6939 027776 000771      BR     1$            ;GO BACK AND LOOK FOR MORE LEADING ZEROS
6940 030000 105710      2$:   TSTB   (R0)        ;SEE IF ZERO BYTE TERMINATOR
6941 030002 001003      BNE    3$            ;BR IF NOT
6942 030004 005300      DEC    R0            ;BACKUP STRING POINTER
6943 030006 112710 000060  MOVB   #'0', (R0)    ;PUT A ZERO BACK IN
6944 030012 016637 000006 030026 3$:   MOV    6(SP), 4$
6945 030020 062637 030026  ADD    (SP)+, 4$
6946 030024 104401      TYPE  ;TYPE THE NUMBER
6947 030026 000000 4$:   .WORD 0            ;ADDRESS OF NUMBER
6948 030030 012600      MOV    (SP)+, R0     ;RESTORE R0
6949 030032 012616      MOV    (SP)+, (SP)   ;MOVE RETURN ADDRESS
6950 030034 000205      RTS    R5            ;RETURN
6951
6952      ;TYPE NUMERICAL ASCIZ STRING SUPRESS LEADING ZEROS
6953
6954      ;CALL
6955      ;      MOV    #NUMADR, -(SP)  ;FIRST ADDRESS OF ASCIZ STRING

```

```

6956 ; JSR PC,$SUPRS
6957 ;
6958 030036 010046 000004 $SUPRS: MOV RO,-(SP) ;SAVE RO
6959 030040 016600 000004 MOV 4(SP),RO ;PICKUP THE POINTER
6960 030044 105710 000004 1$: TSTB (RO) ;TERMINATOR ?
6961 030046 001403 000004 BEQ 2$ ;BR IF YES
6962 030050 122720 000060 CMPB #'0,(RO)+ ;IS THIS AN ASCII '0' ?
6963 030054 001773 000060 BEQ 1$ ;BR IF YES
6964 030056 005300 030066 2$: DEC RO ;BACKUP BY '1'
6965 030060 010037 030066 MOV RO,3$ ;SAVE FOR TYPING
6966 030064 104414 030066 DISPLY ;GO PRINT
6967 030066 000000 030066 3$: .WORD 0 ;ASCIZ POINTER GOES HERE
6968 030070 012600 030066 MOV (SP)+,RO ;RESTORE RO
6969 030072 012616 030066 MOV (SP)+,(SP) ;RESTORE THE STACK
6970 030074 000207 030066 RTS PC ;RETURN
6971 ;
6972 ;ROUTINE TO TYPE AT PRIORITY 4
6973 ;
6974 030076 013746 177776 177776 TYPRI4: MOV 2$PS,-(SP) ;SAVE THE PRESENT STATUS
6975 030102 012737 000200 MOV 200,2$PS ;CHANGE THE PRIORITY TO 4
6976 030110 012537 030120 MOV (R5)+,1$ ;MESSAGE ADDRESS
6977 030114 004737 031516 JSR PC,$TYPE ;TYPE THE MESSAGE
6978 030120 000000 030120 1$: .WORD 0 ;MESSAGE ADDRESS GOES HERE
6979 030122 000205 030120 RTS R5 ;RETURN
6980 ;
6981 ;ROUTINE TO TYPE ERRORS
6982 ;CALL
6983 ; DISPLY ;MUST DEFINED IN 'TRAP' TABLE
6984 ; MESADR ;ADDRESS OF MESSAGE
6985 ; RETURN
6986 ;
6987 030124 032777 020000 151022 $DSPLY: BIT #BIT13,2$SWR ;INHIBIT ERROR TYPEOUT ?
6988 030132 001004 020000 BNE 1$ ;BR IF YES
6989 030134 005037 177776 CLR 2$PS ;SET PRIORITY TO ZERO
6990 030140 000137 031516 JMP $TYPE ;TYPE THE MESSAGE
6991 030144 062716 000002 1$: ADD #2,(SP) ;INCREMENT THE RETURN
6992 030150 000002 030144 RTI ;RETURN
6993 ;
6994 ;THIS ROUTINE IS USED TO CHECK IF AN
6995 ;ASCII CHARACTER IS A DIGIT BETWEEN 0 AND 7.
6996 ;CALL
6997 ; MOV #ADR,R1 ;ADDRESS OF ASCII CHARACTER
6998 ; JSR R5,CK.OCT ;CHECK THE CHARACTER
6999 ; RETURN1 ;CHARACTER IS NOT BETWEEN 0-7
7000 ; RETURN2 ;CHARACTER IS IN R2 AS A
7001 ; ;OCTAL DIGIT
7002 ;
7003 030152 121127 000060 CK.OCT: CMPB (R1),'0' ;LESS THAN ZERO?
7004 030156 103407 000060 BLO 1$ ;YES -- BRANCH
7005 030160 121127 000067 CMPB (R1),'7' ;GREATER THAN SEVEN?
7006 030164 101004 000067 BHI 1$ ;YES -- BRANCH
7007 030166 111102 177770 MOVB (R1),R2 ;GET THE CHARACTER
7008 030170 042702 177770 BIC #7,R2 ;STRIP AWAY THE ASCII
7009 030174 005725 177770 TST (R5)+ ;ADJUST FOR RETURN
7010 030176 000205 177770 1$: RTS R5 ;RETURN
7011 ;

```

7012  
7013  
7014  
7015  
7016  
7017  
7018  
7019  
7020  
7021 030200 121127 000060  
7022 030204 103407  
7023 030206 121127 000071  
7024 030212 101004  
7025 030214 111102  
7026 030216 042702 000060  
7027 030222 005725  
7028 030224 000205  
7029  
7030  
7031  
7032  
7033  
7034  
7035  
7036  
7037  
7038  
7039  
7040  
7041  
7042  
7043 030226 105711  
7044 030230 001417  
7045 030232 121127 000054  
7046 030236 001413  
7047 030240 121127 000056  
7048 030244 001407  
7049 030246 004537 030200  
7050 030252 000410  
7051 030254 004537 030152  
7052 030260 005725  
7053 030262 005725  
7054 030264 005725  
7055 030266 005725  
7056 030270 005725  
7057 030272 005201  
7058 030274 011505  
7059 030276 000205  
7060  
7061  
7062  
7063  
7064  
7065  
7066  
7067

```

; THIS ROUTINE IS USED TO CHECK AN ASCII CHARACTER
; AND DETERMINE IF IT IS A DIGIT BETWEEN 0 AND 9.
CALL
      MOV      #ADR,R1      ; ADDRESS OF ASCII CHARACTER
      JSR      RS,CK.DEC    ; CHECK THE CHARACTER
      RETURN1   ; NOT BETWEEN 0 AND 9
      RETURN2   ; BETWEEN 0 AND 9
                        ; R2 = DIGIT

CK.DEC: CMPB    (R1),#'0    ; LESS THAN ZERO?
        BLO    1$          ; YES -- BRANCH
        CMPB    (R1),#'9    ; GREATER THAN NINE?
        BHI    1$          ; YES -- BRANCH
        MOVB    (R1),R2     ; GET THE CHARACTER
        BIC    #'0,R2      ; STRIP AWAY THE ASCII
        TST    (R5)+       ; ADJUST FOR RETURN
1$:     RTS      RS        ; RETURN

; THIS ROUTINE WILL CHECK AN ASCII CHARACTER TO
; DETERMINE WHAT IT IS.
CALL
      MOV      #ADR,R1      ; ADDRESS OF ASCII CHARACTER
      JSR      RS,CK.CHR    ; CHECK CHARACTER
      RETURN   ; UNKNOWN CHARACTER
      RETURN   ; CARRIAGE RETURN * (R1)=ADR+1
      RETURN   ; COMMA * (R1)=ADR+1
      RETURN   ; PERIOD * (R1)=ADR+1
      RETURN   ; DIGIT BETWEEN 0 AND 7.
      RETURN   ; DIGIT BETWEEN 8 AND 9.
                        ; R2 = DIGIT * (R1)=ADR+1

CK.CHR: TSTB    (R1)       ; "CARRIAGE RETURN"?
        BEQ    3$          ; YES -- BRANCH
        CMPB    (R1),#',    ; "COMMA"?
        BEQ    2$          ; YES -- BRANCH
        CMPB    (R1),#'.    ; "PERIOD"?
        BEQ    1$          ; YES -- BRANCH
        JSR      RS,CK.DEC  ; "DIGIT"?
        BR     4$          ; NO -- BRANCH
        JSR      RS,CK.OCT  ; OCTAL ?
        TST    (R5)+       ; DIGIT BETWEEN 8-9
        TST    (R5)+       ; DIGIT BETWEEN 0-7
1$:     TST    (R5)+       ; PERIOD
2$:     TST    (R5)+       ; COMMA
3$:     TST    (R5)+       ; CARRIAGE RETURN
        INC    R1          ; MOVE POINTER TO NEXT CHARACTER
4$:     MOV     (R5),R5     ; UNKNOWN CHARACTER
        RTS      RS        ; RETURN

; THIS ROUTINE CHECKS AN ASCII STRING FOR LEGAL
; CHARACTERS AND FORMS A DECIMAL VALUE BINARY NUMBER IN R2.
CALL
      MOV      #ADR,R1      ; ADDRESS OF ASCII STRING
      MOV      #NUM,R2     ; MAX. MAGNITUDE OF INPUT NUMBER
      JSR      RS,CK.DIG    ; CHECK DIGITS
      RETURN   ; "CR" ONLY ENTERED -- R2=0
    
```

```

7068 ; RETURN ADR2 ; "PERIOD" ONLY ENTERED -- R2=0
7069 ; RETURN ADR3 ; ILLEGAL CHARACTER OR INPUT TOO LARGE -- R2=?
7070 ; RETURN ADR4 ; "CR" -- R2 = NUMBER
7071 ; RETURN ADR5 ; "COMMA" -- R2 = NUMBER
7072 ; RETURN ADR6 ; "PERIOD" -- R2 = NUMBER
7073
7074 030300 010446 CK.DIG: MOV R4,-(SP) ;SAVE R4
7075 030302 010346 MOV R3,-(SP) ;SAVE R3
7076 030304 010246 MOV R2,-(SP) ;SAVE THE MAX. SIZE ON THE STACK
7077 030306 005002 CLR R2 ;START WITH 0
7078 030310 005003 CLR R3
7079 030312 005004 CLR R4
7080 030314 004537 030226 JSR R5,CK.CHR ;CHECK ONE CHARACTER
7081 030320 030414 6$ ;ILLEGAL CHARACTER
7082 030322 030422 9$ ;CARRIAGE RETURN
7083 030324 030414 6$ ;"
7084 030326 030416 7$ ;"
7085 030330 030334 1$ ;DIGIT 0-7
7086 030332 030334 1$ ;DIGIT 8-9
7087 030334 062705 000004 1$: ADD #4,R5 ;STEP RETURN POINTER PAST "CR" & "PERIOD" RETURNS
7088 030340 006303 2$: ASL R3 ;INPUT NUMBER *2
7089 030342 010346 MOV R3,-(SP) ;SAVE *2
7090 030344 006303 ASL R3 ;*4
7091 030346 006303 ASL R3 ;*8
7092 030350 062603 ADD (SP)+,R3 ;(*2)+(*8) = *10
7093 030352 060203 ADD R2,R3 ;UPDATE THE INPUT NUMBER
7094 030354 004537 030226 JSR R5,CK.CHR ;CHECK ONE CHARACTER
7095 030360 030420 8$ ;ILLEGAL CHARACTER
7096 030362 030404 5$ ;CARRIAGE RETURN
7097 030364 030402 4$ ;"
7098 030366 030374 3$ ;"
7099 030370 030340 2$ ;DIGIT 0-7
7100 030372 030340 2$ ;DIGIT 8-9
7101 030374 105711 3$: TSTB (R1) ;DOES A "CR" FOLLOW THE "PERIOD"
7102 030376 001010 BNE 8$ ;BR IF NOT
7103 030400 005724 TST (R4)+ ;INCREMENT THE RETURN
7104 030402 005724 4$: TST (R4)+ ;INCREMENT THE RETURN
7105 030404 005724 5$: TST (R4)+ ;INCREMENT THE RETURN
7106 030406 020316 CMP R3,(SP) ;CHECK THE MAGNITUDE OF THE NUMBER
7107 030410 101004 BHI 9$ ;BR IF ENTERED NUMBER TOO LARGE
7108 030412 000402 BR 8$ ;BYPASS INCREMENT
7109 030414 005725 6$: TST (R5)+ ;INCREMENT RETURN PAST INVALID RETURN
7110 030416 005725 7$: TST (R5)+ ;INCREMENT RETURN
7111 030420 060405 8$: ADD R4,R5 ;SETUP RETURN POINTER
7112 030422 010302 9$: MOV R3,R2 ;ENTERED VALUE
7113 030424 005726 TST (SP)+ ;CLEAN MAX. SIZE OFF OF STACK
7114 030426 012603 MOV (SP)+,R3 ;RESTORE R3
7115 030430 012604 MOV (SP)+,R4 ;RESTORE R4
7116 030432 011505 MOV (R5),R5 ;GET RETURN ADDRESS
7117 030434 000205 RTS R5 ;RETURN
7118
7119 ;THIS ROUTINE WILL CONVERT A 16-BIT UNSIGNED BINARY NUMBER TO AN
7120 ;UNSIGNED DECIMAL ASCIZ NUMBER.
7121 ;CALL
7122 ; MOV NUMBER,-(SP) ;PUT THE NUMBER ON THE STACK
7123 ; JSR PC,$SB2D ;CALL

```

```

7124      ; RETURN ;ADDRESS OF THE 1ST ASCIZ CHAR IS ON THE STACK
7125      ;
7126      ;NOTE: THE PROGRAM REQUIRES THIS FORM OF '$SB2D', NOT THE VERSION ON
7127      ; THE SYSMAC LIBRARY, REV C AND LATER
7128
7129 030436 016637 000002 030462 $SB2D: MOV 2(SP),1$ ;SAVE THE BINARY NUMBER
7130 030444 012746 030462 MOV #1$,-(SP) ;SET THE POINTER
7131 030450 004737 034050 JSR PC,$DB2D ;CALL THE DOUBLE LENGTH CONVERT
7132 030454 012666 000002 MOV (SP)+,2(SP) ;PICKUP THE POINTER
7133 030460 000207 RTS PC ;RETURN
7134 030462 000000 000000 1$: .WORD 0,0
7135
7136      ;THIS ROUTINE WILL CONVERT A 16-BIT UNSIGNED BINARY NUMBER TO AN
7137      ;UNSIGNED OCTAL ASCIZ NUMBER.
7138      ;CALL
7139      ; MOV NUMBER,-(SP) ;PUT THE NUMBER ON THE STACK
7140      ; JSR PC,$SB2D ;CALL
7141      ; RETURN ;ADDRESS OF THE 1ST ASCIZ CHAR IS ON THE STACK
7142
7143      ;NOTE: THE PROGRAM REQUIRES THIS FORM OF '$SB20', NOT THE VERSION ON
7144      ; THE SYSMAC LIBRARY, REV C AND LATER
7145
7146 030466 016637 000002 030512 $SB20: MOV 2(SP),1$ ;SAVE THE BINARY NUMBER
7147 030474 012746 030512 MOV #1$,-(SP) ;SET THE POINTER
7148 030500 004737 034244 JSR PC,$DB20 ;CALL THE DOUBLE LENGTH CONVERT
7149 030504 012666 000002 MOV (SP)+,2(SP) ;PICKUP THE POINTER
7150 030510 000207 RTS PC ;RETURN
7151 030512 000000 000000 1$: .WORD 0,0
7152
7153      ;KEYBOARD INTERRUPT INITIALIZATION ROUTINE
7154      ;CALL
7155      ; JSR PC,$TKINT
7156      ; RETURN
7157
7158 030516 012737 030546 000060 $TKINT: MOV #STKSRV,TKVEC ;SETUP VECTOR
7159 030524 012737 000100 000062 MOV #100,TKVEC+2 ;PRIORITY TO 4
7160 030532 005777 150424 TST #STKB ;CLEAR THE BUFFER
7161 030536 012777 000100 150414 MOV #BIT06,$STKS ;SET INTERRUPT ENABLE
7162 030544 000207 RTS PC ;RETURN
7163
7164      ;KEYBOARD INTERRUPT SERVICE ROUTINE
7165      ;CALL
7166      ; ENTER VIA INTERRUPT
7167
7168 030546 104410 $TKSRV: RDCHR ;READ THE KEYBOARD
7169 030550 112637 030676 MOVB (SP)+,5$ ;GET THE CHARACTER
7170 030554 023727 030676 000003 CMP 5$,#3 ;'CONTROL C' ?
7171 030562 001012 BNE 1$ ;BR IF NOT
7172 030564 104401 001201 TYPE ,%SCLF ;CR-LF
7173 030570 104401 031170 TYPE ,%SCNTLC ;'tC'
7174 030574 012737 177777 001360 MOV #-1,CFLAG ;SET THE 'CONTROL C' FLAG
7175 030602 005077 150352 CLR $STKS ;CLEAR THE TTY INTERRUPT
7176 030606 000432 BR 4$ ;EXIT
7177 030610 023727 001154 000176 1$: CMP SWR,#SWREG ;SOFTWARE SWITCH REGISTER IN USE ?
7178 030616 001024 BNE 3$ ;BR IF NOT
7179 030620 023727 030676 000007 CMP 5$,#7 ;'CONTROL G' ?

```

7180	030626	001020			BNE	3\$		;BR IF NOT
7181	030630	104401	001201		TYPE	,SCRLF		;CR-LF
7182	030634	104401	033623		TYPE	,SCNTLG		; 'IG'
7183	030640	013746	177776		MOV	PS, -(SP)		;PUT THE STATUS WORD ON THE STACK
7184	030644	012746	030660		MOV	#2\$, -(SP)		;RETURN ADDRESS
7185	030650	005077	150304		CLR	@STKS		;CLEAR THE TTY INTERRUPT ENABLE
7186	030654	000137	033264		JMP	\$GTSWR		;GET THE SWITCH REGISTER ENTRY
7187	030660	012777	000100	150272	MOV	#100, @STKS	2\$:	;ENABLE TTY KEYBOARD INTERRUPT
7188	030666	000402			BR	4\$		;EXIT
7189	030670	104401	030676		TYPE	,5\$	3\$:	;ECHO THE CHARACTER
7190	030674	000002			RTI		4\$:	;RETURN
7191								
7192	030676	000000				.WORD 0	5\$:	;ENTERED CHARACTER
7193								
7194								;THIS ROUTINE WILL INPUT A STRING FROM THE TTY
7195								;CALL:
7196						RDLIN		;: INPUT A STRING FROM THE TTY
7197						RETURN HERE		;ADDRESS OF FIRST CHARACTER WILL BE ON THE STACK
7198								;TERMINATOR WILL BE A BYTE OF ALL 0'S
7199								
7200	030700	010346			\$RDLIN: MOV	R3, -(SP)		;SAVE R3
7201	030702	005046			CLR	-(SP)		;CLEAR THE RUBOUT KEY
7202	030704	012703	031156		MOV	#STTYIN, R3	1\$:	;GET ADDRESS
7203	030710	022703	031170		CMP	#STTYIN+10., R3	2\$:	;BUFFER FULL?
7204	030714	101467			BLOS	4\$		;BR IF YES
7205	030716	104410			RDCHR			;GO READ ONE CHARACTER FROM THE TTY
7206	030720	112613			MOVB	(SP)+, (R3)		;GET CHARACTER
7207	030722	122713	000177		CMPB	#177, (R3)		;IS IT A RUBOUT
7208	030726	001022			BNE	5\$		;BR IF NO
7209	030730	005716			TST	(SP)		;IS THIS THE FIRST RUBOUT?
7210	030732	001007			BNE	6\$		;BR IF NO
7211	030734	112737	000134	031154	MOVB	#'\, 9\$		;TYPE A BACK SLASH
7212	030742	104401	031154		TYPE	9\$		
7213	030746	012716	177777		MOV	#-1, (SP)		;SET THE RUBOUT KEY
7214	030752	005303			R3	DEC	R3	;BACKUP BY ONE
7215	030754	020327	031156		CMP	R3, #STTYIN	6\$:	;STACK EMPTY?
7216	030760	103445			BLO	4\$		;BR IF YES
7217	030762	111337	031154		MOVB	(R3), 9\$		;SETUP TO TYPEOUT THE DELETED CHAR.
7218	030766	104401	031154		TYPE	9\$		;GO TYPE
7219	030772	000746			BR	2\$		;GO READ ANOTHER CHAR.
7220	030774	005716			TST	(SP)	5\$:	;RUBOUT KEY SET?
7221	030776	001406			BEQ	7\$		;BR IF NO
7222	031000	112737	000134	031154	MOVB	#'\, 9\$		;TYPE A BACK SLASH
7223	031006	104401	031154		TYPE	9\$		
7224	031012	005016			CLR	(SP)		;CLEAR THE RUBOUT KEY
7225	031014	122713	000025		CMPB	#25, (R3)	7\$:	;IS CHARACTER A CTRL U?
7226	031020	001003			BNE	10\$		;BR IF NO
7227	031022	104401	033616		TYPE	,SCNTLU		;TYPE A CONTROL "U"
7228	031026	000726			BR	1\$		;GO START OVER
7229	031030	122713	000003		CMPB	#3, (R3)	10\$:	;IS CHARACTER A CTRL C ?
7230	031034	001006			BNE	8\$		;BR IF NOT
7231	031036	012737	177777	001360	MOV	#-1, CFLAG		;SET CNTRL C FLAG
7232	031044	104401	031170		TYPE	,SCNTLC		;ECHO IT
7233	031050	000427			BR	11\$		;EXIT
7234	031052	122713	000012		CMPB	#12, (R3)	8\$:	;IS CHARACTER A "LF"?
7235	031056	001011			BNE	3\$		;BRANCH IF NO



```

7236 031060 105013          CLRAB      (R3)          ;CLEAR THE CHARACTER
7237 031062 104401 001201  TYPE      ,SCLF        ;TYPE A "CR" & "LF"
7238 031066 104401 031156  TYPE      ,STTYIN       ;TYPE THE INPUT STRING
7239 031072 000706          BR          2$          ;GO PICKUP ANOTHER CHAETER
7240 031074 104401 001200  4$:      TYPE      $QUES        ;TYPE A '?'
7241 031100 000701          BR          1$          ;CLEAR THE BUFFER AND LOOP
7242 031102 111337 031154  3$:      MOVAB   (R3),9$      ;ECHO THE CHARACTER
7243 031106 104401 031154  TYPE      9$
7244 031112 122723 000015  CMPAB   15,(R3)+      ;CHECK FOR RETURN
7245 031116 001274          BNE      2$          ;LOOP IF NOT RETURN
7246 031120 105063 177777  CLRAB   -1(R3)       ;CLEAR RETURN (THE 15)
7247 031124 104401 001202  TYPE      $LF         ;TYPE A LINE FEED
7248 031130 005726          11$:     TST      (SP)+        ;CLEAN RUBOUT KEY FROM THE STACK
7249 031132 012603          MOV      (SP)+,R3     ;RESTORE R3
7250 031134 011646          MOV      (SP)-,(SP)   ;ADJUST THE STACK AND PUT ADDRESS OF THE
7251 031136 016666 000004 000002  MOV      4(SP),2(SP)  ;FIRST ASCII CHARACTER ON IT
7252 031144 012766 031156 000004  MOV      #STTYIN,4(SP)
7253 031152 000002          RTI
7254 031154          9$:      .BYTE   0          ;RETURN
7255 031155          .BYTE   0          ;STORAGE FOR ASCII CHAR. TO TYPE
7256 031156 000012          $TTYIN: .BLKB  10.   ;TERMINATOR
7257 031170 041536 005015 000  $CNTLC: .ASCIZ  /↑C/<CR><LF> ;RESERVE 10 BYTES FOR TTY INPUT
7258                                     ;CONTROL "C"
7259                                     .EVEN
7260
7261
7262
7263 ;*****
7264
7265 .SBTTL  MACRO ROUTINES
7266
7267 .SBTTL  ERROR HANDLER ROUTINE
7268
7269 ;*****
7270 ;*THIS ROUTINE WILL INCREMENT THE ERROR FLAG AND THE ERROR COUNT,
7271 ;*SAVE THE ERROR ITEM NUMBER AND THE ADDRESS OF THE ERROR CALL
7272 ;*AND GO TO SERRTYP ON ERROR
7273 ;*THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
7274 ;*SW15=1      HALT ON ERROR
7275 ;*SW13=1      INHIBIT ERROR TYPEOUTS
7276 ;*SW10=1     BELL ON ERROR
7277 ;*CALL
7278 ;*      ERROR  N      ;;ERROR=EMT AND N=ERROR ITEM NUMBER
7279
7280 $ERROR:
7281 031176 104407          CKSWR
7282 031200 010337 001342  MOV      R3,ATTN     ;:TEST FOR CHANGE IN SOFT-SWR
7283 031204 010137 001216  MOV      R1,DRIVE    ;:SAVE THE ATTENTION REGISTER CONTENTS
7284 031210 032777 020000 147736  BIT      #SW13,@SWR  ;:DRIVE NUMBER
7285 031216 001002          BNE      +6          ;:INHIBIT PRINTOUTS ?
7286 031220 004737 023670  JSR      PC,$TIME    ;:BR IF YES
7287 031224 105237 001117  7$:      INCB   $ERFLG   ;:TYPE THE TIME
7288 031230 001775          BEQ      7$          ;:SET THE ERROR FLAG
7289 031232 013777 001116 147716  MOV      $STNM,@DISPLAY ;:DON'T LET THE FLAG GO TO ZERO
7290 031240 032777 002000 147706  BIT      #BIT10,@SWR  ;:DISPLAY TEST NUMBER AND ERROR FLAG
7291 031246 001402          BEQ      1$          ;:BELL ON ERROR?
                                     ;:NO - SKIP

```

```

7292 031250 104401 001174
7293 031254 005237 001126
7294 031260 011637 001132
7295 031264 162737 000002 001132
7296 031272 117737 147634 001130
7297 031300 032777 020000 147646
7298 031306 001004
7299 031310 004737 031362
7300 031314 104401 001201
7301 031320
7302 031320 122737 000001 001224
7303 031326 001007
7304 031330 113737 001130 031342
7305 031336 004737 032016
7306 031342 000
7307 031343 000
7308 031344 000777
7309 031346 005777 147602
7310 031352 100002
7311 031354 000000
7312 031356 104407
7313 031360
7314 031360 000002
7315
7316
7317
7318
7319
7320
7321
7322
7323 031362
7324 031362 104401 001201
7325 031366 010046
7326 031370 005000
7327 031372 153700 001130
7328 031376 001004
7329
7330 031400 013746 001132
7331
7332 031404 104402
7333 031406 000426
7334 031410 005300
7335 031412 006300
7336 031414 006300
7337 031416 006300
7338 031420 062700 003542
7339 031424 012037 031434
7340 031430 001404
7341 031432 104401
7342 031434 000000
7343 031436 104401 001201
7344 031442 012037 031452
7345 031446 001404
7346 031450 104401
7347 031452 000000

```

```

TYPE $BELL ;; RING BELL
1$: INC $ERTTL ;; COUNT THE NUMBER OF ERRORS
MOV (SP), $ERRPC ;; GET ADDRESS OF ERROR INSTRUCTION
SUB #2, $ERRPC
MOVB @ $ERRPC, $ITEMB ;; STRIP AND SAVE THE ERROR ITEM CODE
BIT #BIT13, @SWR ;; SKIP TYPEOUT IF SET
BNE 20$ ;; SKIP TYPEOUTS
JSR PC, $ERRTYP ;; GO TO USER ERROR ROUTINE
TYPE , $CRLF

20$: CMPB #APTENV, $ENV ;; RUNNING IN APT MODE
BNE 2$ ;; NO SKIP APT ERROR REPORT
MOVB $ITEMB, 21$ ;; SET ITEM NUMBER AS ERROR NUMBER
JSR PC, $ATY4 ;; REPORT FATAL ERROR TO APT

21$: .BYTE 0
.BYTE 0

22$: BR 22$ ;; APT ERROR LOOP
2$: TST @SWR ;; HALT ON ERROR
BPL 3$ ;; SKIP IF CONTINUE
HALT ;; HALT ON ERROR!
CKSWR ;; TEST FOR CHANGE IN SOFT-SWR

3$: RTI ;; RETURN

.SBTTL ERROR MESSAGE TYPEOUT ROUTINE
;*****
;THIS ROUTINE USES THE "ITEM CONTROL BYTE" ($ITEMB) TO DETERMINE WHICH
;ERROR IS TO BE REPORTED. IT THEN OBTAINS, FROM THE "ERROR TABLE" ($ERRTB),
;AND REPORTS THE APPROPRIATE INFORMATION CONCERNING THE ERROR.
$ERRTYP:
TYPE , $CRLF ;; "CARRIAGE RETURN" & "LINE FEED"
MOV RO, -(SP) ;; SAVE RO
CLR RO ;; PICKUP THE ITEM INDEX
BISB @ $ITEMB, RO
BNE 1$ ;; IF ITEM NUMBER IS ZERO, JUST
MOV $ERRPC, -(SP) ;; TYPE THE PC OF THE ERROR
;; SAVE $ERRPC FOR TYPEOUT
;; ERROR ADDRESS
;; GO TYPE--OCTAL ASCII(ALL DIGITS)
BR 6$ ;; GET OUT
1$: DEC RO ;; ADJUST THE INDEX SO THAT IT WILL
ASL RO ;; WORK FOR THE ERROR TABLE
ASL RO
ASL RO
ADD # $ERRTB, RO ;; FORM TABLE POINTER
MOV (RO)+, 2$ ;; PICKUP "ERROR MESSAGE" POINTER
BEQ 3$ ;; SKIP TYPEOUT IF NO POINTER
TYPE "ERROR MESSAGE" ;; TYPE THE "ERROR MESSAGE"
;; "ERROR MESSAGE" POINTER GOES HERE
TYPE , $CRLF ;; "CARRIAGE RETURN" & "LINE FEED"
MOV (RO)+, 4$ ;; PICKUP "DATA HEADER" POINTER
BEQ 5$ ;; SKIP TYPEOUT IF 0
TYPE "DATA HEADER" ;; TYPE THE "DATA HEADER"
4$: .WORD 0 ;; "DATA HEADER" POINTER GOES HERE

```

7348 031454 104401 001201  
 7349 031460 011000  
 7350 031462 001004  
 7351 031464 012600  
 7352 031466 104401 001201  
 7353 031472 000207  
 7354 031474  
 7355 031474 013046  
 7356 031476 104402  
 7357 031500 005710  
 7358 031502 001770  
 7359 031504 104401 031512  
 7360 031510 000771  
 7361 031512 020040 000  
 7362 031516  
 7363  
 7364  
 7365  
 7366  
 7367  
 7368  
 7369  
 7370  
 7371  
 7372  
 7373  
 7374  
 7375  
 7376  
 7377  
 7378  
 7379  
 7380  
 7381 031516 105737 001173  
 7382 031522 100002  
 7383 031524 000000  
 7384 031526 000430  
 7385 031530 010046  
 7386 031532 017600 000002  
 7387 031536 122737 000001 001224  
 7388 031544 001011  
 7389 031546 132737 000100 001225  
 7390 031554 001405  
 7391 031556 010037 031566  
 7392 031562 004737 032006  
 7393 031566 000000  
 7394 031570 132737 000040 001225  
 7395 031576 001003  
 7396 031600 112046  
 7397 031602 001005  
 7398 031604 005726  
 7399 031606 012600  
 7400 031610 062716 000002  
 7401 031614 000002  
 7402 031616 122716 000011  
 7403 031622 001430

```

TYPE ,SCRLF ;:"CARRIAGE RETURN" & "LINE FEED"
5$: MOV (RO),RO ;: PICKUP "DATA TABLE" POINTER
   BNE 7$ ;: GO TYPE THE DATA
6$: MOV (SP)+,RO ;: RESTORE RO
   TYPE ,SCRLF ;:"CARRIAGE RETURN" & "LINE FEED"
   RTS PC ;: RETURN
7$: MOV 2(RO)+,-(SP) ;: SAVE 2(RO)+ FOR TYPEOUT
   TYPOC ;: GO TYPE--OCTAL ASCII(ALL DIGITS)
   TST (RO) ;: IS THERE ANOTHER NUMBER?
   BEQ 6$ ;: BR IF NO
   TYPE 8$ ;: TYPE TWO(2) SPACES
   BR 7$ ;: LOOP
8$: .ASCIZ / / ;: TWO(2) SPACES
   .EVEN

```

.SBTTL TYPE ROUTINE

```

;:*****
;:ROUTINE TO TYPE ASCIZ MESSAGE. MESSAGE MUST TERMINATE WITH A 0 BYTE.
;:THE ROUTINE WILL INSERT A NUMBER OF NULL CHARACTERS AFTER A LINE FEED.
;:NOTE1: $NULL CONTAINS THE CHARACTER TO BE USED AS THE FILLER CHARACTER.
;:NOTE2: $FILLS CONTAINS THE NUMBER OF FILLER CHARACTERS REQUIRED.
;:NOTE3: $FILLC CONTAINS THE CHARACTER TO FILL AFTER.
;:
;:CALL:
;:1) USING A TRAP INSTRUCTION
;: * TYPE ,MESADR ;:MESADR IS FIRST ADDRESS OF AN ASCIZ STRING
;:OR
;: * TYPE
;: * MESADR
;:

```

```

$TYPE: TSTB $TFPLG ;: IS THERE A TERMINAL?
        BPL 1$ ;: BR IF YES
        HALT ;: HALT HERE IF NO TERMINAL
        BR 3$ ;: LEAVE
1$: MOV RO,-(SP) ;: SAVE RO
   MOV 2(SP),RO ;: GET ADDRESS OF ASCIZ STRING
   CMPB #APTENV,$ENV ;: RUNNING IN APT MODE
   BNE 62$ ;: NO GO CHECK FOR APT CONSOLE
   BITB #APTPOOL,$ENVM ;: SPOOL MESSAGE TO APT
   BEQ 62$ ;: NO GO CHECK FOR CONSOLE
   MOV RO,61$ ;: SETUP MESSAGE ADDRESS FOR APT
   JSR PC,$ATY3 ;: SPOOL MESSAGE TO APT
   .WORD 0 ;: MESSAGE ADDRESS
62$: BITB #APTCSUP,$ENVM ;: APT CONSOLE SUPPRESSED
   BNE 60$ ;: YES, SKIP TYPE OUT
   MOVB (RO)+,-(SP) ;: PUSH CHARACTER TO BE TYPED ONTO STACK
   BNE 4$ ;: BR IF IT ISN'T THE TERMINATOR
   TST (SP)+ ;: IF TERMINATOR POP IT OFF THE STACK
60$: MOV (SP)+,RO ;: RESTORE RO
3$: ADD #2,(SP) ;: ADJUST RETURN PC
   RTI ;: RETURN
4$: CMPB #HT,(SP) ;: BRANCH IF <HT>
   BEQ 8$

```

```

7404 031624 122716 000200      CMPB    #CRLF,(SP)      ;;BRANCH IF NOT <CRLF>
7405 031630 001006              BNE     5$              ;;
7406 031632 005726              TST     (SP)+           ;;POP <CR><LF> EQUIV
7407 031634 104401              TYPE                    ;;TYPE A CR AND LF
7408 031636 001201              $CRLF
7409 031640 105037 031774      CLRB    $CHARCNT       ;;CLEAR CHARACTER COUNT
7410 031644 000755              BR      2$              ;;GET NEXT CHARACTER
7411 031646 004737 031730      5$:    JSR    PC,$TYPEC   ;;GO TYPE THIS CHARACTER
7412 031652 123726 001172      6$:    CMPB    $FILLC,(SP)+ ;;IS IT TIME FOR FILLER CHARS.?
7413 031656 001350              BNE     2$              ;;IF NO GO GET NEXT CHAR.
7414 031660 013746 001170      MOV     $NULL,-(SP)    ;;GET # OF FILLER CHARS. NEEDED
7415                                ;;AND THE NULL CHAR.
7416 031664 105366 000001      7$:    DECIB  1(SP)      ;;DOES A NULL NEED TO BE TYPED?
7417 031670 002770              BLT     6$              ;;BR IF NO--GO POP THE NULL OFF OF STACK
7418 031672 004737 031730      JSR    PC,$TYPEC   ;;GO TYPE A NULL
7419 031676 105337 031774      DECIB  $CHARCNT      ;;DO NOT COUNT AS A COUNT
7420 031702 000770              BR      7$              ;;LOOP

```

;HORIZONTAL TAB PROCESSOR

```

7421
7422
7423
7424 031704 112716 000040      8$:    MOVB    #' (SP)    ;;REPLACE TAB WITH SPACE
7425 031710 004737 031730      9$:    JSR    PC,$TYPEC   ;;TYPE A SPACE
7426 031714 132737 000007 031774      BITB    #7,$CHARCNT   ;;BRANCH IF NOT AT
7427 031722 001372              BNE     9$              ;;TAB STOP
7428 031724 005726              TST     (SP)+           ;;POP SPACE OFF STACK
7429 031726 000724              BR      2$              ;;GET NEXT CHARACTER
7430 031730 105777 147230      $TYPEC: TSTB    $STPS        ;;WAIT UNTIL PRINTER IS READY
7431 031734 100375              BPL     $TYPEC
7432 031736 116677 000002 147222      MOVB    2(SP), $STPB   ;;LOAD CHAR TO BE TYPED INTO DATA REG.
7433 031744 122766 000015 000002      CMPB    #CR,2(SP)     ;;IS CHARACTER A CARRIAGE RETURN?
7434 031752 001003              BNE     1$              ;;BRANCH IF NO
7435 031754 105037 031774      CLRB    $CHARCNT     ;;YES--CLEAR CHARACTER COUNT
7436 031760 000406              BR      $TYPEX
7437 031762 122766 000012 000002 1$:    CMPB    #LF,2(SP)     ;;IS CHARACTER A LINE FEED?
7438 031770 001402              BEQ     $TYPEX         ;;BRANCH IF YES
7439 031772 105227              INCB   (PC)+          ;;COUNT THE CHARACTER
7440 031774 000000      $CHARCNT: .WORD 0    ;;CHARACTER COUNT STORAGE
7441 031776 000207      $TYPEX: RTS          PC
7442
7443
7444
7445

```

.SBTTL APT COMMUNICATIONS ROUTINE

```

7446
7447 032000 112737 000001 032244  $ATY1: MOVB    #1,$FFLG    ;;TO REPORT FATAL ERROR
7448 032006 112737 000001 032242  $ATY3: MOVB    #1,$MFLG  ;;TO TYPE A MESSAGE
7449 032014 000403              BR      $ATYC
7450 032016 112737 000001 032244  $ATY4: MOVB    #1,$FFLG  ;;TO ONLY REPORT FATAL ERROR
7451 032024
7452 032024 010046              MOV     R0,-(SP)      ;;PUSH R0 ON STACK
7453 032026 010146              MOV     R1,-(SP)      ;;PUSH R1 ON STACK
7454 032030 105737 032242      TSTB    $MFLG        ;;SHOULD TYPE A MESSAGE?
7455 032034 001450              BEQ     5$            ;;IF NOT: BR
7456 032036 122737 000001 001224      CMPB    #APTENV,$ENV  ;;OPERATING UNDER APT?
7457 032044 001031              BNE     3$            ;;IF NOT: BR
7458 032046 132737 000100 001225      BITB    #APTSPOOL,$ENVM ;;SHOULD SPOOL MESSAGES?
7459 032054 001425              BEQ     3$            ;;IF NOT: BR

```

```

7460 032056 017600 000004      MOV      24(SP),RO      ;; GET MESSAGE ADDR.
7461 032062 062766 000002 000004  ADD      #2,4(SP)      ;; BUMP RETURN ADDR.
7462 032070 005737 001204      1$: TST     $MSGTYPE    ;; SEE IF DONE W/ LAST XMISSION?
7463 032074 001375                BNE     1$            ;; IF NOT: WAIT
7464 032076 010037 001220      MOV     RO,$MSGAD     ;; PUT ADDR IN MAILBOX
7465 032102 105720      2$: TSTB   (RO)+        ;; FIND END OF MESSAGE
7466 032104 001376                BNE     2$
7467 032106 163700 001220      SUB     $MSGAD,RO     ;; SUB START OF MESSAGE
7468 032112 006200                ASR     RO            ;; GET MESSAGE LNTH IN WORDS
7469 032114 010037 001222      MOV     RO,$MSGGLT   ;; PUT LENGTH IN MAILBOX
7470 032120 012737 000004 001204  MOV     #4,$MSGTYPE   ;; TELL APT TO TAKE MSG.
7471 032126 000413                BR      5$
7472 032130 017637 000004 032154 3$: MOV     24(SP),4$    ;; PUT MSG ADDR IN JSR LINKAGE
7473 032136 062766 000002 000004  ADD     #2,4(SP)      ;; BUMP RETURN ADDRESS
7474 032144 013746 177776      MOV     177776,-(SP)  ;; PUSH 177776 ON STACK
7475 032150 004737 031516      JSR    PC,$TYPE      ;; CALL TYPE MACRO
7476 032154 000000      4$: .WORD 0
7477 032156                5$:
7478 032156 105737 032244      10$: TSTB   $FFLG      ;; SHOULD REPORT FATAL ERROR?
7479 032162 001416                BEQ     12$          ;; IF NOT: BR
7480 032164 005737 001224      TST     $ENV         ;; RUNNING UNDER APT?
7481 032170 001413                BEQ     12$          ;; IF NOT: BR
7482 032172 005737 001204      11$: TST     $MSGTYPE   ;; FINISHED LAST MESSAGE?
7483 032176 001375                BNE     11$         ;; IF NOT: WAIT
7484 032200 017637 000004 001206  MOV     24(SP),$FATAL ;; GET ERROR #
7485 032206 062766 000002 000004  ADD     #2,4(SP)      ;; BUMP RETURN ADDR.
7486 032214 005237 001204      INC     $MSGTYPE     ;; TELL APT TO TAKE ERROR
7487 032220 105037 032244      12$: CLRB   $FFLG      ;; CLEAR FATAL FLAG
7488 032224 105037 032243      CLRB   $LFLG        ;; CLEAR LOG FLAG
7489 032230 105037 032242      CLRB   $MFLG        ;; CLEAR MESSAGE FLAG
7490 032234 012601      MOV     (SP)+,R1     ;; POP STACK INTO R1
7491 032236 012600      MOV     (SP)+,RO     ;; POP STACK INTO RO
7492 032240 000207      RTS    PC           ;; RETURN
7493 032242 000      $MFLG: .BYTE 0      ;; MESSG. FLAG
7494 032243 000      $LFLG: .BYTE 0      ;; LOG FLAG
7495 032244 000      $FFLG: .BYTE 0      ;; FATAL FLAG
7496 032246      .EVEN
7497 000200      APTSIZE=200
7498 000001      APTENV=001
7499 000100      APTSPool=100
7500 000040      APTCSUP=040

```

.SBTTL POWER DOWN AND UP ROUTINES

```

7501
7502
7503
7504
7505 *****
7506 032246 012737 032412 000024 $PWRDN: MOV     #SILLUP,2#PWRVEC ;; SET FOR FAST UP
7507 032254 012737 000340 000026  MOV     #340,2#PWRVEC+2 ;; PRIO:7
7508 032262 010046      MOV     RO,-(SP)     ;; PUSH RO ON STACK
7509 032264 010146      MOV     R1,-(SP)    ;; PUSH R1 ON STACK
7510 032266 010246      MOV     R2,-(SP)    ;; PUSH R2 ON STACK
7511 032270 010346      MOV     R3,-(SP)    ;; PUSH R3 ON STACK
7512 032272 010446      MOV     R4,-(SP)    ;; PUSH R4 ON STACK
7513 032274 010546      MOV     R5,-(SP)    ;; PUSH R5 ON STACK
7514 032276 017746 146652      MOV     2$SWR,-(SP) ;; PUSH 2$SWR ON STACK
7515 032302 010637 032416      MOV     SP,$SAVR6   ;; SAVE SP

```

```

7516 032306 012737 032320 000024      MOV      #SPWRUP,@PWRVEC ;;SET UP VECTOR
7517 032314 000000                      HALT
7518 032316 000776                      BR       .-2                ;;HANG UP
7519
7520                                     ;:*****
7521                                     ;:POWER UP ROUTINE
7522 032320 012737 032412 000024 $PWRUP: MOV      #SILLUP,@PWRVEC ;;SET FOR FAST DOWN
7523 032326 013706 032416                      MOV      $SAVR6,SP        ;;GET SP
7524 032332 005037 032416                      CLR      $SAVR6          ;;WAIT LOOP FOR THE TTY
7525 032336 005237 032416 1$: INC      $SAVR6          ;;WAIT FOR THE INC
7526 032342 001375                      BNE     1$              ;;OF WORD
7527 032344 012677 146604                      MOV      (SP)+,@SWR      ;;POP STACK INTO @SWR
7528 032350 012605                      MOV      (SP)+,R5       ;;POP STACK INTO R5
7529 032352 012604                      MOV      (SP)+,R4       ;;POP STACK INTO R4
7530 032354 012603                      MOV      (SP)+,R3       ;;POP STACK INTO R3
7531 032356 012602                      MOV      (SP)+,R2       ;;POP STACK INTO R2
7532 032360 012601                      MOV      (SP)+,R1       ;;POP STACK INTO R1
7533 032362 012600                      MOV      (SP)+,R0       ;;POP STACK INTO R0
7534 032364 012737 032246 000024      MOV      #SPWRDN,@PWRVEC ;;SET UP THE POWER DOWN VECTOR
7535 032372 012737 000340 000026      MOV      #340,@PWRVEC+2 ;;PRIO:7
7536 032400 104401                      TYPE
7537 032402 032420 SPWRMG: .WORD  $POWER      ;;REPORT THE POWER FAILURE
7538 032404 012716                      MOV      (PC)+,(SP)     ;;POWER FAIL MESSAGE POINTER
7539 032406 032430 SPWRAD: .WORD  SATPOW     ;;RESTART AT SATPOW
7540 032410 000002                      RTI
7541 032412 000000 SPILLUP: HALT          ;;THE POWER UP SEQUENCE WAS STARTED
7542 032414 000776                      BR       .-2            ;;BEFORE THE POWER DOWN WAS COMPLETE
7543 032416 000000 $SAVR6: 0              ;;PUT THE SP HERE
7544 032420 005015 047520 042527 $POWER: .ASCIZ  <15><12>"POWER"
7545 032426 000122                      .EVEN
7546
7547
7548                                     ;:POW UP ROUTINE  WAIT
7549                                     ;:FIVE MINUTS, THEN AUTO STARTS AT SETVEC
7550
7551 032430 000005 SATPOW: RESET          ;;CLEAR THE BUS
7552 032432 005037 177776                      CLR      @#PS           ;;CLEAR PSW
7553 032436 005037 001364                      CLR      HOUR          ;;RESET THE HOUR COUNT
7554 032442 005037 001366                      CLR      MINUTE        ;;RESET THE MINUTS COUNT
7555 032446 005037 001370                      CLR      SECOND        ;;RESET THE SECOND COUNT
7556 032452 005037 001470                      CLR      INTRVL+2      ;;RESET THE INTERVAL COUNT
7557 032456 004737 022632                      JSR      PC,CKCLK      ;;CHECK THE CLOCK
7558 032462 022737 000005 001470 1$: CMP      #5,INTRVL+2    ;;FIVE MINUTES YET ?
7559 032470 101374                      BHI     1$              ;;WAIT IF NOT
7560 032472 005037 001470                      CLR      INTRVL+2      ;;RESET INTERVAL COUNT
7561 032476 005037 001370                      CLR      SECOND        ;;RESET TIMER
7562 032502 005037 001366                      CLR      MINUTE
7563 032506 012737 000400 001356      MOV      #400,CHGADR   ;;FORGE THE AUTO START
7564 032514 012705 001522                      MOV      #ORDERQ,R5    ;;CLEAR UP THE QUEUE AND BUFFER
7565 032520 005025 002102 2$: CLR      (R5)+
7566 032522 022705                      CMP      #BLKADR,R5    ;;ALL DONE ?
7567 032526 001374                      BNE     2$              ;;BRANCH IF NOT
7568 032530 012737 007070 001264      MOV      #7070,$CDW1   ;;FLAG FROM POWER FAIL
7569 032536 000137 004410                      JMP
7570
7571

```

.SBTTL BINARY TO OCTAL (ASCII) AND TYPE

7572  
7573  
7574  
7575  
7576  
7577  
7578  
7579  
7580  
7581  
7582  
7583  
7584  
7585  
7586  
7587  
7588  
7589  
7590  
7591  
7592  
7593  
7594  
7595  
7596  
7597  
7598  
7599  
7600  
7601  
7602  
7603  
7604  
7605  
7606  
7607  
7608  
7609  
7610  
7611  
7612  
7613  
7614  
7615  
7616  
7617  
7618  
7619  
7620  
7621  
7622  
7623  
7624  
7625  
7626  
7627

032542 017646 000000  
032546 116637 000001 032765  
032554 112637 032767  
032560 062716 000002  
032564 000406  
032566 112737 000001 032765  
032574 112737 000006 032767  
032602 112737 000005 032764  
032610 010346  
032612 010446  
032614 010546  
032616 113704 032767  
032622 005404  
032624 062704 000006  
032630 110437 032766  
032634 113704 032765  
032640 016605 000012  
032644 005003  
032646 006105  
032650 000404  
032652 006105  
032654 006105  
032656 006105  
032660 010503  
032662 006103  
032664 105337 032766  
032670 100016  
032672 042703 177770  
032676 001002  
032700 005704  
032702 001403

```

*****
*THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 6-DIGIT
*OCTAL (ASCII) NUMBER AND TYPE IT.
*$TYPOS---ENTER HERE TO SETUP SUPPRESS ZEROS AND NUMBER OF DIGITS TO TYPE
*CALL:
*      MOV      NUM,-(SP)      ;;NUMBER TO BE TYPED
*      TYPOS    ;;CALL FOR TYPEOUT
*      .BYTE   N              ;;N=1 TO 6 FOR NUMBER OF DIGITS TO TYPE
*      .BYTE   M              ;;M=1 OR 0
*                               ;;1=TYPE LEADING ZEROS
*                               ;;0=SUPPRESS LEADING ZEROS
*$TYPON---ENTER HERE TO TYPE OUT WITH THE SAME PARAMETERS AS THE LAST
*$TYPOS OR $TYPOC
*CALL:
*      MOV      NUM,-(SP)      ;;NUMBER TO BE TYPED
*      TYPON    ;;CALL FOR TYPEOUT
*$TYPOC---ENTER HERE FOR TYPEOUT OF A 16 BIT NUMBER
*CALL:
*      MOV      NUM,-(SP)      ;;NUMBER TO BE TYPED
*      TYPOC    ;;CALL FOR TYPEOUT
*$TYPOS: MOV      2(SP),-(SP)    ;;PICKUP THE MODE
        MOV      1(SP),SOFILL    ;;LOAD ZERO FILL SWITCH
        MOV      (SP)+,SOMODE+1  ;;NUMBER OF DIGITS TO TYPE
        ADD     #2,(SP)          ;;ADJUST RETURN ADDRESS
        BR      $TYPON
*$TYPOC: MOV      #1,SOFILL     ;;SET THE ZERO FILL SWITCH
        MOV      #6,SOMODE+1    ;;SET FOR SIX(6) DIGITS
*$TYPON: MOV      #5,SOCNT      ;;SET THE ITERATION COUNT
        MOV      R3,-(SP)        ;;SAVE R3
        MOV      R4,-(SP)        ;;SAVE R4
        MOV      R5,-(SP)        ;;SAVE R5
        MOV      SOMODE+1,R4     ;;GET THE NUMBER OF DIGITS TO TYPE
        NEG     R4
        ADD     #6,R4           ;;SUBTRACT IT FOR MAX. ALLOWED
        MOV      R4,SOMODE      ;;SAVE IT FOR USE
        MOV      SOFILL,R4      ;;GET THE ZERO FILL SWITCH
        MOV      12(SP),R5      ;;PICKUP THE INPUT NUMBER
        CLR     R3              ;;CLEAR THE OUTPUT WORD
        ROL    R5               ;;ROTATE MSB INTO "C"
        BR     3$               ;;GO DO MSB
        ROL    R5               ;;FORM THIS DIGIT
        ROL    R5
        ROL    R5
        MOV     R5,R3
        ROL    R3               ;;GET LSB OF THIS DIGIT
        DECB   SOMODE           ;;TYPE THIS DIGIT?
        BPL    7$               ;;BR IF NO
        BIC    #177770,R3      ;;GET RID OF JUNK
        BNE    4$               ;;TEST FOR 0
        TST   R4               ;;SUPPRESS THIS 0?
        BEQ   5$               ;;BR IF YES

```

```

7628 032704 005204          4$: INC R4          ;; DON'T SUPPRESS ANYMORE 0'S
7629 032706 052703 000060  5$: BIS #'0,R3      ;; MAKE THIS DIGIT ASCII
7630 032712 052703 000040  5$: BIS #' R3       ;; MAKE ASCII IF NOT ALREADY
7631 032716 110337 032762  5$: MOVB R3,B$     ;; SAVE FOR TYPING
7632 032722 104401 032762  5$: TYPE B$        ;; GO TYPE THIS DIGIT
7633 032726 105337 032764  7$: DECB $OCNT     ;; COUNT BY 1
7634 032732 003347          7$: BGT 2$           ;; BR IF MORE TO DO
7635 032734 002402          7$: BLT 6$           ;; BR IF DONE
7636 032736 005204          7$: INC R4           ;; INSURE LAST DIGIT ISN'T A BLANK
7637 032740 000744          7$: BR 2$           ;; GO DO THE LAST DIGIT
7638 032742 012605 6$: MOV (SP)+,R5    ;; RESTORE R5
7639 032744 012604          6$: MOV (SP)+,R4    ;; RESTORE R4
7640 032746 012603          6$: MOV (SP)+,R3    ;; RESTORE R3
7641 032750 016666 000002 000004 6$: MOV 2(SP),4(SP) ;; SET THE STACK FOR RETURNING
7642 032756 012616          6$: MOV (SP)+,(SP)
7643 032760 000002          6$: RTI              ;; RETURN
7644 032762 000           8$: .BYTE 0          ;; STORAGE FOR ASCII DIGIT
7645 032763 000           8$: .BYTE 0          ;; TERMINATOR FOR TYPE ROUTINE
7646 032764 000           $OCNT: .BYTE 0       ;; OCTAL DIGIT COUNTER
7647 032765 000           $OFILL: .BYTE 0      ;; ZERO FILL SWITCH
7648 032766 000000          $OMODE: .WORD 0    ;; NUMBER OF DIGITS TO TYPE

.SBTTL CONVERT BINARY TO DECIMAL AND TYPE ROUTINE

;*****
;THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 5-DIGIT
;SIGNED DECIMAL (ASCII) NUMBER AND TYPE IT. DEPENDING ON WHETHER THE
;NUMBER IS POSITIVE OR NEGATIVE A SPACE OR A MINUS SIGN WILL BE TYPED
;BEFORE THE FIRST DIGIT OF THE NUMBER. LEADING ZEROS WILL ALWAYS BE
;REPLACED WITH SPACES.
;CALL:
;* MOV NUM,-(SP)          ;; PUT THE BINARY NUMBER ON THE STACK
;* TYPDS                ;; GO TO THE ROUTINE

$TYPDS:
MOV R0,-(SP)            ;; PUSH R0 ON STACK
MOV R1,-(SP)            ;; PUSH R1 ON STACK
MOV R2,-(SP)            ;; PUSH R2 ON STACK
MOV R3,-(SP)            ;; PUSH R3 ON STACK
MOV R5,-(SP)            ;; PUSH R5 ON STACK
MOV #20200,-(SP)        ;; SET BLANK SWITCH AND SIGN
MOV 20(SP),R5           ;; GET THE INPUT NUMBER
BPL 1$                 ;; BR IF INPUT IS POS.
NEG R5                  ;; MAKE THE BINARY NUMBER POS.
MOVB #'-,1(SP)         ;; MAKE THE ASCII NUMBER NEG.
CLR R0                  ;; ZERO THE CONSTANTS INDEX
MOV $DBLK,R3           ;; SETUP THE OUTPUT POINTER
MOVB #' ,(R3)+         ;; SET THE FIRST CHARACTER TO A BLANK
2$: CLR R2              ;; CLEAR THE BCD NUMBER
MOV $DTBL(R0),R1       ;; GET THE CONSTANT
3$: SUB R1,R5           ;; FORM THIS BCD DIGIT
BLT 4$                 ;; BR IF DONE
INC R2                 ;; INCREASE THE BCD DIGIT BY 1
4$: ADD R1,R5           ;; ADD BACK THE CONSTANT
TST R2                 ;; CHECK IF BCD DIGIT=0

```



```

7684 033060 001002      BNE      5$      ;; FALL THROUGH IF 0
7685 033062 105716      TSTB     (SP)    ;; STILL DOING LEADING 0'S?
7686 033064 100407      BMI      7$      ;; BR IF YES
7687 033066 106316      5$: ASLB     (SP)    ;; MSD?
7688 033070 103003      BCC      6$      ;; BR IF NO
7689 033072 116663 000001 177777  MOVB     1(SP),-1(R3) ;; YES--SET THE SIGN
7690 033100 052702 000060 6$: BIS     #'0,R2    ;; MAKE THE BCD DIGIT ASCII
7691 033104 052702 000040 7$: BIS     #' R2     ;; MAKE IT A SPACE IF NOT ALREADY A DIGIT
7692 033110 110223      MOVB     R2,R3)+  ;; PUT THIS CHARACTER IN THE OUTPUT BUFFER
7693 033112 005720      TST      (R0)+   ;; JUST INCREMENTING
7694 033114 020027 000010  CMP      R0,#10  ;; CHECK THE TABLE INDEX
7695 033120 002746      BLT      2$      ;; GO DO THE NEXT DIGIT
7696 033122 003002      BGT      8$      ;; GO TO EXIT
7697 033124 010502      MOV      R5,R2   ;; GET THE LSD
7698 033126 000764      BR       6$      ;; GO CHANGE TO ASCII
7699 033130 105726      8$: TSTB     (SP)+  ;; WAS THE LSD THE FIRST NON-ZERO?
7700 033132 100003      BPL      9$      ;; BR IF NO
7701 033134 116663 177777 177776  MOVB     -1(SP),-2(R3) ;; YES--SET THE SIGN FOR TYPING
7702 033142 105013      9$: CLRB     (R3)   ;; SET THE TERMINATOR
7703 033144 012605      MOV      (SP)+,R5 ;; POP STACK INTO R5
7704 033146 012603      MOV      (SP)+,R3 ;; POP STACK INTO R3
7705 033150 012602      MOV      (SP)+,R2 ;; POP STACK INTO R2
7706 033152 012601      MOV      (SP)+,R1 ;; POP STACK INTO R1
7707 033154 012600      MOV      (SP)+,R0 ;; POP STACK INTO R0
7708 033156 104401 033204  TYPE     $DBLK    ;; NOW TYPE THE NUMBER
7709 033162 016666 000002 000004  MOV      2(SP),4(SP) ;; ADJUST THE STACK
7710 033170 012616      MOV      (SP)+,(SP)
7711 033172 000002      RTI                      ;; RETURN TO USER
7712 033174 023420      $DTBL: 10000.
7713 033176 001750      1000.
7714 033200 000144      100.
7715 033202 000012      10.
7716 033204 000004      $DBLK: .BLKW 4
7717
7718      .SBTTL  TTY INPUT ROUTINE
7719
7720      ;; *****
7721      .ENABL  LSB
7722
7723      ;; *****
7724      ;; SOFTWARE SWITCH REGISTER CHANGE ROUTINE.
7725      ;; ROUTINE IS ENTERED FROM THE TRAP HANDLER, AND WILL
7726      ;; SERVICE THE TEST FOR CHANGE IN SOFTWARE SWITCH REGISTER TRAP CALL
7727      ;; WHEN OPERATING IN TTY FLAG MODE.
7728 033214 022737 000176 001154  $CKSWR: CMP      #SWREG,SWR  ;; IS THE SOFT-SWR SELECTED?
7729 033222 001074      BNE      15$     ;; BRANCH IF NO
7730 033224 105777 145730  TSTB     @STKS    ;; CHAR THERE?
7731 033230 100071      BPL      15$     ;; IF NO, DON'T WAIT AROUND
7732 033232 117746 145724  MOVB     @STKB,-(SP) ;; SAVE THE CHAR
7733 033236 042716 177600  BIC      #1C177,(SP) ;; STRIP-OFF THE ASCII
7734 033242 022726 000007  CMP      #7,(SP)+  ;; IS IT A CONTROL G?
7735 033246 001062      BNE      15$     ;; NO, RETURN TO USER
7736 033250 123727 001150 000001  CMPB     $AUTOB,#1 ;; ARE WE RUNNING IN AUTO-MODE?
7737 033256 001456      BEQ      15$     ;; BRANCH IF YES
7738
7739 033260 104401 033623  TYPE     ,SCNTLG  ;; ECHO THE CONTROL-G (↑G)

```

7740	033264	104401	033630		\$GTSWR: TYPE	\$MSWR	:: TYPE CURRENT CONTENTS
7741	033270	013746	000176		MOV	\$WREG, -(SP)	:: SAVE SWREG FOR TYPEOUT
7742	033274	104402			TYPOC		:: GO TYPE--OCTAL ASCII(ALL DIGITS)
7743	033276	104401	033641		TYPE	\$MNEW	:: PROMPT FOR NEW SWR
7744	033302	005046		19\$:	CLR	-(SP)	:: CLEAR COUNTER
7745	033304	005046			CLR	-(SP)	:: THE NEW SWR
7746	033306	105777	145646	7\$:	TSTB	\$STKS	:: CHAR THERE?
7747	033312	100375			BPL	7\$	:: IF NOT TRY AGAIN
7748							
7749	033314	117746	145642		MOVB	\$STKB, -(SP)	:: PICK UP CHAR
7750	033320	042716	177600		BIC	#1C177, (SP)	:: MAKE IT 7-BIT ASCII
7751							
7752							
7753							
7754	033324	021627	000025	9\$:	CMP	(SP), #25	:: IS IT A CONTROL-U?
7755	033330	001005			BNE	10\$	:: BRANCH IF NOT
7756	033332	104401	033616		TYPE	\$CNTLU	:: YES, ECHO CONTROL-U (↑U)
7757	033336	062706	000006	20\$:	ADD	#6 SP	:: IGNORE PREVIOUS INPUT
7758	033342	000757			BR	19\$	:: LET'S TRY IT AGAIN
7759							
7760							
7761	033344	021627	000015	10\$:	CMP	(SP), #15	:: IS IT A <CR>?
7762	033350	001022			BNE	16\$	:: BRANCH IF NO
7763	033352	005766	000004		TST	4(SP)	:: YES, IS IT THE FIRST CHAR?
7764	033356	001403			BEQ	11\$	:: BRANCH IF YES
7765	033360	016677	000002	145566	MOV	2(SP), \$SWR	:: SAVE NEW SWR
7766	033366	062706	000006		ADD	#6 SP	:: CLEAR UP STACK
7767	033372	104401	001201		TYPE	\$CRLF	:: ECHO <CR> AND <LF>
7768	033376	123727	001151	000001	CMPB	\$INTAG, #1	:: RE-ENABLE TTY KBD INTERRUPTS?
7769	033404	001003			BNE	15\$	:: BRANCH IF NOT
7770	033406	012777	000100	145544	MOV	#100, \$STKS	:: RE-ENABLE TTY KBD INTERRUPTS
7771	033414	000002			RTI		:: RETURN
7772	033416	004737	031730		JSR	PC, \$TYPEC	:: ECHO CHAR
7773	033422	021627	000060		CMP	(SP), #60	:: CHAR < 0?
7774	033426	002420			BLT	18\$	:: BRANCH IF YES
7775	033430	021627	000067		CMP	(SP), #67	:: CHAR > 7?
7776	033434	003015			BGT	18\$	:: BRANCH IF YES
7777	033436	042726	000060		BIC	#60 (SP)+	:: STRIP-OFF ASCII
7778	033442	005766	000002		TST	2(SP)	:: IS THIS THE FIRST CHAR
7779	033446	001403			BEQ	17\$	:: BRANCH IF YES
7780	033450	006316			ASL	(SP)	:: NO, SHIFT PRESENT
7781	033452	006316			ASL	(SP)	:: CHAR OVER TO MAKE
7782	033454	006316			ASL	(SP)	:: ROOM FOR NEW ONE.
7783	033456	005266	000002	17\$:	INC	2(SP)	:: KEEP COUNT OF CHAR
7784	033462	056616	177776		BIS	-2(SP), (SP)	:: SET IN NEW CHAR
7785	033466	000707			BR	7\$	:: GET THE NEXT ONE
7786	033470	104401	001200	18\$:	TYPE	\$QUES	:: TYPE ?<CR><LF>
7787	033474	000720			BR	20\$	:: SIMULATE CONTROL-U
7788					.DSABL	LSB	
7789							
7790							
7791							
7792							
7793							
7794							
7795							

\*\*\*\*\*  
 :: THIS ROUTINE WILL INPUT A SINGLE CHARACTER FROM THE TTY  
 :: \*CALL:  
 :: \* RDCHR :: INPUT A SINGLE CHARACTER FROM THE TTY  
 :: \* RETURN HERE :: CHARACTER IS ON THE STACK

```

7796 ;* ;:WITH PARITY BIT STRIPPED OFF
7797 ;
7798 ;
7799 033476 011646 $RDCHR: MOV (SP),-(SP) ;: PUSH DOWN THE PC
7800 033500 016666 000004 000002 MOV 4(SP),2(SP) ;: SAVE THE PS
7801 033506 105777 145446 1$: TSTB @STKS ;: WAIT FOR
7802 033512 100375 BPL 1$ ;: A CHARACTER
7803 033514 117766 145442 000004 MOVB @STKB,4(SP) ;: READ THE TTY
7804 033522 042766 177600 000004 BIC #C<177>,4(SP) ;: GET RID OF JUNK IF ANY
7805 033530 026627 000004 000023 CMP 4(SP),#23 ;: IS IT A CONTROL-S?
7806 033536 001013 BNE 3$ ;: BRANCH IF NO
7807 033540 105777 145414 2$: TSTB @STKS ;: WAIT FOR A CHARACTER
7808 033544 100375 BPL 2$ ;: LOOP UNTIL ITS THERE
7809 033546 117746 145410 MOVB @STKB,-(SP) ;: GET CHARACTER
7810 033552 042716 177600 BIC #C177,(SP) ;: MAKE IT 7-BIT ASCII
7811 033556 022627 000021 CMP (SP)+,#21 ;: IS IT A CONTROL-Q?
7812 033562 001366 BNE 2$ ;: IF NOT DISCARD IT
7813 033564 000750 BR 1$ ;: YES, RESUME
7814 033566 026627 000004 000140 3$: CMP 4(SP),#140 ;: IS IT UPPER CASE?
7815 033574 002407 BLT 4$ ;: BRANCH IF YES
7816 033576 026627 000004 000175 CMP 4(SP),#175 ;: IS IT A SPECIAL CHAR?
7817 033604 003003 BGT 4$ ;: BRANCH IF YES
7818 033606 042766 000040 000004 BIC #40,4(SP) ;: MAKE IT UPPER CASE
7819 033614 000002 4$: RTI ;: GO BACK TO USER
7820 033616 052536 005015 000 $CNTLU: .ASCIZ /?U/<15><12> ;: CONTROL "U"
7821 033623 136 006507 000012 $CNTLG: .ASCIZ /?G/<15><12> ;: CONTROL "G"
7822 033630 005015 053523 020122 $MSWR: .ASCIZ <15><12>/SWR = /
7823 033636 020075 000
7824 033641 040 047040 053505 $MNEW: .ASCIZ / NEW = /
7825 033646 036440 000040

```

.SBTTL RANDOM NUMBER GENERATOR ROUTINE

```

7826 ;:*****
7827 ;:THIS ROUTINE IS A DOUBLE PRECISION PSEUDO RANDOM NUMBER GENERATOR
7828 ;:WITH A RANGE OF 0 TO 2(+33)-1.
7829 ;:CALL:
7830 ;: JSR PC,$RAND ;: CALL THE ROUTINE
7831 ;: RETURN ;: RETURN HERE THE RANDOM
7832 ;: ;: NUMBER WILL BE IN
7833 ;: ;: $HINUM,$LONUM
7834 ;:
7835 ;:
7836 ;:
7837 ;:
7838 033652 $RAND:
7839 033652 010046 MOV R0,-(SP) ;: PUSH R0 ON STACK
7840 033654 010146 MOV R1,-(SP) ;: PUSH R1 ON STACK
7841 033656 010246 MOV R2,-(SP) ;: PUSH R2 ON STACK
7842 033660 013700 033752 MOV $LONUM,R0 ;: SET R0 WITH LOW
7843 033664 013701 033750 MOV $HINUM,R1 ;: SET R1 WITH HIGH
7844 033670 012702 177771 MOV #-7,R2 ;: SET SHIFT COUNT
7845 033674 006300 1$: ASL R0 ;: SHIFT R0 LEFT AND
7846 033676 006101 ROL R1 ;: ROTATE CARRY INTO R1 AND
7847 033700 005202 INC R2 ;: CHECK FOR DONE
7848 033702 001374 BNE 1$ ;: CONTINUE SHIFT LOOP
7849 033704 063700 033752 ADD $LONUM,R0 ;: ADD NUMBER TO MAKE X 129
7850 033710 005501 ADC R1 ;: PROPOGATE CARRY
7851 033712 063701 033750 ADD $HINUM,R1 ;: ADD NUMBER TO MAKE X 129

```

```

7852 033716 062700 001057
7853 033722 005501
7854 033724 062701 047401
7855 033730 010037 033752
7856 033734 010137 033750
7857 033740 012602
7858 033742 012601
7859 033744 012600
7860 033746 000207
7861 033750 176543
7862 033752 123456
7863
7864
7865
7866
7867
7868
7869
7870
7871
7872
7873
7874
7875
7876
7877
7878
7879
7880
7881 033754
7882 033754 010046
7883 033756 010146
7884 033760 010246
7885 033762 010346
7886 033764 010446
7887 033766 010546
7888 033770 016646 000022
7889 033774 016646 000022
7890 034000 016646 000022
7891 034004 016646 000022
7892 034010 000002
7893
7894
7895
7896
7897 034012
7898 034012 012666 000022
7899 034016 012666 000022
7900 034022 012666 000022
7901 034026 012666 000022
7902 034032 012605
7903 034034 012604
7904 034036 012603
7905 034040 012602
7906 034042 012601
7907 034044 012600

```

```

ADD #1057,R0      ;; ADD LOW CONSTANT
ADC R1            ;; PROPOGATE CARRY
ADD #47401,R1    ;; ADD HIGH CONSTANT
MOV R0,$LONUM    ;; SAVE R0
MOV R1,$SHINUM   ;; SAVE R1
MOV (SP)+,R2    ;; POP STACK INTO R2
MOV (SP)+,R1    ;; POP STACK INTO R1
MOV (SP)+,R0    ;; POP STACK INTO R0
RTS PC          ;; RETURN
$SHINUM: .WORD 176543
$LONUM: .WORD 123456

```

.SBTTL SAVE AND RESTORE R0-R5 ROUTINES

```

*****
*SAVE R0-R5
*CALL:
* SAVREG
*UPON RETURN FROM $SAVREG THE STACK WILL LOOK LIKE:
*
*TOP---(+16)
* +2---(+18)
* +4---R5
* +6---R4
* +8---R3
*+10---R2
*+12---R1
*+14---R0

```

```

$SAVREG:
MOV R0,-(SP)      ;; PUSH R0 ON STACK
MOV R1,-(SP)      ;; PUSH R1 ON STACK
MOV R2,-(SP)      ;; PUSH R2 ON STACK
MOV R3,-(SP)      ;; PUSH R3 ON STACK
MOV R4,-(SP)      ;; PUSH R4 ON STACK
MOV R5,-(SP)      ;; PUSH R5 ON STACK
MOV 22(SP),-(SP)  ;; SAVE PS OF MAIN FLOW
MOV 22(SP),-(SP)  ;; SAVE PC OF MAIN FLOW
MOV 22(SP),-(SP)  ;; SAVE PS OF CALL
MOV 22(SP),-(SP)  ;; SAVE PC OF CALL
RTI

```

```

*RESTORE R0-R5
*CALL:
* RESREG
$RESREG:
MOV (SP)+,22(SP)  ;; RESTORE PC OF CALL
MOV (SP)+,22(SP)  ;; RESTORE PS OF CALL
MOV (SP)+,22(SP)  ;; RESTORE PC OF MAIN FLOW
MOV (SP)+,22(SP)  ;; RESTORE PS OF MAIN FLOW
MOV (SP)+,R5      ;; POP STACK INTO R5
MOV (SP)+,R4      ;; POP STACK INTO R4
MOV (SP)+,R3      ;; POP STACK INTO R3
MOV (SP)+,R2      ;; POP STACK INTO R2
MOV (SP)+,R1      ;; POP STACK INTO R1
MOV (SP)+,R0      ;; POP STACK INTO R0

```

7908 034046 000002  
7909  
7910  
7911  
7912  
7913  
7914  
7915  
7916  
7917  
7918  
7919  
7920  
7921  
7922  
7923 034050 104412  
7924 034052 016602 000002  
7925 034056 012700 034230  
7926 034062 010066 000002  
7927 034066 012201  
7928 034070 012202  
7929 034072 012737 000012 034146  
7930 034100 012704 034160  
7931 034104 012705 034162  
7932 034110 005003  
7933 034112 161401  
7934 034114 005602  
7935 034116 161502  
7936 034120 002402  
7937 034122 005203  
7938 034124 000772  
7939 034126 062401  
7940 034130 005502  
7941 034132 062402  
7942 034134 022525 000060  
7943 034136 052703  
7944 034142 110320  
7945 034144 005327  
7946 034146 000000  
7947 034150 001357  
7948 034152 105020  
7949 034154 104413  
7950 034156 000207  
7951 034160 145000  
7952 034162 035632  
7953 034164 160400  
7954 034166 002765  
7955 034170 113200  
7956 034172 000230  
7957 034174 041100  
7958 034176 000017  
7959 034200 103240  
7960 034202 000001  
7961 034204 023420  
7962 034206 000000  
7963 034210 001750

```

RTI
.SBTTL DOUBLE LENGTH BINARY TO DECIMAL ASCII CONVERT ROUTINE
:*****
:THIS ROUTINE WILL CONVERT A 32-BIT BINARY NUMBER TO AN UNSIGNED
:DECIMAL (ASCII) NUMBER. THE SIGN OF THE BINARY NUMBER MUST BE
:POSITIVE.
:CALL
:*      MOV      #PNTR, -(SP)      ;; POINTER TO LOW WORD OF BINARY NUMBER
:*      JSR      PC, @#$DB2D
:*      RETURN
:; THE FIRST ADDRESS OF ASCII
:; IS ON THE STACK

$DB2D: SAVREG      ;; SAVE REGISTERS
MOV      2(SP), R2      ;; PICKUP THE DATA POINTER
MOV      #$DECVL, R0    ;; GET ADDRESS OF "$DECVL" STRING
MOV      R0, 2(SP)      ;; PUT ADDRESS OF ASCII STRING ON STACK
MOV      (R2)+, R1      ;; PICKUP THE BINARY NUMBER
MOV      (R2)+, R2
MOV      #10, 4$       ;; SET UP TO DO 10 CONVERSIONS
MOV      $STNPWR, R4    ;; ADDRESS OF TEN POWER
MOV      $STNPWR+2, R5

1$: CLR      R3          ;; CLEAR PARTIAL
2$: SUB      (R4), R1    ;; SUBTRACT TEN POWER
SBC      R2
SUB      (R5), R2
BLT      3$           ;; BR IF TEN POWER TO LARGE
INC      R3           ;; ADD 1 TO PARTIAL
BR       2$          ;; LOOP
3$: ADD      (R4)+, R1  ;; RESTORE SUBTRACTED VALUE
ADC      R2
ADD      (R4)+, R2
CMP      (R5)+, (R5)+  ;; MOVE TO NEXT TEN POWER
BIS      #'0, R3       ;; CHANGE PARTIAL TO ASCII
MOVB    R3, (R0)+     ;; SAVE IT
DEC      (PC)+        ;; DONE?
4$: .WORD   0          ;; BR IF NO
BNE     1$           ;; TERMINATOR
CLRB    (R0)+        ;; RESTORE REGISTERS
RESREG
RTS     PC          ;; RETURN
$STNPWR: 145000      ;; 1.0E09
35632
160400      ;; 1.0E08
2765
113200      ;; 1.0E07
230
041100      ;; 1.0E06
17
103240      ;; 1.0E05
1
23420      ;; 1.0E04
0
1750        ;; 1.0E03

```

```

7964 034212 000000
7965 034214 000144
7966 034216 000000
7967 034220 000012
7968 034222 000000
7969 034224 000001
7970 034226 000000
7971 034230 000014
7972
7973
7974
7975
7976
7977
7978
7979
7980
7981
7982
7983
7984 034244 104412
7985 034246 016601 000002
7986 034252 012705 034363
7987 034256 012704 000014
7988 034262 012703 177770
7989 034266 012100
7990 034270 012101
7991 034272 005002
7992 034274 110245
7993 034276 010002
7994 034300 005304
7995 034302 003007
7996 034304 001405
7997 034306 005205
7998 034310 010566 000002
7999 034314 104413
8000 034316 000207
8001 034320 006203
8002 034322 006001
8003 034324 006000
8004 034326 006001
8005 034330 006000
8006 034332 006001
8007 034334 006000
8008 034336 040302
8009 034340 062702 000060
8010 034344 000753
8011 034346 000016
8012
8013
8014
8015
8016
8017
8018
8019

```

```

0
144 ;;1.0E02
0
12 ;;1.0E01
0
1
0 ;;1.0E00
$DECVL: .BLKB 12. ;;RESERVE STORAGE FOR ASCII STRING
.SBTTL DOUBLE LENGTH BINARY TO OCTAL ASCII CONVERT ROUTINE
;*****
;THIS ROUTINE WILL CONVERT A 32-BIT UNSIGNED BINARY NUMBER TO AN
;UNSIGNED OCTAL ASCII NUMBER.
;CALL
;* MOV #PNTR, -(SP) ;; POINTER TO LOW WORD OF BINARY NUMBER
;* JSR PC, @#$D820 ;; CALL THE ROUTINE
;* RETURN ;; THE ADDRESS OF THE FIRST ASCII CHAR. IS ON THE STACK
$D820: SAVREG ;; SAVE ALL REGISTERS
MOV 2(SP), R1 ;; PICKUP THE POINTER TO LOW WORD
MOV #SOCTVL+13., R5 ;; POINTER TO DATA TABLE
MOV #12., R4 ;; DO ELEVEN CHARACTERS
MOV #1C7, R3 ;; MASK
MOV (R1)+, R0 ;; LOWER WORD
MOV (R1)+, R1 ;; HIGH WORD
CLR R2 ;; TERMINATOR
1$: MOVB R2, -(R5) ;; PUT CHARACTER IN DATA TABLE
MOV R0, R2 ;; GET THIS DIGIT
DEC R4 ;; COUNT THIS CHARACTER
BGT 3$ ;; BR IF NOT THE LAST DIGIT
BEQ 2$ ;; BR IF IT IS THE LAST DIGIT
INC R5 ;; ALL DIGITS DONE-ADJUST POINTER FOR FIRST
MOV R5, 2(SP) ;; ASCII CHAR. & PUT IT ON THE STACK
RESREG ;; RESTORE ALL REGISTERS
RTS PC ;; RETURN TO USER
2$: ASR R3 ;; POSITION THE MASK FOR THE LAST DIGIT
3$: ROR R1 ;; POSITION THE BINARY NUMBER FOR
ROR R0 ;; THE NEXT OCTAL DIGIT
ROR R1
ROR R0
ROR R1
ROR R0
ROR R1
ROR R0
BIC R3, R2 ;; MASK OUT ALL JUNK
ADD #0, R2 ;; MAKE THIS CHAR. ASCII
BR 1$ ;; GO PUT IT IN THE DATA TABLE
$SOCTVL: .BLKB 14. ;; RESERVE DATA TABLE
.SBTTL TRAP DECODER
;*****
;THIS ROUTINE WILL PICKUP THE LOWER BYTE OF THE "TRAP" INSTRUCTION
;AND USE IT TO INDEX THROUGH THE TRAP TABLE FOR THE STARTING ADDRESS
;OF THE DESIRED ROUTINE. THEN USING THE ADDRESS OBTAINED IT WILL
;GO TO THAT ROUTINE.

```

```

8020
8021 034364 010046          $TRAP:  MOV    RO, -(SP)          ;; SAVE RO
8022 034366 016600 000002  MOV    2(SP), RO        ;; GET TRAP ADDRESS
8023 034372 005740          TST    -(RO)            ;; BACKUP BY 2
8024 034374 111000          MOVB   (RO), RO         ;; GET RIGHT BYTE OF TRAP
8025 034376 006300          ASL    RO                ;; POSITION FOR INDEXING
8026 034400 016000 034420  MOV    $TRPAD(RO), RO   ;; INDEX TO TABLE
8027 034404 000200          RTS    RO                ;; GO TO ROUTINE
8028
8029
8030          ;; THIS IS USE TO HANDLE THE "GETPRI" MACRO
8031
8032 034406 011646 000004 000002 $TRAP2: MOV   (SP), -(SP)  ;; MOVE THE PC DOWN
8033 034410 016666          MOV   4(SP), 2(SP)     ;; MOVE THE PSW DOWN
8034 034416 000002          RTI                    ;; RESTORE THE PSW
8035
8036          .SBTTL  TRAP TABLE
8037
8038          ; *THIS TABLE CONTAINS THE STARTING ADDRESSES OF THE ROUTINES CALLED
8039          ; *BY THE "TRAP" INSTRUCTION.
8040
8041          ;
8042          ; ROUTINE
8043          ; -----
8043 034420 034406  $TRPAD: .WORD  $TRAP2          TRAP+1(104401)  TTY TYPEOUT ROUTINE
8044 034422 031516  $TYPE   ;; CALL=TYPE          TRAP+2(104402)  TYPE OCTAL NUMBER (WITH LEADING ZEROS)
8045 034424 032566  $TYPOC  ;; CALL=TYPOC        TRAP+3(104403)  TYPE OCTAL NUMBER (NO LEADING ZEROS)
8046 034426 032542  $TYPOS  ;; CALL=TYPOS        TRAP+4(104404)  TYPE OCTAL NUMBER (AS PER LAST CALL)
8047 034430 032602  $TYPON  ;; CALL=TYPON        TRAP+5(104405)  TYPE DECIMAL NUMBER (WITH SIGN)
8048 034432 032770  $TYPDS  ;; CALL=TYPDS
8049
8050 034434 033264  $GTSWR  ;; CALL=GTSWR        TRAP+6(104406)  GET SOFT-SWR SETTING
8051
8052 034436 033214  $CKSWR  ;; CALL=CKSWR        TRAP+7(104407)  TEST FOR CHANGE IN SOFT-SWR
8053 034440 033476  $RDCHR  ;; CALL=RDCHR        TRAP+10(104410) TTY TYPEIN CHARACTER ROUTINE
8054 034442 030700  $RDLIN  ;; CALL=RDLIN         TRAP+11(104411) TTY TYPEIN STRING ROUTINE
8055 034444 033754  $SAVREG ;; CALL=SAVREG          TRAP+12(104412) SAVE RO-R5 ROUTINE
8056 034446 034012  $RESREG ;; CALL=RESREG          TRAP+13(104413) RESTORE RO-R5 ROUTINE
8057 034450 030124  $DSPLY  ;; CALL=DISPLY        TRAP+14(104414) ROUTINE TO TYPE ERROR MESSAGES
8058          000032
8059
8060          $TERM=.-$TRPAD
8061          ;; *****
8062
8063
8064          .SBTTL  SINGLE/DUAL PORT RH70/RM03 DRIVER (REV 5.1)-24-AUG-77
8065          ; NEW DRIVE TYPE ID FOR RM02 *****
8066          ; 10-AUG-77 *****
8067
8068          ; COPYRIGHT (C) 1977
8069          ; DIGITAL EQUIPMENT CORP.
8070          ; MAYNARD, MA 01754
8071          ; AUTHOR(S): JIM LACEY/CHUCK HESS/C. CHEN
8072
8073          ;; *****
8074
8075          ; STORAGE FOR RMD5, RMER1, RMER2, AND RMMR2 ON AN ERROR "2"

```

```

8076                                     ;RMERRS = RMD5
8077                                     ;RMERRS+2 = RMR1
8078                                     ;RMERRS+4 = RMR2
8079                                     ;RMERRS+6 = RMR2
8080
8081 034452 000000 000000 000000 RMERRS: .WORD 0,0,0,0
8082 034460 000000
8083

```

```

;TABLE OF DRIVE ACTIVE INDICATORS (DRVACT=8 BYTES)
;DRVACT=0 IF DRIVE IS IDLE
;DRVACT>0 IF DRIVE IS ACTIVE WITH A COMMAND
;DRVACT<0 IF DRIVE IS ACTIVE WITH AN ERROR RECOVERY OPERATION

```

```

8088
8089 034462 000 DRVACT: .BYTE 0 ;DRIVE 0
8090 034463 000 .BYTE 0 ;DRIVE 1
8091 034464 000 .BYTE 0 ;DRIVE 2
8092 034465 000 .BYTE 0 ;DRIVE 3
8093 034466 000 .BYTE 0 ;DRIVE 4
8094 034467 000 .BYTE 0 ;DRIVE 5
8095 034470 000 .BYTE 0 ;DRIVE 6
8096 034471 000 .BYTE 0 ;DRIVE 7
8097

```

```

;TABLE OF DRIVE STATUS INDICATORS (DRVSTA=8 BYTES)
;DRVSTA=0 IF DRIVE IS OFFLINE OR NONEXISTENT
;DRVSTA>0 IF DRIVE IS ONLINE
;DRVSTA<0 IF DRIVE IS UNSAFE

```

```

8098
8099
8100
8101
8102
8103 034472 000 DRVSTA: .BYTE 0 ;DRIVE 0
8104 034473 000 .BYTE 0 ;DRIVE 1
8105 034474 000 .BYTE 0 ;DRIVE 2
8106 034475 000 .BYTE 0 ;DRIVE 3
8107 034476 000 .BYTE 0 ;DRIVE 4
8108 034477 000 .BYTE 0 ;DRIVE 5
8109 034500 000 .BYTE 0 ;DRIVE 6
8110 034501 000 .BYTE 0 ;DRIVE 7
8111

```

```

;TABLE OF DRIVE TYPES (DRVSTYP=8 BYTES)
;DRVSTYP=0 IF DRIVE IS NONEXISTENT (DRVSTA=0, ALSO)
;DRVSTYP=5 IF DRIVE IS RM02 *****
;DRVSTYP=4 IF DRIVE IS RM03
;DRVSTYP=-1 IF NOT RM03

```

```

8112
8113
8114
8115
8116
8117
8118 034502 000 DRVSTYP: .BYTE 0 ;DRIVE 0
8119 034503 000 .BYTE 0 ;DRIVE 1
8120 034504 000 .BYTE 0 ;DRIVE 2
8121 034505 000 .BYTE 0 ;DRIVE 3
8122 034506 000 .BYTE 0 ;DRIVE 4
8123 034507 000 .BYTE 0 ;DRIVE 5
8124 034510 000 .BYTE 0 ;DRIVE 6
8125 034511 000 .BYTE 0 ;DRIVE 7
8126

```

```

;TABLE OF DUAL PORT INITIALIZATION INDICATORS
;DPINT=0 IF INITIALIZATION IS NOT ACTIVE ON THE DRIVE
;DPINT<0 IF INITIALIZATION IS IN PROGRESS

```

```

8127
8128
8129
8130
8131 034512 000 DPINT: .BYTE 0 ;DRIVE 0

```



```

0132 034513 000
0133 034514 000
0134 034515 000
0135 034516 000
0136 034517 000
0137 034520 000
0138 034521 000
0139
0140
0141
0142
0143
0144 034522 000
0145 034523 000
0146 034524 000
0147 034525 000
0148 034526 000
0149 034527 000
0150 034530 000
0151 034531 000
0152
0153
0154
0155
0156
0157 034532 000000
0158
0159
0160
0161
0162
0163
0164
0165 034534 000000
0166
0167
0168
0169
0170
0171 034536 000
0172
0173
0174
0175
0176
0177 034537 000
0178
0179
0180
0181
0182
0183
0184 034540 000
0185 034541 000
0186 034542 000
0187 034543 000

```

```

.BYTE 0 ;DRIVE 1
.BYTE 0 ;DRIVE 2
.BYTE 0 ;DRIVE 3
.BYTE 0 ;DRIVE 4
.BYTE 0 ;DRIVE 5
.BYTE 0 ;DRIVE 6
.BYTE 0 ;DRIVE 7

;TABLE OF PENDING DUAL PORT REQUESTS
;DPRQS=0 IF THAT A DUAL PORT REQUEST IS NOT PENDING FOR THAT DRIVE
;DPRQS<0 IF THAT A DUAL PORT REQUEST IS PENDING FOR THAT DRIVE

DPRQS: .BYTE 0 ;DRIVE 0
.BYTE 0 ;DRIVE 1
.BYTE 0 ;DRIVE 2
.BYTE 0 ;DRIVE 3
.BYTE 0 ;DRIVE 4
.BYTE 0 ;DRIVE 5
.BYTE 0 ;DRIVE 6
.BYTE 0 ;DRIVE 7

;TRANSFER WAIT FLAG (TRNSWT=1 WORD)
;THIS IS A ONE WORD QUEUE. IT WILL CONTAIN THE ADDRESS OF
;"DPB" OF THE I/O OPERATION.

TRNSWT: .WORD 0

;SEARCH WAIT KEYS (SRCHWT=1 WORD)
;THIS IS A ONE WORD QUEUE THAT WILL CONTAIN A KEY FOR EACH OF
;THE DRIVES THAT ARE PERFORMING A SEARCH COMMAND FOR THE I/O
;REQUEST THAT IS AT THE TOP OF THEIR REQUEST QUEUE.
;EACH DRIVE IS ASSIGNED ONE BIT, STARTING AT BIT00 FOR DRIVE 0.

SRCHWT: .WORD 0

;RM03 DRIVER ACTIVE FLAG (ACTDRV=1 BYTE)
;ACTDRV=0 IF DRIVER IS INACTIVE
;ACTDRV>0 IF DRIVER IS ACTIVE

ACTDRV: .BYTE 0

;SOFTWARE TIMER ROUTINE ACTIVE FLAG (ACTSTR=1 BYTE)
;ACTSTR=0 IF SOFTWARE TIMER ROUTINE IS INACTIVE
;ACTSTR>0 IF SOFTWARE TIMER ROUTINE IS ACTIVE

ACTSTR: .BYTE 0

;UNLOAD FLAG (ULDFLG=8 BYTES)
;ULDFLG=0 IF NO UNLOAD COMMAND
;ULDFLG>0 IF UNLOAD COMMAND IN PROGRESS
;ULDFLG<0 IF UNLOAD COMMAND IN WAIT QUEUE

ULDFLG: .BYTE 0 ;DRIVE 0
.BYTE 0 ;DRIVE 1
.BYTE 0 ;DRIVE 2
.BYTE 0 ;DRIVE 3

```

8188 034544 000  
8189 034545 000  
8190 034546 000  
8191 034547 000  
8192  
8193  
8194  
8195  
8196 034550 000  
8197 034551 000  
8198 034552 000  
8199 034553 000  
8200 034554 000  
8201 034555 000  
8202 034556 000  
8203 034557 000  
8204  
8205  
8206  
8207  
8208  
8209  
8210  
8211 034560 000000  
8212  
8213  
8214  
8215  
8216  
8217  
8218  
8219 034562 177777  
8220  
8221  
8222  
8223  
8224 034564 177777  
8225 034566 177777  
8226 034570 177777  
8227 034572 177777  
8228 034574 177777  
8229 034576 177777  
8230 034600 177777  
8231 034602 177777  
8232  
8233  
8234  
8235  
8236  
8237 034604 177777  
8238  
8239  
8240  
8241  
8242  
8243 034606 001

```

      .BYTE 0           ;DRIVE 4
      .BYTE 0           ;DRIVE 5
      .BYTE 0           ;DRIVE 6
      .BYTE 0           ;DRIVE 7

;LOOK AHEAD COUNT (LACNT=8 BYTES)
;LACNT WILL INDICATE THE NUMBER OF LOOK AHEADS PERFORMED

LACNT: .BYTE 0           ;DRIVE 0
      .BYTE 0           ;DRIVE 1
      .BYTE 0           ;DRIVE 2
      .BYTE 0           ;DRIVE 3
      .BYTE 0           ;DRIVE 4
      .BYTE 0           ;DRIVE 5
      .BYTE 0           ;DRIVE 6
      .BYTE 0           ;DRIVE 7

;SAVE REGISTERS FLAG (SAVEFG =1 WORD)
;SAVEFG <0 IF SAVE THE RH70/RM03 REGISTERS WHEN THE
;OPERATION IS COMPLETED AS PER (DPB+14).
;SAVEFG=0 IF SAVE THE RH70/RM03 REGISTERS, AS PER
;(DPB+14), AFTER AN ERROR.

SAVEFG: .WORD 0

;SEEK FLAG (SEEKFG=1 WORD)
;SEEKFG=0 IF WHEN THE DISK ADDRESS ISN'T IN THE WINDOW
;FOR A DATA TRANSFER START A SEARCH COMMAND
;SEEKFG<0 IF DATA TRANSFER WILL DO IMPLIED SEEKS,
;DISREGARD THE WINDOW

SEEKFG: .WORD -1

;TIMEOUT TABLE (TIMER=8 WORDS)
;THIS TABLE CONTAINS THE TIME ALLOWED FOR AN OPERATION

TIMER: .WORD -1         ;DRIVE 0
      .WORD -1         ;DRIVE 1
      .WORD -1         ;DRIVE 2
      .WORD -1         ;DRIVE 3
      .WORD -1         ;DRIVE 4
      .WORD -1         ;DRIVE 5
      .WORD -1         ;DRIVE 6
      .WORD -1         ;DRIVE 7

;DATA TRANSFER UNDERWAY INDICATOR (DTUW=1 WORD)
;DTUW<0 IF NO DATA TRANSFER UNDERWAY
;DTUW=+N (WHERE N=0 TO 7) IMPLIES DATA TRANSFER UNDERWAY ON DRIVE N

DTUW: .WORD -1

;ATTENTION BITS TABLE (ATABIT=8 BYTES)
;THIS TABLE CONTAINS THE CORRESPONDING BIT TO EACH DRIVES
;ATTENTION BIT

ATABIT: .BYTE 1         ;DRIVE 0

```

```

8244 034607 002 .BYTE 2 ;DRIVE 1
8245 034610 004 .BYTE 4 ;DRIVE 2
8246 034611 010 .BYTE 10 ;DRIVE 3
8247 034612 020 .BYTE 20 ;DRIVE 4
8248 034613 040 .BYTE 40 ;DRIVE 5
8249 034614 100 .BYTE 100 ;DRIVE 6
8250 034615 200 .BYTE 200 ;DRIVE 7
8251
8252 ;FSRM03 TO RH70 "MASSBUS CONTROL BUS PARITY ERRORS" (MCPE) ALLOWED BEFORE
8253 ;CALLING IT FATAL (MCPEMX=1 WORD)
8254
8255 034616 000003 MCPEMX: .WORD 3
8256
8257 ;STORAGE FOR RMADR (THE FIRST ADDRESS (776700) OF THE RH70/RM03),
8258 ;RMVEC (THE VECTOR ADDRESS (254)), AND RMVEC+2 (THE BR LEVEL (5)).
8259
8260 034620 176700 RMADR: .WORD 176700
8261 034622 000254 000240 RMVEC: .WORD 254,5*32.
8262
8263 ;MAXIMUM NUMBER OF LOOK AHEADS ALLOWED IS 4 (MXLACT=1 WORD)
8264
8265 034626 000004 MXLACT: .WORD 4
8266 ;MAXIMUM DELTA DELAY IS 8 SECTORS (MXDLTA=1 WORD)
8267
8268 034630 001000 MXDLTA: .WORD 8.*64.
8269 ;MINIMUM DELTA DELAY IS 2 SECTORS (MNDLTA=1 WORD)
8270
8271 034632 000200 MNDLTA: .WORD 2*64.
8272 ;MAXIMUM SEARCH FOR I/O WINDOW IS 5 SECTORS (MXWNDW=1 WORD)
8273
8274 034634 000005 MXWNDW: .WORD 5
8275
8276 ;DEFINITIONS OF THE RH70/RM03 ADDRESS INDEXES
8277
8278 000000 RMCS1=0 ;CONTROL AND STATUS REGISTER #1 (DRIVE REG. 00)
8279 000002 RMWC=2 ;WORD COUNT REGISTER (NOT A DRIVE REG)
8280 000004 RMBA=4 ;UNIBUS ADDRESS REGISTER (NOT A DRIVE REG)
8281 000006 RMDA=6 ;DESIRED SECTOR/TRACK ADDRESS REGISTER (DRIVE REG. 05)
8282 000010 RMCS2=10 ;CONTROL AND STATUS REGISTER #2 (NOT A DRIVE REG)
8283 000012 RMDS=12 ;DRIVE STATUS REGISTER (DRIVE REG 01)
8284 000014 RMER1=14 ;ERROR REGISTER #1 (DRIVE REG. 02)
8285 000016 RMAS=16 ;ATTENTION SUMMARY PSEUDO REGISTER (DRIVE REG. 04)
8286 000020 RMLA=20 ;LOOK AHEAD REGISTER (DRIVE REG. 07)
8287 000022 RMDB=22 ;DATA BUFFER REGISTER (NOT A DRIVE REG.)
8288 000024 RMMR1=24 ;MAINTAINABILITY REGISTER (DRIVE REG. 03)
8289 000026 RMDT=26 ;DRIVE TYPE REGISTER (DRIVE REG. 06)
8290 000030 RMSN=30 ;SERIAL NUMBER REGISTER (DRIVE REG. 10)
8291 000032 RMOF=32 ;OFFSET REGISTER (DRIVE REG. 11)
8292 000034 RMDC=34 ;DESIRED CYLINDER ADDRESS REGISTER (DRIVE REG. 12)
8293 000036 RMHR=36 ;DUMMY ADDRESS REGISTER (DRIVE REG. 13)
8294 000040 RMMR2=40 ;MAINTENANCE REGISTER #2
8295 000042 RMER2=42 ;ERROR REGISTER #2 (DRIVE REG. 15)
8296 000044 RMEC1=44 ;ECC POSITION REGISTER (DRIVE REG. 16)
8297 000046 RMEC2=46 ;ECC PATTERN REGISTER (DRIVE REG. 17)
8298
8299 ;RH70/RM03 DRIVER INITIALIZATION CODE

```

```

8300 ; THIS ROUTINE WILL DETERMINE WHICH RMO3 DRIVES ARE
8301 ; AVAILABLE FOR TESTING AND SET THE DRVSTA INDICATOR
8302 ; TO THE PROPER STATE FOR EACH DRIVE.
8303 ; NOTE: THIS ROUTINE CALLS DRVINT
8304
8305 :CALL
8306
8307 JSR PC,RMINIT
8308 RETURN
8309
8310 :NOTE: THE 'P' OR 'L' CLOCK MUST BE STARTED
8311
8312 RMINIT: SAVREG ;SAVE R0 - R5
8313 MOV @#PS,-(SP) ;SAVE THE PRESENT PROCESSOR STATUS
8314 MOV @(<5*32.>,@#PS) ;CHANGE THE PRIORITY TO 5
8315 JSR PC,CLRQUE ;CLEAR ALL REQUEST QUEUES
8316 MOV @RMERRS,R1 ;FIRST ADDRESS TO BE CLEARED
8317 MOV @SEEKFG,R2 ;LAST ADDRESS TO BE CLEARED
8318 1$: CLR (R1)+ ;CLEAR
8319 CMP R1,R2 ;ARE WE DONE?
8320 BLO 1$ ;BRANCH IF NO
8321 MOV @DTUW,R2 ;LAST ADDRESS
8322 2$: MOV @-1,(R1)+ ;INITIALIZE
8323 CMP R1,R2 ;DONE?
8324 BLOS 2$ ;LOOP IF NO
8325 CLR DRVSTA ;SET ALL DRIVES TO OFFLINE
8326 CLR DRVSTA+2
8327 CLR DRVSTA+4
8328 CLR DRVSTA+6
8329 MOV RMVEC,R3 ;SETUP THE RH70/RMO3 VECTOR
8330 MOV @ISR,(R3)+
8331 MOV RMVEC+2,(R3)
8332 MOV RMADR,R4 ;FIRST ADDRESS OF RH70/RMO3
8333 MOV @BIT05,RMCS2(R4) ;MASSBUS INIT
8334 CLR R1 ;START WITH DRIVE 0
8335 3$: JSR R0,DRVINT ;INIT THE DRIVE
8336 BR 4$ ;'DVA' NOT SET OR PARITY ERROR
8337 BR 5$ ;NORMAL RETURN
8338 4$: CLRB DRVSTA(R1) ;SET DRIVE STATUS TO OFFLINE
8339 INC R1 ;GO TO NEXT DRIVE
8340 5$: BIC #1C7,R1 ;MASK OUT UNUSED BITS
8341 BNE 3$ ;BR IF MORE DRIVES TO GO
8342 MOV #7,R1 ;START WITH DRIVE 7
8343 CLR @#PS ;CLEAR THE PROCESSOR STATUS
8344 6$: TSTB DPINT(R1) ;WAITING FOR DRIVE TO SWITCH PORTS ?
8345 BEQ 8$ ;BR NOT WAITING
8346 JSR PC,SET.IE ;SET INTERRUPT
8347 7$: TSTB DPINT(R1) ;DRIVE SWITCHED PORTS ?
8348 BNE 7$ ;BR IF NOT
8349 8$: DEC R1 ;GO TO THE NEXT DRIVE
8350 BPL 6$ ;CHECK NEXT DRIVE
8351 MOV (SP)+,@#PS ;RESTORE THE PROCESSOR STATUS
8352 RESREG ;RESTORE R0 - R5
8353 RTS PC ;BYE-BYE
8354
8355 ;DRIVE INITIALIZATION ROUTINE

```

```

8356                                     ; THIS ROUTINE DETERMINES IF A DRIVE EXIST AND IF IT IS
8357                                     ; AN RMO3. IF IT IS, A "READ-IN PRESET" IS ISSUED AND FMT22
8358                                     ; IS SET TO A "1". THEN MOL, DPR, DRY, AND VV ARE CHECKED TO
8359                                     ; INSURE THEY ARE ALL ON A "1". AND DEPENDING ON THEIR STATE,
8360                                     ; DRVSTA IS SET TO THE PROPER CONDITION.
8361                                     ; CALL
8362                                     : CALL
8363                                     : MOV      #DRVNUM,R1      ; DRIVE NUMBER TO R1
8364                                     : MOV      RMADR,R4      ; UNIBUS ADDRESS OF RH70/RMO3 (RMCS1)
8365                                     : JSR      RO,DRVINT    ; CALLED BY A JSR
8366                                     : RETURN1   ; ERROR OCCURRED (PARITY)
8367                                     : RETURN2   ; NORMAL RETURN
8368
8369 035050 010546 034472  DRVINT: MOV      R5,-(SP)      ; SAVE R5
8370 035052 105061 034472  DULP:  CLRB     DRVSTA(R1)  ; START DRIVE STATUS AS OFFLINE
8371 035056 105061 034502  CLRB     DRVSTYP(R1)    ; CLEAR THE DRIVE TYPE INDICATOR
8372 035062 105061 034540  CLRB     ULDFLG(R1)    ; CLEAR THE UNLOAD FLAG
8373 035066 010164 000010  MOV      R1,RMCS2(R4)  ; SELECT A DRIVE
8374 035072 112764 000111 000000  MOVB     #11,RMCS1(R4) ; DO A DRIVE CLEAR COMMAND (& SEIZE DRIVE)
8375 035100 032764 010000 000010  BIT      #BIT12,RMCS2(R4) ; NONEXISTENT DRIVE?
8376 035106 001403  BEQ      1$           ; NO---BRANCH
8377 035110 004737 042214  JSR      PC,SET.IE    ; GO SET "IE" WITHOUT A "TRE"
8378 035114 000507  BR       6$           ; LEAVE THIS ROUTINE
8379 035116 105061 034472 1$:  CLRB     DRVSTA(R1)  ; SET DRIVE STATUS TO OFFLINE
8380 035122 032764 004000 000000  BIT      #BIT11,RMCS1(R4) ; SEE IF DRIVE AVAILABLE
8381 035130 001750  BEQ      DULP        ; BR IF DRIVE NOT AVAILABLE
8382 035132 004037 041534  JSR      RO,RD.RM    ; READ THE DRIVE TYPE REG.
8383 035136 000026  RMDT     8$           ; ERROR RETURN ADDRESS
8384 035140 035360  MOV      (SP)+,R5     ; PUT DRIVE TYPE IN R5
8385 035142 012605  MOVB     #4,DRVSTYP(R1) ; SET RMO3 INDICATOR
8386 035144 112761 000004 034502  CMP      #20024,R5    ; SINGLE PORT RMO3 ?
8387 035152 022705 020024  BEQ      2$           ; BR IF YES
8388 035156 001420  CMP      #24024,R5   ; DUAL PORT RMO3 ?
8389 035160 022705 024024  BEQ      2$           ; BR IF YES
8390 035164 001415  MOVB     #5,DRVSTYP(R1) ; SET RMO2 INDICATOR
8391 035166 112761 000005 034502  CMP      #20025,R5   ; SINGLE PRPT RMO2 ?
8392 035174 022705 020025  BEQ      2$           ; BRANCH IF SO
8393 035200 001407  CMP      #24025,R5   ; DUAL PORT RMO2 ?
8394 035202 022705 024025  BEQ      2$           ; BRANCH IF SO
8395 035206 001404  MOVB     #-1,DRVSTYP(R1) ; SET INDICATOR TO 'OTHER'
8396 035210 112761 177777 034502  BR       6$           ; EXIT
8397 035216 000446 2$:  MOV      #121,-(SP) ; DO A "READ-IN PRESET"
8398 035220 012746 000121  JSR      RO,WRT.RM
8399 035224 004037 041710  RMCS1
8400 035230 000000 8$
8401 035232 035360  MOV      #BIT12,-(SP) ; SET FMT22=1
8402 035234 012746 010000  JSR      RO,WRT.RM
8403 035240 004037 041710  RMOF
8404 035244 000032 8$
8405 035246 035360  JSR      RO,RD.RM    ; READ RMD5
8406 035250 004037 041534  RMD5
8407 035254 000012 8$
8408 035256 035360  MOV      (SP)+,R5    ; AND SAVE IT IN R5
8409 035260 012605 4$         ; BRANCH IF ATA=0
8410 035262 100015  BPL
8411 035264 116164 034606 000016  MOVB     ATABIT(R1),RMAS(R4) ; CLEAR ATTENTION SIT

```

```

8412 035272 004037 041534 JSR RO, RD.RM ;FIND OUT WHY ATA=1
8413 035276 000014 RMER1
8414 035300 035360 B$
8415 035302 006126 ROL (SP)+ ;IS IT UNSAFE?
8416 035304 100004 BPL 4$ ;BR IF NOT
8417 035306 112761 177777 034472 MOVB #-1, DRVSTA(R1) ;SET UNSAFE INDICATOR
8418 035314 000407 BR 6$ ;EXIT
8419 035316 005105 4$: COM R5 ;CHECK MOL, DPR, DRY, AND VV
8420 035320 042705 167077 BIC #1<BIT12!BIT08!BIT07!BIT06>, R5
8421 035324 001003 BNE 6$ ;BRANCH IF MOL, DPR, DRY, OR VV IS CLEAR
8422 035326 112761 000001 034472 MOVB #1, DRVSTA(R1) ;SET DRIVE STATUS TO ONLINE
8423 035334 005720 6$: TST (R0)+ ;STEP OVER THE ERROR RETURN
8424 035336 000410 BR 8$ ;EXIT
8425 035340 006301 7$: ASL R1 ;CHANGE INDEX TO ADDRESS WORDS
8426 035342 012761 060000 034564 MOV #60000, TIMER(R1) ;START 2 SEC TIMER
8427 035350 006201 ASR R1 ;RESTORE R1
8428 035352 112761 177777 034512 MOVB #-1, DPINT(R1) ;SET PORT INITIALIZE INDICATOR
8429 035360 012605 8$: MOV (SP)+, R5 ;RESTORE R5
8430 035362 000200 RTS RO ;EXIT
8431
8432 ;REQUEST PRE-PROCESSOR-HANDLES SUBSYSTEM REQUEST
8433 ;CALL
8434 ;
8435 ;
8436 ; JSR RO, @#RMO3 ;CALL THE RMO3 DRIVER
8437 ; PNTADR ;ADDRESS OF POINTER OF DRIVES PARAMETER BLOCK
8438 ; RETURN1 ;RETURN HERE IF QUEUE IS FULL
8439 ; RETURN2 ;RETURN HERE IF REQUEST IS IN QUEUE OR THERE
8440 ; IS AN ERROR CONDITION
8441
8442 035364 013746 177776 RMO3: MOV @#PS, -(SP) ;SAVE THE CALLING STATUS
8443 035370 013737 034624 177776 MOV RMVEC+2, @#PS ;DON'T ALLOW ANY RMO3 INTERRUPTS
8444 035376 112737 000001 034536 MOVB #1, ACTDRV ;SET "ACTIVE DRIVER" FLAG
8445 035404 104412 SAVREG ;SAVE RO - R5
8446 035406 011002 MOV (R0), R2 ;PICKUP THE DRIVE PARAMETER BLOCK POINTER
8447 035410 005062 000016 CLR 16(R2) ;CLEAR THE STATUS/ERROR INDICATOR
8448 035414 111201 MOVB (R2), R1 ;PICKUP THE DRIVE NUMBER
8449 035416 013704 034620 MOV RMADR, R4 ;UNIBUS ADDRESS OF RMCS1
8450 035422 105761 034472 TSTB DRVSTA(R1) ;CHECK DRIVES STATUS
8451 035426 003014 BGT 1$ ;BRANCH IF ONLINE
8452 035430 105761 034540 TSTB ULDFLG(R1) ;UNLOAD COMMAND IN QUEUE?
8453 035434 001036 BNE 3$ ;BRANCH IF YES
8454 035436 105761 034512 TSTB DPINT(R1) ;TRYING TO INIT THE DRIVE
8455 035442 001042 BNE 5$ ;BR IF YES
8456 035444 004037 035050 JSR RO, DRVINT ;GO INIT. THE DRIVE
8457 035450 000434 BR 4$ ;ERROR RETURN
8458 035452 105761 034472 TSTB DRVSTA(R1) ;IS DRIVE STATUS ONLINE?
8459 035456 003445 BLE 6$ ;BR IF NOT
8460 035460 105761 034522 1$: TSTB DPRQS(R1) ;OUTSTANDING PORT REQUEST FOR THE DRIVE ?
8461 035464 001031 BNE 5$ ;BR IF YES
8462 035466 010164 000010 MOV R1, RMCS2(R4) ;SELECT THE DRIVE
8463 035472 004037 042656 JSR RO, DRVQUE ;PUT THIS REQUEST IN QUEUE
8464 035476 000460 BR 9$ ;QUEUE IS FULL
8465 035500 122762 000103 000002 CMPB #103, 2(R2) ;IS THIS REQ. FOR AN UNLOAD?
8466 035506 001003 BNE 2$ ;BR IF NO
8467 035510 112761 177777 034540 MOVB #-1, ULDFLG(R1) ;SET THE "UNLOAD IN QUEUE" FLAG

```

```

8468 035516 105761 034462      2$:  TSTB  DRVACT(R1)      ;IS THIS DRIVE ACTIVE?
8469 035522 001043              BNE  8$                ;BR IF YES
8470 035524 004737 035656      JSR  PC,OPT            ;CALL THE OPTIMIZER
8471 035530 000440              BR   8$
8472 035532 012762 120000 000016 3$:  MOV  #BIT15!BIT13,16(R2) ;SET THE "UNLOAD IN QUEUE" ERROR FLAG
8473 035540 000434              BR   8$                ;EXIT
8474 035542 004737 036736      4$:  JSR  PC,C17          ;GO HANDLE THE PARITY ERROR
8475 035546 000431              BR   8$
8476 035550 004037 042656      5$:  JSR  RD,DRVQUE       ;PUT REQUEST IN QUEUE
8477 035554 000431              BR   9$                ;QUEUE IS FULL
8478 035556 032714 000100      BIT  #BIT06,(R4)      ;IE BIT SET ?
8479 035562 001023              BNE  8$                ;YES
8480 035564 004737 042214      JSR  PC,SET.IE        ;SET THE INTERRUPT
8481 035570 000420              BR   8$                ;RETURN
8482 035572 105761 034472      6$:  TSTB  DRVSTA(R1)     ;SEE IF DRIVE OFFLINE OR UNSAFE
8483 035576 002412              BLT  7$                ;BR IF UNSAFE
8484 035600 012762 140000 000016  MOV  #BIT15!BIT14,16(R2) ;SET OFFLINE ERROR INDICATOR
8485 035606 105761 034502      TSTB  DRVSTYP(R1)    ;SEE IF OFFLINE OR NONEXISTENT
8486 035612 001007              BNE  8$                ;BR IF OFFLINE
8487 035614 012762 100002 000016  MOV  #BIT15!BIT01,16(R2) ;REPORT DRIVE NONEXISTENT
8488 035622 000403              BR   8$                ;GO TO EXIT
8489 035624 012762 110000 000016 7$:  MOV  #BIT15!BIT12,16(R2) ;DRIVE IS UNSAFE
8490 035632 104413              8$:  RESREG              ;RESTORE R0 - R5
8491 035634 005720              TST  (R0)+             ;SETUP FOR NORMAL RETURN
8492 035636 000401              BR   10$              ;FINISH UP, THEN EXIT
8493 035640 104413              9$:  RESREG              ;RESTORE R0 - R5
8494 035642 005720              10$: TST  (R0)+            ;CORRECT THE RETURN ADDRESS
8495 035644 105037 034536      CLRB  ACTDRV         ;CLEAR "ACTIVE DRIVER" FLAG
8496 035650 012637 177776      MOV  (SP)+,2#PS      ;RETURN "PS" TO USER LEVEL
8497 035654 000200              RTS  RD               ;RETURN TO CALLER
8498
8499
8500
8501
8502
8503
8504
8505 035656 104412
8506 035660 013746 177776
8507 035664 146137 034606 034534
8508 035672 105061 034522
8509 035676 004737 042732
8510 035702 005702
8511 035704 001472
8512 035706 010164 000010
8513 035712 012764 000111 000000
8514 035720 032764 004000 000000
8515 035726 001446
8516 035730 105761 034472      10$: TSTB  DRVSTA(R1)    ;IS DRIVE ONLINE?
8517 035734 003014              BGT  1$                ;YES--BRANCH
8518 035736 004737 042754      JSR  PC,POPQUE       ;NO--REMOVE REQUEST FROM QUEUE
8519 035742 012762 140000 000016  MOV  #BIT15!BIT14,16(R2) ;SET OFFLINE STATUS/ERROR INDICATOR
8520 035750 105761 034472      TSTB  DRVSTA(R1)    ;IS DRIVE UNSAFE ?
8521 035754 100053              BPL  8$                ;BR TO EXIT IF NOT
8522 035756 012762 110000 000016  MOV  #BIT15!BIT12,16(R2) ;SET UNSAFE STATUS/ERROR INDICATOR
8523 035764 000447              BR   8$                ;BRANCH TO EXIT

```

;OPTIMIZER-CALLED FOR A PARTICULAR DRIVE

;CALL

```

MOV  #DRVNUM,R1      ;DRIVE NUMBER TO R1
JSR  PC,OPT          ;SETUP A COMMAND
OPT: SAVREG          ;SAVE R0 - R5
MOV  2#PS, -(SP)    ;SAVE PROC. STATUS
BICB ATABIT(R1),SRCHWT ;CLEAR LA SEACH FLAG
CLRB DPRQS(R1)      ;RESET THE PORT REQ FLAG ****
JSR  PC,GETREQ      ;GET "DPB" POINTER OF REQUEST
TST  R2              ;IS THERE A REQUEST IN QUEUE?
BEQ  7$              ;NO--BRANCH TO EXIT
MOV  R1, RMCS2(R4)   ;LOAD THE DRIVE ADDRESS *****
MOV  #11, RMCS1(R4) ;CLEAR THE DRIVE
BIT  #BIT11, RMCS1(R4) ;DVA SET ?
BEQ  5$              ;TO PROT REQUEST, IF NOT
TSTB DRVSTA(R1)    ;IS DRIVE ONLINE?
BGT  1$              ;YES--BRANCH
JSR  PC,POPQUE      ;NO--REMOVE REQUEST FROM QUEUE
MOV  #BIT15!BIT14,16(R2) ;SET OFFLINE STATUS/ERROR INDICATOR
TSTB DRVSTA(R1)    ;IS DRIVE UNSAFE ?
BPL  8$              ;BR TO EXIT IF NOT
MOV  #BIT15!BIT12,16(R2) ;SET UNSAFE STATUS/ERROR INDICATOR
BR   8$              ;BRANCH TO EXIT

```

```

8524 035766          1S:
8525                :      MOV      #111, -(SP)      ; LOAD COMMAND ONTO THE STACK
8526                :      JSR      RO, WRT.RM      ; LOAD THE REGISTER
8527                :      RMCS1      ; REGISTER INCREMENT
8528                :      B$      ; ERROR RETURN ADDRESS
8529                :      BIT      #BIT11, (R4)      ; DRIVE AVAILABLE ?
8530                :      BEQ      9$      ; BR IF NOT
8531 035766 122762 000150 000002      :      CMPB     #150, 2(R2)      ; IS THE REQUEST FOR I/O?
8532 035774 002403                :      BLT      2$      ; YES--BRANCH
8533 035776 004737 036322      :      JSR      PC, CI4      ; CALL THE COMMAND INITIATOR
8534 036002 000440                :      BR      8$      ; BRANCH TO EXIT
8535 036004 005737 034604      2S:      TST      DTUW      ; DATA TRANSFER UNDERWAY?
8536 036010 002012                :      BGE      4$      ; YES--GO START A SEARCH
8537 036012 005737 034562      :      TST      SEEKFG      ; DO IMPLIED SEEKS?
8538 036016 100404                :      BMI      3$      ; YES---BRANCH
8539 036020 004037 037274      :      JSR      RO, LA      ; NO--DO LOOK AHEAD
8540 036024 000427                :      BR      8$      ; RETURN HERE ON A PARITY ERROR
8541 036026 000403                :      BR      4$      ; GO START A SEARCH
8542 036030 004737 036114      3S:      JSR      PC, CI1      ; START A DATA TRANSFER
8543 036034 000423                :      BR      8$
8544 036036 004737 036222      4S:      JSR      PC, CI3      ; START A SEARCH
8545 036042 000420                :      BR      8$      ; GO TO THE EXIT
8546 036044 112761 177777 034522 5S:      MOVB     #-1, DPRQS(R1)      ; SET PORT REQUEST INDICATOR
8547 036052 010103                :      MOV      R1, R3      ; SET UP TO ADDRESS WORDS
8548 036054 006303                :      ASL      R3      ; CONVERT TO WORD INDEX
8549 036056 012763 060000 034564      :      MOV      #60000, TIMER(R3) ; START 10 SEC TIMER
8550 036064 000402                :      BR      7$      ; EXIT
8551 036066 004737 036736      6S:      JSR      PC, CI7      ; PROCESS THE PARITY ERROR
8552 036072 032714 000100      7S:      BIT      #BIT06, (R4)      ; SEE IF 'IE' ALREADY SET
8553 036076 001002                :      BNE      8$      ; BR IF SET
8554 036100 004737 042214      :      JSR      PC, SET.IE      ; SET "IE" WITHOUT A "TRE"
8555 036104 012637 177776      8S:      MOV      (SP)+, @#PS      ; RESTORE PROC. STATUS
8556 036110 104413                :      RESREG
8557 036112 000207                :      RTS      PC
8558
8559                : COMMAND INITIATOR
8560
8561                : CALL
8562                :      MOV      #DRVNUM, R1      ; DRIVE NUMBER
8563                :      MOV      #DPB, R2      ; ADDRESS OF DPB
8564                :      JSR      PC, CI?      ; CI?= CI1, CI3, OR CI4
8565                :      WHERE:
8566                :      CI1=DATA TRANSFER
8567                :      CI2=SEARCH REQUESTED BY DATA XFER
8568                :      CI4=NOT DATA TRANSFER
8569
8570 036114 004737 042754      CI1:      JSR      PC, POPQUE      ; REMOVE REQUEST FROM "DRIVES WAIT" QUEUE
8571 036120 010237 034532      :      MOV      R2, TRANSW      ; PUT REQ. IN TRANSFER WAIT QUEUE
8572 036124 010203                :      MOV      R2, R3      ; DPB ADDRESS TO R3
8573 036126 013704 034620      :      MOV      RMADR, R4      ; RMCS1 ADDRESS
8574 036132 010164 000010      :      MOV      R1, RMCS2(R4)      ; SELECT DRIVE
8575 036136 062703 000004      :      ADD      #4, R3      ; DESIRED WORD COUNT
8576 036142 062704 000002      :      ADD      #2, R4      ; RMWC ADDRESS
8577 036146 012324                :      MOV      (R3)+, (R4)+      ; LOAD WORD COUNT
8578 036150 012324                :      MOV      (R3)+, (R4)+      ; LOAD BUFFER ADDRESS
8579 036152 012346                :      MOV      (R3)+, -(SP)      ; LOAD SECTOR AND TRACK

```



8580	036154	004037	041710		JSR	RO,WRT.RM	;CALL THE LOAD(WRITE) ROUTINE
8581	036160	000006			RMDA		;INDEX OF REGISTER TO LOAD
8582	036162	036736			CI7		;ERROR RETURN ADDRESS
8583	036164	012346			MOV	(R3)+, -(SP)	;LOAD CYLINDER ADDRESS
8584	036166	004037	041710		JSR	RO,WRT.RM	
8585	036172	000034			RMDC		
8586	036174	036736			CI7		
8587	036176	016246	000002		MOV	2(R2), -(SP)	;LOAD "COMMAND+GO", "A17&A16", AND "PSEL"
8588	036202	004037	041710		JSR	RO,WRT.RM	
8589	036206	000000			RMCS1		
8590	036210	036736			CI7		
8591	036212	010137	034604		MOV	R1,DTUW	;SET "DATA TRANSFER UNDERWAY"
8592	036216	000137	036700		JMP	CI5	
8593	036222	013704	034620	CI3:	MOV	RMADR,R4	;RMCS1 ADDRESS
8594	036226	010164	000010		MOV	R1,RMCS2(R4)	;SELECT DRIVE
8595	036232	016246	000012		MOV	12(R2), -(SP)	;DESIRED CYLINDER ADDRESS
8596	036236	004037	041710		JSR	RO,WRT.RM	
8597	036242	000034			RMDC		
8598	036244	036736			CI7		
8599	036246	116203	000010		MOV	10(R2),R3	;PICKUP SECTOR ADDRESS
8600					SUB	MXWNDW,R3	;BACKUP BY MAX. SEARCH FOR I/O WINDOW
8601					BGE	1\$	
8602					ADD	#32,R3	
8603	036252	010246		1\$:	MOV	R3, -(SP)	;COMBINE THE ADJUSTED SECTOR WITH
8604	036254	042716	177740		BIC	#177740,(SP)	;CHOP OF ALL EXEMTED BITS ,IF ANY
8605	036260	116266	000011	000001	MOV	11(R2),1(SP)	;THE DESIRED TRACK
8606	036266	004037	041710		JSR	RO,WRT.RM	;LOAD DESIRED TRACK & SECTOR
8607	036272	000006			RMDA		
8608	036274	036736			CI7		
8609	036276	012746	000131		MOV	#131, -(SP)	;START A SEARCH
8610	036302	004037	041710		JSR	RO,WRT.RM	
8611	036306	000000			RMCS1		
8612	036310	036736			CI7		
8613	036312	156137	034606	034534	BISB	ATABIT(R1),SRCHWT	;SET "SEARCH WAIT" KEY
8614	036320	000567			BR	CI5	
8615	036322	013704	034620	CI4:	MOV	RMADR,R4	;RMCS1 ADDRESS
8616	036326	010164	000010		MOV	R1,RMCS2(R4)	;SELECT DRIVE
8617	036332	116203	000002		MOV	2(R2),R3	;PICKUP THE REQUESTED COMMAND
8618	036336	122703	000131		CMPB	#131,R3	;IS IT A SEARCH COMMAND?
8619	036342	001007			BNE	1\$	;BRANCH IF NO
8620	036344	016246	000010		MOV	10(R2), -(SP)	;LOAD DESIRED TRACK & SECTOR
8621	036350	004037	041710		JSR	RO,WRT.RM	
8622	036354	000006			RMDA		
8623	036356	036736			CI7		
8624	036360	000403			BR	2\$	;GO LOAD CYLINDER
8625	036362	122703	000105	1\$:	CMPB	#105,R3	;IS IT A SEEK COMMAND
8626	036366	001007			BNE	3\$	;BRANCH IF NO
8627	036370	016246	000012	2\$:	MOV	12(R2), -(SP)	;LOAD DESIRED CYLINDER
8628	036374	004037	041710		JSR	RO,WRT.RM	
8629	036400	000034			RMDC		
8630	036402	036736			CI7		
8631	036404	000546			BR	CI6	
8632	036406	122703	000115	3\$:	CMPB	#115,R3	;IS IT AN "OFFSET" COMMAND?
8633	036412	001013			BNE	4\$	;BR IF NO
8634	036414	004037	041534		JSR	RO,RO.RM	;MERGE THE OFFSET VALUE INTO RMOF
8635	036420	000032			RMOF		;BUT DON'T CHANGE THE UPPER

8636	036422	036736				CI7		
8637	036424	116216	000001			MOV B	1(R2), (SP)	; BYTE WHEN LOADING THE
8638	036430	004037	041710			JSR	RO, WRT.RM	; REGISTER (RMOF)
8639	036434	000032				RM OF		
8640	036436	036736				CI7		
8641	036440	000530				BR	CI6	; GO START THE COMMAND
8642	036442	122703	000107	4\$:		CM PB	#107, R3	; IS IT A "RECALIBRATE" COMMAND?
8643	036446	001525				BEQ	CI6	; BRANCH IF YES
8644	036450	122703	000117			CM PB	#117, R3	; IS IT A RETURN TO CENTER?
8645	036454	001522				BEQ	CI6	; BRANCH IF YES
8646	036456	122703	000103			CM PB	#103, R3	; IS IT AN "UNLOAD" COMMAND?
8647	036462	001016				BNE	5\$	; BRANCH IF NO
8648	036464	112761	000001	034462		MOV B	#1, DRVACT(R1)	; SET THE DRIVE ACTIVE INDICATOR
8649	036472	105061	034472			CLRB	DRVSTA(R1)	; PUT DRIVE STATUS TO OFFLINE
8650	036476	112761	000001	034540		MOV B	#1, ULDFLG(R1)	; SET "UNLOAD IN PROGRESS" FLAG
8651	036504	010346				MOV	R3, -(SP)	; START THE "UNLOAD" COMMAND
8652	036506	004037	041710			JSR	RO, WRT.RM	
8653	036512	000000				RMCS1		
8654	036514	036736				CI7		
8655	036516	000207				RTS	PC	; RETURN TO USER
8656	036520	122703	000143	5\$:		CM PB	#143, R3	; IS IT A "SET FORMAT" COMMAND?
8657	036524	001014				BNE	6\$	; BRANCH IF NO
8658	036526	004037	041534			JSR	RO, RD.RM	; READ THE OFFSET REGISTER
8659	036532	000032				RM OF		
8660	036534	036736				CI7		
8661	036536	116266	000001	000001		MOV B	1(R2), 1(SP)	; COMBINE "FMT22" "ECI" AND "HCI"
8662	036544	004037	041710			JSR	RO, WRT.RM	; LOAD "FMT22", "ECI", AND/OR "HCI".
8663	036550	000032				RM OF		
8664	036552	036736				CI7		
8665	036554	000436				BR	12\$	
8666	036556	122703	000141	6\$:		CM PB	#141, R3	; IS IT A "GET REGISTER" COMMAND?
8667	036562	001023				BNE	10\$	; BRANCH IF NO
8668	036564	016203	000006	7\$:		MOV	6(R2), R3	; POINTS TO 1ST ADDRESS OF WHERE
8669								; TO PUT THE REGISTER(S)
8670	036570	116237	000010	036606		MOV B	10(R2), 9\$	; INIT. THE INDEX FOR THE FIRST REG.
8671	036576	116205	000011			MOV B	11(R2), R5	; INDEX OF LAST REG. TO MOVE
8672	036602	004037	041534	8\$:		JSR	RO, RD.RM	; READ RH70/RMO3 REGISTER
8673	036606	000000		9\$:		RMCS1		; INDEX OF REG. TO READ
8674	036610	036736				CI7		
8675	036612	012623				MOV	(SP)+, (R3)+	; GET THE CONTENTS OF RH70/RMO3 REG.
8676	036614	023705	036606			CM P	9\$, R5	; LAST REG. BEEN READ?
8677	036620	001414				BEQ	12\$	; GET OUT IF YES
8678	036622	062737	000002	036606		ADD	#2, 9\$	; INCREASE THE INDEX BY 2
8679	036630	000764				BR	8\$	; LOOP--MORE TO READ
8680	036632	122703	000145	10\$:		CM PB	#145, R3	; IS IT A "SELECT DRIVE" COMMAND?
8681	036636	001405				BEQ	12\$	; BRANCH IF YES
8682	036640	010346				MOV	R3, -(SP)	; LOAD THE COMMAND
8683	036642	004037	041710			JSR	RO, WRT.RM	
8684	036646	000000				RMCS1		
8685	036650	036736				CI7		
8686	036652	004737	042754			JSR	PC, POPQUE	; REMOVE REG. FROM QUEUE
8687	036656	052762	000200	000016		BIS	#BIT07, 16(R2)	; SET THE "DONE" BIT
8688	036664	005737	034560			TST	SAVEFG	; SAVE THE RH70/RMO3 REGISTERS?
8689	036670	100002				BPL	13\$	; BRANCH IF NO
8690	036672	004737	042076			JSR	PC, SVRH70	; YES--GO SAVE THE REGISTERS
8691	036676	000207				RTS	PC	; RETURN TO USER

8692	036700	006301			C15:	ASL	R1	
8693	036702	012761	060000	034564		MOV	#60000, TIMER(R1)	;SET A ONE SECOND TIMER
8694	036710	006201				ASR	R1	
8695	036712	112761	000001	034462		MOV	#1, DRVACT(R1)	;SET THE DRIVE ACTIVE
8696	036720	000207				RTS	PC	;RETURN TO THE USER
8697	036722	010346			C16:	MOV	R3, -(SP)	;LOAD THE COMMAND
8698	036724	004037	041710			JSR	RO, WRT.RM	
8699	036730	000000				RMCS1		
8700	036732	036736				CI7		
8701	036734	000761				BR	C15	
8702	036736	032764	010000	000010	C17:	BIT	#BIT12, RMCS2(R4)	;DRIVE NON-EXISTENT ?
8703						BNE	C18	;BR IF YES
8704	036744	005702			1s:	TST	R2	;ANYTHING IN QUEUE ?
8705						BEQ	CI7B	;BR IF NOT
8706	036746	001001				BNE	2S	;BRANCH IF QUEUE IS THERE
8707	036750	000207				RTS	PC	;OTHERWISE EXIT
8708	036752	012762	104000	000016	2S:	MOV	#BIT15!BIT11, 16(R2)	;SET "PARITY" ERROR INDICATOR
8709						JSR	PC, SVRH70	;GO SAVE THE RH70/RM03 REGISTERS
8710	036760	012746	000111		CI7B:	MOV	#111, -(SP)	;DO A "DRIVE CLEAR"
8711	036764	004037	041710			JSR	RO, WRT.RM	
8712	036770	000000				RMCS1		
8713	036772	037036				CI8		
8714	036774	004737	042636		2S:	JSR	PC, EMPTYQ	;EMPTY THE QUEUE
8715	037000	105061	034522			CLRB	DPRQS(R1)	;CLEAR THE PORT REQUEST FLAG
8716	037004	105061	034540			CLRB	ULDFLG(R1)	;CLEAR THE UNLOAD IN QUEUE FLAG
8717	037010	105061	034462			CLRB	DRVACT(R1)	;DRIVE IS IDLE
8718	037014	020237	034532			CMP	R2, TRNSWT	;IF THIS DRIVE HAD AN I/O REQUEST
8719						CMP	R1, DTUW	;IF THIS DRIVE HAD AN I/O REQUEST
8720	037020	001005				BNE	1S	;IN PROGRESS CLEAR ALL OF THE FLAGS
8721	037022	005037	034532			CLR	TRNSWT	
8722	037026	012737	177777	034604		MOV	#-1, DTUW	
8723	037034	000207			1S:	RTS	PC	
8724	037036	104412			CI8:	SAVREG		;SAVE R0 - R5
8725	037040	032764	010000	000010		BIT	#BIT12, RMCS2(R4)	;IS 'NED' SET ?
8726						BNE	1S	;BR IF YES
8727	037046	005001				CLR	R1	
8728	037050	005003				CLR	R3	
8729	037052	105761	034462		1S:	TSTB	DRVACT(R1)	;DRIVE ACTIVE?
8730						BEQ	5S	;BRANCH IF NO
8731	037056	001003				BNE	22S	;BRANCH IF IN ACTIVE
8732	037060	105761	034522			TSTB	DPRQS(R1)	;PORT REQUEST
8733	037064	001443				BEQ	5S	;BRANCH IF NOT
8734	037066	013702	034532		22S:	MOV	TRNSWT, R2	;GET THE "TRANSFER WAIT" QUEUE
8735	037072	020137	034604			CMP	R1, DTUW	;DID THIS DRIVE HAVE AN I/O IN PROGRESS?
8736	037076	001402				BEQ	2S	;BRANCH IF YES
8737	037100	004737	042732			JSR	PC, GETREQ	;GET THE DPB POINTER
8738	037104	005702			2S:	TST	R2	;QUEUE ENTRY FOR DRIVE ?
8739	037106	001413				BEQ	4S	;BR IF NOT
8740	037110	032764	010000	000010		BIT	#BIT12, RMCS2(R4)	; 'NED' SET ?
8741	037116	001404				BEQ	3S	;BR IF NOT
8742	037120	012762	100002	000016		MOV	#BIT15!BIT01, 16(R2)	;SET 'DRIVE NON-EXISTENT' INDICATOR
8743	037126	000403				BR	4S	;CONTINUE
8744	037130	012762	102000	000016	3S:	MOV	#BIT15!BIT10, 16(R2)	;SET "NON-CLEARABLE PARITY" ERROR INDICATOR
8745						JSR	PC, SVRH70	;SAVE RH70/RM03 REGISTERS
8746	037136	012763	177777	034564	4S:	MOV	#-1, TIMER(R3)	;STOP THE TIMER
8747	037144	105061	034462			CLRB	DRVACT(R1)	;SET "DRIVE ACTIVE" TO IDLE

```

8748 037150 105061 034522          CLR8  DPRQS(R1)          ;CLEAR PORT REQUEST FLAG
8749 037154 020137 034604          CMP   R1,DTUW           ;IS THIS DRIVE SETUP FOR A TRANSFER
8750 037160 001005                    BNE   5$                ;BR IF NOT
8751 037162 012737 177777 034604    MOV   #-1,DTUW         ;RESET THE INDICATOR
8752 037170 005037 034532          CLR   TRNSWT           ;CLEAR THE TRANSFER QUEUE
8753 037174 105061 034540          CLR8  ULDFLG(R1)       ;CLEAR UNLOAD FLAG
8754 037200 032764 010000 000010    5$:  BIT   #BIT12,RMCS2(R4) ;'NED' SET ?
8755                    ;      BNE   6$                ;BR IF YES
8756 037206 005201                    ;      INC   R1                ;MOVE TO THE NEXT DRIVE
8757 037210 062703 000002          ADD   #2,R3
8758 037214 042701 177770          BIC   #1<7,R1
8759 037220 001314                    BNE   1$                ;BRANCH IF MORE DRIVES
8760 037222 012737 177777 034604    MOV   #-1,DTUW         ;NO DATA TRANSFERS UNDERWAY
8761 037230 005037 034532          CLR   TRNSWT           ;CLEAR THE 'TRANSFER WAIT' QUEUE
8762 037234 004737 042560          JSR   PC,CLRQUE       ;CLEAR ALL OF THE REQUEST QUEUES
8763 037240 012764 000040 000010    MOV   #BIT05,RMCS2(R4) ;DO A MASSBUS INIT.
8764 037246 000406                    BR    7$                ;CONTINUE
8765 037250 004737 042636          6$:  JSR   PC,EMPTYQ    ;CLEAR THE DRIVE'S QUEUE
8766 037254 105061 034472          CLR8  DRVSTA(R1)      ;SET DRIVE TO OFFLINE
8767 037260 105061 034502          CLR8  DRVSTYP(R1)    ;CLEAR THE DRIVE TYPE INDICATOR
8768 037264 004737 042214          7$:  JSR   PC,SET.IE   ;SET "IE" WITHOUT "TRE"
8769 037270 104413                    RESREG ;RESTORE R0 - R5
8770 037272 000207                    RTS   PC                ;RETURN
8771
8772                    ;LOOK AHEAD ROUTINE
8773                    ;CALL
8774                    ;
8775                    ;      MOV   #DRVNUM,R1          ;DRIVE NUMBER
8776                    ;      MOV   #DPB,R2            ;POINT TO DPB
8777                    ;      JSR   RO,LA              ;GO CHECK THE WINDOW
8778                    ;      RETURN1                 ;ERROR RETURN
8779                    ;      RETURN2                 ;START A SEARCH
8780                    ;      RETURN3                 ;START A DATA TRANSFER
8781
8782 037274 013704 034620  LA:      MOV   RMADR,R4          ;GET RMCS1'S ADDRESS
8783 037300 010164 000010          MOV   R1,RMCS2(R4)    ;SELECT DRIVE
8784 037304 004037 041534          JSR   RO,RO.RM        ;READ DRIVE STATUS
8785 037310 000012                    RMDS  4$                ;
8786 037312 037442                    4$   ;ERROR RETURN ADDRESS
8787 037314 042716 157577          BIC   #1<C020200,(SP) ;ON CYLINDER ?
8788 037320 022726 000200          CMP   #200,(SP)+     ;PIP=0,DRY=1?
8789 037324 001044                    BNE   3$                ;NO
8790 037326 105261 034550          INCB  LACNT(R1)       ;INCREMENT THE LOOK AHEAD COUNT
8791 037332 126137 034550 034626    CMPB  LACNT(R1),MXLACT ;EXCEED MAX?
8792 037340 003033                    BGT   2$                ;BRANCH IF YES
8793 037342 116203 000010          MOVB  10(R2),R3       ;GET DESIRED SECTOR ADDRESS AND
8794 037346 000303                    SWAB  R3                ;MULT. BY 64--ALIGN WITH
8795 037350 006203                    ASR   R3                ;LOOK AHEAD REGISTER
8796 037352 006203                    ASR   R3
8797 037354 012737 000340 177776    MOV   #340,2#PS       ;PRIORITY LEVEL "7"
8798 037362 004037 041534          6$:  JSR   RO,RO.RM        ;READ LOOK AHEAD REGISTER
8799 037366 000020                    RMLA  4$                ;
8800 037370 037442                    4$   ;
8801 037372 021664 000020          CMP   (SP),RMLA(R4)  ;CORRECT LA NUMBER ?
8802 037376 001402                    BEQ   7$                ;YES
8803 037400 005726                    TST   (SP)+           ;NO,CLEAR STACK

```

```

8804 037402 000415
8805 037404 162603
8806 037406 002002
8807 037410 062703 004000
8808 037414 023703 034630
8809 037420 002406
8810 037422 023703 034632
8811 037426 002003
8812 037430 105061 034550
8813 037434 005720
8814 037436 005720
8815 037440 000402
8816 037442 004737 036736
8817 037446 000200
8818
8819
8820
; INTERRUPT SERVICE ROUTINE
8821 037450 112737 000001 034536 ISR:  MOVB  #1,ACTDRV ; SET "ACTIVE DRIVER" FLAG
8822 037456 104412 SAVREG ; SAVE R0 - R5
8823 037460 013704 034620 MOV  RMADR,R4 ; ADDRESS OF RHSCS1
8824 037464 013701 034604 MOV  DTUW,R1 ; GET "DATA TRANSFER UNDERWAY" INDICATOR
8825 037470 002403 BLT  1$ ; BRANCH IF NO DATA TRANSFER UNDERWAY
8826 037472 004737 037514 JSR  PC,TD ; CALL TRANSFER DONE
8827 037476 000402 BR   2$ ; EXIT
8828 037500 004737 037770 1$:  JSR  PC,SC ; CALL SPECIAL CONDITIONS
8829 037504 104413 2$:  RESREG ; RESTORE R0 - R5
8830 037506 105037 034536 CLR  ACTDRV ; CLEAR "ACTIVE DRIVER" FLAG
8831 037512 000002 RTI   ; RETURN
8832
8833 ; TRANSFER DONE ROUTINE
8834
8835 037514 105061 034462 TD:  CLR  DRVACT(R1) ; SET DRIVE ACTIVE INDICATOR TO IDLE
8836 037520 012737 177777 034604 MOV  #-1,DTUW ; NO DATA TRANSFERS UNDERWAY
8837 037526 006301 R1
8838 037530 012761 177777 034564 MOV  #-1,TIMER(R1) ; CANCEL TIMEOUT
8839 037536 006201 ASR  R1
8840 037540 013702 034532 MOV  TRNSWT,R2 ; GET "DPB" ADDRESS FROM THE
8841 037544 005037 034532 CLR  TRNSWT ; TRANSFER WAIT QUEUE--CLEAR QUEUE
8842 037550 052762 000200 000016 BIS  #BIT07,16(R2) ; SET DONE
8843 037556 010164 000010 MOV  R1,RMCS2(R4) ; SELECT THE DRIVE
8844 037562 004037 041534 JSR  R0,RD.AM ; TRANSFER ERROR(TRE=1)?
8845 037566 000000 RMCS1
8846 037570 036736 CI7
8847 037572 006126 ROL  (SP)+
8848 037574 100421 BMI  3$ ; BR IF YES
8849 037576 005737 034560 TST  SAVEFG ; SAVE THE RH70/RM03 REGISTERS?
8850 037602 100002 BPL  1$ ; BRANCH IF NO
8851 037604 004737 042076 JSR  PC,SVRH70 ; YES--SAVE THE REGISTERS
8852 037610 004737 037670 1$:  JSR  PC,WC,HK ; SEE IF WRITE CHECK TO BE PUT IN QUEUE
8853 037614 004737 042732 JSR  PC,GETREG ; GET DPB POINTER
8854 037620 005702 TST  R2 ; ENTRY FOR DRIVE ?
8855 037622 001403 BEQ  2$ ; BR IF NOT
8856 037624 004737 035656 JSR  PC,OPT ; CALL OPTIMIZER
8857 037630 000457 BR   SC ; CHECK OTHER DRIVES
8858
8859 037632 012714 000113 ; THE RELEASE DRIVE COMMAND IS FORCED TO ENTER FOR DUAL PORT OPERATION
2$:  MOV  #113,(R4) ; RELEASE THE DRIVE

```

```

8860 037636 000454          BR      SC      ;CHECK FOR OTHER DRIVES
8861 037640 052762 100100 000016 3$:  BIS      #BIT15:BIT06,16(R2) ;SET DATA ERROR FLAG
8862 037646 004737 042636          JSR      PC,EMPTYQ    ;EMPTY THE "DRIVE'S WAIT" QUEUE
8863 037652 004737 042076          JSR      PC,SVRH70    ;SAVE THE RH70/RM03 REGISTERS
8864 037656 012714 040111          MOV      #40111,(R4)  ;ISSUE A "DRIVE CLEAR"
8865 037662 012714 000113          MOV      #113,(R4)   ;ISSUE A RELEASE TO THE DRIVE
8866 037666 000440          BR      SC      ;CHECK FOR OTHER DRIVES
8867
8868
8869 037670 122762 000002 000024 WC.HK: CMPB     #2,$CODE(R2) ;LAST OPERATION WRITE DATA ?
8870 037676 001404          BEQ      1$          ;BR IF IT WAS
8871 037700 122762 000003 000024          CMPB     #3,$CODE(R2) ;LAST OPERATION WRITE HEADER & DATA ?
8872 037706 001027          BNE      2$          ;BR IF NOT
8873 037710 004037 042656          1$:     JSR      R0,DRVQUE ;PUT THE OPERATION IN THE QUEUE
8874 037714 000424          BR      2$          ;QUEUE IS FULL
8875 037716 005062 000016          CLR      16(R2)     ;CLEAR 'DONE' BIT IN DPB
8876 037722 116262 000234 000027          MOVB     $RMCS1(R2),$PREV0(R2) ;SAVE WRITE OPERATION CODE
8877 037730 016262 000012 000034          MOV      $CYL(R2),$PREVA+2(R2) ;SAVE CYLINDER
8878 037736 016262 000010 000032          MOV      $SEC(R2),$PREVA(R2) ;SAVE SECTOR AND TRACK ADDRESSES
8879 037744 142762 000002 000024          BICB     #2,$CODE(R2) ;CHANGE WRITE TO CHECK
8880 037752 142762 000020 000002          BICB     #20,$COMND(R2) ;CHANGE DRIVER CODE TO WRITE CHECK
8881 037760 152762 000010 000002          BISB     #10,$COMND(R2) ;FINISH CHANGING CODE TO WRITE CHECK
8882 037766 000207          2$:     RTS      PC      ;EXIT
8883
8884          ;SPECIAL CONDITION ROUTINE
8885
8886 037770 116403 000016          SC:     MOVB     RMAS(R4),R3 ;READ "RMAS"
8887 037774 001012          BNE      2$          ;BRANCH IF ANY 'ATA' BITS SET
8888 037776 004037 041534          JSR      R0,RD.RM   ;READ CONTROL AND STATUS REGISTER
8889 040002 000000          ;
8890          ;
8891 040004 040020          ;
8892 040006 106126          ;EXIT IF FAIL TO READ
8893 040010 100403          1$:     ROLB     (SP)+   ;IS "IE"=1?
8894 040012 104001          BMI      1$          ;YES NO DRIVES TO CHECK
8895 040014 004737 042214          ERROR   1           ;REPORT AN ILLEGAL INTERRUPT
8896 040020 000207          1$:     JSR      PC,SET.IE ;SET INTERRUPT ENABLE
8897 040022 005046          2$:     RTS      PC      ;RETURN
8898 040024 110316          ;
8899 040026 012703 000001          2$:     CLR      -(SP)  ;PROCESS ALL DRIVES THAT HAVE
8900 040032 005001          MOVB     R3,(SP)   ;AN "ATA"=1
8901 040034 030316          SC3:    MOV      #1,R3
8902 040036 001005          CLR      R1
8903 040040 005201          SC4:    BIT      R3,(SP) ;ATA=1?
8904 040042 106303          BNE      SC5        ;YES--BRANCH
8905 040044 001373          INC      R1         ;MOVE TO THE NEXT DRIVE
8906 040046 005726          ASLB     R3
8907 040050 000207          BNE      SC3        ;BRANCH IF MORE TO CHECK?
8908 040052 105761 034512          TST      (SP)+     ;CLEAN OFF THE STACK
8909 040056 001402          RTS      PC        ;RETURN TO USER
8910 040060 000137 040764          SC5:    TSTB     DPINT(R1) ;INITIALIZING THE DRIVE ?
8911 040064 105761 034522          1$:     BEQ      1$          ;BR IF NOT
8912 040070 001402          JMP      SC13       ;PROCESS THE DRIVE
8913 040072 000137 040764          1$:     TSTB     DPRQS(R1) ;PORT REQUEST OUTSTANDING ?
8914 040076 105761 034472          BEQ      2$          ;BR IF NOT
8915 040102 003025          2$:     JMP      SC13       ;START THE OUTSTANDING COMMAND
          TSTB     DRVSTA(R1) ;CHECK THE DRIVE STATUS
          BGT      5$          ;BRANCH IF ONLINE

```

8916	040104	105761	034540		TSTB	ULDFLG(R1)		;UNLOAD IN PROGRESS?
8917	040110	003422			BLE	5\$		;BRANCH IF NOT
8918	040112	004737	042732		JSR	PC,GETREQ		;GET DPB POINTER
8919	040116	004737	042076		JSR	PC,SVRH70		;SAVE THE RH70/RM03 REGISTERS
8920	040122	004737	040722		JSR	PC,SC12		;SAVE RMD5, RMER1, RMER2, AND RMMR2
8921								;ALSO DO A DRIVE INIT (DRVINT)
8922	040126	105761	034472		TSTB	DRVSTA(R1)		;DID DRIVE COME ONLINE?
8923	040132	003416			BLE	6\$		;NO---BRANCH
8924	040134	032737	040000	034452	BIT	#BIT14,RMERRS		;WAS THERE AN ERROR?
8925	040142	001002			BNE	3\$		;BR IF ERROR
8926	040144	000137	040612		JMP	SC11		;NO ERROR
8927	040150	013705	034454		MOV	RMERRS+2,R5	3\$:	;YES -- PICKUP RMER1 AND
8928	040154	000500			BR	SC6A		;GO PROCESS THE ERROR
8929	040156	105761	034462		TSTB	DRVACT(R1)	5\$:	;DRIVE ACTIVE WITH COMMAND OR ERROR RECOVERY ?
8930	040162	001027			BNE	SC6		;BR IF EITHER
8931	040164	004737	040722		JSR	PC,SC12		;SAVE RMD5, RMER1, RMER2, AND RMMR2
8932								;ALSO DO A DRVINT
8933	040170	105761	034512		TSTB	DPINT(R1)	6\$:	;TRYING TO INIT THE DRIVE ?
8934	040174	001321			BNE	SC4		;BR IF YES, CHECK ON MORE DRIVES
8935	040176	105761	034472		TSTB	DRVSTA(R1)		;CHECK ON DRIVE'S STATUS
8936	040202	100412			BMI	7\$		;BR IF UNSAFE
8937	040204	032737	020000	034456	BIT	#BIT13,RMERRS+4		;ADDRESS PLUG CHANGED ?
8938	040212	001011			BNE	8\$		;BR IF YES
8939					MOV	#113,-(SP)		;RELEASE COMMAND
8940	040214	012746	000111		MOV	#111,-(SP)		;DRIVE CLEAR
8941	040220	004037	041710		JSR	RD,WRT.RM		;WRITE THE COMMAND INTO RMCS1
8942	040224	000000			RMCS1			;REGISTER INDEX
8943	040226	040562			SCB			;PARITY EXIT ADDRESS
8944	040230	011605			MOV	(SP),R5	7\$:	;PICKUP (RMAS) BEFORE THE ERROR CALL
8945	040232	104002			ERROR	2		;REPORT THE UNEXPECTED ATTENTION
8946	040234	000701			BR	SC4		;GO CHECK FOR MORE ATA'S
8947	040236						8\$:	
8948	040236	104005			ERROR	5		;REPORT THE ADDRESS PLUG CHANGE
8949	040240	000677			BR	SC4		;CHECK FOR MORE DRIVES
8950	040242	006301			ASL	R1	SC6:	;SETUP TO ADDRESS WORDS
8951	040244	012761	177777	034564	MOV	#-1,TIMER(R1)		;STOP THE TIMER
8952	040252	006201			ASR	R1		;RESTORE THE DRIVE ADDRESS
8953	040254	004737	042732		JSR	PC,GETREQ		;GET THE DPB POINTER FROM THE QUEUE
8954	040260	010164	000010		MOV	R1,RMCS2(R4)		;SELECT DRIVE
8955	040264	000137	040612		JMP	SC11		;PROCESS THE SEARCH
8956	040270	004037	041534		JSR	RD,RD.RM		;READ THE RM03'S STATUS REG.
8957	040274	000012			RMD5			
8958	040276	040562			SCB			
8959	040300	011605			MOV	(SP),R5		;AND PUT IT IN R5
8960	040302	006126			ROL	(SP)+		;WAS THERE AN ERROR?
8961	040304	100407			BMI	1\$		;BR IF ERROR
8962	040306	105761	034462		TSTB	DRVACT(R1)		;CHECK DRIVE'S STATE
8963	040312	003137			BGT	SC11		;BR IF DRIVE ACTIVE WITH ORDER
8964	040314	052762	100210	000016	BIS	#BIT15!BIT07!BIT03,16(R2)		;INFORM USER OF ERROR RECOVER COMPLETION
8965	040322	000470			BR	SC7		
8966	040324	004037	041534		JSR	RD,RD.RM	1\$:	;READ ERROR REGISTER #1
8967	040330	000014			RMER1			
8968	040332	040562			SCB			
8969	040334	012605			MOV	(SP)+,R5		;AND SAVE IT IN R5
8970	040336	004737	042076		JSR	PC,SVRH70		;SAVE RH70/RM03 REGISTERS
8971	040342	012746	000111		MOV	#111,-(SP)		;ISSUE A DRIVE CLEAR

8972	040346	004037	041710			JSR	RO,WRT.RM	
8973	040352	000000				RMCS1		
8974	040354	040562				SCB		
8975	040356	006105			SC6A:	ROL	R5	; WAS "UNSAFE" CONDITION =1?
8976	040360	100406				BMI	1\$	; BRANCH IF YES
8977	040362	005702				TST	R2	; ANYTHING IN QUEUE ?
8978	040364	001447				BEQ	SC7	; BR IF NOT
8979	040366	052762	100240	000016		BIS	#BIT15!BIT07!BIT05,16(R2)	; INFORM USER OF ERROR
8980	040374	000443				BR	SC7	
8981	040376	004037	041534		1\$:	JSR	RO,RD.RM	; READ DRIVE STATUS REG. #1
8982	040402	000012				RMDS		
8983	040404	040562				SCB		
8984	040406	011605				MOV	(SP),R5	; SAVE RMDS IN R5
8985	040410	006126				ROL	(SP)↓	; "ERR"=1?
8986	040412	100011				BPL	2\$	; BR IF NO--UNSAFE CLEARED
8987	040414	112761	177777	034472		MOVB	#-1,DRVSTA(R1)	; DRIVE IS UNSAFE
8988	040422	004737	042076			JSR	PC,SVRH70	; SAVE RH70/RM03 REGISTERS
8989	040426	052762	110000	000016		BIS	#BIT15!BIT12,16(R2)	; INFORM USER OF UNSAFE ERROR
8990	040434	000423				BR	SC7	
8991	040436	032705	010000		2\$:	BIT	#BIT12,R5	; "MOL" = 1 ?
8992	040442	001015				BNE	3\$	; BR IF YES
8993	040444	112761	177777	034462		MOVB	#-1,DRVACT(R1)	; ACTIVE ERROR RECOVER
8994	040452	112761	000001	034472		MOV6	#1,DRVSTA(R1)	; ONLINE
8995	040460	006301				ASL	R1	
8996	040462	012761	072460	034564		MOV	#30000.,TIMER(R1)	; START 30 SECOND TIMER
8997	040470	006201				ASR	R1	
8998	040472	000137	040040			JMP	SC4	
8999	040476	052762	100220	000016	3\$:	BIS	#BIT15!BIT07!BIT04,16(R2)	; INFORM USER OF ERROR
9000	040504	105061	034462		SC7:	CLRB	DRVACT(R1)	; DRIVE IS IDLE
9001						JSR	PC,EMPTYQ	; DUMP THE QUEUE
9002	040510	004737	042754			JSR	PC,POPQUE	; REMOVE THE QUEUE
9003	040514	105761	034540			TSTB	ULDFLG(R1)	; UNLOAD IN RM0GRESS OR QUEUE?
9004	040520	003002				BGT	1\$	; BR IF NOT
9005	040522	105061	034540			CLRB	ULDFLG(R1)	; CLEAR UNLOAD FLAG
9006	040526	116164	034606	000016	1\$:	MOVB	ATABIT(R1),RMAS(R4)	; CLEAR ATTENTION BIT
9007	040534	105761	034472			TSTB	DRVSTA(R1)	; IS THE DRIVE UNSAFE ?
9008	040540	100406				BMI	2\$	; BR IF IT IS
9009						MOV	#113,-(SP)	; RELEASE COMMAND
9010	040542	012746	000111			MOV	#111,-(SP)	; DRIVE CLEAR COMMAND
9011	040546	004037	041710			JSR	RO,WRT.RM	; WRITE THE COMMAND INTO RPCS1
9012	040552	000000				RMCS1		; REGISTER INDEX
9013	040554	040562				SCB		; PARITY EXIT ADDRESS
9014	040556	000137	040040		2\$:	JMP	SC4	; CHECK FOR MORE DRIVES
9015	040562	105761	034462		SCB:	TSTB	DRVACT(R1)	; IS DRIVE IDLE?
9016	040566	001405				BEQ	1\$	; YES--BRANCH
9017	040570	004737	042732			JSR	PC,GETREQ	; GET DPB POINTER
9018	040574	004737	036736			JSR	PC,C17	; PROCESS THE PARITY ERROR
9019	040600	000402				BR	2\$	; CONTINUE
9020	040602				1\$:			
9021						JSR	PC,C17	; PROCESS THE PARITY ERROR
9022	040602	004737	036760			JSR	PC,C17B	; PROCESS THE UNCORRECTABLE PARITY ERROR
9023	040606	000137	040040		2\$:	JMP	SC4	; CHECK MORE DRIVES
9024	040612	105761	034540		SC11:	TSTB	ULDFLG(R1)	; "UNLOAD IN PROGRESS"?
9025	040616	003402				BLE	1\$	; BRANCH IF NO
9026	040620	105061	034540			CLRB	ULDFLG(R1)	; CLEAR UNLOAD FLAG
9027	040624	105061	034462		1\$:	CLRB	DRVACT(R1)	; SET DRIVE IDLE



```

9028 040630 136137 034606 034534 BITB ATABIT(R1),SRCHWT ;DOING A SEARCH OPERATION FOR
9029 ;AN I/O COMMAND?
9030 040636 001012 BNE 2$ ;BRANCH IF YES
9031 040640 004737 042754 JSR PC,POPQUE ;REMOVE REQUEST FROM QUEUE
9032 040644 052762 000200 000016 BIS #BIT07,16(R2) ;SET "DONE" BIT
9033 040652 005737 034560 TST SAVEFG ;SAVE THE REGISTERS?
9034 040656 100002 BPL 2$ ;BRANCH IF NO
9035 040660 004737 042076 JSR PC,SVRH70 ;YES--SAVE ALL OF THE RH70/RM03 REG'S
9036 040664 116164 034606 000016 2$: MOVB ATABIT(R1),RMAS(R4) ;CLEAR ATTENTION BIT
9037 040672 146137 034606 034534 BICB ATABIT(R1),SRCHWT ;CLEAR IMPLIED SEEK SET
9038 040700 006301 ASL R1 ;WORD INDEX
9039 040702 012761 177777 034564 MOV #-1,TIMER(R1) ;STOP CLOCK
9040 040710 006201 ASR R1 ;RESTORE R1
9041 040712 004737 035656 JSR PC,OPT ;START A REQUEST
9042 040716 000137 040040 JMP SC4 ;CHECK FOR MORE DRIVES
9043 040722 010164 000010 SC12: MOV R1,RMCS2(R4) ;SELECT DRIVE
9044 040726 016437 000012 034452 MOV RMDS(R4),RMERRS ;SAVE THE FOUR REGISTERS THAT
9045 040734 016437 000014 034454 MOV RMER1(R4),RMERRS+2 ;WILL TELL US SOMETHING
9046 040742 016437 000042 034456 MOV RMER2(R4),RMERRS+4
9047 040750 016437 000040 034460 MOV RMMR2(R4),RMERRS+6
9048 ; JSR RO,DRVINT ;INIT. THE STATE OF THE DRIVE
9049 ; BR 1$ ;TAKE ERROR EXIT
9050 040756 000207 RTS PC ;RETURN
9051 040760 005726 1$: TST (SP)+ ;POP PC OFF OF THE STACK
9052 040762 000677 BR SC8 ;PROCESS THE PARITY ERROR
9053 040764 006301 SC13: ASL R1 ;SETUP TO ADDRESS WORDS
9054 040766 012761 177777 034564 MOV #-1,TIMER(R1) ;STOP THE TIMER
9055 040774 006201 ASR R1 ;
9056 040776 010164 000010 MOV R1,RMCS2(R4) ;SELECT THE DRIVE
9057 041002 116164 034606 000016 MOVB ATABIT(R1),RMAS(R4) ;CLEAR THE ATTENTION BIT
9058 041010 105761 034512 1$: TSTB DPINT(R1) ;INITIALIZING THE DRIVE ?
9059 041014 001424 BEQ 2$ ;BR IF NOT
9060 041016 105061 034512 CLRB DPINT(R1) ;CLEAR THE INIT INDICATOR
9061 041022 004037 035050 JSR RO,DRVINT ;GO INIT THE DRIVE
9062 041026 000240 NOP ;DUMMY PARITY ERROR RETURN
9063 041030 105761 034472 TSTB DRVSTA(R1) ;DRIVE ONLINE ?
9064 041034 003014 BGT 2$ ;BR IF YES -- START ORDER
9065 041036 005702 TST R2 ;QUEUE ENTRY FOR THE DRIVE
9066 041040 001426 BEQ 3$ ;BR IF NOT
9067 041042 004737 042732 JSR PC,GETREQ ;GET DPB ADDRESS
9068 041046 052762 140000 000016 BIS #BIT15:BIT14,16(R2) ;INFORM USER THAT DRIVE OFFLINE
9069 041054 004737 042076 JSR PC,SVRH70 ;SAVE THE REGISTERS
9070 ; JSR PC,EMPTYQ ;EMPTY THE REQUEST QUEUE
9071 041060 004737 042754 JSR PC,POPQUE ;REMOVE THE QUEUE
9072 041064 000414 BR 3$ ;
9073 041066 032764 004000 000000 2$: BIT #BIT11,RMCS1(R4) ;DVA SET ?
9074 041074 001006 BNE 4$ ;SET THEN CALL OPT
9075 041076 006301 ASL R1 ;
9076 041100 012761 060000 034564 MOV #60000,TIMER(R1) ;
9077 041106 006201 ASR R1 ;
9078 041110 000402 BR 3$ ;
9079 041112 004737 035656 4$: JSR PC,OPT ;START THE PENDING REQUEST
9080 041116 000137 040040 3$: JMP SC4 ;PROCESS OTHER DRIVES
9081 ;
9082 ;/RM03 TIMER ROUTINE
9083 ;CALL

```



N13

CZRM880 RM03/2 PERF EXER  
CZRM88.P11 21-NOV-77 15:34

MACY11 30(1046) 22-NOV-77 10:06 PAGE 170  
SINGLE/DUAL PORT RH70/RM03 DRIVER (REV 5.1)-24-AUG-77

SEQ 0169

```

9140      ;      MOV      #BIT05,RMCS2(R4) ;"INIT" THE MASS BUS
9141      041316 105061 034462      ;      CLRB     DRVACT(R1) ;DRIVE IS IDLE
9142      041322 105061 034540      ;      CLRB     ULDFLG(R1) ;CLEAR THE UNLOAD FLAG
9143      041326 005037 034532      ;      CLR      TRANSW   ;CLEAR DPB ADDRESS
9144      041332 012737 177777      034604      ;      MOV      #-1,DTUM  ;CLEAR THE TRANSFER DRIVE #
9145      041340 000470      ;      BR      ST09      ;DON'T BOTHER OTHER DRIVES
9146      041342 116405 000016      ST02:      MOVVB    RMAS(R4),R5 ;READ ATTENTION REG
9147      041346 136105 034606      ;      BITB     ATABIT(R1),R5 ;IS ATTENTION FOR THIS DRIVE UP ?
9148      041352 001007      ;      BNE     ST03      ;YES--BRANCH
9149      041354 105761 034512      ;      TSTB    DPINT(R1) ;TRYING TO INITIALIZE THE DRIVE ?
9150      041360 001021      ;      BNE     ST06      ;BR IF YES - DRIVE NOT ONLINE
9151      041362 105761 034522      ;      TSTB    DPRQS(R1) ;OUTSTANDING PORT REQUEST FOR THE DRIVE ?
9152      041366 001035      ;      BNE     ST07      ;BR IF YES - NO RESPONSE TO REQUEST
9153      041370 000454      ;      BR      ST09      ;OTHER WISE EXIT
9154      041372 105761 034512      ST03:      TSTB    DPINT(R1) ;INITIALIZING THE DRIVE ?
9155      041376 001003      ;      BNE     IS       ;BR IF INIT PENDING
9156      041400 105761 034522      ;      TSTB    DPRQS(R1) ;PORT REQUEST PENDING ?
9157      041404 001446      ;      BEQ     ST09      ;BR IF NOT
9158      041406 012763 177777      034564      IS:      MOV      #-1,TIMER(R3) ;STOP THE TIMER
9159      041414 000442      ;      BR      ST09      ;EXIT
9160      041416 004737 037036      ST05:      JSR      PC,CIB   ;GO HANDLE THE PARITY ERROR
9161      041422 000437      ;      BR      ST09
9162      041424 105061 034512      ST06:      CLRB     DPINT(R1) ;CLEAR THE INITIALIZE INDICATOR
9163      041430 105061 034472      ;      CLRB     DRVSTA(R1) ;SET UNIT OFFLINE
9164      041434 012763 177777      034564      ;      MOV      #-1,TIMER(R3) ;STOP THE TIMER
9165      041442 004737 042732      ;      JSR      PC,GETREQ ;GET THE DPB ADDRESS
9166      041446 005702      ;      TST     R2       ;REQUEST IN QUEUE ?
9167      041450 001424      ;      BEQ     ST09      ;BR IF NOT
9168      041452 052762 140000 000016      ;      BIS     #BIT15:BIT14,16(R2) ;INFORM THE USER DRIVE NOT AVAILABLE
9169      041460 000414      ;      BR      ST08      ;FINISH
9170      041462 012763 177777      034564      ST07:      MOV      #-1,TIMER(R3) ;STOP THE TIMER
9171      041470 105061 034522      ;      CLRB     DPRQS(R1) ;CLEAR PORT REQUEST INDICATOR
9172      041474 004737 042732      ;      JSR      PC,GETREQ ;GET DPB ADDRESS
9173      041500 005702      ;      TST     R2       ;QUEUE ENTRY FOR DRIVE ?
9174      041502 001407      ;      BEQ     ST09      ;BR IF NONE
9175      041504 012762 100004 000016      ;      MOV     #BIT15:BIT2,16(R2) ;INFORM USER OF PORT REQUEST ERROR
9176      041512 004737 042636      ST08:      JSR      PC,EMPTYQ ;CLEAR THE QUEUE FOR THE DRIVE
9177      041516 004737 042076      ;      JSR      PC,SVRH70 ;SAVE THE REGISTERS
9178      041522 012604      ST09:      MOV      (SP)+,R4 ;RESTORE R4
9179      041524 012603      ;      MOV     (SP)+,R3 ;RESTORE R3
9180      041526 012602      ;      MOV     (SP)+,R2 ;RESTORE R2
9181      041530 012601      ;      MOV     (SP)+,R1 ;RESTORE R1
9182      041532 000207      ;      RTS     PC      ;RETURN
9183
9184      ;ROUTINE TO READ A RH70/RM03 REGISTER
9185
9186      ;CALL
9187      ;      JSR      RD,RD.RM ;GO READ A REGISTER
9188      ;      INDEX  ERRADR   ;REG. INDEX FROM BASE
9189      ;      ERRADR ;ERROR ADDRESS--PROCESS ERROR STARTING
9190      ;      RETURN ;AT THIS ADDRESS
9191      ;      ;CONTENTS OF REG. IS ON THE STACK
9192
9193      041534 013737 034616 041676      RD.RM:      MOV      MCPMX,RD.RM2 ;MAX. RETRYS ALLOWED
9194      041542 011646      ;      MOV     (SP),-(SP) ;SAVE RD FOR RETURN
9195      041544 013737 034620 041560      ;      MOV     RMADR,RD.ADR ;FORM THE DESIRED ADDRESS

```

9196	041552	062037	041560			ADD	(R0)+, RD.ADR	;	USING THE BASE AND THE INDEX
9197	041556	013727				RD.RM1: MOV	2(PC)+, (PC)+	;	READ THE DESIRED REGISTER OF THE RM03
9198	041560	000000				RD.ADR: .WORD	0	;	ADDRESS IS FORMED HERE
9199	041562	000000				RD.WRD: .WORD	0	;	REG. CONTENTS PUT HERE
9200	041564	013766	041562	000002		MOV	RD.WRD, 2(SP)	;	RETURN IT TO THE USER
9201	041572	013746	034620			MOV	RMADR, -(SP)	;	PUT THE ADDRESS ON THE STACK
9202	041576	062716	000010			ADD	#RMCS2, (SP)	;	FORM THE ADDRESS OF RMCS2
9203	041602	032736	010000			BIT	#BIT12, 2(SP)+	;	CHECK THE 'NED' BIT
9204	041606	001035				BNE	RD.RM3	;	BR IF DRIVE NON-EXISTENT
9205	041610	017746	173004			MOV	ARMADR, -(SP)	;	READ RMCS1
9206	041614	032716	020000			BIT	#BIT13, (SP)	;	DID MCPE SET?
9207	041620	001002				BNE	1\$	;	BRANCH IF YES
9208	041622	022620				CMP	(SP)+, (R0)+	;	ADJUST FOR RETURN
9209	041624	000430				BR	RD.RM4	;	EXIT
9210	041626								
9211	041626	104003				1\$: ERROR	3	;	REPORT "MCPE" ERROR
9212	041630	005737	034604			TST	DTUW	;	DATA TRANSFER UNDERWAY?
9213	041634	100405				BMI	2\$	;	NO--BRANCH
9214	041636	032716	040000			BIT	#BIT14, (SP)	;	NO--"TRE"=1?
9215	041642	001402				BEQ	2\$	;	NO--BRANCH
9216	041644	005726				TST	(SP)+	;	YES--CLEAN OFF THE STACK AND
9217	041646	000415				BR	RD.RM3	;	TAKE THE FATAL ERROR EXIT
9218	041650	052716	040000			2\$: BIS	#BIT14, (SP)	;	CLEAR "MCPE" BY SENDING A "1" TO "TRE"
9219	041654	000316				SWAB	(SP)	;	POSITION BEFORE WRITING
9220	041656	013737	034620	041672		MOV	RMADR, 3\$	;	FORM ADDRESS OF HIGH BYTE
9221	041664	005237	041672			INC	3\$		
9222	041670	112637				MOVB	(SP)+, 2(PC)+	;	WRITE THE HIGH BYTE OF RMCS1
9223	041672	000000				3\$: .WORD	0	;	ADDRESS STORAGE
9224	041674	005327				DEC	(PC)+	;	EXCEEDED MAX. RETRYS
9225	041676	000003				RD.RM2: .WORD	3		
9226	041700	002326				BGE	RD.RM1	;	BRANCH IF NO
9227	041702	011000				RD.RM3: MOV	(R0), R0	;	FATAL ERROR EXIT
9228	041704	012616				MOV	(SP)+, (SP)		
9229	041706	000200				RD.RM4: RTS	R0		
9230									
9231									
9232									
9233									
9234									
9235									
9236									
9237									
9238									
9239									
9240	041710	013737	034616	042062		WRT.RM: MOV	MCPEMX, WRT.R2	;	MAX RETRYS ALLOWED
9241	041716	016637	000002	041776		MOV	2(SP), WRT.WD	;	SAVE THE WORD TO WRITE
9242	041724	012616				MOV	(SP)+, (SP)	;	ADJUST THE STACK
9243	041726	012037	042000			MOV	(R0)+, WRT.AD	;	GET INDEX OF REGISTER TO BE WRITTEN
9244	041732	001015				BNE	1\$	;	BRANCH IF NOT RMCS1
9245	041734	122737	000150	041776		CMPB	#150, WRT.WD	;	IS THE COMMAND FOR DATA TRANSFERS?
9246	041742	002411				BLT	1\$	;	YES--DON'T GET THE OLD A16 & A17, & PSEL
9247	041744	004037	041534			JSR	R0, RD.RM	;	NO---COMBINE A16&A17, & PSEL WITH
9248	041750	000000				RMCS1		;	THE COMMAND BEFORE SENDING IT TO
9249	041752	042066				WRT.R3		;	THE RH70/RM03
9250	041754	000316				SWAB	(SP)		
9251	041756	042716	177770			BIC	#1C7, (SP)		

; ROUTINE TO WRITE A REGISTER

; CALL

```

MOV DATA, -(SP)
JSR R0, WRT.RM
INDEX
ERRADR
RETURN

```

```

; DATA TO BE LOADED ON THE STACK
; CALL THE ROUTINE TO LOAD(WRITE) THE REG.
; INDEX OF THE REGISTER TO BE LOADED
; ADDRESS TO RETURN TO ON AN ERROR
; ERROR FREE RETURN

```

```

; MAX RETRYS ALLOWED
; SAVE THE WORD TO WRITE
; ADJUST THE STACK
; GET INDEX OF REGISTER TO BE WRITTEN
; BRANCH IF NOT RMCS1
; IS THE COMMAND FOR DATA TRANSFERS?
; YES--DON'T GET THE OLD A16 & A17, & PSEL
; NO---COMBINE A16&A17, & PSEL WITH
; THE COMMAND BEFORE SENDING IT TO
; THE RH70/RM03

```

```

9252 041762 112637 041777          MOVB      (SP)+,WRT.WD+1
9253 041766 063737 034620 042000 1$:      ADD      RMADR,WRT.AD      ;FORM THE ADDRESS OF THE DISK REG.
9254 041774 012737          WRT.R1:  MOV      (PC)+,2(PC)+ ;LOAD THE DESIRED REG.
9255 041776 000000          WRT.WD:  .WORD    0          ;WORD TO WRITE GOES HERE
9256 042000 000000          WRT.AD:  .WORD    0          ;ADDRESS IS FORMED HERE
9257 042002 013746 034620          MOV      RMADR,-(SP)      ;PUT THE ADDRESS ON THE STACK
9258 042006 062716 000010          ADD      #RMCS2,(SP)     ;FORM THE ADDRESS OF RMCS2
9259 042012 032736 010000          BIT      #BIT12,2(SP)+   ;CHECK THE 'MED' BIT
9260 042016 001023          BNE      WRT.R3          ;BR IF DRIVE NON-EXISTENT
9261 042020 004037 041534          JSR      RO,RD.RM        ;CHECK FOR PARITY ERROR ON WRITE
9262 042024 000014          RMER1
9263 042026 042066          WRT.R3
9264 042030 032726 000010          BIT      #BIT03,(SP)+
9265 042034 001416          BEQ      WRT.R4          ;BRANCH IF "PAR=0"
9266 042036 016037 177776 042050          MOV      -2(RO),1$      ;PICKUP THE INDEX
9267 042044 004037 041534          JSR      RO,RD.RM        ;READ THE REG.
9268 042050 000000          1$:      .WORD    0          ;REG. INDEX
9269 042052 042066          WRT.R3
9270 042054 104004          ERROR    4              ;RETURN TO THIS ADDRESS ON ERROR
9271 042056 005726          TST      (SP)+          ;REPORT THE PARITY ON WRITE ERROR
9272 042060 005327          DEC      (PC)+          ;CLEAR OFF THE STACK
9273 042062 000003          WRT.R2:  .WORD    3          ;DECREMENT THE ERROR COUNT
9274 042064 002343          BGE      WRT.R1          ;RETRY COUNTER
9275 042066 011000          WRT.R3:  MOV      (RO),RO  ;TRY AGAIN IF NOT FINISHED
9276 042070 000401          BR       WRT.R5          ;TAKE TH: "PARITY ON WRITE" ERROR EXIT
9277 042072 005720          WRT.R4:  TST      (RO)+   ;EXIT
9278 042074 000200          WRT.R5:  RTS      RO      ;ADJUST FOR ERROR FREE EXIT
9279
9280          ;ROUTINE TO SAVE THE RH70/RP04/5/RM03 REGISTERS AS PER DPB+14
9281          ;CALL
9282          ;
9283          MOV      #DPBNUM,R2 ;DPB POINTER TO R2
9284          JSR      PC,SVRH70  ;SAVE THE DRIVES REG'S
9285
9286          SVRH70: SAVREG
9287          TST      R2          ;SAVE R0 - R5
9288          BEQ      6$          ;QUEUE ENTRY FOR THE DRIVE ?
9289          MOV      RMADR,R4  ;BR IF NONE
9290          MOVB     (R2),RMCS2(R4) ;SELECT DRIVE
9291          MOV      14(R2),R3 ;GET THE ERROR TABLE POINTER
9292          BEQ      6$          ;EXIT IF NO ADDRESS
9293          CLR      3$          ;COUNTER & POINTER
9294          1$:  CMP      3$,#RMD8   ;REACHED THE BUFFER REGISTER ?
9295          BNE      2$          ;BR IF NOT
9296          BIT      #BIT07,RMCS2(R4) ;'OR' SET ?
9297          BNE      2$          ;BR IF SET
9298          CLR      (R3)+      ;STORE RMD8 AS ZEROES
9299          BR       4$          ;CONTINUE
9300          2$:  JSR      RO,RD.RM ;READ THE SELECTED REGISTER
9301          3$:  .WORD    0          ;REGISTER INDEX
9302          5$:  MOV      (SP)+,(R3)+   ;ERROR RETURN ADDRESS
9303          MOV      3$,#RMEC2  ;STORE THE REGISTER CONTENTS
9304          4$:  CMP      3$,#2,3$ ;REACHED THE END ?
9305          BEQ      6$          ;BR IF YES
9306          ADD      #2,3$      ;INCREMENT THE REGISTER INDEX
9307          BR       1$          ;CONTINUE READING THE REGISTERS

```

9308 042204 004737 036736  
 9309 042210 104413  
 9310 042212 000207  
 9311  
 9312  
 9313  
 9314  
 9315  
 9316  
 9317  
 9318 042214 010446  
 9319 042216 013704 034620  
 9320 042222 010164 000010  
 9321 042226 011446  
 9322 042230 052716 040000  
 9323 042234 000316  
 9324 042236 112714 000100  
 9325 042242 032764 010000 000010  
 9326 042250 001002  
 9327 042252 005726  
 9328 042254 000402  
 9329 042256 112664 000001  
 9330 042262 012604  
 9331 042264 000207  
 9332  
 9333  
 9334 042266 000  
 9335 042267 000  
 9336 042270 000  
 9337 042271 000  
 9338 042272 000  
 9339 042273 000  
 9340 042274 000  
 9341 042275 000  
 9342  
 9343  
 9344  
 9345 042276 042360  
 9346 042300 042400  
 9347 042302 042420  
 9348 042304 042440  
 9349 042306 042460  
 9350 042310 042500  
 9351 042312 042520  
 9352 042314 042540  
 9353  
 9354  
 9355  
 9356 042316 042360  
 9357 042320 042400  
 9358 042322 042420  
 9359 042324 042440  
 9360 042326 042460  
 9361 042330 042500  
 9362 042332 042520  
 9363 042334 042540

```

5$: JSR PC,C17 ;PROCESS THE UNCORRECTABLE PARITY ERROR
6$: RESREG ;RESTORE R0 - R5
RTS PC ;RETURN

;ROUTINE TO SET THE INTERRUPT WITHOUT GETTING A "TRE"
;CALL
; MOV #DRVNUM,R1 ;DRIVE NUMBER TO R1
; JSR PC,SET.IE ;SET "IE"
; RETURN

SET.IE: MOV R4, -(SP) ;SAVE R4
MOV RMADR,R4 ;PICKUP ADDRESS OF RMCS1
MOV R1, RMCS2(R4) ;SELECT DRIVE
MOV (R4), -(SP) ;READ RMCS1
BIS #BIT14, (SP) ;SET THE "TRE" BIT OF THE WORD READ
SWAB (SP) ;ADJUST FOR DATO
MOVB #BIT06, (R4) ;SET "IE"
BIT #BIT12, RMCS2(R4) ;IS "NED"=1?
BNE 1$ ;YES--CLEAR "TRE"
TST (SP)+ ;CLEAN OFF THE STACK
BR 2$

1$: MOVB (SP)+, 1(R4) ;CLEAR "TRE"
2$: MOV (SP)+, R4 ;RESTORE R4
RTS PC ;RETURN TO CALLER

;QUEUE COUNT
QCNT: .BYTE 0 ;DRIVE 0
.BYTE 0 ;DRIVE 1
.BYTE 0 ;DRIVE 2
.BYTE 0 ;DRIVE 3
.BYTE 0 ;DRIVE 4
.BYTE 0 ;DRIVE 5
.BYTE 0 ;DRIVE 6
.BYTE 0 ;DRIVE 7

;QUEUE INPUT POINTERS
QINPT: .WORD QDRV0 ;DRIVE 0
.WORD QDRV1 ;DRIVE 1
.WORD QDRV2 ;DRIVE 2
.WORD QDRV3 ;DRIVE 3
.WORD QDRV4 ;DRIVE 4
.WORD QDRV5 ;DRIVE 5
.WORD QDRV6 ;DRIVE 6
.WORD QDRV7 ;DRIVE 7

;QUEUE OUTPUT POINTERS
QOUTPT: .WORD QDRV0 ;DRIVE 0
.WORD QDRV1 ;DRIVE 1
.WORD QDRV2 ;DRIVE 2
.WORD QDRV3 ;DRIVE 3
.WORD QDRV4 ;DRIVE 4
.WORD QDRV5 ;DRIVE 5
.WORD QDRV6 ;DRIVE 6
.WORD QDRV7 ;DRIVE 7

```

```

9364
9365 042336 042360 QSTART: .WORD QDRV0 ;DRIVE 0 START ADDRESS
9366 042340 042400 QSTOP: .WORD QDRV1 ;DRIVE 0 STOP ADDRESS & DRIVE 1 START ADDRESS
9367 042342 042420 .WORD QDRV2 ;STOP DRIVE 1--START DRIVE 2
9368 042344 042440 .WORD QDRV3 ;STOP DRIVE 2--START DRIVE 3
9369 042346 042460 .WORD QDRV4 ;STOP DRIVE 3--START DRIVE 4
9370 042350 042500 .WORD QDRV5 ;STOP DRIVE 4--START DRIVE 5
9371 042352 042520 .WORD QDRV6 ;STOP DRIVE 5--START DRIVE 6
9372 042354 042540 .WORD QDRV7 ;STOP DRIVE 6--START DRIVE 7
9373 042356 042560 .WORD QTERM ;STOP DRIVE 7
9374
9375 ;DRIVE REQUEST QUEUES
9376
9377 042360 000010 QDRV0: .BLKW 10
9378 042400 000010 QDRV1: .BLKW 10
9379 042420 000010 QDRV2: .BLKW 10
9380 042440 000010 QDRV3: .BLKW 10
9381 042460 000010 QDRV4: .BLKW 10
9382 042500 000010 QDRV5: .BLKW 10
9383 042520 000010 QDRV6: .BLKW 10
9384 042540 000010 QDRV7: .BLKW 10
9385 042560 042560 QTERM=.
9386
9387 ;ROUTINE TO CLEAR ALL OF THE REQUEST QUEUES
9388
9389 ;CALL
9390 ; JSR PC,CLRQUE
9391
9392 042560 104412 CLRQUE: SAVREG ;SAVE R0 - R5
9393 042562 012702 042266 MOV #QCNT,R2 ;ZERO THE QUEUE COUNTS
9394 042566 005022 CLR (R2)+ ;DRIVES 0 & 1
9395 042570 005022 CLR (R2)+ ;DRIVES 2 & 3
9396 042572 005022 CLR (R2)+ ;DRIVES 4 & 5
9397 042574 005022 CLR (R2)+ ;DRIVES 6 & 7
9398 042576 012703 000010 MOV #8,R3 ;MOVE THE STARTING
9399 042602 012701 042336 MOV #QSTART,R1 ;ADDRESS OF THE QUEUE INTO
9400 042606 012122 1$: MOV (R1)+,(R2)+ ;THE QUEUE INPUT POINTER
9401 042610 005303 DEC R3
9402 042612 001375 BNE 1$
9403 042614 012703 000010 MOV #8,R3 ;MOVE THE STARTING ADDRESS
9404 042620 012701 042336 MOV #QSTART,R1 ;OF THE QUEUE INTO THE
9405 042624 012122 2$: MOV (R1)+,(R2)+ ;QUEUE OUTPUT POINTER
9406 042626 005303 DEC R3
9407 042630 001375 BNE 2$
9408 042632 104413 RESREG ;RESTORE R0 - R5
9409 042634 000207 RTS PC
9410
9411 ;EMPTY THE QUEUE SPECIFIED BY R1
9412
9413 ;CALL
9414 ; MOV DRVNUM,R1 ;DRIVE NUMBER TO R1
9415 ; JSR PC,EMPTYQ
9416
9417 042636 105061 042266 EMPTYQ: CLRB QCNT(R1) ;CLEAR NUMBER OF ITEMS IN QUEUE
9418 042642 006301 ASL R1
9419 042644 016161 042276 042316 MOV QINPT(R1),QOUTPT(R1) ;SET OUTPUT QUEUE POINTER=INPUT POINTER

```

```

9420 042652 006201          ASR      R1
9421 042654 000207          RTS      PC
9422
9423          ;ROUTINE TO PUT A REQUEST IN QUEUE
9424          ;CALL
9425          ;
9426          ;      MOV      #DRVNUM,R1          ;DRIVE NUMBER
9427          ;      MOV      #DPB,R2          ;ADDRESS OF PARAMETER BLOCK
9428          ;      JSR      RO,DRVQUE          ;GO PUT REQUEST IN QUEUE
9429          ;      RETURN1          ;RETURN HERE IF QUEUE IS FULL
9430          ;      RETURN2          ;RETURN HERE IF REQUEST IS IN QUEUE
9431
9432 042656 122761 000010 042266 DRVQUE: CMPB      #10,QCNT(R1)          ;IS QUEUE FULL?
9433 042664 001421          BEQ      2$          ;BR IF YES-TAKE RETURN1
9434 042666 105261 042266          INCB     QCNT(R1)          ;INCREMENT QUEUE COUNT
9435 042672 006301          ASL      R1
9436 042674 010271 042276          MOV      R2,@QINPT(R1)          ;PUT THIS REQUEST IN QUEUE
9437 042700 062761 000002 042276          ADD      #2,QINPT(R1)          ;UPDATE THE QUEUE POINTER
9438 042706 026161 042276 042340          CMP      QINPT(R1),QSTOP(R1) ;TIME TO RESET THE POINTER
9439 042714 001003          BNE     1$          ;BRANCH IF NO
9440 042716 016161 042336 042276          MOV      QSTART(R1),QINPT(R1) ;YES--RESET POINTER
9441 042724 006201          1$:      ASR      R1
9442 042726 005720          TST     (R0)+          ;TAKE RETURN 2
9443 042730 000200          2$:      RTS      RO          ;RETURN TO USER
9444
9445          ;ROUTINE TO GET THE "DPB" ADDRESS OF NEXT REQUEST IN QUEUE
9446          ;CALL
9447          ;
9448          ;      MOV      #DRVNUM,R1          ;DRIVE NUMBER TO R1
9449          ;      JSR      PC,GETREQ          ;GO GET THE REQUEST
9450          ;      RETURN          ;R2="DPB" ADDRESS OF THE REQUEST
9451          ;      ;R2=0 IF NO REQUEST IN QUEUE
9452
9453 042732 005002          GETREQ: CLR      R2
9454 042734 105761 042266          TSTB     QCNT(R1)          ;IS THERE ANY REQUEST IN QUEUE?
9455 042740 001404          BEQ      2$          ;NO---BRANCH
9456 042742 006301          1$:      ASL      R1
9457 042744 017102 042316          MOV      @QOUTPT(R1),R2          ;PICKUP "DPB" POINTER FOR THIS DRIVE
9458 042750 006201          ASR      R1
9459 042752 000207          2$:      RTS      PC          ;RETURN TO USER
9460
9461          ;ROUTINE TO "POP" THE REQUEST FROM QUEUE
9462          ;CALL
9463          ;
9464          ;      MOV      #DRVNUM,R1          ;DRIVE NUMBER TO R1
9465          ;      JSR      PC,POPQUE          ;CALL TO REMOVE REQUEST
9466          ;      RETURN          ;R2=ADDRESS OF DPB REMOVED
9467
9468 042754 105361 042266          POPQUE: DECB     QCNT(R1)          ;DECREMENT QUEUE COUNT
9469 042760 006301          ASL      R1
9470 042762 017102 042316          MOV      @QOUTPT(R1),R2          ;GET THE "DPB" POINTER
9471 042766 005071 042316          CLR      @QOUTPT(R1)          ;REMOVE DPB ADDRESS FROM THE QUEUE
9472 042772 062761 000002 042316          ADD      #2,QOUTPT(R1)          ;UPDATE THE QUEUE POINTER
9473 043000 026161 042316 042340          CMP      QOUTPT(R1),QSTOP(R1) ;TIME TO RESET THE POINTER?
9474 043006 001003          BNE     1$          ;NO--BRANCH TO EXIT
9475 043010 016161 042336 042316          MOV      QSTART(R1),QOUTPT(R1) ;YES--RESET THE POINTER

```



9476 043016 006201  
9477 043020 000207  
9478  
9479  
9480  
9481  
9482  
9483  
9484  
9485  
9486  
9487  
9488  
9489  
9490  
9491  
9492  
9493  
9494  
9495  
9496  
9497  
9498  
9499  
9500  
9501  
9502  
9503  
9504  
9505  
9506  
9507  
9508  
9509  
9510  
9511  
9512  
9513  
9514  
9515  
9516  
9517  
9518  
9519  
9520  
9521  
9522  
9523  
9524  
9525  
9526  
9527  
9528  
9529  
9530  
9531

000001  
000002  
000003  
000004  
000006  
000010  
000011  
000012  
000014  
000016  
  
000020  
000022  
000024  
000026  
000027  
000030  
000032  
000036  
000042  
000046  
000052  
000056  
000060  
000062  
000064  
000066  
000070  
000072  
  
000074  
000075  
000076  
000077  
000100  
000102  
000104

IS: ASR R1  
RTS PC ;RETURN TO USER

\*\*\*\*\*

.SBTTL DATA, CONTROL, & STATUS BLOCKS

\*\*\*\*\*

;BLOCK LOCATION EQUATE STATEMENTS

\$FMT = 1 ;FMT HCI ECI OR OFFSET CODE  
\$COMND = \$FMT+1 ;OPERATION CODE  
\$PSEL = \$FMT+2 ;PORT SELECT & BITS A16, A17  
\$WRDM = \$FMT+3 ;WORD COUNT (2'S COMP)  
\$BUF = \$FMT+5 ;BUFFER ADDR OR REGISTER TABLE POINTER  
\$SEC = \$FMT+7 ;SECTOR ADDRESS OR 1ST REG ADDR  
\$TRK = \$FMT+10 ;TRACK ADDRESS OF LAST REG ADDR  
\$CYL = \$FMT+11 ;CYLINDER ADDR  
\$REG = \$FMT+13 ;REGISTER STORAGE (IF ERROR)  
\$STATUS = \$FMT+15 ;STATUS WORD (SET BY DRIVER)

;DRIVE'S HISTORY AND CURRENT INDICATOR STORAGE EQUATES

\$WRDL = \$FMT+17 ;WORD COUNT (NOT 2'S COMP)  
\$SSEC = \$WRDL+2 ;SECTOR SIZE FOR CURRENT OPERATION  
\$CODE = \$WRDL+4 ;PRESENT COMMAND SELECTION CODE  
\$PACK = \$WRDL+6 ;WRITE DATA PACK INDICATOR  
\$PREVO = \$WRDL+7 ;PREVIOUS COMMAND SELECTION CODE  
\$PATT = \$WRDL+10 ;PATTERN CODE  
\$PREVA = \$WRDL+12 ;PREVIOUS ADDRESS - TRACK, SECTOR, CYLINDER  
\$OPERC = \$WRDL+16 ;OPERATION COUNT  
\$POSIT = \$WRDL+22 ;SEEK COUNT  
\$TRANS = \$WRDL+26 ;TOTAL BITS XFERED COUNT (R & W)  
\$READ = \$WRDL+32 ;TOTAL BITS READ COUNT  
\$TOTAL = \$WRDL+36 ;TOTAL ERRORS (ALL TYPES) COUNT  
\$SOFT = \$WRDL+40 ;'SOFT' ERROR COUNT  
\$HARD = \$WRDL+42 ;'HARD' ERROR COUNT  
\$SKI = \$WRDL+44 ;'SKI' OR 'OCYL' ERROR COUNT  
\$MISPO = \$WRDL+46 ;PROG DETECTED MISPOSITIONING ERROR S COUNT  
\$PASSC = \$WRDL+50 ;PASS COUNTER  
\$FAIR = \$WRDL+52 ;OPERATION QUEUE 'FAIRNESS' COUNT

;INDEX EQUATES TO THE NEXT OPERATION PARAMETERS

\$NCODE = \$WRDL+54 ;NEXT OPERATION CODE  
\$NPATC = \$NCODE+1 ;NEXT PATTERN  
\$NSEC = \$NCODE+2 ;NEXT SECTOR  
\$NTRK = \$NCODE+3 ;NEXT TRACK  
\$NCYL = \$NCODE+4 ;NEXT CYLINDER  
\$NWRDL = \$NCODE+6 ;NEXT BUFFER SIZE  
\$NEXT = \$NCODE+10 ;PARAMETER SELECTION INDICATOR

;INDEX EQUATES FOR MAXIMUM/MINIMUM ADDRESSES

```

9532      000106      MAXCYL =          $NCODE+12      ;MAXIMUM CYLINDER ADDRESS
9533      000110      MINCYL =          MAXCYL+2      ;MINIMUM CYLINDER ADDRESS
9534      000112      MAXTRK =          MAXCYL+4      ;MAXIMUM TRACK ADDRESS
9535      000114      MINTRK =          MAXCYL+6      ;MINIMUM TRACK ADDRESS
9536      000116      MAXSEC =          MAXCYL+10     ;MAXIMUM SECTOR ADDRESS
9537      000120      MINSEC =          MAXCYL+12     ;MINIMUM SECTOR ADDRESS
9538      000122      $FIRST =          MAXCYL+14     ;FIRST OPERATION INDICATOR
9539
9540      ;BAD SECTOR/TRACK ADDRESS STORAGE AREA INDEX EQUATE
9541
9542      000124      $BDSEC =          MAXCYL+16      ;BAD SECTOR STORAGE TABLE
9543
9544      ;DRIVE ID AREA INDEX EQUATE
9545
9546      000224      $DRVID =          $BDSEC+100     ;DRIVE ID
9547
9548      ;RH11/RMO3 REGISTER EQUATES
9549
9550      000234      $RMCS1 =          $DRVID+10      ;RMO3 REGISTER STORAGE
9551      000236      $RMWC =          $RMCS1+2
9552      000240      $RMBA =          $RMCS1+4
9553      000242      $RMDA =          $RMCS1+6
9554      000244      $RMCS2 =          $RMCS1+10
9555      000246      $RMDS =          $RMCS1+12
9556      000250      $RMER1 =          $RMCS1+14
9557      000252      $RMAS =          $RMCS1+16
9558      000254      $RMLA =          $RMCS1+20
9559      000256      $RMD8 =          $RMCS1+22
9560      000260      $RMMR1 =          $RMCS1+24
9561      000262      $RMDT =          $RMCS1+26
9562      000264      $RMSN =          $RMCS1+30
9563      000266      $RMOF =          $RMCS1+32
9564      000270      $RMDC =          $RMCS1+34
9565      000272      $RMHR =          $RMCS1+36
9566      000274      $RMMR2 =          $RMCS1+40
9567      000276      $RMER2 =          $RMCS1+42
9568      000300      $RMEC1 =          $RMCS1+44
9569      000302      $RMEC2 =          $RMCS1+46
9570
9571
9572      ;BLOCK FOR DRIVE 0
9573
9574      043022      000      000      DRIVED: .BYTE 0,0      ;DRIVE NUMBER
9575      043024      000005      .BLKW 5
9576      043036      043256      .WORD .+$RMCS1-$REG
9577      043040      000266      .BLKB $RMEC2-$REG
9578
9579
9580      ;BLOCK FOR DRIVE 1
9581
9582      043326      000      001      DRIVE1: .BYTE 1,0      ;DRIVE NUMBER
9583      043330      000005      .BLKW 5
9584      043342      043562      .WORD .+$RMCS1-$REG
9585      043344      000266      .BLKB $RMEC2-$REG
9586
9587

```

```

9588 ;BLOCK FOR DRIVE 2
9589
9590 043632 002 000 DRIVE2: .BYTE 2,0 ;DRIVE NUMBER
9591 043634 000005 .BLKW 5
9592 043646 044066 .WORD +$RMCS1-$REG
9593 043650 000266 .BLKB $RMEC2-$REG
9594
9595
9596 ;BLOCK FOR DRIVE 3
9597
9598 044136 003 000 DRIVE3: .BYTE 3,0 ;DRIVE NUMBER
9599 044140 000005 .BLKW 5
9600 044152 044372 .WORD +$RMCS1-$REG
9601 044154 000266 .BLKB $RMEC2-$REG
9602
9603
9604 ;BLOCK FOR DRIVE 4
9605
9606 044442 004 000 DRIVE4: .BYTE 4,0 ;DRIVE NUMBER
9607 044444 000005 .BLKW 5
9608 044456 044676 .WORD +$RMCS1-$REG
9609 044460 000266 .BLKB $RMEC2-$REG
9610
9611
9612 ;BLOCK FOR DRIVE 5
9613
9614 044746 005 000 DRIVES: .BYTE 5,0 ;DRIVE NUMBER
9615 044750 000005 .BLKW 5
9616 044762 045202 .WORD +$RMCS1-$REG
9617 044764 000266 .BLKB $RMEC2-$REG
9618
9619
9620 ;BLOCK FOR DRIVE 6
9621
9622 045252 006 000 DRIVE6: .BYTE 6,0 ;DRIVE NUMBER
9623 045254 000005 .BLKW 5
9624 045266 045506 .WORD +$RMCS1-$REG
9625 045270 000266 .BLKB $RMEC2-$REG
9626
9627
9628 ;BLOCK FOR DRIVE 7
9629
9630 045556 007 000 DRIVE7: .BYTE 7,0 ;DRIVE NUMBER
9631 045560 000005 .BLKW 5
9632 045572 046012 .WORD +$RMCS1-$REG
9633 045574 000266 .BLKB $RMEC2-$REG
9634
9635
9636 ;GENERAL PURPOSE DPB - USED BY 'READHD', 'RECALT', 'OFFSET', & 'RTNCTR'
9637
9638 046062 000000 000000 177776 GENDPB: .WORD 0,0,-2,CYLDER
9639 046070 056512 .WORD 0,0,GENREG,0
9640 046072 000000 000000 046102
9641 046100 000000
9642 046102 000024 GENREG: .BLKW 24 ;REGISTER STORAGE IF ERROR
9643

```

9644  
9645  
9646  
9647  
9648  
9649  
9650

;;\*\*\*\*\*

.SBTTL ERROR MESSAGES

;;\*\*\*\*\*

.NLIST BEX

046152	044122	030067	030450	EM1:	.ASCIZ	/RH70(11) INTERRUPT OCCURRED (RMAS = 0)/
046221	125	042516	050130	EM2:	.ASCIZ	/UNEXPECTED ATTENTION OCCURRED/
046257	115	051501	041123	EM3:	.ASCIZ	/MASSBUS PARITY ERROR (MCPE=1)/
046315	115	051501	041123	EM4:	.ASCIZ	/MASSBUS PARITY ERROR (PAR=1)/
046352	042101	051104	051505	EM5:	.ASCIZ	/ADDRESS PLUG CHANGE BIT SET/
046406	044122	030067	030450	EM6:	.ASCIZ	/RH70(11) DIDN'T RESPOND TO ADDRESSING/
046454	047125	047503	051122	EM10:	.ASCIZ	/UNCORRECTABLE MASSBUS PARITY ERROR/
046517	106	052101	046101	EM11:	.ASCIZ	/FATAL MASSBUS PARITY ERROR/
046552	042520	051522	051511	EM12:	.ASCIZ	/PERSISTENT DEVICE UNSAFE/
046603	117	042520	040522	EM13:	.ASCIZ	/OPERATION NOT COMPLETED WITHIN TIME LIMIT/
046655	104	044522	042526	EM14:	.ASCIZ	/DRIVE WENT OFFLINE/
046700	047516	051040	051505	EM15:	.ASCIZ	/NO RESPONSE TO PORT REQUEST/
046734	042510	042101	051105	EM20:	.ASCIZ	/HEADER CRC ERROR/
046755	104	052101	020101	EM21:	.ASCIZ	/DATA CHECK ('DCK') ERROR/
047006	051127	052111	020105	EM22:	.ASCIZ	/WRITE CHECK ERROR - DATA CHECK ('DCK') SET/
047061	127	044522	042524	EM23:	.ASCIZ	/WRITE CHECK ERROR - DATA CHECK ('DCK') NOT SET/
047140	042510	042101	051105	EM24:	.ASCIZ	/HEADER READ ERROR - 'FMT' BIT DROPPED/
047206	042510	042101	051105	EM25:	.ASCIZ	/HEADER READ ERROR - HEADER COMPARE ('HCE') ERROR/
047267	106	051117	040515	EM26:	.ASCIZ	/FORMAT ERROR ('FER')/
047314	042510	042101	051105	EM27:	.ASCIZ	/HEADER COMPARE ('HCE') ERROR/
047351	115	051511	042503	EM30:	.ASCIZ	/MISCELLANEOUS DRIVE ERROR/
047403	117	042520	040522	EM31:	.ASCIZ	/OPERATION INCOMPLETE ('OPI') ERROR/
047446	051104	053111	020105	EM32:	.ASCIZ	/DRIVE TIMING ('DTE') ERROR/
047501	120	051101	052111	EM33:	.ASCIZ	/PARITY ('PAR') ERROR AFTER OPERATION STARTED/

```

047556 051127 052111 020105 EM34: .ASCIZ /WRITE CLOCK FAILURE ('WCF') ERROR/
047620 047111 040526 044514 EM35: .ASCIZ /INVALID ADDRESS ('IAE') ERROR/
047656 051127 052111 020105 EM36: .ASCIZ /WRITE LOCK ('WLE') ERROR/
047707 104 052101 020101 EM37: .ASCIZ /DATA CHECK ('DCK') SET DURING WRITE CHECK COMMAND/
047771 122 030510 020061 EM40: .ASCIZ /RH11 OR UNIBUS TRANSFER ERROR/
050027 102 051525 040440 EM41: .ASCIZ /BUS ADDRESS OR WORD COUNT INCORRECT/
050073 104 052101 020101 EM42: .ASCIZ /DATA COMPARE ERRORS - NO OTHER ERROR(S) DETECTED/
050154 040503 023516 020124 EM43: .ASCIZ /CAN'T MATCH DATA READ WITH A PATTERN/
050221 105 051122 051117 EM44: .ASCIZ /ERROR BIT(S) SET, BUT NO ERROR SIGNALLED BY THE RH11/
050305 105 041503 046040 EM45: .ASCIZ /ECC LOGIC FAILURE - POSITION REGISTER VALUE NOT VALID/
050373 102 051525 040440 EM46: .ASCIZ /BUS ADDRESS AND WORD COUNT NOT CONSISTENT/
050445 123 042505 020113 EM50: .ASCIZ /SEEK INCOMPLETE ('SKI') ERROR/
050503 120 047522 051107 EM51: .ASCIZ /PROGRAM DETECTED POSITIONING ERROR/
050546 051104 053111 020105 EM60: .ASCIZ /DRIVE UNSAFE ERROR/
050571 122 040515 000123 DH1: .ASCIZ /RMAS/
050576 051104 053111 020105 DH2: .ASCIZ /DRIVE RMDS RMER1 RMER2 RMMR2 RMAS/
050652 051104 053111 020105 DH3: .ASCIZ /DRIVE REG ADR DATA/
050700 051104 053111 020105 DH4: .ASCIZ /DRIVE REG ADR GOOD BAD/
050737 044 046522 042101 DH6: .ASCIZ /$RMADR/
050746 051104 020126 046522 DH14: .ASCII /DRV RMCS1 RMCS2 RMDS RMER1 /
051012 046522 051115 020062 .ASCIZ /RMMR2 RMER2 RMEC1 RMEC2/<CR><LF>
051051 122 053515 020103 DH15: .ASCII /RMWC RMBA RMDA RMAS RMLA /
051121 122 042115 020102 .ASCIZ /RMOB RMMR1 RMDT/<CR><LF>
051150 046522 047123 020040 DH16: .ASCIZ /RMSN RMOF RMDC RMHR STATUS/<CR><LF>
051222 .EVEN

```

.LIST BEX

```

9651
9652 051222 001342 000000 DT1: .WORD ATTN,0
9653
9654 051226 001216 034452 034454 DT2: .WORD DRIVE, RMERRS, RMERRS+2, RMERRS+4, RMERRS+6, ATTN, 0
9655 051234 034456 034460 001342
9656 051242 000000
9657

```

9658	051244	001216	041560	041562	DT3:	.WORD	DRIVE, RD. ADR, RD. WRD, 0
9659	051252	000000					
9660							
9661	051254	001216	042000	041776	DT4:	.WORD	DRIVE, WRT. AD, WRT. WD, RD. WRD, 0
9662	051262	041562	000000				
9663							
9664	051266	001270	000000		DT6:	.WORD	\$RMADR, 0
9665							
9666	051272	000234	000244	000246	DT14:	.WORD	\$RMCS1, \$RMCS2, \$RMDS, \$RMER1, \$RMMR2, \$RMER2, \$RMEC1, \$RMEC2, 0
9667	051300	000250	000274	000276			
9668	051306	000300	000302	000000			
9669							
9670	051314	000236	000240	000242	DT15:	.WORD	\$RMWC, \$RMBA, \$RMDA, \$RMAS, \$RMLA, \$RMDB, \$RMMR1, \$RMDT, 0
9671	051322	000252	000254	000256			
9672	051330	000260	000262	000000			
9673							
9674	051336	000264	000266	000270	DT16:	.WORD	\$RMSN, \$RMOF, \$RMDC, \$RMHR, \$STATUS, 0
9675	051344	000272	000016	000000			
9676							
9677							
9678							

.NLIST BEX

051352	051120	051505	047105	LIN2C:	.ASCIZ	/PRESENT ORDER = /
051373	040	050040	042522	LIN2P:	.ASCIZ	/ PREVIOUS ORDER = /
051417	052	042440	051122	LIN2S:	.ASCIZ	2* ERROR AT BAD TRACK/SECTOR2
051453	105	051122	051117	LINM3:	.ASCIZ	/ERROR AT C/
051466	052040	000		T:	.ASCIZ	/ T/
051471	120	042522	042523	LINN3:	.ASCIZ	/PRESENT ADDR = C/
051512	051440	000		S:	.ASCIZ	/ S/
051515	040	020040	051120	LINP3:	.ASCIZ	/ PREV ADDR = C/
051536	052123	051101	020124	LINS3:	.ASCIZ	/START CYL = /
051553	040	042440	042116	LINEN3:	.ASCIZ	/ END CYL = /
051570	020040	041501	052524	LINA3:	.ASCIZ	/ ACTUAL CYL = /
051610	020040	051124	020113	LINT3:	.ASCIZ	/ TRK = /
051621	040	046522	041504	LINCA3:	.ASCIZ	/ RMDC = /
051632	046522	040504	036440	LINDA3:	.ASCIZ	/RMDA = /
051642	046522	040502	036440	LINB3:	.ASCIZ	/RMBA = /
051652	020040	046522	041527	LINW3:	.ASCIZ	/ RMWC = /
051664	052123	051101	020124	LINST3:	.ASCIZ	/START TRK = /
051701	123	040524	052122	LINSS3:	.ASCIZ	/START SEC = /
051716	052502	043106	051105	LINM4:	.ASCIZ	/BUFFER ADDR = /
051735	040	051440	055111	LINS4:	.ASCIZ	/ SIZE = /
051747	040	040440	052103	LINX4:	.ASCIZ	/ ACTUAL NMBR WRDS XFRD = /
052002	047507	042117	042040	LIND5:	.ASCIZ	/GOOD DATA = /
052017	040	041040	042101	LINB5:	.ASCIZ	/ BAD DATA = /
052035	040	053440	051117	LIMP5:	.ASCIZ	/ WORD POS = /
052053	110	040505	042504	LINS5:	.ASCIZ	/HEADER FROM ERROR SECTOR = /
052107	122	042515	030503	LINEP5:	.ASCIZ	/RMEC1 = /
052120	051040	042515	031103	LINEO5:	.ASCIZ	/ RMEC2 = /
052132	042523	052103	051117	LINB6:	.ASCIZ	/SECTOR IS ECC CORRECTABLE /
052165	123	041505	047524	LINC6:	.ASCIZ	/SECTOR READ CORRECTLY /
052214	047503	051122	041505	LING6:	.ASCIZ	/CORRECTED ON /
052232	051040	052105	044522	LINR6:	.ASCIZ	/ RETRIES/
052243	125	041516	051117	LINU06:	.ASCIZ	/UNCORRECTABLE AFTER /
052270	020040	047524	040524	LIN7M:	.ASCIZ	/ TOTAL MISPOS ERR = /
052316	051117	042504	051522	LIN7O:	.ASCIZ	/ORDERS:/

052326	052040	052117	046101	LIN7P:	.ASCIZ	/ TOTAL SEEKS = /
052346	052040	052117	046101	LIN7S:	.ASCIZ	/ TOTAL SKI ERR = /
052370	020040	051105	047522	LIN7T:	.ASCIZ	/ ERRORS: /
052402	020040	051127	051504	LIN7X:	.ASCIZ	/ WRDS XFR: /
052416	020040	051127	051504	LIN7R:	.ASCIZ	/ WRDS READ: /
052433	105	051122	051117	LIN9M:	.ASCIZ	/ERROR DURING RETRY/
052456	040504	040524	041440	LIN9B:	.ASCIZ	/DATA COMPARISON ERRORS/
052505	040	020040	020040	LIN9H:	.ASCIZ	/
052533	114	041517	020040		.ASCIZ	/LOC GOOD BAD<<CR><LF>
052563	114	041517	020040	LIN9I:	.ASCIZ	/LOC DATA DATA<<CR><LF>
052603	124	052117	046101	LIN9E:	.ASCIZ	/TOTAL COMPARE ERRORS = /
052633	124	042510	042040	LIN9G:	.ASCIZ	/THE DATA COMPARED OK<<CR><LF>
052662	051105	047522	020122	LIN10A:	.ASCIZ	/ERROR BURST BEGINS AT WORD /
052716	044440	020116	040504	LIN10B:	.ASCIZ	/ IN DATA FIELD OF ERROR SECTOR<<CR><LF>
052757	105	051122	051117	LIN10C:	.ASCIZ	/ERROR WAS NOT IN THE DATA READ - /<<CR><LF>
053022	041505	020103	047503		.ASCIZ	/ECC CORRECTION CAN'T BE PERFORMED/
053064	041505	020103	047503	LIN10H:	.ASCIZ	/ECC CORRECTION RESULTS<<CR><LF>
053114	042101	051104	020040		.ASCIZ	/ADDR BAD CORRECTED /<<CR><LF>
053151	103	047117	042524	LIN11H:	.ASCIZ	/CONTENTS OF ERROR SECTOR (REPORTED ABOVE)<<CR><LF>
053225	101	042104	020122		.ASCIZ	/ADDR DATA<<CR><LF>
053244	020040			LIN4SP:	.ASCIZ	/
053246	040			LINSP:	.ASCIZ	/
053247	040	000		LINSP0:	.ASCIZ	/
053251	122	052105	044522	LINXS:	.ASCIZ	/RETRIEVED BY A RDHD COMMAND/

.SBTTL TELETYPE MESSAGES

053305	104	044522	042526	UNMSG:	.ASCIZ	/DRIVE/
053313	040	043117	046106	UNOFF:	.ASCIZ	/ OFFLINE/
053324	047440	046116	047111	UNTON:	.ASCIZ	/ ONLINE/
053334	047040	052117	041040	UNNOT:	.ASCIZ	/ NOT BEING TESTED/
053356	040440	051114	040505	UNASN:	.ASCIZ	/ ALREADY BEING TESTED/
053404	047040	052117	040440	NOTRM:	.ASCIZ	@ NOT AN RMD3/RMD2@
053426	047040	052117	050040	NOTPRS:	.ASCIZ	/ NOT PRESENT/
053443	040	047516	020124	NOTAVL:	.ASCIZ	/ NOT AVAILABLE/
053462	052440	051516	043101	NOTSAF:	.ASCIZ	/ UNSAFE/
053472	047125	052111	051440	SYSTAT:	.ASCIZ	/UNIT STATUS:<<CR><LF><LF>
053512	046522	031460	000	RMD3A:	.ASCIZ	/RMD3/
053517	122	030115	000062	RMD3B:	.ASCIZ	/RMD2/
053524	051104	053111	020105	STATM:	.ASCIZ	/DRIVE PERFORMANCE SUMMARY<<CR><LF>
053557	104	053122	050040		.ASCIZ	/DRV PASS ORDERS SEEKS WRDS XFER WRDS READ /
053637	123	043117	020124		.ASCIZ	/SOFT HARD SKI MISP OTHER<<CR><LF>
053673	104	047117	006505	POONE:	.ASCIZ	/DONE<<CR><LF><LF>
053703	007	043077	052101	DROPNG:	.ASCIZ	<07>/?FATAL OR EXCESSIVE ERRORS/
053737	105	042116	047440	ENDPAS:	.ASCIZ	/END OF PASS/
053753	015	042412	042116	ENDTST:	.ASCIZ	<CR><LF>/END OF TEST/
053771	015	042012	044522	DEASSG:	.ASCIZ	<CR><LF>/DRIVE DEASSIGNED/
054014	005015	025052	025052	DRNUM:	.ASCIZ	<CR><LF>/***** DRIVE #/
054041	040	052123	051101	ASGND:	.ASCIZ	/ STARTED<<CR><LF>
054054	005015	020077	046047	NEDCLK:	.ASCIZ	<CR><LF>/? 'L' OR 'P' CLOCK REQUIRED ON SYSTEM<<CR><LF>
054126	000056			PERIOD:	.ASCIZ	/
054130	000077			QUES:	.ASCIZ	/
054132	047111	040526	044514	INVLD:	.ASCIZ	/INVALID COMMAND<<CR><LF>
054154	005015	047105	042524	ENTCOM:	.ASCIZ	<CR><LF>/ENTER COMMANDS: /<<CR><LF>
054201	105	052116	051105	ENTDRV:	.ASCIZ	/ENTER I.D. FOR DRV #/
054226	005015	047105	042524	ENTLMT:	.ASCIZ	<CR><LF>/ENTER ADDRESS LIMITS FOR DRV #/

```

054267 105 052116 051105 ENTADR: .ASCIZ @ENTER BAD TRK/SEC ADRS FOR DRV #a
054330 000072 COLON: .ASCIZ /:/
054332 005015 040504 042524 DATEIS: .ASCIZ <CR><LF>/DATE: /
054343 015 047412 042520 IDIS: .ASCIZ <CR><LF>/OPERATOR I.D.: /
054365 015 005012 051104 HEDLIN: .ASCIZ <CR><LF><LF>/DRV DRV I.D./<CR><LF>
054410 047516 042516 005015 NONE: .ASCIZ /NONE/<CR><LF>
054417 077 044440 053116 BADENT: .ASCIZ /? INVALID ENTRY/<CR><LF>
054441 123 051531 042524 BUSY: .ASCIZ /SYSTEM BUSY.../<CR><LF>
054462 005015 051120 043517 INTDOM: .ASCII <CR><LF>/PROGRAM INITIALIZATION COMPLETE/
054523 015 052012 050131 MERR1: .ASCIZ <CR><LF>/TYPE A 'CONTROL C' TO ENTER COMMANDS/<CR><LF><LF>
054575 015 043012 044501 MERR2: .ASCIZ <CR><LF>/FAIL TO RETRIEVE BAD SPOT FILE ON /
054643 015 047412 042526 MERR2: .ASCIZ <CR><LF>/OVER 16 BAD SECTORS ARE DETECTED ON /

```

054714

.EVEN  
.LIST BEX

9679  
9680  
9681  
9682  
9683  
9684  
9685  
9686  
9687  
9688  
9689  
9690  
9691  
9692  
9693  
9694  
9695  
9696  
9697

;PARAMETER ENTRY TABLE

```

054714 055042 020000 001462 PARLST: .WORD PAR1,8192,MAXDL
054722 055052 177777 001466 .WORD PAR2,-1,INTRVL
054730 055222 177777 001460 .WORD PAR19,-1,PASCNT
054736 055062 000017 001510 .WORD PAR3,15,PATTEN
054744 055162 000001 001476 .WORD PAR11,1,MCSEL
054752 055172 000007 001500 .WORD PAR14,7,RATIO
054760 055212 000001 001506 .WORD PAR16,1,ENDET
054766 055152 000001 001474 .WORD PAR10,1,FORMAT
; .WORD PAR15,1,AUTOCK
054774 055232 000001 001504 .WORD PAR20,1,NOTPRT
055002 055242 000001 001512 .WORD PAR21,1,HEADER ;RANDOM ADDRESS FLAG
055010 000000 .WORD 0 ;TABLE TERMINATOR

```

.NLIST BEX

```

055012 047105 042524 020122 ASKPAR: .ASCIZ /ENTER PARAMETERS: /
055036 027440 000040 SLASH: .ASCIZ @ / @

055042 044523 042532 020040 PAR1: .ASCIZ /SIZE /
055052 044515 052516 042524 PAR2: .ASCIZ /MINUTE /
055062 040520 052124 051105 PAR3: .ASCIZ /PATTERN/
055072 040515 041530 046131 PAR4: .ASCIZ /MAXCYL /
055102 044515 041516 046131 PAR5: .ASCIZ /MINCYL /
055112 040515 052130 045522 PAR6: .ASCIZ /MAXTRK /
055122 044515 052116 045522 PAR7: .ASCIZ /MINTRK /
055132 040515 051530 041505 PAR8: .ASCIZ /MAXSEC /
055142 044515 051516 041505 PAR9: .ASCIZ /MINSEC /
055152 047506 046522 052101 PAR10: .ASCIZ /FORMAT /
055162 040522 042116 046517 PAR11: .ASCIZ /RANDOM /
055172 040522 044524 020117 PAR14: .ASCIZ /RATIO /
055202 044103 041505 020113 PAR15: .ASCIZ /CHECK /
055212 047105 044504 043516 PAR16: .ASCIZ /ENDING /
055222 040520 051523 051505 PAR19: .ASCIZ /PASSES /
055232 042515 051523 043501 PAR20: .ASCIZ /MESSAGE/
055242 042510 042101 051105 PAR21: .ASCIZ /HEADER /

```



.EVEN

.LIST BEX

;PARAMETER TABLE POINTERS FOR ADDRESS LIMITS

TABLE:	.WORD	TABLE0	;PARAMETER TABLE FOR DRIVE 0
	.WORD	TABLE1	;PARAMETER TABLE FOR DRIVE 1
	.WORD	TABLE2	;PARAMETER TABLE FOR DRIVE 2
	.WORD	TABLE3	;PARAMETER TABLE FOR DRIVE 3
	.WORD	TABLE4	;PARAMETER TABLE FOR DRIVE 4
	.WORD	TABLE5	;PARAMETER TABLE FOR DRIVE 5
	.WORD	TABLE6	;PARAMETER TABLE FOR DRIVE 6
	.WORD	TABLE7	;PARAMETER TABLE FOR DRIVE 7

;PARAMETER TABLE FOR ADDRESS LIMITS

9698									
9699									
9700									
9701									
9702	055252	055272							
9703	055254	055340							
9704	055256	055406							
9705	055260	055454							
9706	055262	055522							
9707	055264	055570							
9708	055266	055636							
9709	055270	055704							
9710									
9711									
9712									
9713	055272	055102	000000	043132	TABLE0:	.WORD	PAR5,0,MINCYL+DRIVE0		
9714	055300	055072	000000	043130		.WORD	PAR4,0,MAXCYL+DRIVE0		
9715	055306	055122	000004	043136		.WORD	PAR7,4.,MINTRK+DRIVE0		
9716	055314	055112	000004	043134		.WORD	PAR6,4.,MAXTRK+DRIVE0		
9717	055322	055142	000037	043142		.WORD	PAR9,31.,MINSEC+DRIVE0		
9718	055330	055132	000037	043140		.WORD	PAR8,31.,MAXSEC+DRIVE0,0		
9719	055336	000000							
9720									
9721	055340	055102	000000	043436	TABLE1:	.WORD	PAR5,0,MINCYL+DRIVE1		
9722	055346	055072	000000	043434		.WORD	PAR4,0,MAXCYL+DRIVE1		
9723	055354	055122	000004	043442		.WORD	PAR7,4.,MINTRK+DRIVE1		
9724	055362	055112	000004	043440		.WORD	PAR6,4.,MAXTRK+DRIVE1		
9725	055370	055142	000037	043446		.WORD	PAR9,31.,MINSEC+DRIVE1		
9726	055376	055132	000037	043444		.WORD	PAR8,31.,MAXSEC+DRIVE1,0		
9727	055404	000000							
9728									
9729	055406	055102	000000	043742	TABLE2:	.WORD	PAR5,0,MINCYL+DRIVE2		
9730	055414	055072	000000	043740		.WORD	PAR4,0,MAXCYL+DRIVE2		
9731	055422	055122	000004	043746		.WORD	PAR7,4.,MINTRK+DRIVE2		
9732	055430	055112	000004	043744		.WORD	PAR6,4.,MAXTRK+DRIVE2		
9733	055436	055142	000037	043752		.WORD	PAR9,31.,MINSEC+DRIVE2		
9734	055444	055132	000037	043750		.WORD	PAR8,31.,MAXSEC+DRIVE2,0		
9735	055452	000000							
9736									
9737	055454	055102	000000	044246	TABLE3:	.WORD	PAR5,0,MINCYL+DRIVE3		
9738	055462	055072	000000	044244		.WORD	PAR4,0,MAXCYL+DRIVE3		
9739	055470	055122	000004	044252		.WORD	PAR7,4.,MINTRK+DRIVE3		
9740	055476	055112	000004	044250		.WORD	PAR6,4.,MAXTRK+DRIVE3		
9741	055504	055142	000037	044256		.WORD	PAR9,31.,MINSEC+DRIVE3		
9742	055512	055132	000037	044254		.WORD	PAR8,31.,MAXSEC+DRIVE3,0		
9743	055520	000000							
9744									
9745	055522	055102	000000	044552	TABLE4:	.WORD	PAR5,0,MINCYL+DRIVE4		
9746	055530	055072	000000	044550		.WORD	PAR4,0,MAXCYL+DRIVE4		
9747	055536	055122	000004	044556		.WORD	PAR7,4.,MINTRK+DRIVE4		
9748	055544	055112	000004	044554		.WORD	PAR6,4.,MAXTRK+DRIVE4		

9749	055552	055142	000037	044562	.WORD	PAR9,31.,MINSEC+DRIVE4
9750	055560	055132	000037	044560	.WORD	PAR8,31.,MAXSEC+DRIVE4,0
9751	055566	000000				
9752						
9753	055570	055102	000000	045056	TABLE5: .WORD	PAR5,0,MINCYL+DRIVE5
9754	055576	055072	000000	045054	.WORD	PAR4,0,MAXCYL+DRIVE5
9755	055604	055122	000004	045062	.WORD	PAR7,4.,MINTRK+DRIVE5
9756	055612	055112	000004	045060	.WORD	PAR6,4.,MAXTRK+DRIVE5
9757	055620	055142	000037	045066	.WORD	PAR9,31.,MINSEC+DRIVE5
9758	055626	055132	000037	045064	.WORD	PAR8,31.,MAXSEC+DRIVE5,0
9759	055634	000000				
9760						
9761	055636	055102	000000	045362	TABLE6: .WORD	PAR5,0,MINCYL+DRIVE6
9762	055644	055072	000000	045360	.WORD	PAR4,0,MAXCYL+DRIVE6
9763	055652	055122	000004	045366	.WORD	PAR7,4.,MINTRK+DRIVE6
9764	055660	055112	000004	045364	.WORD	PAR6,4.,MAXTRK+DRIVE6
9765	055666	055142	000037	045372	.WORD	PAR9,31.,MINSEC+DRIVE6
9766	055674	055132	000037	045370	.WORD	PAR8,31.,MAXSEC+DRIVE6,0
9767	055702	000000				
9768						
9769	055704	055102	000000	045666	TABLE7: .WORD	PAR5,0,MINCYL+DRIVE7
9770	055712	055072	000000	045664	.WORD	PAR4,0,MAXCYL+DRIVE7
9771	055720	055122	000004	045672	.WORD	PAR7,4.,MINTRK+DRIVE7
9772	055726	055112	000004	045670	.WORD	PAR6,4.,MAXTRK+DRIVE7
9773	055734	055142	000037	045676	.WORD	PAR9,31.,MINSEC+DRIVE7
9774	055742	055132	000037	045674	.WORD	PAR8,31.,MAXSEC+DRIVE7,0
9775	055750	000000				
9776						
9777						
9778						
9779						
9780						
9781						
9782						
9783						
9784						
9785						
9786						
9787						

;\*\*\*\*\*

;ROUTINE TO GET THE DATE AND THE OPERATOR FROM THE OPERATOR

```

;CALL:
;      JSR      PC,OPRDAT
;      RETURN

```

;NOTE: THIS ROUTINE IS ENTERED ONLY AT INITIAL START

9788	055752	104401	056074	OPRDAT: TYPE	,ENTDAT	;'ENTER DATE'
9789	055756	104411		RDLIN		;'READ THE ENTRY
9790	055760	012605		MOV	(SP)+,R5	;'PUT THE ENTRY ADDRESS INTO R5
9791	055762	112537	001320	MOVB	(R5)+,DATE	;'STORE THE DATE
9792	055766	112537	001321	MOVB	(R5)+,DATE+1	;'STORE THE DATE
9793	055772	112537	001322	MOVB	(R5)+,DATE+2	;'STORE THE DATE
9794	055776	112537	001323	MOVB	(R5)+,DATE+3	;'STORE THE DATE
9795	056002	112537	001324	MOVB	(R5)+,DATE+4	;'STORE THE DATE
9796	056006	112537	001325	MOVB	(R5)+,DATE+5	;'STORE THE DATE
9797	056012	112537	001326	MOVB	(R5)+,DATE+6	;'STORE THE DATE
9798	056016	112537	001327	MOVB	(R5)+,DATE+7	;'STORE THE DATE
9799	056022	005037	001330	CLR	DATE+8.	;'SET TERMINATOR
9800	056026	104401	056113	TYPE	,ENTID	;'ENTER OPERATOR I.D.'
9801	056032	104411		RDLIN		;'READ THE ENTRY
9802	056034	012605		MOV	(SP)+,R5	;'ENTRY ADDRESS
9803	056036	112537	001332	MOVB	(R5)+,OPERID	;'STORE THE I.D.
9804	056042	112537	001333	MOVB	(R5)+,OPERID+1	;'STORE THE I.D.

9805 056046 112537 001334  
 9806 056052 112537 001335  
 9807 056056 112537 001336  
 9808 056062 112537 001337  
 9809 056066 005037 001340  
 9810 056072 000207  
 9811  
 9812 056074 005015 047105 042524  
 9813 056102 020122 040504 042524  
 9814 056110 020072 000  
 9815 056113 105 052116 051105  
 9816 056120 047440 042520 040522  
 9817 056126 047524 020122 027111  
 9818 056134 027104 020072 000  
 9819 056142  
 9820  
 9821  
 9822  
 9823  
 9824  
 9825  
 9826  
 9827  
 9828  
 9829 056142 010046  
 9830 056144 010146  
 9831 056146 013746 000004  
 9832 056152 013746 000006  
 9833 056156 010600  
 9834  
 9835 056160 104400  
 9836 056162 012637 000006 000004  
 9837 056166 012737 056206  
 9838 056174 012701 020000  
 9839 056200 005711  
 9840 056202 005721  
 9841 056204 000775  
 9842 056206 162701 000002  
 9843 056212 010006  
 9844 056214 012637 000006  
 9845 056220 012637 000004  
 9846 056224 010137 056236  
 9847 056230 012601  
 9848 056232 012600  
 9849 056234 000207  
 9850 056236 000000  
 9851  
 9852  
 9853  
 9854  
 9855  
 9856  
 9857  
 9858  
 9859  
 9860

```

MOV# (R5)+,OPERID+2 ;STORE THE I.D.
MOV# (R5)+,OPERID+3 ;STORE THE I.D.
MOV# (R5)+,OPERID+4 ;STORE THE I.D.
MOV# (R5)+,OPERID+5 ;STORE THE I.D.
CLR OPERID+6 ;SET TERMINATOR
RTS PC ;RETURN

ENTDAT: .ASCIZ <CR><LF>/ENTER DATE: /

ENTID: .ASCIZ /ENTER OPERATOR I.D.: /

.EVEN

.SBTTL ROUTINE TO SIZE MEMORY

;*****
;CALL:
;* JSR PC,$SIZE
;* RETURN
;*$LSTAD WILL CONTAIN THE LAST AVAILABLE MEMORY LOCATION

$SIZE: MOV RO,-(SP) ;SAVE RO ON THE STACK
MOV R1,-(SP) ;SAVE R1 ON THE STACK
MOV @#ERRVEC,-(SP) ;SAVE PRESENT ERROR VECTOR PS & PC
MOV @#ERRVEC+2,-(SP)
MOV SP,RO ;SAVE THE STACK POINTER
;;SET THE ERRVEC PS TO THE PRESENT PS
TRAP ;PUSH OLD PSW AND PC ON STACK
MOV (SP)+,@#ERRVEC+2 ;SAVE THE PSW IN @#ERRVEC+2
MOV #2,@#ERRVEC ;SET FOR TIMEOUT
MOV #2000,R1 ;FIRST ADDRESS
1$: TST (R1) ;TEST THIS ADDRESS
TST (R1)+ ;STEP TO NEXT ADDRESS
BR 1$ ;TRY ANOTHER
2$: SUB #2,R1 ;DROP BACK
MOV RO,SP ;RESTORE THE STACK
MOV (SP)+,@#ERRVEC+2 ;RESTORE ERROR VECTOR
MOV (SP)+,@#ERRVEC
MOV R1,$LSTAD ;LAST ADDRESS
MOV (SP)+,R1 ;RESTORE R1
MOV (SP)+,RO ;RESTORE RO
$LSTAD: .WORD 0 ;CONTAINS THE LAST ADDRESS

.SBTTL BUSADR - GET BUS ADDRESS AND VECTOR ADDRESS FOR RH11
;THIS ROUTINE IS USED TO INSURE THE BUS ADDRESS
;OF THE RH11 IS SETUP FOR THE PROPER ADDRESS.
;IT WILL ALSO READ THE ADDRESS FROM THE TTY IF
;REQUIRED.
;NOTE: THIS ROUTINE DESTROYS RO-R4
;CALL
;
; JSR PC,BUSADR

```

```

9861 ; RETURN
9862
9863 056240 005737 001356 BUSADR: TST CHGADR ; INPUT FROM TTY REQUESTED?
9864 056244 002036 BGE 3$ ; NO--BRANCH
9865 056246 005037 001356 CLR CHGADR ; YES--CLEAR THE REQUEST FLAG
9866 056252 104401 001201 TYPE $CRLF ; TYPE A CR-LF
9867 056256 012700 001270 1$: MOV $RMADR,R0 ; FIRST ADDRESS
9868 056262 104401 056360 TYPE MRMCS1 ; "RMCS1="
9869 056266 011046 MOV (R0),-(SP) ; PRESENT RMCS1 ADDRESS
9870 056270 104402 TYPOC ; TYPE IT
9871 056272 104401 053246 TYPE ,LINSP ; 2 SPACES
9872 056276 104411 RDLIN ; GET THE ENTRY
9873 056300 012601 MOV (SP)+,R1 ; ADDRESS OF ASCII TEXT
9874 056302 004537 056402 JSR R5,CK.NUM ; ENTER AND STORE THE NEW ADDRESS
9875 056306 000763 BR 1$ ; ERROR EXIT
9876 056310 012700 001272 2$: MOV $RMVEC,R0 ; VECTOR ADDRESS
9877 056314 104401 056371 TYPE MRHVEC ; "RHVEC="
9878 056320 011046 MOV (R0),-(SP) ; PRESENT RH11 VECTOR ADDRESS ON THE STACK
9879 056322 104402 TYPOC ; TYPE IT
9880 056324 104401 053246 TYPE ,LINSP ; 2 SPACES
9881 056330 104411 RDLIN ; READ THE ENTRY
9882 056332 012601 MOV (SP)+,R1 ; ASCII TEXT ADDRESS
9883 056334 004537 056402 JSR R5,CK.NUM ; ENTER AND STORE NEW ADDRESS
9884 056340 000763 BR 2$ ; ERROR EXIT
9885 056342 012700 001270 3$: MOV $RMADR,R0 ; FIRST ADDRESS OF NEW PARAMETERS
9886 056346 012701 034620 MOV $RMADR,R1 ; FIRST ADDRESS OF WHERE TO PUT THEM
9887 056352 012021 MOV (R0)+,(R1)+ ; BUS ADDRESS
9888 056354 012021 MOV (R0)+,(R1)+ ; VECTOR ADDRESS
9889 056356 000207 RTS PC ; RETURN

```

```

9890
9891 056360 046522 051503 020061 MRMCS1: .ASCIZ @RMCS1 = @
9892 056366 020075 000
9893 056371 122 053110 041505 MRHVEC: .ASCIZ @RHVEC = @
9894 056376 036440 000040

```

```

9895
9896 .SBTTL CK.NUM - CHECK NUMBER (OCTAL)
9897 ; THIS ROUTINE CHECKS AN ASCIZ STRING FOR LEGAL CHARACTERS
9898 ; AND FORMS AN OCTAL NUMBER IN R2
9899 ; CALL:
9900 ; MOV $ADR,R1 ; ADDRESS OF ASCIZ STRING
9901 ; JSR R5,CK.NUM ; R5 CHANGED
9902 ; RET ; ERROR EXIT
9903 ; RET ; NORMAL EXIT
9904 056402 010246 CK.NUM: MOV R2,-(SP) ; SAVE R2
9905 056404 010346 MOV R3,-(SP) ; SAVE R3
9906 056406 010446 MOV R4,-(SP) ; SAVE R4
9907 056410 012703 000006 MOV #6,R3 ; MAX OCTAL DIGITS IN THE NUMBER
9908 056414 005002 CLR R2 ; FINAL OCTAL VALUE
9909 056416 112104 1$: MOVBL (R1)+,R4 ; GET CURRENT POINTED BYTE
9910 056420 001424 BEQ 3$ ; BRANCH IF TERMINATOR DETECTED
9911 056422 120427 000060 CMPB R4,#'0 ; SMALLER THAN ASCII-0 ?
9912 056426 103425 BLO 5$ ; YES, ERROR EXIT
9913 056430 120427 000067 CMPB R4,#'7 ; LARGER THAN ASCII-7 ?
9914 056434 101022 BHI 5$ ; YES, ERROR EXIT
9915 056436 006302 ASL R2 ; SHIFT LEFT
9916 056440 103420 BCS 5$

```

9917	056442	006302		ASL	R2		:ONE
9918	056444	103416		BCS	5\$		
9919	056446	006302		ASL	R2		:OCTAL DIGIT
9920	056450	103414		BCS	5\$		:ERROR IF CARRY BIT SET
9921	056452	042704	177770	BIC	#177770,R4		:CHOP OFF HIGHER BITS
9922	056456	060402		ADD	R4,R2		:APPENDING CURRENT DIGIT TO NUMBER
9923	056460	005303		DEC	R3		:DECREMENT BYTE COUNT
9924	056462	001401		BEQ	2\$		:BRANCH IF LAST BYTE
9925	056464	000754		BR	1\$		:LOOPING BACK
9926	056466	112104		2\$:	MOVB (R1)+,R4		:CHECK TERMINATOR
9927	056470	001004		BNE	5\$		:ERROR EXIT
9928	056472	005702		3\$:	TST R2		:FINAL VALUE = 0
9929	056474	001401		BEQ	4\$		:YES, THEN NOT REPLACE THE ORIGINAL VALUE
9930	056476	010210		MOV	R2,(R0)		:REPLACE THE ORIGINAL VALUE
9931	056500	005725		4\$:	TST (R5)+		:ADJUST FOR NORMAL RETURN
9932	056502	012604		5\$:	MOV (SP)+,R4		:RESTORE R4
9933	056504	012603		MOV	(SP)+,R3		:RESTORE R3
9934	056506	012602		MOV	(SP)+,R2		:RESTORE R2
9935	056510	000205		RTS	R5		:EXIT

9936							
9937	056512	000400		CYLDER:	.BLKW 256.		:ONE SECTOR WORD CTR MAX SIZE
9938		057512		ENDPGM	=		
9939							
9940							
9941							
9942							

.NLIST BEX

057512	005015	055103	046522	TITLE:	.ASCII <CR><LF>/CZRMBO/<CR><LF>
057525	122	030115	027463		.ASCIZ @RMO3/RMO2 PERFORMANCE EXERCISER @<CR><LF><LF>
057571	015	052012	020117	LOADRV:	.ASCII <CR><LF>/TO TEST DRIVE 0, REPLACE THE 'XXDP' PACK ON DRIVE 0/<CR><LF>
057660	044527	044124	040440		.ASCII /WITH ANOTHER PACK, CLEAR MEMORY LOCATION 40,/<CR><LF>
057736	047101	020104	042522		.ASCIZ /AND RESTART THE PROGRAM/<CR><LF>
057770	005015	054523	052123	NOLOAD:	.ASCIZ <CR><LF>/SYSTEM HAS 16K MEMORY, 'XXDP' LOADER WILL BE OVERWRITTEN/<CR><L

.LIST BEX

9943							
9944		000001			.END		

ABASE = 176700	2271#	2561	2602			
ABNRML 027064	3702	6735#				
ACDW1 = 000000	2561	2604				
ACDW2 = 000000	2561	2605				
ACK = 000123	2456#					
ACPUOP = 000000	2561	2576				
ACTDRV 034536	8171#	8444*	8495*	8821*	8830*	9087
ACTSTR 034537	8177#	9089*	9103*			
ADDW0 = 000000	2561					
ADDW1 = 000000	2561					
ADDW10 = 000000	2561					
ADDW11 = 000000	2561					
ADDW12 = 000000	2561					
ADDW13 = 000000	2561					
ADDW14 = 000000	2561					
ADDW15 = 000000	2561					
ADDW2 = 000000	2561					
ADDW3 = 000000	2561					
ADDW4 = 000000	2561					
ADDW5 = 000000	2561					
ADDW6 = 000000	2561					
ADDW7 = 000000	2561					
ADDW8 = 000000	2561					
ADDW9 = 000000	2561					
ADEVCT = 000000	2561	2567				
ADEVN = 000000	2561	2603				
AENV = 000000	2561	2572				
AENVN = 000000	2561	2573				
AFATAL = 000000	2561	2564				
AMADR1 = 000000	2561	2589				
AMADR2 = 000000	2561	2593				
AMADR3 = 000000	2561	2596				
AMADR4 = 000000	2561	2599				
AMAMS1 = 000000	2561	2583				
AMAMS2 = 000000	2561	2591				
AMAMS3 = 000000	2561	2594				
AMAMS4 = 000000	2561	2597				
AMSGAD = 000000	2561	2569				
AMSGLG = 000000	2561	2570				
AMSGTY = 000000	2561	2563				
AMTYP1 = 000000	2561	2584				
AMTYP2 = 000000	2561	2592				
AMTYP3 = 000000	2561	2595				
AMTYP4 = 000000	2561	2598				
AOE = 001000	2361#					
APASS = 000000	2561	2566				
APRIOR = 000000	2561					
APTCSU = 000040	7394	7500#				
APTENV = 000001	7302	7387	7456	7498#		
APTSIZ = 000200	3312	7497#				
APTSPO = 000100	7389	7458	7499#			
ASGND 054041	3598	9678#				
ASGN1 024470	6264#					
ASGN2 024544	3480	6263	6276#			
ASGN3 024626	6273	6284	6291#			
ASGN4 024740	6292	6314#				

# H15

CZRM880 RM03/2 PERF EXER  
CZRM88.P11 21-NOV-77 15:34

MACY11 30(1046) 22-NOV-77 10:06 PAGE 191  
CROSS REFERENCE TABLE -- USER SYMBOLS

SEQ 0189

ASGN6	024742	6299	6315#												
ASGN7	024754	6298	6317#												
ASKPAR	055012	3410	9697#												
ASNERR	026734	6275	6289	6316	6326	6352	6372	6692#							
ASNLST	001544	2751#	3554	3605*	5956	5963	6266	6282	6291	6341	6343*	6365	6374	6388	
		6711*	6725	6807*	6810										
ASNMSG	026754	6265*	6270*	6281*	6315*	6320*	6322*	6324*	6351*	6371*	6700#				
ASSIGN	024462	6262#	6331	6414	6419	6423									
ASWREG=	000000	2561	2574												
ATA =	100000	2348#													
ATABIT	034606	3605	5963	6266	6282	6291	6341	6343	6365	6388	6711	6807	8243#	8411	
		8507	8613	9006	9028	9036	9037	9057	9147						
AATESTN=	000000	2561	2565												
ATTN	001342	2627#	7282*	9652	9654										
ATO =	000001	2374#													
AT1 =	000002	2375#													
AT2 =	000004	2376#													
AT3 =	000010	2377#													
AT4 =	000020	2378#													
AT5 =	000040	2379#													
AT6 =	000100	2380#													
AT7 =	000200	2381#													
AUNIT	000000	2561	2568												
AUSWR =	000000	2561	2575												
AUTOCK	001502	2704#													
AVAIL	001612	2761#	3557	3599	3603*	3645	3648	3681	3705						
AVECT1=	000254	2272#	2561	2600											
AVECT2=	000000	2561	2601												
A16 =	000400	2284#													
A17 =	001000	2285#													
BADENT	054417	6675	9678#												
BADSEC	001362	2636#	3701*	5429*	5503	6084	6096	6108	6120	6132					
BAI =	000010	2302#													
BEGCOD	001516	2732#	6452	6453											
BEGPAT	001514	2731#	6455												
BEGSIZ	001520	2739#	6457	6458											
BIT0 =	000001	2256#	6588	6617											
BIT00 =	000001	2246#	2256	4403	5041	5162	6339								
BIT01 =	000002	2245#	2255	3778	4908	8487	8742								
BIT02 =	000004	2244#	2254	4452	5037	5190	5197	6494							
BIT03 =	000010	2243#	2253	3871	4238	8964	9264								
BIT04 =	000020	2242#	2252	3871	3883	8999									
BIT05 =	000040	2241#	2251	4339	8333	8763	8979								
BIT06 =	000100	2240#	2250	3952	3953	4043	4058	4900	5674	6256	7161	8420	8478	8552	
		8861	9324												
BIT07 =	000200	2239#	2249	3764	3886	4900	8420	8687	8842	8964	8979	8999	9032	9296	
BIT08 =	000400	2238#	2248	3860	8420										
BIT09 =	001000	2237#	2247	3776	9138										
BIT1 =	000002	2255#	6613	6627											
BIT10 =	002000	2236#	3774	3898	3906	7290	8744								
BIT11 =	004000	2235#	3772	3901	8380	8514	8708	9073							
BIT12 =	010000	2234#	3770	3909	3952	3953	3972	4464	5044	5662	8375	8402	8420	8489	
		8522	8702	8725	8740	8754	8989	8991	9203	9259	9325				
BIT13 =	020000	2233#	3889	3915	4210	4306	6987	7297	8472	8937	9206				
BIT14 =	040000	2232#	3751	3753	3778	3874	3877	3915	4033	4084	4128	4168	4274	4289	
		4481	4551	8484	8519	8924	9068	9168	9214	9218	9322				

BIT15 = 100000	2231#	3749	3917	3952	4012	4056	4306	4481	4551	8472	8484	8487	8489
	8519	8522	8708	8742	8744	8861	8964	8979	8989	8999	9068	9138	9168
	9175												
BIT2 = 000004	2254#	3780	9175										
BIT3 = 000010	2253#	3892											
BIT4 = 000020	2252#	4134											
BIT5 = 000040	2251#	3895											
BIT6 = 000100	2250#	3972	5523										
BIT7 = 000200	2249#	3955	4174	4874									
BIT8 = 000400	2248#	4089	4113	4118	4148	4153	4306						
BIT9 = 001000	2247#	3904	4306										
BLKADR 002102	2280#	3361	3508	5961	6302	6308	6345	6368	7566				
BPTVEC= 000014	2263#												
BUFTBL 001700	2773#	3380*	3381*	3382*	3385*	3386*	3388*	3389*	3392*	3396	3398	3399	4935
	4937	4951*	4977	4978	4990*	4995*	5000	5001	5014*				
BUSADR 056240	3352	9863#											
BUSY 054441	6199	9678#											
CFLAG 001360	2635#	3371*	3540	6202*	6208	6525*	6535	6652*	6664	6680*	7174*	7231*	
CHGADR 001356	2634#	3272*	3274*	3478	3497	7563*	9863	9865*					
CHKADR 017172	3736	5167	5213#										
CI1 036114	8542	8570#											
CI3 036222	8544	8593#											
CI4 036322	8533	8615#											
CI5 036700	8592	8614	8692#	8701									
CI6 036722	8631	8641	8643	8645	8697#								
CI7 036736	8474	8551	8582	8586	8590	8598	8608	8612	8623	8630	8636	8640	8654
	8660	8664	8674	8685	8700	8702#	8816	8846	9018	9308			
CI7B 036760	8710#	9022											
CI8 037036	8713	8724#	9160										
CKBUS 012732	3756	4434#											
CKCLK 022632	3424	5917#	7557										
CKCLK1 022726	5919	5930#											
CKCLK2 022774	5931	5939#											
CKCLK3 023024	5929	5938	5946#										
CKERR 012640	3755	4415#											
CKFMT 010712	3885	4113#											
CKHCE 011106	3888	4148#											
CKSWR = 104407	7281	7312	8052#										
CK.CHR 030226	7043#	7080	7094										
CK.DEC 030200	7021#	7049											
CK.DIG 030300	6666	7074#											
CK.NUM 056402	9874	9883	9904#										
CK.OCT 030152	7003#	7051											
CLKFLG 001310	2618#	5917*	5922*	5933*	6142								
CLOCK 023766	5925	5935	6163#										
CLR = 000040	2304#												
CLRDPB 025432	3509	6303	6431#										
CLRQUE 042560	8315	8762	9392#										
CMCNT 001410	2651#	4402*	4406*	4461*	4462*	4472	4474	4475*	4478*	4528	4532	4535*	4558*
CMCYL 001412	2652#	4463*	4464*	4465*	4482	4547*	4548	4552					
CMDAT 013270	4480	4490	4494#	4536	4538								
CMHED 013216	4481#												
CMPAR 013016	3759	4452#											
CMPARD 013034	4001	4456#											
CMPLMT 001472	2688#	4410	4467										
CMPRES 017666	3576	3634	3683	3709	5324#	5327							













LINE2B	020650	5504	5507#																	
LINE3	021070	3798	3832	3852	3863	3949	4018	4040	4081	4106	4126	4166	4207	4272						
		4287	4303	4353	4426	5554#														
LINE3A	021076	4334	4371	4593	5560#															
LINE3B	021104	4323	5566#																	
LINE3C	021116	4192	5573#																	
LINE3D	021126	4444	5533	5579#																
LINE3E	021174	4235	5593#																	
LINE3F	021262	4253	5612#																	
LINE4	021540	3799	3833	3853	3864	3950	4019	4041	4082	4127	4167	4208	4236	4273						
		4288	4304	4335	4372	4427	4445	4594	5534	5674#										
LINE5	021630	4020	4042	4086	4130	4170	4276	4291	5693#											
LINE5A	021730	4083	4131	4171	4194	4277	4292	5714#												
LINE5B	021776	3992	5729#																	
LINE6	022040	3955	5742#																	
LINE6A	022052	3998	5749#																	
LINE6B	022060	3991	5755#																	
LINE6C	022066	3939	4025	4051	4060	4093	4138	4178	4214	4242	4312	4342	4358	5761#						
LINE6D	022074	3941	3996	4027	4096	4141	4181	4217	4245	4314	4345	4360	5767#							
LINE7	022150	3801	3835	3855	3866	3942	3988	4006	4065	4068	4094	4097	4108	4139						
		4142	4179	4182	4215	4218	4243	4255	4264	4279	4294	4315	4343	4361						
		4429	4447	4631	4888	5791#														
LINE7A	022276	4197	4326	5819#																
LINE8	022416	3985	4062	4887	5845#															
LING6	052214	5761	9678#																	
LINKDV	027522	4666	4758	5704	6846	6856#														
LINH3	051455	5554	9678#																	
LINH4	051716	5676	9678#																	
LINN3	051471	5560	9678#																	
LINOCT	022430	4378	4381	4384	4387	4390	4393	4396	4399	4610	4613	4616	4724	4727						
		4730	4736	4739	4742	4772	4777	5543	5583	5586	5616	5620	5678	5696						
		5699	5717	5720	5731	5735	5855#													
LINP3	051515	5634	9678#																	
LINP5	052035	5706	9678#																	
LINR6	052232	5784	9678#																	
LINSP	053246	3456	4379	4385	4391	4397	4611	4614	4725	4728	4731	4737	4740	4743						
		4775	5512	5545	5596	5601	5617	5718	5721	5732	6016	6021	6026	6032						
		6038	9678#	9871	9880															
LINSP0	053247	5455	5509	6044	6051	6056	6061	6066	9678#											
LINSS3	051701	5602	9678#																	
LINST3	051664	5597	9678#																	
LINS3	051536	5593	5650	9678#																
LINS4	051735	5679	9678#																	
LINS5	052053	5715	9678#																	
LINT3	051610	5664	9678#																	
LINU06	052243	5767	9678#																	
LINW3	051652	5584	9678#																	
LINX4	051747	5682	9678#																	
LINX5	053251	5722	9678#																	
LIN10A	052662	4685	9678#																	
LIN10B	052716	4690	9678#																	
LIN10C	052757	4745	9678#																	
LIN10H	053064	4722	9678#																	
LIN11H	053151	4769	9678#																	
LIN2C	051352	5475	9678#																	
LIN2P	051373	5481	9678#																	



























SSB20	030436	4688	5872	6018	6048	6053	6058	6063	6072	6146	6151	6156	7129#	
SSB20	030466	5856	7146#											
SSEC	= 000010	4466	4844#	5046	5226	5279	5305*	5352*	5360*	5604	6513*	6578*	6585*	6586
SSETUP	= 000156	6615#	8878	9493#										
		3263#	3286	3287	3289	3291	3293	3295	3328	6816	7281	7312	7314	7723
		7826												
SSIZE	056142	3378	9829#											
SSKI	= 000064	5833	6070	6110	6112*	9515#								
SSOFT	= 000060	6068	6086	6088#	9513#									
SSSEC	= 000022	4472	4477	4478	4665	4757	5310*	5313*	5381*	5385*	5703	6460*	6463*	9502#
SSTUP	= 177777	3263#												
SSUPRS	030036	4689	5795	5803	5808	5823	5828	5873	6958#					
SSVPC	= 000210	2486#	2491											
SSWR	= 122000	2128#	2139	2143	2144	2145	2146	2553	3277	3295	6748	6816	6826	6832
		6834	7273	7274	7275	7276	7277	7290	7297	7309	7313	7315	7540	
SSWREG	001226	2574#	3314											
STATUS	= 000016	3694	3747	3764	3770	3772	3774	3776	3778	3780	3871	3962	3965	3982
		4047	4816	4852	4868	4874	4900	5523	5674	6582	9497#	9674		
		8058#												
STERM	= 000032	2565#	3277*	6834#										
STESTN	001210	5454	5995	6142#	6203	7286								
STIME	023670	2546#	6204	6255	7160	7721	7732	7749	7803	7809				
STKB	001162	3327	3489	7158#										
STKINT	030516	2545#	6256*	7161*	7175*	7185*	7187*	7721	7730	7746	7770*	7801	7807	
STKS	001160	7158	7168#											
STKSRV	030546	2128#	2139	3275	3277#									
STN	= 000002	7930	7931	7951#										
STNPR	034160	5797	6067	6134	6136*	6737	9512#							
STOTAL	= 000056	2548#	7432*	7443										
STPB	001166	2552#	7381	7443										
STPFLG	001173	2547#	7430	7443										
STPS	001164	4906#	4907*	4912*	4913*	5800	9510#							
STRANS	= 000046	3289	8021#											
STRAP	034364	8032#	8043											
STRAP2	034406	4843#	5224	5357	5359*	5599	6514*	6569*	9494#					
STRK	= 000011	8036#	8045#	8046#	8047#	8048#	8049#	8050	8051#	8052	8053#	8054#	8055#	8056#
STRP	= 000015	8057#	8058#											
		8026	8043#	8058										
STRPAD	034420	2511#												
STSTM	001104	2525#	7289	7315										
STSTM	001116	7202	7203	7215	7238	7252	7256#							
STTYIN	031156	8049												
STYPBN	= ***** U	7662#	8048											
STYPDS	032770	6977	6990	7381#	7475	8036	8044							
STYPE	031516	7411	7418	7425	7430#	7431	7772							
STYPEC	031730	7436	7438	7441#										
STYPEX	031776	7602#	8045											
STYPOC	032566	7601	7604#	8047										
STYPON	032602	7597#	8046											
STYPOS	032542	2568#	2626											
SUNIT	001216	2513#												
SUNITM	001110	2575#												
SUSWR	001230	2600#	3341	3343										
SVECT1	001254	2601#												
SVECT2	001256	4436	4461	4563	4754	4912	4938	4945	4947*	4948	4949*	4980	4989	4994
SWRDL	= 000020	4998	5040	5307*	5370*	5371*	5377*	5525	5680	5701	6457*	9501#	9502	9503





.SCATC	2128#	2468
.SCMTA	2128#	2516
.SDB2D	2128#	7910
.SDB2O	2128#	7973
.SEOP	2128#	6744
.SERRO	2128#	7267
.SERRT	2128#	7316
.SPOWE	2128#	7502
.SRAND	2128#	7827
.SREAD	2128#	7718
.SSAVE	2128#	7864
.SSIZE	2128#	9821
.STRAP	2128#	8013
.STYPD	2128#	7650
.STYPE	2128#	7364
.STYPO	2128#	7572

. ABS. 060065 000

ERRORS DETECTED: 0

RMO3:CZRMBB,RMO3:CZRMBB.SEQ/NL:MD:MC:CND:TOC/DOC/SOL/CRF=RMO3:RMDRV5.P11,RMO3:CZRMBB.P11  
RUN-TIME: 34 27 2 SECONDS  
RUN-TIME RATIO: 2633/64=40.7  
CORE USED: 42K (83 PAGES)

DOCUMENT PAGES: 211