

VT50,52,55

VT50A,B,H/52 ACCPT
CZVTCF0

AH-9508F-MC

SEP 1979

COPYRIGHT 74-79
FICHE 1 OF 1

digital
MADE IN USA

The image shows a microfiche card. The left side contains a grid of frames, each containing a small image or document snippet. The right side is a large, mostly blank area, likely reserved for a title or additional information. The card is dark blue with a red header at the top.

.REM ^

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49

IDENTIFICATION

PRODUCT CODE:	AC-9506F-MC
PRODUCT NAME:	CZVTCFO VT50A,B,H/52 ACCPT
PRODUCT DATE:	APRIL 1979
MAINTAINER:	DIAGNOSTIC ENGINEERING

COPYRIGHT (C) 1974,1979 DIGITAL EQUIPMENT CORP., MAYNARD, MASS.

THIS SOFTWARE IS FURNISHED TO PURCHASER UNDER A LICENSE FOR USE ON A SINGLE COMPUTER SYSTEM AND CAN BE COPIED (WITH INCLUSION OF DEC'S COPYRIGHT NOTICE) ONLY FOR USE IN SUCH SYSTEM, EXCEPT AS MAY OTHERWISE BE PROVIDED IN WRITING BY DEC.

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION.

DEC ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT WHICH IS NOT SUPPLIED BY DEC.

50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102

1. ABSTRACT

THIS PROGRAM IS AN ACCEPTANCE TEST OF THE VT50/52 VIDEO TERMINAL. THE PROGRAM CONSISTS OF FOUR PARTS, ALL OF WHICH REQUIRE OPERATOR INSPECTION OR INTERACTION. THE PROGRAM IS CAPABLE OF HANDLING MULTIPLE UNITS IN A SEQUENTIAL DL11 FASHION (REF 8.2).

ONLY ONE VT50/52 IS TESTED AT ONE TIME.

THE PROGRAM WILL DEFAULT TO THE CONSOLE TTY (REF 5.0 AND 8.2). ALL CHARACTERS AND COMMANDS ARE TESTED. IN THE KEYBOARD CHARACTER TEST THE FOLLOWING 'FUNCTION' KEYS ARE NOT TESTED:
BREAK, REPEAT, AUTO-PRINT, AND SCROLL.

PART 1 CONSISTS OF A SERIES OF TEST PATTERNS DISPLAYED ON THE VT50/52 SCREEN AND COPIER (REF 9. FOR DESCRIPTION). THE OPERATOR MUST VISUALLY INSPECT EACH TEST PATTERN FOR ERROR DETECTION.

PART 2 IS A KEYBOARD CHARACTER TEST. THIS TEST IS TO DETERMINE THAT THE TERMINAL IS GENERATING THE EXPECTED ASCII CODES. IN THIS TEST AN OPERATOR WILL BE REQUIRED TO FOLLOW THE INSTRUCTIONS DISPLAYED ON THE VT50/52 SCREEN AND EXECUTE THEM. DUE TO THE FLEXIBILITY OF DIFFERENT PROCESSORS OR OPTIONS, PARITY BIT TESTING MUST BE SELECTED BY THE OPERATOR. THE OPERATOR SELECTS THE TYPE OF PARITY TO BE TESTED BY SW00-01.

PART 3 IS A KEYBOARD OCTAL VALUE LOOP. WHEN A KEY IS DEPRESSED, THE OCTAL VALUE WILL BE DISPLAYED ON THE SCREEN. IF THE KEY DEPRESSED WAS PRINTABLE, IT WILL ALSO BE DISPLAYED ON THE SCREEN. IF A 'DEFINED' CHARACTER, A TWO LETTER EQUALIVENT (I.E., BL=BELL, ES=ESCAPE, ETC.) WILL BE DISPLAYED.

PART 4 IS A KEYBOARD ECHO LOOP. WHEN A KEY IS DEPRESSED, THE CHARACTER IS ECHOED TO THE SCREEN. NO TESTING OF THE CHARACTER IS PERFORMED. THIS ALLOWS THE OPERATOR A 'LOCAL' MODE OF OPERATION BETWEEN THE VT50/52 AND THE HOST COMPUTER.

2. REQUIREMENTS

2.1 EQUIPMNT

PDP-11 FAMILY COMPUTER WITH 8K WORDS OF MEMORY.
VT50A, B, H, 52 VIDEO TERMINAL CONNECTED VIA A DL11A/B TYPE INTERFACE.

2.2 STORAGE

THIS PROGRAM USES 8K OF MEMORY.

103
104
105
106
107
108
109
110
111
112
113
114
115
116
117
118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152

3. LOADING PROCEDURE

PROCEDURE FOR NORMAL BINARY TAPES SHOULD BE FOLLOWED.

4. STARTING PROCEDURE

4.1 CONTROL SWITCH SETTINGS

STANDARD PDF-11 FORMAT

SW 15 = 1	HALT ON ERROR
SW 14 = 1	LOOP ON TEST
SW 13 = 1	INHIBIT ERROR TYPEOUTS
SW 12 = 1	INHIBIT PROGRAM SUB-TEST DELAY
SW 11 = 1	INHIBIT COPIER TESTING
SW 10 = 1	ENABLE 'SAVE COPIER PAPER' MODE
SW 08 = 1	LOOP ON TEST IN SWR <4:0>
SW 07 = 1	KEYBOARD CONTROL OF THE TEST <SW 8 AND SW 7 = 1 IS AN ERROR>

KEYBOARD CHARACTER TEST ONLY

SW02 =	1	ENABLE PARITY BIT TEST
SW00-01=	00	EVEN PARITY CHECK
SW00-01=	01	ODD PARITY CHECK
SW00-01=	10	ALWAYS A 0
SW00-01=	11	ALWAYS A 1

SPECIAL NOTE: IF THE COMPUTER UTILIZED IS AN LSI-11 OR A COMPUTER WITHOUT A SWITCH REGISTER, THE PROGRAM WILL UTILIZE LOCATIONS 174 AND 176 AS A 'DISPLAY' REGISTER AND A 'SWITCH' REGISTER RESPECTIVELY. THE OPERATOR WILL BE RESPONSIBLE FOR THE LOADING OF THE 'SWITCH' REGISTER LOCATION PRIOR TO STARTING OR RESTARTING THE PROGRAM.

4.2 STARTING ADDRESS OR ADDRESSES

200	IS THE STARTING ADDRESS OF THE ACCEPTANCE TEST
204	IS THE RESTART ADDRESS OF THE ACCEPTANCE TEST
210	IS THE STARTING ADDRESS OF THE KEYBOARD CHARACTER TEST
214	IS THE STARTING ADDRESS OF THE KEYBOARD OCTAL VALUE LOOP
220	IS THE STARTING ADDRESS OF THE KEYBOARD ECHO LOOP
224	IS THE SPECIAL STARTING ADDRESS FOR VT50 PRODUCTION

153
154
155
156
157
158
159
160
161
162
163
164
165
166
167
168
169
170
171
172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193

5. OPERATING PROCEDURE

THE OPERATOR MUST INSERT THE CORRECT INFORMATION IN THE SWITCH REGISTER WHEN REQUIRED BY THE PROGRAM OR AN ERROR WILL OCCUR. ONCE STARTED, THE TEST WILL RUN IN ITS NORMAL MANNER WITHOUT OPERATOR INTERVENTION OR SWITCH CHANGES.

THIS PROGRAM ALLOWS THE OPERATOR TWO MODES OF TEST PATTERN SELECTION. THESE MODES ARE SELECTED BY THE STATE OF SW07 AT THE BEGINNING OF THE PROGRAM. WHEN SW07 IS A ZERO, THE PROGRAM IS UNDER SWITCH REGISTER CONTROL FOR TEST PATTERN SELECTION. IF SW07 IS EQUAL TO A ONE, THE PROGRAM IS UNDER KEYBOARD CONTROL OF THE TEST PATTERN SELECTION. IN THIS MODE THE OPERATOR WILL BE REQUIRED TO TYPE IN ON THE CONSOLE TTY THE FIRST AND LAST OCTAL BASE ADDRESS OF THE DL11'S TO WHICH VT50'S ARE CONNECTED.

IN THE KEYBOARD SELECT MODE, TWO CHARACTERS ARE USED TO SELECT THE "STARTING WITH" OR "LOOPING ON" A PARTICULAR TEST PATTERN BY '/' OR '\ ' RESPECTFULLY.

THE '/' KEY IS USED TO SUSPEND THE CURRENT TEST AND ASK THE OPERATOR A WHICH TEST PATTERN HE/SHE WISHES TO START. THE OPERATOR NOW DEPRESSES THE LETTER WHICH REPRESENTS THE TEST PATTERN TO BE STARTED WITH. REFER TO THE PROGRAM LISTING TABLE OF CONTENTS FOR THE TEST LETTER OF EACH PATTERN.

THE '\ ' KEY IS USED TO SUSPEND THE CURRENT TEST AND ASK THE OPERATOR WHICH TEST PATTERN HE/SHE WISHES TO LOOP ON. THE OPERATOR NOW DEPRESSES THE LETTER OF THE TEST TO LOOP ON.

IF DURING THE EXECUTION OF A TEST PATTERN, A KEY IS DEPRESSED AND SW07 EQUALS A ZERO, AN ERROR WILL BE REPORTED TO THE CONSOLE TTY. IF SW07 EQUALS A ONE, AND THE CHARACTER RECEIVED WAS NOT A '/' OR '\ ', AN ERROR WILL BE REPORTED. THE CODES 'X-OFF' AND 'X-ON' ARE THE ONLY EXCEPTIONS.

194
195
196
197
198
199
200
201
202
203
204
205
206
207
208
209
210
211
212
213
214
215
216
217
218
219
220
221
222
223
224
225
226
227
228
229
230
231
232
233
234
235
236
237
238
239
240
241
242
243
244
245
246
247
248
249

6. ERRORS

THIS PROGRAM USES THE DIAGNOSTIC 'SYSMAC' PACKAGE FOR ERROR REPORTING AND TYPEOUT. REFER TO THE 'ERROR POINTER TABLE' FOR TYPE AND DESCRIPTION OF ERRORS. THE ERROR INFORMATION CONSISTS OF THE FOLLOWING:

ERRPC - LOCATION AT WHICH AN ERROR WAS DETECTED
VTNOW - CURRENT DL11 BUS ADDRESS OF VT50/52 UNDER TEST
TSTNUM - TEST PATTERN NUMBER OF FAILING TEST
EXPT - EXPECTED INPUT CHARACTER
RCVD - RECEIVED INPUT CHARACTER

7. RESTRICTIONS

- A. THE OPERATOR SHOULD SET SW15 AND SW13 IF THE VT50/52 UNDER TEST IS THE CONSOLE TTY.
- B. ONLY ONE VT50/52 CAN BE TESTED AT ONE TIME.
- C. THE FIRST TIME AFTER LOADING THE PROGRAM, THE TERMINAL IDENTIFIER MUST BE RUN.

8. MISCELLANEOUS

8.1 EXECUTION TIME

EXECUTION TIME WILL VARY WITH THE 'BAUD' RATE, AND IF A COPIER IS CONNECTED. THE PROGRAM WILL TYPE 'END PASS' WHEN A PASS HAS BEEN COMPLETED. THE KEYBOARD LOOP AND CHARACTER TEST WILL NOT EXIT UNTIL THE PROGRAM IS RESTARTED.

8.2 DEVICE ADDRESS PROGRAM LOCATIONS (AT APPROX. 1240)

THE LOCATION 'FIRST' CONTAINS THE FIRST DL11 ADDRESS IF SEVERAL VT50'S ARE BEING TESTED. THE DEFAULT IS THE CONSOLE ADDRESS <177560> THE LOCATION 'LAST' CONTAINS THE LAST DL11 ADDRESS IF SEVERAL VT50'S ARE BEING TESTED. LOCATION VTNOW CONTAINS THE CURRENT DL11 BASE ADDRESS.

*NOTE: IF THESE LOCATIONS ARE CHANGED, THE OPERATOR MUST START THE TEST AGAIN AT LOC. 200. THE PROGRAM WILL USE THE BASE ADDRESS TO UPDATE THE ACTUAL PROGRAM VALUES.

8.3 COPIER SAVE PAPER SWITCH

IF SW10 = 1 AND A COPIER IS INSTALLED, THE COPIER TESTS WILL BE EXECUTED ON THE FIRST PASS AND THEN BYPASSED FOR THE NEXT TEN PASSES. THIS REDUCES PAPER USAGE WHEN THE PROGRAM IS RUN FOR AN EXTENDED PERIOD. (LOC. PTCT IS # OF PASSES.)

250
251
252
253
254
255
256
257
258
259
260
261
262
263
264
265
266
267
268
269
270
271
272
273
274
275
276
277
278
279
280
281
282
283
284
285
286
287
288
289
290
291
292
293
294
295
296
297
298
299
300
301
302
303
304
305

9. PROGRAM DESCRIPTION <SCREEN>

9.1 A TERMINAL IDENTIFICATION TEST

THIS TEST WILL INTERROGATE THE VT50/52 UNDER TEST AS TO ITS TYPE. THE RESPONSE RECEIVED IS USED TO DETERMINE THE MODES TO BE TESTED (I.E., COPIER, 12/24 LINES, D.C.A. <DIRECT CURSOR ADDRESSING>, ETC.). IF AN UNDEFINED OR AN INCORRECT RESPONSE IS RECEIVED, THE PROGRAM ASSUMES VT50A MODEL (I.E., 12 LINES, NO COPIER, NO D.C.A., NO KEYPAD).

9.2 B FULL SCREEN OF THE LETTER E

THIS TEST WILL FILL THE SCREEN WITH THE LETTER E. THIS TEST WILL LOAD THE SCREEN RAM WITH A SINGLE CHARACTER IN ALL LOCATIONS.

9.3 C DATA PATH AND RAM NOISE TEST

THIS TEST WILL PRODUCE TWO FULL SCREENS OF WORST CASE NOISE PATTERN FOR THE SCREEN RAM AND THE DATA PATH. ALTERNATING LINES OF THE FOLLOWING PATTERNS SHOULD BE DISPLAYED.

*U*U*U*U*U CODES 52 AND 125
@?@?@?@?@? CODES 77 AND '00
*U*U*U*U*U
@?@?@?@?@?

9.4 D SINGLE CHARACTER SET

ONE FULL LINE OF EACH CHARACTER (CODES 40 THRU 137) OF THE CHARACTER SET. THIS WILL ALSO TEST THAT ALL WORDS IN THE SCREEN RAM CAN BE LOADED. THIS WILL ALSO EXERCISE THE SCROLLING FUNCTION.

IE: AAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAAA
BB
CC
DDDDDDDDDDDDDDDDDDDDDDDDDDDDDDDDDDDDDD

9.5 E INCREMENTING AND SLIDING CHARACTER SET

ONE FULL LINE OF AN INCREMENTING CHARACTER SET ACROSS THE FULL SCREEN STARTING WITH THE CODE 40 (SPACE) THE NEXT LINE SHOULD BEGIN WITH THE '!' CHARACTER (CODE 41), ETC. CONTINUE THE PATTERN BY INCREMENTING THE FIRST COLUMN CHARACTER UNTIL THE FULL CHARACTER SET HAS BEEN EXHAUSTED.

CZVTCFO VT50A,B,H/52 ACCPT
CZVTCF.P11 11-APR-79 15:31

MACY1; 30A(1052) 11-APR-79 15:34 ^{H 1} PAGE 8

SEG 0007

306
307
308
309


THIS PATTERN WILL VERIFY THAT THE FULL
CHARACTER SET CAN BE DISPLAYED IN EACH
SCREEN WORD.

310
311
312
313
314
315
316
317
318
319
320
321
322
323
324
325
326
327
328
329
330
331
332
333
334
335
336
337
338
339
340
341
342
343
344
345
346
347
348
349
350
351
352
353
354
355
356
357
358
359
360
361
362
363
364

9.6 F CURSOR MOTION

IN THIS TEST THE BASIC CURSOR MOTIONS ARE TESTED. THE FOLLOWING TEST PATTERN IS GENERATED TO TEST THE CURSOR FUNCTIONS

BEFORE



UPON COMPLETION OF THE SETUP THE BLINKING CURSOR WILL BE TO THE RIGHT OF #4.

TO TEST 'CURSOR UP': GENERATE CURSOR UP 6/12 TIMES AND DISPLAY A 'X'


TO TEST 'CURSOR LEFT': GENERATE CURSOR LEFT (BACKSPACE) FORTY-FOUR TIMES AND DISPLAY A 'X'

TO TEST 'CURSOR DOWN': GENERATE CURSOR DOWN 6/12 TIMES AND DISPLAY A 'X'

TO TEST 'CURSOR RIGHT': GENERATE CURSOR RIGHT FORTY-TWO TIMES AND DISPLAY A 'X'

TO TEST 'CURSOR HOME': GENERATE CURSOR HOME AND DISPLAY A 'X'

AFTER



419
420
421
422
423
424
425
426
427
428
429
430
431
432
433
434
435
436
437
438
439
440
441
442
443
444
445
446
447
448
449
450
451
452
453
454
455
456
457
458
459
460
461
462
463
464
465
466
467
468
469
470
471
472
473
474

9.11 I ERASE FROM CURSOR TO END OF THE SCREEN:

GENERATE A FULL SCREEN OF THE CHARACTER 'E'
EXECUTE FOURTY 'CURSORS LEFT'
EXECUTE 'ERASE SCREEN' AND 'CURSOR UP'
REPEAT THIS 12 OR 24 TIMES, UPON COMPLETION THE PATTERN WILL
BE A LINE OF FOURTY CHARACTRS AT THE TOP LEFT OF THE SCREEN.

9.12 J VIDEO COUPLING:

THIS PATTERN WILL ALLOW FOR THE CHECKING OF VIDEO
COUPLING BETWEEN THE VIDEO AND VERTICAL CIRCUITS.
IF COUPLING OCCURS, THE VERTICAL DOTS OF THE CHARACTERS
WILL BE UNEVENLY SPACED OR DOTS WILL SPARKLE.

```
T @@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@ T  
T EEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEE T  
T @@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@ T  
T EEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEE T  
T @@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@ T  
T EEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEE T  
T @@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@ T  
T EEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEE T  
T @@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@ T  
T EEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEE T  
T @@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@ T  
T EEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEE T
```

9.13 K DIRECT CURSOR ADDRESSING (D.C.A.)

THIS TEST IS ONLY EXECUTED ON A VT50H. WHEN EXECUTED ON A VT50H
THIS TEST WILL BE RUN TWO TIMES. THE FIRST TIME WILL BE WITH
AN 'ESC-Y' AND THE SECOND WITH AN 'CODE 16'.
IF AN INCORRECT I.D., THIS TEST WILL NOT BE EXECUTED.
THIS TEST WILL RANDOMLY FILL THE SCREEN. THE END RESULT
WILL BE THE SAME STATEMENT ON ALL VERTICAL LINES.
EACH OF THE LINES SHOULD APPEAR THE SAME.

9.14 L HOLD SCREEN TEST

NOT EXECUTED IF VT50/52 PRODUCTION STARTING ADDRESS.
THIS TEST DETERMINES THAT THE 'XON-XOFF' FEATURE IS FUNCTIONING.
A FULL SCREEN SCROLL IS EXECUTED AND A SUB-TEST TITLE
WILL BE DISPLAYED. THE HOLD SCREEN MODE IS ENABLED AND
THE PROGRAM WILL ATTEMPT TO SCROLL THE SCREEN AGAIN AND SEND A MESSAGE.
THIS WILL CAUSE AN 'X-OFF' TO BE SENT AND THE SCREEN IS
INHIBITED FROM SCROLLING. ANY ADDITIONAL CHARACTERS RECEIVED
WILL BE PLACED INTO THE SILO STORAGE BUFFER. UPON RECEIPT
OF AN 'X-OFF', THE PROGRAM WILL DISABLE HOLD SCREEN MODE AND
SHOULD RECEIVE AN 'X-ON'. TO CHECK PROPER SILO OPERATION,
THE MESSAGE 'TESTING SILO REG' SHOULD APPEAR UNDER THE SUB-TEST TITLE
FOLLOWED BY 'SILO TEST DONE' ON THE NEXT LINE.

475
476
477
478
479
480
481
482
483
484
485
486
487
488
489
490
491
492
493
494
495
496
497
498
499
500
501
502
503
504
505
506
507
508
509
510
511
512
513
514
515
516
517
518
519
520
521
522
523
524
525

COPIER TEST PATTERNS

THE TEST PATTERNS USED TO TEST THE COPIER ARE THE SAME PATTERNS AS SOME OF THE SCREEN TESTS. TWO ADDITIONAL PATTERNS HAVE BEEN INCLUDED.

9.15 M GRAPHICS MODE/REVERSE LINE FEED TEST

THIS TEST IS EXECUTED ONLY IF THE UNIT IS A VT52. GRAPHICS MODE IS ENTERED AND 37 LINES OF GRAPHICS CHARACTERS(LINE LENGTH IS DECREMENTED BY ONE CHAR. AFTER A LINE IS PRINTED)ARE GENERATED. THE BOTTOM LINE OF THE WILL FORM A COMPLETE SERIES OF GRAPHIC CHARACTERS WHICH CAN BE VERIFIED FOR ACCURACY. IF REVERSE LINE FEED IS NOT OPERATIONAL A SINGLE LINE OF GRAPHICS CHARACTERS WILL BE GENERATED ON LINE 0 ONLY.

9.16 N COPIER - AUTO COPY MODE

THIS TEST DETERMINES IF THE AUTO COPY MODE IS FUNCTIONING CORRECTLY. THE SUB-TEST TITLE AND A ROW OF THE LETTER 'E' WILL BE DISPLAYED. THE AUTO-COPY MODE IS ENABLED. THE COPIER SHOULD THEN START. A PROGRAM DELAY IS EXECUTED BETWEEN EACH LINE. THE RESULT IS THE COPIER SHOULD COPY ONE LINE AND THEN STOP FOR THE PROGRAM DELAY TIME. WHEN THE PROGRAM DELAY IS COMPLETED ANOTHER LINE OF 'E'S WILL BE DISPLAYED AND THE COPIER SHOULD START AGAIN. UPON COMPLETION OF THE 12 OR 24 LINES, DISABLE AUTO-COPY MODE IS SENT TO THE VT50. IF THE AUTO COPY MODE IS NOT DISABLED THE NEXT SUB-TEST WOULD PERFORM IN A SIMILAR MANNER.

9.17 O COPIER - FULL SCREEN OF THE LETTER E

SAME AS SCREEN PATTERN

9.20 P COPIER - DATA PATH TEST PATTERN

SAME AS SCREEN PATTERN

9.21 Q COPIER - SINGLE CHARACTER PER LINE

SAME AS SCREEN PATTERN

9.22 R COPIER - ROTATING CHARACTER TEST

SAME AS SCREEN PATTERN

526
527
528
529
530
531
532
533
534
535
536
537
538
539
540
541
542
543
544
545
546
547
548
549
550
551
552
553
554
555
556
557
558
559
560
561
562
563
564
565
566
567

9.23 S COPIER - PERIMETER TEST

THIS TEST COPIES THE PERIMETER OF THE SCREEN AND THE
RESULTING PICTURE SHOULD RESEMBLE BELOW

```
EEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEE  
EEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEE  
EEE                                                                 EEE  
EEE                                                                 EEE  
EEE                                                                 EEE  
EEE                                                                 EEE  
EEE                                                                 EEE  
EEE                                                                 EEE  
EEE                                                                 EEE  
EEE                                                                 EEE  
EEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEE  
EEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEEE
```

9.24 T COPIER - DISCLAIMER STATEMENT

IN THIS TEST THE DISCLAIMER STATEMENT FROM THE COVER PAGE
OF THIS DOCUMENT IS DISPLAYED ON THE SCREEN AND THEN COPIED.
THE COPIED VERSION SHOULD BE COMPARED TO THE FRONT COVER TO
CHECK FOR ERRORS.

9.25 U PRINTER CONTROLLER MODE TEST

A 'ROLLING' PATTERN OF INCREMENTING CHARACTERS IS
ISSUED TO THE UNIT AFTER PRINTER CONTROLLER
MODE HAS BEEN ENTERED. 92 LINES(OF 132 CHAR. EACH)
SHOULD BE PRINTED WITH NO DATA APPERING ON SCREEN.

9.26 V PRINT SCREEN TEST

THE SCREEN IS FILLED WITH 24 LINES OF 'E'S. THE
PRINT SCREEN ESCAPE SEQUENCE IS ISSUED AND ALL
24 LINES SHOULD BE PRINTED.

9.27 W AUTO PRINT TEST

OPERATION IS SAME AS AUTO COPY TEST EXCEPT THAT
THE PRINTER, RATHER THAN THE COPIER, IS THE DESTINATION.

568
569
570
571
572
573
574
575
576
577
578
579
580
581
582
583
584
585
586
587
588
589
590
591
592
593
594
595
596
597
598
599
600
601
602
603
604
605
606
607
608
609
610
611
612
613
614
615

9.30 X KEYBOARD OCTAL VALUE LOOP

THIS LOOP IS PROVIDED TO ENABLE THE OPERATOR TO EXAMINE THE OCTAL VALUE OF A CHARACTER. WHEN A KEY IS DEPRESSED, THE OCTAL VALUE WILL BE DISPLAYED. IF THE CHARACTER WAS A PRINTABLE CHARACTER, IT WILL BE DISPLAYED. THOSE CODES DEFINED AS 'CONTROL' WILL BE DISPLAYED AS A TWO LETTER MNEMONIC, E.G., DE=DELETE, BL=BELL, CL=CURSOR LEFT, ETC.

9.31 Y KEYBOARD CHARACTER TEST

THIS TEST IS DESIGNED TO VERIFY THAT CORRECT CHARACTER CODES AND PARITY BIT ARE GENERATED WHEN A KEY IS DEPRESSED. THIS TEST REQUIRES THE OPERATOR TO EXECUTE THE INSTRUCTIONS DISPLAYED ON THE SCREEN. THE OPERATOR SHOULD ONLY DEPRESS ONE KEY AT A TIME WITH SOME EXCEPTIONS. THE OPERATOR WILL BE REQUIRED TO SKIP THOSE KEYS THAT ARE NOT IMPLEMENTED IF THE UNIT IS A VT50. THE PROGRAM WILL INFORM THE OPERATOR WHICH ROW TO TEST.

IN TESTING THE PARITY BIT, SW0 AND SW1 ARE USED TO INFORM THE PROGRAM OF THE EXPECTED PARITY. AN INCORRECT SWITCH SETTING WILL RESULT IN AN ERROR.

A KEYPAD TEST IS INCLUDED FOR THE VT50H AND VT52. IF AN INCORRECT KEY IS DEPRESSED DURING THE TEST, THE BAD KEY MNEMONIC AND THE BAD KEY CODE ARE DISPLAYED AS WELL AS A PROMPT TO THE OPERATOR INDICATING THE EXPECTED KEY MNEMONIC AND THE EXPECTED KEY CODE.

9.32 Z KEYBOARD ECHO LOOP

WHEN A KEY IS DEPRESSED, THE CHARACTER WILL BE DISPLAYED. NO MODIFICATION OR DATA TEST IS PERFORMED. THIS TEST CAN BE USED TO DETERMINE IF THERE IS A 'UART' OR SERIAL LINE PROBLEM. WHEN THE VT50/52 IS IN LOCAL MODE (NO UART/SERIAL LINE) THE CHARACTERS SHOULD BE ECHOED CORRECTLY. IF NOT, THE PROBLEM IS IN THE VT50 UNIT. IF CHANGED TO REMOTE MODE AND THE CHARACTERS ARE IN ERROR, THERE IS A UART/SERIAL LINE PROBLEM.

```
616 .TITLE CZVTCFO VT50A,B,H/52 ACCPT
617 .*COPYRIGHT (C) 1979
618 .*DIGITAL EQUIPMENT CORP.
619 .*MAYNARD, MASS. 01754
620 .*
621 .*PROGRAM BY TERMINAL DIAGNOSTICS
622 .*
623 .*THIS PROGRAM WAS ASSEMBLED USING THE PDP-11 MAINDEC SYSMAC
624 .*PACKAGE (MAINDEC-11-DZQAC-C3), JAN 19, 1977.
625 .*
626 .SBTTL BASIC DEFINITIONS
627
628 .*INITIAL ADDRESS OF THE STACK POINTER *** 1100 ***
629 001100 STACK= 1100
630 .EQUIV EMT,ERROR ;;BASIC DEFINITION OF ERROR CALL
631 .EQUIV IOT,SCOPE ;;BASIC DEFINITION OF SCOPE CALL
632
633 .*MISCELLANEOUS DEFINITIONS
634 000011 -I= 11 ;;CODE FOR HORIZONTAL TAB
635 000012 LF= 12 ;;CODE FOR LINE FEED
636 000015 CR= 15 ;;CODE FOR CARRIAGE RETURN
637 000200 CRLF= 200 ;;CODE FOR CARRIAGE RETURN-LINE FEED
638 177776 PS= 177776 ;;PROCESSOR STATUS WORD
639 .EQUIV PS,PSW
640 177774 STKLMT= 177774 ;;STACK LIMIT REGISTER
641 177772 PIRQ= 177772 ;;PROGRAM INTERRUPT REQUEST REGISTER
642 177570 DSWR= 177570 ;;HARDWARE SWITCH REGISTER
643 177570 DDISP= 177570 ;;HARDWARE DISPLAY REGISTER
644
645 .*GENERAL PURPOSE REGISTER DEFINITIONS
646 000000 R0= %0 ;;GENERAL REGISTER
647 000001 R1= %1 ;;GENERAL REGISTER
648 000002 R2= %2 ;;GENERAL REGISTER
649 000003 R3= %3 ;;GENERAL REGISTER
650 000004 R4= %4 ;;GENERAL REGISTER
651 000005 R5= %5 ;;GENERAL REGISTER
652 000006 R6= %6 ;;GENERAL REGISTER
653 000007 R7= %7 ;;GENERAL REGISTER
654 000006 SP= %6 ;;STACK POINTER
655 000007 PC= %7 ;;PROGRAM COUNTER
656
657 .*PRIORITY LEVEL DEFINITIONS
658 000000 PR0= 0 ;;PRIORITY LEVEL 0
659 000040 PR1= 40 ;;PRIORITY LEVEL 1
660 000100 PR2= 100 ;;PRIORITY LEVEL 2
661 000140 PR3= 140 ;;PRIORITY LEVEL 3
662 000200 PR4= 200 ;;PRIORITY LEVEL 4
663 000240 PR5= 240 ;;PRIORITY LEVEL 5
664 000300 PR6= 300 ;;PRIORITY LEVEL 6
665 000340 PR7= 340 ;;PRIORITY LEVEL 7
666
667 .*'SWITCH REGISTER' SWITCH DEFINITIONS
668 100000 SW15= 100000
669 040000 SW14= 40000
670 020000 SW13= 20000
671 010000 SW12= 10000
```

672	004000	SW11=	4000
673	002000	SW10=	2000
674	001000	SW09=	1000
675	000400	SW08=	400
676	000200	SW07=	200
677	000100	SW06=	100
678	000040	SW05=	40
679	000020	SW04=	20
680	000010	SW03=	10
681	000004	SW02=	4
682	000002	SW01=	2
683	000001	SW00=	1
684		.EQUIV	SW09,SW9
685		.EQUIV	SW08,SW8
686		.EQUIV	SW07,SW7
687		.EQUIV	SW06,SW6
688		.EQUIV	SW05,SW5
689		.EQUIV	SW04,SW4
690		.EQUIV	SW03,SW3
691		.EQUIV	SW02,SW2
692		.EQUIV	SW01,SW1
693		.EQUIV	SW00,SW0

:*DATA BIT DEFINITIONS (BIT00 TO BIT15)

695		BIT15=	100000
696	100000	BIT14=	40000
697	040000	BIT13=	20000
698	020000	BIT12=	10000
699	010000	BIT11=	4000
700	004000	BIT10=	2000
701	002000	BIT09=	1000
702	001000	BIT08=	400
703	000400	BIT07=	200
704	000200	BIT06=	100
705	000100	BIT05=	40
706	000040	BIT04=	20
707	000020	BIT03=	10
708	000010	BIT02=	4
709	000004	BIT01=	2
710	000002	BIT00=	1
711	000001	.EQUIV	BIT09,BIT9
712		.EQUIV	BIT08,BIT8
713		.EQUIV	BIT07,BIT7
714		.EQUIV	BIT06,BIT6
715		.EQUIV	BIT05,BIT5
716		.EQUIV	BIT04,BIT4
717		.EQUIV	BIT03,BIT3
718		.EQUIV	BIT02,BIT2
719		.EQUIV	BIT01,BIT1
720		.EQUIV	BIT00,BIT0

:*BASIC 'CPU' TRAP VECTOR ADDRESSES

723		ERRVEC=	4	::TIME OUT AND OTHER ERRORS
724	000004	RESVEC=	10	::RESERVED AND ILLEGAL INSTRUCTIONS
725	000010	TBITVEC=	14	::'T' BIT
726	000014	TRTVEC=	14	::TRACE TRAP
727	000014			

728 000014 BPTVEC= 14 ;;BREAKPOINT TRAP (BPT)
729 000020 IOTVEC= 20 ;;INPUT/OUTPUT TRAP (IOT) **SCOPE**
730 000024 PWRVEC= 24 ;;POWER FAIL
731 000030 EMTVEC= 30 ;;EMULATOR TRAP (EMT) **ERROR**
732 000034 TRAPVEC=34 ;;'TRAP' TRAP
733 000060 TKVEC= 60 ;;TTY KEYBOARD VECTOR
734 000064 TPVEC= 64 ;;TTY PRINTER VECTOR
735 000240 PIRQVEC=240 ;;PROGRAM INTERRUPT REQUEST VECTOR

736
737 .SBTTL OPERATIONAL SWITCH SETTINGS
738 :*
739 :* SWITCH USE
740 :* -----
741 :* 15 HALT ON ERROR
742 :* 14 LOOP ON TEST
743 :* 13 INHIBIT ERROR TYPEOUTS
744 :* 12 INHIBIT SUB-TEST DELAY'S
745 :* 10 ENABLE SAVE COPIER PAPER MODE
746 :* 8 LOOP ON TEST IN SWR<7:0>

747 .SBTTL TRAP CATCHER
748
749 000000 .=0
750 :*ALL UNUSED LOCATIONS FROM 4 - 776 CONTAIN A ".+2,HALT"
751 :*SEQUENCE TO CATCH ILLEGAL TRAPS AND INTERRUPTS
752 :*LOCATION 0 CONTAINS 0 TO CATCH IMPROPERLY LOADED VECTORS

753 000174 .=174
754 000174 000000 DISPREG: .WORD 0 ;;SOFTWARE DISPLAY REGISTER
755 000176 000000 SWREG: .WORD 0 ;;SOFTWARE SWITCH REGISTER

756 .SBTTL STARTING ADDRESS(ES)
757 000200 000137 001334 JMP @#BEGIN ;;JUMP TO STARTING ADDRESS OF PROGRAM
758 000204 000137 001364 JMP RBEGIN ;JUMP TO RESTART ADDRESS
759 000210 000137 001410 JMP BEGIN1 ;JUMP TO KEYBOARD CHARACTER TEST
760 000214 000137 001420 JMP BEGIN2 ;JUMP TO CHAR OCTAL VALUE LOOP
761 000220 000137 001400 JMP BEGIN3 ;JUMP TO ASCII ECHO LOOP
762 000224 000137 001360 JMP MANFU ;JUMP TO W.F. SPECIAL TEST PARAM.

763
764
765
766
767
768
769 001100
770 001100
771 001100 000000
772 001102 000
773 001103 000
774 001104 000000
775 001106 000000
776 001110 000000
777 001112 000000
778 001114 000
779 001115 001
780 001116 000000
781 001120 000000
782 001122 000000
783 001124 000000
784 001126 000000
785 001130 000000
786 001132 000000
787 001134 000
788 001135 000
789 001136 000000
790 001140 17757C
791 001142 177570
792 001144 177560
793 001146 177562
794 001150 177564
795 001152 177566
796 001154 000
797 001155 002
798 001156 012
799 001157 000
800 001160 000000
801
802 001162 000000
803 001164 000000
804 001166 077
805 001167 015
806 001170 000012
807

.SBTTL COMMON TAGS

::*****
:*THIS TABLE CONTAINS VARIOUS COMMON STORAGE LOCATIONS
:*USED IN THE PROGRAM.

.=1100
\$CMTAG: .WORD 0 :: START OF COMMON TAGS
\$PASS: .WORD 0 :: CONTAINS PASS COUNT
\$TSTNM: .BYTE 0 :: CONTAINS THE TEST NUMBER
\$ERFLG: .BYTE 0 :: CONTAINS ERROR FLAG
\$ICNT: .WORD 0 :: CONTAINS SUBTEST ITERATION COUNT
\$LPADR: .WORD 0 :: CONTAINS SCOPE LOOP ADDRESS
\$LPERR: .WORD 0 :: CONTAINS SCOPE RETURN FOR ERRORS
\$ERTTL: .WORD 0 :: CONTAINS TOTAL ERRORS DETECTED
\$ITEMB: .BYTE 0 :: CONTAINS ITEM CONTROL BYTE
\$ERMAX: .BYTE 1 :: CONTAINS MAX. ERRORS PER TEST
\$ERRPC: .WORD 0 :: CONTAINS PC OF LAST ERROR INSTRUCTION
\$GDADR: .WORD 0 :: CONTAINS ADDRESS OF 'GOOD' DATA
\$BDADR: .WORD 0 :: CONTAINS ADDRESS OF 'BAD' DATA
\$GDDAT: .WORD 0 :: CONTAINS 'GOOD' DATA
\$BDDAT: .WORD 0 :: CONTAINS 'BAD' DATA
 .WORD 0 :: RESERVED--NOT TO BE USED
 .WORD 0
\$AUTOB: .BYTE 0 :: AUTOMATIC MODE INDICATOR
\$INTAG: .BYTE 0 :: INTERRUPT MODE INDICATOR
 .WORD 0
SWR: .WORD DSWR :: ADDRESS OF SWITCH REGISTER
DISPLAY: .WORD DDISP :: ADDRESS OF DISPLAY REGISTER
\$TKS: 177560 :: TTY KBD STATUS
\$TKB: 177562 :: TTY KBD BUFFER
\$TPS: 177564 :: TTY PRINTER STATUS REG. ADDRESS
\$TPB: 177566 :: TTY PRINTER BUFFER REG. ADDRESS
\$NULL: .BYTE 0 :: CONTAINS NULL CHARACTER FOR FILLS
\$FILLS: .BYTE 2 :: CONTAINS # OF FILLER CHARACTERS REQUIRED
\$FILLC: .BYTE 12 :: INSERT FILL CHARS. AFTER A 'LINE FEED'
\$TPFLG: .BYTE 0 :: 'TERMINAL AVAILABLE' FLAG (BIT<07>=0=YES)
\$REGAD: .WORD 0 :: CONTAINS THE ADDRESS FROM
 WHICH (\$REGO) WAS OBTAINED
\$REGO: .WORD 0 :: CONTAINS ((\$REGAD)+0)
\$REG1: .WORD 0 :: CONTAINS ((\$REGAD)+2)
\$QUES: .ASCII /?/ :: QUESTION MARK
\$CRLF: .ASCII <15> :: CARRIAGE RETURN
\$LF: .ASCII <12> :: LINE FEED
::~*****


```
808 .SBTTL ERROR POINTER TABLE
809
810 ;*THIS TABLE CONTAINS THE INFORMATION FOR EACH ERROR THAT CAN OCCUR.
811 ;*THE INFORMATION IS OBTAINED BY USING THE INDEX NUMBER FOUND IN
812 ;*LOCATION $ITEMB. THIS NUMBER INDICATES WHICH ITEM IN THE TABLE IS PERTINENT.
813 ;*NOTE1: IF $ITEMB IS 0 THE ONLY PERTINENT DATA IS ($ERRPC).
814 ;*NOTE2: EACH ITEM IN THE TABLE CONTAINS 4 POINTERS EXPLAINED AS FOLLOWS:
815
816 ;* EM ;:POINTS TO THE ERROR MESSAGE
817 ;* DH ;:POINTS TO THE DATA HEADER
818 ;* DT ;:POINTS TO THE DATA
819 ;* DF ;:POINTS TO THE DATA FORMAT
820
821
822 001172 $ERRTB:
823
824
825 ;ITEM 1
826 001172 021102 EM1 ;:ERROR FLAG ON HOST TRANSMIT STATUS
827 001174 021325 DH1 ;:ERRPC VTNOW TSTNUM
828 001176 021472 DT1 ;:SERRPC VTNOW TSTNUM
829 001200 000000 0
830
831 ;ITEM 2
832 001202 021147 EM2 ;:NO HOST INPUT FLAG RECEIVED
833 001204 021325 DH1 ;:ERRPC VTNOW TSTNUM
834 001206 021472 DT1 ;:SERRPC VTNOW TSTNUM
835 001210 000000 0
836
837 ;ITEM 3
838 001212 021176 EM3 ;:INCORRECT I.D. RESPONSE
839 001214 021354 DH3 ;:ERRPC VTNOW 1ST WD 2ND WD 3RD WD
840 001216 021502 DT3 ;:SERRPC VTNOW SAVE4 SAVE2 SAVE3
841 001220 000000 0
842
843 ;ITEM 4
844 001222 021222 EM4 ;:INCORRECT OR UNEXPECTED INPUT CHARACTER
845 001224 021423 DH4 ;:ERRPC VTNOW TSTNUM EXPT RCVD
846 001226 021516 DT4 ;:SERRPC VTNOW TSTNUM $GDDAT $BDDAT
847 001230 000000 0
848
849 ;ITEM 5
850 001232 021265 EM5 ;:INVALID BUSS ADDRESS, TRY AGAIN
851 001234 000000 0
852 001236 000000 0
853 001240 000000 0
854 001242 177560 FIRST: 177560 ;:FIRST DEVICE ADDRESS OF SEQUENTIAL DL11-A/B TYPE DEVICE
855 ;:DEFAULT TO THE CONSOLE ADDRESS
856 001244 000000 LAST: 0 ;:LAST DEVICE ADDRESS OF DL11-A/B TYPE
857 001246 177560 VTNOW: 177560 ;:CURRENT DEVICE BUSS ADDRESS
858 001250 100011 PTCT: 100011 ;:COPIER PAPER SAVE COUNT <LOW BYTE>
859 001252 000000 TSTNUM: 0 ;:ERROR PATTERN
860
861 001254 000300 TIMEO: 300 ;:CHARACTER FLAG TIMEOUT CONSTANT
862 001256 000005 SUBTST: 5 ;:SUBTEST DELAY CONSTANT
863 001260 000000 VT5XX: 0 ;:I.D. AND CHARACTERISTICS
```

```
864 001262 000053 LASTLN: 53 ;OR 67 ;LAST VALID LINE # +40
865 001264 001700 TOTALC: 960. ;OR 1920. ;TOTAL CHARACTER COUNT
866 001266 000014 VHO: 12. ;24. ;VERTICAL LINE COUNT
867 001270 000006 VH1: 6. ;12. ;1/2 VERTICAL LINE COUNT
868 001272 000003 VH2: 3. ;6. ;1/4 VERTICAL LINE COUNT
869 001274 000000 PRTCNT: 0
870 001276 177560 VTIS: 177560 ;DEVICE ADDRESSES
871 001300 177562 V*IB: 177562 ;IN DATA
872 001302 177564 VTOS: 177564 ;OUT STAT
873 001304 177566 VTOB: 177566 ;OUT DATA
874 001306 000000 STCHAR: 0 ;TEMP REG'S
875 001310 000140 LASTCH: 140 ;OR 200 ;FIRST NON-VALID CHARACTER
876 001312 000000 TEMP: 0 ;TEMP REG'S
877 001314 000000 TEMPO: 0
878 001316 000204 PNTWID: 132. ;COLUMN COUNT FOR LINE PRINTER.
879 001320 000120 WIDTH: 80. ;COLUMN WIDTH
880 001322 000000 SAVE1: 0 ;TEMP REG'S
881 001324 000000 SAVE2: 0
882 001326 000000 SAVE3: 0
883 001330 000000 SAVE4: 0
884 001332 000000 WFTST: 0 ;NON-ZERO IF SA = 224
885
886
887 001334 012737 002466 002402 BEGIN: MOV #TST2,WHERE ;STARTING ACCEPTANCE TEST ADDRESS
888 001342 005037 001330 CLR SAVE4
889 001346 005037 001332 CLR WFTST
890 001352 005037 001274 CLR PRTCNT
891 001356 000426 BR GINA
892 001360 005237 001332 MANFU: INC WFTST ;SET W.F. PARAM.
893 001364 005037 001274 RBEGIN: CLR PRTCNT ;RESTART ADDRESS
894 001370 012737 002466 002402 MOV #TST2,WHERE
895 001376 000413 BR GIN
896 001400 012737 010110 002402 BEGIN3: MOV #KRBECH,WHERE ;START AT ECHO LOOP
897 001406 000407 BR GIN
898 001410 012737 007404 002402 BEGIN1: MOV #KRSTST,WHERE ;STARTING CHARACTER TEST ADDRESS
899 001416 000403 BR GIN
900 001420 012737 007110 002402 BEGIN2: MOV #KRBECC,WHERE ;STARTING CHARACTER LOOP ADDRESS
901 001426 012737 000001 001330 GIN: MOV #1,SAVE4
902 001434 000005 GINA: RESET
903
904 .SBTTL INITIALIZE THE COMMON TAGS
905 001436 012706 001100 ;:CLEAR THE COMMON TAGS ($CMTAG) AREA
906 001442 005026 MOV #SCMTAG,R6 ;:FIRST LOCATION TO BE CLEARED
907 001444 022706 001140 CLR (R6)+ ;:CLEAR MEMORY LOCATION
908 001450 001374 CMP #SWR,R6 ;:DONE?
909 001452 012706 001100 BNE -6 ;:LOOP BACK IF NO
910 MOV #STACK,SP ;:SETUP THE STACK POINTER
911 ;:INITIALIZE A FEW VECTORS
912 MOV #SCOPE,@IOTVEC ;:IOT VECTOR FOR SCOPE ROUTINE
913 MOV #340,@IOTVEC+2 ;:LEVEL 7
914 MOV #ERROR,@EMTVEC ;:EMT VECTOR FOR ERROR ROUTINE
915 MOV #340,@EMTVEC+2 ;:LEVEL 7
916 MOV #STRAP,@TRAPVEC ;:TRAP VECTOR FOR TRAP CALLS
917 MOV #340,@TRAPVEC+2 ;:LEVEL 7
918 MOV #SPWRDN,@PWRVEC ;:POWER FAILURE VECTOR
919 MOV #340,@PWRVEC+2 ;:LEVEL 7
920 MOV $FNDCT,$EOPCT ;:SETUP END-OF-PROGRAM COUNTER
```

```
920 001544 012737 001544 001106      MOV      #.,$LPADR      ;;INITIALIZE THE LOOP ADDRESS FOR SCOPE
921                                     ;;SIZE FOR A HARDWARE SWITCH REGISTER. IF NOT FOUND OR IT IS
922                                     ;;EQUAL TO A "-1", SETUP FOR A SOFTWARE SWITCH REGISTER.
923 001552 013746 000004                MOV      @#ERRVEC,-(SP)  ;;SAVE ERROR VECTOR
924 001556 012737 001612 000004        MOV      #64$,@#ERRVEC  ;;SET UP ERROR VECTOR
925 001564 012737 177570 001140        MOV      #DSWR,SWR     ;;SETUP FOR A HARDWARE SWICH REGISTER
926 001572 012737 177570 001142        MOV      #DDISP,DISPLAY ;;AND A HARDWARE DISPLAY REGISTER
927 001600 022777 177777 177332        CMP      #-1,@SWR      ;;TRY TO REFERENCE HARDWARE SWR
928 001606 001012                BNE      66$           ;;BRANCH IF NO TIMEOUT TRAP OCCURRED
929                                     ;;AND THE HARDWARE SWR IS NOT = -1
930 001610 000403                BR       65$           ;;BRANCH IF NO TIMEOUT
931 001612 012716 001620                64$:  MOV      #65$, (SP)  ;;SET UP FOR TRAP RETURN
932 001616 000002                RTI
933 001620 012737 000176 001140        65$:  MOV      #SWREG,SWR    ;;POINT TO SOFTWARE SWR
934 001626 012737 000174 001142        MOV      #DISPREG,DISPLAY
935 001634 012637 000004                66$:  MOV      (SP)+,@#ERRVEC ;;RESTORE ERROR VECTOR
936
937 001640 005037 010676                CLR      IGNORE
938 001644 005037 010660                CLR      LOOP
939 001650 012737 024700 000020        MOV      #MSCOPE,@#IOTVEC
940 001656 005737 001330                TST      SAVE4         ;TEST FLAG
941 001662 001051                BNE      SBEGIN       ;BR IF NON-ZERO
942 001664 104401                TYPE
943 001666 013704                TITLE
944 001670 105777 177244                TSTB    @SWR
945 001674 100044                BPL     SBEGIN        ;BR IF CLEARED
946 001676 012737 001776 000004        MOV      #12$,4       ;SET UP SLAVE TIMEOUT
947 001704 012737 000340 000006        MOV      #340,6       ;LOCK OUT ANY INTERRUPTS
948 001712 104401                11$:  TYPE
949 001714 020713                WHAT0
950 001716 104410                RDOCT
951 001720 012637 001242                MOV      (SP)+,FIRST  ;SAVE THE ADDRESS
952 001724 022737 160000 001242        CMP      #160000,FIRST
953 001732 101367                BHI     11$           ;BR IF INVALID
954 001734 005777 177302                TST     @FIRST       ;TEST IF VALID
955 001740 005037 001244                CLR     LAST
956 001744 104401                TYPE
957 001746 020756                WHAT1
958 001750 104410                RDOCT
959 001752 012637 001244                MOV      (SP)+,LAST  ;SAVE LAST ADDRESS
960 001756 005777 177262                TST     @LAST        ;TEST IF VALID
961 001762 012737 000006 000004        MOV      #6,@#4
962 001770 005037 000006                CLR     @#6
963 001774 000404                BR     SBEGIN
964 001776 022626                12$:  CMP     (SP)+,(SP)+  ;ADJUST STACK FROM TIMEOUT
965 002000 104401                TYPE
966 002002 016676                INVLID
967 002004 000742                BR     11$           ;INVALID ADDRESS MESSAGE
968 002006 013737 001242 001246        SBEGIN: MOV     FIRST,VTNOW ;LET OPERATOR HAVE ANO TRY
969                                     ;LOAD INITIAL DEVICE ADDRESS
970 002014 012700 001276                RSTRT: MOV     #VTIS,R0 ;LOAD POINTER
971 002020 013701 001246                MOV     VTNOW,R1      ;LOAD INPUT STAT
972 002024 010120                MOV     R1,(R0)+
973 002026 005721                TST    (R1)+
974 002030 010120                MOV     R1,(R0)+
975 002032 005721                TST    (R1)+
```

CZVTCFO VT50A.B.H/52 ACCT
CZVTCF.P11 11-APR-79 15:31

MACY11 30A(1052) 11-APR-79 15:34
INITIALIZE THE COMMON TAGS

SEQ 0021

976 002034 010120
977 002036 005721
978 002040 010110

MOV R1,(R0)+
TST (R1)+
MOV R1,(R0)

```
979
980
981 :*****
982 :*TEST 1 A TERMINAL IDENTIFICATION TEST
983 :*****
984 002042 000004 TST1: SCOPE
985 :IDENTIFY TERMINAL TYPE (VT50,VT50H,VT52) INVOKED BY ESC Z (033 132).
986 :ESCAPE SEQUENCES TRANSMITTED BY THE VARIOUS MODELS WHEN THEY RECEIVE THIS COMMAND:
987 : VT50 ESC/A 033 057 101
988 : VT50H ESC/H 033 057 110
989 : VT52 ESC/K 033 057 113
990 : VT55 ESC/C 033 057 103
991 JSR R5,AMSG ;DISPLAY HEADER
992 M914
993 JSR R5,AMSG ;SEND REQUEST FOR IDENTIFICATION
994 RFI ;INVOKES ESC Z ESCAPE SEQUENCE TO REQUEST TERMINAL TYPE
995 JSR PC,GETCHR ;GET A CHARACTER FOUND IN R0 AFTER EXIT
996 BR 2$ ;BR BACK IF NO INPUT
997 MOV R0,SAVE4 ;SAVE RESPONSE
998 JSR PC,GETCHR ;GET A CHAR. (2ND CHAR. OF RESPONSE)
999 BR 2$ ;BR IF NO INPUT
1000 MOV R0,SAVE2
1001 JSR PC,GETCHR ;GET A CHAR. (3RD CHAR. OF RESPONSE)
1002 BR 2$ ;BR IF NO INPUT
1003 MOV R0,SAVE3
1004 BIC #177600,SAVE4 ;MASK BIT 7
1005 BIC #177600,SAVE2
1006 BIC #177600,SAVE3
1007 TST WFTEST
1008 BEQ 10$
1009 JSR PC,ADelay ;EXTRA DELAY
1010 10$: CMPB #33,SAVE4 ;TEST FIRST CHAR.
1011 BNE 1$ ;BR TO ERROR
1012 122737 000033 001330 10$: CMPB #'/,SAVE2 ;TEST SECOND CHAR.
1013 BNE 1$ ;BR TO ERROR
1014
1015 ;NOW DETERMINE WHICH VT5XX AND ITS CHARACTERISTICS
1016
1017 002172 005000 CLR R0 ;CLEAR INITIAL POINTER
1018 002174 126037 002404 001326 3$: CMPB TYPEPT(R0),SAVE3 ;TEST I.D. TO KNOWN VALUE
1019 BEQ 4$ ;BR IF CORRECT
1020 002202 001406 TST (R0)+ ;BUMP THE INDEX
1021 002206 105760 002404 TSTB TYPEPT(R0) ;CHECK IF MORE VALID I.D.'S
1022 002212 001370 BNE 3$ ;BR IF MORE
1023 002214 104003 1$: ERROR 3 ;INCORRECT I.D. CODE
1024 002216 005000 11$: CLR R0 ;DEFAULT TO VT50A MODE
1025
1026 ;HAVE NOW FOUND THE I.D. - REPORT TO CONSOLE
1027
1028 002220 016037 002404 001260 4$: MOV TYPEPT(R0),VT5XX ;SAVE I.D. AND CHARACTERISTICS
1029 002226 016037 002436 002242 MOV MSGTYP(R0),5$ ;SAVE ASCII MESSAGE POINTER
1030 002234 001403 BEQ 13$ ;BR IF ZERO MESSAGE POINTER
1031 002236 004537 011454 JSR R5,AMSG ;TELL THE UUT
1032 002242 017520 5$: VT50A ;POINTER TO VT5XX MESSAGE
1033
1034 002244 012737 001700 001264 13$: MOV #960.,TOTALC ;LOAD TOTAL CHARACTER COUNT
```



```

1035 002252 012737 000014 001266 MOV #12.,VH0 ;LOAD MAX VERTICAL LINE COUNT
1036 002260 012737 000053 001262 MOV #53, LASTLN ;LOAD LAST LINE VALUE +40 FOR DCA TESTING
1037 002266 005737 001260 TST VT5XX ;TEST IF 24 LINES AVAIL
1038 002272 100007 BPL 6$ ;BR IF NOT
1039 002274 006337 001264 ASL TOTALC ;ADJUST CHARACTER COUNT
1040 002300 006337 001266 ASL VH0 ;ADJUST LINE COUNT
1041 002304 062737 000014 001262 ADD #12., LASTLN ;ADJUST VALID LINE # +40
1042
1043 002312 013737 001266 001270 6$: MOV VH0, VH1 ;LOAD OTHER LINE COUNTS
1044 002320 006237 001270 ASR VH1
1045 002324 013737 001270 001272 MOV VH1, VH2
1046 002332 006237 001272 ASR VH2
1047 002336 012737 000140 001310 MOV #140, LASTCH ;LOAD FIRST NON-VALID CHARACTER
1048 002344 032737 004000 001260 BIT #BIT11, VT5XX ;TEST IF UPPER-LOWER CASE TERM.
1049 002352 001403 BEQ 7$ ;BR IF NOT
1050 002354 062737 000037 001310 ADD #37, LASTCH ;UPDATE TO ALLOW UP-LW CASE CHARACTER SET
1051 002362 7$:
1052 002362 000403 BR 12$ ;:BR AND START TESTING
1053
1054 002364 104002 2$: ERROR 2 ;NO RESPONSE FROM UUT AFTER ASKING FOR IDENTIFY
1055 002366 000713 BR 11$
1056 002370 000240 NOP
1057 002372 004737 011274 12$: JSR PC, DELAY
1058 002376 000177 000000 JMP @WHERE
1059 002402 002466 WHERE: TST2
1060
1061 ;I.D. VALUES AND CHARACTERISTICS
1062 : BIT15 = 1 24 LINES
1063 : BIT14 = 1 COPIER CONNECTED
1064 : BIT13 = 1 DIRECT CURSOR ADDRESSING (ESC Y) + 'ESC-B' + 'ESC-D'
1065 : BIT12 = 1 KEYPAD
1066 : BIT11 = 1 UPPER AND LOWER CASE CHARACTERS
1067 : BIT10 = 1 PRINTER CONNECTED
1068 : BIT09 = 1 VT52X MODEL
1069 : VT52 24-LINE, UPPER AND LOWER CASE
1070 : VT50H 12-LINE, UPPER CASE WITH KEYPAD
1071 : VT50 12-LINE, UPPER CASE WITHOUT KEYPAD
1072 : VT55 SAME AS VT50 EXCEPT FOR GRAPHIC CAPABILITIES
1073 : VT52 I.D.:LOW BYTE CONTAINS THE I.D. FOR EACH KNOWN VT5??
1074
1075 002404 000101 TYPEPT: .WORD 000101 ;I.D. = 101 ;VT50A
1076 002406 040102 .WORD 040102 ;I.D. = 102 ;VT50B COPIER
1077 002410 140103 .WORD 140103 ;I.D. = 103 ;VT55 24. LINES, COPIER(VT50 BASED)
1078 002412 070110 .WORD 070110 ;I.D. = 110 ;VT50H COPIER DCA VT50H KEYPAD
1079 002414 135113 .WORD 135113 ;I.D. = 113 ;VT52
1080 002416 175114 .WORD 175114 ;I.D. = 114 ;VT52 WITH COPIER
1081 002420 137115 .WORD 137115 ;I.D. = 115 ;VT52 WITH PRINTER.
1082 002422 175105 .WORD 175105 ;I.D. = 105 ;VT55,24LINES,WITH COPIER(VT52 BASED)
1083 002424 000000 0
1084 002426 000000 0
1085 002430 000000 0
1086 002432 000000 0
1087 002434 000000 0
1088
1089 ;ASCII MESSAGE POINTERS
1090

```

1091 002436 017520
1092 002440 017572
1093 002442 017641
1094 002444 017723
1095 002446 020001
1096 002450 020065
1097 002452 020146
1098 002454 020227
1099 002456 000000
1100 002460 000000
1101 002462 000000
1102 002464 000000

MSGTYP: VT50A ;VT50A NO COPIER
VT50B ;VT50B COPIER
VT55 ;VT55 COPIER
VT50H ;VT50H COPIER
VT52K ;VT52
VT52L ;VT52 WITH COPIER
VT52M ;VT52 WITH PRINTER
VT55E
0
0
0
0

1103
1104
1105
1106 002466 000004
1107
1108 002470 004537 011454
1109 002474 013745
1110
1111 002476 004737 013550
1112
1113 002502 004737 011274
1114
1115

*TEST 2 B FULL SCREEN OF A CHARACTER

TST2: SCOPE
JSR R5,AMSG
M91
JSR PC,FILLWC ;FILL SCREEN WITH A 'E'S
JSR PC,DELAY

1116
1117
1118 002506 000004
1119 002510 004537 011454
1120 002514 014013
1121 002516 013737 001270 001312
1122
1123 002524 004537 011166
1124 002530 000077
1125 002532 000100
1126
1127 002534 004537 011172
1128 002540 000125
1129 002542 000052
1130

*TEST 3 C DATA TRANSFER PATH TEST

TST3: SCOPE
JSR R5,AMSG ;DISPLAY HEADING
M92
MOV VH1,TEMP ;SET-UP A COUNTER
JSR R5,DTPSR ;SET-UP BUFFER
77 ;OCTAL '?'
100 ;OCTAL '@'
JSR R5,DTPSRB ;SET-UP BUFFER
125 ;OCTAL 'U'
52 ;OCTAL '*'

1131 002544 004737 010246
1132 002550 005337 001312
1133 002554 001373
1134
1135 002556 004737 011274
1136

1\$: JSR PC,XPRNT ;DISPLAY THIS LINE
DEC TEMP ;COMPLETED FULL COUNT?
BNE 1\$;BRANCH IF NOT COMPLETED
JSR PC,DELAY ;TEST DELAY SWITCH

1137
1138
1139 002562 000004
1140 002564 004537 011454
1141 002570 014041
1142 002572 012737 000040 001306
1143
1144 002600 013737 001266 001314
1145 002606 013701 001306
1146 002612 004737 010144

*TEST 4 D SINGLE CHARACTER ACROSS ALL COLS. <ALL CHARACTERS>

TST4: SCOPE
JSR R5,AMSG ;DISPLAY HEADING
M93
MOV #40,STCHAR ;SET-UP STARTING CHARACTER
MOV VH0,TEMPO ;LOAD COUNT
1\$: MOV STCHAR,R1 ;LOAD R1= TO CHARACTER
JSR PC,FILBUF ;LOAD A BUFFER WITH THAT CHARACTER

```

CZVTCFO VT50A,B,H/52 ACCPI MACY11 30A(1052) 11-APR-79 15:34 M 2 PAGE 26
CZVTCF.P11 11-APR-79 15:31 T4 D SINGLE CHARACTER ACROSS ALL COLS. <ALL CHARACTERS> SEQ 0025

1147
1148 002616 004737 010246 JSR PC,XPRNT ;DISPLAY A FULL LINE FROM THE BUFFER
1149
1150 002622 005337 001314 DEC TEMPO ;DONE ?
1151 002626 001005 BNE 2$ ;FINISHED
1152 002630 004737 011274 JSR PC,DELAY
1153 002634 013737 001266 001314 MOV VHO,TEMPO
1154 002642 005237 001306 2$: INC STCHAR ;UPDATE THE CHARACTER
1155 002646 023737 001310 001306 CMP LASTCH,STCHAR ;TEST FOR FINAL CHARACTER
1156 002654 001354 BNE 1$ ;BRANCH IF NOT COMPLETED
1157
1158 002656 004737 011274 JSR PC,DELAY ;TEST DELAY SWITCH
1159
1160
1161 :*****
1162 :*TEST 5 E ROTATING CHARACTERS ACROSS ALL COLS. <ALL CHARACTERS>
1163 :*****
1164 002662 000004 TST5: SCOPE
1165 002664 004537 011454 JSR R5,AMSG ;DISPLAY HEADING
1166 002670 014101 M94
1167 002672 012737 000040 001306 MOV #40,STCHAR ;SET-UP STARTING CHARACTER
1168 002700 013737 001266 001314 MOV VHO,TEMPO ;LOAD TEMP
1169 002706 013701 001306 1$: MOV STCHAR,R1 ;LOAD R1=TO CHARACTER
1170 002712 004537 010200 JSR R5,LIC ;LOAD A BUFFER STARTING WITH
1171 002716 001320 WIDTH ; THAT CHARACTER AND WIDTH <BYTE>
1172
1173 002720 004737 010246 JSR PC,XPRNT ;DISPLAY A FULL LINE FROM THE BUFFER
1174
1175 002724 005337 001314 DEC TEMPO ;DONE ?
1176 002730 001005 BNE 2$ ;BR IF YES
1177 002732 004737 011274 JSR PC,DELAY
1178 002736 013737 001266 001314 MOV VHO,TEMPO
1179 002744 005237 001306 2$: INC STCHAR ;UPDATE THE STARTING CHARACTER
1180 002750 023737 001310 001306 CMP LASTCH,STCHAR ;TEST FOR FINAL CHARACTER
1181 002756 001353 BNE 1$ ;BRANCH IF NOT COMPLETED
1182
1183 002760 004737 011274 JSR PC,DELAY ;TEST DELAY SWITCH
1184
1185 :*****
1186 :*TEST 6 F CURSOR MOTION TEST
1187 :*****
1188 002764 000004 TST6: SCOPE
1189 002766 004537 011454 JSR R5,AMSG ;DISPLAY HEADING
1190 002772 014131 M96
1191 ;ROUTINE TO LOAD REFERENCE LINES FOR CURSOR MOTION TEST
1192
1193 002774 012700 026346 LBMT: MOV #BUFFER,R0 ;LOAD POINTER
1194 003000 012720 000065 MOV #65,(R0)+ ;LOAD #5
1195 003004 013701 001270 MOV VH1,R1 ;LOAD R1
1196 003010 005301 DEC R1
1197 003012 004737 003110 JSR PC,MOVDN1 ;MOVE CURSOR DOWN
1198 003016 004737 003126 JSR PC,MOVRIG ;MOVE RIGHT
1199 003022 112720 000062 MOVB #62,(R0)+ ;LOAD #2
1200 003026 004737 003126 JSR PC,MOVRIG ;MOVE RIGHT
1201 003032 004737 003126 JSR PC,MOVRIG ;MOVE RIGHT
1202 003036 112720 000040 MOVB #40,(R0)+

```

```
1203 003042 112720 000061      MOVB      #61,(R0)+      :LOAD #1
1204 003046 004737 003104      JSR      PC,MOVDWN      :MOVE DOWN
1205 003052 004737 003126      JSR      PC,MOVRIG      :MOVE RIGHT
1206 003056 112720 000063      MOVB      #63,(R0)+      :LOAD #3
1207 003062 004737 003126      JSR      PC,MOVRIG      :MOVE RIGHT
1208 003066 004737 003126      JSR      PC,MOVRIG      :MOVE RIGHT
1209 003072 112720 000064      MOVB      #64,(R0)+      :LOAD #4
1210 003076 112710 000377      MOVB      #377,(R0)      :TERM
1211 003102 000420      BR      LBMT1           :;BR TO NEXT PART
1212
1213 003104 013701 001270      MOVDWN:  MOV      VH1,R1
1214 003110 112720 000015      MOVDN1:  MOVB     #15,(R0)+      :LOAD CR
1215 003114 112720 000012      MOVB     #12,(R0)+      :LOAD LF
1216 003120 005301      DEC      R1
1217 003122 001372      BNE     MOVDN1          :LOOP UNTIL DONE
1218 003124 000207      RTS     PC              :ESIT
1219
1220 003126 012701 000024      MOVRIG:  MOV      #20.,R1      :LOAD R1
1221 003132 112720 000040      1$:     MOVB     #40,(R0)+      :LOAD SPACES
1222 003136 005301      DEC      R1
1223 003140 100374      BPL     1$             :LOOP UNTIL DONE
1224 003142 000207      RTS     PC              :EXIT
1225
1226 003144 004737 010246      LBMT1:   JSR      PC,XPRNT      :DISPLAY THIS LINE
1227 003150 004737 011274      JSR      PC,DELAY       :TEST DELAY SWITCH
1228
1229      :CURSOR MOTION SUBROUTINE
1230      :IF VT50H TYPE - USE 'ESC-D' FOR CURSOR LEFT AND USE 'ESC-B' FOR CURSOR DOWN
1231 003154 013701 001270      LCM:     MOV      VH1,R1      :LOAD COUNT
1232 003160 012700 026346      MOV      #BUFFER,R0      :LOAD BUFFER POINTER
1233 003164 112720 000033      1$:     MOVB     #33,(R0)+      :LOAD 'ESC'
1234 003170 112720 000101      MOVB     #101,(R0)+      :LOAD 'A' CURSOR UP
1235 003174 005301      DEC      R1
1236 003176 001372      BNE     1$             :LOOP UNTIL DONE
1237 003200 112720 000130      MOVB     #130,(R0)+      :LOAD 'X'
1238 003204 012701 000054      MOV      #44.,R1        :LOAD COUNT
1239 003210 032737 020000 001260      BIT      #BIT13,VT5XX    :TEST IF VT50H TYPE
1240 003216 001407      BEQ     20$           :BR IF NOT
1241 003220 112720 000033      2$:     MOVB     #33,(R0)+      :LOAD 'ESC'
1242 003224 112720 000104      MOVB     #104,(R0)+      :LOAD 'CURSOR LEFT'
1243 003230 005301      DEC      R1
1244 003232 100372      BPL     2$             :LOOP UNTIL DONE
1245 003234 000404      BR      21$
1246 003236 112720 000010      20$:    MOVB     #10,(R0)+      :LOAD 'BACKSPACE'
1247 003242 005301      DEC      R1            :DONE ALL ?
1248 003244 100374      BPL     20$           :BR IF NOT
1249 003246 112720 000130      21$:    MOVB     #130,(R0)+      :LOAD 'X'
1250 003252 112720 000010      MCVB     #10,(R0)+      :LOAD BACKSPACE
1251 003256 013701 001270      MOV      VH1,R1        :LOAD COUNT
1252 003262 032737 020000 001260      BIT      #BIT13,VT5XX    :TEST IF VT50H TYPE
1253 003270 001407      BEQ     30$           :BR IF NOT
1254 003272 112720 000033      3$:     MOVB     #33,(R0)+      :LOAD 'ESC' CURSOR DOWN
1255 003276 112720 000102      MOVB     #102,(R0)+      :
1256 003302 005301      DEC      R1
1257 003304 001372      BNE     3$
1258 003306 000404      BR      31$           :LOOP UNTIL DONE
```

```
1259 003310 112720 000012 30$: MOVB #12,(R0)+ ;LOAD CURSOR DOWN (LF)
1260 003314 005301 DEC R1 ;DONE ?
1261 003316 001374 BNE 30$ ;BR IF NOT
1262 003320 112720 000130 31$: MOVB #130,(R0)+ ;LOAD 'X'
1263 003324 112720 000010 MOVB #10,(R0)+ ;LOAD BACKSPACE
1264 003330 012701 000052 MOV #42,R1 ;LOAD COUNT
1265 003334 112720 000033 4$: MOVB #33,(R0)+ ;LOAD 'ESC'
1266 003340 112720 000103 MOVB #103,(R0)+ ;LOAD 'C' CURSOR RIGHT
1267 003344 005301 DEC R1
1268 003346 100372 BPL 4$ ;LOOP UNTIL DONE
1269 003350 112720 000130 MOVB #130,(R0)+ ;LOAD 'X'
1270 003354 112720 000033 MOVB #33,(R0)+ ;LOAD 'ESC'
1271 003360 112720 000110 MOVB #110,(R0)+ ;LOAD 'H' CURSOR HOME
1272 003364 112720 000130 MOVB #130,(R0)+
1273 003370 112720 000377 MOVB #377,(R0)+
1274 003374 004737 010246 JSR PC,XPRNT ;DISPLAY THIS LINE
1275 003400 004737 011274 JSR PC,DELAY ;DELAY
1276 003404 004537 011454 JSR R5,AMSG ;
1277 003410 017223 CRLFB
1278 003412 005737 001260 TST VT5XX ;TEST IF 24 LINES
1279 003416 100003 BPL TST7 ;:BR IF 12 LINES
1280 003420 004537 011454 JSR R5,AMSG ;SCROLL MORE LINES
1281 003424 017223 CRLFB
1282
1283
1284 :*****
1285 :*TEST 7 G TAB, BACKSPACE AND BELL TEST
1286 :*****
1286 003426 000004 TST7: SCOPE
1287 003430 004537 011454 JSR R5,AMSG ;DISPLAY HEADING
1288 003434 014163 M97
1289
1290 003436 012700 026346 LRL: MOV #BUFFER,R0 ;LOAD BUFFER POINTER
1291 003442 112720 000007 MOVB #7,(R0)+ ;LOAD 'BELL'
1292 003446 012701 000011 MOV #9,R1 ;LOAD LINE COUNT
1293 003452 012702 000006 1$: MOV #6,R2 ;LOAD COLUMN COUNT
1294 003456 112720 000111 MOVB #11,(R0)+ ;LOAD COLUMN MARK
1295 003462 112720 000040 2$: MOVB #40,(R0)+ ;LOAD SPACE
1296 003466 005302 DEC R2 ;
1297 003470 100374 BPL 2$ ;BR UNTIL DONE
1298 003472 005301 DEC R1 ;
1299 003474 100366 BPL 1$ ;BR UNTIL FINISHED ALL TAB STOPS
1300 003476 112720 000015 MOVB #15,(R0)+ ;LOAD CR
1301 003502 112720 000012 MOVB #12,(R0)+ ;LOAD LF
1302 003506 112720 000377 MOVB #377,(R0)+ ;LOAD TERM
1303
1304 003512 004737 010246 JSR PC,XPRNT
1305
1306 003516 004537 003706 JSR R5,LTAB ;LOAD TAB LINE #1
1307 003522 000000 0
1308 003524 004737 010246 JSR PC,XPRNT ;DISPLAY THIS LINE
1309
1310 003530 004537 003706 JSR R5,LTAB ;LOAD TAB LINE #2
1311 003534 000001 1
1312 003536 004737 010246 JSR PC,XPRNT ;DISPLAY THIS LINE
1313
1314 003542 004537 003706 JSR R5,LTAB ;LOAD TAB LINE #3
```

```
1315 003546 000002          2
1316 003550 004737 010246   JSR    PC,XPRNT      ;DISPLAY THIS LINE
1317
1318 003554 004537 003706   JSR    R5,LTAB      ;LOAD TAB LINE #4
1319 003560 000003          3
1320 003562 004737 010246   JSR    PC,XPRNT      ;DISPLAY THIS LINE
1321
1322 003566 004537 003706   JSR    R5,LTAB      ;LOAD TAB LINE #5
1323 003572 000004          4
1324 003574 004737 010246   JSR    PC,XPRNT      ;DISPLAY THIS LINE
1325
1326 003600 004537 003706   JSR    R5,LTAB      ;LOAD TAB LINE #6
1327 003604 000005          5
1328 003606 004737 010246   JSR    PC,XPRNT      ;DISPLAY THIS LINE
1329
1330 003612 004537 003706   JSR    R5,LTAB      ;LOAD TAB LINE #7
1331 003616 000006          6
1332 003620 004737 010246   JSR    PC,XPRNT      ;DISPLAY THIS LINE
1333 ;NOW EXECUTE THE BACKSPACE SECTION
1334
1335 003624 013702 001320   MOV    WIDTH,R2     ;LOAD WIDTH COUNT
1336 003630 005302          DEC    R2            ;ADJUST WIDTH
1337 003632 005302          DEC    R2            ; BY 2
1338 003634 012701 000040   MOV    #40,R1       ;LOAD 'SPACE' INTO THE LINE
1339 003640 004737 010150   JSR    PC,FILBFB    ;LOAD LINE
1340 003644 013701 001320   MOV    WIDTH,R1     ;LOAD # OF CHARACTER POSITIONS
1341 003650 112720 000130 3$:  MOVB  #'X,(R0)+     ;LOAD ASCII 'X'
1342 003654 112720 000010   MOVB  #10,(R0)+    ;LOAD BACKSPACE CODE
1343 003660 112720 000010   MOVB  #10,(R0)+
1344 003664 005301          DEC    R1            ;DONE ALL POSITIONS ?
1345 003666 001370          BNE   3$           ;BR IF NOT
1346 003670 112720 000377   MOVB  #377,(R0)+   ;LOAD TERM.
1347 003674 004737 010246   JSR    PC,XPRNT     ;EXECUTE ASCII CODE
1348 003700 004737 011274   JSR    PC,DELAY     ;TEST DELAY SWITCH
1349 003704 000434          BR    TST10        ;:BR TO NEXT TEST
1350
1351 ;SUBROUTINE TO LOAD THE TAB TEST INTO THE BUFFER
1352
1353 003706 012537 001322  LTAB: MOV    (R5)+,SAVE1 ;LOAD # OF CHARACTERS
1354 003712 012702 026346   MOV    #BUFFER,R2  ;LOAD BUFFER POINTER
1355 003716 012701 000011   MOV    #9,R1       ;LOAD WIDTH COUNTER
1356 003722 112722 000007   MOVB  #7,(R2)+    ;LOAD BELL AT START OF LINE
1357 003726 112722 000111 3$:  MOVB  #11,(R2)+   ;LOAD 'I'
1358 003732 013700 001322   MOV    SAVE1,R0    ;GET THE NO. OF THE CHAR
1359 003736 001404          BEQ   1$           ;BR IF 0
1360 003740 112722 000101 2$:  MOVB  #101,(R2)+  ;LOAD THE 'A' CHAR.
1361 003744 005300          DEC    R0           ;
1362 003746 001374          BNE   2$           ;LOOP UNTIL DONE
1363 003750 112722 000011 1$:  MOVB  #11,(R2)+   ;LOAD 'TAB' CHAR
1364 003754 005301          DEC    R1           ;
1365 003756 100363          BPL   3$           ;BR TO NEXT TAB COLUMN CHAR
1366 003760 112722 000015   MOVB  #15,(R2)+   ;LOAD 'CR'
1367 003764 112722 000012   MOVB  #12,(R2)+   ;LOAD 'LF'
1368 003770 112722 000377   MOVB  #377,(R2)+  ;LOAD TERM
1369 003774 000205          RTS   R5           ;EXIT
1370 ;:*****
```

```
1371 ;*TEST 10 H ERASE FROM CURSOR TO END OF LINE
1372 ;:*****
1373 TST10: SCOPE
1374 JSR R5,AMSG ;DISPLAY HEADING
1375 M910
1376
1377 JSR PC,FILLWC ;FILL BUFFER WITH A CHAR
1378 ;DISPLAY THIS LINE
1379 JSR PC,DELAY ;DELAY
1380
1381 ;LOAD ERASE LINE TEST INTO BUFFER
1382
1383 LODERL: MOV #BUFFER,R0
1384 MOV #33,(R0)+ ;LOAD ESC
1385 MOV #H,(R0)+ ;LOAD HOME
1386 MOV VHO,2$ ;LOAD COUNT
1387 DEC 2$
1388 3$: MOV #33,(R0)+ ;LOAD ESC
1389 MOV #K,(R0)+ ;LOAD ERASE LINE CHAR
1390 DEC 2$ ;FINISHED ?
1391 BMI 1$ ;BR WHEN DONE
1392 MOV #6,10$ ;LOAD COUNT
1393 TST VT5XX ;TEST IF 12 LINES
1394 BPL 4$ ;BR IF 12 LINES
1395 ASR 10$ ;ADJUST HORIZ. COUNT
1396 NOP
1397 NOP
1398 NOP
1399 4$: MOV #33,(R0)+
1400 MOV #C,(R0)+ ;CURSOR RIGHT
1401 DEC 10$
1402 BNE 4$ ;LOOP
1403 MOV #12,(R0)+ ;CURSOR DOWN
1404 BR 3$
1405 2$: 0
1406 10$: 0
1407 1$: MOV #377,(R0)+ ;LOAD TERM
1408
1409
1410 JSR PC,XPRNT ;DISPLAY THIS TEST
1411
1412 JSR PC,DELAY ;TEST DELAY SWITCH
1413
1414 ;:*****
1415 ;*TEST 11 I ERASE FROM CURSOR TO END OF SCREEN
1416 ;:*****
1417 TST11: SCOPE
1418 JSR R5,AMSG ;DISPLAY HEADING
1419 M911
1420 JSR PC,FILLWC ;FILL BUFFER WITH A CHAR
1421 ;DISPLAY THIS LINE
1422 JSR PC,DELAY ;DELAY
1423
1424 ;LOAD ERASE SCREEN TEST INTO BUFFER
1425
1426 LODERS: MOV WIDTH,2$ ;LOAD COUNT
```

```

1427 004202 006237 004270 ASR 2$
1428 004206 012700 026346 MOV #BUFFER,R0
1429 004212 112720 000010 1$: MOVB #10,(R0)+ ;LOAD CURSOR LEFT
1430 004216 005337 004270 DEC 2$ ;DONE ?
1431 004222 100373 BPL 1$ ;BR UNTIL DONE
1432 004224 013737 001266 004270 MOV V#0,2$ ;LOAD COUNT
1433 004232 112720 000033 4$: MOVB #33,(R0)+ ;LOAD ESC
1434 004236 112720 000112 MOVB #'J,(R0)+ ;LOAD ERASE SCREEN
1435 004242 005337 004270 DEC 2$ ;DONE ?
1436 004246 100405 BPL 3$ ;BR WHEN DONE
1437 004250 112720 000033 MOVB #33,(R0)+ ;LOAD ESC
1438 004254 112720 000101 MOVB #'A,(R0)+ ;LOAD CURSOR UP
1439 004260 000764 BR 4$ ;LOOP
1440 004262 112720 000377 3$: MOVB #377,(R0)+ ;LOAD TERM
1441 004266 000401 BR 5$
1442 004270 000000 2$: 0
1443
1444 004272 004737 010246 5$: JSR PC,XPRNT ;DISPLAY THIS TEST
1445 004276 004737 011274 JSR PC,DELAY ;TEST DELAY SWITCH
1446
1447
1448
1449

```

```

*****
;*TEST 12 J VIDEO COUPLING TEST
*****

```

```

1450 004302 000004 TST12: SCOPE
1451 004304 004537 011454 JSR R5,AMSG ;DISPLAY HEADER
1452 004310 014310 M912
1453 004312 013737 001270 001312 MOV VH1,TEMP ;LOAD COUNTER
1454 004320 004537 011454 1$: JSR R5,AMSG
1455 004324 017251 PATH
1456
1457 004326 005337 001312 DEC TEMP ;FINISHED COUNT ?
1458 004332 001372 BNE 1$ ;BR UNTIL DONE
1459 004334 004737 011274 JSR PC,DELAY ;TEST DELAY SWITCH
1460
1461
1462
1463

```

```

*****
;*TEST 13 K DIRECT CURSOR ADDRESS TEST
*****

```

```

1464 004340 000004 TST13: SCOPE
1465 ; RANDOM NUMBERS ARE GENERATED AND USED AS 'X' AND 'Y' COORDINATES
1466 ; ADDRESSING A 960 CHARACTER PRINTOUT.
1467 ; VERIFICATION OF DISPLAY IS PERFORMED VISUALLY BY THE USER
1468 ; EXECUTE 1ST TIME USING 'ESC-Y' SEQUENCE AND IF I.D. IS AN 'H'
1469 ; EXECUTE 2ND TIME USING 'CODE 16' SEQUENCE
1470
1471 004342 032737 020000 001260 BIT #BIT13,VT5XX ;TEST IF DCA TYPE TERMINAL
1472 004350 001002 BNE 3$ ;:BR IF CURSOR ADDRESSING
1473 004352 000137 005100 1$: JMP TST14 ;BYPASS THIS TEST
1474 004356 005737 001332 3$: TST WFTST ;TEST IF IN W.F. MODE
1475 004362 001373 BNE 1$ ;BYPASS IF W.F. MODE
1476 004364 004537 011454 JSR R5,AMSG ;ERASE SCREEN AND IDENTIFY TEST
1477 004370 020650 M98
1478 004372 112737 000033 026346 MOVB #33,BUFFER ;LOAD 'ESC' CODE
1479 004400 112737 000131 026347 MOVB #'Y,BUFFER+1 ;LOAD ASCII 'Y' (D.C.A. ENABLE)
1480 004406 004737 004462 JSR PC,DCAST ;RUN TEST WITH ESC Y SEQUENCE
1481 004412 004737 011274 JSR PC,DELAY ;DELAY TESTING
1482 004416 122737 000110 001260 CMPB #'H,VT5XX ;TEST IF VT50H TYPE DISPLAY

```



```

1483 004424 001352          BNE      1$          ;;BR IF NOT VT50H TYPE
1484 004426 004537 011454   JSR      R5,AMSG    ;ERASE SCREEN AND IDENTIFY TEST
1485 004432 020650          M98
1486 004434 112737 000000 026346   MOVB    #0,BUFFER  ;LOAD "SPACE" AS FIRST VALUE
1487 004442 112737 000016 026347   MOVB    #16,BUFFER+1 ;LOAD CODE-16 SEQUENCE
1488 004450 004737 004462   JSR      PC,DCATST  ;RUN TEST WITH CODE 16 SEQUENCE
1489 004454 004737 011274   JSR      PC,DELAY
1490 004460 000734          BR       1$          ;;BR TO NEXT TEST
1491
1492 004462 012737 123456 026046   DCATST: MOV    #123456,$LONUM ;PRIME RANDOM NUMBER GENERATOR
1493 004470 012737 176543 026044   MOV    #176543,$HINUM
1494 004476 013737 001264 004754   MOV    TOTALC,OVRAL ;LOAD CHAR COUNT
1495 004504 013737 001266 004752   MOV    VHO,SET      ;LOAD LINE COUNT
1496 004512 012700 026366   MOV    #BUFFER+20,RO ;LOAD DESTINATION BUFFER
1497 004516 012701 004756   2$: MOV    #MSGTXT,R1 ;LOAD MESSAGE POINTER
1498 004522 012120   1$: MOV    (R1)+,(R0)+ ;LOAD 2 CHARACTERS
1499 004524 022701 005076   CMP    #MSGTND,R1   ;TEST FOR LAST CHAR
1500 004530 001374          BNE      1$          ;BR UNTIL DONE 1 LINE
1501 004532 005337 00475?   DEC    SET          ;FINISHED ALL LINES
1502 004536 001367          BNE      2$          ;BR IF NOT
1503 004540 012737 177777 026352   MOV    #-1,BUFFER+4 ;LOAD MESSAGE TERMINATOR
1504
1505 004546 004737 025746          GENER: JSR    %7,$RAND   ;GENERATE RANDOM NUMBER
1506 004552 013700 026044          MOV    $HINUM,RO      ;GET RNADOM NUMBER
1507 004556 042700 177700          BIC    #177700,%0     ;RANDOM NO. MUST BE TWO DIGITS
1508 004562 020027 000037          CMP    %0,#37        ;NO, MUST BE LESS THAN 40
1509 004566 101767          BLOS   GENER         ;LOWER, REGENERATION
1510 004570 020037 001262          CMP    %0,LASTLN    ;NO, MUST NOT BE GREATER THAN 54 OR 67
1511 004574 101364          BHI   GENER         ;GREATER, REGENERATION
1512 004576 010037 004746          MOV    %0,YADDS     ;STORE RANDOM Y COORDINATE
1513 004602 010001          MOV    %0,%1        ;COPY DATA
1514 004604 012737 026366 004752   MOV    #BUFFER+20,SET ;LOAD BASE POINTER
1515 004612 162701 000040          SUB    #40,%1        ;MINIMUM Y INDEX
1516 004616 001405          BEQ    GENRX        ;RESULT, MINIMUM Y COORDINATE
1517 004620 062737 000120 004752   1$: ADD    #80,,SET   ;SETUP Y INDEX LOCATION FOR PRINTOUT
1518 004626 005301          DEC    %1
1519 004630 001373          BNE    1$          ;Y COORDINATE IS SET
1520 004632 004737 025746          GENRX: JSR    %7,$RAND  ;GENERATE RANDOM NUMBER
1521 004636 013700 026044          MOV    $HINUM,RO    ;GET A RANDOM NUMBER
1522 004642 042700 177600          BIC    #177600,%0   ;RANDOM NO. MAY BE LESS THAN 200
1523 004646 020027 000037          CMP    %0,#37      ; MUST NOT BE LESS THAN 40
1524 004652 101767          BLOS   GENRX        ;LOWER, REGENERATION
1525 004654 020027 000157          CMP    %0,#157     ; MUST NOT BE GREATER THAN 157
1526 004660 101364          BHI   GENRX        ;GREATER, REGENERATION
1527 004662 010037 004750          MOV    %0,XADDS     ;STORE RANDOM X COORDINATE
1528 004666 162700 000040          SUB    #40,%0       ;SETUP MINIMUM X INDEX
1529 004672 060037 004752          ADD    %0,SET       ;SETUP X COOR, FOR PNTOUT.
1530 004676 013701 004752          MOV    SET,%1       ;SETUP CHECK
1531 004702 105711          TSTB   (1)          ;HAS CURRENT CHAR, ALREADY BEEN USED?
1532 004704 100720          BMI   GENER        ;YES, REGENERATE
1533 004706 113737 004746 026350   MOVB    YADDS,BUFFER+2 ;LOAD Y COORDINATE
1534 004714 113737 004750 026351   MOVB    XADDS,BUFFER+3 ;LOAD X COORDINATE
1535 004722 111137 026352          MOVB    (1),BUFFER+4 ;LOAD CHARACTER TO BE PRINTED
1536 004726 152711 000200          BISB   #200,(1)     ;INDICATE USE OF CURSOR POSITION
1537 004732 004737 010246          JSR    PC,XPRNT     ;EXECUTE AND PRINT CHARACTER
1538 004736 005337 004754          DEC    OVRAL        ;MAXIMUM NO. OF COORDINATES

```

```

1539 004742 001301          BNE      GENER      ;BR BACK UNTIL DONE
1540 004744 000207          RTS      PC          ;EXIT
1541
1542 004746 000000          YADDS:  0
1543 004750 000000          XADDS:  0
1544 004752 000000          SET:    0
1545 004754 000000          OVRAL:  0
1546 004756 052126 030065 050055  MSGTXT: .ASCII \VT50-PLUS-DIRECT-CURSOR-ADDRESSING-TEST\
1547 004764 052514 026523 044504
1548 004772 042522 052103 041455
1549 005000 051125 047523 026522
1550 005006 042101 051104 051505
1551 005014 044523 043516 052055
1552 005022 051505      124
1553 005025      055 044504 044507          .ASCII \-DIGITAL-EQUIPMENT-CORP.-MAYNARD-MA.-VT50\
1554 005032 040524 026514 050505
1555 005040 044525 046520 047105
1556 005046 026524 047503 050122
1557 005054 026456 040515 047131
1558 005062 051101 026504 040515
1559 005070 026456 052126 030065
1560 005076 100000
1561
1562
1563
1564
1565 005100 000004          MSGTND: BIT15
1566 005102 005037 010606          ;ONLY 12 LINE TERMINALS WILL RUN THIS TEST
1567 005106 005037 010670          ;*****
1568 005112 004537 011454          ;*TEST 14      L      HOLD SCREEN TEST
1569 005116 017223          ;*****
1570 005120 004537 011454          TST14:  SCOPE
1571 005124 017223          CLR      AXOFF
1572
1573 005126 005737 001332          CLR      XOFFRC      ;CLEAR SOFT FLAG
1574 005132 001046          JSR      R5,AMSG     ;DISPLAY
1575 005134 005737 001260          CRLFEB
1576 005140 100443          JSR      R5,AMSG     ;CR-LF
1577 005142 004537 011454          CRLFEB
1578 005146 014472          TST      WFTEST      ;TEST IF IN W.F. MODE
1579
1580 005150 012737 000001 010664          BNE      TST15      ;:BR IF W.F. MODE
1581 005156 012737 000001 010662          TST      VT5XX      ;TEST IF 12 LINE
1582 005164 004537 011454          BMI      TST15      ;:BR IF NOT 12 LINE
1583 005170 020540          JSR      R5,AMSG     ;DISPLAY MESSAGE
1584
1585 005172 005737 010670          M922
1586 005176 001001          MOV      #1,XOFFOK
1587
1588 005200 104002          MOV      #1,XOFFBR   ;ENABLE XOFF
1589
1590
1591
1592 005202 005037 010672          JSR      R5,AMSG     ;TRY TO SCROLL THE SCREEN
1593 005206 005037 010662          GOHDSC      ;ENABLE HOLD SCREEN
1594 005212 012737 000001 010666          TST      XOFFRC      ;TEST IF XOFF SENSED
1595
1596
1597
1598
1599
1600
1601
1602
1603
1604
1605
1606
1607
1608
1609
1610
1611
1612
1613
1614
1615
1616
1617
1618
1619
1620
1621
1622
1623
1624
1625
1626
1627
1628
1629
1630
1631
1632
1633
1634
1635
1636
1637
1638
1639
1640
1641
1642
1643
1644
1645
1646
1647
1648
1649
1650
1651
1652
1653
1654
1655
1656
1657
1658
1659
1660
1661
1662
1663
1664
1665
1666
1667
1668
1669
1670
1671
1672
1673
1674
1675
1676
1677
1678
1679
1680
1681
1682
1683
1684
1685
1686
1687
1688
1689
1690
1691
1692
1693
1694
1695
1696
1697
1698
1699
1700
1701
1702
1703
1704
1705
1706
1707
1708
1709
1710
1711
1712
1713
1714
1715
1716
1717
1718
1719
1720
1721
1722
1723
1724
1725
1726
1727
1728
1729
1730
1731
1732
1733
1734
1735
1736
1737
1738
1739
1740
1741
1742
1743
1744
1745
1746
1747
1748
1749
1750
1751
1752
1753
1754
1755
1756
1757
1758
1759
1760
1761
1762
1763
1764
1765
1766
1767
1768
1769
1770
1771
1772
1773
1774
1775
1776
1777
1778
1779
1780
1781
1782
1783
1784
1785
1786
1787
1788
1789
1790
1791
1792
1793
1794
1795
1796
1797
1798
1799
1800
1801
1802
1803
1804
1805
1806
1807
1808
1809
1810
1811
1812
1813
1814
1815
1816
1817
1818
1819
1820
1821
1822
1823
1824
1825
1826
1827
1828
1829
1830
1831
1832
1833
1834
1835
1836
1837
1838
1839
1840
1841
1842
1843
1844
1845
1846
1847
1848
1849
1850
1851
1852
1853
1854
1855
1856
1857
1858
1859
1860
1861
1862
1863
1864
1865
1866
1867
1868
1869
1870
1871
1872
1873
1874
1875
1876
1877
1878
1879
1880
1881
1882
1883
1884
1885
1886
1887
1888
1889
1890
1891
1892
1893
1894
1895
1896
1897
1898
1899
1900
1901
1902
1903
1904
1905
1906
1907
1908
1909
1910
1911
1912
1913
1914
1915
1916
1917
1918
1919
1920
1921
1922
1923
1924
1925
1926
1927
1928
1929
1930
1931
1932
1933
1934
1935
1936
1937
1938
1939
1940
1941
1942
1943
1944
1945
1946
1947
1948
1949
1950
1951
1952
1953
1954
1955
1956
1957
1958
1959
1960
1961
1962
1963
1964
1965
1966
1967
1968
1969
1970
1971
1972
1973
1974
1975
1976
1977
1978
1979
1980
1981
1982
1983
1984
1985
1986
1987
1988
1989
1990
1991
1992
1993
1994
1995
1996
1997
1998
1999
2000

```

```

1595 005220 004537 011454      JSR      R5,AMSG
1596 005224 020566                GODSHS      ;DISABLE HOLD SCREFN MODE
1597
1598 005226 004537 011454      JSR      R5,AMSG
1599 005232 017234                CRLF      ;TRY SCROLLING THE SCREEN
1600
1601 005234 005737 010672      TST      XONRC      ;TEST SOFT FLAG (X-ON)
1602 005240 001001                BNE      2$         ;BR IF SENSED
1603
1604 005242 104002                ERROR     2         ;DISABLE HOLD SCREEN MODE FAILED TO ENABLE
1605                                ;THE SCREEN TO SCROLL BY SENDING AN 'X-ON'
1606
1607 005244 004737 011274      2$:      JSR      PC,DELAY      ;PROGRAM DELAY
1608
1609                                ;*****
1610                                ;*TEST 15          M          TEST GRAPHICS MODE AND REV. LINE FEED
1611                                ;*****
1612 005250 000004                TST15:  SCOPE
1613 005252 032737 001000 001260  BIT      #BIT09,VT5XX      ;IS UNIT VT52?
1614 005260 001002                BNE      GRPHST          ;YES-TEST GRAPHICS AND REV. LINE FEED
1615 005262 000137 005362                JMP      COPTST          ;NO-GO CHECK FOR COPIER
1616 005266 012704 000120      GRPHST: MOV      #80.,R4
1617 005272 004537 011454      1$:      JSR      R5,AMSG      ;HOME THE CURSOR AND CLEAR THE SCREEN.
1618 005276 017243                HOMERS
1619 005300 004537 011454      JSR      R5,AMSG      ;DISPLAY TEST MESSAGE
1620 005304 014525                M9221
1621 005306 004537 011454      JSR      R5,AMSG      ;ENTER GRAPHICS MODE.
1622 005312 022313                ENGRAF
1623 005314 012737 000045 001314  MOV      #37.,TEMPO      ;SET UP TC XMIT 80 LINES
1624 005322 004737 011232      2$:      JSR      PC,GBBUF      ;LOAD BUFFER WITH GRAPHICS
1625 005326 004737 010246      JSR      PC,XPRNT        ;DISPLAY 1 LINE
1626 005332 004537 011454      JSR      R5,AMSG        ;ISSUE REV. LINE FEED AND
1627 005336 022274                REVLFF      ;A CARRIAGE RETURN
1628 005340 005304                DEC      R4            ;DECREMENT BUFFER COUNT
1629 005342 005337 001314      3$:      DEC      TEMPO        ;DONE?
1630 005346 001365                BNE      2$           ;NO-LOOP
1631 005350 004537 011454      JSR      R5,AMSG        ;YES-EXIT GRAPHICS MODE
1632 005354 022320                EXGRAF
1633 005356 004737 011274      JSR      PC,DELAY      ;AND GO CHECK DELAY
1634 005362                COPTST:
1635                                ;*****
1636                                ;*TEST 16          N          COPIER - AUTO COPY TEST
1637                                ;*****
1638 005362 000004                TST16:  SCOPE
1639 005364 032737 040000 001260  BIT      #BIT14,VT5XX      ;TEST IF COPIER IS AVAILABLE
1640 005372 001002                BNE      2$           ;:BR IF AVAILABLE
1641 005374 000137 006342      3$:      JMP      PRNTST          ;NOT AVAILABLE SO BYPASS COPIER TESTS
1642 005400 032777 004000 173532  2$:      BIT      #BIT11,@SWR      ;TEST IF INHIBIT COPIER TEST SWITCH IS SET
1643 005406 001372                BNE      3$           ;BR IF SET
1644 005410 032777 002000 173522  BIT      #BIT10,@SWR      ;TEST IF PAPER SAVE SWITCH IS SET
1645 005416 001406                BNE      6$           ;BR IF NOT SET AND START COPIER TESTING
1646 005420 105737 001274      TSTB     PRTCNT        ;TEST IF TIME TO TEST COPIER
1647 005424 001363                BNE      3$           ;NOT TIME TO RUN THE COPIER
1648 005426 013737 001250 001274  MOV      PTCT,PRTCNT      ;RELOAD COUNTER AND TEST COPIER
1649
1650 005434 004537 011454      6$:      JSR      R5,AMSG

```

```

1651 005440 014600 M923 ;DISPLAY HEADER
1652 005442 004537 011454 JSR R5,AMSG ;ENABLE AUTO-COPY
1653 005446 020614 GOAPMD
1654
1655 005450 013737 001266 001314 MOV V#0,TEMPO ;LOAD A EXECUTION COUNT
1656 005456 012701 000101 MOV #101,R1 ;LOAD A CHARACTER
1657 005462 004737 010144 JSR PC,FILBUF ;LOAD CHARACTER INTO BUFFER
1658 005466 012737 000001 010664 1$: MOV #1,XOFFOK
1659 005474 004737 010246 JSR PC,XPRNT ;DISPLAY IT
1660 005500 004737 011274 JSR PC,DELAY ;PROGRAM DELAY
1661 005504 005337 001314 DEC TEMPO ;FINISHED ?
1662 005510 100366 BPL 1$ ;BR IF NOT
1663 005512 012737 000001 010664 MOV #1,XOFFOK
1664 005520 004537 011454 JSR R5,AMSG ;DISABLE AUTO-COPY
1665 005524 020621 GONAPM
1666 005526 004737 011274 JSR PC,DELAY ;ANOTHER DELAY
1667
1668
1669 ::*****
1670 :*TEST 17 0 COPIER - FULL SCREEN OF A CHARACTER
1671 :*****
1672 TST17: SCOPE
1673 1$: JSR R5,AMSG ;DISPLAY HEADER
1674 M91
1675 JSR PC,FILLWC ;FILL BUFFER WITH CHAR
1676 ;DISPLAY IT
1677 MOV #1,XOFFOK ;ALLOW XOFF
1678 JSR R5,AMSG ;COPY INST
1679 GOPRNT
1680 JSR PC,DELAY
1681
1682
1683 ::*****
1684 :*TEST 20 P COPIER - DATA PATH TEST
1685 :*****
1686 TST20: SCOPE
1687 JSR R5,AMSG ;DISPLAY HEADING
1688 M92
1689 MOV V#1,TEMP ;SET-UP A COUNTER
1690 JSR R5,DTPSR ;SET-UP BUFFER
1691 77 ;OCTAL '?'
1692 100 ;OCTAL '@'
1693 JSR R5,DTPSRB ;SET-UP BUFFER
1694 125 ;OCTAL 'U'
1695 52 ;OCTAL '*'
1696 1$: JSR PC,XPRNT ;DISPLAY THIS LINE
1697 DEC TEMP ;COMPLETED FULL COUNT?
1698 BNE 1$ ;BRANCH IF NOT COMPLETED
1699 MOV #1,XOFFOK
1700 JSR R5,AMSG ;COPY INST
1701 GOPRNT ;TEST DELAY SWITCH
1702 JSR PC,DELAY
1703
1704 ::*****
1705 :*TEST 21 0 COPIER - SINGLE CHARACTER ACROSS ALL COLS. <ALL CHARACTERS>
1706 :*****
1707 TST21: SCOPE
  
```

```

1707 005660 004537 011454 JSR R5,AMSG ;DISPLAY HEADING
1708 005664 014041 M93
1709 005666 012737 000040 001306 MOV #40,STCHAR ;SET-UP STARTING CHARACTER
1710 005674 013737 001266 001314 MOV VHO,TEMPO
1711 005702 013701 001306 1$: MOV STCHAR,R1 ;LOAD R1= TO CHARACTER
1712 005706 004737 010144 JSR PC,FILBUF ;LOAD A BUFFER WITH THAT CHARACTER
1713 005712 004737 010246 JSR PC,XPRNT ;DISPLAY A FULL LINE FROM THE BUFFER
1714 005716 005337 001314 DEC TEMPO ;DONE
1715 005722 001011 BNE 3$
1716 005724 013737 001266 001314 MOV VHO,TEMPO
1717 005732 012737 000001 010664 MOV #1,XOFFOK ;ALLOW XOFF
1718 005740 004537 011454 JSR R5,AMSG
1719 005744 020512 GOPRNT ;COPY INST
1720 005746 005237 001306 3$: INC STCHAR ;UPDATE THE CHARACTER
1721 005752 023737 001310 001306 CMP LASTCH,STCHAR ;TEST FOR FINAL CHARACTER
1722 005760 001350 BNE 1$ ;BRANCH IF NOT COMPLETED
1723 005762 004537 011454 JSR R5,AMSG ;CRLF
1724 005766 017232 CRLFA-2
1725 005770 012737 000001 010664 MOV #1,XOFFOK ;ENABLE XOFF
1726 005776 004537 011454 JSR R5,AMSG ;COPY INST
1727 006002 020512 GOPRNT
1728 006004 004737 011274 JSR PC,DELAY ;TEST DELAY SWITCH
1729
1730
1731
1732

```

```

*****
*TEST 22 R COPIER - ROTATING CHARACTERS ACROSS ALL COLS. <ALL CHARACTERS>
*****
TST22: SCOPE

```

```

1733 006010 000004
1734 006012 004537 011454 JSR R5,AMSG ;DISPLAY HEADING
1735 006016 014101 M94
1736 006020 012737 000040 001306 MOV #40,STCHAR ;SET-UP STARTING CHARACTER
1737 006026 013737 001266 001314 MOV VHO,TEMPO
1738 006034 013701 001306 1$: MOV STCHAR,R1 ;LOAD R1=TO CHARACTER
1739 006040 004537 010200 JSR R5,LIC ;LOAD A BUFFER STARTING WITH
1740 006044 001320 WIDTH ; THAT CHARACTER AND WIDTH <BYTE>
1741 006046 004737 010246 JSR PC,XPRNT ;DISPLAY A FULL LINE FROM THE BUFFER
1742 006052 005337 001314 DEC TEMPO ;DONE ?
1743 006056 001011 BNE 3$
1744 006060 013737 001266 001314 MOV VHO,TEMPO
1745 006066 012737 000001 010664 MOV #1,XOFFOK
1746 006074 004537 011454 JSR R5,AMSG
1747 006100 020512 GOPRNT ;COPY INST
1748 006102 005237 001306 3$: INC STCHAR ;UPDATE THE STARTING CHARACTER
1749 006106 023737 001310 001306 CMP LASTCH,STCHAR ;TEST FOR FINAL CHARACTER
1750 006114 001347 BNE 1$ ;BRANCH IF NOT COMPLETED
1751 006116 004537 011454 JSR R5,AMSG ;CRLF
1752 006122 017232 CRLFA-2
1753 006124 012737 000001 010664 MOV #1,XOFFOK ;ENABLE XOFF
1754 006132 004537 011454 JSR R5,AMSG ;COPY INST
1755 006136 020512 GOPRNT
1756 006140 004737 011274 JSR PC,DELAY ;TEST DELAY SWITCH
1757
1758
1759
1760

```

```

*****
*TEST 23 S COPIER - PERIMETER PATTERN
*****
TST23: SCOPE

```

```

1761 006144 000004
1762 006146 004537 011454 JSR R5,AMSG ;DISPLAY HEADER

```

```
1763 006152 014412 M920
1764 006154 012701 000105 MOV #E,R1 ;LOAD STARTING CHARACTER
1765 006160 004737 010144 JSR PC,FILBUF ;FILL THE EJFFER
1766 006164 004737 010246 JSR PC,XPRNT ;DISPLAY A LINE
1767 006170 004737 010246 JSR PC,XPRNT ;DISPLAY A LINE
1768 006174 013737 001270 001312 MOV VH1,TEMP ;LOAD VERT COUNT
1769 006202 062737 000002 001312 ADD #2,TEMP ;UPDATE BY 2
1770 006210 004737 011072 1$: JSR PC,FIRLST ;FILL FIRST AND LAST
1771 006214 004737 010246 JSR PC,XPRNT ;DISPLAY A LINE
1772 006220 005337 001312 DEC TEMP ;DONE ?
1773 006224 001371 BNE 1$
1774 006226 012701 000105 MOV #E,R1 ;LOAD STARTING CHAR
1775 006232 004737 010144 JSR PC,FILBUF ;LOAD LINE WITH E'S
1776 006236 004737 010246 JSR PC,XPRNT ;DISPLAY A LINE
1777 006242 004737 010246 JSR PC,XPRNT
1778 006246 012737 000001 010664 MOV #1,XOFFOK
1779 006254 004537 011454 JSR R5,AMSG
1780 006260 020512 GOPRNT ;COPY SCREEN
1781 006262 004737 011274 JSR PC,DELAY
1782
1783 ;*****
1784 ;*TEST 24 T COPIER - DISCLAIMER STATEMENT
1785 ;*****
1786 006266 000004 TST24: SCOPE
1787
1788 006270 004537 011454 JSR R5,AMSG ;DISPLAY HEADER
1789 006274 014440 M921
1790
1791 006276 005004 CLR R4
1792 006300 016437 006616 006314 1$: MOV DISPCH(R4),10$ ;LOAD A POINTER
1793 006306 001405 BEQ 2$ ;BR IF DONE
1794 006310 004537 011454 JSR R5,AMSG ;DISPLAY COPYRIGHT
1795 006314 023221 10$: MTEXT0
1796 006316 005724 TST (R4)+ ;UPDATE POINTER
1797 006320 000767 BR 1$
1798
1799
1800 006322 012737 000001 010664 2$: MOV #1,XOFFOK ;ENABLE XOFF
1801 006330 004537 011454 JSR R5,AMSG ;COPY SCREEN
1802 006334 020512 GOPRNT
1803 006336 004737 011274 JSR PC,DELAY
1804 006342 000240 PRNTST: NOP ;TRY PRINTER TESTS
1805
1806 ;*****
1807 ;*TEST 25 U PRINTER CONTROLLER MODE TEST
1808 ;*****
1809 006344 000004 TST25: SCOPE
1810 006346 032737 002000 001260 BIT #BIT10,VT5XX ;IS UNIT EQUIPPED WITH PRINTER.
1811 006354 001002 BNE 1$ ;YES-TEST IT
1812 006356 000137 006644 JMP $EOP ;NO-EXIT TEST
1813 006362 004537 011454 1$: JSR R5,AMSG ;DISPLAY HEADER
1814 006366 014635 MPTCNT
1815 006370 004537 011454 JSR R5,AMSG ;ENABLE PRINTER CONTROLLER MODE.
1816 006374 022325 ENPNTM
1817 006376 012737 000040 001306 MOV #40,STCHAR ;LOAD INITIAL CHAR.
1818 006404 013701 001306 2$: MOV STCHAR,R1
```

```

1819 006410 004537 010200 JSR R5,LIC ;BUILD A 132 COL. LINE.
1820 006414 001316 PNTWID
1821 006416 012737 000001 010664 MOV #1,XOFFOK ;ALLOW XOFF/XON PROTOCOL
1822 006424 004737 010246 JSR PC,XPRNT ;DISPLAY IT.
1823 006430 005237 001306 INC STCHAR ;INCREMENT 1ST CHAR.
1824 006434 023737 001306 001310 CMP STCHAR,LASTCH ;ISSUED 92 LINES?
1825 006442 001360 BNE 2$ ;NO-LOOP
1826 006444 004537 011454 JSR R5,AMSG ;YES-DISABLE PRINTER
1827 006450 022332 EXPNTM ;CONTROLLER MODE.
1828 006452 004737 011274 JSR PC,DELAY ;TEST DELAY SWITCH AND EXIT.
1829
1830

```

```

*****
:*TEST 26 V PRINT SCREEN TEST
*****
TST26. SCOPE

```

```

1833 006456 000004
1834
1835
1836 006460 004537 011454 JSR R5,AMSG ;DISPLAY PRINT SCREEN MESSAGE
1837 006464 014704 MPTSCN
1838
1839 006466 004737 013550 JSR PC,FILLWC ;FILL THE SCREEN WITH E
1840
1841 006472 012737 000001 010664 MOV #1,XOFFOK ;ALLOW XOFF/XON PROTOCOL
1842 006500 004537 011454 JSR R5,AMSG ;PRINT THEM
1843 006504 020512 GOPRNT
1844
1845 006506 004737 011274 JSR PC,DELAY ;TEST DELAY SWITCH.
1846
1847

```

```

*****
:*TEST 27 W AUTO PRINT TEST
*****
TST27: SCOPE

```

```

1848
1849
1850 006512 000004
1851
1852 006514 004537 011454 JSR R5,AMSG
1853 006520 014741 M923A ;DISPLAY HEADER
1854 006522 004537 011454 JSR R5,AMSG ;ENABLE AUTO-PRINT
1855 006526 020614 GOAPMD
1856
1857 006530 013737 001266 001314 MOV VHO,TEMPO ;LOAD A EXECUTION COUNT
1858 006536 012701 000101 MOV #101,R1 ;LOAD A CHARACTER
1859 006542 004737 010144 JSR PC,FILBUF ;LOAD CHARACTER INTO BUFFER
1860 006546 012737 000001 010664 1$: MOV #1,XOFFOK
1861 006554 004737 010246 JSR PC,XPRNT ;DISPLAY IT
1862 006560 004737 011274 JSR PC,DELAY ;PROGRAM DELAY
1863 006564 005337 001314 DEL TEMPO ;FINISHED ?
1864 006570 100366 BPL 1$ ;BR IF NOT
1865 006572 012737 000001 010664 MOV #1,XOFFOK
1866 006600 004537 011454 JSR R5,AMSG ;DISABLE AUTO-PRINT
1867 006604 020621 GONAPM
1868 006606 004737 011274 JSR PC,DELAY ;ANOTHER DELAY
1869
1870 006612 000137 006644 JMP $EOP ;END OF PASS
1871 006616 023221 DISPCH: MTEXT0
1872 006620 023325 MTEXT1
1873 006622 023426 MTEXT2
1874 006624 023530 MTEXT3

```

CZVTCFO VT50A,B,H/52 ACCPT
CZVTCF.P11 11-APR-79 15:31

MACY11 30A(1052) 11-APR-79 15:34 M 3
T27 W AUTO PRINT TEST PAGE 39

SEQ 0038

1875	006626	023613	MTEXT4
1876	006630	023715	MTEXT5
1877	006632	024016	MTEXT6
1878	006634	024050	MTEXT7
1879	006636	024150	MTEXT8
1880	006640	000000	0
1881	006642	000000	0
1882			

1883
1884
1885
1886
1887
1888
1889
1890
1891
1892
1893
1894
1895
1896
1897
1898
1899
1900
1901
1902
1903
1904
1905
1906
1907
1908
1909
1910
1911
1912
1913
1914
1915
1916
1917
1918
1919
1920
1921
1922
1923
1924
1925
1926
1927
1928
1929
1930
1931
1932
1933
1934
1935
1936
1937
1938

006644
006644 000004
006646 005737 001244
006652 001414
006654 023737 001244 001246
006662 001410
006664 062737 000010 001246
006672 012737 002466 002402
006700 000137 002014
006704 005737 001100
006710 001002
006712 104401 021035
006716 000005
006720 005737 001332
006724 001402
006726 004737 011402
006732 000240
006734 005037 001102
006740 005237 001100
006744 042737 100000 001100
006752 005327
006754 000001
006756 003022
006760 012737
006762 000001
006764 006754
006766 104401 007033
006772 013746 001100
006776 104405
007000 104401 007030
007004 013700 000042
007010 001405
007012 000005
007014 004710
007016 000240
007020 000240
007022 000240
007024
007024 000137
007026 007050
007030 377 377 000
007033 015 042412 042116
007040 050040 051501 020123
007046 000043
007050 005737 001274

.SBTTL END OF PASS ROUTINE

: *INCREMENT THE PASS NUMBER (\$PASS)
: *INDICATE END-OF-PROGRAM AFTER 1 PASSES THRU THE PROGRAM
: *TYPE 'END PASS #XXXXX' (WHERE XXXXX IS A DECIMAL NUMBER)
: *IF THERES A MONITOR GO TO IT
: *IF THERE ISN'T JUMP TO NOWEOP

\$EOP:
SCOPE
TST LAST :TEST IF MORE
BEQ 1\$:BR IF NONE
CMP LAST,VTNOW :IS THIS THE LAST ONE
BEQ 1\$:BR IF YES
ADD #10,VTNOW
MOV #TST2,WHERE
JMP RSTRT :TEST NEXT ONE
1\$: TST \$PASS :TEST IF FIRST PASS
BNE 2\$:BR IF NOT
TYPE ,PASHED :TYPE EOP HEADER
2\$: RESET
TST WFTST :TEST IF W.F. MODE
BEQ 3\$:BR IF NOT
JSR PC,ADELAY :EXTRA DELAY
3\$: NOP
CLR \$TSTNM :ZERO THE TEST NUMBER
INC \$PASS :INCREMENT THE PASS NUMBER
BIC #100000,\$PASS :DON'T ALLOW A NEG. NUMBER
DEC (PC)+ :LOOP?
\$EOPCT: .WORD 1
BGT \$DOAGN :YES
MOV (PC)+,@(PC)+ :RESTORE COUNTER
\$ENDCT: .WORD 1
TYPE ,SENDMG :TYPE 'END PASS #'
MOV \$PASS,-(SP) :SAVE \$PASS FOR TYPEOUT
TYPDS :GO TYPE--DECIMAL ASCII WITH SIGN
\$GET42: MOV ,SENULL :TYPE A NULL CHARACTER
BEQ @#42,R0 :GET MONITOR ADDRESS
RESET \$DOAGN :BRANCH IF NO MONITOR
\$ENDAD: JSR PC,(R0) :CLEAR THE WORLD
NOP :GO TO MONITOR
NOP :SAVE ROOM
NOP :FOR
NOP :ACT11
\$DOAGN: JMP @(PC)+ :RETURN
\$RTNAD: .WORD NOWEOP
\$ENULL: .BYTE -1,-1,0 :NULL CHARACTER STRING
\$ENDMG: .ASCIZ <15><12>/END PASS #/
NOWEOP: TST PRTCNT

```

1939 007054 100002          BPL      11$
1940 007056 105337 001274    DECB    PRTCNT
1941 007062 012737 002466    002402 11$:  MOV     #TST2,WHERE
1942 007070 013746 001112    MOV     $ERTTL,-(SP)
1943 007074 104405          TYPDS
1944 007076 104401 007030    TYPE   , $ENULL
1945 007102 000137 002006    JMP     SBEGIN
1946
1947          ;*****
1948          ;*TEST 30      X      KEYBOARD OCTAL VALUE LOOP
1949          ;*****
1949 007106 000004          TST30: SCOPE
1950 007110 012706 001100    KRBECD: MOV     #STACK,SP
1951 007114 004537 011454    JSR     R5,AMSG          ;DISPLAY HEADER
1952 007120 016744          MKE
1953 007122 004737 013612    1$:  JSR     PC,GETCHR      ;GET CHAR
1954 007126 000775          BR      1$              ;;BR BACK IF NO INPUT
1955 007130 004737 011474    JSR     PC,OCTAL        ;CONVERT RO TO OCTAL
1956 007134 113737 011564 017165    MOVB   DIG0,MKEB       ;LOAD DIGIT
1957 007142 113737 011566 017166    MOVB   DIG1,MKEB+1     ;LOAD DIGIT
1958 007150 113737 011570 017167    MOVB   DIG2,MKEB+2     ;LOAD DIGIT
1959 007156 042700 177600    BIC    #177600,RO
1960 007162 001001          BNE    10$
1961 007164 005200          INC    RO
1962 007166 012701 007276    10$:  MOV     #BFCHR,R1      ;LOAD POINTER
1963 007172 121100          5$:  CMPB   (R1),RO         ;TEST IF = TO VALUF IN TABLE ?
1964 007174 001403          BEQ    3$              ;BR IF FOUND
1965 007176 005721          TST   (R1)+           ;MOVE POINTER
1966 007200 001374          BNE    5$             ;BR IF MORE
1967 007202 000407          BR     2$             ;BR IF NOT IN LIST
1968 007204 062701 000040    3$:  ADD    #BFCHAR-BFCHR,R1 ;UPDATE POINTER
1969 007210 112137 017160    MOVB   (R1)+,MKEA1     ;LOAD 1ST CHAR
1970 007214 112137 017161    MOVB   (R1)+,MKEA1+1   ;LOAD 2ND
1971 007220 000420          BR     4$
1972 007222 120027 000040    2$:  CMPB   RO,#40         ;TEST IF LESS THAN 40
1973 007226 101010          BHI    6$             ;BR IF ABOVE
1974 007230 062700 000100    ADD    #100,RO        ;MAKE PRINTABLE
1975 007234 110037 017161    MOVB   RO,MKEA1+1     ;SAVE CHAR
1976 007240 112737 000136 017160    MOVB   #136,MKEA1     ;ADD A '^' BEFORE CHARACTER
1977 007246 000405          BR     4$
1978 007250 112737 000040 017161    6$:  MOVB   #40,MKEA1+1   ;LOAD SPACE
1979 007256 110037 017160    MOVB   RO,MKEA1       ;LOAD CHARACTER
1980 007262 005237 010676    4$:  INC    IGNORE        ;IGNORE DOUBLE CHARACTER FLAG
1981 007266 004537 011454    JSR     R5,AMSG       ;DISPLAY MESSAGE
1982 007272 017147          MKEA
1983 007274 000712          BR     1$             ;LOOP BACK
1984
1985          ;TABLE OF DEFINED CHARACTERS
1986
1987 007276 000007          BFCHR: 7              ;BELL CODE
1988 007300 000010          10      ;CURSOR LEFT CODE
1989 007302 000011          11      ;TAB CODE
1990 007304 000012          12      ;LINE FEED CODE
1991 007306 000015          15      ;CARRIAGE RETURN CODE
1992 007310 000033          33      ;ESCAPE CODE
1993 007312 000040          40      ;SPACE CODE
1994 007314 000177          177     ;DELETE CODE

```

1995 007316 000000
1996 007320 000000
1997 007322 000000
1998 007324 000000
1999 007326 000000
2000 007330 000000
2001 007332 000000
2002 007334 000000

0
0
0
0
0
0
0
0

;DEFINED CHARACTER EQUIL

2006 007336 046102
2007 007340 046103
2008 007342 052110
2009 007344 043114
2010 007346 051103
2011 007350 051505
2012 007352 050123
2013 007354 042504
2014 007356 000000 000000 000000
2015 007364 000000 000000 000000
2016 007372 000000 000000 000000
2017 007400 000000

BFCHAR: .ASCII /BL/ :BELL
.ASCII /CL/ :CURSOR LEFT
.ASCII /HT/ :H TAB
.ASCII /LF/ :LINE FEED
.ASCII /CR/ :CARIAGE RETURN
.ASCII /ES/ :ESCAPE
.ASCII /SP/ :SPACE
.ASCII /DE/ :DELETE
0,0,0,0,0,0,0,0,0,0

.EVEN

2018
2019
2020
2021
2022 007402 000004
2023
2024 007404 032737 001000 J01260
2025 007412 001403
2026 007414 012703 021550
2027 007420 000402
2028 007422 012703 021532
2029 007426 012706 001100
2030 007432 004537 011454
2031 007436 014774
2032 007440 012302
2033 007442 032737 001000 001260
2034 007450 001404
2035 007452 004537 011454
2036 007456 015275
2037 007460 000403
2038 007462 004537 011454
2039 007466 015160
2040 007470 004737 011572
2041
2042 007474 012302
2043 007476 004537 011454
2044 007502 015361
2045 007504 004737 011572
2046
2047 007510 012302
2048 007512 032737 001000 001260
2049 007520 001404
2050 007522 004537 011454

: *TEST 31 Y KEYBOARD CHARACTER TEST

TST31: SCOPE
:CHECKS THAT TERMINAL IS GENERATING THE EXPECTED ASCII CODES
KRBTST: BIT #BIT09,VT5XX :IS UNIT A VT52?
BEQ 1\$
MOV #V52RW,R3 :YES-SET UP FOR LOWER CASE CHAR.
BR 2\$
1\$: MOV #V50RW,R3 :NO-SET UP FOR UPPER CASE CHAR.
2\$: MOV #STACK,SP
A: JSR R5,AMSG :DISPLAY HEADER
MKB
MOV (R3)+,R2 :LOAD ROW #
BIT #BIT09,VT5XX :UNIT A VT52?
BEQ 1\$:NO-USE UPPER CASE KEYBOARD.
JSR R5,AMSG :ISSUE VT52 ROW1 MESSAGE.
MKB2
BR 2\$
1\$: JSR R5,AMSG
2\$: JSR PC,TSTROW :TOP ROW
 :CHECK THE ROW
B: MOV (R3)+,R2 :LOAD ROW #
JSR R5,AMSG :2ND ROW
MKB3
JSR PC,TSTROW :CHECK 2ND ROW
C: MOV (R3)+,R2 :LOAD ROW #
BIT #BIT09,VT5XX :UNIT A VT52?
BEQ 1\$:NO-USE UPPER CASE KEYBOARD.
JSR R5,AMSG :ISSUE VT52 ROW 3 MESSAGE.

```
2051 007526 015526 MKBD2
2052 007530 000403 BR 2$
2053 007532 004537 011454 1$: JSR R5,AMSG
2054 007536 015421 MKBD
2055 007540 004737 011572 2$: JSR PC,TSTROW ;CHECK ROW 3
2056
2057 007544 012302 MOV (R3)+,R2 ;LOAD ROW #
2058 007546 004537 011454 JSR R5,AMSG
2059 007552 015615 MKBE
2060 007554 004737 011572 JSR PC,TSTROW ;CHECK ROW 4
2061
2062 007560 012702 021734 MOV #ROW5,R2
2063 007564 004537 011454 JSR R5,AMSG ;DISPLAY MSG
2064 007570 015756 MKBF ;'DEPRESS SPACE BAR''
2065 007572 000261 SEC ;SET FLAG DENOTING FIFTH ROW TEST
2066 007574 004737 011572 JSR PC,TSTROW ;CHECK ROW 5
2067
2068 ;TEST THE 'LEFT-SHIFT' KEY
2069
2070 007600 004537 011454 D: JSR R5,AMSG ;DEPRESS THE 'LEFT-SHIFT' KEY
2071 007604 016013 MKBG
2072 007606 012302 MOV (R3)+,R2 ;LOAD ROW 1 SHIFTED TABLE
2073 007610 032737 001000 001260 BIT #BIT09,VT5XX ;UNIT A VT52?
2074 007616 001404 BEQ 1$ ;NO-USE UPPER CASE KEYBOARD.
2075 007620 004537 011454 JSR R5,AMSG ;ISSUE VT52 ROW1 MESSAGE.
2076 007624 015275 MKBB2
2077 007626 000403 BR 2$
2078 007630 004537 011454 1$: JSR R5,AMSG ;TEST ROW 1
2079 007634 015160 MKBB
2080 007636 004737 011572 2$: JSR PC,TSTROW ;TEST THE ROW
2081 007642 004537 011454 JSR R5,AMSG ;RELEASE THE SHIFT KEY
2082 007646 015032 MKB1
2083
2084 ;TEST THE 'RIGHT-SHIFT' KEY
2085
2086 007650 004537 011454 E: JSR R5,AMSG ;SET THE 'RIGHT-SHIFT' KEY
2087 007654 016062 MKBGA
2088 007656 012302 MOV (R3)+,R2 ;LOAD TABLE POINTER
2089 007660 032737 001000 001260 BIT #BIT09,VT5XX ;UNIT A VT52?
2090 007666 001404 BEQ 1$ ;NO-USE UPPER CASE KEYBOARD.
2091 007670 004537 011454 JSR R5,AMSG ;ISSUE VT52 ROW1 MESSAGE.
2092 007674 015275 MKBB2
2093 007676 000403 BR 2$
2094 007700 004537 011454 1$: JSR R5,AMSG
2095 007704 015160 MKBB
2096 007706 004737 011572 2$: JSR PC,TSTROW ;TEST THE ROW AGAIN WITH THE RIGHT-SHIFT SET
2097 007712 004537 011454 JSR R5,AMSG
2098 007716 015032 MKB1 ;RELEASE SKIFT KEY
2099 ;TEST THE CONTROL MODE
2100
2101 007720 004537 011454 F: JSR R5,AMSG ;SET CTRL
2102 007724 016133 MKBH
2103 007726 012302 MOV (R3)+,R2 ;LOAD ROW 1 CTRL TABLE
2104 007730 032737 001000 001260 BIT #BIT09,VT5XX ;UNIT A VT52?
2105 007736 001404 BEQ 1$ ;NO-USE UPPER CASE KEYBOARD.
2106 007740 004537 011454 JSR R5,AMSG ;ISSUE VT52 ROW1 MESSAGE.
```

```
2107 007744 015275 MKBB2
2108 007746 000403 BR 2$
2109 007750 004537 011454 1$: JSR R5,AMSG
2110 007754 015160 MKBB
2111 007756 004737 011572 2$: JSR PC,TSTROW ;TEST THE ROW
2112
2113 ;KEYPAD TEST FOR VT50H AND VT52
2114
2115 007762 032737 010000 001260 BIT #BIT12,VT5XX ;KEYPAD ON UUT?
2116 007770 001441 BEQ KRBDON ;NO EXIT TEST
2117 007772 004537 011454 JSR R5,AMSG ;TYPE TEST ID
2118 007776 016406 MKBN ;'VT50H/VT52 KEYPAD TEST IN NORMAL MODE''
2119 010000 004537 011454 JSR R5,AMSG ;TYPE INSTRUCTIONS
2120 010004 023134 INSTR ;'START TOP ROW LEFT TO RIGHT
2121 ;/PROCEED TO BOTTOM ROW''
2122 010006 004537 011454 JSR R5,AMSG ;DISABLE ALTERNATE KEYPAD MODE
2123 010012 022306 EXAKP
2124 010014 012702 022340 MOV #KPTAB,R2 ;SET TABLE POINTER TO NORMAL MODE CODES
2125 010020 004737 012202 CALL TSTKPS ;DO THE TEST
2126 010024 032737 001000 001260 BIT #1000,VT5XX ;IS UUT VT52?
2127 010032 001420 BEQ KRBDON ;NO EXIT TEST
2128 010034 004537 011454 JSR R5,AMSG ;TYPE TEST ID
2129 010040 016463 MKB52 ;'VT52 ALTERNATE KEYPAD MODE TEST''
2130 010042 004537 011454 JSR R5,AMSG ;TYPE INSTRUCTIONS
2131 010046 023134 INSTR
2132 010050 004537 011454 JSR R5,AMSG ;ENTER ALT-MODE
2133 010054 022301 ENAKP
2134 010056 012702 022416 MOV #AKPTAB,R2 ;SET TABLE POINTER TO ALTERNATE MODE CODES
2135 010062 004737 012202 CALL TSTKPS ;DO THE TEST
2136 010066 004537 011454 JSR R5,AMSG ;EXIT ALT-MODE
2137 010072 022306 EXAKP
2138 ;COMPLETION OF KEYBOARD-KEYPAD TEST
2139
2140 010074 004537 011454 KRBDON: JSR R5,AMSG ;END OF KEYBOARD TEST
2141 010100 016625 MKBR
2142 010102 000137 007404 JMP KRBTST ;LOOP
2143 ;*****
2144 ;*TEST 32 Z KEYBOARD ECHO LOOP
2145 ;*****
2146 010106 000004 ST32: SCOPE
2147 010110 012706 001100 KRBECH: MOV #STACK,SP
2148 010114 004537 011454 JSR R5,AMSG ;DISPLAY HEADER
2149 010120 017174 MKEH
2150
2151 010122 004737 013612 1$: JSR PC,GETCHR ;GET CHARACTER
2152 010126 000775 BR 1$
2153 010130 110077 171150 MOVB R0,@VT0B ;LOAD THE CHARACTER
2154 010134 105777 171142 2$: TSTB @VTOS ;WAIT FOR DONE
2155 010140 100375 BPL 2$
2156 010142 000767 BR 1$ ;LOOP BACK
2157
2158 ;LOAD A SINGLE CHARACTER ACROSS THE SCREEN WIDTH
2159 ;
2160
2161 010144 013702 001320 FILBUF: MOV WIDTH,R2 ;LOAD WIDTH VALUE
2162 010150 012700 026346 FILBFB: MOV #BUFFER,R0 ;SET-UP BUFFER POINTER
```

2163	010154	112720	000015		MOV B	#15,(R0)+	:LOAD 'CR'
2164	010160	112720	000012		MOV B	#12,(R0)+	:LOAD 'FL'
2165	010164	110120		FILBFA:	MOV B	R1,(R0)+	:SAVE THE CHARACTER IN THE BUFFER
2166	010166	005302			DEC	R2	:FINISHED?
2167	010170	001375			BNE	FILBFA	:BRANCH IF NOT COMPLETED
2168	010172	112710	000377		MOV B	#377,(R0)	:LOAD TERM.
2169	010176	000207			RTS	PC	:EXIT
2170							
2171							
2172							
2173							
2174	010200	012700	026346	LIC:	MOV	#BUFFER,R0	:SET-UP BUFFER POINTER
2175	010204	013502			MOV	@(5)+,R2	:SET-UP WIDTH
2176	010206	112720	000015		MOV B	#15,(R0)+	:LOAD 'CR'
2177	010212	112720	000012		MOV B	#12,(R0)+	:LOAD 'LF'
2178	010216	110120		LICA:	MOV B	R1,(0)+	:SAVE A CHARACTER IN THE BUFFER
2179	010220	005201			INC	R1	:UPDATE THE CHARACTER
2180	010222	023701	001310		CMP	LASTCH,R1	:TEST FOR
2181	010226	001002			BNE	LICB	:BRANCH IF NOT
2182	010230	012701	000040		MOV	#40,R1	:MAKE A LEGAL CHARACTER
2183	010234	005302		LICB:	DEC	R2	:DECREMENT COUNT
2184	010236	001367			BNE	LICA	:BRANCH IF NOT COMPLETED
2185	010240	112710	000377		MOV B	#377,(R0)	:LOAD TERM
2186	010244	000205			RTS	R5	:EXIT
2187							
2188							
2189							
2190							
2191	010246	012700	026346	XPRNT:	MOV	#BUFFER,R0	:SETUP BUFFER POINTER
2192	010252	105777	171024	XPRNTA:	TST B	@VTOS	:TEST READY
2193	010256	100404			BMI	XPRNTB	:BRANCH IF SET
2194	010260	005777	171016		TST	@VTOS	:TEST ERROR
2195	010264	100372			BPL	XPRNTA	:BRANCH IF RESET
2196	010266	104001			ERROR	1	:ERROR FLAG SET ON TRANSMITTER STATUS
2197	010270	112001		XPRNTB:	MOV B	(0)+,R1	
2198	010272	100563			BMI	1\$:BR IF MINUS
2199	010274	122701	000033	5\$:	CMP B	#33,R1	:TEST FOR ESC
2200	010300	001003			BNE	3\$:BR IF NOT
2201	010302	005237	010674		INC	ANESC	:SET SOFT FLAG
2202	010306	000402			BR	4\$	
2203	010310	005037	010674	3\$:	CLR	ANESC	:CLEAR SOFT FLAG
2204	010314	110177	170764	4\$:	MOV B	R1,@VTOB	:LOAD CHAR
2205	010320	105777	170752		TST B	@VTIS	:TEST INPUT FLAG
2206	010324	100352			BPL	XPRNTA	:BR IF CLEARED
2207	010326	005737	010674		TST	ANESC	:TEST IF ESC
2208	010332	001347			BNE	XPRNTA	
2209	010334	013737	001254	013664	52\$:	MOV	TIME0,TIME1
2210	010342	005037	013666		CLR	TIME2	:LOAD DELAY
2211	010346	105777	170724	2\$:	TST B	@VTIS	:TEST IF INPUT FLAG
2212	010352	100407			BMI	53\$:BR IF SET
2213	010354	005337	013666		DEC	TIME2	:DELAY
2214	010360	001372			BNE	2\$	
2215	010362	005337	013664		DEC	TIME1	:DELAY
2216	010366	001367			BNE	2\$	
2217	010370	000440			BR	60\$:REPORT ERROR
2218	010372	005737	010676	53\$:	TST	IGNORE	:IGNORE KEYBOARD CHARACTERS ?

```
2219 010376 001104          BNE      15$          ;BR IF YES
2220 010400 017737 170674 001126  MOV      @VTIB,$BDDAT ;READ CHAR
2221 010406 042737 177600 001126  BIC      #177600,$BDDAT ;MASK
2222 010414 022737 000021 001126  CMP      #XON,$BDDAT  ;TEST FOR X ON
2223 010422 001003          BNE      50$
2224 010424 005237 010672          INC      XONRC        ;SET FLAG
2225 010430 000710          BR       XPRNTA       ;START AGAIN
2226 010432 022737 000023 001126 50$:  CMP      #XOFF,$BDDAT ;TEST FOR X OFF
2227 010440 001020          BNE      51$          ;BR IF NOT
2228 010442 005237 010670          INC      XOFFRC
2229 010446 005737 010664          TST      XOFFOK
2230 010452 001730          BEQ      52$          ;XOFF ENABLED ?
2231 010454 012737 000001 010666  MOV      #1,AXOFF     ;SET X OFF SOFT FLAG
2232 010462 005737 010662          TST      XOFFBR
2233 010466 001271          BNE      XPRNTA       ;TEST
2234 010470 000721          BR       XPRNTA       ;BR BACK
2235 010472 012737 000000 001124 60$:  MOV      #0,$GDDAT    ;BR
2236 010500 000437          BR       13$
2237 010502 105777 170432          51$:  TSTB    @SWR          ;TEST SWR
2238 010506 100371          BPL      60$          ;BR IF CLEARED
2239 010510 012737 000057 001124  MOV      #'/, $GDDAT  ;LOAD EXPECTED
2240 010516 023737 001124 001126  CMP      $GDDAT,$BDDAT ;COMPARE
2241 010524 001437          BEQ      14$          ;BR IF EQUAL
2242 010526 012737 000134 001124  MOV      #'\", $GDDAT ;LOAD EXPECTED
2243 010534 023737 001124 001126  CMP      $GDDAT,$BDDAT ;COMPARE
2244 010542 001016          BNE      13$          ;BR IF NOT
2245
2246                               ;'\'' OR LOOP EXIT
2247
2248 010544 012737 000001 010660  MOV      #1,LOOP      ;SET SOFT FLAG
2249 010552 012737 020317 010716  MOV      #MQ0,FINDTA  ;SETUP MESSAGE
2250 010560 005037 010662          16$:  CLR      XOFFBR
2251 010564 005037 010664          CLR      XOFFOK
2252 010570 005037 010676          CLR      IGNORE
2253 010574 000137 010706          JMP      FINDOT
2254
2255 010600 005737 010676          13$:  TST      IGNORE      ;IGNORE INPUT CHARACTER
2256 010604 001001          BNE      15$
2257 010606 104004          ERROR    4           ;UNEXPECTED OR INCORRECT INPUT FLAG
2258 010610 000240          15$:  NOP
2259 010612 000240          NOP
2260 010614 000240          NOP
2261 010616 000240          NOP
2262 010620 000137 010252          JMP      XPRNTA
2263
2264                               ;'''' OR STANDARD EXIT
2265
2266 010624 005037 010660          14$:  CLR      LOOP
2267 010630 012737 020404 010716  MOV      #MQ1,FINDTA  ;SETUP MESSAGE
2268 010636 000137 010560          JMP      16$
2269
2270                               ;NORMAL EXIT
2271
2272 010642 005037 010664          1$:  CLR      XOFFOK
2273 010646 005037 010676          CLR      IGNORE
2274 010652 005037 010662          CLR      XOFFBR
```

```
2275 010656 000207          RTS      PC          ;EXIT
2276
2277 010660 000000          LOOP:    0
2278 010662 000000          XOFFBR: 0
2279 010664 000000          XOFFOK: 0
2280 010666 000000          AXOFF:  0
2281 010670 000000          XOFFRC: 0
2282 010672 000000          XONRC:  0
2283 010674 000000          ANESC:  0
2284 010676 000000          IGNORE: 0          ;WHEN SET IGNORE KEYBOARD FLAGS
2285
2286          ;DETERMINE THE TEST TO GO TO
2287 010700 004537 011454      FNDA:    JSR      R5,AMSG
2288 010704 020472          MQ2
2289 010706 012706 001100      FINDOT: MOV      #STACK,SP          ;ERROR ASK AGAIN
2290 010712 004537 011454          JSR      R5,AMSG
2291 010716 020404          FINDTA: MQ1
2292 010720 004737 013612          JSR      PC,GETCHR
2293 010724 000770          BR      FINDOT
2294 010726 042700 100600          BIC      #100600,R0          ;MASK
2295 010732 122700 000101          CMPB    #'A,R0          ;TEST FOR NUMBER
2296 010736 101360          BHI     FNDA
2297 010740 122700 000132          CMPB    #'Z,R0          ;TEST FOR OTHERS
2298 010744 103755          BLO     FNDA
2299 010746 042700 177740          BIC      #177740,R0          ;MAKE 0-32
2300 010752 005300          DEC     R0
2301 010754 110037 001102          MOVB    R0,$STSTM          ;LOAD THAT TEST #
2302 010760 006300          ASL     R0
2303 010762 005760 011006          TST     DSPCH(R0)          ;TEST IF VALID
2304 010766 001744          BEQ     FNDA          ;BR IF NOT
2305 010770 000240          NOP
2306 010772 000240          NOP
2307 010774 016037 011006 001106      MOV     DSPCH(R0),$LPADR          ;LOAD LOOP ADDRESS
2308 011002 000170 011006          JMP     @DSPCH(R0)          ;GO TO THAT TEST
2309
2310          ;SUBTEST DISPATCH TABLE
2311
2312 011006 002044      DSPCH:  TST1+2
2313 011010 002470          TST2+2
2314 011012 002510          TST3+2
2315 011014 002564          TST4+2
2316 011016 002664          TST5+2
2317 011020 002766          TST6+2
2318 011022 003430          TST7+2
2319 011024 004000          TST10+2
2320 011026 004156          TST11+2
2321 011030 004304          TST12+2
2322 011032 004342          TST13+2
2323 011034 005102          TST14+2
2324 011036 005252          TST15+2
2325 011040 005364          TST16+2
2326 011042 005534          TST17+2
2327 011044 005570          TST20+2
2328 011046 005660          TST21+2
2329 011050 006012          TST22+2
2330 011052 006146          TST23+2
```


2331 011054 006270
2332 011056 006346
2333 011060 006460
2334 011062 006514
2335 011064 007110
2336 011066 007404
2337 011070 010110
2338
2339

TST24+2
TST25+2
TST26+2
TST27+2
TST30+2
TST31+2
TST32+2

;SUBROUTINE TO LOAD COPIER TEST

2341 011072 012700 026346
2342 011076 112720 000015
2343 011102 112720 000012
2344 011106 112720 000105
2345 011112 112720 000105
2346 011116 112720 000105
2347 011122 013702 001320
2348 011126 163702 001270
2349 011132 005302
2350 011134 112720 000040
2351 011140 005302
2352 011142 100374
2353 011144 112720 000105
2354 011150 112720 000105
2355 011154 112720 000105
2356 011160 112710 000377
2357 011164 000207
2358
2359

FIRLST: MOV #BUFFER,R0
MOV #15,(R0)+ ;LOAD CR
MOVB #12,(R0)+ ;LOAD LF
MOVB #'E,(R0)+
MOVB #'E,(R0)+
MOVB #'E,(R0)+
MOV WIDTH,R2 ;LOAD WIDTH
SUB VH1,R2
DEC R2
1\$: MOVB #40,(R0)+ ;LOAD A SPACE
DEC R2 ;DONE ?
BPL 1\$;BR UNTIL DONE
MOVB #'E,(R0)+
MOVB #'E,(R0)+
MOVB #'E,(R0)+ ;LOAD 80 TH
MOVB #377,(R0) ;LOAD TERM
RTS PC ;EXIT

;SUBROUTINE FOR THE DATA PATH TEST

2361 011166 012700 026346
2362 011172 012501
2363 011174 012502
2364 011176 013703 001320
2365 011202 006203
2366 011204 112720 000015
2367 011210 112720 000012
2368 011214 110120
2369 011216 110220
2370 011220 005303
2371 011222 100374
2372 011224 112710 000377
2373 011230 000205
2374
2375

DTPSR: MOV #BUFFER,R0
DTPSRB: MOV (5)+,R1 ;GET FIRST CHARACTER
MOV (5)+,R2 ;GET SECOND CHARACTER
MOV WIDTH,R3 ;SET THE WIDTH
ASR R3 ;DIVIDE BY 2
MOVB #15,(R0)+ ;LOAD 'CR'
MOVB #12,(R0)+ ;LOAD 'LF'
DTPSRA: MOVB R1,(0)+
MOVB R2,(0)+
DEC R3
BPL DTPSRA
2372: MOVB #377,(R0) ;LOAD TERM
RTS R5

;SUBROUTINE TO LOAD BUFFER WITH GRAPHICS CHARACTERS

2377 011232 012700 026346
2378 011236 012701 000136
2379 011242 010402
2380 011244 110120
2381 011246 005201
2382 011250 122701 000177
2383 011254 001002
2384 011256 012701 000136
2385 011262 005302
2386 011264 001367

GBBUF: MOV #BUFFER,R0 ;LOAD BUFFER ADDRESS
MOV #136,R1 ;LOAD INITIAL CHAR.
MOV R4,R2 ;LOAD BUFFER COUNT
1\$: MOVB R1,(R0)+ ;INSERT A CHAR. IN THE BUFFER
INC R1 ;INCREMENT CHAR.
CMPB #177,R1 ;AT END OF GRAPHICS STRING?
BNE 2\$;NO
MOV #136,R1 ;YES-RESET IT TO 1ST GRAPH. CHAR.
2\$: DEC R2 ;DECREMENT BUFFER COUNT.
BNE 1\$;NOT AT END-LOOP

```
2387 011266 112710 000377      MOVB  #377,(R0)      ;END OF BUFFER-INSERT TERMINATOR
2388 011272 000207      RTS    PC            ;AND EXIT.
2389
2390      ;PROGRAM DELAY ROUTINE
2391
2392 011274 013737 001256 011376 DELAY:  MOV    SUBTST,10$      ;LOAD COUNT
2393 011302 005037 011400      CLR    11$
2394 011306 005737 001332      TST    WFTST        ;TEST IF W.F. MODE
2395 011312 001413      BEQ    2$           ;BR IF NOT
2396 011314 006237 011376      ASR    10$         ;CHANGE DELAY TIMER
2397 011320 006237 011376      ASR    10$
2398 011324 006237 011376      ASR    10$
2399 011330 000240      NOP
2400 011332 000240      NOP
2401 011334 000240      NOP
2402 011336 000240      NOP
2403 011340 000240      NOP
2404 011342 032777 010000 167570 2$:  BIT    #BIT12,@SWR   ;TEST SR
2405 011350 001006      BNE    3$           ;BR IF SET
2406 011352 005337 011400      DEC    11$         ;DELAY
2407 011356 001371      BNE    2$
2408 011360 005337 011376      1$:  DEC    10$
2409 011364 100375      BPL    1$           ;DELAY
2410 011366 000240      3$:  NOP
2411 011370 000240      NOP
2412 011372 000240      NOP
2413 011374 000207      RTS    PC            ;EXIT
2414
2415 011376 000002      10$:  2
2416 011400 000000      11$:  0
2417
2418 011402 013737 001256 011450 ADELAY: MOV    SUBTST,10$
2419 011410 005037 011452      CLR    11$
2420 011414 006237 011450      ASR    10$
2421 011420 006237 011450      ASR    10$
2422 011424 005337 011452      2$:  DEC    11$
2423 011430 001375      BNE    2$
2424 011432 005337 011450      DEC    10$
2425 011436 100372      BPL    2$
2426 011440 000240      NOP
2427 011442 000240      NOP
2428 011444 000240      NOP
2429 011446 000207      RTS    PC
2430 011450 000000      10$:  0
2431 011452 000000      11$:  0
2432
2433
2434      ;HEADER SUBROUTINE FOR VT50 AND VT52
2435
2436 011454 012537 011464      AMSG:  MOV    (R5)+,10$      ;GET POINTER
2437 011460 004537 013670      1$:  JSR    R5,MT0B        ;MOVE TO BUFFER
2438 011464 000000      10$:  0
2439 011466 004737 010246      11$:  JSR    PC,XPRNT      ;DISPLAY IT
2440 011472 000205      RTS    R5            ;EXIT
2441
2442
```

```

2443          ;OCTAL - 3 BIT CONVERSION
2444
2445 011474 010001          OCTAL:  MOV    R0,R1          ;LOAD R1
2446 011476 042701 177770  BIC    #177770,R1        ;MASK
2447 011502 062701 000060  ADD    #60,R1
2448 011506 110137 011570  MOV    R1,DIG2          ;SAVE LSD
2449 011512 010001          MOV    R0,R1
2450 011514 006001          ROR    R1
2451 011516 006001          ROR    R1
2452 011520 006001          ROR    R1
2453 011522 042701 177770  BIC    #177770,R1
2454 011526 062701 000060  ADD    #60,R1
2455 011532 110137 011566  MOV    R1,DIG1          ;SAVE IT
2456 011536 010001          MOV    R0,R1
2457 011540 006101          ROL    R1
2458 011542 006101          ROL    R1
2459 011544 000301          SWAB   R1
2460 011546 042701 177770  BIC    #177770,R1
2461 011552 062701 000060  ADD    #60,R1
2462 011556 110137 011564  MOV    R1,DIG0          ;SAVE MSD
2463 011562 000207          RTS     PC              ;EXIT
2464
2465 011564 000000          DIG0:  0
2466 011566 000000          DIG1:  0
2467 011570 000000          DIG2:  0
2468
2469          ;SUBROUTINE FOR THE KEYBOARD CHARACTER TEST
2470 011572 103403          TSTROW: BCS   BYPASS      ;BYPASS HEADER MESSAGE IF FLAG IS SET
2471 011574 004537 011454  JSR    R5,AMSG          ;DISPLAY HEADER
2472 011600 015071          MKBA
2473 011602 000241          BYPASS: CLC           ;CLEAR FLAG
2474 011604 004737 013612  1$:   CALL   GETCHR        ;GET A CHARACTER
2475 011610 000775          BR     1$             ;WAIT FOR INPUT
2476 011612 004737 012010  CALL   PARITY         ;ADJUST CHAR IF PARITY
2477 011616 120037 012000  CMPB   R0,100$        ;CMP EXPCT AND RCVD
2478 011622 001003          BNE    2$             ;TYPE ERROR INFO
2479 011624 005722          TST    (R2)+
2480 011626 100366          BPL    1$             ;LOOP TILL DONE
2481 011630 000207          RETURN              ;EXIT TEST
2482
2483          ;COME HERE IF EXPECTED NOT EQUAL TO RECVD
2484          ;CONVERT RESULTS TO OCTAL FOR TYPEOUT
2485
2486 011632 010037 001126          2$:   MOV    R0,$BDDAT      ;LOAD BAD CHARACTER
2487 011636 004737 011474          JSR    PC,OCTAL        ;CONVERT TO OCTAL
2488 011642 113737 011564 016616  MOV    DIG0,MKBQB      ;LOAD OCTAL #
2489 011650 113737 011566 016617  MOV    DIG1,MKBQB+1
2490 011656 113737 011570 016620  MOV    DIG2,MKBQB+2
2491 011664 042700 177600          BIC    #177600,R0
2492 011670 120027 000040          CMPB   R0,#40         ;TEST IF PRINTABLE
2493 011674 101002          BHI    10$           ;BR IF PRINTABLE
2494 011676 112700 000056          MOV    #56,R0         ;CONVERT TO A '*' CHARACTER
2495 011702 110037 016612          10$:  MOV    R0,MKBQ2        ;SAVE CHAR
2496 011706 011200          MOV    (R2),R0        ;GET GOOD CHAR
2497 011710 053700 012006          BIS    MASK2,R0
2498 011714 010037 001124          MOV    R0,$GDDAT      ;LOAD GOOD CHARACTER
  
```

2499	011720	004737	011474		JSR	PC,OCTAL		:CONVERT IT
2500	011724	113737	011564	016577	MOV B	DIG0,MKBQA		:LOAD DIGIT
2501	011732	113737	011566	016600	MOV B	DIG1,MKBQA+1		
2502	011740	113737	011570	016601	MOV B	DIG2,MKBQA+2		
2503	011746	042700	177600		BIC	#177600,R0		
2504	011752	110037	016573		MOV B	R0,MKBQ1		:SAVE CHAR
2505	011756	023737	001276	001144	CMP	VTIS,\$TKS		:TEST IF ON CTY
2506	011764	001403			BEQ	3\$:BR IF YES
2507	011766	004537	011454		JSR	R5,AMSG		:DISPLAY ERROR MESSAGE
2508	011772	016532			MKBQ			
2509	011774	104004		3\$:	ERROR	4		:CHARACTER RECVD NOT EQUAL TO EXPECTED
2510	011776	000702			BR	1\$:BRANCH BACK AND TEST THE CHARACTER AGAIN
2511	012000	000000		100\$:	0			
2512	012002	000000		101\$:	0			
2513	012004	177600		MASK1:	177600			
2514	012006	000000		MASK2:	0			
2515								
2516								
2517								
2518								
2519								
2520								
2521								
2522								
2523								
2524								
2525								
2526	012010	012737	177600	012004	PARITY:	MOV #177600,MASK1		
2527	012016	005037	012006		CLR	MASK2		
2528	012022	032777	000004	167110	BIT	#BIT2,@SWR		:TEST SWR
2529	012030	001416			BEQ	4\$:DO NOT TEST PARITY BIT
2530	012032	042737	000200	012004	BIC	#BIT7,MASK1		:ENABLE PARITY BIT
2531	012040	032777	000002	167072	BIT	#BIT1,@SWR		:TEST IF FORCED PARITY
2532	012046	001417			BEQ	5\$:BR IF NOT FORCED PARITY BIT
2533	012050	032777	000001	167062	BIT	#BIT0,@SWR		:TEST FOR EVEN/ODD PARITY
2534	012056	001403			BEQ	4\$:BR IF ALWAYS OFF
2535	012060	052737	000200	012006	BIS	#BIT7,MASK2		:SET BIT 7
2536	012066	111237	012000		4\$:	MOV B (R2),100\$:GET EXPECTED
2537	012072	053737	012006	012000	BIS	MASK2,100\$:SET BIT 7 IF EXPECTED
2538	012100	043700	012004		BIC	MASK1,R0		:MASK VALUE READ
2539	012104	000207			RETURN			:EXIT ROUTINE
2540	012106	005037	012002		5\$:	CLR 101\$:CLEAR TEMP
2541	012112	111237	012000		MOV B	(R2),100\$:CLEAR CHAR SAVE
2542	012116	006037	012000		20\$:	ROR 100\$:ROTATE CHAR
2543	012122	103002			BCC	21\$:BR IF NO CARRY
2544	012124	005237	012002		INC	101\$:UPDATE CNT
2545	012130	105737	012000		21\$:	TSTB 100\$:DONE ?
2546	012134	001370			BNE	20\$:BR IF NOT
2547	012136	032777	000001	166774	BIT	#BIT0,@SWR		:TEST EVEN/ODD
2548	012144	001407			BEQ	23\$:BR IF OPER. SAYS EVEN
2549	012146	006037	012002		ROR	101\$		
2550	012152	103403			BCS	22\$:BR IF ODD ALREADY
2551	012154	052737	000200	012006	BIS	#BIT7,MASK2		:SET PARITY BIT
2552	012162	000741			22\$:	BR 4\$:BR TO TEST CHAR
2553	012164	006037	012002		23\$:	ROR 101\$		
2554	012170	103003			BCC	24\$:BR IF EVEN ALREADY

```

2555 012172 052737 000200 012006      BIS      #BIT7,MASK2
2556 012200 000732      24$:    BR      4$      ;BR TO TEST CHAR
2557
2558      ;ROUTINE TO TEST THE KEYPAD INPUTS.
2559      ;STORES THE RECEIVED DATA IN 'HOLD' AND THE EXPECTED DATA IN
2560      ;'GOOD'. INVOKES TSTDAT TO COMPARE THE KEY VALUES.
2561 012202      TSTKPS:
2562 012202 010146      MOV      R1,-(SP)      ;;PUSH R1 ON STACK
2563 012204 010346      MOV      R3,-(SP)      ;;PUSH R3 ON STACK
2564 012206 010446      MOV      R4,-(SP)      ;;PUSH R4 ON STACK
2565 012210 010546      MOV      R5,-(SP)      ;;PUSH R5 ON STACK
2566 012212 012703 026304      70$:    MOV      #HOLD,R3      ;INITIALIZE POINTER TO RCVD DATA
2567 012216 010237 026344      MOV      R2,RETRY      ;SAVE TABLE POINTER FOR EXPECTED DATA
2568 012222 004737 013612      71$:    CALL     GETCHR      ;GET INPUT-RETURN WITH RCVD IN R0
2569 012226 000775      BR      71$      ;LOOP IF NONE
2570 012230 042700 177600      BIC      #177600,R0      ;STRIP PARITY BIT FROM CHARACTER IF ANY
2571 012234 120027 000033      CMPB    R0,#33      ;IS FIRST CHARACTER 33?
2572 012240 001402      BEQ     40$      ;BRANCH IF RCVD IS NOT SINGLE-CHARACTER
2573
2574      ;PROCESSING FOR SINGLE-CHARACTER RCVD DATA
2575 012242 110023      MOVB    R0,(R3)+      ;STORE CHARACTER IN HOLD
2576 012244 000422      BR      DELIM      ;BRANCH TO PUT ON DELIMITER
2577
2578 012246 110023      ;PROCESSING IF MORE THAN A SINGLE-CHARACTER RCVD SEQUENCE
2579 012250 004737 013612      40$:    MOVB    R0,(R3)+      ;STORE 1ST CHARACTER IN HOLD
2580 012254 000775      41$:    CALL     GETCHR      ;GET 2ND CHARACTER
2581 012256 042700 177600      BR      41$      ;LOOP IF NONE
2582 012262 120027 000077      BIC      #177600,R0      ;STRIP PARITY BIT FROM CHARACTER IF ANY
2583 012266 001402      CMPB    R0,#77      ;IS INPUT A THREE-CHARACTER SEQUENCE?
2584      BEQ     42$      ;BRANCH FOR A THREE-CHARACTER SEQUENCE
2585 012270 110023      ;PROCESSING FOR TWO-CHARACTER RCVD DATA
2586 012272 000407      MOVB    R0,(R3)+      ;STORE 2ND CHARACTER IN HOLD
2587      BR      DELIM      ;BRANCH TO PUT ON DELIMITER
2588 012274 110023      ;PROCESSING FOR THREE-CHARACTER RCVD DATA
2589 012276 004737 013612      42$:    MOVB    R0,(R3)+      ;STORE 2ND CHARACTER IN HOLD
2590 012302 000775      43$:    CALL     GETCHR      ;GET 3RD CHARACTER
2591 012304 042700 177600      BR      43$      ;LOOP IF NONE
2592 012310 110023      BIC      #177600,R0      ;STRIP PARITY BIT FROM CHARACTER IF ANY
2593 012312 112713 000377      MOVB    R0,(R3)+      ;STORE 3RD CHARACTER IN HOLD
2594      DELIM:  MOVB    #377,(R3)      ;PUT ON DELIMITER
2595 012316 012701 026324      ;PROCESSING TO STORE EXPECTED DATA
2596 012322 112221      MOV      #GOOD,R1      ;INITIALIZE POINTER TO EXPCTD DATA
2597 012324 121227 000377      72$:    MOVB    (R2)+,(R1)+      ;PUT EXPCTD DATA IN GOOD
2598 012330 001374      CMPB    (R2),#377      ;END OF KEY DATA?
2599 012332 112211      BNE     72$      ;GET REST OF KEY DATA
2600 012334 004737 012360      MOVB    (R2)+,(R1)      ;PUT ON DELIMITER
2601 012340 105712      CALL     TSTDAT      ;COMPARE THE KEY VALUES
2602 012342 001401      TSTB    (R2)      ;END OF TABLE?
2603 012344 000722      BEQ     73$      ;EXIT TEST
2604 012346      BR      70$      ;GET NEXT KEY
2605 012346 012605      73$:    MOV      (SP)+,R5      ;;POP STACK INTO R5
2606 012350 012604      MOV      (SP)+,R4      ;;POP STACK INTO R4
2607 012352 012603      MOV      (SP)+,R3      ;;POP STACK INTO R3
2608 012354 012601      MOV      (SP)+,R1      ;;POP STACK INTO R1
2609 012356 000207      RETURN
2610

```

```

2611 ;ROUTINE TO COMPARE EXPECTED AND RECEIVED KEY VALUES FOR THE KEYPAD TESTS.
2612 ;THE MNEMONIC OF THE EXPECTED KEY IS DISPLAYED.
2613 ;ENTER WITH RCVD DATA IN 'HOLD' STORAGE AREA AND EXPCTD DATA IN
2614 ;'GOOD' STORAGE AREA.
2615 012360 012703 026304 TSTDAT: MOV #HOLD,R3 ;SET DATA POINTER FOR RCVD DATA
2616 012364 012701 026324 MOV #GOOD,R1 ;SET DATA POINTER FOR EXPCTD DATA
2617 012370 010305 MOV R3,R5 ;POINTER FOR RCVD DATA
2618 012372 010104 MOV R1,R4 ;POINTER FOR EXPCTD DATA
2619 012374 121127 000377 75$: CMPB (R1),#377 ;DELIMITER YET?
2620 012400 001001 BNE CONT ;BRANCH TO CONTINUE COMPARISON IF
2621 ;/DELIMITER IS NOT DETECTED
2622 012402 000207 RETURN ;EXIT ROUTINE
2623 012404 122123 CONT: CMPB (R1)+,(R3)+ ;COMPR EXPCTD AND RCVD
2624 012406 001772 BEQ 75$
2625 ;CODE SEQUENCE ENTERED FOR ERROR CONDITION
2626 012410 013702 026344 MOV RETRY,R2 ;SAVE TABLE PTR FOR EXPCTD CHARS
2627 012414 005237 010676 INC IGNORE
2628 012420 004537 011454 JSR R5,AMSG ;REPORT ERROR
2629 012424 022766 ERCHR ;MSG. 'KEY CODE ERROR'
2630 012426 010146 MOV R1,-(SP) ;PUSH R1 ON STACK
2631 012430 010246 MOV R2,-(SP) ;PUSH R2 ON STACK
2632 012432 010346 MOV R3,-(SP) ;PUSH R3 ON STACK
2633 012434 010446 MOV R4,-(SP) ;PUSH R4 ON STACK
2634 012436 012701 026324 MOV #GOOD,R1 ;INITIALIZE PTR TO EXPCTD DATA
2635 012442 121127 000033 CMPB (R1),#33 ;DOES 1ST CHAR DENOTE A
2636 ;/MULTI-CHAR SEQUENCE?
2637 012446 001414 BEQ PROC1 ;BRANCH TO PROCESS MULTI-CHAR SEQUENCE IF EQUAL
2638 ;PROCESSING FOR ONE-CHAR SEQUENCE
2639 012450 012702 022524 MOV #KPTB0,R2 ;PTR TO TABLE OF POSSIBLE CHARS
2640 012454 012703 177777 MOV #-1,R3 ;INITIALIZE TABLE INDEX
2641 012460 005203 LOOP1: INC R3 ;STEP INDEX THRU TABLE
2642 012462 121122 CMPB (R1),(R2)+ ;COMPARE CHAR WITH TABLE
2643 ;/OF POSSIBLE VALUES
2644 012464 001375 BNE LOOP1 ;BRANCH TO COMPARE WITH NEXT CHAR IN
2645 ;/TABLE IF NOT EQUAL
2646 012466 012704 022560 MOV #TB1MNE,R4 ;INITIALIZE MNEMONIC TABLE PTR
2647 012472 004737 013050 JSR PC,INSMNE ;INSERT MNEMONIC CHAR INTO MSG
2648 012476 000434 BR MNEMSG ;BRANCH TO DISPLAY EXPCTD MNEMONIC KEY
2649 012500 105721 PROC1: TSTB (R1)+ ;INCREMENT PTR TO ACCESS 2ND CHAR
2650 012502 121127 000077 CMPB (R1),#77 ;DOES THE 2ND CHAR DENOTE A
2651 ;/THREE-CHAR ESCAPE SEQUENCE?
2652 012506 001414 BEQ PROC2 ;BRANCH FOR THREE-CHAR ESCAPE SEQUENCE
2653 ;PROCESSING FOR TWO-CHAR ESCAPE SEQUENCE
2654 012510 012702 022640 MOV #AKPTB2,R2 ;INITIALIZE PTR TO EXPCTD CHAR
2655 012514 012703 177777 MOV #-1,R3 ;INITIALIZE TABLE INDEX
2656 012520 005203 LOOP2: INC R3 ;STEP INDEX THRU TABLE
2657 012522 121122 CMPB (R1),(R2)+ ;COMPARE CHAR WITH TABLE EXPCTD CHAR
2658 012524 001375 BNE LOOP2 ;BRANCH IF NOT EQUAL
2659 012526 012704 022650 MOV #TB2MNE,R4 ;INITIALIZE MNEMONIC TABLE PTR
2660 012532 004737 013050 JSR PC,INSMNE ;INSERT MNEMONIC CHAR INTO MSG
2661 012536 000414 BR MNEMSG ;BRANCH TO DISPLAY EXPCTD MNEMONIC KEY
2662 ;PROCESSING FOR THREE-CHAR ESCAPE SEQUENCE
2663 012540 105721 PROC2: TSTB (R1)+ ;INCREMENT PTR TO ACCESS 3RD CHAR
2664 012542 012702 022542 MOV #AKPTB1,R2 ;INITIALIZE PTR TO EXPCTD CHAP
2665 012546 012703 177777 MOV #-1,R3 ;INITIALIZE TABLE INDEX
2666 012552 005203 LOOP3: INC R3 ;STEP INDEX THRU TABLE

```

```

2667 012554 121122          CMPB   (R1),(R2)+      ;COMPARE RCVD CHAR WITH TABLE EXPCTD CHAR
2668 012556 001375          BNE    LOOP3          ;CONTINUE SEARCH IF NOT EQUAL
2669 012560 012704 022560      MOV    #TB1MNE,R4     ;INITIALIZE MNEMONIC TABLE PTR
2670 012564 004737 013050      JSR    PC,INSMNE      ;INSERT MNEMONIC CHAR INTO MSG
2671 012570 004537 011454      MNEMSG: JSR   R5,AMSG  ;DISPLAY MSG
2672 012574 023011          EXPDKY ;'EXPECTED KEY MNEMONIC='
2673 012576 005237 010676      INC    IGNORE        ;MSG. 'EXPECTED KEY CODE='
2674 012602 004537 011454      JSR    R5,AMSG
2675 012606 022704          SHBE   ;MSG. 'EXPECTED KEY CODE='
2676 012610 012704 026324      MOV    #GOOD,R4      ;INITIALIZE POINTER TO 'EXPECTED KEY CODE' DATA
2677 012614 004737 013140      CALL  OUTPUT         ;DISPLAY 'EXPECTED KEY CODE' DATA
2678 012620 005237 010676      INC    IGNORE
2679 012624 004537 011454      JSR    R5,AMSG
2680 012630 022746          AWAS   ;MSG. 'BAD KEY CODE='
2681 012632 010504          MOV    R5,R4         ;MOVE RCVD PTR TO #HOLD INTO R4 FOR DISPLAY
2682 012634 004737 013140      CALL  OUTPUT         ;RCVD CHARS POINTED TO #HOLD IN R4
2683                                     ;CODE SEQUENCE ENTERED TO IDENTIFY THE BAD KEY MNEMONIC
2684 012640 012701 026304      MOV    #HOLD,R1      ;SET DATA PTR TO BAD RCVD DATA
2685                                     ;INSPECT 1ST CHAR OF BAD RCVD DATA
2686 012644 121127 000033      CMPB   (R1),#33      ;IS 1ST CHAR 33?
2687 012650 001417          BEQ    MULCHR        ;IF 1ST CHAR IS 33, BRANCH FOR MULTIPLE
2688                                     ;/CHAR PROCESSING
2689                                     ;PROCESSING TO DISPLAY BAD KEY MNEMONIC FOR SINGLE-CHAR SEQUENCE
2690 012652 012702 022524      MOV    #KPTB0,R2     ;INITIALIZE TABLE PTR
2691 012656 012703 177777      MOV    #-1,R3        ;INITIALIZE TABLE INDEX
2692 012662 121227 000000      LOOP4: CMPB  (R2),#0   ;AT END OF TABLE?
2693 012666 001456          BEQ    NOTFND        ;BRANCH TO REPORT THAT KEY CAN NOT
2694                                     ;/BE IDENTIFIED
2695                                     ;STEP INDEX THRU TABLE
2696 012670 005203          INC    R3            ;STEP INDEX THRU TABLE
2697 012672 121122          CMPB   (R1),(R2)+    ;COMPARE RCVD CHAR WITH TABLE VALUES
2698 012674 001372          BNE    LOOP4         ;CONTINUE SEARCH IF CHAR NOT FOUND
2699 012676 012704 022560      MOV    #TB1MNE,R4     ;INITIALIZE MNEMONIC TABLE PTR
2700 012702 004737 013104      JSR    PC,INSBAD      ;INSERT MNEMONIC CHAR INTO MSG
2701 012706 000442          BR    BADMNE         ;BRANCH TO DISPLAY BAD MNEMONIC KEY
2702 012710 105721          ;PROCESSING TO DETERMINE WHETHER A TWO- OR THREE-CHAR SEQUENCE
2703 MULCHR: TSTB   (R1)+   ;INCREMENT DATA PTR TO ACCESS
2704                                     ;/2ND RCVD CHAR
2705 012712 121127 000077      CMPB   (R1),#77      ;IS 2ND CHAR 77?
2706 012716 001417          BEQ    MORE          ;BRANCH TO GET 3RD CHAR IF 77
2707                                     ;PROCESSING TO DISPLAY BAD KEY MNEMONIC FOR TWO-CHAR SEQUENCE
2708 012720 012702 022640      MOV    #AKPTB2,R2     ;INITIALIZE TABLE PTR
2709 012724 012703 177777      MOV    #-1,R3        ;INITIALIZE TABLE INDEX
2710 012730 121227 000000      LOOP5: CMPB  (R2),#0   ;AT END OF TABLE?
2711 012734 001433          BEQ    NOTFND        ;BRANCH TO REPORT THAT KEY CAN NOT
2712                                     ;/BE IDENTIFIED
2713                                     ;STEP INDEX THRU TABLE
2714 012736 005203          INC    R3            ;STEP INDEX THRU TABLE
2715 012740 121122          CMPB   (R1),(R2)+    ;COMPARE RCVD CHAR WITH TABLE VALUES
2716 012742 001372          BNE    LOOP5         ;CONTINUE SEARCH IF CHAR NOT FOUND
2717 012744 012704 022650      MOV    #TB2MNE,R4     ;INITIALIZE MNEMONIC TABLE PTR
2718 012750 004737 013104      JSR    PC,INSBAD      ;INSERT MNEMONIC CHAR INTO MSG
2719 012754 000417          BR    BADMNE         ;BRANCH TO DISPLAY BAD MNEMONIC KEY
2720 012756 105721          ;PROCESSING TO DISPLAY BAD KEY MNEMONIC FOR THREE-CHAR SEQUENCE
2721 MORE:  TSTB   (R1)+   ;INCREMENT DATA PTR TO ACCESS 3RD CHAR
2722 012760 012702 022542      MOV    #AKPTB1,R2     ;INITIALIZE TABLE PTR
2723 012764 012703 177777      MOV    #-1,R3        ;INITIALIZE TABLE INDEX
2724 012770 121227 000000      LOOP6: CMPB  (R2),#0   ;AT END OF TABLE?

```

```
2723 012774 001413          BEQ     NOTFND          ;BRANCH TO REPORT THAT KEY CAN NOT
2724                                     ;/BE IDENTIFIED
2725 012776 005203          INC     R3              ;STEP INDEX THRU TABLE
2726 013000 121122          CMPB   (R1),(R2)+      ;COMPARE RCVD CHAR WITH TABLE VALUES
2727 013002 001372          BNE    LOOP6           ;CONTINUE SEARCH IF CHAR NOT FOUND
2728 013004 012704 022560    MOV    #TB1MNE,R4     ;INITIALIZE MNEMONIC TABLE PTR
2729 013010 004737 013104    JSR    PC,INSBAD      ;INSERT MNEMONIC CHAR INTO MSG
2730 013014 004537 011454    BADMNE: JSR    R5,AMSG ;DISPLAY MESSAGE
2731 013020 023046          BADKEY ;'BAD KEY MNEMONIC='
2732 013022 000403          BR     74$             ;BRANCH TO EXIT ROUTINE
2733 013024 004537 011454    NOTFND: JSR    R5,AMSG ;DISPLAY MESSAGE
2734 013030 023076          UNLKEY ;'KEY CAN NOT BE IDENTIFIED'
2735 013032          74$:
2736 013032 012604          MOV    (SP)+,R4       ;;POP STACK INTO R4
2737 013034 012603          MOV    (SP)+,R3       ;;POP STACK INTO R3
2738 013036 012602          MOV    (SP)+,R2       ;;POP STACK INTO R2
2739 013040 012601          MOV    (SP)+,R1       ;;POP STACK INTO R1
2740 013042 105777 166232    TSTB  @VTIB          ;CLEAR CONDITION CODES
2741 013046 000207          RETURN                ;RETURN TO RETRIEVE NEXT INPUT FROM KEYPAD
2742                                     ;++
2743                                     ;SUBROUTINE TO INSERT MNEMONIC INTO MESSAGE TO IDENTIFY THE EXPECTED KEY
2744                                     ;CALLING SEQUENCE: JSR    PC,INSMNE
2745                                     ;ENTRY CONDITIONS: (R3)=TABLE INDEX
2746                                     ;                   (R4)=TABLE POINTER
2747                                     ;EXIT CONDITIONS:  MNEMONIC CHAR INSERTED INTO MESSAGE
2748                                     ;--
2749 013050 006303          INSMNE: ASL    R3              ;MULTIPLY TABLE INDEX BY 4 TO GET ADDRESS
2750 013052 006303          ASL    R3              ;/DISPLACEMENT OF TABLE ENTRY
2751 013054 060304          ADD    R3,R4           ;ADD ADJ INDEX TO GET ADDRESS OF KEY CHAR
2752 013056 012703 023011    MOV    #EXPDKY,R3     ;INITIALIZE MSG ADDRESS PTR
2753 013062 112463 000030    MOVB  (R4)+,30(R3)    ;LOAD CHARS FOR EXPCTD KEY MNEMONIC INTO MSG
2754 013066 112463 000031    MOVB  (R4)+,31(R3)
2755 013072 112463 000032    MOVB  (R4)+,32(R3)
2756 013076 112463 000033    MOVB  (R4)+,33(R3)
2757 013102 000207          RTS    PC              ;TRANSFER PROGRAM CONTROL BACK TO MAIN
2758                                     ;SUBROUTINE TO INSERT MNEMONIC INTO MESSAGE TO IDENTIFY THE BAD KEY
2759 013104 006303          INSBAD: ASL    R3              ;MULTIPLY TABLE INDEX BY 4 TO GET ADDRESS
2760 013106 006303          ASL    R3              ;/DISPLACEMENT OF TABLE ENTRY
2761 013110 060304          ADD    R3,R4           ;ADD ADJ INDEX TO GET ADDRESS OF KEY CHAR
2762 013112 012703 023046    MOV    #BADKEY,R3     ;INITIALIZE MSG ADDRESS PTR
2763 013116 112463 000023    MOVB  (R4)+,23(R3)    ;LOAD CHARS FOR BAD KEY MNEMONIC INTO MSG
2764 013122 112463 000024    MOVB  (R4)+,24(R3)
2765 013126 112463 000025    MOVB  (R4)+,25(R3)
2766 013132 112463 000026    MOVB  (R4)+,26(R3)
2767 013136 000207          RTS    PC              ;TRANSFER PROGRAM CONTROL BACK TO MAIN
2768
2769
2770                                     ;ROUTINE TO OUTPUT GOOD AND BAD KEYPAD OCTAL VALUES ON SCREEN
2771                                     ;ENTER WITH ADDRESS CONTAINING CHARACTER IN R4
2772                                     OUTPUT:
2773 013140 010146          MOV    R1,-(SP)       ;;PUSH R1 ON STACK
2774 013142 005001          CLR    R1
2775 013144 112761 000040 022731 77$: MOVB  #40,OUT(R1)     ;FILL AREA WITH SPACES
2776 013152 005201          INC    R1
2777 013154 120127 000013    CMPB  R1,#13          ;FULL YET
2778 013160 001371          BNE    77$
```



```
2779 013162 012601      MOV      (SP)+,R1      ;;POP STACK INTO R1
2780 013164 112400      MOVB     (R4)+,R0      ;;SETUP KEY VALUE TO CONVERT
2781 013166 004737 011474  CALL     OCTAL        ;;DO IT
2782 013172 113737 011564 022731  MOVB     DIG0,OUT
2783 013200 113737 011566 022732  MOVB     DIG1,OUT+1
2784 013206 113737 011570 022733  MOVB     DIG2,OUT+2
2785 013214 121427 000377      CMPB     (R4),#377    ;;DELIMITER
2786 013220 001433      BEQ      76$         ;;EXIT
2787 013222 112400      MOVB     (R4)+,R0      ;;SETUP 2ND VALUE OF KEY
2788 013224 004737 011474  CALL     OCTAL        ;;DO IT
2789 013230 113737 011564 022735  MOVB     DIG0,OUT+4
2790 013236 113737 011566 022736  MOVB     DIG1,OUT+5
2791 013244 113737 011570 022737  MOVB     DIG2,OUT+6
2792 013252 121427 000377      CMPB     (R4),#377    ;;DELIMITER ?
2793 013256 001414      BEQ      76$         ;;EXIT
2794 013260 112400      MOVB     (R4)+,R0      ;;SETUP 3RD VALUE OF KEY
2795 013262 004737 011474  CALL     OCTAL
2796 013266 113737 011564 022741  MOVB     DIG0,OUT+10
2797 013274 113737 011566 022742  MOVB     DIG1,OUT+11
2798 013302 113737 011570 022743  MOVB     DIG2,OUT+12
2799 013310 005237 010676 76$:    INC     IGNORE
2800 013314 004537 011454      JSR     R5,AMSG      ;;OUTPUT VALUES ON SCREEN
2801 013320 022731      OUT
2802 013322 000207      RETURN
```

.SBTTL CONVERT BINARY TO DECIMAL AND TYPE ROUTINE

```
2803
2804
2805 *****
2806 *THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 5-DIGIT
2807 *SIGNED DECIMAL (ASCII) NUMBER AND TYPE IT. DEPENDING ON WHETHER THE
2808 *NUMBER IS POSITIVE OR NEGATIVE A SPACE OR A MINUS SIGN WILL BE TYPED
2809 *BEFORE THE FIRST DIGIT OF THE NUMBER. LEADING ZEROS WILL ALWAYS BE
2810 *REPLACED WITH SPACES.
2811 *CALL:
2812 *
2813 *      MOV      NUM,-(SP)      ;;PUT THE BINARY NUMBER ON THE STACK
2814 *      TYPDS
2815 *      ;;GO TO THE ROUTINE
2816
2817 $TYPDS:
2818      MOV      R0,-(SP)      ;;PUSH R0 ON STACK
2819      MOV      R1,-(SP)      ;;PUSH R1 ON STACK
2820      MOV      R2,-(SP)      ;;PUSH R2 ON STACK
2821      MOV      R3,-(SP)      ;;PUSH R3 ON STACK
2822      MOV      R5,-(SP)      ;;PUSH R5 ON STACK
2823      MOV      #20200,-(SP)   ;;SET BLANK SWITCH AND SIGN
2824      MOV      20(SP),R5     ;;GET THE INPUT NUMBER
2825      BPL     1$            ;;BR IF INPUT IS POS.
2826      NEG     R5            ;;MAKE THE BINARY NUMBER POS.
2827      MOVB    #'-,1(SP)     ;;MAKE THE ASCII NUMBER NEG.
2828      CLR     R0            ;;ZERO THE CONSTANTS INDEX
2829      MOV     #$DBLK,R3     ;;SETUP THE OUTPUT POINTER
2830      MOVB    #' ,(R3)+     ;;SET THE FIRST CHARACTER TO A BLANK
2831      CLR     R2            ;;CLEAR THE BCD NUMBER
2832      MOV     $DTBL(R0),R1  ;;GET THE CONSTANT
2833      SUB     R1,R5         ;;FORM THIS BCD DIGIT
2834      BLT     4$            ;;BR IF DONE
```

```
2835 013404 005202          INC      R2          ;;INCREASE THE BCD DIGIT BY 1
2836 013406 000774          BR       3$
2837 013410 060105          4$: ADD    R1,R5      ;;ADD BACK THE CONSTANT
2838 013412 005702          TST     R2          ;;CHECK IF BCD DIGIT=0
2839 013414 001002          BNE     5$          ;;FALL THROUGH IF 0
2840 013416 105716          TSTB   (SP)        ;;STILL DOING LEADING 0'S?
2841 013420 100407          BMI     7$          ;;BR IF YES
2842 013422 106316          5$: ASLB  (SP)        ;;MSD?
2843 013424 103003          BCC     6$          ;;BR IF NO
2844 013426 116663 000001 177777  MOVB   1(SP),-1(R3) ;;YES--SET THE SIGN
2845 013434 052702 000060 6$: BIS  #'0,R2      ;;MAKE THE BCD DIGIT ASCII
2846 013440 052702 000040 7$: BIS  #' ,R2      ;;MAKE IT A SPACE IF NOT ALREADY A DIGIT
2847 013444 110223          MOVB   R2,(R3)+    ;;PUT THIS CHARACTER IN THE OUTPUT BUFFER
2848 013446 005720          TST    (R0)+       ;;JUST INCREMENTING
2849 013450 020027 000010  CMP    RC,#10      ;;CHECK THE TABLE INDEX
2850 013454 002746          BLT    2$          ;;GO DO THE NEXT DIGIT
2851 013456 003002          BGT    8$          ;;GO TO EXIT
2852 013460 010502          MOV    R5,R2      ;;GET THE LSD
2853 013462 000764          BR     6$          ;;GO CHANGE TO ASCII
2854 013464 105726          8$: TSTB (SP)+      ;;WAS THE LSD THE FIRST NON-ZERO?
2855 013466 100003          BPL    9$          ;;BR IF NO
2856 013470 116663 177777 177776 9$: MOVB -1(SP),-2(R3) ;;YES--SET THE SIGN FOR TYPING
2857 013476 105013          CLRB  (R3)        ;;SET THE TERMINATOR
2858 013500 012605          MOV    (SP)+,R5   ;;POP STACK INTO R5
2859 013502 012603          MOV    (SP)+,R3   ;;POP STACK INTO R3
2860 013504 012602          MOV    (SP)+,R2   ;;POP STACK INTO R2
2861 013506 012601          MOV    (SP)+,R1   ;;POP STACK INTO R1
2862 013510 012600          MOV    (SP)+,R0   ;;POP STACK INTO R0
2863 013512 104401 013540  TYPE   ,SDBLK      ;;NOW TYPE THE NUMBER
2864 013516 016666 000002 000004  MOV    2(SP),4(SP) ;;ADJUST THE STACK
2865 013524 012616          MOV    (SP)+,(SP)
2866 013526 000002          RTI
2867 013530 023420          $DTBL: 10000.
2868 013532 001750          1000.
2869 013534 000144          100.
2870 013536 000012          10.
2871 013540 000004          $DBLK: .BLKW 4
2872
2873          ;SUBROUTINE TO FILL THE SCREEN WITH A CHARACTER
2874
2875 013550 012701 000105  FILLWC: MOV    #'E,R1      ;LOAD CHARACTER BYTE
2876 013554 004737 010144  JSR    PC,FILBUF    ;LOAD THE LINE WITH CHAR
2877 013560 013737 001266 013610  MOV    VHO,10$     ;LOAD COUNT
2878 013566 012737 000001 010664 1$: MOV    #1,XOFFOK  ;INSURE XOFF/XON CONTROL.
2879 013574 004737 010246  JSR    PC,XPRNT    ;DISPLAY THE LINE
2880 013600 005337 013610  DEC    10$
2881 013604 001370          BNE    1$          ;LOOP UNTIL DONE
2882 013606 000207          RTS    PC          ;EXIT
2883 013610 000000          10$: 0
2884
2885          ;SUBROUTINE TO GET A CHARACTER FROM THE VT50 AND VT52
2886          ;CALLED AFTER CHAR. HAS BEEN ENTERED INTO INPUT BUFFER
2887          ;RETURN IS WITH CHAR. IN R0
2888
2889 013612 013737 001254 013664  GETCHR: MOV    TIME0,TIME1 ;LOAD TIME COUNTER
2890 013620 005037 013666  CLR    TIME2
```

```
2891
2892 013624 105777 165446      1$:  TSTB  @VTIS      ;TEST INPUT STATUS
2893 013630 100005              BPL  2$           ;BR IF CLEARED
2894 013632 017700 165442      MOV  @VTIB,R0     ;READ A CHAR
2895 013636 062716 000002      ADD  #2,(SP)     ;UPDATE RETURN
2896 013642 000207              RTS   PC          ;EXIT
2897
2898 013644 005337 013666      2$:  DEC  TIME2     ;DELAY
2899 013650 001365              BNE  1$           ;FINISHED ?
2900 013652 005337 013664      DEC  TIME1       ;LOOP TILL TIME EXPIRED
2901 013656 100362              BPL  1$           ;NO INPUT FLAG FROM DEVICE
2902 013660 104002              ERROR 2          ;EXIT
2903 013662 000207              RTS   PC
2904
2905 013664 000000      TIME1: 0
2906 013666 000000      TIME2: 0
2907
2908      ;MOVE TO THE OUTPUT BUFFER
2909      ;CALLED WITH SOURCE ADDRESS OF DATA IN R5
2910      ;RETURN WITH BUFFER LOADED WITH DATA
2911
2912 013670 012500      MTOB: MOV  (R5)+,R0 ;LOAD DEST.
2913 013672 012701 026346      MOV  #BUFFER,R1  ;LOAD R1
2914 013676 112021      1$:  MOVB (R0)+,(R1)+ ;LOAD BYTE
2915 013700 100376      BPL  1$           ;OUTPUT BUFFER LOADED WHEN '377' CHAR.
2916      ;/IS ENCOUNTERED
2917 013702 000205      RTS   R5         ;EXIT
2918
```

2919
2920
2921

;ASCII MESSAGES

013704	006415	041412	053132	TITLE:	.ASCIIZ	<15><15><12>%CZVTCFO VT50A,B,H/52 ACPT%<15><12><377>
013745	015	005012	043012	M91:	.ASCIIZ	<15><12><12><12>/FULL SCREEN OF THE CHARACTER E/<15><12><377>
014013	015	005012	042012	M92:	.ASCIIZ	<15><12><12><12>/DATA PATH TEST/<15><12><377>
014041	015	005012	051412	M93:	.ASCIIZ	<15><12><12><12>/SINGLE CHARACTER PER LINE/<15><377>
014101	015	005012	051012	M94:	.ASCIIZ	<15><12><12><12>/ROTATING PATTERN/<15><12><377>
014131	015	005012	041412	M96:	.ASCIIZ	<15><12><12><12>/CURSOR MOTION TEST/<15><12><377>
014163	015	005012	052012	M97:	.ASCIIZ	<15><12><12><12>/TAB, BACKSPACE AND BELL TEST/<15><12><12><377>
014230	005015	005012	051105	M910:	.ASCIIZ	<15><12><12><12>/ERASE LINE TEST/<15><12><377>
014257	015	005012	042412	M911:	.ASCIIZ	<15><12><12><12>/ERASE SCREEN TEST/<15><12><377>
014310	005015	005012	044526	M912:	.ASCIIZ	<15><12><12><12>/VIDEO COUPLING TEST/<15><12><377>
014343	033	015510	006512	M914:	.ASCIIZ	<33><110><33><112><15><12><12>/TERMINAL IDENTIFICATION TEST/<15><12><377>
014412	005015	047503	044520	M920:	.ASCIIZ	<15><12>/COPIER PERIMETER/<15><12><377>
014440	005015	044504	041523	M921:	.ASCIIZ	<15><12>/DISCLAIMER STATEMENT/<15><12><377>
014472	005015	047510	042114	M922:	.ASCIIZ	<15><12>/HOLD SCREEN MODE TEST/<15><12><377>
014525	015	043412	040522	M9221:	.ASCIIZ	<15><12>/GRAPHICS MODE AND REV. LINE FEED TEST/<15><12><377>
014600	057433	044033	045033	M923:	.ASCIIZ	<33><137><33><110><33><112>/AUTO COPY MODE TEST/<15><12><377>
014635	033	015510	050112	MPTCNT:	.ASCIIZ	<33><110><33><112>/PRINTER CONTROLLER MODE ENTERED/<15><12><377>
014704	044033	045033	051120	MPTSCN:	.ASCIIZ	<33><110><33><112>/PRINT A SCREEN OF E'S/<15><12><377>
014741	110	045033	052501	M923A:	.ASCIIZ	<110><33><112>/AUTO PRINT MODE TEST/<15><12><377>
014774	005015	005012	042513	MKB:	.ASCII	<15><12><12><12>/KEYBOARD CHARACTER TEST/<15><12><12>
015032	042522	042514	051501	MKB1:	.ASCIIZ	/RELEASE THE 'CAPS LOCK' KEY/<15><12><377>
015071	015	046012	043105	MKBA:	.ASCIIZ	<15><12>/LEFT TO RIGHT IN A ROW, DEPRESS ONE KEY AT A TIME/<15><12><377>
015160	005015	052123	051101	MKBB:	.ASCII	<15><12>/STARTING WITH THE TOP ROW EXCEPT THE THIRD/
015234	043040	047522	020115		.ASCIIZ	/ FROM RIGHT END AND LAST KEYS/<15><12><377>
015275	015	005012	052123	MKBB2:	.ASCIIZ	<15><12><12>/STARTING WITH THE TOP ROW EXCEPT THE LAST KEY/<15><12><377>
015361	015	005012	052123	MKBC:	.ASCIIZ	<15><12><12>/START WITH THE SECOND ROW/<15><12><377>
015421	015	005012	052123	MKBD:	.ASCII	<15><12><12>/START WITH THE THIRD ROW EXCEPT THE CTRL/
015474	005015	047101	020104		.ASCIIZ	<15><12>/AND THE 'BLANK' KEYS/<15><12><377>
015526	005015	051412	040524	MKBD2:	.ASCIIZ	<15><12><12>/START WITH THE THIRD ROW, BEGIN ROW WITH 'A' KEY/<15><12><3>
015615	015	005012	052123	MKBE:	.ASCII	<15><12><12>/START WITH THE FOURTH ROW EXCEPT THE SCROLL, LEFT-SHIFT, /
015707	015	051012	043511		.ASCIIZ	<15><12>/RIGHT-SHIFT, REPEAT AND COPY KEYS/<15><12><377>
015756	005015	042012	050105	MKBF:	.ASCIIZ	<15><12><12>/DEPRESS THE SPACE BAR/<15><12><12><377>
016013	015	047012	053517	MKBG:	.ASCII	<15><12>/NOW HOLD DOWN THE 'LEFT-SHIFT' KEY/<15><12><377>
016062	005015	047012	053517	MKBGA:	.ASCII	<15><12><12>/NOW HOLD DOWN THE 'RIGHT-SHIFT' KEY/<15><12><377>
016133	015	005012	047516	MKBH:	.ASCII	<15><12><12>/NOW HOLD DOWN THE 'CTRL' KEY/<15><12><377>
016175	015	051412	040524	MKBI:	.ASCII	<15><12>/START WITH THE TOP ROW/<15><12><377>
016230	005015	052123	051101	MKBJ:	.ASCII	<15><12>/START WITH THE 2ND ROW/<15><12><377>
016263	015	051412	040524	MKBK:	.ASCII	<15><12>/START WITH THE 3RD ROW/<15><12><377>
016317	015	051412	040524	MKBL:	.ASCII	<15><12>/START WITH THE 4TH ROW/<15><12><377>
016352	005015	052123	051101	MKBM:	.ASCII	<15><12>/START WITH THE LAST ROW/<15><12><377>
016406	005015	005012	052126	MKBN:	.ASCII	<15><12><12><12>%VT50H/VT52 KEYPAD TEST IN NORMAL MODE%<15><12><12><377>
016463	015	005012	053012	MKB52:	.ASCII	<15><12><12><12>/VT52 ALTERNATE KEYPAD MODE TEST/<15><12><12><377>
016532	005015	044103	051101	MKBQ:	.ASCII	<15><12>/CHARACTER WAS IN ERROR/<15><12>
016564	047507	042117	036440		.ASCII	/GOOD = /
016573	040	040	075	MKBQ1:	.BYTE	40,40,75,40
016577	040	040	040	MKBQA:	.BYTE	40,40,40,40,40
016604	040502	020107	020075		.ASCII	/BAD = /
016612	040	040	075	MKBQ2:	.BYTE	40,40,75,40
016616	040	040	040	MKBQB:	.BYTE	40,40,40,15,12,377,0
016625	015	005012	005012	MKBR:	.ASCIIZ	<15><12><12><12><12>/KEYBOARD CHARACTER TEST COMPLETE/<15><12><377>
016676	005015	047111	040526	INVLID:	.ASCIIZ	<15><12>/INVALID BUSS ADDRESS-PLEASE RETRY/<15><12>
016744	005015	042513	041131	MKE:	.ASCII	<15><12>/KEYBOARD ASCII AND OCTAL LOOP/<15><12>
017005	015	012			.BYTE	15,12

021502 001116 001246 001330 DT3: \$ERRPC,VTNOW,SAVE4,SAVE2,SAVE3,0
 021516 001116 001246 001252 DT4: \$ERRPC,VTNOW,TSTNUM,\$GDDAT,\$BDDAT,0

.SBTTL KEYBOARD CHARACTER CODE TABLES

;THE ACTUAL KEYBOARD LAYOUT IS REQUIRED

021532 021566 021622 021660 V50RW: ROW1,ROW2,ROW3,ROW4,ROW1S,ROW1S,ROW1C
 021550 021736 021774 022032 V52RW: ROW12,ROW22,ROW32,ROW42,ROW12S,ROW12S,ROW12C

;VT50 KEYBOARD EQUIVALENCIES(UPPER CASE CHAR.)

021566 000033 000061 000062 ROW1: .WORD 33,61,62,63,64,65,66,67,70,71,60,55,75,100010
 021622 000011 000121 000127 ROW2: .WORD 11,121,127,105,122,124,131,125,111,117,120,133,134,12,100177
 021660 000101 000123 000104 ROW3: .WORD 101,123,104,106,107,110,112,113,114,73,47,100015
 021710 000132 000130 000103 ROW4: .WORD 132,130,103,126,102,116,115,54,56,100057
 021734 100040 ROW5: .WORD 100040

;VT52 KEYBOARD EQUIVALENCES(LOWER CASE CHAR.)

021736 000033 000061 000062 ROW12: .WORD 33,61,62,63,64,65,66,67,70,71,60,55,75,140,100010
 021774 000011 000161 000167 ROW22: .WORD 11,161,167,145,162,164,171,165,151,157,160,133,134,12,100177
 022032 000141 000163 000144 ROW32: .WORD 141,163,144,146,147,150,152,153,154,73,47,173,100015
 022064 000172 000170 000143 ROW42: .WORD 172,170,143,166,142,156,155,54,56,100057

;SHIFTED ROW CODES

022110 000033 000041 000100 ROW1S: .WORD 33,41,100,43,44,45,136,46,52,50,51,137,53,100010
 022144 000033 000041 000100 ROW12S: .WORD 33,41,100,43,44,45,136,46,52,50,51,137,53,176,100010

;CONTROL ROW CODES

022202 000033 000021 000022 ROW1C: .WORD 33,21,22,23,24,25,26,27,30,31,20,15,35,100010
 022236 000033 000021 000022 ROW12C: .WORD 33,21,22,23,24,25,26,27,30,31,20,15,35,0,100010

;VT52 ESCAPE SEQUENCES

022274 033 111 015 REVLf: .BYTE 33,111,015,377,0 ;REVERSE LINE FEED.
 022301 033 075 377 ENAKP: .BYTE 33,075,377,0,0 ;ENABLE ALTERNATE KEYPAD MODE.
 022306 033 076 377 EXAKP: .BYTE 33,076,377,0,0 ;EXIT ALTERNATE KEYPAD MODE
 022313 033 106 000 ENGRAF: .BYTE 33,106,0,377,0 ;ENTER GRAPHICS MODE.
 022320 033 107 000 EXGRAF: .BYTE 33,107,0,377,0 ;EXIT GRAPHICS MODE.
 022325 033 127 377 ENPNTM: .BYTE 33,127,377,0,0 ;ENABLE PRINTER CONTROLLER MODE.
 022332 033 130 377 EXPNTM: .BYTE 33,130,377,0,0 ;DISABLE PRINTER CONTROLLER MODE.

;VT50H/VT52 KEYPAD CODES IN NORMAL MODE

022340 033 120 377 KPTAB: .BYTE 33,120,-1,33,121,-1,33,122,-1,33,101,-1
 022354 067 377 070 .BYTE 67,-1,70,-1,71,-1,33,102,-1
 022365 064 377 065 .BYTE 64,-1,65,-1,66,-1,33,103,-1
 022376 061 377 062 .BYTE 61,-1,62,-1,63,-1,33,104,-1
 022407 060 377 056 .BYTE 60,-1,56,-1,15,-1,0

```

022416 033 120 377 ;VT52 KEYPAD CODES IN ALTERNATE MODE
022432 033 077 167 AKPTAB: .BYTE 33,120,-1,33,121,-1,33,122,-1,33,101,-1
022451 033 077 164 .BYTE 33,77,167,-1,33,77,170,-1,33,77,171,-1,33,102,-1
022470 033 077 161 .BYTE 33,77,164,-1,33,77,165,-1,33,77,166,-1,33,103,-1
022507 033 077 160 .BYTE 33,77,161,-1,33,77,162,-1,33,77,163,-1,33,104,-1
                                .BYTE 33,77,160,-1,33,77,156,-1,33,77,115,-1,0
;KEYPAD CODES FOR ONE-CHAR SEQUENCES IN NORMAL MODE
022524 060 061 062 .EVEN
                                KPTB0: .BYTE 60,61,62,63,64,65,66,67,70,71,56,15,0
;ALTERNATE KEYPAD MODE TABLES TO IDENTIFY MNEMONICS OF KEYPAD CHARACTERS
022542 022542 161 162 .EVEN
                                AKPTB1: .BYTE 160,161,162,163,164,165,166,167,170,171,156,115,0
022560 020060 020040 .EVEN
                                TB1MNE: .ASCII /0 /
022564 020061 020040 .ASCII /1 /
022570 020062 020040 .ASCII /2 /
022574 020063 020040 .ASCII /3 /
022600 020064 020040 .ASCII /4 /
022604 020065 020040 .ASCII /5 /
022610 020066 020040 .ASCII /6 /
022614 020067 020040 .ASCII /7 /
022620 020070 020040 .ASCII /8 /
022624 020071 020040 .ASCII /9 /
022630 020056 020040 .ASCII / /
022634 047105 051124 .ASCII /ENTR/
022640 101 102 103 AKPTB2: .BYTE 101,102,103,104,120,121,122
                                .EVEN
                                TB2MNE: .ASCII /UP /
                                .ASCII /DOWN/
                                .ASCII /RGHT/
                                .ASCII /LEFT/
                                .ASCII /L BL/
                                .ASCII /C BL/
                                .ASCII /R BL/
022650 050125 020040 SHBE: .ASCII <15><12>/EXPECTED KEY CODE=/<377>
022654 047504 047127 OUT: .ASCII / /
022660 043522 052110 AWAS: .ASCII <15><12>/BAD KEY CODE=/<377>
022664 042514 052106 ERCHR: .ASCII <15><12><12>/KEY CODE ERROR/<377>
022670 020114 046102 EXPDKY: .ASCII <15><12>/EXPECTED KEY MNEMONIC= /<377>
022674 020103 046102 BADKEY: .ASCII <15><12>/BAD KEY MNEMONIC= /<377>
022700 020122 046102 UNLKEY: .ASCII <15><12>/KEY CAN NOT BE IDENTIFIED/<15><12><377>
022704 005015 054105 INSTR: .ASCII /START TOP ROW LEFT TO RIGHT/<15><12>
022731 040 020040 .ASCII /PROCEED TO BOTTOM ROW/<15><12><377>
022746 005015 040502 020104 MTEXT0: .ASCIIZ <15><12><12>/THIS SOFTWARE IS FURNISHED TO PURCHASER UNDER A LICENSE FOR
022766 005015 005012 042513 MTEXT1: .ASCIIZ <15><12>/ON A SINGLE COMPUTER SYSTEM AND CAN BE COPIED (WITH INCLUSION/<
023011 015 042412 050130 MTEXT2: .ASCIIZ <15><12>/OF DEC'S COPYRIGHT NOTICE) ONLY FOR USE IN SUCH SYSTEM, EXCEPT/
023046 005015 040502 020104 MTEXT3: .ASCIIZ <15><12>/AS MAY OTHERWISE BE PROVIDED IN WRITING BY DEC./<377>
023076 005015 042513 020131 MTEXT4: .ASCIIZ <15><12><12>/THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHO
023134 052123 051101 020124 MTEXT5: .ASCIIZ <15><12>/NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL/<
023171 120 047522 042503 MTEXT6: .ASCIIZ <15><12>/EQUIPMENT CORPORATION./<377>
023221 015 005012 044124 MTEXT7: .ASCIIZ <15><12><12>/DEC ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF
023325 015 047412 020116 MTEXT8: .ASCIIZ <15><12>/ITS SOFTWARE ON EQUIPMENT WHICH IS NOT SUPPLIED BY DEC./
023426 005015 043117 042040 .BYTE 15,12,377,0
023530 005015 051501 046440 .SBTTL TTY INPUT ROUTINE
023613 015 005012 044124
023715 015 047012 052117
024016 005015 050505 044525
024050 005015 042012 041505
024150 005015 052111 020123
024241 015 012 377
```

(1)


```
2922
2923
2924      ;:*****
2925      .ENABL  LSB
2926
2927      .DSABL  LSB
2928
2929      ;:*****
2930      ;*THIS ROUTINE WILL INPUT A SINGLE CHARACTER FROM THE TTY
2931      ;*CALL:
2932      ;*      RDCHR          ;;INPUT A SINGLE CHARACTER FROM THE TTY
2933      ;*      RETURN HERE   ;;CHARACTER IS ON THE STACK
2934      ;*                   ;;WITH PARITY BIT STRIPPED OFF
2935      ;*
2936      ;*
2937 024246 011646 $RDCHR: MOV      (SP),-(SP)      ;;PUSH DOWN THE PC
2938 024250 016666 000004 000002 MOV      4(SP),2(SP)      ;;SAVE THE PS
2939 024256 105777 154662 1$: TSTB    @STKS          ;;WAIT FOR
2940 024262 100375 BPL      1$          ;;A CHARACTER
2941 024264 117766 154656 000004 MOVB    @STKB,4(SP)      ;;READ THE TTY
2942 024272 042766 177600 000004 BIC     #^C<177>,4(SP)  ;;GET RID OF JUNK IF ANY
2943 024300 026627 000004 000023 CMP     4(SP),#23      ;;IS IT A CONTROL-S?
2944 024306 001013 BNE     3$          ;;BRANCH IF NO
2945 024310 105777 154630 2$: TSTB    @STKS          ;;WAIT FOR A CHARACTER
2946 024314 100375 BPL      2$          ;;LOOP UNTIL ITS THERE
2947 024316 117746 154624 MOVB    @STKB,-(SP)     ;;GET CHARACTER
2948 024322 042716 177600 BIC     #^C177,(SP)    ;;MAKE IT 7-BIT ASCII
2949 024326 022627 000021 CMP     (SP)+,#21      ;;IS IT A CONTROL-Q?
2950 024332 001366 BNE     2$          ;;IF NOT DISCARD IT
2951 024334 000750 BR      1$          ;;YES, RESUME
2952 024336 026627 000004 000140 3$: CMP     4(SP),#140      ;;IS IT UPPER CASE?
2953 024344 002407 BLT      4$          ;;BRANCH IF YES
2954 024346 026627 000004 000175 CMP     4(SP),#175     ;;IS IT A SPECIAL CHAR?
2955 024354 003003 BGT      4$          ;;BRANCH IF YES
2956 024356 042766 000040 000004 BIC     #40,4(SP)     ;;MAKE IT UPPER CASE
2957 024364 000002 4$: RTI          ;;GO BACK TO USER
2958      ;:*****
2959      ;*THIS ROUTINE WILL INPUT A STRING FROM THE TTY
2960      ;*CALL:
2961      ;*      RDLIN         ;;INPUT A STRING FROM THE TTY
2962      ;*      RETURN HERE  ;;ADDRESS OF FIRST CHARACTER WILL BE ON THE STACK
2963      ;*                   ;;TERMINATOR WILL BE A BYTE OF ALL 0'S
2964      ;*
2965 024366 010346 $RDLIN: MOV      R3,-(SP)      ;;SAVE R3
2966 024370 012703 024474 1$: MOV     #$TTYIN,R3      ;;GET ADDRESS
2967 024374 022703 024504 2$: CMP     #$TTYIN+8.,R3      ;;BUFFER FULL?
2968 024400 101405 BLOS    4$          ;;BR IF YES
2969 024402 104406 RDCHR          ;;GO READ ONE CHARACTER FROM THE TTY
2970 024404 112613 MOVB    (SP)+,(R3)      ;;GET CHARACTER
2971 024406 122713 000177 10$: CMPB   #177,(R3)      ;;IS IT A RUBOUT
2972 024412 001003 BNE     3$          ;;SKIP IF NOT
2973 024414 104401 001166 4$: TYPE    ,QUES      ;;TYPE A '?'
2974 024420 000763 BR      1$          ;;CLEAR THE BUFFER AND LOOP
2975 024422 111337 024472 3$: MOVB   (R3),9$      ;;ECHO THE CHARACTER
2976 024426 104401 024472 TYPE    ,9$
2977 024432 122723 000015 CMPB   #15,(R3)+      ;;CHECK FOR RETURN
```



```

2978 024436 001356          BNE      2$          ;;LOOP IF NOT RETURN
2979 024440 105063 177777  CLRB    -1(R3)       ;;CLEAR RETURN (THE 15)
2980 024444 104401 001170  TYPE    , $LF        ;;TYPE A LINE FEED
2981 024450 012603          MOV     (SP)+,R3     ;;RESTORE R3
2982 024452 011646          MOV     (SP),-(SP)   ;;ADJUST THE STACK AND PUT ADDRESS OF THE
2983 024454 016666 000004 000002  MOV     4(SP),2(SP)  ;; FIRST ASCII CHARACTER ON IT
2984 024462 012766 024474 000004  MOV     #$TTYIN,4(SP)
2985 024470 000002          RTI              ;;RETURN
2986 024472      000          9$: .BYTE 0          ;;STORAGE FOR ASCII CHAR. TO TYPE
2987 024473      000          .BYTE 0          ;;TERMINATOR
2988 024474 000010          $TTYIN: .BLKB 8     ;;RESERVE 8 BYTES FOR TTY INPUT
2989 024504 052536 005015      000  $CNTLU: .ASCIZ /^U/<15><12>  ;;CONTROL 'U'
2990 024511      136 006507 000012  $CNTLG: .ASCIZ /^G/<15><12>  ;;CONTROL 'G'
2991 024516 005015 053523 020122  $MSWR: .ASCIZ <15><12>/SWR = /
2992 024524 020075      000          $MNEW: .ASCIZ / NEW = /
2993 024527      040 047040 053505
2994 024534 036440 000040
2995
2996          .SBTTL READ AN OCTAL NUMBER FROM THE TTY
2997
2998          ;*****
2999          ;*THIS ROUTINE WILL READ AN OCTAL (ASCII) NUMBER FROM THE TTY AND
3000          ;*CHANGE IT TO BINARY.
3001          ;*THE INPUT CHARACTERS WILL BE CHECKED TO INSURED THEY ARE LEGAL
3002          ;*OCTAL DIGITS. IF AN ILLEGAL CHARACTER IS READ A '?' WILL BE TYPED
3003          ;*FOLLOWED BY A CARRIAGE RETURN-LINE FEED. THE COMPLETE NUMBER MUST
3004          ;*THEN BE RETYPED. THE INPUT IS TERMINATED BY TYPING A CARRIAGE RETURN.
3005          ;*CALL:
3006          ;*      RDOCT          ;;READ AN OCTAL NUMBER
3007          ;*      RETURN HERE   ;;LOW ORDER BITS ARE ON TOP OF THE STACK
3008          ;*                  ;;HIGH ORDER BITS ARE IN $HIOCT
3009 024540 011646          $RDOCT: MOV     (SP),-(SP)  ;;PROVIDE SPACE FOR THE
3010 024542 016666 000004 000002  MOV     4(SP),2(SP)  ;;INPUT NUMBER
3011 024550 010046          MOV     R0,-(SP)    ;;PUSH R0 ON STACK
3012 024552 010146          MOV     R1,-(SP)    ;;PUSH R1 ON STACK
3013 024554 010246          MOV     R2,-(SP)    ;;PUSH R2 ON STACK
3014 024556 104407          1$: RDLIN        ;;READ AN ASCII LINE
3015 024560 012600          MOV     (SP)+,R0    ;;GET ADDRESS OF 1ST CHARACTER
3016 024562 010037 024666          MOV     R0,5$      ;;AND SAVE IT
3017 024566 005001          CLR     R1          ;;CLEAR DATA WORD
3018 024570 005002          CLR     R2
3019 024572 112046          2$: MOV     (R0)+,-(SP)  ;;PICKUP THIS CHARACTER
3020 024574 001420          BEQ     3$          ;;IF ZERO GET OUT
3021 024576 122716 000060          CMPB   #'0,(SP)    ;;MAKE SURE THIS CHARACTER
3022 024602 003026          BGT     4$          ;;IS AN OCTAL DIGIT
3023 024604 122716 000067          CMPB   #'7,(SP)
3024 024610 002423          BLT     4$
3025 024612 006301          ASL    R1          ;;*2
3026 024614 006102          ROL    R2
3027 024616 006301          ASL    R1          ;;*4
3028 024620 006102          ROL    R2
3029 024622 006301          ASL    R1          ;;*8
3030 024624 006102          ROL    R2
3031 024626 042716 177770          BIC    #'C7,(SP)   ;;STRIP THE ASCII JUNK
3032 024632 062601          ADD    (SP)+,R1    ;;ADD IN THIS DIGIT
3033 024634 000756          BR     2$          ;;LOOP

```

```
3034 024636 005726          3$:  TST      (SP)+      ;;CLEAN TERMINATOR FROM STACK
3035 024640 010166 000012    MOV      R1,12(SP)      ;;SAVE THE RESULT
3036 024644 010237 024676    MOV      R2,$HIOCT
3037 024650 012602          MOV      (SP)+,R2      ;;POP STACK INTO R2
3038 024652 012601          MOV      (SP)+,R1      ;;POP STACK INTO R1
3039 024654 012600          MOV      (SP)+,R0      ;;POP STACK INTO R0
3040 024656 000002          RTI
3041 024660 005726          4$:  TST      (SP)+      ;;CLEAN PARTIAL FROM STACK
3042 024662 105010          CLR      (R0)          ;;SET A TERMINATOR
3043 024664 104401          TYPE
3044 024666 000000          ;;TYPE UP THRU THE BAD CHAR.
3045 024670 104401 001166    5$:  .WORD    0
3046 024674 000730          TYPE    $QUES        ;; '?' 'CR' & 'LF'
3047 024676 000000          BR      1$           ;; TRY AGAIN
3048 024700 105777 154234    $HIOCT: .WORD    0      ;; HIGH ORDER BITS GO HERE
3049 024704 100003          MSCOPE: TSTB    @SWR    ;; TEST BIT 7
3050 024706 005737 010660    BPL     $SCOPE       ;; NOT SET
3051 024712 001041          TST     LOOP        ;; TEST LOOP
3052          BNE     $OVER      ;; SET LOOP ON TEST
3053
3054          .SBTTL  SCOPE HANDLER ROUTINE
3055          ;*****
3056          ;*THIS ROUTINE CONTROLS THE LOOPING OF SUBTESTS. IT WILL INCREMENT
3057          ;*AND LOAD THE TEST NUMBER($TSTNM) INTO THE DISPLAY REG.(DISPLAY<7:0>)
3058          ;*AND LOAD THE ERROR FLAG ($ERFLG) INTO DISPLAY<15:08>
3059          ;*THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
3060          ;*SW14=1      LOOP ON TEST
3061          ;*SW08=1      LOOP ON TEST IN SWR<7:0>
3062          ;*CALL
3063          ;*          SCOPE          ;;SCOPE=IOT
3064
3065 024714          $SCOPE:
3066 024714 032777 040000 154216 1$:  BIT      #BIT14,@SWR    ;;LOOP ON PRESENT TEST?
3067 024722 001035          BNE     $OVER        ;;YES IF SW14=1
3068          ;####START OF CODE FOR THE XOR TESTER####
3069 024724 000416          $XTSTR: BR      6$
3070          ;;IF RUNNING ON THE 'XOR' TESTER CHANGE
3071 024726 013746 000004          MOV     @ERRVEC,-(SP)  ;;THIS INSTRUCTION TO A 'NOP' (NOP=240)
3072 024732 012737 024752 000004    MOV     #5,$ERRVEC    ;;SAVE THE CONTENTS OF THE ERROR VECTOR
3073 024740 005737 177060          TST     @177060      ;;SET FOR TIMEOUT
3074 024744 012637 000004          MOV     (SP)+,@ERRVEC ;;TIME OUT ON XOR?
3075 024750 000414          BR      $SVLAD       ;;RESTORE THE ERROR VECTOR
3076 024752 022626          5$:  CMP     (SP)+,(SP)+  ;;GO TO THE NEXT TEST
3077 024754 012637 000004          MOV     (SP)+,@ERRVEC ;;CLEAR THE STACK AFTER A TIME OUT
3078 024760 000416          BR      $OVER        ;;RESTORE THE ERROR VECTOR
3079 024762          6$:;####END OF CODE FOR THE XOR TESTER####
3080 024762 032777 000400 154150    BIT     #BIT08,@SWR   ;;LOOP ON SPEC. TEST?
3081 024770 001404          BEQ     $SVLAD       ;;BR IF NO
3082 024772 127737 154142 001102    CMPB   @SWR,$TSTNM   ;;ON THE RIGHT TEST? SWR<7:0>
3083 025000 001406          BEQ     $OVER        ;;BR IF YES
3084 025002 105237 001102          $SVLAD: INCB    $TSTNM ;;COUNT TEST NUMBERS
3085 025006 011637 001106          MOV     (SP),$LPADR  ;;SAVE SCOPE LOOP ADDRESS
3086 025012 105037 001103          CLRB   $ERFLG       ;;ZERO THE ERROR FLAG
3087 025016 013777 001102 154116 $OVER: MOV     $TSTNM,@DISPLAY ;;DISPLAY TEST NUMBER
3088 025024 013716 001106          MOV     $LPADR,(SP)  ;;FUDGE RETURN ADDRESS
3089 025030 000002          RTI                ;;FIXES PS
```

3090
3091
3092
3093
3094
3095
3096
3097
3098
3099
3100
3101
3102
3103
3104
3105
3106
3107
3108
3109
3110
3111
3112
3113
3114
3115
3116
3117
3118
3119
3120
3121
3122
3123
3124
3125
3126
3127
3128
3129
3130
3131
3132
3133
3134
3135
3136
3137
3138
3139
3140
3141
3142
3143
3144
3145

025032
025032 113737 001102 001252
025040 105237 001103
025044 001775
025046 013777 001102 154066
025054 005237 001112
025060 011637 001116
025064 162737 000002 001116
025072 117737 154020 001114
025100 032777 020000 154032
025106 001004
025110 004737 025144
025114 104401 001167
025120
025120 005777 154014
02512 100001
025126 000000
025130
025130 022737 007014 000042
025136 001001
025140 000000
025142
025142 000002

.SBTTL ERROR HANDLER ROUTINE

*THIS ROUTINE WILL INCREMENT THE ERROR FLAG AND THE ERROR COUNT,
*SAVE THE ERROR ITEM NUMBER AND THE ADDRESS OF THE ERROR CALL
*AND GO TO \$ERRTYP ON ERROR
*THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
*SW15=1 HALT ON ERROR
*SW13=1 INHIBIT ERROR TYPEOUTS
*CALL
* ERROR N ;;ERROR=EMT AND N=ERROR ITEM NUMBER

\$ERROR:

MOVB \$TSTNM,TSTNUM
7\$: INCB \$ERFLG ;;SET THE ERROR FLAG
BEQ 7\$;;DON'T LET THE FLAG GO TO ZERO
MOV \$TSTNM,@DISPLAY ;;DISPLAY TEST NUMBER AND ERROR FLAG
INC \$ERTTL ;;INC THE ERROR COUNT
MOV (SP),\$ERRPC ;;GET ADDRESS OF ERROR INSTRUCTION
SUB #2,\$ERRPC
MOVB @\$ERRPC,\$ITEMB ;;STRIP AND SAVE THE ERROR ITEM CODE
BIT #BIT13,@SWR ;;SKIP TYPEOUT IF SET
BNE 20\$;;SKIP TYPEOUTS
JSR PC,\$ERRTYP ;;GO TO USER ERROR ROUTINE
TYPE ,\$CRLF
20\$:
2\$: TST @SWR ;;HALT ON ERROR
BPL 3\$;;SKIP IF CONTINUE
HALT ;;HALT ON ERROR!
3\$:
CMP #SENDAD,@#42 ;;ACT-11 AUTO-ACCEPT?
BNE 6\$;;BRANCH IF NO
HALT ;;YES
6\$:
RTI ;;RETURN

.SBTTL ERROR MESSAGE TYPEOUT ROUTINE

*THIS ROUTINE USES THE 'ITEM CONTROL BYTE' (\$ITEMB) TO DETERMINE WHICH
*ERROR IS TO BE REPORTED. IT THEN OBTAINS, FROM THE 'ERROR TABLE' (\$ERRTB),
*AND REPORTS THE APPROPRIATE INFORMATION CONCERNING THE ERROR.

\$ERRTYP:

TYPE , \$CRLF ;;'CARRIAGE RETURN' & 'LINE FEED'
MOV RO,-(SP) ;;SAVE RO
CLR RO ;;PICKUP THE ITEM INDEX
BISB @#\$ITEMB,RO
BNE 1\$;;IF ITEM NUMBER IS ZERO, JUST
MOV \$ERRPC,-(SP) ;;TYPE THE PC OF THE ERROR
;;SAVE \$ERRPC FOR TYPEOUT
;;ERROR ADDRESS
TYPOC ;;GO TYPE--OCTAL ASCII(ALL DIGITS)
BR 6\$;;GET OUT
1\$: DEC RO ;;ADJUST THE INDEX SO THAT IT WILL

```

146 025174 006300 ASL R0 ;; WORK FOR THE ERROR TABLE
147 025176 006300 ASI R0
3148 025200 006300 ASL R0
3149 025202 062700 001172 ADD #ERRTB,R0 ;; FORM TABLE POINTER
3150 025206 012037 025216 MOV (R0)+,2$ ;; PICKUP 'ERROR MESSAGE' POINTER
3151 025212 001404 BEQ 3$ ;; SKIP TYPEOUT IF NO POINTER
3152 025214 104401 TYPE ;; TYPE THE 'ERROR MESSAGE'
3153 025216 000000 2$: .WORD 0 ;; 'ERROR MESSAGE' POINTER GOES HERE
3154 025220 104401 001167 TYPE , $CRLF ;; 'CARRIAGE RETURN' & 'LINE FEED'
3155 025224 012037 025234 3$: MOV (R0)+,4$ ;; PICKUP 'DATA HEADER' POINTER
3156 025230 001404 BEQ 5$ ;; SKIP TYPEOUT IF 0
3157 025232 104401 TYPE ;; TYPE THE 'DATA HEADER'
3158 025234 000000 4$: .WORD 0 ;; 'DATA HEADER' POINTER GOES HERE
3159 025236 104401 001167 TYPE , $CRLF ;; 'CARRIAGE RETURN' & 'LINE FEED'
3160 025242 011000 5$: MOV (R0),R0 ;; PICKUP 'DATA TABLE' POINTER
3161 025244 001004 BNE 7$ ;; GO TYPE THE DATA
3162 025246 012600 6$: MOV (SP)+,R0 ;; RESTORE R0
3163 025250 104401 001167 TYPE , $CRLF ;; 'CARRIAGE RETURN' & 'LINE FEED'
3164 025254 000207 RTS PC ;; RETURN
3165 025256 7$:
3166 025256 013046 MOV @ (R0)+,-(SP) ;; SAVE @ (R0)+ FOR TYPEOUT
3167 025260 104402 TYPOC ;; GO TYPE--OCTAL ASCII(ALL DIGITS)
3168 025262 005710 TST (R0) ;; IS THERE ANOTHER NUMBFR?
3169 025264 001770 BEQ 6$ ;; BR IF NO
3170 025266 104401 025274 TYPE , 8$ ;; TYPE TWO(2) SPACES
3171 025272 000771 BR 7$ ;; LOOP
3172 025274 020040 000 8$: .ASCIZ / / ;; TWO(2) SPACES
3173 025300 .EVEN
3174
3175 .SBTTL TYPE ROUTINE
3176
3177 ;*****
3178 ;*ROUTINE TO TYPE ASCIZ MESSAGE. MESSAGE MUST TERMINATE WITH A 0 BYTE.
3179 ;*THE ROUTINE WILL INSERT A NUMBER OF NULL CHARACTERS AFTER A LINE FEED.
3180 ;*NOTE1: $NULL CONTAINS THE CHARACTER TO BE USED AS THE FILLER CHARACTER.
3181 ;*NOTE2: $FILLS CONTAINS THE NUMBER OF FILLER CHARACTERS REQUIRED.
3182 ;*NOTE3: $FILLC CONTAINS THE CHARACTER TO FILL AFTER.
3183 ;*
3184 ;*CALL:
3185 ;*1) USING A TRAP INSTRUCTION
3186 ;* TYPE ,MESADR ;;MESADR IS FIRST ADDRESS OF AN ASCIZ STRING
3187 ;*OR
3188 ;* TYPE
3189 ;* MESADR
3190 ;*
3191
3192 025300 105737 001157 $TYPE: TSTB $TPFLG ;; IS THERE A TERMINAL?
3193 025304 100002 BPL 1$ ;; BR IF YES
3194 025306 000000 HALT ;; HALT HERE IF NO TERMINAL
3195 025310 000407 BR 3$ ;; LEAVE
3196 025312 010046 1$: MOV R0,-(SP) ;; SAVE R0
3197 025314 017600 000002 MOV @2(SP),R0 ;; GET ADDRESS OF ASCIZ STRING
3198 025320 112046 2$: MOVB (R0)+,-(SP) ;; PUSH CHARACTER TO BE TYPED ONTO STACK
3199 025322 001005 BNE 4$ ;; BR IF IT ISN'T THE TERMINATOR
3200 025324 005726 TST (SP)+ ;; IF TERMINATOR POP IT OFF THE STACK
3201 025326 012600 60$: MOV (SP)+,R0 ;; RESTORE R0

```

```
3202 025330 062716 000002 3$: ADD #2,(SP) ;;ADJUST RETURN PC
3203 025334 000002 RTI ;;RETURN
3204 025336 122716 000011 4$: CMPB #HT,(SP) ;;BRANCH IF <HT>
3205 025342 001430 BEQ 8$
3206 025344 122716 000200 CMPB #CRLF,(SP) ;;BRANCH IF NOT <CRLF>
3207 025350 001006 BNE 5$
3208 025352 005726 TST (SP)+ ;;POP <CR><LF> EQUIV
3209 025354 104401 TYPE ;;TYPE A CR AND LF
3210 025356 001167 $CRLF
3211 025360 105037 025514 CLRB $CHARCNT ;;CLEAR CHARACTER COUNT
3212 025364 000755 BR 2$ ;;GET NEXT CHARACTER
3213 025366 004737 025450 5$: JSR PC,$TYPEC ;;GO TYPE THIS CHARACTER
3214 025372 123726 001156 6$: (MPB $FILLC,(SP)+ ;;IS IT TIME FOR FILLER CHARS.?
3215 025376 001350 BNE 2$ ;;IF NO GO GET NEXT CHAR.
3216 025400 013746 001154 MOV $NULL,-(SP) ;;GET # OF FILLER CHARS. NEEDED
3217 ;;AND THE NULL CHAR.
3218 025404 105366 000001 7$: DECB 1(SP) ;;DOES A NULL NEED TO BE TYPED?
3219 025410 002770 BLT 6$ ;;BR IF NO--GO POP THE NULL OFF OF STACK
3220 025412 004737 025450 JSR PC,$TYPEC ;;GO TYPE A NULL
3221 025416 105337 025514 DECB $CHARCNT ;;DO NOT COUNT AS A COUNT
3222 025422 000770 BR 7$ ;;LOOP
```

:HORIZONTAL TAB PROCESSOR

```
3223
3224
3225
3226 025424 112716 000040 8$: MOVB #' ,(SP) ;;REPLACE TAB WITH SPACE
3227 025430 004737 025450 9$: JSR PC,$TYPEC ;;TYPE A SPACE
3228 025434 132737 000007 025514 BITB #7,$CHARCNT ;;BRANCH IF NOT AT
3229 025442 001372 BNE 9$ ;;TAB STOP
3230 025444 005726 TST (SP)+ ;;POP SPACE OFF STACK
3231 025446 000724 BR 2$ ;;GET NEXT CHARACTER
3232 025450 105777 153474 $TYPEC: TSTB @STPS ;;WAIT UNTIL PRINTER IS READY
3233 025454 100375 BPL $TYPEC
3234 025456 116677 000002 153466 MOVB 2(SP),@STPB ;;LOAD CHAR TO BE TYPED INTO DATA REG.
3235 025464 122766 000015 000002 CMPB #CR,2(SP) ;;IS CHARACTER A CARRIAGE RETURN?
3236 025472 001003 BNE 1$ ;;BRANCH IF NO
3237 025474 105037 025514 CLRB $CHARCNT ;;YES--CLEAR CHARACTER COUNT
3238 025500 000406 BR $TYPEX ;;EXIT
3239 025502 122766 000012 000002 1$: CMPB #LF,2(SP) ;;IS CHARACTER A LINE FEED?
3240 025510 001402 BEQ $TYPEX ;;BRANCH IF YES
3241 025512 105227 INCB (PC)+ ;;COUNT THE CHARACTER
3242 025514 000000 $CHARCNT: .WORD 0 ;;CHARACTER COUNT STORAGE
3243 025516 000207 $TYPEX: RTS PC
```

.SBTTL BINARY TO OCTAL (ASCII) AND TYPE

```
3244
3245
3246
3247
3248 ;;*****
3249 ;;*THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 6-DIGIT
3250 ;;*OCTAL (ASCII) NUMBER AND TYPE IT.
3251 ;;*$TYPOS---ENTER HERE TO SETUP SUPPRESS ZEROS AND NUMBER OF DIGITS TO TYPE
3252 ;;*CALL:
3253 ;;* MOV NUM,-(SP) ;;NUMBER TO BE TYPED
3254 ;;* TYPOS ;;CALL FOR TYPEOUT
3255 ;;* .BYTE N ;;N=1 TO 6 FOR NUMBER OF DIGITS TO TYPE
3256 ;;* .BYTE M ;;M=1 OR 0
3257 ;;* ;:1=TYPE LEADING ZEROS
```

```
3258                                     ;*                                     ;:0=SUPPRESS LEADING ZEROS
3259                                     ;*
3260                                     ;*$TYPON----ENTER HERE TO TYPE OUT WITH THE SAME PARAMETERS AS THE LAST
3261                                     ;*$TYPOS OR $TYPOC
3262                                     ;*CALL:
3263                                     ;*      MOV      NUM,-(SP)          ;:NUMBER TO BE TYPED
3264                                     ;*      TYPON                    ;:CALL FOR TYPEOUT
3265                                     ;*
3266                                     ;*$TYPOC---ENTER HERE FOR TYPEOUT OF A 16 BIT NUMBER
3267                                     ;*CALL:
3268                                     ;*      MOV      NUM,-(SP)          ;:NUMBER TO BE TYPED
3269                                     ;*      TYPOC                     ;:CALL FOR TYPEOUT
3270
3271 025520 017646 000000 025743 $TYPOS: MOV @ (SP),-(SP)          ;:PICKUP THE MODE
3272 025524 116637 000001 025743 MOV 1(SP), $OFILL          ;:LOAD ZERO FILL SWITCH
3273 025532 112637 025745 025743 MOV (SP)+, $OMODE+1      ;:NUMBER OF DIGITS TO TYPE
3274 025536 062716 000002 025743 ADD #2, (SP)              ;:ADJUST RETURN ADDRESS
3275 025542 000406 025743 BR $TYPON
3276 025544 112737 000001 025743 $TYPOC: MOV #1, $OFILL          ;:SET THE ZERO FILL SWITCH
3277 025552 112737 000006 025745 MOV #6, $OMODE+1          ;:SET FOR SIX(6) DIGITS
3278 025560 112737 000005 025742 $TYPON: MOV #5, $OCNT          ;:SET THE ITERATION COUNT
3279 025566 010346 025742 MOV R3, -(SP)              ;:SAVE R3
3280 025570 010446 025742 MOV R4, -(SP)              ;:SAVE R4
3281 025572 010546 025742 MOV R5, -(SP)              ;:SAVE R5
3282 025574 113704 025745 MOV #5, $OMODE+1, R4          ;:GET THE NUMBER OF DIGITS TO TYPE
3283 025600 005404 025745 NEG R4
3284 025602 062704 000006 025745 ADD #6, R4              ;:SUBTRACT IT FOR MAX. ALLOWED
3285 025606 110437 025744 025745 MOV R4, $OMODE          ;:SAVE IT FOR USE
3286 025612 113704 025743 025743 MOV $OFILL, R4          ;:GET THE ZERO FILL SWITCH
3287 025616 016605 000012 025743 MOV 12(SP), R5          ;:PICKUP THE INPUT NUMBER
3288 025622 005003 025743 CLR R3                    ;:CLEAR THE OUTPUT WORD
3289 025624 006105 025743 1$: ROL R5                    ;:ROTATE MSB INTO 'C'
3290 025626 000404 025743 BR 3$
3291 025630 006105 025743 2$: ROL R5                    ;:GO DO MSB
3292 025632 006105 025743 ROL R5                    ;:FORM THIS DIGIT
3293 025634 006105 025743 ROL R5
3294 025636 010503 025743 MOV R5, R3
3295 025640 006103 025743 3$: ROL R3                    ;:GET LSB OF THIS DIGIT
3296 025642 105337 025744 025743 DECB $OMODE          ;:TYPE THIS DIGIT?
3297 025646 100016 025744 025743 BPL 7$              ;:BR IF NO
3298 025650 042703 177770 025743 BIC #177770, R3          ;:GET RID OF JUNK
3299 025654 001002 025743 BNE 4$                    ;:TEST FOR 0
3300 025656 005704 025743 TST R4                    ;:SUPPRESS THIS 0?
3301 025660 001403 025743 BEQ 5$                    ;:BR IF YES
3302 025662 005204 025743 4$: INC R4                  ;:DON'T SUPPRESS ANYMORE 0'S
3303 025664 052703 000060 025743 BIS #'0, R3          ;:MAKE THIS DIGIT ASCII
3304 025670 052703 000040 025743 5$: BIS #' , R3          ;:MAKE ASCII IF NOT ALREADY
3305 025674 110337 025740 025743 MOV R3, 8$          ;:SAVE FOR TYPING
3306 025700 104401 025740 025743 TYPE 8$              ;:GO TYPE THIS DIGIT
3307 025704 105337 025742 7$: DECB $OCNT              ;:COUNT BY 1
3308 025710 003347 025742 BGT 2$                    ;:BR IF MORE TO DO
3309 025712 002402 025742 BLT 6$                    ;:BR IF DONE
3310 025714 005204 025742 INC R4                    ;:INSURE LAST DIGIT ISN'T A BLANK
3311 025716 000744 025742 BR 2$                    ;:GO DO THE LAST DIGIT
3312 025720 012605 025742 6$: MOV (SP)+, R5          ;:RESTORE R5
3313 025722 012604 025742 MOV (SP)+, R4          ;:RESTORE R4
```

```
3314 025724 012603          MOV      (SP)+,R3          ;;RESTORE R3
3315 025726 016666 000002 000004  MOV      2(SP),4(SP)      ;;SET THE STACK FOR RETURNING
3316 025734 012616          MOV      (SP)+,(SP)
3317 025736 000002          RTI                       ;;RETURN
3318 025740          000          8$: .BYTE 0                ;;STORAGE FOR ASCII DIGIT
3319 025741          000          .BYTE 0                ;;TERMINATOR FOR TYPE ROUTINE
3320 025742          000          $OCNT: .BYTE 0           ;;OCTAL DIGIT COUNTER
3321 025743          000          $OFILL: .BYTE 0         ;;ZERO FILL SWITCH
3322 025744 000000          $OMODE: .WORD 0          ;;NUMBER OF DIGITS TO TYPE
3323          .SBTTL RANDOM NUMBER GENERATOR ROUTINE
3324
3325          ;;*****
3326          ;;*THIS ROUTINE IS A DOUBLE PRECISION PSEUDO RANDOM NUMBER GENERATOR
3327          ;;*WITH A RANGE OF 0 TO 2(+33)-1.
3328          ;;*CALL:
3329          ;;* JSR      PC,$RAND          ;;CALL THE ROUTINE
3330          ;;* RETURN                    ;;RETURN HERE THE RANDOM
3331          ;;*                          ;;NUMBER WILL BE IN
3332          ;;*                          ;;$HINUM,$LONUM
3333
3334          $RAND:
3335 025746 010046          MOV      R0,-(SP)         ;;PUSH R0 ON STACK
3336 025750 010146          MOV      R1,-(SP)         ;;PUSH R1 ON STACK
3337 025752 010246          MOV      R2,-(SP)         ;;PUSH R2 ON STACK
3338 025754 013700 026046          MOV      $LONUM,R0        ;;SET R0 WITH LOW
3339 025760 013701 026044          MOV      $HINUM,R1        ;;SET R1 WITH HIGH
3340 025764 012702 177771          MOV      #-7,R2           ;;SET SHIFT COUNT
3341 025770 006300          1$: ASL      R0             ;;SHIFT R0 LEFT AND
3342 025772 006101          ROL      R1             ;;ROTATE CARRY INTO R1 AND
3343 025774 005202          INC      R2             ;;CHECK FOR DONE
3344 025776 001374          BNE      1$             ;;CONTINUE SHIFT LOOP
3345 026000 063700 026046          ADD      $LONUM,R0        ;;ADD NUMBER TO MAKE X 129
3346 026004 005501          ADC      R1             ;;PROPOGATE CARRY
3347 026006 063701 026044          ADD      $HINUM,R1        ;;ADD NUMBER TO MAKE X 129
3348 026012 062700 001057          ADD      #1057,R0         ;;ADD LOW CONSTANT
3349 026016 005501          ADC      R1             ;;PROPOGATE CARRY
3350 026020 062701 047401          ADD      #47401,R1        ;;ADD HIGH CONSTANT
3351 026024 010037 026046          MOV      R0,$LONUM        ;;SAVE R0
3352 026030 010137 026044          MOV      R1,$HINUM        ;;SAVE R1
3353 026034 012602          MOV      (SP)+,R2         ;;POP STACK INTO R2
3354 026036 012601          MOV      (SP)+,R1         ;;POP STACK INTO R1
3355 026040 012600          MOV      (SP)+,R0         ;;POP STACK INTO R0
3356 026042 000207          RTS      PC              ;;RETURN
3357 026044 176543          $HINUM: .WORD 176543
3358 026046 123456          $LONUM: .WORD 123456
3359          .SBTTL TRAP DECODER
3360
3361          ;;*****
3362          ;;*THIS ROUTINE WILL PICKUP THE LOWER BYTE OF THE "TRAP" INSTRUCTION
3363          ;;*AND USE IT TO INDEX THROUGH THE TRAP TABLE FOR THE STARTING ADDRESS
3364          ;;*OF THE DESIRED ROUTINE. THEN USING THE ADDRESS OBTAINED IT WILL
3365          ;;*GO TO THAT ROUTINE.
3366
3367 026050 010046          $TRAP: MOV      R0,-(SP)         ;;SAVE R0
3368 026052 016600 000002          MOV      2(SP),R0         ;;GET TRAP ADDRESS
3369 026056 005740          TST      -(R0)           ;;BACKUP BY 2
```

```
3370 026060 111000          MOVB   (R0),R0          ;;GET RIGHT BYTE OF TRAP
3371 026062 006300          ASL    R0              ;;POSITION FOR INDEXING
3372 026064 016000 026104    MOV    $TRPAD(R0),R0   ;;INDEX TO TABLE
3373 026070 000200          RTS    R0              ;;GO TO ROUTINE
3374
3375
3376          ;;THIS IS USE TO HANDLE THE 'GETPRI' MACRO
3377
3378 026072 011646          $TRAP2: MOV   (SP),-(SP)  ;;MOVE THE PC DOWN
3379 026074 016666 000004 000002  MOV    4(SP),2(SP)     ;;MOVE THE PSW DOWN
3380 026102 000002          RTI                    ;;RESTORE THE PSW
3381
3382          .SBTTL  TRAP TABLE
3383
3384          ;*THIS TABLE CONTAINS THE STARTING ADDRESSES OF THE ROUTINES CALLED
3385          ;*BY THE 'TRAP' INSTRUCTION.
3386
3387          :          ROUTINE
3388          :          -----
3389 026104 026072          $TRPAD: .WORD   $TRAP2
3390 026106 025300          $TYPE   ;;CALL=TYPE      TRAP+1(104401)  TTY TYPEOUT ROUTINE
3391 026110 025544          $TYPOC  ;;CALL=TYPOC     TRAP+2(104402)  TYPE OCTAL NUMBER (WITH LEADING ZEROS)
3392 026112 025520          $TYPOS  ;;CALL=TYPOS     TRAP+3(104403)  TYPE OCTAL NUMBER (NO LEADING ZEROS)
3393 026114 025560          $TYPON  ;;CALL=TYPON     TRAP+4(104404)  TYPE OCTAL NUMBER (AS PER LAST CALL)
3394 026116 013324          $TYPDS  ;;CALL=TYPDS     TRAP+5(104405)  TYPE DECIMAL NUMBER (WITH SIGN)
3395
3396
3397 026120 024246          $RDCHR  ;;CALL=RDCHR     TRAP+6(104406)  TTY TYPEIN CHARACTER ROUTINE
3398 026122 024366          $RDLIN  ;;CALL=RDLIN     TRAP+7(104407)  TTY TYPEIN STRING ROUTINE
3399 026124 024540          $RDOCT  ;;CALL=RDOCT     TRAP+10(104410) READ AN OCTAL NUMBER FROM TTY
3400          .SBTTL  POWER DOWN AND UP ROUTINES
3401
3402          ;*****
3403          ;POWER DOWN ROUTINE
3404 026126 012737 026266 000024  $PWRDN: MOV    # $ILLUP,@#PWRVEC ;;SET FOR FAST UP
3405 026134 012737 000340 000026    MOV    #340,@#PWRVEC+2 ;;PRIO:7
3406 026142 010046          MOV    R0,-(SP)        ;;PUSH R0 ON STACK
3407 026144 010146          MOV    R1,-(SP)        ;;PUSH R1 ON STACK
3408 026146 010246          MOV    R2,-(SP)        ;;PUSH R2 ON STACK
3409 026150 010346          MOV    R3,-(SP)        ;;PUSH R3 ON STACK
3410 026152 010446          MOV    R4,-(SP)        ;;PUSH R4 ON STACK
3411 026154 010546          MOV    R5,-(SP)        ;;PUSH R5 ON STACK
3412 026156 017746 152756          MOV    @SWR,-(SP)      ;;PUSH @SWR ON STA K
3413 026162 010637 026272          MOV    SP,$SAVR6      ;;SAVE SP
3414 026166 012737 026200 000024    MOV    # $PWRUP,@#PWRVEC ;;SET UP VECTOR
3415 026174 000000          HALT
3416 026176 000776          BR     -2             ;;HANG UP
3417
3418          ;*****
3419          ;POWER UP ROUTINE
3420 026200 012737 026266 000024  $PWRUP: MOV    # $ILLUP,@#PWRVEC ;;SET FOR FAST DOWN
3421 026206 013706 026272          MOV    $SAVR6,SP      ;;GET SP
3422 026212 005037 026272          CLR    $SAVR6         ;;WAIT LOOP FOR THE TTY
3423 026216 005237 026272          $:    INC    $SAVR6    ;;WAIT FOR THE INC
3424 026222 001375          BNE    1$             ;;CF WORD
3425 026224 012677 152710          MOV    (SF)+,@SWR     ;;POP STACK INTO @SWR
```



```
3426 026230 012605      MOV      (SP)+,R5      ;;POP STACK INTO R5
3427 026232 012604      MOV      (SP)+,R4      ;;POP STACK INTO R4
3428 026234 012603      MOV      (SP)+,R3      ;;POP STACK INTO R3
3429 026236 012602      MOV      (SP)+,R2      ;;POP STACK INTO R2
3430 026240 012601      MOV      (SP)+,R1      ;;POP STACK INTO R1
3431 026242 012600      MOV      (SP)+,R0      ;;POP STACK INTO R0
3432 026244 012737 026126 000024  MOV      #PWRDN,@PWRVEC ;;SET UP THE POWER DOWN VECTOR
3433 026252 012737 000340 000026  MOV      #340,@PWRVEC+2 ;;PRIO:7
3434 026260 104401      TYPE                                ;REPORT THE POWER FAILURE
3435 026262 026274      $PWRMG: .WORD $POWER                ;;POWER FAIL MESSAGE POINTER
3436 026264 000002      RTI
3437 026266 000000      $ILLUP: HALT
3438 026270 000776      BR      .-2                        ;;THE POWER UP SEQUENCE WAS STARTED
3439 026272 000000      $SAVR6: 0                          ;; BEFORE THE POWER DOWN WAS COMPLETE
3440 026274 005015 047520 042527  $POWER: .ASCIZ <15><12>'POWER'    ;;PUT THE SP HERE
3441 026302 000122
3442
3443 026304 000010      .EVEN
3444 026324 000010      HOLD:  .BLKW 10
3445 026344 000000      GOOD:  .BLKW 10
3446 026346 000000      RETRY: .WORD 0
3447 000001      BUFFER: 0
                                .END
```


CZVTCFO VT50A,B,H/52 ACCPT
CZVTCF.P11 11-APR-79 15:31

MACY11 30A(1052) 11-APR-79 15:34 PAGE 76
CROSS REFERENCE TABLE -- USER SYMBOLS

SEQ 0074

GBBUF	011232	1624	2377#										
GENER	004546	1505#	1509	1511	1532	1539							
GENRX	004632	1516	1520#	1524	1526								
GETCHR	013612	995	998	1001	1953	2151	2292	2474*	2568*	2579*	2589*	2889#	
GIN	001426	895	897	899	901#								
GINA	001434	891	902#										
GNS	= ***** U	753	3390	3391	3392	3393	3394	3397	3398	3399			
GOAPMD	020614	1653	1855	2921#									
GODSHS	020566	1596	2921#										
GOHDSC	020540	1583	2921#										
GO*APM	020621	1665	1867	2921#									
GOOD	026324	2595	2616	2634	2676	3444#							
GOPRNT	020512	1678	1700	1719	1727	1747	1755	1780	1802	1843	2921#		
GRPHST	005266	1614	1616#										
HOLD	026304	2566	2615	2684	3443#								
HOMERS	017243	1618	2921#										
HT	= 000011	634#	3204	3245									
IGNORE	010676	937*	1980*	2218	2252*	2255	2273*	2284#	2627*	2673*	2678*	2799*	
INSBAD	013104	2699	2716	2729	2759#								
INSMNE	013050	2647	2660	2670	2749#								
INSTR	023134	2120	2131	2921#									
INVLID	016676	966	2921#										
IOTVEC	= 000020	729#	911*	912*	939*								
KPTAB	022340	2124	2921#										
KPTBO	022524	2639	2690	2921#									
KRBDON	010074	2116	2127	2140#									
KRBECH	010110	896	2147#										
KRBECO	007110	900	1950#										
KRBTST	007404	898	2024#	2142									
LAST	001244	856#	955*	959*	960	1895	1897						
LASTCH	001310	875#	1047*	1050*	1155	1180	1721	1749	1824	2180			
LASTLN	001262	864#	1036*	1041*	1510								
LBMT	002774	1193#											
LBMT1	003144	1211	1226#										
LCM	003154	1231#											
LF	= 000012	635#	3239	3245									
LIC	010200	1170	1739	1819	2174#								
LICA	010216	2178#	2184										
LICB	010234	2181	2183#										
LODERL	004016	1383#											
LODERS	004174	1426#											
LOOP	010660	938*	2248*	2266*	2277#	3050							
LOOP1	012460	2641#	2644										
LOOP2	012520	2656#	2658										
LOOP3	012552	2666#	2668										
LOOP4	012662	2692#	2697										
LOOP5	012730	2709#	2714										
LOOP6	012770	2722#	2727										
LRL	003436	1290#											
LTAB	003706	1306	1310	1314	1318	1322	1326	1330	1353#				
MANFU	001360	762	892#										
MASK1	012004	2513#	2526*	2530*	2538								
MASK2	012006	2497	2514#	2527*	2535*	2537	2551*	2555*					
MKB	014774	2031	2921#										
MKBA	015071	2472	2921#										
MKBB	015160	2039	2079	2095	2110	2921#							

CZVTCFO VT50A,B,H/52 ACCPT
CZVTCF.P11 11-APR-79 15:31

MACY11 30A(1052) 11-APR-79 15:34 PAGE 77
CROSS REFERENCE TABLE -- USER SYMBOLS

K 6

SEQ 0075

MKBB2	015275	2036	2076	2092	2107	2921#				
MKBC	015361	2044	2921#							
MKBD	015421	2054	2921#							
MKBD2	015526	2051	2921#							
MKBE	015615	2059	2921#							
MKBF	015756	2064	2921#							
MKBG	016013	2071	2921#							
MKBGA	016062	2087	2921#							
MKBH	016133	2102	2921#							
MKBI	016175	2921#								
MKBJ	016230	2921#								
MKBK	016263	2921#								
MKBL	016317	2921#								
MKBM	016352	2921#								
MKBN	016406	2118	2921#							
MKBQ	016532	2508	2921#							
MKBQA	016577	2500*	2501*	2502*		2921#				
MKBQB	016616	2488*	2489*	2490*		2921#				
MKBQ1	016573	2504*	2921#							
MKBQ2	016612	2495*	2921#							
MKBR	016625	2141	2921#							
MKB1	015032	2082	2098	2921#						
MKB52	016463	2129	2921#							
MKE	016744	1952	2921#							
MKEA	017147	1982	2921#							
MKEA1	017160	1969*	1970*	1975*	1976*	1978*	1979*	2921#		
MKEB	017165	1956*	1957*	1958*	2921#					
MKEH	017174	2149	2921#							
MNEMSG	012570	2648	2661	2671#						
MORE	012756	2705	2719#							
MOVDN1	003110	1197	1214#	1217						
MOVDWN	003104	1204	1213#							
MOVRIG	003126	1198	1200	1201	1205	1207	1208	1220#		
MPTCNT	014635	1814	2921#							
MPTSCN	014704	1837	2921#							
MQ0	020317	2249	2921#							
MQ1	020404	2267	2291	2921#						
MQ2	020472	2288	2921#							
MSCOPE	024700	939	3048#							
MSGTND	005076	1499	1560#							
MSGTXT	004756	1497	1546#							
MSGTYP	002436	1029	1091#							
MTEXT0	023221	1795	1871	2921#						
MTEXT1	023325	1872	2921#							
MTEXT2	023426	1873	2921#							
MTEXT3	023530	1874	2921#							
MTEXT4	023613	1875	2921#							
MTEXT5	023715	1876	2921#							
MTEXT6	024016	1877	2921#							
MTEXT7	024050	1878	2921#							
MTEXT8	024150	1879	2921#							
MTOB	013670	2437	2912#							
MULCHR	012710	2687	2702#							
M91	013745	1109	1673	2921#						
M910	014230	1375	2921#							
M911	014257	1419	2921#							

CZVTCFO VT50A,B,H/52 ACCPT
CZVTCF.P11 11-APR-79 15:31

MACY11 30A(1052) 11-APR-79 15:34 PAGE 80
CROSS REFERENCE TABLE -- USER SYMBOLS

SEQ 0078

TIME1	013664	2209*	2215*	2889*	2900*	2905#								
TIME2	013666	2210*	2213*	2890*	2898*	2906#								
TITLE	013704	943	2921#											
TKVEC =	000060	733#												
TOTALC	001264	865#	1034*	1039*	1494									
TPVEC =	000064	734#												
TRAPVE=	000034	732#	915*	916*										
TRTVEC=	000014	727#												
TSTDAT	012360	2600*	2615#											
TSTKPS	012202	2125*	2135*	2561#										
TSTNUM	001252	859#	2921	3104*										
TSTROW	011572	2040	2045	2055	2060	2066	2080	2096	2111	2470#				
TST1	002042	983#	2312											
TST10	003776	1349	1373#	2319										
TST11	004154	1417#	2320											
TST12	004302	1450#	2321											
TST13	004340	1464#	2322											
TST14	005100	1473	1565#	2323										
TST15	005250	1574	1576	1612#	2324									
TST16	005362	1638#	2325											
TST17	005532	1671#	2326											
TST2	002466	887	894	1059	1106#	1900	1941	2313						
TST20	005566	1635#	2327											
TST21	005656	1706#	2328											
TST22	006010	1733#	2329											
TST23	006144	1761#	2330											
TST24	006266	1786#	2331											
TST25	006344	1809#	2332											
TST26	006456	1833#	2333											
TST27	006512	1850#	2334											
TST3	002506	1118#	2314											
TST30	007106	1949#	2335											
TST31	007402	2022#	2336											
TST32	010106	2146#	2337											
TST4	002562	1139#	2315											
TST5	002662	1163#	2316											
TST6	002764	1187#	2317											
TST7	003426	1279	1286#	2318										
TYPDS =	104405	1922	1943	3394#										
TYPE =	104401	942	948	956	965	1904	1920	1923	1944	2863	2973	2976	2980	3043
TYPEPT	002404	3045	3115	3135	3152	3154	3157	3159	3163	3170	3209	3306	3390#	3434
TYPOC =	104402	1018	1021	1028	1075#									
TYPON =	104404	3143	3167	3391#										
TYPOS =	104403	3393#												
UNLKEY	023076	3392#												
VHO	001266	2734	2921#											
VH1	001270	866#	1035*	1040*	1043	1144	1153	1168	1178	1386	1432	1495	1655	1710
VH2	001272	1716	1737	1744	1857	2877								
VTIB	001300	867#	1043*	1044*	1045	1121	1195	1213	1231	1251	1453	1688	1768	17348
VTIS	001276	868#	1045*	1046*										
VTNOW	001246	871#	2220	2740	2894									
VTOS	001304	870#	970	2205	2211	2505	2892							
VT5XX	001260	857#	968*	971	1897	1899*	2921							
VTOS	001302	873#	2153*	2204*										
VT5XX	001260	872#	2154	2192	2194									
VT5XX	001260	863#	1028*	1037	1048	1239	1252	1278	1393	1471	1482	1575	1613	1639

CZVTCFO VT50A,B,H/52 ACPT
CZVTCF.P11 11-APR-79 15:31

MACY11 30A(1052) 11-APR-79 15:34 PAGE 83
CROSS REFERENCE TABLE -- USER SYMBOLS

SEQ 0081

	3097	3098	3099	3100	3108	3112	3117	3120	3126	3436				
\$SWRMK= 000000	746	747	3061	3062	3082									
\$TKB 001146	793#	2924	2941	2947										
\$TKS 001144	792#	2505	2924	2939	2945									
\$TN = 000033	616#	626	980	984#	1103	1107#	1115	1119#	1136	1140#	1160	1164#	1184	
	1188#	1279	1283	1287#	1349	1370	1374#	1414	1418#	1447	1451#	1461	1465#	
	1562	1566#	1574	1576	1609	1613#	1635	1639#	1668	1672#	1682	1686#	1703	
	1707#	1730	1734#	1758	1762#	1783	1787#	1806	1810#	1830	1834#	1847	1851#	
	1946	1950#	2019	2023#	2143	2147#								
\$TPB 001152	795#	3234*	3245											
\$TPFLG 001157	799#	3192	3245											
\$TPS 001150	794#	3232	3245											
\$TRAF 026050	915	3367#												
\$TRAP2 026072	3378#	3389												
\$TRP = 000011	3382#	3391#	3392#	3393#	3394#	3395#	3397	3398#	3399#	3400#				
\$TRPAD 026104	3372	3389#												
\$STNM 001102	772#	1911*	2301*	3058	3082	3084*	3087	3090	3104	3107	3126			
\$TTYIN 024474	2966	2967	2984	2988#										
\$TYPBN= ***** U	3395													
\$TYPDS 013324	2817#	3394												
\$TYPE 025300	3192#	3382	3390											
\$TYPEC 025450	3213	3220	3227	3232#	3233									
\$TYPEX 025516	3238	3240	3243#											
\$YPOC 025544	3276#	3391												
\$YPON 025560	3275	3278#	3393											
\$YPOS 025520	3271#	3392												
\$XTSTR 024724	3069#													
\$GET4= 000000	1926#													
\$OFILL 025743	3272*	3276*	3286	3321#										
\$4OCAT= ***** L	3066	3114												
.	749#	753#	769#	807	908	920	1934	1938	2871#	2921#	2924	2988#	2989	
= 026350	2995	3048	3090	3126	3173#	3245	3416	3438	3443#	3444#				

CZVTCFO VT50A,B,H/52 ACCPT
CZVTCF.P11 11-APR-79 15:31

F 7
MACY11 30A(1052) 11-APR-79 15:34 PAGE 86
CROSS REFERENCE TABLE -- MACRO NAMES

SEQ 0083

.\$DB2D	1#		
.\$DB20	1#		
.\$DIV	1#		
.\$EOP	1#	616#	1884
.\$ERRO	1#	616#	3091
.\$ERRT	1#	616#	3127
.\$MULT	1#		
.\$PARM	616#		
.\$POWE	1#	616#	3400
.\$RAND	1#	616#	3323
.\$RDDE	1#		
.\$RDOC	1#	616#	2995
.\$READ	1#	616#	2921
.\$R2AZ	1#		
.\$SAVE	1#	616#	
.\$SB2D	1#		
.\$SB20	1#		
.\$SCOP	1#	616#	3053
.\$SIZE	1#		
.\$SPAC	616#		
.\$SUPR	1#		
.\$SWDO	616#		
.\$TRAP	1#	616#	3359
.\$TYPB	1#		
.\$TYPD	1#	616#	2805
.\$TYPE	1#	616#	3175
.\$TYPO	1#	616#	3246
.\$4OCA	1#		
.\$1170	1#		

. ABS. 026350 000

ERRORS DETECTED: 0

CZVTCF.BIN,CZVTCF.LST/CRF/SOL/NL:TOC=CZVTCF.SML,CZVTCF.P11
RUN-TIME: 43 57 3 SECONDS
RUN-TIME RATIO: 608/104=5.8
CORE USED: 33K (65 PAGES)