



```

BBBBBBBB 000000 000000 TTTTTTTTTT BBBBBBBB LL 000000 CCCCCCCC KK KK
BBBBBBBB 000000 000000 TTTTTTTTTT BBBBBBBB LL 000000 CCCCCCCC KK KK
BB BB 00 00 00 00 00 00 TT BB BB LL 00 00 CC CCCCCC KK KK
BB BB 00 00 00 00 00 00 TT BB BB LL 00 00 CC CCCCCC KK KK
BB BB 00 00 00 00 00 00 TT BB BB LL 00 00 CC CCCCCC KK KK
BBPBBBBB 00 00 00 00 00 00 TT BBBBBBBB LL 00 00 CC CCCCCC KKKKKK
BBBBBBBB 00 00 00 00 00 00 TT BBBBBBBB LL 00 00 CC CCCCCC KKKKKK
BB BB 00 00 00 00 00 00 TT BB BB LL 00 00 CC CCCCCC KK KK
BB BB 00 00 00 00 00 00 TT BB BB LL 00 00 CC CCCCCC KK KK
BB BB 00 00 00 00 00 00 TT BB BB LL 00 00 CC CCCCCC KK KK
BB BB 00 00 00 00 00 00 TT BB BB LL 00 00 CC CCCCCC KK KK
BBBBBBBB 000000 000000 TT BBBBBBBB LLLLLLLLLL 000000 CCCCCCCC KK KK
BBBBBBBB 000000 000000 TT BBBBBBBB LLLLLLLLLL 000000 CCCCCCCC KK KK

```

```

LL          IIIIII  SSSSSSSS
LL          IIIIII  SSSSSSSS
LL          II      SS
LL          II      SS
LL          II      SS
LL          II      SS
LL          II      SSSSSS
LL          II      SSSSSS
LL          II      SS
LL          II      SS
LL          II      SS
LL          II      SS
LLLLLLLLLL IIIIII  SSSSSSSS
LLLLLLLLLL IIIIII  SSSSSSSS

```

BOOTBLOCK  
Table of contents

(2) 50  
(3) 79

Declarations  
BOOTBLOCK - reads in and starts boot code

```
0000 1 .TITLE BOOTBLOCK
0000 2 .IDENT 'V04-000'
0000 3
0000 4
0000 5 *****
0000 6 *
0000 7 * COPYRIGHT (c) 1978, 1980, 1982, 1984 BY *
0000 8 * DIGITAL EQUIPMENT CORPORATION, MAYNARD, MASSACHUSETTS. *
0000 9 * ALL RIGHTS RESERVED. *
0000 10 *
0000 11 * THIS SOFTWARE IS FURNISHED UNDER A LICENSE AND MAY BE USED AND COPIED *
0000 12 * ONLY IN ACCORDANCE WITH THE TERMS OF SUCH LICENSE AND WITH THE *
0000 13 * INCLUSION OF THE ABOVE COPYRIGHT NOTICE. THIS SOFTWARE OR ANY OTHER *
0000 14 * COPIES THEREOF MAY NOT BE PROVIDED OR OTHERWISE MADE AVAILABLE TO ANY *
0000 15 * OTHER PERSON. NO TITLE TO AND OWNERSHIP OF THE SOFTWARE IS HEREBY *
0000 16 * TRANSFERRED. *
0000 17 *
0000 18 * THE INFORMATION IN THIS SOFTWARE IS SUBJECT TO CHANGE WITHOUT NOTICE *
0000 19 * AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT *
0000 20 * CORPORATION. *
0000 21 *
0000 22 * DIGITAL ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS *
0000 23 * SOFTWARE ON EQUIPMENT WHICH IS NOT SUPPLIED BY DIGITAL. *
0000 24 *
0000 25 *
0000 26 *****
0000 27
0000 28 ++
0000 29
0000 30 FACILITY:
0000 31
0000 32 Device-independent boot block for VAX
0000 33
0000 34 ABSTRACT:
0000 35
0000 36 Reads a file (usually VMB.EXE) off the booting medium into
0000 37 memory and transfers control to the VMB code.
0000 38
0000 39 AUTHOR:
0000 40
0000 41 Carol Peters 23 August 1979
0000 42
0000 43 REVISION HISTORY:
0000 44
0000 45 Robert Rappaport 13 Sept 1979
0000 46 Simplified references to local data items.
0000 47
0000 48 --
```

Declarations

```
0000 50      .SBTTL Declarations
0000 51
0000 52      ;
0000 53      ; Own storage.
0000 54      ;
0000 55
0000 56 FILE_STATS:      ; Reserve space to contain
0000 57 FILE_SIZE:      ;
00000000 0000 58      .LONG 0      ; # blocks in primary boot.
00000000 0004 59 START_LBN:      ;
00000000 0004 60      .LONG 0      ; Swapped words of start LBN.
00000000 0008 61 LOAD_ADDR:      ;
00000000 0008 62      .LONG 0      ; Load address for primary boot.
000C 63      ; NOTE - the load address here is
000C 64      ; relative to the base of the 64KB
000C 65      ; of physical memory in which we are
000C 66      ; currently running. As explained
000C 67      ; below, the UNIBUS (or MASSBUS) map
000C 68      ; registers numbered 0-127 will be
000C 69      ; mapped to this same 64KB. Therefore,
000C 70      ; this address, as is, can be used by
000C 71      ; UNIBUS (or MASSBUS) devices to
000C 72      ; pinpoint where to load the primary
000C 73      ; bootstrap program. However, to
000C 74      ; calculate the physical memory address
000C 75      ; corresponding to this relative
000C 76      ; address, we must add in the physical
000C 77      ; offset of the base of the 64KB.
```

```

BOO$BLOCK - reads in and starts boot cod
000C 79 .SBTTL BOO$BLOCK - reads in and starts boot code
000C 80
000C 81 :++
000C 82 : Functional description:
000C 83 :
000C 84 : The boot block code reads the primary bootstrap file into
000C 85 : physical memory a block at a time. The code calls the device-
000C 86 : dependent ROM subroutine once for each block in the bootstrap
000C 87 : file. Then the routine jumps to byte 0 of the loaded code.
000C 88 :
000C 89 : Inputs:
000C 90 :
000C 91 : R0 - type of boot device
000C 92 : R1 - (UNIBUS) address of the I/O page for the boot device's
000C 93 : UNIBUS
000C 94 : (MASSBUS) address of the device's MASSBUS adapter
000C 95 : R2 - (UNIBUS) 32-bit physical address of the boot device's
000C 96 : CSR (bits <31:24> must be zero)
000C 97 : (MASSBUS) adapter's controller/formatter number
000C 98 : R3 - unit number of the boot device
000C 99 : R5 - software boot control flags
000C 100 : R6 - physical address of the device-dependent ROM routine
000C 101 : that reads an arbitrary LBN into memory
000C 102 :
000C 103 : SP - <base_address + ^X200> of 64kb of good memory
000C 104 :
000C 105 : Implicit inputs:
000C 106 :
000C 107 : UNIBUS adapter map registers 0-127 are mapped to the 64kb of
000C 108 : good memory. MR 0 maps to first page of memory, etc.
000C 109 :
000C 110 : The boot block is loaded into the 1st page of the 64KB of
000C 111 : memory, i.e. the page which corresponds to MR 0.
000C 112 :
000C 113 : The first longword (bytes 0-3) of the boot block contains
000C 114 : the size of the primary bootstrap.
000C 115 :
000C 116 : The second longword (bytes 4-7) contains the starting LBN of
000C 117 : the bootstrap file, expressed as swapped words.
000C 118 :
000C 119 : The third longword (bytes 8-11) contains the relative offset
000C 120 : from the base of the 64KB of memory into which we should load
000C 121 : the primary bootstrap program. This must be a positive
000C 122 : number less than or equal to 64KB-(size*512) where size is the
000C 123 : size of the primary bootstrap.
000C 124 :
000C 125 : The starting LBN format is defined by DSC and cannot be
000C 126 : changed. The load address is defined by WRITEBOOT and cannot
000C 127 : be changed.
000C 128 :
000C 129 : Outputs:
000C 130 :
000C 131 : R0 - type of boot device
000C 132 : R1 - (UNIBUS) address of the I/O page for the boot device's
000C 133 : UNIBUS
000C 134 : (MASSBUS) address of the device's MASSBUS adapter
000C 135 : R2 - (UNIBUS) 18-bit UNIBUS address of the boot device's

```

BOOSBLOCK - reads in and starts boot cod

```

000C 136 :
000C 137 :
000C 138 : R3 - unit number of the boot device
000C 139 : R5 - software boot control flags
000C 140 : R6 - physical address of the device-dependent ROM routine
000C 141 : that reads an arbitrary LBN into memory
000C 142 :
000C 143 : SP - <base_address + ^X200> of 64kb of good memory
000C 144 :
000C 145 : Implicit outputs:
000C 146 :
000C 147 : The routine preserves R0-R1, R3, R4, R5-R6, R8, R10-R11, AP, and SP.
000C 148 :
000C 149 : Transfers control to the 0th byte of the primary bootstrap
000C 150 : program.
000C 151 :
000C 152 :--
000C 153 :
000C 154 : BOOSBLOCK CODE:
000C 155 : PUSHAB FILE_STATS ; Start of device independent code.
000F 156 : ; Move physical address of base of
6E F6 AF C0 000F 157 : ADDL LOAD_ADDR,(SP) ; 64KB of memory.
0013 158 : ; Add in relative load address. Result
0013 159 : ; is physical address of load point.
0013 160 : ; Leave on stack for final JMP inst.
0013 161 :
54 0131 8F BB 0013 161 : PUSHR #^M<R0,R4,R5,R8> ; Save 4 registers for temps.
58 E6 AF D0 0017 162 : MOVL FILE_SIZE,R4 ; Get # of blocks in VMB.
EO AF E4 AF B0 001B 163 : MOVW START_LBN,R8 ; Get upper word value of LBN.
0024 164 : MOVW START_LBN+2,START_LBN ; Move lower word value of LBN into
DE AF 58 B0 0024 165 : ; lower word position.
0028 166 : MOVW R8,START_LBN+2 ; Move upper word value to upper
58 D9 AF D0 0028 167 : ; word position.
55 D9 AF D0 0028 168 : MOVL START_LBN,R8 ; Pickup the swapped LBN.
10 AE DD 002C 169 : MOVL LOAD_ADDR,R5 ; Get primary boot relative load addr.
0030 170 : PUSHL 16(SP) ; Copy physical transfer address to
0033 171 : ; top of stack for those devices such
0033 172 : ; as the TUS8 which need physical
0033 173 : ; rather than UNIBUS virtual addresses.
0033 174 :
0033 175 : READ_BLOCK:
0033 176 : JSB (R6) ; VMB read loop.
01 50 EB 0035 177 : BLBS R0,NEXT_BLOCK ; Call ROM read LBN routine.
0038 178 : HALT ; Branch on successful read.
0039 179 : ; Halt on failure to read.
0039 180 : NEXT_BLOCK:
55 00000200 8F C0 0039 181 : ADDL #^X200,R5 ; Read next block.
6E 00000200 8F C0 0040 182 : ADDL #^X200,(SP) ; Increment relative address 512 bytes.
58 BA AF D6 0047 183 : INCL START_LBN ; Increment physical address one page.
E2 54 F5 004A 184 : MOVL START_LBN,R8 ; Increment LBN number.
8E D5 004E 185 : SOBGTR R4,READ_BLOCK ; Next LBN is LBN+1.
0051 186 : TSTL (SP)+ ; If more blocks, loop.
0053 187 : ; Pop now useless data from stack.
0053 188 :
0053 189 : The primary bootstrap program is now in physical memory starting at
0053 190 : the specified load address. Restore the saved registers, convert the
0053 191 : CSR address to an 18-bit UNIBUS address, and transfer control to the
0053 192 : program.

```

BOO\$BLOCK - reads in and starts boot cod

```

          0053 193 ;
          0053 194
52 0131 8F BA 0053 195 POPR #^M<R0,R4,R5,R8> ; Restore registers.
   FFFC0000 8F CA 0057 196 BICL #^XFFFC0000,R2 ; Reduce 32-bit CSR to 18-bit
          005E 197 ; CSR that VMB expects.
          9E 17 005E 198 JMP @ (SP)+ ; Jump to primary bootstrap program.
          0060 199
          0060 200 .END
```



BOOTBLOCK  
 Symbol table

BOOSBLOCK_CODE	0000000C	R	01
FILE_SIZE	00000000	R	01
FILE_STATS	00000000	R	01
LOAD_ADDR	00000008	R	01
NEXT_BLOCK	00000039	R	01
READ_BLOCK	00000033	R	01
START_LBN	00000004	R	01

-----  
 ! Psect synopsis !  
 -----

PSECT name	Allocation	PSECT No.	Attributes
. ABS :	00000000 ( 0.)	00 ( 0.)	NOPIC USR CON ABS LCL NOSHR NOEXE NORD NOWRT NOVEC BYTE
. BLANK :	00000060 ( 96.)	01 ( 1.)	NOPIC USR CON REL LCL NOSHR EXE RD WRT NOVEC BYTE

-----  
 ! Performance indicators !  
 -----

Phase	Page faults	CPU Time	Elapsed Time
Initialization	35	00:00:00.08	00:00:00.29
Command processing	141	00:00:00.60	00:00:02.09
Pass 1	68	00:00:00.55	00:00:01.56
Symbol table sort	0	00:00:00.00	00:00:00.00
Pass 2	52	00:00:00.39	00:00:01.01
Symbol table output	2	00:00:00.01	00:00:00.01
Psect synopsis output	1	00:00:00.02	00:00:00.02
Cross-reference output	0	00:00:00.00	00:00:00.00
Assembler run totals	301	00:00:01.65	00:00:04.98

The working set limit was 900 pages.  
 2158 bytes (5 pages) of virtual memory were used to buffer the intermediate code.  
 There were 10 pages of symbol table space allocated to hold 7 non-local and 0 local symbols.  
 200 source lines were read in Pass 1, producing 9 object records in Pass 2.  
 0 pages of virtual memory were used to define 0 macros.

-----  
 ! Macro library statistics !  
 -----

Macro library name	Macros defined
-\$255\$DUA28:[BOOTS.OBJ]BOOTS.MLB;1	0
-\$255\$DUA28:[SYS.OBJ]LIB.MLB;1	0
-\$255\$DUA28:[SYSLIB]STARLET.MLB;2	0
TOTALS (all libraries)	0

0 GETS were required to define 0 macros.

There were no errors, warnings or information messages.

MACRO/LIS=LIS\$:BOOTBLOCK/OBJ=OBJ\$:BOOTBLOCK MSRC\$:BOOTBLOCK/UPDATE=(ENH\$:BOOTBLOCK)+EXECMLS/LIB+LIB\$:BOOTS.MLB/LIB

0037 AH-BT13A-SE  
VAX/VMS V4.0

DIGITAL EQUIPMENT CORPORATION  
CONFIDENTIAL AND PROPRIETARY

The image displays a grid of 144 small technical diagrams or code snippets, arranged in a 12x12 grid. Each diagram is contained within a rectangular frame. The diagrams are highly detailed and appear to be technical drawings or code listings. Several diagrams are labeled with text, including:

- CONFIG LIS
- BTMEM85 LIS
- BTMEM79 LIS
- BOOTDEF LIS
- BOOTIO LIS
- BOOTDRIV LIS
- BTMEM73 LIS
- BTMEM75 LIS
- BTMEM78 LIS
- BOOTBLOCK LIS

The diagrams themselves show various technical details, including vertical lines, text-based structures, and what appears to be code or data listings. The overall appearance is that of a technical manual or a collection of reference diagrams for a specific system.