

A graphic representation of Katsushika Hokusai's 'The Great Wave off Kanagawa' using the letters B, S, and T. The image features a large wave at the bottom, a prominent Mt. Fuji in the background, and several boats in the foreground. The letter B is used for the base of the wave and the hulls of the boats. The letter S is used for the white foam of the waves and the masts of the boats. The letter T is used for the peaks of the waves and the rigging of the boats.

\*\*FILE\*\*ID\*\*BTMEM8SS

BBBBBBBBBB	TTTTTTTTTT	MM	MM	EEEEEEEEE	MM	MM	888888	SSSSSSSS	SSSSSSSS
BBBBBBBBBB	TTTTTTTTTT	MM	MM	EEEEEEEEE	MM	MM	888888	SSSSSSSS	SSSSSSSS
BB	BB	TT	MMMM	MMMM	EE	MMMM	MMMM	88	88
BB	BB	TT	MMMM	MMMM	EE	MMMM	MMMM	88	88
BB	BB	TT	MM	MM	EE	MM	MM	88	88
BB	BB	TT	MM	MM	EE	MM	MM	88	88
BBBBBBBBBB	TT	MM	MM	EEEEEEEEE	MM	MM	888888	SSSSSS	SSSSSS
BBBBBBBBBB	TT	MM	MM	EEEEEEEEE	MM	MM	888888	SSSSSS	SSSSSS
BB	BB	TT	MM	MM	EE	MM	MM	88	88
BB	BB	TT	MM	MM	EE	MM	MM	88	88
BB	BB	TT	MM	MM	EE	MM	MM	88	88
BB	BB	TT	MM	MM	EE	MM	MM	88	88
BBBBBBBBBB	TT	MM	MM	EEEEEEEEE	MM	MM	888888	SSSSSS	SSSSSS
BBBBBBBBBB	TT	MM	MM	EEEEEEEEE	MM	MM	888888	SSSSSS	SSSSSS
LL	IIIIII	SSSSSSSS	SSSSSSSS						
LL	IIII	SS	SS						
LL	II	SS	SS						
LL	II	SSSSSS	SSSSSS						
LL	II	SS	SS						
LL	II	SS	SS						
LL	II	SS	SS						
LLLLLLLL	IIIIII	SSSSSSSS	SSSSSSSS						

(2) 119 Declarations  
(3) 148 CHECKMEM\_8SS, Identify 11/8SS memory


0000 1 .TITLE BTMEM8SS - Configure and Test 11/8SS Memory  
0000 2 .IDENT 'V04-000'  
0000 3 :\*\*\*\*\*  
0000 4 :  
0000 5 : \* COPYRIGHT (c) 1978, 1980, 1982, 1984 BY  
0000 6 : \* DIGITAL EQUIPMENT CORPORATION, MAYNARD, MASSACHUSETTS.  
0000 7 : \* ALL RIGHTS RESERVED.  
0000 8 :  
0000 9 :  
0000 10 :  
0000 11 : \* THIS SOFTWARE IS FURNISHED UNDER A LICENSE AND MAY BE USED AND COPIED  
0000 12 : \* ONLY IN ACCORDANCE WITH THE TERMS OF SUCH LICENSE AND WITH THE  
0000 13 : \* INCLUSION OF THE ABOVE COPYRIGHT NOTICE. THIS SOFTWARE OR ANY OTHER  
0000 14 : \* COPIES THEREOF MAY NOT BE PROVIDED OR OTHERWISE MADE AVAILABLE TO ANY  
0000 15 : \* OTHER PERSON. NO TITLE TO AND OWNERSHIP OF THE SOFTWARE IS HEREBY  
0000 16 : \* TRANSFERRED.  
0000 17 :  
0000 18 : \* THE INFORMATION IN THIS SOFTWARE IS SUBJECT TO CHANGE WITHOUT NOTICE  
0000 19 : \* AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT  
0000 20 : \* CORPORATION.  
0000 21 :  
0000 22 : \* DIGITAL ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS  
0000 23 : \* SOFTWARE ON EQUIPMENT WHICH IS NOT SUPPLIED BY DIGITAL.  
0000 24 :  
0000 25 :  
0000 26 :\*\*\*\*\*  
0000 27 :  
0000 28 :++  
0000 29 :  
0000 30 :  
0000 31 :  
0000 32 : Facility:  
0000 33 : Linked with VMB.EXE - part of the  
0000 34 : bootstrap module for VAX 11/8SS hardware.  
0000 35 :  
0000 36 :  
0000 37 : Environment:  
0000 38 : Runs at IPL 31, kernel mode, memory management is OFF, IS=1  
0000 39 : (running on interrupt stack), and code must be PIC.  
0000 40 :  
0000 41 : Functional Description:  
0000 42 :  
0000 43 : This routine is 11/8SS specific and  
0000 44 : determines how many memory controllers are on the system,  
0000 45 : where they are, how much memory they control, which pages  
0000 46 : of that memory are present (and good). Then the routines  
0000 47 : set bits in the PFN bitmap to represent each present (and  
0000 48 : good) page of memory.  
0000 49 :  
0000 50 : As a side effect, the routines store the type of adapter located  
0000 51 : at each bus slot in the RPB.  
0000 52 :  
0000 53 : Inputs:  
0000 54 :  
0000 55 : R7 - address of the SCB  
0000 56 : R11 - address of the RPB  
0000 57 :  
C  
V

## 0000 58 : IMPLICIT INPUTS:

0000 59  
0000 60 The positions on the 11/8SS system bus, the BI, are called nodes, and  
0000 61 are identified by node numbers 0-15.

0000 62  
0000 63 BI I/O space begins at ^x20000000 (512MB), and each node occupies  
0000 64 an 8KB node space of registers.

0000 65  
0000 66 BI nodes are self identifying in that the first register (relative 0)  
0000 67 in the node space is constrained to be the DEVTYPE register. The  
0000 68 format of this register is as follows:  
0000 69



0000 70  
0000 71 This register is to be interpreted as follows:  
0000 72  
0000 73  
0000 74  
0000 75  
0000 76  
0000 77  
0000 78  
0000 79  
0000 80

0000 81 The Device Type field is broken up into three sub-fields.  
0000 82 The main sub-field of interest here is the one defined  
0000 83 by bits <14:08>. If this sub-field is zero then this  
0000 84 node is a BI memory node. All other types of node,  
0000 85 i.e. processors, adapters, etc., are constrained to  
0000 86 have non-zero values here.  
0000 87

0000 88 The ND field, bit <15>, if non-zero, indicates that the  
0000 89 node is a non-DEC device.  
0000 90  
0000 91  
0000 92

## 0000 93 : OUTPUTS:

0000 94 R7, R8, R11, and SP are preserved  
0000 95 All others (including AP and FP) are altered  
0000 96

## 0000 97 : IMPLICIT OUTPUTS:

0000 98 The PFN bitmap is modified to describe all of physical memory.  
0000 99 RPB\$L\_PFN\_CNT stores the number of pages of physical memory.  
0000 100  
0000 101  
0000 102  
0000 103  
0000 104  
0000 105  
0000 106  
0000 107  
0000 108  
0000 109

## 0000 110 : AUTHOR:

Robert L. Rappaport, creation date 10-Oct-1983

## 0000 111 : REVISION HISTORY:

V03-002 RLR0001 Robert L. Rappaport 6-Apr-1984  
0000 112 Several modifications. i) Test for BROKE bit, and do NOT  
0000 113 test memory if set; 2) Clear error bits in CSR1 and CSR2;  
0000 114 3) move replacement of Machine Check handler from loop;  
0000 115 4) PUSHL original Machine Check handler addr and POPL it

BTMEM8SS  
V04-000

- Configure and Test 11/BSS Memory

G 11

15-SEP-1984 23:44:25 VAX/VMS Macro V04-00  
4-SEP-1984 23:03:23 [BOOTS.SRC]BTMEM8SS.MAR;1

Page 3  
(1)

0000 115 ;  
0000 116 ;--  
0000 117 ;--

after loop.

```
0000 119 .SBTTL Declarations
0000 120
0000 121 .DEFAULT DISPLACEMENT, WORD
0000 122
0000 123 : Macros to describe VMS data structures
0000 124
0000 125
0000 126
0000 127 $BIICDEF : BIIC registers
0000 128 $BIMEMDEF : BI Memory registers
0000 129 $DMPDEF : System dump file header definitions
0000 130 $IO8SSDEF : 11/8SS definitions
0000 131 $NDTDEF : Nexus device types
0000 132 $PRDEF : Processor registers
0000 133 $PR8SSDEF : CPU Specific Processor registers
0000 134 $RPBDEF : Restart parameter block
0000 135 $BUADEF : BI-UNIBUS adapter
0000 136
0000 137 : Macros
0000 138
0000 139
0000 140
0000 141 .MACRO ERROR,STR ; Outputs an error string to the
0000 142 BSBW ERROUT ; console terminal.
0000 143 .ASCIZ STR
0000 144 .ENDM ERROR
0000 145
00000000 146 .PSECT YBTMEM, LONG
```

	0000	148	.SBTTL CHECKMEM_8SS, Identify 11/8SS memory
	0000	149	
	0000	150	++
	0000	151	CHECKMEM_8SS, Locate and test memory for 11/8SS
	0000	152	
	0000	153	---
	0000	154	
	0000	155	
	0000	156	CHECKMEM_8SS:: ; Entry for 11/8SS.
	0000	157	
	0000	158	
	0000	159	Start testing slot positions to find adapters. First save the stack
	0000	160	position so it can be restored after a machine check.
	0000	161	:
	0000	162	
	0000	163	INIT_SEARCH: ; Start searching for adapters
	0000	164	
	0000	165	; Save original machine check handler address on stack.
	0000	166	
5D 04 A7 DD	0000	167	PUSHL 4(R7) ; Save original handler address.
5D 5E DD	0003	168	MOVL SP,FP ; Save current top of stack.
	0006	169	
	0006	170	
	0006	171	Set up the physical address of the 1st slot on the system bus and
	0006	172	the address of the adapter type table.
	0006	173	
	0006	174	
54 20000000 9F 9E	0006	175	MOVAB #IO8SSAL IOBASE,R4 ; Get address of 1st slot.
5C 10 9A	000D	176	MOVZBL #IO8SSAL_NNEX,AP ; Set up NEXUS loop counter.
	0010	177	
	0010	178	
	0010	179	During this memory locate and test loop, the following registers are
	0010	180	used:
	0010	181	
	0010	182	R0 - the contents of the slot's configuration register
	0010	183	R4 - address of the configuration register at the current
	0010	184	slot position
	0010	185	R7 - address of the SCB
	0010	186	R9 - bit setting in memory present map;
	0010	187	starting page number in this controller
	0010	188	R10 - address of the memory description list in RPB (pagcnt & pfn)
	0010	189	R11 - address of the RPB
	0010	190	
	0010	191	Initialize R10 (RPB memory descriptor list pointer) for search loop
	0010	192	
30 AB 5A 00BC CB	0010	193	MOVAB RPB\$L MEMDSC(R11),R10 ; Set pointer to memory description list
00005800 8F CA	0015	194	BICL #<RPB\$M MPM ! RPB\$M_USEMPM ! RPB\$M_FINDMEM>, -
	001D	195	RPB\$L_BOOTRS(R11) ; Clear all MA780-specific boot flags
	001D	196	
	001D	197	
	001D	198	TRY_NEXUS_8SS: ; Memory locate and test loop.
	001D	199	
	001D	200	
	001D	201	Set up a machine check fault handler to gain control if the main loop
	001D	202	here addresses a non-existent configuration register (an empty slot).
	001D	203	Note we do this within the loop since we re-set to another machine
	001D	204	check handler later on in the loop.

```

04 A7 6D'AF 9E 001D 205      MOVAB  B^DO_NEXT_8SS+1,4(R7) : Set up fault handler (+1 for
0022 206      : handler execution on the
0022 207      : interrupt stack).
0022 208
0022 209 ; Then read the slot's configuration register.
0022 210
50 64 D0 0022 211      MOVL   (R4),R0          ; Read CR at current slot.
0025 212
0025 213
0025 214 ; Execution continues here if the configuration register is present.
0025 215 ; If the adapter type is a memory controller, proceed to test memory.
0025 216 ; Otherwise, move to the next BI slot.
0025 217
0025 218
0025 219
50 50 08 EF 0025 220      EXTZV #BIIC$V_MEMNODE,- : Extract sub-field of BI devtype
0027 221      #BIIC$S_MEMNODE,R0,R0 : field that tells if we have memory.
40 12 002A 222      BNEQ  DO_NEXT_8SS : No, advance to next slot.
002C 223
002C 224 ; Here check BROKE bit to see if memory passed self test.
002C 225
50 0100 C4 D0 002C 226      MOVL   BIMEMSL_CSR1(R4),R0 : Read CSR containing BROKE bit.
0031 227      BBS    #BIMEM$V_BROKE,- : If BROKE, ignore this node.
37 50 0033 228
0035 229
0035 230 ; Memory controller found:
0035 231
50 20 A4 D0 0035 232      MOVL   BIIC$L_SAR(R4),R0 : R0 = Starting Address for this memory.
51 24 A4 D0 0039 233      MOVL   BIIC$L_EAR(R4),R1 : R1 = Ending Address for this memory.
59 50 17 9C 003D 234      ROTL  #<32-95,R0,R9 : Equivalent of ASHL #9,R0,R9. Result
0041 235      : is starting PFN to R9.
53 51 50 C3 0041 236      SUBL3 R0,R1,R3 : R3 = length of memory segment in bytes.
53 53 17 9C 0045 237      ROTL  #<32-9>,R3,R3 : Equivalent of ASHL #9,R3,R3. Result
0049 238      : is # of pages to R3.
0049 239
8A 53 D0 0049 240      MOVL   R3,(R10)+ : Save # of pages in this memory
004C 241      ASSUME DMP$V_TR EQ 24
004C 242      ASSUME DMP$S_TR EQ 8
FF AA 10 90 004C 243      MOVB  #IO8SS$AL_NNEX,-1(R10) : Compute the TR number for this
FF AA 5C 82 0050 244      SUBB  AP,-1(R10) : memory and store in descriptor
8A 59 D0 0054 245      MOVL   R9,(R10)+ : Save starting PFN for this memory
0057 246
0057 247
0057 248 ; Before starting memory test, establish a page skipping handler for
0057 249 ; machine checks, and turn off the cache so that writes followed by
0057 250 ; reads to memory don't write to memory and then read from the cache.
0057 251 ; Also, enable CRD error reporting if requested by the RPB BOOTR5 flag.
0057 252
0057 253
04 A7 00B9'CF 9E 0057 254      MOVAB  PAGE_MCHECK_8SS+1,4(R7) : Set page skipping handler (+1
005D 255      : for interrupt stack).
01 DA 005D 256      MTPR  #PR8SS$M_CADR_D,- : Turn off memory cache.
25 005F 257
52 0088'CF 9E 0060 258      MOVAB  TEST_QUAD_8SS,R2 : Page test routine address
FF98' 30 0065 259      BSBW  BOOSTTEST_MEM : Test the specified range of PFN's
02 11 0068 260      BRB   DO_NEXT_8SS : Do the next controller if any
006A 261

```

006A 262 .ALIGN LONG ; Longword-aligned handler.  
 006C 263  
 006C 264  
 006C 265 : Fault handler for non-existent configuration register, or unreadable  
 registers, or a non-memory controller slot device. Restore stack  
 pointer, clear all errors, and try for another slot if any remain.  
 006C 266  
 006C 267  
 006C 268  
 006C 269  
 006C 270 DO\_NEXT\_8SS:  
 26 5E 5D D0 006C 271 MOVL FP,SP ; Skip to next slot.  
 54 FFFFFFFF 8F DA 006F 272 MTPR #-1,#PRS\_MCESR ; Restore stack pointer.  
 2000 C4 9E 0076 273 MOVAB IO8SS\$AL\_PERNEX(R4),R4 ; Clear any faults.  
 9F 5C F5 007B 274 SOBGTR AP,TRY\_NEXUS\_8SS ; Move to next slot.  
 007E 275  
 007E 276  
 007E 277 : If still a slot, loop.  
 007E 278  
 007E 279  
 007E 280 ASSUME PR8SS\$V\_CADR\_D EQ 0  
 25 00 DA 007E 281 MTPR #0,#PR8SS\_CADR ; Re-enable cache.  
 04 A7 8ED0 0081 282 POPL 4(R7) ; Restore original handler address.  
 8A D4 0085 283 CLRL (R10)+ ; Indicate end of RPB memory descr list  
 05 0087 284 RSB ; Return to main routine.  
 0088 285  
 0088 286 ++  
 0088 287  
 0088 288 Functional Description:  
 0088 289 Test a page of 8SS memory.  
 0088 290  
 0088 291 Calling Sequence:  
 0088 292 JSB TEST\_QUAD\_8SS  
 0088 293  
 0088 294 Inputs:  
 0088 295  
 0088 296 R0 = starting address to test  
 0088 297 R1 = Quad word iteration count (64)  
 0088 298 R4 => Node Registers  
 0088 299 R11= Address of RPB  
 0088 300  
 0088 301  
 0088 302  
 0088 303 Outputs:  
 0088 304 Returns via RSB if the entire page is OK  
 0088 305 Error exit via Machine Check code to BOO\$PAGE\_MCHECK  
 0088 306  
 0088 307  
 0088 308 --  
 0088 309  
 0088 310 TEST\_QUAD\_8SS: ; Test 1 quadword at a time.  
 0088 311 CERQ (R0) ; Clear a quadword.  
 008A 312 CMPL (R0)+,(R0)+ ; Read both longwords, and  
 008D 313  
 008D 314  
 008D 315  
 008D 316 If no gross errors occur in the clear to the quadword or in the  
 008D 317 subsequent read instruction, then execution continues below. Otherwise  
 008D 318 execution goes to the fault handler.

```

      008D 319 :
      F8 51  F5 008D 320
      0100 C4  D0 0090 321 SOBGTR R1,TEST_QUAD_8SS
      0100 C4  51  D0 0095 322 MOVL BIMEMSL_CSR1(R4),R1 ; Continue clearing unless done.
      51 0104 C4  D0 009A 323 MOVL R1,BIMEMSL_CSR1(R4)
      51 0104 C4  D0 009F 324 MOVL BIMEMSL_CSR2(R4),R1 ; Read memory CSR1.
      0104 C4  51  D0 009F 325 MOVL R1,BIMEMSL_CSR2(R4) ; Re-write (write 1 to clear) CSR1.
      10   E1 00A4 326 BBC #RPBS$V CRDTEST_-
      01 30 AB  00A6 327 RPB$L_BOOTR5(R11),10$ ; Read memory CSR2 and retain value
      05   00A9 328          : in R1 for later testing CRD bit.
      00AA 329 5$: RSB ; Re-write (write 1 to clear) CSR2.
      00AA 330          : Branch if CRD test is requested.
      00AA 331          : Check if a CRD error occurred on this page.
      00AA 332          :
      00AA 333 10$:          :
      51 20000000 8F  D3 00AA 334 BITL #BIMEMSM_CRDLOGR,R1 ; test if CRD errors encountered.
      F6 13  00B1 335 BEQL 5$ ; Branch if no CRD error occurred.
      1E 11  00B3 336 BRB  ERR_EXIT_8SS ; Else take error path.
      00B5 337          :
      00B5 338          : ALIGN LONG ; All handlers longword-aligned.
      00B8 339          :
      00B8 340          :
      00B8 341          : Handler that gains control when a page has gross memory errors. Just
      00B8 342          : clear the error, recover the stack top, and advance to the next page.
      00B8 343          :
      00B8 344          :
      00B8 345 PAGE_MCHECK_8SS:          : Handle machine check.
      51 0100 C4  D0 00B8 346 MOVC BIMEMSL_CSR1(R4),R1 ; Read memory CSR1.
      0100 C4  51  D0 00BD 347 MOVL R1,BIMEMSL_CSR1(R4) ; Re-write (write 1 to clear) CSR1.
      51 0104 C4  D0 00C2 348 MOVL BIMEMSL_CSR2(R4),R1 ; Read memory CSR2.
      0104 C4  51  D0 00C7 349 MOVL R1,BIMEMSL_CSR2(R4) ; Re-write (write 1 to clear) CSR2.
      26 FFFFFFFF 8F  DA 00CC 350 MTPR #-1,#PRS_MCESR ; Clear error indicator.
      00D3 351 ERR_EXIT_8SS:          :
      FF2A' 31  00D3 352 BRW  BOOS$PAGE_MCHECK ; Exit to common bad page code
      00D6 353 .END          :

```

BTMEM8SS  
Symbol table

- Configure and Test 11/8SS Memory

M 11

15-SEP-1984 23:44:25 VAX/VMS Macro V04-00  
4-SEP-1984 23:03:23 [BOOTS.SRC]BTMEM8SS.MAR;1

Page 9  
(3)

BIICSL_EAR	= 00000024
BIICSL_SAR	= 00000020
BIICSS_MEMNODE	= 00000007
BIICSV_MEMNODE	= 00000008
BIMEMSL_CSR1	= 00000100
BIMEMSL_CSR2	= 00000104
BIMEMSM_CRDLOGR	= 20000000
BIMEMSV_BROKE	= 0000000C
BOOSPAGE_MCHECK	***** X 02
BOOSTEST_MEM	***** X 02
CHECKMEM_8SS	00000000 RG 02
DMPSS_TR	= 00000008
DMPSV_TR	= 00000018
DO_NEXT_8SS	0000006C R 02
ERR_EXIT_8SS	000000D3 R 02
INIT_SEARCH	00000000 R 02
IO8SSAL_IOPAGE	= 20000000
IO8SSAL_NNEX	= 00000010
IO8SSAL_PERNEX	= 00002000
PAGE_MCHECK_8SS	000000B8 R 02
PRS_MCESR	= 00000026
PR8SSSM_CADR_D	= 00000001
PR8SSSV_CADR_D	= 00000000
PR8SSS_CADR	= 00000025
RPB\$L_BOOTR5	= 00000030
RPB\$L_MEMDSC	= 000000BC
RPB\$M_FINDMEM	= 00004000
RPB\$M_MPMM	= 00000800
RPB\$M_USEMPM	= 00001000
RPB\$V_CRDTEST	= 00000010
TEST_QUAD_8SS	00000088 R 02
TRY_NEXUS_8SS	0000001D R 02

+-----+  
! Psect synopsis !  
+-----+

PSECT name

	Allocation	PSECT No.	Attributes
. ABS .	00000000 ( 0.) 00 ( 0.) NOPIC USR CON ABS LCL NOSHR NOEXE NORD NOWRT NOVEC BYTE		
\$ABSS	00000000 ( 0.) 01 ( 1.) NOPIC USR CON ABS LCL NOSHR EXE RD WRT NOVEC BYTE		
YBTMEM	000000D6 ( 214.) 02 ( 2.) NOPIC USR CON REL LCL NOSHR EXE RD WRT NOVEC LONG		

+-----+  
! Performance indicators !  
+-----+

Phase

	Page faults	CPU Time	Elapsed Time
Initialization	29	00:00:00.07	00:00:01.81
Command processing	118	00:00:00.59	00:00:06.13
Pass 1	234	00:00:06.50	00:00:15.60
Symbol table sort	0	00:00:00.87	00:00:01.69
Pass 2	75	00:00:01.37	00:00:02.74
Symbol table output	5	00:00:00.05	00:00:00.05
Psect synopsis output	1	00:00:00.02	00:00:00.02
Cross-reference output	0	00:00:00.00	00:00:00.00

Assembler run totals 464 00:00:09.48 00:00:28.06

The working set limit was 1350 pages.

35196 bytes (69 pages) of virtual memory were used to buffer the intermediate code.

There were 40 pages of symbol table space allocated to hold 631 non-local and 2 local symbols.

353 source lines were read in Pass 1, producing 13 object records in Pass 2.

18 pages of virtual memory were used to define 17 macros.

+-----+  
! Macro Library statistics !  
+-----+

Macro Library name

Macros defined

-----  
-\$255\$DUA28:[BOOTS.OBJ]BOOTS.MLB;1  
-\$255\$DUA28:[SYS.OBJ]LIB.MLB;1  
-\$255\$DUA28:[SYSLIB]STARLET.MLB;2

0  
6  
7  
13

TOTALS (all libraries)

719 GETS were required to define 13 macros.

There were no errors, warnings or information messages.

MACRO/LIS=LISS:BTMEM8SS/OBJ=OBJ\$:BTMEM8SS MSRCS:BTMEM8SS/UPDATE=(ENH\$:BTMEM8SS)+EXECMLS/LIB+LIB\$:BOOTS.MLB/LIB

0037 AH-BT13A-SE  
VAX/VMS V4.0

DIGITAL EQUIPMENT CORPORATION  
CONFIDENTIAL AND PROPRIETARY

CONFIG  
LIS

BTMEM855  
LIS

BTMEM790  
LIS

CONFIGURE  
LIS

BOOTDEF  
LIS

BOOTIO  
LIS

BOOTDRIVR  
LIS

BOOTBLOCK  
LIS

BTMEM200  
LIS

BTMEM250  
LIS

BTMEM280  
LIS

CONFIGMN  
LIS