



```

DDDDDDDD LL DDDDDDD RRRRRRR I I I I I VV VV EEEEEEEEE RRRRRRR
DDDDDDDD LL DDDDDDD RRRRRRR I I I I I VV VV EEEEEEEEE RRRRRRR
DD DD DD LL DD DD RR RR RR II II VV VV EE EEEEEEE RR RR RR
DD DD DD LL DD DD RR RR RR II II VV VV EE EEEEEEE RR RR RR
DD DD DD LL DD DD RR RR RR II II VV VV EE EEEEEEE RR RR RR
DD DD DD LL DD DD RR RR RR II II VV VV EE EEEEEEE RR RR RR
DD DD DD LL DD DD RR RR RR II II VV VV EE EEEEEEE RR RR RR
DD DD DD LL DD DD RR RR RR II II VV VV EE EEEEEEE RR RR RR
DD DD DD LL DD DD RR RR RR II II VV VV EE EEEEEEE RR RR RR
DD DD DD LL DD DD RR RR RR II II VV VV EE EEEEEEE RR RR RR
DDDDDDDD LLLLLLLLL DDDDDDD RR RR RR II I I I I I VV VV EEEEEEEEE RRRRRRR
DDDDDDDD LLLLLLLLL DDDDDDD RR RR RR II I I I I I VV VV EEEEEEEEE RRRRRRR

```

```

LL I I I I I SSSSSSS
LL I I I I I SSSSSSS
LL II SSSSSSS
LL II SSSSSSS
LL II SSSSSSS
LL II SSSSSSS
LL II SSSSSSS
LL II SSSSSSS
LL II SSSSSSS
LL II SSSSSSS
LLLLLLLLLL I I I I I SSSSSSS
LLLLLLLLLL I I I I I SSSSSSS

```

DLDRIVER  
Table of contents

- VAX/VMS RL11/RL01,RL02 DISK DRIVER<sup>6 5</sup>

16-SEP-1984 00:17:29 VAX/VMS Macro V04-00

Page 0

DL  
VO

(1)	113	EXTERNAL AND LOCAL DEFINITIONS
(1)	299	STANDARD TABLES
(1)	522	CONTROLLER INITIALIZATION ROUTINE
(1)	572	UNIT INITIALIZATION ROUTINE
(1)	695	DRIVER SPECIFIC SUBROUTINES
(1)	718	FDT ROUTINE - TEST TRANSFER BYTE COUNT ALIGNMENT
(1)	754	START I/O ROUTINE
(1)	1532	INTERRUPT SERVICE ROUTINE
(1)	1593	REGISTER DUMP ROUTINE
(1)	1632	MOVE TO USER BUFFER ROUTINE
(1)	1676	MOVE FROM USER BUFFER ROUTINE

```

0000 1 .TITLE DLDRIVER - VAX/VMS RL11/RL01,RL02 DISK DRIVER
0000 2 .IDENT 'V04-000'
0000 3
0000 4 :*****
0000 5 :*
0000 6 :* COPYRIGHT (c) 1978, 1980, 1982, 1984 BY
0000 7 :* DIGITAL EQUIPMENT CORPORATION, MAYNARD, MASSACHUSETTS.
0000 8 :* ALL RIGHTS RESERVED.
0000 9 :*
0000 10 :* THIS SOFTWARE IS FURNISHED UNDER A LICENSE AND MAY BE USED AND COPIED
0000 11 :* ONLY IN ACCORDANCE WITH THE TERMS OF SUCH LICENSE AND WITH THE
0000 12 :* INCLUSION OF THE ABOVE COPYRIGHT NOTICE. THIS SOFTWARE OR ANY OTHER
0000 13 :* COPIES THEREOF MAY NOT BE PROVIDED OR OTHERWISE MADE AVAILABLE TO ANY
0000 14 :* OTHER PERSON. NO TITLE TO AND OWNERSHIP OF THE SOFTWARE IS HEREBY
0000 15 :* TRANSFERRED.
0000 16 :*
0000 17 :* THE INFORMATION IN THIS SOFTWARE IS SUBJECT TO CHANGE WITHOUT NOTICE
0000 18 :* AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT
0000 19 :* CORPORATION.
0000 20 :*
0000 21 :* DIGITAL ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS
0000 22 :* SOFTWARE ON EQUIPMENT WHICH IS NOT SUPPLIED BY DIGITAL.
0000 23 :*
0000 24 :*
0000 25 :*****
0000 26 :
0000 27 :
0000 28 FACILITY:
0000 29
0000 30 VAX/VMS RL11/RL01,RL02 DISK DRIVER
0000 31
0000 32 AUTHOR:
0000 33
0000 34 C. FRANKS 05-OCT-1979
0000 35
0000 36 MODIFIED BY:
0000 37
0000 38 V03-008 WHM0001 Bill Matthews 15-May-1984
0000 39 Added MicroVAX I/QBUS support.
0000 40
0000 41 V03-007 RAS0300 Ron Schaefer 27-Apr-1984
0000 42 Add DEV$M_NNM characteristic to DECHAR2 so that these
0000 43 devices will have the 'node$' prefix.
0000 44
0000 45 V03-006 PRD0033 Paul R. DeStefano 09-Sep-1983
0000 46 Added EXE$LCLDSKVALID to function decision table.
0000 47
0000 48 V03-005 ROW0211 Ralph O. Weber 16-AUG-1983
0000 49 Change device-dependent UCB definition base from UCBSW_BCR+2
0000 50 to UCBSK_LCL_DISK_LENGTH.
0000 51
0000 52 V03-004 KDM0059 Kathleen D. Morse 14-Jul-1983
0000 53 Change time-wait loops to use new TIMEDWAIT macro.
0000 54
0000 55 V03-003 PRD0020 Paul R. DeStefano 26-Apr-1983
0000 56 Modified FATALERR routine to return $$$_PARITY only for
0000 57 errors that possibly indicate bad media. All other error

```

DLDRIVER  
V04-000

0000 58 : conditions whic' ormerly returned SSS\_PARITY now return  
0000 59 : SSS\_CNLERR.  
0000 60 :  
0000 61 : V03-002 KDM0002 Kathleen D. Morse 28-Jun-1982  
0000 62 : Added \$DYNDEF.  
0000 63 :  
0000 64 : V03-001 KTA0100 Kerbey T. Altmann 07-Jun-1982  
0000 65 : Add code to set UCBSL\_MEDIA\_ID.  
0000 66 :  
0000 67 :\*\*

DL  
VC

```
0000 69 : ABSTRACT:
0000 70 :
0000 71 : THIS MODULE CONTAINS THE TABLES AND ROUTINES NECESSARY TO
0000 72 : PERFORM ALL DEVICE-DEPENDENT PROCESSING OF AN I/O REQUEST
0000 73 : FOR RL11/RL01,RL02 DISK TYPES ON A VAX/VMS SYSTEM.
0000 74 :
0000 75 : THE DISKS HAVE THE FOLLOWING PHYSICAL GEOMETRY:
0000 76 :
0000 77 :           TRACKS/   SECTORS/   BYTES/   MAXIMUM
0000 78 :           # CYL     CYLINDER  TRACK    SECTOR   BLOCKS
0000 79 :
0000 80 : RL01      256        2         40       256      10240
0000 81 : RL02      512        2         40       256      20480
0000 82 :
0000 83 : SINCE THE SECTOR SIZE IS ONLY 1/2 BLOCK, LOGICAL TO PHYSICAL
0000 84 : CONVERSION OF THE DISK ADDRESS IS DONE IN THE DRIVER STARTIO
0000 85 : ROUTINE RATHER THAN IN THE IOC$CVTLOGPHY FDT ROUTINE.
0000 86 :
0000 87 : OVERLAPPED SEEKS ARE NOT ATTEMPTED BECAUSE THE DEVICE DOES
0000 88 : NOT INTERRUPT AT THE COMPLETION OF A SEEK.
0000 89 :
0000 90 : ALSO, THE DEVICE DOES NOT PERFORM AN IMPLICIT SEEK WHEN PERFORMING
0000 91 : A READ OR WRITE FUNCTION,SO SEEK FUNCTIONS ARE ISSUED BY THIS
0000 92 : DRIVER WHERE NECESSARY PRIOR TO ISSUING A READ OR WRITE FUNCTION.
0000 93 : THE READ OR WRITE FUNCTION IS THEN ISSUED AS SOON AS THE RL11
0000 94 : CONTROLLER COMES READY (WHILE THE SEEK IS IN PROGRESS), AND A
0000 95 : WAIT FOR INTERRUPT (UPON COMPLETION OF THE READ OR WRITE) IS
0000 96 : ISSUED. IF A SEEK FUNCTION IS REQUESTED SEPARATELY FROM A READ OR
0000 97 : WRITE, A DUMMY READ HEADER FUNCTION IS ISSUED FOLLOWING THE SEEK
0000 98 : FUNCTION AND A WAIT FOR INTERRUPT (UPON COMPLETION OF THE READ
0000 99 : HEADER) IS ISSUED.
0000 100 :
0000 101 : THE IOSX INHSEEK FUNCTION MODIFIER IS TREATED AS A NO-OP BY
0000 102 : THIS DRIVER, SINCE AN EXPLICIT SEEK IS NECESSARY FOR THE RL02
0000 103 : TO TRANSFER DATA PROPERLY.
0000 104 :
0000 105 : THE RL'S DO NOT READ OR WRITE BEYOND THE END OF TRACK (THEY DO NOT
0000 106 : AUTOMATICALLY SEEK THE NEXT TRACK), SO ALL READ AND WRITE FUNCTIONS
0000 107 : ARE BROKEN UP BY THIS DRIVER INTO PARTIAL TRANSFERS TO THE END OF
0000 108 : TRACK, FOLLOWED BY A SEEK TO THE NEXT TRACK, THEN ANOTHER READ OR
0000 109 : WRITE FUNCTION UNTIL THE TOTAL DATA TRANSFER IS COMPLETE.
0000 110 :
0000 111 :--
```

```

0000 113      .SBTTL  EXTERNAL AND LOCAL DEFINITIONS
0000 114
0000 115      :
0000 116      : EXTERNAL SYMBOLS
0000 117      :
0000 118
0000 119      $ADPDEF      ;DEFINE ADAPTER CONTROL BLOCK
0000 120      $CRBDEF      ;DEFINE CHANNEL REQUEST BLOCK
0000 121      $DCDEF       ;DEFINE DEVICE CLASS
0000 122      $DDBDEF      ;DEFINE DEVICE DATA BLOCK
0000 123      $DEVDEF      ;DEFINE DEVICE CHARACTERISTICS
0000 124      $DPTDEF      ;DEFINE DRIVER PROLOGUE TABLE
0000 125      $DYNDEF      ;DEFINE DYNAMIC DATA STRUCTURE TYPES
0000 126      $EMBDEF      ;DEFINE ERROR MESSAGE BUFFER
0000 127      $IDBDEF      ;DEFINE INTERRUPT DATA BLOCK
0000 128      $IODEF       ;DEFINE I/O FUNCTION CODES
0000 129      $IRPDEF      ;DEFINE I/O REQUEST PACKET
0000 130      $PRDEF       ;DEFINE PROCESSOR REGISTERS
0000 131      $PTEDEF      ;DEFINE SYSTEM PTES
0000 132      $SSDEF       ;DEFINE SYSTEM STATUS CODES
0000 133      $UCBDEF      ;DEFINE UNIT CONTROL BLOCK
0000 134      $VADEF       ;DEFINE VIRTUAL ADDRESS BITS
0000 135      $VECDEF      ;DEFINE INTERRUPT VECTOR BLOCK
0000 136
0000 137      :
0000 138      : LOCAL MACROS
0000 139      :
0000 140
0000 141      :
0000 142      : EXFUNCL
0000 143      : BRANCH TO SUBROUTINE WHICH REQUESTS CHANNEL (IF NOT ALREADY OWNED),
0000 144      : EXECUTES FCODE (OR R3) FUNCTION, AND BRANCHES TO BDST ON ERROR
0000 145      :
0000 146      .MACRO  EXFUNCL  BDST,FCODE
0000 147      .IF  NB  FCODE      ;IS FCODE NON-BLANK?
0000 148      MOVZBL  #CD'FCODE,R3 ;IF NB - SPECIFY FCODE FUNCTION
0000 149      .ENDC      ;IF B - SPECIFY FMTN IN EXISTING R3
0000 150      BSBW  FEXL      ;EXECUTE FUNCTION
0000 151      .BYTE  BDST-.-1    ;WHERE TO GO IF ERROR
0000 152      .ENDM
0000 153
0000 154      :
0000 155      : GENF
0000 156      : GENERATE FUNCTION TABLE ENTRY AND CASE TABLE INDEX SYMBOL
0000 157      :
0000 158      .MACRO  GENF  FCODE
0000 159      CD'FCODE=-.FTAB/2
0000 160      .WORD  FCODE!RL_CS_M_IE ;FCODE WITH INT ENABLE BIT
0000 161      .ENDM
0000 162
0000 163      :
0000 164      : CKPWR
0000 165      : DISABLE INTERRUPTS, CHECK IF POWER HAS FAILED,
0000 166      : AND PUT DEVICE UNIT NUMBER IN R2<9:8>
0000 167      :
0000 168      :
0000 169      .MACRO  CKPWR ?L1
0000 169      CLRL  R2      ;CLEAR R2 FOR UNIT NUMBER

```

```

0000 170      INSV      UCBSW_UNIT(R5),- ;PUT UNIT # IN R2<9:8>
0000 171      #8,#2,R2
0000 172      DSBINT    ;DISABLE INTERRUPTS
0000 173      BBC      #UCBSV_POWER,- ;IF CLR - NO POWER FAILURE
0000 174      UCBSW_STS(R5),L1
0000 175      ENBINT    ;POWER FAILURE - ENABLE INTERRUPTS
0000 176      BRW      RETREG ;EXIT
0000 177      L1:      ;RETURN FOR NO POWER FAILURE
0000 178      .ENDM
0000 179
0000 180
0000 181      ;
0000 182      ; LOCAL SYMBOLS
0000 183      ;
0000 184      ;
00000004 0000 185      RL_NUM_REGS =4 ;NUMBER OF DEVICE REGISTERS
00000005 0000 186      RL_SLM =5 ;STATE=SEEK LINEAR MODE (READY TO GO)
000000C9 0000 187      UCBSB_DL_DCHEK =UCBSW_OFFSET+1 ;REDEFINE FOR DATA CHECK USE
0000 188      ;
0000 189      ;
0000 190      ; UCB OFFSETS WHICH FOLLOW THE STANDARD UCB FIELDS
0000 191      ;
0000 192      $DEFINI UCB ;START OF UCB DEFINITIONS
0000 193      ;
000000CC 0000 194      .=UCBSK_LCL_DISK_LENGTH ;BEGIN DEFINITIONS AT END OF UCB
00CC 195      $DEF UCBSW_DL_PBCR .BLKW 1 ;PARTIAL BYTE COUNT
00CE 196      $DEF UCBSW_DL_CS .BLKW 1 ;CONTROL STATUS REGISTER
00D0 197      $DEF UCBSW_DL_BA .BLKW 1 ;BUS ADDRESS REGISTER
00D2 198      $DEF UCBSW_DL_DA .BLKW 1 ;DISK ADDRESS REGISTER
00D4 199      $DEF UCBSW_DL_MP .BLKW 1 ;MULTIPURPOSE REGISTER
00D6 200      $DEF UCBSW_DL_DPN .BLKW 1 ;DATA PATH NUMBER
00D8 201      $DEF UCBSL_DL_SVAPTE ;SAVED SVAPTE OF THE USER'S BUFFER
00D8 202      $DEF UCBSL_DL_DPR .BLKL 1 ;DATAPATH REGISTER
00DC 203      $DEF UCBSL_DL_BUFADR ;USER BUFFER ADDRESS
00DC 204      $DEF UCBSL_DL_FMPR .BLKL 1 ;FINAL MAP REGISTER
00E0 205      $DEF UCBSA_DL_MOVRTN ;BUFFER MOVE ROUTINE ADDRESS
00E0 206      $DEF UCBSL_DL_PMPR .BLKL 1 ;PREVIOUS MAP REGISTER
00E4 207      $DEF UCBSB_DL_DPPE .BLKB 1 ;DATAPATH PURGE ERROR
00E5 208      $DEF UCBSW_DL_DB .BLKW 3 ;DATA BUFFER REGISTER
00EB 209      $DEF UCBSB_DL_XBA .BLKB 1 ;BUS ADDRESS EXTENSION BITS
00EC 210      $DEF UCBSW_DL_SBA .BLKW 1 ;SAVED BUFFER ADDRESS
00EE 211      $DEF UCBSA_DL_BUF_VA .BLKL 1 ;PHYSICAL BUFFER VIRTUAL ADDRESS
00F2 212      $DEF UCBSA_DL_BUF_PA .BLKL 1 ;PHYSICAL BUFFER PHYSICAL ADDRESS
00F6 213      $DEF UCBSW_DL_FLAGS .BLKW 1 ;FLAGS
00F8 214      $VIELD UCB,0,<- ;START THE FLAG DEFINITIONS
00F8 215      <DL_22BIT,,M>,- ;22 BIT ADDRESSING
00F8 216      <DL_MAPPING,,M>,- ;ADAPTER MAPPING
00F8 217      > ;END OF FLAG DEFINITIONS
00F8 218      $DEF UCBSK_DL_LEN .BLKW 1 ;LENGTH OF UCB
00FA 219      $EQU UCBSK_DL_BUFSZ 20 ;BUFFER SIZE = 40 SECTORS *
00FA 220      ;256 BYTES/SECTOR / 512 BYTES/PAGE
00FA 221      $DEFEND UCB ;END OF UCB DEFINITIONS
0000 222      ;
0000 223      ;
0000 224      ; RL11/RL01 REGISTER OFFSETS FROM CSR ADDRESS
0000 225      ;
0000 226      $DEFINI RL ; START OF REGISTER DEFINITIONS

```



```

0000 227
0000 228 $DEF RL_CS .BLKW 1 ;CONTROL STATUS REGISTER (CSR)
0002 229 _VIELD RL_CS,0,<- ;START OF CSR BIT DEFINITIONS
0002 230 <DRDY,,M>,- ;DRIVE READY
0002 231 <FCODE,,3>,- ;FUNCTION CODE
0002 232 <XBA,,2>,- ;BUS ADDRESS EXTENSION BITS
0002 233 <IE,,M>,- ;INTERRUPT ENABLE
0002 234 <CRDY,,M>,- ;CONTROLLER READY
0002 235 <DS,,2>,- ;DRIVE SELECT
0002 236 <OPI,,M>,- ;OPERATION INCOMPLETE
0002 237 <CRC,,M>,- ;DATA CRC OR HEADER CRC
0002 238 <DLT,,M>,- ;DATA LATE OR HEADER NOT FOUND
0002 239 <NXM,,M>,- ;NON-EXISTENT MEMORY
0002 240 <DE,,M>,- ;DRIVE ERROR
0002 241 <CE,,M>,- ;COMPOSITE ERROR
0002 242 > ;END CSR BIT DEFINITIONS
0002 243
0002 244 $DEF RL_BA .BLKW 1 ;BUS ADDRESS REGISTER (BAR)
0004 245
0004 246 $DEF RL_DA .BLKW 1 ;DISK ADDRESS REGISTER (DAR)
0006 247 _VIELD RL_DA,0,<- ;START OF DAR BIT DEFINITIONS
0006 248 <MRK,,M>,- ;MARK (ALWAYS 1)
0006 249 <STS,,M>,- ;GET STATUS
0006 250 <,1>,- ;RESERVED BIT
0006 251 <RST,,M>,- ;RESET
0006 252 <,12>,- ;RESERVED BITS
0006 253 > ;END OF DAR BIT DEFINITIONS
0006 254
0006 255 $DEF RL_MP .BLKW 1 ;MULTIPURPOSE REGISTER (MPR)
0008 256 _VIELD RL_MP,0,<- ;START OF MPR BIT DEFINITIONS
0008 257 <STA,,3>,- ;DRIVE STATE
0008 258 <BH,,M>,- ;BRUSH HOME
0008 259 <HO,,M>,- ;HEADS OUT
0008 260 <CO,,M>,- ;COVER OPEN
0008 261 <HS,,M>,- ;HEAD SELECT
0008 262 <TYP,,M>,- ;DRIVE TYPE
0008 263 <DSE,,M>,- ;DRIVE SELECT ERROR
0008 264 <VC,,M>,- ;VOLUME CHECK
0008 265 <WGE,,M>,- ;WRITE GATE ERROR
0008 266 <SPE,,M>,- ;SPIN ERROR
0008 267 <SKTO,,M>,- ;SEEK TIME OUT
0008 268 <WL,,M>,- ;WRITE LOCK
0008 269 <CHE,,M>,- ;CURRENT HEAD ERROR
0008 270 <WDE,,M>,- ;WRITE DATA ERROR
0008 271 > ;END MPR BIT DEFINITIONS
0008 272
0008 273 $DEF RL_BAE .BLKW 1 ;BUS ADDRESS EXTENSION REGISTER(BAE)
000A 274 $DEFEND RL ;END RL11/RL01 REGISTER DEFINITIONS
0000 276
0000 277 ;
0000 278 ; HARDWARE FUNCTION CODES
0000 279 ;
00000000 0000 280 F_NOP=0*2 ;NO OPERATION
00000000 0000 281 F_UNLOAD=F_NOP ;NO OPERATION
00000006 0000 282 F_SEEK=3*2 ;SEEK CYLINDER
00000000 0000 283 F_RECAL=F_NOP ;NO OPERATION

```

00000004	0000	284	F_DRVCLR=2*2	:DRIVE CLEAR (GET STATUS)
00000000	0000	285	F_RELEASE=F_NOP	:NO OPERATION
00000000	0000	286	F_OFFSET=F_NOP	:NO OPERATION
00000000	0000	287	F_RETCENTER=F_NOP	:NO OPERATION
00000004	0000	288	F_PACKACK=2*2	:PACK ACKNOWLEDGE (SET VOLUME VALID)
00000000	0000	289	F_SEARCH=F_NOP	:NO OPERATION
00000002	0000	290	F_WRITECHECK=1*2	:WRITE CHECK
0000000A	0000	291	F_WRITEDATA=5*2	:WRITE DATA
00000000	0000	292	F_WRITEHEAD=F_NOP	:NO OPERATION
0000000C	0000	293	F_READDATA=6*2	:READ DATA
00000008	0000	294	F_READHEAD=4*2	:READ HEADER
00000000	0000	295	F_AVAILABLE=F_NOP	:NO OPERATION
00000004	0000	296	F_GETSTATUS=2*2	:GET STATUS (DRIVER INTERNAL USE)
	0000	297		

```

0000 299      .SBTTL STANDARD TABLES
0000 300
0000 301      :
0000 302      : DRIVER PROLOGUE TABLE
0000 303      :
0000 304      : THE DPT DESCRIBES DRIVER PARAMETERS AND I/O DATABASE FIELDS
0000 305      : THAT ARE TO BE INITIALIZED DURING DRIVER LOADING AND RELOADING
0000 306      :
0000 307      :
0000 308      DPTAB      -      ;DPT CREATION MACRO
0000 309      END=DL END,-      ;END OF DRIVER LABEL
0000 310      ADAPTER=UBA,-      ;ADAPTER TYPE = UNIBUS
0000 311      FLAGS=DPT$M_SVP,-      ;SYSTEM PAGE TABLE ENTRY REQUIRED
0000 312      UCBSIZE=UCB$K_DL_LEN,-      ;LENGTH OF UCB
0000 313      NAME=DLDRIVER      ;DRIVER NAME
0038 314
0038 315      DPT_STORE INIT      ;START CONTROL BLOCK INIT VALUES
0038 316      DPT_STORE DDB,DB$K_ACPD,L,<^A\F11\> ;DEFAULT ACP NAME
003F 317      DPT_STORE DDB,DB$K_ACPD+3,B,DB$K_CART ;ACP CLASS
0043 318      DPT_STORE UCB,UCB$B_FIPL,B,8      ;FORK IPL
0047 319      DPT_STORE UCB,UCB$K_DEVCHAR,L,-      ;DEVICE CHARACTERISTICS
0047 320      <DEV$M_FOD-      ;FILES ORIENTED
0047 321      !DEV$M_DIR-      ;DIRECTORY STRUCTURED
0047 322      !DEV$M_AVL-      ;AVAILABLE
0047 323      !DEV$M_ELG-      ;ERROR LOGGING
0047 324      !DEV$M_SHR-      ;SHAREABLE
0047 325      !DEV$M_IDV-      ;INPUT DEVICE
0047 326      !DEV$M_ODV-      ;OUTPUT DEVICE
0047 327      !DEV$M_RND>      ;RANDOM ACCESS
004E 328      DPT_STORE UCB,UCB$K_DEVCHAR2,L,-      ;DEVICE CHARACTERISTICS
004E 329      <DEV$M_NNM>      ;PREFIX NAME WITH 'node$'
0055 330      DPT_STORE UCB,UCB$B_DEVCLASS,B,DC$ DISK ;DEVICE CLASS
0059 331      DPT_STORE UCB,UCB$W_DEVBUFSIZ,W,512 ;DEFAULT BUFFER SIZE
005E 332      DPT_STORE UCB,UCB$B_SECTORS,B,40 ;NUMBER OF SECTORS PER TRACK
0062 333      DPT_STORE UCB,UCB$B_TRACKS,B,2 ;NUMBER OF TRACKS PER CYLINDER
0066 334      DPT_STORE UCB,UCB$B_DIPL,B,21 ;DEVICE IPL
006A 335      DPT_STORE UCB,UCB$B_ERTMAX,B,8 ;MAX ERROR RETRY COUNT
006E 336      DPT_STORE UCB,UCB$W_DEVSTS,W,-      ;INHIBIT LOG TO PHYS CONVERSION IN FDT
006E 337      <UCB$M_NOCNVRT>      ;...
0073 338
0073 339      DPT_STORE REINIT      ;START CONTROL BLOCK RE-INIT VALUES
0073 340      DPT_STORE CRB,CRB$K_INTD+4,D,DL INT ;INTERRUPT SERVICE ROUTINE ADDRESS
0078 341      DPT_STORE CRB,CRB$K_INTD+VEC$K_INITIAL,- ;CONTROLLER INIT ADDRESS
0078 342      D,DL RL11 INIT      ;...
007D 343      DPT_STORE CRB,CRB$K_INTD+VEC$K_UNITINIT,- ;UNIT INIT ADDRESS
007D 344      D,DL RLOX_INIT      ;...
0082 345      DPT_STORE DDB,DB$K_DDT,D,DL$DDT ;DDT ADDRESS
0087 346
0087 347      DPT_STORE END      ;END OF INITIALIZATION TABLE
0000 348
0000 349      :
0000 350      : DRIVER DISPATCH TABLE
0000 351      :
0000 352      : THE DDT LISTS ENTRY POINTS FOR DRIVER SUBROUTINES WHICH ARE
0000 353      : CALLED BY THE OPERATING SYSTEM.
0000 354      :
0000 355

```

```

0000 356          DDTAB -                ;DDT CREATION MACRO
0000 357          DEVNAM=DL -           ;NAME OF DEVICE
0000 358          START=DL $STARTIO,-  ;START I/O ROUTINE
0000 359          UNSOLIC=DL UNSOLNT,-  ;UNSOLICITED INTERRUPT
0000 360          FUNCTB=DL FUNCTABLÉ,- ;FUNCTION DECISION TABLE
0000 361          CANCEL=0,-            ;CANCEL=NO-OP FOR FILES DEVICE
0000 362          REGDMP=DL REGDUMP,-    ;REGISTER DUMP ROUTINE
0000 363          DIAGBF=<<<RL_NUM_REGS+5+5+3+1>*4>,- ;BYTES IN DIAG BUFFER
0000 364          ERLGBF=<<<<RL_NUM_REGS+5+1>*4>+EMBSL_DV_REGSAV> ;BYTES IN
0038 365                                               ;ERROR LOG BUFFER
0038 366
0038 367 : DIAGNOSTIC BUFFER SIZE = <<<4 RL02 REGISTER LONGWORDS + 5 UCB FIELD LONGWORDS
0038 368 : + 5 IOC$DIAGBUFILL LONGWORDS + 3 BUFFER ALLOCATION
0038 369 : LONGWORDS + 1 LONGWORD FOR # REGISTERS IN DL_REGDUMP>
0038 370 : * 4 BYTES/LONGWORD>
0038 371
0038 372 : ERROR LOG BUFFER SIZE = <<<<4 RL02 REGISTER LONGWORDS + 5 UCB FIELD LONGWORDS
0038 373 : + 1 LONGWORD FOR # REGISTERS IN DL_REGDUMP>
0038 374 : * 4 BYTES/LONGWORD> + BYTES NEEDED FOR ERROR LOGGER
0038 375 : TO SAVE SOFTWARE REGISTERS>
0038 376
0038 377
0038 378 :
0038 379 : HARDWARE FUNCTION CODE TABLE
0038 380 :
0038 381 : THIS TABLE MERGES THE FUNCTION CODE BITS WITH THE
0038 382 : INTERRUPT ENABLE BIT AND GENERATES THE CASE TABLE
0038 383 : INDEX SYMBOL.
0038 384
0038 385 FTAB: GENF F_NOP                ;NO-OP
003A 386 GENF F_UNLOAD                ;UNLOAD VOLUME (NOP)
003C 387 GENF F_SEEK                  ;SEEK
003E 388 GENF F_RECAL                 ;RECALIBRATE (NOP)
0040 389 GENF F_DRVCLR                ;DRIVE CLEAR (RESET & GET STATUS)
0042 390 GENF F_RELEASE               ;RELEASE PORT (NOP)
0044 391 GENF F_OFFSET                ;OFFSET HEADS (NOP)
0046 392 GENF F_RETCENTER              ;RETURN HEADS TO CENTERLINE (NOP)
0048 393 GENF F_PACKACK                ;PACK ACKNOWLEDGE (RESET & GET STATUS)
004A 394 GENF F_SEARCH                 ;SEARCH (NOP)
004C 395 GENF F_WRITECHECK             ;WRITE CHECK
004E 396 GENF F_WRITEDATA              ;WRITE DATA
0050 397 GENF F_READDATA               ;READ DATA
0052 398 GENF F_WRITEHEAD              ;WRITE HEADERS (NOP)
0054 399 GENF F_READHEAD               ;READ HEADERS
0056 400 GENF F_NOP                    ;place holder
0058 401 GENF F_NOP                    ;place holder
005A 402 GENF F_AVAILABLE              ;AVAILABLE
005C 403

```

```

005C 405 :
005C 406 : FUNCTION DECISION TABLE
005C 407 :
005C 408 : THE FDT LISTS VALID FUNCTION CODES, SPECIFIES WHICH
005C 409 : CODES ARE BUFFERED, AND DESIGNATES SUBROUTINES TO
005C 410 : PERFORM PREPROCESSING FOR PARTICULAR FUNCTIONS.
005C 411 :
005C 412 :
005C 413 DL_FUNCABLE:
005C 414 FUNCTAB :- ;LIST LEGAL FUNCTIONS
005C 415 <NOP,- ; NO-OP
005C 416 UNLOAD,- ; UNLOAD
005C 417 SEEK,- ; SEEK
005C 418 DRVCLR,- ; DRIVE CLEAR
005C 419 PACKACK,- ; PACK ACKNOWLEDGE
005C 420 SENSECHAR,- ; SENSE CHARACTERISTICS
005C 421 SETCHAR,- ; SET CHARACTERISTICS
005C 422 SENSEMODE,- ; SENSE MODE
005C 423 SETMODE,- ; SET MODE
005C 424 WRITECHECK,- ; WRITE CHECK
005C 425 READHEAD,- ; READ HEADER
005C 426 READLBLK,- ; READ LOGICAL BLOCK
005C 427 WRITELBLK,- ; WRITE LOGICAL BLOCK
005C 428 READPBLK,- ; READ PHYSICAL BLOCK
005C 429 WRITEPBLK,- ; WRITE PHYSICAL BLOCK
005C 430 READVBLK,- ; READ VIRTUAL BLOCK
005C 431 WRITEVBLK,- ; WRITE VIRTUAL BLOCK
005C 432 AVAILABLE,- ; AVAILABLE
005C 433 ACCESS,- ; ACCESS FILE / FIND DIRECTORY ENTRY
005C 434 ACPCONTROL,- ; ACP CONTROL FUNCTION
005C 435 CREATE,- ; CREATE FILE AND/OR DIRECTORY ENTRY
005C 436 DEACCESS,- ; DEACCESS FILE
005C 437 DELETE,- ; DELETE FILE AND/OR DIRECTORY ENTRY
005C 438 MODIFY,- ; MODIFY FILE ATTRIBUTES
005C 439 MOUNT- ; MOUNT VOLUME
005C 440 >
0064 441 FUNCTAB :- ;BUFFERED FUNCTIONS
0064 442 <NOP,- ; NO-OP
0064 443 UNLOAD,- ; UNLOAD
0064 444 SEEK,- ; SEEK
0064 445 DRVCLR,- ; DRIVE CLEAR
0064 446 PACKACK,- ; PACK ACKNOWLEDGE
0064 447 SENSECHAR,- ; SENSE CHARACTERISTICS
0064 448 SETCHAR,- ; SET CHARACTERISTICS
0064 449 SENSEMODE,- ; SENSE MODE
0064 450 SETMODE,- ; SET MODE
0064 451 AVAILABLE,- ; AVAILABLE
0064 452 ACCESS,- ; ACCESS FILE / FIND DIRECTORY ENTRY
0064 453 ACPCONTROL,- ; ACP CONTROL FUNCTION
0064 454 CREATE,- ; CREATE FILE AND/OR DIRECTORY ENTRY
0064 455 DEACCESS,- ; DEACCESS FILE
0064 456 DELETE,- ; DELETE FILE AND/OR DIRECTORY ENTRY
0064 457 MODIFY,- ; MODIFY FILE ATTRIBUTES
0064 458 MOUNT- ; MOUNT VOLUME
0064 459 >
006C 460 FUNCTAB DL ALIGN,- ;TEST ALIGNMENT FUNCTIONS
006C 461 <READHEAD,- ; READ HEADER

```

```
006C 462 READBLK,- : READ LOGICAL BLOCK
006C 463 READPBLK,- : READ PHYSICAL BLOCK
006C 464 READVBLK,- : READ VIRTUAL BLOCK
006C 465 WRITECHECK,- : WRITE CHECK
006C 466 WRITELBLK,- : WRITE LOGICAL BLOCK
006C 467 WRITEPBLK,- : WRITE PHYSICAL BLOCK
006C 468 WRITEVBLK- : WRITE VIRTUAL BLOCK
006C 469 >
0078 470 FUNCTAB +ACPSREADBLK,- :READ FUNCTIONS
0078 471 <READHEAD,- : READ HEADER
0078 472 READBLK,- : READ LOGICAL BLOCK
0078 473 READPBLK,- : READ PHYSICAL BLOCK
0078 474 READVBLK- : READ VIRTUAL BLOCK
0078 475 >
0084 476 FUNCTAB +ACPSWRITEBLK,- :WRITE FUNCTIONS
0084 477 <WRITECHECK,- : WRITE CHECK
0084 478 WRITELBLK,- : WRITE LOGICAL BLOCK
0084 479 WRITEPBLK,- : WRITE PHYSICAL BLOCK
0084 480 WRITEVBLK- : WRITE VIRTUAL BLOCK
0084 481 >
0090 482 FUNCTAB +ACPSACCESS,- :ACCESS FUNCTIONS
0090 483 <ACCESS,- : ACCESS FILE / FIND DIRECTORY ENTRY
0090 484 CREATE- : CREATE FILE AND/OR DIRECTORY ENTRY
0090 485 >
009C 486 FUNCTAB +ACPSDEACCESS,- :DEACCESS FUNCTION
009C 487 <DEACCESS- : DEACCESS FILE
009C 488 >
00A8 489 FUNCTAB +ACPSMODIFY,- :MODIFY FUNCTIONS
00A8 490 <ACPCONTROL,- : ACP CONTROL FUNCTION
00A8 491 DELETE,- : DELETE FILE AND/OR DIRECTORY ENTRY
00A8 492 MODIFY- : MODIFY FILE ATTRIBUTES
00A8 493 >
00B4 494 FUNCTAB +ACPSMOUNT,- :MOUNT FUNCTION
00B4 495 <MOUNT- : MOUNT VOLUME
00B4 496 >
00C0 497 FUNCTAB +EXESLCLDSKVALID,- :LOCAL DISK VALID FUNCTIONS
00C0 498 <UNLOAD,- :UNLOAD VOLUME
00C0 499 AVAILABLE,- :UNIT AVAILABLE
00C0 500 PACKACK- :PACK ACKNOWLEDGE
00C0 501 >
00CC 502 FUNCTAB +EXESZEROPARM,- :ZERO PARAMETER FUNCTIONS
00CC 503 <NOP,- : NO-OP
00CC 504 UNLOAD,- : UNLOAD
00CC 505 DRVCLR,- : DRIVE CLEAR
00CC 506 PACKACK,- : PACK ACKNOWLEDGE
00CC 507 AVAILABLE,- : AVAILABLE
00CC 508 >
00D8 509 FUNCTAB +EXESONEPARM,- :ONE PARAMETER FUNCTION
00D8 510 <SEEK- : SEEK
00D8 511 >
00E4 512 FUNCTAB +EXESSENSEMODE,- :SENSE FUNCTIONS
00E4 513 <SENSECHAR,- : SENSE CHARACTERISTICS
00E4 514 SENSEMODE- : SENSE MODE
00E4 515 >
00F0 516 FUNCTAB +EXESSETCHAR,- :SET FUNCTIONS
00F0 517 <SETCHAR,- : SET CHARACTERISTICS
00F0 518 SETMODE- : SE, MODE
```

DLDRIVER  
V04-000

- VAX/VMS RL11/RL01,RL02 DISK DRIVER<sup>F 6</sup>  
STANDARD TABLES

00F0 519

>

16-SEP-1984 00:17:29  
5-SEP-1984 00:12:24

VAX/VMS Macro V04-00  
[DRIVER.SRC]DLDRIVER.MAR;1

Page 12  
(1)

DL  
VC

```

00FC 521
00FC 522 .SBTTL CONTROLLER INITIALIZATION ROUTINE
00FC 523 :++
00FC 524
00FC 525 : FUNCTIONAL DESCRIPTION:
00FC 526
00FC 527 : THIS ROUTINE IS A NO-OP FOR THE RL11 BUT MUST BE INCLUDED
00FC 528 : SINCE IT IS CALLED WHEN THE RL02 IS BOOTED AS A SYSTEM DEVICE.
00FC 529
00FC 530 : THE OPERATING SYSTEM CALLS THIS ROUTINE:
00FC 531 : - AT SYSTEM STARTUP
00FC 532 : - DURING DRIVER LOADING
00FC 533 : - DURING RECOVERY FROM POWER FAILURE
00FC 534
00FC 535 : INPUTS:
00FC 536
00FC 537 : R4 - CSR ADDRESS (DEVICE CONTROL STATUS REGISTER)
00FC 538 : R5 - IDB ADDRESS (INTERRUPT DATA BLOCK)
00FC 539 : R6 - DDB ADDRESS (DEVICE DATA BLOCK)
00FC 540 : R8 - CRB ADDRESS (CHANNEL REQUEST BLOCK)
00FC 541 : ALL INTERRUPTS ARE LOCKED OUT
00FC 542
00FC 543 : OUTPUTS:
00FC 544
00FC 545 : ALL REGISTERS EXCEPT R0-R3 ARE PRESERVED.
00FC 546 : CONTROL IS RETURNED TO THE CALLER.
00FC 547
00FC 548 :--
00FC 549
00FC 550 DL_RL11_INIT: ;CONTROLLER INITIALIZATION
00FC 551
00FC 552 : FOR MICROVAX I, ALLOCATE A PHYSICALLY CONTIGUOUS BUFFER
00FC 553 : AREA FOR PERFORMING I/O.
00FC 554
00FC 555 (PUDISP <<790,20$>,-
00FC 556 <785,20$>,-
00FC 557 <780,20$>,-
00FC 558 <750,20$>,-
00FC 559 <730,20$>,-
00FC 560 <UV1,10$>> ;FOR MICROVAX I, ALLOCATE BUFFER AREA
012E 561 ;FOR ALL OTHERS, SKIP BUFFER AREA
012E 562
00000000'GF 51 14 3C 012E 563 10$: MOVZWL #UCB$K_DL_BUFSZ,R1 ;LOAD SIZE OF BUFFER
05 50 E9 0131 564 JSB G^EXE$XLOPHYCNTG ;ALLOCATE PHYSICALLY-CONTIGUOUS MEMORY
10 A8 52 D0 0137 565 BLBC R0,20$ ;EXIT ON ERROR
05 013A 566 MOVL R2,CRB$L_AUXSTRUC(R8) ;GET BUFFER VIRTUAL ADDRESS
05 013E 567 RSB ;RETURN TO CALLER
013F 568
10 A8 D4 013F 569 20$: CLRL CRB$L_AUXSTRUC(R8) ;INDICATE MEMORY ALLOCATION FAILURE
05 0142 570 RSB ;RETURN TO CALLER

```



```

0143 572          .SBTTL UNIT INITIALIZATION ROUTINE
0143 573
0143 574      :++
0143 575
0143 576      : DL_RLOX_INIT - UNIT INITIALIZATION ROUTINE
0143 577
0143 578      : FUNCTIONAL DESCRIPTION:
0143 579
0143 580          THIS ROUTINE READIES THE RL01/RL02 UNITS FOR I/O OPERATIONS.
0143 581
0143 582          THE OPERATING SYSTEM CALLS THIS ROUTINE:
0143 583              - AT SYSTEM STARTUP
0143 584              - DURING DRIVER LOADING
0143 585              - DURING RECOVERY FROM POWER FAILURE
0143 586
0143 587      : INPUTS:
0143 588
0143 589          R4      - CSR ADDRESS (CONTROLLER STATUS REGISTER)
0143 590          R5      - UCB ADDRESS (UNIT CONTROL BLOCK)
0143 591
0143 592      : OUTPUTS:
0143 593
0143 594          THE DRIVE UNIT IS RESET, UCB FIELDS ARE INITIALIZED, AND THE
0143 595          ROUTINE WAITS FOR ONLINE UNITS TO SPIN UP. ALL REGISTERS
0143 596          EXCEPT R0-R3 ARE PRESERVED.
0143 597
0143 598      :--
0143 599
0143 600      DL_RLOX_INIT:          ;RL01/RL02 UNIT INITIALIZATION
0143 601      MOVW      #1@UCBSV_DL_MAPPING,- ; DEFAULT TO ADAPTER MAPPING
0143 602      UCBSW_DL_FLAGS(R5) ; AND 18 BIT ADDRESSING
0143 603
0143 604      : SET CPU DEPENDENT UCB FLAGS FOR DL
0143 605
0143 606      CPUDISP <<790,10$>,-
0143 607      <<785,10$>,-
0143 608      <<780,10$>,-
0143 609      <<750,10$>,-
0143 610      <<730,10$>,-
0143 611      <<UV1,5$>>
0143 612      5$:      MOVW      #1@UCBSV_DL_22BIT,- ; FOR MICROVAX I 22 BIT
0143 613      UCBSW_DL_FLAGS(R5) ; ADDRESSING AND NO ADAPTER MAPPING
0143 614      10$:     MOVZWL   UCBSW_STS(R5),R3 ; SAVE CURRENT UNIT STATUS
0143 615      BICW      #UCBSM_ONLINE!UCBSM_VALID,- ; ASSUME OFFLINE/INVALID
0143 616      UCBSW_STS(R5) ;...
0143 617
0143 618      :
0143 619      : WAIT FOR CONTROLLER (6 SECONDS MAX) IF CHANNEL IS BUSY WITH ANOTHER UNIT
0143 620      :
0143 621
0143 622      MOVL     UCB$L_CRB(R5),R0 ; GET CRB ADDRESS
0143 623      BBC     #CRB$V_BSY,CRB$B_MASK(R0),20$ ; IF CLEAR - CHANNEL NOT BUSY
0143 624      TIMEDWAIT TIME=#600*1000,- ; 6 SECOND WAIT LOOP
0143 625      INS1=<TSTB RL(CS(R4))>,- ; IS CONTROLLER READY
0143 626      INS2=<BLSS 15$>,- ; IF LSS - YES
0143 627      DONELBL=15$ ; LABEL TO EXIT WAIT LOOP
0143 628      BLBC    R0,25$ ; TIME EXPIRED - EXIT

```

```

01BB 629 :
01BB 630 : GET CURRENT DRIVE STATUS AND RESET DRIVE
01BB 631 :
01BB 632 :
04 A4 0B B0 01BB 633 20$: MOVW #RL_DA_M_RST!- ;PUT RESET AND GET STATUS IN DAR
01BF 634 RL_DA_M_STS!RL_DA_M_MRK,RL_DA(R4) ;...
51 08 08 54 A5 F0 01CF 635 CLR R1 ;CLEAR R1 FOR UNIT NUMBER
64 04 51 A9 01C7 636 INSV UCBSW_UNIT(R5),#8,#8,R1 ;GET UNIT NUMBER
0095 30 01CB 637 B1SW3 R1,#F_GETSTATUS,RL_CS(R4) ;EXECUTE GET STATUS FUNCTION
64 95 01CE 638 BSBW DL_WAIT ;WAIT FOR CONTROLLER
24 18 01D0 639 TSTB RL_CS(R4) ;WAS CONTROLLER READY?
01D2 640 BGEQ 25$ ;IF GEQ - NO
01D2 641 :
01D2 642 :
01D2 643 : CLASSIFY DRIVE TYPE
01D2 644 :
01D2 645 :
2324C001 8F D0 01D2 646 MOVL #*X2324C001,-
008C C5 01D8 647 UCBSL_MEDIA_ID(R5) ;SET MEDIA IDENT 'DL RL01'
06 A4 0080 8F B3 01DB 648 BITW #RL_MP_M_TYP,RL_MP(R4) ;IS DRIVE TYPE = RL02?
15 12 01E1 649 BNEQ 30$ ;IF NEQ - YES
09 90 01E3 650 MOVB S^#DTS_RL01,-
41 A5 01E5 651 UCBSB_DEVTYPE(R5) ;SET RL01 DEVICE TYPE
46 A5 0100 8F B0 01E7 652 MOVW #256,UCBSW_CYLINDERS(R5);SET NUMBER OF RL01 CYLINDERS
0080 C5 2800 8F 3C 01ED 653 MOVZWL #10240,UCBSL_MAXBLOCK(R5) ;SET MAX RL01 BLOCK NUMBER
17 11 01F4 654 BRB 40$
6A 11 01F6 655 BRB 70$ ;BRANCH TO COMMON EXIT
01F8 656 25$: BRB 70$ ;BRANCH TO COMMON EXIT
01FA 657 30$: MOVB S^#DTS_RL02,-
41 A5 01FA 658 UCBSB_DEVTYPE(R5) ;SET RL02 DEVICE TYPE
46 A5 0200 8F B0 01FC 659 MOVW #512,UCBSW_CYLINDERS(R5);SET NUMBER OF RL02 CYLINDERS
0080 C5 5000 8F 3C 0202 661 MOVZWL #20480,UCBSL_MAXBLOCK(R5) ;SET MAX RL02 BLOCK NUMBER
008C C5 D6 0209 662 INCL UCBSL_MEDIA_ID(R5) ;SET MEDIA IDENT 'DL RL02'
16 53 0B E1 020D 663 40$: BBC #UCBSV_VALID,R3,60$ ; Branch around wait for drive to spinup
0211 664 ; if the drive did NOT have a VALID
0211 665 ; volume on it before POWER failure.
0211 666 :
0211 667 :
0211 668 : INITIALIZE UCB FIELDS AND WAIT FOR ONLINE UNITS TO SPIN UP
0211 669 :
0211 670 :
64 01 B3 0211 671 45$: BITW #RL_CS_M_DRDY,RL_CS(R4) ; Is drive ready?
0B 12 0214 672 BNEQ 50$ ;IF NEQ - YES
00000000 GF 16 0216 673 JSB G^EXESPWRTIMCHK ;IS MAX TIME EXCEEDED?
F2 50 E8 021C 674 BLBS R0,45$ ;IF LBS - NO, STILL MORE TIME NEEDED
06 11 021F 675 BRB 60$ ;POWER UP TIME EXCEEDED
0221 676 50$:
64 A5 0800 8F A8 0221 677 BISW #UCBSM_VALID,UCBSW_STS(R5) ;SET UCB STATUS VOLUME VALID
0227 678
01 E0 0227 679 60$: BBS #UCBSV_DL_MAPPING,- ;ADAPTER MAPPING?
31 00F6 C5 0229 680 UCBSW_DL_FLAGS(R5),65$ ;IF BS YES
51 24 A5 D0 022D 681 MOVL UCBSL_CRB(R5),R1 ;GET CRB ADDRESS
52 10 A1 D0 0231 682 MOVL CRBSL_AUXSTRU(R1),R2 ;MEMORY ALLOC FAILURE DURING CTL INIT?
28 13 0235 683 BEQL 70$ ;IF EQL YES, LEAVE OFFLINE
00EE C5 52 D0 0237 684 MOVL P^,UCBSA_DL_BUF_VA(R5) ;SAVE BUFFER'S VIRTUAL ADDRESS
51 52 15 09 EF 023C 685 EXTZV #VASV_VPN,#VASS_VPN,R2,R1 ;GET VIRTUAL PAGE NUMBER OF BUFFER

```

50	00000000	'GF	DO	0241	686	MOVL	G*MMG\$GL_SPTBASE,R0	;GET BASE ADDRESS OF SPTS
	50	6041	DO	0248	687	MOVL	(R0)[R1],R0	;GET THE PTE CONTENTS
51	52	FFFFFFE0	BF	CB	024C	688	BICL3	#^C<VASM BYTE>,R2,R1 ;GET BUFFER OFFSET (BA00-BA08)
					0254	689	ASSUME	PTES\$ PFR GE 13
51	0D	09	50	FO	0254	690	INSV	R0,#9,#13,R1 ;COPY BA09-BA21
	00F2	C5	51	DO	0259	691	MOVL	R1,UCBSA_DL_BUF_PA(R5) ;SAVE PHYSICAL ADDRESS OF BUFFER
	64	A5	10	AB	025E	692	BISW	#UCBSM_ONLINE,UCBSW_STS(R5) ;SET UCB STATUS VOLUME VALID
				05	0262	693	RSB	708:

```

0263 695          .SBTTL DRIVER SPECIFIC SUBROUTINES
0263 696          :
0263 697          : DL_WAIT - WAIT FOR CONTROLLER READY
0263 698          :
0263 699          : INPUTS:
0263 700          : R4          - DEVICE CSR ADDRESS
0263 701          :
0263 702          : FUNCTIONAL DESCRIPTION:
0263 703          :
0263 704          : THIS ROUTINE IS CALLED FROM THE DRIVER UNIT INITIALIZATION ROUTINE
0263 705          : TO WAIT UNTIL THE RL11 CONTROLLER IS READY. TO PREVENT HANGING UP
0263 706          : AT HIGH IPL, A MAXIMUM OF 30 USEC ELAPSES BEFORE CONTROL IS
0263 707          : RETURNED TO THE CALLER.
0263 708          :
0263 709          :
0263 710          DL_WAIT:          :WAIT FOR CONTROLLER READY
7E 50 7D 0263 711          MOVQ    R0,-(SP)          :SAVE R0, R1
0266 712          DSBINT          :DISABLE INTERRUPTS
026C 713          TIMEWAIT      #3,#RL_CS_M_CRDY,RL(CS(R4),W)
0291 714          ENBINT          :ENABLE INTERRUPTS
50 8E 7D 0294 715          MOVQ    (SP)+,R0          :RESTORE R0, R1
05 0297 716          RSB          :RETURN TO UNIT INIT OR STARTIO

```

```

0298 718          .SBTTL FDT ROUTINE - TEST TRANSFER BYTE COUNT ALIGNMENT
0298 719
0298 720 :++
0298 721 :
0298 722 : DL_ALIGN - FDT ROUTINE TO TEST XFER BYTE COUNT
0298 723 :
0298 724 : FUNCTIONAL DESCRIPTION:
0298 725 :
0298 726 : THIS ROUTINE IS CALLED FROM THE FUNCTION DECISION TABLE DISPATCHER
0298 727 : TO CHECK THE BYTE COUNT PARAMETER SPECIFIED BY THE USER PROCESS
0298 728 : FOR AN EVEN NUMBER OF BYTES (WORD BOUNDARY).
0298 729 :
0298 730 : INPUTS:
0298 731 :
0298 732 : R3      - IRP ADDRESS (I/O REQUEST PACKET)
0298 733 : R4      - PCB ADDRESS (PROCESS CONTROL BLOCK)
0298 734 : R5      - UCB ADDRESS (UNIT CONTROL BLOCK)
0298 735 : R6      - CCB ADDRESS (CHANNEL CONTROL BLOCK)
0298 736 : R7      - BIT NUMBER OF THE I/O FUNCTION CODE
0298 737 : R8      - ADDRESS OF FDT TABLE ENTRY FOR THIS ROUTINE
0298 738 : 4(AP)   - ADDRESS OF FIRST FUNCTION DEPENDENT QIO PARAMETER
0298 739 :
0298 740 : OUTPUTS:
0298 741 :
0298 742 : IF THE QIO BYTE COUNT PARAMETER IS ODD, THE I/O OPERATION IS
0298 743 : TERMINATED WITH AN ERROR. IF IT IS EVEN, CONTROL IS RETURNED
0298 744 : TO THE FDT DISPATCHER.
0298 745 :
0298 746 :--
0298 747 :
0298 748 DL_ALIGN:
0298 749         BLBS      4(AP),10$           ;CHECK BYTE COUNT AT P1(AP)
0298 750         RSB           ;IF LBS - ODD BYTE COUNT
0298 751 10$:      MOVZWL   #SS$ IVBUFLN,R0  ;EVEN - RETURN TO CALLER
0298 752         JMP        G^EX$ABORTIO     ;SET BUFFER ALIGNMENT STATUS
0298         ;ABORT I/O

```

```

01 04 AC   E8
50 034C BF 05
00000000'GF 3C 029D 751
17 02A2 752

```

```

02A8 754          .SBTTL  START I/O ROUTINE
02A8 755
02A8 756      :++
02A8 757      :
02A8 758      : DL_STARTIO - START I/O ROUTINE
02A8 759      :
02A8 760      : FUNCTIONAL DESCRIPTION:
02A8 761      :
02A8 762      : THIS FORK PROCESS IS ENTERED FROM THE EXECUTIVE AFTER AN I/O REQUEST
02A8 763      : PACKET HAS BEEN DEQUEUED, AND PERFORMS THE FOLLOWING:
02A8 764      :
02A8 765      :     - ACTIVATES THE DISK AFTER SETTING UCB FIELDS, OBTAINING
02A8 766      :       UBA AND CONTROLLER RESOURCES, AND SETTING RL11 REGISTERS
02A8 767      :
02A8 768      :     - WAITS FOR AN INTERRUPT
02A8 769      :
02A8 770      :     - REGAINS CONTROL AFTER THE ISR SERVICES THE INTERRUPT, AND
02A8 771      :       - RE-ACTIVATES THE DISK IF THE ORIGINAL FUNCTION
02A8 772      :         IS NOT YET COMPLETE, OR
02A8 773      :       - COMPLETES THE I/O REQUEST BY RELEASING RESOURCES,
02A8 774      :         SETTING STATUS CODES, AND RETURNING TO THE EXECUTIVE.
02A8 775      :
02A8 776      : INPUTS:
02A8 777      :
02A8 778      :     R3          - IRP ADDRESS (I/O REQUEST PACKET)
02A8 779      :     R5          - UCB ADDRESS (UNIT CONTROL BLOCK)
02A8 780      :     IRP$L_MEDIA - PARAMETER LONGWORD (LOGICAL BLOCK NUMBER)
02A8 781      :
02A8 782      : OUTPUTS:
02A8 783      :
02A8 784      :     R0          - FIRST I/O STATUS LONGWORD: STATUS CODE & BYTES XFFRED
02A8 785      :     R1          - SECOND I/O STATUS LONGWORD: 0 FOR DISKS
02A8 786      :
02A8 787      : THE I/O FUNCTION IS EXECUTED.
02A8 788      :
02A8 789      : ALL REGISTERS EXCEPT R0-R4 ARE PRESERVED.
02A8 790      :
02A8 791      :--
02A8 792      :
02A8 793      : DL_STARTIO:          ;START I/O OPERATION
02A8 794      :
02A8 795      :
02A8 796      :     COMPUTE PHYSICAL MEDIA ADDRESS
02A8 797      :
02A8 798      :         LBN = LBN * (SECTORS/BLOCK)
02A8 799      :         LBN/(SECTORS/TRACK) = D * SECTOR
02A8 800      :         D/(TRACKS/CYLINDER) = CYLINDER * TRACK
02A8 801      :
02A8 802      :
02A8 803      :
02A8 804      :     PREPROCESS UCB FIELDS
02A8 805      :
02A8 806      :
02A8 807      : PREPROCESS:
02A8 808      :     MOVL  IRP$L_MEDIA(R3),-      ; Copy given MEDIA address (logical)
02A8 809      :     UCB$L_MEDIA(R5)          ; to the UCB.
02AE 810      :     BBS   #IRP$V_PHYSIO,-      ;IF SET - PHYSICAL I/O

```

38 A3 DO  
0JBC C5  
08 E0

```

50 00BC C5 26 2A A3 02 C5 02B0 811 IRPSW STS(R3),10$
      52 44 A5 9A 02B3 812 MULL3 #2,UCBSL_MEDIA(R5),R0 ;SCALE LBN IN R0
      51 D4 02BD 814 MOVZBL UCBSB_SECTORS(R5),R2 ;GET NUMBER OF SECTORS PER TRACK
00BC C5 50 50 52 7B 02BF 815 CLRL R1 ;CLEAR HIGH PART OF DIVIDEND
      52 45 A5 9A 02C6 816 EDIV R2,R0,R0,UCBSL_MEDIA(R5) ;CALCULATE SECTOR NUMBER AND STORE
51 50 50 52 7B 02CA 817 MOVZBL UCBSB_TRACKS(R5),R2 ;GET NUMBER OF TRACKS PER CYLINDER
      00BD C5 51 90 02CF 818 EDIV R2,R0,R0,R1 ;CALCULATE TRACK AND CYLINDER
      00BE C5 50 80 02D4 819 MOVB R1,UCBSL_MEDIA+1(R5) ;STORE TRACK NUMBER
      02D9 820 10$: MOVW R0,UCBSL_MEDIA+2(R5) ;STORE CYLINDER NUMBER
      0081 C5 90 02D9 821 MOVB UCBSB_ERTMAX(R5),- ;INITIALIZE ERROR RETRY COUNT
      0080 C5 02DD 822 UCBSB_ERTCNT(R5)
00C0 C5 7E A5 AE 02E0 823 MNEGW UCBSB_BCNT(R5),UCBSW_BCR(R5) ;INIT NEG BYTES LEFT TO XFER
      00D6 C5 84 02E6 824 CLRW UCBSW_DL_DPN(R5) ;CLEAR DATA PATH NO. FOR USE AS-
      00E4 C5 94 02EA 825 ;UBA RESOURCE ALLOCATION FLAG
009A C5 20 A3 80 02EE 826 CLRB UCBSB_DL_DPPE(R5) ;CLEAR DATAPATH PURGE ERROR REGISTER
      00 00 EF 02F4 827 MOVW IRPSW_FUNC(R3),UCBSW_FUNC(R5) ;SAVE FUNCTION CODE
51 20 A3 06 90 02F6 828 EXTZV #IRPSV_FCODE,- ;EXTRACT I/O FUNCTION CODE
      0092 C5 51 90 02FA 830 MOVB R1,UCBSB_FEX(R5) ;STORE FUNCTION DISPATCH INDEX
      51 02 91 02FF 831 CMPB #IOS_SEER,R1 ;SEEK FUNCTION?
      06 12 0302 832 BNEQ 20$ ;IF NEQ - NO
      38 A3 80 0304 833 MOVW IRPSL_MEDIA(R3),- ;STORE CYLINDER ADDRESS
      00BE C5 0307 834 UCBSW_DC(R5) ;...
      02 AA 030A 835 20$. BICW #UCBSM_DIAGBUF,-
      68 A5 030C 836 UCBSW_DEVSTS(R5) ;CLR DIAGNOSTIC BUFFER PRESENT
      07 E1 030E 837 BBC #IRPSV_DIAGBUF,- ;IF CLR - NO DIAG BUFFER
      04 2A A3 0310 838 IRPSW_ST(SR3),FDISPATCH ;...
      68 A5 02 A8 0313 839 BISW #UCBSM_DIAGBUF,UCBSW_DEVSTS(R5) ;SET DIAG BUFFER PRESENT
      0317 841 ;
      0317 842 ;
      0317 843 ;
      0317 844 ;
      0317 845 ;
      0317 846 FDISPATCH: ;FUNCTION DISPATCH
      53 58 A5 D0 0317 847 MOVL UCBSL_IRP(R5),R3 ;GET IRP ADDRESS
      08 08 E0 0318 848 BBS #IRPSV_PHYSIO,- ;IF SET - PHYSICAL I/O FUNCTION
      0D 2A A3 031D 849 IRPSW_ST(SR3),10$ ;...
      08 08 E0 0320 850 BBS #UCBSV_VALID,- ;IF SET - V _ME SOFTWARE VALID
      50 08 64 A5 3C 0322 851 UCBSW_ST(SR5),10$ ;...
      0254 8F 31 0325 852 MOVZWL #SSV_VOLINV,R0 ;SET VOLUME INVALID STATUS
      05AE 31 032A 853 BRW RESETXFR ;RESET BYTE COUNT AND EXIT
      00C9 C5 94 032D 854 10$: CLRB UCBSB_DL_DCHEK(R5) ;CLEAR DATA CHECK IN PROGRESS
      53 0092 C5 9A 0331 855 MOVZBL UCBSB_FEX(R5),R3 ;GET FUNCTION DISPATCH INDEX
      0336 856 CASE R3,- ;DISPATCH TO FUNCTION HANDLING ROUTINE
      0336 857 UNLOAD,- ;UNLOAD
      0336 858 SEEK,- ;SEEK
      0336 859 NOP,- ;RECALIBRATE (unsupported)
      0336 860 DRVCLR,- ;DRVCLR
      0336 861 NOP,- ;RELEASE PORT (unsupported)
      0336 862 NOP,- ;OFFSET HEADS (unsupported)
      0336 863 NOP,- ;RETURN TO CENTER (unsupported)
      0336 864 PACKACK,- ;PACK ACKNOWLEDGE
      0336 865 NOP,- ;SEARCH (unsupported)
      0336 866 WRITECHECK,- ;WRITE CHECK
      0336 867 WRITEDATA,- ;WRITE DATA

```

```

0336 868 READDATA,- ; READ DATA
0336 869 NOP - ; WRITE HEADER (unsupported)
0336 870 READHEAD,- ; READ HEADER
0336 871 NOP,- ; place holder
0336 872 NOP,- ; place holder
0336 873 AVAILABLE- ; AVAILABLE
0336 874 >,LIMIT=#CDF_UNLOAD ;
035C 875
035C 876 NOP: ;NO-OP
035C 877 SEEK: ;SEEK
035C 878 DRVCLR: ;DRIVE CLEAR (GET STATUS & RESET)
035C 879 DO_FUNCTION:
035C 880 EXFUNCL RETRYERR ;EXECUTE FUNCTION - RETRY IF FAILURE
27 11 0360 881 BRB NORMAL ;SUCCESSFUL - EXIT WITH NORMAL STATUS
0362 882
0362 883 PACKACK: ;PACK ACKNOWLEDGE (GET STATUS & RESET)
64 A5 0800 8F AB 0362 884 BISW #UCBSM_VALID, - ;Set software volume valid bit.
0368 885 UCBSW_STS(R5)
F2 11 0368 886 BRB DO_FUNCTION ;Then go do hardware function.
036A 887
036A 888 UNLOAD: ;UNLOAD
64 A5 0800 8F AA 036A 889 AVAILABLE: ;AVAILABLE
0370 890 BICW #UCBSM_VALID, - ;Clear software volume valid bit.
17 11 0370 891 UCBSW_STS(R5) ;and go complete operation without
0370 892 BRB NORMAL ;any hardware interaction.
0372 893
0372 894 WRITECHECK: ;WRITE CHECK
4000 8F AA 0372 895 READHEAD: ;READ HEADER
009A C5 0372 896 BICW #IOSM_DATACHECK,- ;CLEAR DATA CHECK REQUEST-
0376 897 UCBSW_FUNC(R5) ;TO PREVENT EXTRA WRITE CHECK
0379 898
0379 899 WRITEDATA: ;WRITE DATA
0379 900 READDATA: ;READ DATA
0379 901 EXFUNCL RETRYERR,F_SEEK ;EXECUTE EXPLICIT SEEK - RETRY IF FAIL
53 0092 C5 9A 0380 902
0380 903 MOVZBL UCBSB_FEX(R5),R3 ;GET FUNCTION DISPATCH INDEX
0385 904 EXFUNCL RETRYERR ;EXECUTE TRANSFER FUNCTION
0389 905
0389 906 ::
0389 907 :: OPERATON COMPLETION
0389 908 ::
0389 909
0389 910 NORMAL: ;SUCCESSFUL OPERATION COMPLETE
50 01 3C 0389 911 MOVZWL #SS$ NORMAL,R0 ;SET NORMAL COMPLETION STATUS
0057 31 038C 912 BRW FUNCXT ;FUNCTION EXIT
038F 913
038F 914 RETRYERR: ;RETRIABLE ERROR
0080 C5 97 038F 915 DECB UCBSB_ERTCNT(R5) ;ANY RETRIES LEFT?
03 13 0393 916 BEQL FATALERR ;IF EQL - NO
FF7F 31 0395 917 BRW FDISPATCH ;RETRY FUNCTION
0398 918
0398 919 FATALERR: ;UNRECOVERABLE ERROR
50 0254 8F 3C 0398 920 MOVZWL #SS$ VOLINV,R0 ;ASSUME VOLUME INVALID STATUS
09 E0 039D 921 BBS #RL_MP_V_VC,- ;IF SET - VOLUME INVALID
43 00D4 C5 039F 922 UCBSW_DL_MP(R5),FUNCXT ;...
03A3 923
50 025C 8F 3C 03A3 924 MOVZWL #SS$ WRITLCK,R0 ;ASSUME WRITE LOCK ERROR STATUS

```



```

06 00D4 0D E1 03A8 925 BBC #RL MP V_WL,- ;IF CLR - VOLUME NOT WRITE LOCKED
      C5 03AA 926 UCBSW_DL_MP(R5),5$ ;...
      OA E0 03AE 927 #RL MP V_WGE,- ;IF SET - WRITE GATE ERROR
32 00D4 C5 03B0 928 UCBSW_DL_MP(R5),FUNCXT ;IF WL & WGE SET - WRITE LOCK ERROR
      03B4 929
50 005C 8F 3C 03B4 930 5$: MOVZWL #SS$ DATACHECK,R0 ;ASSUME DATA CHECK ERROR STATUS
      C5 95 03B9 931 TSTB UCBSB_DL_DCHEK(R5) ;WRITE CHECK IN PROGRESS?
      OC 13 03BD 932 BEQL 10$ ;IF EQL - NO
      OA E0 03BF 933 BBS #RL CS V_OPI,- ;IF SET - NOT WRITE CHECK ERROR
      C5 03C1 934 UCBSW_DL_CS(R5),10$ ;...
      OB E0 03C5 935 BBS #RL CS V_CRC,- ;IF SET - WRITE CHECK ERROR
      C5 03C7 936 UCBSW_DL_CS(R5),FUNCXT ;...
      03CB 937
50 01F4 8F 3C 03CB 938 10$: MOVZWL #SS$ PARITY,R0 ;ASSUME PARITY ERROR STATUS
      OB E0 03D0 939 BBS #RL CS V_CRC,- ;IF SET - CRC ERROR
      C5 03D2 940 UCBSW_DL_CS(R5),FUNCXT ;OR DATAPATH PURGE ERROR
      03D6 941
50 008C 8F 3C 03D6 942 20$: MOVZWL #SS$ DRVERR,R0 ;ASSUME DRIVE ERROR STATUS
      OE E0 03DB 943 BBS #RL CS V_DE,- ;IF SET - DRIVE ERROR
      C5 03DD 944 UCBSW_DL_CS(R5),FUNCXT ;...
      03E1 945
50 0054 8F 3C 03E1 946 MOVZWL #SS$_CTRLERR,R0 ;ASSUME CONTROLLER ERROR STATUS
      03E6 947
      03E6 948 FUNCXT: ;FUNCTION EXIT
50 DD 03E6 949 PUSHL R0 ;SAVE FINAL REQUEST STATUS
00000000 GF 16 03E8 950 JSB G*IOC$DIAGBUFILL ;FILL DIAGNOSTIC BUFFER IF PRESENT
0092 C5 OA 91 03EE 951 CMPB #CDF_WRITECHECK,UCBSB_FEX(R5) ;DRIVE RELATED FUNCTION?
      C5 2D 1A 03F3 952 BGTRU 10$ ;IF GTRU - YES
0092 C5 11 91 03F5 953 CMPB #CDF_AVAILABLE,UCBSB_FEX(R5) ;DRIVE RELATED FUNCTION?
      C5 26 13 03FA 954 BEQL 10$ ;IF EQL - YES
53 58 A5 D0 03FC 955 MOVL UCBSL_IRP(R5),R3 ;RETRIEVE ADDRESS OF IRP
00C0 C5 A1 0400 956 ADDW3 UCBSW_BCR(R5),- ;CALCULATE BYTES TRANSFERRED
02 AE 32 A3 0404 957 IRPSW_BCNT(R3),2(SP) ;...
      C5 B5 0408 958 TSTW UCBSW_DL_DPN(R5) ;ARE UBA RESOURCES ALLOCATED?
      C5 1A 13 040C 959 BEQL 20$ ;IF EQL - NO
      C5 01 E1 040E 960 BBS #UCBSV_DL_MAPPING,- ;ADAPTER MAPPING?
      C5 0410 961 UCBSW_DL_FLAGS(R5),10$ ;IF BC NO
      0414 962 RELDPR ;RELEASE DATA PATH
      041A 963 RELMPR ;RELEASE MAP REGISTERS
      C5 06 11 0420 964 BRB 20$ ;JOIN COMMON CODE
00D8 C5 D0 0422 965 10$: MOVL UCBSL_DL_SVAPTE(R5),- ;RESTORE ORIGINAL SVAPTE
      A5 78 0426 966 UCBSL_SVAPTE(R5) ;...
      0428 967 20$: RELCHAN ;RELEASE CHANNEL IF OWNED
      042E 968
      C5 51 D4 042E 969 CLRL R1 ;CLEAR SECOND STATUS LONGWORD
      C5 50 8ED0 0430 970 POPL R0 ;RETRIEVE FINAL REQUEST STATUS
      0433 971 REQCOM ;COMPLETE REQUEST

```

```
0439 973 :  
0439 974 : FEXL - RL11 HARDWARE FUNCTION EXECUTION  
0439 975 :  
0439 976 : THIS ROUTINE IS CALLED VIA A BSB WITH A BYTE IMMEDIATELY FOLLOWING THAT  
0439 977 : SPECIFIES THE ADDRESS OF AN ERROR ROUTINE. ALL DATA IS ASSUMED TO HAVE BEEN  
0439 978 : SET UP IN THE UCB BEFORE THE CALL. THE APPROPRIATE PARAMETERS ARE LOADED  
0439 979 : INTO DEVICE REGISTERS AND THE FUNCTION IS INITIATED. THE RETURN ADDRESS  
0439 980 : IS STORED IN THE UCB AND A WAITFOR INTERRUPT IS EXECUTED. WHEN THE  
0439 981 : INTERRUPT OCCURS, CONTROL IS RETURNED TO THE CALLER.  
0439 982 :  
0439 983 : INPUTS:  
0439 984 :  
0439 985 : R3 = FUNCTION TABLE DISPATCH INDEX  
0439 986 : R5 = DEVICE UNIT UCB ADDRESS  
0439 987 :  
0439 988 : 00(SP) = RETURN ADDRESS OF CALLER  
0439 989 : 04(SP) = RETURN ADDRESS OF CALLER'S CALLER  
0439 990 :  
0439 991 : IMMEDIATELY FOLLOWING INLINE AT THE CALL SITE IS A BYTE WHICH CONTAINS  
0439 992 : A BRANCH DESTINATION TO AN ERROR RETRY ROUTINE.  
0439 993 :  
0439 994 : OUTPUTS:  
0439 995 :  
0439 996 : THERE ARE FOUR EXITS FROM THIS ROUTINE:  
0439 997 :  
0439 998 : 1. SPECIAL CONDITION - THIS EXIT IS TAKEN IF A POWER FAILURE OCCURS  
0439 999 : OR THE OPERATION TIMES OUT. IT IS A JUMP TO THE APPROPRIATE  
0439 1000 : ERROR ROUTINE.  
0439 1001 :  
0439 1002 : 2. FATAL ERROR - THIS EXIT IS TAKEN IF A FATAL CONTROLLER OR DRIVE  
0439 1003 : ERROR OCCURS OR IF ANY ERROR OCCURS AND ERROR RETRY IS EITHER  
0439 1004 : INHIBITED OR EXHAUSTED. IT IS A JUMP TO THE FATAL ERROR EXIT  
0439 1005 : ROUTINE.  
0439 1006 :  
0439 1007 : 3. RETRIABLE ERROR - THIS EXIT IS TAKEN IF A RETRIABLE CONTROLLER  
0439 1008 : OR DRIVE ERROR OCCURS AND ERROR RETRY IS NEITHER INHIBITED  
0439 1009 : NOR EXHAUSTED. IT CONSISTS OF TAKING THE ERROR BRANCH EXIT  
0439 1010 : SPECIFIED AT THE CALL SITE.  
0439 1011 :  
0439 1012 : 4. SUCCESSFUL OPERATION - THIS EXIT IS TAKEN IF NO ERRORS OCCUR  
0439 1013 : DURING THE OPERATION. IT CONSISTS OF A RETURN INLINE.  
0439 1014 :  
0439 1015 : IN ALL CASES IF AN ERROR OCCURS, AN ATTEMPT IS MADE TO LOG THE ERROR.  
0439 1016 :  
0439 1017 : IN ALL CASES FINAL DEVICE REGISTERS ARE RETURNED VIA THE UCB.  
0439 1018 :  
0439 1019 : UCBSW_BCR(R5) = NEGATIVE BYTES REMAINING TO TRANSFER
```

```
0093 009C C5 8ED0 0439 1021 FEXL:
50 24 A5 D0 0439 1022 POPL UCBSL_DPC(R5) ;FUNCTION EXECUTOR
51 2C A0 D0 043E 1023 MOVB R3,UCBSB_CEX(R5) ;SAVE DRIVER PC VALUE
04 A1 55 D1 0443 1024 MOVL UCBSL_CRB(R5),R0 ;SAVE CASE INDEX
54 61 D0 0447 1025 MOVL UCBSL_CRB(R5),R0 ;GET ADDRESS OF PRIMARY CRB
06 11 12 044B 1026 MOVL CRBSL_INTD+VECSL_IDB(R0),R1 ;GET ADDRESS OF IDB
05 12 044F 1027 CMPL R5,IDBSL_OWNER(RT) ;DOES THIS PROCESS OWN CHANNEL?
10$ 10$ BNEQ 10$ ;IF NEQ - NO
20$ 20$ MOVL IDBSL_CSR(R1),R4 ;SET ASSIGNED CHANNEL CSR ADDRESS
BRB 20$ ;
REQPCHAN ;REQUEST CHANNEL (RETURNS R4 = CSR ADR)
CASE R3,- ;DISPATCH TO PROPER FUNCTION ROUTINE
IMMED,- ;NO OPERATION
IMMED,- ;UNLOAD VOLUME (NOP)
POSIT,- ;SEEK CYLINDER
IMMED,- ;RECALIBRATE (NOP)
DRCLR,- ;DRIVE CLEAR (GET STATUS & RESET)
IMMED,- ;RELEASE DRIVE (NOP)
IMMED,- ;OFFSET HEADS (NOP)
IMMED,- ;RETURN TO CENTERLINE (NOP)
DRCLR,- ;PACK ACKNOWLEDGE
IMMED,- ;SEARCH (NOP)
> ;
BRW XFER ;TRANSFER FUNCTION
```

```

0477 1046 :
0477 1047 : IMMEDIATE FUNCTION EXECUTION
0477 1048 :
0477 1049 :     FUNCTIONS INCLUDE:
0477 1050 :
0477 1051 :         NO OPERATION,
0477 1052 :         DRIVE CLEAR, AND
0477 1053 :         PACK ACKNOWLEDGE
0477 1054 :
0477 1055 :     INPUTS:
0477 1056 :         R3     - CASE INDEX
0477 1057 :         R4     - CSR ADDRESS
0477 1058 :         R5     - UCB ADDRESS
0477 1059 :
0477 1060 :     FUNCTIONAL DESCRIPTION:
0477 1061 :
0477 1062 :     INTERRUPTS ARE LOCKED OUT, THE APPROPRIATE FUNCTION IS INITIATED WITH
0477 1063 :     INTERRUPT ENABLE, AND A WAITFOR INTERRUPT AND KEEP CHANNEL IS EXECUTED.
0477 1064 :
0477 1065 :
0477 1066 : DRCLR:
0477 1067 :     BISW     #RL_DA_M_STS!-           ;DRIVE CLEAR
0478 1068 :     RL_DA_M_RST!RL_DA_M_MRK,RL_DA(R4) ;SET GETSTATUS,RESET,AND MARK IN DAR
0478 1069 :
0478 1070 : IMMED:
0478 1071 :     CKPWR
0494 1072 :
0494 1073 :     BISW3   R2,FTAB[R3],RL_CS(R4)   ;IMMEDIATE FUNCTION EXECUTION
0498 1074 :     WFIKPC RETREG,#2                ;DISABLE INTERRUPTS,CHECK POWER,-
04A5 1075 :     IOFORK
04AB 1076 :
04AB 1077 :     BRW     RETREG                   ;AND PUT UNIT NUMBER IN R2<9:8>
                                         ;MERGE UNIT WITH FNTN AND EXECUTE
                                         ;WAITFOR INTERRUPT
                                         ;RETURN FROM ISR-
                                         ;CREATE FORK PROCESS (&JSB BACK TO ISR)
                                         ;
04  A4  08  A8
64  FB9E CF43 52  A9
0371 31 04AB 1077

```

```

04AE 1079 :
04AE 1080 : POSITIONING FUNCTION EXECUTION
04AE 1081 :
04AE 1082 :     FUNCTIONS INCLUDE:
04AE 1083 :
04AE 1084 :         SEEK CYLINDER
04AE 1085 :
04AE 1086 :     INPUTS:
04AE 1087 :         R3     - CASE INDEX
04AE 1088 :         R4     - DEVICE CSR ADDRESS
04AE 1089 :         R5     - UCB ADDRESS
04AE 1090 :
04AE 1091 :     FUNCTIONAL DESCRIPTION:
04AE 1092 :
04AE 1093 :     THE CYLINDER DIFFERENCE WORD IS CALCULATED AND LOADED INTO THE DISK
04AE 1094 :     ADDRESS REGISTER, INTERRUPTS ARE LOCKED OUT, AND THE SEEK FUNCTION
04AE 1095 :     IS INITIATED WITHOUT INTERRUPT ENABLE. THE CONTROLLER IS THEN POLLED
04AE 1096 :     FOR READY, AND DEVICE INTERRUPTS ARE ENABLED.
04AE 1097 :
04AE 1098 :     SINCE THE RL01/RL02 DO NOT ISSUE AN INTERRUPT UPON COMPLETION OF A
04AE 1099 :     SEEK, OVERLAPPED SEEKS ARE NOT ATTEMPTED, AND ONE OF THE FOLLOWING IS
04AE 1100 :     PERFORMED.
04AE 1101 :
04AE 1102 :         IF ONLY A SEEK FUNCTION IS BEING REQUESTED, A DUMMY READ HEADER
04AE 1103 :         FUNCTION IS ISSUED AND A WAITFOR INTERRUPT IS INITIATED.
04AE 1104 :         THE READ HEADER IS USED TO SIGNAL THE END OF THE SEEK, SINCE IT
04AE 1105 :         WILL ISSUE AN INTERRUPT SHORTLY (315 USEC AVG) AFTER THE SEEK IS
04AE 1106 :         COMPLETE. IT WILL ALSO SENSE FOR A TIMEOUT DURING THE SEEK.
04AE 1107 :
04AE 1108 :         IF THE SEEK IS ASSOCIATED WITH A DATA TRANSFER REQUEST (RL01/RL02
04AE 1109 :         TRANSFER FUNCTIONS REQUIRE EXPLICIT SEEKS), THE PROGRAM KEEPS THE
04AE 1110 :         CHANNEL AND RETURNS TO FDISPATCH TO ISSUE THE TRANSFER REQUEST
04AE 1111 :         WHILE THE SEEK IS STILL IN PROGRESS. WHEN THE SEEK COMPLETES, THE
04AE 1112 :         RL11 CONTROLLER WILL BEGIN THE TRANSFER.
04AE 1113 :
04AE 1114 :
04AE 1115 :     POSIT:                                ;POSITIONING FUNCTION
04AE 1116 :
04AE 1117 :     OBTAIN CURRENT DISK ADDRESS
04AE 1118 :
04AE 1119 :     IF THERE HAS NOT BEEN A PREVIOUS TRANSFER DURING THIS REQUEST,
04AE 1120 :     A READ HEADER IS EXECUTED TO DETERMINE THE CURRENT DISK ADDRESS.
04AE 1121 :
04AE 1122 :     TSTW   UCBSW_DL_DPN(R5)                ;WAS THERE A PREVIOUS TRANSFER?
04AE 1123 :     BEQL   10$                               ;IF EQL - NO, READ HEADER
04AE 1124 :     BICW3  #^077,UCBSW_DL_DA(R5),R1        ;PUT CURRENT CYL & SURFACE IN R1
04AE 1125 :     BRW    60$                               ;CALCULATE DIFFERENCE WORD
04AE 1126 :
04AE 1127 :     MOVZBL #8,R3                             ;SET READ HEADER RETRY COUNT IN R3
04AE 1128 :     CKPWR 20$                               ;DISABLE INTERRUPTS, CHECK POWER,-
04AE 1129 :     AND PUT UNIT NUMBER IN R2<9:8>
04AE 1130 :     BISW3  R2,4F,READHEAD!RL_CS_M_1E,-    ;EXECUTE READ HEADER
04AE 1131 :     RL(CSTR4)
04AE 1132 :     WFIKPCM 40$,#2                          ;WAIT FOR INTERRUPT OR TIMEOUT
04AE 1133 :     IOFORK                                ;CREATE FORK PROCESS
04AE 1134 :     BITW   #RL_CS_M_CE,UCBSW_DL_CS(R5)    ;ANY ERRORS?
04AE 1135 :     BEQL   50$                               ;IF EQL - NO

```

```

53 97 04FB 1136      DECB   R3           :DECREMENT READ HEADER RETRY COUNT
C4 12 04FA 1137      BNEQ   20$         :IF NEQ - RETRY READ HEADER
                   04FC 1138      :IF EQL - READ HEADER RETRY EXHAUSTED -
                   04FC 1139      :TRY PREVIOUS TRACK
00B1 8F B0 04FC 1140      MOVW   #^0200!RL_DA_M_MRK,- :LOAD REVERSE SEEK DIFFERENCE WORD
04  A4 0500 1141      RL_DA(R4)
                   0502 1142      CKPWR          :DISABLE INTERRUPTS, CHECK POWER,-
0046 8F 52 A9 051B 1143      :AND PUT UNIT NUMBER IN R2<9:8>
                   051B 1144      BISW3   R2,#F SEEK!RL_CS_M_IE,- :EXECUTE REVERSE SEEK
                   0520 1145      RL_CSTR4)
                   0521 1146      WFIKPCM 40$,#2       :WAIT FOR SEEK TO BEGIN (INTERRUPT)
                   052B 1147      IOFORK          :CREATE FORK PROCESS
                   0531 1148      CKPWR          :DISABLE INTERRUPTS, CHECK POWER,-
0048 8F 52 A9 054A 1149      :AND PUT UNIT NUMBER IN R2<9:8>
                   054A 1150      BISW3   R2,#F READHEAD!RL_CS_M_IE,- :TRY READ HEADER ON NEW TRACK
                   054F 1151      RL_CSTR4)
                   0550 1152      WFIKPCM 40$,#2       :WAITFOR INTERRUPT OR TIMEOUT
00CE C5 8000 8F B3 055A 1153      IOFORK          :CREATE FORK PROCESS
                   0560 1154      BITW   #RL_CS_M_CE,UCBSW_DL_CS(R5) :READ HEADER ERROR?
                   0567 1155      BEQL   50$         :IF EQL - NO
                   0569 1156      40$:          :CAN NOT READ CURRENT DISK ADDRESS
                   0569 1157      :          :CLEAR RETRY COUNT
                   02B3 31 0569 1158      CLRB   UCBSB_ERTCNT(R5)
                   BRW   RETREG
                   51 00D4 C5 3F AB 056C 1159      50$:          :FOUND CURRENT DISK ADDRESS
                   056C 1160      BICW3   #^077,UCBSW_DL_MP(R5),R1 :PUT CURRENT CYL & SURFACE IN R1
                   0572 1161      :
                   0572 1162      :
                   0572 1163      : CALCULATE CYLINDER DIFFERENCE WORD
                   0572 1164      :
                   0572 1165      :
50 01 06 00BD C5 D4 0572 1166      60$:      CLFL   R0           :CLEAR R0 FOR DESIRED ADDRESS
50 09 07 00BE C5 F0 0574 1167      INSV   UCBSW_DA+1(R5),#6,#1,R0 :INSERT DESIRED SURFACE IN R0<6>
                   51 50 B1 057B 1168      INSV   UCBSW_DC(R5),#7,#9,R0 :INSERT DESIRED CYLINDER IN R0<15:7>
                   52 13 0582 1169      CMPW   R0,R1       :IS A SEEK NEEDED?
                   51 007F 8F AA 0585 1170      BEQL   80$         :IF EQL - NO
                   50 007F 8F AA 0587 1171      BICW   #^0177,R1   :REMOVE SURFACE BIT
                   51 50 A2 058C 1172      BICW   #^0177,R0   :REMOVE SURFACE BIT
                   08 13 0591 1173      SUBW   R0,R1       :SUBTRACT DESIRED FROM ACTUAL
                   51 51 AE 0594 1174      BEQL   70$         :IF EQL - ONLY CHANGE SURFACE
                   51 04 AB 0596 1175      BCC    70$         :IF CC - ACTUAL>=DESIRED
                   51 51 AE 0598 1176      MNEGW R1,R1       :ACTUAL<DESIRED, MAKE POSITIVE DIFF
51 01 04 00BD C5 F0 059B 1177      BISW   #4,R1       :SET SIGN FOR MOVE TO CENTER OF DISK
04  A4 51 01 A9 059E 1178      70$:      INSV   UCBSW_DA+1(R5),#4,#1,R1 :INSERT SURFACE BIT
                   05A5 1179      BISW3   #RL_DA_M_MRK,R1,RL_DA(R4) :SET MARKER AND LOAD DIFFERENCE WORD
                   05AA 1180      :
                   05AA 1181      :
                   05AA 1182      : EXECUTE SEEK
                   05AA 1183      :
                   05AA 1184      :
                   05AA 1185      CKPWR          :DISABLE INTERRUPTS, CHECK POWER,-
0046 8F 52 A9 05C3 1186      :AND PUT UNIT NUMBER IN R2<9:8>
                   05C3 1187      BISW3   R2,#F SEEK!RL_CS_M_IE,- :EXECUTE SEEK FUNCTION
                   05C8 1188      RL_CSTR4)
                   05C9 1189      WFIKPCM 40$,#2       :WAIT FOR SEEK TO BEGIN (INTERRUPT)
0092 C5 02 91 05D3 1190      IOFORK          :CREATE FORK PROCESS
                   05D9 1191      80$:      CMPB   #10$,SEEK,UCBSB_FEX(R5) :IS SEEK ASSOCIATED WITH A TRANSFER?
                   08 13 05DE 1192      BEQL   90$         :IF EQL - NO, SEEK ONLY

```

```
05E0 1193  
05E0 1194 :  
05E0 1195 : RETURN FOR SEEK ASSOCIATED WITH A TRANSFER REQUEST  
05E0 1196 :  
05E0 1197 :  
009C C5 D6 05E0 1198 INCL UCBSL_DPC(R5) :ADJUST TO CORRECT RETURN ADDRESS  
009C D5 17 05E4 1199 JMP @UCBSC_DPC(R5) :RETURN TO DRIVER FOR TRANSFER  
05E8 1200 :  
05E8 1201 : RETURN FOR SEEK ONLY REQUEST  
05E8 1202 :  
05E8 1203 :  
05E8 1204 90$: CKPWR :DISABLE INTERRUPTS, CHECK POWER,-  
0601 1205 :AND PUT UNIT NUMBER IN R2<9:8>  
0048 8F 52 A9 0601 1206 BISW3 R2,#F READHEAD!RL_CS_M_IE,- :EXECUTE DUMMY READ HEADER  
64 0606 1207 RL(CSTR4)  
0607 1208 WFIKPCW RETREG,#2 :WAIT FOR SEEK TO COMPLETE (INTERRUPT)  
0611 1209 IOFORK :CREATE FORK PROCESS  
0205 31 0617 1210 BRW RETREG  
:
```

```

061A 1212
061A 1213
061A 1214 : TRANSFER FUNCTION EXECUTION
061A 1215 :
061A 1216 : FUNCTIONS INCLUDE:
061A 1217 :
061A 1218 : WRITE CHECK
061A 1219 : WRITE DATA
061A 1220 : READ DATA, AND
061A 1221 : READ HEADER
061A 1222 :
061A 1223 : INPUTS:
061A 1224 : R3 - CASE INDEX
061A 1225 : R4 - DEVICE CSR ADDRESS
061A 1226 : R5 - UCB ADDRESS
061A 1227 :
061A 1228 : FUNCTIONAL DESCRIPTION:
061A 1229 :
061A 1230 : A UNIBUS DATAPATH IS REQUESTED FOLLOWED BY THE APPROPRIATE NUMBER OF MAP
061A 1231 : REGISTERS REQUIRED FOR THE TRANSFER. THE TRANSFER PARAMETERS ARE LOADED
061A 1232 : INTO THE DEVICE REGISTERS, INTERRUPTS ARE LOCKED OUT, THE FUNCTION IS
061A 1233 : INITIATED, AND A WAITFOR INTERRUPT AND KEEP CHANNEL IS EXECUTED.
061A 1234 :
061A 1235 : UPON RETURN FROM THE INTERRUPT SERVICE ROUTINE, IF THE TRANSFER IS
061A 1236 : COMPLETE, THE APPROPRIATE EXIT IS TAKEN. IF THE FUNCTION IS NOT COMPLETE
061A 1237 : TRANSFER PARAMETERS ARE UPDATED AND A RETURN TO FDISPATCH IS EXECUTED TO
061A 1238 : RE-ISSUE SEEK AND TRANSFER FUNCTIONS WHILE KEEPING CHANNEL AND UBA
061A 1239 : RESOURCES. IF A DATA CHECK HAS BEEN REQUESTED, IT IS PERFORMED
061A 1240 : BEFORE RETURNING TO FDISPATCH.
061A 1241 :
061A 1242 :
061A 1243 XFER:
061A 1244 : TRANSFER FUNCTION EXECUTION
061C 1245 : BBS #UCBSV_DL_MAPPING,- :ADAPTER MAPPING?
0620 1246 : MOVW UCBSW_DL_FLAGS(R5),28 :BRANCH IF ADAPTER MAPPING.
0627 1247 : MOVZWL UCBSA_DL_BUF_PA(R5),UCBSW_DL_SBA(R5);GET 1ST WORD OF BUFFER ADDR
062C 1248 : MOVW R0,RL_BAE(R4) :SET MEMORY EXTENSION BITS IN BAE
0630 1249 : ASHL #4,R0,R0 :PUT MEMORY EXTENSION BITS IN <5:4>
0634 1250 : MOVB R0,UCBSB_DL_XBA(R5) :OF CSR
0639 1251 :
0639 1252 : FIRST TRANSFER OF THIS I/O REQUEST - ALLOCATE RESOURCES
0639 1253 :
00D6 C5 B5 0639 1254 : TSTW UCBSW_DL_DPN(R5) :RESOURCES ALREADY ALLOCATED?
0612 1255 : BNEQ 5$ :IF NEQ - YES
00E0 C5 D4 063F 1256 : CLRL UCBSA_DL_MOVRTN(R5) :ASSUME READ
0053 08 91 0643 1257 : CMPB #CDF_WRITEDATA,R3 :WRITE DATA?
0009 12 0646 1258 : BNEQ 1$ :IF NEQ NO
00000000 GF 9E 0648 1259 : MOVAB G^IIOC$MOVFRUSER,- :SET MOVE ROUTINE ADDRESS FOR
00E0 C5 064E 1260 : UCBSA_DL_MOVRTN(R5) :1ST PARTIAL WRITE
00D8 C5 78 A5 D0 0651 1261 1$: MOVL UCBSL_SVAPTE(R5),UCBSL_DL_SVAPTE(R5);SAVE SVAPTE FOR BUFFER COPY
00D6 C5 01 AE 0657 1262 : MNEGW #1,UCBSW_DL_DPN(R5) :SET FIRST XFER FLAG
0042 11 065C 1263 : BRB 5$ :JOIN COMMON CODE
065E 1264 :
065E 1265 :
065E 1266 : FIRST TRANSFER OF THIS I/O REQUEST - ALLOCATE RESOURCES
065E 1267 :
00D6 C5 B5 065E 1268 2$: TSTW UCBSW_DL_DPN(R5) :UBA RESOURCES ALREADY ALLOCATED?

```



```

3C 12 0662 1269      BNEQ 58          ;IF NEQ - YES
                0664 1270      REQDPR          ;REQUEST DATAPATH
                066A 1271      REQMPR          ;REQUEST MAP REGISTERS
                0670 1272      LOADUBA         ;LOAD UNIBUS MAP REGISTERS
51 24 A5 DO 0676 1273      MOVL UCBSL_CRB(R5),R1      ;GET CRB ADDRESS
50 05 00 EF 067A 1274      EXTZV #VEC$V DATAPATH,#VEC$S DATAPATH,- ;EXTRACT DATAPATH NUMBER -
00D6 C5 50 B0 067D 1275      CRBSL INTD+VEC$B DATAPATH(R1),R0 ;FOR UBA RESOURCE FLAG
50 7C A5 3C 0680 1276      MOVW RO,UCBSW_DL_DPN(R5) ;INDICATE UBA RESOURCES ALLOCATED
50 34 A1 FO 0685 1277      MOVZWL UCBSW_BOFF(R5),R0 ;GET BYTE OFFSET IN PAGE
50 07 09 EF 0689 1279      INSV CRBSL_INTD+VEC$W_MAPREG(R1),- ;INSERT HIGH 7 BITS OF ADDRESS
00EC C5 50 B0 068C 1280      #9,#7-R0
50 34 A1 02 07 EF 068F 1281      MOVW RO,UCBSW_DL_SBA(R5) ;SET BUFFER ADDRESS
00EB C5 50 10 B5 0694 1282      EXTZV #7,#2,CRBSL_INTD+VEC$W_MAPREG(R1),R0 ;GET MEMORY EXTENSION BITS
                069A 1283      MULB3 #16,R0,UCBSB_DL_XBA(R5) ;POSITION MEMORY EXTENSION BITS TO <5:4>
                06A0 1284
                06A0 1285 :
                06A0 1286 : COMMON TRANSFER POINT
                06A0 1287 :
                06A0 1288 :
                06A0 1289 :
                06A0 1290 : FOR A READ OPERATION WHEN NO ADAPTER MAPPING IS PRESENT EMPTY THE
                06A0 1291 : INTERNAL PHYSICALLY CONTIGUOUS BUFFER FROM THE PREVIOUS READ TO THE
                06A0 1292 : USER'S BUFFER.
                06A0 1293 :
02DA 30 06A0 1294 58: BSBW DL_MOVE_TO_BUFFER ;COPY TO USER BUFFER
                06A3 1295 :
                06A3 1296 : PUT BUFFER ADDRESS, WORD COUNT, AND DISK ADDRESS IN DEVICE REGISTERS
                06A3 1297 :
                06A3 1298 :
02 A4 00EC C5 B0 06A3 1299      MOVW UCBSW_DL_SBA(R5),RL_BA(R4) ;SET BUFFER ADDRESS
                00CO C5 AE 06A9 1300      MNEGW UCBSW_BCR(R5),- ;GET BYTES LEFT TO TRANSFER AND -
                00CC C5 06AD 1301      UCBSW_DL_PBCR(R5) ;ASSUME ONLY ONE TRANSFER NEEDED
52 44 A5 9A 06B0 1302      MOVZBL UCBSB_SECTORS(R5),R2 ;GET SECTORS/SURFACE
51 00BC C5 9A 06B4 1303      MOVZBL UCBSW_DA(R5),R1 ;GET DESIRED SECTOR
52 52 51 A2 06B9 1304      SUBW R1,R2 ;CALCULATE SECTORS LEFT ON SURFACE
52 0100 8F A4 06BC 1305      MULW #256,R2 ;CONVERT TO BYTES LEFT ON SURFACE
52 00CC C5 B1 06C1 1306      CMPW UCBSW_DL_PBCR(R5),R2 ;ARE ADDITIONAL TRANSFERS REQUIRED?
00CC C5 05 1B 06C6 1307      BLEQU 108 ;IF LEQU - NO
                06C8 1308      MOVW R2,UCBSW_DL_PBCR(R5) ;SET BYTE COUNT FOR THIS TRANSFER
                06CD 1309 :
                06CD 1310 : FOR A WRITE OPERATION WHEN NO ADAPTER MAPPING IS PRESENT
                06CD 1311 : FILL INTERNAL PHYSICALLY CONTIGUOUS BUFFER FROM THE USER'S BUFFER.
                06CD 1312 :
02F2 30 06CD 1313 108: BSBW DL_MOVE_FROM_BUFFER ;COPY FROM USER BUFFER
                06D0 1314 :
50 00EB C5 9A 06D0 1315      MOVZBL UCBSB_DL_XBA(R5),R0 ;SET MEMORY EXTENSION BITS
50 F95E CF43 AB 06D5 1316      BISW FTAB[R3],R0 ;MERGE XBA BITS WITH FUNCTION
52 00CC C5 02 A7 06DB 1317      DIVW3 #2,UCBSW_DL_PBCR(R5),R2 ;CALCULATE TRANSFER WORD COUNT
52 06 A4 52 AE 06E1 1318      MNEGW R2,RL_MPTR4 ;SET TRANSFER WORD COUNT
                06E5 1319 :
51 01 51 00BC C5 9A 06E5 1320      MOVZBL UCBSW_DA(R5),R1 ;PUT DESIRED SECTOR IN R1<5:0>
51 09 06 00BD C5 FO 06EA 1321      INSV UCBSW_DA+1(R5),#6,#1,R1 ;INSERT DESIRED SURFACE IN R1<6>
                07 00BE C5 FO 06F1 1322      INSV UCBSW_DC(R5),#7,#9,R1 ;INSERT DESIRED CYLINDER IN R1<15:7>
                04 A4 51 B0 06F8 1323      MOVW R1,RL_DA(R4) ;SET DESIRED DISK ADDRESS
                06FC 1324
                06FC 1325 :

```

```
06FC 1326 : EXECUTE THE TRANSFER FUNCTION
06FC 1327 :
06FC 1328 :
06FC 1329 CKPWR ;DISABLE INTERRUPTS, CHECK POWER,-
0715 1330 ;AND PUT UNIT NUMBER IN R2<9:8>
64 50 52 A9 0715 1331 BISW3 R2,RO,RL CS(R4) ;EXECUTE FUNCTION
0719 1332 WFIKPCW RETREG,#8 ;WAITFOR INTERRUPT AND KEEP CHANNEL
0723 1333 ;RETURN HERE FROM ISR SAVING REGISTERS
0723 1334 IOFORK ;CREATE FORK PROCESS (RETURN TO ISR)
0729 1335 ;RETURN HERE FROM ISR REI ROUTINE
0729 1336 :
0729 1337 :
0729 1338 : PURGE DATAPATH
0729 1339 :
0729 1340 :
00E4 C5 94 0729 1341 CLR B UCBSB_DL_DPPE(R5) ;CLEAR DATAPATH PURGE ERROR
00000000 GF 16 072D 1342 JSB G*IOCS$PURGDATAP ;PURGE DATAPATH
04 50 E8 0733 1343 BLBS RO,20$ ;IF SET - NO PURGE ERRORS
00E4 C5 96 0736 1344 INCB UCBSB_DL_DPPE(R5) ;SET DATAPATH PURGE ERROR
073A 1345 :
073A 1346 :
073A 1347 : SAVE UBA REGISTERS FOR UPDATE AND REGDUMP ROUTINES
073A 1348 :
073A 1349 :
50 00D0 C5 01 E1 073A 1350 20$: BBC #UCBSV_DL_MAPPING, - ;ADAPTER MAPPING?
3E 00F6 C5 51 DO 073C 1351 UCBSW_DL_FLAGS(R5),30$ ;IF BC NO
00DB C5 07 09 EF 0740 1352 MOVL R1,UCBSL_DL_DPR(R5) ;SAVE DATAPATH REGISTER
51 00CE C5 02 04 EF 0745 1353 EXTZV #9,#7,UCBSW_DL_BA(R5),RO ;EXTRACT LOW BITS OF FINAL MAP REG NO.
50 02 07 51 FO 074C 1354 EXTZV #4,#2,UCBSW_DL_CS(R5),R1 ;EXTRACT HI BITS OF FINAL MAP REG NO.
50 01EF 8F B1 0753 1355 INSV R1,#7,#2,RO ;INSERT HIGH BITS OF FINAL MAP REGISTER
05 18 075D 1356 CMPW #495,RO ;LEGAL MAP REGISTER NUMBER?
50 01EF 8F 3C 0758 1357 BGEQ 25$ ;IF GEQ - YES
00DC C5 6240 DO 0764 1358 MOVZWL #495,RO ;RESTRICT MAP REGISTER NUMBER
00E0 C5 D4 0764 1359 25$: MOVL (R2)[RO],UCBSL_DL_FMPR(R5) ;SAVE FINAL MAP REGISTER NUMBER
50 D7 076E 1360 CLRL UCBSL_DL_PMPR(R5) ;CLEAR PREVIOUS MAP REGISTER CONTENTS
0F 00 EC 0770 1361 DECL RO ;CALCULATE PREVIOUS MAP REGISTER NUMBER
50 34 A3 0773 1362 CMPV #VECSV_MAPREG,#VECSS_MAPREG,- ;ANY PREVIOUS MAP REGISTER?
00E0 C5 6240 DO 0776 1363 CRBSL_INTD+VECSW_MAPREG(R3),RO ;...
03 00CE C5 0F E1 0777 1364 BGTR 30$ ;IF GTR - NO
0098 31 0784 1365 MOVL (R2)[RO],UCBSL_DL_PMPR(R5) ;SAVE PREVIOUS MAP REGISTER
03 00E4 C5 E9 077E 1366 30$: BBC #RL_CS_V_CE,UCBSW_DL_CS(R5),40$ ;IF CLR - NO RL ERRORS
0090 31 0784 1367 BRW RETREG ;DEVICE ERROR
078F 1368 40$: BLBC UCBSB_DL_DPPE(R5),45$ ;IF CLR - NO PURGE ERROR
078F 1369 BRW RETREG ;PURGE ERROR
078F 1370 :
078F 1371 :
078F 1372 : RETURN HEADER INFORMATION FOR READ HEADER FUNCTION
078F 1373 :
078F 1374 :
0093 C5 0E 91 078F 1375 45$: CMPB #CDF_READHEAD,UCBSB_CEX(R5) ;READ HEADER FUNCTION?
2F 12 0794 1376 BNEQ DATA$CHECK ;IF NEQ - NO
00C0 C5 DD 0796 1377 PUSHL UCBSW_BCR(R5) ;SAVE NEG BYTES REMAINING
78 A5 DD 079A 1378 PUSHL UCBSL_SVAPTE(R5) ;SAVE ADDRESS OF PTE
51 00E5 C5 9E 079D 1379 MOVAB UCBSW_DL_DB(R5),R1 ;SET ADDRESS OF INTERNAL BUFFER
52 06 DO 07A2 1380 MOVL #6,R2 ;SET NUMBER OF BYTES TO MOVE
7E A5 52 B1 07A5 1381 CMPW R2,UCBSW_BCNT(R5) ;ROOM FOR FULL HEADER?
04 1F 07A9 1382 BLSSU 50$ ;IF LSSU - YES
```

```

00C0 C5 52 7E A5 3C 07AB 1383 MOVZWL UCBSW_BCNT(R5),R2 ;SET LENGTH OF PARTIAL HEADER
          52 7E A5 A3 07AF 1384 50$: SUBW3 UCBSW_BCNT(R5),R2,UCBSW_BCR(R5) ;CALCULATE TRANSFER BYTE COUNT
          00000000 GF 16 07B6 1385 JSB G^IOCS$MOVTOUSER ;MOVE HEADER TO USER BUFFER
          78 A5 8ED0 07BC 1386 POPL UCBSL_SVAPE(R5) ;RESTORE ADDRESS OF PTE
          00C0 C5 8ED0 07C0 1387 POPL UCBSW_BCR(R5) ;RESTORE NEG BYTES REMAINING
          07C5 1388
          07C5 1389
          07C5 1390 ; PERFORM DATA CHECK, IF REQUESTED
          07C5 1391
          07C5 1392
          07C5 1393
          10 009A OE E1 07C5 1394 DATACHECK: ;DATACHECK AFTER PARTIAL TRANSFER
          00C9 C5 00 E4 07C7 1395 BBC #IOSV_DATACHECK,- ;IF CLR - DATA CHECK NOT REQUESTED
          0A 07CB 1396 BBSC #0,UCBSB_DL_DCHEK(R5),- ;IF SET - DATA CHECK ALREADY PERFORMED
          00C9 C5 96 07D0 1397 UPDATE ;...
          53 0A 9A 07D1 1398 INCB UCBSB_DL_DCHEK(R5) ;SET DATA CHECK IN PROGRESS
          FE3F 31 07D5 1399 MOVZBL #IOS_WRITECHECK,R3 ;SET CASE INDEX TO WRITE CHECK
          07DB 1400 BRW XFER ;BRANCH TO PERFORM WRITE CHECK
          07DB 1401
          07DB 1402
          07DB 1403 ; UPDATE BUFFER ADDRESS, CURRENT DISK ADDRESS, AND BYTES REMAINING
          07DB 1404 ; FOR NEXT TRANSFER
          07DB 1405
          07DB 1406
          07DB 1407 UPDATE: ;UPDATE TRANSFER PARAMETERS
          10 00F6 01 E1 07DB 1408 BBC #UCBSV_DL_MAPPING,- ;ADAPTER MAPPING?
          00CE C5 CF 8F 8B 07DD 1409 UCBSW_DL_FLAGS(R5),10$ ;IF BC NO
          00EB C5 07E1 1410 BICB3 #^XCF,UCBSW_DL_CS(R5),- ;SAVE MEMORY EXTENSION BITS
          00D0 C5 80 07E7 1411 UCBSB_DL_XBA(R5) ;...
          00EC C5 07EA 1412 MOVW UCBSW_DL_BA(R5),- ;UPDATE SAVED BUFFER ADDRESS
          07EE 1413 UCBSW_DL_SBA(R5) ;...
          07F1 1414
          51 00D2 C5 00000040 8F C1 07F1 1415 10$: CLRB UCBSW_DA(R5) ;UPDATE DESIRED SECTOR TO ZERO
          52 51 01 06 EF 07F5 1416 ADDL3 #^0100,UCBSW_DL_DA(R5),R1 ;INCREMENT CYLINDER & SURFACE
          00BD C5 52 90 07FF 1417 EXTZV #6,#1,R1,R2 ;EXTRACT DESIRED DISK SURFACE
          52 51 09 07 EF 0804 1418 MOVW R2,UCBSW_DA+1(R5) ;UPDATE DESIRED DISK SURFACE
          00BE C5 52 80 0809 1419 EXTZV #7,#9,R1,R2 ;EXTRACT DESIRED DISK CYLINDER
          00CC C5 A0 080E 1420 MOVW R2,UCBSW_DC(R5) ;UPDATE DESIRED DISK CYLINDER
          00C0 C5 0813 1421 ADDW UCBSW_DL_PBCR(R5),- ;UPDATE NEG BYTES REMAINING TO XFER
          03 13 0817 1422 UCBSW_BCR(R5) ;...
          FAFB 31 081A 1423 BEQL RETREG ;IF EQL - TRANSFER COMPLETE
          081C 1424 BRW FDISPATCH ;MORE BYTES REMAINING - CONTINUE
          081F 1425
          081F 1426
          081F 1427 ; GET STATUS AND RESET ERRORS
          081F 1428
          081F 1429
          081F 1430 RETREG: ;GET STATUS AND RESET ERRORS
          081F 1431
          081F 1432 ; FOR A READ OPERATION WHEN NO ADAPTER MAPPING IS PRESENT
          081F 1433 ; EMPTY INTERNAL BUFFER INTO USER'S BUFFER FOR LAST READ
          081F 1434
          015B 30 081F 1435 BSBW DL_MOVE_TO_BUFFER ;MOVE LAST READ INTO USER'S BUFFER
          0822 1436
          0822 1437 SETIPL UCBSB_FIPL(R5) ;MAKE SURE AT FORK IPL (TIMEOUT)
          04 A4 03 B0 0826 1438 MOVW #RL_DA_M_STS!- ;PUT GET STATUS IN DAR
          082A 1439 RL_DA_M_MRK,RL_DA(R4) ;...

```

```

52 08 08 54 A5 52 D4 082A 1440 CLR  R2 ;CLEAR R2 FOR UNIT NUMBER
    64 04 52 A9 082C 1441 INSV UCBSW_UNIT(R5),#8,#8,R2 ;GET UNIT NUMBER
    FA2A 30 0832 1442 BISW3 R2,#F-GETSTATUS,RL_CS(R4) ;EXECUTE GET STATUS
00D4 C5 06 A4 B0 0836 1443 BSBW DL_WAIT ;WAIT FOR CONTROLLER
    04 A4 08 B0 0839 1444 MOVW RL_MP(R4),UCBSW_DL_MP(R5) ;RETRIEVE ERROR REGISTER
    64 04 52 A9 083F 1445 MOVW #RL_DA_M_RST!- ;PUT GET STATUS & RESET IN DAR
    FA19 30 0843 1446 RL_DA_M_STS!RL_DA_M_MRK,RL_DA(R4) ;
    0843 1447 BISW3 R2,#F-GETSTATUS,RL_CS(R4) ;EXECUTE RESET
    084A 1448 BSBW DL_WAIT ;WAIT FOR CONTROLLER
    084A 1449
    084A 1450 ;
    084A 1451 ; DETERMINE EXIT - SPECIAL CONDITION, FATAL ERROR, RETRIABLE ERROR, OR SUCCESS
    084A 1452 ;
    084A 1453 ;
00D4 C5 05 00 ED 084A 1454 CMPZV #0,#5,UCBSW_DL_MP(R5),- ;HEADS, BRUSHES, STATE OK?
    1D 0850 1455 #RL_MP_M_BH!RL_MP_M_HO!RL_SLM ;...
    OE 13 0851 1456 BEQL 1$ ;IF EQL - YES, ONLINE
    64 A5 0040 8F AA 0853 1457 BICW #UCBSM TIMEOUT,UCBSW_STS(R5) ;CLEAR DEVICE TIME OUT
    50 01A4 8F 3C 0859 1458 MOVZWL #SS$ MEDOFL,R0 ;SET MEDIUM OFFLINE STATUS
    FB85 31 085E 1459 BRW FUNCRT ;RETURN
    64 A5 0060 8F B3 0861 1460 1$: BITW #UCBSM POWER!- ;POWER FAIL OR DEVICE TIMEOUT?
    0867 1461 UCBSM TIMEOUT,UCBSW_STS(R5) ;
    53 12 0867 1462 BNEQ SPECORD ;IF NEQ - YES, SPECIAL CONDITION
    0869 1463
    4A 00D4 C5 09 E0 0869 1464 BBS #RL_MP_V_VC,UCBSW_DL_MP(R5),20$ ;IF SET - VOLUME INVALID
    05 00CE C5 0F E0 086F 1465 BBS #RL_CS_V_CE,UCBSW_DL_CS(R5),2$ ;IF SET - RL ERROR
    37 00E4 C5 E9 0875 1466 BLBC UCBSB_DL_DPPE(R5),10$ ;IF CLR - NO PURGE ERROR
    00000000 GF 16 087A 1467 2$: JSB G*ERL$DEVICERR ;ALLOCATE AND FILL ERROR MESSAGE BUFFER
    33 009A C5 0F E0 0880 1468 BBS #IOSV INHRETRY,UCBSW_FUNC(R5),20$ ;IF SET - RETRY INHIBITED
    2D 00CE C5 0D E0 0886 1469 BBS #RL_CS_V_NXM,UCBSW_DC_CS(R5),20$ ;IF SET - NONEXISTENT MEMORY
    15 00C2 C5 0E E1 088C 1470 BBC #RL_CS_V_DE,UCBSW_DL_CS(R5),5$ ;IF CLR - NO DRIVE ERRORS
    06 00D4 C5 0D E1 0892 1471 BBC #RL_MP_V_WL,UCBSW_DL_MP(R5),4$ ;IF CLR - NOT WRITE LOCKED
    1B 00D4 C5 0A E0 0898 1472 BBS #RL_MP_V_WGE,UCBSW_DC_MP(R5),20$ ;IF WL & WGE SET - WL ERROR
00D4 C5 C500 8F B3 089E 1473 4$: BITW #RL_MP_M_WDE!- ;WRITE DATA ERROR, OR
    08A5 1474 RL_MP_M_CHE!- ;CURRENT HEAD ERROR, OR
    08A5 1475 RL_MP_M_WGE!- ;WRITE GATE ERROR, OR
    08A5 1476 RL_MP_M_DSE,UCBSW_DL_MP(R5) ;DRIVE SELECT ERROR?
    12 12 08A5 1477 BNEQ 20$ ;IF NEQ - YES
    08A7 1478
    08A7 1479 ;
    08A7 1480 ; RETRIABLE ERROR EXIT
    08A7 1481 ;
    08A7 1482 ;
    7E 009C D5 98 08A7 1483 5$: CVTBL @UCBSL_DPC(R5),-(SP) ;GET BRANCH DISPLACEMENT
    009C C5 8E C0 08AC 1484 ADDL (SP)+,UCBSL_DPC(R5) ;CALCULATE RETURN ADDRESS - 1
    08B1 1485
    08B1 1486 ;
    08B1 1487 ; SUCCESSFUL OPERATION EXIT
    08B1 1488 ;
    08B1 1489 ;
    009C C5 D6 08B1 1490 10$: INCL UCBSL_DPC(R5) ;ADJUST TO CORRECT RETURN ADDRESS
    009C D5 17 08B5 1491 JMP @UCBSL_DPC(R5) ;RETURN TO DRIVER
    08B9 1492
    08B9 1493 ;
    08B9 1494 ; FATAL ERROR EXIT
    08B9 1495 ;
    08B9 1496

```

```

FADC 31 08B9 1497 20$: BRW FATALERR :FATAL ERROR EXIT
      08BC 1498
      08BC 1499 :
      08BC 1500 : SPECIAL CONDITION EXIT (POWER FAILURE OR DEVICE TIMEOUT)
      08BC 1501 :
      08BC 1502 :
      08BC 1503 SPECOND:
27 64 A5 05 E0 08BC 1504 BBS #UCBSV_POWER,UCBSW_STS(R5),PWRFAIL ;IF SET - POWER FAILURE
      08C1 1505 ;IF CLR - DEVICE TIMEOUT
      08C1 1506 JSB G^ERL$DEVICTMO ;LOG DEVICE TIMEOUT
64 A5 0040 8F AA 08C7 1507 BICW #UCBSM_TIMEOUT,UCBSW_STS(R5) ;CLEAR TIMEOUT STATUS
50 022C 8F 3C 08CD 1508 MOVZWL #SS$ TIMEOUT,R0 ;SET DEVICE TIMEOUT STATUS
      0080 C5 97 08D2 1509 DECB UCBSB_ERTCNT(R5) ;ANY ERROR RETRIES REMAINING?
      03 13 08D6 1510 BEQL RESETXFR ;IF EQL - NO
      FA3C 31 08DB 1511 BRW FDISPATCH ;RETURN
      08DB 1512
      08DB 1513 RESETXFR: ;RESET TRANSFER BYTE COUNT
00C0 53 58 A5 D0 08DB 1514 MOVL UCBSL_IRP(R5),R3 ;GET ADDRESS OF I/O PACKET
      C5 32 A3 AE 08DF 1515 MNEGW IRPSW_BCNT(R3),UCBSW_BCR(R5) ;RESET BYTE COUNT
      FAFE 31 08E5 1516 BRW FUNCXT ;EXIT
      08E8 1517
      08E8 1518 PWRFAIL: ;POWER FAILURE
64 A5 20 AA 08E8 1519 BICW #UCBSM_POWER,UCBSW_STS(R5) ;CLEAR POWER FAILURE BIT
      00D6 C5 B5 08EC 1520 TSTW UCBSW_DL_DPN(R5) ;ARE UCB RESOURCES ALLOCATED?
      12 13 08F0 1521 BEQL 50$ ;IF EQL - NO
      01 E1 08F2 1522 BBC #UCBSV_DL_MAPPING,- ;ADAPTER MAPPING?
OC 00F6 C5 08F4 1523 UCBSW_DL_FLAGS(R5),50$ ;IF BC NO
      08F8 1524 RELDPR ;RELEASE DATA PATH
      08FE 1525 RELMPR ;RELEASE MAP REGISTERS
53 58 A5 D0 0904 1526 RELCHAN ;RELEASE CHANNEL IF OWNED
      2C A3 7D 090A 1527 MOVL UCBSL_IRP(R5),R3 ;GET ADDRESS OF I/O PACKET
      78 A5 7D 090E 1528 MOVQ IRPSL_SVApte(R3),- ;RESTORE TRANSFER PARAMETERS
      F992 31 0911 1529 UCBSL_SVApte(R5)
      0913 1530 BRW PREPROCESS ;RETURN TO PREPROCESS UCB FIELDS

```

```

0916 1532 .SBITL INTERRUPT SERVICE ROUTINE
0916 1533 :++
0916 1534 : DL$INT - RL11 INTERRUPT SERVICE ROUTINE
0916 1535 :
0916 1536 : FUNCTIONAL DESCRIPTION:
0916 1537 :
0916 1538 : THIS ROUTINE IS ENTERED VIA A JSB INSTRUCTION WHEN AN INTERRUPT
0916 1539 : OCCURS ON AN RL11 DISK CONTROLLER. IF THE INTERRUPT IS NOT EXPECTED,
0916 1540 : THE UNSOLICITED INTERRUPT ROUTINE DISMISSES THE INTERRUPT. IF
0916 1541 : THE INTERRUPT IS EXPECTED, DEVICE REGISTERS ARE SAVED AND THE
0916 1542 : DRIVER IS CALLED AT ITS INTERRUPT RETURN ADDRESS. THE DRIVER FORKS,
0916 1543 : CAUSING A RETURN TO THIS ROUTINE, WHICH RESTORES GENERAL REGISTERS
0916 1544 : AND DISMISSES THE INTERRUPT.
0916 1545 :
0916 1546 : INPUTS:
0916 1547 :
0916 1548 : 00(SP) - POINTER TO ADDRESS OF THE IDB
0916 1549 : 04(SP) - SAVED R0
0916 1550 : 08(SP) - SAVED R1
0916 1551 : 12(SP) - SAVED R2
0916 1552 : 16(SP) - SAVED R3
0916 1553 : 20(SP) - SAVED R4
0916 1554 : 24(SP) - SAVED R5
0916 1555 : 28(SP) - PC AT THE TIME OF THE INTERRUPT
0916 1556 : 32(SP) - PSL AT THE TIME OF THE INTERRUPT
0916 1557 :
0916 1558 : OUTPUTS:
0916 1559 :
0916 1560 : DEVICE REGISTERS ARE SAVED, IPL IS LOWERED TO FORK LEVEL, THE
0916 1561 : INTERRUPT IS DISMISSED, ALL REGISTERS EXCEPT R0-R5 ARE PRESERVED.
0916 1562 :
0916 1563 :--
0916 1564 :
0916 1565 DL_INT:: : INTERRUPT SERVICE ROUTINE
53 9E D0 0916 1566 MOVL @ (SP)+, R3 : REMOVE ADDRESS OF IDB FROM STACK
54 63 7D 0919 1567 MOVQ (R3), R4 : GET ADDRESS OF CSR AND UCB
55 05 091C 1568 TSTL R5 : IS R5 A ZERO
39 13 091E 1569 BEQL DL_UNSOINT : IF EQL NO OWNER
01 E5 0920 1570 BBCC #UCB$V_INT, - : IF CLR - INTERRUPT NOT EXPECTED
34 64 A5 0922 1571 UCBSW_STS(R5), DL_UNSOINT ;...
0925 1572
0093 C5 0E 91 0925 1573 CMPB #CDF_READHEAD, UCBSB_CEX(R5) : READ HEADER FUNCTION?
12 12 092A 1574 BNEQ 10$ : IF NEQ - NO
00E5 C5 06 A4 80 092C 1575 MOVW RL_MP(R4), UCBSW_DL_DB(R5) : SAVE SECTOR HEADER INFORMATION
00E7 C5 06 A4 80 0932 1576 MOVW RL_MP(R4), UCBSW_DL_DB+2(R5) :...
00E9 C5 06 A4 80 0938 1577 MOVW RL_MP(R4), UCBSW_DL_DB+4(R5) :...
093E 1578
53 52 64 9E 093E 1579 10$: MOVAB RL_CS(R4), R2 : GET ADDRESS OF CONTROL STATUS REGISTER
00CE C5 9E 0941 1580 MOVAB UCBSW_DL_CS(R5), R3 : GET ADDRESS OF REGISTER SAVE AREA
83 82 80 0946 1581 MOVW (R2)+, (R3)+ : SAVE CONTROL STATUS REGISTER
83 82 80 0949 1582 MOVW (R2)+, (R3)+ : SAVE BUFFER ADDRESS REGISTER
83 82 80 094C 1583 MOVW (R2)+, (R3)+ : SAVE DISK ADDRESS REGISTER
83 82 80 094F 1584 MOVW (R2)+, (R3)+ : SAVE MULTIPURPOSE REGISTER
0952 1585
53 10 A5 7D 0952 1586 20$: MOVQ UCBSL_FR3(R5), R3 : RESTORE DRIVER CONTEXT
OC B5 16 0956 1587 JSB @UCBSL_FPC(R5) : CALL DRIVER AT INTERRUPT RETURN ADDRESS
0959 1588

```

DLDRIVER  
V04-000

- VAX/VMS RL11/RL01,RL02 DISK DRIVER<sup>D 8</sup>  
INTERRUPT SERVICE ROUTINE

16-SEP-1984 00:17:29 VAX/VMS Macro V04-00  
5-SEP-1984 00:12:24 [DRIVER.SRC]DLDRIVER.MAR;1

Page 36  
(1)

DMD  
V04

```
3F  BA 0959 1589 DL_UNSolNT:      ;UNSolICITED INTERRUPT
    02 0959 1590          POPR      ;RESTORE R0-R5
    02 095B 1591          REI       ;RETURN FROM INTERRUPT
```

```

095C 1593      .SBTTL REGISTER DUMP ROUTINE
095C 1594      :++
095C 1595      :
095C 1596      : DL_REGDUMP - REGISTER DUMP ROUTINE
095C 1597      :
095C 1598      : FUNCTIONAL DESCRIPTION:
095C 1599      :
095C 1600      : THIS ROUTINE IS CALLED TO SAVE THE DEVICE REGISTERS AND UBA RESOURCE
095C 1601      : REGISTERS IN A SPECIFIED BUFFER. IT IS CALLED FROM THE DEVICE ERROR
095C 1602      : LOGGING ROUTINE AND FROM THE DIAGNOSTIC BUFFER FILL ROUTINE.
095C 1603      :
095C 1604      : INPUTS:
095C 1605      :
095C 1606      :     R0      - ADDRESS OF REGISTER SAVE BUFFER
095C 1607      :     R4      - ADDRESS OF DEVICE CONTROL STATUS REGISTER (CSR)
095C 1608      :     R5      - ADDRESS OF UNIT CONTROL BLOCK (UCB)
095C 1609      :
095C 1610      : OUTPUTS:
095C 1611      :
095C 1612      :     THE DEVICE AND UBA REGISTERS ARE SAVED IN THE SPECIFIED BUFFER.
095C 1613      :     R0 CONTAINS THE ADDRESS OF THE NEXT EMPTY LONGWORD IN THE BUFFER.
095C 1614      :     ALL REGISTERS EXCEPT R1 AND R2 ARE PRESERVED.
095C 1615      :
095C 1616      :--
095C 1617      :
095C 1618      DL_REGDUMP:
095C 1619      MOVL   #<RL_NUM_REGS+5>,(R0)+ ;REGISTER DUMP ROUTINE
51  80 09 D0 095C 1620      MOVAL   UCBSW DL-CS(R5),R1 ;INSERT NUMBER OF REGISTERS
      00CE C5 DE 095F 1621      MOVZBL  #RL_NUM_REGS,R2 ;GET ADDRESS OF SAVED DEVICE REGISTERS
      52 04 9A 0964 1622      MOVZWL  (R1)+,(R0)+ ;GET NUMBER OF DEVICE REGISTERS TO MOVE
      80 81 3C 0967 1623      SOBGR   R2,10$ ;DUMP REGISTER IN BUFFER
      FA 52 F5 096A 1624      MOVZWL  (R1)+,(R0)+ ;IF GTR - STILL MORE TO MOVF
      80 81 3C 096D 1625      MOVL   (R1)+,(R0)+ ;DUMP DATAPATH NUMBER
      80 81 D0 0970 1626      MOVL   (R1)+,(R0)+ ;DUMP DATAPATH REGISTER
      80 81 D0 0973 1627      MOVL   (R1)+,(R0)+ ;DUMP FINAL MAP REGISTER
      80 81 D0 0976 1628      MOVZBL (R1)+,(R0)+ ;DUMP PREVIOUS MAP REGISTER
      80 81 9A 0979 1629      RSB ;DUMP DATAPATH PURGE ERROR REGISTER
      05 097C 1630      ;RETURN
      097D 1630

```



```

097D 1632 .SBTTL MOVE TO USER BUFFER ROUTINE
097D 1633 :++
097D 1634 :
097D 1635 : DL_MOVE_TO_BUFFER - MOVE TO USER BUFFER
097D 1636 :
097D 1637 : FUNCTIONAL DESCRIPTION:
097D 1638 :
097D 1639 : THIS ROUTINE MOVES DATA BETWEEN THE PHYSICALLY CONTIGUOUS BUFFER AND
097D 1640 : THE USER'S BUFFER.
097D 1641 :
097D 1642 : INPUTS:
097D 1643 :
097D 1644 :     R5 - UCB ADDRESS
097D 1645 :
097D 1646 : OUTPUTS:
097D 1647 :
097D 1648 :     DATA MOVE BETWEEN THE PHYSICALLY CONTIGUOUS BUFFER AND THE USER'S BUFFER.
097D 1649 :     REGISTER'S R0,R1, AND R2 ARE DESTROYED
097D 1650 :
097D 1651 :--
097D 1652 :
097D 1653 DL_MOVE_TO_BUFFER:
097D 1654 BBS #UCBSV_DL_MAPPING,- ;BUFFER MOVE ROUTINE
097F 1655 UCBSW_DL_FLAGS(R5),10$ ;ADAPTER MAPPING?
0983 1656 CMPB #CDF_READDATA,UCBSB_CEX(R5);READ DATA OPERATION? ;IF BS YES NOTHING TO MOVE
0988 1657 BNEQ 10$ ;IF NEQ NOT A READ
098A 1658 BBS #0,UCBSB_DL_DCHEK(R5),- ;DATA CHECK IN PROGRESS?
098F 1659 10$ ;IF BS YES NOTHING TO MOVE
0990 1660 TSTL UCBSA_DL_MOVRTN(R5) ;ANYTHING TO MOVE?
0994 1661 BEQL 20$ ;IF EQL NO
0996 1662 MOVL UCBSL_DL_BUFADR(R5),R0 ;GET USER BUFFER POINTER
0998 1663 MOVL UCBSA_DL_BUF_VA(R5),R1 ;GET PHYSICALLY CONTIGUOUS BUFFER ADDRESS
09A0 1664 MOVZWL UCBSW_DL_PBCR(R5),R2 ;GET NUMBER OF BYTES TO TRANSFER
09A5 1665 JSB @UCBSA_DL_MOVRTN(R5) ;CALL MOVE ROUTINE
09A9 1666 MOVL R0,UCBSL_DL_BUFADR(R5) ;SAVE INTERNAL BUFFER POINTER
09AE 1667 MOVAB G^IOC$MOVTOUSER,- ;SET NEXT MOVE ROUTINE TO BE USED
0984 1668 UCBSA_DL_MOVRTN(R5)
0987 1669 10$: RSB ;RETURN
0988 1670
0988 1671 20$: MOVAB G^IOC$MOVTOUSER,- ;SET NEXT MOVE ROUTINE TO BE USED
09BE 1672 UCBSA_DL_MOVRTN(R5)
09C1 1673 RSB ;RETURN
09C2 1674

```

```

09C2 1676      .SBTTL MOVE FROM USER BUFFER ROUTINE
09C2 1677      :++
09C2 1678      :
09C2 1679      : DL_MOVE_FROM_BUFFER - MOVE FROM USER BUFFER
09C2 1680      :
09C2 1681      : FUNCTIONAL DESCRIPTION:
09C2 1682      :
09C2 1683      : THIS ROUTINE MOVES DATA BETWEEN THE PHYSICALLY CONTIGUOUS BUFFER AND
09C2 1684      : THE USER'S BUFFER.
09C2 1685      :
09C2 1686      : INPUTS:
09C2 1687      :
09C2 1688      :     R5 - UCB ADDRESS
09C2 1689      :
09C2 1690      : OUTPUTS:
09C2 1691      :
09C2 1692      :     DATA MOVE BETWEEN THE PHYSICALLY CONTIGUOUS BUFFER AND THE USER'S BUFFER.
09C2 1693      :     REGISTER'S R0,R1, AND R2 ARE DESTROYED
09C2 1694      :
09C2 1695      :--
09C2 1696      :
09C2 1697      DL_MOVE_FROM_BUFFER:      ;BUFFER MOVE ROUTINE
09C2 1698      BBS      #UCB$V_DL_MAPPING,-      ;ADAPTER MAPPING?
09C4 1699      UCB$W_DL_FLAGS(R5),10$      ;IF BS YES NOTHING TO MOVE
0093 C5 08 91 09C8 1700      CMPB      #CDF_WRITEDATA,UCB$B_CEX(R5);WRITE DATA OPERATION?
00C9 C5 27 12 09CD 1701      BNEQ      10$      ;IF NEQ NOT A WRITE
09CF 1702      BBS      #0,UCB$B_DL_DCHEK(R5),-      ;DATA CHECK IN PROGRESS?
09D4 1703      10$      ;IF BS YES NOTHING TO MOVE
50 00DC C5 D0 09D5 1704      MOVL      UCB$L_DL_BUFADR(R5),R0      ;GET USER BUFFER POINTER
51 00EE C5 D0 09DA 1705      MOVL      UCB$A_DL_BUF_VA(R5),R1      ;GET PHYSICALLY CONTIGUOUS BUFFER ADDRESS
52 00CC C5 3C 09DF 1706      MOVZWL   UCB$W_DL_PBCR(R5),R2      ;GET NUMBER OF BYTES TO TRANSFER
00DC C5 50 D0 09E4 1707      JSB      @UCB$A_DL_MOVRTN(R5)      ;CALL MOVE ROUTINE
00000000'GF 9E 09E8 1708      MOVL      R0,UCB$L_DL_BUFADR(R5)      ;SAVE INTERNAL BUFFER POINTER
09E9 1709      MOVAB   G^IOC$MOVFRUSER2,-      ;SET NEXT MOVE ROUTINE TO BE USED
09F3 1710      UCB$A_DL_MOVRTN(R5)      ;
05 09F6 1711 10$:      RSB      ;RETURN
09F7 1712      ;
09F7 1713      DL_END:      ;ADDRESS OF LAST LOCATION IN DRIVER
09F7 1714      .END

```

\$\$\$	= 00000020	R	02	DL_INT	00000916	RG	03
\$\$BASE	= 00000001			DL_MOVE_FROM_BUFFER	000009C2	R	03
\$\$DISPL	= 0000000A			DL_MOVE_TO_BUFFER	0000097D	R	03
\$\$GENSW	= 00000001			DL_REGDUMP	0000095C	R	03
\$\$HIGH	= 00000009			DL_RLOX_INIT	00000143	R	03
\$\$LIMIT	= 00000008			DL_RL11_INIT	000000FC	R	03
\$\$LOW	= 00000001			DL_STARTIO	000002A8	R	03
\$\$MNSW	= 00000001			DL_UNSLMT	00000959	R	03
\$\$MXSW	= 00000001			DL_WAIT	00000263	R	03
\$\$OP	= 00000002			DO_FUNCTION	0000035C	R	03
ACPSACCESS	*****	X	03	DPTSC_LENGTH	= 00000038		
ACPSDEACCESS	*****	X	03	DPTSC_VERSION	= 00000004		
ACPSMODIFY	*****	X	03	DPTSIRITAB	00000038	R	02
ACPSMOUNT	*****	X	03	DPTSM_SVP	= 00000002		
ACPSREADBLK	*****	X	03	DPTSREINITAB	00000073	R	02
ACPSWRITEBLK	*****	X	03	DPTSTAB	00000000	R	02
ATS_UBA	= 00000001			DRCLR	00000477	R	03
AVAILABLE	0000036A	R	03	DRVCLR	0000035C	R	03
BUGS_UNSUPRTCPU	*****	X	03	DTS_RLO1	= 00000009		
CDF_AVAILABLE	= 00000011			DTS_RLO2	= 0000000A		
CDF_DRVCLR	= 00000004			DYN\$C_CRB	= 00000005		
CDF_NOP	= 00000010			DYN\$C_DDB	= 00000006		
CDF_OFFSET	= 00000006			DYN\$C_DPT	= 0000001E		
CDF_PACKACK	= 00000008			DYN\$C_UCB	= 00000010		
CDF_READDATA	= 0000000C			EMBSL_DV_REGSAV	= 0000004E		
CDF_READHEAD	= 0000000E			ERL\$DEVICERR	*****	X	03
CDF_RECAL	= 00000003			ERL\$DEVICTMO	*****	X	03
CDF_RELEASE	= 00000005			EXESABORTIO	*****	X	03
CDF_RETCENTER	= 00000007			EXESALOPHYCNTG	*****	X	03
CDF_SEARCH	= 00000009			EXESGB_CPUDATA	*****	X	03
CDF_SEEK	= 00000002			EXESGB_CPUTYPE	*****	X	03
CDF_UNLOAD	= 00000001			EXESGL_TENUSEC	*****	X	03
CDF_WRITECHECK	= 0000000A			EXESGL_UBDELAY	*****	X	03
CDF_WRITEDATA	= 0000000B			EXESIOFORK	*****	X	03
CDF_WRITEHEAD	= 0000000D			EXESLCLDSKVALID	*****	X	03
CRBSB_MASK	= 0000000E			EXESONEPARM	*****	X	03
CRBSL_AUXSTRUC	= 00000010			EXESPRTIMCHK	*****	X	03
CRBSL_INTD	= 00000024			EXESSENSEMODE	*****	X	03
CRBSV_BSY	= 00000000			EXESSETCHAR	*****	X	03
DATA\$CHECK	= 000007C5	R	03	EXESZEROPARM	*****	X	03
DC\$_DISK	= 00000001			FATALERR	00000398	R	03
DDB\$K_CART	= 00000002			FDISPATCH	00000317	R	03
DDB\$L_ACPD	= 00000010			FEXL	00000439	R	03
DDB\$L_DDT	= 0000000C			FTAB	00000038	R	03
DEVSM_AVL	= 00040000			FUNCTAB_LEN	= 000000A0		
DEVSM_DIR	= 00000008			FUNCT	000003E6	R	03
DEVSM_ELG	= 00400000			F_AVAILABLE	= 00000000		
DEVSM_FOD	= 00004000			F_DRVCLR	= 00000004		
DEVSM_IDV	= 04000000			F_GETSTATUS	= 00000004		
DEVSM_NNM	= 00000200			F_NOP	= 00000000		
DEVSM_ODV	= 08000000			F_OFFSET	= 00000000		
DEVSM_RND	= 10000000			F_PACKACK	= 00000004		
DEVSM_SHR	= 00010000			F_READDATA	= 0000000C		
DL\$DDT	00000000	RG	03	F_READHEAD	= 00000008		
DL_ALIGN	00000298	R	03	F_RECAL	= 00000000		
DL_END	000009F7	R	03	F_RELEASE	= 00000000		
DL_FUNC\$TABLE	0000005C	R	03	F_RET\$CENTER	= 00000000		

F_SEARCH	= 00000000	IRPSS_FCODE	= 00000006
F_SEEK	= 00000006	IRPSV_DIAGBUF	= 00000007
F_UNLOAD	= 00000000	IRPSV_FCODE	= 00000000
F_WRITECHECK	= 00000002	IRPSV_PHYSIO	= 00000008
F_WRITEDATA	= 0000000A	IRPSW_BCNT	= 00000032
F_WRITEHEAD	= 00000000	IRPSW_FUNC	= 00000020
IDBSL_CSR	= 00000000	IRPSW_STS	= 0000002A
IDBSL_OWNER	= 00000004	MASKH	= 00000008
IMMED	0000047B R 03	MASKL	= 04000000
IOSM_DATACHECK	= 00004000	MMGSGL_SPTBASE	***** X 03
IOSV_DATACHECK	= 0000000E	NOP	0000035C R 03
IOSV_INHRETRY	= 0000000F	NORMAL	00000389 R R 03
IOS_ACCESS	= 00000032	PACKACK	00000362 R R 03
IOS_ACPCONTROL	= 00000038	POSIT	000004AE R 03
IOS_AVAILABLE	= 00000011	PRS_IPL	= 00000012
IOS_CREATE	= 00000033	PRS_SID_TYP730	= 00000003
IOS_DEACCESS	= 00000034	PRS_SID_TYP750	= 00000002
IOS_DELETE	= 00000035	PRS_SID_TYP780	= 00000001
IOS_DRVCLR	= 00000004	PRS_SID_TYP785	= 00000009
IOS_MODIFY	= 00000036	PRS_SID_TYP790	= 00000004
IOS_MOUNT	= 00000039	PRS_SID_TYP_MAX	= 00000008
IOS_NOP	= 00000000	PRS_SID_TYP_JV1	= 00000007
IOS_PACKACK	= 00000008	PREPROCESS	000002A8 R 03
IOS_READHEAD	= 0000000E	PTESS_PFN	= 00000015
IOS_READBLK	= 00000021	PWRFATL	000008E8 R 03
IOS_READPBLK	= 0000000C	READDATA	00000379 R R 03
IOS_READVBLK	= 00000031	READHEAD	00000372 R R 03
IOS_SEEK	= 00000002	RESETXFR	000008DB R R 03
IOS_SENSECHAR	= 0000001B	RETREG	0000081F R R 03
IOS_SENSEMODE	= 00000027	RETRYERP	0000038F R 03
IOS_SETCHAR	= 0000001A	RL_BA	00000002
IOS_SETMODE	= 00000023	RL_BAE	00000008
IOS_UNLOAD	= 00000001	RL_CS	00000000
IOS_VIRTUAL	= 0000003F	RL_CS_M_CE	= 00008000
IOS_WRITECHECK	= 0000000A	RL_CS_M_CRDY	= 00000080
IOS_WRITEBLK	= 00000020	RL_CS_M_DRDY	= 00000001
IOS_WRITEPBLK	= 0000000B	RL_CS_M_IE	= 00000040
IOS_WRITEVBLK	= 00000030	RL_CS_V_CE	= 0000000F
IOCSDIAGBUILL	***** X 03	RL_CS_V_CRC	= 0000000B
IOCSLOADUBAMAP	***** X 03	RL_CS_V_DE	= 0000000E
IOCSMNTVER	***** X 03	RL_CS_V_NXM	= 0000000D
IOCSMOVFRUSER	***** X 03	RL_CS_V_OPI	= 0000000A
IOCSMOVFRUSER2	***** X 03	RL_DA	00000004
IOCSMOVTOUSER	***** X 03	RL_DA_M_MRK	= 00000001
IOCSMOVTOUSER2	***** X 03	RL_DA_M_RST	= 00000008
IOCSPURGDATAP	***** X 03	RL_DA_M_STS	= 00000002
IOCSRELCHAN	***** X 03	RL_MP	00000006
IOCSRELDATAP	***** X 03	RL_MP_M_BH	= 00000008
IOCSRELMAPREG	***** X 03	RL_MP_M_CHE	= 00004000
IOCSREQCOM	***** X 03	RL_MP_M_DSE	= 00000100
IOCSREQDATAP	***** X 03	RL_MP_M_HO	= 00000010
IOCSREQMAPREG	***** X 03	RL_MP_M_TYP	= 00000080
IOCSREQPCMANL	***** X 03	RL_MP_M_WDE	= 00008000
IOCSRETURN	***** X 03	RL_MP_M_WGE	= 00000400
IOCSWFIKPC	***** X 03	RL_MP_V_VC	= 00000009
IRPSL_MEDIA	= 00000038	RL_MP_V_WGE	= 0000000A
IRPSL_SVAPTE	= 0000002C	RL_MP_V_WL	= 0000000D

RL\_NUM\_REGS = 00000004  
RL\_SLM = 00000005  
SEEK = 0000035C R 03  
SIZ... = 00000001  
SPECOND = 000008BC R 03  
SSS\_CTRLERR = 00000054  
SSS\_DATACHECK = 0000005C  
SSS\_DRVERR = 0000008C  
SSS\_IVBUFLEN = 0000034C  
SSS\_MEDOFL = 000001A4  
SSS\_NORMAL = 00000001  
SSS\_PARITY = 000001F4  
SSS\_TIMEOUT = 0000022C  
SSS\_VOLINV = 00000254  
SSS\_WRITLCK = 0000025C  
UCBSA\_DL\_BUF\_PA = 000000F2  
UCBSA\_DL\_BUF\_VA = 000000EE  
UCBSA\_DL\_MOVRTN = 000000E0  
UCBSB\_CEX = 00000093  
UCBSB\_DEVCLASS = 00000040  
UCBSB\_DEVTYPE = 00000041  
UCBSB\_DIPL = 0000005E  
UCBSB\_DL\_DCHEK = 000000C9  
UCBSB\_DL\_DPPE = 000000E4  
UCBSB\_DL\_XBA = 000000EB  
UCBSB\_ERTCNT = 00000080  
UCBSB\_ERTMAX = 00000081  
UCBSB\_FEX = 00000092  
UCBSB\_FIPL = 0000000B  
UCBSB\_SECTORS = 00000044  
UCBSB\_TRACKS = 00000045  
UCBSK\_DL\_BUF SZ = 00000014  
UCBSK\_DL\_LEN = 000000F8  
UCBSK\_LCC\_DISK\_LENGTH = 000000CC  
UCBSL\_CRB = 00000024  
UCBSL\_DEVCHAR = 00000038  
UCBSL\_DEVCHAR2 = 0000003C  
UCBSL\_DL\_BUFADR = 000000DC  
UCBSL\_DL\_DPR = 000000DB  
UCBSL\_DL\_FMPR = 000000DC  
UCBSL\_DL\_PMPR = 000000E0  
UCBSL\_DL\_SVAPTE = 000000DB  
UCBSL\_DPC = 0000009C  
UCBSL\_FPC = 0000000C  
UCBSL\_FR3 = 00000010  
UCBSL\_IRP = 00000058  
UCBSL\_MAXBLOCK = 00000080  
UCBSL\_MEDIA = 0000008C  
UCBSL\_MEDIA\_ID = 0000008C  
UCBSL\_SVAPTE = 00000078  
UCBSM\_DIAGBUF = 00000002  
UCBSM\_NOCNVRT = 00000004  
UCBSM\_ONLINE = 00000010  
UCBSM\_POWER = 00000020  
UCBSM\_TIMEOUT = 00000040  
UCBSM\_VALID = 00000800  
UCBSV\_DL\_22BIT = 00000000

UCBSV\_DL\_MAPPING = 00000001  
UCBSV\_INT = 00000001  
UCBSV\_POWER = 00000005  
UCBSV\_VALID = 0000000B  
UCBSW\_BCNT = 0000007E  
UCBSW\_BCR = 000000C0  
UCBSW\_BOFF = 0000007C  
UCBSW\_CYLINDERS = 00000046  
UCBSW\_DA = 0000008C  
UCBSW\_DC = 0000008E  
UCBSW\_DEVBUFSIZ = 00000042  
UCBSW\_DEVSTS = 00000068  
UCBSW\_DL\_BA = 000000D0  
UCBSW\_DL\_CS = 000000CE  
UCBSW\_DL\_DA = 000000D2  
UCBSW\_DL\_DB = 000000E5  
UCBSW\_DL\_DPN = 000000D6  
UCBSW\_DL\_FLAGS = 000000F6  
UCBSW\_DL\_MP = 000000D4  
UCBSW\_DL\_PBCR = 000000CC  
UCBSW\_DL\_SBA = 000000EC  
UCBSW\_FUNC = 0000009A  
UCBSW\_OFFSET = 000000C8  
UCBSW\_STS = 00000064  
UCBSW\_UNIT = 00000054  
UNLOAD = 0000036A R 03  
UPDATE = 000007DB R 03  
VASM\_BYTE = 000001FF  
VASS\_VPN = 00000015  
VASV\_VPN = 00000009  
VECSB\_DATAPATH = 00000013  
VECSL\_IDB = 00000008  
VECSL\_INITIAL = 0000000C  
VECSL\_UNITINIT = 00000018  
VECSS\_DATAPATH = 00000005  
VECSS\_MAPREG = 0000000F  
VECSV\_DATAPATH = 00000000  
VECSV\_MAPREG = 00000000  
VECSW\_MAPREG = 00000010  
WRITECHECK = 00000372 R 03  
WRITEDATA = 00000379 R 03  
XFER = 0000061A R 03

-----  
! Psect synopsis !  
-----

PSECT name	Allocation	PSECT No.	Attributes
. ABS .	00000000 ( 0.)	00 ( 0.)	NOPIC USR CON ABS LCL NOSHR NOEXE NORD NOWRT NOVEC BYTE
\$AB\$\$	000000FA ( 250.)	01 ( 1.)	NOPIC USR CON ABS LCL NOSHR EXE RD WRT NOVEC BYTE
\$\$\$105_PROLOGUE	00000088 ( 136.)	02 ( 2.)	NOPIC USR CON REL LCL NOSHR EXE RD WRT NOVEC BYTE
\$\$\$115_DRIVER	000009F7 ( 2551.)	03 ( 3.)	NOPIC USR CON REL LCL NGSHR EXE RD WRT NOVEC LONG

-----  
! Performance indicators !  
-----

Phase	Page faults	CPU Time	Elapsed Time
Initialization	30	00:00:00.05	00:00:00.55
Command processing	128	00:00:00.39	00:00:01.95
Pass 1	642	00:00:20.98	00:01:13.05
Symbol table sort	0	00:00:02.56	00:00:09.30
Pass 2	308	00:00:04.50	00:00:21.00
Symbol table output	38	00:00:00.23	00:00:01.81
Psect synopsis output	2	00:00:00.02	00:00:00.02
Cross-reference output	0	00:00:00.00	00:00:00.00
Assembler run totals	1150	00:00:28.74	00:01:47.68

The working set limit was 2250 pages.  
171426 bytes (335 pages) of virtual memory were used to buffer the intermediate code.  
There were 130 pages of symbol table space allocated to hold 2340 non-local and 91 local symbols.  
1714 source lines were read in Pass 1, producing 24 object records in Pass 2.  
67 pages of virtual memory were used to define 62 macros.

-----  
! Macro library statistics !  
-----

Macro library name	Macros defined
_\$255\$DUA28:[SYS.OBJ]LIB.MLB;1	40
_\$255\$DUA28:[SYSLIB]STARLET.MLB;2	11
TOTALS (all libraries)	51

2659 GETS were required to define 51 macros.

There were no errors, warnings or information messages.

MACRO/LIS=LIS\$DLDRIVER/OBJ=OBJ\$DLDRIVER MSRC\$DLDRIVER/UPDATE=(ENH\$DLDRIVER)+EXECMLS/LIB

The image displays a grid of 100 small, illegible document thumbnails arranged in 10 rows and 10 columns. The thumbnails are too small to read, but some contain faint text such as "DDRIVER LIS", "DLDRIVER LIS", and "DMDRIVER LIS".