



\*\*FILE\*\* ID\*\*DUHIRT

G 12

DDDDDDDD DDDDDDDDD UU UU HH HH HH I I I I I RRRRRRRR RRRRRRRR TTTTTTTTTT  
DD DD UU UU UU HH HH HH II RR RR TT  
DD DD UU UU UU HH HH HH II RR RR TT  
DD DD UU UU UU HH HH HH II RR RR TT  
DD DD UU UU UU HH HH HH II RR RR TT  
DD DD UU UU UU HHHHHHHHHHHH II RRRRRRRR RRRRRRRR TT  
DD DD UU UU UU HHHHHHHHHHHH II RRRRRRRR TT  
DD DD UU UU UU HH HH HH II RR RR TT  
DD DD UU UU UU HH HH HH II RR RR TT  
DD DD UU UU UU HH HH HH II RR RR TT  
DD DD UU UU UU HH HH HH II RR RR TT  
DDDDDDDD DDDDDDDDD UUUUUUUUUU HH HH HH I I I I I RRR RR TT  
DDDDDDDD DDDDDDDDD UUUUUUUUUU HH HH HH I I I I I RRR RR TT

(2)	81	DECLARATIONS
(3)	130	MACRO DEFINITIONS
(4)	199	IRP - CDRP Consistency Check
(5)	241	Static Storage
(5)	242	- HIRT - Host Initiated Replacement Table
(5)	332	- HIR Error Processing Information
(6)	418	DUSINIT HIRT - Initialize Host Initiated Replacement Table
(7)	535	ALLOC_POOL
(8)	577	DUSLOCK HIRT - Gain exclusive access to HIRT
(9)	654	GRANT HIRT - Complete granting access to the HIRT
(10)	718	DUSUNLOCK HIRT - Release HIRT access
(11)	814	DUSTEST HIRT_RWAITCNT - Accumulate RWAITCNT for HIRT
(12)	856	DUSCANCEL FROM HIRT - Cancel requests from the HIRT
(13)	958	DUSDISCONNECT HIRT - Do HIRT cleanup for a disconnect
(14)	1013	DUSRSTRTQ HIRT_CDRP - Do connection failed cleanup of HIRT CDRP
(15)	1076	DUSREPLACE LBN - Replace a failing block
(16)	1834	DUSONLINE_COMPLETE - Perform HIRT operations after ONLINE
(17)	2001	WRITE_RCT_BLOCK - Write an RCT sector
(18)	2116	READ_RCT_BLOCK - Read an RCT sector
(19)	2208	BUILD_RCT_PACKET - Recycle an MSCP end message
(19)	2209	FILL_RCT_PACKET - Prepare an MSCP packet for an RCT transfer
(20)	2288	MAP_PAGE - Map a page for a transfer
(21)	2318	SEARCH_RCT - Locate an available RBN
(22)	2436	TEST_RCT_ENTRY - Test for allocated RBN
(23)	2491	HASH_LBN - Hash an LBN into a RCT block and an offset
(23)	2529	DUSHIR_ERROR - Process error encountered during HIRT processing

0000 1 .TITLE DUHIRT HOST INITIATED REPLACEMENT FOR THE DISK CLASS DRIVER  
0000 2 .IDENT 'V04-000'  
0000 3  
0000 4  
0000 5 \*\*\*\*\*  
0000 6 \*  
0000 7 \* COPYRIGHT (c) 1978, 1980, 1982, 1984 BY  
0000 8 \* DIGITAL EQUIPMENT CORPORATION, MAYNARD, MASSACHUSETTS.  
0000 9 \* ALL RIGHTS RESERVED.  
0000 10 \*  
0000 11 \* THIS SOFTWARE IS FURNISHED UNDER A LICENSE AND MAY BE USED AND COPIED  
0000 12 \* ONLY IN ACCORDANCE WITH THE TERMS OF SUCH LICENSE AND WITH THE  
0000 13 \* INCLUSION OF THE ABOVE COPYRIGHT NOTICE. THIS SOFTWARE OR ANY OTHER  
0000 14 \* COPIES THEREOF MAY NOT BE PROVIDED OR OTHERWISE MADE AVAILABLE TO ANY  
0000 15 \* OTHER PERSON. NO TITLE TO AND OWNERSHIP OF THE SOFTWARE IS HEREBY  
0000 16 \* TRANSFERRED.  
0000 17 \*  
0000 18 \* THE INFORMATION IN THIS SOFTWARE IS SUBJECT TO CHANGE WITHOUT NOTICE  
0000 19 \* AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT  
0000 20 \* CORPORATION.  
0000 21 \*  
0000 22 \* DIGITAL ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS  
0000 23 \* SOFTWARE ON EQUIPMENT WHICH IS NOT SUPPLIED BY DIGITAL.  
0000 24 \*  
0000 25 \*  
0000 26 \*\*\*\*\*  
0000 27  
0000 28 ++  
0000 29  
0000 30 FACILITY:  
0000 31 MSCP Disk Class Driver  
0000 32  
0000 33  
0000 34 ABSTRACT:  
0000 35  
0000 36 Buddy! You're in a world of HIRT (Host Initiated Replacement Table).  
0000 37  
0000 38 This module contains all the routines and data structure definitions  
0000 39 needed by the disk class driver to perform host initiated replacement  
0000 40 of questionable blocks on disks conforming to the DSA specification.  
0000 41  
0000 42 ENVIRONMENT:  
0000 43  
0000 44 This module is linked into DUDRIVER, the VMS disk class driver.  
0000 45  
0000 46 --  
0000 47  
0000 48 AUTHOR: Ralph O. Weber (ghost writer for Robert L. Rappaport)  
0000 49  
0000 50 CREATION DATE: 21-JAN-1984  
0000 51  
0000 52 MODIFIED BY:  
0000 53  
0000 54 V03-004 ROW0398 Ralph O. Weber 21-JUL-1984  
0000 55 Setup use of class driver write-lock bit in UCB\$W\_DEVSTS.  
0000 56 Also eliminate alteration and use of DEV\$V\_SWL bit in  
0000 57 UCB\$L\_DEVCHAR. That bit is controlled by the file system.

0000 58  
0000 59  
0000 60  
0000 61  
0000 62  
0000 63  
0000 64  
0000 65  
0000 66  
0000 67  
0000 68  
0000 69  
0000 70  
0000 71  
0000 72  
0000 73  
0000 74  
0000 75  
0000 76  
0000 77  
0000 78  
0000 79 :--

- V03-003 ROW0346 Ralph O. Weber 11-APR-1984  
> Add worst failure status reporting to insure that I/O requests producing failed replacement requests get failure status codes.  
> Add several more error logging points.  
> Suppress error recovery and error correction when testing the possibly bad block in step 7.  
> Use cheap class driver macros for common functions like testing MSCP success/failure and initializing a MSCP command packet.
- V03-002 ROW0332 Ralph O. Weber 2-APR-1984  
Cause message to appear on the system console whenever an error occurs during RDT processing.
- V03-001 ROW0331 Ralph O. Weber 29-MAR-1984  
Change DUSCANCEL\_FROM\_HIRT to count wait count adjustment in CDRPSW\_DUTUCNTR. Also add comments from old DUDRIVER to its module header.

0000 81 .SBTTL DECLARATIONS  
0000 82  
0000 83 : INCLUDE FILES:  
0000 84 :  
0000 85 \$CDDBDEF ; Define CDDB offsets  
0000 86 \$CDRPDEF ; Define CDRP offsets  
0000 87 \$CDTDEF ; Define CDT offsets  
0000 88 \$CRBDEF ; Define CRB offsets  
0000 89 \$SDBDEF ; Define DDB offsets  
0000 90 \$DEVDEF ; Define DEVICE CHARACTERISTICS bits  
0000 91 \$DYNDEF ; Define DYN symbols  
0000 92 \$EMBLTDEF ; Define EMB Log Message Types  
0000 93 \$FKBDEF ; Define FKB offsets  
0000 94 \$IODEF ; Define I/O FUNCTION codes  
0000 95 \$IPLDEF ; Define IPL levels  
0000 96 \$IRPDEF ; Define IRP offsets  
0000 97 \$MSCPDEF ; Define MSCP packet offsets  
0000 98 \$MSLGDEF ; Define MSCP Error Log offsets  
0000 99 \$PBDEF ; Define Path Block offsets  
0000 100 \$PCBDEF ; Define PCB offsets  
0000 101 \$PDTDEF ; Define PDT offsets  
0000 102 \$PRDEF ; Define Processor Registers  
0000 103 \$RCTDEF ; Define RCT offsets  
0000 104 \$RDDEF ; Define RDTE offsets  
0000 105 \$SSBDEF ; Define System Block Offsets  
0000 106 \$SSCSMGDEF ; Define SCS Connect Message offsets  
0000 107 \$SSDEF ; Define System Status values  
0000 108 \$UCBDEF ; Define UCB offsets  
0000 109 \$VADEF ; Define Virtual Address offsets  
0000 110 \$VECDEF ; Define INTERRUPT DISPATCH VECTOR offsets  
0000 111  
0000 112  
0000 113 \$DUTUDEF ; Define common class driver CDDB  
0000 114 ; extensions and other common symbols  
0000 115  
0000 116  
0000 117 : CONSTANTS  
0000 118 B6DBC6D 119 TEST\_PATTERN=^xB6DBC6D ; Pattern to write on bad blocks.  
0000 120  
0000 121 : MODULE PSECT  
0000 122 :  
0000 123 :  
0000 124 00000000 .PSECT \$\$115\_DRIVER LONG  
0000 125 :  
0000 126 : SET DEFAULT DISPLACEMENT  
0000 127 :  
0000 128 .DEFAULT DISPLACEMENT WORD

0000 130 .SBTTL MACRO DEFINITIONS  
0000 131  
0000 132 .MACRO HIRT\_SUBSAVE : Save return on HIRT substack.  
0000 133 POPL #HIRTSL\_STKPTR : Pop return from stack onto substack.  
0000 134 ADDL #4\_HIRTSL\_STKPTR : Bump substack pointer.  
0000 135 .ENDM HIRT\_SUBSAVE  
0000 136  
0000 137 .MACRO HIRT\_SUBUNSAVE : Pop top of SUBSTACK and push onto stack.  
0000 138 SUBL #4\_HIRTSL\_STKPTR : Pop substack.  
0000 139 PUSHL #HIRTSL\_STKPTR : Put top of substack onto top of stack.  
0000 140 .ENDM HIRT\_SUBUNSAVE  
0000 141  
0000 142 .MACRO HIRT\_SUBRETURN : HIRT\_SUBUNSAVE and return to caller.  
0000 143 HIRT\_SUBUNSAVE  
0000 144 RSB : Return to subroutine caller.  
0000 145 .ENDM HIRT\_SUBRETURN  
0000 146  
0000 147 : Expanded opcode macros - Branch word conditional pseudo opcodes.  
0000 148 :  
0000 149 :  
0000 150  
0000 151 :  
0000 152 : BNNEQ - Branch (word offset) not equal  
0000 153 :  
0000 154  
0000 155 .MACRO BNNEQ DEST,?L1  
0000 156 .SHOW  
0000 157 BEQL L1 : Branch around if NOT NEQ.  
0000 158 BRW DEST : Branch to destination if NEQ.  
0000 159 L1: : Around.  
0000 160 .NOSHOW  
0000 161 .ENDM BNNEQ  
0000 162  
0000 163 :  
0000 164 : BWEQL - Branch (word offset) equal  
0000 165 :  
0000 166  
0000 167 .MACRO BWEQL DEST,?L1  
0000 168 .SHOW  
0000 169 BNEQ L1 : Branch around if NOT EQL.  
0000 170 BRW DEST : Branch to destination if EQL.  
0000 171 L1: : Around.  
0000 172 .NOSHOW  
0000 173 .ENDM BWEQL  
0000 174  
0000 175 :  
0000 176 : BWBS - Branch (word offset) bit set.  
0000 177 :  
0000 178  
0000 179 .MACRO BWBS BIT,FIELD,DEST,?L1  
0000 180 .SHOW  
0000 181 BBC BIT,FIELD,L1 : Branch around if bit NOT set.  
0000 182 BRW DEST : Branch to destination if bit set.  
0000 183 L1: : Around.  
0000 184 .NOSHOW  
0000 185 .ENDM BWBS  
0000 186

```
0000 187 : BWBC - Branch (word offset) bit clear.  
0000 188 :  
0000 189 :  
0000 190 :  
0000 191 .MACRO BWBC BIT,FIELD,DEST,?L1  
0000 192 .SHOW  
0000 193 BBS BIT,FIELD,L1 : Branch around if bit NOT clear.  
0000 194 BRW DEST : Branch to destination if bit clear.  
0000 195 L1: : Around.  
0000 196 .NOSHOW  
0000 197 .ENDM BWBC
```

0000 199 .SBTTL IRP - CDRP Consistency Check  
0000 200  
0000 201 : The following set of ASSUME statements will all be true as long as  
0000 202 : the IRP and CDRP definitions remain consistent.  
0000 203  
0000 204 ASSUME CDRPSL\_I0QFL-CDRPSL\_I0QFL EQ IRPSL\_I0QFL  
0000 205 ASSUME CDRPSL\_I0QBL-CDRPSL\_I0QFL EQ IRPSL\_I0QBL  
0000 206 ASSUME CDRPSW\_IRP\_SIZE-CDRPSL\_I0QFL EQ IRPSW\_SIZE  
0000 207 ASSUME CDRPSB\_IRP\_TYPE-CDRPSL\_I0QFL EQ IRPSB\_TYPE  
0000 208 ASSUME CDRPSB\_RMOD-CDRPSL\_I0QFL EQ IRPSB\_RMOD  
0000 209 ASSUME CDRPSL\_PID-CDRPSL\_I0QFL EQ IRPSL\_PID  
0000 210 ASSUME CDRPSL\_AST-CDRPSL\_I0QFL EQ IRPSL\_AST  
0000 211 ASSUME CDRPSL\_ASTPRM-CDRPSL\_I0QFL EQ IRPSL\_ASTPRM  
0000 212 ASSUME CDRPSL\_WIND-CDRPSL\_I0QFL EQ IRPSL\_WIND  
0000 213 ASSUME CDRPSL\_UCB-CDRPSL\_I0QFL EQ IRPSL\_UCB  
0000 214 ASSUME CDRPSW\_FUNC-CDRPSL\_I0QFL EQ IRPSW\_FUNC  
0000 215 ASSUME CDRPSB\_EFN-CDRPSL\_I0QFL EQ IRPSB\_EFN  
0000 216 ASSUME CDRPSB\_PRI-CDRPSL\_I0QFL EQ IRPSB\_PRI  
0000 217 ASSUME CDRPSL\_IOSB-CDRPSL\_I0QFL EQ IRPSL\_IOSB  
0000 218 ASSUME CDRPSW\_CHAN-CDRPSL\_I0QFL EQ IRPSW\_CHAN  
0000 219 ASSUME CDRPSW\_STS-CDRPSL\_I0QFL EQ IRPSW\_STS  
0000 220 ASSUME CDRPSL\_SVAPTE-CDRPSL\_I0QFL EQ IRPSL\_SVAPTE  
0000 221 ASSUME CDRPSW\_BOFF-CDRPSL\_I0QFL EQ IRPSW\_BOFF  
0000 222 ASSUME CDRPSL\_BCNT-CDRPSL\_I0QFL EQ IRPSL\_BCNT  
0000 223 ASSUME CDRPSW\_BCNT-CDRPSL\_I0QFL EQ IRPSW\_BCNT  
0000 224 ASSUME CDRPSL\_IOST1-CDRPSL\_I0QFL EQ IRPSL\_IOST1  
0000 225 ASSUME CDRPSL\_MEDIA-CDRPSL\_I0QFL EQ IRPSL\_MEDIA  
0000 226 ASSUME CDRPSL\_IOST2-CDRPSL\_I0QFL EQ IRPSL\_IOST2  
0000 227 ASSUME CDRPSL\_TT TERM-CDRPSL\_I0QFL EQ IRPSL\_TT TERM  
0000 228 ASSUME CDRPSB\_CARCON-CDRPSL\_I0QFL EQ IRPSB\_CARCON  
0000 229 ASSUME CDRPSQ\_NT PRVMSK-CDRPSL\_I0QFL EQ IRPSQ\_NT PRVMSK  
0000 230 ASSUME CDRPSL\_ABCNT-CDRPSL\_I0QFL EQ IRPSL\_ABCNT  
0000 231 ASSUME CDRPSW\_ABCNT-CDRPSL\_I0QFL EQ IRPSW\_ABCNT  
0000 232 ASSUME CDRPSL\_OBCNT-CDRPSL\_I0QFL EQ IRPSL\_OBCNT  
0000 233 ASSUME CDRPSW\_OBCNT-CDRPSL\_I0QFL EQ IRPSW\_OBCNT  
0000 234 ASSUME CDRPSL\_SEGVBN-CDRPSL\_I0QFL EQ IRPSL\_SEGVBN  
0000 235 ASSUME CDRPSL\_JNL\_SEQNO-CDRPSL\_I0QFL EQ IRPSL\_JNL\_SEQNO  
0000 236 ASSUME CDRPSL\_DIAGBUF-CDRPSL\_I0QFL EQ IRPSL\_DIAGBUF  
0000 237 ASSUME CDRPSL\_SEQNUM-CDRPSL\_I0QFL EQ IRPSL\_SEQNUM  
0000 238 ASSUME CDRPSL\_EXTEND-CDRPSL\_I0QFL EQ IRPSL\_EXTEND  
0000 239 ASSUME CDRPSL\_ARB-CDRPSL\_I0QFL EQ IRPSL\_ARB

```

0000 241 .SBTTL Static Storage
0000 242 .SBTTL - HIRT - Host Initiated Replacement Table
0000 243
0000 244 :+
0000 245 : The following table is allocated within the Disk Class Driver. There is
0000 246 : only one such table per system. The HIRT is used to control resources
0000 247 : needed by the Host Initiated Replacement of disk blocks algorithms. In
0000 248 : order to limit the resources dedicated to this activity, only one such
0000 249 : replacement is allowed to proceed at any given instant of time. Replacement
0000 250 : requests which cannot be immediately satisfied are queued.
0000 251 ;-
0000 252
0000 253 .SAVE
0000 254 .PSECT $$$300_HIRT LONG
0000 255
00000000 0000 256 HIRTS$ _RPLQFL: .LONG 0 ; Request Queue FLINK.
00000000 0004 257 HIRTS$ _RPLQTP: .LONG 0 ; Request Queue Tail Pointer.
00000000 0008 258 HIRTS$ _IHOST: .WORD 0 ; Static storage for routines.
00000000 000A 259 HIRTS$ _IOWORST: .WORD 0 ; Worst I/O status encountered.
00000000 000C 260 .WORD 0
00000000 000E 261 HIRTS$ _STS: .WORD 0 ; HIRT status word.
0010 262
0010 263 $VIELD HIRT,0,<
0010 264 <ACTIVE,,M>,- ; Set means HIRT has been initialized.
0010 265 <BUSY,,M>,- ; Set means HIRT being used currently.
0010 266 <FE,,M>,- ; Set means force error on original data
0010 267 <MATCH,,M>,- ; SEARCH RCT bit - set => LBN matched
0010 268 <EMPTYPE,,M>,- ; SEARCH RCT BIT - set => not primary
0010 269 <RESCAN,,M>,- ; SEARCH RCT BIT - set => reached NULLS
0010 270 <RCTFULL,,M>,- ; SEARCH RCT BIT - set => no more RBNS avail
0010 271 <ERLOGIP,,M>,- ; Error Log message has been generated
0010 272 <RCTFE,,M>,- ; Write RCT block with Forced Error
0010 273 >
0010 274
00000000 0010 275 HIRTS$ _LOOPCNT: .LONG 0 ; Loop count used in READ_RCT_BLOCK and
00000000 0014 276 .WRITE_RCT_BLOCK.
00000000 0014 277 HIRTS$ _OWNUCB: .LONG 0 ; If HIRT busy, owner UCB address.
00000000 0018 278 HIRTS$ _LBN: .LONG 0 ; LBN being replaced for UCB.
00000000 001C 279 HIRTS$ _SAVDCDRP:.LONG 0 ; CDRP address of I/O request of owner.
00000000 0020 280 HIRTS$ _CDRP: .LONG 0 ; Address of permanent CDRP for replacement.
0024 281
00000000 0024 282 HIRTS$ _PAGEOPTR:.LONG 0 ; System Virtual Address of scratch page
00000000 0028 283 .needed by Replacement algorithm.
00000000 0028 284 HIRTS$ _PAGE1PTR:.LONG 0 ; System Virtual Address of scratch page
00000000 002C 285 .needed by Replacement algorithm.
00000000 002C 286 HIRTS$ _PAGE2PTR:.LONG 0 ; System Virtual Address of scratch page
00000000 0030 287 .needed by Replacement algorithm.
00000000 0030 288 HIRTS$ _PAGE3PTR:.LONG 0 ; System Virtual Address of scratch page
00000000 0034 289 .needed by Replacement algorithm.
00000000 0034 290
00000000 0034 291 HIRTS$ _SVAPTE0: .LONG 0 ; SVAPTE of page 0.
00000000 0038 292 HIRTS$ _SVAPTE1: .LONG 0 ; SVAPTE of page 1.
00000000 003C 293 HIRTS$ _SVAPTE2: .LONG 0 ; SVAPTE of page 2.
00000000 0040 294 HIRTS$ _SVAPTE3: .LONG 0 ; SVAPTE of page 3.
0044 295
0000 0044 296 HIRTS$ _BOFF0: .WORD 0 ; BOFF of page 0.
0000 0046 297 HIRTS$ _BOFF1: .WORD 0 ; BOFF of page 1.

```

0000 0048 298 HIRTSW\_BOFF2: .WORD 0 ; BOFF of page 2.  
0000 004A 299 HIRTSW\_BOFF3: .WORD 0 ; BOFF of page 3.  
004C 300  
004C 301 ; Array of words that give the relative RCT sector number contained in a page.  
004C 302  
0000 004C 303 HIRTSW\_PGOCNTNT:.WORD 0 ; Page 0 contents.  
0000 004E 304 HIRTSW\_PG1CNTNT:.WORD 0 ; Page 1 contents.  
0000 0050 305 HIRTSW\_PG2CNTNT:.WORD 0 ; Page 2 contents.  
0000 0052 306 HIRTSW\_PG3CNTNT:.WORD 0 ; Page 3 contents.  
0054 307  
0054 308 ; Static storage needed by several routines that read and write RCT blocks.  
0000 0054 309  
0000 0054 310 HIRTSW\_SECTORNO:.WORD 0 ; Sector number.  
0000 0056 311 HIRTSW\_PAGENO: .WORD 0 ; Page number.  
0058 312  
0058 313 ; Static storage needed by SEARCH\_RCT subroutine.  
0058 314  
00000000 0058 315 HIRTSL\_RBN: .LONG 0 ; RBN returned to caller.  
00000000 005C 316 HIRTSL\_MATCHRBN:.LONG 0 ; Previous RBN that failed.  
00000000 0060 317 HIRTSL\_BADRBND: .LONG 0 ; Bad RBN descriptor contents,  
0064 318 ; used in STEP15 error recovery.  
00000000 0064 319 HIRTSL\_STARTBLK:.LONG 0 ; Sector number of Primary RBN.  
00000000 0068 320 HIRTSL\_RCTBLOCK:.LONG 0 ; Current RCT sector number.  
00000000 006C 321 HIRTSL\_OFFSET: .LONG 0 ; Offset into current RCT sector.  
0070 322  
0070 323 ; HIRT SUBSTACK - used by single threaded replacement algorithm as a return  
0070 324 point stack.  
0070 325  
00000000 0070 326 HIRTSL\_STKPTR: .LONG 0 ; Pointer to top of SUBSTACK.  
00000000 0074 327 HIRTSL\_SUBSTACK:.LONG 0,0,0,0,0 ; SUBSTACK itself.  
00000000 0084  
00000005 0088 328 HIRTSK\_SUBSTKLN=<.-HIRTSL\_SUBSTACK>/4 ; Total length of SUBSTACK in longwords.  
0088 329  
00000000 330 .RESTORE

0000 332 .SBTTL - HIR Error Processing Information  
0000 333  
0000 334 ; Constants used in forming HIR error messages  
0000 335  
0000 336 \$VIELD HIRER, 0, <-  
0000 337 <STEP,8,M>, - ; Step number  
0000 338 <TYPE,4,M>, - ; Error type  
0000 339 <ONLINE,,M> - ; Online (not HIR)  
00000000 340 >  
00000000 341 HIRERSM\_REPLACE = 0  
00000000 342  
00000001 343 HIRERSK\_READ = 1 ; Error type codes:  
00000002 344 HIRERSK\_WRITE = 2 ; READ  
00000003 345 HIRERSK\_RCTFULL = 3 ; WRITE  
00000004 346 HIRERSK\_REPFAIL = 4 ; RCT FULL  
00000000 347  
00000000 348 .SAVE  
00000000 349 .PSECT \$\$S301\_HIR\_ERRORS LONG  
00000000 350  
00000000 351 HIR\_ERR\_TYPES:  
00000000 352  
00000000 353  
00000000 354 .BYTE 0  
44 41 45 52 00' 0001 355 .ASCIC /READ/  
04 0001  
45 54 49 52 57 00' 0006 356 .ASCIC /WRITE/  
05 0006  
4C 4C 55 46 20 54 43 52 00' 000C 357 .ASCIC /RCT FULL/  
08 000C  
49 41 46 20 45 43 41 4C 50 45 52 00' 0015 358 .ASCIC /REPLACE FAILURE/  
45 52 55 4C 0021  
0F 0015  
0025  
0025 359 HIR\_ERR\_REPLACE:  
0025 360  
0025 361 .ASCIC /REPLACE/  
002D  
002D 362  
002D 363 HIR\_ERR\_ONLINE:  
002D 364  
002D 365 .ASCIC /ONLINE/  
0034  
0034 366  
0034 367 HIR\_ERR\_SEG1:  
0034 368  
0034 369  
65 72 65 74 6E 75 6F 63 6E 65 20 00' 0034 370 .ASCIC / encountered a /  
20 61 20 64 0040  
0F 0034  
0044  
0044 371 HIR\_ERR\_SEG2:  
0044 372  
0044 373 .ASCIC / error in /  
004F  
004F 374  
004F 375 HIR\_ERR\_SEG3:  
004F 376  
004F 377 .ASCIC / step /  
20 70 65 74 73 20 00' 004F 378

```
06 004F
0056 379
0056 380 ;
0056 381 ; Compute maximum HIR message size
0056 382 ;
0056 383 ;
00000012 0056 384 DEVNAMSIZ = 18 ; size of a device name
00000007 0056 385 TYPORIZ = 7 ; largest error type character count
00000007 0056 386 FUNCISZ = 7 ; largest REPLACE/ONLINE character count
00000002 0056 387 STEPSIZ = 2 ; max characters in step number
00000023 0056 388 FIXEDSIZ = <. - HIR_ERR_SEG1> + 1 ; size of fixed text
00000012 0056 389
00000045 0056 390 HIRERSK_DEVNAMSIZ = DEVNAMSIZ
00000045 0056 391 SIZE = FIXEDSIZ + DEVNAMSIZ + TYPORIZ + FUNCISZ + STEPSIZ
00000048 0056 392 HIRERSK_MSGSIZE = <SIZE + 3> & ^c3
0056 393
00000000 394 .RESTORE
0000 395
0000 396 ++
0000 397
0000 398 HIR_ERROR
0000 399
0000 400 This macro calls the HIR error reporting routine.
0000 401
0000 402 Parameters:
0000 403
0000 404 STEP step number in which the error occurred
0000 405 TYPE error type (one of READ / WRITE / RCTFULL)
0000 406 FUNC function incurring error (one of REPLACE / ONLINE;
0000 407 default = REPLACE)
0000 408 --
0000 409
0000 410 .MACRO HIR_ERROR step, type, func=REPLACE
0000 411 ASSUME HIRERSV_ONLINE LE 15
0000 412 MOVZWL #<HIRERSM-'func'-
0000 413 +<HIRERSK-'type' @ HIRERSV_TYPE > -
0000 414 + 'step', R0
0000 415 BSBW DUSHIR_ERROR
0000 416 .ENDM HIR_ERROR
```

0000 418 .SBTTL DUSINIT\_HIRT - Initialize Host Initiated Replacement Table  
 0000 419 :++  
 0000 420  
 0000 421 DUSINIT\_HIRT - Initialize Host Initiated Replacement Table  
 0000 422  
 0000 423 Functional Description:  
 0000 424  
 0000 425 This routine initializes the HIRT, if it has not already been  
 0000 426 initialized. There is one HIRT per system and it resides in the  
 0000 427 disk class driver. It is initialized the first time an intelligent  
 0000 428 controller that requires Host Initiated Bad Block Replacement is  
 0000 429 brought online.  
 0000 430  
 0000 431 HIRT initialization includes setting up its FLINK and BLINK, allocating  
 0000 432 a permanent CDRP for it, allocating an RSPID for it, allocating an  
 0000 433 MSCP buffer (without Send Credit on any connection) and allocating  
 0000 434 four pages of memory that are needed by the replacement algorithm.  
 0000 435  
 0000 436 Inputs:  
 0000 437  
 0000 438 R3 CDDB address  
 0000 439 R4 PDT address  
 0000 440 R5 Connection permanent CDRP address  
 0000 441  
 0000 442 Outputs:  
 0000 443 Registers R0-R2 are modified.  
 0000 444 Registers R3-R5 are preserved.  
 0000 445  
 0000 446 Implicit Outputs:  
 0000 447 The HIRT is initialized as described above.  
 0000 448  
 0000 449 :--  
 0000 450  
 0000 451  
 0000 452 DUSINIT\_HIRT:::  
 0000 453  
 44 A3 8ED0 0000 454 POPL CDDBSL\_SAVED\_PC(R3) ; Save caller's PC in CDDB.  
 00 E3 0004 455 BBCS S^#HIRT\$V\_ACTIVE,- ; Now see if HIRT already init'ed.  
 03 000E'CF 0006 456 HIRT\$W\_STS,10\$  
 00A4 31 000A 457 BRW END\_INIT\_HIRT ; Branch around if already initialized.  
 0000'CF D4 000D 458  
 0000'CF 9E 0011 459 10\$: CLRL HIRT\$L\_RPLQFL ; Singly linked list with second  
 0004'CF 0015 460 MOVAB HIRT\$L\_RPLQFL,- longword pointing to tail of list.  
 0018 461 HIRT\$L\_RPLQTP  
 000E'CF 02 A8 0018 462  
 001D 463 BISW S^#HIRT\$M\_BUSY, - ; Prevent use of HIRT until fully  
 001D 464 HIRT\$W\_STS ; init'ed.  
 001D 465  
 001D 466 ; Allocate the CDRP to be used and re-used during the I/O operations  
 001D 467 ; associated with dynamic Host Initiated Replacement of bad blocks.  
 001D 468  
 001D 469  
 51 00C4 8F 3C 001D 470 20\$: MOVZWL #IRPSK\_LENGTH,R1 ; R1 contains amount of space to alloc.  
 008F 30 0022 471 BSBW ALLOC\_POOL ; Allocate space. Returns R2=>space.  
 0025 472  
 0A A2 90 0025 473 MOVB #DYN\$C\_IRP,-  
 0027 474 IRPSB\_TYPE(R2) ; Make first part of CDRP look like an  
 ; IRP.

G 13

08 A2 51	B0 0029	475	MOVW R1,IRP\$W_SIZE(R2)	: Save type and size inside "IRP".
55 60 A2	9E 002D	476	MOVAB -CDRPSL_I0QFL(R2),R5	: R5 => CDRP portion of packet.
0020'CF 55	D0 0031	477	MOVL R5,HIRTSL_CDRP	: Save address of replacement CDRP.
FFAO BF	B0 0036	478	MOVW #CDRPSL_I0QFL,-	: Size field in CDRP portion is negative
08 A5	003A	479	CDRPSW_CDRPSIZE(R5)	: offset of IRP from CDRP portion.
39	90 003C	480	MOVB #DYNSC_CDRP,-	: Mark type of CDRP portion.
0A A5	003E	481	CDRPSB_CD_TYPE(R5)	
24 A5	D4 0040	482	CLRL CDRPSL_CDT(R5)	: So far we have no connection for CDRP.
28 A5	D4 0043	483	CLRL CDRPSL_RWCPTR(R5)	: This CDRP will not use RWAITCNT.
2C A5	D4 0046	484	CLRL CDRPSL_LBUFH_AD(R5)	: Signal that no mapping resources allocated
20 A5	D4 0049	485	CLRL CDRPSL_RSPID(R5)	
1C A5	D4 004C	486	CLRL CDRPSL_MSG_BUF(R5)	: Clear RSPID to show none yet allocated.
40 A5 10	9A 004F	487	MOVZBL #CDRPSM_HIRT,-	: Likewise show no MSCP buffer.
	0053	488	CDRPSL_BUTUFLAGS(R5)	: Set HIRT permanent CDRP flag.
	0053	489		
	0053	490		
	0053	491		
	0053	492	: Allocate pages from pool to serve as buffers when reading RCT sectors	
	0053	493	: during replacement of bad blocks on a disk.	
	0053	494	:	
	0053	495		
51 020C 8F	3C 0053	496	50\$: MOVZWL #512+12,R1	: R1 contains amount of space for a
	0058	497		: page and a VMS structure header.
	0058	498		
55 00D0 C3	9E 0058	499	MOVAB CDDBSA_PRMCDRP(R3), R5	: ALLOC_POOL needs R5 => Permanent CDRP.
0054	30 005D	500	BSBW ALLOC_POOL	: Allocate space. Returns R2=>space.
55 0020'CF	D0 0060	501	MOVL HIRTSL_CDRP,R5	: Restore R5 => Hirt CDRP.
	0065	502	ASSUME CDDBSB_SUBTYPE_EQ CDDBSB_TYPE+1	
	B0 0065	503	MOVW #DYNSC_CLASSDRV-	: Place type and subtype descriptors
	0066	504	!<DYNSC_CD_BBRPG@8>,-	: into header using convenient (CDDB)
0A A2 0264 8F	0066	505	CDDBSB_TYPE(R2)	: offset definition.
08 A2 51	B0 006B	506	MOVW R1,CDDBSW_SIZE(R2)	: Also place size into header.
52 0C A2	9E 006F	507	MOVAB 12(R2),R2	: R2 => beyond VMS structure header.
51	D4 0073	508	CLRL R1	: Clear loop index register.
	0075	509		
	0075	510		
0024'CF41	D5 0075	511	80\$: TSTL HIRTSL_PAGEOPTR[R1]	: Test where to put address of allocated pag
04 13	007A	512	BEQL 90\$	: EQL implies we have found a depository.
51	D6 007C	513	INCL R1	: Else bump index register
F5 11	007E	514	BRB 80\$	: and go back and try again.
	0080	515		
0024'CF41	52 D0 0080	516	90\$: MOVL R2,HIRTSL_PAGEOPTR[R1]	: Else save Page address.
52 FE00 8F	AB 0086	517	BICW3 #^XFE00,R2,-	: Calculate BOFF of page just allocated
	008F	518	HIRTSL_BOFFO[R1]	: and save it in the Indexed slot.
	EF 008F	519	EXTZV S^#VASV_VPN,-	: Now calculate SVAPTE of allocated
52 52 15	0091	520	S^#VASS_VPN,R2,R2	: page. First get VPN.
50 00000000'GF	D0 0094	521	MOVL G^MMGSGE_SPBASE,RO	: Then RO => base of system page table.
	0098	522		
0034'CF41	6042 DE 0098	523	MOVAL (RO)[R2],HIRTSL_SVAPTE0[R1]	: Move SVAPTE into proper slot.
03 51	D1 00A2	524	CMPL R1,#3	: See if we are done allocating.
AC 19	00A5	525	BLSS 50\$	: LSS implies NO, so we go to try again.
	00A7	526		
000E'CF 02	AA 00A7	528	BICW S^#HIRTSM_BUSY,-	: Allow use of HIRT now that it has
	00AC	529	HIRTSL_STS	: been initialized.
55 00D0 C3	9E 00AC	530	MOVAB CDDBSA_PRMCDRP(R3), R5	: Get controller permanent CDRP in R5.
	00B1	531		

DUHIRT  
V04-000

HOST INITIATED REPLACEMENT FOR THE DISK <sup>H 13</sup> 16-SEP-1984 00:58:58 VAX/VMS Macro V04-00  
DUSINIT\_HIRT - Initialize Host Initiated 5-SEP-1984 00:13:32 [DRIVER.SRC]DUHIRT.MAR;1

Page 13  
(6)

44 B3 17 00B1 532 END\_INIT\_HIRT:  
JMP acDDBSL\_SAVED\_PC(R3) ; Return to caller.

00B4 535 .SBTTL ALLOC\_POOL  
 00B4 536  
 00B4 537 ;+  
 00B4 538 This subroutine allocates and zeroes nonpaged pool.  
 00B4 539  
 00B4 540 Inputs:  
 00B4 541 R1  
 00B4 542 R5 -# bytes of pool to allocate  
 00B4 543 -Addr of CDRP  
 00B4 544  
 00B4 545 Outputs:  
 00B4 546 R0 -0/1 for fail/success  
 00B4 547 R1 -# bytes actually allocated  
 00B4 548 R2 -Addr of buffer allocated  
 00B4 549 :-  
 00B4 550  
 00B4 551  
 00B4 552 ALLOC\_POOL: ; Allocate and zero pool  
 00B4 553  
 00000000'GF 53 DD 00B4 554 PUSHL R3 ; Save R3.  
 0E 50 E9 00B6 555 JSB G^EXESALONONPAGED ; Allocate from nonpaged pool  
 37 BB 00BF 556 BLBC R0,10\$ ; Skip clearing structure if failure  
 62 51 00 6E 00 2C 00C1 557 PUSHR #^M<R0,R1,R2,R4,R5> ; Save MOVC registers  
 37 BA 00C7 558 MOVC5 #0,(SP),#0,R1,(R2) ; Zero initialize structure  
 53 BED0 00C9 559  
 05 00CC 560 POPR #^M<R0,R1,R2,R4,R5> ; Restore MOVC registers  
 00CD 561 POPL R3 ; Restore R3.  
 00CD 562 RSB  
 00CD 563  
 00CD 564 10\$: ; Allocation failure.  
 00CD 565 ; Prepare to wait awhile before trying again.  
 00CD 566  
 14 A5 10 A5 8ED0 00CD 567 POPL CDRPSL\_FR3(R5) ; Save R3 in R5=>UCB or CDRP.  
 54 DD 00D1 568 MOVL R4, CDRPSL\_FR4(R5) ; Likewise R4  
 20 A5 18 A5 8ED0 00D5 569 POPL CDRPSL\_SAVD\_RTN(R5) ; and caller's return address.  
 51 00DD 570 MOVL R1, CDRPSL\_RSPID(R5) ; Save allocation size.  
 20 A5 51 DD 00D9 571 FORK\_WAIT ; Wait awhile.  
 18 A5 20 A5 00E3 572 MOVL CDRPSL\_RSPID(R5), R1 ; Restore size of block to allocate.  
 C5 D4 00E7 573 CLRL CDRPSL\_RSPID(R5) ; Restore CDRP field.  
 11 00EA 574 PUSHL CDRPSL\_SAVD\_RTN(R5) ; Restore caller's return address.  
 00ED 575 BRB ALLOC\_POOL ; Go try again.

```

      00EF 577 .SBTTL DUSLOCK_HIRT - Gain exclusive access to HIRT
      00EF 578 ++
      00EF 579
      00EF 580 DUSLOCK_HIRT - Gain exclusive access to HIRT
      00EF 581
      00EF 582 Functional Description:
      00EF 583 Gain exclusive access to the H(ost) I(initiated) bad block
      00EF 584 R(eplacement) T(able). Also, lockout new activity on the unit by
      00EF 585 bumping UCBSW_RWAITCNT.
      00EF 586
      00EF 587
      00EF 588 Inputs:
      00EF 589
      00EF 590     R3      UCB address
      00EF 591     R5      a fork block
      00EF 592
      00EF 593 Implicit Inputs:
      00EF 594
      00EF 595     (SP)    caller's return address
      00EF 596     4(SP)   caller's caller's return address
      00EF 597
      00EF 598 Outputs:
      00EF 599
      00EF 600     R0 - R2 are modified.
      00EF 601     All other registers are preserved.
      00EF 602
      00EF 603 Implicit Outputs:
      00EF 604
      00EF 605     HIRT is owned by caller.
      00EF 606 --
      00EF 607
      00EF 608 DUSLOCK_HIRT:::
      00EF 609
      000E'CF 00 E0 00EF 610 BBS      S^#HIRT$V ACTIVE, - ; Make sure HIRT is active.
      04          00F4 611 HIRT$W_STS, 5S
      00F5 612 BUG_CHECK - DISKCLASS,FATAL
      00F9 613
      56 A3 B6 00F9 614 5$: INCW    UCBSW_RWAITCNT(R3) ; Prevent new CDRP's from being begun
      00FC 615          ; on this UCB.
      000E'CF 01 E3 00FC 616 BBCS    S^#HIRT$V BUSY - ; Allocate the Host Initiated Replac
      1B          0101 617 HIRT$W_STS, 10$ ; ment Table (HIRT).
      0102 618
      10 A5 53 7D 0102 619 MOVQ    R3, FKB$L_FR3(R5) ; If here, already allocated, save
      0C A5 8BED0 0106 620 POPL    FKB$L_FPC(R5) ; thread context in fork block.
      010A 621
      010A 622 ; Thread R5 (a fork block) onto the tail of the singly threaded list
      010A 623 ; of fork blocks awaiting use of the HIRT. The listhead is a quadword
      010A 624 ; whose first longword points to the first fork block on the list and
      010A 625 ; whose second longword points to the last forkblock on the list. An
      010A 626 ; empty list is characterized by having the first longword contain a
      010A 627 ; zero with the second longword pointing to the first longword. Each
      010A 628 ; fork block on the list, has the first longword of its link quadword
      010A 629 ; pointing to the next fork block on the list, with the last fork
      010A 630 ; block containing a zero in this longword. The second longword of
      010A 631 ; each fork block's link quadword contains the address of the CDDB of
      010A 632 ; the intelligent controller associated with the device unit
      010A 633 ; attempting to gain exclusive use of the HIRT.

```

010A 634  
010A 635  
010A 636  
010A 637  
65 D4 010A 638 ; Note the reason for CDDB address here is to facilitate finding CDRPs  
010C 639 ; associated with a CONNECTION that has failed (gone down).  
04 A5 00BC C3 D0 010C 640 CLRL FKBSL\_FQFL(R5) ; Prepare this fork block to be at  
0004'DF 65 9E 0112 641 MOVL UCBSL\_CDDB(R3), - tail of the list.  
0004'CF 65 9E 0117 643 MOVAB FKBSL\_FQBL(R5) ; Second longword of link quadword  
05 011C 644 MOVAB FKBSL\_FQFL(R5), - points to CDDB.  
011C 645 MOVAB FKBSL\_FQBL(R5), - Move address of this fork block into  
011D 646 RSB AHIRT\$L\_RPLQTP forward ptr of previous tail.  
011D 647 RSB HIRT\$C\_RPLQTP ; Also move address of this fork block  
011D 648 RSB to list tail pointer.  
01 10 011D 649 10\$: ; Terminate this execution thread by  
011F 650 BSBB GRANT\_HIRT returning to caller's caller.  
05 011F 651 RSB ; Call to initialize various structures  
 ; with data of the new HIRT owner.  
 ; And return to caller who now owns HIRT.

0120 654 .SBTTL GRANT\_HIRT - Complete granting access to the HIRT  
 0120 655 ++  
 0120 656  
 0120 657  
 0120 658  
 0120 659  
 0120 660  
 0120 661  
 0120 662  
 0120 663  
 0120 664  
 0120 665  
 0120 666  
 0120 667  
 0120 668  
 0120 669  
 0120 670  
 0120 671  
 0120 672  
 0120 673  
 0120 674  
 0120 675 R3 UCB address  
 0120 676 R5 User CDRP address  
 0120 677  
 0120 678  
 0120 679  
 0120 680  
 0120 681  
 0120 682  
 0120 683  
 0120 684

This routine is called from DUSLOCK\_HIRT and DUSUNLOCK\_HIRT, upon granting ownership of the HIRT to a thread. GRANT\_HIRT initializes various data fields reflecting this ownership and facilitating the thread's use of the HIRT CDRP.

## Note:

Since both subroutines that require ownership of the HIRT, REPLACE\_LBN and ONLINE\_COMPLETE, make use of the user's original RSPID so as to be able to co-relate all Error Log messages generated by a user I/O request, GRANT\_HIRT passes the RSPID from the user CDRP to the HIRT permanent CDRP.

## Inputs:

R3 UCB address  
 R5 User CDRP address

## Outputs:

Various HIRT and CDRP fields updated.

## GRANT\_HIRT:

20 A5 DD	0120 685 PUSHL CDRPSL_RSPID(R5) : Pass current RSPID to HIRT CDRP.
20 A5 D4	0123 686 CLRL CDRPSL_RSPID(R5) : Prevent spurious deallocate.
001C'CF 55	0126 687 MOVL R5, HIRTS defense SAVDCDRP : Save given R5.
0070'CF 0074'CF	0128 688 MOVAB HIRTSUBSTACK, - : Initialize SUBSTACK in HIRT.
0014'CF 53	0132 689 MOVL R3, HIRTS_OWNUCB : Indicate who owns HIRT.
55 6E D0	0137 690
7E 50 7D	0137 691 MOVL (SP), R5 : Get RSPID.
013A	692 MOVQ R0, -(SP) : Save registers.
013D	693 FIND_RSPID_RDT : Lookup RDT for RSPID.
04 50 E8	0143 694 BLBS R0, 10\$ : Branch if lookup successful.
65 0020'CF D0	0146 695 BUG CHECK DISKCLASS,FATAL : Else, major inconsistency.
0020'CF	014A 696 10\$: MOVE HIRTS_CDRP - : For now pass ownership of RDTE to HIRT permanent CDRP.
50 8E 7D	014F 697 RDTE_CDRP(R5) : Restore saved registers.
55 0020'CF D0	0152 700 MOVL HIRTS_CDRP,R5 : R5 => permanent replacement CDRP.
20 A5 BED0	0157 701 POPL CDRPSL_RSPID(R5) : Pickup RSPID to use thruout replacement.
2C A5 D4	0158 702 CLRL CDRPSL_LBUFH AD(R5) : Indicate no resources yet allocated except RSPID.
1C A5 D4	015E 703 CLRL CDRPSL_MSG_BOF(R5) : Make HIRT permanent CDRP => this UCB.
BC A5 53	0161 704 MOVL R3, CDRPSL_UCB(R5) : This allow UNIBUS mapping to work.
00C8 C3 D0	0165 705 MOVL UCBSL_CDT(R3) - : Place CDT pointer into CDRP for handy reference by SCS routines. Note this must be done each time the HIRT is locked since we may be using a different port (and therefore CONNECTION) each
24 A5	0169 706 CDRPSL_CDT(R5) :
	016B 707
	016B 708
	016B 709
	016B 710

DUHIRT  
V04-000

M 13  
HOST INITIATED REPLACEMENT FOR THE DISK 16-SEP-1984 00:58:58 VAX/VMS Macro V04-00  
GRANT\_HIRT - Complete granting access to 5-SEP-1984 00:13:32 [DRIVER.SRC]DUHIRT.MAR;1

Page 18  
(9)

56 A3	9E	016B	711	MOVAB	UCBSW_RWAITCNT(R3),-	; time.
28 A5		016B	712		CDRPSC_RWCPT(R5)	; Point CDRP field to UCB field.
0080 BF	AA	0170	713	BICW	#HIRTSM_ERLOGIP,-	; Initialize bit.
000E CF		0174	714		HIRTSW_STS	
	05	0177	715	RSB		; Return to caller.
			716			

0178 718 .SBTTL DUSUNLOCK\_HIRT - Release HIRT access  
 0178 719 :++  
 0178 720  
 0178 721 DUSUNLOCK\_HIRT - Release HIRT access  
 0178 722  
 0178 723 Functional Description:  
 0178 724  
 0178 725 Caller wishes to relinquish exclusive control of the HIRT.  
 0178 726 It becomes the current owner's obligation to restart the first  
 0178 727 thread (if any are there) that may be waiting on the HIRT wait  
 0178 728 list.  
 0178 729  
 0178 730 Note:  
 0178 731 DUSUNLOCK\_HIRT passes back the user's RSPID from the HIRT permanent  
 0178 732 CDRP to the user's CDRP.  
 0178 733  
 0178 734 Inputs:  
 0178 735 R3 UCB of HIRT owner  
 0178 736  
 0178 737  
 0178 738 Implicit Inputs:  
 0178 739  
 0178 740  
 0178 741 HIRT owned by caller  
 0178 742  
 0178 743 Outputs:  
 0178 744 R5 Original CDRP address  
 0178 745 All other registers are preserved.  
 0178 746  
 0178 747  
 0178 748 Implicit Outputs:  
 0178 749  
 0178 750 HIRT ownership relinquished. If any threads are on the HIRT wait list,  
 0178 751 first of these is granted HIRT ownership and is started up.  
 0178 752 :--  
 0178 753  
 0178 754 DUSUNLOCK\_HIRT:::  
 0178 755  
 56 A3 B7 0178 756 DECW UCBSW\_RWAITCNT(R3) : Decrement to again allow normal I/O.  
 7E 50 7D 0178 757 MOVQ R0, -TSP) : Save some registers.  
 1C BB 017E 758 PUSHR #^M<R2,R3,R4> : Save more registers.  
 55 53 D0 0180 759 MOVL R3, R5 : Setup UCB for UNSTALLUCB.  
 00000000'GF 16 0183 760 JSB G\$SC\$UNSTALLUCB : Call to start up IRP's on UCB\$L\_I0QFL.  
 1C BA 0189 761 POPR #^M<R2,R3,R4> : Restore registers.  
 0178 762  
 55 0020'CF D0 0188 763 MOVL HIRTS\$LCDRP,R5 : R5 => HIRT CDRP.  
 20 A5 DD 0190 764 PUSHL CDRPSL\_RSPID(R5) : Save current RSPID so as to restore to  
 2C 13 0193 765 user CDRP.  
 0195 766 BEQL 15\$ : EQL implies RSPID has been deallocated  
 55 20 A5 D4 0195 767 due to re-CONNECT. Branch around.  
 6E DD 0198 768 CLRL CDRPSL\_RSPID(R5) : Prevent spurious deallocate.  
 0198 769 MOVL (SP), R5 : Get RSPID.  
 04 50 E8 01A1 770 FIND\_RSPID\_RDT : Lookup RDT entry for RSPID.  
 01A4 771 BLBS R0, 5\$ : Branch if lookup successful.  
 50 001C'CF D0 01AB 772 BUG\_CHECK DISKCLASS,FATAL : Else, major inconsistency.  
 OF 12 01AD 773 5\$: MOVE HIRTS\$SAVDCDRP, R0 : Get saved CDRP address.  
 774 BNEQ 10\$ : Branch if there still is a saved CDRP.

55 65 D0 01AF 775							: Else, it has been canceled.
20 A5 8ED0 01AF 776							: Which means, use HIRT CDRP.
							: Restore its RSPID so it can be
							deallocated.
							: And branch around.
11 11 01B2 777							
55 50 D0 01B6 778							
11 11 01BC 779							
55 001C'CF 04 13 01BE 780							
20 A5 50 D0 01C1 781 10\$:							
50 8ED0 01C4 782 15\$:							
55 001C'CF 04 13 01C9 783							
20 A5 50 D0 01CB 784							
50 8E 7D 01CF 785							
50 8E 7D 01CF 786							
50 8E 7D 01D2 787 19\$:							
50 8E 7D 01D2 788							
50 8E 7D 01D2 789							
0000'CF 27 13 01D2 790							
0000'CF 27 13 01D6 791							
0000'CF 27 13 01D8 792							
3F BB 01D8 793							
3F BB 01D8 794							
55 0000'CF D0 01DA 795							
65 D0 01DF 796							
0000'CF 01E1 797							
07 12 01E4 798							
0000'CF 9E 01E6 799							
0004'CF 01EA 800							
53 10 A5 FF2C 7D 01ED 801 35\$:							
30 01F1 802							
01F4 803							
01FF 804							
000E'CF 02 AA 01FF 805 50\$:							
0C B0 16 01F9 806							
3F BA 01FC 807							
05 01FE 808							
01FF 809 50\$:							
000E'CF 02 AA 01FF 810							
0204 811							
05 0204 812							

MOVL RD\$L\_CDRP(R5), R5  
POPL CDRPSL\_RSPID(R5)  
DEALLOC\_RSPID  
BRB 19\$  
MOVL R0, RD\$L\_CDRP(R5)  
POPL R0  
MOVL HIRT\$L\_SAVDCDRP, R5  
BEQL 19\$  
MOVL R0, CDRPSL\_RSPID(R5)  
MOVQ (SP)+, R0  
TSTL HIRT\$L\_RPLQFL  
BEQL 50\$  
PUSHR #^M<R0,R1,R2,R3,R4,R5>  
MOVL HIRT\$L\_RPLQFL,R5  
MOVL FKBSL\_FQFL(R5),-  
HIRT\$L\_RPLQFL  
BNEQ 35\$  
MOVAB HIRT\$L\_RPLQFL,-  
HIRT\$L\_RPLQTP  
MOVQ FKBSL\_FR3(R5),R3  
BSBW GRANT\_HIRT  
MOVL HIRT\$L\_SAVDCDRP,R0  
JSB @FKBSL\_FPC(R0)  
POPR #^M<R0,R1,R2,R3,R4,R5>  
RSB  
BICW S^#HIRT\$M\_BUSY, -  
HIRT\$W\_STS  
RSB

; Else, it has been canceled.  
; Which means, use HIRT CDRP.  
; Restore its RSPID so it can be  
; deallocated.  
; And branch around.  
; Pass ownership of RDTE back to user  
; Get RSPID.  
; Get original CDRP address in R5.  
; Branch if original CDRP canceled.  
; Else, restore user's original RSPID.  
; Restore 1st group of saved registers.  
; Determine if HIRT wait list is empty.  
; EQL implies list empty.  
; Save caller's registers.  
; R5 => 1st fork block on list.  
; Replace 1st fork block on list with  
; next fork block.  
; NEQ implies there was a next fork block.  
; Else wait list is now empty, so re-  
; direct list Tail Pointer to listhead.  
; Restore waiting thread's context.  
; Call to initialize various structures  
; with data of the new HIRT owner.  
; R0 => User CDRP. Now  
; resume its waiting thread.  
; Restore relinquisher's registers.  
; And return to relinquisher.  
; If here, list was empty.  
; So mark HIRT as NOT busy.  
; And return to relinquisher.

0205 814 .SBTTL DUSTEST\_HIRT\_RWAITCNT - Accumulate RWAITCNT for HIRT  
0205 815 ++  
0205 816  
0205 817 DUSTEST\_HIRT\_RWAITCNT - Accumulate RWAITCNT for HIRT  
0205 818  
0205 819 Functional Description:  
0205 820  
0205 821 This routine accumulates an RWAITCNT value for the input UCB based  
0205 822 upon the amount RWAITCNT has been increment for HIRT usage.  
0205 823  
0205 824 Inputs:  
0205 825  
0205 826 R0 RWAITCNT accumulator  
0205 827 R5 UCB address  
0205 828  
0205 829 Outputs:  
0205 830  
0205 831 R0 RWAITCNT accumulator (with additions for HIRT usage)  
0205 832 R1 destroyed  
0205 833  
0205 834 All other registers preserved.  
0205 835 --  
0205 836  
0205 837 DUSTEST\_HIRT\_RWAITCNT::  
0205 838  
1D 000E'CF 01 E1 0205 839 BBC S^#HIRTSV\_BUSY, HIRTSW\_STS, 90\$ ; Branch if HIRT not busy.  
0014'CF 55 D1 020B 840  
02 12 0210 841 CMPL R5 HIRTSL\_OWNUCB ; Is the UCB the HIRT owner?  
50 D6 0212 842 BNEQ 10\$ ; Branch if not HIRT owner.  
0214 843 INCL R0 ; Else, increment RWAITCNT.  
0214 844  
51 0000'CF 9E 0214 845 10\$: ASSUME FKBSL\_FQFL EQ 0 ; Init. "previous" wait CDRP.  
51 61 D0 0219 846 MOVAB HIRTS[ RPLQFL, R1 ; Link to next waiting CDRP.  
0A 13 021C 847 11\$: MOVL FKBSL\_FQFL(R1), R1 ; Branch if no more waiters.  
BC A1 55 D1 021E 848 BEQL 90\$ ; Is this waiter for this UCB?  
F5 12 0222 849 CMPL R5 CDRPSL\_UCB(R1) ; Branch if not right UCB.  
50 D6 0224 850 BNEQ 11\$ ; Else, increment RWAITCNT.  
F1 11 0226 851 INCL R0 ; Loop, till no more waiters.  
0228 852 BRB 11\$  
05 0228 853  
05 0228 854 90\$: RSB ; All done; exit.

0229 856 .SBTTL DUSCANCEL\_FROM\_HIRT - Cancel requests from the HIRT  
 0229 857 ++  
 0229 858 DUSCANCEL\_FROM\_HIRT - Cancel requests from the HIRT  
 0229 859  
 0229 860 Functional Description:  
 0229 861 This routine is called to locate and cancel any I/O requests current  
 0229 862 or pending for host initiated replacement. The queue of pending  
 0229 863 requests is scanned. The then current HIRT owner is tested.  
 0229 864 The HIRT wait queue is scanned and all CDRPs that meet the cancel  
 0229 865 criteria are removed from the HIRT wait queue and queued for I/O post  
 0229 866 processing. The current owner of the HIRT (if any) is similarly  
 0229 867 tested against the cancel criteria and if needed it too is queued for  
 0229 868 I/O post processing. The HIRT is left "ownerless" in the sense that  
 0229 869 HIRTS\_L\_SAVDCDRP is left zero. This allows the current HIRT I/O to  
 0229 870 continue until it completes on its own. Then, when the HIRT is  
 0229 871 UNLOCKED, the "ownerless" state is noticed and the HIRT thread for the  
 0229 872 former owner is evaporated.  
 0229 873  
 0229 874 Inputs:  
 0229 875 R3 UCB address  
 0229 876 R5 Cancel CDRP address  
 0229 877  
 0229 878 Implicit Inputs:  
 0229 879 CDRPSW\_DUTUCNTR(R5) count of number of times to increment RWAITCNT  
 0229 880 after cancel is completed.  
 0229 881  
 0229 882 Outputs:  
 0229 883 R0 through R2 are destroyed  
 0229 884 All other registers are preserved.  
 0229 885  
 0229 886 Implicit Outputs:  
 0229 887 CDRPSW\_DUTUCNTR(R5) count of number of times to increment RWAITCNT  
 0229 888 after cancel is completed.  
 0229 889  
 0229 890 DUSCANCEL\_FROM\_HIRT::  
 0229 891  
 000E'CF 01 E1 0229 892 BBC S^#HIRTSV\_BUSY - ; Is the HIRT busy? If not, there is  
 79 022E 900 HIRTS\_W\_STS, 900\$ ; nothing to do: so branch to exit.  
 022F 901  
 022F 902 : Scan the HIRT pending requests queue  
 022F 903  
 022F 904  
 51 0000'CF 9E 022F 905 ASSUME FKB\$L\_FQFL EQ 0  
 022F 906 MOVAB HIRTS\_C\_RPLQFL, R1 ; Get "previous" CDRP on wait list.  
 0234 907  
 52 61 D0 0234 908 10\$: MOVL FKB\$L\_FQFL(R1), R2 ; Get next CDRP.  
 3C 13 0237 909 BEQL 100\$ ; Branch if no more CDRPs on wait list.  
 04 A2 00BC C3 D1 0239 910 CMPL UCBSL\_CDDB(R3), - ; Is CDRP for this CDDB?  
 023F 911 FKB\$L\_FQBL(R2)  
 06 12 023F 912 BNEQ 40\$ ; Branch if not the right CDDB.

51 52 D0 0241 913      IFCANCEL cdrp=(R2), then=70\$ ; Branch if CDRP should be canceled.  
   E8 11 0247 914 40\$:      MOVL R2 R1 ; Current becomes previous.  
                               BRB 10\$ ; Loop through all waiting CDRPs.

61 62 D0 024C 917 70\$:      MOVL FKB\$L\_FQFL(R2), - ; Unlink cancelable CDRP.  
                              024F 918 ; FKB\$L\_FQFL(R1)

0004'CF 05 12 024F 919      BNEQ 75\$ ; If cancelable CDRP was last,  
   51 D0 0251 920      MOVL R1, HIRT\$L\_RPLQTP ; adjust queue tail pointer.  
   50 52 D0 0256 921 75\$:      MOVL R2, R0 ; Setup CDRP to cancel.  
   44 A5 B6 0259 922      INCW CDRPSW\_DUTUCNTR(R5) ; Account for RWAITCNT increment during  
                               025C 923 ; attempt to lock the HIRT.  
                               0261 924 ; Save registers.  
   55 50 D0 025E 925      PUSHR #^M<R0,R1,R2,R3,R4,R5> ; Setup for message deallocate.  
                               0261 926 ; Deallocate End Message that told of  
                               0264 927 ; block to be replaced.  
                               3F BA 0264 928 ; Restore registers.  
                               0266 929 ; Insert IRP/CDRP in IOPOST queue.  
                               BF 11 0273 930 ; Branch back to scan entire list.  
                               0275 931  
                               0275 932 100\$: ; Is the HIRT owner a cancelable CDRP? If so retrieve this HIRT owner  
                               0275 933 ; CDRP, clear HIRT\$L\_SAVDCDRP, and POST CDRP the retrieved CDRP. Note  
                               0275 934 ; this works in conjunction with DUSUNLOCM\_HIRT and DU\$RSTRTQ\_HIRT\_CDRP  
                               0275 935 ; which must be prepared to find HIRT\$L\_SAVDCDRP = 0.  
                               0275 936

BC A5 0014'CF D1 0275 937      CMPL HIRT\$L\_OWNUCB, - ; Check for correct HIRT owner UCB.  
                               027B 938 ; CDRPSL\_UCB(R5)

52 001C'CF 2B 12 027B 939      BNEQ 900\$ ; Branch in wrong HIRT owner.  
                               D0 027D 940 ; Get CDRP owner of HIRT.  
                               24 13 0282 941 ; Branch if owner already canceled,  
                               0284 942 ; replacement running to completion.  
                               0284 943 ; Branch if owner shouldn't be canceled.  
                               001C'CF D4 028A 944 ; Else, indicate HIRT owner canceled.  
                               50 52 D0 028E 945 ; Setup CDRP to cancel.  
                               0291 946 ; Following instruction deleted due to its causing RWAITCNT to be  
                               0291 947 ; decremented twice; once here and once Replacement runs to completion.  
                               0291 948 ; INCW CDRPSW\_DUTUCNTR(R5) ; Account for owning the HIRT.  
                               55 50 BB 0291 949 ; Save registers.  
                               D0 0293 950 ; MOVL R0, R5 ; Setup for message deallocate.  
                               0296 951 ; DEALLOC\_MSG\_BUF ; Deallocate End Message that told of  
                               0299 952 ; block to be replaced.  
                               3F BA 0299 953 ; Restore registers.  
                               029B 954 ; POST\_CDRP status=\$SS\_CANCEL ; Insert IRP/CDRP in IOPOST queue.  
                               02A8 955  
                               05 02A8 956 900\$: RSB ; Return to caller.

02A9 958 .SBTTL DU\$DISCONNECT\_HIRT - Do HIRT cleanup for a disconnect  
 02A9 959 ++  
 02A9 960  
 02A9 961 DU\$DISCONNECT\_HIRT - Do HIRT cleanup for a disconnect  
 02A9 962  
 02A9 963 Functional Description:  
 02A9 964 Scan the HIRT wait queue for CDRPs belonging to this CDDB. Remove  
 them and place on the restart queue. This must be done before the RDT  
 resource wait is scanned. It is essential to deallocate SCS resources  
 held by CDRPs on the HIRT wait queue before scanning any of the SCS  
 resource wait queues.  
 02A9 970  
 02A9 971 Inputs:  
 02A9 972  
 02A9 973 R3 CDDB address  
 02A9 974 R4 PDT address  
 02A9 975 R5 Permanent CDRP address  
 02A9 976  
 02A9 977 Outputs:  
 02A9 978 R0 through R2 are destroyed.  
 02A9 979 All other registers are preserved.  
 02A9 980 ;--  
 02A9 981 ;--  
 02A9 982  
 02A9 983 DU\$DISCONNECT\_HIRT::  
 02A9 984  
 000E'CF 00 E1 02A9 985 BBC S#HIRT\$V\_ACTIVE, - ; See if HIRT has been activated.  
 30 02AE 986 HIRT\$W\_ST5, 99\$ ; If HIRT not active, branch around.  
 55 DD 02AF 987 PUSHL R5 ; Save a register.  
 02B1 988  
 50 0000'CF 9E 02B1 989 30\$: ASSUME FKBSL\_FQFL\_EQ\_0 ; Get "previous" CDRP on wait list.  
 02B1 990 MOVAB HIRT\$C\_RPLQFL, R0  
 02B6 991  
 55 60 D0 02B6 992 40\$: MOVL FKBSL\_FQFL(R0), R5 ; Get next CDRP on wait list.  
 21 13 02B9 993 BEQL 90\$ ; Branch if no more waiting CDRPs.  
 04 A5 53 D1 02BB 994 CMPL R3, FKBSL\_FQBL(R5) ; See if waiter has right CDDB.  
 16 12 02BF 995 BNEQ 60\$ ; Branch if wrong CDDB.  
 60 65 D0 02C1 996 MOVL FKBSL\_FQFL(R5), - ; Let previous point to next.  
 02C4 997 FKBSL\_FQFL(R0)  
 0004'CF 05 12 02C4 998 BNEQ 50\$ ; Branch if current CDRP is not last.  
 50 D0 02C6 999 MOVL R0, HIRT\$L\_RPLQTP ; Else, previous is new end.  
 50 BC A5 D0 02CB 1000 50\$: MOVL CDRPSL\_UCB(R5), R0 ; Get UCB of interest.  
 56 A0 B7 02CF 1001 DECW UCBSW\_RWAITCNT(R0) ; Decrement count incremented during  
 02D2 1002 attempt to allocate HIRT.  
 FD2B' 30 02D2 1003 BSBW DUTUSINSERT\_RESTARTQ ; Insert this CDRP in restart queue.  
 DA 11 02D5 1004 BRB 30\$ ; Branch back to re-scan entire  
 02D7 1005 HIRT wait queue.  
 50 55 D0 02D7 1006 60\$: ; Setup to move to next waiting CDRP.  
 DA 11 02DA 1007 MOVL R5, R0 ; Current becomes previous.  
 02DC 1008 BRB 40\$ ; Loop back.  
 55 8ED0 02DC 1010 90\$: POPL R5 ; Restore saved register.  
 05 02DF 1011 99\$: RSB ; Return to caller.

G 14

02E0 1013 .SBTTL DUSRSTRTQ\_HIRT\_CDRP - Do connection failed cleanup of HIRT CDRP

02E0 1014 ++

02E0 1015

02E0 1016 :+ DUSRSTRTQ\_HIRT\_CDRP - Do connection failed cleanup of HIRT CDRP

02E0 1017

02E0 1018 Functional Description:

02E0 1019

02E0 1020

02E0 1021

02E0 1022

02E0 1023

02E0 1024

02E0 1025

02E0 1026

02E0 1027

02E0 1028

02E0 1029

02E0 1030

02E0 1031

02E0 1032

02E0 1033

02E0 1034

02E0 1035

02E0 1036

02E0 1037

02E0 1038

02E0 1039

02E0 1040

02E0 1041

02E0 1042

02E0 1043

02E0 1044

02E0 1045

02E0 1046 DUSRSTRTQ\_HIRT\_CDRP::

02E0 1047

This routine is called by DUTU\$INSERT\_RESTARTQ when it is discovered that the CDRP destined for the restart queue is the HIRT permanent CDRP. This action is taken instead of placing the HIRT permanent CDRP on the restart queue.

The CDRP owning the HIRT is located and processed with a recursive call to DUTU\$INSERT\_RESTARTQ. Any mapping resources owned by the HIRT permanent CDRP are copied to one of the CDDB permanent CDRPs. This allows the resources to be deallocated sometime after the connection is DISCONNECTed. This prevents "insane" servers for incorrectly overwriting memory due to reallocation of mapping resources. Finally, the HIRT is unlocked, thus making it available for some other replacement operation.

Inputs:

R3 CDDB address

R4 PDT address

R5 HIRT permanent CDRP address

Outputs:

R0 is destroyed.

All other registers are preserved.

55 001C'CF	DD	02E0	1048	PUSHL R5	; Save permanent replacement CDRP addr.
03 40 A5 03	E0	02E2	1049	MOVL HIRTSV_SAVDCDRP, R5	; Get HIRT owner CDRP address.
08 13	02E7	1050	BEQL 10S	; Branch if HIRT owner was canceled.	
FDOF' 30	02EE	1051	BBS #CDRPSV_PERM, -	; Branch if HIRT owner was a CDDB	
55 8ED0	02F1	1052	CDRPSL_DUTUFLAGS(R5), -	permanent CDRP.	
2C A5 D5	02F4	1053	10S		
17 13	02F7	1054	BSBW DUTU\$INSERT_RESTARTQ	; Insert HIRT owner on restart queue.	
2C A5 D4	02F9	1055	10\$: POPL R5	; Restore HIRT permanent CDRP addr.	
50 00D0 C3	9E	02FC	1057	TSTL CDRPSL_LBUFH_AD(R5)	; Were mapping resources allocated?
2C A0 30 A0	9E	0301	1058	BEQL 20S	Branch if no mapping res. allocated.
0306	1061	CLRL CDRPSL_LBUFH_AD(R5)	Prevent duplicate deallocations.		
0306	1062	MOVAB CDDBSA_PRMCDRP(R3), R0	Get CDDB permanent CDRP address.		
0306	1063	MOVAB CDRPST_LBUFHNDL(R0), -	Put address of Local BUFFer HaNDLe		
0306	1064	ASSUME CDRPSL_LBUFH_AD(R0)	field into field that points to it.		
030B	1065	MOVQ CDRPST_LBUFHNDL(R5), -	COPY contents of buffer handle to		
030B	1066	CDRPSL_LBUFHNDL(R0)	CDDB permanent CDRP. Also copy		
0310	1067	MOVQ CDRPST_LBUFHNDL+8(R5), -	CDRPSL UBARSCE in case this is		
0310	1068	CDRPSL_LBUFHNDL+8(R0)	a UNIBUS controller.		
53 DD 0310	1069 20\$:	PUSHL R3			; Save CDDB address.

53 BC A5 D0 0312 1070      MOVL CDRPSL\_UCB(R5), R3 ; Setup UCB for unlocking HIRT.  
FESF 30 0316 1071      BSBW DU\$UNLOCK\_HIRT ; Release HIRT.  
53 BE00 0319 1072      POPL R3 ; Restore CCDB address.  
05 031C 1073      RSB ; Return  
05 031C 1074

031D 1076 .SBTTL DUSREPLACE\_LBN - Replace a failing block  
 031D 1077 ;++  
 031D 1078  
 031D 1079 DUSREPLACE\_LBN - Replace a failing block  
 031D 1080  
 031D 1081 Functional Description:  
 031D 1082 Perform dynamic bad block replacement. At the time of invocation,  
 031D 1083 the HIRT is already owned by the caller.  
 031D 1084 Also entry to this routine made be made by branching (from subroutine  
 031D 1085 ONLINE\_COMPLETE) to labels STEP7 and STEP11.  
 031D 1086  
 031D 1087  
 031D 1088  
 031D 1089 Inputs:  
 031D 1090  
 031D 1091 R3 UCB address  
 031D 1092 R5 HIRT permanent CDRP address  
 031D 1093  
 031D 1094 Implicit Inputs:  
 031D 1095  
 031D 1096 CDRPSL\_RSPID(R5) user RSPID  
 031D 1097 HIRTSR\_SAVDCDRP original user CDRP address  
 031D 1098  
 031D 1099 HIRT owned by caller which implies HIRT SUBSTACK is operative  
 031D 1100  
 031D 1101 Outputs:  
 031D 1102  
 031D 1103 R0 Replacement status  
 031D 1104 R1 Setting for CDRPSV\_ERLIP  
 031D 1105 R3 UCB address (unchanged)  
 031D 1106  
 031D 1107 R2, R4, R5 destroyed.  
 031D 1108 All other registers preserved.  
 031D 1109 ;--  
 031D 1110  
 031D 1111  
 031D 1112 DUSREPLACE\_LBN:::  
 031D 1113  
 50 001C'CF DO 0327 1114 HIRT\_SUBSAVE : Save callers return point on SUBSTACK.  
 50 1C A0 DO 032C 1115 MOVL HIRTSR\_SAVDCDRP,R0 : R0 => original CDRP.  
 1C A0 DO 0330 1116 MOVL CDRPSL\_MSG\_BUF(R0),R0 : R0 => END PACKET.  
 0018'CF 01 B0 0333 1117 MOVL MSCPSL\_FRST\_BAD(R0),- : Indicate which LBN we are  
 000A'CF 01 B0 0336 1118 HIRTSR\_LBN fixing on this unit.  
 0338 1119 MOVW #SS\$ NORMAL, - : Initialize worst case I/O status.  
 0338 1120 HIRTSR\_IOWORST  
 0338 1121  
 0338 1122 ; Invalidate contents of incore scratch pages.  
 0338 1123  
 004C'CF 01 CE 0338 1124 ASSUME HIRTSR\_PG0CNTNT+2 EQ HIRTSR\_PG1CNTNT  
 033B 1125 MNEGL #1,HIRTSR\_PG0CNTNT ; Invalidate pages 0 and 1.  
 0340 1126  
 0050'CF 01 CE 0340 1127 ASSUME HIRTSR\_PG2CNTNT+2 EQ HIRTSR\_PG3CNTNT  
 0340 1128 MNEGL #1,HIRTSR\_PG2CNTNT ; Invalidate pages 2 and 3.  
 0345 1129  
 0345 1130  
 0345 1131 ALLOC\_MSG\_BUF : Allocate a send credit.  
 03 50 E8 0348 1132 BLBS R0,10\$ ; Branch around if successful alloc.

04BD 31 034B 1133      BRW      REPLACE\_CONNECT\_FAILURE ; If we had an allocation failure branch,  
           034E 1134 10\$:  
           034E 1135  
           034E 1136 : STEP 4 of replacement algorithm.  
           034E 1137 : We clear (zero) a sector sized buffer, then read the current  
           034E 1138 : contents of the bad block into the buffer. The buffer is cleared first  
           034E 1139 : for the rare case when no data can be transferred (such as a valid sync  
           034E 1140 : pattern is not detected). The read is performed with error recovery and  
           034E 1141 : error correction enabled. In addition to saving the data, we  
           034E 1142 : remember whether or not the read succeeded. The saved data is  
           034E 1143 : considered valid if the read succeeded, or invalid if it did not.  
           034E 1144 ;  
           034E 1145  
           034E 1146 : First we zero out the buffer to receive the contents of the failing block.  
           034E 1147  
 0200 8F 00 FE AF 3C BB 034E 1148      PUSHR #^M<R2,R3,R4,R5>      ; Save registers.  
           00 2C 0350 1149      MOVC5 #0,,#512-      ; Clear page 1 prior to read.  
           0028'DF 0358 1150      AHIRTS PAGE1PTR  
           3C BA 035B 1151      POPR #^M<R2,R3,R4,R5>      ; Restore registers.  
           035D 1152  
           035D 1153 : Step 4 continued. Prepare the CDRP with SVAPTE, BOFF, and BCNT of page 1  
           035D 1154 : (receiving field for upcoming read) so as to facilitate mapping of  
           035D 1155 : this region.  
           035D 1156  
           50 01 D0 035D 1157      MOVL #1,R0      ; Pass page to map to subroutine.  
           0748 30 0360 1158      BSBW MAP\_PAGE      ; Map page 1.  
           0363 1159  
           0363 1160 : Step 4 continued. Prepare the MSCP packet to read failing block into page 1.  
           0363 1161  
           0716 30 0363 1162      BSBW FILL\_RCT\_PACKET      ; Subroutine that fills most fields in  
           0366 1163      MSCP packet. Returns R2=>MSCP packet.  
           21 90 0366 1164      MOVB #MSCP\$K\_OP READ,-      ; Copy the READ opcode, field not filled  
           08 A2 0018'CF 0368 1165      MSCP\$B\_OPCODE(R2)      ; by above subroutine.  
           1C A2 00 036A 1166      MOVL HIRTS\_LBN,-      ; And also the LBN of the bad block.  
           036E 1167      MSCP\$L\_LBN(R2)  
           0370 1168  
           0370 1169      SEND\_MSCP\_MSG      ; Send message to the MSCP server.  
           0373 1170  
           07 09 A2 0373 1171      BBC #MSCP\$V\_EF\_ERLOG,-      ; Test for error log message generated  
           0080 8F 000E'CF A8 0375 1172      MSCP\$B\_FLAGS(R2),15\$      ; and branch around if not.  
           0378 1173      BISW #HIRTS\_M\_ERLOGIP,-      ; Else remember that error log messages  
           037C 1174      HIRTSW\_STS      ; Have been generated.  
           037F 1175 15\$:  
           037F 1176  
           52 2C A5 D0 037F 1177      UNMAP      ; Release mapping resources.  
           1C A5 0382 1178      CLRL CDRPSL\_LBUFH\_AD(R5)      ; Show no mapping resources allocated.  
           0385 1179      MOVL CDRPSL\_MSG\_BUF(R5),R2      ; Refresh R2 after unmap.  
           0389 1180  
           0389 1181 : Remember status of read of failing block so as to be able to write it later  
           0389 1182 : with or without the forced error flag.  
           0389 1183  
           000E'CF 04 AA 0389 1184      BICW s^#HIRTS\_M\_FE,HIRTSW\_STS ; Initialize bit.  
           000E'CF 04 A8 038E 1185      IF MSCP SUCCESS Then=20\$ ; Branch if READ succeeded.  
           0394 1186      BISW s^#HIRTS\_M\_FE,HIRTSW\_STS ; Set bit if read failed.  
           0399 1187 20\$:  
           0399 1188  
           0399 1189 ; Step 5.

0399 1190 : Record the data obtained when the bad block was read during step 4 in  
 0399 1191 sector 1 of each RCT copy. If the data cannot be successfully recorded  
 0399 1192 in the RCT, report the error to the error log and go to step 18. Note  
 0399 1193 that the Multi-Write algorithm used to record the data in sector 1 uses  
 0399 1194 write-compare operations to guarantee that the data is successfully  
 0399 1195 recorded.  
 0399 1196  
 0399 1197  
 0399 1198 STEP5:  
 0399 1199  
 0399 1200 : Write contents of page 1 to sector 1 of each RCT copy.  
 0399 1201  
 50 01 D0 0399 1202 MOVL #1,R0 : Pass sector and page number to routine,  
 004E'CF 50 B0 039C 1203 MOVW R0,HIRTSW\_PG1CNTNT : Indicate that page 1 contains RCT sector  
 03A1 1204  
 0565 30 03A1 1205 BSBW WRITE\_RCT\_BLOCK : Call internal subroutine to write.  
 0B 50 E8 03A4 1206 BLBS R0,STEP6 : LBS implies successful write to at  
 03A7 1207 HIR\_ERROR - : Signal HIR error.  
 0434 31 03A7 1208 BRW STEP18 : And branch to step 18.  
 03B2 1209  
 03B2 1210  
 03B2 1211 : Step 6. Record bad block's LBN, whether or not the saved data is valid and  
 03B2 1212 the fact that we are now in phase 1 of replacement in sector 0 of each  
 03B2 1213 RCT copy. This means that we read sector 0 modify it and  
 03B2 1214 then rewrite the updated sector to each RCT copy. If we cannot  
 03B2 1215 read any sector 0 successfully, we go to step 18. If we cannot  
 03B2 1216 successfully write at least one sector 0, we go to step 17.  
 03B2 1217  
 50 7C 03B2 1218 STEP6:  
 03B2 1219 CLRQ R0 : Prepare to read sector #0 into page #0.  
 03B4 1220  
 03B4 1221  
 03B4 1222  
 060C 30 03B4 1223 BSBW READ\_RCT\_BLOCK : Call to read RCT block.  
 0B 50 E8 03B7 1224 BLBS R0,10\$ : LBS implies successful read.  
 03BA 1225 HIR\_ERROR - : Signal HIR error.  
 0421 31 03C2 1226 BRW STEP18 : On failure goto step 18.  
 50 0024'CF D0 03C5 1228 10\$: MOVL HIRTSL\_PAGEOPTR,R0 : R0 => sector 0 in memory.  
 0018'CF D0 03CA 1229 MOVL HIRTSL\_LBN,- : Copy bad block's LBN to RCT sector  
 OC A0 03CE 1230 RCTS\_LBN(R0) : 0 copy in memory.  
 08 A0 8000 8F A8 03D0 1232 BISW #RCTSM\_RP1,RCTS\_W\_FLAGS(R0) : Set bit to signal phase 1.  
 AA 03D6 1233 BICW #RCTSM\_RP2- : Clear bit to signal not phase 2  
 03D7 1234 #RCTSM\_BR- : clear bad RBN flag.  
 03D7 1235 #RCTSM\_FE- : and also clear force error before  
 03D7 1236 RCTS\_W\_FLAGS(R0) : testing for valid data.  
 08 A0 6080 8F 03DC 1238 BBC S#HIRTSV\_FE,- : See if original data is valid.  
 000E'CF 02 E1 03DC 1239 HIRTSW\_ST5,20\$  
 06 03E1 1240 BISW #RCTSM\_FE,- : Set force error if appropriate.  
 08 A0 0080 8F A8 03E2 1241 RCTS\_W\_FLAGS(R0)  
 03E8 1242  
 50 D4 03E8 1244 CLRL R0 : Rewrite page 0.  
 051C 30 03EA 1245 BSBW WRITE\_RCT\_BLOCK : Go to rewrite sector 0.  
 0B 50 E8 03ED 1246 BLBS R0,STEP7- : LBS implies successful rewrite.

```

03CA 31 03F0 1247      HIR_ERROR -          ; Signal HIR error.
03F0 1248              step=6, type=WRITE
03FB 1249              BRW STEP17           ; And go to step 17.

03FB 1250 : STEP7.          Write and read test patterns on the suspected bad block to determine
03FB 1251 : whether or not it is in fact a bad block.
03FB 1252 : Go to step 9 if the test patterns fail,
03FB 1253 : indicating that the block is indeed bad. Continue with step 8 if the
03FB 1254 : test patterns succeed, indicating that the block may be good. The test
03FB 1255 : patterns fail if either the block is again reported as a bad block or if
03FB 1256 : the test patterns cannot be written and read back correctly.
03FB 1257 :
03FB 1258 :
03FB 1259 :
03FB 1260 STEP7:          MOVL HIRTS'L PAGE2PTR,R2      ; R2 => target page.
51 52 002C'CF 00         MOVL #TEST PATTERN,R1      ; Get test pattern to write to bad block.
B6DBCB6D BF 00          MOVZBL #512/4,R0        ; Loop counter set to # longwords in block.
50 80 8F 9A 0400 1262
50 80 8F 9A 0407 1263
50 80 8F 9A 040B 1264 10$:   MOVL R1,(R2)+          ; Copy test pattern to page 2.
FA 50 F5 040E 1265      SOBGTR R0,10$          ; Loop thru page.
50 02 D0 0411 1266
50 02 D0 0411 1267
0694 30 0414 1268      MOVL #2,R0            ; Pass page to map to subroutine.
0417 1269      BSBW MAP_PAGE          ; Call to map page 2.
0417 1270
0417 1271 : Call subroutine that recycles current END PACKET, recycles current RSPID and
0417 1272 : fills in most relevant data in the MSCP packet.
0417 1273 :
063B 30 0417 1274      BSBW BUILD_RCT_PACKET     ; Build a packet to transfer mapped
041A 1275              : page to random LBN.
041A 1276
08 A2 43000022 8F 00     ASSUME MSCPSW MODIFIER EQ MSCPSB_OPCODE+2
041A 1277              MOVL #MSCPSR_OP WRITE-      ; Fill in field not prepared by
0422 1278              !<<MSCPSM_MD_COMP -          ; BUILD_RCT_PACKET.
0422 1279              !MSCPSM-MD_SECOR -          ;
0422 1280              !MSCPSM-MD_SEREC> a 16>. -
0422 1281
0422 1282              MSCPSB_OPCODE(R2)
0422 1283
0018'CF 1C A2 D0 0422 1284      MOVL HIRTS'L_LBN,-          ; Fill in field filled in incorrectly
0426 1285              MSCPSL_LBN(R2)          ; by BUILD_RCT_PACKET.
0428 1286              SEND_MSCP_MSG          ; Send message to the MSCP server.
0428 1287
07 09 A2 05 E1 0428 1288      BBC #MSCPSV_EF_ERLOG,-      ; Test for error log message generated
0080 8F A8 042D 1289      MSCPSB_FLAGS(R2),15$      ; and branch around if not.
000E'CF 0430 1290      BISW #HIRTS'M_ERLOGIP,-      ; Else remember that error log messages
0434 1291      HIRTSW_STS           ; Have been generated.
0437 1292 15$:   UNMAP CDRPSL_LBUFH AD(R5)      ; If write no good, give up resources.
0437 1293      CLRL CDRPSL_MSG_BOF(R5),R2      ; And show that deallocation was done.
043D 1294      MOVL CDRPSL_MSG_BOF(R5),R2      ; Refresh R2 => END PACKET after unmap.
0441 1295      IF_MSCP SUCCESS, then=30$      ; Branch if WRITE successful.
0447 1296
00B4 31 0447 1297 20$:   BRW STEP9           ; Proceed to next step of replacement.
044A 1298
044A 1300 07 E0 044A 1301 30$:   BBS #MSCPSV_EF_BBLKR,-      ; If bad block reported again on write,
044C 1301              MSCPSB_FLAGS(R2),20$      ; then branch back to proceed with
044F 1302              : replacement.
044F 1303 40$:   :

```

			044F 1304		
			044F 1305	; Clear page to receive test pattern written block.	
			044F 1306		
0200 8F 00 FE AF 3C 00 002C'DF	BB 2C	044F 1307	PUSHR #^M<R2,R3,R4,R5>	; Save registers.	
		0451 1308	MOVCS #0, #0,#512,-	; Clear page 2 prior to read.	
		0459 1309	AH!R!SL PAGE2PTR		
	3C BA	045C 1310	POPR #^M<R2,R3,R4,R5>	; Restore registers.	
		045E 1311			
		045E 1312	; Call subroutine that recycles current END PACKET, recycles current RSPID and		
		045E 1313	fills in most relevant data in the MSCP packet.		
50 02 0647 05EE	D0 30 30	045E 1314	MOVL #2, R0	; Pass page to map to subroutine.	
		0461 1315	BSBW MAP PAGE	; Call to map page 2.	
		0464 1316	BSBW BUILD_RCT_PACKET	; Build MSCP packet to transfer page 2	
		0467 1317			
		0467 1318			
08 A2 43000021 8F	D0	0467 1319	ASSUME MSCPSW_MODIFIER EQ MSCPSB_OPCODE+2		
		0467 1320	MOVL #MSCPSR_OP READ-	; Fill in field not prepared by	
		046F 1321	!<<MSCPSM MD COMP -	; BUILD_RCT_PACKET.	
		046F 1322	!MSCPSM MD SECOR -		
		046F 1323	!MSCPSM MD SEREC> a 16>, -		
		046F 1324	MSCPSB_OPCODE(R2)		
		046F 1325			
0018'CF 1C A2	D0	046F 1326	MOVL HIRTS_LBN,-	; Fill in field filled in incorrectly	
		0473 1327	MSCPSL_LBN(R2)	; by BUILD_RCT_PACKET.	
		0475 1328	SEND_MSCP_MSG	; Send message to the MSCP server.	
07 09 A2 0080 8F 000E'CF	E1 AB	0478 1329	BBC #MSCPSV EF ERLOG,-	; Test for error log message generated	
		047A 1330	MSCPSB_FLAGS(R2),45\$	and branch around if not.	
		047D 1331	BISW #HIRTS_ERLOGIP,-	; Else remember that error log messages	
		0481 1332	HIRTSW_STS	; Have been generated.	
		0484 1333			
		0484 1334	45\$: UNMAP	; Give up MAP resources.	
52 2C A5 52 1C A5	D4 D0	0487 1335	CLRL CDRPSL_LBUFH AD(R5)	; And show that deallocation was done.	
		048A 1336	MOVL CDRPSL_MSG_BUF(R5),R2	; Refresh R2 => END PACKET after unmap.	
		048E 1337			
		048E 1338			
		048E 1339	IF_MSCP SUCCESS, then=60\$	; Branch if WRITE successful.	
0067	31	0494 1340	50\$: BRW STEP9	; On any error, goto step 9.	
F8 09 A2	E0	0497 1341			
		0497 1342	60\$: BBS #MSCPSV EF BBLKR,-	; If bad block reported on read,	
			MSCPSB_FLAGS(R2),50\$	then branch back to proceed with	
				replacement of same.	
51 52 B6DBCB6D 50 80 8F	002C'CF 8F 9A	049C 1343	MOVL HIRTS_PAGE2PTR,R2	; R2 => target page.	
		04A1 1344	MOVL #TEST PATTERN,R1	; Test pattern to compare to bad block.	
		049C 1345	MOVZBL #512/4,R0	; Loop counter set to # longwords in block.	
		04AC 1346			
		04AC 1347			
		04AB 1348			
		04AC 1349	70\$: CMPL R1, (R2)+	; Compare test pattern to page 2.	
82 51 E3 F8 50	D1 12 F5	04AC 1350	BNEQ 50\$	; On any discrepancy, branch.	
		04AF 1351	SOBGTR R0,70\$	; Loop thru page.	
		04B1 1352			
		04B4 1353			
		04B4 1354	: STEP8.		
		04B4 1355	We write the saved data back out to the bad block using a		
		04B4 1356	write-compare operation. The write-compare is performed with the "force		
		04B4 1357	error" modifier if and only if the saved data is invalid. Go to step 13		
		04B4 1358	if the write-compare both succeeds AND the block is no longer reported as		
		04B4 1359	a bad block -- the original problem was a transient. The write-compare		
		04B4 1360	succeeds if no error is detected and the saved data is valid or if only a		

04B4 1361 : forced error is detected and the saved data is invalid.

04B4 1362 :

04B4 1363 :

04B4 1364 STEP8:

04B4 1365 :

04B4 1366 : Try to write original data out to block originally reported as bad since  
error now appears to have been transient.

04B4 1367 :

04B4 1368 :

50 01 D0 04B4 1369 MOVL #1,R0 ; Data from bad block is in page 1.  
05F1 30 04B7 1370 BSBW MAP PAGE ; Map page 1.  
0598 30 04BA 1371 BSBW BUILD\_RCT\_PACKET ; Recycle etc., and fill in packet.

08 A2 40000022 8F 04BD 1372 :

04BD 1373 ASSUME MSCPSW\_MODIFIER EQ MSCPSB\_OPCODE+2  
DO 04BD 1374 MOVL #MSCPSR\_OP\_WRITE- ; Fill in field not prepared by  
!<MSCPSM MD COMP@16>,- ; BUILD\_RCT\_PACKET.  
04BE 1375 MSCPSB\_OPCODE(R2)

000E'CF 02 E1 04C5 1376 BBC S^#HIRTSV\_FE,- ; See if original data is valid.  
06 04CA 1377 HIRTSW\_STS, 10\$

0A A2 1000 8F A8 04CB 1378 BISW #MSCPSM\_MD\_ERROR,- ; Set force error modifier if  
04D1 1379 MSCPSW\_MODIFIER(R2) ; original data is invalid.

0018'CF 1C A2 04D1 1380 10\$: MOVL HIRTSL\_LBN,- ; Fill in field filled in incorrectly  
04D5 1381 MSCPSL\_LBN(R2) ; by BUILD\_RCT\_PACKET.  
04D7 1382 SEND\_MSCP\_MSG ; Send message to the MSCP server.

05 07 09 A2 E1 04DA 1383 BBC #MSCPSV\_EF\_ERLOG,- ; Test for error log message generated  
04DC 1384 MSCPSB\_FLAGS(R2),15\$ ; and branch around if not.  
0080 8F A8 04DF 1385 BISW #HIRTSR\_ERLOGIP,- ; Else remember that error log messages  
000E'CF 04E3 1386 HIRTSW\_STS ; Have been generated.

04E6 1391 15\$: UNMAP ; If write no good, give up resources.  
52 2C A5 D4 04E9 1392 CLRL CDRPSL\_LBUFH\_AD(R5) ; And show that deallocation was done.  
1C A5 DO 04EC 1393 MOVL CDRPSL\_MSG\_BUF(R5),R2 ; Refresh R2 => END PACKET after unmap.

04F0 1394 :

03 09 A2 04FO 1396 IF\_MSCP\_FAILURE, then=STEP9  
07 E0 04F6 1397 BBS #MSCPSV\_EF\_BBLKR,- ; Branch if problem not transient.  
04FB 1398 MSCPSB\_FLAGS(R2),STEP9 ; If bad block reported on write,  
04FB 1399 ; then branch ahead to proceed with  
01B2 31 04FB 1400 replacement of same.  
04FE 1401 BRW STEP13 ; Branch if error was transient.

04FE 1402 :

04FE 1403 : STEP9.  
04FE 1404 : We scan the RCT and determine what new RBN the bad block  
04FE 1405 : should be replaced with, whether or not the the bad block has been  
04FE 1406 : previously replaced, and (if it has previously been replaced) the bad  
04FE 1407 : block's old RBN. The RCT is NOT updated at this time. If the RCT scan  
04FE 1408 : fails, we report the error to the error log and go to step 16.

04FE 1409 :

04FE 1410 :

04FE 1411 STEP9:  
05DA 30 04FE 1412 BSBW SEARCH\_RCT ; Routine to search the RCT for an RBN.  
22 50 E8 0501 1413 BLBS R0,STEP10 ; LBC implies success, so goto step 10.  
06 E0 0504 1414 BBS S^#HIRTSV\_RCTFULL, - ; Check for RCTFULL error and  
0A 0509 1415 HIRTSW\_STS, 910\$ ; branch if that is the problem.  
050A 1416 HIR\_ERROR - ; Else, signal HIR READ error.  
050A 1417 step=9, type=READ

OF 11 0512 1418 BRB 980\$ ; Join common branch to step 16.  
 0514 1419 910\$: HIR\_ERROR -  
 0514 1420 step=9, type=RCTFULL ; Signal HIR RCTFULL error.  
 000A'CF 216C 8F B0 051C 1421 MOVW #SSS\_BADRCT, - ; Also, supply a worst case error  
 0523 1422 HIRTSW\_IOWORST ; status.  
 025D 31 0523 1423 980\$: BRW STEP16 ; Go to step 16 after any failure.  
 0526 1424 :  
 0526 1425 : STEP10.  
 0526 1426 : Record the new RBN, whether or not the bad block has been previously  
 0526 1427 : replaced, the bad block's old RBN (if it has been previously replaced),  
 0526 1428 : and the fact that we are in phase 2 of bad block replacement in sector 0  
 0526 1429 : of each RCT copy. The RCT must be updated without reading sector 0,  
 0526 1430 : instead using the copy of sector 0 last read from or written to the RCT.  
 0526 1431 : If the RCT cannot be updated, report the error to the error log and go to  
 0526 1432 : step 16.  
 0526 1433 :  
 0526 1434 :  
 0526 1435 :  
 0526 1436 STEP10:  
 50 0024'CF D0 0526 1437 MOVL HIRTSL\_PAGEOPTR,R0 ; R0 => Page 0.  
 0058'CF D0 052B 1438 MOVL HIRTSL\_RBN,- ; Update date to sector 0 copy in  
 10 A0 052F 1439 RCTS\_L\_RBN(R0) ; in memory.  
 000E'CF 03 E1 0531 1440 BBC S^#HIRTSV\_MATCH, - ; See if we had a failing RBN, and  
 0C 0536 1441 HIRTSW\_STS,10\$ ; if NOT, branch around.  
 2000 8F A8 0537 1442 BISW #RCTSM\_BR,- ; Indicate failing RBN in sector 0  
 08 A0 053B 1443 RCTS\_W\_FLAGS(R0) ; flags word.  
 005C'CF D0 053D 1444 MOVL HIRTSL\_MATCHRBN,- ; And also indicate the failing RBN.  
 14 A0 0541 1445 RCTS\_L\_BAD\_RBN(R0)  
 0543 1446 10\$: BICW #RCTSM\_RP1,- ; Show that we are leaving phase 1  
 8000 8F AA 0543 1447 RCTS\_W\_FLAGS(R0) ; of replacement processing.  
 08 A0 0547 1448 BISW #RCTSM\_RP2,- ; And entering phase 2.  
 4000 8F A8 0549 1449 RCTS\_W\_FLAGS(R0)  
 08 A0 054D 1450 :  
 054F 1451 CLRL R0 : Rewrite page 0.  
 50 D4 054F 1452 BSBW WRITE\_RCT\_BLOCK : Go write the sector.  
 03B5 30 0551 1453 BLBS R0,STEP11 : If success, go to next step.  
 0B 50 E8 0554 1454 HIR\_ERROR - ; Signal HIR error.  
 0557 1455 :  
 0221 31 055F 1456 step=10, type=WRITE : Branch on failure.  
 0562 1457 BRW STEP16  
 0562 1458 :  
 0562 1459 : STEP11.  
 0562 1460 : We update the RCT to indicate that the bad block has been  
 0562 1461 : replaced with the new RBN, and that the old RBN (if any) is unusable. If  
 0562 1462 : this requires updating two blocks in the RCT, then both blocks must be  
 0562 1463 : read before either is written. If a block cannot be read successfully,  
 0562 1464 : report the error to the error log and go to step 16. If a block cannot  
 0562 1465 : be written successfully, report the error to the error log and go to step  
 0562 1466 : 15.  
 0562 1467 :  
 0562 1468 :  
 0562 1469 :  
 0562 1470 STEP11:  
 50 0058'CF 07 00 EF 0562 1471 EXTZV #0,#7,HIRTSL\_RBN,R0 ; R0 = offset in sector of RBN descriptor.  
 51 002C'CF DO 0569 1472 MOVL HIRTSL\_PAGE2PTR,R1 ; R1 => sector containing RBN descriptor.  
 50 6140 DE 056E 1473 MOVAL (R1)[R0],R0 ; R0 => RBN descriptor.  
 0572 1474

```

20000000 8F C9 0572 1475      BISL3 #RCTSM_ALLOCATED,-      ; Put LBN being replaced into descriptor.
60 0018'CF 04 E1 0578 1476      HIRTS'LBN,(R0)           ; and or in ALLOCATED bit.
000E'CF 04 E1 057C 1477      BBC S^#HIRTSV_EMPTYTYPE,- ; Branch if primary RBN allocation.
07 0581 1478      HIRTSW_STS,10$ 
60 10000000 8F C8 0582 1479      BISL #RCTSM_NONPRIME,(R0) ; Indicate non prime allocation.
000E'CF 03 E0 0589 1480 10$:      BBS S^#HIRTSV_MATCH,- ; Branch if RCT search showed RBN failed.
03 058E 1481      HIRTSW_STS,20$ 
0063 31 058F 1483      BRW 60$          ; If NOT RBN failure, skip RBN
0592 1484          ; descriptor update.

51 005C'CF F9 8F 78 0592 1485 20$:      ASHL #-7,HIRTS'L_MATCHRBN,R1 ; R1 = relative RCT block containing
51 02 C0 0599 1486          ; bad RBN descriptor.
0050'CF 51 B1 059C 1487      ADDL #2,R1           ; Add in sectors 0 and 1.
05A1 1488      CMPW R1,HIRTSW_PG2CNTNT ; Page 2 contains RBN descriptor of
05A1 1490          ; allocatable RBN and maybe also
05A1 1491          ; descriptor of bad RBN.
1B 13 05A1 1492      BEQL 40$          ; EQL implies both descriptors in same
05A3 1493          ; block.
50 03 D0 05A3 1494      MOVL #3,R0           ; Indicate that we want to read into
05A6 1495          ; page 3.
041A 30 05A6 1496      BSBW READ_RCT_BLOCK ; Read sector (R1) into page 3.
OB 50 E8 05A9 1497      BLBS R0,30$          ; If success, continue.
05AC 1498          ; Signal HIR error.

01CC 31 05B4 1500      BRW STEP16          ; Branch on failure.

52 0030'CF 05 D0 05B7 1501 30$:      MOVL HIRTS'L_PAGE3PTR,R2 ; R2 => page with bad RBN descriptor.
11 05BC 1502          ; Branch around.

52 002C'CF D0 05BE 1503 40$:      MOVL HIRTS'L_PAGE2PTR,R2 ; R2 => page with bad RBN descriptor.

50 005C'CF 07 00 EF 05C3 1504 50$:      EXTZV #0,#7,HIRTS'L_MATCHRBN,R0 ; R0 = offset of bad RBN descriptor.
50 6240 DE 05CA 1505          ; R0 => bad RBN descriptor.
0060'CF 60 D0 05CE 1506          ; Save Bad RBN descriptor in case
05D3 1507          ; we have to restore due to failure.
60 40000000 8F D0 05D3 1512      MOVL #RCTSM_UNUSABLE,(R0) ; Clear LBN and mark unusable bit in
002C'CF 52 D1 05DA 1513          ; descriptor.
14 13 05DF 1514          ; See if both descriptors in same page.
05E1 1515          ; EQL implies yes. Go do only 1 write.

50 03 D0 05E1 1516      MOVL #3,R0          ; Rewrite page 3 [R0].
0322 30 05E4 1517      BSBW WRITE_RCT_BLOCK ; Go write.
OB 50 E8 05E7 1518      BLBS R0,60$          ; If success, continue.
05EA 1519          ; Signal HIR error.

00FA 31 05F2 1520      CMPL R2,HIRTS'L_PAGE2PTR ; Branch on failure.

50 02 D0 05F5 1521 60$:      BEQL 60$          ; Rewrite page 3 [R0].
030E 30 05F8 1522      MOVL #2,R0          ; Go write.
OB 50 E8 05FB 1523      BSBW WRITE_RCT_BLOCK ; If success, goto next step.
05FE 1524          ; Signal HIR error.

010E 31 0606 1529      BLBS R0,STEP12-      ; Branch on failure.
0609 1530          ; Signal HIR error.
0609 1531          ; Branch on failure.

```

0609 1532 : STEP12.  
 0609 1533 : We use the REPLACE command to revector the bad block to the  
 0609 1534 : chosen replacement block, then use the standard WRITE command (addressed  
 0609 1535 : to the bad block's LBN) with the "compare" modifier asserted to store the  
 0609 1536 : saved data in the replacement block. The write-compare is performed with  
 0609 1537 : the "force error" modifier if and only if the saved data is invalid.  
 0609 1538 : Note that the REPLACE command implicitly verifies that a head or servo  
 0609 1539 : track failure has not occurred, causing a large number of improper  
 0609 1540 : replacements. If the REPLACE command fails, go to step 15. If the WRITE  
 0609 1541 : command fails, go to step 9 to re-scan the RCT for another RBN. Note  
 0609 1542 : that the current new RBN will become the old RBN for this next pass.  
 0609 1543 : Either failure will have already been reported to the error log. The  
 0609 1544 : WRITE command succeeds if no error is detected and the saved data is  
 0609 1545 : valid or if only a forced error is detected and the saved data is  
 0609 1546 : invalid.  
 0609 1547 :  
 0609 1548 :  
 0609 1549 STEP12:  
 03 50 E8 0609 1550 RECYCH\_MSG\_BUF : Recycle END PACKET into MSCP buffer.  
 01F9 31 060C 1551 BLBS R0,5\$ : LBS means allocation success.  
 060F 1552 BRW REPLACE\_CONNECT\_FAILURE : Allocation failure means CONNECTION  
 0612 1553 : failure.  
 0612 1554 SS: INIT\_MSCP\_MSG ucb=(R3) : Initialize MSCP packet for REPLACE.  
 0615 1555 :  
 0615 1556 :  
 08 A2 80000014 8F 0615 1557 ASSUME MSCPSW\_MODIFIER EQ MSCPSB\_OPCODE+2  
 DO 0615 1558 MOVL #MSCPSR\_OP\_REPLACE- : Fill in field not prepared by  
 0616 1559 !<MSCPSM MD\_EXPRSA16>,- : BUILD\_RCT\_PACKET.  
 MSCPSB\_OPCODE(R2)  
 0616 1560 :  
 061D 1561 BBS S^#HIRTSV\_EMPTYPE, - : See if primary or secondary RBN,  
 04 E0 061D 1562 HIRTSV\_STS,10\$ branch if secondary.  
 04 0622 1563 BISW #MSCPSM MD\_PRIMR,- : Set primary modifier if  
 01 A8 0623 1564 MSCPSW\_MODIFIER(R2) called for.  
 0A A2 0625 1565  
 0627 1566 10\$: MOVL HIRTSL\_RBN,MSCPSL\_RBN(R2); Fill in special REPLACE field.  
 0C A2 0058'CF DO 0627 1567 MOVL HIRTSL\_LBN,- : Fill in field filled in incorrectly  
 0018'CF DO 062D 1568 MSCPSL\_LBN(R2) : by BUILD\_RCT\_PACKET.  
 1C A2 0631 1569 SEND\_MSCP\_MSG : Send message to the MSCP server.  
 0633 1570 :  
 0636 1571 BBC #MSCPSV\_EF\_ERLOG,- : Test for error log message generated  
 07 09 A2 0636 1572 MSCPSB\_FLAGS(R2),15\$ and branch around if not.  
 0080 8F A8 0638 1573 BISW #HIRTSV\_ERLOGIP,- : Else remember that error log messages  
 000E'CF 063B 1574 HIRTSV\_STS : Have been generated.  
 0642 1575 :  
 0642 1576 15\$: IF MSCP SUCCESS, then=20\$ : Branch if REPLACE was successful.  
 0648 1577 HIR\_ERROR - : Signal HIR error.  
 00C4 31 0648 1578 step=12, type=REPFAIL  
 50 01 0648 1579 BRW STEP15\_B  
 0452 30 0650 1580 20\$: MOVL #1,R0 : Data from bad block is in page 1.  
 03F9 30 0653 1581 BSBW MAP\_PAGE : Map page 1.  
 0656 1582 BSBW BUILD\_RCT\_PACKET : Recycle etc., and fill in packet.  
 0659 1583 :  
 065C 1584 :  
 065C 1585 :  
 00 065C 1586 ASSUME MSCPSW\_MODIFIER EQ MSCPSB\_OPCODE+2  
 DO 065C 1587 MOVL #MSCPSR\_OP\_WRITE- : Fill in field not prepared by  
 065D 1588 !<MSCPSM\_MD\_COMPA16>,- : BUILD\_RCT\_PACKET.

E 15

```

08 A2 40000022 8F      065D 1589      MSCPSB_OPCODE(R2)
000E'CF 02             0664 1590      BBC   S^#HIRTSV_FE,-      ; See if original data is valid.
06               E1 0664 1591
0A A2 1000 8F      0669 1592      BISW  #MSCPSM_MD_ERROR,- ; Set force error modifier if
06               AB 066A 1593      MSCPSW_MODIFIER(R2)  ; original data is invalid.
0670 1594      0670 1595 30$:      MOVL   HIRTSL_LBN,-      ; Fill in field filled in incorrectly
0674 1597      0676 1598      SEND_MSCP_MSG    ; by BUILD_RCT_PACKET.
0679 1599      0679 1600      BBC   #MSCPSV_EF_ERLOG,- ; Fill in field filled in incorrectly
07 09 A2             067B 1601      MSCPSB_FLAGS(R2),35$ ; by BUILD_RCT_PACKET.
0080 8F             A8 067E 1602      BISW  #HIRTSM_ERLOGIP,- ; Else remember that error log messages
000E'CF            0682 1603      HIRTSW_STS     ; Have been generated.
0685 1604 35$:      UNMAP
52 2C A5             D4 0688 1605      CLRL   CDRPSL_LBUFH_AD(R5) ; If write no good, give up resources.
0688 1606      0688 1607      MOVL   CDRPSL_MSG_BUF(R5),R2 ; And show that deallocation was done.
068F 1608      068F 1609      IF_MSCP SUCCESS, then=STEP13 ; Refresh R2 => END PACKET after unmap.
0695 1610      0695 1611 ; ASSUME that the force data subcode is zero
0A 08 B1 0695 1612      CMPW   #MSCPSK_ST_DATA,- ; See if data error with force error
0A A2 0697 1613      MSCPSW_STATUS(R2)  ; subcode.
0A 12 0699 1614      BNEQ   50$          ; If NOT, then branch to take action.
000E'CF 02 E0 069B 1615      BBS    S^#HIRTSV_FE,-      ; To STEP13 if force error expected.
0F               06A0 1617      HIRTSW_STS,STEP13
06A1 1618      06A5 1619 50$:      BUG_CHECK DISKCLASS,FATAL ; Shouldn't happen.
06A5 1620      06A5 1621      HIR_ERROR -      ; Signal HIR error.
06AD 1622      06B0 1623      BRW    STEP9        ; Following algorithm, goto step 9.
06B0 1624      : STEP13.
06B0 1625      : We update sector 0 of the RCT copies to indicate that we are no
06B0 1626      : longer in the middle of replacing a bad block. The RCT must be updated
06B0 1627      : without reading sector 0, instead using the copy of sector 0 last read
06B0 1628      : from or written to the RCT. If the RCT cannot be updated, report the
06B0 1629      : error to the error log and go to step 17.
06B0 1630      :
06B0 1631      :
50 0024'CF 00 06B0 1632 STEP13:      MOVL   HIRTSL_PAGEOPTR,R0 ; R0 => page 0, which contains sector 0.
AA 06B5 1633      BICW   #RCTSM_RP1- ; Reset flags in sector zero. We are
06B6 1634      !RCTSM_RP2- ; NOT in phase 1 nor in phase 2.
06B6 1635      !RCTSM_BR- ; Also we clear Bad RBN flag and
06B6 1636      !RCTSM_FE- ; force error flag as well.
06B6 1637      RCTSW_FLAGS(R0)
06B8 1638      :
06B8 1639      :
06BB 1640 : ASSUME RCTS_LBN_EQ RCTS_LBN+4
0C A0 7C 06BB 1641 : CLRQ   RCTS_LBN(R0) ; Zero out RBN and LBN.
14 A0 D4 06BE 1642 : CLRL   RCTS_BAD_RBN(R0) ; Also clear BADRBN field.
06C1 1643      :
50 D4 06C1 1644      CLRL   R0      ; Rewrite page 0.
0243 30 06C3 1645      BSBW   WRITE_RCT_BLOCK ; Go write page into sector.

```

OB 50 E8 06C6 1646      BLBS R0,STEP14 ; LBS is success.  
                   06C9 1647 HIR\_ERROR - ; Signal HIR error.  
 00F1 31 06D1 1649      BRW STEP17 ; After failure goto step 17.  
                   06D4 1650  
                   06D4 1651 : STEP14.  
                   06D4 1652 : We set the success return code and return to our internal caller.  
                   06D4 1653 :  
                   06D4 1654 :  
                   06D4 1655 STEP14:  
                   06D4 1656 DEALLOC\_MSG\_BUF  
                   51 D4 06D7 1657 CLRL R1  
 03 000E'CF 07 E5 06D9 1658 BBCC S^#HIRTSV\_ERLOGIP,- ; Prepare to return ERLIP bit if set.  
                   51 04 A8 06DB 1659 HIRTSW\_STS,10\$ ; Branch around if clear and clear if  
                   50 01 3C 06E2 1660 BISW #CDRPSA\_ERLIP,R1 already set.  
                   06EF 1661 10\$: ; Set bit in R1 so as to return to caller.  
                   06EF 1662 MOVZWL S^#SSS\_NORMAL,R0 ; Prepare to return status to caller.  
                   06EF 1663 HIRT\_SUBRETURN ; Return to caller.  
                   06EF 1664  
                   06EF 1665 : STEP15 - If here we failed to update the RCT (STEP11) or we failed in the  
                   06EF 1666 : REPLACE (STEP12).  
                   06EF 1667 : We restore the RCT to indicate that the new RBN is unallocated  
                   06EF 1668 : and usable and that the bad block is either not replaced or revectored to  
                   06EF 1669 : the old RBN, whichever was it's original status. The RCT must be updated  
                   06EF 1670 : without reading any blocks from it, instead using the copies of the  
                   06EF 1671 : relevant blocks that were read from the RCT in step 11. Any errors are  
                   06EF 1672 : reported to the error log but otherwise ignored.  
                   06EF 1673 :  
                   06EF 1674 :  
                   06EF 1675 STEP15\_A:  
                   06EF 1676 :  
                   06EF 1677 : Here we failed to write the RCT block containing the Bad RBN only when  
                   06EF 1678 : this descriptor resided in a different RCT block than that of the  
                   06EF 1679 : selected RBN. Because of the way that STEP11 works the copy  
                   06EF 1680 : of the RCT Block is in page 3.  
                   06EF 1681  
 50 005C'CF 52 0030'CF DO 06EF 1682 MOVL HIRTSL\_PAGE3PTR,R2 ; R2 => copy of page 3 in memory.  
                   07 00 EF 06F4 1683 EXTZV #0,#7,HIRTSL\_MATCHRBN,R0 ; R0 = offset (longword) of Bad RBN  
                   06FB 1684 descriptor in page 3.  
 60 50 6240 DE 06FB 1685 MOVAL (R2)[R0],R0 ; R0 => Bad RBN descriptor slot.  
                   0060'CF DO 06FF 1686 MOVL HIRTSL\_BADRBND,(R0) ; Restore Bad RBN descriptor.  
                   50 03 DO 0704 1687 MOVL #3,R0 ; Prepare to try to rewrite page 3.  
                   01FF 30 0707 1688 BSBW WRITE\_RCT\_BLOCK ; Try to rewrite.  
                   08 50 EB 070A 1689 BLBS R0, 90\$ ; Branch if WRITE succeeded.  
                   070D 1690 HIR\_ERROR - ; Else, signal HIR error.  
                   070D 1691 90\$: BRB STEP16 ; Always go to step 16.  
                   0717 1692  
                   0717 1693  
                   0717 1694 STEP15\_B:  
                   0717 1695  
                   0717 1696 : If here we failed in the REPLACE operation or in updating the RCT block  
                   0717 1697 : containing the selected RBN descriptor. So we try to restore the  
                   0717 1698 : RCT sector(s) that contained the RBN descriptor(s). If there was  
                   0717 1699 : no Bad RBN, then we simply want to restore the contents of page 2  
                   0717 1700 : to the sector indicated by HIRTSW\_PG2CNTNT after clearing the  
                   0717 1701 : RBN descriptor slot associated with the selected RBN.  
                   0717 1702

G 15

```

000E'CF 03 E1 0717 1703 BBC s^#HIRTSV_MATCH, - ; If NO Bad RBN, branch ahead to
        43          071C 1704 HIRTSW_STS,20$ ; restore only one descriptor.

        071D 1705 : If there was a Bad RBN, and its descriptor happened to reside in the
        071D 1706 same RCT sector as the descriptor of the selected RBN, then we first
        071D 1707 first restore the old contents of the Bad RBN descriptor then
        071D 1708 if this descriptor resided in a different sector than the selected
        071D 1709 RBN's descriptor, we rewrite this other sector first. Note the
        071D 1710 other sector is contained in page 3 while the selected
        071D 1711 RBN's descriptor is always in page 2.
        071D 1712
        071D 1713

51 005C'CF 002C'CF D0 071D 1714 MOVL HIRTSL_PAGE2PTR,R2 ; R2 => copy of page 2.
      F9 8F 78 0722 1715 ASHL #7,HIRTSL_MATCHRBN,R1 ; Calculate RCT sector # for Bad RBN.
      51 02 C0 0729 1716 ADDL #2,R1 ; Add in RCT sectors 0 and 1.
      0050'CF 51 B1 072C 1717 CMPW R1,HIRTSW_PG2CNTNT ; See if in same sector.
      05 13 0731 1718 BEQL 10$ ; EQL implies yes.

52 0030'CF D0 0733 1720 MOVL HIRTSL_PAGE3PTR,R2 ; R2 => copy of page 3.
      0738 1721 10$: EXTZV #0,#7,HIRTSL_MATCHRBN,R0; R0 = offset (longword) of Bad RBN
      073F 1722 descriptor in page 2 or 3.
      073F 1723 MOVAL (R2)[R0],R0 ; R0 => Bad RBN descriptor slot.
      073F 1724 MOVL HIRTSL_BADRBND,(R0) ; Restore Bad RBN descriptor.
      0060'CF 52 D1 0743 1725 CMPL R2,HIRTSL_PAGE2PTR ; See if we have to do both pages.
      11 13 074D 1726 BEQL 20$ ; EQL implies NO, only page 2.
      50 03 D0 074F 1728 MOVL #3,R0 ; Prepare to try to rewrite page 3.
      01B4 30 0752 1729 BSBW WRITE_RCT_BLOCK ; Try to rewrite.
      08 50 E8 0755 1730 BLBS R0,20$ ; Branch if WRITE succeeded.
      0758 1731 HIR_ERROR - ; Else, signal HIR error.

      0758 1732 step=15, type=WRITE
      0760 1733 20$: ; Here we clear the selected RBN's descriptor and rewrite the sector from
      0760 1734 page 2.
      0760 1735 : Here we clear the selected RBN's descriptor and rewrite the sector from
      0760 1736 : page 2.
      0760 1737

50 0058'CF 002C'CF D0 0760 1738 MOVL HIRTSL_PAGE2PTR,R2 ; R2 => page 2 in memory.
      07 00 EF 0765 1739 EXTZV #0,#7,HIRTSL_RBN,R0 ; R0 = offset (longword) of selected RBN
      076C 1740 descriptor in page 2.
      50 6240 DE 076C 1741 MOVAL (R2)[R0],R0 ; R0 => RBN descriptor slot.
      60 D4 0770 1742 CLRL (R0) ; Restore to available RBN descriptor.

      0772 1743
      50 02 D0 0772 1744 MOVL #2,R0 ; Prepare to try to rewrite page 2.
      0191 30 0775 1745 BSBW WRITE_RCT_BLOCK ; Try to rewrite.
      08 50 E8 0778 1746 BLBS R0,STEP16 ; Branch if WRITE succeeded.
      077B 1747 HIR_ERROR - ; Else, signal HIR error.

      077B 1748 step=15, type=WRITE
      0783 1749 : ----- BRB STEP16 ; Always continue with step 16.

      0783 1750
      0783 1751 : STEP16.
      0783 1752 : We use the standard WRITE command (addressed to the bad block's
      0783 1753 : LBN) to restore the saved data. The write is performed with the "force
      0783 1754 : error" modifier if and only if the saved data is invalid. Any errors are
      0783 1755 : reported to the error log but otherwise ignored.
      0783 1756 :
      0783 1757 :
      0783 1758 STEP16: MOVL #1,R0 ; Prepare to try to write original data
  
```



000E'CF 51 D6 07E6 1817 STEP18:  
07 07E6 1818 DEALLOC\_MSG\_BUF  
03 E5 07E9 1819 CLRL R1 ; Prepare to return ERLOGIP bit if set.  
51 04 A8 07EB 1820 BBCC S^#HIRTSV\_ERLOGIP, - ; Branch around if clear and clear if  
05 50 E9 07F0 1821 HIRTSW\_STS,10S already set.  
50 0008'CF 3C 07F1 1822 BISW #CDRPSM\_ERLIP,R1 ; Set bit in R1 so as to return to caller.  
05 50 3C 07F4 1823 10\$: MOVZWL HIRTSW\_IOST,RO ; Indicate failure to caller.  
50 000A'CF 3C 07FC 1824 BLBC RO, 15S ; Branch if error already found.  
0801 1825 15\$: MOVZWL HIRTSW\_IOWORST, RO ; Else, get worst case I/O status.  
080B 1826 1828 HIRT\_SUBRETURN  
080B 1829 REPLACE\_CONNECT\_FAILURE: ; Come here if CONNECTION failure  
080B 1830 ; anywhere in REPLACE logic.  
080B 1831 F7F2' 31 080B 1832 BRW DUTUSKILL\_THIS\_THREAD ; Branch to kill this thread.

080E 1834 .SBTTL DU\$ONLINE\_COMPLETE - Perform HIRT operations after ONLINE  
 080E 1835 ++  
 080E 1836  
 080E 1837 DU\$ONLINE\_COMPLETE - Perform HIRT operations after ONLINE  
 080E 1838  
 080E 1839 Functional Description:  
 080E 1840 Complete bringing a unit ONLINE when it is attached to a controller  
 080E 1841 that require HOST INITIATED dynamic bad block replacement. This  
 080E 1842 routine reads sector zero of the RCT to see if the disk went offline  
 080E 1843 in the middle of bad block replacement. If so the replacement is  
 080E 1844 completed.  
 080E 1845  
 080E 1846  
 080E 1847 Inputs:  
 080E 1848 R3 UCB address for the unit that being brought ONLINE  
 080E 1849 R5 HIRT permanent CDRP address  
 080E 1850  
 080E 1851 Implicit Inputs:  
 080E 1852 HIRTS\$L\_SAVDCDRP CDRP that describes the current operation  
 080E 1853  
 080E 1854 HIRT is owned by the current thread  
 080E 1855 HIRT SUBSTACK is reset  
 080E 1856  
 080E 1857  
 080E 1858  
 080E 1859 Outputs:  
 080E 1860 R0 Replacement status  
 080E 1861 R1 Setting for CDRP\$V\_ERLIP  
 080E 1862 R3 UCB address (unchanged)  
 080E 1863  
 080E 1864 R2, R4, R5 destroyed.  
 080E 1865 All other registers preserved.  
 080E 1866  
 080E 1867 --  
 080E 1868  
 080E 1869  
 080E 1870 DU\$ONLINE\_COMPLETE:::  
 080E 1871  
 080E 1872 HIRT\_SUBSAVE : Save return point on SUBSTACK.  
 0818 1873  
 004C'CF 01 CE 0818 1874 ASSUME HIRTSW\_PG0CNTNT+2 EQ HIRTSW\_PG1CNTNT  
 081D 1875 MNEGL #1,HIRTSW\_PG0CNTNT : Invalidate contents of pages 0 and 1.  
 0050'CF 01 CE 081D 1876  
 081D 1877 ASSUME HIRTSW\_PG2CNTNT+2 EQ HIRTSW\_PG3CNTNT  
 081D 1878 MNEGL #1,HIRTSW\_PG2CNTNT : Invalidate contents of pages 2 and 3.  
 0822 1879  
 0822 1880 : Here we want to read sector 0 of the RCT into page 0 so as to be able to  
 0822 1881 determine whether or not we went down in the middle of Dynamic Bad  
 0822 1882 Block replacement.  
 0822 1883 : Note we have NOT allocated a Message Buffer. READ\_RCT\_BLOCK (via a call  
 0822 1884 to BUILD\_RCT\_PACKET) will do it for us.  
 0822 1885  
 50 7C 0822 1886 CLRQ R0 : Indicate read sector 0 (R1) into  
 0824 1887 : page 0 (R0).  
 019C 30 0824 1888 BSBW READ\_RCT\_BLOCK : Read indicated sector into page.  
 0B 50 E8 0827 1889 BLBS R0,20\$ : LBS means successful read.  
 082A 1890 HIR\_ERROR - : Signal HIR error.

FFB1 31 082A 1891 step=1, func=ONLINE, -  
 082A 1892 type=READ  
 0832 1893 BRW STEP18 ; Goto deallocate and set RCT\_FAILURE  
 0835 1894 ; status code before returning.  
 0835 1895 20\$:  
 0835 1897 ; Here we do a write of page 0 to sector 0 (all copies) to insure that we  
 0835 1898 did not crash in the middle of an update of sector 0 and thereby  
 0835 1899 get a set of inconsistent copies.  
 0835 1900  
 50 D4 0835 1901 CLRL R0 Rewrite page 0.  
 00CF 30 0837 1902 BSBW WRITE\_RCT\_BLOCK Write indicated sector from page.  
 0B 50 EB 083A 1903 BLBS R0,30\$ LBS means successful write.  
 083D 1904 HIR\_ERROR - Signal HIR error.  
 083D 1905  
 083D 1906  
 FF9E 31 0845 1907 BRW STEP18 ; Goto deallocate and set RCT\_FAILURE  
 0848 1908 ; status code before returning.  
 50 0024'CF D0 0848 1910 MOVL HIRTS\$PAGEOPTR,R0 ; R0 => sector 0 in memory.  
 B3 084D 1911 BITW #RCTSM\$RP1- Test for phase 1 of replacement  
 084E 1912 #RCTSM\$RP2- or phase 2.  
 08 A0 C000 BF 1B 12 084F 1913 RCTS\$FLAGS(R0)  
 0853 1914 BNEQ 40\$ NEQ implies that we were in the  
 0855 1915 middle of replacement.  
 000E'CF 51 D4 0855 1916 DEALLOC\_MSG\_BUF Else we deallocate the buffer  
 07 E5 0858 1917 CLRL R1 Prepare to return ERLOGIP bit if set.  
 03 085A 1918 BBCC \$^#HIRTS\$V\_ERLOGIP, - Branch around if clear and clear if  
 51 04 AB 0860 1920 HIRTS\$STS,35S already set.  
 0863 1921 35\$: BISW #CDRPS\$ERLIP,R1 Set bit in R1 so as to return to caller.  
 50 01 3C 0863 1922 MOVZWL #SSS\$NORMAL,R0 deallocate the RSPID, and we return  
 0866 1923 HIRTS\$SUBRETURN to caller with a success status.  
 0870 1924 ; Return.  
 OC A0 D0 0870 1925 40\$: MOVL RCTS\$LBN(R0),- ; Restore LBN to replace to HIRT.  
 0018'CF 0873 1927 HIRTS\$LBN  
 50 01 D0 0876 1928 MOVL #1,R0 ; Read into page 1.  
 51 01 D0 0879 1929 MOVL #1,R1 From RCT sector 1.  
 0144 30 087C 1930 BSBW READ\_RCT\_BLOCK Read RCT block.  
 08 50 E8 087F 1931 BLBS R0,50\$ LBS means successful read.  
 0882 1932 HIR\_ERROR - Signal HIR error.  
 0882 1933 step=3, func=ONLINE, -  
 0882 1934 type=READ  
 FF59 31 088A 1935 BRW STEP18 ; Goto deallocate and set RCT\_FAILURE  
 088D 1936 ; status code before returning.  
 50 0024'CF D0 088D 1937 50\$: MOVL HIRTS\$PAGEOPTR,R0 ; Again, R0 => sector 0 contents.  
 0892 1938 BICW #HIRTS\$FE- ; Initialize incore bits.  
 AA 0892 1940 #HIRTS\$MATCH-  
 0893 1941 #HIRTS\$EMPTYTYPE-  
 0893 1942 #HIRTS\$RESCAN-  
 0893 1943 #HIRTS\$RCTFULL,-  
 0893 1944 HIRTS\$STS  
 000E'CF 007C BF 0893 1945  
 0899 1946 BBC #RCT\$V\_FE,- ; Branch if no forced error.  
 07 E1 0899 1947

05 08 A0 089B 1948 RCTSW\_FLAGS(R0),60\$  
 000E'CF 04 A8 089E 1949 S^#HIRTS\_M\_FE,HIRTSW\_STS ; Set incore forec error bit.  
 03 08 A0 08A3 1950 60\$: BBC #RCTSV\_RP1,-  
 FB50 31 E1 08A3 1951 RCTSW\_FLAGS(R0),70\$ ; See if NOT in phase 1.  
 04 08 A0 08AB 1952 BRW STEP7 ; Branch into step 7 to continue.  
 04 08 A0 08AB 1953 70\$: BBS #RCTSV\_RP2,-  
 08AD 1956 RCTSW\_FLAGS(R0),75\$ ; Sanity check.  
 08B0 1957 BUG\_CHECK DISKCLASS,FATAL  
 10 A0 08B4 1958 75\$: MOVL RCTSL\_RBN(R0),-  
 0058'CF D0 08B4 1959 HIRTS\_C\_RBN ; Remember RBN that we had selected.  
 08B7 1960  
 08BA 1961 BBC #RCTSV\_BR,-  
 08BA 1962 RCTSW\_FLAGS(R0),80\$ ; See if we had had bad RBN.  
 08BC 1963 BISW S^#HIRTS\_M\_MATCH, - ; Clear means no.  
 000E'CF 08 A8 08BF 1964 HIRTSW\_STS ; We set equivalent bit in core.  
 14 A0 08C4 1965 MOVL RCTSL\_BAD\_RBN(R0),-  
 005C'CF D0 08C4 1966 HIRTS\_C\_MATCHRBN ; Copy the old bad RBN.  
 08CA 1967  
 08CA 1968 80\$: ; Here figure out whether this is prime RBN.  
 08CA 1969  
 08CA 1970  
 08CA 1971  
 0309 30 08CA 1972 BSBW HASH\_LBN : Hash HIRTS\_LBN to produce values  
 51 0068'CF 02 C3 08CD 1973 08CD 1973 for HIRTS\_L\_RCTBLOCK and HIRTS\_L\_OFFSET.  
 51 51 07 78 08D3 1974 SUBL3 #2,HIRTS\_L\_RCTBLOCK,R1 ; Subtract out RCT sectors 0 and 1.  
 08D7 1975 ASHL #7,R1,R1 ; R1 = relative block containing prime  
 51 006C'CF C0 08D7 1977 ADDL HIRTS\_L\_OFFSET,R1 ; RBN descriptor \* 128.  
 0058'CF 51 D1 08DC 1978 CMPL R1\_HIRTS\_L\_RBN ; R1 = prime RBN.  
 05 13 08E1 1979 BEQL 90\$ ; See if this the one.  
 10 A8 08E3 1980 BISW #HIRTS\_M\_EMPTYPE,- ; EQL implies yes.  
 000E'CF 08E5 1981 HIRTSW\_STS ; Set bit meaning NOT prime RBN.  
 08E8 1982 90\$: ; Here read sector containing allocatable RBN into page 2.  
 08E8 1983  
 08E8 1984  
 08E8 1985 ASHL #-7,HIRTS\_L\_RBN,R1 ; R1 = relative RCT block containing  
 51 02 C0 08EF 1986 08EF 1987 this RBN descriptor.  
 50 02 D0 08F2 1988 ADDL #2,R1 ; Add in sectors 0 and 1.  
 00CB 30 08F5 1990 MOVL #2,RO ; Read into page 2.  
 OB 50 E8 08F8 1991 BSBW READ\_RCT\_BLOCK ; Go read RCT sector.  
 08FB 1992 BLBS RO,100\$ ; Branch on success.  
 08FB 1993 HIR\_ERROR - ; Signal HIR error.  
 08FB 1994 step=4, func=ONLINE, -  
 08FB 1995 type=READ  
 FEE0 31 0903 1996 BRW STEP18 ; Goto deallocate and set RCT\_FAILURE  
 0906 1997 0906 1998 100\$: status code before returning.  
 FC59 31 0906 1999 BRW STEP11

0909 2001 .SBTTL WRITE\_RCT\_BLOCK - Write an RCT sector  
 0909 2002  
 0909 2003 :+ WRITE\_RCT\_BLOCK - internal subroutine to write a block to a particular  
 0909 2004 relative sector in each RCT copy.  
 0909 2005  
 0909 2006  
 0909 2007  
 0909 2008  
 0909 2009  
 0909 2010  
 0909 2011  
 0909 2012  
 0909 2013  
 0909 2014  
 0909 2015  
 0909 2016  
 0909 2017  
 0909 2018  
 0909 2019  
 0909 2020  
 0909 2021  
 0909 2022  
 0909 2023  
 0909 2024  
 0909 2025  
 0909 2026  
 0909 2027  
 0909 2028  
 0909 2029  
 0909 2030  
 0909 2031  
 0909 2032  
 0909 2033  
 0909 2034 WRITE\_RCT\_BLOCK:  
 0909 2035  
 0909 2036 HIRT\_SUBSAVE : Save return point in SUBSTACK.  
 0913 2037 MOVW R0,HIRTSW\_PAGENO : Save input argument as to which page.  
 0918 2038 MOVW HIRTSW\_PG0CNTNT[R0],- : Also save input argument as to which  
 0920 2039 HIRTSW\_SECTORNO sector (page) to write.  
 0920 2040 MOVW #SSS BADRCT,HIRTSW\_IOST : Initialize combined status word.  
 0927 2041 CLRL HIRTSL\_LOOPCNT : Initialize loop counter. Note loop  
 092B 2042 counter is longword even though we  
 092B 2043 only use one byte since we MULL2  
 092B 2044 with the counter in BUILD RCT PACKET.  
 092B 2045 BBS #UCBSV\_MSCP\_WRTP, - : If disk is software write protected  
 0930 2046 UCBSW\_DEVSTS(R3), 46\$ : branch around and reject.  
 0930 2047 20\$: BICW #HIRTSW\_RCTFE,- : Initialize flag each time thru loop.  
 0930 2048 HIRTSW\_STS  
 0934 2049 CMPB HIRTSL\_LOOPCNT,- : See if we are all done with all  
 0937 2050 UCBSB\_BU\_RCTCPYS(R3) RCT copies.  
 0938 2051 BLSSU 30\$ : LSSU implies NOT done.  
 093E 2052 BRB 70\$ : If done, branch around.  
 0940 2053 30\$: MOVZWL HIRTSW\_PAGENO,R0 : R0 contains which page to map.  
 0942 2054 BSBW MAP\_PAGE : Map page selected by R0.  
 094A 2057

		094A 2058	: Recycle the current END PACKET, the current RSPID and then prepare
		094A 2059	the MSCP packet to write page into the next RCT copy at relative
		094A 2060	sector of this copy. All this is accomplished by BUILD_RCT_PACKET.
		094A 2061	
0108	30	094A 2062	BSBW BUILD_RCT_PACKET : Routine fills most MSCP fields.
		094D 2063	: Returns R2 => MSCP packet.
22	90	094D 2064	MOVB #MSCPSK_OP_WRITE,- : Copy the WRITE opcode.
08 A2		094F 2065	MSCPSB_OPCODE(R2)
4000 8F	B0	0951 2066	MOVW #MSCPSM_MD_COMP,-
0A A2		0955 2067	MSCPSW_MODIFIER(R2) : Move in compare modifier to get a
		0957 2068	write compare operation.
000E'CF	08	E1 0957 2069	BBC S^#HIRTSV_RCTFE, - : Bit clear says write WITHOUT force
06		095C 2070	HIRTSW_STS,40S : error.
1000 8F	A8	095D 2071	BISW #MSCPSM_MD_ERROR,- : Set force error modifier.
0A A2		0961 2072	MSCPSW_MODIFIER(R2)
		0963 2073	40\$: SEND MSCP_MSG : Send message to the MSCP server.
		0963 2074	UNMAP : Unmap page.
2C A5	D4	0966 2075	CLRL CDRPSL_LBUFH_AD(R5) : Indicate no mapping resources
		096C 2076	currently allocated.
52 1C A5	D0	096C 2077	MOVL CDRPSL_MSG_BUF(R5),R2 : Refresh R2 => End message.
		0970 2078	
07 09 A2	05	E1 0970 2080	BBC #MSCPSV_EF_ERLOG,- : Test for error log message generated
0080 8F	A8	0972 2081	MSCPSB_FLAGS(R2),45\$ : and branch around if not.
000E'CF		0975 2082	BISW #HIRTSM_ERLOGIP,- : Else remember that error log messages
		0979 2083	HIRTSW_STS : Have been generated.
		097C 2084	45\$: : See if write succeeded and if so set HIRTSW_IOST to success; otherwise
		097C 2085	do nothing. In this way if one or more writes succeed, HIRTSW_IOST
		097C 2086	: will have a success indication.
		097C 2087	
		097C 2088	
000E'CF	08	E0 097C 2089	BBS S^#HIRTSV_RCTFE, - : Branch around status update if
24		0981 2090	HIRTSW_STS,60S we had force error.
		0982 2091	IF_MSCP_SUCCESS, then=50\$, - : Branch if request was successful,
		0982 2092	status=R0 leaving MSCP status in R0.
50	06	B1 098A 2093	CMPW #MSCPSK_ST_WRTPR, R0 : Check for write protected.
09	12	098D 2094	BNEQ 48\$ : If NOT, some other error.
		098F 2095	
0008'CF	025C 8F	B0 098F 2096	46\$: MOVW #SSS_WRITLCK, HIRTSW_IOST : Indicate why we couldn't write.
14	11	0996 2097	BRB 70\$ : And branch around.
		0998 2098	
0100 8F	A8	0998 2100	48\$: BISW #HIRTSM_RCTFE,- : Set force error flag and
000E'CF		099C 2101	HIRTSW_STS : branch back to rewrite it.
A1	11	099F 2102	BRB 30\$
		09A1 2103	
0008'CF	01	B0 09A1 2104	50\$: MOVW S^#SSS_NORMAL,- : If success, remember it in static
		09A3 2105	HIRTSW_IOST field.
0010'CF	D6	09A6 2106	60\$: INCL HIRTSL_LOOPCNT : Increment loop counter.
84	11	09AA 2107	BRB 20\$ : And branch back to do next copy.
		09AC 2108	
		09AC 2109	
50 0008'CF	3C	09AC 2110	70\$: MOVZWL HIRTSW_IOST, R0 : Here after we finish all RCT copies.
05 50	E8	09AC 2111	BLBS R0, 75\$ : Return status to caller.
000A'CF	50	B0 09B1 2112	MOVW R0, HIRTSW_IOWORST : Branch if successful.
		09B4 2113	
		09B9 2114	75\$: HIRTSUBRETURN : Else, save "worst" error.

09C3 2116 .SBTTL READ\_RCT\_BLOCK - Read an RCT sector  
 09C3 2117  
 09C3 2118 :+  
 09C3 2119 : READ\_RCT\_BLOCK - internal routine to read contents of a relative sector of  
 09C3 2120 : the RCT.  
 09C3 2121 :  
 09C3 2122 : INPUTS:  
 09C3 2123 : R0 = page number of page into which we read the sector  
 09C3 2124 : R1 = relative sector number to read  
 09C3 2125 : R3 => UCB  
 09C3 2126 : R5 => CDRP  
 09C3 2127 : CDRPSL\_MSG\_BUF contains an END PACKET to recycle  
 09C3 2128 : CDRPSL\_RSPID contains an RSPID to recycle  
 09C3 2129 :  
 09C3 2130 : OUTPUTS:  
 09C3 2131 : R0 - LBS indicates we were successful in the block from one of the  
 09C3 2132 : RCT copies.  
 09C3 2133 : R0 - LBC indicates failure in reading from all RCT copies.  
 09C3 2134 :  
 09C3 2135 : SIDE EFFECTS:  
 09C3 2136 : We use HIRTSW\_IOST to temporarily save the status to be returned  
 09C3 2137 : to out caller.  
 09C3 2138 :  
 09C3 2139 : NOTE:  
 09C3 2140 : Since this subroutine is one of those that calls SCS routines which  
 09C3 2141 : may fork, and since we may not leave anything permanent on the stack,  
 09C3 2142 : the caller's return point is popped off the stack and pushed onto  
 09C3 2143 : the HIRT SUBSTACK via use of the HIRT\_SUBSAVE macro. Return to the  
 09C3 2144 : caller is effected by use of the HIRT\_SUBRETURN macro.  
 09C3 2145 :  
 09C3 2146 :  
 09C3 2147 READ\_RCT\_BLOCK:  
 09C3 2148  
 0056'CF 50 B0 09CD 2150 HIRT\_SUBSAVE ; Save return point in SUBSTACK.  
 0054'CF 51 B0 09D2 2151 MOVW R0,HIRTSW\_PAGENO ; Save input argument as to which page.  
 09D7 2152 MOVW R1,HIRTSW\_SECTORNO ; Also save input argument as to which  
 004C'CF40 01 AE 09D7 2153 MNEGW #1,HIRTSW\_PGOCNTNT[R0] ; sector to write.  
 0010'CF D4 09DD 2154 CLRL HIRTSL\_LOOPCNT ; Invalidate page(R0) contents.  
 09E1 2155 20\$: CMPB HIRTSL\_LOOPCNT,- ; Initialize loop counter.  
 0010'CF 91 09E1 2156 UCBSB\_BU\_RCTCPYS(R3) ; See if we are all done with all  
 0000'C3 09E5 2157 BLSSU 30\$ ; RCT copies.  
 09 1F 09E8 2158 ; LSSU implies NOT done.  
 J9EA 2159  
 0008'CF 216C 8F B0 09EA 2160 MOVW #SSS\_BADRCT,HIRTSW\_IOST ; Pass failure to our caller.  
 4B 11 09F1 2161 BRB 50\$ ; If done, branch around.  
 09FB 2162 30\$: MOVZWL HIRTSW\_PAGENO,RO ; R0 contains which page to map.  
 0056'CF 3C 09F3 2163 BSBW MAP\_PAGE ; Map page selected by R0.  
 00B0 30 09F8 2164  
 09FB 2165  
 09FB 2166 : Recycle the current END PACKET, the current RSPID and then prepare  
 09FB 2167 : the MSCP packet to read page from the next RCT copy at relative  
 09FB 2168 : sector of this copy. All this is accomplished by BUILD\_RCT\_PACKET.  
 09FB 2169 BSBB BUILD\_RCT\_PACKET ; Routine fills in most of MSCP packet.  
 58 10 09FB 2170 09FD 2171 ; Returns R2 => MSCP packet.  
 21 90 09FD 2172 MOVB #MSCPSK\_OP\_READ,- ; Copy the READ opcode since this field

08 A2	09FF	2173					
4000 8F	B0	0A01	2174	MOVW	#MSCPSB_OPCODE(R2)	;	is not filled in by BUILD_RCT_PACKET.
0A A2		0A05	2175		MSCPSM_MD COMP -		Move in compare modifier to get a
		0A07	2176		MSCPSW_MODIFIER(R2)		compare operation.
		0A07	2177	SEND	MSCP_MSG	;	Send message to the MSCP server.
		0A0A	2178	UNMAP		;	Unmap page.
2C A5	D4	0A0D	2179	CLRL	CDRPSL_LBUFH_AD(R5)	;	Indicate no mapping resources
		0A10	2180				currently allocated.
52 1C A5	D0	0A10	2181	MOVL	CDRPSL_MSG_BUFR(R5),R2	;	Refresh R2 => End message.
		0A14	2182				
07 09 05	E1	0A14	2183	BBC	#MSCPSV_EF_ERLOG,-	;	Test for error log message generated
07 09 A2		0A16	2184		MSCPSB_FLAGS(R2),35\$	;	and branch around if not.
0080 8F	A8	0A19	2185	BISW	#HIRTSW_ERLOGIP,-	;	Else remember that error log messages
000E'CF		0A1D	2186		HIRTSW_STS		Have been generated.
		0A20	2187	35\$:			
		0A20	2188				
		0A20	2189	:	See if read succeeded and if so we now have a valid copy of the sector so we		
		0A20	2190	:	simply continue. If we did not succeed we bump the loop counter and		
		0A20	2191	:	go back to try and read the sector from the next (if any) RCT copy.		
		0A20	2192				
0010'CF	D6	0A26	2193	IF MSCP SUCCESS, then=40\$		;	Branch if request was successful.
B5	11	0A2A	2194	INCL	HIRTSW_LOOPCNT	;	Increment loop counter.
		0A2C	2195	BRB	20\$	;	And branch back to try next copy.
		0A2C	2196				
50 0056'CF	3C	0A2C	2197	40\$:			Here after we finish all RCT copies.
0054'CF	B0	0A31	2198	MOVZWL	HIRTSW_PAGENO,RO	;	R0 = page number into which we read.
004C'CF40		0A35	2199	MOVW	HIRTSW_SECTORNO,-	;	Update contents of this page by
0008'CF 01	B0	0A39	2200		HIRTSW_PGOCNTNT[RO]	;	remembering sector therein contained.
		0A3E	2201	MOVW	S^\$\$\$NORMAL,HIRTSW_IOST	;	Indicate success.
50 0008'CF	3C	0A3E	2202	50\$:			
05 50	E8	0A43	2203	MOVZWL	HIRTSW_IOST,RO	;	Return status to caller.
000A'CF 50	B0	0A46	2204	BLBS	RO, 55\$	;	Branch if successful.
		0A4B	2205	MOVW	RO, HIRTSW_IOWORST	;	Else, save "worst" error.
			2206	HIRT_SUBRETURN			Return to caller.

D 16

```

0A55 2208 :SBTTL BUILD_RCT_PACKET - Recycle an MSCP end message
0A55 2209 :SBTTL FILL_RCT_PACKET - Prepare an MSCP packet for an RCT transfer
0A55 2210
0A55 2211 :+
0A55 2212 :+ BUILD_RCT_PACKET - internal subroutine to recycle the current END PACKET
0A55 2213 :+ and then to fall thru to
0A55 2214 :
0A55 2215 :+ FILL_RCT_PACKET - which prepares an MSCP packet to do an I/O transfer
0A55 2216 :+ to or from the RCT.
0A55 2217 :
0A55 2218 :+ INPUTS:
0A55 2219 :+ R3 => UCB
0A55 2220 :+ R5 => CDRP
0A55 2221 :+ CDRPSL_RSPID contains a RSPID to re-cycle
0A55 2222 :+ CDRPSL_MSG_BUF address of MSCP buffer to re-cycle or 0 (zero)
0A55 2223 :+ 0 (zero) means that we must here allocate an MSCP buffer
0A55 2224 :+ CDRPSL_BUFHNDL contains 96 bit buffer handle
0A55 2225 :+ UCBSL_ABCNT contains which RCT copy we are accessing
0A55 2226 :+ HIRTSQ_SECTORNO contains which relative sector number in the RCT copy
0A55 2227 :
0A55 2228 :+ OUTPUTS:
0A55 2229 :+ R2 => MSCP PACKET
0A55 2230 :+ Registers R0 and R1 are modified
0A55 2231 :
0A55 2232 :
0A55 2233 :
0A55 2234 :
0A55 2235 :
0A55 2236 :
0A55 2237 :
0A55 2238 :
0A55 2239 :
0A55 2240 :
0A55 2241 :
0A55 2242 :
0A55 2243 :
0A55 2244 BUILD_RCT_PACKET:
0A55 2245 :
0A55 2246 : HIRT_SUBSAVE ; Save return point on HIRT SUBSTACK.
0A5F 2247 :
0A5F 2248 : ASSUME MSCPSL_CMD_REF EQ 0
0A5F 2249 : TSTL CDRPSL_MSG_BUF(R5) ; See if we need a Message Buffer.
0A62 2250 : BEQL 20$ ; EQL means Buffer needed.
0A64 2251 :
0A64 2252 : RECYCH_MSG_BUF ; Else Recycle END PACKET into MSCP buffer.
0A67 2253 : BLBS R0,30$ ; LBS means allocation success.
0A6A 2254 10$: BRW REPLACE_CONNECT_FAILURE ; Allocation failure means CONNECTION
0A6D 2255 : failure.
0A6D 2256 20$: :
0A6D 2257 : ALLOC_MSG_BUF ; Allocate a Message Buffer.
0A70 2258 : BLBC R0,10$ ; LBC means allocation failure.
0A73 2259 30$: HIRT_SUBUNSAVE ; Restore caller's return point.
0A73 2260 :
0A7C 2261 :
0A7C 2262 FILL_RCT_PACKET: ; Alternate entry that only fills in packet.
0A7C 2263 :
0A7C 2264 INIT_MSCP_MSG ucb=(R3) ; Initialize MSCP command packet.

```

0C A2 0200 BF	3C 0A7F 2265	MOVZWL #512, - MSCP\$L_BYTE(CNT(R2))	; Setup transfer byte count.
30 A5 7D	0A85 2266	MOVQ CDRP\$T-LBUFHNDL(R5),-	; Copy 96 bit buffer handle.
10 A2	0A85 2267	MSCPSB_BUFFER(R2)	"
38 A5 D0	0A88 2268	MOVL CDRP\$T-LBUFHNDL+8(R5),-	"
18 A2	0A8A 2269	MSCPSB_BUFFER+8(R2)	"
	0A8D 2270		
	0A8F 2271		
	0A8F 2272	: Calculate LBN of relative sector for this RCT copy.	
	0A8F 2273	: It is done by multiplying the number of RCT copies already written,	
	0A8F 2274	: (contained in HIRT\$L_LOOPCNT) by the size of an RCT copy (contained in	
	0A8F 2275	: UCBSW DU RCTSIZEx), adding in the LBN of the base of the first RCT copy	
	0A8F 2276	: (UCBS\$C_D0_USIZE) and then adding in the relative sector number	
	0A8F 2277	: passed to us when we were called (HIRT\$W_SECTORNO).	
	0A8F 2278		
50 0000'C3	3C 0A8F 2279	MOVZWL UCBSW DU RCTSIZEx(R3),R0	; R0 contains size of one RCT copy.
50 0010'CF	C4 0A94 2280	MULL2 HIRT\$C_LDOPCNT,R0	; R0 contains COPY# * COPIYSIZE.
50 0000'C3	C0 0A99 2281	ADDL UCBSL DU USIZE(R3),R0	; R0 contains LBN of base of this copy.
51 0054'CF	3C 0A9E 2282	MOVZWL HIRT\$W_SECTORNO,R1	; R1 contains input relative sector #.
50 51	C0 0AA3 2283	ADDL R1,R0	; R0 contains LBN.
1C A2 50	D0 0AA6 2284	MOVL R0,MSCP\$L_LBN(R2)	; Move LBN to MSCP packet.
	0AAA 2285		
	05 0AAA 2286	RSB	; Return to caller.

0AAB 2288 .SBTTL MAP\_PAGE - Map a page for a transfer  
0AAB 2289  
0AAB 2290 :+  
0AAB 2291 : MAP\_PAGE - internal subroutine to map the page selected by R0.  
0AAB 2292  
0AAB 2293 : INPUTS:  
0AAB 2294 : R0 contains the number of the page to map.  
0AAB 2295 : R5 => CDRP  
0AAB 2296  
0AAB 2297 : OUTPUTS:  
0AAB 2298 : CDRPSL\_SVAPTE, CDRPSW\_BOFF, CDRPSL\_BCNT and set to page parameters.  
0AAB 2299  
0AAB 2300 : CDRPSL\_LBUFH\_AD set to => CDRP\$T\_LBUFHNDL  
0AAB 2301  
0AAB 2302 : Mapping resources allocated.  
0AAB 2303  
0AAB 2304 : MAP\_PAGE:  
CC A5 0034'CF40 D0 0A85 2305 HIRT\_SUBSAVE : Save caller's return point on SUBSTACK.  
DO A5 0044'CF40 B0 0ABC 2306 MOVL HIRT\$L\_SVAPTE0[R0],- : Copy mapping date for relative page  
0ABC 2307 CDRPSL\_SVAPTE(R5) : to CDRP.  
D2 A5 0200 8F 3C 0AC3 2308 MOVW HIRT\$W\_BOFF0[R0],- : Copy BOFF as well as SVAPTE.  
0AC3 2309 CDRPSW\_BOFF(R5)  
30 A5 9E 0AC9 2310 MOVZWL #512,CDRPSL\_BCNT(R5) : Finally copy BCNT for page.  
2C A5 0ACC 2311 MOVAB CDRP\$T\_LBUFHNDL(R5),- : Point CDRP field to local buffer  
0ACE 2312 CDRPSL\_LBUFH\_AD(R5) : handle field.  
0AD1 2313 MAP\_IRP : Map page.  
0AD1 2314 HIRT\_SUBRETURN : Return to caller.

OADB 2318 .SBTTL SEARCH\_RCT - Locate an available RBN  
 OADB 2319  
 OADB 2320 :+  
 OADB 2321 : SEARCH\_RCT - internal subroutine to search the RCT for an available RBN  
 OADB 2322 to allocate for the current failing LBN. This routine is called from  
 OADB 2323 STEP9 of the replacement algorithm and is only done here as an  
 OADB 2324 internal subroutine to simplify the reading of that algorithm.  
 OADB 2325  
 OADB 2326 INPUTS:  
 OADB 2327 R3 => UCB  
 OADB 2328 R5 => CDRP  
 OADB 2329 HIRT\$L\_LBN LBN that is failing  
 OADB 2330 UCBSW\_DU\_LBNPTRK number of LBNs on a track of this unit  
 OADB 2331 UCBSB\_DU\_RBNPTRK number of RBNs on a track of this unit  
 OADB 2332  
 OADB 2333 OUTPUTS:  
 OADB 2334 R0 = SSS NORMAL then:  
 OADB 2335 HIRT\$L\_RBN - new RBN selected to replace the failing LBN  
 OADB 2336 and HIRT\$V\_EMPTYPE clear means this is a primary RBN, else  
 OADB 2337 secondary RBN.  
 OADB 2338  
 OADB 2339 If HIRT\$V\_MATCH set this implies that the LBN which failed  
 OADB 2340 had previously been replaced by an RBN which in  
 OADB 2341 turn has failed. This failing RBN is in  
 OADB 2342 HIRT\$L\_MATCHRBN.  
 OADB 2343  
 OADB 2344 R0 = 0 then we could not find an allocatable RBN and HIRT\$L\_RBN is  
 OADB 2345 not valid. The cause of the failure to find an RBN is  
 OADB 2346 transmitted to the caller by:  
 OADB 2347  
 OADB 2348 HIRT\$V\_RCTFULL set implies that the RCT on the disk  
 OADB 2349 is full  
 OADB 2350 HIRT\$V\_RCTFULL clear implies we had a read error on  
 OADB 2351 some RCT sector.  
 OADB 2352  
 OADB 2353  
 OADB 2354 SEARCH\_RCT:  
 OADB 2355  
 OADB 2356 HIRT\_SUBSAVE ; Save return on HIRT substack.  
 OAE5 2357  
 00EE 30 OAE5 2358 BSBW HASH\_LBN ; Hash LBN value in HIRT\$L\_LBN returning  
 OAE5 2359 ; HIRT\$L\_RCTBLOCK and HIRT\$L\_OFFSET.  
 0068'CF DO OAE8 2360 MOVL HIRT\$L\_RCTBLOCK,- ; And remember the starting sector  
 0064'CF OAE8 2361 OAEF HIRT\$L\_STARTBLK ; number in static storage.  
 OAE8 2362  
 OAE8 2363  
 OAEF 2364 ; Here we initialize a few bits.  
 OAEF 2365  
 AA OAEF 2366 BICW #HIRT\$M\_MATCH- ; Initialize the following flags.  
 OAF0 2367 !HIRT\$M\_EMPTYPE- ; Match set implies valid MATCHRBN,  
 OAF0 2368 !HIRT\$M\_RESCAN- ; EMPTYPE set implies secondary RBN,  
 OAF0 2369 !HIRT\$M\_RCTFULL,- ; Rescan implies reached Nulls,  
 OAF0 2370 HIRT\$W\_STS ; and RCTFULL means the RCT is full.  
 OAF6 2371  
 OAF6 2372 ; Here we prepare to read the RCT sector containing the primary RBN descriptor.  
 OAF6 2373  
 50 02 DO OAF6 2374 MOVL #2,R0 ; Prepare to read into page #2.

```

51 0068'CF D0 0AF9 2375      MOVL HIRTSR_RCTBLOCK,R1 ; And we read this relative sector #.
FEC2 30 0AFE 2376      BSBW READ_RCT_BLOCK
77 50 E9 0B01 2377      BLBC R0,SEARCH_RTN ; Subroutine does read.
                                ; LBC implies read failure.

                                ; Here we scan the RCT sector containing the primary RBN descriptor. The
                                ; method of scanning is to scan outward from the primary RBN descriptor.

52 D4 0B04 2382 10$: CLRL R2 ; Set up delta.
                                ; R1 = next entry to test in first RCT
                                ; sector to scan.

51 006C'CF 52 C1 0B06 2383 ADDL3 R2,HIRTSR_OFFSET,R1 ; LSS implies invalid offset into page.
0F 19 0B0C 2384 20$: BLSS 40$ ; See if we are within sector page.
                                ; GTR implies no, out of bounds, go
                                ; to increment delta.

0000007F BF 51 D1 0B0E 2385 CMPL R1,#127 ; If in bounds, go test RCT entry.
06 14 0B15 2386 30$: BGTR 40$ ; LBS implies success.

006B 30 0B17 2389 BSBW TEST_RCT_ENTRY
5E 50 E8 0B1A 2393 BLBS R0,SEARCH_RTN ; Negate delta.
                                ; Branch to try again if negative.

52 52 CE 0B1D 2395 MNEGL R2,R2
E4 19 0B20 2396 BLSS 20$ ; Else increment delta.
52 D6 0B22 2397 INCL R2
00000080 BF 52 D1 0B24 2398 CMPL R2,#128 ; See if delta too big.
D9 19 0B2B 2399 BLSS 20$ ; LSS implies not too big.
                                ; Else we fall thru to try next sector.

0068'CF D6 0B2D 2401 NEXT: INCL HIRTSR_RCTBLOCK ; Increment RCT sector to scan.

0068'CF D1 0B31 2402 10$: CMPL HIRTSR_RCTBLOCK,- ; See if we are all done with search.
0064'CF 38 13 0B35 2404 HIRTSR_STARTBLK
                                ; EQL means that we are finished.

51 50 02 D0 0B3A 2408 MOVL #2,R0 ; Prepare to read into page 2.
0068'CF D0 0B3D 2409 MOVL HIRTSR_RCTBLOCK,R1 ; And to read this sector.
FE7E 30 0B42 2410 BSBW READ_RCT_BLOCK
33 50 E9 0B45 2411 BLBC R0,SEARCH_RTN ; Go to read sector into page.
                                ; LBC implies read failure

OF 002C'DF 1F E1 0B48 2413 BBC #RCTSV_NULL,- ; Before linear scan of this sector,
0068'CF 02 D0 0B4A 2414 @HIRTSR_PAGE2PTR,20$ see if we are beyond RCT.
000E'CF 05 E3 0B53 2415 MOVL #2,HIRTSR_RCTBLOCK ; Here beyond RCT. Wrap to start and
D8 0B58 2416 BBCS S^#HRTSV_RESCAN, - go back to search some more after
                                ; setting bit that says we have wrapped.
0B59 2417 HIRTSR_ST5,10$ BUG_CHECK DISKCLASS,FATAL ; Impossible situation.

52 D4 0B5D 2419 20$: CLRL R2 ; Clear loop index register.

51 52 D0 0B5F 2422 30$: MOVL R2,R1 ; Pass RCT entry of interest to routine.
0020 30 0B62 2423 BSBW TEST_RCT_ENTRY ; Call subroutine to test entry.
13 50 E8 0B65 2424 BLBS R0,SEARCH_RTN ; LBS means we have the RBN, go from loop.
EF 52 00000080 BF F2 0B68 2425 AOBLSR #128,R2,30$ ; If we return here, (entry not avail.)
                                ; then loop back after incrementing R2.

BB 11 0B70 2427 BRB NEXT ; If we fall thru, goto NEXT sector.

0040 50 D4 0B72 2429 SEARCH_FAIL: CLRL R0 ; Indicate failure to caller and
A8 0B74 2430 BISW #HRTSM_RCTFULL,- indicate reason for failure.

```

DUHIRT  
V04-000

I 16  
HOST INITIATED REPLACEMENT FOR THE DISK 16-SEP-1984 00:58:58 VAX/VMS Macro V04-00  
SEARCH\_RCT - Locate an available RBN 5-SEP-1984 00:13:32 [DRIVER.SRC]DUHIRT.MAR;1

Page 53  
(21)

000E'CF 0B78 2432 HIRTSW\_STS  
0B7B 2433 SEARCH\_RTN:  
0B7B 2434 HIRT\_SUBRETURN

; Return to caller.

	0B85	2436	.SBTTL TEST_RCT_ENTRY - Test for allocated RBN					
	0B85	2437						
	0B85	2438	;+ TEST_RCT_ENTRY - internal subroutine called to test an RCT entry to see if it represents an allocatable RBN or if it is already allocated.					
	0B85	2439						
	0B85	2440						
	0B85	2441						
	0B85	2442	INPUTS:					
	0B85	2443	R1 = index of RCT entry.					
	0B85	2444						
	0B85	2445	OUTPUTS:					
	0B85	2446	R0 = success code.					
	0B85	2447	= SSS NORMAL then HIRTS <sub>L</sub> _RBN is set to the RBN associated with the RCT entry defined by HIRTS <sub>L</sub> _RCTBLOCK and R1 (entry index).					
	0B85	2448						
	0B85	2449						
	0B85	2450	= 0 implies that the entry is not allocatable. In addition if the RBN is currently allocated and if it is allocated to this LBN (i.e. to HIRTS <sub>L</sub> _LBN), then HIRTS <sub>V</sub> _MATCH is set in HIRTS <sub>W</sub> _STS and the RBN associated with the current entry is stored in HIRTS <sub>L</sub> _MATCHRBN.					
	0B85	2451						
	0B85	2452						
	0B85	2453						
	0B85	2454						
	0B85	2455	:					
	0B85	2456						
	0B85	2457						
	0B85	2458	TEST_RCT_ENTRY:					
50	0068'CF	52	DD	0B85	2459	PUSHL R2	; Save register.	
50	50	02	C3	0B87	2460	SUBL3 #2,HIRTS <sub>L</sub> _RCTBLOCK,R0	; R0 = found sector without bias of 2.	
50	50	07	78	0B8D	2461	ASHL #7,R0,R0	; Multiply by 128.	
50	51	C0	OB91	0B94	2462	ADDL R1,R0	; R0 = RBN associated with this entry.	
52	002C'CF	D0	OB94	0B94	2463			
6241	D5	OB99	2464	MOVL HIRTS <sub>L</sub> _PAGE2PTR,R2	; R2 => page 2, which contains sector.			
0A	12	OB9C	2465	TSTL (R2)[RT]	; Test contents of current entry.			
0058'CF	50	DO	OB9E	BNEQ 10\$	; NEQ implies that it is not available.			
50	01	3C	OBA3	MOVL R0,HIRTS <sub>L</sub> _RBN	; Save RBN of this entry in HIRT.			
2A	11	OBA6	2468	MOVZWL #SSS_NORMAL,R0	; Set success code.			
		OBA8	2469	BRB 40\$	; And branch to return to caller.			
52	6241	DE	OBAB	2470 10\$:				
10	A8	OBAC	2471	MOVAL (R2)[R1],R2	; R2 => entry of interest.			
000E'CF	OBAE	2472		BISW #HIRTS <sub>M</sub> _EMPTYTYPE,-	; Set bit meaning any find will now			
1B 62	1D	E1	OBBI	HIRTS <sub>W</sub> _STS	; have to be a secondary RBN.			
		OBBS	2474	BBC #RCTSV_ALLOCATED,(R2),30\$	; If clear, then unusable RBN.			
52	62	EF	OBBS	EXTZV #RCTSV_LBN,-	; If allocated, see if for this LBN.			
0018'CF	52	D1	OBBA	#RCTSS_LBN,(R2),R2	; R2 = LBN for this RBN.			
000E'CF	OF	12	OBBF	CMPL R2,HIRTS <sub>L</sub> _LBN	; See if this LBN.			
03	E3	OBBC1	2478	BNEQ 30\$	; NEQ means not for this LBN.			
04		OBBC6	2480	BBCS S^#HIRTS <sub>V</sub> _MATCH,-	; Set bit that means we have a match.			
		OBBC7	2481	HIRTS <sub>W</sub> _STS,20\$				
		OBBC7	2482	BUG_CHECK DISKCLASS,FATAL	; Impossible situation.			
005C'CF	50	DO	OBBCB	2483 20\$:	MOVW R0,HIRTS <sub>L</sub> _MATCHRBN	; Save RBN that matched.		
		OBBD0	2484	30\$:	CLRL R0	; Failure to find allocatable RBN.		
50	D4	OBBD0	2485		POPL R2	; Restore register.		
52	8ED0	OBBD2	2486	40\$:	RSB	; Return to caller.		
	05	OBBD5	2488					
		OBBD5	2489					

				.SBTTL HASH_LBN - Hash an LBN into a RCT block and an offset
				HASH_LBN - internal routine to hash HIRTS <sub>L</sub> _LBN giving HIRTS <sub>L</sub> _RCTBLOCK and HIRTS <sub>L</sub> _OFFSET.
				INPUTS:
				R3 => UCB HIRTS <sub>L</sub> _LBN
				OUTPUTS:
				HIRTS <sub>L</sub> _RCTBLOCK = RCT sector containing prime RBN descriptor for this LBN HIRTS <sub>L</sub> _OFFSET = offset of prime RBN descriptor in sector.
				SIDE EFFECTS:
				Registers R0 an R1 altered.
				HASH_LBN:
51	50 0000'C3 0018'CF 50	3C C7	OBDB OBE1	MOVZWL UCB\$W_DU_LBNPTRK(R3),R0 ; R0 contains LBNs per track. DIVL3 R0,HIRTS <sub>L</sub> _LBN,P1 ; R1 = QUO(LBN/(LBNs per track)).
	50 0000'C3 51	9A C4	OBE1 OBE6	MOVZBL UCB\$B_DU_RBNPTRK(R3),R0 ; R0 = RBNs per track. MULL R1,R0 ; R0 = (RBNs per)*QUO(LBN/(LBNs per))
	51	D4	OBE9	CLRL R1 ; Clear high order part of dividend.
	50 00000080 8F	7B	OBEB	EDIV #128,R0,-
	006C'CF 0068'CF	OBF2	OBF2	HIRTS <sub>L</sub> _RCTBLOCK,-
	0068'CF 02	C0 05	OBF8 OBF8	HIRTS <sub>L</sub> _OFFSET
				Divide result by 128 giving the quotient and the remainder.
				ADDL #2,HIRTS <sub>L</sub> _RCTBLOCK ; Add in sector 0 and sector 1.
				RSB ; Return to caller

OBFE 2529 .SBTTL DUSHIR\_ERROR - Process error encountered during HIRT processing  
 OBFE 2530 :++  
 OBFE 2531  
 OBFE 2532  
 OBFE 2533  
 OBFE 2534  
 OBFE 2535  
 OBFE 2536  
 OBFE 2537  
 OBFE 2538  
 OBFE 2539  
 OBFE 2540  
 OBFE 2541  
 OBFE 2542  
 OBFE 2543  
 OBFE 2544  
 OBFE 2545  
 OBFE 2546  
 OBFE 2547  
 OBFE 2548  
 OBFE 2549  
 OBFE 2550  
 OBFE 2551  
 OBFE 2552  
 OBFE 2553  
 OBFE 2554  
 OBFE 2555 R0 A parameter giving the <type>, <func>, and <n> values above  
 OBFE 2556 R3 UCB address  
 OBFE 2557  
 OBFE 2558  
 OBFE 2559  
 OBFE 2560  
 OBFE 2561  
 OBFE 2562  
 OBFE 2563  
 OBFE 2564  
 OBFE 2565  
 SE 00FE 8F BB OBFE 2566 PUSHR #^M<R1,R2,R3,R4,R5,R6,R7> ; Save some registers.  
 B8 AE 9E OC02 2567 MOVAB -HIRER\$K\_MSGSIZE(SP), SP ; Make message space on stack.  
 56 5E DO OC06 2568 MOVL SP, R6 ; Save base of message space.  
 57 50 DO OC09 2569 MOVL R0, R7 ; Copy error parameter.  
 :--  
 55 53 D0 OC0C 2571 ; Form device name.  
 51 56 D0 OC0F 2572 MOVL R3, R5 ; Move UCB address.  
 81 25 90 OC12 2573 MOVL R6, R1 ; Setup buffer address.  
 50 12 D0 OC15 2574 MOVB #^A/%/, (R1)+ ; Insert percent sign.  
 54 01 CE OC18 2575 MOVL #HIRER\$K\_DEVNAMSIZ, R0 ; Setup buffer size.  
 00000000'GF 16 OC1B 2577 MNEGL #1, R4 ; Setup formation code.  
 53 56 51 C1 OC21 2578 JSB G^IOC\$CVT\_DEVNAME ; Get device name for UCB.  
 53 D6 OC25 2579 ADDL3 R1, R6, R3 ; Init working buffer pointer.  
 : Copy first fixed segment.  
 51 0034'CF 9E OC27 2581 INCL R3 ; Adjust for percent sign.  
 68 10 OC2C 2582 MOVAB HIR\_ERR\_SEG1, R1 ; Get string address.  
 OC2E 2583 BSBB COPY\_ASCIC ; Copy string.  
 OC2E 2584  
 : Insert proper <type> segment.

52 57 04 08 EF OC2E 2586 EXTZV #HIRERSV\_TYPE, #HIRERSS\_TYPE, R7, R2 ; Get type number.  
 51 0000'CF 9E OC33 2587 MOVAB HIR\_ERR\_TYPES, R1 ; Get error types strings base.  
 50 81 9A OC38 2588 32\$: MOVZBL (R1)+, R0 ; Get length of this message.  
 51 50 C0 OC3B 2589 ADDL R0, R1 ; Point to next message.  
 F7 52 F5 OC3E 2590 SOBGTR R2, 32\$ ; Loop till message located.  
 53 10 OC41 2591 BSBB COPY\_ASCIC ; Copy <type> string.  
 51 0044'CF 9E OC43 2593 ; Copy second fixed segment.  
 4C 10 OC48 2594 MOVAB HIR\_ERR\_SEG2, R1 ; Get string address.  
 51 0025'CF 9E OC4A 2595 BSBB COPY\_ASCIC ; Copy string.  
 05 57 OC E1 OC4F 2598 ; Insert proper <func> segment.  
 51 002D'CF 9E OC53 2600 BBC #HIRERSV\_ONLINE, R7, 45\$ ; Assume REPLACE.  
 3C 10 OC58 2601 45\$: MOVAB HIR\_ERR\_ONLINE, R1 ; Branch if not ONLINE.  
 51 004F'CF 9E OC5A 2602 BSBB COPY\_ASCIC ; Else, get ONLINE.  
 35 10 OC5F 2603 ; Copy third fixed segment.  
 50 63 57 9A OC61 2604 MOVAB HIR\_ERR\_SEG3, R1 ; Get string address.  
 OF 15 OC64 2605 BSBB COPY\_ASCIC ; Copy string.  
 51 50 0A 7B OC6C 2606 ; Convert two digits of <n> and insert them.  
 83 50 30 81 OC71 2607 ASSUME HIRERSV\_STEP EQ 0  
 83 51 30 81 OC75 2608 ASSUME HIRERSS\_STEP EQ 8  
 50 52 56 D0 OC79 2610 MOVZBL R7, R0 ; Get step number.  
 53 52 C3 OC7C 2611 CMPB #99, R0 ; Is number to big?  
 00000000'GF 9E OC80 2612 BLEQ 60\$ ; Branch if number to big.  
 00000000'GF 16 OC87 2613 CLRL R1 ; Quadword extend number.  
 5E 48 AE 9E OC8D 2614 EDIV #10, R0, R0, R1 ; Split digits.  
 00FE 8F BA OC91 2615 ADDB3 #^A/0/, R0, (R3)+ ; Insert tens digit.  
 05 OC95 2616 ADDB3 #^A/0/, R1, (R3)+ ; Insert units digit.  
 55 52 56 D0 OC79 2618 60\$: ; Compute message size and broadcast message to OPA0:.  
 51 53 52 C3 OC7C 2619 MOVL R6, R2 ; Setup base message address.  
 00000000'GF 9E OC80 2620 SUBL3 R2, R3, R1 ; Setup message size.  
 00000000'GF 16 OC87 2621 MOVAB G^OPASUCB0, R5 ; Get OPA0 UCB address.  
 OC8D 2622 JSB G^IOC\$BROADCAST ; Broadcast message.  
 5E 48 AE 9E OC8D 2624 MOVAB HIRERSK\_MSGSIZE(SP), SP ; Clear message from stack.  
 00FE 8F BA OC91 2625 POPR #^M<R1,R2,R3,R4,R5,R6,R7> ; Restore saved registers.  
 05 OC95 2626 RSB ; Exit.  
 OC96 2627 ++  
 OC96 2628 : Routine to copy ASCIC string to buffer.  
 OC96 2629 : Inputs:  
 OC96 2630 : R1 ASCIC string address  
 OC96 2631 : R3 buffer address  
 OC96 2632 : Outputs:  
 OC96 2633 : R3 updated buffer address (complements of MOVC3)  
 OC96 2634 : R0 through R5 are altered.  
 OC96 2635 : All other registers are preserved.  
 OC96 2636 :  
 OC96 2637 :  
 OC96 2638 :  
 OC96 2639 :  
 OC96 2640 :  
 OC96 2641 :  
 OC96 2642 :

0C96 2643 ;--  
0C96 2644  
63 50 81 9A 0C96 2645 COPY\_ASCIC:  
61 50 28 05 0C99 2646 MOVZBL (R1)+, R0 : Get string size.  
0C9D 2647 MOVC3 R0, (R1), (R3) ; Copy string.  
0C9E 2648 RSB  
0C9E 2649  
0C9E 2650  
0C9E 2651  
0C9E 2652 .END

ALLOC_POOL	000000B4	R	02	CDRPSL_TT_TERM	= FFFFFFFD
ATE_MSCPCODE	00000002			CDRPSL_UBARSRCE	= 0000003C
ATE_OFFSET	00000000			CDRPSL_UCB	= FFFFFFFB
ATE_SS CODE	00000003			CDRPSL_WIND	= FFFFFFFB
BIT...	= 00000000			CDRPSM_ERLIP	= 00000004
BUGS_DISKCLASS	***** X	X	02	CDRPSM_HIRT	= 00000010
BUILD_RCT_PACKET	00000A55	R	02	CDRPSQ_NT_PRVMSK	= FFFFFFFE
CDDBSA_2PFB	00000174			CDRPST_LBUFHNDL	= 00000030
CDDBSA_DAPCDRP	00000194			CDRPSV_PERM	= 00000003
CDDBSA_DAPIRP	00000134			CDRPSW_ABCNT	= FFFFFFFE
CDDBSA_PRMC DRP	000000D0			CDRPSW_BCNT	= FFFFFFFD
CDDBSA_PRMIRP	00000070			CDRPSW_BOFF	= FFFFFFFD
CDDBSB_SUBTYPE	= 0000000B			CDRPSW_CDRPSIZE	= 00000008
CDDBSB_TYPE	= 0000000A			CDRPSW_CHAN	= FFFFFFFC
CDDBSK_LENGTH	= 00000070			CDRPSW_DUTUCNTR	= 00000044
CDDBSL_CANCLQBL	000000B4			CDRPSW_FUNC	= FFFFFFC0
CDDBSL_CANCLQFL	000000B0			CDRPSW_IRP_SIZE	= FFFFFFA8
CDDBSL_CDT	000000F4			CDRPSW_OBCNT	= FFFFFFFE
CDDBSL_DAPCDT	000001B8			CDRPSW_STS	= FFFFFFFC
CDDBSL_DAPUCB	00000150			COPY_A5CIC	00000C96 R 02
CDDBSL_PRMUCB	0000008C			DEVNAMSIZ	= 00000012
CDDBSL_SAVED_PC	= 00000044			DUSCANCEL_FROM_HIRT	00000229 RG 02
CDDBSW_SIZE	= 00000008			DUSDISCONNECT_HIRT	000002A9 RG 02
CDRPSB_CARCON	= FFFFFFFD			DUSHIR_ERROR	00000BFE R 02
CDRPSB_CD_TYPE	= 0000000A			DUSINIT_HIRT	00000000 RG 02
CDRPSB_EFN	= FFFFFFC2			DUSLOCK_HIRT	000000EF RG 02
CDRPSB_IRP_TYPE	= FFFFFFAA			DUSONLINE_COMPLETE	0000080E RG 02
CDRPSB_PRI	= FFFFFC3			DUSREPLACE_LBN	0000031D RG 02
CDRPSB_RMOD	= FFFFFFAB			DUSRSTRTQ_HIRT_CDRP	000002E0 RG 02
CDRPSL_ABCNT	= FFFFFFE0			DUSTEST_HIRT_WAITCNT	00000205 RG 02
CDRPSL_ARB	= FFFFFFF8			DUSUNLOCK_HIRT	00000178 RG 02
CDRPSL_AST	= FFFFFFB0			DUTUSINIT_MSCP_MSG_UNIT	***** X 02
CDRPSL_ASTPRM	= FFFFFFB4			DUTUSINSERT_RESTARTQ	***** X 02
CDRPSL_BCNT	= FFFFFFD2			DUTUSKILL THIS_THREAD	***** X 02
CDRPSL_CDT	= 00000024			DUTUSL_CDBB_LISTHEAD	00000000
CDRPSL_DIAGBUF	= FFFFFFEC			DUTUSPOST_CDRP	***** X 02
CDRPSL_DUTUFLAGS	= 00000040			DUTUSSEND_MSCP_MSG	***** X 02
CDRPSL_EXTEND	= FFFFFFF4			DUTUSTEST_CANCEL_CDRP	***** X 02
CDRPSL_FR3	= 00000010			DYNSC_CDRP	= 00000039
CDRPSL_FR4	= 00000014			DYNSC_CD_BBRPG	= 00000002
CDRPSL_I0QBL	= FFFFFFA4			DYNSC_CLASSDRV	= 00000064
CDRPSL_I0QFL	= FFFFFFA0			DYNSC_IRP	= 0000000A
CDRPSL_I0SB	= FFFFFC4			END_INIT_HIRT	000000B1 R 02
CDRPSL_I0ST1	= FFFFFD8			EXESALONNPAGED	***** X 02
CDRPSL_I0ST2	= FFFFFDC			EXESFORK_WAIT	***** X 02
CDRPSL_JNL SEQNO	= FFFFFFE8			FILL_RCT_PACKET	00000A7C R 02
CDRPSL_LBUFH_AD	= 0000002C			FIXEDSIZ	= 00000023
CDRPSL_MEDIA	= FFFFFFFD			FKBSK_LENGTH	= 00000018
CDRPSL_MSG_BUF	= 0000001C			FKBSL_FPC	= 0000000C
CDRPSL_OBCNT	= FFFFFFE4			FKBSL_FQBL	= 00000004
CDRPSL_PID	= FFFFFFAC			FKBSL_FQFL	= 00000000
CDRPSL_RSPID	= 00000020			FKBSL_FR3	= 00000010
CDRPSL_RWC PTR	= 00000028			FUNCSTZ	= 00000007
CDRPSL_SAVD RTN	= 00000018			GRANT_HIRT	00000120 R 02
CDRPSL_SEGVBN	= FFFFFE8			HASH_CBN	00000BD6 R 02
CDRPSL_SEQNUM	= FFFFFFF0			HIRERSK_DEVNAMSIZ	= 00000012
CDRPSL_SVAPTE	= FFFFFFCC			HIRERSK_MSGSIZE	= 00000048

HIRERSK_RCTFULL	= 00000003		HIRTSW_BOFF2	= 00000048 R	03
HIRERSK_READ	= 00000001		HIRTSW_BOFF3	= 0000004A R	03
HIRERSK_REPFAIL	= 00000004		HIRTSW_IOST	= 00000008 R	03
HIRERSK_WRITE	= 00000002		HIRTSW_IWORST	= 0000000A R	03
HIRERSM_ONLINE	= 00001000		HIRTSW_PAGENO	= 00000056 R	03
HIRERSM_REPLACE	= 00000000		HIRTSW_PG0CNTNT	= 0000004C R	03
HIRERSM_STEP	= 000000FF		HIRTSW_PG1CNTNT	= 0000004E R	03
HIRERSM_TYPE	= 00000F00		HIRTSW_PG2CNTNT	= 00000050 R	03
HIRERSS_STEP	= 00000008		HIRTSW_PG3CNTNT	= 00000052 R	03
HIRERSS_TYPE	= 00000004		HIRTSW_SECTORNO	= 00000054 R	03
HIRERSV_ONLINE	= 0000000C		HIRTSW_STS	= 0000000E R	03
HIRERSV_STEP	= 00000000		HIR_ERR_ONLINE	= 0000002D R	04
HIRERSV_TYPE	= 00000008		HIR_ERR_REPLACE	= 00000025 R	04
HIRTSK_SUBSTKLN	= 00000005		HIR_ERR_SEG1	= 00000034 R	04
HIRTSL_BADRBND	00000060 R	03	HIR_ERR_SEG2	= 00000044 R	04
HIRTSL_CDRP	00000020 R	03	HIR_ERR_SEG3	= 0000004F R	04
HIRTSL_LBN	00000018 R	03	HIR_ERR_TYPES	= 00000000 R	04
HIRTSL_LOOPCNT	00000010 R	03	IOC\$BROADCAST	***** X	02
HIRTSL_MATCHRBN	0000005C R	03	IOC\$CVT_DEVNAM	***** X	02
HIRTSL_OFFSET	0000006C R	03	IRPSB_C\$RCON	= 0000003C	
HIRTSL_OWNUCB	00000014 R	03	IRPSB_EFN	= 00000022	
HIRTSL_PAGEOPTR	00000024 R	03	IRPSB_PRI	= 00000023	
HIRTSL_PAGE1PTR	00000028 R	03	IRPSB_RMOD	= 00000008	
HIRTSL_PAGE2PTR	0000002C R	03	IRPSB_TYPE	= 0000000A	
HIRTSL_PAGE3PTR	00000030 R	03	IRPSL_LENGTH	= 000000C4	
HIRTSL_RBN	00000058 R	03	IRPSL_ABCNT	= 00000040	
HIRTSL_RCTBLOCK	00000068 R	03	IRPSL_ARB	= 00000058	
HIRTSL_RPLQFL	00000000 R	03	IRPSL_AST	= 00000010	
HIRTSL_RPLQTP	00000004 R	03	IRPSL_ASTPRM	= 00000014	
HIRTSL_SAVDCDRP	0000001C R	03	IRPSL_BCNT	= 00000032	
HIRTSL_STARTBLK	00000064 R	03	IRPSL_CDT	= 00000084	
HIRTSL_STKPTR	00000070 R	03	IRPSL_DIAGBUF	= 0000004C	
HIRTSL_SUBSTACK	00000074 R	03	IRPSL_EXTEND	= 00000054	
HIRTSL_SVAPTE0	00000034 R	03	IRPSL_FQFL	= 00000060	
HIRTSL_SVAPTE1	00000038 R	03	IRPSL_IOQBL	= 00000004	
HIRTSL_SVAPTE2	0000003C R	03	IRPSL_IOQFL	= 00000000	
HIRTSL_SVAPTE3	00000040 R	03	IRPSL_IOSB	= 00000024	
HIRTSM_ACTIVE	= 00000001		IRPSL_IOST1	= 00000038	
HIRTSM_BUSY	= 00000002		IRPSL_IOST2	= 0000003C	
HIRTSM_EMPTYPE	= 00000010		IRPSL_JNL_SEQNO	= 00000048	
HIRTSM_ERLOGIP	= 00000080		IRPSL_MEDIA	= 00000038	
HIRTSM_FE	= 00000004		IRPSL_OBCNT	= 00000044	
HIRTSM_MATCH	= 00000008		IRPSL_PID	= 0000000C	
HIRTSM_RCTFE	= 00000100		IRPSL_SEGVBN	= 00000048	
HIRTSM_RCTFULL	= 00000040		IRPSL_SEQNUM	= 00000050	
HIRTSM_RESCAN	= 00000020		IRPSL_SVAPTE	= 0000002C	
HIRTSV_ACTIVE	= 00000000		IRPSL_TT_TERM	= 0000003C	
HIRTSV_BUSY	= 00000001		IRPSL_UCB	= 0000001C	
HIRTSV_EMPTYPE	= 00000004		IRPSL_WIND	= 00000018	
HIRTSV_ERLOGIP	= 00000007		IRPSQ_NT_PRVMSK	= 00000040	
HIRTSV_FE	= 00000002		IRPSW_ABCNT	= 00000040	
HIRTSV_MATCH	= 00000003		IRPSW_BCNT	= 00000032	
HIRTSV_RCTFE	= 00000008		IRPSW_BOFF	= 00000030	
HIRTSV_RCTFULL	= 00000006		IRPSW_CHAN	= 00000028	
HIRTSV_RESCAN	= 00000005		IRPSW_FUNC	= 00000020	
HIRTSW_BOFF0	00000044 R	03	IRPSW_OBCNT	= 00000044	
HIRTSW_BOFF1	00000046 R	03	IRPSW_SIZE	= 00000008	

IRPSW_STS	= 0000002A		READ RCT_BLOCK	000009C3 R	02
MAP_PAGE	00000AAB R	X 02	REPLACE_CONNECT_FAILURE	0000080B R	02
MMG\$GL_SPTBASE	***** X	02	SCSS\$DEALL_RSPID	***** X	02
MSCP\$B_BUFFER	= 00000010		SCSS\$FIND_RDT	***** X	02
MSCP\$B_FLAGS	= 00000009		SCSS\$UNSTALLUCB	***** X	02
MSCP\$B_OPCODE	= 00000008		SEARCH_FAIL	00000872 R	02
MSCP\$K_OP_READ	= 00000021		SEARCH_RCT	00000ADB R	02
MSCP\$K_OP_REPLACE	= 00000014		SEARCH_RTN	0000087B R	02
MSCP\$K_OP_WRITE	= 00000022		SIZ...	= 00000001	
MSCP\$K_ST_DATA	= 00000008		SIZE	= 00000045	
MSCP\$K_ST_SUCC	= 00000000		SSS_BADRCT	= 0000216C	
MSCP\$K_ST_WRTPR	= 00000006		SSS_CANCEL	= 00000830	
MSCP\$L_BYTECNT	= 0000000C		SSS_NORMAL	= 00000001	
MSCP\$L_CMDREF	= 00000000		SSS_WRITLCK	= 0000025C	
MSCP\$L_FRST_BAD	= 0000001C		STEP10	00000526 R	02
MSCP\$L_LBN	= 00000001C		STEP11	00000562 R	02
MSCP\$L_RBN	= 0000000C		STEP12	00000609 R	02
MSCP\$M_MD_COMP	= 00004000		STEP13	000006B0 R	02
MSCP\$M_MD_ERROR	= 00001000		STEP14	000006D4 R	02
MSCP\$M_MD_EXPRS	= 00008000		STEP15_A	000006EF R	02
MSCP\$M_MD_PRIMR	= 00000001		STEP15_B	00000717 R	02
MSCP\$M_MD_SECOR	= 00000200		STEP16	00000783 R	02
MSCP\$M_MD_SEREC	= 00000100		STEP17	000007C5 R	02
MSCP\$M_ST_MASK	= 0000001F		STEP18	000007E6 R	02
MSCP\$S_ST_MASK	= 00000005		STEP5	00000399 R	02
MSCP\$V_EF_BBLKR	= 00000007		STEP6	000003B2 R	02
MSCP\$V_EF_ERLOG	= 00000005		STEP7	000003FB R	02
MSCP\$V_ST_MASK	= 00000000		STEP8	000004B4 R	02
MSCP\$W_MODIFIER	= 0000000A		STEP9	000004FE R	02
MSCP\$W_STATUS	= 0000000A		STEPSIZ	= 00000002	
NEXT	00000B2D R	X 02	TEST_PATTERN	= B6DBC86D	
OPA\$UCBO	***** X	02	TEST_RCT_ENTRY	00000B85 R	02
PDTSL_ALLOCMSG	= 00000014		TYPSIZ	= 00000007	
PDTSL DEALLOMSG	= 00000020		UCBS\$B_DU_RBNPTRK	***** X	02
PDTSL_MAPIRP	= 00000034		UCBS\$B_DU_RCTCPYS	***** X	02
PDTSL_RCHMSGBUF	= 00000044		UCBSL_CDB	= 000000BC	
PDTSL_UNMAP	= 00000064		UCBSL_CDT	= 000000C8	
RCTSL_BAD_RBN	= 00000014		UCBSL_DU_USIZE	***** X	02
RCTSL_LBN	= 0000000C		UCBSV_MSCP_WRTP	= 0000000D	
RCTSL_RBN	= 00000010		UCBSW_DEVSTS	= 00000068	
RCTS\$M_ALLOCATED	= 20000000		UCBSW_DU_LBNPTRK	***** X	02
RCTS\$M_BR	= 00002000		UCBSW_DU_RCTSIZE	***** X	02
RCTS\$M_FE	= 00000080		UCBSW_RWAITCNT	= 00000056	
RCTS\$M_NONPRIME	= 10000000		VASS_VPN	= 00000015	
RCTS\$M_RP1	= 00008000		VASV_VPN	= 00000009	
RCTS\$M_RP2	= 00004000		WRITE_RCT_BLOCK	00000909 R	02
RCTS\$M_UNUSABLE	= 40000000				
RCTS\$L_LBN	= 0000001C				
RCTS\$V_ALLOCATED	= 0000001D				
RCTS\$V_BR	= 0000000D				
RCTS\$V_FE	= 00000007				
RCTS\$V_LBN	= 00000000				
RCTS\$V_NULL	= 0000001F				
RCTS\$V_RP1	= 0000000F				
RCTS\$V_RP2	= 0000000E				
RCTS\$W_FLAGS	= 00000008				
RDSL_CDRP	= 00000000				

```
+-----+  
! Psect synopsis !  
+-----+
```

PSECT name	Allocation	PSECT No.	Attributes	CON	ABS	LCL	NOSHR	NOEXE	NORD	NOWRT	NOVEC	BYTE
ABS	00000000 ( 0.)	00 ( 0.)	NOPIC	USR	CON	ABS	LCL	NOSHR	NOEXE	NORD	NOWRT	NOVEC
\$ABSS	000001F8 ( 504.)	01 ( 1.)	NOPIC	USR	CON	ABS	LCL	NOSHR	EXE	RD	WRT	NOVEC
\$\$\$115_DRIVER	00000C9E ( 3230.)	02 ( 2.)	NOPIC	USR	CON	REL	LCL	NOSHR	EXE	RD	WRT	NOVEC
\$\$\$300_HIRT	00000088 ( 136.)	03 ( 3.)	NOPIC	USR	CON	REL	LCL	NOSHR	EXE	RD	WRT	NOVEC
\$\$\$301_HIR_ERRORS	00000056 ( 86.)	04 ( 4.)	NOPIC	USR	CON	REL	LCL	NOSHR	EXE	RD	WRT	NOVEC
												LONG

```
+-----+  
! Performance indicators !  
+-----+
```

Phase	Page faults	CPU Time	Elapsed Time
Initialization	37	00:00:00.07	00:00:00.33
Command processing	139	00:00:00.44	00:00:02.55
Pass 1	724	00:00:22.06	00:01:13.75
Symbol table sort	0	00:00:03.17	00:00:09.39
Pass 2	407	00:00:05.60	00:00:41.25
Symbol table output	1	00:00:00.20	00:00:00.47
Psect synopsis output	0	00:00:00.03	00:00:00.03
Cross-reference output	0	00:00:00.00	00:00:00.00
Assembler run totals	1310	00:00:31.58	00:02:07.79

The working set limit was 2700 pages.

187469 bytes (367 pages) of virtual memory were used to buffer the intermediate code.

There were 160 pages of symbol table space allocated to hold 2953 non-local and 117 local symbols.

2652 source lines were read in Pass 1, producing 29 object records in Pass 2.

61 pages of virtual memory were used to define 59 macros.

```
+-----+  
! Macro library statistics !  
+-----+
```

Macro library name	Macros defined
\$255\$DUA28:[DRIVER.OBJ]DUTULIB.MLB;1	8
\$255\$DUA28:[SYS.OBJ]LIB.MLB;1	31
\$255\$DUA28:[SYSLIB]STARLET.MLB;2	9
TOTALS (all libraries)	48

3143 GETS were required to define 48 macros.

There were no errors, warnings or information messages.

MACRO/LIS=LIS\$:DUHIRT/OBJ=OBJ\$:DUHIRT MSRC\$:\$DUHIRT/UPDATE=(ENH\$:\$DUHIRT)+EXECML\$:/LIB+LIB\$:\$DUTULIB/LIB

0110 AH-BT13A-SE  
VAX/VMS V4.0

DIGITAL EQUIPMENT CORPORATION  
CONFIDENTIAL AND PROPRIETARY

DUORIVER  
15

DUHIRT  
LIS

0111 AH-BT13A-SE  
VAX/VMS V4.0

DIGITAL EQUIPMENT CORPORATION  
CONFIDENTIAL AND PROPRIETARY