

NE

NE

SR

NNN	NNN	EEEEEEEEE	TTTTTTTTT	AAAAAAA	CCCCCCC	PPPPPPPPP
NNN	NNN	EEEEEEEEE	TTTTTTT	AAAAAAA	CCCCCCC	PPPPPPPPP
NNN	NNN	EEEEEEEEE	TTTTTTT	AAAAAAA	CCCCCCC	PPPPPPPPP
NNN	NNN	EEE	TTT	AAA	CCC	PPP
NNN	NNN	EEE	TTT	AAA	CCC	PPP
NNN	NNN	EEE	TTT	AAA	CCC	PPP
NNNNNN	NNN	EEE	TTT	AAA	CCC	PPP
NNNNNN	NNN	EEE	TTT	AAA	CCC	PPP
NNNNNN	NNN	EEE	TTT	AAA	CCC	PPP
NNNNNN	NNN	EEE	TTT	AAA	CCC	PPP
NNN NNN	NNN	EEEEEEEEE	TTT	AAA	CCC	PPPPPPPPP
NNN NNN	NNN	EEEEEEEEE	TTT	AAA	CCC	PPPPPPPPP
NNN NNN	NNN	EEEEEEEEE	TTT	AAA	CCC	PPPPPPPPP
NNN NNNNNN	NNNNNN	EEE	TTT	AAAAAAA	CCC	PPP
NNN NNNNNN	NNNNNN	EEE	TTT	AAAAAAA	CCC	PPP
NNN NNNNNN	NNNNNN	EEE	TTT	AAAAAAA	CCC	PPP
NNN NNN	NNN	EEE	TTT	AAA	CCC	PPP
NNN NNN	NNN	EEE	TTT	AAA	CCC	PPP
NNN NNN	NNN	EEE	TTT	AAA	CCC	PPP
NNN NNN	NNN	EEEEEEEEE	TTT	AAA	CCCCCCC	PPP
NNN NNN	NNN	EEEEEEEEE	TTT	AAA	CCCCCCC	PPP
NNN NNN	NNN	EEEEEEEEE	TTT	AAA	CCCCCCC	PPP

FILEID**NETCNFDLL

E 15

NE
VO

NN	NN	EEEEEEEEE	TTTTTTTTT	CCCCCCC	NN	NN	FFFFFFF	DDDDDDD	LL	LL
NN	NN	EEEEEEEEE	TTTTTTTTT	CCCCCCC	NN	NN	FFF	DDDDDDDD	LL	LL
NN	NN	EE	TT	CC	NN	NN	FF	DD	DD	LL
NN	NN	EE	TT	CC	NNNN	NN	FF	DD	DD	LL
NNNN	NN	EE	TT	CC	NNNN	NN	FF	DD	DD	LL
NNNN	NN	EE	TT	CC	NNNN	NN	FF	DD	DD	LL
NN	NN	NN	EEEEEEE	TT	CC	NN	NN	FFFFFFF	DD	LL
NN	NN	NN	EEEEEEE	TT	CC	NN	NN	FFFFFFF	DD	LL
NN	NNNN	EE	TT	CC	NN	NNNN	FF	DD	DD	LL
NN	NNNN	EE	TT	CC	NN	NNNN	FF	DD	DD	LL
NN	NN	EE	TT	CC	NN	NN	FF	DD	DD	LL
NN	NN	EE	TT	CC	NN	NN	FF	DD	DD	LL
NN	NN	EEEEEEE	TT	CCCCCCC	NN	NN	FF	DDDDDDDD	LLLLLLL	LLLLLLL
NN	NN	EEEEEEE	TT	CCCCCCC	NN	NN	FF	DDDDDDDD	LLLLLLL	LLLLLLL
LL	LL		SSSSSSS					
LL	LL		SSSSSSS					
LL	LL		SS					
LL	LL		SS					
LL	LL		SS					
LL	LL		SSSSSS					
LL	LL		SSSSSS					
LL	LL		SS					
LL	LL		SS					
LL	LL		SS					
LLLLLLL	LLLLLLL		SSSSSSS					
LLLLLLL	LLLLLLL		SSSSSSS					

(2)	245	DECLARATIONS
(7)	561	NET\$SCAN xxx - Scan database
(8)	602	NET\$PRE_QIO_xxx - Pre-QIO processing
(9)	767	NET\$SHOW xxx - Pre-SHOW processing
(10)	861	JAM_CNF = Store driver values into CNF
(11)	960	GET_PSI_xxx - Get current PSI parameter values
(12)	1065	CLEAR_VOLATILE - Clear list of volatile parameters
(13)	1089	NET\$DEFAULT_CRI - Apply default values
(14)	1170	NET\$DEFAULT_PLI - Apply default values
(15)	1252	NET\$INSERT_CRI - Pre-insertion processing
(16)	1339	CRI TO PSI - Send CRI parameters to PSIACP
(17)	1409	NET\$INSERT_PLI - Pre-insertion processing
(18)	1525	ALLOC_PLVEC - Setup PLVEC entry for new line
(19)	1631	NET\$SET_QIOW - Issue datalink SETMODE function
(20)	1699	PLI TO PSI - Send PLI parameters to PSIACP
(21)	1741	SEND_TO_PSI - Send control QIO to PSIACP
(22)	1897	NET\$DELETE_CRI - Pre-delete processing
(23)	1945	NET\$DELETE_PLI - Pre-delete processing
(24)	1994	NET\$REMOVE_xxx - Pre-remove processing
(25)	2012	CRI parameter action routines
(26)	2374	PLI parameter action routines
(27)	2750	BUILD_DEVBUF - Build DLLQIO buffer
(28)	2813	NET\$CVT_NMA_INT - Convert NMA to NFB code
(29)	2872	TRAN_DEVNAM - Translate device name
(30)	2938	PRS_MNEMONIC - Parse device mnemonic
(31)	2990	PRS_DECIMAL - Parse decimal number
(32)	3027	DEV_CNT_QIO - Get device counters

0000 1 .TITLE NETCNFDLL - Datalink database action routines
0000 2 .IDENT 'V04-000'
0000 3 .DEFAULT DISPLACEMENT, LONG
0000 4
0000 5 *****
0000 6 *
0000 7 * COPYRIGHT (c) 1978, 1980, 1982, 1984 BY
0000 8 * DIGITAL EQUIPMENT CORPORATION, MAYNARD, MASSACHUSETTS.
0000 9 * ALL RIGHTS RESERVED.
0000 10 *
0000 11 * THIS SOFTWARE IS FURNISHED UNDER A LICENSE AND MAY BE USED AND COPIED
0000 12 * ONLY IN ACCORDANCE WITH THE TERMS OF SUCH LICENSE AND WITH THE
0000 13 * INCLUSION OF THE ABOVE COPYRIGHT NOTICE. THIS SOFTWARE OR ANY OTHER
0000 14 * COPIES THEREOF MAY NOT BE PROVIDED OR OTHERWISE MADE AVAILABLE TO ANY
0000 15 * OTHER PERSON. NO TITLE TO AND OWNERSHIP OF THE SOFTWARE IS HEREBY
0000 16 * TRANSFERRED.
0000 17 *
0000 18 * THE INFORMATION IN THIS SOFTWARE IS SUBJECT TO CHANGE WITHOUT NOTICE
0000 19 * AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT
0000 20 * CORPORATION.
0000 21 *
0000 22 * DIGITAL ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS
0000 23 * SOFTWARE ON EQUIPMENT WHICH IS NOT SUPPLIED BY DIGITAL.
0000 24 *
0000 25 *
0000 26 *****
0000 27 *
0000 28 :
0000 29 : FACILITY: NETWORK ACP
0000 30 :
0000 31 : ABSTRACT:
0000 32 : Action routines for CRI and PLI databases.
0000 33 :
0000 34 : This module provides support to the NETACP database management
0000 35 : including database entry insertion and action routines to
0000 36 : retrieve data for parameters which are not stored in any of
0000 37 : the datalink CNF control blocks (CRI and PLI).
0000 38 :
0000 39 : ENVIRONMENT:
0000 40 : The module runs in kernel mode and at possibly elevated IPL.
0000 41 : It is therefore locked into the ACP's virtual address space
0000 42 : in order to prevent the need for paging.
0000 43 :
0000 44 : Since the ACP is work-queue driven, and since it is the ACP
0000 45 : that modifies the structure of the non-paged pool data base
0000 46 : including the RCB (actually a VCB) and the private structures
0000 47 : hanging off of the RCB, there is no need to obtain the system
0000 48 : data base mutex -- no races can occur. However, it is
0000 49 : necessary to raise IPL in order to stop any races with
0000 50 : NETDRIVER.
0000 51 :
0000 52 : AUTHOR: A.Eldridge 14-Feb-80
0000 53 :
0000 54 : MODIFIED BY:
0000 55 :
0000 56 :
0000 57 : V021 RNG0021 Rod Gamache 17-Jul-1984

0000	58	Add more checks to insure the DEV\$V_NET bit is set for datalink drivers.
0000	59	
0000	60	
0000	61	V020 RNG0020 Rod Gamache 16-Mar-1984 Make sure DEV\$V_NET bit is on before attempting to use any device driver.
0000	62	
0000	63	
0000	64	
0000	65	V019 RNG0019 Rod Gamache 13-Jan-1984 Add DPV and KMV support for X.25.
0000	66	
0000	67	
0000	68	V018 RNG0018 Rod Gamache 18-Nov-1983 Add QNA support for communication over the NI.
0000	69	
0000	70	
0000	71	V017 TMH0017 Tim Halvorsen 27-Apr-1983 Add pseudo-point-to-point version of PPUNA circuit for testing of point-to-point circuits over the NI.
0000	72	
0000	73	
0000	74	
0000	75	V016 RNG0015 Rod Gamache 15-Apr-1983 Allow driver NMA parameter i.d.'s to be returned which the NETACP doesn't know about. This allows drivers the flexibility of adding parameters which the NETACP can ignore.
0000	76	
0000	77	
0000	78	
0000	79	
0000	80	V015 RNG0015 Rod Gamache 11-Apr-1983 Make the REMOVE_XXX routines call the REMOVE_DEF routine to remove the PCI or CRI CNF structure.
0000	81	
0000	82	
0000	83	
0000	84	V014 TMH0014 Tim Halvorsen 04-Mar-1983 Add new DEVNAM circuit parameter action routine. Return second longword of IOSB from datalink setmode to issuer of SET LINE STATE ON function.
0000	85	
0000	86	
0000	87	
0000	88	
0000	89	V013 TMH0013 Tim Halvorsen 14-Feb-1983 Make datalink BUS parameter variable, depending on the type of datalink. It now returns a larger value for NI datalinks, to account for the additional Phase IV Ethernet route header. Make BUS return line BFS parameter if system manager wants to override the executor buffer size on a per-line basis. Conditionally allow the DMC to perform I/O functions on the controller.
0000	90	
0000	91	
0000	92	
0000	93	
0000	94	
0000	95	
0000	96	
0000	97	
0000	98	
0000	99	
0000	100	V012 TMH0012 Tim Halvorsen 20-Dec-1982 Add new UNA parameter to table of parameters to ignore on sensemode requests. If the error qualifier returned by a datalink driver is "physical address", meaning that DECnet's requested physical address is in conflict with another user of the device, then map the qualifier to "hardware address", for which a NICE parameter exists. This is so that when an NCP user requests to have the line turned on, and it fails due to address conflict, then a parameter is returned with "bad parameter value". Suppress node addresses if areas have been hidden.
0000	101	
0000	102	
0000	103	
0000	104	
0000	105	
0000	106	
0000	107	
0000	108	
0000	109	
0000	110	
0000	111	
0000	112	
0000	113	V011 TMH0011 Tim Halvorsen 29-Nov-1982 Remove one lagging reference to NMASC_CIRTY_LAP symbol.
0000	114	

0000 115 : Add support for Ethernet protocol type parameter, rather than using a hard-coded constant. This is so that a UNA can be used on another protocol type without interfering with the normal DECnet traffic on an experimental basis.

0000 116 :
0000 117 :
0000 118 :
0000 119 :
0000 120 :
0000 121 :
0000 122 :
0000 123 :
0000 124 :
0000 125 :
0000 126 :
0000 127 :
0000 128 :
0000 129 :
0000 130 :
0000 131 :
0000 132 :
0000 133 :
0000 134 :
0000 135 :
0000 136 :
0000 137 :
0000 138 :
0000 139 :
0000 140 :
0000 141 :
0000 142 :
0000 143 :
0000 144 :
0000 145 :
0000 146 :
0000 147 :
0000 148 :
0000 149 :
0000 150 :
0000 151 :
0000 152 :
0000 153 :
0000 154 :
0000 155 :
0000 156 :
0000 157 :
0000 158 :
0000 159 :
0000 160 :
0000 161 :
0000 162 :
0000 163 :
0000 164 :
0000 165 :
0000 166 :
0000 167 :
0000 168 :
0000 169 :
0000 170 :
0000 171 :
V010 TMH0010 Tim Halvorsen 13-Oct-1982
Journal I/O requests to PSIACP.
Replace all occurrences of NMASC_CIRTY_LAP with NMASC_CIRTY_LAPB.
Remove defaulting of USAGE to OUTGOING if NUMBER is set, since NUMBER now is used for both incoming and outgoing DLM circuits.
Fix bug in SET LINE if mnemonic doesn't parse correctly.

V009 TMH0009 Tim Halvorsen 27-Sep-1982
Change meaning of LPD DRT cell from the designated router's node address to it's ADJ index.
Modify circuit substate action routine so that value is returned if circuit is in 'S' state.

V008 TMH0008 Tim Halvorsen 14-Sep-1982
Deassign channel if error detected trying to start a broadcast line and the executor type is not Phase IV.
(channel was getting left assigned).
If an INCOMING DLM circuit is defined, then declare NETACP as able to receive incoming calls, in case it wasn't already defined in the SET EXECUTOR (PSI might not have been up then).
Make USAGE default to OUTGOING if the NUMBER parameter is set on a DLM circuit.
Add DLM circuit defaulting (separate from transport defaults).
Add support for automatic line counters and automatic PSI native circuit counters.

V007 TMH0007 Tim Halvorsen 31-Aug-1982
Add action routine to return designated router on NI.
Fix counter returns for DLM switched circuits.

V006 TMH0006 Tim Halvorsen 01-Jul-1982
Add Phase IV line, circuit support.
Add journaling of SETMODE QIOWS.
Fix error path in PSI counter sensing.
Modify PNA, PNN, BLO and add LIT to work with adjacencies.
Add PLI DEVNAM action routine, which returns the physical device name being used by the line, in VMS format, including the unit number.
Do not allow user to turn on an NI line device unless the executor type is set to Phase IV, since Phase III doesn't handle broadcast circuits.
Fix bug in preallocation of receive buffers - it wasn't including the CXB overhead in the buffer size.
Clear PLI MCD before each SHOW function.

V005 TMH0005 Tim Halvorsen 30-Jun-1982
Change defaulting of line and circuit parameters, to be dependant on the type of line or circuit. This is done because the default parameters for a DDCMP circuit

0000 172 : are not the same as for a X25 circuit, or an NI circuit.
 0000 173 : The same thing is true for DDCMP or LAPB lines.
 0000 174 : Add code to ask PSI for it's line/circuit parameters on
 0000 175 : SHOW functions, so that a show returns the sum for both
 0000 176 : NETACPs and PSIs databases.
 0000 177 : Change mnemonic of KMS to KMX, marking it "multiple-unit
 0000 178 : controller" and add KMY.
 0000 179 :
 0000 180 : V004 TMH0004 Tim Halvorsen 16-Jun-1982
 0000 181 : Always give null context area on PSI control QIOs.
 0000 182 : Fix list of line/circuit parameters which are passed to PSI.
 0000 183 : Add support for asking PSI for its line/circuit counters.
 0000 184 : Fix bug in sensing of datalink counters, to correctly
 0000 185 : detect and remove the "seconds since last zeroed" counter
 0000 186 : (it never worked, but no driver ever returned it either).
 0000 187 : Don't tell PSI about SVCs, since it doesn't want to know
 0000 188 : about them.
 0000 189 : Add kludge to SEND TO PSI, so that all ACPCONTROL functions
 0000 190 : to PSIACP are terminated with NFBSC ENDOFLIST, to avoid the
 0000 191 : check which doesn't allow 0 field identifiers.
 0000 192 :
 0000 193 : V003 TMH0003 Tim Halvorsen 15-Jun-1982
 0000 194 : Remove code to disable error reporting from PSI control QIOs.
 0000 195 :
 0000 196 : V002 TMH0002 Tim Halvorsen 04-Apr-1982
 0000 197 : Make this new module from the CRI and PLI routines in CNFACT
 0000 198 : in an attempt to reduce the size of that module.
 0000 199 : Remove code to make the start key canonical, since
 0000 200 : the start key no longer exists.
 0000 201 : Add code to check if we are dealing with a LAPB line,
 0000 202 : and if so, give it to PSIACP.
 0000 203 : Remove some obsolete symbols.
 0000 204 : Remove X.25 parameters from NICE-NFB translation table,
 0000 205 : since we will never have to translate PSI NICE parameters.
 0000 206 : Clean up code in INSERT CRI and INSERT PLI.
 0000 207 : Fix code to "update" volatile fields in CNF from values given
 0000 208 : by the datalink driver, so that it doesn't stop when it can't
 0000 209 : modify a particular field, but continues thru all the rest of
 0000 210 : the parameters returned by the driver. A single field which
 0000 211 : is conditionally writable might stop the code from ever
 0000 212 : processing the rest of the fields.
 0000 213 : Make default word displacement.
 0000 214 : Send DELETE requests to PSI.
 0000 215 : Clean up SHOW_xxx routines.
 0000 216 : Pre-allocate receive buffers before issuing a SETMODE
 0000 217 : startup function to a datalink driver, so that pool
 0000 218 : expansion can be done to accomodate the buffers. It
 0000 219 : is done here because pool expansion can't be done on
 0000 220 : the interrupt stack in the datalink driver.
 0000 221 : Default the line protocol based on the line name mnemonic.
 0000 222 : Add X25 to the list of allowed mnemonics for circuit names.
 0000 223 : Send all circuits set/clears with TYPE=X25 to PSI.
 0000 224 : Change all CNF action routines to use the new action routine
 0000 225 : interface (NETCNF now automatically allocates a TMP buffer).
 0000 226 : Remove obsolete NUL action routines.
 0000 227 : Do not send "show-only" datalink parameters (returned by the
 0000 228 : driver and stored into the CNF) back to the driver in the

0000 229 : next setmode. Mark show-only datalink parameters in the
0000 230 : translation table.
0000 231 : Make circuits of the form X25-x default to TYPE=X25 so that
0000 232 : you don't have to enter TYPE all the time.
0000 233 : Reformat secondary search key into canonical form if the
0000 234 : field is the line or circuit name.
0000 235 : Add KMS to device list for X.25 network management.
0000 236 : Add X.25 datalink mapping support.
0000 237 : Allow any characters to appear after circuit names of the
0000 238 : form "X25-xxx"
0000 239 :
0000 240 : V001 TMH0001 Tim Halvorsen 27-Mar-1982
0000 241 : Fix code to translate an NMA parameter code returned by
0000 242 : a datalink driver validation error to a NFB code.
0000 243 :---

```
0000 245 .SBTTL DECLARATIONS
0000 246
0000 247 : INCLUDE FILES:
0000 248 :
0000 249     $DEVDEF      : Define device characteristics bits
0000 250     $DVIDEF     : $GETDVI item codes
0000 251     $DCDEF       : Device classs definitions
0000 252     $CCBDEF     : Channel Control Block
0000 253     $CXBDEF     : Complex-chained buffers
0000 254     $UCBDEF     : Unit Control Block
0000 255     $XMDEF      : XMDRIVER (general communications device driver)
0000 256
0000 257     $NFBDEF      : Network Function Block (ACP control QIO definitions)
0000 258     $NMADEF     : Network Management (NICE protocol) definitions
0000 259     $EVCFDEF    : DECnet Event logging symbols
0000 260     $CNRDEF      : Configuration Root block
0000 261     $CNFDEF      : Configuration data block
0000 262     $DEVTRNDEF   : Device translation (VMS vs. Nice protocol) info
0000 263     $DLLQIODEF   : Data-Link Layer QIO definitions
0000 264     $RCBDEF      : Routing Control Block (analogous to Volume Control
0000 265           block)
0000 266     $LPDDEF      : Logical path descriptor
0000 267     $ADJDEF      : Adjacency control block
0000 268     $NETSYMDEF   : Miscellaneous network symbols
0000 269     $NETUPDDEF   : Symbols used in private NETACP interface to NETDRIVER
0000 270     $NSPMSGDEF   : DNA architecture definitions & message formats
0000 271
0000 272 :
0000 273 : Macros
0000 274 :
0000 275
0000 276     .MACRO SWAP,ARG1,ARG2      ; Swap arguments in-place
0000 277     XORL ARG1,ARG2
0000 278     XORL ARG2,ARG1
0000 279     XORL ARG1,ARG2
0000 280     .ENDM
0000 281
0000 282 : Define the following symbol to allow controller I/O functions on the DMC.
0000 283 : DMC_MODEM = 0
0000 284 :
0000 285 : Define special CNF flags for each database
0000 286 :
0000 287 :
0000 288 : PLI_V_NEW      = CNFSV_FLG_MRK1      ; New PLI being built for first time
0000 289 :
0000 290 :
0000 291 PLI_V_NEW      = CNFSV_FLG_MRK1      ; New PLI being built for first time
00000004 0000
```

```

0000 293 : OWN STORAGE
0000 294 : 
0000 295 : 
0000 296 : 
0000 297 .PSECT NET_PURE,NOWRT,NOEXE,LONG
0000 298 : 
0000 299 : 
0000 300 : The following macros build a conversion table for formatting counters
0000 301 : into NICE format. Each counter i.d. contain is bit encoded to contain
0000 302 : formatting information as follows:
0000 303 :      15   14   13   12   11       0      Bit
0000 304 : < 1 >< width >< 0 >< counter i.d. >      Field
0000 305 : 
0000 306 : 
0000 307 : 
0000 308 : 
00000001 309     $WIDTH_B = 1      ; Counter width specifier for bytes
00000002 310     $WIDTH_W = 2      ; Counter width specifier for words
00000003 311     $WIDTH_L = 3      ; Counter width specifier for longwords
00000C000 312     NETSC_NMACNT_SLZ = <1@15>!<$WIDTH_W>@13>!0      ; Seconds since last zeroed
00000C000 313     .MACRO $COUNT_ENT base,nice,pre,mod,count,width; Insert table entry
00000C000 314     .WORD <1@15>!<$WIDTH_width>@13>!-      ; Counter flag, Counter width
00000C000 315     <NMASC_nice'_count>      ; Nice counter i.d.
00000C000 316     .WORD 'pre'$width'_mod'count' -      ; Offset into internal structure
00000C000 317     - base      ; minus internal structure base
00000C000 318     .ENDM $COUNT_ENT      ; 
00000C000 319     .MACRO $COUNT_TAB base,nice,pre,mod,list      ; Create counter formatting table
00000C000 320     .IRP A,<list>
00000C000 321     $COUNT_ENT base,nice,pre,mod,A      ; Insert table entry
00000C000 322     .ENDR      ; 
00000C000 323     .LONG 0      ; Terminate the table
00000C000 324     .ENDM $COUNT_TAB      ; 
00000C000 325     .MACRO LPD_CNT_TAB:      ; Circuit counter formatting table
00000C000 326     $COUNT_TAB LPDSL_ABS_TIM,CTCIR,LPD,CNT_,-
00000C000 327     <-
00000C000 328     <APR,L>,-      ; Arriving packets received
00000C000 329     <DPS,L>,-      ; Departing packets sent
00000C000 330     <ACL,W>,-      ; Arriving congestion loss
00000C000 331     <TPR,L>,-      ; Transit packets received
00000C000 332     <TPS,L>,-      ; Transit packets sent
00000C000 333     <TCL,W>,-      ; Transit congestion loss
00000C000 334     <LDN,B>,-      ; Line down events
00000C000 335     <IFL,B>,-      ; Initialization failures
00000C000 336     >
00000C000 337     .ENDM X25_CNT_TAB:      ; X.25 native circuit counter formatting table
0024

```

0024 350
0024 351 \$COUNT_TAB ; Currently only "seconds since last zeroed"
0028 352 ; is maintained outside PSIAACP
0028 353
0028 354 PLI_CNT_TAB: ; Line counter formatting table
0028 355
0028 356 \$COUNT_TAB ; Currently only "seconds since last zeroed"
002C 357 ; is maintained outside the driver
002C 358

BCDEFGHIJKLMNOPBCDEFGHIJKLMNOPBCDEFGHIJKLMNOPBCDEFGHIJKLMNOP

```

002C 360 : 
002C 361 : Build a table to driver the translation between Network Management (NICE)
002C 362 : device names to VMS devices names and to supply miscellaneous information
002C 363 : about known devices
002C 364 :
FFFFFFF 002C 365 NMASC_LINPR_ = -1 ; Define protocol type for protocols
002C 366 ; not defined by the NICE protocol
002C 367 :
0000000F 002C 368 MAX_C_DEVNAM = 15 ; Maximum device name string
002C 369 ; (dev-c-u.t)
002C 370 :
002C 371 .MACRO .devtrn netman,vms,type,prot,char ; Create table entry
002C 372 :
002C 373 $Sdevtrn =
002C 374 .ascic "NETMAN" ; Remember where we are
002C 375 . = $Sdevtrn + devtrn$b_vms ; Enter Net Man device mnemonic
002C 376 .ascic "VMS" ; Advance to next field
002C 377 . = $Sdevtrn + devtrn$b_dev ; Enter VMS device mnemonic
002C 378 .byte devtrn$c_dev 'TYPE' ; Advance to next field
002C 379 . = $Sdevtrn + devtrn$b_prot ; Enter default protocol type
002C 380 .byte nmasc_linpr 'PROT' ; Advance to device characteristics
002C 381 . = $Sdevtrn + devtrn$b_char ; Advance to device characteristics
002C 382 .if nb,char ; Enter device characteristics
002C 383 .byte devtrn$M_CHAR'
002C 384 .iff
002C 385 .byte 0
002C 386 .endc
002C 387 . = $Sdevtrn + devtrn$c_length ; Advance to next table entry
002C 388 :
002C 389 .ENDM .devtrn
002C 390 :
002C 391 DEVTRN_TABLE: ; Device translation table
002C 392 :
002C 393 .devtrn <DMC>, <XM>, <DMC>, <POI>, <> : DMC-11
0039 394 .devtrn <DMP>, <XD>, <DMP>, <POI>, <> : DMP-11
0046 395 .devtrn <PCL>, <XP>, <PCL>, <MAS>, <> : PCL-11
0053 396 .devtrn <DMF>, <XG>, <DMF>, <POI>, <> : DMF-11 (combo board)
0060 397 .devtrn <CI>, <CN>, <CI>, <>, <> : CI-780
006D 398 .devtrn <UNA>, <XE>, <UNA>, <NI>, <> : UNA (Ethernet)
007A 399 .devtrn <PPUNA>, <XE>, <PPUNA>, <POI>, <MULTI> : "point-to-point" UNA
0087 400 ; (internal only)
0087 401 : "XE" must be used to distinguish PPUNA datalinks from UNA datalinks,
0087 402 : since they both use the same driver, and since matching of lines and
0087 403 : and circuits is done by the VMS device name given here.
0087 404 .devtrn <QNA>, <XQ>, <UNA>, <NI>, <> : QNA (Ethernet)
0094 405 .devtrn <UE>, <XX>, <UNA>, <NI>, <> : 3COM UE (Ethernet)
00A1 406 .devtrn <DUP>, <>, <DUP>, <LAPB>, <> : DUP-11 (for X.25)
00AE 407 .devtrn <DPV>, <>, <DPV>, <LAPB>, <> : DPV-11 (for X.25)
00BB 408 .devtrn <KMX>, <>, <KMS>, <LAPB>, <MULTI> : KMS-11 (for X.25)
00C8 409 .devtrn <KMY>, <>, <KMS>, <LAPB>, <> : KMS-11 (for X.25)
00D5 410 .devtrn <KMV>, <>, <KMS>, <LAPB>, <> : KMY-11 (for X.25)
00E2 411 .devtrn <X25>, <NW>, <X25>, <>, <> : X25 DLM circuits
00EF 412 .devtrn <>, <>, <UNK>, <>, <MULTI> : Terminate the table
00FC 413 .devtrn <>, <>, <UNK>, <>, <MULTI> ; with foreign device
00FC 414 .ALIGN LONG

```

```

00FC 416 :
00FC 417 : The following tables contain a list of parameters which need to be cleared,
00FC 418 : in a given (PLI or CRI) CNF block before that block is process for a "show".
00FC 419 : QIO. The reason for this is that the parameters are maintained only by the
00FC 420 : device driver and the copy of this information stored in the CNF is stale.
00FC 421 :
00FC 422 PLI_CLR_TAB: .CNFFLD pli,s,mcd      ; X.25 microcode dump file [write only]
0100 423      .LONG 0                      ; Terminate the table
0104 424 :
0104 425 CRI_CLR_TAB: .CNFFLD cri,l,pls      ; Polling sub-state
0108 426      .LONG 0                      ; Terminate the table
010C 427 :
010C 428 :
010C 429 : The following table lists those CRI parameters which must be processed by
010C 430 : PSIACP if the circuit is of TYPE X25. This table is used to build
010C 431 : a control QIO to send the parameters to PSIACP. PSIACP only needs to "know"
010C 432 : about the parameters listed in this table.
010C 433 :
010C 434 CRI_PSI_TAB:
010C 436      .CNFFLD cri,l,STA      ; State
0110 437      .CNFFLD cri,l,USE      ; Circuit usage
0114 438      .CNFFLD cri,l,TYP      ; Circuit type
0118 439      .CNFFLD cri,l,CHN      ; Channel
011C 440      .CNFFLD cri,l,MBL      ; Maximum data
0120 441      .CNFFLD cri,l,MWI      ; Maximum window
0124 442      .CNFFLD cri,s,DTE      ; DTE
0128 443      .LONG 0                      ; Terminate table
00000000 0128 444      .LONG 0                      ; Terminate table
00000020 012C 445 CRI_PSI_SIZ = . - CRI_PSI_TAB
012C 446 :
012C 447 :
012C 448 : The following table lists those PLI parameters which must be processed by
012C 449 : PSIACP if the line is using PROTOCOL LAPB. This table is used to build
012C 450 : a control QIO to send the parameters to PSIACP. PSIACP only needs to "know"
012C 451 : about the parameters listed in this table.
012C 452 :
012C 453 :
012C 454 PSI_PLI_CLR_TAB:                  ; Params cleared before every SET function
012C 455      .CNFFLD pli,l,sub      ; Line substate
0130 456      .LONG 0                      ; Terminate the table
0134 457 :
0134 458 PLI_PSI_TAB:
0134 459      .CNFFLD pli,v,DUP      ; Duplex
0138 460      .CNFFLD pli,v,CON      ; Controller mode
013C 461      .CNFFLD pli,l,STA      ; State
0140 462      .CNFFLD pli,l,SUB      ; Substate [SHOW only]
0144 463      .CNFFLD pli,l,PRO      ; Protocol
0148 464      .CNFFLD pli,l,HTI      ; Holdback timer
014C 465      .CNFFLD pli,l,MBL      ; Maximum block
0150 466      .CNFFLD pli,l,MRT      ; Maximum retransmits
0154 467      .CNFFLD pli,l,MWI      ; Maximum window
0158 468      .CNFFLD pli,l,BFN      ; Receive buffers
015C 469      .CNFFLD pli,l,RTT      ; Retransmit timer
0160 470      .CNFFLD pli,l,MOD      ; X.25 mode (DCE, DTE, etc.)
0164 471      .CNFFLD pli,s,MCD      ; Microcode dump filespec [SET only]
0168 472

```

```

00000000 0168 473 .LONG 0
00000038 016C 474 PLI_PSI_SIZ = . - PLI_PSI_TAB ; Terminate table
016C 475
016C 476
016C 477 : Build the tables which drive datalink QIO parameter translation. The
016C 478 : datalink QIO parameter buffers are stored in NICE protocol format.
016C 479
00003FFF 016C 480 CNVTABSC_INTRNL = ^X3FFF ; Index = INTRNL means datalink only
016C 481
016C 482 SVIELD CNVTAB,0,<
016C 483 <NMA,12,M>,- ; Define conversion table enter
016C 484 <RO,1,M>,- ; NICE protocol param i.d.
016C 485 <,3>,- ; Read-only flag
016C 486 <INT,14,M>,- ; 3 spare bits
016C 487 <FMT,2,M>,- ; Internal parameter index
016C 488 > ; Parameter format (string,value,etc)
016C 489
016C 490 .MACRO .cnvtab nma,db,param,readonly=0 ; Insert parameter i.d. table entry
016C 491
016C 492 .LONG <<nma$>'nma'-'param'>> ; <cnvtab$>_nma> -
016C 493 + <'readonly'> ; cnvtab$>_ro> -
016C 494 + <<nfb$>'db'-'param'>> & nfb$m_inx> ; <cnvtab$>_int-nfb$>_inx> -
016C 495 + <<nfb$>'db'-'param'>> & nfb$m_typ> ; <cnvtab$>_fmt-nfb$>_typ> -
016C 496 .ENDM
016C 497
016C 498 .MACRO .inttab nma,typ,param ; Describe internal NMA codes
016C 499 ; returned by datalink drivers
016C 500 .LONG <nma$>'nma'-'param'>> ; <cnvtab$>_nma> -
016C 501 + <cnvtab$>_intrnl ; cnvtab$>_int> -
016C 502 + <nfb$>'typ' ; cnvtab$>_fmt>
016C 503 .ENDM
016C 504
016C 505 CRI_TRN_TAB: ; NICE-internal param i.d. translation
016C 506 .cnvtab pcci,cri,POL ; Polling state
0170 507 .cnvtab pcci,cri,PLS,1 ; Polling sub-state [READ ONLY]
0174 508 .cnvtab pcci,cri,TYP,1 ; Protocol type [READ ONLY]
0178 509 .cnvtab pcci,cri,TRI ; Tributary station address
017C 510 .cnvtab pcci,cri,BBT ; Babbel timer
0180 511 .cnvtab pcci,cri,TRT ; Transmit timer
0184 512 .cnvtab pcci,cri,MRB ; Maximum receive buffers
0188 513 .cnvtab pcci,cri,MTR ; Maximum transmits
018C 514 .cnvtab pcci,cri,ACB ; Active base
0190 515 .cnvtab pcci,cri,ACI ; Active increment
0194 516 .cnvtab pcci,cri,IAB ; Inactive base
0198 517 .cnvtab pcci,cri,IAI ; Inactive increment
019C 518 .cnvtab pcci,cri,IAT ; Inactive threshold
01A0 519 .cnvtab pcci,cri,DYB ; Dying base
01A4 520 .cnvtab pcci,cri,DYI ; Dying increment
01A8 521 .cnvtab pcci,cri,DYT ; Dying threshold
01AC 522 .cnvtab pcci,cri,DTH ; Dead threshold
01B0 523 .cnvtab pcci,cri,MST ; Maintenance mode state
01B4 524
00000000 01B4 525 .LONG 0 ; Terminate the table
01B8 526
01B8 527
01B8 528 PLI_TRN_TAB: ; NICE-internal param i.d. translation
01B8 529 .cnvtab plci,pli,BUS ; Receive buffer size

```

01B0	530	.cnvtab pcii,pli,DUP	; Duplex mode
01C0	531	.cnvtab pcii,pli,CON	; Contrc'ler (loopback) mode
01C4	532	.cnvtab pcii,pli,CLO	; Clock mode
01C8	533	.cnvtab pcii,pli,PRO	; Protocol
01CC	534	.cnvtab pcii,pli,SLT	; Scheduling timer
01D0	535	.cnvtab pcii,pli,DDT	; Dead timer
01D4	536	.cnvtab pcii,pli,DLT	; Delay timer
01D8	537	.cnvtab pcii,pli,SRT	; Stream timer
01DC	538	.cnvtab pcii,pli,BFN	; Number of buffers in pool
01E0	539	.cnvtab pcii,pli,RTT	; Retransmit timer
01E4	540	.cnvtab pcii,pli,HWA,1	; UNA hardware address [READ ONLY]
01E8	541		
00000000	01E8	.LONG 0	; Terminate the table
	01EC	542	
		543	

```
00000000 545 .PSECT NET_IMPURE,WRT,NOEXE
      0000 546
00000001 0000 547 PLI_B_STATE: .BLKB 1 ; Device state
00000000 0001 548 PLI_Q_DEVNAM: .QUAD 0 ; Device name descriptor
      0009 549
00000020 0009 550 DEVNAM_C_SIZ = 32 ; Size of SEARCH key buffer
      0009 551 ; for line and circuit names
      0009 552
00000029 0009 553 SRCH_BUF: .BLKB DEVNAM_C_SIZ ; Optional SEARCH KEY buffer
      0029 554
00000000 0029 555 QIOW_Q_IOSB: .QUAD 0 ; General QIOW IOSB
00000033 0031 556 QIOW_W_RETLEN: .BLKW 1 ; Return length word for PSI QIOW
00000000 0033 557 TMP_Q_DESC: .QUAD 0 ; Scratch descriptor
      0038 558
00000000 559 .PSECT NET_CODE,NOWRT,EXE
```

0000 561 .SBTTL NET\$SCAN_xxx - Scan database
0000 562 :+
0000 563 : NET\$SCAN_CRI - Scan CRI database
0000 564 : NET\$SCAN_PLI - Scan PLI database
0000 565 :
0000 566 : This co-routine is used to scan the database, and return to the caller
0000 567 : (co-routine) for each entry in the database. These routines establish
0000 568 : the order of the database entries, above that of the natural ordering of
0000 569 : the collating field.
0000 570 :
0000 571 : Inputs:
0000 572 :
0000 573 : R11 = Address of CNR
0000 574 : R10 = Address of starting CNF (or 0 if to start at the beginning)
0000 575 :
0000 576 : Outputs:
0000 577 :
0000 578 : R10 = Address of CNF if dialogue aborted prematurely, else 0.
0000 579 :
0000 580 : The caller receives control on each database entry in list (via co-routine
0000 581 : call).
0000 582 :
0000 583 : On input to co-routine:
0000 584 :
0000 585 : R0 = True if entry was found. False if at end of list (R10 invalid)
0000 586 : R10 = Address of CNF entry found
0000 587 :
0000 588 : On output from co-routine:
0000 589 :
0000 590 : R0 = CNFS_ADVANCE Advance to next CNF, continue dialogue
0000 591 : CNFS_TAKE_PREV Return previous CNF, abort dialogue
0000 592 : CNFS_TAKE_CURR Return current CNF, abort dialogue
0000 593 : CNFS_QUIT Return no CNF (R10 = 0), abort dialogue
0000 594 :
0000 595 : *** These routines must be abortable via a RET ***
0000 596 :---
0000 597 :
0000 598 NET\$SCAN_CRI::
0000 599 NET\$SCAN_PLI::
FFF'D' 31 0000 600 BRW DEFAULT_SCAN ; Use default scanner with collating field

```

0003 602 .SBTTL NET$PRE_QIO_xxx - Pre-QIO processing
0003 603 :+
0003 604 : NET$PRE_QIO_CRI - Perform pre-QIO CRI database processing
0003 605 : NET$PRE_QIO_PLI - Perform pre-QIO PLI database processing
0003 606 :
0003 607 : This routine is called just after validating the NFB for a database
0003 608 : function to do any special pre-processing before the request is attempted.
0003 609 :
0003 610 : Here, for CRI and PLI databases, we reformat the search key into a standard
0003 611 : format for line and circuit names, so that we don't get two database entries
0003 612 : for DMC-0 and DMC-0.0, which should refer to the same entry.
0003 613 :
0003 614 : Inputs:
0003 615 :
0003 616 : R11 = Address of CNR
0003 617 : NET$GQ_SRCH_KEY = Descriptor of search key value
0003 618 : NET$GL_SRCH_ID = Field ID of search field.
0003 619 : NET$GQ_SRCH2_KEY = Descriptor of secondary search key value
0003 620 : NET$GL_SRCH2_ID = Field ID of secondary search field.
0003 621 :
0003 622 : Outputs:
0003 623 :
0003 624 : NET$GQ_SRCH_KEY = Reformatted search key value
0003 625 : NET$GQ_SRCH2_KEY = Reformatted secondary search key value
0003 626 :---
0003 627 :
0003 628 NET$PRE_QIO_CRI:::
07 11 000A 629 SCNFFLD cri,s,nam,R9 ; Get circuit name field i.d.
000C 630 BRB PREQIO_PRI_CRI ; Continue in common
000C 631 :
000C 632 NET$PRE_QIO_PLI:::
000C 633 SCNFFLD pli,s,nam,R9 ; Get line name field i.d.
0013 634 ; Fall thru to common code
0013 635 PREQIO_PRI_CRI:
0013 636 :
0013 637 : Rebuild SEARCH key if needed
0013 638 :
00000000'EF 59 D1 0013 639 CMPL R9,NET$GL_SRCH_ID ; Is the SEARCH key the name?
29 12 001A 640 BNEQ 10$ ; If NEQ no
57 00000000'EF 7D 001C 641 MOVQ NET$GQ_SRCH_KEY,R7 ; Get the SEARCH KEY descriptor
53 00000009'EF 9E 0023 642 MOVAB SRCH BUF,R3 ; Point to the SEARCH KEY buffer
00000000'EF 53 CE 002A 643 MNEGL R3,NET$GQ_SRCH_KEY ; Prepare for size calculation
00000004'EF 53 D0 0031 644 MOVL R3,NET$GQ_SRCH_KEY+4 ; Point to new SEARCH KEY string
0040 30 0038 645 BSBW REBUILD_NAME ; Rebuild the circuit name
3C 50 E9 003B 646 BLBC R0,210$ ; If LBC then error in name
00000000'EF 53 C0 003E 647 ADDL R3,NET$GQ_SRCH_KEY ; Calculate size of the string
0045 648 :
0045 649 : Rebuild secondary SEARCH key if needed
0045 650 :
00000000'EF 59 D1 0045 651 10$: CMPL R9,NET$GL_SRCH2_ID ; Is the secondary SEARCH key the name?
29 12 004C 652 BNEQ 100$ ; If NEQ no
57 00000000'EF 7D 004E 653 MOVQ NET$GQ_SRCH2_KEY,R7 ; Get the secondary search key descriptor
53 00000009'EF 9E 0055 654 MOVAB SRCH BUF,R3 ; Point to the SEARCH KEY buffer
00000000'EF 53 CE 005C 655 MNEGL R3,NET$GQ_SRCH2_KEY ; Prepare for size calculation
00000004'EF 53 D0 0063 656 MOVL R3,NET$GQ_SRCH2_KEY+4 ; Point to new SEARCH KEY string
000E 30 006A 657 BSBW REBUILD_NAME ; Rebuild the circuit name
0A 50 E9 006D 658 BLBC R0,210$ ; If LBC then error in name

```

```

00000000'EF 53 0070 659 ADDL R3,NET$GQ_SRCH2_KEY ; Calculate size of the string
50 00 0077 660 100$: MOVL S^#SSS_NORMAL,R0 ; Indicate success
05 007A 661 210$: RSB ; Return status in R0

007B 662
007B 663
007B REBUILD_NAME: ; Rebuild the name to canonical form
007B 664
007B 665
007B 666
007B 667
007B 668
007B 669
007B 670
007B 671
007B 672
007B 673
20 57 D1 007B 674 CMPL R7,#DEVNAM_C_SIZ ; Output name will be LEQ input name,
60 1A 007E 675 BGTRU 40$ ; If GTRU unsigned then may overflow buf
0080 676
0080 677
0080 678
0080 679
0080 680
0080 681
008A 682
008A 683
008A 684
008A 685
008A 686
08 0A A6 91 008A 687 CMPB DEVTRNSB_DEV(R6),#DEVTRNSC_DEV_X25 ; X.25 circuit name?
0A 0A 12 008E 688 BNEQ 1$ ; Branch if not
83 2D 90 0090 689 MOVBL "#A'-'",R4+ ; Move delimiter
63 68 57 28 0093 690 MOVC R7,(R8),(R3) ; Copy in rest of name
0073 31 0097 691 BRW 90$ ; Exit successfully
009A 692 1$: ; Move the controller i.d. -- suppress leading zeroes. If the device
009A 693 is not a "MULTI-plexed" device then the units field may not be
009A 694 present and the name may be end with the controller specifier field
009A 695 or it may end with either the units field or the tributary field or
009A 696 both. If the device is "MULTI-plexed" then the name must contain
009A 697 at least the units field following the controller specifier field.
009A 698
009A 699
54 2D 9A 009A 700 MOVZBL "#A'-'",R4 ; Setup the field delimiter
83 54 90 009D 701 MOVB R4,(R3)+ ; Enter it into the output buffer
00 E0 00A0 702 BBS #DEVTRNSV_MULTI,- ; If BS then multi-unit device
14 0C A6 00A2 703 DEVS DEVTRNSB_CHAR(R6),10$ ; Copy string descriptor
50 57 7D 00A5 704 MOVQ R7,R0 ; Any characters left
50 D7 00A8 705 5$: DECL R0 ; If LSS then no
0D 19 00AA 706 BLSS 10$ ; Delimited by a "-" ?
61 2D 91 00AC 707 CMPB "#A'-'",R1 ; If EQL yes
08 13 00AF 708 BEQL 10$ ; Delimited by a ":" ?
81 2E 91 00B1 709 CMPB "#A'.'",R1+ ; If NEQ then keep trying
F2 12 00B4 710 BNEQ 5$ ; Reset delimiter for parse
54 2E 9A 00B6 711 MOVZBL "#A'.'",R4 ; Get binary value of controller
134A 30 00B9 712 10$: BSBW PRS_DECIMAL ; If LBC then error
21 50 E9 00BC 713 BLBC R0,40$ ; Any decimal characters parsed?
52 D5 00BF 714 TSTL R2 ; If EQL no, error in name
1D 13 00C1 715 BEQL 40$ ; If NEQ then keep trying

```

```

50 51 00 00C3 716      MOVL R1, R0          ; Setup binary value to be converted
FF37' 30 00C6 717      BSBW NEf$BIN2ASC    ; Convert to ascii and insert
00C9 718
00C9 719
00C9 720
00C9 721      BBS #DEVTRNSV_MULTI,-
00CB 722      DEVTRNSB_CHAR(R6),50$ ; If BS then multi-unit device
00CE 723
00CE 724
00CE 725
54 2E 91 00CE 726      CMPB #^A'.'',R4   ; Did we already rule out a unit field?
25 13 00D1 727      BEQL 70$           ; If EQL then yes
54 2E 9A 00D3 728      MOVZBL #^A'.'',R4 ; Setup the field delimiter
132D 30 00D6 729      BSBW PRS_DECIMAL ; Get binary unit number
36 50 E9 00D9 730      BLBC R0,TO0$    ; If LBC then error
51 D5 00DC 731      TSTL R1           ; Single unit device, is it unit 0?
18 13 00DE 732      BEQL 70$           ; If EQL yes, process tributary field
30 11 00E0 733 40$: BRB 100$        ; Else error in name
00E2 734 50$:       :
00E2 735       : Device is a multi-unit device, move unit number field
00E2 736
83 2D 90 00E2 737      MOVB #^A'-'',(R3)+ ; Enter prefix to unit number field
54 2E 9A 00E5 738      MOVZBL #^A'.'',R4 ; Setup the field delimiter
131B 30 00E8 739      BSBW PRS_DECIMAL ; Get binary unit number
24 50 E9 00EB 740      BLBC R0,TO0$    ; If EQL then error
52 D5 00EE 741      TSTL R2           ; Any decimal characters parsed?
20 13 00F0 742      BEQL 100$        ; If EQL then error
50 51 00 00F2 743      MOVL R1, R0          ; Get binary value for ascii conversion
FF08' 30 00F5 744      BSBW NEf$BIN2ASC ; Move as ascii @R3
00F8 745 70$:       :
00F8 746       : Process the tributary field. If this is the CRI database then move
00F8 747       : the remainder of the name (unfortunately we cannot determine if a
00F8 748       : tributary specifier is valid for this device yet since we cannot
00F8 749       : determine for sure if the device is to be run in the multi-drop or
00F8 750       : point-to-point mode until later on in the QIO cycle).
00F8 751
0A 04 91 00F8 752      CMPB #NFBSC_DB_CRI,- ; Circuit database ?
AB 04 13 00FA 753      CNRSB_TYPE(R11)   ; If EQL yes
04 13 00FC 754      BEQL 80$           ; Else there must be no characters left
57 D5 00FE 755      TSTL R7           ; If NEQ then illegal name
10 12 0100 756      BNEQ 100$        ; Any characters left?
57 D5 0102 757 80$: TSTL R7           ; If EQL no, return success
07 13 0104 758      BEQL 90$           ; Enter delimiter
83 2E 90 0106 759      MOVB #^A'.'',(R3)+ ; Enter remaining characters, update R3
63 68 57 28 0109 760      MOVC3 R7,(R8),(R3)
50 00' 00 010D 761 90$: MOVL S$#SS$_NORMAL,R0 ; Indicate success
05 11 0110 762      BRB 110$         ; Take common exit
0112 763
50 0000'8F 3C 0112 764 100$: MOVZHL #SS$_IVDEVNAM,R0 ; Indicate invalid device name
05 0117 765 110$: RSB            ; Return status in R0

```

```

0118 767 .SBTTL NET$SHOW_xxx - Pre-SHOW processing
0118 768 :+
0118 769 : NET$SHOW_CRI - Show QIO pre-processing for CRI database
0118 770 : NET$SHOW_PLI - Show QIO pre-processing for PLI database
0118 771 :
0118 772 : This routine is called for each CNF which is about to be returned
0118 773 : to a "show" QIO. For the CRI and PLI databases, we must "update"
0118 774 : the fields reflecting datalink driver status, by issuing a SENSEMODE
0118 775 : QIO to the driver, and taking it's current values for datalink parameters
0118 776 : and storing them into the CNF. This makes both the CNF and the driver
0118 777 : consistent.
0118 778 :
0118 779 : Inputs:
0118 780 :
0118 781 : R11 = Address of CNR
0118 782 : R10 = Address of CNF
0118 783 :
0118 784 : Outputs:
0118 785 :
0118 786 : R0 = Status code
0118 787 :
0118 788 : The CNF may be updated.
0118 789 ;-
0118 790 :
55 00000104'EF 9E 0118 791 NET$SHOW_CRI:: : "Show" QIO pre-processing for one CNF
      023E 30 0118 792 MOVAB CRI_CLR_TAB,R5 : Get table of params to clear
03 08 50 E9 0122 793 BSBW CLEAR_VOLATILE : Clear volatile parameters
      58 D1 0122 794 :
      03 12 0132 795 : If this is an X.25 circuit, then ask PSI for its parameter values
      03 12 0135 796 :
      0147 31 0137 797 $GETFLD cri,l,typ : Get type of circuit
      013A 800 BLBC R0,5$ : Branch if not set
      013A 801 CMPL R8,#NMASC_CIRTY_X25 : X.25 circuit?
      013A 802 BNEQ 5$ : Branch if not
      013A 803 BRW GET_PSI_CRI : Get current PSI parameter values
      013A 804 :
      FEC3' 30 013A 805 5$: BSBW NET$LOCATE_LPD : Get LPD associated with this CRI
      18 50 E9 013D 806 BLBC R0,10$ : If EQL then none
      58 28 A6 9A 0140 807 MOVZBL LPDSB_PLVEC(R6),R8 : Get PLVEC index
      12 13 0144 808 BEQL 10$ : Skip if none assigned
      53 14 A6 3C 0146 809 MOVZWL LPDSW_CHAN(R6),R3 : Get I/O channel
      54 0000'8F 3C 014A 810 MOVZWL #IOS_SENSEMODE,R4 : Get I/O function code
      0000016C'EF 9E 014F 811 MOVAB CRI_TRN_TAB,R6 : Get table for NICIE param translation
      46 11 0156 812 BRB SHO_PLI_CRI : Pre-process the CRI CNF block
      0158 813 :
      50 01 D0 0158 814 10$: MOVL #1,R0 : Report success - return parameters
      05 0158 815 RSB :
      015C 816 :
55 000000FC'EF 9E 015C 817 NET$SHOW_PLI:: : "Show" QIO pre-processing for one CNF
      01FA 30 015C 818 MOVAB PLI_CLR_TAB,R5 : Get table of params to clear
0166 819 BSBW CLEAR_VOLATILE : Clear volatile parameters
      0166 820 :
      0166 821 : If this is a LAPB line, ask PSIACP for it's parameter values
      0166 822 $GETFLD pli,l,pro : Get protocol parameter value
      0166 823
  
```

```

08 50 E9 0173 824 BLBC R0,5$ ; If not specified, skip it
05 58 D1 0176 825 CMPL R8,#NMASC_LINPR_LAPB ; LAPB line?
03 12 0179 826 BNEQ 5$ ; Branch if not
0149 31 017B 827 BRW GET_PSI_PLI ; Get current PSI PLI parameter values
017E 828
017E 829 : Ask the datalink driver for it's parameter values
017E 830
50 12 AA 3C 017E 831 5$: MOVZWL CNF$W_ID(R10),R0 ; Get PLVEC index
16 13 0182 832 BEQL 10$ ; If EQL then none assigned
53 00000000'EF40 80 0184 833 MOVW PLVECSAW_CHAN[R0],R3 ; Get I/O channel
54 0000'8F 80 018C 834 MOVW #IOS_SENSEMODE!IO$M_CTRL,R4 ; Get QIO function code
56 000001B8'EF 9E 0191 835 MOVAB PLI_TRN_TAB,R6 ; Get table for NICe param translation
04 11 0198 836 BRB SHO_PLI_CRI
019A 837
50 01 D0 019A 838 10$: MOVL #1,R0 ; Report success - return parameters
05 019D 839 RSB
019E 840
019E 841 SHO_PLI_CRI:
019E 842
019E 843 : Get a list of parameters from the driver
019E 844
00000029'EF 7C 019E 845 CLRQ QIOW_Q_IOSB ; Init IOSB image
01A4 846 $QIOW_S - ; Issue QIO to get device info
01A4 847 EFN = #NETSC_EFN_WAIT,-
01A4 848 CHAN = R3,-
01A4 849 FUNC = R4,-
01A4 850 IOSB = QIOW_Q_IOSB,-
01A4 851 P2 = #TMPBUF_DESC
1A 50 E9 01C7 852 BLBC R0,100$ ; If LBC asume unsupported by driver
13 00000029'EF E9 01CA 853 BLBC QIOW_Q_IOSB,100$ ; If LBC assume unsupported by driver
0B 0000002D'EF 0B E1 01D1 854 BBC #XMSV_STS_ACTIVE,QIOW_Q_IOSB+4,100$ ; Skip if datalink not active
54 C0000004'EF D0 01D9 855 MOVL TMPBUF_DESC+4,R4 ; Point to parameter list
06 10 01E0 856 BSB8 JAM CNF ; Stuff the params into the CNF block
03 11 01E2 857 BRB 110$ ; Take common exit
50 01 D0 01E4 858 100$: MOVL #1,R0 ; Report success
05 01E7 859 110$: RSB ; Return status in R0

```

01E8 861 .SBTTL JAM_CNF - Store driver values into CNF
 01E8 862 :+
 01E8 863 JAM_CNF - Store datalink driver parameters into CNF
 01E8 864 :
 01E8 865 This routine updates the CNF with the latest and greatest parameter
 01E8 866 values from the datalink driver.
 01E8 867 :
 01E8 868 Inputs:
 01E8 869 :
 01E8 870 R11 = Address of CNR
 01E8 871 R10 = Address of CNF
 01E8 872 R6 = Address of datalink-NICE translation table
 01E8 873 R4 = Address of buffer returned by SENSEMODE
 01E8 874 QIOW_Q_IOSB = IOSB from SENSEMODE operation
 01E8 875 :
 01E8 876 Outputs:
 01E8 877 :
 01E8 878 R0 = Status code
 01E8 879 :-
 01E8 880 .ENABL LSB
 01E8 881 :
 00000000'EF DD 01E8 882 JAM_CNF:
 01E8 883 PUSHL NET\$GL_FLAGS ; Save current flags
 01EE 884 CLRBIT NET\$V_CNFLCK,NET\$GL_FLAGS ; Allow update of cond. write fields
 01F6 885 :
 01F6 886 : Jam the values from the QIO buffer one at time into the CNF block.
 01F6 887 :
 0000002B'EF B5 01F6 888 10\$: TSTW QIOW_Q_IOSB+2 ; Any params left?
 66 13 01FC 889 BEQL 110\$; If EQL we're done
 70 10 01FE 890 BSSB TAKE 2 IOSB ; See if we have two bytes left
 59 84 3C 0200 891 MOVZWL (R4)T,R9 ; Get NICE protocol param i.d. + type
 55 56 D0 0203 892 MOVL R6,R5 ; Point to translation table
 1136 30 0206 893 BSBW CVT_NMA_INT ; Convert NMA i.d. to internal i.d.
 2C 50 E9 0209 894 BLBC R0,70\$; If LBC then not found
 02 59 02 10 ED 020C 895 CMPZV #NFBSS_TYP,#NFBSS_TYP,R9,#NFBSC_TYP STR ; Is it a string ?
 JA 13 0211 896 BEQL 50\$; If EQL yes
 0213 897 :
 0213 898 : It's a longword
 0213 899 :
 57 04 D0 0213 900 MOVL #4,R7 ; We'll take 4 more bytes
 58 10 0216 901 BSSB TAKE R7 IOSB ; Deplete IOSB count
 58 84 D0 0218 902 MOVL (R4)T,R8 ; Get the value
 OF 11 021B 903 BRB 60\$; Continue
 021D 904 :
 021D 905 : It's a string
 021D 906 :
 57 51 10 021D 907 50\$: BSSB TAKE 2 IOSB ; Account for count field
 57 84 32 021F 908 CVTWL (R4)T,R7 ; Get string size
 45 19 0222 909 BLSS 120\$; If LSS then string is too long
 58 54 D0 0224 910 MOVL R4,R8 ; Point to string
 54 57 C0 0227 911 ADDL R7,R4 ; Skip over it
 47 10 022A 912 BSSB TAKE R7 IOSB ; Deplete bytes for string
 3FFF 8F 59 B1 022C 913 60\$: CMPW R9,#CNVTABSC_INTRNL ; Datalink only parameter?
 C3 13 0231 914 BEQL 10\$; If so, just ignore it
 FDEA. 30 0233 915 BSBW CNF\$PUT_FIELD ; Store it in the CNF
 BE 11 0236 916 BRB 10\$; Ignore errors - field might be R/O
 BE 11 0236 917 : Loop through all parameters

		0238	918			
		0238	919	;	Parameter is not found in tables, skip it if present in buffer	
		0238	920			
0000002B'EF 08 59 0C	B5 E0	0238 023E	921 922	70\$: fSTW BBS	QIOW_Q_IOSB+2 #12,R9,80\$; Deplete bytes ; Br if string value
		0242	923			
		0242	924			
		0242	925			
57 04 20 54 04 FFA9	D0 10 C0 31	0242 0245 0247 024A	926 927 928 929	MOVL BSBB ADDL BRW	#4,R7 TAKE_R7_IOSB #4,R4 10\$; We'll take 4 more bytes ; Deplete IOSB count ; Skip valued parameter ; Get rest of buffer
		024D	930			
		024D	931			
		024D	932			
57 21 84 15 54 57 1A FF9A	10 32 19 C0 31	024D 024F 0252 0254 0259	933 934 935 936 938	BSBB CVTWL BLSS ADDL BSBB BRW	TAKE_2_IOSB (R4)+,R7 120\$ R7,R4 TAKE_R7_IOSB 10\$; Account for count field ; Get string size ; If LSS then string is too long ; Skip over it ; Deplete bytes for string ; Get rest of buffer
00000000'EF	8ED0 05	025C 0263	940 941	100\$: POPL RSB	NET\$GL_FLAGS	; Restore flags ; Return status in R0
		0264	942			
50 01 F3	D0 11	0264 0267	943 944	110\$: MOVL BRB	#1,R0 100\$; Return success
50 0000'8F	3C EC	0269 026E	945 947	120\$: MOVZWL BRB	#SSS_RESULTOVF,R0 100\$; Indicate buffer error
		0270	948			
57 02	3C	0270 0273	949 950	TAKE_2_IOSB: MOVZWL #2,R7		, Setup bytes to take
0000002B'EF	57 04 8E E9	A2 18 D5 11 05	0273 027A 027C 027E 0280	951 TAKE_R7_IOSB: SUBW BGEQ TSTL	R7,QIOW_Q_IOSB+2 200\$ (SP)+	; Deplete bytes ; If GEQ then okay ; Pop caller's return address
		J281	955	BRB	120\$; Exit with buffer error
		0281	956 200\$:	RSB		
		0281	957			
		0281	958	.DSABL	LSB	

```

0281 960 .SBTTL GET_PSI_xxx - Get current PSI parameter values
0281 961 :+
0281 962 : GET_PSI_CRI - Get current PSI circuit parameter values
0281 963 : GET_PSI_PLI - Get current PSI line parameter values
0281 964 :
0281 965 : This routine is called to get the current PSI parameter values
0281 966 : from it's database, and store them in ours, so the SHOW function returns
0281 967 : the sum of both databases.
0281 968 :
0281 969 : Inputs:
0281 970 :
0281 971 : R11 = CRI CNR address
0281 972 : R10 = CRI CNF address
0281 973 :
0281 974 : Outputs:
0281 975 :
0281 976 : R0 = status
0281 977 :
0281 978 GET_PSI_CRI:
0281 979 :
0281 980 : If this is a PVC, then go ahead and ask PSI. If it's a
0281 981 : incoming or outgoing SVC, then don't bother, since PSI
0281 982 : doesn't know anything about them.
0281 983 :
0281 984 $GETFLD cri,l,use : Get USAGE parameter
0281 985 BLBC R0,5$ : Branch if not set - defaulting error
0281 986 CMPL R8,#NMASC_CIRUS_PER : PVC?
0281 987 BEQL 10$ : If not, then exit successfully
0281 988 5$: MOVL #1,R0 : Do nothing
0281 989 RSB
029A 990 :
029A 991 : Issue a SHOW function to PSI for its circuit parameters
029A 992 :
029A 993 10$: $CNFFLD cri,s,nam,R9 : Set field ID of circuit name
029A 994 BSRW SEND_TO_PSI : Call co-routine to setup NFB, etc.
029A 995 BLBC R0,90$ : Branch if error detected
029A 996 MOVB #NFBSC_FC_SHOW_NFBsb_Fct(R6) : Set function code
029A 997 PUSHR #^M<R2,R3,R4,R5> : Save registers
029A 998 ASSUME NFBSC_ENDOFLIST EQ 0 : NFB terminator and PSI_TAB are same
029A 999 MOVC #CRI_PSI_SIZ,CRI_PSI_TAB,(R2) : Copy in the field IDs
029A 1000 POPR #^M<R2,R3,R4,R5> : Restore registers
029A 1001 MOVAB CRI_PSI_SIZ(R2),R2 : Increment field ID list pointer
029A 1002 ADDL #P4BUF_SIZE,R3 : Set size of P4 return buffer
029A 1003 JSB a(SP)+ : Call SEND_TO_PSI back to issue QIO
029A 1004 BLBS R0,STORE_PSI_PARAMS : Branch if ok
029A 1005 90$: RSB : Return with error
029A 1006 :
029A 1007 GET_PSI_PLI:
029A 1008 :
029A 1009 : Issue a SHOW function to PSI for its line parameters
029A 1010 :
029A 1011 $CNFFLD pli,s,nam,R9 : Set field ID of circuit name
029A 1012 BSBW SEND_TO_PSI : Call co-routine to setup NFB, etc.
029A 1013 BLBC R0,90$ : Branch if error detected
029A 1014 MOVB #NFBSC_FC_SHOW_NFBsb_Fct(R6) : Set function code
029A 1015 PUSHR #^M<R2,R3,R4,R5> : Save registers
029A 1016 ASSUME NFBSC_ENDOFLIST EQ 0 : NFB terminator and PSI_TAB are same

```

62	00000134'EF	38	28	02D9	1017	MOVC	#PLI_PSI_SIZ,PLI_PSI_TAB,(R2)	; Copy in the field IDs	
		3C	BA	02E1	1018	POPR	#^M<R2,R3,R4,R5>	; Restore registers	
53	00000200'8F	52 38 A2	9E	02E3	1019	MOVAB	PLI_PSI_SIZ(R2),R2	; Increment field ID list pointer	
		9E	C0	02E7	1020	ADDL	#P4BUF_SIZE,R3	; Set size of P4 return buffer	
		01 50	16	02EE	1021	JSB	@(SP)+	; Call SEND_TO_PSI back to issue QIO	
		05	E8	02F0	1022	BLBS	R0,STORE_PSI_PARAMS	; Branch if ok	
		02F4	02F3	1023	90\$:	RSB		; Return with error	
		02F4	02F4	1024					
		02F4	02F4	1025	STORE_PSI_PARAMS:				
		02F4	02F4	1026					
		02F4	02F4	1027					
		02F4	02F4	1028					
		56 54 57	7D	02F4	1029	MOVQ	R7,R4	; Make copy of result descriptor	
		56 10 A6	9E	02F7	1030	MOVAB	NFB\$L_FLDID(R6),R6	; Point to field ID list	
		0200 8F	BB	02FB	1031	PUSHR	#^M<R9>	; Save registers	
		00000000'EF	DD	02FF	1032	PUSHL	NET\$GL_FLAGS	; Save ACP flags	
				0305	1033	CLRBIT	NET\$V_CNFLCK,NET\$GL_FLAGS	; Allow update of cond. write fields	
		59 86	J0	0300	1034	20\$:	MOVL	(R6)+,R9	; Get next field ID
		34	13	0310	1035	BEQL	80\$; Branch if end of list	
02	59 02	10	ED	0312	1036	CMPZV	#NFB\$V_TYP,#NFB\$S_TYP,R9	; Is it a string?	
		OC	13	0317	1037	BEQL	30\$; Branch if so	
		54 C4	C2	0319	1038	SUBL	#4,R4	; Decrement buffer space left	
		21	19	031C	1039	BLSS	70\$; Branch if not enough space returned	
		58 85	DD	031E	1040	MOVL	(R5)+,R8	; Get longword value	
		EA	19	0321	1041	BLSS	20\$; Branch if "cleared"	
		15	11	0323	1042	BRB	50\$; Store parameter	
		54 02	C2	0325	1043	30\$:	SUBL	#2,R4	; Decrement space left
		15	19	0328	1044	BLSS	70\$; Branch if not enough space returned	
		57 85	3C	032A	1045	MOVZWL	(R5)+,R7	; Get length of string	
		DE	13	032D	1046	BEQL	20\$; Branch if "cleared"	
		54 57	C2	032F	1047	SUBL	R7,R4	; Decrement space left	
		08	19	0332	1048	BLSS	70\$; Branch if not enough space returned	
		58 55	DD	0334	1049	MOVL	R5,R8	; Point to start of string	
		55 57	CO	0337	1050	ADDL	R7,R5	; Skip past string	
		FCC3'	30	033A	1051	50\$:	BSBW	CNF\$PUT_FIELD	; Store the parameter
		CE	11	033D	1052	BRB	20\$; Loop thru all parameters	
				033F	1053				
50	0000'8F	3C	033F	1054	70\$:	MOVZWL	#SSS_RESULTOVF,R0	; Set overflow status	
		03	11	0344	1055	BRB	90\$		
				0346	1056				
		50 01	D0	0346	1057	80\$:	MOVL	#1,R0	
		51 50	D0	0349	1058	90\$:	MOVL	R0,R1	; Save final status
		00000000'EF	8ED0	034C	1059	POPL	NET\$GL_FLAGS	; Restore ACP flags	
		50 50	8ED0	0353	1060	POPL	RO	; Point to scratch storage	
		00000000'EF	16	0356	1061	JSB	NET\$DEALLOCATE	; Deallocate SHOW buffer	
		50 51	D0	035C	1062	MOVL	R1,R0	; Restore final status	
			05	035F	1063	RSB			

0360 1065 .SBTTL CLEAR_VOLATILE - Clea list of volatile parameters
0360 1066 :+
0360 1067 :+ CLEAR_VOLATILE - Clear list of volatile parameters from a CNF
0360 1068 :+
0360 1069 :+ This routine is called with a list of parameters to be cleared so
0360 1070 :+ that stale data is not kept in a CNF block.
0360 1071 :+
0360 1072 :+ Inputs:
0360 1073 :+
0360 1074 :+ R11 = Address of CNR
0360 1075 :+ R10 = Address of CNF
0360 1076 :+ R5 = Address of list of longword parameter IDs
0360 1077 :+
0360 1078 :+ Outputs:
0360 1079 :+
0360 1080 :+ None
0360 1081 :+
0360 1082 CLEAR_VOLATILE:
59 85 00 0360 1083 10\$: MOVL (R5)+,R9 ; Get next parameter i.d.
05 13 0363 1084 BEQL 20\$; If EQL then none left
FC98' 30 0365 1085 BSBW CNF\$CLR_FIELD ; Clear param i.. CNF, ignore errors
F6 11 0368 1086 BRB 10\$; Loop
05 036A 1087 20\$: RSB

```

036B 1089 .SBTTL NET$DEFAULT_CRI - Apply default values
036B 1090 :+
036B 1091 : NET$DEFAULT_CRI - Apply default values to selected CNF parameters.
036B 1092 :
036B 1093 : This routine is called by CNF$INSERT just prior to validating a CNF
036B 1094 : entry which is to be inserted into the database. Its purpose is to
036B 1095 : supply default values to selected parameters.
036B 1096 :
036B 1097 : INPUTS: R11 CNR pointer
036B 1098 : R10 CNF pointer
036B 1099 :
036B 1100 : OUTPUTS: R11 CNR pointer
036B 1101 : R10 CNF pointer
036B 1102 : R0 Status code.
036B 1103 :
036B 1104 :
036B 1105 : All other registers contain garbage.
036B 1106 NET$DEFAULT_CRI:::
FC92' 30 036B 1107 BSBW NET$APPLY_DFLT ; Apply standard table defaults
103F 30 036E 1108 $GETFLD cri,s,nam ; Get descriptor of circuit name
75 50 E9 037B 1109 BSBW PRS_MNEMONIC ; Locate the table entry
          037E 1110 BLBC R0,T0$ ; If not found, assume DDCP
          0381 1111 :
          0381 1112 :
          0381 1113 :
          0381 1114 :
          0381 1115 :
          0381 1116 :
          0381 1117 :
          0381 1118 :
          0381 1119 :
          0381 1120 :
          0381 1121 :
          0381 1122 :
          0381 1123 :
          0381 1124 :
          0381 1125 :
          0381 1126 :
          0381 1127 :
          03A1 1128 :
          03A1 1129 :
          03A1 1130 :
          03A9 1131 :
          03AB 1132 4$: BRB 5$ ; If X.25 datalink mapping is enabled, then apply the Transport
          03AE 1133 : MOVL #1,R8 ; defaults.
          0388 1134 :
          0388 1135 :
          0388 1136 :
          0388 1137 :
          0388 1138 5$: $GETFLD cri,v,dlm ; Is X.25 datalink mapping enabled?
          51 50 E9 03C8 1139 BLBC R0,80$ ; Branch if not
          4E 58 E9 03C8 1140 BLBC R8,80$ :
          56 00000000'EF 9E 03CE 1141 MOVAB NET$G_CRI_DLM,R6 ; Get address of DLM defaults
          FC28' 30 03D5 1142 BSBW NET$TABLE_DFLT ; Apply the default values
          02 58 D1 03D8 1143 $GETFLD cri,l,use ; Get circuit usage
          28 12 03E8 1144 CMPL R8,#NMASC_CIRUS_OUT ; Outgoing circuit?
          BNEQ 20$ ; Skip if not
    
```

56 00000000'EF, 9E 03EA 1146 MOVAB NET\$G_CRI_DLMOUT,R6 ; Get address of outgoing DLM defaults
FC0C, 30 03F1 1147 BSBW NET\$TABLE_DFLT ; Apply the default values
1C 11 03F4 1148 BRB 20\$; then apply Transport defaults
03F6 1149
03F6 1150 ; If it's a NI circuit, then apply the appropriate defaults
03F6 1151
09 0A A6 91 03F6 1152 10\$: CMPB DEVTRNSB_DEV(R6),#DEVTRNSC_DEV_UNA ; Is it an NI circuit?
FBFA, 12 03FA 1153 BNEQ 15\$; If not, skip it
56 00000000'EF, 9E 03FC 1154 MOVAB NET\$G_CRI_NI,R6 ; Get address of NI circuit defaults
FBFA, 30 0403 1155 BSBW NET\$TABLE_DFLT ; Apply the default values
OA 11 0406 1156 BRB 20\$; Apply Transport defaults as well
0408 1157
0408 1158 ; For DDCMP circuits, apply another set of default values
0408 1159
56 00000000'EF, 9E 0408 1160 15\$: MOVAB NET\$G_CRI_DDCMP,R6 ; Get address of DDCMP circuit defaults
FBEE, 30 040F 1161 BSBW NET\$TABLE_DFLT ; Apply the default values
0412 1162
0412 1163 ; For circuits used by Transport, then apply the Transport defaults.
0412 1164
56 00000000'EF, 9E 0412 1165 20\$: MOVAB NET\$G_CRI_TRN,R6 ; Get address of transport defaults
FBE4, 30 0419 1166 BSBW NET\$TABLE_DFLT ; Apply the default values
50 01 D0 041C 1167 80\$: MOVL #1,R0 ; Return successful
05 041F 1168 RSB

```

0420 1170 .SBTTL NET$DEFAULT_PLI - Apply default values
0420 1171 :+
0420 1172 : NET$DEFAULT_PLI - Apply default values to selected CNF parameters.
0420 1173 :
0420 1174 : This routine is called by CNFS$INSERT just prior to validating a CNF
0420 1175 : entry which is to be inserted into the database. Its purpose is to
0420 1176 : supply default values to selected parameters.
0420 1177 :
0420 1178 : INPUTS: R11 CNR pointer
0420 1179 : R10 CNF pointer
0420 1180 :
0420 1181 : OUTPUTS: R11 CNR pointer
0420 1182 : R10 CNF pointer
0420 1183 : R0 Status code
0420 1184 :
0420 1185 : All other registers contain garbage.
0420 1186 :
0420 1187 NET$DEFAULT_PLI:::
FBDD' 30 0420 1188 9SBQ NET$APPLY_DFLT : Apply standard table defaults
0F8A 30 0423 1189 $GETFLD pli.s.nam : Get descriptor of line name
01 50 E8 0430 1190 BSBW PRS MNEMONIC : Locate the table entry
05 0433 1191 BLBS R0,TOS : If found, proceed
05 0436 1192 RSB : Else, not found
0437 1193 10$: :
0437 1194 : If the protocol is not specified yet, stuff it's default value
0437 1195 : based on the line name mnemonic.
0437 1196 :
0437 1197 $GETFLD pli.l.pro : Was protocol explicitly specified?
58 0D 50 E8( 0444 1198 BLBS R0,20$ : If so, don't change it
0B A6 9A 0447 1199 MOVZBL DEVTRNSB PROT(R6),R8 : Get default protocol type
FF 8F 58 91 0448 1200 CMPB R8 #NMASC_LINPR_ : Is there a default protocol?
03 13 044F 1201 BEQL 20$ : Branch if not
FBAC' 30 0451 1202 BSBW CNF$PUT_FIELD : Store the protocol into the CNF
0454 1203 :
0454 1204 : Based on the type of line protocol, apply a different set of
0454 1205 : defaults for each type.
0454 1206 :
0A A6 91 0454 1207 20$: CMPB DEVTRNSB DEV(R6),- : Is this a "point-to-point" XE?
0A 0457 1208 #DEVTRNSC_DEV_PPUNA :
3C 13 0458 1209 BEQL 50$ : If so, use NI defaults
4E 50 E9 045A 1210 SGETFLD pli.l.pro : Get line protocol type
0467 1211 BLBC R0,80$ : If none, then no defaults
046A 1212 $DISPATCH R8,<- : Based on line protocol,
046A 1213 <NMASC_LINPR_POI,30$>- : DDCMP Point-to-point
046A 1214 <NMASC_LINPR_CON,30$>- : DDCMP Controller station
046A 1215 <NMASC_LINPR_TRI,30$>- : DDCMP Tributary
046A 1216 <NMASC_LINPR_DMC,30$>- : DDCMP DMC compatible mode
046A 1217 <NMASC_LINPR_LAPB,40$>- : X.25 LAPB protocol
046A 1218 <NMASC_LINPR_NI,50$>> : NI protocol
3A 11 047C 1219 BRB 80$ : If none of the above, then skip it
047E 1220 :
047E 1221 : Apply DDCMP defaults
047E 1222 :
56 00000000'EF, 9E 047E 1223 30$: MOVAB NET$G_PLI_DDCMP,R6 : Get address of DDCMP defaults
FB78' 30 0485 1224 BSBW NET$TABLE_DFLT : Apply default values
2E 11 0488 1225 BRB 80$ :
048A 1226 :

```

048A 1227 : Apply LAPB defaults
048A 1228
56 00000000'EF, 9E 048A 1229 40\$: MOVAB NET\$G_PLI_LAPB,R6 ; Get address of LAPB defaults
FB6C' 30 0491 1230 BSBW NET\$TABLE_DFLT ; Apply default values
22 11 0494 1231 BRB 80\$
0496 1232
0496 1233 : Apply NI defaults
0496 1234
56 00000000'EF, 9E 0496 1235 50\$: MOVAB NET\$G_PLI_NI,R6 ; Get address of NI defaults
FB60' 30 049D 1236 BSBW NET\$TABLE_DFLT ; Apply default tables
04A0 1237
04A0 1238 : For NI lines, add the "hardware address" parameter at this time,
04A0 1239 : so that there is enough space reserved in the CNF block for future
04A0 1240 : replacements of the value by the datalink layer. Initially, it
04A0 1241 : will have the value of 6 bytes of binary zero. This is done here
04A0 1242 : because the defaulting tables don't handle string defaults.
04A0 1243
57 7E 7C 04A0 1244 CLRQ -(SP) ; Zero 8 byte buffer
57 06 D0 04A2 1245 MOVL #6,R7 ; Set length of string to 6 bytes
58 SE D0 04A5 1246 MOVL SP,R8 ; Point to buffer of 8 null bytes
5E 08 C0 04B5 1248 SPUTFLD pli,s,hwa ; Allocate space for NI hardware address
50 01 D0 04B8 1249 80\$: ADDL #8,SP ; Deallocate buffer
05 04B8 1250 90\$: MOVL #1,RO ; Return successful
RSB

```

04BC 1252      .SBTTL NET$INSERT_CRI - Pre-insertion processing
04BC 1253      ;+
04BC 1254      ; NET$INSERT_CRI - Insert CRI entry into database
04BC 1255      ;
04BC 1256      ; This routine is called to validate a CRI CNF entry before inserting
04BC 1257      ; it into the database.
04BC 1258      ;
04BC 1259      ; Inputs:
04BC 1260      ;
04BC 1261      ; R11 = Address of CNR
04BC 1262      ; R10 = Address of CNF
04BC 1263      ;
04BC 1264      ; Outputs:
04BC 1265      ;
04BC 1266      ; R0 = Status code. If error, entry is not inserted.
04BC 1267      ;-
04BC 1268      NET$INSERT_CRI::
04BC 1269      CLRL -(SP)          ; Scratch space on stack for STATE
04BE 1270      MOVZWL #SS$INSFARG,R0   ; Set error if parameter not present
04C3 1271      $GETFLD cri_l,sta    ; Get the operator state
04D0 1272      BLBS R0,5$          ; Error if not already defaulted
04D3 1273      BRW 200$           ; Exit with status
04D6 1274      MOVL R8,(SP)        ; Save new STATE value
04D9 1275      ;
04D9 1276      ; If STATE=SERVICE, then make sure that SERVICE is ENABLED.
04D9 1277      ;
04D9 1278      $GETFLD cri_v,ser    ; See if service functions are enabled
04E6 1279      BLBC R0,10$         ; Branch if parameter not set
04E9 1280      BLBC R8,10$         ; If LBC then "service" state is legal
04EC 1281      MOVL #SS$BADPARAM,R0  ; Assume state is "service"
04F3 1282      CMPL (SP),#NMASC_STATE_SER ; Is it?
04F6 1283      BEQL 200$           ; If so then conflicts with <cri,v,ser>
04F8 1284      ;
04F8 1285      ; Make sure that the circuit name is valid
04F8 1286      ;
50  D4 04F8 1287 10$: CLRL R0          ; No default error status
04FA 1288      $GETFLD cri_s,vmsnam  ; Check if circuit name is valid
66 50 E9 0507 1289      BLBC R0,200$       ; If LBC then error
050A 1290      ;
050A 1291      ; If the circuit type associated with this CNF is X25, then ship
050A 1292      ; the X.25 specific circuit parameters to PSIACP via a control QIO.
050A 1293      ; If the QIO succeeds, then allow the CNF to be inserted. In
050A 1294      ; either case, we do not perform any datalink processing.
050A 1295      ;
050A 1296      $GETFLD cri_l,typ     ; Get circuit type
0517 1297      BLBC R0,25$          ; If error, assume not X.25
051A 1298      CMPL R8,#NMASC_CIRTY_X25 ; X25 circuit?
051D 1299      BEQL 28$            ; Branch if so
051F 1300      PUSHL R10          ; Save pointer to current CNF
0521 1301      MOVL R6,R10        ; Point to old version of CNF
0524 1302      BEQL 26$            ; Branch if none
0526 1303      $GETFLD cri_l,typ     ; Get old circuit type
0533 1304      BLBC R0,26$          ; If error, assume still not X.25
0536 1305      CMPL R8,#NMASC_CIRTY_X25 ; Did it used to be X25?
0539 1306      BNEQ 26$            ; Branch if not
50  3C 053B 1307      MOVZWL #SS$WRITLCK,R0  ; Do not allow type change w/o CLEAR
0540 1308      POPL R10          ; Restore current CNF

```

5A 05 0543 1309 RSB ; Return - do not allow insertion
 8ED0 0544 1310 26\$: POPL ; Restore current CNF
 18 11 0547 1311 BRB ; and allow Transport to use it
 0549 1312
 28 10 0549 1313 28\$: BSBB ; Tell it to PSIACP
 50 E9 054B 1314 BLBC ; Exit if error detected
 054E 1315
 054E 1316 ; For X.25 circuits, do not initialize the circuit if we haven't
 054E 1317 ; been granted ownership of it by the network manager. This
 054E 1318 ; prevents the circuit from being used both by native mode X.25
 054E 1319 ; users and by Transport.
 054E 1320
 OC 50 E9 054E 1321 29\$: \$GETFLD cri_v_DLM ; X.25 datalink mapping enabled?
 09 58 E9 055B 1322 BLBC ; If not set, do not use this circuit
 055E 1323 BLBC ; If disabled, do not use this circuit
 0561 1324
 0561 1325 ; Call Transport to init circuit
 0561 1326 ; Signal datalink control module that the CRI has been changed
 0561 1327
 58 6F D0 0561 1328 50\$: MOVL ; Get STATE value
 FA99' 30 0564 1329 RSBW ; Signal operator event
 06 50 E9 0567 1330 BLBC ; If LBC then error
 056A 1331
 056A 1332 ; Start counter timer ticking
 056A 1333
 50 FA93' 30 056A 1334 60\$: BSBW ; Reset automatic counter timer
 01 D0 056D 1335 MOVL ; Indicate success
 8E D5 0570 1336 200\$: TSTL ; Cleanup the stack
 05 0572 1337 RSB ; Return status in R0

```

0573 1339 .SBTTL CRI_TO_PSI - Send CRI parameters to PSIACP
0573 1340 :+ CRI_TO_PSI - Issue SET of CRI parameters to PSIACP
0573 1341 : Send the CRI parameters that PSIACP cares about via a ACP control QIO.
0573 1342 :
0573 1343 :
0573 1344 :
0573 1345 : Inputs:
0573 1346 :
0573 1347 : R11 = Address of CNR
0573 1348 : R10 = Address of CNF
0573 1349 :
0573 1350 : Outputs:
0573 1351 :
0573 1352 : R0 = Status code
0573 1353 :-
0573 1354 :
0573 1355 CRI_TO_PSI:
0573 1356 :
0573 1357 : Check if required parameters are present
0573 1358 :
0573 1359 MOVZWL #SS$_INSFARG,R0 ; Set error if parameter not present
0573 1360 SGETFLD cri[T]use ; Check if USAGE parameter specified
0573 1361 BLBC R0,90$ ; If not, error - must be specified
0573 1362 :
0573 1363 :
0573 1364 :
0573 1365 :
0573 1366 :
0573 1367 :
0573 1368 CMPL R8,#NMASC_CIRUS_INC ; Incoming SVC?
0573 1369 BNEQ 5$ ; Branch if not
0573 1370 PUSHR #^M<R10,R11> ; Save registers
0573 1371 MOVL NET$GL_CNR_LNI,R11 ; Get LNI root address
0573 1372 MOVL NET$GL_PTR_LNI,R10 ; Get LNI CNF address
0573 1373 BSBW NET$DECLARE_PSI ; Declare ourselves to accept calls
0573 1374 POPR #^M<R10,R11> ; Restore registers
0573 1375 BLBC R0,90$ ; Exit if error detected
0573 1376 5$: :
0573 1377 :
0573 1378 :
0573 1379 :
0573 1380 CMPL R8,#NMASC_CIRUS_PER ; PVC?
0573 1381 BNEQ 90$ ; If not, then exit successfully
0573 1382 :
0573 1383 :
0573 1384 :
0573 1385 :
0573 1386 $CNFFLD cri,s,nam,R9 ; Set field ID of circuit name
0573 1387 BSBW SEND_TO_PSI ; Call co-routine to setup NFB, etc.
0573 1388 BLBC R0,90$ ; Branch if error detected
0573 1389 MOVB #NFBSC_FC_SET_NFB$B_FCT(R6) ; Store function code
0573 1390 MOVAB CRI_PSI_TAB,R5 ; Point to PSI circuit parameters
0573 1391 MOVL (R5)+,R9 ; Get next parameter ID
10$: BEQL 50$ ; Branch if end of table
0573 1392 BSBW CNF$GET_FIELD ; Get the parameter value
0573 1393 BLBC R0,10$ ; Skip it if it doesn't exist
0573 1394 MOVL R9,(R2)+ ; Store into NFB
0573 1395 :

```

02	10	ED	05D3	1396	CMPZV	#NFBSV TYP,#NFBSS_TYP,-	; String or binary?
02	59		05D6	1397		R9 #NFBSC_TYP_STR	
	05	13	05D8	1398	BEQL	20\$; Branch if string
83	58	D0	05DA	1399	MOVL	R8,(R3)+	; Store longword into P4 buffer
	E6	11	05DD	1400	BRB	10\$	
83	57	B0	05DF	1401 20\$:	MOVW	R7,(R3)+	; Store string count word
	34	88	05E2	1402	PUSHR	#^M<R2,R4,R5>	; Save registers
63	68	57	28	05E4 1403	MOVC	R7,(R8),(R3)	; Store string text
	34	BA	05E8	1404	POPR	#^M<R2,R4,R5>	; Restore registers
	D9	11	05EA	1405	BRB	10\$	
	9E	16	05EC	1406 50\$:	JSB	a(SP)+	; Call SEND_TO_PSI back to issue QIO
	05	05EE	1407 90\$:	RSB			; Return with status

```

05EF 1409      .SBTTL NET$INSERT_PLI - Pre-insertion processing
05EF 1410      :+
05EF 1411      :+ NET$INSERT_PLI - Insert PLI entry into database
05EF 1412      :
05EF 1413      : This routine is called to validate a PLI CNF entry before inserting
05EF 1414      : it into the database.
05EF 1415      :
05EF 1416      : Inputs:
05EF 1417      :
05EF 1418      :     R11 = Address of CNR
05EF 1419      :     R10 = Address of CNF
05EF 1420      :     R6 = Address of previous version of CNF (zero if none)
05EF 1421      :
05EF 1422      : Outputs:
05EF 1423      :
05EF 1424      :     R0 = Status code
05EF 1425      :- NET$INSERT_PLI:::
05EF 1426      :
05EF 1427      :     Get new value of STATE parameter.
05EF 1428      :
05EF 1429      :
05EF 1430      $GETFLD pli,l,sta          ; Get the operator state
05FC 1431      MOVB    R8,PLI_B_STATE   ; Save state value
0603 1432      :
0603 1433      : If the protocol associated with this CNF is LAPB, then ship
0603 1434      : the X.25 specific line parameters to PSIACP via a control QIO.
0603 1435      : If the QIO succeeds, then allow the CNF to be inserted. In
0603 1436      : either case, we do not perform any PLVEC or datalink processing.
0603 1437      :
0603 1438      $GETFLD pli,l,pro          ; Get protocol type
0610 1439      BLBC    R0,25$           ; If error, assume not X.25
0613 1440      CMPL    R8,#NMASC_LINPR_LAPB ; LAPB protocol?
0616 1441      BNEQ    25$             ; Branch if not
0618 1442      BSBW    PLI_TO_PSI       ; If so, send it to PSIACP
061B 1443      BLBC    R0,24$           ; Branch if error detected
061E 1444      BSBW    NET$SET_CTR_TIMER ; Start/reset automatic counter timer
0621 1445      MOVL    #1,R0            ; Set successful
0624 1446      RSB                 ; Exit with status
0625 1447      24$: PUSHL   R10           ; Save pointer to current CNF
0627 1448      25$: MOVL    R6,R10         ; Point to old version of CNF
062A 1449      BEQL    26$             ; Branch if none
062C 1450      $GETFLD pli,l,pro          ; Get old protocol type
0639 1451      BLBC    R0,26$           ; If error, assume still not X.25
063C 1452      CMPL    R8,#NMASC_LINPR_LAPB ; Did it used to be LAPB?
063F 1453      BNEQ    26$             ; Branch if not
0641 1454      MOVZWL #SSS_WRITLCK,R0 ; Do not allow protocol change w/o CLEAR
0646 1455      POPL    R10           ; Restore current CNF
0649 1456      RSB                 ; Return - do not allow insertion
064A 1457      26$: POPL    R10           ; Restore current CNF
064D 1458      :
064D 1459      : Locate the PLVEC index for this PLI. If there is none then
064D 1460      : assign and initialize a PLVEC entry for this PLI.
064D 1461      :
064D 1462      MOVZWL CNFSW_ID(R10),R4 ; Get i.d. (PLVEC index) of this entry
0651 1463      BNEQ    30$             ; If NEQ then its valid
0653 1464      BSBW    ALLOC_PLVEC   ; This is a new PLI, set it up
0656 1465      BLBC    R0,29$           ; If error then simply exit

```

01 00000000'EF44 90 0659 1466 SETBIT PLI_V_NEW,CNF\$B_FLG(R10); Indicate PLVEC has been newly assigned
 065D 1467 MOVB #NMASC_STATE OFF- ; Init to "off" state
 065F 1468 PLVECSAB_STATE[R4]; Setup an undefined state value
 0665 1469 :
 0665 1470 : If this is an NI driver, then make sure that the executor
 0665 1471 : type is Phase IV, since Phase III doesn't support
 0665 1472 : broadcast circuits.
 0665 1473 :
09 00000000'EF44 91 0665 1474 CMPB PLVECSAB_DEV[R4],#DEVTRNSC_DEV_UNA ; NI device?
 24 12 066D 1475 BNEQ 28\$; Branch if not
50 00000000'EF 50 008A C0 9A 0676 1476 MOVL NET\$GL_PTR_VCB,R0 ; Get RCB address
 0676 1477 MOVZBL RCB\$BETY(R0),R0 ; Get executor type
 0678 1478 SDISPATCH R0,Z- ; Allow only if set to one of:
 0678 1479 <ADJSC_PTY_PH4,28\$>,- ; Phase IV routing
 0678 1480 <ADJSC_PTY_PH4N,28\$>,- ; Phase IV endnode
 0678 1481 <ADJSC_PTY_AREA,28\$>> ; Phase IV area routing
50 0000'8F 3C 0685 1482 MOVZWL #SSS_BADPARAM,R0 ; Else, illegal protocol
 068A 1483 \$CNFFLD pli,[.pro,R9] ; Indicate parameter in error
 5B 11 0691 1484 29\$: BRB 100\$; Exit with error
 0693 1485 28\$: :
 0693 1486 : Issue the line control QIO to setup the driver with the control
 0693 1487 : information. The IOS_STARTUP and IOS_SHUTDOWN modifiers are
 0693 1488 : illegal unless there is a state change.
 0693 1489 :
7E 00000000'EF44 9A 0693 1490 30\$: MOVZBL PLVECSAB_STATE[R4],-(SP); Save old state value
 51 D4 069B 1491 CLRL R1 ; Clear illegal I/O modifier mask
 00000000'EF 91 069D 1492 CMPB PLI_B_STATE,-P[VECSAB_STATE[R4]] ; Are old and new state value the same?
 00000000'EF44 06A3 1493 :
 05 12 06A9 1494 BNEQ 40\$; If NEQ then state change
 0000'8F 80 06AB 1495 MOVW #IOSM_STARTUP!-IOSM_SHUTDOWN,R1 ; Specify unwanted I/O modifiers
 51 06AF 1496 :
 00000000'EF 90 06B0 1497 40\$: MOVB PLI_B_STATE,-P[VECSAB_STATE[R4]] ; Setup new state value
 00000000'EF44 06B6 1498 \$CNFFLD pli,s,chr,R9 ; Set field i.d.
 52 00000000'EF44 3C 06C3 1500 MOVZWL PLVECSAW_CHAN[R4],R2 ; Get channel
 0176 30 06CB 1501 BSBW NET\$SET_QIOW ; Issue set characteristics QIO
 00000000'EF44 59 51 8E F6 06D1 1502 MOVL R1,R9 ; Return 2nd IOSB longword as well
 12 50 E9 06D9 1503 CVTLB (SP)+PLVECSAB_STATE[R4]; Restore original state
 00000000'EF 90 06DC 1504 BLBC R0,100\$; If LBC then error
 00000000'EF44 06E2 1505 MOVB PLI_B_STATE,-P[VECSAB_STATE[R4]] ; Setup the new state value
 06E8 1506 :
 06E8 1507 : Start counter timer ticking
 06E8 1508 :
 50 F915' 01 30 06E8 1510 BSBW NET\$SET_CTR_TIMER ; Reset automatic counter timer
 00 01 D0 06EB 1511 MOVL #1,R0 ; Set successful
 06EE 1512 :
 06EE 1513 : If the PLI is not new then simply return the status in R0. If
 06EE 1514 : the PLI is new then the newly allocated PLVEC slot must be
 06EE 1515 : deallocated if R0 indicates an error.
 06EE 1516 :
08 08 AA 04 E5 06EE 1517 100\$: BBCC #PLI_V_NEW,-CNFSB_FLG(R10),110\$; Br unless PLVEC has been newly
 08 50 E8 06F0 1518 BLBS R0,110\$; assigned
 50 DD 06F3 1519 PUSHL R0 ; If BS then no clean-up needed
 040B 30 06F6 1520 BSBW DEAL_PLVEC ; Save error code
 50 8ED0 06FB 1521 POPL R0 ; Free the PLVEC cell
 00 00 00 00 00 00 : Restore status

C 2
- Datalink database action routines 16-SEP-1984 01:15:07 VAX/VMS Macro V04-00
NET\$INSERT_PLI - Pre-insertion processin 5-SEP-1984 02:18:18 [NETACP.SRC]NETCNFDLL.MAR;1 Page 35
(17)

05 06FE 1523 110\$: RSB ; Return status in R0

```

06FF 1525 .SBTTL ALLOC_PLVEC - Setup PLVEC entry for new line
06FF 1526 :+
06FF 1527 : ALLOC_PLVEC - Setup a new PLVEC entry for a new PLI entry
06FF 1528 :
06FF 1529 : Inputs:
06FF 1530 :
06FF 1531 : R11 = Address of CNR
06FF 1532 : R10 = Address of CNF
06FF 1533 :
06FF 1534 : Outputs:
06FF 1535 : R0 = Status code
06FF 1536 :
06FF 1537 :-
```

54 50 0000'8F 3C 06FF 1538 ALLOC_PLVEC:

```

00000000'EF 9A 0704 1540 MOVZWL #SS$_INSMEM,R0
00000000'EF44 95 070B 1541 MOVZBL PLVEC$GB_MAX,R4
06 13 0712 1542 10$: TSTB PLVECSAB_REF[R4]
F4 54 F5 0714 1543 BEQL 20$ R4,10$
0113 31 0717 1544 SOBGTR R4,10$ R0,10$ BRW
12 AA 54 B0 071A 1545 19$: MOVW R4,CNFSW_ID(R10)
00000000'EF44 96 071E 1546 20$: INCB PLVECSAB_REF[R4]
00000000'EF44 B4 0725 1547 CLRW PLVECSAW_CHAN[R4]
50 0000'8F 3C 072C 1548 MOVZWL #SS$_NOSUCHDEV,R0
D6 50 E9 073E 1549 $GETFLD pli$nam
0731 1550 BLBC R0,19$ R0,19$ : Branch to 100$ if cannot translate it
0741 1551 :
0741 1552 :
0741 1553 : Get the VMS name of the device and the device code. Assign an
0741 1554 : I/O channel to the device and squirrel away the device code
0741 1555 :
53 SE 17 C2 0741 1556 SUBL #MAX_C_DEVNAM+8,SP : Create scratch space on stack
08 AE 9E 0744 1557 MOVAB 8(SPT),R3 : Point to scratch space for name text
6E 53 CE 0748 1558 MNEG L R3,(SP) : Bias count field of name descriptor
04 AE 53 D0 074B 1559 MOVL R3,4(SP) : Enter ptr field of name descriptor
OC1A 30 074F 1560 BSBW TRAN_DEVNAM : Translate device name to VMS format
0752 1561 BLBC R0,40$ : - advances R3, table entry -> R6
50 0000'8F 3C 0755 1562 MOVZWL #SS$_IVDEVNAM,R0 : If LBC then error
57 D5 075A 1563 TSTL R7 : Assume error
25 12 075C 1564 BNEQ 40$ : Any unparsed characters?
54 12 AA 3C 075E 1565 MOVZWL CNFSW_ID(R10),R4 : If NEQ yes, name format error
0A A6 90 0752 1566 MOVB DEVTRNSB_DEV(R6) : Recover R4
00000000'EF44 745 1567 ADDL R3,(SP) : Enter device type code
6E 53 CC 0755 1568 MOVL SP,R3 : Complete device name descriptor
53 SE D0 076E 1570 $ASSIGN_S - : Point to it
0771 1571 : Assign an I/O channel
0771 1572 : CHAN = PLVECSAW_CHAN[R4],-
0771 1573 : DEVNAM = (R3)
5E 17 C0 0783 1574 40$: ADDL #MAX_C_DEVNAM+8,SP : Restore stack
4D 50 E9 0786 1575 BLBC R0,49$ : If LBC then error
50 00000000'EF44 3C 0789 1576 MOVZWL PLVECSAW_CHAN[R4],R0 : Get I/O channel
00000000'GF 16 0791 1577 LSR G$IOCSVER;SYCHAN : Return CCB in R1 regardless of error
61 D0 0797 1578 MOVL CCB$L_UCB(R1),- : Store device UCB
00000000'EF44 0799 1579 PEVECSAL_UCB[R4]
079F 1580 SUBL #4,SP : Use stack for device characteristics
SE 04 C2 079F 1580
```

53	5E	DD	07A2	1582		MOVL SP,R3	: Point R3 at return buffer	
00	00	DD	07A5	1583		PUSHL #0	: Terminate GETDVI item list	
00000031	EF	9F	07A7	1584		PUSHAB QIOW_W_RETLEN	: Point to result length word	
53	53	DD	07AD	1585		PUSHL R3	: Point to DEVCCHAR return buffer	
7E	02	B0	07AF	1586		MOVW #DVIS_DEVCHAR,-(SP)	: Item code	
7E	04	B0	07B2	1587		MOVW #4,-(SP)	: Size of DEVCCHAR result buffer	
51	5E	DD	07B5	1588		MOVL SP,R1	: Point to item list	
			07B8	1589		\$GETDVI_S ITMLST=(R1),-	: Get device characteristics	
			07B8	1590		EFN=#NETSC_EFN_WAIT,-	: Use synchronous event flag	
			07B8	1591		CHAN = PLVEC\$AW_CHAN[R4]		
5E	14	C0	07D3	1592		ADDL #5*4,SP	: Pop item list	
			07D6	1593				
50	55	E9	07D6	1594	49\$:	BLBC R0,120\$: Branch if error detected	
0000008F	3C	07D9	1595			MOVZWL #\$\$\$_IVDEVNAM_R0	: Assume error	
4C 63	OD	E1	07DE	1596		BBC #DEV\$V_NET,(R3),120\$; Br if not a network device	
			07E2	1597				
			07E2	1598		: Pre-allocate (and deallocate) the receive buffers for the datalink		
			07E2	1599		driver from the system nonpaged pool. This is done here before		
			07E2	1600		invoking the driver so that the pool expansion mechanism can be used		
			07E2	1601		in case there isn't enough pool. It is done here because pool		
			07E2	1602		expansion can't be done on the interrupt stack in the datalink driver.		
			07E2	1603				
55	58	38	0000004C	1604		\$GETFLD pli_l,bus	: Get datalink receive buffer size	
		50	8F	1605		BLBC R0,70\$: If not set, skip it	
		C1	07EF	1606		ADDL3 #CXBSC_OVERHEAD,R8,R5	: Add in datalink's overhead	
		07FA	1607			\$GETFLD pli_l,5fn	: Get number of line receive buffers	
		20	50	E9	1608	BLBC R0,70\$: Wasn't defaulted properly - skip it	
		D4	080A	1609		CLRL -(SP)	: Terminate list of allocated blocks	
		51	55	DO	080C	1610	50\$::	Set size of block to allocate
		00000000	EF	16	080F	1611		Allocate from nonpaged pool
		05	50	E9	0815	1612		If error, give up
		52	DD	0818	1613	PUSHL R2	: Save block address	
		EF	58	F5	081A	1614		Loop until all allocated
		50	8ED0	081D	1615	SOBGTR R8,50\$: Get next buffer address	
		08	13	0820	1616	POPL R0	: Branch if all blocks deallocated	
		00000000	EF	16	0822	1617	BEQL 70\$: Deallocate the block
		F3	11	0828	1618	JSB NET\$DEALLOCATE	: Loop until all blocks cleaned up	
		50	01	DO	082A	1619	70\$::	: Success
		05	082D	1620	100\$:	MOVL #1,R0	: Return status in R0	
			082E	1621				
			082E	1622	120\$:			
			082E	1623		: DEASSIGN the channel on error		
			082E	1624				
		50	DD	082E	1625	PUSHL R0	: Save error code	
			0830	1626		\$DASSGN_S -	: Deassign the I/O channel	
			0830	1627		CHAN = PLVEC\$AW_CHAN[R4]		
		50	8ED0	083F	1628	POPL R0	: Restore error code	
		E9	11	0842	1629	BRB 100\$: And exit	

```

0844 1631      .SBTTL NET$SET_QIOW - Issue datalink SETMODE function
0844 1632      :+
0844 1633      : NET$SET_QIOW - Issue datalink SETMODE function
0844 1634      :
0844 1635      : This routine is called when a line or circuit is to be initialized
0844 1636      : with a SETMODE function.
0844 1637      :
0844 1638      : Inputs:
0844 1639      :
0844 1640      : R11 = Address of CNR
0844 1641      : R10 = Address of CNF
0844 1642      : R9 = Parameter ID for CHR field, which returns DLLQIO buffer
0844 1643      : R2 = Channel to datalink driver
0844 1644      :
0844 1645      : Outputs:
0844 1646      :
0844 1647      : R0/R1 = I/O status quadword
0844 1648      : R9 = Parameter ID qualifying error, if any.
0844 1649      ;-
0844 1650      :
0844 1651      NET$SET_QIOW:::
50 0000'8F      3C 0844 1652      MOVZWL #SS$ NOSUCHDEV,R0      ; Assume error
      F7B'      30 0849 1653      BSBW CNFS$GET_FIELD      ; Get datalink DLLQIO buffer
      7D 5u      E9 084C 1654      BLBC R0,100$      ; If LBC then error
      68 51      CA 084F 1655      BICL R1,DLLQIOSL FUNC(R8)      ; Mask out illegal I/O modifier bits
      04 A8      D5 0852 1656      TSTL DLLQIOSL_P1(R8)      ; Any P1 buffer?
      04        13 0855 1657      BEQL 5$      ; If EQL no
      58        C0 0857 1658      ADDL R8,DLLQIOSL_P1(R8)      ; Else turn offset into a pointer
      A8        D5 0858 1659 5$:      TSTL DLLQIOSL_P2(R8)      ; Any P2 buffer?
      OC        13 085E 1660      BEQL 10$      ; If EQL then none
      58        C0 0860 1661      ADDL R8,DLLQIOSL_P2(R8)      ; Turn offset into a pointer
      08 A8      D0 0864 1662      MOVL DLLQIOSL_P2(R8),R0      ; Point to P2 buffer descriptor
      58        C0 0868 1663      ADDL R8,4(R0)      ; Turn offset into a pointer
      086C 1664 10$:      SQIOW_S -      ; Set the device characteristics
      1665      EFN = #NETSC_EFN_WAIT,-
      1666      !OSB = QIOW_Q_IOSB,-
      1667      C'AN = R2,-
      1668      FUNC = DLLQIOSL FUNC(R8),-
      1669      P1 = @DLLQIOSL_P1(R8),-      ; This is a PUSHAL
      1670      P2 = DLLQIOSL_P2(R8),-
      1671      P3 = DLLQIOSL_P3(R8)
00000029'EF      50 0890 1672      BLBS R0,20$      ; Branch if queued ok
      50        D0 0893 1673      MOVL R0,QIOW_Q_IOSB      ; If error, store status into IOSB
      59 0000002D'EF      D0 089A 1674 20$:      MOVL QIOW_Q_IOSB+4,R9      ; Get remainder of IOSB
      00000B04 8F      59 08A1 1675      CMPL R9,#NMASC_PCLI_PHA      ; "physical address"?
      07        12 08A8 1676      BNEQ 22$      ; If so,
      59 00000488 8F      D0 08AA 1677      MOVL #NMASC_PCLI_HWA,R9      ; then map it to "hardware address"
      0A70      30 08B1 1678      07        12 08A8 1676      ; (so that we see it at the NICe level)
      3FFF 8F      59 08B4 1681      BSBW NETSCVT_NMA_INT      ; Convert NMA parameter i.d. to an
      07        12 08B9 1682      CMPW R9,#CNVTABSC_INTRNL      ; internal parameter i.d.
      59 0000002D'EF      D0 08B8 1683      BNEQ 25$      ; Datalink only parameter?
      50 00000029'EF      7D 08C2 1684 25$:      MOVL QIOW_Q_IOSB+4,R9      ; Branch if not
      08C9 1685      MOVQ QIOW_Q_IOSB,R0      ; If so, I'd rather see the NMA code
      08C9 1686      ; Get I/O status
      08C9 1687      ; Log the final status into the journal file, if any

```

00000029'EF	58	68	3C	08C9	1688		MOVZWL	DLLQIO\$L FUNC(R8),R8	: Pass I/O function code into journal
	50	7D	08CC	1689	100\$:		MOVQ	R0_QIOW @ IOSB	: Save final status
	F72A'	30	08D3	1690			BSBW	#EFSJNX-C0	: Initialize journalling co-routine
	10	50	E9	08D6	1691		BLBC	R0,120\$: Branch if not enabled
	81	44	8F	90	08D9	1692	MOVB	#^X44,(R1)+	: Journal record type = QIOW completion
	81	81	58	80	08DD	1693	MOVW	R8,(R1)+	: I/O function code
	81	000029'EF	7D	08E0	1694		MOVQ	QIOW_Q_IOSB,(R1)+	: I/O status quadword
50	00000029'EF	9E	16	08E7	1695		JSB	@(SP)+-	: Log the journalling record
		7D	08E9	1696	120\$:		MOVQ	QIOW_Q_IOSB,R0	: Restore final status
		05	08F0	1697			RSB		

```

08F1 1699      .SBTTL PLI_TO_PSI - Send PLI parameters to PSIACP
08F1 1700 :+
08F1 1701 : PLI_TO_PSI - Issue SET of PLI parameters to PSIACP
08F1 1702 :
08F1 1703 : Send the PLI parameters that PSIACP cares about via a ACP control QIO.
08F1 1704 :
08F1 1705 : Inputs:
08F1 1706 :
08F1 1707 :     R11 = Address of CNR
08F1 1708 :     R10 = Address of CNF
08F1 1709 :
08F1 1710 : Outputs:
08F1 1711 :
08F1 1712 :     R0 = Status code
08F1 1713 :-  

08F1 1714 :
08F1 1715 PLI_TO_PSI:  

55 0000012C'EF 9E 08F1 1716 MOVAB  PSI_PLI_CLR_TAB,R5      ; Get table of params to clear
FA65 30 08F8 1717 BSBW  CLEAR_VOLATILE   ; Clear volatile parameters
      37 10 0902 1718 $CNFFLD pli,s,nam,R9    ; Set field ID of line name
      33 50 E9 0904 1720 BSBB  SEND_TO_PSI    ; Call co-routine to setup NFB, etc.
      66 23 90 0907 1721 BLBC  R0,90$        ; Branch if error detected
      59 85 D0 0911 1722 10$: MOVAB  #NFBSC_FC_SET_NFB$B_FCT(R6) ; Store function code
      22 13 0914 1723 MOVL  (R5)+,R9       ; Point to PSI Line parameters
      F6E7' 30 0916 1725 BSBW  CNF$GET_FIELD  ; Get next parameter ID
      F5 50 E9 0919 1726 BLBC  R0,10$        ; Branch if end of table
      82 59 D0 091C 1727 MOVL  R9,(R2)+      ; Get the parameter value
      02 10 ED 091F 1728 CMPZV #NFB$V_TYP,#NFB$S_TYP,- ; Skip it if it doesn't exist
      02 59 0922 1729 R9,#NFBSC_TYP_STR    ; Store into NFB
      05 13 0924 1730 BEQL  20$             ; String or binary?
      83 58 D0 0926 1731 MOVL  R8,(R3)+      ; Branch if string
      83 E6 11 0929 1732 BRB   10$           ; Store longword into P4 buffer
      83 57 B0 092B 1733 20$: MOVW  R7,(R3)+      ; Store string count word
      34 88 092E 1734 PUSHR #^M<R2,R4,R5>  ; Save registers
      63 68 57 28 0930 1735 MOVC  R7,(R8),(R3)  ; Store string text
      34 BA 0934 1736 POPR  #^M<R2,R4,R5>  ; Restore registers
      D9 11 0936 1737 BRB   10$           ; Call SEND_TO_PSI back to issue QIO
      9E 16 0938 1738 50$: JSB   a(SP)+      ; Return with status
      05 093A 1739 90$: RSB

```

```

093B 1741 .SBTTL SEND_TO_PSI - Send control QIO to PSIACP
093B 1742 :+
093B 1743 : SEND_TO_PSI - Send ACP control QIO to PSIACP
093B 1744 :
093B 1745 : This routine is called to transmit an ACP control function to PSIACP
093B 1746 : on behalf on a local CNF, such as a LAPB line. CNFs like these are
093B 1747 : "known" about by both NETACP and PSIACP, NETACP in order to perform
093B 1748 : network management functions, and PSIACP in order to manage the line.
093B 1749 :
093B 1750 : Inputs:
093B 1751 :
093B 1752 : R11 = Address of CNR
093B 1753 : R10 = Address of CNF
093B 1754 : R9 = Address of parameter ID describing entity name
093B 1755 :
093B 1756 : Outputs:
093B 1757 :
093B 1758 : R0 = Status code
093B 1759 :
093B 1760 : If the function code is NFB$C_FC_SHOW or NFB$C_FC_ZERCOU, then:
093B 1761 :
093B 1762 : R7/R8 = Descriptor of result P4 buffer
093B 1763 : R9 = Address of scratch storage, which should be deallocated
093B 1764 : when processing of the P4 buffer is completed.
093B 1765 :
093B 1766 : R1-R6 are destroyed.
093B 1767 :
093B 1768 : This routine makes a co-routine call back to the caller after setting
093B 1769 : up the NFB and associated control QIO buffers, so that the caller can
093B 1770 : fill in the essential fields. When the caller returns via co-routine
093B 1771 : call to this routine, the control QIO is issued to PSIACP.
093B 1772 :
093B 1773 : On input to co-routine:
093B 1774 :
093B 1775 : R6 = Address of NFB
093B 1776 : R3 = Address of P4 buffer
093B 1777 : R2 = Address of NFB$L_FLDID list
093B 1778 :
093B 1779 : On return from co-routine:
093B 1780 :
093B 1781 : R3 = Updated pointer to end of P4 buffer
093B 1782 : R2 = Updated pointer to end of FLDID list
093B 1783 :
093B 1784 : R0-R1,R4-R5,R7-R9 may be destroyed by co-routine.
093B 1785 :-
093B 1786 :
00000088 093B 1787 NFB_SIZE = NFB$C_LENGTH + 30*4 ; allow for all PSI field IDs
00000066 093B 1788 P2BUF_SIZE = 4+2*DEVNAM_C_SIZ+NFB$C_CTX_SIZE ; P2 holds CNF count and entity ID
093B 1789 : plus context area
00000200 093B 1790 P4BUF_SIZE = 512 ; P4 holds all parameter values
093B 1791 :
093B 1792 ASSUME PLI_PSI_SIZ LE 30*4 ; Must be enough room for PLI params
093B 1793 :
093B 1794 SEND_TO_PSI:
093B 1795 MOVZWL #12+NFB_SIZE+P2BUF_SIZE+P4BUF_SIZE,R1 ; Set size of block overhead
0940 1796 : plus NFB, P2 and P4 buffer sizes
00000000'EF 16 0940 1797 JSB NET$ALLOCATE ; Allocate the storage

```

		01 50	E8 0946	1798	BLBS R0,5\$: Branch if successful
		05 52	0949	1799	RSB	: Else, exit with error status
66 10	56 0C	A2 6E 00	094A	1800	5\$: PUSHL R2	: Save address of block
	02 A6	0A AB	094C	1801	MOVAB 12(R2),R6	: Point to scratch NFB
	01 A6	04	0956	1802	MOVCS #0,(SP),#0,NFBSC LENGTH(R6)	: Zero it
	03 A6	00	095B	1803	MOVB CNRSB_TYPE(R11),NFBSC DATABASE(R6)	: Store database ID
	04 A6	59	095F	1804	MOVB #NFBSC_NOCTX,NFBSC FLAGS(R6)	: Indicate one-shot request
	F696'	30	0963	1805	MOVB #NFBSC_OP_EQL,NFBSC_OPER(R6)	: Search for key EQL
	03 50	F8	0967	1806	MOVL R9,NFBSC_SRCH_KEY(R6)	: Search for specific entry
	00BC C6	57	B0	0967	1807	: by it's network management name
00BE C6	68	57	0970	1808	BSBW CNF\$GET_FIELD	: Get descriptor of name
	83	B4	0975	1809	BLBS R0,10\$: Branch if ok
	52 10	A6 9E	097B	1810	BRW 110\$: Abort if unable to get entity name
53 011E	C6 9E	097D	1811	10\$: MOVW R7,NFB_SIZE+4(R6)	: Store size of string	
	50 01	D0	0981	1812	MOVC R7,(R8),NFB_SIZE+6(R6)	: Copy into buffer
	0986	D0	0986	1813	CLRW (R3)+	: Make context a null string
	0989		0989	1814	MOVAB NFBSC_FLDID(R6),R2	: Point to NFB field ID list
	0989		0989	1815	MOVAB NFB_SIZE+P2BUF_SIZE(R6),R3	: Get address of P4 buffer
	0989		0989	1816	MOVL #1,R0	: Indicate co-routine init. successful
	0989		0989	1817	:	
	0989		0989	1818	: Call the caller back so that he can fill in the NFB and P4 buffers.	
	0989		0989	1819	:	
	0995	9E 16	0995	1820	SWAP (SP),4(SP)	: Swap block pointer & return address
	0997		0995	1821	:	so that caller's address is on top
	09A3		0995	1822	JSB a(SP)+	: Fill in the NFB and P4 buffers
	09A3		0997	1823	SWAP (SP),4(SP)	: Swap return address & block pointer
	09A3		09A3	1824	:	
	09A3		09A3	1825	: Terminate the NFB field ID list	
	09A3		09A3	1826	:	
	82 D4	09A3	09A3	1827	ASSUME NFBSC_ENDOFLIST EQ 0	
	09A5		09A5	1828	CLRL (R2)+	: Terminate NFB parameter ID list
	09A5		09A5	1829	:	
	09A5		09A5	1830	: Construct descriptors of NFB, P2 and P4 buffers for QIO	
	09A5		09A5	1831	:	
7E 04 AE	7E 6E 0C	C1 09A5	1832	ADDL3 #12,(SP),-(SP)	: Retrive starting address of NFB	
	52 6E	C3 09A9	1833	SUBL3 (SP),R2,-(SP)	: Compute length of NFB	
	0000011E 8F	C1 09AD	1834	ADDL3 #NFB_SIZE+P2BUF_SIZE,4(SP),-(SP)	: Construct descriptor of P4	
51 0C AE	7E 53 6E	C3 09B6	1835	SUBL3 (SP),R3,-(SP)	: Compute length of P4 buffer	
	000000B8 8F	C1 09BA	1836	ADDL3 #NFB_SIZE,12(SP),R1	: Get address of P2 buffer	
	50 04 A1	3C 09C3	1837	MOVZWL 4(R1),R0	: Pick up length of entity name	
	00000046 8F	C0 09C7	1838	ADDL #4+2+NFBSC_CTX_SIZE,R0	: Add 4 bytes for CNF count	
	09CE		09CE	1839	: plus 2 bytes for entity string size	
	09CE		09CE	1840	: and context area size	
	7E 50	7D 09CE	1841	MOVQ R0,-(SP)	: Push P2 descriptor onto stack	
53 08 A2	52 5E	D0 09D1	1842	MOVL SP,R2	: Point to P2/P4/NFB descriptors	
	9E 09D4	1843	MOVAB 8(R2),R3	: Point to P4 descriptor directly		
	09D8		09D8	1844	:	
	09D8		09D8	1845	: Send database request to PSIACP	
	09D8		09D8	1846	:	
00000000'EF	B5	09D8	1847	TSTW NETSGW_X25_CHAN	: Is there an active channel?	
06	12	09DE	1848	BNEQ 60\$: If NEQL then yes	
F61D'	30	09E0	1849	BSBW NET\$GET_X25_CHAN	: Assign channel, get PSI mutex	
3C 50	E9	09E3	1850	BLBC R0,100\$: If LBC then error	
	09E6	1851	60\$:	\$QIOW_S FUNC = #IOS_ACPCONTROL,-	: Re-issue QIO	
	09E6	1852		EFN = #NETSC_EFN_WAIT,-	: event flag for synchronous calls	
	09E6	1853		CHAN = NETSGW_X25_CHAN,-		
	09E6	1854		IOSB = QIOW_Q_IOSB,-	: Scratch quadword buffer	

		09E6	1855	P1	= 8(R3),-	; Address of NFB descriptor		
		09E6	1856	P2	= R2,-	; Address of P2 buffer descriptor		
		09E6	1857	P3	= #QIOW_W_RETLEN,-	; Address of return length word		
		09E6	1858	P4	= R3	; Address of P4 buffer		
50	00000029'EF	0D 50	E9 0A12	BLBC	R0,100\$; If LBC then error		
		03 50	7D 0A15	MOVQ	QIOW_Q_IOSB,R0	; Setup IOSB image		
		59 51	E8 0A1C	BLBS	R0,100\$; Branch if successful		
		5E 18	D0 0A1F	MOVL	R1,R9	; Set error qualifier		
			C0 0A22	ADDL	#3*8,SP	; Deallocate descriptors		
		00000029'EF	50	7D 0A25	1865	MOVQ R0,QIOW_Q_IOSB	; Save final status	
			F5D1'	30 0A2C	1866	BSBW NET\$JNX_C0	; Initialize journalling co-routine	
			12 50	E9 0A2F	1867	BLBC R0,105\$; Branch if not enabled	
			81 44	90 0A32	1868	MOVB #^X44,(R1)+	; Journal record type = QIOW completion	
81	00000029'EF	81 0000'8F	B0 0A36	MOVW #IOS_ACPCONTROL,(R1)+		; I/O function code		
			9E	16 0A42	1871	MOVQ QIOW_Q_IOSB,(R1)+	; I/O status quadword	
50	00000029'EF	50	7D 0A44	JSB @(SP)+		; Log the journalling record		
				1872	105\$:	MOVQ QIOW_Q_IOSB,R0	; Restore final status	
				0A4B	1873			
			0A 50	E9 0A4B	1874	BLBC R0,110\$; Branch if error detected	
			22 66	91 0A4E	1875	CMPB NFB\$B_FCT(R6),#NFB\$C_FC_SHOW	; SHOW function?	
			15	13 0A51	1876	BEQL 150\$; Branch if so	
			25 66	91 0A53	1877	CMPB NFB\$B_FCT(R6),#NFB\$C_FC_ZERCOU	; READ & ZERO function?	
			10	13 0A56	1878	BEQL 150\$; Branch if so	
			51 50	D0 0A58	1879	110\$:	MOVL R0,R1	; Save final status
			50	8ED0 0A5B	1880	POPL R0	; Retreive address of storage	
			50 51	D0 0A5E	1881	JSB NET\$DEALLOCATE	; Deallocate scratch storage	
			05	D0 0A64	1882	MOVL R1,R0	; Restore final status	
				0A67	1883	RSB	; Done	
				0A68	1884			
				0A68	1885	:		
				0A68	1886	: The function is either SHOW or READ/ZERO. Since the caller will most		
				0A68	1887	: likely want to process the returned P4 buffer from the QIO, we return		
				0A68	1888	: from the routine with a descriptor of the returned buffer, and the		
				0A68	1889	: address of our scratch storage, which the caller will deallocate.		
				0A68	1890	:		
				0A68	1891			
57	00000031'EF	59 8ED0	0A68	1892	150\$:	POPL R9	; Return scratch pointer in R9	
		58 012A C9	3C 0A6B	1893		MOVZWL QIOW_W_RETLEN,R7	; Return descriptor of P4 buffer	
			9E 0A72	1894		MOVAB 12+NFB_SIZE+P2BUF_SIZE(R9),R8		
			05 0A77	1895		RSB	; Exit successfully	

```

0A78 1897      .SBTTL NET$DELETE_CRI - Pre-delete processing
0A78 1898 :+
0A78 1899 : NET$DELETE_CRI - Special processing before a CRI entry is marked for delete
0A78 1900 :
0A78 1901 : This routine is called to perform any special action that may need to be
0A78 1902 : taken before marking a CNF for delete.
0A78 1903 :
0A78 1904 : INPUTS:    R11   CNR pointer
0A78 1905 :          R10   CNF pointer
0A78 1906 :
0A78 1907 : OUTPUTS:   R11,R10 Preserved
0A78 1908 :          R0    LBS if successful
0A78 1909 :          LBC if CNF should not be marked for delete
0A78 1910 :
0A78 1911 :-
0A78 1912 :-     All registers may be destroyed.
0A78 1913 :
0A78 1914 NET$DELETE_CRI:::
0A78 1915 :
0A78 1916 : If this is an X25 circuit, ask PSIACP if it's ok to delete CNF
0A78 1917 :
0A78 1918 $GETFLD cri_l_typ           ; Get circuit type parameter value
03 50 E9 0A85 1919 BLBC R0,10$       ; If not specified, skip it
03 58 D1 0A88 1920 CMPL R8,#NMASC_CIRTY_X25 ; X25 circuit?
03 2C 12 0A8B 1921 BNEQ 10$        ; Branch if not
00 1C 50 E9 0A9A 1922 $GETFLD cri_l_use ; Get X.25 usage
00 58 D1 0A9D 1923 BLBC R0,10$       ; If not specified, skip it
00 17 12 0AA0 1924 CMPL R8,#NMASC_CIRUS_PER ; PVC?
00 17 12 0AA2 1925 BNEQ 10$        ; Only ask PSI about PVCs
00 FE8F 30 0AA9 1926 $CNFFLD cri_s_nam,R9 ; Set field ID of circuit name
00 13 50 E9 0AAC 1927 BSBW SEND TO_PSI ; Call co-routine to setup NFB, P4, etc.
00 21 90 0AAF 1928 BLBC R0,90$       ; Branch if error detected
00 9E 16 0AB2 1929 MOVB #NFBSC_FC_DELETE,NFB$B_FCT(R6) ; Set function code
00 0B 50 E9 0AB4 1930 JSB @(SP)+      ; Call SEND TO_PSI to issue QIO
00 06 11 0AB7 1931 BLBC R0,90$       ; Branch if error detected
00 06 11 0AB9 1932 BRB 50$          ; Allow delete
00 06 11 0AB9 1933 :
00 06 11 0AB9 1934 : For all circuits, if the LPD is no longer present (as a result
00 06 11 0AB9 1935 : of an ON -> OFF state transition), then allow the delete.
00 06 11 0AB9 1936 :
00 F544' 30 0AB9 1937 10$: BSBW NET$LOCATE_LPD ; Locate the LPD
00 04 50 E8 0ABC 1938 BLBS R0,80$       ; If found, then do not allow delete
00 01 D0 0ABF 1939 50$: MOVL #1,R0      ; Allow delete
00 05 0AC2 1940 90$: RSB
00 05 0AC3 1941 :
00 50 D4 0AC3 1942 80$: CLRL R0        ; Do not allow delete
00 05 0AC5 1943 :

```

	OAC6	1945	.SBTTL NET\$DELETE_PLI - Pre-delete processing	
	OAC6	1946	:+ NET\$DELETE_PLI - Special processing before a PLI entry is marked for delete	
	OAC6	1948		
	OAC6	1949	: This routine is called to perform any special action that may need to be	
	OAC6	1950	taken before marking a CNF for delete.	
	OAC6	1951		
	OAC6	1952	: INPUTS: R11 CNR pointer	
	OAC6	1953	R10 CNF pointer	
	OAC6	1954		
	OAC6	1955	: OUTPUTS: R11,R10 Preserved	
	OAC6	1956	R0 LBS if successful	
	OAC6	1957	LBC if CNF should not be marked for delete	
	OAC6	1958		
	OAC6	1959	All registers may be destroyed.	
	OAC6	1960	:-	
	OAC6	1961		
	OAC6	1962	NET\$DELETE_PLI::	
58 08 50	OAC6	1963	\$GETFLD pli,l,sta	: Get the state value
01	E9	1964	BLBC R0,10\$: If LBC then no need to check state
03	D1	1965	CMPL #NMASC_STATE_OFF,R8	: Is the line turned off?
50	D1	1966	BEQL 10\$: If NEQ then cannot delete PLI
05	D4	1967	CLRL R0	: Say "cannot delete PLI"
	OADD	1968	RSB	: Done
	OADE	1969		
	OADE	1970	: If this is a LAPB line, ask PSIACP if it's ok to delete CNF	
	OADE	1971		
05 18 50	OADE	1972	10\$: \$GETFLD pli,l,pro	: Get protocol parameter value
05 58	E9	1973	BLBC R0,DEAL_PLVEC	: If not specified, skip it
13	D1	1974	CMPL R8,#NMASC_LINPR_LAPB	: LAPB line?
	0AF1	1975	BNEQ DEAL_PLVEC	: Branch if not
FE3E	0AF3	1976	\$CNFFLD pli,s,nam,R9	: Set field ID of line name
05 50	0AFA	1977	BSBW SEND TO_PSI	: Call co-routine to setup NFB, P4, etc.
66 21	E9	1978	BLBC R0,90\$: Branch if error detected
9E	0AFD	1979	MOV B #NFB\$C_FC_DELETE,NFB\$B_FCT(R6)	: Set function code
	OB00	1980	JSB @(SP)+	: Call SEND TO_PSI to issue QIO
	OB03	1981	RSB	: Return with \$status.
	OB05	1981	90\$: RSB	
	OB06	1982		
54 12 AA	OB06	1983	DEAL_PLVEC:	: Deallocate PLVEC cell
1D	3C	1984	MOVZWL CNFSW_ID(R10),R4	: Get the PLVEC index
00000000'EF44	13	1985	BEQL 10\$: If EQL then done
00000000'EF44	94	1986	CLRB PLVECSAB_REF[R4]	: No longer any references to this slot
	D4	1987	CLRL PLVECSAL_UCB[R4]	: No UCB
	OB0A	1988	\$DASSGN_S -	: Deassign the I/O channel
	OB1A	1989	CHAN = PLVECSAW_CHAN[R4];	
	OB29	1990		
50 00'	OB29	1991	10\$: MOVL S^#SSS_NORMAL,R0	: Ignore errors
05	OB2C	1992	RSB	: Indicate success

0B2D 1994 .SBTTL NET\$REMOVE_xxx - Pre-remove processing
0B2D 1995 :+
0B2D 1996 : NET\$REMOVE_CRI - Processing after CRI block has been removed.
0B2D 1997 : NET\$REMOVE_PLI - Processing after PLI block has been removed.
0B2D 1998 :
0B2D 1999 : This routine is called to perform special processing after a CNF block has
0B2D 2000 : been removed from the database. On return, the block is deallocated.
0B2D 2001 :
0B2D 2002 : INPUTS: R11 CNR pointer
0B2D 2003 : R0 CNF pointer
0B2D 2004 :
0B2D 2005 : OUTPUTS: All registers are preserved.
0B2D 2006 :-
0B2D 2007 NET\$REMOVE_CRI:: : Remove Circuit CNF action routine
0B2D 2008 NET\$REMOVE_PLI:: : Remove Line CNF action routine
00000000'EF 16 0B2D 2009 JSB NET\$REMOVE_DEF ; Let default routine do the work
05 0B33 2010 RSB

0834 2012 .SBTTL CRI parameter action routines
 0834 2013 :+
 0834 2014 : NET\$CRI_V_LCK - Get status of conditionally writeable fields
 0834 2015 :
 0834 2016 : NET\$CRI_L_SUB - Get circuit's substate
 0834 2017 : NET\$CRI_L_DRT - Get broadcast circuit's designated router
 0834 2018 :
 0834 2019 : NET\$CRI_L_PNA - Get partner's node address
 0834 2020 : NET\$CRI_L_BLO - Get partner's receive block size
 0834 2021 : NET\$CRI_L_LIT - Get partner's listen timer
 0834 2022 :
 0834 2023 : NET\$CRI_S_COL - Get circuit's collating value
 0834 2024 : NET\$CRI_S_PNN - Get partner's node name
 0834 2025 : NET\$CRI_S_LOO - Get line's loopback name
 0834 2026 : NET\$CRI_S_CNT - Get (optionally clear) circuit counters
 0834 2027 : NET\$CRI_S_VMSNAM Get VMS name of associated device
 0834 2028 : NET\$CRI_S_CHR - Get circuit's characteristics buffer
 0834 2029 :
 0834 2030 : INPUTS: R11 CRI CNR address
 0834 2031 : R10 CRI CNF address
 0834 2032 : R9 FLD i.d. of field being read
 0834 2033 : R1 Scratch
 0834 2034 : R0 Scratch
 0834 2035 :
 0834 2036 : OUTPUTS: R1 Address of string descriptor or address of field value
 0834 2037 : R0 Low bit set if R1 is valid
 0834 2038 : Low bit clear otherwise
 0834 2039 :
 0834 2040 : ALL other register values are preserved.
 0834 2041 :
 0834 2042 :-
 0834 2043 :
 F4C9' 30 0834 2044 NET\$CRI_V_LCK:: : Get status of cond. writeable fields
 07 50 E9 0834 2045 BSBW NET\$LOCATE_LPD : Locate the LPD
 1B A6 95 0834 2046 BLBC R0,10\$: If LBC no LPD, not locked
 02 12 0834 2047 TSTB LPDSB_ASTCNT(R6) : Any I/O outstanding?
 50 D4 0834 2048 BNEQ 10\$: If NEQ yes, locked
 51 50 0841 2049 CLRL R0 : Else not locked
 50 00 0844 2050 10\$: MOVL R0,R1 : Return as field value
 05 0847 2051 MOVL S^#SS\$_NORMAL,RO : Success
 0848 2052 RSB :
 0848 2053 :
 0848 2054 :
 F4B5' 30 0848 2055 NET\$CRI_L_SUB:: : Get circuit's substate
 0E 50 E9 0848 2056 BSBW NET\$LOCATE_LPD : Locate the LPD
 50 D4 0848 2057 BLBC R0,10\$: If LBC, no LPD, or substate
 04 E0 0850 2058 CLRL R0 : Assume in "run" state
 07 22 A6 0852 2059 BBS #LPDSV_RUN,- : If BS then no sub-state
 51 27 A6 9A 0855 2060 LPDSW_STS(R6),10\$:
 50 00 0859 2061 MOVZBL LPDSB_SUB_STA(R6),R1 : Get sub-state
 05 085C 2062 MOVL S^#SS\$_NORMAL,RO : Set status
 085D 2063 10\$: RSB : Return to co-routine
 085D 2064 :
 F4A0' 30 085D 2065 NET\$CRI_L_DRT:: : Get broadcast circuit's designated router
 25 50 E9 085D 2066 BSBW NET\$LOCATE_LPD : Locate the LPD
 50 D4 0860 2067 BLBC R0,90\$: If not found, return "not set"
 0863 2068 CLRL R0 : Assume not a valid address

1E 22 A6 0A E1 0B65 2069 BBC #LPDSV_BC,LPDSW_STS(R6),90\$; No DRT if not broadcast circuit
 51 2C A6 3C 0B6A 2070 MOVZWL LPDSW_BRT(R6),RT ; Get designated router ADJ index
 18 13 0B6E 2071 BEQL 90\$; If 0, then DRT 'not set'
 54 00000000'EF DO 0B70 2072 MOVL NET\$GL_PTR_VCB,R4 ; Get RCB address
 51 2C B441 DO 0B77 2073 MOVL @RCBSL_PTR_ADJ(R4)[R1],R1 ; Get ADJ address
 51 04 A1 3C 0B7C 2074 MOVZWL ADJSW_PNA(R1),R1 ; Get DRT node address
 06 13 0B80 2075 BEQL 90\$; If 0, then DRT 'not set'
 F47B' 30 0B82 2076 BSBW SUPPRESS_AREA ; Suppress area, if necessary
 50 00' DO 0B85 2077 MOVL S^#SSS_NORMAL,RO ; Set status
 05 0B88 2078 90\$: RSB ; Exit with status/value
 0B89 2079
 0B89 2080 NET\$CRI_L_BLO::
 F474' 30 0B89 2081 BSBW NET\$LOCATE_LPD ; Get partner's receive block size
 1E 50 E9 0B8C 2082 BLBC R0,10\$; Locate the LPD
 50 D4 0B8F 2083 CLRL R0 ; If LBC, no LPD or partner node
 04 E1 0B91 2084 BBC #LPDSV_RUN,- ; Assume not in 'run' state
 17 22 A6 0B93 2085 LPDSW_STS(R6),10\$; If BS then no block size
 54 57 20 A6 9A 0B96 2086 MOVZBL LPDSB_PTH_INX(R6),R7 ; Get LPD index
 00000000'EF DO 0B9A 2087 MOVL NET\$GE_PTR_VCB,R4 ; Get RCB address
 57 2C B447 DO 0BA1 2088 MOVL @RCBSL_PTR_ADJ(R4)[R7],R7 ; Get ADJ address
 51 06 A7 3C 0BA6 2089 MOVZWL ADJSW_BUFSIZ(R7),R1 ; Get partner's node address
 50 00' DO 0BAA 2090 MOVL S^#SSS_NORMAL,RO ; Set status
 05 0BAD 2091 10\$: RSB ; Return to co-routine
 0BAE 2092
 0BAE 2093 NET\$CRI_L_LIT::
 F44F' 30 0BAE 2094 BSBW NET\$LOCATE_LPD ; Get partner's listen timer
 23 50 E9 0BB1 2095 BLBC R0,10\$; Locate the LPD
 50 D4 0BB4 2096 CLRL R0 ; If LBC, no LPD or partner node
 04 E1 0BB6 2097 BBC #LPDSV_RUN,- ; Assume not in 'run' state
 1C 22 A6 0BB8 2098 LPDSW_STS(R6),10\$; If BS then no listen timer
 0A E0 0BBB 2099 BBS #LPDSV_BC,- ; If a broadcast circuit,
 17 22 A6 0BBD 2100 LPDSW_STS(R6),10\$; then no listen timer
 54 57 20 A6 9A 0BC0 2101 MOVZBL LPDSB_PTH_INX(R6),R7 ; Get LPD index
 00000000'EF DO 0BC4 2102 MOVL NET\$GE_PTR_VCB,R4 ; Get RCB address
 57 2C B447 DO 0BCB 2103 MOVL @RCBSL_PTR_ADJ(R4)[R7],R7 ; Get ADJ address
 51 08 A7 3C 0BD0 2104 MOVZWL ADJSW_INT[SN(R7)],R1 ; Get partner's listen timer
 50 00' DO 0BD4 2105 MOVL S^#SSS_NORMAL,RO ; Set status
 05 0BD7 2106 10\$: RSB ; Return to co-routine
 0BD8 2107
 0BD8 2108 NET\$CRI_L_PNA::
 F425' 30 0BD8 2109 BSBW NET\$LOCATE_LPD ; Get partner's node address
 26 50 E9 0BDB 2110 BLBC R0,10\$; Locate the LPD
 50 D4 0BDE 2111 CLRL R0 ; If LBC, no LPD or partner node
 04 E1 0BE0 2112 BBC #LPDSV_RUN,- ; Assume not in 'run' state
 1F 22 A6 0BE2 2113 LPDSW_STS(R6),10\$; If BC then no partner node
 0A E0 0BE5 2114 BBS #LPDSV_BC,- ; If a broadcast circuit,
 1A 22 A6 0BE7 2115 LPDSW_STS(R6),10\$; then no block size
 54 57 20 A6 9A 0BEA 2116 MOVZBL LPDSB_PTH_INX(R6),R7 ; Get LPD index
 00000000'EF DO 0BEE 2117 MOVL NET\$GE_PTR_VCB,R4 ; Get RCB address
 57 2C B447 DO 0BF5 2118 MOVL @RCBSL_PTR_ADJ(R4)[R7],R7 ; Get ADJ address
 51 04 A7 3C 0BFA 2119 MOVZWL ADJSW_PNA(R7),R1 ; Get partner's node address
 F3FF' 30 0BFE 2120 BSBW SUPPRESS_AREA ; Suppress area, if necessary
 50 00' DO 0C01 2121 MOVL S^#SSS_NORMAL,RO ; Set status
 05 0C04 2122 10\$: RSB ; Return to co-routine
 0C05 2123
 F3F8' 30 0C05 2124 NET\$CRI_L_MST:: ; Get maintenance mode state
 0C05 2125 BSBW NET\$LOCATE_LPD ; Locate the LPD

0E 50 E9 0C08 2126 BLBC R0,20\$: If LBC, no LPD or partner node
 51 00 3C 0C0B 2127 MOVZWL #NMASC STATE_ON,R1 : Assume state is "ON"
 02 E0 0COE 2128 BBS #LPDSV_DLE,- : If BS then maintenance state is "ON"
 03 22 A6 0C10 2129 MOVZWL LPDSW_STS(R6),10\$:
 51 01 3C 0C13 2130 MOVL #NMASC STATE OFF,R1 : Else state is "OFF"
 50 00' 05 0C16 2131 10\$: S^\$SS_NORMA[R0] : Set status
 0C19 2132 20\$: RSB : Return to co-routine
 0C1A 2133
 0C1A 2134
 0C1A 2135 NET\$CRI_S_COL:: : Get circuit's collating value
 0C1A 2136 \$GETFLD cri,s,nam : Get circuit's name
 63 09 50 E9 0C27 2137 BLBC R0,10\$: Branch if not present
 50 68 57 28 0C2A 2138 MOVC3 R7,(R8),(R3) : Move the name
 50 0000'8F 3C 0C2E 2139 MOVZWL #SSS_NORMAL,R0 : Indicate success
 05 0C33 2140 10\$: RSB : Return status in R0
 0C34 2141
 0C34 2142 NET\$CRI_S_PNN:: : Get partner's node name
 F3C9' 30 0C34 2143 BSBW NET\$LOCATE_LPD : Locate the LPD
 46 50 E9 0C37 2144 BLBC R0,20\$: If LBC, no LPD or partner node
 50 D4 0C3A 2145 CLRL R0 : Assume not in "run" state
 04 E1 0C3C 2146 BBC #LPDSV_RUN,- : If BC then no partner node
 3F 22 A6 0A E0 0C41 2147 LPDSW_STS(R6),20\$:
 3A 22 A6 0C43 2148 BBS #LPDSV_BC,- : If a broadcast circuit,
 57 20 A6 9A 0C46 2150 LPDSW_STS(R6),20\$: then no block size
 54 00000000'EF DO 0C4A 2151 MOVZBL LPDSB_PTH_INX(R6),R7 : Get LPD index
 57 2C B447 DO 0C51 2152 MOVL NET\$GE_PTR_VCB,R4 : Get RCB address
 58 04 A7 3C 0C56 2153 MOVZWL @RCBSL_PTR_ADJ(R4)[R7],R7 : Get ADJ address
 5B 00000000'EF DO 0C5A 2154 MOVL NET\$GE_CNR_NDI,R11 : Get partner's node address
 F39C' 30 0C61 2155 BSBW NET\$NDI_BY_ADD : Get NDI root block
 19 50 E9 0C64 2156 BLBC R0,20\$: Get the associated NDI CNF
 0C67 2157 \$GETFLD ndi,s,nna : If LBC then none
 09 50 E9 0C74 2158 BLBC R0,20\$: Get node name
 63 68 57 28 0C77 2159 MOVC3 R7,(R8),(R3) : If LBC then not set
 50 0000'8F 3C 0C78 2160 MOVZWL #SSS_NORMAL,R0 : Move the name
 05 0C80 2161 20\$: RSB : Indicate success
 0C81 2162 : Return status in R0
 0C81 2163 NET\$CRI_S_L00:: : Get line's loopback nodename
 0C81 2164 \$GETFLD cri,s,nam : Get line name
 5B 34 50 E9 0C8E 2165 BLBC R0,20\$: If LBC then error
 00000000'EF DO 0C91 2166 MOVL NET\$GL_CNR_NDI,R11 : Get NDI root block
 5A D4 0C98 2167 CLRL R10 : Indicate no current NDI CNF
 19 50 E9 0C9A 2168 \$SEARCH egl_ndi,s,nli : Get find NDI with this loopback line
 0C9C 2169 BLBC R0,20\$: If LBC then not found
 0CAC 2170 \$GETFLD ndi,s,nna : Get the node name
 09 50 E9 0CB9 2171 BLBC R0,20\$: If LBC then not set
 63 68 57 28 0CBC 2172 MOVC3 R7,(R8),(R3) : Move the name
 50 0000'8F 3C 0CC0 2173 MOVZWL #SSS_NORMAL,R0 : Indicate success
 05 0CC5 2174 20\$: RSB : Return status in R0
 0CC6 2175
 0CC6 2176 NET\$CRI_S_VMSNAM:: : Get VMS name of device
 0CC6 2177 \$GETFLD cri,s,nam : Get network management circuit name
 03 50 E9 0CD3 2178 BLBC R0,10\$: If LBC then error
 0693 30 0CD6 2179 BSBW TRAN_DEVNAM : Get VMS device name
 0CD9 2180 : Exit with status
 05 0CD9 2181 100\$: RSB : Assume that any remaining characters are part of tributary identifier
 : Return status in R0

OCDA 2183
 OCDA 2184 NET\$CRI_S_DEVNAM:::
 F323' 30 OCDA 2185 BSBW NET\$LOCATE_LPD : Get VMS device name, including unit
 59 50 E9 OCDD 2186 BLBC R0,80\$: Locate LPD
 04 E1 OCEO 2187 BBC #LPDSV_RUN,- : Branch if none
 54 22 A6 OCE2 2188 LPDSW_STS(R6),80\$: Exit if circuit not in run state
 SE 04 C2 OCE5 2189 SUBL #4,SP : Used for returning device characteristics
 54 5E DD OCE8 2190 MOVL SP,R4 : Point R4 at return buffer
 00 DD OCEB 2191 PUSHL #0 : Terminate GETDVI item list
 00000029' EF 9F OCED 2192 PUSHAB QIOW_Q_IOSB : Point to DEVCHAR length word (use IOSB)
 54 DD OCF3 2193 PUSHL R4 : Point to DEVCHAR return buffer
 7E 02 B0 OCF5 2194 MOVW #DVIS_DEVCHAR,-(SP) : Item code
 7E 04 B0 OCF8 2195 MOVW #4,-(SP) : Size of DEVCHAR result buffer
 00000031' EF 9F OCFB 2196 PUSHAB QIOW_W_RETLEN : Point to result length word
 53 DD OD01 2197 PUSHL R3 : Point to result buffer
 7E 20 B0 OD03 2198 MOVW #DVIS_DEVNAM,-(SP) : Item code
 7E 20 B0 OD06 2199 MOVW #DEVNAM_C_SIZE,-(SP) : Size of result buffer
 51 5E DD OD09 2200 MOVL SP,R1 : Point to item list
 ODOC 2201 \$GETDVI_S_ITMLST=(R1),- : Construct actual device name
 ODOC 2202 EFN=#NET\$C_EFN_WAIT,- : Use synchronous event flag
 ODOC 2203 CHAN=LPDSW_CHAN(R6)
 SE 20 C0 OD23 2204 ADDL #8*4,SP : Pop item list
 15 50 E9 OD26 2205 BLBC R0,90\$: Branch if error detected
 51 00000031' EF 3C OD29 2206 BBC #DEV\$V_NET,(R4),80\$: Br if not a network device
 53 51 C0 OD34 2207 MOVZWL QIOW_W_RETLEN,R1 : Get length of result buffer
 05 11 OD37 2208 ADDL R1,R3 : Point past result string
 50 0000' 8F 3C OD39 2210 80\$: BRB 90\$: Success
 ODOC 2211 80\$: MOVZWL #SSS_IVDEVNAM,R0 : Error in <cri,s,nam> field, or
 ODOC 2212 90\$: RSB : not a network device
 ODOC 2213 : Return status in R0
 ODOC 2214 NET\$CRI_S_CNT:: :
 53 DD OD3F 2215 PUSHL R3 : Get line counters (maybe clear them)
 03 58 E9 OD41 2216 \$GETFLD cri_l_typ : Save starting address of counter block
 31 50 D1 OD4E 2217 BLBC R0,20\$: Get circuit type
 58 12 OD51 2218 CMPL R8,#NMASC_CIRTY_X25 : Branch if not set, assume not X25
 2C 12 OD54 2219 BNEQ 20\$: X.25 circuit?
 F2A7' 30 OD56 2220 BSBW NET\$LOCATE_LPD : Branch if not
 21 50 E9 OD59 2221 BLBC R0,10\$: Get associated LPD, if any
 ODOC 2222 : Branch if no datalink mapping enabled
 ODOC 2223 : X.25 datalink mapping circuit counters
 ODOC 2224 :
 3F 10 OD5C 2225 BSBW 50\$: Get Transport counters & seconds
 53 DD OD5E 2226 PUSHL R3 : Save current position in buffer
 0065 30 OD60 2227 BSBW 200\$: Get PSI circuit counters & seconds
 58 8ED0 OD63 2228 POPL R8 : Get start of PSI counter block
 OF 50 E9 OD66 2229 BLBC R0,5\$: Branch if no PSI counters (possible
 for switched circuits)
 COOO 8F 68 B1 OD69 2231 CMPW (R8),#NET\$C_NMACNT_SLZ : "seconds since last zeroed" ?
 1A 12 OD6E 2232 BNEQ 30\$: Branch if not
 68 04 A8 57 C2 OD70 2233 SUBL #4,R7 : Account for loss of PSI "seconds"
 50 01 28 OD73 2234 MOVC R7,4(R8),(R8) : Delete PSI seconds counter from block
 OD 11 OD78 2235 5\$: MOVL #1,R0 : Success
 ODOC 2236 : Native X.25 circuit counters
 ODOC 2237 :
 ODOC 2238 :
 ODOC 2239 :

0048 08 30 0D7D 2240 10\$: BSBW 200\$; Get PSI circuit counters & seconds
 11 0D80 2241 BRB 30\$; and continue with status in R0
 OD82 2242
 OD82 2243 : Non-X25 circuit counters
 OD82 2244
 F27B' 30 0D82 2245 20\$: BSBW NET\$LOCATE_LPD ; Get associated LPD
 11 50 E9 0D85 2246 BLBC R0,40\$; Error if LBC
 13 10 0D88 2247 BSBB 50\$; Get the Transport counters
 52 6E D0 0D8A 2248 30\$: MOVL (SP),R2 ; Recover original counter block ptr
 09 50 E9 0D8D 2249 BLBC R0,40\$; If LBC then error
 50 03 D0 0D90 2250 MOVL S^#EVCS_C_SRC_CIR,R0 ; Setup database event i.d.
 F26A' 30 0D93 2251 BSBW LOG_COUNTERS ; Log the counters if they were zeroed
 50 00 D0 0D96 2252 MOVL S^#5SS_NORMAL,R0 ; Success
 5E 04 C0 0D99 2253 40\$: ADDL #4,SP ; Pop buffer pointer
 05 0D9C 2254 RSB ; Done
 OD9D 2255
 OD9D 2256 :
 OD9D 2257 : Subroutine to move Transport and datalink counters
 OD9D 2258
 55 00000000'EF 9E 0D9D 2259 50\$: MOVAB LPD_CNT_TAB,R5 ; Point to Transport counter table
 52 1A 3C 0DA4 2260 MOVZWL #4+LPD\$C_CNT_SIZE,R2 ; Number of bytes of Transport counters
 ODA7 2261
 51 36 A6 9E 0DA7 2262 MOVAB LPDSL_ABS_TIM(R6),R1 ; Point to counters
 00000000'EF 16 0DAB 2263 JSB MOVE_FMT_CNT ; Move and format Transport counters
 0DB1 2264
 0DB1 2265 : Get the counters from the driver and append to current counters
 0DB1 2266 : minus the 'seconds since last zeroed' counter.
 0DB1 2267
 OE 22 A6 07 E0 0DB1 2268 BBS #LPDSV_X25,LPDSW_STS(R6),90\$; Skip if X.25 datalink
 52 14 A6 3C 0DB6 2269 MOVZWL LPDSW_CHAN(R6),R2 ; Is there an I/O channel
 08 13 0DBA 2270 BEQL 90\$; If EQL no, skip this phase
 0000'8F 3C 0DBC 2271 MOVZWL #IOS_SENSEMODE!- ; Setup function code
 50 00 0DC0 2272 IOSM_RD_COUNT,R0
 0673 30 0DC1 2273 BSBW DEV_CNT_QIO ; Issue circuit QIO for counters
 50 0C 3C 0DC4 2274 90\$: MOVZWL S^#5SS_NORMAL,R0 ; Indicate success
 05 0DC7 2275 100\$: RSB ; Done
 0DC8 2276
 0DC8 2277 :
 0DC8 2278 : Subroutine to move PSI circuit counters
 0DC8 2279 :
 0DC8 2280 :
 0048 8F B8 0DC8 2281 200\$: PUSHR #^M<R3,R6> ; Save registers
 ODCC 2282 \$CNFFLD cri,s,nam,R9 ; Set field ID of circuit name
 FB55 30 0DD3 2283 BSBW SEND_TO_PSI ; Call co-routine to setup NFB, etc.
 22 50 E9 0DD6 2284 BLBC R0,59\$; Branch if error detected
 0DD9 2285 \$CNFFLD cri,s,cnt,(R2)+ ; Store counter field ID into NFB
 66 22 90 0DE0 2286 MOVB #NFB\$C_FC_SHOW,NFB\$B_FCT(R6) ; Set function code
 02 E` 0DE3 2287 BBC #NET\$V_CLR_CNT,NET\$GL_FLAGS,55\$; Branch if not clearing counters
 66 25 90 0DEB 2288 MOVB #NFB\$C_FC_ZERO,NFB\$B_FCT(R6) ; Set READ & ZERO function code
 03 00000000'EF 8F C0 0DEE 2289 55\$: ADDL #P4BUF_SIZE,R3 ; Set size of P4 return buffer
 9E 16 0DF5 2290 JSB a(SP)+ ; Call SEND_TO_PSI back to issue QIO
 0048 8F BA 0DF7 2291 POPR #^M<R3,R6> ; Restore registers
 C9 50 E9 0DFB 2292 59\$: BLBC R0,100\$; Branch if error detected
 57 88 3C 0DFE 2293 MOVZWL (R8)+,R7 ; Make descriptor of CNT string
 63 68 57 28 0E01 2294 MOVC R7,(R8),(R3) ; Copy P4 buffer into counter block
 50 59 D0 0E05 2295 MOVL R9,R0 ; Point to scratch storage
 00000000'EF 16 0E08 2296 JSB NE\$DEALLOCATE ; Deallocate SHOW buffer

50 01 D0 0E0E 2297 MOVL #1,R0 ; Success
 05 0E11 2298 RSB
 0E12 2299
 0E12 2300 NET\$CRI_S_CHR::
 F1EB' 30 0E12 2301 BSBW NET\$LOCATE_LPD
 45 50 E9 0E15 2302 BLBC R0,100\$
 53 DD 0E18 2303 PUSHL R3
 00 6E 00 2C 0E1A 2304 MOVC5 #0,(SP),#0,-
 63 18 0E1E 2305 #DLLQIOSL_LENGTH,(R3)
 55 8ED0 0E20 2306 POPL R5
 50 28 A6 9A 0E23 2307 CLRL R0
 32 13 0E29 2308 MOVZBL LPDSB_PLVEC(R6),R4
 50 10 A6 D0 0E2B 2310 BEQL 100\$
 2C 13 0E2F 2311 MOVL LPDSL_UCB(R6),R0
 0000'8F 3C 0E31 2312 BEQL 100\$
 65 0E35 2313 MOVZWL #IOS_SETMODE,-
 0E40 2314 DELLQIOSL_FUNC(R5)
 52 0000016C'EF 9E 0E36 2315 MOVAB CRI_TRN_TAB,R2
 5D'AF 9F 0E3D 2316 PUSHAB B^10\$
 0E40 2317 \$DISPATCH TYPE=B,PLVECSAB_DEV[R4],- ; Dispatch on device type
 0E40 2318 <-
 0E40 2319 <DEVTRNSC_DEV_DMC, CRI_DMC>,-
 0E40 2320 <DEVTRNSC_DEV_PCL, CRI_PCL>,-
 0E40 2321 <DEVTRNSC_DEV_DMP, CRI_DMP>,-
 0E40 2322 <DEVTRNSC_DEV_CI, CRI_CI>,-
 0E40 2323 >
 01 11 0E58 2324 BRB CRI_FOREIGN ; Br if device is unknown
 05 0E5D 2325 10\$: RSB
 0E5D 2326 100\$:
 0E5E 2327
 0E5E 2328 CRI_DMP:
 0E5E 2329 CRI_PCL:
 0E5E 2330 CRI_CI:
 0E5E 2331 CRI_UNA:
 044F 0E5E 2332 CRI_FOREIGN:
 30 0E5E 2333 BSBW BUILD_DEVBUF ; Build the device parameter buffer
 05 0E61 2334 RSB ;
 0E62 2335
 04 A5 53 55 C3 0E62 2336 CRI_DMC:
 0E62 2337 SUBL3 R5,R3,DLLQIOSL_P1(R5) ; Setup offset to characteristics buffer
 0E67 2338
 0E67 2339
 0E67 2340 : Get the characteristics buffer form the UCB. This buffer was setup
 0E67 2341 properly (with the exception of the MOP bit) from the PLI database
 0E67 2342 when the corresponding DMC "line" was turned on.
 0E67 2343
 0E67 2344
 0E67 2345 ASSUME UCBSL_DEVDEPEND EQ 2+UCBSW_DEVBUFSIZ
 0E67 2346 ASSUME UCBSW_DEVBUFSIZ EQ 1+UCBSB_DEVTYPE
 0E67 2347 ASSUME UCBSB_DEVTYPE EQ 1+UCBSB_DEVCLASS
 83 40 A0 7D 0E67 2348 MOVQ UCBSB_DEVCLASS(R0),(R3)+; Enter device characteristics
 0E68 2349 CLRBIT XMSV_CHR_MOP,-4(R3) ; Assume MOP mode not needed
 02 E1 0E6F 2350 BBC #LPDSV_DCE,- ; If BC not in use for direct-access
 04 22 A6 0E71 2351 LPDSW_STS(R6),10\$; functions
 0E74 2353 SETBIT XMSV_CHR_MOP,-4(R3) ; Put line in MOP mode

		OE78	2354	10\$:		
		OE78	2355		:	
		OE78	2356		: Get number of receive buffers from the PLI database	
		OE78	2357		:	
		OE78	2358		:	
5B	00000000'EF	BB	OE78	2359	PUSHR #^M<R1,R10,R11>	; Save regs
	5A	D0	OE7C	2360	MOVL NET\$GL_CNR_PLI,R11	; Get PLI root block
58	54	D4	OE83	2361	CLRL R10	; Search from begining of list
		D0	OE85	2362	MOVL R4,R8	; Search key is the PLVEC index
10	50	E9	OE88	2363	\$SEARCH eq[pli,l,plvec	; Find PLI's CNF block
			OE9A	2364	BLBC R0,15\$; If LBC then not found
03	50	E8	OE97	2365	\$GETFLD pli,l,bfn	; Get # of receive buffers
OC	58	D0	OEAA	2366	BLBS R0,20\$; If LBS then field was active
A5	58	D0	OEAD	2367	15\$: MOVL #4,R8	; Setup default
OC02	8F	BA	OE81	2368	20\$: MOVL R8,DLLQ10\$L P3(R5)	; Setup # of receive buffers
			OE85	2369	POPR #^M<R1,R10,R11>	; Restore regs
50	01	90	OE85	2370		
		05	OE88	2371	MOVW #1,R0	; Indicate success
				100\$:	RSB	; Return status in R0

0EB9 2374 .SBTTL PLI parameter action routines
 0EB9 2375 :+
 0EB9 2376 : NET\$PLI_V_LCK - Get status of conditionally writeable fields
 0EB9 2377 :
 0EB9 2378 : NET\$PLI_L_SUB - Get line's substate
 0EB9 2379 : NET\$PLI_L_BUS - Get line's receive buffer size
 0EB9 2380 : NET\$PLI_L_PLVEC Get line's PLVEC index
 0EB9 2381 :
 0EB9 2382 : NET\$PLI_S_COL - Get line's collating value
 0EB9 2383 : NET\$PLI_S_VMSNAM Get VMS name of associated device
 0EB9 2384 : NET\$PLI_S_DEVNAM Get VMS name of associated device, but with unit included
 0EB9 2385 : NET\$PLI_S_CNT - Get (optionally clear) line counters
 0EB9 2386 : NET\$PLI_S_CHR - Get line's characteristics buffer
 0EB9 2387 :
 0EB9 2388 : INPUTS: R11 PLI CNR address
 0EB9 2389 : R10 PLI CNF address
 0EB9 2390 : R9 FLD i.d. of field being read
 0EB9 2391 : R1 Scratch
 0EB9 2392 : R0 Scratch
 0EB9 2393 :
 0EB9 2394 : OUTPUTS: R1 Address of string descriptor or address of field value
 0EB9 2395 : R0 Low bit set if R1 is valid
 0EB9 2396 : Low bit clear otherwise
 0EB9 2397 :
 0EB9 2398 : All other register values are preserved.
 0EB9 2399 :
 0EB9 2400 :-
 0EB9 2401 :
 0EB9 2402 NET\$PLI_V_LCK:: : Get status of cond. writeable fields
 0EB9 2403 \$GETFLD pli_l_sta : Get the state value
 07 50 E9 0EC6 2404 BLBC RO,10\$: : If LBC then not locked
 58 01 D1 0EC9 2405 CMPL #NMASC_STATE_OFF,R8 : Is the line turned off?
 02 12 0ECC 2406 BNEQ 10\$: If NEQ then locked
 51 50 D4 0ECE 2407 CLRL RO : Say "not locked"
 50 50 D0 0ED0 2408 10\$: MOVL RO,R1 : Return as field value
 50 00' D0 0ED3 2409 MOVL S^#SSS_NORMAL,RO : Success
 05 0ED6 2410 RSB :
 0ED7 2411 :
 50 D4 0ED7 2412 NET\$PLI_L_SUB:: : Get line's substate
 0ED9 2413 CRL RO : No substate is defined for lines
 at this time
 05 0ED9 2414 RSB : Return status in R0
 0EDA 2415 :
 51 12 AA, 9A 0EDA 2417 NET\$PLI_L_PLVEC:: : Get line's PLVEC index
 50 00' D0 0ED0 2418 MOVZBL CNFSW_ID(R10),R1 : Get the PLVEC index
 05 0EE1 2419 MOVL S^#SSS_NORMAL,RO : Success
 0EE2 2420 RSB : Return
 0EE2 2421 :
 0EE2 2422 NET\$PLI_L_BUS:: : Get line's receive buffer size
 0EE2 2423 : (MUST preserve R2-R11)
 51 0380 8F BB 0EE2 2424 PUSHR #^M<R7,R8,R9> : Save registers
 00000000'EF D0 0EE6 2425 MOVL NET\$GL_PTR_VCB,R1 : Get RCB address
 51 7E A1 3C 0EE6 2426 MOVZWL RCBSW_TOTB0FSIZ(R1),R1 : Store the local block size
 51 004C 8F A2 0EF1 2427 SUBW #CXB\$C_OVERHEAD,R1 : Subtract out overhead
 0EF6 2428 :
 0EF6 2429 : If this is an Ethernet controller, then add an additional
 0EF6 2430 : 15 bytes overhead to account for the extended Ethernet

			0EF6	2431	: Route Header used by Transport. This is done only for	
			0EF6	2432	: Ethernet datalinks to avoid burdening point-to-point datalinks	
			0EF6	2433	: with the additional memory for its buffers.	
			0EF6	2434		
09	50 12 AA 0D 00000000'EF40	3C 91	0EF6 OF04	2435 2437	MOVZWL CNFSW_ID(R10),R0 BEQL 50\$: Get PLVEC index
			0EFA OF04	2436 2438	CMPB PLVECSAB_DEV[R0],- #DEVTRNSC_DEV_UNA	: If none, skip it
	51 03 16	12 C0	OF06 OF09	2439 2441	BNEQ 50\$ ADDL #TRSC_MAXHDR-6,R1	: Is this an Ethernet controller?
			OF09 OF09	2442 2443		: Skip if not
			OF09 OF09	2444 2445		: Add additional overhead for
			OF09 OF09	2446 2447		: Phase IV Ethernet Transport header
50	51 03 50 51 58 0000'8F 0380 8F	E9 D0 3C BA 05	OF16 OF19 OF1C OF21 OF25	2448 2449 2450 2451 2452	\$GETFLD pli_l_bfs BLBC R0,90\$ MOVL R8,R1 MOVZWL #SSS_NORMAL,R0 POPR #^M<R7,R8,R9> RSB	: Executor buffer size overridden? : Skip if not set : If set, use it (includes xpt header) : Success : Restore registers : Return status in R0
63	68 09 50 50 0000'8F	E9 28 3C 05	OF33 OF36 OF3A OF3F	2455 2456 2457 2458	\$GETFLD pli_s_nam BLBC R0,10\$ MOVC3 R7,(R8),(R3) MOVZWL #SSS_NORMAL,R0	: Get line's collating value : Get line's name : Branch if not present : Move the name : Indicate success : Return status in R0
50	OF 50 0419 09 50 57 05 0000'8F	E9 30 E9 D5 13 3C 05	OF40 OF40 OF50 OF53 OF56 OF58 OF5A OF5F	2459 2460 2461 2462 2464 2465 2467 2468	10\$: RSB NET\$PLI_S_VMSNAM: \$GETFLD pli_s_nam BLBC R0,10\$ BSBW TRAN_DEVNAM BLBC R0,10\$ TSTL R7 BEQL 10\$ MOVZWL #SSS_IVDEVNAM,R0	: Get VMS name of device : Get network management line name : If LBC then error : Translate the device name : If LBC then error : Any characters left? : If EQL then none, name is okay : Error in <pli,s,nam> field : Return status in R0
58	58 12 AA 58 00000000'EF48 5E 04 54 5E 00 00000029'EF 54 7E 02 7E 04 00000031'EF 53 7E 20 7E 20 51 5E	3C 13 3C C2 DD 9F DD 80 80 9F DD 80 80 0D	OF60 OF64 OF66 OF6E OF71 OF74 OF76 OF7C OF7E OF81 OF84 OF8A OF92 OF95	2471 2472 2473 2474 2475 2476 2477 2478 2479 2480 2481 2482 2483 2484 2485 2486	NET\$PLI_S_DEVNAM: MOVZWL CNFSW_ID(R10),R8 BEQL 80\$ MOVZWL PLVECSAW_CHAN[R8],R0 SUBL #4,SP MOVL SP,R4 PUSHL #0 PUSHAB QIOW_Q_IOSB PUSHL R4 MOVW #DVIS_DEVCHAR,-(SP) MOVW #4,-(SP) PUSHAB QIOW_W_RETLEN PUSHL R3 MOVW #DVIS_DEVNAM,-(SP) MOVW #DEVNAM_C_SIZE,-(SP) MOVL SP,R1 SGETDVI_S_ITMLST=(R1),-	: Get VMS device name, including unit : Get PLVEC index : Branch if none : Get channel used by line : Used for returning device characteristics : Point R4 at return buffer : Terminate GETDVI item list : Point to DEVCHAR length word (use IOSB) : Point to DEVCHAR return buffer : Item code : Size of DEVCHAR result buffer : Point to result length word : Point to result buffer : Item code : Size of result buffer : Point to item list : Construct actual device name

51 00000031'EF 5E 15 20 0F95 2488 EFN=#NET\$C_EFN_WAIT,- ; Use synchronous event flag
 0C 64 0D E9 0FAE 2489 CHAN=R0
 53 51 3C 0FB1 2490 ADDL #8*4 SP
 05 11 CO 0FB5 2491 BLBC R0,90\$; Pop item list
 50 0000'8F 3C 0FB5 2492 BBC #DEV\$V_NET,(R4),80\$; Branch if error detected
 05 11 CO 0FB5 2493 MOVZWL QIOW_W_RETLEN,R1 ; Br if not a network device
 05 11 OFBF 2494 ADDL R1,R3 ; Get length of result buffer
 05 11 OFBF 2495 BRB 90\$; Point past result string
 05 11 OFC1 2496 80\$: MOVZWL #SSS_IVDEVNAM,RO ; Success
 05 11 OFC6 2497 90\$: RSB ; Error in <pli,s,nam> field or
 05 11 OFC7 2498 not a network device
 05 11 OFC7 2499 90\$: RSB ; Return status in R0
 53 DD 0FC7 2500 NET\$PLI_S_CNT:: ; Get line counters (maybe clear them)
 05 09 50 E9 0FD6 2501 PUSHL R3 ; Save starting address of counter block
 05 58 D1 0FD9 2502 ;
 04 12 OFDC 2503 ; If this is an X.25 circuit, then ask PSI for its counters.
 05 10 OFDE 2504 ;
 05 11 OFEO 2505 \$GETFLD pli_l_pro ; Get line protocol code
 05 11 OFEO 2506 BLBC R0,10\$; Branch if not specified
 05 11 OFEO 2507 CMPL R8,#NMASC_LINPR_LAPB ; LAPB line?
 05 11 OFEO 2508 BNEQ 10\$; If not, use normal SENSEMODE
 05 11 OFEO 2509 BSSB 200\$; Get PSI line counters & seconds
 05 11 OFEO 2510 BRB 20\$;
 05 11 OFE2 2511 ;
 05 11 OFE2 2512 ; Get non-X25 line counters
 05 11 OFE2 2513 ;
 01 00000000'EF46 56 12 AA 3C 0FE2 2514 10\$: MOVZWL CNFSW_ID(R10),R6 ; Get PLVEC index
 01 00000000'EF46 18 13 0FE6 2515 BEQL 30\$; Branch if none
 01 00000000'EF46 91 0FE8 2516 CMPB PLVECSAB_DEV[R6],- ; No counters for DMC "lines" (special
 01 00000000'EF46 0E 13 OFF0 2517 #DEVTRNSC_DEV_DMC ; case this since XMDRIVER does not
 01 00000000'EF46 0E 13 OFF0 2518 BEQL 30\$; support the standard datalink driver
 01 00000000'EF46 13 10 OFF2 2519 ; interface).
 52 6E DD 0FF4 2520 BSSB 50\$; Get the counters
 52 09 50 E9 0FF7 2521 20\$: MOVL (SP),R2 ; Recover original counter block ptr
 50 01 DD 0FFA 2522 BLBC R0,40\$; If LBC then error
 50 F000' 30 OFFD 2523 MOVL S^#EVCS_C_SRC_LIN,RO ; Setup database event i.d.
 50 00' DD 1000 2524 BSBW LOG_COUNTERS ; Log the counters if they were zeroed
 5E 04 CO 1003 2525 30\$: MOVL S^#SSS_NORMAL,RO ; Success
 5E 04 CO 1003 2526 40\$: ADDL #4,SP ; Pop counter address off stack
 5E 04 CO 1006 2527 RSB ; Done
 5E 04 CO 1007 2528 ;
 5E 04 CO 1007 2529 50\$: ; Subroutine to build the counter block
 51 00000000'EF46 DE 1007 2530 1007 ;
 55 00000028'EF 52 04 DD 100F 2531 1007 ;
 55 00000000'EF 9E 1012 2532 MOVAL PLVECSAL_ABS_TIM[R6],R1 ; Point to seconds since last zeroed
 16 1019 2533 100F ; counters
 101F 2534 MOVL #4,R2 ; Number of bytes in block
 101F 2535 MOVAB PLI_CNT_TAB,R5 ; Point to counter formatting table
 101F 2536 JSB MOVE_FMT_CNT ; Move and format the counters
 101F 2537 ;
 101F 2538 ; Get the counters from the driver and append to counter block
 101F 2539 ; being constructed.
 52 00000000'EF46 3C 101F 2540 ;
 08 13 1027 2541 70\$: MOVZWL PLVECSAW_CHAN[R6],R2 ; Is there an I/O channel
 3C 1029 2542 BEQL 90\$; If EQL no, skip this phase
 3C 102A 2543 MOVZWL #IOS_SENSEMODE!- ; Setup function code
 3C 102A 2544 IOS_CTRL!-

```

50 0000'8F 102A 2545      IOSM RD COUNT,RO : SSD
      0406 102E 2546      BSBW DEV CNT QIO : SST
      50 00' 3C 1031 2547 90$: MOVZWL S^#55$_NORMAL,RO : SS-
      05 1034 2548 100$: RSB ; Done : SS-
      1035 2549 : SWI
      1035 2550 : SWI
      1035 2551 : SWI
      1035 2552 : SWI
      0048 8F BB 1035 2553 200$: PUSHR #^M<R3,R6> : ACP
      F8F8 30 1039 2554 $CNFFLD pli,s,nam,R9 : ACP
      22 50 E9 1040 2555 BSBW SEND_TO_PSI : ACP
      66 22 90 1040 2556 BLBC R0,59$ : ACP
      02 E1 1050 2557 $CNFFLD pli,s,cnt,(R2)+ : ACP
      66 25 90 1058 2558 MOVB #NFBSC_FC SHOW,NFB$B_FCT(R6) : Set function code : ACP
      03 00000000'EF 02 E1 1050 2559 BBC #NET$V_CLR_CNT,NET$GL_FLAGS,55$ : Branch if not clearing counters : ADJ
      00000200 8F C0 1058 2560 MOVB #NFBSC_FC ZERCOU,NFB$B_FCT(R6) : Set READ & ZERO function code : ADJ
      9E 16 1062 2561 55$: ADDL #P4BUF_SIZE,R3 : Set size of P4 return buffer : ADJ
      0048 8F BA 1064 2562 JSB @(SP)+ : Call SEND_TO_PSI back to issue QIO : ADJ
      C9 50 E9 1068 2563 POPR #^M<R3,R6> : Restore registers : ADJ
      57 88 3C 1068 2564 59$: BLBC R0,100$ : Branch if error detected : ALL
      63 68 57 28 106E 2565 MOVZWL (R8)+,R7 : Make descriptor of CNT string : BIT
      50 59 00 1072 2566 MOVC R7,(R8),(R3) : Copy string into counter block : BUI
      00000000'EF 16 1075 2567 MOVL R9,RO : Point to scratch storage : CCB
      50 01 00 1078 2568 JSB NET$DEALLOCATE : Deallocate SHOW buffer : CLE
      05 107E 2569 MOVL #1,RO : Success : CNF
      107F 2570 RSB : CNF
      107F 2571 NET$PLI_S_CHR:: : CNF
      00 6E 53 DD 107F 2572 PSHL R3 : Get line's startup characteristics : CNF
      63 00 2C 1081 2573 MOVCS #0,(SP),#0,- : Save pointer to buffer : CNF
      63 18 1085 2574 #DLQIO$C_LENGTH,(R3) : Zero buffer header : CNF
      55 8BED0 1087 2575 POPL R5 : ..advance R3 : CNF
      50 D4 108A 2576 CLRL RO : Point to top of buffer : CNF
      54 12 AA 3C 108C 2577 MOVZWL CNFSW_ID(R10),R4 : Assume no PLVEC index assigned : CNF
      4C 13 1090 2578 BEQL 100$ : Get PLVEC index : CNF
      1092 2580 : If EQL then return error : CNF
      1092 2581 : Setup default function value : CNR
      1092 2582 : CNV
      1092 2583 $DISPATCH TYPE=B,PLVEC$AB_STATE[R4],- ; Dispatch by state value : CNV
      1092 2584 <- : CNV
      1092 2585 <NMASC STATE OFF, 10$>,- : CNV
      1092 2586 <NMASC STATE ON, 20$>,- : CNV
      1092 2587 > : CNV
      50 0000'8F B0 109F 2588 MOVW #IOS_SETMODE!IOSM_CTRL,RO ; Use this for all other states : CNV
      0C 11 10A4 2589 BRB 30$ : Continue : CNV
      0000'8F B0 10A6 2590 10$: MOVW #IOS_SETMODE!IOSM_CTRL!- : State is "off" : CNV
      50 10AA 2591 10$>,- IO$M_SHUTDOWN,RO : CNV
      05 11 10AB 2592 BRB 30$ : Continue : CNV
      0000'8F B0 10AD 2593 20$: MOVW #IOS_SETMODE!IOSM_CTRL!- : State is "on" : CNV
      50 10B1 2594 20$>,- IO$M_STARTUP,RO : CNV
      52 000001B8'EF 65 50 3C 10B2 2595 30$: MOVZWL R0,D[LQIOSL_FUNC(R5)] : CRI
      DE'AF 9E 10B5 2596 MOVAB PLI TRN_TAB,R2 : Point to param translation table : CRI
      9F 10BC 2597 PUSHAB B^40$ : Setup return address : CRI
      10BF 2598 : CRI
      10BF 2599 : CRI
      10BF 2600 : CRI
      10BF 2601 : CRI
      $DISPATCH TYPE=B,PLVEC$AB_DEV[R4],- ; Dispatch on device type : CRI
      <- <DEVTRNSC_DEV_DMC, PLI_DMC>,- : CRI
  
```

NET
Sym

10BF 2602 <DEVTRNSC_DEV_PCL, PLI_PCL>,-
 10BF 2603 <DEVTRNSC_DEV_DMP, PLI_DMP>,-
 10BF 2604 <DEVTRNSC_DEV_CI, PLI_CI>,-
 10BF 2605 <DEVTRNSC_DEV_UNA, PLI_UNA>,-
 10BF 2606 <DEVTRNSC_DEV_PPUNA, PLI_PPUNA>,-
 10BF 2607 >
 01 11 10DC 2608 BRB PLI_FOREIGN ; Br if device is unknown
 05 10DE 2609 40\$: RSB
 10DF 2610 100\$: RSB
 10DF 2611
 10DF 2612 PLI_DMP:
 10DF 2613 PLI_PCL:
 10DF 2614 PLI_CI:
 01CE 30 10DF 2615 PLI_FOREIGN:
 05 10E2 2616 BSBW BUILD_DEVBUF ; Build the parameter buffer
 10E3 2617 RSB
 10E3 2618
 10E3 2619 PLI_UNA:
 01CA 30 10E3 2620 BSBW BUILD_DEVBUF ; Build standard parameter buffer
 53 DD 10E6 2621 PUSHL R3 ; Save position in P2 buffer
 83 0B18 8F BO 10E8 2622 MOVW #NMASC_PCLI_PRM,(R3)+ ; Promiscuous mode = OFF
 83 01 DO 10ED 2623 MOVL #NMASC_STATE_OFF,(R3)+ ; Multicast address state = OFF
 83 0B19 8F BO 10F0 2624 MOVW #NMASC_PCLI_MLT,(R3)+ ; MAX
 83 01 DO 10F5 2625 MOVL #NMASC_STATE_OFF,(R3)+ ; Padding on transmits = ON
 83 0B1A 8F BO 10F8 2626 MOVW #NMASC_PCLI_PAD,(R3)+ ; MOV
 83 00 DO 10FD 2627 MOVL #NMASC_STATE_ON,(R3)+ ; NET
 83 0B1B 8F BO 1100 2628 MOVW #NMASC_PCLI_DCH,(R3)+ ; NET
 83 01 DO 1105 2629 MOVL #NMASC_STATE_OFF,(R3)+ ; (DLLTRN can't handle multiple XBs)
 83 0B1C 8F BO 1108 2630 MOVL #NMASC_PCLI_CRC,(R3)+ ; NET
 83 00 DO 110D 2631 MOVL #NMASC_STATE_ON,(R3)+ ; NET
 83 0B1E 8F BO 1110 2632 MOVL #NMASC_PCLI_ACC,(R3)+ ; NET
 83 03 DO 1115 2633 MOVL #NMASC_ACC_EXC,(R3)+ ; NET
 83 0B0E 8F BO 1118 2634 MOVL #NMASC_PCLIPTY,(R3)+ ; NET
 111D 2635 SGETFLD pli_L_pty ; Protocol type parameter code
 05 50 E8 112A 2636 BLBS R0,10\$; Get protocol type to be used
 58 0360 8F 3C 112D 2637 MOVZWL #TRSC_NI_PROT,R8 ; Branch if ok
 83 58 DO 1132 2638 10\$: MOVL R8,(R3)+ ; Else, provide a default value
 83 0B04 8F BO 1135 2639 MOVL #NMASC_PCLI_PHA,(R3)+ ; Set protocol type
 83 08 BO 113A 2640 MOVL #8,(R3)+ ; Physical address = Phase IV address
 83 01 BO 113D 2641 MOVL #NMASC_LINMC_SET,(R3)+ ; 8 byte string:
 57 000400AA 8F DO 1140 2642 MOVL #TRSC_NI_PREFIX,(R3)+ ; Set the address
 57 00000000 EF DO 1147 2643 MOVL NETSGE_PTR_VCB,R7 ; Phase IV NI prefix
 83 0E A7 BO 114E 2644 MOVL RCBSW_ADDR(R7),(R3)+ ; Phase IV node number
 83 0B0F 8F BO 1152 2645 MOVL #NMASC_PCLI_MCA,(R3)+ ; Multicast addresses are:
 83 08 BO 1157 2646 MOVL #8,(R3)+ ; 8 byte string:
 83 01 BO 115A 2647 MOVL #NMASC_LINMC_SET,(R3)+ ; Set the address
 83 030000AB 8F DO 115D 2648 MOVL #TRSC_NI_ALLROUT1,(R3)+ ; Phase IV "all routers" multicast
 83 00 BO 1164 2649 MOVL #TRSC_NI_ALLROUT2,(R3)+
 05 008A C7 91 1167 2650 CMPB RCBSB_ETY(R7),#ADJSC_PTY_PH4N ; If Phase IV endnode,
 0D 12 116C 2651 BNEQ 20\$ use "all endnodes" instead
 83 040000AB 8F DO 1171 2652 SUBL #6,R3 ; of "all routers"
 53 06 C2 116E 2653 MOVL #TRSC_NI_ALLEND1,(R3)+ ; Phase IV "all endnodes" multicast
 83 00 BO 1178 2654 MOVL #TRSC_NI_ALLEND2,(R3)+
 51 52 53 8E C3 1178 2655 20\$: SUBL3 (SP)+,R3,R2 ; Compute size of additional params
 08 A5 55 C1 117F 2656 ADDL3 R5,DLLQI0SL_P2(R5),R1 ; Point to P2 buffer descriptor
 61 52 C0 1184 2657 ADDL R2,(R1) ; Append these params to P2 buffer
 50 01 DO 1187 2658 MOVL #1,RO ; Success

	05	118A	2659	RSB		
		118B	2660			
		118B	2661	PLI_PPUNA_TAB:	: Parameter table for PPUNA pseudo-datalink	
		118B	2662	.cnvtab pcl.i,pli,BUS	: Receive buffer size	
		118F	2663	.cnvtab pcl.i,pli,CON	: Controller (loopback) mode	
		1193	2664	.cnvtab pcl.i,pli,BNF	: Number of buffers in pool	
		00000000	1197	.LONG 0	: Terminate the table	
			119B	2666		
			119B	2667	PLI_PPUNA:	
52	ED AF	9E	119B	2668	MOVAB PLI_PPUNA TAB,R2	: (used only for internal testing)
	010E	30	119F	2669	BSBW BUILD_DEVBUF	: Point to param translation table
		53	DD	11A2	PUSHL R3	: Build standard parameter buffer
83	0458 8F	B0	11A4	2671	MOVW #NMASC_PCLI PRO,(R3)+	: Save position in P2 buffer
	83 00	DO	11A9	2672	MOVL #NMASC_LINPR POI,(R3)+	: Protocol type = POINT
83	0B18 8F	B0	11AC	2673	MOVW #NMASC_PCLI PRM,(R3)+	: Promiscuous mode = OFF
	83 01	DO	11B1	2674	MOVL #NMASC_STATE OFF,(R3)+	: Multicast address state = OFF
83	0B19 8F	B0	11B4	2675	MOVW #NMASC_PCLI MLT,(R3)+	: Padding on transmits = ON
	83 01	DO	11B9	2676	MOVL #NMASC_STATE OFF,(R3)+	: Data chaining = OFF
83	0B1A 8F	B0	11BC	2677	MOVW #NMASC_PCLI PAD,(R3)+	: (DLLTRN can't handle multiple CXBs)
	83 00	DO	11C1	2678	MOVL #NMASC_STATE ON,(R3)+	: CRC generation = ON
83	0B1B 8F	B0	11C4	2679	MOVW #NMASC_PCLI BCH,(R3)+	: Protocol access mode = limited
	83 01	DO	11C9	2680	MOVL #NMASC_STATE OFF,(R3)+	: Remote destination = (dead timer)
83	0B1C 8F	B0	11CC	2681	MOVW #NMASC_PCLI CRC,(R3)+	: 8 byte string:
	83 00	DO	11D1	2682	MOVL #NMASC_STATE ON,(R3)+	: Set the address
83	0B1E 8F	B0	11D4	2683	MOVW #NMASC_PCLI ACC,(R3)+	: Phase IV NI prefix
	83 02	DO	11D9	2684	MOVL #NMASC_ACC [IM,(R3)+	: Get value of dead timer
83	0B21 8F	B0	11DC	2685	MOVW #NMASC_PCLI DES,(R3)+	: Is area portion of address 0?
	83 08	DO	11E1	2686	MOVW #8,(R3)+	: If not, set it as is
	83 01	DO	11E4	2687	MOVW #NMASC_LINMC SET,(R3)+	: Else, insert our own area
83	000400AA 8F	DO	11E7	2688	MOVL #TRSC_NI PREFIX,(R3)+	: (leave R8 set for code below)
			11EE	2689	\$GETFLD pli l_ddf	: Set remote destination address
00	58 06	ED	11FB	2690	CMPZV #TR4SV_ADDR_AREA,-	: Protocol type parameter code
	OE	12	11FD	2691	BN EQ 5\$: Get protocol type to be used
57	00000000'EF	DO	1200	2692	MOVL NETSGL_PTR VCB,R7	: Branch if ok
	008B C7	FO	1202	2693	INSV RCBSB_HOMEAREA(R7),-	: Else, provide a default value
	OA		1209	2694	#TR4SV_ADDR_AREA,-	: Set protocol type
	58 06		120D	2695	#TR4SS_ADDR_AREA,R8	: Physical address = Phase IV address
	83 58	B0	120E	2696	MOVW R8,(R3)+	: 8 byte string:
83	0B0E 8F	B0	1210	2697	SGETFLD pli l_ept	: Set the address
			1213	2698	BLBS R0,10\$: Phase IV NI prefix
58	A002 8F	3C	1228	2700	MOVZWL #^XA002,R8	: Phase IV node number
	83 58	DO	122D	2701	MOVL R8,(R3)+	: Compute size of additional params
83	0B04 8F	B0	1230	2702	MOVW #NMASC_PCLI_PHA,(R3)+	: Point to P2 buffer descriptor
	83 08	DO	1235	2703	MOVL #8,(R3)+	: Append these params to P2 buffer
	83 01	DO	1238	2704	MOVW #NMASC_LINMC SET,(R3)+	: Success
83	000400AA 8F	DO	1238	2705	MOVL #TRSC_NI PREFIX,(R3)+	
57	00000000'EF	DO	1242	2706	MOVL NETSGE_PTR VCB,R7	
	83 0E A7	B0	1249	2708	MOVW RCBSB_ADDR(R7),(R3)+	
51	52 53 8E	C3	124D	2709	SUBL3 (SP)+,R3,R2	
	08 A5 55	C1	1251	2710	ADDL3 R5,DLLQIOSL_P2(R5),R1	
	61 52	CO	1256	2711	ADDL R2,(R1)	
	50 01	DO	1259	2712	MOVL #1,R0	
		05	125C	2713	RSB	
			125D	2714		
			125D	2715	PLI_DMC:	

NET Sym

					.IF NDF DMC_MODEM		
			125D	2716			; Disallow controller functions if
			125D	2717			; there is no modem support in DMC
			125D	2718			
		51	D4	125D	2719	CLRL	R1
	ED9E'	30	125F	2720	BSBW	NET\$GET_PLVECLPD	; Say "start with LPD index 0"
	05 50	E8	1262	2721	BLBS	R0_10\$	Find next LPD actively using this line
0000'8F	AA	1265	2722	BICW	#IOSM_SHUTDOWN,-	If LBS then found one	
65		1269	2723		DLLQIOSL_FUNC(R5)	Can't issue "SHUTDOWN" if device is	
		AA	126A	2724	10\$: BICW	#IOSM_STARTUP!-	not active
			126B	2725		I0SM_CTRL,-	Special case -- DMC does not support
65	0000'8F		126B	2726		DLLQIOSL_FUNC(R5)	these modifiers in for its "line" aspect
			126F	2727			
			126F	2728	.ENDC	; DF DMC_MODEM	
			126F	2729			
04 A5	53 55	C3	126F	2730	SUBL3	R5,R3,DLLQIOSL_P1(R5)	; Setup offset to characteristics buffer
	83 20	90	1274	2731	MOVB	#DCS_SCOM,(R3)+	Enter device class
	83 01	90	1277	2732	MOVB	#DT\$_DMC11,(R3)+	Enter device type
			127A	2733			
			127A	2734		: For now, all lines use the same buffer size.	
			127A	2735			
	FC65	30	127A	2736	BSBW	NET\$PLI_L_BUS	; Get datalink buffer size
83	51	B0	127D	2737	MOVW	R1,(R3)+	Store the block size
	63	D4	1280	2738	CLRL	(R3)	Zero the characteristics
			1282	2739	\$GETFLD	pli_v.con	Get loopback field value
05 58	E9	128F	2740		BLBC	R8_20\$	If LBC not in controller loopback
	13	11	1292	2741	SETBIT	XMSV_CHR_LOOPB,(R3)	Else set loopback bit
			1295	2742	BRB	30\$	Don't bother with HDPLX
03 58	E9	1297	2743	20\$: BLBC	\$GETFLD	pli_v.dup	Get duplex selector
		12A4	2744			R8_30\$	LBS in R0 if half-duplex
		12A7	2745		SETBIT	XMSV_CHR_HDPLX,(R3)	Put line in half-duplex
50	83	D5	12AA	2746	30\$: TSTL	(R3)+	Advance past characteristics
	01	90	12AC	2747	MOVW	#1,R0	Indicate success
		05	12AF	2748	RSB		Return status in R0

1280 2750 .SBTTL BUILD_DEVBUF - Build DLLQIO buffer
 1280 2751 :+
 1280 2752 : BUILD_DEVBUF - Build P2 buffer for SETMODE of line or circuit
 1280 2753 :
 1280 2754 : This routine is called to setup a standard P2 buffer for a line or
 1280 2755 : circuit SETMODE function. The P2 buffer contains all the datalink
 1280 2756 : parameters for the line/circuit to be initialized.
 1280 2757 :
 1280 2758 : Inputs:
 1280 2759 :
 1280 2760 : R11 = PLI CNR address
 1280 2761 : R10 = PLI CNF address
 1280 2762 : R5 = Address of DLLQIO buffer
 1280 2763 : R3 = Address of scratch buffer
 1280 2764 : R2 = Address of datalink parameter translation table (CNVTAB)
 1280 2765 :
 1280 2766 : Outputs:
 1280 2767 :
 1280 2768 : R3 = Updated pointer to end of scratch buffer
 1280 2769 : R0 = Status code
 1280 2770 :-
 1280 2771 :
 08 A5 53 D0 1280 2772 BUILD_DEVBUF:
 FC A3 08 B5 53 08 C0 1280 2773 MOVL R3,DLLQIOSL_P2(R5) ; Build device param buffer
 0070 53 55 C3 1287 2774 ADDL #8,R3 ; Setup pointer to device parameter
 56 52 D0 1288 2775 MNEGL R3,@DLLQIOSL_P2(R5) ; buffer descriptor
 12C0 2776 SUBL3 R5,R3,-4(R3) ; Allow 8 bytes for the descriptor
 12C4 2777 PUSHR #^MCR4,R5,R6> ; Prepare for size calculation
 12C7 2778 MOVL R2,R6 ; Setup offset to param buffer
 12C9 2779 TSTL (R6) ; Save regs
 12CB 2780 BEQL 40\$; Point to translation table
 3D 66 0C E0 12C9 2781 10\$: TSTL (R6) ; At end of table?
 7E 0A AB 90 12CF 2782 BEQL 40\$; If EQL then yes
 51 66 02 12D3 2783 BBS #CNVTABSV R0,(R6),30\$; Skip if should not send to driver
 7E 51 90 12D8 2784 MOVBL CNRSB_TYPE(R11),-(SP) ; Enter database i.d.
 10 EF 12DB 2785 EXTZV #CNVTABSV_FMT,- ; Get param format type
 51 66 0F 12DD 2786 MOVBL R1,-(SP) ; Append to param database i.d.
 7E 51 B0 12E0 2787 EXTZV #CNVTABSS_FMT,(R6),R1 ; Get internal param i.d. index
 59 8ED0 12E3 2788 MOVW R1,-(SP) ; Append param i.d.
 3FFF 8F 59 B1 12E6 2789 POPL R9 ; Get complete param i.d., fix stack
 1F 13 12EB 2790 CMPW R9,#CNVTABSC_INTRNL ; Datalink only parameter?
 ED10' 30 12ED 2791 BEQL 30\$; If so, just ignore it
 19 50 E9 12F0 2792 BSBW CNFSGET_FIELD ; Get the field value
 00 EF 12F3 2793 BLBC R0,30\$; If LBC then param is not set
 50 66 0C 12F5 2794 EXTZV #CNVTABSS_NMA,- ; Get the NICE parameter code
 83 50 B0 12F8 2795 MOVW R0,(R3)+ ; Enter the NICE param i.d.
 02 51 D1 12FB 2799 CMPL R1,#NFBSC_TYP_STR ; String ?
 83 05 13 12FE 2800 BEQL 20\$; If EQL yes
 83 58 D0 1300 2801 MOVL R8,(R3)+ ; Enter the parameter value
 07 11 1303 2802 BRB 30\$; Continue
 83 57 B0 1305 2803 20\$: MOVW R7,(R3)+ ; Enter the string length
 63 68 57 28 1308 2804 MOVC3 R7,(R8),(R3) ; Enter the string text, update R3
 86 D5 130C 2805 30\$: TSTL (R6)+ ; Advance to next table entry
 87 11 130E 2806 BRB 10\$; Loop

0070 8F BA 1310 2807 40\$: POPR #^M<R4,R5,R6>
08 B5 53 C0 1314 2808 ADDL R3,@DLLQIOSL_P2(R5) ; Restore regs
08 A5 55 C2 1318 2809 SUBL R5,DLLQIOSL_P2(R5) ; Complete size calculation
50 00000000'8F D0 131C 2810 MOVL #SSS_NORMAL,R0 ; Convert pointer to offset
05 1323 2811 RSB ; Setup status

```

1324 2813 .SBTTL NET$CVT_NMA_INT - Convert NMA to NFB code
1324 2814 :+
1324 2815 : NET$CVT_NMA_INT - Convert an NMA code returned by a datalink driver
1324 2816 : to a internal NFB parameter code.
1324 2817 :
1324 2818 : Inputs: R11 = CNR address
1324 2819 : R9 = NMA code
1324 2820 :
1324 2821 : Outputs: R9 = NFB code corresponding to NMA code
1324 2822 : (or original, if could not map the code)
1324 2823 :-
1324 2824 NET$CVT_NMA_INT:: : Convert NMA i.d. to internal i.d.
1324 2825 PUSRR #^M<R1,R2,R5> : Save regs
1324 2826 MOVAB CRI TRN TAB,RS : Assume CRI database
1324 2827 CMPB #NFBSC DB CRI,- : Circuit database ?
1324 2828 CNRSB_TYPE(R11)
55 0000016C'EF 26 BB 1324 2829 BEQL 10$ : If EQL then yes
04 9E 1324 2830 MOVAB PLI TRN TAB,RS : Else PLI database
OA AB 1324 2831 10$: BSBB CVT_NMA_INT : Convert the i.d.
07 13 1331 2832 POPR #^M<R1,R2,R5> : Restore regs
133C 2833 RSB
133F 2834 :
133F 2835 :
133F 2836 : Do the actual conversion of NMA to NFB parameter codes.
133F 2837 :
133F 2838 : Inputs:
133F 2839 : R9 = NMA i.d. code, with format type
133F 2840 : R5 = Conversion table address
133F 2841 :
133F 2842 : Outputs:
133F 2843 : R1 = Last table entry used (zero if end of table)
133F 2844 : R0 = Status indicator
133F 2845 :
133F 2846 : R2 is destroyed.
133F 2847 :
133F 2848 :
133F 2849 CVT_NMA_INT: : Convert NMA i.d. to internal i.d.
52 59 0C 00 EF 133F 2850 EXTZV #0,#CNVTABSS_NMA,R9,R2 : Get only NMA param i.d.
51 50 D4 1344 2851 CLRL R0 : Assume conversion error
51 85 D0 1346 2852 40$: MOVL (R5)+,R1 : Get next table entry
20 13 1349 2853 BEQL 100$ : If EQL table is exhausted, report
1348 2854 :
1348 2855 ASSUME NFBSV_INX EQ 0 : that the driver is not supported
1348 2856 ASSUME NFBSV_TYP EQ 16 :
1348 2857 ASSUME NFBSV_DB EQ 24 :
1348 2858 :
134B 2859 CMPZV #CNVTAB$V_NMA,-
52 51 0C 00 ED 134D 2860 #CNVTAB$S_NMA,R1,R2 : Is this it?
F4 12 1350 2861 BNEQ 40$ : If NEQ then keep trying
7E 51 0E , EF 1352 2862 EXTZV #CNVTAB$V_INT,-
10 , 12 1354 2863 #CNVTAB$S_INT,R1,-(SP) : Put internal code on stack longword
1E EF 1357 2864 EXTZV #CNVTAB$V_FMT,- : Get field format type
52 51 02 02 1359 2865 #CNVTAB$S_FMT,R1,R2
02 AE 52 90 135C 2866 MOVB R2,2(SP) : Insert format into TYP field
03 AE 0A AB 90 1360 2867 MOVB CNRSB_TYPE(R11),3(SP) : Insert database id into DB field
59 8ED0 1365 2868 POPL R9 : Get full field i.d., cleanup stack
50 01 00 1368 2869 MOVL #1,RO : Indicate successful conversion

```

NETCNFDLL
V04-000

F 4
- Datalink database action routines 16-SEP-1984 01:15:07 VAX/VMS Macro V04-00
NET\$CVT_NMA_INT - Convert NMA to NFB cod 5-SEP-1984 02:18:18 [NETACP.SRC]NETCNFDLL.MAR;1 Page 64 (28)
05 136B 2870 100\$: RSB

**F

136C 2872 .SBTTL TRAN_DEVNAM - Translate device name
 136C 2873 :+
 136C 2874 TRAN_DEVNAM Translate Network Management name to VMS device name
 136C 2875 :
 136C 2876 This routine translates a network management line/circuit name to a VMS
 136C 2877 device name. Network management line names have the format "dev-c-u" and
 136C 2878 circuit names have the format "dev-c-u.t" where c,u,t are ascii-decimal
 136C 2879 strings and "dev" is a network management device numeric.
 136C 2880 :
 136C 2881 INPUTS: R8 Pointer to network management name
 136C 2882 R7 Number of characters in name
 136C 2883 R3 Output buffer pointer
 136C 2884 :
 136C 2885 OUTPUTS: R8 Pointer to first unparsed character
 136C 2886 R7 Number of unparsed characters
 136C 2887 R6 Pointer to device table entry
 136C 2888 R5,R4 Garbage
 136C 2889 R3 Advanced by characters in translated name
 136C 2890 R2,R1 Garbage
 136C 2891 R0 Status
 136C 2892 :
 136C 2893 All other regs are preserved
 136C 2894 :-
 136C 2895 TRAN_DEVNAM:
 136C 2896 :
 136C 2897 Parse the device mnemonic, locate translation table entry
 136C 2898 :
 63 4B 4F 10 136C 2899 BSBB PRS_MNEMONIC ; Parse name, locate entry in table
 08 61 50 E9 136E 2900 BLBC R0,T10\$; If LBC then error
 0A A6 28 1371 2901 MOVC3 R2,(R1),(R3) ; Move the VMS device mnemonic
 33 13 1375 2902 CMPB DEVTRNSB_DEV(R6),#DEVTRNSC_DEV_X25 ; X25 circuit name?
 1379 2903 BEQL 40\$; If so, then use only device name
 137B 2904 :
 137B 2905 : dev-c-u.t
 137B 2906 : We've parsed up to here ^ Translate the controller specifier.
 137B 2907 :
 54 2E 9A 137B 2908 MOVZBL #^A'.'',R4 ; Setup field delimiter for single-unit
 137E 2909 : device (i.e., no unit field)
 03 0C A6 00 E1 137E 2910 BBC #DEVTRNSV_MULTI,- ; If BC then not multi-unit device
 54 2D 9A 1380 2911 2911 : DEVTRNSB_CHAR(R6),20\$ and there's no unit field
 7E 10 1383 2912 MOVZBL #^A'-'',R4 ; Setup field delimiter
 31 50 E9 1388 2914 BSBB PRS_DECIMAL ; Convert the controller to binary
 52 D5 138B 2915 BLBC R0,T10\$; If LBC then error
 28 13 138D 2916 TSTL R2 ; Any decimal characters parsed ?
 19 51 91 138F 2917 BEQL 100\$; If EQL no, illegal name
 23 1A 1392 2918 CMPB R1,#25 ; Within range (0=A, 25=Z)
 83 51 41 8F 81 1394 2919 BGTRU 100\$; If GTRU then out of range
 1399 2920 ADDB3 #^A'A'',R1,(R3)+ ; Store as VMS controller designator
 1399 2921 :
 1399 2922 : dev-c-u.t
 1399 2923 : We have parsed up to here ^ Parse the unit number.
 50 D4 1399 2924 CLRL R0
 00 E1 139B 2925 BBC #DEVTRNSV_MULTI,- ; Assume single-unit device
 0B 0C A6 54 2E 9A 13A0 2926 2926 : If BC then single-unit device and
 61 10 13A3 2927 MOVZBL #^A'-'',R4 ; there's no unit field
 BSBB PRS_DECIMAL ; Setup field delimiter
 ; Convert the Ascii unit to binary

50 14 50 E9 13A5 2929 BLBC R0,110\$; If LBC then illegal name
51 51 00 13AB 2930 MOVL R1,R0 ; Get the binary value
EC52. 30 13AB 2931 30\$: BSBW NEf\$BIN2ASC ; Move to @R3 as Ascii
05 05 11 13AE 2932 40\$: MOVL #SSS_NORMAL,R0 ; Indicate success
05 13B5 2933 BRB 110\$; Take common exit
50 0000'8F 3C 13B7 2935 100\$: MOVZWL #SSS_IVDEVNAM,R0 ; Error in translated name
05 13BC 2936 110\$: RSB ; Return status in R0

13BD 2938 .SBTTL PRS_MNEMONIC - Parse device mnemonic
 13BD 2939 :+
 13BD 2940 : PRS_MNEMONIC - Parse device mnemonic
 13BD 2941 :
 13BD 2942 : INPUTS: R8 Pointer to device name
 13BD 2943 : R7 Characters left in device name string
 13BD 2944 :
 13BD 2945 : OUTPUTS: R8 Advanced by characters parsed
 13BD 2946 : R7 Reduced by characters parsed
 13BD 2947 : R6 Pointer to device table entry
 13BD 2948 : R5 Size of network management device mnemonic
 13BD 2949 : R4 Pointer to network management device mnemonic
 13BD 2950 : R2 Size of VMS device mnemonic
 13BD 2951 : R1 Pointer to VMS device mnemonic
 13BD 2952 : R0 SSS_NORMAL if successful
 13BD 2953 : SSS_IVDEVNAM otherwise
 13BD 2954 :
 13BD 2955 : All other regs are unchanged
 13BD 2956 :-
 53 DD 13BD 2957 PRS_MNEMONIC:
 13BD 2958 PUSHL R3 ; Save reg
 13BF 2959 :
 13BF 2960 : Parse the device mnemonic
 13BF 2961 :
 50 0000'8F 3C 13BF 2962 MOVZWL #SSS_IVDEVNAM,R0 ; Assume error in name format
 54 58 D0 13C4 2963 MOVL R8,R4 ; Make a copy of the name pointer
 55 01 CE 13C7 2964 MNEGL #1,R5 ; Init the character count
 55 D6 13CA 2965 10\$: INCL R5 ; Update the character count
 03 57 F5 13CC 2966 SOBGTR R7,20\$; If GTR then more characters are left
 0030 31 13CF 2967 BRW 10\$; Take common exit to report the error
 2D 88 91 13D2 2968 20\$: CMPB (R8)+,#"A"-" ; Mnemonic delimiter ?
 F3 12 13D5 2969 BNEQ 10\$; If NEQ then keep trying
 13D7 2970 :
 13D7 2971 : Locate the table entry
 13D7 2972 :
 56 0000001F'EF 9E 13D7 2973 30\$: MOVAB DEVTRN_TABLE-DEVTRNSC_LENGTH,R6 ; Prepare to scan device table
 56 0D C0 13DE 2974 ADDL #DEVTRNSC_LENGTH,R6 ; Advance to next entry
 51 66 9A 13E1 2975 MOVZBL DEVTRNSB_NETMAN(R6),R1 ; Get length of network management name
 51 16 13 13E4 2976 BEQL 40\$; If EQL then at end of table
 55 51 D1 13E6 2977 CMPL R1,R5 ; Same size ?
 F3 12 13E9 2978 BNEQ 30\$; If NEQ no, advance to next entry
 64 55 29 13EB 2979 CMPC R5,(R4),- ; Is this it ?
 01 A6 13EE 2980 DEVTRNST_NETMAN(R6) :
 EC 12 13F0 2981 BNEQ 30\$; If NEQ then loop
 52 06 A6 9A 13F2 2982 MOVZBL DEVTRNSB_VMS(R6),R2 ; Setup length of VMS mnemonic
 51 07 A6 9E 13F6 2983 MOVAB DEVTRNST_VMS(R6),R1 ; Setup pointer to mnemonic
 03 11 13FA 2984 BRB 50\$; Take common exit
 51 54 7D 13FC 2985 40\$: MOVQ R4,R1 ; Make a copy of the Net Man. mnemonic
 50 00' DO 13FF 2986 50\$: MOVL S^#SSS_NORMAL,R0 ; Indicate success
 53 8ED0 1402 2987 100\$: POPL R3 ; Restore R3
 05 1405 2988 RSB ; Return status in R0

```

1406 2990 .SBTTL PRS_DECIMAL - Parse decimal number
1406 2991 :+ PRS_DECIMAL - Convert Ascii decimal number to a binary value
1406 2992 :| INPUTS: R7 Count of characters remaining in the string
1406 2993 :| R8 Address of string
1406 2994 :| R4 Field delimiter
1406 2995 :| OUTPUTS: R8 Advanced by characters parsed
1406 2996 :| R7 Reduced by characters parsed
1406 2997 :| R2 Number of numeric characters parsed
1406 2998 :| R1 Binary value
1406 2999 :| R0 SSS_NORMAL if successful
1406 3000 :| SSS_INVDEVNAM otherwise
1406 3001 :|-
1406 3002 :|-
1406 3003 :|-
1406 3004 :|-
1406 3005 PRS_DECIMAL: ; Parse/convert ascii decimal to binary
51 7C 1406 3006 CLRQ R1 ; Init binary value, character count
57 D7 1408 3007 10$: DECL R7 ; Account for next character
1E 19 140A 3008 BLSS 15$ ; If LSS then done
50 88 9A 140C 3009 MOVZBL (R8)+,R0 ; Get next character
50 54 91 140F 3010 CMPB R4,R0 ; Is it the delimiter?
50 18 13 1412 3011 BEQL 20$ ; If EQL then done
50 30 82 1414 3012 SUBB "#A'0',R0 ; Convert to binary
50 18 19 1417 3013 BLSS 30$ ; If LSS then not decimal
09 50 91 1419 3014 CMPB R0,#9 ; Decimal ?
13 1A 141C 3015 BGTRU 30$ ; If GTRU not decimal
51 52 D6 141E 3016 INCL R2 ; Bump number of digits
51 0A C4 1420 3017 MULL #10,R1 ; Shift total one digit
51 0C 1D 1423 3018 BVS 30$ ; If VS then R1 has overflowed
51 50 C0 1425 3019 ADDL R0,R1 ; Complete the sum
51 DE 11 1428 3020 BRB 10$ ; Loop
57 D4 142A 3021 15$: CLRL R7 ; Repair R7
50 00' 3C 142C 3022 20$: MOVZWL S^#SSS_NORMAL,R0 ; Indicate success
05 11 142F 3023 BRB 40$ ; Take common exit
50 0000'8F 3C 1431 3024 30$: MOVZWL #SSS_INVDEVNAM,R0 ; Indicate invalid device name
05 1436 3025 40$: RSB ; Return status in R0

```

```

1437 3027 .SBTTL DEV_CNT_QIO - Get device counters
1437 3028 :+ DEV_CNT_QIO - Get counters from device driver
1437 3029 : INPUTS: R3 Address of next byte in output buffer
1437 3030 : R2 Channel to device driver
1437 3031 : R0 $QIO function code
1437 3032 : OUTPUTS: R3 Updated to next free byte in output buffer
1437 3033 : R0 SSS_NORMAL
1437 3034 :
1437 3035 :
1437 3036 :
1437 3037 :
1437 3038 :
1437 3039 : R1-R2,R4-R5 are destroyed.

      54 53 DO 1437 3040 DEV_CNT_QIO:
05 00000000'EF 02 E1 143A 3041 MOVL R3,R4 : Save output buffer pointer
      50 C000'8F A8 143C 3042 BBC #NETSV CLRcnt,- : If BC, don't clear the counters
51 00000029'EF 7C 1442 3043 20$: BISW #IOSM CLR COUNT,R0 : Else clear the counters
      55 00000000'EF 9E 1447 3044 CLRQ QIOW @ IOSB : Init IOSB image
      65 04 A1 61 C1 144D 3045 MOVAB TMPPUF DESC,R1 : Get address of TMP_BUF descriptor
      65 53 C2 1454 3046 MOVAB TMP Q DESC,R5 : Get address of our buffer descriptor
      04 A5 53 DO 145B 3047 ADDL3 (R1),Z(R1),(R5) : Get ending buffer address
      65 53 C2 1460 3048 SUBL R3,(R5) : Setup bytes left in buffer
      04 A5 53 DO 1463 3049 MOVL R3,4(R5) : Point to it
      1467 3050 SQIOW_S FUNC = R0,-
      1467 3051 1467 3052 CHAN = R2,-
      1467 3053 1467 3054 EFN = #NETSC_EFN_WAIT,-
      1467 3055 1467 3056 IOSB = QIOW_Q_IOSB,-
      50 0000002B'EF 3C 1486 3057 MOVZWL P2 = R5 : Get number of bytes returned
      17 13 148D 3058 BEQL QIOW_Q_IOSB+2,R0 : If EQL then none
      53 50 C0 148F 3059 ADDL R0,R3 : Advance R3
      50 04 D1 1492 3059 CMPL #4,R0 : At least 4 bytes ?
      0F 14 1495 3060 BGTR 90$ : If GTR no, return all bytes
      C000 8F 64 B1 1497 3061 CMPW (R4),#NETSC_NMACNT_SLZ : Seconds since last zeroed ?
      08 12 149C 3062 BNEQ 90$ : If NEQ no, return whats left
      64 04 A4 50 C2 149E 3063 SUBL #4,R0 : Reduce by size of counter field
      50 00 28 14A1 3064 MOVC3 R0,4(R4),(R4) : Shift remainig counters, setup R3
      3C 14A6 3065 90$: MOVZWL S^#SSS_NORMAL,R0 : Indicate success
      05 14A9 3066 RSB : Done
      14AA 3067
      14AA 3068 .END

```

SSDEVTRN	= 000000EF R 02	CRI_PSI_TAB	0000010C R 02
SS\$1	= 00000001	CRI_TO_PSI	00000573 R 04
SS_NSPMSG	= 00000000	CRI_TRN_TAB	0000016C R 02
SS_TR3MSG	= 00000000	CRI_UNA	00000E5E R 04
SS_TR4MSG	= 00000000	CVT_NMA_INT	0000133F R 04
SWIDTH_B	= 00000001	CXBSC_OVERHEAD	= 0000004C
SWIDTH_L	= 00000003	DCS_SCOM	= 00000020
SWIDTH_W	= 00000002	DEAC_PLVEC	00000B06 R 04
ACPSC_STA_F	= 00000004	DEFAULT_SCAN	***** X 04
ACPSC_STA_H	= 00000005	DEV\$V_NET	= 0000000D
ACPSC_STA_I	= 00000000	DEVNAM_C_SIZ	= 00000020
ACPSC_STA_N	= 00000001	DEVTRNSB_CHAR	= 0000000C
ACPSC_STA_R	= 00000002	DEVTRNSB_DEV	= 0000000A
ACPSC_STA_S	= 00000003	DEVTRNSB_NETMAN	= 00000000
ADJSC_PTY_AREA	= 00000003	DEVTRNSB_PROT	= 00000008
ADJSC_PTY_PH4	= 00000004	DEVTRNSB_VMS	= 00000006
ADJSC_PTY_PH4N	= 00000005	DEVTRNSC_DEV_CI	= 00000004
ADJSW_BUFSIZ	= 00000006	DEVTRNSC_DEV_DMC	= 00000001
ADJSW_INT_LSN	= 00000008	DEVTRNSC_DEV_DMF	= 00000003
ADJSW_PNA	= 00000004	DEVTRNSC_DEV_DMP	= 00000005
ALLOC_PLVEC	000006FF R 04	DEVTRNSC_DEV_DLIP	= 00000006
BIT...	= 00000020	DEVTRNSC_DEV_KMS	= 00000007
BUILD_DEVBUF	00001280 R 04	DEVTRNSC_DEV_PCL	= 00000002
CCBSL_UCB	= 00000000	DEVTRNSC_DEV_PPUNA	= 0000000A
CLEAR_VOLATILE	00000360 R 04	DEVTRNSC_DEV_UNA	= 00000009
CNF\$B_FLG	= 00000008	DEVTRNSC_DEV_UNK	= 00000000
CNF\$CER_FIELD	***** X 04	DEVTRNSC_DEV_X25	= 00000008
CNF\$GET_FIELD	***** X 04	DEVTRNSC_LENGTH	= 0000000D
CNF\$KEY_SEARCH	***** X 04	DEVTRNSM_MULTI	= 00000001
CNF\$PUT_FIELD	***** X 04	DEVTRNST_NETMAN	= 00000001
CNF\$V_FLG_MRK1	= 00000004	DEVTRNST_VMS	= 00000007
CNF\$W_ID	= 00000012	DEVTRNSV_MULTI	= 00000000
CNF\$_ADVANCE	= 00000000	DEVTRN_TABLE	0000002C R 02
CNF\$_QUIT	= 00000002	DEV_CNT_QIO	00001437 R 04
CNF\$_TAKE_CURR	= 00000003	DLLQIOSC_LENGTH	= 00000018
CNF\$_TAKE_PREV	= 00000001	DLLQIOSL_FUNC	= 00000000
CNR\$B_TYPE	= 0000000A	DLLQIOSL_P1	= 00000004
CNVTABSC_INTRL	= 00003FFF	DLLQIOSL_P2	= 00000008
CNVTABSM_FMT	= C0000000	DLLQIOSL_P3	= 0000000C
CNVTABSM_INT	= 3FFF0000	DTS_DMC1T	= 00000001
CNVTABSM_NMA	= 00000FFF	DVIS_DEVCHAR	= 00000002
CNVTABSM_RO	= 00001000	DVIS_DEVNAM	= 00000020
CNVTABSS_FMT	= 00000002	EVCSC_SRC_CIR	= 00000003
CNVTABSS_INT	= 0000000E	EVCSC_SRC_LIN	= 00000001
CNVTABSS_NMA	= 0000000C	GET_PSI_CRI	00000281 R 04
CNVTABSS_RO	= 00000001	GET_PSI_PLI	000002C7 R 04
CNVTABSV_FMT	= 0000001E	I0SM_CLR_COUNT	***** X 04
CNVTABSV_INT	= 00000010	I0SM_CTRC	***** X 04
CNVTABSV_NMA	= 00000000	I0SM_RD_COUNT	***** X 04
CNVTABSV_RO	= 0000000C	I0SM_SHUTDOWN	***** X 04
CRI_CI	00000E5E R 04	I0SM_STARTUP	***** X 04
CRI_CLR_TAB	00000104 R 02	I0S_ACPCONTROL	***** X 04
CRI_DMC	00000E62 R 04	I0S_SENSEMODE	***** X 04
CRI_DMP	00000E5E R 04	I0S_SETMODE	***** X 04
CRI_FOREIGN	00000E5E R 04	I0C\$VERIFYCHAN	***** X 04
CRI_PCL	00000E5E R 04	JAM_CNF	000001E8 R 04
CRI_PSI_SIZ	= 00000020	LOG_COUNTERS	***** X 04

LPDSB_ASTCNT	= 0000001B	NETSC_MAX_OBJ	= 000000FF
LPDSB_CNT_IFL	= 0000004F	NETSC_MAX_WQE	= 00000014
LPDSB_CNT_LDN	= 0000004E	NETSC_MINBUFSIZ	= 000000C0
LPDSB_PLVEC	= 00000028	NETSC_NMACNT_SLZ	= 0000C000
LPDSB_PTH_INX	= 00000020	NETSC_TID_ACT	= 00000003
LPDSB_SUB_STA	= 00000027	NETSC_TID_RUS	= 00000001
LPDSC_CNT_SIZE	= 00000016	NETSC_TID_XRT	= 00000002
LPDSL_ABS_TIM	= 00000036	NETSC_TRCTL_CEL	= 00000002
LPDSL_CNT_APR	= 0000003A	NETSC_TRCTL_OVR	= 00000005
LPDSL_CNT_DPS	= 00000042	NETSC_UTLBUFSIZ	= 00001000
LPDSL_CNT_TPR	= 0000003E	NET\$DEALLOCATE	***** X 04
LPDSL_CNT_TPS	= 00000046	NET\$DECLARE_PSI	***** X 04
LPDSL_UCB	= 00000010	NET\$DEFAULT_CRI	0000036B RG 04
LPDSV_BC	= 0000000A	NET\$DEFAULT_PLI	00000420 RG 04
LPDSV_DLE	= 00000002	NET\$DELETE_CRI	00000A78 RG 04
LPDSV_RUN	= 00000004	NET\$DELETE_PLI	00000AC6 RG 04
LPDSV_X25	= 00000007	NET\$DLL_OPR_SET	***** X 04
LPDSW_CHAN	= 00000014	NET\$GET_PLVECLFD	***** X 04
LPDSW_CNT_ACL	= 0000004A	NET\$GET_X25_CHAN	***** X 04
LPDSW_CNT_TCL	= 0000004C	NET\$GL_CNR_NI	***** X 04
LPDSW_DRT	= 0000002C	NET\$GL_CNR_NDI	***** X 04
LPDSW_STS	= 00000022	NET\$GL_CNR_PLI	***** X 04
LPD_CNT_TAB	= 00000000 R 02	NET\$GL_FLAGS	***** X 04
MAX_C_DEVNAM	= 0000000F	NET\$GL_PTR_LNI	***** X 04
MOVE_FMT_CNT	***** X 04	NET\$GL_PTR_VCB	***** X 04
NET\$ALLOCATE	***** X 04	NET\$GL_SRCA2_ID	***** X 04
NET\$ALONPAGED	***** X 04	NET\$GL_SRCH_ID	***** X 04
NET\$APPLY_DFLT	***** X 04	NET\$GQ_SRCH2_KEY	***** X 04
NET\$BIN2ASC	***** X 04	NET\$GQ_SRCH_REL	***** X 04
NET\$CRI_L_BLO	00000B89 RG 04	NET\$GW_X25_CHAN	***** X 04
NET\$CRI_L_DRT	00000B5D RG 04	NET\$G_CRI_BDCMP	***** X 04
NET\$CRI_L_LIT	00000BAE RG 04	NET\$G_CRI_DLM	***** X 04
NET\$CRI_L_MST	00000C05 RG 04	NET\$G_CRI_DLMOUT	***** X 04
NET\$CRI_L_PNA	00000BD8 RG 04	NET\$G_CRI_NI	***** X 04
NET\$CRI_L_SUB	00000B48 RG 04	NET\$G_CRI_TRN	***** X 04
NET\$CRI_S_CHR	00000E12 RG 04	NET\$G_CRI_X25	***** X 04
NET\$CRI_S_CNT	00000D3F RG 04	NET\$G_PLI_DDCMP	***** X 04
NET\$CRI_S_COL	00000C1A RG 04	NET\$G_PLI_LAPB	***** X 04
NET\$CRI_S_DEVNAM	00000CDA RG 04	NET\$G_PLI_NI	***** X 04
NET\$CRI_S_LOO	00000C81 RG 04	NET\$INSERT_CRI	000004BC RG 04
NET\$CRI_S_PNN	00000C34 RG 04	NET\$INSERT_PLI	000005EF RG 04
NET\$CRI_S_VMSNAM	00000CC6 RG 04	NET\$JNX_CO	***** X 04
NET\$CRI_V_LCK	00000B34 RG 04	NET\$LOCATE_LPD	***** X 04
NET\$CVT_NMA_INT	00001324 RG 04	NET\$M_MAXLNKMSK	= 000003FF
NET\$C_ACT_TIMER	= 0000001E	NET\$NDI_BY_ADD	***** X 04
NET\$C_EFN_ASYNC	= 00000002	NET\$PLI_L_BUS	00000EE2 RG 04
NET\$C_EFN_WAIT	= 00000001	NET\$PLI_L_PLVEC	00000EDA RG 04
NET\$C_IPL	= 00000008	NET\$PLI_L_SUB	00000ED7 RG 04
NET\$C_MAXACCFLD	= 00000027	NET\$PLI_S_CHR	0000107F RG 04
NET\$C_MAXLINNAM	= 0000000F	NET\$PLI_S_CNT	00000FC7 RG 04
NET\$C_MAXLNK	= 000003FF	NET\$PLI_S_COL	00000F26 RG 04
NET\$C_MAXNODNAM	= 00000006	NET\$PLI_S_DEVNAM	00000F60 RG 04
NET\$C_MAXOBJNAM	= 0000000C	NET\$PLI_S_VMSNAM	00000F40 RG 04
NET\$C_MAX.Areas	= 0000003F	NET\$PLI_V_LCK	00000EB9 RG 04
NET\$C_MAX_LINES	= 00000040	NET\$PRE_QIO_CRI	00000003 RG 04
NET\$C_MAX_NCB	= 0000006E	NET\$PRE_QIO_PLI	0000000C RG 04
NET\$C_MAX_NODES	= 000003FF	NET\$REMOVE_CRI	00000B2D RG 04

00' 00' 00' 00' 00' 00' 00' 00' 00' 00' 00' 00' 00' 00' 00' 00' 00' 00'

42

NETSREMOVE_DEF
 NETSREMOVE_PLI
 NETSSCAN_CRI
 NETSSCAN_PLI
 NETSSET_CTR_TIMER
 NETSSET_QIOW
 NETSSHOW_CRI
 NETSSHOW_PLI
 NETSTABLE_DFLT
 NETSV_CLR_CNT
 NETSV_CNFLCK
 NFBSC_DATABASE
 NFBSC_FCT
 NFBSC_FLAGS
 NFBSC_OPER
 NFBSC_CRI_ACB
 NFBSC_CRI_ACI
 NFBSC_CRI_BBT
 NFBSC_CRI_CHN
 NFBSC_CRI_CNT
 NFBSC_CRI_DLM
 NFBSC_CRI_DTE
 NFBSC_CRI_DTH
 NFBSC_CRI_DYB
 NFBSC_CRI_DYI
 NFBSC_CRI_DYT
 NFBSC_CRI_IAB
 NFBSC_CRI_IAI
 NFBSC_CRI_IAT
 NFBSC_CRI_MBL
 NFBSC_CRI_MR
 NFBSC_CRI_MST
 NFBSC_CRI_MTR
 NFBSC_CRI_MWI
 NFBSC_CRI_NAM
 NFBSC_CRI_PLS
 NFBSC_CRI_POL
 NFBSC_CRI_SER
 NFBSC_CRI_STA
 NFBSC_CRI_TRI
 NFBSC_CRI_TRT
 NFBSC_CRI_TYP
 NFBSC_CRI_USE
 NFBSC_CRI_VMSNAM
 NFBSC_CTX_SIZE
 NFBSC_DB_CRI
 NFBSC_ENDOFLIST
 NFBSC_FC_DELETE
 NFBSC_FC_SET
 NFBSC_FC_SHOW
 NFBSC_FC_ZERCOU
 NFBSC_LENGTH
 NFBSC_NDI_NLI
 NFBSC_NDI_NNA
 NFBSC_OP_EQL
 NFBSC_PLI_BFN
 NFBSC_PLI_BFS

***** X 04	NFBSC_PLI_BUS	= 0501001F
00000B2D RG 04	NFBSC_PLI_CHR	= 05020043
00000000 RG 04	NFBSC_PLI_CLO	= 05000005
00000000 RG 04	NFBSC_PLI_CNT	= 05020044
***** X 04	NFBSC_PLI_CON	= 05000004
00000844 RG 04	NFBSC_PLI_DDT	= 05010018
00000118 RG 04	NFBSC_PLI_DLT	= 0501001C
0000015C RG 04	NFBSC_PLI_DUP	= 05000003
***** X 04	NFBSC_PLI_EPT	= 05010026
= 00000002	NFBSC_PLI_HTI	= 05010016
= 00000008	NFBSC_PLI_HWA	= 05020046
= 00000002	NFBSC_PLI_MBL	= 05010017
= 00000000	NFBSC_PLI_MCD	= 05020045
= 00000001	NFBSC_PLI_MOD	= 05010022
= 00000003	NFBSC_PLI_MRT	= 05010018
= 04010029	NFBSC_PLI_MWI	= 05010019
= 0401002A	NFBSC_PLI_NAM	= 05020041
= 04010025	NFBSC_PLI_PLVEC	= 05010020
= 04010021	NFBSC_PLI_PRO	= 05010014
= 04020044	NFBSC_PLI_RTT	= 05010021
= 04000005	NFBSC_PLI_SLT	= 0501001A
= 04020049	NFBSC_PLI_SRT	= 0501001D
= 04010031	NFBSC_PLI_STA	= 05010011
= 0401002E	NFBSC_PLI_SUB	= 05010012
= 0401002F	NFBSC_TYP_STR	= 00000002
= 04010030	NFBSL_FLDID	= 00000010
= 0401002B	NFBSL_SRCH_KEY	= 00000004
= 0401002C	NFBSM_INX	= 0000FFFF
= 0401002D	NFBSM_NOCTX	= 00000004
= 04010022	NFBSM_TYP	= 00030000
= 04010027	NFBSS_TYP	= 00000002
= 04010032	NFBSV_DB	= 00000018
= 04010028	NFBSV_INX	= 00000000
= 04010023	NFBSV_TYP	= 00000010
= 04020041	NFB_SIZE	= 00000088
= 0401001E	NMASC_ACC_EXC	= 00000003
= 0401001D	NMASC_ACC_LIM	= 00000002
= 04000002	NMASC_CIRTY_X25	= 00000003
= 04010013	NMASC_CIRUS_INC	= 00000001
= 04010024	NMASC_CIRUS_OUT	= 00000002
= 04010026	NMASC_CIRUS_PER	= 00000000
= 04010020	NMASC_CTCIR_ACL	= 00000322
= 0401001F	NMASC_CTCIR_APP	= 00000320
= 04020042	NMASC_CTCIR_DPS	= 00000321
= 00000040	NMASC_CTCIR_IFL	= 00000335
= 00000004	NMASC_CTCIR_LDN	= 00000334
= 00000000	NMASC_CTCIR_TCL	= 0000032C
= 00000021	NMASC_CTCIR_TPR	= 0000032A
= 00000023	NMASC_CTCIR_TPS	= 0000032B
= 00000022	NMASC_LINMC_SET	= 00000001
= 00000025	NMASC_LINPR	= FFFFFFFF
= 00000010	NMASC_LINPR_CON	= 00000001
= 0202004C	NMASC_LINPR_DMC	= 00000004
= 02020043	NMASC_LINPR_LAPB	= 00000005
= 00000000	NMASC_LINPR_MAS	= 00000001
= 0501001E	NMASC_LINPR_NI	= 00000006
= 05010027	NMASC_LINPR_POI	= 00000000

NMASC_LINPR TRI	= 00000002	NSPSC_HSZ_ACK	= 00000007
NMASC_PCCI_ACB	= 000047E	NSPSC_HSZ_CA	= 00000003
NMASC_PCCI_ACI	= 000047F	NSPSC_HSZ_CC	= 00000064
NMASC_PCCI_BBT	= 0000475	NSPSC_HSZ_CD	= 000000F0
NMASC_PCCI_DTH	= 0000486	NSPSC_HSZ_CI	= 000000F0
NMASC_PCCI_DYB	= 0000483	NSPSC_HSZ_DATA	= 00000009
NMASC_PCCI_DYI	= 0000484	NSPSC_HSZ_DC	= 00000016
NMASC_PCCI_DYT	= 0000485	NSPSC_HSZ_DI	= 00000016
NMASC_PCCI_IAB	= 0000480	NSPSC_HSZ_INT	= 00000009
NMASC_PCCI_IAI	= 0000481	NSPSC_HSZ_LS	= 00000009
NMASC_PCCI_IAT	= 0000482	NSPSC_INF_V31	= 00000001
NMASC_PCCI_MRB	= 0000479	NSPSC_INF_V32	= 00000000
NMASC_PCCI_MST	= 0000AFA	NSPSC_INF_V33	= 00000002
NMASC_PCCI_MTR	= 000047A	NSPSC_MAXADR	= 00000009
NMASC_PCCI_PLS	= 00003F3	NSPSC_MSG_CA	= 00000024
NMASC_PCCI_POL	= 00003F2	NSPSC_MSG_CC	= 00000028
NMASC_PCCI_TRI	= 0000474	NSPSC_MSG_CI	= 00000018
NMASC_PCCI_TRT	= 0000476	NSPSC_MSG_DATA	= 00000000
NMASC_PCCI_TYP	= 0000458	NSPSC_MSG_DC	= 00000048
NMASC_PCLI_ACC	= 0000B1E	NSPSC_MSG_DI	= 00000038
NMASC_PCLI_BFN	= 0000451	NSPSC_MSG_DTACK	= 00000004
NMASC_PCLI_BUS	= 0000AF1	NSPSC_MSG_INT	= 00000030
NMASC_PCLI_CLO	= 0000459	NSPSC_MSG_LIACK	= 00000014
NMASC_PCLI_CON	= 0000456	NSPSC_MSG_LS	= 000C0010
NMASC_PCLI_CRC	= 0000B1C	NSPSC_SRV_MFC	= 00000002
NMASC_PCLI_DCH	= 000081B	NSPSC_SRV_NFC	= 00000000
NMASC_PCLI_DDT	= 000047F	NSPSC_SRV_REQ	= 00000001
NMASC_PCLI_DES	= 00000B21	NSPSC_SRV_SFC	= 00000001
NMASC_PCLI_DLT	= 00000480	NSPSM_ACK_NAK	= 00001000
NMASC_PCLI_DUP	= 00000457	NSPSM_ACK_NUM	= 0000FFF
NMASC_PCLI_HWA	= 00000488	NSPSM_ACK_VALID	= 00008000
NMASC_PCLI_MCA	= 00000B0F	NSPSM_DATA_BOM	= 00000020
NMASC_PCLI_MLT	= 00000B19	NSPSM_DATA_EOM	= 00000040
NMASC_PCLI_PAD	= 00000B1A	NSPSM_DATA_OVFW	= 00000080
NMASC_PCLI_PHA	= 00000B04	NSPSM_FLW_CHAN	= 0000000C
NMASC_PCLI_PRM	= 00000B18	NSPSM_FLW_DRV	= 000000F0
NMASC_PCLI_PRO	= 00000458	NSPSM_FLW_INT	= 00000020
NMASC_PCLI_PTY	= 00000B0E	NSPSM_FLW_INUSE	= 00000010
NMASC_PCLI_RTT	= 00000461	NSPSM_FLW_LISUB	= 00000004
NMASC_PCLI_SLT	= 0000047E	NSPSM_FLW_MODE	= 00000003
NMASC_PCLI_SRT	= 00000481	NSPSM_FLW_SP1	= 00000008
NMASC_STATE_OFF	= 00000001	NSPSM_FLW_SP2	= 00000040
NMASC_STATE_ON	= 00000000	NSPSM_FLW_SP3	= 00000080
NMASC_STATE_SER	= 00000002	NSPSM_FLW_XOFF	= 00000001
NSPSSS_QUAL_ACK	= 00000000	NSPSM_FLW_XON	= 00000002
NSPSSS_QUAL_ALTFW	= 00000000	NSPSM_INF_VER	= 00000003
NSPSSS_QUAL_DATA	= 00000000	NSPSM_MSG_INT	= 00000020
NSPSSS_QUAL_FLW	= 00000000	NSPSM_MSG_LI	= 00000010
NSPSSS_QUAL_INF	= 00000000	NSPSM_SRV_01	= 00000003
NSPSSS_QUAL_MSG	= 00000000	NSPSM_SRV_EXT	= 00000080
NSPSSS_QUAL_SRV	= 00000000	NSPSM_SRV_FLW	= 0000000C
NSPSC_EXT_LRK	= 0000001E	NSPSM_SRV_REQ	= 000000F3
NSPSC_FLW_DATA	= 00000000	NSPSM_SRV_SP1	= 00000070
NSPSC_FLW_INT	= 00000001	NSPSR_QUA[= 00000000
NSPSC_FLW_NOP	= 00000000	NSPSS_ACK_NUM	= 0000000C
NSPSC_FLW_XOFF	= 00000001	NSPSS_ACK_SP2	= 00000002
NSPSC_FLW_XON	= 00000002	NSPSS_DATA_SP	= 00000005

NSPSS_FLW_CHAN	= 00000002	PLI_PPUNA_TAB	= 00001188 R 04
NSPSS_FLW_DRV	= 00000004	PLI_PSI_SIZ	= 00000038
NSPSS_FLW_MODE	= 00000002	PLI_PSI_TAB	= 0000134 R 02
NSPSS_INF_VER	= 00000002	PLI_Q_DEVNAM	= 00000001 R 03
NSPSS_MSG_SP1	= 00000004	PLI_TO_PSI	= 000008F1 R 04
NSPSS_NSPMSG	= 00000005	PLI_TRNS_TAB	= 00001B8 R 02
NSPSS_QUAL	= 00000005	PLI_UNA	= 000010E3 R 04
NSPSS_QUAL_ACK	= 00000002	PLI_V_NEW	= 00000004
NSPSS_QUAL_ALTFWL	= 00000001	PLVECSAB_DEV	***** X 04
NSPSS_QUAL_DATA	= 00000001	PLVECSAB_REF_C	***** X 04
NSPSS_QUAL_FLW	= 00000001	PLVECSAB_STATE	***** X 04
NSPSS_QUAL_INF	= 00000001	PLVECSAL_ABS_TIM	***** X 04
NSPSS_QUAL_MSG	= 00000005	PLVECSAL_UCB	***** X 04
NSPSS_QUAL_SRV	= 00000001	PLVECSAW_CHAN	***** X 04
NSPSS_SRV_01	= 00000002	PLVECSGB_MAX	***** X 04
NSPSS_SRV_FLW	= 00000002	PREQIO_PRI_CRI	00000013 R 04
NSPSS_SRV_SP1	= 00000003	PRS_DECIMAL	00001406 R 04
NSPSV_ACK_NAK	= 0000000C	PRS_MNEMONIC	000013BD R 04
NSPSV_ACK_NUM	= 00000000	PSI_PLI_CLR_TAB	0000012C R 02
NSPSV_ACK_SP2	= 0000000D	QIOW_Q_IOSB	00000029 R 03
NSPSV_ACK_VALID	= 0000000F	QIOW_W_RETLEN	00000031 R 03
NSPSV_DATA_BOM	= 00000005	RCBSBETY	= 0000008A
NSPSV_DATA_EOM	= 00000006	RCBSB_HOMEAREA	= 0000008B
NSPSV_DATA_OVFW	= 00000007	RCBSL_PTR_ADJ	= 0000002C
NSPSV_DATA_SP	= 00000000	RCBSW_ADDR	= 0000000E
NSPSV_FLW_CHAN	= 00000002	RCBSW_TOTBUFSIZ	= 0000007E
NSPSV_FLW_DRV	= 00000004	REBUILD_NAME	0000007B R 04
NSPSV_FLW_INT	= 00000005	SEND_TO_PSI	0000093B R 04
NSPSV_FLW_INUSE	= 00000004	SHO_PLI_CRI	0000019E R 04
NSPSV_FLW_LISUB	= 00000002	SIZ...	= 00000002
NSPSV_FLW_MODE	= 00000000	SRCH_BUF	00000009 R 03
NSPSV_FLW_SP1	= 00000003	SS\$_BADPARAM	***** X 04
NSPSV_FLW_SP2	= 00000006	SS\$_INSFARG	***** X 04
NSPSV_FLW_SP3	= 00000007	SS\$_INSFMEM	***** X 04
NSPSV_FLW_XOFF	= 00000000	SS\$_IVDEVNAM	***** X 04
NSPSV_FLW_XON	= 00000001	SS\$_NORMAL	***** X 04
NSPSV_INF_VER	= 00000000	SS\$_NOSUCHDEV	***** X 04
NSPSV_MSG_INT	= 00000005	SS\$_RESULTOVF	***** X 04
NSPSV_MSG_LI	= 00000004	SS\$_WRITLCK	***** X 04
NSPSV_MSG_SP1	= 00000000	STORE_PSI_PARAMS	000002F4 R 04
NSPSV_SRV_01	= 00000000	SUPPRESS_AREA	***** X 04
NSPSV_SRV_EXT	= 00000007	SYSS\$ASSIGN	***** GX 04
NSPSV_SRV_FLW	= 00000002	SYSS\$DASSGN	***** GX 04
NSPSV_SRV_SP1	= 00000004	SYSS\$GETDVI	***** GX 04
NSPSW_DSTLNK	= 00000001	SYSS\$QIOW	***** GX 04
NSPSW_SRCLNK	= 00000003	TAKE_2_IOSB	00000270 R 04
P2BUF_SIZE	= 00000066	TAKE_R7_IOSB	00000273 R 04
P4BUF_SIZE	= 00000200	TMPBUF_DESC	***** X 04
PLI_BSTATE	000000000 R 03	TMPQ_DESC	00000033 R 03
PLI_CI	000010DF R 04	TRSC_MAXHDR	= 0000001C
PLI_CLR_TAB	000000FC R 02	TRSC_NI_ALLEND1	= 040000AB
PLI_CNT_TAB	00000028 R 02	TRSC_NI_ALLEND2	= 00000000
PLI_DMC	0000125D R 04	TRSC_NI_ALLROUT1	= 030000AB
PLI_DMP	000010DF R 04	TRSC_NI_ALLROUT2	= 00000000
PLI_FOREIGN	000010DF R 04	TRSC_NI_PREFIX	= 000400AA
PLI_PCL	000010DF R 04	TRSC_NI_PROT	= 00000360
PLI_PPUNA	00001198 R 04	TRSC_PRTECL	= 0000001F

TR\$C_PRI_RTHRU	= 0000001F	TR4\$R_QUAL	= 00000000
TR3\$\$S_QUAL_MSG	= 00000000	TR4\$\$S_ADDR_AREA	= 00000006
TR3\$\$S_QUAL_RTFLG	= 00000000	TR4\$\$S_ADDR_DEST	= 0000000A
TR3\$C_RSZ_DATA	= 00000006	TR4\$\$S_QUAL	= 00000002
TR3\$C_MSG_DATA	= 00000002	TR4\$\$S_QUAL_ADDR	= 00000002
TR3\$C_MSG_HELLO	= 00000005	TR4\$\$S_QUAL_RTFLG	= 00000001
TR3\$C_MSG_INIT	= 00000001	TR4\$\$S_QUAL_SCLASS	= 00000001
TR3\$C_MSG_NOP2	= 00000008	TR4\$\$S_RTFLG_01	= 00000002
TR3\$C_MSG_ROUT	= 00000007	TR4\$\$S_RTFLG_VER	= 00000002
TR3\$C_MSG_STR2	= 00000058	TR4\$\$S_SCLASS_57	= 00000003
TR3\$C_MSG_VERF	= 00000003	TR4\$\$S_TR4MSG	= 00000002
TR3\$M_MSG_CTL	= 00000001	TR4\$V_ADDR_AREA	= 0000000A
TR3\$M_MSG_RTH	= 00000002	TR4\$V_ADDR_DEST	= 00000000
TR3\$M_RTFLG_PH2	= 00000040	TR4\$V_RTFLG_01	= 00000000
TR3\$M_RTFLG_RQR	= 00000008	TR4\$V_RTFLG_INI	= 00000005
TR3\$M_RTFLG_RTS	= 00000010	TR4\$V_RTFLG_LNG	= 00000002
TR3\$R_QUAL	= 00000000	TR4\$V_RTFLG_RQR	= 00000003
TR3\$S_QUAL	= 00000001	TR4\$V_RTFLG_RTS	= 00000004
TR3\$\$S_QUAL_MSG	= 00000001	TR4\$V_RTFLG_VER	= 00000006
TR3\$\$S_QUAL_RTFLG	= 00000001	TR4\$V_SCLASS_1	= 00000001
TR3\$\$S_RTFLG_012	= 00000003	TR4\$V_SCLASS_57	= 00000005
TR3\$\$S_TR3MSG	= 00000001	TR4\$V_SCLASS_BC	= 00000004
TR3\$V_MSG_CTL	= 00000000	TR4\$V_SCLASS_LS	= 00000002
TR3\$V_MSG_RTH	= 00000001	TR4\$V_SCLASS_METR	= 00000000
TR3\$V_RTFLG_012	= 00000000	TR4\$V_SCLASS_SUBA	= 00000003
TR3\$V_RTFLG_5	= 00000005	TRAN_DEVNAM	0000136C R 04
TR3\$V_RTFLG_7	= 00000007	UCBSB_DEVCLASS	= 00000040
TR3\$V_RTFLG_PH2	= 00000006	UCBSB_DEVTYPE	= 00000041
TR3\$V_RTFLG_RQR	= 00000003	UCBSL_DEVDEPEND	= 00000044
TR3\$V_RTFLG_RTS	= 00000004	UCBSW_DEVBUFSIZ	= 00000042
TR4\$\$S_QUAL_ADDR	= 00000000	X25_CRT_TAB	00000024 R 02
TR4\$\$S_QUAL_RTFLG	= 00000000	XMSV_CHR_HDPLX	= 00000002
TR4\$\$S_QUAL_SCLASS	= 00000000	XMSV_CHR_LOOPB	= 00000001
TR4\$C_BCE_MID1	= 040000AB	XMSV_CHR_MOP	= 00000000
TR4\$C_BCE_MID2	= 00000000	XMSV_STS_ACTIVE	= 0000000B
TR4\$C_BCR_MID1	= 030000AB	_SS	= 000000EF
TR4\$C_BCR_MID2	= 00000000		
TR4\$C_BCT3MULT	= 00000008		
TR4\$C_END_NODE	= 00000003		
TR4\$C_HIORD	= 000400AA		
TR4\$C_HSZ_DATA	= 00000015		
TR4\$C_MSG_BCEHEL	= 0000000D		
TR4\$C_MSG_BCRHEL	= 00000008		
TR4\$C_MSG_LDATA	= 00000006		
TR4\$C_MSG_RDATA	= 00000002		
TR4\$C_PRO_TYPE	= 00000360		
TR4\$C_RTR_LVL1	= 00000002		
TR4\$C_RTR_LVL2	= 00000001		
TR4\$C_T3MULT	= 00000002		
TR4\$C_VER_HIB	= 00000000		
TR4\$C_VER_LOWW	= 00000002		
TR4\$M_ADDR_AREA	= 0000FC00		
TR4\$M_ADDR_DEST	= 000003FF		
TR4\$M_RTFLG_INI	= 00000020		
TR4\$M_RTFLG_LNG	= 00000004		
TR4\$M_RTFLG_RQR	= 00000008		
TR4\$M_RTFLG_RTS	= 00000010		

```
+-----+
! Psect synopsis !
+-----+
```

PSECT name	Allocation	PSECT No.	Attributes
ABS .	00000000 (0.)	00 (0.)	NOPIC USR CON ABS LCL NOSHP NOEXE NORD NOWRT NOVEC BYTE
\$ABSS	00000000 (0.)	01 (1.)	NOPIC USR CON ABS LCL NOSHR EXE RD WRT NOVEC BYTE
NET_PURE	000001EC (492.)	02 (2.)	NOPIC USR CON REL LCL NOSHR NOEXE RD NOWRT NOVEC LONG
NET_IMPURE	0000003B (59.)	03 (3.)	NOPIC USR CON REL LCL NOSHR NOEXE RD WRT NOVEC BYTE
NET_CODE	000014AA (5290.)	04 (4.)	NOPIC USR CON REL LCL NOSHR EXE RD NOWRT NOVEC BYTE

```
+-----+
! Performance indicators !
+-----+
```

Phase	Page faults	CPU Time	Elapsed Time
Initialization	29	00:00:00.09	00:00:00.86
Command processing	136	00:00:00.98	00:00:03.49
Pass 1	1392	00:00:40.45	00:01:21.84
Symbol table sort	15	00:00:05.13	00:00:07.36
Pass 2	1392	00:00:10.20	00:00:24.47
Symbol table output	59	00:00:00.52	00:00:00.68
Psect synopsis output	2	00:00:00.05	00:00:00.16
Cross-reference output	0	00:00:00.00	00:00:00.00
Assembler run totals	3030	00:00:57.42	00:01:58.87

The working set limit was 1500 pages.

224419 bytes (439 pages) of virtual memory were used to buffer the intermediate code.

There were 190 pages of symbol table space allocated to hold 3313 non-local and 227 local symbols.

3068 source lines were read in Pass 1, producing 44 object records in Pass 2.

69 pages of virtual memory were used to define 57 macros.

```
+-----+
! Macro library statistics !
+-----+
```

Macro library name	Macros defined
-\$255\$DUA28:[SHRLIB]NMALIBR.Y.MLB;1	1
-\$255\$DUA28:[SHRLIB]EVCDEF.MLB;1	1
-\$255\$DUA28:[NETACP.OBJ]NETDRV.MLB;1	1
-\$255\$DUA28:[NETACP.OBJ]NET.MLB;1	18
-\$255\$DUA28:[SYS.OBJ]LIB.MLB;1	3
-\$255\$DUA28:[SYSLIB]STARLET.MLB;2	18
TOTALS (all libraries)	42

3516 GETS were required to define 42 macros.

There were no errors, warnings or information messages.

MACRO/LIS=LISS:NETCNFDLL/OBJ=OBJS:NETCNFDLL MSRC\$:NETCNFDLL/UPDATE=(ENHS:NETCNFDLL)+EXECMLS/LIB+LIBS:NET/LIB+LIBS:NETDRV/LIB+SHRLIBS

0274 AH-BT13A-SE
VAX/VMS V4.0

DIGITAL EQUIPMENT CORPORATION
CONFIDENTIAL AND PROPRIETARY

NETCNF
LIS

NETCNFACT
LIS

NETCNFDLL
LIS

0275 AH-BT13A-SE
VAX/VMS V4.0

DIGITAL EQUIPMENT CORPORATION
CONFIDENTIAL AND PROPRIETARY

