



```

IIIIII  NN    NN  IIIIII  AAAAAA  DDDDDDDD  PPPPPPPP  UU    UU  VV    VV  11
IIIIII  NN    NN  IIIIII  AAAAAA  DDDDDDDD  PPPPPPPP  UU    UU  VV    VV  11
  II    NN    NN  II      AA    AA  DD    DD  PP    PP  UU    UU  VV    VV  1111
  II    NN    NN  II      AA    AA  DD    DD  PP    PP  UU    UU  VV    VV  1111
  II    NNNN   NN  II      AA    AA  DD    DD  PP    PP  UU    UU  VV    VV  11
  II    NNNN   NN  II      AA    AA  DD    DD  PP    PP  UU    UU  VV    VV  11
  II    NN  NN  NN  II      AA    AA  DD    DD  PPPPPPPP  UU    UU  VV    VV  11
  II    NN  NN  NN  II      AA    AA  DD    DD  PPPPPPPP  UU    UU  VV    VV  11
  II    NN    NN  NN  II      AAAAAAAAAA  DD    DD  PP    PP  UU    UU  VV    VV  11
  II    NN    NN  NN  II      AAAAAAAAAA  DD    DD  PP    PP  UU    UU  VV    VV  11
  II    NN    NN  NN  II      AA    AA  DD    DD  PP    PP  UU    UU  VV    VV  11
  II    NN    NN  NN  II      AA    AA  DD    DD  PP    PP  UU    UU  VV    VV  11
  II    NN    NN  NN  II      AA    AA  DD    DD  PP    PP  UU    UU  VV    VV  11
  II    NN    NN  NN  II      AA    AA  DD    DD  PP    PP  UU    UU  VV    VV  11
  II    NN    NN  NN  IIIIII  DDDDDDDD  PP    PP  UU    UU  VV    VV  111111
IIIIII  NN    NN  IIIIII  AA    AA  DDDDDDDD  PP    PP  UUUUUUUUU  VV    VV  111111
IIIIII  NN    NN  IIIIII  AA    AA  DDDDDDDD  PP    PP  UUUUUUUUU  VV    VV  111111

```

```

LL      IIIIII  SSSSSSS
LL      IIIIII  SSSSSSS
LL      II      SS
LL      II      SS
LL      II      SS
LL      II      SS
LL      II      SSSSSS
LL      II      SSSSSS
LL      II      SS
LL      II      SS
LL      II      SS
LL      II      SS
LLLLLLLLLLLL IIIIII  SSSSSSS
LLLLLLLLLLLL IIIIII  SSSSSSS

```

INIADPIV1  
Table of contents

(3)	254	Macros to describe nexus configurations
(4)	379	Adapter-specific data structures
(5)	523	CPU-specific data structures
(6)	723	Message strings
(7)	734	INISIO MAP, Initialize and map nexuses
(8)	899	INITADP 780, 750, 730, and UV1
(9)	916	CONFIG_IOSPACE
(10)	1066	CREATE_ARRAYS
(11)	1109	MAP_PAGES
(13)	1269	INISUBSPACE
(14)	1339	INISUBADP - BUILD ADP AND INITIALIZE UBA
(14)	1815	INISMBADP - BUILD ADP AND INITIALIZE MBA
(14)	1816	INISDPADP - BUILD ADP AND INITIALIZE DR32
(14)	1817	INISCIADP - BUILD ADP AND INITIALIZE CI
(14)	1997	INISKDZ11
(14)	2031	INISCONSOLE, init data structures for console
(15)	2141	EXESINI_TIMWAIT - COMPUTE CORRECT TIMEWAIT LOOP VALUES
(16)	2299	EXESINIT_TODR - SET SYSTEM TIME TO CORRECT VALUE AT STARTUP

```
0000 1      .NLIST  CND
0000 5
0000 9
0000 13
0000 17
0000 19      .TITLE  INIADPUV1 - ADAPTER INITIALIZATION FOR MICRO-VAX I
0000 21
0000 25
0000 26      .IDENT  'V04-002'
0000 27
0000 28 :*****
0000 29 :*
0000 30 :*  COPYRIGHT (c) 1978, 1980, 1982, 1984 BY
0000 31 :*  DIGITAL EQUIPMENT CORPORATION, MAYNARD, MASSACHUSETTS.
0000 32 :*  ALL RIGHTS RESERVED.
0000 33 :*
0000 34 :*  THIS SOFTWARE IS FURNISHED UNDER A LICENSE AND MAY BE USED AND COPIED
0000 35 :*  ONLY IN ACCORDANCE WITH THE TERMS OF SUCH LICENSE AND WITH THE
0000 36 :*  INCLUSION OF THE ABOVE COPYRIGHT NOTICE. THIS SOFTWARE OR ANY OTHER
0000 37 :*  COPIES THEREOF MAY NOT BE PROVIDED OR OTHERWISE MADE AVAILABLE TO ANY
0000 38 :*  OTHER PERSON. NO TITLE TO AND OWNERSHIP OF THE SOFTWARE IS HEREBY
0000 39 :*  TRANSFERRED.
0000 40 :*
0000 41 :*  THE INFORMATION IN THIS SOFTWARE IS SUBJECT TO CHANGE WITHOUT NOTICE
0000 42 :*  AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT
0000 43 :*  CORPORATION.
0000 44 :*
0000 45 :*  DIGITAL ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS
0000 46 :*  SOFTWARE ON EQUIPMENT WHICH IS NOT SUPPLIED BY DIGITAL.
0000 47 :*
0000 48 :*
0000 49 :*****
0000 50
0000 51 : Facility: System bootstrapping and initialization
0000 52
0000 53 : Abstract: This module contains initialization routines that are loaded
0000 54 :           during system initialization (rather than linked into the system).
0000 55
0000 56 : Environment: Mode = KERNEL, Executing on INTERRUPT stack, IPL=31
0000 57
0000 58 : Author:   Trudy C. Matthews           Creation date: 22-Jan-1981
0000 59
0000 60 : Modification history:
0000 61
0000 62 :           V04-002 TCM0013           Trudy C. Matthews           10-Sep-1984
0000 63 :           Add $BQODEF missing from TCM0012.
0000 64
0000 65 :           V04-001 TCM0012           Trudy C. Matthews           07-Sep-1984
0000 66 :           For venus processor: turn on cache before calibrating
0000 67 :           TIMEDWAIT cells (routine EX$INI_TIMWAIT). Store the TIMEDWAIT
0000 68 :           values calculated after cache is enabled in the boot driver's
0000 69 :           TIMEDWAIT cells. This is because the boot driver initially
0000 70 :           has to run with cache off, but after booting will run with
0000 71 :           cache on.
0000 72
0000 73 :           V03-024 TCM0011           Trudy C. Matthews           31-Jul-1984
0000 74 :           Change venus's CRD interrupt vector back to ^X54 in the SCB.
```

```

0000 75 : and its SBIA Fail vector to ^X64.
0000 76 :
0000 77 : V03-023 WMC0001 Wayne Cardoza 30-Jul-1984
0000 78 : Add H memory to 780 list.
0000 79 :
0000 80 : V03-022 TCM0010 Trudy C. Matthews 25-Jul-1984
0000 81 : Fix a bug in INISUBSPACE for the 11/790 that caused second
0000 82 : and subsequent unibus adapter spaces to be mapped incorrectly.
0000 83 : Fix bugs in INISSCB for the 11/790. Fix conditional
0000 84 : assembly flags in INISCONSOLE for the 11/790.
0000 85 :
0000 86 : V03-021 KDM0100 Kathleen D. Morse 01-May-1984
0000 87 : Correct address of memory CSRs to be past the 8 missing
0000 88 : Qbus adapter pages that do not exist.
0000 89 :
0000 90 : V03-020 KDM0099 Kathleen D. Morse 27-Apr-1984
0000 91 : On a MicroVAX I, if the sysgen parameter TIMEDWAIT is set
0000 92 : to request no time-prompting, then use the last recorded
0000 93 : system time instead. This is found in EXESGQ_TODCBASE
0000 94 : which can be updated with a SET TIME command.
0000 95 :
0000 96 : V03-019 RLRSCORPIO Robert L. Rappaport 16-Mar-1984
0000 97 : Begin additions (to INISIOMAP) for Scorpio support.
0000 98 : Also move ADAPDESC to SYSMAR.MAR, changing it to remove
0000 99 : the ADAP_GENERAL array.
0000 100 :
0000 101 : V03-018 RLRINIADP Robert Rappaport 28-Feb-1984
0000 102 : Add refinements to previous update that introduces
0000 103 : longword array CONFREG. Mainly add logic to allow for
0000 104 : independently assembled invocations of ADAPDESC macro
0000 105 : to be linked into this code. This provides possible
0000 106 : support of BI as a public bus, with user defined nodes.
0000 107 :
0000 108 : V03-017 KPL0100 Peter Lieberwirth 30-Jan-1984
0000 109 : Implement first step towards a longword-array CONFREG to
0000 110 : replace current byte array CONFREG. INIADP will construct
0000 111 : two confregs, CONFREG and CONFREGL. CONFREGL will be
0000 112 : a longword array. The high byte will be a VMS-bus
0000 113 : designation, and the low word will contain the 16-bit
0000 114 : device type. The BI introduces 16 bit device types.
0000 115 :
0000 116 : When all references to CONFREG have been modified to touch
0000 117 : CONFREGL, INIADP will be modified again to stop creating
0000 118 : the byte array.
0000 119 :
0000 120 : While here, map 9 pages of CI register space, up from 8.
0000 121 :
0000 122 : V03-016 KPL0001 Peter Lieberwirth 17-Jan-1984
0000 123 : Fix bug in V03-015 that caused a failure to boot on 750s.
0000 124 : Specifically, add NDT$_MEM1664NI to ADAPDESC macro.
0000 125 :
0000 126 : V03-015 TCM0009 Trudy C. Matthews 12-Dec-1983
0000 127 : Add support for booting from VENUS console device to
0000 128 : INISCONSOLE. When mapping I/O space on VENUS, use the
0000 129 : PAMM to determine if any adaptors are present on the
0000 130 : ABUS.
0000 131 :

```

0000	132	:	V03-014	KDM0081	Kathleen D. Morse	13-Sep-1983
0000	133	:			Create version for Micro-VAX I.	
0000	134	:				
0000	135	:	V03-013	DWT0126	David W. Thiel	30-Aug-1983
0000	136	:			Modify EXESINIT_TODR to set internal time without	
0000	137	:			modifying the contents of the system disk.	
0000	138	:				
0000	139	:	V03-012	KDM0062	Kathleen D. Morse	18-Jul-1983
0000	140	:			Add loadable, cpu-dependent routine for initializing	
0000	141	:			the time-wait loop data cells, EXESINI_TIMWAIT.	
0000	142	:				
0000	143	:	V03-011	KDM0057	Kathleen D. Morse	15-Jul-1983
0000	144	:			Added loadable, cpu-dependent routine for initializing	
0000	145	:			the system time, EXESINIT_TODR.	
0000	146	:				
0000	147	:	V03-010	KTA3071	Kerbey T. Altmann	12-Jul-1983
0000	148	:			Include CPU-specific console init code.	
0000	149	:				
0000	150	:	V03-009	TCM0008	Trudy C. Matthews	10-Jan-1983
0000	151	:			Change PSECT of 11/790 data that must stick around after	
0000	152	:			INIADP is deleted. Build arrays ABUS VA, ABUS_TYPE, and	
0000	153	:			ABUS_INDEX that describe the 11/790 ABUS configuration.	
0000	154	:				
0000	155	:	V03-008	MSH0002	Maryann Hinden	08-Dec-1982
0000	156	:			Add powerfail support for DW750.	
0000	157	:				
0000	158	:	V03-007	ROW0142	Ralph O. Weber	24-NOV-1982
0000	159	:			Change UBA interrupt services routines prototype so that	
0000	160	:			UBAERRADR is correctly computed as an offset from UBAINTRASE.	
0000	161	:				
0000	162	:	V03-006	TCM0007	Trudy C. Matthews	10-Nov-1982
0000	163	:			Add 11/790-specific initialization of SCB.	
0000	164	:				
0000	165	:	V03-005	TCM0006	Trudy C. Matthews	8-Nov-1982
0000	166	:			Initialize field ADPSL_AVECTOR with the address of	
0000	167	:			each adapter's first SCB vector.	
0000	168	:				
0000	169	:	V03-004	KTA3018	Kerbey T. Altmann	30-Oct-1982
0000	170	:			Move from INILOA facility, rename from INITADP,	
0000	171	:			put in conditional assembly, rewrite some routines.	
0000	172	:				
0000	173	:	V03-003	MSH0001	Maryann Hinden	24-Sep-1982
0000	174	:			Change EXESDW780_INT to EXESUBAERR_INT.	
0000	175	:				
0000	176	:	V03-002	TCM0005	Trudy C. Matthews	10-Aug-1982
0000	177	:			Added support for 11/790 processor.	
0000	178	:				
0000	179	:	V03-001	KDM0002	Kathleen D. Morse	28-Jun-1982
0000	180	:			Added \$DCDEF.	
0000	181	:				
0000	182	:--				

```
0000 184 :  
0000 185 : MACRO LIBRARY CALLS  
0000 186 :  
0000 187 $ADPDEF ; Define ADP offsets.  
0000 188 $BIICDEF ; Define BIIC offsets.  
0000 189 $BQODEF ; Define boot vector offsets.  
0000 190 $BTODEF ; Define boot devices  
0000 191 $BUADEF ; Define BUA Register offsets.  
0000 192 $CRBDEF ; Define CRB offsets.  
0000 193 $DCDEF ; Define adapter types  
0000 194 $DDBDEF ; Define DDB offsets  
0000 195 $DYNDEF ; Define data structure type codes.  
0000 196 $IDBDEF ; Define interrupt dispatcher offsets.  
0000 213 $IOUV1DEF ; Define Micro-VAX I I/O space.  
0000 219 $MCHKDEF ; Define machine check masks.  
0000 220 $NDTDEF ; Define nexus device types.  
0000 221 $PRDEF ; Define IPR numbers.  
0000 222  
0000 226  
0000 230  
0000 234  
0000 238  
0000 240 $PRUV1DEF ; Define Micro-VAX I specific IPRs.  
0000 242  
0000 246  
0000 247 $PTEDEF ; Define Page Table Entry bits.  
0000 248 $RPBDEF ; Define Restart Parameter Block fields.  
0000 249 $SUBADEF ; Define UBA register offsets.  
0000 250 $UCBDEF ; Define UCB offsets.  
0000 251 $VADEF ; Define virtual address fields.  
0000 252 $VECDEF ; Define vec offsets.
```

```

0000 254 .SBTTL Macros to describe nexus configurations
0000 255 :
0000 256 : The macros FLOAT_NEXUS and FIXED_NEXUS add one or more entries to a
0000 257 : nexus descriptor table. Each entry is of the form:
0000 258 : -----
0000 259 : | PFN of nexus I/O space |
0000 260 : -----
0000 261 : | bus | 0 | type |
0000 262 : -----
0000 263 : type = 0 -> floating nexus
0000 264 : type = non-zero -> fixed nexus; type = fixed adapter type
0000 265 : bus = 0, if SBI; %x80 if BI (this is a VMS-only designation)
0000 266 :
0000 267 :
0000 268 : device_type: SBI adapters have 8-bit device type codes. These
0000 269 : device types are simple integers.
0000 270 :
0000 271 : BI adapters have 16-bit device type codes, that are
0000 272 : subject to the following interpretation:
0000 273 :
0000 274 : - the MSB of the device-type field will be 0 for DEC
0000 275 : devices and 1 for non-DEC devices,
0000 276 :
0000 277 : - DEC memory devices will have 0s in the high-order
0000 278 : byte of the device type,
0000 279 :
0000 280 : - non-DEC supplied memory devices will have a 1 in the
0000 281 : MSB of the high-order byte, and the rest of the high
0000 282 : order byte will contain 0s.
0000 283 :
0000 284 : - The "all 0s" and "all 1s" device-type codes are
0000 285 : reserved for DEC.
0000 286 :
0000 287 : If SBI type codes were simply expanded to a word for purposes of the routines
0000 288 : in this module, there would be possible conflicts between SBI devices and
0000 289 : BI memory adapters supplied by DEC. Voila: the bus type.
0000 290 :
0000 291 : Macro FLOAT_NEXUS.
0000 292 : INPUTS:
0000 293 : PHYSADR -- physical address of 1 or more contiguous floating nexus
0000 294 : slots
0000 295 : NUMNEX -- number of contiguous floating nexuses, default = 1
0000 296 : PERNEX -- amount of address space per nexus (does not have to be
0000 297 : specified if NUMNEX = 1)
0000 298 :
0000 299 : .MACRO FLOAT_NEXUS PHYSADR,NUMNEX=1,PERNEX=0
0000 300 : PA = PHYSADR
0000 301 : .REPEAT NUMNEX ; For each nexus...
0000 302 : .LONG <PA/^X200> ; Store PFN.
0000 303 : .LONG 0 ; Store floating nexus type.
0000 304 : PA = PA + PERNEX ; Increment to physical address of next nexus.
0000 305 : .ENDR
0000 306 : .ENDM FLOAT_NEXUS
0000 307 :
0000 308 :
0000 309 : Macro FIXED_NEXUS.
0000 310 :

```



```

0000 311 : INPUTS:
0000 312 : PHYSADR - physical address of 1 or more contiguous fixed nexus slots
0000 313 : PERNEX - amount of address space per nexus
0000 314 : NEXUSTYPES - a list of fixed nexus types, enclosed in <>
0000 315 :
0000 316 : .MACRO FIXED_NEXUS PHYSADR,PERNEX=0,NEXUSTYPES
0000 317 : PA = PHYSADR
0000 318 : .IRP TYPECODE,NEXUSTYPES : For each fixed nexus type...
0000 319 : .LONG <PA/^X200> : Store PFN.
0000 320 : .LONG TYPECODE : Store fixed nexus type.
0000 321 : PA = PA + PERNEX : Increment to address of next nexus.
0000 322 : .ENDR
0000 323 : .ENDM FIXED_NEXUS
0000 324 :
0000 325 :
0000 326 : Macro NEXUSDESC_TABLE - declare the beginning of a NEXUS descriptor table
0000 327 :
0000 328 : 1st byte in table (at offset -5 from label) contains length of
0000 329 : adapter type code field in CSR's on this bus. [Note for SBI like
0000 330 : busses, this is 1.] The next longword (at offset -4) in the
0000 331 : table contains the Software defined bus type byte defined in the
0000 332 : high order byte of the longword. [Note for SBI like busses, this
0000 333 : value is 0, for the BI it is ^x80.]
0000 334 :
0000 335 :
0000 336 : Define parameters that may be specified or used in macro invocation.
0000 337 :
00000000 0000 338 BI_LIKE = 0 : BI like bus.
00000001 0000 339 SBI_LIKE = 1 : SBI like bus.
0000 340 :
00000001 0000 341 SBI_CSR_LEN = 1 : Length of type code field in adapter CSR's
0000 342 : on SBI, CMI, etc.
00000002 0000 343 BI_CSR_LEN = 2 : Length of type code field in adapter CSR's
0000 344 : on BI.
0000 345 :
00000000 0000 346 SBI_BUS_CODE = 0 : Software defined bus code for SBI like busses.
80000000 0000 347 BI_BUS_CODE = ^x80000000 : Software defined bus code for the BI.
0000 348 :
0000 349 : .MACRO NEXUSDESC_TABLE LABEL,BUS_TYPE=SBI_LIKE
0000 350 : .IF EQ,BUS_TYPE-SBI_LIKE
0000 351 : .BYTE SBI_CSR_LEN
0000 352 : .LONG SBI_BUS_CODE
0000 353 : .IFF
0000 354 : .IF EQ,BUS_TYPE-BI_LIKE
0000 355 : .BYTE BI_CSR_LEN
0000 356 : .LONG BI_BUS_CODE
0000 357 : .IFF
0000 358 : .ERROR ; UNRECOGNIZED BUS TYPE, NEXUSDESC_TABLE;
0000 359 : .ENDC
0000 360 : .ENDC
0000 361 :
0000 362 LABEL: : .ENDM NEXUSDESC_TABLE
0000 363 :
0000 364 :
FFFFF7FB 0000 365 CSR_LEN_OFFSET = -5 : Offset before nexus descriptor of
0000 366 : byte containing length of adapter
0000 367 : type field in adapter CSR.

```

INIADPUV1  
V04-002

D 15

- ADAPTER INITIALIZATION FOR MICRO-VAX I 16-SEP-1984 01:04:35 VAX/VMS Macro V04-00  
Macros to describe nexus configurations 11-SEP-1984 16:29:18 [SYSLOA.SRC]INIADP.MAR;3

Page 7  
(3)

```
FFFFFFFFC 0000 368 BUS_CODE_OFFSET = -4 ; Offset before nexus descriptor table
           0000 369 ; of longword containing software
           0000 370 ; defined bus type to be or'ed with
           0000 371 ; adapter type to produce NDIS_ value.
           0000 372 :
           0000 373 : Macro END_NEXUSDESC.
           0000 374 :
           0000 375 .MACRO END_NEXUSDESC
           0000 376 .LONG 0 ; PFN=0 -> end of nexus descriptors.
           0000 377 .ENDM END_NEXUSDESC
```

```

0000 379      .SBTTL Adapter-specific data structures
0000 380      ;
0000 381      ; Put a symbol for arrays built by macros in the correct psects.
0000 382      ;
0000 383      ;***** ADAPTERS array *****
00000000 384      .PSECT $$$INIT$DATA0
0000 385 ADAPTERS:                ; Build adapter type code arrays here.
0000 386
00000000 387      .PSECT $$$INIT$DATA1                ; User contributions in this .PSECT.
0000 388      ; End of ADAPTERS array.
0000 389      ;***** End of ADAPTERS array *****
0000 390
0000 391      ;***** NUM PAGES array *****
00000000 392      .PSECT $$$INIT$DATA2
0000 393 NUM_PAGES:                ; Build 'number of pages to map' array.
00000000 394      .PSECT $$$INIT$DATA3                ; User contributions in this .PSECT.
0000 395      ;***** End of NUM_PAGES array *****
0000 396
0000 397      ;***** INIT ROUTINES array *****
00000000 398      .PSECT $$$INIT$DATA4
0000 399 INIT_ROUTINES:            ; Build 'address of init routine' array.
00000000 400      .PSECT $$$INIT$DATA5                ; User contributions in this .PSECT.
0000 401      ;***** End of INIT_ROUTINES array *****
0000 402
0000 403      ;
0000 404      ; To add a new adapter type:
0000 405      ; 1) Add a new ADAPDESC macro invocation to the end of this list.
0000 406      ;
00000000 407      .PSECT $$$INIT$DATA, LONG
0000 408
0000 409      ;
0000 410      ; Default interrupt vectors for UNIBUS system devices
0000 411      ; (This array is indexed by the RPB field RPB$B_DEVTYPE, if the RPB field
0000 412      ; RPB$W_ROUBVEC is zero. If RPB$W_ROUBVEC is not zero, then RPB$W_ROUBVEC
0000 413      ; is used and this array is not referenced at all. RPB$W_ROUBVEC is set up
0000 414      ; by PQDRIVER. RPB$L_BOOTRO is set by VMB to contain the device name in
0000 415      ; ASCII, not the vector number and device type, as it does on full
0000 416      ; architecture VAX machines.
0000 417      ;
0000 418 BOOTVECTOR:
0088 0000 419      .WORD    ^X88                ; RK06/7 Interrupt vector
0070 0002 420      .WORD    ^X70                ; RL01/2 Interrupt vector
0004 421
0004 422 BUS_CSR_LEN:                ; Static byte containing the length (in bytes)
00 0004 423      .BYTE    0                    ; of the adapter type field in the CSR's of
0005 424      ; the bus currently being configured. The
0005 425      ; proper value for the bus of interest is
0005 426      ; copied here, from the current nexus
0005 427      ; descriptor table, when we enter subroutine
0005 428      ; CONFIG_IOSPACE.
0005 429
0005 430 SW_BUS_CODE:                ; Static longword containing the software
00000000 0005 431      .LONG    0                    ; defined bus type, of the bus currently being
0009 432      ; configured, in the high order byte. The
0009 433      ; proper value for the bus of current interest
0009 434      ; is copied here, from the nexus descriptor
0009 435      ; table, when we enter subroutine

```

```

0009 436 ; CONFIG_IOSPACE.
0009 437
0009 438 DIRECT_VEC_NODE_CNT: ; Static longword that counts the number of
0009 439 ; direct vectoring adapter nodes that we have
00000000 0009 440 .LONG 0 ; run across so far.
000D 441
00000001 000D 442 $$$VMSDEFINED = 1 ; Define symbol that means VMS system software.
00000080 000D 443 NUMUBAVEC = 128 ; ALLOW FOR 128 UNIBUS VECTORS
000D 444
000D 445 ADAPDESC - ; Memory. ** MUST BE 1ST IN DESCRIPTOR LIST **
000D 446 ADPTYPES=<NDTS_MEM1664NI,NDTS_MEM4NI,NDTS_MEM4I,NDTS_MEM16NI, -
000D 447 NDT$_MEM16I, -
000D 448 NDT$_MEM64NIL,NDTS_MEM64EIL,NDTS_MEM64NIU,NDTS_MEM64EIU, -
000D 449 NDT$_MEM64I, -
000D 450 NDT$_MEM256NIL,NDTS_MEM256EIL,NDTS_MEM256NIU,NDTS_MEM256EIU, -
000D 451 NDT$_MEM256I, -
000D 452 NDT$_SCORMEM> -
000D 453 NUMPAGES=1
000D 454
000D 455 ADAPDESC - ; MASSbus.
000D 456 ADPTYPES=NDT$_MB, -
000D 457 NUMPAGES=8, -
000D 458 INITRTN=INI$MBADP
000D 459
000D 460 ADAPDESC - ; UNibus.
000D 461 ADPTYPES=<NDTS_UB0,NDTS_UB1,NDTS_UB2,NDTS_UB3,NDTS_BUA>, -
000D 462 NUMPAGES=8, -
000D 463 INITRTN=INI$SUBSPACE
000D 464
000D 465 ADAPDESC - ; Multi-port memory.
000D 466 ADPTYPES=<NDTS_MPM0,NDTS_MPM1,NDTS_MPM2,NDTS_MPM3>, -
000D 467 NUMPAGES=1, -
000D 468 INITRTN=INI$MPMADP
000D 469
000D 470 ADAPDESC - ; DR32.
000D 471 ADPTYPES=NDT$_DR32, -
000D 472 NUMPAGES=4, -
000D 473 INITRTN=INI$DRADP
000D 474
000D 475 ADAPDESC - ; C1780
000D 476 ADPTYPES=NDT$_CI, -
000D 477 NUMPAGES=9, -
000D 478 INITRTN=INI$CIADP
000D 479
000D 480 ADAPDESC - ; KDZ11 Processor
000D 481 ADPTYPES=NDT$_KDZ11, -
000D 482 NUMPAGES=1, -
000D 483 INITRTN=INI$KDZ11
000D 484

```

```

000D 523      .SBTTL CPU-specific data structures
000D 524      :
000D 525      : To add a new CPU type:
000D 526      : 1) Create a new nexus descriptor table, using FLOAT_NEXUS and
000D 527      :     FIXED_NEXUS macros. Put an END_NEXUSDESC macro at the end.
000D 528      :
000D 529      :
000D 552      :
000D 590      :
000D 617      :
000D 659      :
000D 660      :
000D 662 CPU_ADPSIZE:
0258 000D 663      .WORD ADP$C_UBAADPLEN
000F 664      :
000F 665      :
000F 666      :
000F 667      : Declare the beginning of a nexus-descriptor table.
000F 668      :
000F 669      :     NEXUSDESC_TABLE LABEL=NEXUSDESC
0014 670      :
0014 671      :
0014 672      :
0014 673      : Describe all nexuses on a Micro-VAX I processor.
0014 674      :
00000000 0014 675      SBI_CPU = 0
00000000 0014 676      BI_CPU = 0
0014 677      FIXED_NEXUS =
0014 678      PHYSADR=IOUV1$AL_QBOSP, -
0014 679      NEXUSTYPES=NDT$_DBO
001C 680      END_NEXUSDESC
0020 682      :
0020 706      :
0020 707      :
0020 708      : Nexus "descriptor" arrays -- these arrays hold the nexus-device type and
0020 709      : virtual address of every adapter on the system. The arrays, CONFREG and
0020 710      : SBICONF, are allocated enough space to hold the maximum number of adapters
0020 711      : that can be attached to any CPU. When the code discovers how many adapters
0020 712      : actually exist on the system, it will allocate space from non-paged pool
0020 713      : and move a permanent copy of these arrays into that space.
0020 714      :
00000040 0020 715 MAXNEXUS = 64
00000060 0020 716 CONFREG: ; Byte array of nexus-device type codes..
00000060 0020 717      .BLKB MAXNEXUS
00000160 0060 718 SBICONF: ; Longword array of VAs of adapter space.
00000160 0060 719      .BLKL MAXNEXUS
00000260 0160 720 CONFREG: ; Longword array of nexus-device type codes
00000260 0160 721      .BLKL MAXNEXUS

```

```
0260 723 .SBTTL Message strings
0260 724
0000000D 0260 725 CR = 13
0000000A 0260 726 LF = 10
0260 727 NOSPT:
2D 54 49 4E 49 43 45 58 45 25 0A 0D 0260 728 .ASCIZ <CR><LF>/%EXECINIT-F-Insufficient SPT entries/<CR><LF>
65 69 63 69 66 66 75 73 6E 49 2D 46 026C
69 72 74 6E 65 20 54 50 53 20 74 6E 0278
00 0A 0D 73 65 0284
```

```

0289 734 .SBTTL INIS$IOMAP, Initialize and map nexuses
0289 735 :++
0289 736 : FUNCTIONAL DESCRIPTION:
0289 737 : This routine is executed only once, during system initialization.
0289 738 : It loops through all nexuses on the system, testing for
0289 739 : adapters. When it finds an adapter, it maps its I/O space and
0289 740 : initializes it.
0289 741 :
0289 742 : INPUTS:
0289 743 : BOO$GL_SPTFREL - next free VPN
0289 744 : MMG$GL_SPTBASE - base of system page table
0289 745 : EXE$GL_RPB - address of reboot parameter block
0289 749 :
0289 750 : OUTPUTS:
0289 751 : RO - $$$_NORMAL
0289 752 :
0289 753 : For each adapter found, its accessible I/O space is mapped to virtual
0289 754 : addresses. An ADP (Adapter Control Block) is built, and the hardware
0289 755 : adapter is initialized.
0289 756 :
0289 757 : The arrays CONFREG (a byte array of nexus-device type codes, defined
0289 758 : by NDT$ symbols) and SBICONF (a longword array of
0289 759 : virtual addresses that map adapter space) are initialized. Pointers
0289 760 : to these arrays are stored in EXE$GL_CONFREG and
0289 761 : MMG$GL_SBICONF. The number of entries in these two parallel arrays is
0289 762 : stored in EXE$GL_NUMNEXUS.
0289 763 :
0289 764 : Since BI devices have a 16-bit device type code, a new CONFREG array is
0289 765 : constructed. This is a longword array called CONFREG_L.
0289 766 :
0289 767 : Several locations in the RPB that describe the boot device are init'ed:
0289 768 : RPBS$L_BOOTR1 - holds index into CONFREG and SBICONF for the boot
0289 769 : adapter
0289 770 : RPBS$L_ADPVIR - holds VA of boot device adapter's register space
0289 771 : RPBS$L_CSRVIR - holds VA of boot device's register space
0289 772 :--
0289 773 :
00000000 774 .PSECT $$$INIT$CODE,QUAD
0000 775 INIS$IOMAP::
0000 776
OFFF 8F BB 0000 777 PUSHR #*M<R0,R1,R2,R3,R4,R5,R6,R7,R8,R9,R10,R11>
0004 778 :
0004 779 : Set up common inputs to CONFIG_IOSPACE subroutine for the CPU-specific code.
0004 780 :
52 00000000'GF DO 0004 781 MOVL G^BOO$GL_SPTFREL,R2 ; Get next available VPN.
53 00000000'GF DO 000B 782 MOVL G^MMG$GL_SPTBASE,R3 ; Get base of System Page Table.
53 53 6342 DE 0012 783 MOVAL (R3)[R2],R3 ; Compute SVASPT.
52 52 09 78 0016 784 ASHL #9,R2,R2 ; Convert VPN to VA.
52 80000000 8F C8 001A 785 BISL #VASM_SYSTEM,R2 ; Set system bit.
54 D4 0021 786 CLRL R4 ; Clear index into CONFREG and SBICONF.
59 00000000'GF DO 0023 787 MOVL G^EXE$GL_RPB,R9 ; Get address of RPB.
00000000'GF 0060'CF DE 002A 791 MOVAL W^SBICONF,G^MMG$GL_SBICONF ; Set pointers to local copies
00000000'GF 0020'CF DE 0033 792 MOVAL W^CONFREG,G^EXE$GL_CONFREG ; of these arrays for init routines.
00000000'GF 0160'CF DE 003C 793 MOVAL W^CONFREG_L,G^EXE$GL_CONFREG_L ; ...

```

```

      0045 899      .SBTTL INITADP_780, _750, _730, and _UV1
      0045 900      :
      0045 901      : I/O address space for the 11/780, 11/750, 11/730, and Micro-VAX I cpus
      0045 902      : is statically defined in their respective nexus descriptor tables.
      0045 903      :
56  0014'CF DE 0045 904      MOVAL  W^NEXUSDESC,R6      : Get address of nexus table.
      5B   D4 004A 905      CLRL   R11              : Signal use 1st page of SCB.
      0B   10 004C 906      BSBB   CONFIG_IOSPACE     : Configure processor I/O space.
      0079 30 004E 907
      OFFF 8F BA 004E 909
      50   01 D0 0051 910      BSBW   CREATE_ARRAYS      : Create CONFREG and SBICONF arrays.
      05   05 D0 0055 911      POPR   #^M<R0,R1,R2,R3,R4,R5,R6,R7,R8,R9,R10,R11>
      05   05 D0 0055 912      MOVL  #1,R0              : Set success status
      05   05 D0 0058 913      RSB   : Return.
  
```



```

0059 916      .SBTTL CONFIG_IOSPACE
0059 917      :
0059 918      : CONFIG_IOSPACE
0059 919      : Given a nexus descriptor table, which describes what 'nexuses' or
0059 920      : 'slots' are available on a system to hold I/O adapters, find and
0059 921      : initialize all adapters on the system.
0059 922      :
0059 923      : Inputs:
0059 924      : R2 - next available virtual address, to be used for mapping I/O space
0059 925      : R3 - address of PTE associated with VA in R2
0059 926      : R4 - Current index into CONFREG and SBICONF arrays (should be 0 the
0059 927      : first time CONFIG_IOSPACE is called)
0059 928      : R6 - address of nexus descriptor table
0059 929      : R9 - address of Restart Parameter Block (RPB)
0059 930      : R10 - PFN of boot adapter space
0059 931      : R11- page offset from beginning of SCB; tells which page of the SCB
0059 932      : to use for this set of nexuses (passed to routines that init ADP)
0059 933      :
0059 934      : Outputs:
0059 935      : R2,R3,R4 - updated
0059 936      : R9,R10,R11 - preserved; all other registers potentially modified
0059 937      : CONFREG - initialized with adapter NDT$ code for each nexus
0059 938      : SBICONF - initialized with adapter space VA for each nexus
0059 939      :
0059 940      CONFIG_IOSPACE:
0059 946      :
0059 947      : There is only one adapter, the Qbus.
0059 948      :
0059 950      :
0059 951      : FB A6 90 0059 951      MOVB      CSR_LEN_OFFSET(R6),-      ; Move length of adapter type field
0059 952      : 0004'CF      : W^BUS_CSR_LEN      ; in CSR's to static location.
0059 953      : FC A6  D0 005F 953      MOVL      BUS_CODE_OFFSET(R6),-      ; Move software defined bus type code
0059 954      : 0005'CF      : W^SW_BUS_CODE      ; to static longword.
0059 955      :
0059 956      : 58 86  D0 0065 956      NXT_NEXUS:      ; For each nexus...
0059 957      : 0065 957      MOVL      (R6)+,R8      ; Get PFN of nexus.
0059 984      :
0059 985      : Execution continues here if adapter was present.
0059 986      :
0059 987      : 57 86  D0 0068 987      GET_TYPE:
0059 988      : 0068 988      MOVL      (R6)+,R7      ; Get nexus-device type from nexus table.
0059 1005     :
0059 1006     : Here R7 has hardware adapter code or'ed with software bus code.
0059 1007     : Translate specific nexus device type code into general adapter type code.
0059 1008     :
0059 1009     : 0068 1009     GET_GEN_TYPE:
0059 1010     : 0068 1010     MOVB      R7,W^CONFREG[R4]      ; Save nexus-device type in CONFREG.
0059 1011     : 0071 1011     MOVL      R7,W^CONFREGL[R4]      ; CONFREGL also filled in.
0059 1012     : 0077 1012     CLRL      R5      ; Clear loop index.
0059 1013     :
0059 1014     : 50 0000'CF45 DE 0079 1014     30$:      MOVAL      W^ADAPTERS[R5],R0      ; Get address of adapter type code.
0059 1015     : 0000'CF 9F 007F 1015     PUSHAB   W^NUM_PAGES      ; Push addr of end of ADAPTERS array.
0059 1016     : 8E 50  D1 0083 1016     CMPL      R0,(SP)+      ; See if we went beyond array.
0059 1017     : 3F 1E  D1 0086 1017     BGEQU     END_NEXUS      ; unrecognized adapter, do not map.
0059 1018     : 60 57  D1 0088 1018     CMPL      R7,(R0)      ; Adapter type match?
0059 1019     : 04 13  D1 008B 1019     BEQL      40$      ; If EQL yes, adapter type match.
0059 1020     : 55  D6  D1 008D 1020     INCL      R5      ; Increment loop index.

```

```

E8 11 008F 1021 BRB 30$ ; Look at next adapter.
      0091 1022 40$:
      0091 1023
      0091 1024 ;
      0091 1025 ; Store boot parameters.
      0091 1026 ;
      60 A9 52 D0 0091 1031 MOVL R2,RPB$L_ADPVIR(R9) ; Store VA of boot adapter space.
      20 A9 54 D0 0095 1032 MOVL R4,RPB$L_BOOTR1(R9) ; Store boot adapter nexus number.
51 54 A9 0D 00 EF 0099 1033 EXTZV #0,#13, = ; Get offset into UNIBUS/QBUS I/O page.
      009F 1034 RPB$L_CSRPHY(R9),R1 ;
      58 A9 1000 C241 9E 009F 1035 MOVAB <8*512>(R2)[R1], - ; Set VA of UNIBUS/QBUS registers.
      00A6 1036 RPB$L_CSRVIR(R9) ;
      00A6 1037 ;
      00A6 1038 ;
      00A6 1039 ;
      00A6 1040 ; R5/ general adapter type; index into "general" adapter arrays.
      00A6 1041 ; For each adapter -
      00A6 1042 ; Map the # of pages specified in ADAPDESC macro
      00A6 1043 ; JSB to initialization routine specified in ADAPDESC macro
      00A6 1044 ;
      58 2000 C8 9E 00A6 1045 MAP_NEXUS:
      00AB 1048 MOVAB <16*512>(R8),R8 ; Since no Qbus adapter space, point to
      00AB 1050 MOVL R2,W^SBICONF[R4] ; non-exist memory past Qbus I/O space.
      51 0060'CF44 52 D0 00AB 1050 MOVL R2,W^SBICONF[R4] ; Save VA of adapter space in SBICONF.
      51 0000'CF45 3C 00B1 1051 MOVZWL W^NUM_PAGES[R5],R1 ; Get number of pages to map.
      6A 10 00B7 1052 BSBB MAP_PAGES ; Map the I/O pages.
      51 0000'CF45 6A 10 00B7 1052 BSBB MAP_PAGES ; Map the I/O pages.
      61 D5 00B9 1053 MOVAL W^INIT_ROUTINES[R5],R1 ; Get address of initialization routine.
      04 13 00BF 1054 TSTL (R1) ; Initialization routine specified?
      00 B141 16 00C1 1055 BEQL END_NEXUS ; Branch if none.
      54 D6 00C7 1057 JSB @ (RT)[R1] ; Call initialization routine.
      05 05 00C9 1062 END_NEXUS:
      00CA 1064 INCL R4 ; Increment CONFREG and SBICONF index.
      RSB ; Return, as only one nexus.

```

```

00CA 1066      .SBTTL  CREATE_ARRAYS
00CA 1067      :
00CA 1068      : CREATE_ARRAYS
00CA 1069      :
00CA 1070      : Move the local CONFREG and SBICONF arrays into non-paged pool.
00CA 1071      :
00CA 1072      : Inputs:
00CA 1073      : R4 - Number of nexuses on the system.
00CA 1074      : CONFREG and SBICONF have been initialized.
00CA 1075      :
00CA 1076      : Outputs:
00CA 1077      : R0 - R5 destroyed
00CA 1078      : EXE$GL_CONFREG points to a copy of the CONFREG array in non-paged pool
00CA 1079      : MMG$GL_SBICONF points to a copy of the SBICONF array in non-paged pool
00CA 1080      : EXE$GL_NUMNEXUS contains the number of nexuses on the system
00CA 1081      :
00CA 1082      :
00CA 1083      : CREATE_ARRAYS:
00000000'GF 54 DO 00CA 1084      MOVL  R4,G^EXE$GL_NUMNEXUS      ; Store number of nexuses on system.
51 0C A444 DE 00D1 1085      MOVAL 12(R4)[R4],R1      ; Allocate n bytes for CONFREG plus
; 4n bytes for SBICONF + header
51 6144 DE 00D6 1086      MOVAL (R1)[R4],R1      ; Another 4n bytes for CONFREG.
017D 30 00DA 1088      BSBW  ALONPAGD      ; Get pool for CONFREG and SBICONF.
82 7C 00DD 1089      CLRQ  (R2)+      ; Clear out unused
82 82 51 80 00DF 1090      MOVW  R1,(R2)+      ; Set in size
82 0763 8F 80 00E2 1091      MOVW  #<DYN$C_CONF$8>!DYN$C_INIT,(R2)+ ; Set type and subtype
00000000'GF 62 9E 00E7 1092      MOVAB (R2),G^EXE$GL_CONFREG- ; Store address of system CONFREG.
51 6244 9E 00FE 1093      MOVAB (R2)[R4],R1      ; Two steps to CONFREG, 1st, SBICONF,
00000000'GF 51 DO 00F2 1094      MOVL  R1,G^MMG$GL_SBICONF ; Store address of system SBICONF.
00000000'GF 6144 LE 00F9 1095      MOVAL (R1)[R4],G^EXE$GL_CONFREG ; And address of system CONFREG.
14 BB 0101 1096      PUSHR #^M<R2,R4>      ; Save pool address and nexus count.
62 0020'CF 54 28 0103 1097      MOVCL R4,W^CONFREG,(R2) ; Copy CONFREG to pool.
14 BA 0109 1098      POPR  #^M<R2,R4>      ; Retrieve pool address and nexus count.
51 54 04 C5 010B 1099      MULL3 #4,R4,R1      ; Number of bytes in SBICONF.
7E 51 DO 010F 1100      MOVL  R1,-(SP)      ; Save, SBICONF size = CONFREG size
6244 0060'CF 51 28 0112 1101      MOVCL R1,W^SBICONF,(R2)[R4] ; Copy SBICONF to pool.
51 8E DO 0119 1102      MOVL (SP)+,R1      ; Restore size of SBICONF and CONFREG.
63 0160'CF 51 28 011C 1103      MOVCL R1,W^CONFREG,(R3) ; Copy CONFREG to pool. R3 is output
; from SBICONF MOVCL, so SBICONF and
; CONFREG must be adjacent.
0122 1104
0122 1105
0122 1106
05 0122 1107      RSB

```

```

0123 1109 .SBTTL MAP_PAGES
0123 1110 :++
0123 1111 : INPUTS:
0123 1112 : R1/ Number of pages to map.
0123 1113 : R2/ VA of page to map.
0123 1114 : R3/ VA of system page table entry to be used.
0123 1115 : R8/ PFN of page(s) to map.
0123 1116 :
0123 1117 : OUTPUTS:
0123 1118 : R2,R3 updated; R1,R8 destroyed; all other registers preserved
0123 1119 :
0123 1120 :--
0123 1121 :
0123 1122 MAP_PAGES:
0123 1123 :
83 58 90000000 8F C9 0123 1124 BISL3 #<PTESM_VALID!PTESC_KW>,R8,(R3)+
0128 1125 : Map a page.
0128 1126 INCL R8 : Next PFN.
52 0200 C2 9E 012D 1127 MOVAB 512(R2),R2 : Next VA.
00000000'GF D6 0132 1128 INCL G^BOO$GL_SPTFREL : Next free entry.
00000000'GF D1 0138 1129 CMPL G^BOO$GL_SPTFREL, - : Check for no more system page
0143 1130 G^BOO$GL_SPTFREL : table entries.
04 15 0143 1131 BLEQ ERROR_HALT : Branch if out of SPTEs.
DB 51 F5 0145 1132 SOBGTR R1,MAP_PAGES : Map another page.
05 0148 1133 RSB : All done.
0149 1134 :
0149 1135 ERROR_HALT:
51 0260'CF 9E 0149 1136 MOVAB W^NOSPT,R1 : Set error message.
014E 1137 ERROR_HALT_1:
014E 1138 CLRRL R11 : Indicate console terminal.
00000000'GF 5B D4 014E 1138 JSB G^EXE$OUTZSTRING : Output error message.
16 0150 1139 : ***** FATAL ERROR *****
00 0156 1140 HALT

```

```

0157 1269 .SBTTL INISUBSPACE
0157 1270 :++
0157 1271 : Map UNIBUS space; initialize UNIBUS ADP.
0157 1272 :
0157 1273 : INPUTS:
0157 1274 : R2 - VA of next free system page
0157 1275 : R3 - VA of system page table entry to be used to map VA in R2
0157 1276 : R4 - nexus identification number of this adapter
0157 1277 : -8(R6) - PFN of this UNIBUS adapter's register space
0157 1278 :
0157 1279 : OUTPUTS:
0157 1280 : UNIBUS space is mapped.
0157 1281 : INISUBADP is called to build an ADP block and initialize UNIBUS
0157 1282 : adapter hardware.
0157 1283 :
0157 1284 :--
0157 1285
0157 1286 INISUBSPACE:
0157 1287
58 58 0160'CF44 DE 0157 1290 MOVAL W^CONFREGL[R4],R8 ; R8 => CONFREGL slot.
58 68 02 00 EF 015D 1291 EXTZV #0,#2,(R8),R8 ; Get UBA number.
58 58 58 09 78 0162 1292 ASHL #9,R8,R8 ; Position UB number.
0166 1295
0166 1304
0166 1309
0166 1314
0166 1319
0166 1325
58 00100000 8F 58 C3 0166 1327 SUBL3 R8,#<IOUV1$AL_QBOSP/^X200>,R8 ; Get PFN of Qbus I/O page.
016E 1328
016E 1330
51 10 D0 016E 1331 MOVL #16,R1 ; Number of pages to map (UB/Qbus space).
FFAF 30 0171 1332 BSBW MAP_PAGES ; Map I/O pages.
0174 1333 :
0174 1334 : Call adapter initialization routine.
0174 1335 :
0174 1336 : BSBW INISUBADP ; Init ADP block.
0174 1337 : RSB

```

```

0174 1339          .SBTTL  INISUBADP - BUILD ADP AND INITIALIZE UBA
0174 1340          :+
0174 1341          : INISUBADP ALLOCATES AND FILLS IN AN ADAPTER CONTROL BLOCK, INTERRUPT
0174 1342          : DISPATCHER AND CONNECTS THEM TO THE PROPER SCB VECTORS.  A CALL IS
0174 1343          : THEN MADE TO UBASINITIAL TO INITIALIZE THE ADAPTER HARDWARE.
0174 1344          :
0174 1345          : INPUT:
0174 1346          : R4 - nexus identification number of this adapter
0174 1347          : R11- offset from beginning of SCB to correct SCB page for this adapter
0174 1348          :-
0174 1349
0174 1350 INISUBADP:
0174 1351
0174 1352          PUSHR  #^M<R0,R1,R2,R3,R4,R5,R6,R7,R8> ; SAVE R0-R8
0178 1353          :
0178 1354          : Allocate and initialize Adapter Control Block (ADP).
0178 1355          :
0178 1356          MOVZWL W^CPU ADPSIZE,R1          ; PICK UP LENGTH OF ADP
BSBW ALONPAGD          ; ALLOCATE SPACE FOR ADP
017D 1357          MOVW  R1,ADP$W_SIZE(R2)        ; SET SIZE INTO ADP BLOCK
0180 1358          MOVW  #DYN$C_ADP,-          ; AND SET TYPE OF BLOCK
0184 1359          MOVW  ADP$B_TYPE(R2)
0188 1360          MOVW  #AT$_UBA,-          ; SET TYPE OF ADAPTER
0188 1361          MOVW  ADP$Q_ADPTYPE(R2)
018C 1362          MOVL  W^SBI[CONF[R4],-      ; SET VA OF CONFIGURATION REG
62 0060'CF44  D0 018C 1363          MOVL  ADP$L_CSR(R2)
0192 1364          MOVW  R4,ADP$W_TR(R2)      ; SET TR NUMBER FOR ADAPTER
0196 1365          MOVAL ADP$L_DPQFL(R2),R0    ; ADDRESS OF DATA PATH WAIT QUEUE
0196 1366          MOVL  R0,(R0)              ; INIT QUEUE HEADER
04 A0 50  D0 019A 1368          MOVL  R0,4(R0)
019D 1369          MOVL  R0,4(R0)
01A1 1370
01A1 1371          MOVAL ADP$L_MRQFL(R2),R0    ; ADDRESS OF MAP WAIT QUEUE
01A5 1372          MOVL  R0,(R0)              ; INIT QUEUE HEADER
04 A0 50  D0 01A8 1373          MOVL  R0,4(R0)
01AC 1374          CLRL  ADP$L_LINK(R2)        ; ZAP ADAPTER CHAIN LINK
01AF 1375          BSBW  ADPLINK              ; LINK ADP TO END OF LIST
01B2 1376          :
01B2 1377          : Initialize adapter interrupt vectors in System Control Block.
01B2 1378          :
58 00000000'GF  D0 01B2 1379          MOVL  G^EXE$GL_SCB,R8          ; GET SCB ADDRESS
01B9 1380
01B9 1387
01B9 1447
01B9 1507
01B9 1508
01B9 1536
01B9 1537
01B9 1539          : REMAINING ADP INIT FOR MICRO-VAX I:
01B9 1540          MOVAL  ^X200(R8),-          ; ASSUME UBO
01BD 1541          ADP$L_VECTOR(R2)          ; VECTOR SPACE
01BF 1542
01BF 1543          MOVW  #^XE,ADP$W_DPBITMAP(R2) ; MARK DATAPATHS 1-3 AVAILABLE
53 00000001'GF  DE 01C3 1544          MOVAL  G^UBA$UNEXINT+1,R3      ; GET ADDR OF UNEXP INT SERVICE
01CA 1545          : (+1 MEANS HANDLE ON INT STACK)
54 0001'CF  DE 01CA 1546          MOVAL  W^UBA$INT0+1,R4      ; SPECIAL CASE TO COUNT PASSIVE RELEASE
01CF 1547

```

```

01CF 1548 :
01CF 1549 : INIT QBUS VECTORS TO UNEXPECTED INTERRUPT SERVICE
01CF 1550 :
50 10 A2 D0 01CF 1551      MOVL  ADP$L_VECTOR(R2),R0      ; GET ADDRESS OF VECTORS
      80 54 D0 01D3 1552      MOVL  R4,(R0)+                 ; SPECIAL CASE FOR VECTOR 0
51 7F 8F 9A 01D6 1553      MOVZBL #<NUMUBAVEC-1>,R1        ; REST OF VECTORS
      80 53 D0 01DA 1554 30$: MOVL  R3,(R0)+                 ; FILL VECTOR WITH UNEXP INT
      FA 51 F5 01DD 1555      SOBGTR R1,30$                ; FILL ALL VECTORS
01E0 1556
01E0 1558
01E0 1559
01E0 1601
01E0 1602
01E0 1604 :
01E0 1605 : All memory on the QBUS is main memory. There is no memory analogous
01E0 1606 : to UNIBUS memory.
01E0 1607 :
01E0 1608 : Now locate the memory controllers and build a list of the addresses
01E0 1609 : at which they are located. This list is used by the memory error logic
01E0 1610 : in machine-check. This information must be determined outside of machine-
01E0 1611 : check, since the machine-check code cannot cause another machine-check
01E0 1612 : without causing a cpu double-error halt.
01E0 1613 :
01E0 1614 : The list is a count of controllers, followed by the virtual addresses
01E0 1615 : that are the memory controller CSRs. Each MSV-11P has a single word CSR.
01E0 1616 :
01E0 1617 :
53 0000000'GF D0 01E0 1618      .ENABLE LSB
      04 A3 DD 01E7 1619      MOVL  G^EXE$GL_SCB,R3          ; Get SCB address.
      50 5E DD 01E7 1619      PUSHL 4(R3)                  ; Save current mcheck handler address.
04 A3 20'AF DE 01EA 1620      MOVL  SP,R0                   ; Mark current stack position.
      DE 01ED 1621      MOVAL  B^MCHK_HANDLER,4(R3) ; Connect temp mcheck handler.
01F2 1622
51 0000000'GF D0 01F2 1623      MOVL  G^MMG$GL_SBICONF,R1     ; Get address of SBICONF array.
      51 61 D0 01F9 1624      MOVL  (R1),R1                 ; Get VA of Qbus I/O space.
51 00002440 8F C0 01FC 1625      ADDL  #<012100+^X1000>,R1    ; Offset to memory controller CSR(772100).
54 00000000'GF DE 0203 1626      MOVAL G^EXE$AL_MEMCSRS,R4    ; Get address of memory CSR count.
      56 04 A4 DE 020A 1627      MOVAL 4(R4),R6               ; Get address of buffer for CSRs.
      55 D4 020E 1628      CLRL  R5                     ; Initialize index.
      0210 1629
      6145 B5 0210 1630 50$: TSTW  (R1)[R5] ; Touch possible memory CSR.
      64 D6 0213 1631      INCL  (R4) ; Count number of error bits set.
      86 6145 3E 0215 1632      MOVAW (R1)[R5],(R6)+ ; Save address of this CSR
      F3 55 10 F2 0219 1633 60$: AOBLS #16,R5,50$ ; Loop through all possible CSRs.
      09 11 021D 1634      BRB  70$ ; Continue with common code.
021F 1635 :
021F 1636 : TEMPORARY MACHINE CHECK HANDLER
021F 1637 :
021F 1638 :
021F 1639 :
0220 1640 MCHK_HANDLER: .ALIGN LONG ; Align machine-check vector.
0220 1641 :
26 0F DA 0220 1642      MTPR  #^XF,#PRUV1$_MCESR ; Clear machine-check state.
SE 50 D0 0223 1643      MOVL  R0,SP ; Clean mcheck frame from stack.
      F1 11 0226 1644      BRB  60$ ; Continue looking for memory CSRs.
      0228 1645
04 A3 8ED0 0228 1646 70$: POPL  4(R3) ; Restore mcheck handler address.
022C 1647

```

```

      56 62 D0 022C 1648      .DISABLE LSB
      51 D4 022C 1661      MOVL ADPSL_CSR(R2),R6      ; Pick up adapter pointer
0256 C2 51 B0 022F 1662      CLRL R1      ; Zero out number of UMR to disable
      B0 0231 1686      MOVW R1,ADPSW_UMR_DIS(R2) ; Record number disabled
      0236 1700      ;
      0236 1701      ; Initialize fields for the Qbus map register allocation. Since there
      0236 1702      ; are no map registers for the Micro-VAX I Qbus, initialize the data structures
      0236 1703      ; so that the standard allocate routine will just return an error.
      0236 1704      ;
64 A2 5C A2 01 D0 0236 1705      MOVL #1,ADPSL_MRACTMDRS(R2) ; 1 active map descriptor
      01F0 8F 51 A3 023A 1706      SUBW3 R1,#496,ADPSW_MRNREGARY(R2); for a range of 496 registers
      0241 1707      CLRL ADPSL_MRACTMDRS(R2) ; No active descriptors.
      0241 1708      CLRL ADPSW_MRNREGARY(R2) ; No registers to allocate,
015E C2 51 B0 0241 1710      MOVW R1,ADPSW_MRFREGARY(R2) ; starting at register zero.
      62 A2 01 AE 0246 1711      MNEGW #1,ADPSW_MRFENCE(R2) ; Also init 'fences' which precede
015C C2 01 AE 024A 1712      MNEGW #1,ADPSW_MRFFENCE(R2) ; the two descriptor arrays.
      024F 1713      ;
      024F 1714      ; Initialize adapter hardware.
      024F 1715      ;
      54 62 D0 024F 1716      MOVL ADPSL_CSR(R2),R4      ; Get CSR address to init
      FDAB' 30 0252 1717      BSBW UBASINITIAL ; And initialize adapter
      01FF 8F BA 0255 1718      POPR #^M<R0,R1,R2,R3,R4,R5,R6,R7,R8> ; Restore registers
      05 0259 1719      RSB ; Return
      025A 1720
      025A 1728
  
```



```

025A 1815          .SBTTL INISMBADP - BUILD ADP AND INITIALIZE MBA
025A 1816          .SBTTL INISDRADP - BUILD ADP AND INITIALIZE DR32
025A 1817          .SBTTL INISCIADP - BUILD ADP AND INITIALIZE CI
025A 1818          :+
025A 1819          : INISMBADP IS CALLED AFTER MAPPING THE REGISTERS FOR A MASSBUS ADAPTER.
025A 1820          : AN ADAPTER CONTROL BLOCK IS ALLOCATED AND FILLED. A CRB AND IDB ARE
025A 1821          : ALSO ALLOCATED AND INITIALIZED. THE ADAPTER HARDWARE IS THEN INITIALIZED
025A 1822          : BY CALLING MBASINITIAL.
025A 1823          :
025A 1824          : INISDRADP IS CALLED AFTER MAPPING THE REGISTERS FOR THE DR32
025A 1825          : ADAPTER. THE ADAPTER CONTROL BLOCK, CRB, AND IDB ARE ALLOCATED
025A 1826          : AND INITIALIZED. THE ADAPTER HARDWARE IS THEN INITIALIZED BY
025A 1827          : CALLING DR$INITIAL.
025A 1828          :
025A 1829          : INISMBADP AND INISDRADP SHARE COMMON CODE AFTER THE TABLE OF ADAPTER
025A 1830          : SPECIFIC CONSTANTS IS SELECTED AND STORED IN R8.
025A 1831          :
025A 1832          : INPUT:
025A 1833          : R4 - nexus identification number of this adapter
025A 1834          : R11- offset from beginning of SCB to correct SCB page for this adapter
025A 1835          :
025A 1836          : OUTPUTS:
025A 1837          : ALL REGISTERS PRESERVED
025A 1838          :-
025A 1839          :
00000000'GF 17 025A 1840 ALONPAGD:JMP      G^INISALONONPAGED
0260 1841
0260 1842          .ENABL  LSB
0260 1843
0260 1844 INISDRADP:          : INITIALIZE DR32 DATA STRUCTURES
0260 1845
0260 1855
0260 1856 INISCIADP:          : INITIALIZE CI DATA STRUCTURES
0260 1857
0260 1867
0260 1868 INISMBADP:          : INIT MBA DATA STRUCTURES
0260 1869

```

```
0260 1997      .SBTTL INISKDZ11
0260 1998      :++
0260 1999      :
0260 2000      : INPUTS:
0260 2001      : R2 - VA of next free system page
0260 2002      : R3 - VA of system page table entry to be used to map VA in R2
0260 2003      : R4 - nexus identification number of this adapter
0260 2004      :
0260 2005      : OUTPUTS:
0260 2006      :
0260 2007      :--
0260 2008      :
0260 2009      INISKDZ11:
0260 2010      :
05 0260 2029      RSB                                ; Return to caller.
```

```

0261 2031 .SBTTL INI$CONSOLE, init data structures for console
0261 2032 :++
0261 2033 : FUNCTIONAL DESCRIPTION:
0261 2034 :
0261 2035 : This routine is executed only once, during system initialization.
0261 2036 : It initializes the CRB and IDB for boot/console device.
0261 2037 :
0261 2038 : This routine is called from INIT.
0261 2039 :
0261 2040 : INPUTS:
0261 2041 :
0261 2042 : R3 --> DISK [CLASS] DRIVER DDB
0261 2043 : R4 --> DISK [CLASS] DRIVER DPT
0261 2044 : R5 --> DISK [CLASS] DRIVER UCB
0261 2045 : R6 --> RPB
0261 2046 : R7 --> ADP FOR EITHER A REAL DISK OR A PORT
0261 2047 : R9 --> PORT DRIVER DPT (IF PRESENT)
0261 2048 : R10--> PORT DIRVER UCB (IF PRESENT)
0261 2049 :
0261 2050 :--
0261 2051 :
0261 2052 INI$CONSOLE::
0261 2053 .ENABL LSB
0261 2054
0261 2062
0261 2067
0261 2075
0261 2076 :
0261 2077 : NOW BUILD THE AUXILIARY DATA BLOCKS (CRB, IDB)
0261 2078 :
0261 2079 BLD_CRB:
58 10 A7 DO 0261 2080 MOVL ADP$$_CRB(R7),R8 ; GET ADDRESS OF CRB IF IT EXISTS
OE A7 01 B1 0265 2081 CMPW #ATS_OBA,ADP$$_ADPTYPE(R7); IS THIS A UNIBUS ADAPTER?
03 13 0269 2082 BEQL FILL_CRB ; YES, ALLOCATE CRB
005D 31 026B 2083 BRW 100$ ; NO, CRB/IDB ALREADY ALLOCATED
026E 2084
026E 2085 FILL_CRB:
24 A2 00000000'9F 16 026E 2086 JSB @#INISALLOC_CRB ; GO ALLOCATE AND SETUP CRB
9F163FBB 8F DO 0274 2087 MOVL #^X9F163FBB,CRB$_INTD(R2) ; SET PUSHR #^M<R0,...,R5>
027C 2088 ; JSB @#0 INTO INTERRUPT DISPATCH
38 A2 57 DO 027C 2089 MOVL R7,CRB$_INTD+VECS$_ADP(R2) ; SET POINTER TO ADP
58 52 DO 0280 2090 R2,R8 ; SAVE CRB POINTER
51 0058 8F 3C 0283 2091 MOVZWL #<IDB$C_LENGTH+<8*4>>,R1 ; SIZE TO ALLOCATE FOR IDB
00000000'9F 16 0288 2092 JSB @#INISACONONPAGED ; ALLOCATE IDB
08 A2 51 B0 028E 2093 MOVW R1,IDB$_SIZE(R2) ; SET SIZE OF IDB
0A A2 09 90 0292 2094 MOVB #DYN$C_IDB,IDB$_TYPE(R2); AND STRUCTURE TYPE CODE
2C A8 52 DO 0296 2095 MOVL R2,CRB$_INTD+VECS$_IDB(R8) ; SET IDB INTO CRB
029A 2096
029A 2113
62 58 A6 DO 029A 2114 10$: MOVL RPB$_CSR VIR(R6), - ; SAVE BOOT DEVICE CSR ADDRESS
029E 2115 IDB$_CSR(R2) ; IN INTERRUPT DISPATCH BLOCK
11 91 029E 2116 CMPB #BTD$R_UDA,- ; LOW ORDER BYTE OF ORIGINAL R0 TELLS
66 A6 02A0 2117 RPB$_DEV TYP(R6) ; BOOT DEVICE TYPE.
08 12 02A2 2118 BNEQ 20$ ; IF NOT BOOTING FROM A UDA BRANCH
02A4 2119 ; AROUND.
00000000'9F 58 A6 DO 02A4 2120 MOVL RPB$_CSR VIR(R6), - ; COPY VIRTUAL ADDRESS OF UDA PORT CSR
02AC 2121 @#BOO$GB_SYSTEMID ; TO LOW ORDER LONGWORD OF SYSTEMID
  
```

			02AC	2122	20\$:			
14	A2	57	D0	02AC	2123	MOVL	R7, IDB\$L ADP(R2)	: POINT IDB TO ADP
50	1E	A6	3C	02B0	2124	MOVZWL	RPB\$W_R00BVEC(R6), R0	: GET USER SPECIFIED VECTOR
		0A	12	02B4	2125	BNEQ	30\$	: BRANCH IF VECTOR SPECIFIED
50	66	A6	9A	02B6	2126	MOVZBL	RPB\$B_DEV TYP(R6), R0	: ELSE GET DEVICE TYPE CODE
50	FFFE	CF40	3C	02BA	2127	MOVZWL	W^BOOTVECTOR-2[R0], R0	: GET DEFAULT INTERRUPT VECTOR
50	10	B740	9E	02C0	2128	MOVAB	@ADP\$L_VECTOR(R7)[R0], R0	: COMPUTE ADDRESS OF VECTOR
60	26	A8	9E	02C5	2129	MOVAB	CRB\$L_INTD+2(R8), (R0)	: SET ADDR OF INTERRUPT VECTOR
				02C9	2130			
		60	D7	02C9	2133	DECL	(R0)	: BACK TWO BYTES TO PUSHR, +1 TO
				02CB	2136			:
				02CB	2137			:
			05	02CB	2138	RSB		: RETURN
				02CC	2139	.DISABLE	LSB	

```

02CC 2141      .SBTTL EXESINI_TIMWAIT - COMPUTE CORRECT TIMEWAIT LOOP VALUES
02CC 2142      :++
02CC 2143      : FUNCTIONAL DESCRIPTION:
02CC 2144      :
02CC 2145      : EXESINI_TIMWAIT initializes EXESGL_TENUSEC and EXESGL_UBDELAY, cells used
02CC 2146      : in the time-wait macros. The first data cell, EXESGL_TENUSEC, is the number
02CC 2147      : of times the following loop will be executed in ten u-seconds. This is
02CC 2148      : done once here to calibrate the loop instead of reading the processor clock.
02CC 2149      : The resulting number is used in the system macros TIMEWAIT and TIMEDWAIT.
02CC 2150      :
02CC 2151      : The first step is to initialize EXESGL_UBDELAY. If the bit test instruction
02CC 2152      : in the TIMEWAIT macro is executed too rapidly in a loop, it can saturate the
02CC 2153      : Unibus. EXESGL_UBDELAY is used to introduce a 3 microsecond delay loop into
02CC 2154      : the TIMEWAIT bit test loop.
02CC 2155      :
02CC 2156      : This routine is called only once, from INIT.
02CC 2157      :
02CC 2158      : INPUT PARAMETERS:
02CC 2159      :
02CC 2160      :     NONE
02CC 2161      :
02CC 2162      : IMPLICIT INPUTS:
02CC 2163      :
02CC 2164      :     Time-of-day processor clock.
02CC 2165      :     Interval timers.
02CC 2166      :
02CC 2167      : OUTPUT PARAMETERS:
02CC 2168      :
02CC 2169      :     R0 - Destroyed.
02CC 2170      :
02CC 2171      : IMPLICIT OUTPUTS:
02CC 2172      :
02CC 2173      :     EXESGL_TENUSEC - set to appropriate value to make TIMEWAIT and TIMEDWAIT
02CC 2174      :     macros loop for 10 micro-seconds.
02CC 2175      :
02CC 2176      :     EXESGL_UBDELAY - set to appropriate value to make TIMEWAIT and TIMEDWAIT
02CC 2177      :     macros loop for 3 micro-seconds in the unibus delay
02CC 2178      :     loop.
02CC 2179      :
02CC 2180      :--
02CC 2181      :
02CC 2182      EXESINI_TIMWAIT::
00000000'GF  01  9A 02CC 2294      MOVZBL #1,G^EXESGL_UBDELAY      ; Initialize time-wait data cells
00000000'GF  01  9A 02D3 2295      MOVZBL #1,G^EXESGL_TENUSEC     ; Set UV1 value same as 11/73^
02CC 2296      RSB                      ; Return

```

```

02DB 2299 .SBTTL EXESINIT_TODR - SET SYSTEM TIME TO CORRECT VALUE AT STARTUP
02DB 2300 :++
02DB 2301 : FUNCTIONAL DESCRIPTION:
02DB 2302 :
02DB 2303 : EXESINIT_TODR SOLICITS THE CORRECT TIME FROM THE OPERATOR IF NECESSARY,
02DB 2304 : CONVERTS THE ASCII RESPONSE TO BINARY FORMAT AND CALLS AN INTERNAL
02DB 2305 : ENTRY POINT OF THE $SETIME SYSTEM SERVICE TO SET THE NEW SYSTEM TIME
02DB 2306 : IN MEMORY WITHOUT MODIFYING THE CONTENTS OF THE SYSTEM DISK.
02DB 2307 :
02DB 2308 : IF THE TIME WOULD NORMALLY BE SOLICITED FROM AN OPERATOR, BECAUSE
02DB 2309 : THE HARDWARE TIME OF YEAR CLOCK IS ZERO, THEN THE SYSGEN PARAMETER
02DB 2310 : "TPWAIT" IS CHECKED. IF IT IS ZERO, THEN IT IS ASSUMED THAT NO
02DB 2311 : OPERATOR IS PRESENT AND THE SYSTEM IS BOOTED USING THE LAST TIME
02DB 2312 : RECORDED IN THE SYSTEM IMAGE. IF THE PARAMETER IS NON ZERO THEN
02DB 2313 : THAT TIME IS USED AS THE MAXIMUM TIME TO WAIT BEFOR ASSUMING THAT
02DB 2314 : THERE IS NO OPERATOR AND BOOTING ANY WAY. IF THE PARAMETER IS
02DB 2315 : NEGATIVE, THE SYSTEM WILL WAIT FOREVER.
02DB 2316 :
02DB 2317 : THIS ROUTINE IS CALLED ONLY ONCE, FROM SYSINIT OR STASYSGEN.
02DB 2318 :
02DB 2319 : INPUT PARAMETERS:
02DB 2320 :
02DB 2321 : NONE
02DB 2322 :
02DB 2323 : IMPLICIT INPUTS:
02DB 2324 :
02DB 2325 : TIME-OF-DAY PROCESSOR CLOCK.
02DB 2326 :
02DB 2327 : OUTPUT PARAMETERS:
02DB 2328 :
02DB 2329 : R0,R1 - DESTROYED
02DB 2330 :
02DB 2331 : IMPLICIT OUTPUTS:
02DB 2332 :
02DB 2333 : EXESGQ_SYSTIME - SET TO CURRENT TIME IN 100 NANOSECOND UNITS SINCE
02DB 2334 : 17-NOV-1858 00:00:00.
02DB 2335 :
02DB 2336 :--
02DB 2337 :
02DB 2338 :
02DB 2339 : Stack storage offsets:
02DB 2340 :
00000000 02DB 2341 TTCHAN = ^X00 ; CHANNEL FOR TERMINAL (LONGWORD)
00000004 02DB 2342 TTNAME = ^X04 ; STRING DESCRIPTOR FOR OPERATOR'S TERM
0000000C 02DB 2343 TMPDESC = ^X0C ; TEMPORY STRING DESCRIPTOR (QUADWORD)
00000014 02DB 2344 INTIME = ^X14 ; INPUT TIME VALUE (QUADWORD)
0000001C 02DB 2345 LINBUF = ^X1C ; INPUT LINE BUFFER (5 LONGWORDS)
00000014 02DB 2346 LINBUFSIZ = ^X14 ; (LENGTH OF LINE BUFFER IN BYTES)
02DB 2347 :
02DB 2348 :
02DB 2349 : PURE DATA
02DB 2350 :
02DB 2351 : TERM_NAMADR:
20 41 50 4F 02DB 2352 .ASCII \OPA0\ ; DEVICE NAME FOR OPERATOR'S TERMINAL
74 61 64 20 64 69 6C 61 76 6E 69 00' 02DF 2353 TERM NAMSIZ = . - TERM_NAMADR ;
65 6D 69 74 2F 65 02DF 2354 TIMERR: .ASCII \invalid date/time\ ;
02EB

```

```

11 02DF
02F1 2355 TIMEPROMPT:
33' 02F1 2356 .BYTE NPROMPT
02F2 2357 .ASCII <13><10>/PLEASE ENTER DATE AND TIME (DD-MMM-YYYY HH:MM) /
02FE
4D 4D 4D 2D 44 44 28 20 45 4D 49 54 030A
4D 4D 3A 48 48 20 20 59 59 59 59 2D 0316
20 20 29 0322
00000033 0325 2358 NPROMPT=-.TIMEPROMPT-1
0325 2359
0325 2360
0325 2361 EXESINIT_TODR:: ; SET CORRECT TIME
0325 2362 .ENABLE LSB
0325 2363 PUSH R #*M<R2,R3,R4,R5,R6,R8,R9,R10> ; SAVE REGISTERS
0329 2364 SUBL #4*12,SP ; SCRATCH STORAGE
032C 2365 MOVL SP,R6 ; SAVE ADDRESS OF SCRATCH STORAGE
032F 2366 MOVZBL #TERM NAMSIZ,TTNAME(R6) ; SET SIZE OF OPERATOR'S TERM NAME AND
0333 2367 MOVAB W^TERM NAMADR,TTNAME+4(R6) ; PIC ADDRESS INTO TERM NAME DESC
0339 2368 BBS S^#EXESV_SETTIME,G^EXESGL_FLAGS,READTIME ; BR TO SOLICIT TIME
0341 2369
0341 2370
0341 2374
0341 2378
0341 2382
0341 2386
06 11 0341 2394 BRB READTIME ; ON MICROVAX I, ALWAYS SOLICIT TIME
14 A6 7C 0343 2396 5$: CLRQ INTIME(R6) ; NULL ARGUMENT FOR EXESSETIME_INT
00C5 31 0346 2397 BRW 2008 ; RETURN TO CALLER
0349 2398
0349 2399 READTIME: ; SOLICIT TIME
58 00000000'GF 04 0349 2400 CLRL R9 ; CLEAR A FLAG
32 034B 2401 CVTWL G^SGN$GW_TPWAIT,R8 ; PICK UP TIMEOUT WAIT INTERVAL
12 14 0352 2402 BGTR 8$ ; POSITIVE, WAIT THAT PERIOD ONCE
08 19 0354 2403 BLSS 7$ ; NEGATIVE IS WAIT FOREVER
0356 2404 6$:
0356 2408
0356 2412
0356 2416
0356 2420
0356 2424
0356 2428
14 A6 00000000'GF 7D 0356 2430 MOVQ G^EXESGQ_TODCBASE,INTIME(R6) ; USE LAST KNOWN SYSTEM TIME
00AD 31 035E 2431 BRW 2008 ; IF THE USER REQUESTS NO PROMPTING
0361 2433
58 14 0361 2434 7$: MOVL #20,R8 ; STARTING WAIT
59 D6 0364 2435 INCL R9 ; NEGATIVE - WAIT FOREVER
0366 2436 8$: $ASSIGN S TTNAME(R6),TTCHAN(R6) ; AND ASSIGN TO INPUT DEVICE
DF 50 E9 0374 2437 BLBC R0,6$ ; ERROR - FALL BACK TO STORED TIME
52 FF76 CF 9E 0377 2438 10$: MOVAB W^TIMEPROMPT,R2 ; GET ADDRESS OF PROMPT STRING
53 82 9A 037C 2439 MOVZBL (R2)+,R3 ; AND LENGTH
037F 2440 $QIOW_S #0,W^TTCHAN(R6),- ; PROMPT AND READ TIME
037F 2441 #<IOS READPROMPT!IOSM_PURGE!IOSM_TIMED!IOSM_CVTLOW>- ;
037F 2442 TMPDESC(R6) ; I/O STATUS BLOCK, NO AS1 OR PARAM
037F 2443 LINBUF(R6),#LINBUFSIZ,- ; BUFFER ADDRESS AND SIZE
037F 2444 R8,#0,- ; TIME OUT
037F 2445 R2,R3 ; PROMPT ADDRESS AND SIZE
AF 50 E9 03A4 2446 BLBC R0,6$ ; ERROR - FALL BACK TO STORED TIME

```

54	OC A6	7D	03A7	2447	MOVQ	TMPDESC(R6),R4	:	GET COMPLETION STATUS
	OD 54	E8	03AB	2448	BLBS	R4,20\$	:	CONTINUE IF SUCCESSFUL READ
	A5 59	E9	03AE	2449	BLBC	R9,6\$	:	FAILED ON ONE-TIME READ, RETURN
58	01 A848	9E	03B1	2450	MOVAB	1(R8)[R8],P8	:	(2 * TIMEOUT) + 1
	58 58	3C	03B6	2451	MOVZWL	R8,R8	:	BOUND TIMEOUT
	BC	11	03B9	2452	BRB	10\$	:	TRY AGAIN FOR TIME
			03BB	2453			:	SOMETHING WAS INPUT
OC A6	OE A6	3C	03BB	2454	MOVZWL	TMPDESC+2(R6),TMPDESC(R6)	:	FORM DESCRIPTOR FOR BUFFER
10 A6	1C A6	9E	03C0	2455	MOVAB	LINBUF(R6),TMPDESC+4(R6)	:	SET DESCRIPTOR ADDRESS
			03C5	2456	\$BINTIM_S	TMPDESC(R6),INTIME(R6)	:	CONVERT TO BINARY TIME
	05 50	E9	03D2	2457	BLBC	R0,89\$	:	INVALID TIME
	18 A6	D5	03D5	2458	TSTL	INTIME+4(R6)	:	CHECK FOR DELTA TIME
	2A	14	03D8	2459	BGTR	100\$	:	BRANCH IF NOT - OK
			03DA	2460			:	INVALID TIME VALUE INPUT
52	FF01 CF	9E	03DA	2461	MOVAB	W^TIMERR,R2	:	ADDRESS OF ERROR MESSAGE
	53 82	9A	03DF	2462	MOVZBL	(R2)+,R3	:	GET STRING LENGTH
			03E2	2463	\$QIOW_S	#0,TTCHAN(R6),-	:	GIVE ERROR MESSAGE
			03E2	2464		#IOS_WRITEVBLK,-	:	
			03E2	2465			:	NO I/O STATUS,AST OR AST PARAM
			03E2	2466		(R2),R3,-	:	BUFFER ADDRESS, LENGTH
			03E2	2467		#0,#32	:	SET CARRIAGE CONTROL TO CR/LF
	FF73	31	0401	2468	BRW	10\$	:	AND TRY AGAIN
			0404	2469			:	EXIT
			0404	2470	\$DASSGN_S	TTCHAN(R6)	:	DE-ASSIGN TERMINAL CHANNEL
	14 A6	7F	040E	2471	PUSHAQ	INTIME(R6)	:	SET NEW SYSTEM TIME
00000000'GF	01	FB	0411	2472	CALLS	#1,G^EXE\$SETIME INT	:	USE TODR CLOCK TO SET SYSTEM TIME
00000000'GF	00000000'GF	7D	0418	2473	MOVQ	G^EXE\$GQ_TODCBASE,G^EXE\$GQ_BOOTTIME	:	SAVE BOOT TIME
	5E 30	CO	0423	2474	ADDL	#12*4,SP	:	CLEAN OFF SCRATCH STORAGE
	077C 8F	BA	0426	2475	POPR	#^M<R2,R3,R4,R5,R6,R8,R9,R10>	:	RESTORE REGISTERS
			042A	2476			:	
			042A	2477			:	
			042A	2478			:	Fall through into the deallocate logic.
			042A	2479			:	
			042A	2480			:	
			042A	2481	RSB		:	*** This goes in if another piece of
			042A	2482			:	*** initialization code is added that
			042A	2483			:	*** is executed after EXE\$INI_TIMWAIT.
			042A	2484	.DISABLE LSB		:	



```

042A 2486 DEAL_INIT_CODE: ; DEALLOCATE THE INITIALIZATION CODE
042A 2487 ;
042A 2488 ; It is the duty of the last-executed, loadable initialization
042A 2489 ; routine to make itself and all other such routines disappear, i.e.,
042A 2490 ; release the space they occupy to non-paged pool. Each routine's vector
042A 2491 ; must be disconnected, e.g., be made to point to the symbol, EXES$LOAD_ERROR.
042A 2492 ;
042A 2493 ; NOTE: This means that new initialization routines should be added
042A 2494 ; to this module in a particular order, not necessarily at the
042A 2495 ; end of the module!
042A 2496 ;
042A 2497 ;
7E 52 7D 042A 2498 .ENABLE LSB ; Save some registers
MOVQ R2,-(SP)
042D 2499 ;
042D 2500 ;
042D 2501 ; First find the vectors that point to these initialization routines
042D 2502 ; and reset them to point to EXES$LOAD_ERROR.
042D 2503 ;
51 50 50 0000'CF 9E 042D 2504 MOVAB W^SYSL$BEGIN,R0 ; Compute bounds of releasable piece:
52 50 00000000'8F C1 0432 2505 ADDL3 #<STAY_HEADER-SYSL$BEGIN>,R0,R1 ; starting and ending addresses.
53 52 00000000'GF 9E 043A 2506 MOVAB G^EXES$LOAD_ERROR,R2 ; Get starting address of vectors.
53 53 00000000'GF 9E 0441 2507 MOVAB G^EXES$LOAD_ERROR,R3 ; Get end of vectors.
9F17 8F 62 81 0448 2508 10$: CMPW (R2),#^X9FT7 ; Is this JMP @#?
1B 13 044D 2509 BEQL 30$ ; Br if yes, skip past it.
80 8F 03 A2 91 044F 2510 CMPB 3(R2),#^X80 ; Is this a system space address
16 12 0454 2511 BNEQ 40$ ; Br if no, assume it's a HALT instr.
50 62 D1 0456 2512 CMPL (R2),R0 ; Is address before the releasable
0C 1F 0459 2513 BLSSU 20$ ; piece of memory? Br on yes.
51 62 D1 045B 2514 CMPL (R2),R1 ; Is address after the releasable
07 1A 045E 2515 BGTRU 20$ ; piece of memory? Br on yes.
62 62 00000000'GF 9E 0460 2516 MOVAB G^EXES$LOAD_ERROR,(R2) ; Reset this vector.
52 02 C0 0467 2517 20$: ADDL #2,R2 ; Point past this vector.
52 D6 046A 2518 30$: INCL R2 ; Come here to point past JMP @#.
52 D6 046C 2519 40$: INCL R2 ; Come here to point past HALT.
53 52 D1 046E 2520 CMPL R2,R3 ; Past the end of the vectors?
D5 1F 0471 2521 BLSSU 10$ ; Keep searching vectors.
0473 2522 ;
0473 2523 ; Now release the memory to non-paged pool.
0473 2524 ;
50 50 0000'CF 9E 0473 2525 MOVAB W^SYSL$BEGIN,R0 ; Point to start of module
51 51 0000'8F 3C 0478 2526 MOVZWL #<STAY_HEADER-SYSL$BEGIN>,R1 ; Length to vaporize
FB8C' 31 047D 2527 BRW 50$ ; Br to code that is not released.
0480 2528 ;
00000000 2529 .PSECT $$$INIT__END,PAGE ; 'PAGE' SINCE 16-BYTE ALIGN IS NOT
0000 2530 ;
0000 2531 STAY_HEADER:
00000000 00000000 0000 2532 .LONG 0,0
0000' 0008 2533 .WORD <SYSL$END-STAY_HEADER>
62 000A 2534 .BYTE DYN$C_LOADCODE
00 000B 2535 .BYTE 0
000C 2536 ;
00000000'9F 16 000C 2537 50$: JSB @#EXES$DEANONPGDSIZ ; Just the smile on the Chesire cat
52 8E 7D 0012 2538 MOVQ (SP)+,R2 ; Restore
05 0015 2539 RSB ; Return.
0016 2540 ;
0016 2541 .DISABLE LSB
0016 2542 .END

```

INIADPUV1  
Symbol table

\$\$\$VMSDEFINED	=	00000001		EXES\$DEANONPGDSIZ	*****	X	0A
\$\$T1	=	00000001		EXES\$GL_CONFREG	*****	X	09
ADAPTERS	=	00000000	R 02	EXES\$GL_CONFREGL	*****	X	09
ADPSB_TYPE	=	0000000A		EXES\$GL_FLAGS	*****	X	09
ADPSC_UBAADPLEN	=	00000258		EXES\$GL_NUMNEXUS	*****	X	09
ADPSL_CRB	=	00000010		EXES\$GL_RPB	*****	X	09
ADPSL_CSR	=	00000000		EXES\$GL_SCB	*****	X	09
ADPSL_DPQFL	=	00000014		EXES\$GL_TENUSEC	*****	X	09
ADPSL_LINK	=	00000004		EXES\$GL_UBDELAY	*****	X	09
ADPSL_MRACTMDRS	=	0000005C		EXES\$GQ_BOOTTIME	*****	X	09
ADPSL_MRQFL	=	C0000030		EXES\$GQ_TODCBASE	*****	X	09
ADPSL_VECTOR	=	00000010		EXES\$INIT TODR	00000325	RG	09
ADPSW_ADPTYPE	=	0000000E		EXES\$INI TIMWAIT	000002CC	RG	09
ADPSW_DPBITMAP	=	00000060		EXES\$LOAD ERROR	*****	X	09
ADPSW_MRFENCE	=	0000015C		EXES\$OUTSTRING	*****	X	09
ADPSW_MRFRECALLY	=	0000015E		EXES\$SETIME INT	*****	X	09
ADPSW_MRNFBENCE	=	00000062		EXESV SETTME	*****	X	09
ADPSW_MRNREGARY	=	00000064		FILL_CRB	0000026E	R	09
ADPSW_SIZE	=	00000008		GET_GEN_TYPE	0000006B	R	09
ADPSW_TR	=	0000000C		GET_TYPE	00000068	R	09
ADPSW_UMR_DIS	=	00000256		IDB\$B_TYPE	= 0000000A		
ADPLINK	*****		X 09	IDB\$C_LENGTH	= 00000038		
ALONPAGD	=	0000025A	R X 09	IDB\$L_ADP	= 00000014		
ATS_UBA	=	00000001		IDB\$L_CSR	= 00000000		
BI_BUS_CODE	=	80000000		IDB\$W_SIZE	= 00000008		
BI_CPU	=	00000000		INISALOC_CRB	*****	X	09
BI_CSR_LEN	=	00000002		INISALONONPAGED	*****	X	09
BI_LIKE	=	00000000		INISCIADP	00000260	R	09
BLD_CRB	=	00000261	R 09	INISCONSOLE	00000261	RG	09
BOOS\$GB_SYSTEMID	*****		X 09	INISDRADP	00000260	R	09
BOOS\$GL_SPTFREQ	*****		X 09	INISDIOMAP	00000000	RG	09
BOOS\$GL_SPTFRELE	*****		X 09	INISKDZ11	00000260	R	09
BOCTVECTOR	=	00000000	R 08	INISMBADP	00000260	R	09
BTDSK_UDA	=	00000011		INISMPMADP	*****	X	06
BUS_CODE_OFFSET	=	FFFFFFFFC		INISUBADP	00000174	R	09
BUS_CSR_LEN	=	00000004	R 08	INISUBSPACE	00000157	R	09
CONFIG_IOSPACE	=	00000059	R 09	INIT_ROUTINES	00000000	R	06
CONFREG	=	00000020	R 08	INTIME	= 00000014		
CONFREGL	=	00000160	R 08	IOSM_CVTLOW	*****	X	09
CPU_ADPSIZE	=	0000000D	R 08	IOSM_PURGE	*****	X	09
CPU_TYPE	=	00000007		IOSM_TIMED	*****	X	09
CR	=	0000000D		IOS_READPROMPT	*****	X	09
CRASL_INTD	=	00000024		IOS_WRITEVBLK	*****	X	09
CREATE_ARRAYS	=	000000CA	R 09	IOU\$1\$AL_QBOSP	= 20000000		
CSR_LEN_OFFSET	=	FFFFFFFFB		LF	= 0000000A		
DEAL_INIT_CODE	=	0000042A	R 09	LINBUF	= 0000001C		
DIRECT_VEC_NODE_CNT	=	00000009	R 08	LINBUFSIZ	= 00000014		
DYN\$C_ADP	=	00000001		MAP_NEXUS	000000A6	R	09
DYN\$C_CONF	=	00000007		MAP_PAGES	00000123	R	09
DYN\$C_IDB	=	00000009		MAXNEXUS	= 00000040		
DYN\$C_INIT	=	00000063		MCHK_HANDLER	00000220	R	09
DYN\$C_LOADCODE	=	00000062		MMG\$GL_SBICONF	*****	X	09
END_NEXUS	=	000000C7	R 09	MMG\$GL_SPTBASE	*****	X	09
ERROR_HALT	=	00000149	R 09	NDT\$_BOA	= 80000102		
ERROR_HALT_1	=	0000014E	R 09	NDT\$_CI	= 00000038		
EXES\$AL_LOADVEC	*****		X 09	NDT\$_DR32	= 00000030		
EXES\$AL_MEMCSRS	*****		X 09	NDT\$_KDZ11	= 80000105		

INIADPUV1  
Symbol table

```

NDTS_MB = 00000020
NDTS_MEM1664NI = 00000012
NDTS_MEM16I = 00000011
NDTS_MEM16NI = 00000010
NDTS_MEM256EIL = 00000071
NDTS_MEM256EIU = 00000073
NDTS_MEM256I = 00000074
NDTS_MEM256NIL = 00000070
NDTS_MEM256NIU = 00000072
NDTS_MEM4I = 00000009
NDTS_MEM4NI = 00000008
NDTS_MEM64EIL = 00000069
NDTS_MEM64EIU = 00000068
NDTS_MEM64I = 0000006C
NDTS_MEM64NIL = 00000068
NDTS_MEM64NIU = 0000006A
NDTS_MPM0 = 00000040
NDTS_MPM1 = 00000041
NDTS_MPM2 = 00000042
NDTS_MPM3 = 00000043
NDTS_SCORMEM = 80000001
NDTS_UB0 = 00000028
NDTS_UB1 = 00000029
NDTS_UB2 = 0000002A
NDTS_UB3 = 0000002B
NEXUSDESC = 00000014 R 08
NOSPT = 00000260 R 08
NPROMPT = 00000033
NUMUBAVEC = 00000080
NUM_PAGES = 00000000 R 04
NXT_NEXUS = 00000065 R 09
PA = 20000000
PR$_SID_TYP730 = 00000003
PR$_SID_TYP750 = 00000002
PR$_SID_TYP780 = 00000001
PR$_SID_TYP790 = 00000004
PR$_SID_TYP8NN = 00000006
PR$_SID_TYP8SS = 00000005
PR$_SID_TYPUV1 = 00000007
PROV1$_ACESR = 00000026
PTESC_RW = 10000000
PTESM_VALID = 80000000
READTIME = 00000349 R 09
RPBSB_DEVTYP = 00000066
RPBSL_ADPVIR = 00000060
RPBSL_BOOTR1 = 00000020
RPBSL_CSRPHY = 00000054
RPBSL_CSRVIR = 00000058
RPBSW_ROUBVEC = 0000001E
SBICONF = 00000060 R 08
SBI_BUS_CODE = 00000000
SBI_CPU = 00000000
SBI_CSR_LEN = 00000001
SBI_LIKE = 00000001
SGN$GW_TPWAIT = ***** X 09
STAY_HEADER = 00000000 R 0A
SW_BOS_CODE = 00000005 R 08

```

```

SYSS$ASSIGN ***** GX 09
SYSS$BINTIM ***** GX 09
SYSS$DASSGN ***** GX 09
SYSS$QIOW ***** GX 09
SYSL$BEGIN ***** X 09
SYSL$END ***** X 0A
TERM_NAMADR = 000002DB R 09
TERM_NAMSIZ = 00000004
TIMEPROMPT = 000002F1 R 09
TIMERR = 000002DF R 09
TMPDESC = 0000000C
TTCHAN = 00000000
TTNAME = 00000004
UBAS$INITIAL ***** X 09
UBAS$INTO ***** X 09
UBAS$UNEXINT ***** X 09
VASM_SYSTEM = 80000000
VECSL_ADP = 00000014
VECSL_IDB = 00000008

```

+-----+  
! Psect synopsis !  
+-----+

PSECT name	Allocation	PSECT No.	Attributes
. ABS .	00000000 ( 0.)	00 ( 0.)	NOPIC USR CON ABS LCL NOSHR NOEXE NORD NOWRT NOVEC BYTE
\$ABSS	00000000 ( 0.)	01 ( 1.)	NOPIC USR CON ABS LCL NOSHR EXE RD WRT NOVEC BYTE
\$\$\$INIT\$DATA0	00000074 ( 116.)	02 ( 2.)	NOPIC USR CON REL LCL NOSHR EXE RD WRT NOVEC BYTE
\$\$\$INIT\$DATA1	00000000 ( 0.)	03 ( 3.)	NOPIC USR CON REL LCL NOSHR EXE RD WRT NOVEC BYTE
\$\$\$INIT\$DATA2	0000003A ( 58.)	04 ( 4.)	NOPIC USR CON REL LCL NOSHR EXE RD WRT NOVEC BYTE
\$\$\$INIT\$DATA3	00000000 ( 0.)	05 ( 5.)	NOPIC USR CON REL LCL NOSHR EXE RD WRT NOVEC BYTE
\$\$\$INIT\$DATA4	00000074 ( 116.)	06 ( 6.)	NOPIC USR CON REL LCL NOSHR EXE RD WRT NOVEC BYTE
\$\$\$INIT\$DATA5	00000000 ( 0.)	07 ( 7.)	NOPIC USR CON REL LCL NOSHR EXE RD WRT NOVEC BYTE
\$\$\$INIT\$DATA	00000289 ( 649.)	08 ( 8.)	NOPIC USR CON REL LCL NOSHR EXE RD WRT NOVEC LONG
\$\$\$INIT\$CODE	00000480 ( 1152.)	09 ( 9.)	NOPIC USR CON REL LCL NOSHR EXE RD WRT NOVEC QUAD
\$\$\$INIT__END	00000016 ( 22.)	0A ( 10.)	NOPIC USR CON REL LCL NOSHR EXE RD WRT NOVEC PAGE

+-----+  
! Performance indicators !  
+-----+

Phase	Page faults	CPU Time	Elapsed Time
Initialization	35	00:00:00.06	00:00:01.64
Command processing	141	00:00:00.45	00:00:03.20
Pass 1	507	00:00:12.82	00:00:47.78
Symbol table sort	0	00:00:01.65	00:00:06.88
Pass 2	234	00:00:03.78	00:00:17.39
Symbol table output	24	00:00:00.13	00:00:00.82
Psect synopsis output	4	00:00:00.03	00:00:00.03
Cross-reference output	0	00:00:00.00	00:00:00.00
Assembler run totals	947	00:00:18.92	00:01:17.74

The working set limit was 2100 pages.  
132724 bytes (260 pages) of virtual memory were used to buffer the intermediate code.  
There were 90 pages of symbol table space allocated to hold 1600 non-local and 24 local symbols.  
2546 source lines were read in Pass 1, producing 36 object records in Pass 2.  
42 pages of virtual memory were used to define 40 macros.

+-----+  
! Macro library statistics !  
+-----+

Macro library name	Macros defined
_\$255\$DUA28:[SYS.OBJ]LIB.MLB;1	19
-\$255\$DUA28:[SYSLIB]STARLET.MLB;2	14
TOTALS (all libraries)	33

1745 GETS were required to define 33 macros.

There were no errors, warnings or information messages.

MACRO/LIS=LISS:INIADPUV1/OBJ=OBJ\$:INIADPUV1 MSRC\$:CPUSWUV1/UPDATE=(ENH\$:CPUSWUV1)+MSRC\$:INIADP/UPDATE=(ENH\$:INIADP)+EXECMLS/LIB



The image displays a grid of 100 small technical diagrams, arranged in 10 rows and 10 columns. Each diagram contains various symbols, lines, and text, likely representing circuit board layouts or component specifications. Some diagrams are highlighted with larger text labels:

- INIADP250 LIS
- INIADP230 LIS
- INIADP280 LIS
- INIADP211 LIS
- INIADP290 LIS



0397 AH-BT13A-SE  
VAX/VMS V4.0

DIGITAL EQUIPMENT CORPORATION  
CONFIDENTIAL AND PROPRIETARY

The image displays a grid of 160 small terminal window screenshots, arranged in 10 rows and 16 columns. Each window shows a different view of a system's operation, likely related to the VAX/VMS V4.0 software. The windows contain various types of information, including:

- System status reports and messages.
- Command-line prompts and user input.
- Data tables and lists.
- Diagnostic outputs and error messages.

Several windows are explicitly labeled with titles, such as:

- LTIOSUB750 LIS** (top-left)
- MCHECK730 LIS** (second row, third column)
- MCHECK750 LIS** (second row, fourth column)
- MCHECK780 LIS** (fourth row, eighth column)
- MCF790 LIS** (seventh row, third column)
- LTIOSUBU1 LIS** (bottom row, second column)

The overall appearance is that of a comprehensive test suite or diagnostic tool, with each window representing a different component or function being tested or monitored.