



## SECTION 592-017-302

digits of manufacture code (i. e.,175, 182, etc). Reorder boards using the AR code listed in Table A of Section 592-017-102. The grooves are keyed by a black stripe at the top and bottom of the shelf. When inserting a board, align the board edge with both top and bottom keys of the location. Using the key markings prevents misalignment with the mating connector at the rear of the data set. Removal of a printed circuit board requires gripping the front edge with both hands and pulling out in a straight movement.

***Caution: Failure to observe and follow board removal procedure may result in a damaged board.***

**3.04** ◆ When necessary replacements have been accomplished on the data set, carefully press the cover into the locked position. A retaining bar is attached to the cover to hold the printed circuit boards securely in place. Be sure all boards are firmly seated in their respective connector plugs. Press the lower corners of the cover until the retaining latch locks on the cover edge.◆